

Basic System Setup

Version 7.2

Table of Contents

1	Introduction	9
2	CLI Management Interface.....	11
2.1	Examples	15
2.1.1	Accessing the Device	15
2.1.2	Using the "do" Command	15
2.1.3	Accessing the Data Configuration Mode	15
2.1.4	Exiting the Data Configuration Mode	15
2.1.5	Accessing the Device through WAN Port.....	16
3	Port Naming Convention	17
3.1	Examples	18
3.1.1	Displaying System Assembly	18
3.1.2	Port Naming.....	18
4	SNMP Management.....	19
4.1	SNMPV2C	19
4.2	SNMPV3	19
4.3	SNMPV2C and SNMPV3 General Commands	21
4.4	SNMP Traps.....	22
4.5	Examples	22
4.5.1	SNMPV2C Access.....	22
5	NetFlow	25
5.1	CLI Commands	25
5.2	Examples	25
6	Copy Methods	27
6.1	CLI Commands	27
6.2	Examples	28
6.2.1	Copying Firmware from TFTP Server.....	28
6.2.2	Copying Configuration from HTTP Server.....	28
6.2.3	Using Startup-Script.....	29
6.2.4	Export Device Configuration	29
7	USB Functionality	31
7.1	USB Commands.....	31
7.2	USB Auto-Run.....	31
7.3	Examples of USB Commands	31
7.4	Examples of USB Auto-Run	32
8	Upgrading the Device	35
8.1	Upgrading through CLI	35
8.2	Example	35
8.3	Upgrading from Version 6.6.....	35
8.4	Example	36
9	Automatic Update.....	37
9.1	Example	38
9.2	Zero Configuration.....	40

10	NTP	43
10.1	Examples	44
11	Banner Message	45
11.1	Example	45
12	RADIUS Configuration	47
12.1	Example	48
12.1.1	FreeRADIUS Configuration	48
12.1.2	Internal RADIUS Configuration	49
12.1.2.1	Testing Password-based Authentication on Windows	49
12.1.2.2	Testing Certificates	50
13	TACACS+ Configuration	51
13.1	Example for TACACS+ Authentication	52
13.2	Example for TACACS+ Authorization	53
13.3	TACACS+ Flags and Flow Chart	58
13.3.1	TACACS+ Configuration Flags	58
13.3.2	TACACS+ Flow Chart	58
14	Recovery Procedures	59
14.1	Password Recovery Procedure	59
14.2	Rescue Process	59
15	Factory Setting	61
16	Device Reload	63
17	Certificates	65
17.1	Example	65
18	Syslog	67
18.1	Examples	67
19	Network Quality Monitor	69
19.1	Overview	69
19.1.1	MOS Results	70
19.2	Configuring the 'Sender Termination' Side	70
19.2.1	Step 1: Bind a WAN Interface to the NQM Service	70
19.2.2	Step 2: Configure a Line in the Probing Table	70
19.2.3	Step 3: Configure a Line in the Sender Table to Define a Sender Termination	71
19.3	Configuring the 'Responder Termination' Side	71
19.3.1	Step 1: Bind a WAN interface to the NQM service	72
19.3.2	Step 2: Configure a Line in the Responder Table	72
19.4	Viewing Results	73
19.4.1	CLI interface	73
19.4.2	SNMP Interface	74
20	Debugging - Packet Capturing	75
20.1	Example of Capturing Data on Physical Interface	77
20.2	Example of Capturing Data on an Interface	77

21 PacketSmart	79
21.1 Configuring the Device for PacketSmart	81
21.1.1 Configuring the PacketSmart Agent through CLI	81
21.1.2 Viewing PacketSmart Statistics	82
22 Customizing Web Interface	85
22.1 Configuring the Web Interface	85
22.1.1 Assigning Interfaces to Menus	85
22.1.2 Allowing End User to Configure Cellular Interface	86
22.1.3 Allowing End User to Change PPPoE User Name and Password	87
22.1.4 Allowing End User to Perform Reset to Factory Defaults	88
22.1.5 Allowing End User to use Syslog and LAN Port Mirroring	89
22.1.6 Allowing End User to Configure WAN Settings	90
22.1.7 Allowing End User to Configure LAN Guest Interfaces	91
22.1.8 Allowing End User to Configure Port Forwarding	92
22.1.9 Allowing End User to Configure DMZ	93
22.1.10 Allowing End User to Configure Multiple Subscriber Number Table	94
22.1.11 Allowing End User to View Voice Statistics	95
22.1.12 Configure Languages	97
22.2 Accessing the Web Interface	98
22.3 Web Interface Overview	99

This page is intentionally left blank.

Notice

Information contained in this document is believed to be accurate and reliable at the time of printing. However, due to ongoing product improvements and revisions, AudioCodes cannot guarantee accuracy of printed material after the Date Published nor can it accept responsibility for errors or omissions. Updates to this document can be downloaded from <https://www.audiocodes.com/library/technical-documents>.

This document is subject to change without notice.

Date Published: February-14-2023

WEEE EU Directive

Pursuant to the WEEE EU Directive, electronic and electrical waste must not be disposed of with unsorted waste. Please contact your local recycling authority for disposal of this product.

Customer Support

Customer technical support and services are provided by AudioCodes or by an authorized AudioCodes Service Partner. For more information on how to buy technical support for AudioCodes products and for contact information, please visit our website at <https://www.audiocodes.com/services-support/maintenance-and-support>.

Stay in the Loop with AudioCodes



Abbreviations and Terminology

Each abbreviation, unless widely used, is spelled out in full when first used.

Throughout this manual, unless otherwise specified, the term *device* refers to AudioCodes Mediant MSBR and Mediant 500Li products.

Related Documentation

Document Name
Mediant 500Li Hardware Installation Manual
Mediant 500Li User's Manual
Mediant 500L MSBR Hardware Installation Manual
Mediant 500L MSBR User's Manual
Mediant 500 MSBR Hardware Installation Manual
Mediant 500 MSBR User's Manual
Mediant 800 MSBR Hardware Installation Manual
Mediant 800 MSBR User's Manual

Document Revision Record

LTRT	Description
31606	Initial document release.
31607	Added Chapter 8 - Upgrading the MSBR.
31608	Updates to Copy method, NTP command, RADIUS configuration, Syslog configuration and Debug packet capturing.
31612	Added RADIUS and TACACS+ for console bypass commands. Added TACACS+ configuration flags.
31613	Updates to CLI Management Interface, Accessing the MSBR through WAN Port, SNMPV2C, SNMPV3, SNMPV2C and SNMPV3 General Commands, SNMPV2C Access, Syslog, Configuring the 'Sender Termination' Side, Configuring the 'Responder Termination' Side Section removed: How to Set up NQM
31617	Added chapter for BroadSoft's BroadCloud PacketSmart.
31618	Added a chapter for the device's Web interface displaying status information on the device's interfaces.
31619	Updated Customizing a Web Interface; Added the following chapters - Configuring PPPoE Settings, Configuring reset to factory Defaults, Enabling Troubleshooting, Configuring WAN Settings.
31780	Added a new section "Allowing End User to configure Cellular interface".
31781	New commands: allow-lan-guest-setting; allow-msn-authentication-settings; allow-voice-settings
31782	Mediant 500Li added; miscellaneous
31783	Voice statistics display for end-user
31784	DMZ and port forwarding for end-user
31785	SBC Registered Users page added to End-User Web
31786	CRC check for auto-update
31787	Updated Allowing End User to Configure Cellular Interface section; updated screenshots in Customizing Web Interface section.

Documentation Feedback

AudioCodes continually strives to produce high quality documentation. If you have any comments (suggestions or errors) regarding this document, please fill out the Documentation Feedback form on our website at <https://online.audiocodes.com/documentation-feedback>.

1 Introduction

This document describes the configuration of the system functionality of AudioCodes Mediant Multi-Service Business Routers (MSBR), using the command-line interface (CLI).

The document describes many of the administration aspects of the device such as CLI management, SNMP management, uploading and downloading of software files to and from remote servers (such as HTTPS and an attached USB device), clock features, management access authorization, authentication and accounting, password recovery process, configuration reload, packet capturing and many others.

The document describes the CLI commands required for configuring each aspect including typical configuration examples. The document also describes the configuration of third-party applications (such as RADIUS server) where necessary.

This page is intentionally left blank.

2 CLI Management Interface

Management through the CLI allows the administrator to configure every feature of the device. The CLI administration is easy, efficient and intuitive.

The CLI is divided into *Basic* configuration mode and *Enabled* configuration mode. The Basic configuration mode is marked by the chevron ">". The Enabled mode is marked by the hash sign "#". The Basic mode provides a limited set of commands and options. The Enabled mode allows the use of all the commands including access to configuration of the system, data and voice functionalities, as well as show and debug commands and access to the maintenance actions such as copy, write and reload.

Use the following commands to access or exit the Enabled mode:

Command	Description
Enable	Enters the Enabled mode
Exit	When in the Basic or Enabled mode, the command exits the CLI and the CLI waits for the username to be entered again. Leaves the current command-set and returns one level up.
Quit	While in the Basic or Enabled mode, the command exits the CLI and the CLI waits for the username to be entered again.

To improve the work of the network administrator, the CLI allows the use of the following keyboard shortcuts:

Keyboard shortcut	Description
Up arrow	Re-displays the previously entered command. If you continue pressing the up arrow key, it will cycle through all the previously entered commands, starting with the most recent.
Tab	Pressing the Tab key after entering a partial (but unique) command completes the command, displays it on the command prompt line, and waits for further input. Pressing the Tab key after entering a partial and non-unique command displays all completing options.
?	<ul style="list-style-type: none"> Displays a list of all subcommands in the current mode. Displays a list of available commands beginning with certain letter(s). Obtains syntax help for the commands. Displays the range of values and a brief description of the next parameter expected for that command. If there is a command that can be invoked (all its arguments are inserted), using the question mark at its end displays "<cr>".
CTRL + A	Jumps to the beginning of the displayed command line.
CTRL + E	Jumps to the end of the displayed command line.
CTRL + U	Clears the current displayed command line.
CTRL + Z	Returns to the Enabled mode prompt "#".

If sufficient letters are entered to identify a command, the auto-finish function of the CLI identifies the command and there is no need to write the entire command. For example, instead of typing the entire command "enable", you can simply type "en".

To access the device, Use the default username and password, as listed in the following table:

Access	Default Value
Username	Admin
Password	Admin
Enable password	Admin

CLI management of the device is available using SSH, Telnet or the console. To access the console port, use the following RS-232 terminal emulation configuration for any terminal client (e.g., PuTTY, Tera Term, and HyperTerminal):

- 115200 Baud rate
- 8 Data bits
- No parity
- 1 Stop bits
- No flow control

By default, Telnet access to the management interface is allowed. Use any Telnet client (such as Telnet or PuTTY) to access the device. The default device address is 192.168.0.1.

By default, SSH access to the management interface is disabled. Use the following commands to enable or disable SSH or Telnet access to the device:

Command	Description
# configure system	Enters system configuration level.
(config-system) # cli-terminal	Enters cli-terminal configuration level.
(cli-settings) # telnet-network-source-ipv4 [STRING]	Defines the source network interface (IPv6 address alias/IPv6 VRF alias). Note: This is applicable only to Mediant 500Li MSBR.
(cli-settings) # telnet-network-source-ipv6 [STRING]	Defines the source network interface (IPv6 address alias/IPv6 VRF alias). Note: This is applicable only to Mediant 500Li MSBR.
(cli-settings) # telnet-mode enable	Enables Telnet to the device.
(cli-settings) # telnet-mode disable	Disables Telnet to the device.
(cli-settings) # ssh-network-source-ipv4 [STRING]	Defines the source network interface (IPv4 address alias/IPv4 VRF alias). Note: This is applicable only to Mediant 500Li MSBR.
(cli-settings) # ssh-network-source-ipv6 [STRING]	Defines the source network interface (IPv6 address alias/IPv6 VRF alias). Note: This is applicable only to Mediant 500Li MSBR.
(cli-settings) # ssh on	Enables SSH to the device.
(cli-settings) # ssh off	Disables SSH to the device.

By default, the device administration through the WAN port is disabled. Use the following command to enable device administration through the WAN port:

Command	Description
wan-telnet-allow	Enables Telnet to the device through the WAN port.

The following are common commands used in the CLI:

Command	Description
do	Executes commands in the Enable mode without the need to exit the current command set.
no	Undoes an issued command or disables a feature.
list	Displays a list of the available command(s) of the current command set.
history	Displays a list of previously run commands.
exit	Leaves the current command set and returns one level up.

The configuration of the device is divided into five configuration set levels:

- **System:** Contains the general and system oriented configuration command of the device
- **VoIP:** Contains VoIP-oriented configuration commands.
- **Data:** Contains all configuration tasks relating to the data entity of the device.
- **Network:** VoIP Network configuration commands.
- **Troubleshoot:** Troubleshooting oriented commands.

The following commands enter these different configuration levels:

Command	Description
configure system	Enters the System configuration level.
configure voip	Enters the VoIP configuration level.
configure data	Enters the Data configuration level.
configure network	Enters the Network configuration level.
configure troubleshoot	Enter the Troubleshoot configuration.



Note: It is important to understand some of the device's architecture design qualities. One of the important qualities is the existence of two CPUs. One CPU handles the voice traffic while the other handles the data traffic. The management services such as SSH is handled by the voice CPU. This becomes important when commands such as `set wan-telnet-allow` are issued. On the LAN side, there is no impact - the switch is connected to both CPUs and it knows to which CPU to deliver the Telnet session. However, on the WAN side, the WAN ports are connected only to the data CPU and the Telnet session needs to be delivered to the voice CPU. The voice CPU and data CPUs are connected. When the `set wan-telnet-allow` command is issued, the data CPU acts as a proxy for the Telnet protocol, and connection to the WAN interface is delivered to the voice CPU through the connection between the two CPUs. In addition, if for protocols such as RADIUS, TACACS+, SNMP and others, no source IP is configured, the default source IP is the voice CPU address.

2.1 Examples

2.1.1 Accessing the Device

```
Welcome to AudioCodes CLI

Username: Admin
Password: *****

MSBR> ena
Password: *****
MSBR#
```

2.1.2 Using the "do" Command

```
MSBR(config-data)# do show run voip

# Running Configuration M500L

## SIGNALING & MEDIA

configure voip
coders-and-profiles audio-coders-groups 0
coders-group-name "AudioCodersGroups_0"
activate
audio-coders 0
name g711-alaw
p-time 20
rate 64
activate
exit
```

2.1.3 Accessing the Data Configuration Mode

```
MSBR# conf data

MSBR(config-data)#
```

2.1.4 Exiting the Data Configuration Mode

```
MSBR(config-data)# exit

MSBR#
```

2.1.5 Accessing the Device through WAN Port

The following procedure describes how to enable access to the device through its WAN port:

1. Enter the System configuration level:

```
MSBR# configure system
```

2. Access the cli-terminal commands:

```
MSBR(config-system)# cli-settings
```

3. Enable telnet on the device:

```
MSBR(cli-settings)# telnet-mode enable
```

4. Enable telnet through the WAN interface:

```
MSBR(cli-settings)# wan-telnet-allow on
```

5. Exit to the previous level:

```
MSBR(cli-settings)# exit
```


3 Port Naming Convention

The port naming convention is a method for assigning names to ports. Each port name consists of a port name, module slot number, and port number.

The port name is typically the type of interface. The port name depends in the device assembly. The following table describes the port naming conventions for different port types:

Port Type	Port Name
Fast Ethernet 100Mbps	FastEthernet
Giga Ethernet 1Gbps	GigabitEthernet
Fiber 1 GIG SFP Ethernet	Fiber
PSTN ports, including FXS, FXO, BRI, PRI	Port

The module slot number also depends on the device assembly; however, some of the slot numbers are always fixed for the same module types. The following table describes the module types and the numbers assigned to the ports:

Module Type	Module Number
WAN	0
LAN	1,4,5
VOICE	2,3

The port numbers are assigned to ports according to the number of ports in each module.

To view the modules installed in the device, use the following command:

Command	Description
<code>show system assembly</code>	Displays installed modules and port types.

3.1 Examples

3.1.1 Displaying System Assembly

Output of show system assembly command:

```
MSBR# show system assembly
```

Board Assembly Info:

Slot No.	Ports	Module Type
0/0	1	WAN-Copper
0/1	1	WAN-Fiber
0/2	1	WAN-A/VDSL
1	1-4	LAN-GE
2	1-4	FXS

USB Port 1: Empty

USB Port 2: Empty

MSBR#

The output of the show system assembly command displays every slot, port and module type of the ports installed on the device. The "Slot No." column displays the slot number of a port; the "Ports" column displays the port number; the "Module Type" displays the port type.

3.1.2 Port Naming

The following table describes the port names of each interface in different module types.

Port Description	Port Name
WAN port, 1 Gbps	GigabitEthernet 0/0
LAN port number 2, 1 Gbps port, module slot 1	GigabitEthernet 1/2
LAN port number 1, 100 Mbps, on module slot 5	FastEthernet 5/1
WAN port, DSL at port number 3	DSL 0/3

4 SNMP Management

The device supports Simple Network Management Protocol (SNMP) for configuration and management. The device supports SNMPv2c and SNMPv3 for access and for sending traps. The SNMP engine – the process which responds to SNMP requests and sends SNMP traps – runs on the VoIP CPU. Therefore, SNMP requests need to be sent to the VoIP CPU.

4.1 SNMPV2C

To configure SNMPv2 read-only access to the device, use the following commands:

Command	Description
# configure system	Enters the System configuration level.
(config-system) # snmp settings	Enters the SNMP configuration level.
(snmp) # ro-community-string 0 P@ssw0rd	Sets the read-only community string with the index 0 to "P@ssw0rd". The index can be a value from 0 to 4 and therefore, there can be only five read-only community strings.
(snmp) # network-source [STRING]	Defines the source network interface (IP address alias/IP VRF alias). Note: This is applicable only to Mediant 500Li MSBR.
(snmp) # activate	Changes to parameters will take effect when applying the activate or exit command.

To configure read-write community string, use the following command:

Command	Description
(snmp) # rw-community-string 0 rw-P@ssw0rd	Sets the read-write community string with the index 0 to "rw-P@ssw0rd". The index can be a value from 0 to 4 and therefore, there can be only five read-write community strings.

4.2 SNMPV3

To configure SNMPv3, use the following commands:

Command	Description
MSBR# configure system	Enters the System configuration level.
(config-system) # snmp v3-users 0	Enters the configuration level of an SNMPv3 user with the index 0. If a user with index 0 does not exist, a new user at index 0 will be created. If a user with index 0 does exist, this user configuration will be modified. Use new instead of an index number, and a new user will be created at the first available index. Use display instead of the index number and users configuration will be displayed.
(v3-users-0) # username	Sets the SNMPv3 username to "Tim".


Command	Description
(v3-users-0) # auth-protocol sha-1	Sets the authentication protocol for the user to sha-1. Other options include md-5 and none for not using authentication.
(v3-users-0) # auth-key P@ssw0rd	Sets the authentication key to "P@ssw0rd".
(v3-users-0) # group read-write	Assigns the user to the read-write group. Other options are to assign the user to the read-only group and to the trap group. Assignment of the user to the trap group is described in the SNMPv3 traps section.

The SNMPv3 can be configured in three modes of the security level:

Security Level	Description
NoAuth, NoPriv	No authentication and no privacy. No authentication means that the username is not authenticated. No privacy means that the data of the MIB is not encrypted.
Auth, NoPriv	Authentication; however, no privacy. The user is authenticated, but the MIB data is sent without encryption. The key encryption algorithms available for authentication are MD-5 and SHA-1.
Auth, Priv	Authentication and privacy. The user is authenticated and the MIB data is encrypted. The key encryption algorithms available for privacy are DES, 3des, AES-128, AES-192, and AES-256.


To emphasize the encryption of the SNMPv3 packets, see the below captured SNMPv3 packet. The packet is a device response to SNMPv3 Get of the system location MIB value. The next captured packet shows the NoAuth-NoPriv operation mode. The MIB value is sent unencrypted.

Figure 4-1: SNMP Packet in NoAuth-NoPriv mode



The screenshot below displays a captured packet using the AuthPriv mode. The MIB value is sent encrypted.

Figure 4-2: SNMP Packet in AuthPriv mode



4.3 SNMPV2C and SNMPV3 General Commands

The following commands are applicable to both SNMP versions for accessing the device:

Command	Description
(snmp) # sys-name "AudioCodes"	Sets system name.
(snmp) # sys-location "AudioCodes main office"	Sets system location. The brackets are required if spaces are used.
(snmp) # sys-contact "AudioCodes Inc"	Sets the system contact.
(snmp) # wan-snmp-allow on	Allows SNMP access on the WAN interface.
(snmp) # port 2162	Sets the device to use port 2162 for SNMP.
(snmp) # snmp-acl community-string P@ssw0rd ro snmp-acl	Sets ACL called snmp-acl for RO community P@ssw0rd. It is recommended to use either the <code>snmp-acl</code> command or <code>trusted-managers</code> command, but not both.
(snmp) # trusted-managers 0 192.168.0.3	Allows the IP address of 192.168.0.3 to access the SNMP. It is recommended to use either the <code>snmp-acl</code> command or <code>trusted-managers</code> command, not both of them.
(snmp) # sys-oid <string>	Changes the system OID value.
(snmp) # engine-id <Engine ID>	Changes the engine ID value for SNMPv3.

4.4 SNMP Traps

To send SNMP traps, use the following commands:

Command	Description
MSBR# configure system	Enters the System configuration level.
(config-system)# snmp trap	Accesses the SNMP trap configuration level.
(snmp-trap)# community-string P@ssw0rd	Sets the community string for traps to "P@ssw0rd".
(config-system)# snmp trap destination 0	Sets the number of SNMP trap destinations. The 0 represents the index, meaning the number of the SNMP trap destination to edit. The index can be between 0 and 4 and therefore, there can be only five destinations for sending traps. Use the <code>display</code> keyword instead of the index number to display IP destinations configuration.
(trap-destination 0)# ip-address 192.168.0.3	Sets the IP address 192.168.1.3 as the trap destination.
(trap-destination 0)# trap-user Tim	Enables SNMPv3 traps, assuming an SNMPv3 user called "Tim" was configured. Traps will be sent using this user. For SNMPv2C traps, do not configure any user. The traps are sent using the community string configured above.
(trap-destination 0)# send-trap enable	Enables the sending traps from the device device.

4.5 Examples

4.5.1 SNMPV2C Access

This example uses a free MIB browser to get and set MIB values using SNMP:

```
MSBR# configure system

MSBR(config-system)# snmp
Note: Changes to parameters will take effect when applying the
'activate' or 'exit' command

# Configure SNMPv2C RO connection string to "P@ssw0rd"
MSBR(snmp)# ro-community-string 0 P@ssw0rd

# Configure SNMPv2C RW connection string to rw-P@ssw0rd
MSBR(snmp)# rw-community-string 0 rw-P@ssw0rd

# Configure system name to "Audio Codes"
MSBR(snmp)# sys-name AudioCodes
```

```
# Configure system location name to
MSBR(snmp)# sys-location "The Back Office"

# Configure system contact to IT Operations
MSBR(snmp)# sys-contact "IT Operations"


MSBR(snmp)# exit

MSBR(config-system)# exit

MSBR#
```


Use an SNMP MIB browser to access the device to get System Name, System Location, System Contact:

Figure 4-3: SNMPv2C get



Use the SNMP MIB browser to set the System Location to The Front Office:

Figure 4-4: SNMPv2C Get and Set



5 NetFlow

NetFlow is a feature that provides the ability to collect IP network traffic. The NetFlow records are generated from the firewall statistics. Since the NetFlow information is taken from the firewall, you must activate firewall capabilities on the monitored interface.

5.1 CLI Commands

The commands used to configure the device NetFlow parameters are listed below:

Command	Description
<code>ip flow-export enable</code>	Enables NetFlow.
<code>ip flow-export destination <Netflow Server Address> <Netflow Server Port ></code>	Sets the NetFlow destination server and server port (default port 2055).
<code>ip flow-export version 5 enable</code>	Enables NetFlow version 5.
<code>ip flow-export version 9 enable</code>	Enables NetFlow version 9.
<code>ip flow-export source-address interface < bvi cellular gigabitethernet gre ipip l2tp loopback pppoe ptp vlan ></code>	Sets the source of the NetFlow packets. If not specified, the source will be set according to the routing table interface.

5.2 Examples

This example activates the firewall and NAT. The device WAN IP address is obtained from a DHCP server located on the WAN subnet.

```
configure data
ip flow-export enable
ip flow-export destination 10.4.40.144 2055
ip flow-export version 5 enable
ip flow-export version 9 enable
ip flow-export source-address interface GigabitEthernet 0/0
interface GigabitEthernet 0/0
ip address dhcp
mtu auto
desc "WAN Ethernet"
speed auto
duplex auto
no service dhcp
ip dns server auto
napt
firewall enable
no shutdown
exit
```

Figure 5-1: NetFlow Displayed in Simple Grabber

Paessler NetFlow 9 Tester

Port:

Local IP:

NF9 Packets received (SrcIP:#)	Unassigned Flows (ID:#)	Templates received (ID)
10.4.40.33: 10022 - active		4444

Decoded Flows (Last 1000)

```
ID:4444 - 255.255.255.255:17500->10.4.4.201:17500 P:17 IF/OF:0/0 15:33:07 386
ID:4444 - 192.168.0.101:59296->195.189.193.28:443 P:6 IF/OF:0/0 15:16:28 40
ID:4444 - 195.189.193.28:443->192.168.0.101:59296 P:6 IF/OF:0/0 15:16:28 109
ID:4444 - 192.168.0.101:59321->195.189.193.18:443 P:6 IF/OF:0/0 15:16:29 40
ID:4444 - 195.189.193.18:443->192.168.0.101:59321 P:6 IF/OF:0/0 15:16:29 130
ID:4444 - 10.4.255.255:138->10.4.5.100:138 P:17 IF/OF:0/0 14:59:50 239
ID:4444 - 10.4.255.255:17500->10.4.4.2:17500 P:17 IF/OF:0/0 14:59:50 129
ID:4444 - 255.255.255.255:17500->10.4.4.2:17500 P:17 IF/OF:0/0 14:59:56 129
ID:4444 - 224.0.0.1:0->10.4.4.69:0 P:2 IF/OF:0/0 14:59:56 36
ID:4444 - 192.168.0.101:59343->195.189.193.20:443 P:6 IF/OF:0/0 14:43:19 2558
ID:4444 - 195.189.193.20:443->192.168.0.101:59343 P:6 IF/OF:0/0 14:43:19 343
ID:4444 - 192.168.0.101:59338->195.189.193.20:443 P:6 IF/OF:0/0 14:43:19 2558
ID:4444 - 195.189.193.20:443->192.168.0.101:59338 P:6 IF/OF:0/0 14:43:19 343
```

6 Copy Methods

The device allows you to copy files using HTTP, HTTPS, TFTP and NFS.

6.1 CLI Commands

The commands for copying files from a server to the device are listed below:

Command	Description
<code>Copy <file> from <URL> source [data voip] [[interface source-address vrf] voip]</code>	Copies a file from a server using HTTP, HTTPS, TFTP or NFS. Note: This is applicable only to Mediant 500/500L/800 MSBRs.
<code>Copy <file> from <URL> network-source [STRING - Source network interface (IP address alias/IP VRF alias)]</code>	Copies a file from a server using HTTP, HTTPS, TFTP or NFS. Note: This is applicable only to Mediant 500Li MSBR.

The following files can be copied from the server using the `copy` command:

File	Description
call-progress-tones	Call Progress Tones file
cas-table	CAS configuration table file
cli-script	CLI configuration file
coder-table	Coder table file
data-configuration	Data configuration file
dial-plan	Dial Plan file
feature-key	Feature key file
firmware	Firmware, burn and reload
nqm-history	Export Network Quality Monitoring history file
prerecorded-tones	Prerecorded tones file
startup-script	CLI configuration file
tls-cert	TLS certificate file
tls-private-key	TLS private key file
tls-root-cert	TLS trusted root certificate file
user-info	User Info file
ini-file	Voice configuration file (ini file)
voice-prompts	Voice Prompts file
voice-xml	Voice XML file
web-logo	Web logo file
source [data voip]	Copy using source: data or voip

The voice configuration and cli-script can also be exported using the following command:

Command	Description
<code>copy <ini-file or cli-script>to <URL></code>	Copies the voice configuration or CLI-script to HTTP, HTTPS, TFTP or NFS server Note: This is applicable only to Mediant 500/500L/800 MSBRs.
<code>copy <ini-file or cli-script> to <URL> network-source [STRING - Source network interface (IP address alias/IP VRF alias)]</code>	Copies the voice configuration or CLI-script to HTTP, HTTPS, TFTP or NFS server Note: This is applicable only to Mediant 500Li MSBR.

The cli-script is the complete configuration of the device. Therefore, to export the cli-script means to export the entire device configuration.

When `cli-config` is copied to the device, the configuration is appended to the current device configuration. When the startup-script is copied to the device, the device configuration is cleared, and the device resets. After the reset, the new configuration from the startup script is applied and the device resets again.

When using the `copy` command, please note that the HTTP server timeout is greater than the TFTP server timeout. Therefore, it is recommended to use a TFTP server to copy from or to the LAN and an HTTP server to copy to or from the WAN.

To upload a file to an HTTP server, the Web-based Distributed Authoring and Versioning (WebDAV) extensions to HTTP protocols must be used. WebDAV is a set of extensions to the HTTP protocol which allows users to collaboratively edit and manage files on remote Web servers. Basically, it allows the device to upload files to an HTTP server. The device does not send a username and password. The WebDAV server should be configured without username and password.

6.2 Examples

6.2.1 Copying Firmware from TFTP Server

In this example, the device copies the firmware file from the TFTP server, burns it to memory, and then reboots.

```
MSBR# copy firmware from
http://192.169.11.11:80/M5XX_SIP_F6.60A.260.002.cmp
Copying file...
done.
Restarting...
```

6.2.2 Copying Configuration from HTTP Server

In this example, configuration is downloaded from a text file on an HTTP server.

```
MSBR# copy cli-script from http://192.168.0.199:80/runcfg.txt
Copying file...
MSBR# # Running Config voip

MSBR(config-voip)# coders-and-profiles coders-group-0 0

MSBR(coders-group-0-0)# set name "g711Alaw64k"

... output omitted
```

If the HTTP port is 80, it is not necessary to add the port number. However, if the port number is different, then the port number should be added to the syntax.

6.2.3 Using Startup-Script

This example shows how to use the `startup-script` keyword with the `copy` command. The configuration from a text file on an HTTP server is downloaded to the device. The device configuration is then cleared and the device resets. The configuration from the downloaded file is applied to the device, after which it resets again.

```
MSBR# copy startup-script from http://192.168.0.199/runcfg.txt
Copying file...
done.
Restarting system...
MSBR# [4788750.760000] Restarting system.
**AUDC*** end of serial init

U-Boot 1.1.1 (Development build) (Build time: Dec  2 2012 -
17:18:21)

AudioCodes uKernel U-Boot Version: MP500 K6

...output omitted
```

6.2.4 Export Device Configuration

The example below shows how to export the device configuration to a text file.

```
MSBR# copy cli-script to tftp://192.168.0.3/sci-scr.txt
Sending file...done
```

This page is intentionally left blank.

7 USB Functionality

7.1 USB Commands

Command	Description
<code>usb list</code>	Prints files to a USB. This behaves like the "dir" command in Windows or Linux.
<code>copy <file> from/to <URL></code>	Copies files to or from a USB.
<code>MSBR# usb remove</code>	Safely removes attached USB device.

7.2 USB Auto-Run

You can run commands by simply connecting a USB flash drive to the device. Once connected, the device runs commands located in the file, "ac_autorun.txt", line-by-line similar to a Telnet connection. The device treats the commands in the "ac_autorun.txt" file as a regular console input and therefore, the username, password and enable password need to be included in the "ac_autorun.txt" file. The output of the commands is written in the file "ac_output.txt".

While reading and executing commands from the USB flash drive, the "Status" LED is lit red. After finishing the command execution, the LED flashes green.

7.3 Examples of USB Commands

The following is an example of using USB commands:

```
# Message that appears on USB insertion
MSBR# [4297251.615000] sda: assuming d[4297251.621000] sda:
assuming drive cache: write through
[4297251.628000] sda: p1 exceeds device capacity

# Backup configuration
MSBR# copy cli-script to usb:///config_back_up_27apr2014.cfg
Sending file...done

# Show files on the USB
MSBR# usb list
-rwxrwxrwx    1 root    0          34330640 Apr 24 2014
MP500_MSBG_SIP_F6.80A.025.cmp
drwxrwxrwx    2 root    0          4096 Feb 25 20:58 System
Volume Information
-rwxrwxrwx    1 root    0          31759825 Apr 9 2014
YairE_CFM_FIX_MSBR_LAB_UB.cmp
-rwxrwxrwx    1 root    0          3559 Apr 4 23:29
config_back_up_27apr2014.cfg
-rwxrwxrwx    1 root    0          3559 Apr 4 22:54 runcfg.txt
```

```
#Remove the USB drive
MSBR# usb remove
You may now remove the USB drive safely.

MSBR#
```

7.4 Examples of USB Auto-Run

In this example, the "USB auto-run" function used to deliver basic configuration to the device for the administrator to log in remotely. The configuration sent to the device sets the WAN interface Gig0/0 IP address to 100.0.10.10 and allows an SSH connection from the WAN interface.

```
Admin
Admin
en
Admin
configure data
    interface GigabitEthernet 0/0
    ip address 100.0.10.10 255.255.0.0
    exit
exit
configure system
    cli-terminal
        ssh on
        wan-ssh-allow on
    exit
exit
reload now
```

The output from the device to the "ac_output" file:

```
Welcome to AudioCodes CLI

Username: Admin
Password:

MSBR> en
Password:
MSBR# configure data

MSBR(config-data)# interface GigabitEthernet 0/0

MSBR(conf-if-GE 0/0)# ip address 100.0.10.10 255.255.0.0

MSBR(conf-if-GE 0/0)# exit

MSBR(config-data)# exit

MSBR# configure system

MSBR(config-system)# cli-terminal
```



```
MSBR(cli-terminal)#
activate defaults exit help
history list pwd quit
set

MSBR(cli-terminal)# ssh on

MSBR(cli-terminal)#
activate defaults exit help
history list pwd quit
set

MSBR(cli-terminal)# wan-ssh-allow on
Note: Setting this parameter requires a reset.

MSBR(cli-terminal)*# exit

MSBR(config-system)*# exit

MSBR*# write
Writing configuration...done

MSBR*#
```

This page is intentionally left blank.

8 Upgrading the Device

8.1 Upgrading through CLI

Upgrading the device from the network is possible using HTTP, HTTPS or TFTP servers.

Command	Description
MSBR# copy firmware from <code>http://10.31.2.7/MP500_MSBG_SIP_F6.80.264.cmp</code>	Copies software from HTTP server.
MSBR# copy firmware from <code>https://10.31.2.7/MP500_MSBG_SIP_F6.80.264.cmp</code>	Copies software from HTTPS server.
MSBR# copy firmware from <code>tftp://10.31.2.7/MP500_MSBG_SIP_F6.80.264.cmp</code>	Copies software from TFTP server.

After issuing the *copy* command, the device will load the software version and reboot.

8.2 Example

```
MSBR # copy firmware from http://10.180.1.215
/MP500_MSBG_SIP_F6.80A.281.004.cmp

  % Total      % Received % Xferd  Average Speed   Time    Time
Time  Current
                                 Dload  Upload  Total  Spent
Left  Speed
100 33.9M 100 33.9M    0     0  936k      0  0:00:37  0:00:37 --
:--:--  936k

Processing firmware file. The system will reboot when done...
```

8.3 Upgrading from Version 6.6

In Version 6.8, the image file, in addition to the device software, contains an image for the ADSL component. In Version 6.6, the ADSL component is not in the device software image file, so it needs to be updated manually. When upgrading from a sub-version of 6.8 to another sub-version of 6.8 (e.g., 6.8.120 to 6.8.121), the ADSL component is automatically installed. However, while upgrading from Version 6.6 to Version 6.8, the ADSL component is not installed.

➤ **To upgrade from Version 6.6 to Version 6.8 in order to upgrade the ADSL component:**

1. Upgrade from Version 6.6 to Version 6.8 using the steps described in Section 8.1 on page 35. The device will reboot.
2. Perform the upgrade again to the same image as described in Section 8.1 on page 35. The image will be loaded and the ADSL component will be upgraded. A reboot of the device is not required, and the device will not reboot by itself.

It is also possible to upgrade the A/VDSL image before upgrading to Version 6.8. This is sometimes useful, when the upgrade is performed via the DSL link itself (*). In this case, the upgrade of Version 6.8 is required to be done only once. The command for uploading the A/VDSL image is *copy adsl-firmware from http://address/file*. As with device software, the URL can be HTTP, HTTPS or TFTP server.



Note: The exact upgrade technique, especially between major versions, has to be carefully planned and verified at the customer lab, before applied to the field.

Command	Description
MSBR# copy adsl-firmware from http://10.31.2.7/ADSL_A_F6.80.281.004.img	Copy ADSL software from http server

This command is only available in Version 6.6.

8.4 Example

This example describes the output of upgrading from image *MP500_MSBG_SIP_F6.80A.281.004.cmp* to the same image *MP500_MSBG_SIP_F6.80A.281.004.cmp*.

```
MSBR# copy firmware from http://
10.180.1.215/MP500_MSBG_SIP_F6.80A.281.004.cmp

  % Total      % Received % Xferd  Average Speed   Time    Time
Time  Current
                                Dload  Upload  Total      Spent
Left  Speed
100 33.9M 100 33.9M    0     0   938k      0  0:00:37  0:00:37 --
:--:--   943k

Processing firmware file. The system will reboot when done...

Firmware file was not modified. Update skipped.
```

9 Automatic Update

The Automatic Update feature allows you to download a configuration file or an image file from a server. If the file is different from the file currently on the device, it will be applied using the same rules as the `copy` command. In other words, configuration of the "cli-script" is added to the current configuration, and the "startup-script" will then rewrite the configuration and the device will reset twice.

When software or configuration files are being downloaded from an HTTP server, the HTTP server must support HTTP's last-modified flag for this feature to function correctly and to avoid problems such as unnecessary download of software or configuration files that already exist.

When a file is downloaded from TFTP or FTP servers, the TFTP or FTP protocol doesn't support the last-modified flags feature. Therefore, to avoid applying a file that already exists, the command "crc-check" can be used. This makes sure that after the file is downloaded, the CRC hash of the file is compared against the existing file. If the CRC hash is identical, the file will not be applied. This is not applicable to the software file.

To configure Automatic Update, use the following commands:

Command	Description
MSBR# <code>configure system</code>	Accesses the System configuration level.
<code>(config-system)# automatic-update</code>	Accesses the Automatic-Update configuration level.
<code>(auto-update)# <file type> <URL></code>	Sets file to check for update. This file is checked at the URL and will be applied if it is different than the file on the device.
<code>(auto-update)# update-frequency <minutes></code>	Sets the frequency for checking for an update.
<code>(auto-update)# crc-check regular</code>	For TFTP and FTP servers - checks CRC of downloaded configuration file and only applies it if it's a new file.
<code>(auto-update)# network-source [STRING]</code>	Defines the source network interface (IP address alias/IP VRF alias). Note: This is applicable only to Mediant 500Li MSBR.

The <file> for the Automatic Update can be one of the following:

File	Description
<code>call-progress-tones</code>	Call progress tones file
<code>cas-table</code>	CAS configuration table file
<code>cli-script</code>	CLI configuration file
<code>coder-table</code>	Code table file
<code>data-configuration</code>	Data configuration file
<code>dial-plan</code>	Dial plan file
<code>firmware</code>	Firmware, burn and reload
<code>nqm-history</code>	Export Network Quality Monitoring history file
<code>prerecorded-tones</code>	Prerecorded tones file

File	Description
startup-script	CLI configuration file
tls-cert	TLS certificate file
tls-private-key	TLS private key file
tls-root-cert	TLS trusted root certificate file
user-info	User info file
voice-configuration	Voice configuration file (ini file)
voice-prompts	Voice prompts file
voice-xml	Voice xml file
web-logo	WEB logo file

9.1 Example

In this example, Auto-Update will be configured to get the cli-script file from HTTP server, with a frequency of one minute. Later on, the hostname in the fetched configuration file will be changed.

```
tim@Server:~$ ssh Admin@192.168.0.1
Welcome to AudioCodes CLI
Admin@192.168.0.1's password:
Last login: Wed Mar 26 2014 at 10:52:14

MSBR> en
Password:
MSBR#

MSBR# configure system

MSBR(config-system)# automatic-update

MSBR(auto-update)#
MSBR(auto-update)# update-frequency 1
Note: Changes to this parameter will take effect when applying the
'activate' or 'exit' command

MSBR(automatic-update)# cli-script "http://192.168.0.199/cli-
conf.txt"
Note: Changes to this parameter will take effect when applying the
'activate' or 'exit' command

MSBR(automatic-update)# activate

MSBR(automatic-update)# exit

MSBR(config-system)# exit

MSBR#
```

Now the hostname in the file cli-conf.txt at the HTTP server is changed to "MSBR-2". After one minute, the hostname will be changed.

```
tim@Server:~$ ssh Admin@192.168.0.1
Welcome to AudioCodes CLI
Admin@192.168.0.1's password:
Last login: Wed Mar 26 2014 at 10:52:14
```

```
MSBR-2> en
```

The hostname changed to "MSBR-2".


9.2 Zero Configuration

The Zero Configuration feature enables automatic, remote configuration of newly deployed, non-configured devices, using AudioCodes HTTPS Redirect Server. This feature offers an almost plug-and-play experience for quick-and-easy initial deployment of multiple devices at the end-customer premises. Zero Configuration requires only minimal pre-configuration of the device for WAN connectivity. Once an Internet connection is established, all that is needed is a device reset to activate the Zero Configuration mechanism.

Zero Configuration operates in combination with the Automatic Update feature. It redirects the device to an HTTP/S provisioning server from where the configuration file, configured with Automatic Update settings, can be downloaded and applied to the device. The device then performs the regular Automatic Update process according to these Automatic Update settings.

Once the device is powered up and connectivity to the WAN is established, it automatically sends an HTTP request to AudioCodes HTTPS Redirect server. If the device's MAC address is listed on the server, the server responds to the device with an HTTP Redirect response containing the URL of the HTTP/S server (typically, a provisioning server maintained by the Service Provider) where the configuration file is located. The device then downloads the configuration file from this provisioning server and updates its configuration. Typically, this configuration file only enables the Automatic Update mechanism and therefore, once downloaded, the device executes the Automatic Update mechanism accordingly.

Figure 9-1: Zero Configuration Process



The following describes the process that is described in Figure 9-1:

1. Device sends HTTPS request to AudioCodes HTTPS Redirect server.
2. Redirect server sends HTTPS response with redirect URL.
3. Device sends HTTPS request to redirected URL (i.e., provisioning server).
4. Device downloads configuration file for enabling the regular Automatic Update feature.

The configuration file contains only CLI commands for configuration, which its settings are applied to the device, in addition to the device's current configuration. The device resets only if the configuration file contains an explicit command instructing it to reset.

To enable Zero Configuration, the customer needs to define the devices on the HTTPS Redirect server by entering their MAC addresses and the configuration file URL. This may be done either through the corresponding Web interface or through SOAP/XML interface (that may be integrated with the Service Provider's provisioning system). For more information, contact AudioCodes support.

If the regular Automatic Update process succeeds, the device repeats the Zero Configuration process only if it undergoes a reset to factory defaults. If the Automatic Update process fails, the device repeats the Zero Configuration process at the next device reset or power up.

For security reasons, communication between the device and the HTTPS Redirect server is encrypted (HTTPS) and setup with mutual authentication. The device uses a special factory-set certificate to authenticate itself with the HTTPS Redirect server and to verify authenticity of the latter. If the redirect URL (where the configuration file is stored) also uses the HTTPS protocol, the device can use a regular certificate or the Zero Configuration certificate to authenticate itself and validate the server's certificate if a trusted root certificate (regular) is configured. This is determined by the `AupdUseZeroConfCerts` parameter.

If the Automatic Update feature has been configured, the Zero Configuration process is performed first. Only after Zero Configuration completes (successfully or not), does the Automatic Update process begin.

If the device is configured with multiple WAN interfaces, Zero Configuration is attempted on all configured WAN interfaces, sequentially.

The recommended method for using both Zero Configuration and Automatic Update is as follows:

- Zero Configuration is done to redirect the non-configured device to the URL of the provisioning server which contains only the configuration for the Automatic Update feature (e.g., CLI script URL and timeout for periodic update check).
- Once the Zero Configuration process completes (i.e., the device has downloaded the configuration file and applied the Automatic Update settings) without undergoing a reset, the Automatic Update mechanism begins.

To configure Zero Configuration, use the following commands:

Command	Description
MSBR# configure system	Access the System configuration level.
(config-system)# automatic-update	Access the Automatic-Update configuration level.
(automatic-update)# zero-conf on	Activate zero configuration. Note: This configuration change requires a reset.
(automatic-update)*# zero-conf-server http://192.168.0.199/	Configure the server IP address from which the router downloads the Zero Configuration. Note: This configuration change requires a reset.

10 NTP

The MSBR supports NTP clock synchronization. To configure NTP, use the following commands:

Command	Description
MSBR# configure system	Accesses the System configuration level.
(config-system)# ntp	Accesses the NTP configuration level.
(ntp)# primary-server 192.168.0.199	Configures the primary NTP server.
(ntp)# secondary-server 192.168.0.3	Configures the secondary NTP server.
(ntp)# auth-key-id 1	Sets the authentication key ID. If 0, the authentication is off.
(ntp)# auth-key-md5 <key>	Sets the key for the authentication.
(ntp)# activate	Activates the NTP configuration.
# configure system (config-system)# clock (clock)# utc-offset 120	Sets offset to the clock that is received from the NTP server. Use this command to calibrate the clock according to the device's time zone.

It is possible to send NTP requests from a specific interface.

Command	Description
(ntp)# source data int g 0/0	Select interface g 0/0 as source for NTP requests. Note: This is applicable only to Mediant 500/500L/800 MSBRs.
(ntp)# source voip	Select voice as a source for NTP requests. Note: This is applicable only to Mediant 500/500L/800 MSBRs.
(ntp)# network-source (main-vrf-ipv4)	Defines the source network interface (IP address alias/IP VRF alias). Note: This is applicable only to Mediant 500Li MSBR.

To view NTP status, use the following command:

Command	Description
MSBR# show system ntp-status	Displays the NTP status.

10.1 Examples

The following example configures NTP:

```
ntp
  secondary-server "192.168.0.3"
  primary-server "192.168.0.199"
  activate
```

Output of the "show system ntp-status" command

```
MSBR# show system ntp-status
Configured NTP server #1 is 192.168.0.199
Configured NTP server #2 is 192.168.0.3
NTP is synchronized, stratum 0, reference is INIT
** Precision          0.00000 seconds
** Root delay         0.00000 seconds
** Root dispersion    0.01824 seconds
** Reference time     00000000.00000000 (2036-02-07 06:28:16 UTC)
** UTC offset         0 seconds
Current local time: 2014-03-16 10:49:03
```

The output contains synchronization status, synchronization data, and a synchronized clock.

11 Banner Message

The banner message appears when the administrator connects to the device. To configure the banner message, use the following commands:

Command	Description
MSBR# configure system	Accesses the System configuration level.
(config-system)# welcome-msg [index new display]	You can configure 20 banner messages, index counting from 0 to 19. The <code>new</code> keyword configures the first banner message with an empty configuration. The <code>display</code> keyword displays the banner configuration.
(welcome-msg-0)# text "banner text"	Enters the message and enclose it in double apostrophes.

11.1 Example

This example below configures a short banner message:

```
MSBR# configure system

MSBR(config-system)# welcome-msg 0

MSBR(welcome-msg-0)# text "Property of AudioCodes"
Note: Changes to this parameter will take effect when applying the
'activate' or 'exit' command

MSBR(welcome-msg-0)# exit
MSBR(config-system)#
MSBR# exitConnection closed by foreign host.
tim@Server:~$
```

The message will appear when connecting to the device:

```
tim@Server:~$ telnet 192.168.2.1
Trying 192.168.2.1...
Connected to 192.168.2.1.
Escape character is '^]'.

Property of AudioCodes

Username: Admin
Password:

MSBR>
```

This page is intentionally left blank.

12 RADIUS Configuration

The device supports the RADIUS protocol. Use the following configuration steps to configure the device to authenticate using RADIUS with an external RADIUS server.

Command	Description
MSBR# configure system	Accesses the System configuration level.
(config-system)# radius settings	Accesses the RADIUS configuration level.
(radius)# source data interface vlan 1	Optional: Defines the source network interface for communicating with the RADIUS server. Note: This is applicable only to Mediant 500/500L/800 MSBRs.
(radius)# enable-mgmt-login on	Enables RADIUS for access to the device's management interface.
(radius)*# allow-console-bypass on	Enables the option to bypass RADIUS authentication when the user is connected directly through a serial interface. Note: This configuration requires a reset.
(radius)*# exit (config-system)# radius servers [index new display]	Accesses the RADIUS configuration level.
(servers-0)# ip-address 192.168.0.199	Configures the RADIUS server IP address.
(servers-0)# auth-port 1812	Configures the RADIUS server port number.
(servers-0)# network-source [STRING]	Optional: Defines the source network interface (IP address alias/IP VRF alias) for communicating with the RADIUS server. Note: This is applicable only to Mediant 500Li MSBR.
(servers-0)# exit (config-system)*# exit	Exits to the main configuration level.
MSBR*# reload now Writing configuration and restarting...	Resets the device.

12.1 Example

12.1.1 FreeRADIUS Configuration

In this example, a program called FreeRADIUS acts as a RADIUS server and is used to authenticate administrators connecting to the device. The program is installed on the Ubuntu Linux platform.

1. Use the following commands in Ubuntu to install FreeRADIUS:

```
sudo apt-get install mysql-client mysql-server
sudo apt-get install freeradius freeradius-utils freeradius-
mysql
sudo apt-get install php5 php-pear php5-gd php-DB
```

2. After the installation is complete, use the following configuration to configure the device in the FreeRADIUS server. Edit the file "clients.conf", and add the IP address of the VoIP CPU as the RADIUS client:

```
' open the "clients.conf" file for edit
edit sudo nano /etc/freeradius/clients.conf

' add the clients at the bottom of the file
client 192.168.0.2 {
secret=P@ssw0rd
shortname=audiocodes
}
```

3. Edit the "client" file to add the users:

```
' open the "users" file for edit
sudo nano /etc/freeradius/users

' add the users at the bottom
tim Cleartext-password := "P@ssw0rd"
```

4. Use the next set of commands to configure the device to work with radius server

```
radius
    enable on
    auth-server-port 1812
    auth-server-ip 192.168.0.199
    enable-mgmt-login on
    activate
    exit
```


12.1.2 Internal RADIUS Configuration

When the RADIUS server is internally activated for the device, wireless security (WPA2-Enterprise) and LAN security (802.1x) can work with the internal server, allowing easier deployment.

This supports both password-based authentication and certificates.

```
configure data
dot1x local-user AUDIOCODES-USER password 1234
dot1x local-user dot1x password PASSWORD
```

■ Wireless:

```
interface dot11radio 1
security 802.1x radius local
security wpa mode 802.1x
security mode wpa2
no shutdown
```

■ Wired:

```
dot1x lan-authentication enable
dot1x radius-server local
interface GigabitEthernet 4/4
authentication dot1x
```

12.1.2.1 Testing Password-based Authentication on Windows

➤ To test password-based authentication on Windows:

1. On the Windows task bar, click the **wireless** icon to open the Wireless Network Connection window.
2. In the list of wireless connections, right-click the device wireless connection and then from the shortcut menu, choose **Properties**; the Wireless Network Properties dialog box appears.
3. Click the **Security** tab, and then click the **Settings** button, located alongside the PEAP authentication method; the Protected EAP Properties dialog box appears.
4. Clear the **Validate server certificate** check box.
5. Click the **Configure** button; the EAP MSCHAPv2 Properties dialog box appears.
6. Clear the **Automatically use my Windows logon name and** check box, and then click **OK**.

12.1.2.2 Testing Certificates

➤ **To test certificates:**

1. Load a signed certificate to the device.
2. Reset the device.
3. Load a client certificate to your PC, and then install the CA certificate.
4. On the Windows task bar, click the wireless icon to open the Wireless Network Connection window.
5. In the list of wireless connections, right-click the device wireless connection and then from the shortcut menu, choose **Properties**; the Wireless Network Properties dialog box appears.
6. Click the **Security** tab.
7. From the 'Choose a network authentication method' drop-down list, select **Smart card or other certificate**, and then click **OK**.

13 TACACS+ Configuration

The device supports the TACACS+ protocol. Use the following configuration steps to configure the MSBR to authenticate using TACACS+.

Command	Description
MSBR# configure data	Accesses the Data configuration level. TACACS+ configuration needs to be done in the data level.
(config-data)# tacacs-server host 192.168.0.199	Configures the TACACS+ server IP address.
(config-data)# tacacs-server key <key>	Assigns the shared <key> to the TACACS+ server.
(config-data)# tacacs-server source data interface vlan 1	Optional: Defines the source network interface for communicating with the TACACS+ server. Note: This is applicable only to Mediant 500/500L/800 MSBRs.
(config-data)# tacacs-server network-source [STRING	Optional: Defines the source network interface (IP address alias/IP VRF alias) for communicating with the TACACS+ server. Note: This is applicable only to Mediant 500Li MSBR.
(config-data)# aaa accounting command start-stop tacacs+	Configures accounting for commands using the TACACS+ server.
(config-data)# aaa accounting exec start-stop tacacs+	Configures accounting for execution using the TACACS+ server.
(config-data)# aaa authentication login tacacs+ local	Configures authentication using the TACACS+ server. The local keyword means that if the TACACS+ server is unavailable, the local user configuration is used to authenticate.
(config-data)# aaa authentication login tacacs+ allow-console-bypass authentication	Allow bypassing TACACS+ authentication when user is connected via serial interface. After login, non-privileged commands will be allowed without negotiating with the TACACS+ Server. This will not affect TACACS+ users.
(config-data)# aaa authentication login tacacs+ allow-console-bypass authentication authorization	Allow bypassing TACACS+ enable authorization (privileged mode) when the user is connected via serial interface. After login, privileged commands will be allowed without negotiating with the TACACS+ server. This will not affect TACACS+ users.
(config-data)# aaa authorization login tacacs+	Configures authorization for the login using the TACACS+ server.
(config-data)# aaa authorization command tacacs+	Configures authorization for commands using the TACACS+ server.

The device sends packets to the TACACS+ server from its VoIP CPU. If the TACACS+ server is installed on the LAN side, no problems are experienced, because the VoIP CPU IP address is local. However, if the TACACS+ server is on the WAN side, the packets, originating from the VoIP CPU's local IP address, need to be NAT'ed. Use the `NATP enable` command or preferably, a NAT rule to make sure that the packets that are arriving to the TACACS+ server come from the same IP address. In this case, the NAT IP address needs to be configured as the host address. From version 6.8, the source address for the TACACS+ server can be configured using CLI.

13.1 Example for TACACS+ Authentication

In this example, simple authentication using a TACACS+ server is configured. The TACACS+ server is installed on an Ubuntu Linux server.

To install a TACACS+ server, use the following command on Ubuntu server:

```
apt-get install tacacs+
```

Tacacs_plus server configuration can be found in the `/etc/tacacs+/tac_plus.conf` file. Edit this file using a text editor such as vi or nano, and make sure that the following configuration line is in this file:

```
# This is the shared key that the device uses to access Tacacs+
key = P@ssw0rd

# Tacacs host ip address. In our case it the NATed VOIP CPU
address
host = 180.1.100.151 {
    key = P@ssw0rd
}
# Username configuration
user = AudioCodes {
    name = "AudioCodes"
    member = staff
    login = cleartext P@ssw0rd
}
# user $enab15$. This is a user that configured for the device's
enable command
user = $enab15$ {
    login = cleartext P@ssw0rd
}
# AudioCodes's username group configuration permits all commands
group = staff {
    cmd = conf {
        permit .*
    }
}
```

Remember to restart the TACACS+ service on the server, using the following command:

```
root@server-VirtualBox:~# sudo service tacacs_plus restart
* Restarting TACACS+ authentication daemon tacacs+
[ OK ]
root@server-VirtualBox:~#
```

Device configuration:

```
conf data
MSBR2# conf data

MSBR2(config-data)# aaa authentication login tacacs+

MSBR2(config-data)# tacacs-server host 192.162.0.199

MSBR2(config-data)# tacacs-server key P@ssw0rd

#Configure NAT for the WAN side
MSBR2(config-data)# access-list tacacs_ACL permit ip 192.168.0.2
0.0.0.0 any

MSBR2(config-data)# ip nat pool tacacs_srv 180.1.100.151
180.1.100.151

MSBR2(config-data)# ip nat inside source list tacacs_ACL interface
GigabitEthernet 0/0 pool tacacs_srv
```

13.2 Example for TACACS+ Authorization

In this example, the TACACS+ server is used to authenticate two types of administrators -- voice administrator and data administrator. The voice administrator will have access to voice configuration, and the data administrator will have access to data administration.

1. Configure authorization and authentication in the device to work with TACACS+:

```
Conf data
MSBR2# conf data
MSBR2(config-data)# aaa authentication login tacacs+
MSBR2(config-data)# aaa authorization command tacacs+
MSBR2(config-data)# tacacs-server host 192.162.0.199
MSBR2(config-data)# tacacs-server key P@ssw0rd
```

2. Configure the TACACS server to authenticate two different user types. The following is the voice user configuration on TACACS+ server on Ubuntu Linux, in the `/etc/tacacs+/tac_plus.conf` file:

```
user = voice-user {
    name = "Voice administrator"
    member = voice-admin
    login = cleartext P@ssw0rd
}
```

3. The data user configuration:

```
user = data-user {
    name = "Data administrator"
    member = data-admin
    login = cleartext P@ssw0rd
}
```

The user names are "voice-admin" and "data-admin". The voice-user is a member of the "voice-admin" group. The data-user is a member of the "data-admin" group. The password for both is "P@ssw0rd".

4. Configure the "voice-admin" and "data-admin" groups, and the commands each group is allowed to use:

```
# voice group
group = voice-admin {
  cmd = configure {
    permit voip
  }
  cmd = enable {
    permit .*
  }
  cmd = access-list {
    permit .*
  }
  cmd = appli-enabling {
    permit .*
  }
  cmd = coders-and-profiles {
    permit .*
  }
  cmd = control-network {
    permit .*
  }
  cmd = dns {
    permit .*
  }
  cmd = ether-group {
    permit .*
  }
  cmd = exit {
    permit .*
  }
  cmd = gw {
    permit .*
  }
  cmd = help {
    permit .*
  }
  cmd = history {
    permit .*
  }
  cmd = interface {
    permit .*
  }
  cmd = ip-media {
    permit .*
  }
  cmd = ldap {
    permit .*
  }
  cmd = list {
    permit .*
  }
}
```

```
}
cmd = media {
    permit .*
}
cmd = physical-port {
    permit .*
}
cmd = pwd {
    permit .*
}
cmd = qos {
    permit .*
}
cmd = quit {
    permit .*
}
cmd = rba {
    permit .*
}
cmd = routing {
    permit .*
}
cmd = sas {
    permit .*
}
cmd = sbc {
    permit .*
}
cmd = services {
    permit .*
}
cmd = sip-definition {
    permit .*
}
cmd = tdm {
    permit .*
}
cmd = do {
    permit .*
}
cmd = no {
    permit .*
}
}
#data group
group = data-admin {
    cmd = configure {
        permit data
    }
    cmd = enable {
        permit .*
    }
}
```

```
}  
cmd = aaa {  
    permit .  
}  
cmd = access-list {  
    permit .  
}  
cmd = backup-group {  
    permit .  
}  
cmd = crypto {  
    permit .  
}  
cmd = exit {  
    permit .  
}  
cmd = help {  
    permit .  
}  
cmd = history {  
    permit .  
}  
cmd = interface {  
    permit .  
}  
cmd = ip {  
    permit .  
}  
cmd = key {  
    permit .  
}  
cmd = l2tp-server {  
    permit .  
}  
cmd = list {  
    permit .  
}  
cmd = lldp {  
    permit .  
}  
cmd = pptp-server {  
    permit .  
}  
cmd = pwd {  
    permit .  
}  
cmd = qos {  
    permit .  
}  
cmd = quit {  
    permit .  
}
```



```
}  
cmd = route-map {  
    permit .*  
}  
cmd = router {  
    permit .*  
}  
cmd = router-id {  
    permit .*  
}  
cmd = service {  
    permit .*  
}  
cmd = spanning-tree {  
    permit .*  
}  
cmd = tacacs-server {  
    permit .*  
}  
cmd = track {  
    permit .*  
}  
cmd = vpn-users {  
    permit .*  
}  
cmd = web-restrict {  
    permit .*  
}  
cmd = do {  
    permit .*  
}  
cmd = no {  
    permit .*  
}  
}
```

13.3 TACACS+ Flags and Flow Chart


This section describes the TACACS+ flags and flow chart.

13.3.1 TACACS+ Configuration Flags

- aaa authentication login tacacs+ <local>
- aaa authentication login tacacs+ allow-console-bypass authentication
- aaa authentication login tacacs+ allow-console-bypass authentication authorization
- aaa authorization enable if-authenticated tacacs+
- aaa authorization login tacacs+
- aaa authorization command tacacs+
- aaa authorization enable local tacacs+

13.3.2 TACACS+ Flow Chart

Figure 13-1: TACACS+ Flow Chart



14 Recovery Procedures

14.1 Password Recovery Procedure

If the login password for accessing the device's management interface has been forgotten, the Password Recovery procedure can be used to gain access to the device. Press the device's reset button for 15 to 30 seconds. The device's configuration is deleted and the username and password are set to "Admin". The enable password is also set to "Admin".

14.2 Rescue Process

If the device's operation system file has been corrupted, follow the Rescue process to rescue the device. Press the device's reset button for more than thirty seconds. The device resets and uses the BootP protocol to boot itself from the first LAN port. All other ports enter shutdown mode. This is called the *Rescue Mode*. The device also enters rescue mode if it resets as a result of crashing three times while booting, or if a software upgrade fails.

The following is the description of the rescue procedure:

1. Attach a computer to the first LAN port of the device.
2. Configure the IP address 192.168.0.3/24 on the attached computer.
3. Verify the MTU size. The MTU mustn't be greater than 1500. To set the MTU size in Windows 7:
 - a. Start CMD.
 - b. Type "netsh", and then press Enter.
 - c. Type "interface ipv4", and then press Enter.
 - d. Type "set interface "Local Area Connection" mtu=1500", and then press Enter.
4. Create a BootP client in the BootP/TFTP utility.
5. Assign the IP address of 192.168.0.2/24 to the MAC address of the device.
6. Select the .cmp file to upload to the device.
7. Boot the device to rescue mode by pressing the reset button for 30 seconds; the device downloads the .cmp image file.

This page is intentionally left blank.

15 Factory Setting

To delete the device's configuration, use the following command:

Command	Description
MSBR# write factory	Clears configuration and resets the device.

The device's configuration can also be cleared by pressing the reset button for a period of 15 to 30 seconds.

This page is intentionally left blank.

16 Device Reload

To reload the device, enter the following command:

Command	Description
MSBR# reload now	Saves configuration and resets the device.

An alternative method to reload the device is by pressing the reset button for a period of one to fifteen seconds.

This page is intentionally left blank.

17 Certificates

To import certificates, use the following command:

Command	Description
MSBR# copy <cert file> from <server>	Copies the certificate file from the server.

The certificate file can be one of the following:

File	Description
tls-cert	TLS Certificate file.
tls-private-key	TLS Private Key file.
tls-root-cert	TLS Trusted-Root Certificate file.

17.1 Example

This example uses the `copy` command to download the certificate from the TFTP server to the device.

```
MSBR# copy tls-cert from tftp://192.168.0.3/cert.pem
```

```
Copying file... 0 bytes
```

```
done.
```

```
use 'write' command in order to burn to NV memory
```

```
MSBR# copy tls-root-cert from tftp://192.168.0.3/caroot.pem
```

```
Copying file... 0 bytes
```

```
done.
```

```
use 'write' command in order to burn to NV memory
```

```
MSBR# copy tls-private-key from tftp://192.168.0.3/pkey.pem
```

```
Copying file... 0 bytes
```

```
done.
```

```
use 'write' command in order to burn to NV memory
```

```
MSBR# write
```

```
Writing configuration...done
```

```
MSBR#
```

This page is intentionally left blank.

18 Syslog

The device supports remote logging. To configure the remote Syslog server, use the following commands:

Command	Description
MSBR# configure troubleshoot	Accesses the Data system configuration level.
(config-troubleshoot)# syslog	Accesses the syslog configuration level.
(syslog)# syslog-ip 192.168.0.3	Configures the Syslog server's IP address. Note: Changes to this parameter will take effect when applying the <code>activate</code> or <code>exit</code> command.
(syslog)# source data interface vlan 1	Optional: Set source interface for sending syslog messages Note: This is applicable only to Mediant 500/500L/800 MSBRs.
(syslog)# network-source [STRING]	Defines the source network interface (IP address alias/IP VRF alias) for sending syslog messages. Note: This is applicable only to Mediant 500Li MSBR.
(syslog)# debug-level 0 [basic detailed no-debug]	Sets the debug level.
(syslog)# syslog on	Enables syslog.
(syslog)# activate	Activates the configuration.

The configurable debug levels are from 0 to 7. The most common option is level 1, where the VoIP debug is enabled. At level 0, the VoIP debug is disabled, however at level 1, VoIP debugging is enabled.

18.1 Examples

The following is an example of the Syslog configuration:

```
MSBR# conf syst
MSBR(config- troubleshoot)# syslog
MSBR(syslog)# syslog-ip 192.168.0.3
Note: Changes to this parameter will take effect when applying the
'activate' or 'exit' command
MSBR(syslog)# debug-level basic
MSBR(syslog)# syslog on
MSBR(logging)# activate
```

Log messages received at the Syslog server for state changes in interface Gig0/0:

```
Mar 16 13:10:31 192.168.0.2 [S=354] RAISE-
ALARM:acDataInterfaceStatus; Textual Description: Data interface
GigabitEthernet 0/0 is DOWN; Severity:indeterminate; Source;;
Unique ID:6;
```

```
Mar 16 13:10:40 192.168.0.2 [S=357] RAISE-  
ALARM:acDataInterfaceStatus; Textual Description: Data interface  
GigabitEthernet 0/0 is UP; Severity:indeterminate; Source;; Unique  
ID:7;
```

19 Network Quality Monitor

This chapter describes the Network Quality Monitoring (NQM) feature.


19.1 Overview

The NQM feature is designed for monitoring the quality of a current network path between two network NQM terminations, a 'Sender termination' and a 'Responder termination'.

The quality is measured according to the following criteria:

- Round trip time
- Packet jitter
- Packet loss rate
- Listener quality MOS as per ITU-T spec.¹.
- Conversation quality MOS as per ITU-T spec².

The figure below illustrates the network paths between the Responder and the Sender termination points.



¹ Available only when packets sent are a valid g711 stream in terms of payload size and packet interval. – see table in Section 19.1.1 for valid g711 parameter values.

² See note 1 above.

19.1.1 MOS Results

The table below shows the legal pair values for valid MOS results.

Sender table parameter → packet-interval [msec]	Sender table parameter → Payload-size [bytes]
5	60
10	100
20	180
40	340
60	500
80	660
100	820
120	980

19.2 Configuring the 'Sender Termination' Side

This section describes how to configure the Sender Termination side.

19.2.1 Step 1: Bind a WAN Interface to the NQM Service

Bind a WAN interface to the NQM service:

```
(config- network)# bind interface GigabitEthernet 0/0 nqm
```



Note:

- This is applicable only to the Mediant 500/500L/800 MSBRs.
- The chosen WAN interface should be the interface on which the NQM packets are planned to flow bi-directionally and binding is necessary to create the corresponding static NAT rules.
If the NQM session is planned to flow within the LAN, then no binding is needed and this step can be skipped.

19.2.2 Step 2: Configure a Line in the Probing Table

Configure a line in the Probing table:

```
MSBR(config-network)# nqm probing-table 0
MSBR(probing-table-0)#
```

Configure a Probe name – name tag to identify this line:

```
MSBR(probing-table-0)# probe-name voip_probe_1
```

Activate the probe line:

```
MSBR(probing-table-0)# exit
MSBR(config-network)#
```

19.2.3 Step 3: Configure a Line in the Sender Table to Define a Sender Termination

Configure a line in the Sender table to define a Sender termination:

```
MSBR(config-network) # nqm sender-table 0
MSBR(sender-table-0) #
```

Configure a Sender name – name tag to identify this specific sender:

```
MSBR(sender-table-0) # sender-name main_office_voip_checker_1
```

Configure a Target IP address – set IP address of Responder termination:

```
MSBR(sender-table-0) # target-ip 10.4.3.98
```

Configure a Target port – set port number on which the Responder termination listens:

```
MSBR(sender-table-0) # target-port 3900
```

Activate this

```
MSBR(sender-table-0) # start-time now
```



Note: A Responder termination defined by the pair <target IP address, target port> can be defined only once for a single sender line. Two or more senders can't be defined to send packets to the same Responder termination.

Configure a Probe name – name of probing line previously configured to be used by this sender:

```
MSBR(sender-table-0) # probe-name voip_probe_1
```



Note: A single probe line in the probing table may be shared by several senders thereby sharing and simplifying common attributes configuration.

Configure a source network interface to send packets:

- Mediant 500/500L/800 MSBRs (name of network interface):

```
MSBR(sender-table-0) # source-interface-name OAM_IF
```

- Mediant 500Li (IP address alias/IP VRF alias):

```
(sender-table-0) # network-source [STRING]
```



Note: If you wish to output packets to the WAN interface, simply set NQM_WAN as the source interface name, otherwise set the interface name to be a specific interface name found in the network interface table.

Activate the sender line:

```
MSBR(sender-table-0) # exit
MSBR(config-network) #
```

19.3 Configuring the 'Responder Termination' Side

Enter the 'configure system' sub menu in the CLI:

```
MSBR> enable
Password:
MSBR# configure system
MSBR(config-network) #
```

19.3.1 Step 1: Bind a WAN interface to the NQM service

Bind a WAN interface to the NQM service:

```
MSBR(config-network) # bind GigabitEthernet 0/0 nqm
MSBR(config-network) #
```



Note:

- This is applicable only to the Mediant 500/500L/800 MSBRs.
- The chosen WAN interface should be the interface on which the NQM packets are planned to flow bi-directionally and binding is necessary to create the corresponding static NAT and port forwarding rules.
If the NQM session is planned to flow within the LAN, then no binding is required and therefore this step can be skipped.

19.3.2 Step 2: Configure a Line in the Responder Table

Configure a line in the Responder table as follows:

```
MSBR(config-network) # nqm responder-table 0
MSBR(responder-table-0) #
```

Configure a Responder name – name tag to identify this line:

```
MSBR(responder-table-0) # responder-name
main_office_voip_responder_1
```

Configure a Target port – set port number on which the Responder termination listens:

```
MSBR(responder-table-0) # local-port 3900
```



Note: Make sure the local-port value is in-sync with the target-port value set for the corresponding Sender termination.

Configure a source network interface to listen for incoming packets:

- Mediant 500/500L/800 MSBRs (name of network interface):

```
MSBR(responder-table-0) # source-interface-name OAM_IF
```

- Mediant 500Li (IP address alias/IP VRF alias):

```
(responder-table-0) # network-source [STRING]
```



Note: If you wish to listen to the WAN interface, simply set NQM_WAN as the source interface name, otherwise set the interface name to be a specific interface name found in the Network Interface table



Note: Make sure the network interface that the Responder termination is listening upon is in-sync with the target-ip value set for the corresponding Sender termination.

Activate the responder line:

```
MSBR(responder-table-0) # exit
MSBR(config-network) #
```


19.4 Viewing Results

This section describes how to view the results of the Responder termination.

19.4.1 CLI interface

On the Sender termination device, in the CLI, configure the following:

```
MSBR> enable
Password:
MSBR# show network nqm 0 8
```

Probe Time	Valid	RTT	PL Tx	PL Rx	Total PL	Jit. Tx	Jit. Rx	Total Jit.	MOS CQ	MOS LQ
01-01-2010@02:46:24	yes	7	0	0	0	0	17	17	0.0	0.0
01-01-2010@02:47:24	yes	10	0	0	0	30	1	31	0.0	0.0
01-01-2010@02:48:25	yes	9	0	0	0	31	20	51	0.0	0.0
01-01-2010@02:49:25	yes	6	0	0	0	32	4	36	0.0	0.0
01-01-2010@02:50:25	yes	5	0	0	0	0	5	5	0.0	0.0
01-01-2010@02:51:25	yes	5	0	0	0	15	15	30	0.0	0.0
01-01-2010@02:52:25	yes	6	0	0	0	32	7	39	0.0	0.0
01-01-2010@02:53:25	yes	6	0	0	0	30	5	35	0.0	0.0

there are 10 entries in the log, displaying last 8 entries

```
MSBR#
```

19.4.2 SNMP Interface

Access the acSysNqmHistoryTable object.

SNMP OID info

Name: acSysNqmHistoryTable

Type: OBJECT-TYPE

OID: 1.3.6.1.4.1.5003.9.10.10.2.12.1

Full path:
iso(1).org(3).dod(6).internet(1).private(4).enterprises(1).audioCodes(5003).acProducts(9).acBoardMibs(10).acSystem(10).acSystemStatus(2).acSysNqmStatus(12).acSysNqmHistoryTable(1)

Module: AC-SYSTEM-MIB

Parent: acSysNqmStatus

First child: acSysNqmHistoryEntry

Figure 19-2: SNMP Interface

Instance	acSysNqmHistorySenderIndex(IDX)	acSysNqmHistoryIndex(IDX)	acSysNqmHistoryProbeTime	acSysNqmHistoryIsValid	acSysNqmHistoryRow...	acSysNqmHistoryPacketLossTx	acSysNqmHistoryPa
1.0	Not accessible	Not accessible	11-22-2014@00:56:42	yes	6	0	0
1.1	Not accessible	Not accessible	11-22-2014@00:57:42	yes	5	0	0
1.2	Not accessible	Not accessible	11-22-2014@00:58:42	yes	6	0	0
1.3	Not accessible	Not accessible	11-22-2014@00:59:42	yes	5	0	0
1.4	Not accessible	Not accessible	11-22-2014@01:00:42	yes	5	0	0
1.5	Not accessible	Not accessible	11-22-2014@01:01:42	yes	6	0	0
1.6	Not accessible	Not accessible	11-22-2014@01:02:42	yes	6	0	0

20 Debugging - Packet Capturing

The device supports advanced debugging using packet capturing. The captured files are saved to a PCAP file. You can also send the file to an FTP or a TFTP server or save the file to a USB device connected to the device. You can also save the file locally on the device, where in this case, the file size is limited to 20 MB.

To capture traffic on a physical interface, use the following commands:

Command	Description
MSBR# debug capture data physical eth-lan Interface eth-lan was added to the debug capture rules	Sets the Ethernet interface as a source for capturing packets.
MSBR# debug capture data physical target tftp	Sets the destination for the captured packet file as a TFTP server.
MSBR# debug capture data physical start NOTE: Debug capture data will be collected locally, and later sent to a PC via TFTP/FTP. Please make sure that VLAN 1 is defined and the PC is accessible through it.	Starts capturing files. Note: The capture data is collected locally, and only then sent to the PC later on.
MSBR# debug capture data physical stop 192.168.0.3 Trying to send capture to TFTP/FTP server , filename debug-capture-data-16032014-154400 Finished MSBR#	The command stops capturing files and then uploads the file to a TFTP server with IP address 192.168.0.3.
MSBR# debug capture data physical stop 192.168.0.3 VRF MGMT Trying to send capture to TFTP/FTP server , filename debug-capture-data-16032014-154400 Finished MSBR#	There is an ability to stop the capture and send the captured traffic from a specific VRF, in this example, the VRF is called MGMT.

The available sources for file captures are listed below:

Source	Description
cellular-wan	Cellular WAN interface.
eth-lan	LAN Ethernet interfaces.
eth-wan	WAN Ethernet interfaces.
fiber-wan	WAN fiber interface.
xdsl-wan	Any DSL interface (ADSL, VDSL) that is installed on the device.

Use the following commands to capture traffic on a logical interface:

Command	Description
<pre>MSBR# debug capture data interface <interface> <proto ipsec> <all arp icmp ip ipv6 tcp udp> host <IP IPv6 all> <cr port> <any 1-65535 <cr ftp tftp> IP</pre>	<ul style="list-style-type: none"> ▪ <interface>: interface to capture the data on. ▪ <proto ipsec>: if IPsec is selected, it is decrypted and captured. ▪ <all arp icmp ip ipv6 tcp udp>: selects protocol for capturing. ▪ host <IP IPv6 all>: select traffic to capture using the IP or IPv6 address as a filter. ▪ <cr port> <any 1 – 65535>: select the port to capture or press Enter. If you press Enter, the packets are displayed in the console. ▪ <cr ftp tftp> IP: press Enter to display the captured packets on screen, or send captured packets to TFTP or FTP server.

To view the currently configured capture, use the following command:

Command	Description
<pre>MSBR# debug capture data physical show</pre>	Displays currently configured capture.

20.1 Example of Capturing Data on Physical Interface


This example captures data from the Ethernet interface on the LAN side and sends it to a USB device:

```
MSBR# debug capture data physical eth-lan
Interface eth-lan was added to the debug capture rules
      Use start command in order to start the debug capture
MSBR# debug capture data physical target usb
MSBR# debug capture data physical start
Saving capture to USB storage.
File name: debug-capture-data-16032014-155634.pcap
MSBR# debug capture data physical stop
Finished. Type "usb remove" to safely remove the drive.

MSBR# usb remove
You may now remove the USB drive
```

The captured file is written to the root directory of the USB drive.

Figure 20-1: Captured file on USB drive



20.2 Example of Capturing Data on an Interface

This example captures data from the Ethernet interface on the WAN side and sends it to a TFTP server:

```
MSBR# debug capture data interface gigabitethernet 0/0 proto all
host any port any tftp-server 192.168.0.50
.....
MSBR#
```

This page is intentionally left blank.

21 PacketSmart

This chapter describes how to setup the BroadSoft's BroadCloud PacketSmart embedded agent that is bundled with AudioCodes Mediant 500, Mediant 500L and Mediant 800 Gateway and E-SBC products.

PacketSmart is a powerful toolkit used for network assessments. Comprised of Assessment, Verification, Diagnostics and Monitoring, PacketSmart is a lifecycle management solution that ensures VoIP services are deployed correctly, accepted by customers and monitored to meet customer satisfaction.

PacketSmart Monitoring observes customer networks and live calls to identify the source of local area network (LAN) and wide area network (WAN) issues that may impact VoIP quality.


PacketSmart uses proactive alerting with automated reporting that enables service providers to address issues prior to customer complaints arising into support groups, thereby reducing overall trouble tickets.



Notes:

- You must configure the Gateway or SBC before enabling PacketSmart. Refer to the *Mediant 800B Gateway and E-SBC User's Manual Ver.7.0*.
- PacketSmart functionality requires a Feature key.

Figure 21-1: PacketSmart Management Solution



The following figures show typical deployment models for the SBC and Gateway.

Figure 21-2: SBC in DMZ Model





Figure 21-3: SBC on LAN Model



Command	Description
<code>(config-system)# packetsmart server port</code>	Defines the TCP port of the PacketSmart server to which the PacketSmart agent connects. The default is 80.

21.1.2 Viewing PacketSmart Statistics

The PacketSmart Web client is the user interface to the PacketSmart cloud-based service platform.

➤ **To view PacketSmart statistics:**


1. Download and launch the PacketSmart Web GUI client.
2. Enter the login credentials you received from BroadSoft, in the PacketSmart Login screen.
3. Click **Login**.

Figure 21-5: Converged Media Network Management

The screenshot displays the PacketSmart login interface. At the top, there's a blue header with the text 'Converged Media Network Management' and the 'PacketSmart' logo. To the right of the logo is a 'Login' button and a small icon of a person. Below the header, the login form consists of several labeled input fields: 'Domain', 'SME', 'User', and 'Password'. The 'Password' field has a blue link for 'Forgot Password'. Below these are two dropdown menus: 'P Smart IP/Name' (currently showing 'psmart-beta (PST)') and 'Time Zone' (currently showing 'Asia/Jerusalem'). At the bottom of the form are two buttons: a green 'Login' button and a red 'Cancel' button. A progress bar is visible at the very bottom of the window.

4. PacketSmart statistics appear on the screen.

Figure 21-6: BroadSoft Server View



5. Confirm that the SBC devices are connected to the BroadSoft server.

This page is intentionally left blank.

22 Customizing Web Interface

Service Providers can customize the device's Web interface to manage the basic functionality of the device and define the type and name of the interface to manage. The following is a list of functions that can be configured for management in the device's Web interface:

- LAN interface
- LAN guest
- WAN
- WAN backup

For example, the LAN interface or LAN guest can be any VLAN, BVI or dot11radio. The WAN or WAN backup can be any WAN interface: Fiber, EFM, Gigabit Ethernet 0/0, etc.

22.1 Configuring the Web Interface

This section describes how to configure the Web interface.

22.1.1 Assigning Interfaces to Menus

1. Create a user with privilege "end-user". This can be done via the Web: (**Setup** menu > **Administration** tab > **WEB&CLI** folder) or using CLI as follows:

```
M500L# configure system
M500L(config-system)# user root
Configure new user root
M500L (user-root)# password root
M500L (user-root)# privilege end-user
M500L (user-root)# exit
M500L(config-system)# exit
M500L#
```

2. Assign one of the device's interfaces to manage in the Web interface. The following example configuration assigns the interface BVI 2 to the LAN menu. The interface "BVI 1" is assigned to LAN GUEST menu, the interface "PPPoE 1" is assigned to the WAN menu and the interface "PPPoE 2" is assigned to the WAN BACKUP menu.

```
configure system
end-user
lan-if bvi 2
guest-if bvi 1
wan-if pppoe 1
wan-backup-if pppoe 2
exit
```

3. The information that can be displayed or modified under the different menus depends on the features of the interface. For example, only on PPPoE interfaces can a user and password be configured.
4. The same configuration can be performed via the device's ini file. The following are the ini parameters:

```
EndUserLanIf = 'bvi 2'
EndUserGuestIf = 'bvi 2'
EndUserWanIf = 'pppoe 1'
EndUserWanBackUp= 'pppoe 2'
```

22.1.2 Allowing End User to Configure Cellular Interface

The procedure below describes how to configure the end user permission to change the cellular interface configuration.

The cellular interface is configured under WAN interface or WAN-backup interface.

1. Configure wan-if of the “End User” feature to cellular 0/0:

```
MSBR# con system
MSBR(config-system)# end-user
MSBR(end-user)# wan-if cellular 0/0
```

2. Configure cellular interface to run in mode dhcp or ppp mode:

- a. mode dhcp:

```
MSBR# con data
MSBR(config-data)# interface cellular 0/0
MSBR(conf-cellular)# mode dhcp
MSBR(conf-cellular)# exit
MSBR(config-data)# exit
```

Note: Some of the interface's configuration was lost due to the mode change.

- b. mode ppp:

```
SBR# con data
SBR(config-data)# interface cellular 0/0
SBR(conf-cellular)# mode ppp
SBR(conf-cellular)# exit
SBR(config-data)# exit
```

Note: Some of the interface's configuration was lost due to the mode change

22.1.3 Allowing End User to Change PPPoE User Name and Password

The procedure below describes how to allow the end user permission to change the PPPoE username and password.

➤ **To allow changing the PPPoE username and password using the Web interface:**

1. Do one of the following:

a. Use the CLI commands as shown below:

```
configure system
end-user
allow-pppoe-settings enable
exit
```

b. Use the *ini* file to set the parameter as shown below:

```
Set EndUserAllowPppoeSettings = 1
```

To disable, use 0 instead of 1.

2. As a result of running either the CLI command or using *ini* file, the PPPoE Settings appear on the WAN Interface page on the Web interface. This allows the end user to change the PPPoE username and password using the Web interface.

Figure 22-1: PPPoE Settings

The screenshot displays the Audiocodes web interface for configuring the WAN Interface. The left sidebar shows navigation options: MONITOR, DEVICE INFORMATION, LAN, LAN Ports, WAN, WAN Interface (selected), and ADVANCED. The main content area is titled 'WAN Interface' and contains three sections: PHYSICAL INTERFACE INFORMATION, INTERFACE INFORMATION, and PERFORMANCE MONITORING. The PPPoE SETTINGS section is highlighted with a red box and contains the following fields:

PPPOE SETTINGS	
PPPoE Username	<input type="text" value="test@011"/>
PPPoE Password	<input type="password"/>

22.1.4 Allowing End User to Perform Reset to Factory Defaults

The procedure below describes how to allow the end user perform a factory reset using the Web interface.

➤ **To perform a factory reset using the Web interface:**

1. Do one of the following:

a. Use the CLI commands as shown below:

```
configure system
end-user
allow_factory_defaults enable
exit
```


b. Use the *ini* file to set the parameter as shown below:

```
Allowfactorydefaults = 1
```

To disable, use 0 instead of 1.

2. As a result of running either the CLI command or using *ini* file, the Restore Defaults Settings appear on the Device Information page on the Web interface. This allows the end user to reset the device to factory defaults.

Figure 22-2: Restore Defaults



22.1.5 Allowing End User to use Syslog and LAN Port Mirroring

The procedures below describe how to allow the end user to use Syslog and LAN Port Mirroring.

➤ **To allow troubleshooting using the Web interface:**

1. Do one of the following:

a. Use the CLI commands as shown below:

```
configure system
end-user
allow-troubleshooting enable
exit
```


b. Use the *ini* file to set the parameter as shown below:

```
EndUserAllowTroubleShooting = 1
```

To disable, use 0 instead of 1.

2. As a result of running either the CLI command or using *ini* file, the Troubleshooting Settings appear on the Syslog Settings page on the Web interface. This allows the end user to use the Troubleshooting settings.

Figure 22-3: Syslog Settings



22.1.6 Allowing End User to Configure WAN Settings

The procedure below describes how to allow the end user to set the WAN with static IP or DHCP.

➤ **To allow troubleshooting using the Web interface:**

1. Do one of the following:

a. Use the CLI commands as shown below:

```
configure system
end-user
allow-wan-settings enable
exit
```

b. Use the *ini* file to set the parameter as shown below:

```
EndUserAllowWanSettings = 1
```

To disable, use 0 instead of 1.

2. As a result of running either the CLI command or using *ini* file, the WAN Backup Interface is enabled on the Web interface. This allows the end user to configure WAN settings.

Figure 22-4: WAN Backup Interface

The screenshot displays the 'WAN Backup Interface' configuration page in the audiocodes web interface. The left sidebar shows a navigation menu with options like MONITOR, DEVICE INFORMATION, LAN, WAN, WAN BACKUP, ADVANCED, and TROUBLESHOOTING. The 'WAN Backup Interface' option is selected. The main content area is divided into four sections:

- PHYSICAL INTERFACE INFORMATION:**

Name	GigabitEthernet 0/0
Type	Copper
Description	WAN Copper
Port Link	Down
- INTERFACE INFORMATION:**

Name	GigabitEthernet 0/0
Description	WAN Copper
Status	Enabled
State Time	01:19:10
- PERFORMANCE MONITORING:**

15 Seconds Input Rate	0 bps
15 Seconds Output Rate	0 bps
5 Minutes Input Rate	0 bps
5 Minutes Output Rate	0 bps
- WAN SETTINGS:**

IP Address Mode	Static
IP Address	
Subnet Mask	
DEFAULT_GATEWAY	
DNS Server Mode	Static
Primary DNS Server IP Address	
Secondary DNS Server IP Address	

An 'APPLY' button is located at the bottom right of the configuration area.

22.1.7 Allowing End User to Configure LAN Guest Interfaces

The parameters on the LAN Interface page under the LAN Guest folder are read-only by default. In other words, the user cannot configure the LAN and DHCP parameters that are located under the LAN Interfaces Settings group and DHCP Settings group, respectively.

➤ **To allow LAN Guest Interface configuration through the Web interface:**

■ **CLI:**

```
configure system
end-user
    allow-lan-guest-setting enable
exit
```

■ **ini file:**

```
EndUserAllowLanGuestSettings = 1
```

Figure 22-5: LAN Guest > LAN Interface Page

The screenshot displays the 'LAN Interface' configuration page. On the left is a navigation menu with sections: MONITOR, DEVICE INFORMATION, LAN, LAN GUEST, VOICE, and ADVANCED. The 'LAN GUEST' section is expanded, showing 'LAN Interface' as the selected item. The main content area is titled 'LAN Interface' and contains several tabs: 'INTERFACE INFORMATION', 'LAN INTERFACES SETTINGS', 'PERFORMANCE MONITORING', and 'DHCP SETTINGS'. The 'INTERFACE INFORMATION' tab is active, showing details for 'dot11radio 1'. The 'LAN INTERFACES SETTINGS' tab is also visible, showing IP Address (192.168.3.10) and Subnet Mask (255.255.255.0). The 'PERFORMANCE MONITORING' tab shows input/output rates. The 'DHCP SETTINGS' tab shows DHCP server configuration, including 'Enable DHCP Server' (set to 'Enable'), IP pool addresses, and lease time.

INTERFACE INFORMATION		LAN INTERFACES SETTINGS	
Name	dot11radio 1	IP Address	192.168.3.10
Type	LAN	Subnet Mask	255.255.255.0
Description	LAN Wireless 802.11n Access Point		
Status	Disabled		
State Time	18:30:01		
Primary DNS Server IP Address			
Secondary DNS Server IP Address			

PERFORMANCE MONITORING		DHCP SETTINGS	
15 Seconds Input Rate	0 bps	Enable DHCP Server	Enable
15 Seconds Output Rate	0 bps	First IP Pool Address	192.168.3.15
5 Minutes Input Rate	0 bps	Last IP Pool Address	192.168.3.234
5 Minutes Output Rate	0 bps	IP Pool Subnet Mask	255.255.255.0
		Primary DNS Server IP Address	0.0.0.0
		Secondary DNS Server IP Address	0.0.0.0
		Client Lease Time [Minutes]	60

APPLY

22.1.8 Allowing End User to Configure Port Forwarding

The Port Forwarding Settings page (Monitor > Advanced folder > Port Forwarding Settings) is hidden by default. You can show the page and allow configuration.

➤ To allow port forwarding configuration through the Web interface:


■ CLI:

```
configure system
end-user
  allow-port-forwarding enable
exit
```

■ *ini* file:

```
EndUserAllowPortForwarding = 1
```

Figure 22-6: Port Forwarding Settings Page



22.1.9 Allowing End User to Configure DMZ

The DMZ Settings page (Monitor > Advanced folder > DMZ) is hidden by default. You can show the page and allow configuration.

➤ **To allow DMZ configuration through the Web interface:**


■ **CLI:**

```
configure system
end-user
  allow-dmz-settings enable
exit
```

■ **ini file:**

```
EndUserAllowDMZSettings = 1
```

Figure 22-7: DMZ Settings Page



22.1.10 Allowing End User to Configure Multiple Subscriber Number Table

By default, the Voice folder from which the Multiple Subscriber Number table is accessed (Monitor > Voice folder > Multiple Subscriber Number) is hidden.

- To show Voice folder (and Multiple Subscriber Number table) through the Web interface:

- CLI:

```
configure system
end-user
    allow-voice-settings enable
exit
```

When this table is shown, by default, the 'User ID' parameter value is read-only and the 'Password' parameter and value are hidden.

- To allow User ID and password configuration through the Web interface:


- CLI:

```
configure system
end-user
    allow-msn-authentication-settings enable
exit
```

- ini file:

```
EndUserMsnSettings = 1
```

Figure 22-8: Multiple Subscriber Number Configuration



22.1.11 Allowing End User to View Voice Statistics

If the device has voice (e.g., E1/T1) interfaces, the Web interface displays various statistical information under the Monitor > Voice folder. By default, the Voice folder is hidden. To show the Voice folder, perform the following procedure:

➤ **To show the Voice folder:**

```
configure system
end-user
    allow-voice-settings enable
exit
```

Voice statistics are displayed on the following Web pages under the Voice folder:

■ **Calls Count page** - displays IP-to-Tel and Tel-to-IP call statistics:

The screenshot shows the Audiocodes web interface. The left sidebar has a 'MONITOR' section with 'VOICE' expanded. The main content area shows two columns: 'IP-TO-TEL' and 'TEL-TO-IP'. Each column lists various call statistics with values of 0 or a dash. There are 'Press To Reset' buttons at the bottom of each column.

IP-TO-TEL		TEL-TO-IP	
Number of Attempted Calls	0	Number of Attempted Calls	0
Number of Established Calls	0	Number of Established Calls	0
Percentage of Successful Calls (ASR)	—	Percentage of Successful Calls (ASR)	—
Number of Calls Terminated due to a Busy Line	0	Number of Calls Terminated due to a Busy Line	0
Number of Calls Terminated due to No Answer	0	Number of Calls Terminated due to No Answer	0
Number of Calls Terminated due to Forward	0	Number of Calls Terminated due to Forward	0
Number of Failed Calls due to No Route	0	Number of Failed Calls due to No Route	0
Number of Failed Calls due to No Matched Capabilities	0	Number of Failed Calls due to No Matched Capabilities	0
Number of Failed Calls due to No Resources	0	Number of Failed Calls due to No Resources	0
Number of Failed Calls due to Other Failures	0	Number of Failed Calls due to Other Failures	0
Average Call Duration (ACD) [sec]	0	Average Call Duration (ACD) [sec]	0
Attempted Fax Calls Counter	0	Attempted Fax Calls Counter	0
Successful Fax Calls Counter	0	Successful Fax Calls Counter	0
RESET_COUNTERS	Press To Reset	RESET_COUNTERS	Press To Reset

■ **SBC Registered Users** – displays information on SBC users that are registered on the device

The screenshot shows the Audiocodes web interface. The left sidebar has a 'MONITOR' section with 'VOICE' expanded. The main content area shows a table with two columns: 'ADDRESS OF RECORD' and 'CONTACT'. The table contains one row of data.

ADDRESS OF RECORD	CONTACT
10.4.2.251	*sip:10.4.2.251:5060>expires=180 IPG:1 ST:0 ID:29

- **Registration Status page** – displays information on user registrations on the device:

The screenshot shows the 'Registration Status' page. On the left is a sidebar with a 'MONITOR' section containing links for 'DEVICE INFORMATION', 'LAN', 'LAN Ports', 'VOICE', 'Calls Count', 'Registration Status' (highlighted), 'Gateway CDR History', 'Multiple Subscriber Number', and 'ADVANCED'. The main content area is titled 'Registration Status' and shows 'Registered Per Gateway' as 'No'. Below this are two empty tables. The first table has columns: '#', 'GROUP TYPE', 'GROUP NAME', and 'STATUS'. The second table has columns: 'PHONE NUMBER', 'GATEWAY PORT', and 'STATUS'. Both tables contain the text 'No table entries to display'.

- **Gateway CDR History page** – displays CDRs relating to Gateway calls:

The screenshot shows the 'Gateway CDR History' page. The sidebar is identical to the previous page, with 'Gateway CDR History' highlighted. The main content area is titled 'Gateway CDR History'. It features a pagination bar showing 'Page 1 of 1' and a '20' dropdown. Below the pagination bar is a table with the following columns: 'CALL END TIME', 'END POINT', 'CALLER', 'CALLEE', 'DIRECTION', 'REMOTE IP', 'DURATION', 'TERMINATION REASON', and 'SESSION ID'. The table is empty, and the text 'No records to view' is displayed at the top right.

- **SBC CDR History page** – displays CDRs relating to SBC calls:

The screenshot shows the 'SBC CDR History' page. The sidebar on the left has 'SBC CDR History' highlighted. The main content area is titled 'SBC CDR History'. It includes a pagination bar with 'Page 1 of 1' and a '20' dropdown. Below the pagination bar is a table with columns: 'CALL END TIME', 'ENDPOINT TYPE', 'IP GROUP', 'CALLER', 'CALLEE', 'DIRECTION', 'REMOTE IP', 'DURATION', 'TERMINATION REASON', and 'SESSION ID'. The table is empty, and the text 'No records to view' is displayed at the top right.

22.1.12 Configure Languages

You can configure the Web interface language settings.

1. Do one of the following:

- a. Use the CLI commands as shown below:

```
Languages = en-US,de-DE
```

- b. Use the *ini* file to set the parameter as shown below:

```
Defaultlanguage = de-DE
```

22.2 Accessing the Web Interface

The procedure below describes how to access the Web interface.

➤ **To access the Web interface:**

1. Open a standard Web browser.
2. In the Web browser, specify the OAMP IP address of the device (e.g., `http://10.1.10.10`).
3. In the 'Username' and 'Password' fields, enter the username and password, respectively. The credentials are case-sensitive.
4. If you want the Web browser to remember your username and password, select the 'Remember Me' check box and then agree to the browser's prompt (depending on your browser). On your next login attempt, the 'Username' field is automatically populated with your username. Simply press the Tab or Enter key to auto-fill the 'Password' field, and then click **Login**.
5. Click **Login**.

Note:

- The default login username and password is "Admin" (case-sensitive). To change the login credentials, see 'Configuring Management User Accounts' on page 79.
- By default, Web access is only through the IP address of the OAMP interface. However, you can allow access from all the device's IP network interfaces, by setting the `EnableWebAccessFromAllInterfaces` parameter to 1.
- By default, autocompletion of the login username is enabled whereby the 'Username' field offers previously entered usernames. To disable autocompletion, use the `WebLoginBlockAutoComplete` ini file parameter.
- Depending on your Web browser's settings, a security warning box may be displayed. The reason for this is that the device's certificate is not trusted by your PC. The browser may allow you to install the certificate, thus skipping the warning box the next time you connect to the device. If you are using Windows Internet Explorer, click **View Certificate**, and then **Install Certificate**. The browser also warns you if the host name used in the URL is not identical to the one listed in the certificate. To resolve this, add the IP address and host name (ACL_nnnnnn, where *nnnnnn* is the serial number of the device) to your hosts file, located at `/etc/hosts` on UNIX or `C:\Windows\System32\Drivers\ETC\hosts` on Windows; then use the host name in the URL (e.g., `https://ACL_280152`). Below is an example of a host file:

```
127.0.0.1 localhost
10.31.4.47 ACL_280152
```




22.3 Web Interface Overview

The device's Web interface displays status information of the device. The following information is displayed in the device's Web interface:

- **Monitor:** This screen is displayed by default when logging into the device's Web interface. It displays the device's basic details including its IP address, Firmware version and Serial Number. This view displays the LED statuses of the device's components that are represented on the device's Front Panel. In addition, a separate pane displays call data statistics for the SBC application.

Figure 22-9: Monitor



- **Device Information:** This screen displays general information on device components such as the firmware version, MAC addresses, serial numbers, flash/RAM/CPU details.

Figure 22-10: Device Information

The screenshot shows the 'Device Information' screen. On the left is a sidebar with a 'MONITOR' header and several expandable sections: 'DEVICE INFORMATION' (expanded), 'LAN', 'LAN GUEST', 'WAN', 'WAN BACKUP', 'VOICE', 'ADVANCED', and 'TROUBLESHOOTING'. The main content area is titled 'Device Information' and contains two panels: 'GENERAL SETTINGS' and 'VERSIONS'.

GENERAL SETTINGS		VERSIONS	
VoIP MAC Address	00:90:8F:CD:19:16	Version ID	7.26A.356.041
WAN MAC Address	00:90:8F:CD:19:17	DSP Software Version	72307
Serial Number	13441302	DSP Software Name	5011AE3_R
Board Type	M500Li		
Device Up Time	0d:0h:19m:44.17s		
Flash Size	512 Mb		
RAM Size	438 Mb		
CPU Speed	800 MHz		

- **LAN Interface:** This screen displays the details of the configured LAN interface. This screen also allows users to configure the device's IP address.

Figure 22-11: LAN interface


The screenshot shows the 'LAN Interface' screen. The sidebar is identical to the previous figure, with 'LAN' expanded and 'LAN Interface' selected. The main content area is titled 'LAN Interface' and contains three panels: 'INTERFACE INFORMATION', 'LAN INTERFACES SETTINGS', and 'PERFORMANCE MONITORING'.

INTERFACE INFORMATION		LAN INTERFACES SETTINGS	
Name	BVI 2	IP Address	<input type="text"/>
Type	LAN	Subnet Mask	<input type="text"/>
Description	Bridge 2		
Status	Disabled		
State Time	00:20:06		
Primary DNS Server IP Address			
Secondary DNS Server IP Address			

PERFORMANCE MONITORING		DHCP SETTINGS	
15 Seconds Input Rate	0 bps	DHCP Server	Disable
15 Seconds Output Rate	0 bps		
5 Minutes Input Rate	0 bps		
5 Minutes Output Rate	0 bps		

- **LAN Ports:** This screen displays LAN port information. This sub-menu is only displayed under the **LAN** folder.


Figure 22-12: LAN Ports



NAME	DESCRIPTION	STATUS	PORT MODE	SPEED	DUPLEX MODE
GigabitEthernet 1/1		UP	FORWARDING	1Gbps	FULL
GigabitEthernet 1/2		Down	FORWARDING		
GigabitEthernet 1/3		Down	FORWARDING		
GigabitEthernet 1/4		Down	FORWARDING		

- **Wi-Fi:** This screen displays the details of the Wi-Fi interface and enables user to enable and disable the interface. This screen is displayed if BVI is assigned to LAN or LAN guest, and Wi-Fi is assigned to this BVI using a bridge-group command.

Figure 22-13: Wi-Fi Interface



MONITOR
DEVICE INFORMATION
LAN
LAN Interface
LAN Ports
Wi-Fi
DHCP Settings
DHCP Clients
LAN GUEST
LAN Interface
DHCP Settings
DHCP Clients
WAN
WAN BACKUP
ADVANCED
TROUBLESHOOTING

Wi-Fi Interface

Wi-Fi STATUS

Name	dot11radio 1
Description	LAN Wireless 802.11n Access Point
Status	Disabled
State Time	16:19:27
Channel	Automatic
Connected Clients	0

Wi-Fi SETTINGS

Enable Wi-Fi Interface	Disable
------------------------	---------

PERFORMANCE MONITORING

15 Seconds Input Rate	0 bps
15 Seconds Output Rate	0 bps
5 Minutes Input Rate	0 bps
5 Minutes Output Rate	0 bps

APPLY

- **DHCP Settings and DHCP Clients:** These screens display details of the DHCP client and server. Users can also enable and disable the DHCP server. These screens are displayed under both **LAN** and **LAN GUEST** folders.

Figure 22-14: DHCP Settings

MONITOR

- DEVICE INFORMATION
- LAN
- LAN Interface
- LAN Ports
- DHCP Clients
- DHCP Clients Reservation
- LAN GUEST
- WAN
- WAN Interface
- WAN BACKUP
- VOICE
- ADVANCED
- TROUBLESHOOTING

LAN Interface

Type: LAN
Description: Bridge 2
Status: Disabled
State Time: 00:22:10
Primary DNS Server IP Address
Secondary DNS Server IP Address

PERFORMANCE MONITORING

15 Seconds Input Rate	0 bps
15 Seconds Output Rate	0 bps
5 Minutes Input Rate	0 bps
5 Minutes Output Rate	0 bps

DHCP SETTINGS

DHCP Server: Enable
First IP Pool Address: 0.0.0.0
Last IP Pool Address: 0.0.0.0
IP Pool Subnet Mask: 0.0.0.0
Primary DNS Server IP Address: 0.0.0.0
Secondary DNS Server IP Address: 0.0.0.0
Client Lease Time [Minutes]: 60

Figure 22-15: DHCP Client

MONITOR

- DEVICE INFORMATION
- LAN
- LAN Interface
- LAN Ports
- DHCP Clients
- DHCP Clients Reservation
- LAN GUEST
- WAN
- WAN Interface
- WAN BACKUP
- VOICE
- ADVANCED
- TROUBLESHOOTING

DHCP Clients

CLIENT HOSTNAME	IP ADDRESS	MAC	LEASE EXPIRATION [MINUTES]
dhcp-host	192.168.0.3	38:f3:ab:f4:42:32	47
il-rois-ip	192.168.0.3	38:f3:ab:f4:42:32	75

- **WAN:** This screen displays details of the WAN interface. If logical interface, for example if PPPoE 1 is assigned to WAN, and the PPPoE 1 has the configuration "underlying GigabitEthernet 0/0.3 ", the sub-menu WAN Interface displays the highest interface (PPPoE 1) under the Interface Information section, and the lowest interface, in this case GigabitEthernet 0/0, under the Physical Interface Information section.

Figure 22-16: WAN Interface

MONITOR

- DEVICE INFORMATION
- LAN
 - LAN Interface
 - LAN Ports
 - Wi-Fi
 - DHCP Settings
 - DHCP Clients
- LAN GUEST
- WAN
 - WAN Interface**
 - WAN BACKUP
 - WAN Backup Interface
- ADVANCED

WAN DSL

PHYSICAL INTERFACE INFORMATION

Type
DSL
DSL Status
Disconnected
Line Termination
CPE, Annex A
Administrative Status
No Shutdown
Line State
0x200 (Silent)
Vectoring
Off
Downstream Actual Rate
Downstream Max Rate
Upstream Actual Rate
Upstream Max Rate
Performance Monitoring
15 Seconds Input Rate 0 bps

INTERFACE INFORMATION

Name
PPPOE 1
Description
PPPoE connection 1
Status
Enabled
State Time
IP Address
Subnet Mask
Primary DNS Server IP Address
Secondary DNS Server IP Address


PPPOE SETTINGS

PPPoE Username
PPPoE Password

APPLY

- **WAN Backup:** This screen displays the details of the WAN Backup interface.
In case the PPPoE interface is assigned to an EFM interface, the lowest interface will be DSL as shown in Figure 22-16:

Figure 22-17: WAN Backup Interface



- **Port Forwarding** configuration is displayed under the **Advanced** folder. Users can configure port forwarding rules.
- **Routing status** is displayed under the **Advanced** folder and displays all configured device routing tables.

This page is intentionally left blank.

International Headquarters

1 Hayarden Street,
Airport City
Lod 7019900, Israel
Tel: +972-3-976-4000
Fax: +972-3-976-4040

AudioCodes Inc.

80 Kingsbridge Rd
Piscataway, NJ 08854, USA
Tel: +1-732-469-0880
Fax: +1-732-469-2298

Contact us: <https://www.audiocodes.com/corporate/offices-worldwide>

Website: <https://www.audiocodes.com>

©2023 AudioCodes Ltd. All rights reserved. AudioCodes, AC, HD VoIP, HD VoIP Sounds Better, IPmedia, Mediant, MediaPack, What's Inside Matters, OSN, SmartTAP, User Management Pack, VMAS, VoIPerfect, VoIPerfectHD, Your Gateway To VoIP, 3GX, VocaNom, AudioCodes One Voice, AudioCodes Meeting Insights, and AudioCodes Room Experience are trademarks or registered trademarks of AudioCodes Limited. All other products or trademarks are property of their respective owners. Product specifications are subject to change without notice.

Document #: LTRT-31787

