Quick Setup Guide

AudioCodes MediaPack[™] Family

Connecting AudioCodes MP-1288 High-Density Analog Gateway to BroadCloud Hosted UC

Version 7.2.100





Table of Contents

1	Intro	troduction5			
	1.1	Component Information			
		1.1.1 AudioCodes Gateway Version	.5		
		1.1.2 BroadCloud Hosted UC Version	.5		
		1.1.3 Solution Topology	.6		
2	Insta	alling the Hardware	.7		
	2.1	Front Panel	.7		
		2.1.1 LED Descriptions	.7		
		2.1.1.1 SYS LED	.7		
		2.1.1.2 TEL LED	.8		
		2.1.1.3 PWR LED	.ठ. 8		
	22	Rear Panel	.0 .9		
		2.2.1 LED Descriptions	10		
		2.2.1.1 Ethernet LEDs	10		
		2.2.1.2 STAT LED	10		
		2.2.1.3 FXS LEDS	11 11		
	23		12		
	2.0	2.3.1 Connecting Ethernet Interfaces	12		
		2.3.2 Connecting FXS Interfaces	12		
		2.3.3 Connecting FXS Interfaces using AudioCodes FXS Patch Panel	15		
		2.3.4 Connecting FXS Interfaces using Centronics Cable	18		
	24	2.3.5 Connecting FAS interfaces Directly to an MDF	19		
	2.4				
3	Con	necting to the Management Interface2	:3		
	3.1	Default OAMP IP Address			
	3.2	Connecting to the Embedded Web Server	23		
		3.2.1 Change Default Management User Login Passwords	24		
4	Con	figuring the Device2	27		
	4.1	Step 1: Download, Install BroadCloud Certified Firmware / Configuration	27		
	4.2	Step 2: Configure a Network Interface for the Device	31		
		4.2.1 Step 2a: Configure the Local DMZ IP Address of the Gateway	32		
		4.2.2 Step 2b: Configure NAT	33		
	4.3	Step 3: Configure Registration to the BroadCloud Service	34		
		4.3.1 Configure Credentials	34		
		4.3.2 Configure the SIP Register Domain Name	35		
	4.4	Step 4: Configure Trunk Group Parameters	57		
	4.5	Step 5: Check the SIP Registration Status	88		
	4.0	Step 6: Secure Device Access	59		
	47	4.0.1 Secure Management Access	10		
	4.7		rU		
Α	Trou	Ibleshooting4	1		
	A.1	Connecting to CLI4	11		
	A.2	Enabling Logging on CLI4	11		

Notice

This Quick Setup Guide shows how to connect the AudioCodes' MP-1288 High-Density Analog Media Gateway to the BroadCloud Hosted Unified Communications (UC) service.

Information contained in this document is believed to be accurate and reliable at the time of printing. However, due to ongoing product improvements and revisions, AudioCodes cannot guarantee accuracy of printed material after the Date Published, nor can it accept responsibility for errors or omissions. Updates to this document and other documents as files well as software can be viewed by registered customers at http://www.audiocodes.com/downloads.

This document is subject to change without notice.

Date Published: Mar-07-2017

1 Introduction

This guide shows how to set up AudioCodes' MP-1288 High-Density Analog Media Gateway to interoperate with the BroadCloud Hosted Unified Communications (UC) service.

1.1 Component Information

1.1.1 AudioCodes Gateway Version

Table 1-1: AudioCodes Gateway Version

SBC Vendor	AudioCodes
Models	 MP-1288
Software Version	 F7.20A.100.025 and later
Protocol	 SIP/UDP (to the BroadCloud Hosted UC service)

1.1.2 BroadCloud Hosted UC Version

Table 1-2: BroadCloud Version

Vendor/Service Provider	BroadSoft
SSW Model/Service	BroadWorks
Software Version	21.SP1
Protocol	SIP

1.1.3 Solution Topology

Interoperability between AudioCodes' MP-1288 High-Density Analog Media Gateway and the BroadCloud Hosted UC was achieved using the following topology setup:

- AudioCodes MP-1288 Gateway device, connecting the enterprise's FXS extensions to the BroadCloud Hosted UC service over IP
- Internet/MPLS network connectivity to the BroadCloud Hosted UC service



Figure 1-1: BroadCloud Hosted UC Solution Topology

2 Installing the Hardware

2.1 Front Panel

The device's front panel is shown in the figure below and described in the subsequent table.





Table 2-1: Front Panel Description

Item #	Label	Description
1	-	Fan Tray cover.
2	SYS / TEL / PWR / FAN	Front-panel LEDs.

2.1.1 LED Descriptions

This section describes the LEDs on the front panel of the chassis.

2.1.1.1 SYS LED

The SYS LED indicates the device's operating status, as described in the table below.

Table 2-2: SYS LED Description

Color	State	Description
Green	On	LED lit as a result of one of the following:Device is operating normallyDuring first stage of boot up when device is powered on
Orange	On	Chassis is approaching high temperature threshold, but it's not yet critical
Red	On	 LED lit as a result of one of the following: Fault detected in CPU module Incompatible or faulty software version (.cmp file) detected during boot up Approaching critical high temperature threshold
	Off	No power

2.1.1.2 TEL LED

The **TEL** LED indicates the status of the FXS blades, as described in the table below.

Color	State	Description
Green	On	 LED lit as a result of one of the following: During booting up phase During normal operation, indicating normal FXS blade operation
Orange		At least one DSP has reached the high temperature threshold
Red	On	 LED lit as a result of one of the following: During initial phase of power-up Failure detected in at least one FXS blade No FXS blades detected in the chassis
-	Off	No power.

Table 2-3: TEL LED Description

2.1.1.3 PWR LED

The **PWR** LED indicates the power status, as described in the table below.

Table 2-4: PWR LED Description

Color	State	Description
Green	On	Chassis receiving power and Power Supply modules are functioning normally. If the device is configured to use only one Power Supply module, the LED is lit if at least one of them is operating normally.
Red	On	One of the Power Supply modules is faulty (if device is configured to use two Power Supply modules).
-	Off	No power received by the device.

2.1.1.4 FAN LED

The **FAN** LED indicates the status of the Fan Tray module, as described in the table below.

Table 2-5: FAN LED Description

Color	State	Description
Green	On	Fans are functioning normally.
Red	On	At least one fan in the Fan Tray module is faulty.
-	Off	No power.

2.2 Rear Panel

The device's rear panel is shown in the figure below and described in the subsequent table.

Figure 2-2: Rear Panel Description



Note: The figure above is used only as an example. The number of installed FXS blades and Power Supply modules depends on your ordered hardware configuration.

Table 2	-6: Rear	Panel	Description

Item #	Label	Description
1	CPU	CPU module providing the central processing unit and various network port interfaces.
2	PS1 / PS2	Power Supply modules.
3	Blades: S1 / S2 / S3 / S4 FXS Ports: FXS 1-24 / FXS 25-48 / FXS 49-72	FXS blades providing FXS port interfaces.
4	Ţ	Protective grounding for connecting a grounding lug for chassis ground connection for ESD-preventive equipment or a grounding wire.

2.2.1 LED Descriptions

This section describes the LEDs on the rear panel of the chassis.

2.2.1.1 Ethernet LEDs

Each Ethernet port on the CPU module provides a LED (located on its left) which indicates network connectivity status, as described in the table below.

Color	State	Description
Green	On	Ethernet link established.
	Flashing	Data is being received or transmitted.
-	Off	No Ethernet link.

Table 2-7: Ethernet LEDs Description

2.2.1.2 STAT LED

The **STAT** LED on the CPU module indicates the operating status of the CPU module, as described in the table below.

Color	State	Description
Green	On	LED lit as a result of one of the following:Device is operating normallyDuring first stage of boot up when device is powered on
Orange	On	Chassis is approaching high temperature threshold, but it's not yet critical
Red	On	 LED lit as a result of one of the following: Fault detected in CPU module Incompatible or faulty software version (.cmp file) detected during boot up Approaching critical high temperature threshold
-	Off	No power.

Table 2-8: STAT LED Description

2.2.1.3 FXS LEDs

Color	State	Description
Green	On	FXS blade initialization completed and is functioning normally.
Orange	On	Some FXS ports (less than a third) are out of service.
Red	On	FXS blade initialization has not completed or a failure is detected in the FXS blade due to any of the following:Multiple FXS ports (more than a third) are out of service
		DSP failure
-	Off	No power.

Table 2-9: FXS LEDs Description

2.2.1.4 Power Supply LED

The Power Supply module, located on the chassis rear panel, provides a LED which indicates the operating status of the module, as described in the table below.

Color	State	Description
Green	On	Connected to power source, chassis receiving power, and Power Supply module's fan operating normally.
Amber	Flashing	Connected to power source but chassis not receiving power or fault detected in Power Supply module's fan. If the chassis houses two Power Supply modules but only one of them is connected to the power source, the LED on the Power
		Supply module that is not connected flashes amber.
-	Off	No power received from power source.

Table 2-10: Power Supply Module LED Description

2.3 Cabling

2.3.1 Connecting Ethernet Interfaces

The device provides two 100/1000Base-T Gigabit Ethernet ports (RJ-45) for connecting to the IP network (e.g., LAN). The ports support half- and full-duplex modes, auto-negotiation, and straight or crossover cable detection.

The ports can operate as a pair (*Ethernet Group*) to provide 1+1 port redundancy, where one port serves as the active port while the other as standby. When the active port fails, the device switches to the standby port.

The cabling specifications and procedure for connecting the device to the LAN is as follows:

- **Cable:** Straight-through, Category (Cat) 5, 5e or 6 cable
- **Connector:** Standard RJ-45

> To connect the Ethernet interfaces:

1. Connect the RJ-45 connector, at one end of a straight-through Cat 5e or Cat 6 cable,

to one of the Ethernet ports (labeled 🚰 🖬) on the CPU module located on the chassis' rear panel, as shown below:





- 2. Connect the other end of the cable to your network.
- **3.** For 1+1 Ethernet port redundancy, repeat steps 1 through 2 for the standby port. Make sure that you connect each port to a different network (but in the same subnet).

2.3.2 Connecting FXS Interfaces

The device interfaces with the FXS analog telephone equipment (e.g., fax machines, modems, or telephones) through the 50-pin Telco connectors provided on the FXS blades.



Safety Notice

- Make sure that the FXS ports are connected to the appropriate, external devices; otherwise, damage to the device may occur.
- FXS ports are considered TNV-2.

FXS Outdoor Cabling and Power Surge Protection

The device includes an integrated secondary surge protection but excludes primary telecom protection! When the FXS telephone lines are routed outside the building, additional protection - usually a 350V three-electrode Gas Discharge Tube (GDT) as described in ITU-T K.44 - must be provided at the entry point of the telecom wires into the building (usually on the main distribution frame / MDF), in conjunction with proper grounding. The center pin of the GDT (MDF grounding bar) must be connected to the equipotential grounding bus bar of the telecommunications room.



- Failing to install primary surge protectors and failing to comply with the grounding instructions or any other installation instructions, may cause permanent damage to the device!
- As most of the installation is the responsibility of the customer, AudioCodes can assume responsibility for damage only if the customer can establish that the device does not comply with the standards specified above (and the device is within the hardware warranty period).
- The device complies with protection levels as required by EN 55024/EN 300386. Higher levels of surges may cause damage to the device.
- To protect against electrical shock and fire, use a minimum of 26-AWG wire size to connect the FXS ports.



Note: To configure the current (mA) that the device supplies to the FXS ports in off-hook state, use the 'EnhancedFXSLineCurrent' parameter. Configuration is applicable only to the first and last ports (e.g., 1 and 24) on each FXS connector. For more information, refer to the *User's Manual*.

AudioCodes

The FXS cabling specifications include the following:

- **Cable:** You can use any of the following cables:
 - AudioCodes orderable FXS Patch Panel
 - AudioCodes orderable Centronics cable connector (10 m) to open leads, which needs to be connected to a distribution panel
 - Third-party, main distribution frame (MDF) connector
- **Connector Type:** 50-pin Telco



Connector Pinouts:

Table 2-11: 50-pin Telco Connector Pinouts

FXS Phone Channel (Ports)	Connector Pins
1	1/26
2	2/27
3	3/28
4	4/29
5	5/30
6	6/31
7	7/32
8	8/33
9	9/34
10	10/35
11	11/36
12	12/37
13	13/38
14	14/39
15	15/40
16	16/41
17	17/42
18	18/43
19	19/44
20	20/45
21	21/46
22	22/47

FXS Phone Channel (Ports)	Connector Pins
23	23/48
24	24/49
25 for Analog Lifeline	25/50

2.3.3 Connecting FXS Interfaces using AudioCodes FXS Patch Panel

You can purchase AudioCodes' FXS Patch Panel, as shown below, to connect the FXS interfaces to FXS equipment. The Patch Panel can be mounted in a 19-inch rack using integrated mounting brackets and provides a 2-meter (78.7 in.) extension cable with a 50-pin male connector for connection to the FXS port on the FXS blade. All incoming wires from the 50-pin Telco connector are terminated to the back of the Patch Panel. The FXS endpoints (e.g., telephones) can be plugged into the corresponding RJ-11 jacks on the front of the Patch Panel.







> To connect the FXS interfaces using the FXS Patch Panel:

1. Mount the Patch Panel in a 19-inch rack, using the integrated mounting brackets located on either side of the Patch Panel. Use four 19-inch rack bolts (not supplied) to securely attach the brackets to the front-rack posts. Make sure that the left and right mounting brackets are attached to the rack posts at the same level so that the Patch Panel is supported in a horizontal position.





2. Connect the Patch Panel's 50-pin male connector to one of the FXS blade's 50-pin female Telco connectors located on the chassis' rear panel, and secure the connector with the two captive screws located on either side of the connector, using a flat-head screwdriver:





3. Connect your analog equipment to the Patch Panel by plugging the RJ-11 connectors into the RJ-11 sockets on the Patch Panel's front panel:



Figure 2-8: Connecting Analog Equipment to FXS Patch Panel

FXS Ports

For **outdoor FXS cabling installations**, you **must** install additional power surge protection as illustrated in the following figure. For indoor FXS cabling installations, there is no need for primary lightning protection usage.





2.3.4 Connecting FXS Interfaces using Centronics Cable

You can purchase AudioCodes' Centronics-type cable connector, as shown below, to connect the FXS interfaces to FXS equipment. The 10-meter (32.8 ft.) cable provides a 50-pin male Telco connector on one end and open leads on the other end, which need to be connected to your Patch Panel or distribution frame.





> To connect the FXS interfaces using the Centronics cable:

 Connect the 50-pin male connector on end of the cable to one of the FXS blade's 50pin female Telco connectors located on the chassis' rear panel, and secure the connector with the two captive screws located on either side of the connector, using a Phillips screwdriver:



Figure 2-11: Connecting 50-Pin Telco Connector to Port on FXS Blade

- 2. Terminate the wires on the other end of the cable to your Patch Panel or distribution frame. The wires are grouped in pairs with labels indicating the FXS channels (see Figure 2-10). Make sure that you connect the wires according to the correct port channels as labelled on the wires.
- **3.** Connect your analog equipment to your Patch Panel or distribution frame by plugging their RJ-11 connectors into the RJ-11 sockets on the Patch Panel or distribution frame.

2.3.5 Connecting FXS Interfaces Directly to an MDF

If you are using your own third-party MDF, follow the instructions below.



Warning: To reduce noise interference, use a twisted pair Octopus cable that is terminated on a metal-hooded 50-pin Telco connector.

> To connect FXS interfaces directly to an MDF:

- 1. Wire the 50-pin Telco connectors according to the pinouts in Table 2-11.
- 2. Connect the wire-pairs at the other end of the cable to a 50-pin male Telco connector (not supplied).
- 3. Attach the male connector to one of the FXS blade's 50-pin female Telco connectors, located on the chassis' rear panel.
- 4. Attach each pair of wires from a 25-pair Octopus cable (not supplied) to its corresponding socket on the MDF.
- 5. Connect the telephone lines from the MDF to the analog equipment, by inserting each RJ-11 connector on the 2-wire line cords to the RJ-11 sockets on the front of the MDF:







2.4 Connecting to Power

The device receives power from a standard alternating current (AC) electrical outlet. The connection is made using the supplied AC power cord. The device can host up to two hot-swappable Power Supply modules for load-sharing and power redundancy in case of failure in one of the modules.

Physical Specification	Value			
Input Voltage	Dual universal AC power supply 100-240V~			
AC Input Frequency	50/60 Hz			
Max. AC Input Current	10 A			
Max. Power Consumption	FXS Interfaces	Short Haul (W)	Long Haul (W)	
	288	450	950	
	216	400	770	
	144	350	600	

Table 2-12: Power Specifications



Note: If you are using two Power Supply modules, connect each one to a different AC power supply source. The two AC power sources must have the same ground potential.

> To connect the device to power:

1. Swing the cable anchor clip, located over the power inlet of the Power Supply module, sideways, away from the power inlet to provide space for the power plug.

Figure 2-13: Swinging Cable Anchor Clip away from Power Inlet



2. Plug the female end of the AC power cord (supplied) into the power inlet.

Figure 2-14: Connecting to Power



3. Secure the power cord to the power inlet by providing strain relief, using the cable anchor clip. Slide the cable anchor clip sideways, towards the power inlet and then push the power cord into the cable anchor clip, as shown in the figure below. This protects the plug from accidentally being pulled out.

Figure 2-15: Strain Relief for Power Cord using Cable Anchor Clip





Note: Strain relief for the power cord using the cable anchor clip is not mandatory.

- 4. Connect the male end of the power cord to a standard AC electrical outlet.
- 5. If you are using two Power Supply modules, repeat steps 1 through 3 for connecting the second Power Supply module, but using the power socket associated with the second Power Supply module and connecting this to a different supply circuit.
- **6.** Turn on the power at the power source (if required).
- 7. Check that the LED on each Power Supply module (front panel) is lit green, indicating that the device is receiving power.

3 Connecting to the Management Interface

This section shows how to connect to the device's management interface for the first time.

3.1 Default OAMP IP Address

The device is shipped with a factory default IP address for operations, administration, maintenance, and provisioning (OAMP), through its VoIP LAN interface. Use this address to initially access the device's embedded Web server. Default IP address is:

Table 3-1: Default VoIP LAN IP Address for OAMP

IP Address	Value
IP Address	192.168.0.2
Prefix Length	255.255.255.0 (24)
Default Gateway	192.168.0.1

3.2 Connecting to the Embedded Web Server

To connect to the embedded Web server:

1. Connect one of the Ethernet ports (labeled 🚰) on the CPU module located on the chassis' rear panel directly to the network interface of your computer, using a straight-through Ethernet cable.





- 2. Change the IP address and subnet mask of your computer to correspond with the default OAMP IP address and subnet mask of the device.
- 3. Access the Web interface:
 - a. On your computer, start a Web browser and in the URL address field, enter the default IP address of the device; the Web interface's Web Login screen appears:

Figure 3-2: Web Login Screen

Web L	ogin
Username	
1	
Password	
Remember Me	Login

- **b.** In the 'Username' and 'Password' fields, enter the case-sensitive, default login username (**Admin**) and password (**Admin**).
- c. Click Login.

3.2.1 Change Default Management User Login Passwords

To secure access to the device's Web management interface, follow these recommended guidelines:

The device is shipped with a default Security Administrator access-level user account – username 'Admin' and password 'Admin'. This user has full read-write access privileges to the device. It is recommended to change the default password to a hard-to-hack string. The login username and password are configured in the Web Local Users table (Setup menu > Administration tab > Web & CLI folder > Local Users) using the 'Password' field, as shown below:

Local Users			– x
GENERAL		SECURITY	
Index	0	Password Age 0	
Username	Admin	Session Limit 2	
	• ••••	Session Timeout	5
User Level	• Security Administrator	Block Duration 60	0
Status	• Valid 🔻		
	Cancel		
	Cancel	APPET	

Figure 3: Changing Password of Default Security Administrator User

The device is shipped with a default Monitor access-level user account - username 'User' and password 'User'. This user only has read access privileges to the device. The read access privilege is also limited to certain Web pages. However, this user can view certain SIP settings such as proxy server addresses. Therefore, to prevent an attacker from obtaining sensitive SIP settings that could result in possible call theft,etc., change its default login password to a hard-to-hack string.

Local Users					- x
GENERAL			SECURITY		
Index	1		Password Age	• 0	
Username	• User		Session Limit	2	
Password	•		Session Timeout	15	
User Level	Monitor	•	Block Duration	60	
Status	 Inactivity 	•			

Figure 4: Changing Password of Default Monitor User



This page is intentionally left blank.

4 **Configuring the Device**

This section shows how to configure the device to interwork with the BroadCloud Hosted UC, based on the solution test topology shown in Section 1.1.3 which includes these areas:

- BroadCloud WAN interface BroadCloud Hosted UC environment
- BroadCloud TDM interface FXS ports

Configuration is performed using the device's embedded Web server (Web interface).

4.1 Step 1: Download, Install BroadCloud Certified Firmware / Configuration

This section shows how to download the certified BroadCloud firmware and configuration.

- > To download the certified BroadCloud firmware and configuration:
- 1. Open a web browser, go to http://www.audiocodes.com/broadcloud-resource-center
- 2. Download the zip file associated with your device, unzip the package, and save the enclosed configuration_xxxx.ini file and firmware_xxx.cmp file to your local drive.
- **3.** Download the Call Progress Tones file suitable for your country call_progress_xxxxx.dat ('xxxxx' being the country name).
- 4. Enter the device's Software Upgrade Wizard.
- To load files using the Software Upgrade Wizard:
- 1. Open the Software Upgrade Wizard:
 - Select the Maintenance tab, click the Software Update menu, and then click Software Upgrade Wizard -or-
 - On the toolbar, click **Actions** and then choose **Software Upgrade**.

Figure 4-1: Start Software Upgrade Wizard Screen

AudioCodes	SETUP MONITOR TROUBLESHOOT Save Reset Actions •
IP NETWORK SIGNALING & MEDIA	ADMINISTRATION Q Entity, parameter, value
♦ ↔ SRD All ▼	
TIME & DATE WEB & CLI SNMP	Software Upgrade
▲ MAINTENANCE Configuration File Auxiliary Files Maintenance Actions License Key Software Upgrade	Warning: In case of an upgrade failure, the device will reset and the previous configuration saved to flash will be restored.

2. Click Start Software Upgrade; the wizard starts, prompting you to load a .cmp file:

🔁 Software Upgrade Wizard - Google Chrome			
① 10.15.77.55/SoftwareUpdateIndex			
CMP file	Load a CMP file from your computer to the device.		
INI file	Choose File No file chosen		
CPT file	complete the upgrade process.		
PRT file	Load File		
CAS file			
USRINF file			
AMD file			
FINISH			
	Back Next Cancel Reset		

Figure 4-2: Software Upgrade Wizard - Load CMP File



Note: At this stage, you can quit the wizard without needing to reset the device (click **Cancel**). But if you continue with the wizard and load the .cmp file, the upgrade process must be completed with a device reset.

- **3.** Click **Browse**, and then navigate to where the .cmp file is located on your computer. Select the file, and then click **Open**.
- 4. Click Load File; the device installs the .cmp file. A progress bar displays the loading process status and a message informs you when file load successfully completes.



Figure 4-3: Software Upgrade Wizard – CMP File Loading Progress Bar

- **5.** Select the following upgrade option:
 - System Reset Upgrade
- 6. Press the **Next** button to navigate through the wizard.
- 7. In the wizard page for loading an ini file:
 - **Deselect** the 'Use existing configuration' option
 - Load File: In the 'Ini File' field, click Browse, and then navigate to where the ini file is located on your computer. Select the file, and then click Load File; the device loads the ini file.

Figure 4-4: Software Upgrade Wizard – Load INI File

Load an <i>ini</i> file from your computer to the device. Browse No file selected.
Load File
Warning: 1. If you choose to load an ini file, parameters that are omitted from the file, revert to default settings. Therefore, make sure that the ini file contains all required configuration (e.g. IP networking parameters). 2. The device restores to factory default settings if you clear the Use Existing Configuration check box and don't select a file to load.
Back Next Cancel Reset

8. Press the **Next** button to navigate to the Call Progress Tones (CPT) wizard page.

BroadCloud Hosted UC

AudioCodes

- 9. In the wizard page for loading the Call Progress Tones (CPT) file, click Browse, and then navigate to where the call_progress_xxxx.dat ('xxxxx' being the country name) file is located on your computer. Select it and click Load File; the device loads the tones file.
- **10.** Click **Next** until the last wizard page appears (the **FINISH** button is highlighted in the left pane).
- **11.** Click **Reset** to burn the files to the device's flash memory; the 'Burn and reset in progress' message is displayed and the device 'burns' the newly loaded files to flash memory and then resets.



Note: Reset may take a few minutes (even up to 30) depending on the .cmp file version.

When the device finishes the installation process and resets, the following wizard page is displayed, showing the installed software version and other files (ini file and auxiliary files) that you may also have installed:

I Progress Tone File Name: usa_tones_13.d I Plan File Name: dialplan.dat er Info File Name: UIF_SBC.txt	CMP Version ID:	7.10A.045.006
I Plan File Name: dialplan.dat er Info File Name: UIF_SBC.txt	Call Progress Tone File Name:	usa_tones_13.dat
er Info File Name: UIF_SBC.txt	Dial Plan File Name:	dialplan.dat
	User Info File Name:	UIF_SBC.txt
End Process	End Proc	ess

Figure 4-5: Software Upgrade Process Completed Successfully (Example)

- 12. Click End Process to close the wizard; Web Login is displayed.
- **13.** Enter your login username and password (**Admin**, **Admin** respectively), and then click **Login**; a message box appears informing you of the new .cmp file version.
- 14. Click **OK**; the Web interface becomes active, reflecting the upgraded device.

4.2 Step 2: Configure a Network Interface for the Device

This section describes typical physical Ethernet port connections of the deployed device. The device is connected to the BroadCloud Hosted UC network with a 'local-DMZ-IP Address' behind a NAT. The firewall is configured with the following rules (for example):



a. Firewall allow rule:

	Original			Translated			
	Source	Destination	Ports/Service	Source	Destination	Ports/Service	
1	<any> (e.g. ITSP)</any>	Global IP Address (public address)	SIP service: 5060 / UDP RTP service: 6000-7000 / UDP	<any> (e.g. ITSP)</any>	Local-DMZ- IP-Address	<as original=""></as>	

	 b. NAT rules (port forwarding): 								
	Source	Destination	Ports/Service	Source	Destination	Ports/Service			
1	<any> (e.g. ITSP)</any>	Global IP Address (public address)	SIP service: 5060 / UDP RTP service: 6000-7000 / UDP	<any> (e.g. ITSP)</any>	Local-DMZ- IP-Address	<as original=""></as>			
1	Local-DMZ- IP-Address	<any> (e.g. ITSP)</any>	SIP service: 5060 / UDP RTP service: 6000-7000 / UDP	Global IP Address (public address)	<any> (e.g. ITSP)</any>	<as original=""></as>			

4.2.1 Step 2a: Configure the Local DMZ IP Address of the Gateway

- > To configure the IP network interface:
- Open the IP Interfaces table (Setup menu > IP Network tab > Core Entities folder > IP Interfaces).
- 2. Modify the existing network interface:
 - a. Select the 'Index' radio button of the OAMP + Media + Control table row, and then click Edit.
 - **b.** Configure the interface as follows:

Parameter	Value
Name	"Voice" (arbitrary descriptive name)
Ethernet Device	vlan 1
IP Address	Local-DMZ-IP-Address
Prefix Length	Subnet mask in bits
Default Gateway	Default Gateway
Primary DNS Server IP Address	IP address of the DNS Server

3. Click Apply.



Note: The change only takes effect after you save your settings by resetting the device with a flash burn. This only occurs at the end of the configuration process.

The figure below shows an example of a configured IP network interface.

Figure 4-6: Example of a Configured Network Interface in IP Interfaces Table

AudioCodes	SETUP MONI	TOR TROUB	LESHOOT				Save	Reset	Actions •	🕂 🛛 Admin 🔻
IP NETWORK SIGNALING & MEDIA	ADMINISTRATION								D Entity, p	arameter, value
SRD All										
NETWORK VIEW CORE ENTITIES	IP Inte	erfaces (1) .		Page	E of 1 N	Show 10 V	erords per page			0
IP Interfaces (1) Ethernet Devices (1)	INDEX 🗢	NAME	APPLICATION TYPE	INTERFACE MODE	IP ADDRESS	PREFIX	DEFAULT GATEWAY	PRIMARY DNS	SECONDARY DNS	ETHERNET DEVICE
Physical Ports (2) Static Routes (0) NAT Translation (0)	0	Voice	OAMP + Media +	IPv4 Manual	10.8.7.1	16	10.8.0.1	0.0.00	0.0.00	vian 1

4.2.2 Step 2b: Configure NAT



Note: Do not configure this setting if you are not behind a firewall NAT.



Note: The 'NAT IP Address' is the Global-IP-address used in front of the firewall facing the BroadCloud service. If the DMZ holds the global-IP-address (no NAT is performed by the firewall) and the gateway is already assigned with the global-IP-address as its 'local DMZ IP address', skip NAT configuration.

> Define NAT address on the gateway device:

 Open the Gateway General Settings page (Setup menu > Signaling & Media tab > Gateway folder > Gateway General Settings).

Figure 4-7: Configuring Static NAT IP Address

NAT IP Address 0.0	.0.0.0	۶

- 2. In the 'NAT IP Address' field, enter the NAT IP address in dotted-decimal notation.
- 3. Click Apply.

4.3 Step 3: Configure Registration to the BroadCloud Service

4.3.1 Configure Credentials

This step shows how to configure the SIP Proxy and Registration parameters, including configuring a Proxy Name, Registrar Name, DNS query for the BroadCloud Proxy Set, Registration and Subscription modes.

- > To configure the SIP Proxy & Registration parameters:
- Open the Proxy & Registration page (Setup menu > Signaling & Media tab > SIP Definitions folder > Proxy & Registration). Configure parameters according to following table:

Parameter	Value
Proxy Name	BroadCloud Register Domain . The BroadCloud Register Domain is found on the BroadCloud MySite Device Management Page under the 'Configuration Settings' section.
Registrar Name	BroadCloud Register Domain . The BroadCloud Register Domain is found on the BroadCloud MySite Device Management Page under the 'Configuration Settings' section.
Serving IP Group	BroadCloud
Username	BroadCloud SIP User. The BroadCloud SIP User value is found on the BroadCloud MySite Device Management Page under the 'Configuration Settings' section.
Password	BroadCloud SIP Password . The BroadCloud SIP Password value is found on the BroadCloud MySite Device Management Page under the 'Configuration Settings' section.

2. Click Apply.

AudioCodes	MONITOR TROUBLESHOOT			Save F	Reset Actions	• 🗸	A
ETWORK SIGNALING & MEDIA ADM	INISTRATION				וס	ntity, parameter, v	val
I SRD All							
TOPOLOGY VIEW	Proxy & Registration						
CORE ENTITIES							
GATEWAY	GENERAL			GATEWAY PROXY			
MEDIA	Redundancy Mode	Parking	٣	Use Default Proxy	Use P	оху 🔻	
	Proxy IP List Refresh Time	60			Proxy	et Table	
CODERS & PROFILES	Proxy DNS Query Type	A-Record	•	Proxy Name	custo	merdomain.com	
SBC	Number of RTX Before Hot-Swap	3		Prefer Routing Table	Yes	*	
SIP DEFINITIONS	Use Proxy IP as Host	Disable		Use Routing Table for Host Names and Pro	files Disabl	e 🔻	
Accounts (0)	Epoble Licer Information Licero	Disable	× /	Always Use Proxy	Disabl	e 🔻	
SIP Definitions General Settings		Disable	7	Enable Fallback to Routing Table	Enable		
Message Structure Transport Settings	Add Empty Authorization Header	Disable	•				
Proxy & Registration	Gateway Name						
Priority and Emergency	Use Gateway Name for OPTIONS	No	•	SEC AUTHENTICATION			
Call Setup Rules (0)	Challenge Caching Mode	None	٣	Lifetime of nonce [sec]	300		
Least Cost Routing	_			Authentication Challenge Method	0		
MESSAGE MANIPULATION	REGISTRATION			Authentication Quality of Protection	2		
INTRUSION DETECTION		100		BYE Authentication	Disable	•	
SIP RECORDING	Registration Time	180					
	Re-registration Timing [%]	50					
	Registration Retry Time	30		GATEWAT AUTHENTICATION			
	Registration Time Threshold	0		User Name	123456789		
	Re-register On INVITE Failure	Disable	٣	Password	Default_Pass	vd	
			_				

Figure 4-8: Configuring Proxy & Registration Parameters

4.3.2 Configure the SIP Register Domain Name

This section shows how to configure the SIP Register Domain Name.

- > To configure the SIP Register Domain Name:
- 1. Open the IP Groups table (Setup menu > Signaling & Media tab > Core Entities folder > IP Groups).
- 2. Edit the host name in the 'SIP Group Name' field, with the value provided by BroadCloud.

Parameter	Value
Index	0
SIP Group Name	BroadCloud Register Domain . The BroadCloud Register Domain is found on the BroadCloud MySite Device Management Page under the 'Configuration Settings' section.



	ETUP MONITOR TROUBLESHOOT	Save	Reset Action	ns 🔹 🛃 🛛 Admin 🔹
IP NETWORK SIGNALING & MEDIA	ADMINISTRATION		م	Entity, parameter, value
🔄 🄄 SRD All 💌				
CORE ENTITIES	IP Groups (1)			
Applications Enabling	+ New Edit 💼	I ← << Page 1 of 1 → ►I Show 10 ▼ records per pag	ge	Q
SRDs (1) SIP Interfaces (1) Media Realms (1)	INDEX 🗘 NAME SRD TYPE	SBC OPERATION PROXY SET IP PROFILE MEDIA MODE	SIP GROUP NAME SET	INBOUND OUTBOUN MESSAGE MESSAGE MANIPULAT MANIPULA SET SET
Proxy Sets (1)	0 Default_IPG DefaultS Server	Not Configur ProxySet_0	customerdo Disabl	-1 -1
IP Groups (1) GATEWAY				

Figure 4-9: Configured IP Group in IP Group Table

4.4 **Step 4: Configure Trunk Group Parameters**



Note: This configuration should be adopted according to each customer requirement.

This step shows how to configure the device's channels, which includes assigning them to Trunk Groups. A Trunk Group is a logical group of physical trunks and channels. A Trunk Group can include multiple trunks and ranges of channels. To enable and activate the device's channels, Trunk Groups must be configured. Channels not configured in this table are disabled. After configuring Trunk Groups, use them to route incoming IP calls to the Tel side, represented by a specific Trunk Group (ID). You can also use Trunk Groups for routing Tel calls to the IP side.

> To configure a Trunk Group:

 Open the Trunk Group table (Setup menu > Signaling & Media tab > Gateway folder > Trunks & Groups > Trunk Groups).

Add Phon			t As Prefix	Disable	•				
	Trunk Group Index		¢	1-12	•				
Group Index	Module	Channels	Phone Number	Trunk Group ID	Tel Profile Name				
1	FXS Blade 1 👻	1-72	20000		None 👻				
2	FXS Blade 2 👻	1-72	20072		None 👻				
3	FXS Blade 3 👻	1-72	20144		None 👻				
4	FXS Blade 4 👻	1-72	20216		None 👻				
5					None 👻				
6					None 👻				
7					None 👻				
8					None 👻				
9					None 👻				
10					None 👻				
11					None 👻				
12					None 👻				
	Register Un-Register								

Figure 4-10: Configuring FXS Trunk Group Table

- 2. Configure each Trunk Group as required by customer.
- 3. Click Apply.

4.5 Step 5: Check the SIP Registration Status

- > To check if the device successfully registered with BroadCloud service:
- 1. Open the Registration Status table (Monitor menu > Monitor tab > VolP Status folder > Registration Status).
- 2. Check the registration status of the first row on top: Registered Per Gateway. A successful registration will show as YES (see the figure below).

Figure 4-11: Successful SIP Registration

		Save	Reset	Actions •	4	Admin 🔻
MONITOR				🔎 Entit	y, paramete	er, value
SRD All						
MONITOR SUMMARY	Registration Status Registered Per Gateway YES					
PERFORMANCE MONITORING	Ports Registration Status					
	GATEWAY PORT	STATUS				
A VOIP STATUS	Module 1 Port 1 FXS	NOT REGISTERED				
IP to Tel Calls Count	Module 1 Port 2 FXS	NOT REGISTERED				
Tel to IP Calls Count	Module 1 Port 3 FXS	NOT REGISTERED				
SBC Registered Users	Module 1 Port 4 FXS	NOT REGISTERED				
Proxy Sets Status	Module 1 Port 5 FXS	NOT REGISTERED				
Registration Status	Module 1 Port 6 FXS	NOT REGISTERED				
IP Connectivity	Module 1 Port 7 FXS	NOT REGISTERED				
Gateway CDR History	Module 1 Port 8 FXS	NOT REGISTERED				

Note: If the status of 'Registered Per Gateway' shows NO, check your connectivity:

- Check Ethernet cable wiring.
- DMZ configuration may not be correct on the firewall.
- Check IP address configuration (Setup menu > IP Network tab > Core Entities folder > IP Interfaces).
- Check proxy (BroadCloud) configuration (Setup menu > Signaling & Media tab > SIP Definitions folder > Proxy & Registration).

4.6 Step 6: Secure Device Access

4.6.1 Secure Management Access

It's recommended that when leaving the device at the end customer's premises, its management interface will be accessible by remote only when required.

Ask the end customer's IT administrator to disable the following ports:

- Port 80 HTTP Web interface access
- Port 443 HTTPS Web interface access
- Port 22 SSH access
- Port 23 Telnet access
- Ports 161 SNMP access

If future remote management is required, first ask the end customer's IT administrator to open the appropriate port (e.g., HTTP or HTTPS port) in order to manage the device.

4.7 Step 7: Save the Configuration, Connect to DMZ



Note: Firewall settings for the DMZ must be in place before resetting the device. After the device is reset, its IP configuration is applied and it is no longer available for management via the default IP address.

> To save the configuration and reset the device:

- 1. On the toolbar, click **Reset**.
- 2. Under the 'Save To Flash', choose Yes.
- 3. Click the **Reset**.

Figure 4-12: Maintenance Actions Page

	UP MONITOR TROUBLESHOOT		Save Reset	Actions 🔹 🧘 Admin 🔹
IP NETWORK SIGNALING & MEDIA A	DMINISTRATION			<i>©</i> Entity, parameter, value
↔ ↔ SRD All ▼				
☆ TIME & DATE ▶ WEB & CLI	Maintenance Actions			
▶ SNMP	RESET DEVICE		LOCK / UNLOCK	
MAINTENANCE	Reset Device	Reset	Lock	LOCK
Configuration File Auxiliary Files	Save To Flash	Yes V	Graceful Option Gateway Operational State	No v UNLOCKED
Maintenance Actions License Key Software Upgrade	For Reset Device : If you choose not to sa all changes made since the last time the o	ve the device's configuration to flash configuration was saved will be lost a ion to flash memory may cause som	memory, fter the device is reset. e temporary degradation	
in voice quality, therefore, it is recommended to perform this during low-traffic periods				

> To connect the device to DMZ:

After the device is reset, the IP address of the device changes to the address configured in Section 4.2, Step 2. At this point, disconnect your PC from the device and connect the Ethernet cable from the device's port 1 (see Section 2) to the DMZ port provided by the local firewall:





A Troubleshooting

A.1 Connecting to CLI

Connect to the device's serial port labeled CONSOLE connecting a standard RJ-45 to DB-9 female serial cable to a PC (sold separately). Connect to the console CLI and then:

- 1. Establish a serial communication (e.g., Telnet) with the device using a terminal emulator program such as HyperTerminal, with the following communication port settings:
 - Baud Rate: 115,200 bps
 - Data Bits: 8
 - Parity: None
 - Stop Bits: 1
 - Flow Control: None
- 2. At the CLI prompt, type the username (default is **Admin** case sensitive): Username: Admin
- At the prompt, type the password (default is Admin case sensitive): Password: Admin
- 4. At the prompt, type the following: enable
- At the prompt, type the password again: Password: Admin

A.2 Enabling Logging on CLI

- **1.** To enable the device to send the error messages (e.g. Syslog messages) to the CLI console. Use the following commands:
- Start the syslog on the screen by typing: debug log
- Enable SIP call debugging debug sip 5
- Stop Syslog on the screen by typing: no debug log

International Headquarters

1 Hayarden Street, Airport City Lod 7019900, Israel Tel: +972-3-976-4000 Fax: +972-3-976-4040 27 World's Fair Drive, Somerset, NJ 08873 Tel: +1-732-469-0880 Fax: +1-732-469-2298

AudioCodes Inc.

Contact us: <u>www.audiocodes.com/contact</u> Website: <u>www.audiocodes.com</u>

©2017 AudioCodes Ltd. All rights reserved. AudioCodes, AC, HD VoIP, HD VoIP Sounds Better, IPmedia, Mediant, MediaPack, What's Inside Matters, OSN, SmartTAP, User Management Pack, VMAS, VoIPerfect, VoIPerfectHD, Your Gateway To VoIP, 3GX, VocaNom, AudioCodes One Voice and CloudBond are trademarks or registered trademarks of AudioCodes Limited. All other products or trademarks are property of their respective owners. Product specifications are subject to change without notice.

Document #: LTRT-12554



