

# Mediant 500 Gateway and E-SBC

Version 7.6



## Notice

Information contained in this document is believed to be accurate and reliable at the time of publishing. However, due to ongoing product improvements and revisions, AudioCodes cannot guarantee accuracy of published material after the Date Published nor can it accept responsibility for errors or omissions. Updates to this document can be downloaded from <https://www.audiocodes.com/library/technical-documents>.

This document is subject to change without notice.

Date Published: May-11-2025

## WEEE EU Directive

Pursuant to the WEEE EU Directive, electronic and electrical waste must not be disposed of with unsorted waste. Please contact your local recycling authority for disposal of this product.

## Security Vulnerabilities

All security vulnerabilities should be reported to [vulnerability@audiocodes.com](mailto:vulnerability@audiocodes.com).

## Customer Support

Customer technical support and services are provided by AudioCodes or by an authorized AudioCodes Service Partner. For more information on how to buy technical support for AudioCodes products and for contact information, please visit our website at <https://www.audiocodes.com/services-support/maintenance-and-support>.

## Documentation Feedback

AudioCodes continually strives to produce high quality documentation. If you have any comments (suggestions or errors) regarding this document, please fill out the Documentation Feedback form on our website at <https://online.audiocodes.com/documentation-feedback>.

## Stay in the Loop with AudioCodes



## Notes and Warnings



The device is an indoor unit and therefore, must be installed only **INDOORS**.



Configuration and usage of this device must be in accordance with your local security regulations, telephony regulations, or any other related regulations.



The scope of this document doesn't fully cover security aspects for deploying the device in your environment. Security measures should be done in accordance with your organization's security policies. For basic security guidelines, refer to the *Recommended Security Guidelines* document.



Throughout this manual, unless otherwise specified, the term *device* refers to your AudioCodes product.



Before configuring the device, ensure that it is installed correctly as instructed in the *Hardware Installation Manual*.



**OPEN SOURCE SOFTWARE.** Portions of the software may be open source software and may be governed by and distributed under open source licenses, such as the terms of the GNU General Public License (GPL), the terms of the Lesser General Public License (LGPL), BSD and LDAP. If any open source software is provided in object code, and its accompanying license requires that it be provided in source code as well, the Buyer may receive such source code by contacting AudioCodes.



- This device includes software developed by the OpenSSL Project for use in the OpenSSL Toolkit (<http://www.openssl.org/>).
- This device includes cryptographic software written by Eric Young ([eay@cryptsoft.com](mailto:eay@cryptsoft.com)).



- Some of the features described in this document are licensed features and are available only if the installed License Key contains these features.

## Related Documentation

Document Name
<a href="#">SBC-Gateway Series Release Notes for Latest Release (LR) Versions</a>
<b>Installation Manuals</b>
<a href="#">Mediant 500 E-SBC Hardware Installation Manual</a>
<b>Complementary Guides</b>

Document Name
Gateway and SBC CLI Reference Guide
SBC-Gateway Performance Monitoring Reference Guide
SBC-Gateway SNMP Alarm Reference Guide
SBC-Gateway SNMP Reference Guide
SBC-Gateway Recommended Security Guidelines
SIP Message Manipulation Syntax Reference Guide
REST API for SBC-Gateway Devices
IP-based Voice Mail Configuration Note
CAS Protocol Table Configuration Note
<b>Utility Guides</b>
<a href="#">INI Viewer &amp; Editor Utility User's Guide</a>
<a href="#">DConvert Utility User's Guide</a>
<a href="#">CLI Wizard Utility User's Guide</a>
<a href="#">Syslog Viewer User's Guide</a>

## Document Revision Record

LTRT	Description
14024	<p>Initial document release for Version 7.6 (7.60A.100.022).</p> <ul style="list-style-type: none"> <li>■ New sections: ; Downloading the DSP Core Dump File</li> <li>■ Updated sections: Configuring an HTTP-based OVOC Service ('OVOC Backup Server' removed); Viewing Active Web Interface and CLI Users relocated); Configuring LDAP Cache; Configuring Password Obfuscation; Configuring Local Management User Accounts (new 'TLS Subject Name'); Assigning CSR-based Certificates to TLS Contexts (new 'Authority Information Access - OCSP URI'); Upgrading the Device's (.cmp) Software (only .cmp file); Configuring IP Network Interfaces (new IPv4 DHCP option for 'Interface Mode')</li> <li>■ Updated parameters: HTTPSRequireClientCertificate (obsolete);</li> </ul>



LTRT	Description
	<p>           SSHKexAlgorithmsString; SNMPReadOnlyCommunityStringsPassword (removed); SNMPReadWriteCommunityStringsPassword (removed);            SNMPTrapCommunityStringPassword (removed);            SNMPTrapManagerHostName (removed);            SNMPIPV6TrapManagerHostName (removed);            SNMPTrapManagerHostName (removed); RadiusVSAVendorID (max.);            MaintenanceEventsMonitoringEnable (Web name);            MaintenanceEventsTreatmentEnable (web name); NTPServerUTCOffset (multiples of 60); NTPUpdateInterval (multiples of 60); BackupServer (removed); BackupSubscriptions (web name);            DisconnectSubscriptionsMode (web name); DHCPEnable (removed);            SNMPPort (web parameter); AltRoutingTel2IPConnMethod (removed)         </p> <ul style="list-style-type: none"> <li>■ New parameters: EmergencyCallAlertInfoUri;            ReloadTimeoutForEmergencyCall; BFCPNatFromAudio;            SBCBFCPNatFromAudio (IP Profile); PoolAlarmRaise; PoolAlarmClear;            RaiseAlarmXDaysBeforePwExpired; HASecuredConnectivityMode;            HaFileTransferPort; HaSecureFileTransferPort; HTTPCacheEnable</li> <li>■ Miscellaneous: Web UI redesign (refer to <i>Release Notes</i>); FAE page replaced by Admin page; improved SNMP configuration experience (refer to <i>Release Notes</i>); parameter name changes (refer to <i>Release Notes</i>);</li> </ul>

---

## Table of Contents

---

<b>1 Introduction</b>	<b>1</b>
Product Overview	1
Typographical Conventions	1
Configuration Concepts and Terminology	2
SBC Application Concepts and Terms	2
Gateway Application Concepts and Terms	7
<b>Part I</b>	<b>10</b>
<b>Getting Started with Initial Connectivity</b>	<b>10</b>
<b>2 Overview</b>	<b>11</b>
<b>3 Default IP Address</b>	<b>12</b>
<b>4 Configuring OAMP Interface</b>	<b>13</b>
Changing OAMP Address through Web Interface	13
Changing OAMP Address through CLI	14
Changing OAMP Address through ini File	16
<b>Part II</b>	<b>18</b>
<b>Management Tools</b>	<b>18</b>
<b>5 Overview</b>	<b>19</b>
<b>6 Web-Based Management</b>	<b>20</b>
Getting Acquainted with Web Interface	20
Computer Requirements	20
Logging into the Web Interface	20
Areas of Web Interface	22
Accessing Configuration Pages from Navigation Tree	25
Configuring Global Parameters	27
Configuring Tables	30
Adding Table Rows	31
Inserting Table Rows	32
Editing Table Rows	33
Deleting Table Rows	33
Invalid Value Indications	34
Viewing Table Rows	36
Sorting Tables Rows	37
Changing Table Row Position	37
Searching Values in Tables	38
Parameter Values Referencing Table Rows	39
Searching for Configuration Parameters	40
Getting Help	42
Logging Out the Web Interface	42
Customizing the Web Interface	43

Corporate Logo .....	43
Replacing the Corporate Logo with an Image .....	44
Replacing Corporate Logo with Text .....	45
Replacing Text with Corporate Logo .....	45
Web Browser's Tab Title .....	46
Customizing Browser Tab to Display Device's IP Address .....	46
Customizing Browser Tab to Display Text .....	46
Customizing the Product Name .....	47
Customizing the Browser Favicon .....	49
Creating a Login Welcome Message .....	50
Displaying Referenced Document List .....	51
Configuring Web Interfaces .....	51
Configuring Local Management User Accounts .....	54
Deleting All Users in Local Users Table .....	63
Configuring Login Username and Password Complexity .....	64
Detection of Weak Login Passwords .....	66
Enabling Detection of Weak Password .....	66
Configuring the Weak Passwords List .....	66
Changing Login Password .....	67
Configuring Login Password Expiration Alarm .....	69
User Login Authentication Methods .....	69
Denying Access for Failed Login Attempts .....	69
Displaying Login Information upon Login .....	71
Viewing Currently Logged-In User Information .....	72
Terminating Other Active Web Sessions of User .....	73
Configuring Web Session Timeouts .....	73
Configuring Secured (HTTPS) Web and REST Access .....	74
Adding TLS Certificates to REST Client .....	79
Adding Client Certificate to Web Browser Client .....	80
Enabling CSRF Protection .....	82
Customizing Access Levels per Web Page .....	82
Configuring a Hostname for Device's Web Interface .....	86
Configuring Management Access List .....	87
Viewing Active Web Interface and CLI Users .....	89
<b>7 CLI-Based Management .....</b>	<b>91</b>
Configuring Telnet for CLI .....	91
Configuring CLI over SSH using Public Key Authentication .....	92
Enabling SSH for Public Key Authentication .....	92
Configuring SSH Public Key Authentication on Windows .....	93
Configuring SSH Public Key Authentication on Linux .....	96
Configuring Telnet Interface .....	97
Configuring SSH Interfaces .....	98
Establishing a CLI Session .....	100

Configuring Maximum Telnet and SSH Sessions .....	101
Running Multiple Non-Interactive SSH Commands from Command Line .....	101
Viewing Current CLI and Web Sessions .....	102
Terminating a User's CLI Session .....	103
Configuring CLI Command Aliases .....	103
Configuring Maximum Number of Displayed CLI Output Lines .....	105
Idle CLI Session Timeout for RS-232 Connections .....	106
<b>8 SNMP-Based Management .....</b>	<b>107</b>
Enabling or Disabling SNMP .....	107
Configuring SNMP Get / Set Port .....	107
Configuring SNMP Community Strings .....	108
Configuring SNMP Trap Destinations .....	110
Configuring SNMP Community String for Traps .....	112
Enabling SNMP Traps for Web Activity .....	113
Configuring SNMP Interfaces .....	113
Configuring SNMP Trusted Managers .....	114
Configuring SNMPv3 Users .....	115
Customizing SNMP Alarm Severity .....	118
Configuring SNMP for OVOC Connectivity .....	121
Configuring WebSocket Tunnel with OVOC .....	122
<b>9 INI File-Based Management .....</b>	<b>126</b>
INI File Format .....	126
Configuring Individual ini File Parameters .....	126
Configuring Table ini File Parameters .....	126
Syntax Rules for the ini File .....	128
Methods for Configuring an ini File .....	129
Uploading an ini File to Device .....	129
Secured Encoded ini File .....	130
INI Viewer and Editor Utility .....	130
<b>10 REST-Based Management .....</b>	<b>131</b>
<b>Part III .....</b>	<b>134</b>
<b>General System Settings .....</b>	<b>134</b>
<b>11 Date and Time .....</b>	<b>135</b>
Viewing Date and Time .....	135
Configuring Date and Time Manually .....	136
Synchronizing Date and Time through SNTP .....	137
Synchronizing Date and Time through SIP .....	139
Configuring UTC Offset or Time Zone .....	140
Configuring Daylight Saving Time .....	141
<b>12 Configuring a Hostname for the Device .....</b>	<b>143</b>

<b>Part IV</b>	<b>144</b>
<b>General VoIP Configuration</b>	<b>144</b>
<b>13 Network</b>	<b>145</b>
Building and Viewing your Network Topology	145
Configuring Physical Ethernet Ports	149
Configuring Ethernet Port Groups	151
Configuring Underlying Ethernet Devices	154
Configuring IP Network Interfaces	157
Networking Configuration Examples	171
Configuring Static IP Routes	174
Configuration Example of Static IP Routes	176
Troubleshooting the Static Routes Table	177
Network Address Translation Support	178
Device Located behind NAT	178
Configuring a Static NAT IP Address for All Interfaces	179
Configuring NAT per IP Interface	179
SIP User Agent Located behind NAT	181
Enabling SIP NAT Detection when UA Located behind NAT	181
Media (RTP/RTCP/T.38)	182
Implementing ICE for Media Sessions	184
Media Latching for Robust Receipt of Media Streams	187
Configuring Static ARP Table	188
Configuring Quality of Service	190
Configuring Class-of-Service QoS	190
Configuring DiffServ-to-VLAN Priority Mapping	192
Configuring ICMP Message Handling	193
DNS	194
Default DNS Fallback Sequence	194
Configuring Default DNS Servers	195
Configuring the Internal DNS Table	197
Configuring the Internal SRV Table	199
Configuring DNS Fallback Policy	201
IP Multicasting	204
<b>14 Security</b>	<b>205</b>
Overview of GDPR	205
Masking PII from Syslog Files using PII Log Scrubber Tool	205
Masking PII in CDRs	206
Masking Digits in Syslog Messages	208
Deleting Locally Stored CDRs	209
Concealing Configured Passwords	209
Password Obfuscation in CLI Script and ini Files	209
Configuring Password Obfuscation	210
Disabling Password Obfuscation	213

Enabling or Disabling Password Obscured for CLI .....	214
Default Password Obscured in Ini File .....	215
Approved FIPS 140-3 Operation Modes .....	215
Security Rules .....	215
User Roles .....	216
FIPS Cryptographic Algorithms .....	216
Enabling FIPS Mode .....	217
Prerequisites .....	217
Initial FIPS Mode Settings .....	218
Ongoing FIPS Settings .....	221
Create Default Snapshot .....	223
Replacing a Faulty Device in HA System .....	223
FIPS-Related CLI Commands .....	223
<b>TLS Certificates .....</b>	<b>224</b>
Configuring TLS Certificate Contexts .....	224
Assigning CSR-based Certificates to TLS Contexts .....	231
TLS Context Parameters Relevancy per Application .....	235
Viewing Certificate Information .....	236
Assigning Externally Created Private Keys to TLS Contexts .....	237
Generating Private Keys for TLS Contexts .....	238
Creating Self-Signed Certificates for TLS Contexts .....	240
Importing Certificates into Trusted Root CA Certificate Store .....	241
Configuring TLS Server Certificate Expiry Check .....	243
Configuring SNI-to-TLS Mapping .....	244
Configuring TLS for Secured SIP .....	245
Configuring Mutual TLS Authentication .....	247
TLS for SIP Clients .....	247
TLS for Remote Device Management .....	248
Reliable (TCP/TLS) Connections .....	248
Configuring Firewall Rules .....	248
Configuring Firewall Rules to Allow Incoming OVOC Traffic .....	256
Intrusion Detection System .....	258
Enabling IDS .....	259
Configuring IDS Policies .....	259
Assigning IDS Policies .....	265
Viewing IDS Alarms .....	268
Configuring SIP Response Codes to Exclude from IDS .....	270
Configuring SIP Header Value Encryption .....	271
<b>15 Media .....</b>	<b>273</b>
Voice Settings .....	273
Configuring Voice Gain (Volume) Control .....	273
Configuring Echo Cancellation .....	273
Fax and Modem Capabilities .....	274
Fax and Modem Operating Modes .....	275

Fax and Modem Transport Modes .....	275
T.38 Fax Relay Mode .....	276
G.711 Fax and Modem Transport Mode .....	279
Fax Fallback .....	279
Fax and Modem Bypass Mode .....	280
Fax and Modem NSE Mode .....	282
Fax and Modem Transparent with Events Mode .....	283
Fax / Modem Transparent Mode .....	284
RFC 2833 ANS Report upon Fax and Modem Detection .....	285
V.34 Fax Support .....	285
Bypass Mechanism for V.34 Fax Transmission .....	286
Relay Mode for T.30 and V.34 Faxes .....	287
V.34 Fax Relay for SG3 Fax Machines .....	287
V.152 Support .....	289
RTP and RTCP Settings .....	290
Configuring the Dynamic Jitter Buffer .....	290
Enabling Comfort Noise Generation .....	292
Configuring DTMF Transport Types .....	293
Configuring RFC 2833 Payload .....	295
Configuring RTP Base UDP Port .....	295
Event Detection and Notification using X-Detect Header .....	297
SIT Event Detection .....	299
Detecting Answering Machine Beeps .....	301
SIP Call Flow Examples of Event Detection and Notification .....	302
Answering Machine Detection (AMD) .....	304
Configuring AMD .....	308
Enabling IP-to-Tel Call Disconnection upon Detection of Answering Machine .....	310
Configuring the Answer Detector Feature .....	310
Automatic Gain Control (AGC) .....	311
Media Security .....	313
Configuring SRTP .....	313
Configuring SRTP Crypto Suite Groups .....	315
<b>16 Services .....</b>	<b>318</b>
DHCP Server Functionality .....	318
Configuring the DHCP Server .....	318
Configuring the Vendor Class Identifier .....	324
Configuring Additional DHCP Options .....	325
Configuring Static IP Addresses for DHCP Clients .....	328
Viewing and Deleting DHCP Clients .....	329
SIPREC SIP-based Media Recording .....	330
SIPREC Overview .....	330
SIP Message Flow for SIPREC .....	332
SIPREC for SRTP Calls .....	336
SIPREC for Real-Time Text .....	337



Sending SIPREC to Multiple SRSs .....	337
Load Balancing SIPREC SRSs using IP Group Set .....	339
Configuring SIP Recording Rules .....	340
Starting a SIPREC Session using Message Conditions .....	345
Configuring Format of SIPREC Metadata .....	346
Configuring Video Recording Synchronization .....	346
On-demand SIPREC .....	347
On-Demand SIPREC using SIP INFO Messages .....	347
On-Demand SIPREC using SIP 200 OK Responses .....	350
On-Demand SIPREC using REST .....	352
Configuring SIP User Part for SRS .....	354
Sending DTMF Digits Notifications using SIP INFO Messages to SRS .....	355
Interworking SIP-based Media Recording with Third-Party Vendors .....	356
SIPREC with Genesys Equipment .....	356
SIPREC with Avaya Equipment .....	356
Customizing Recorded SIP Messages Sent to SRS .....	357
RADIUS-based Services .....	360
Enabling RADIUS Services .....	360
Configuring RADIUS Servers .....	360
Configuring RADIUS Packet Retransmission .....	364
Configuring the RADIUS Vendor ID .....	364
Securing RADIUS Messages with Message-Authenticator Attribute .....	365
RADIUS-based User Login Authentication .....	365
Setting Up a Third-Party RADIUS Server .....	366
Configuring RADIUS-based User Authentication .....	368
Securing RADIUS Communication .....	369
RADIUS-based User Authentication in URL .....	369
RADIUS-based CDR Accounting .....	369
LDAP-based Services .....	369
Enabling the LDAP Service .....	372
Enabling LDAP-based User Login Authentication .....	372
Configuring LDAP Server Groups .....	373
Configuring LDAP Servers .....	376
Configuring LDAP DN's (Base Paths) per LDAP Server .....	383
Configuring the LDAP Search Filter Attribute .....	384
Configuring Access Level per Management Groups Attributes .....	385
Configuring the Device's LDAP Cache .....	387
Refreshing LDAP Cache for LDAP Server Groups .....	390
Clearing LDAP Cache .....	391
Configuring Fallback Options to Local Users Table .....	391
LDAP-based Login Authentication Example .....	392
Enabling LDAP Searches for Numbers with Characters .....	396
Routing for Microsoft Teams or Skype for Business using Microsoft Entra ID .....	397
Querying Microsoft Entra ID and Routing Priority .....	398
Configuring Routing Rules based on Microsoft Entra ID .....	401



Querying Microsoft Entra ID for Calling Name .....	404
OAuth 2.0 Based Authentication Services .....	405
Configuring OAuth 2.0 Servers .....	405
OAuth-based User Login Authentication and Authorization .....	408
Setting Up Microsoft Entra ID for User Login OAuth Authentication .....	409
Device Configuration Summary .....	414
Microsoft Entra ID Login to Device's Web Interface .....	417
Microsoft Entra ID Login to Device's CLI .....	417
Microsoft Entra ID Login to Device's REST API .....	417
Configuring OAuth Servers for User Login Authentication .....	420
Enabling OAuth-based User Login Authentication .....	421
OAuth 2.0 Based SIP Message Authentication .....	424
Authenticating SIP Messages using Device's OAuth 2.0 Server with Microsoft Entra ID .....	424
Authenticating SIP Messages with External OAuth 2.0 Server .....	425
Remote Web Services .....	429
Configuring Remote Web Services .....	429
Configuring Remote HTTP Hosts .....	438
Enabling Topology Status Services .....	441
Enabling Registration Status Services .....	441
Centralized Routing by ARM (AudioCodes Routing Manager) .....	442
Configuring QoS-based Routing by ARM .....	446
Configuring an HTTP GET Web Service .....	447
Configuring HTTP POST Web Service .....	450
Least Cost Routing .....	452
Overview of LCR .....	452
Configuring LCR .....	455
Configuring Cost Groups .....	455
Assigning Cost Groups to Routing Rules .....	459
HTTP-based Proxy Services .....	459
Enabling the HTTP Proxy Application .....	461
Debugging Remote HTTP Services .....	461
Caching HTTP Responses .....	462
Configuring a DNS Server for HTTP Services .....	462
Configuring HTTP Proxy Servers .....	463
Configuring HTTP Locations .....	466
Configuring TCP-UDP Proxy Servers .....	470
Configuring Upstream Groups .....	474
Configuring Upstream Hosts .....	476
Configuring HTTP Directive Sets .....	478
Configuring HTTP Directives .....	480
Configuring an HTTP-based OVOC Service .....	481
Troubleshooting NGINX Configuration .....	486
Configuring a Public IP Address for NGINX NAT Traversal .....	487
Configuring LDAP Authentication for NGINX HTTP Reverse Proxy .....	487
E9-1-1 Support for Microsoft Teams and Skype for Business .....	489

About E9-1-1 Services .....	490
Microsoft Skype for Business and E9-1-1 .....	491
Gathering Location Information of Skype for Business Clients for 911 Calls .....	491
Adding ELINs to the Location Information Server .....	493
Passing Location Information to the PSTN Emergency Provider .....	494
AudioCodes ELIN Device for Teams / Skype for Business E9-1-1 Calls to PSTN .....	495
Detecting and Handling E9-1-1 Calls .....	496
Pre-empting Existing Calls for E9-1-1 Calls .....	499
PSAP Callback for Dropped E9-1-1 Calls .....	499
Selecting ELIN for Multiple Calls within Same ERL .....	500
Location Based Emergency Routing .....	501
Configuring AudioCodes ELIN Device .....	501
Enabling the E9-1-1 Feature .....	501
Configuring the E9-1-1 Callback Timeout .....	502
Enabling SIP Release Cause Code Response for Failed E9-1-1 Calls .....	502
Configuring SBC IP-to-IP Routing Rule for E9-1-1 .....	503
Configuring Location-Based Emergency Routing .....	503
Viewing the ELIN Table .....	505
Microsoft Skype for Business Presence of Third-Party Endpoints .....	505
Configuring Skype for Business Server for Presence .....	508
Configuring the Device for Microsoft Teams Presence .....	509
Microsoft Teams with Local Media Optimization .....	511
<b>17 Quality of Experience .....</b>	<b>514</b>
Reporting Voice Quality of Experience to OVOC .....	514
Reporting QoE to OVOC .....	514
Configuring Clock Synchronization between Device and OVOC .....	518
Configuring Firewall Rules for OVOC Traffic .....	518
Enabling RTCP XR Reporting to OVOC .....	518
Configuring Interval for QoE Report Collection and Generation .....	519
Configuring Quality of Experience Profiles .....	519
Configuring Bandwidth Profiles .....	526
Configuring Quality of Service Rules .....	531
Configuring Voice Quality for Registered Users .....	535
Configuring Voice Quality for Unregistered Users .....	537
<b>18 Core Entities .....</b>	<b>539</b>
Configuring Media Realms .....	539
Configuring Remote Media Subnets .....	543
Configuring Media Realm Extensions .....	546
Configuring SRDs .....	549
Multiple SRDs for Multi-tenant Deployments .....	557
Cloning SRDs .....	559
Color-Coding of SRDs in Web Interface .....	560
Automatic Configuration based on SRD .....	560

Configuring SIP Interfaces .....	561
Configuring IP Groups .....	581
Configuring Proxy Sets .....	622
Building and Viewing SIP Entities in Topology View .....	643
<b>19 Coders and Profiles .....</b>	<b>651</b>
Configuring Coders Groups .....	651
Supported Audio Coders .....	655
Configuring Various Codec Attributes .....	658
Configuring Allowed Audio Coder Groups .....	659
Configuring Allowed Video Coder Groups .....	662
Configuring IP Profiles .....	664
Configuring Tel Profile .....	738
<b>20 SIP Definitions .....</b>	<b>750</b>
Configuring Registration Accounts .....	750
Regular Registration Mode .....	763
Single Registration for Multiple Phone Numbers using GIN .....	763
Registrar Stickiness .....	765
Configuring Proxy and Registration Parameters .....	765
SIP Message Authentication Example .....	766
Configuring User Information .....	768
Enabling the User Information Table .....	768
Gateway User Information for PBX Extensions and "Global" Numbers .....	769
Configuring Gateway User Information Table through Web Interface .....	770
Configuring Gateway User Information Table through CLI .....	772
Configuring Gateway User Information Table from a Loadable File .....	774
Configuring SBC User Information .....	775
Configuring SBC User Information Table through Web Interface .....	776
Configuring SBC User Information Table through CLI .....	779
Configuring SBC User Information Table from a Loadable File .....	781
Configuring Call Setup Rules .....	782
Examples of Call Setup Rules .....	793
Configuring Dial Plans .....	798
Dial Plan Notations and Priority Matching .....	804
Dial Plan Notations .....	804
Dial Plan Matching Priority .....	807
Importing Dial Plans .....	811
Creating Dial Plan Files .....	812
Exporting Dial Plans .....	813
Using Dial Plan Tags for SBC IP-to-IP Routing .....	813
Using Dial Plan Tags for Matching Routing Rules .....	814
Using Destination Tags for Choosing Routing Destinations .....	815
Dial Plan Backward Compatibility .....	819
Using Dial Plan Tags for SBC Outbound Manipulation .....	821

Using Dial Plan Tags for Call Setup Rules .....	821
Using Dial Plans for IP-to-Tel or Tel-to-IP Call Routing .....	822
Using Dial Plan Tags for Message Manipulation .....	824
Using Dial Plans for Microsoft Local Media Optimization .....	825
Configuring Push Notification Servers .....	826
<b>21 SIP Message Manipulation .....</b>	<b>829</b>
Configuring SIP Message Manipulation .....	829
Configuring Message Condition Rules .....	838
Configuring SIP Message Policy Rules .....	840
Configuring Pre-Parsing Manipulation Rules .....	843
<b>Part V .....</b>	<b>847</b>
<b>Gateway Application .....</b>	<b>847</b>
<b>22 Overview .....</b>	<b>848</b>
Call Processing Summary .....	848
<b>23 Digital PSTN .....</b>	<b>850</b>
Configuring Trunk Settings .....	850
TDM and Timing .....	878
TDM Bus Clock Settings .....	878
Recovering Clock from PSTN Line Interface .....	878
Configuring Internal Clock as Clock Source .....	879
Configuring CAS State Machines .....	880
Configuring Digital Gateway Parameters .....	883
Tunneling Applications .....	883
TDM Tunneling .....	883
DSP Pattern Detector .....	887
Configuring Private Wire Interworking .....	888
QSIG Tunneling .....	894
ISDN Non-Facility Associated Signaling (NFAS) .....	895
NFAS Interface ID .....	896
Working with DMS-100 Switches .....	897
Creating an NFAS-Related Trunk Configuration .....	898
Performing Manual D-Channel Switchover in NFAS Group .....	898
ISDN Overlap Dialing .....	899
Collecting ISDN Digits and Sending Complete Number in SIP .....	899
Interworking ISDN Overlap Dialing with SIP According to RFC 3578 .....	900
Redirect Number and Calling Name (Display) .....	901
<b>24 Trunk Groups .....</b>	<b>903</b>
Configuring Trunk Groups .....	903
Configuring Trunk Group Settings .....	906
<b>25 Routing .....</b>	<b>914</b>
Configuring Tel-to-IP Routing Rules .....	914

Configuring IP-to-Tel Routing Rules .....	928
Configuring a Gateway Routing Policy Rule .....	934
Alternative Routing for Tel-to-IP Calls .....	937
IP Destinations Connectivity Feature .....	937
Alternative Tel-to-IP Routing Based on IP Connectivity .....	938
Alternative Tel-to-IP Routing Based on SIP Responses .....	940
Alternative Tel-to-IP Routing upon SIP 3xx with Multiple Contacts .....	943
PSTN Fallback .....	944
Alternative Routing for IP-to-Tel Calls .....	945
Alternative Routing to Trunk upon Q.931 Call Release Cause Code .....	945
Alternative Routing to an IP Destination upon a Busy Trunk .....	947
Alternative Routing upon ISDN Disconnect .....	949
<b>26 Manipulation .....</b>	<b>950</b>
Configuring Redirect Reasons .....	950
Configuring Source-Destination Number Manipulation Rules .....	950
Manipulating Number Prefix .....	958
SIP Calling Name Manipulations .....	960
Configuring Redirect Number Manipulation .....	966
Manipulating Redirected and Diverted Numbers for Call Diversion .....	971
Mapping NPI/TON to SIP Phone-Context .....	973
Configuring Release Cause Mapping .....	975
SIP-to-ISDN Release Cause Mapping .....	975
Configuring SIP-to-ISDN Release Cause Mapping .....	976
Fixed Mapping of SIP Response to ISDN Release Reason .....	977
SIP-to-ISDN Disconnect Release Cause Code Mapping .....	979
ISDN-to-SIP Release Cause Mapping .....	981
Configuring ISDN-to-SIP Release Cause Mapping .....	981
Fixed Mapping of ISDN Release Reason to SIP Response .....	983
Configuring ISDN-to-ISDN Release Cause Mapping .....	987
SIP Reason Header for Release Cause .....	989
Numbering Plans and Type of Number .....	989
<b>27 Configuring DTMF and Dialing .....</b>	<b>992</b>
Dialing Plan Features .....	992
Digit Mapping .....	992
Dial Plan Rules .....	994
Interworking Keypad DTMFs for SIP-to-ISDN Calls .....	994
Configuring Hook Flash .....	995
<b>28 Configuring Supplementary Services .....</b>	<b>996</b>
Call Hold and Retrieve .....	996
Call Transfer .....	996
Consultation Call Transfer .....	997
Consultation Transfer for QSIG Path Replacement .....	997
Blind Call Transfer .....	998

Call Forward .....	999
Enabling Call Forwarding .....	999
Message Waiting Indication .....	999
Emergency E911 Phone Number Services .....	1001
Pre-empting Existing Calls for E911 IP-to-Tel Calls .....	1001
Multilevel Precedence and Preemption .....	1002
MLPP Preemption Events in SIP Reason Header .....	1005
Precedence Ring Tone .....	1007
Detecting Collect Calls .....	1007
Advice of Charge Services for Euro ISDN .....	1007
Configuring Charge Codes .....	1010
Configuring Voice Mail .....	1014
Converting Accented Characters from IP to Tel .....	1016
<b>Part VI .....</b>	<b>1018</b>
<b>Session Border Controller Application .....</b>	<b>1018</b>
<b>29 Overview .....</b>	<b>1019</b>
Feature List .....	1019
B2BUA and Stateful Proxy Operating Modes .....	1021
Call Processing of SIP Dialog Requests .....	1023
User Registration .....	1026
Initial Registration Request Processing .....	1027
Classification and Routing of Registered Users .....	1028
General Registration Request Processing .....	1029
Registration Refreshes .....	1029
Registration Restriction Control .....	1030
Deleting Registered Users .....	1030
Media Handling .....	1031
Media Anchoring .....	1032
Direct Media Calls .....	1033
Restricting Audio Coders .....	1036
Prioritizing Coder List in SDP Offer .....	1037
Multiple RTP Media Streams per Call Session .....	1037
Interworking Miscellaneous Media Handling .....	1038
Interworking RTP Redundancy .....	1038
Interworking RTP-RTCP Multiplexing .....	1038
Interworking RTCP Attribute in SDP .....	1038
Interworking Crypto Lifetime Field .....	1038
Interworking Media Security Protocols .....	1038
Interworking ICE for NAT Traversal .....	1039
SBC Authentication .....	1039
SIP Authentication Server Functionality .....	1039
RADIUS-based Authentication of SIP User Agents .....	1040
Interworking SIP Signaling .....	1040

Interworking SIP 3xx Redirect Responses .....	1041
Resultant INVITE Traversing Device .....	1041
Local Handling of SIP 3xx .....	1042
Interworking SIP Diversion and History-Info Headers .....	1043
Interworking SIP REFER Messages .....	1045
Interworking SIP PRACK Messages .....	1045
Interworking SIP Session Timer .....	1046
Interworking SIP Early Media .....	1046
Interworking SIP re-INVITE Messages .....	1048
Interworking SIP UPDATE Messages .....	1048
Interworking SIP re-INVITE to UPDATE .....	1049
Interworking Delayed Offer .....	1049
Interworking Call Hold .....	1049
Interworking SIP Via Headers .....	1050
Interworking SIP User-Agent Headers .....	1050
Interworking SIP Record-Route Headers .....	1050
Interworking SIP To-Header Tags in Multiple SDP Answers .....	1050
Interworking In-dialog SIP Contact and Record-Route Headers .....	1050
<b>30 Utilizing Gateway Channel Resources for SBC .....</b>	<b>1051</b>
<b>31 Configuring General SBC Settings .....</b>	<b>1052</b>
Interworking Dialog Information in SIP NOTIFY Messages .....	1052
<b>32 Configuring Call Admission Control .....</b>	<b>1054</b>
<b>33 Routing SBC .....</b>	<b>1061</b>
Configuring Classification Rules .....	1061
Classification Based on URI of Selected Header Example .....	1072
Configuring Classification Based on Tags .....	1073
Configuring Action for Classification Failure .....	1075
Configuring SBC IP-to-IP Routing Rules .....	1076
Configuring Rerouting of Calls to Fax Destinations .....	1096
Configuring Specific UDP Ports using Tag-based Routing .....	1098
Configuring a Routing Response Timeout .....	1104
Configuring SIP Response Codes for Alternative Routing Reasons .....	1104
Configuring SBC Routing Policies .....	1108
Configuring IP Group Sets .....	1113
<b>34 SBC Manipulations .....</b>	<b>1118</b>
Configuring IP-to-IP Inbound Manipulations .....	1121
Configuring IP-to-IP Outbound Manipulations .....	1126
Using Proprietary SIP X-AC-Action Header .....	1134
<b>35 Configuring Malicious Signatures .....</b>	<b>1137</b>
<b>36 Advanced SBC Features .....</b>	<b>1139</b>
Configuring Call Preemption for SBC Emergency Calls .....	1139



Configuring Message Session Relay Protocol .....	1141
Emergency Call Routing using LDAP to Obtain ELIN .....	1146
Configuring Dual Registration for SIP Entity .....	1147
Handling Registered AORs with Same Contact URIs .....	1151
Enabling Interworking of SIP and SIP-I Endpoints .....	1152
Configuring SBC MoH from External Media Source .....	1154
Configuring Background Tones for SBC Calls .....	1158
Call Forking .....	1159
Initiating SIP Call Forking .....	1159
Configuring SIP Forking Initiated by SIP Proxy .....	1160
Configuring Call Forking-based IP-to-IP Routing Rules .....	1161
Call Survivability .....	1161
Enabling Auto-Provisioning of Subscriber-Specific Information of BroadWorks Server for Survivability .....	1161
Configuring BroadSoft's Shared Phone Line Call Appearance for Survivability .....	1162
Configuring Call Survivability for Call Centers .....	1164
Enabling Survivability Display on Aastra IP Phones .....	1166
Alternative Routing upon Detection of Failed SIP Response .....	1167
Configuring Push Notification Service .....	1167
Configuring Maximum SBC Call Duration .....	1170
Configuring Maximum Concurrent Calls per Specific User .....	1171
Playing Tone upon Call Connect .....	1172
<b>Part VII .....</b>	<b>1175</b>
<b>High-Availability System .....</b>	<b>1175</b>
<b>37 Overview of High Availability Mode .....</b>	<b>1176</b>
Connectivity and Synchronization between Devices .....	1176
Device Switchover upon Failure .....	1177
Viewing HA Status on Monitor Web Page .....	1178
<b>38 HA Configuration .....</b>	<b>1181</b>
Prerequisites for HA .....	1181
Initial HA Configuration .....	1181
Network Topology Types and Rx/Tx Ethernet Port Group Settings .....	1181
Configuring the HA Devices .....	1183
Step 1: Configure the First Device .....	1183
Step 2: Configure the Second Device .....	1185
Step 3: Initialize HA on the Devices .....	1186
Quick-and-Easy Initial HA Configuration .....	1187
Configuration while HA is Operational .....	1188
Configuring Firewall Allowed Rules .....	1189
Configuring DiffServ for HA Maintenance Traffic .....	1190
Configuring Ports for File Transfer between Active and Redundant Devices .....	1190
Enabling Secured TLS Communication between Active and Redundant Devices .....	1191



Monitoring IP Entities and HA Switchover upon Ping Failure .....	1191
<b>39 HA Maintenance .....</b>	<b>1197</b>
Maintenance of Redundant Device .....	1197
Replacing a Failed Device .....	1197
Initiating an HA Switchover .....	1197
Restarting Redundant Device .....	1198
Software Upgrade .....	1198
Disconnecting and Reconnecting HA .....	1198
Accessing Files on Redundant Device from Active through SSH .....	1200
Backing Up and Restoring HA Configuration .....	1201
<b>Part VIII .....</b>	<b>1202</b>
<b>Maintenance .....</b>	<b>1202</b>
<b>40 Basic Maintenance .....</b>	<b>1203</b>
Restarting the Device .....	1203
Remotely Restarting Device using SIP NOTIFY .....	1204
Locking and Unlocking the Device .....	1205
Saving Configuration .....	1206
<b>41 Channel Maintenance .....</b>	<b>1208</b>
Restarting a B-Channel .....	1208
Locking and Unlocking Trunk Groups .....	1208
Disconnecting Active Calls .....	1210
Remotely Disconnecting Calls using SIP NOTIFY .....	1210
Configuring a Description for Telephony Ports .....	1211
<b>42 Upgrading the Device's (.cmp) Software .....</b>	<b>1213</b>
Recommendations Before Upgrading .....	1213
Upgrading a Standalone Device .....	1213
Upgrading Devices in High-Availability Mode .....	1216
<b>43 Uploading Auxiliary Files .....</b>	<b>1220</b>
Uploading Auxiliary Files through Web Interface .....	1221
Uploading Auxiliary Files through CLI .....	1223
Deleting Auxiliary Files .....	1223
Uploading an ini File .....	1224
Call Progress Tones File .....	1224
Uploading a Prerecorded Tones File .....	1228
Uploading CAS Files .....	1230
Uploading an AMD Sensitivity File .....	1231
Uploading a User Info File .....	1232
<b>44 License Key .....</b>	<b>1233</b>
Viewing the License Key .....	1233
Local License Key .....	1235

Installing License Key through Web Interface .....	1235
Installing a License Key String .....	1236
Installing a License Key File .....	1238
Installing License Key String through CLI .....	1241
Verifying Installed License Key .....	1242
Backing up Local License Key .....	1242
OVOC-Managed Capacity Licenses .....	1243
Fixed License Pool Model .....	1243
Floating License Model .....	1245
Flex License Model .....	1248
Enabling Floating or Flex License .....	1251
Viewing Flex License Utilization and Status .....	1252
Configuring Floating or Flex License Allocation Profiles .....	1253
Viewing Floating or Flex License Reports .....	1255
Viewing the Device's Product Key .....	1256
<b>45 Downloading and Uploading Configuration Files .....</b>	<b>1257</b>
Downloading or Uploading ini File .....	1257
Downloading or Uploading CLI Script File .....	1258
Uploading CLI Startup Script File .....	1259
Downloading or Uploading Configuration Package File .....	1260
Configuring Default Password for Configuration Package File .....	1264
<b>46 Automatic Provisioning .....</b>	<b>1266</b>
Automatic Configuration Methods .....	1266
DHCP-based Provisioning .....	1266
Provisioning from HTTP Server using DHCP Option 67 .....	1267
Provisioning from TFTP Server using DHCP Option 66 .....	1269
Provisioning the Device using DHCP Option 160 .....	1269
HTTP-based Provisioning .....	1271
FTP-based Provisioning .....	1271
Provisioning through OVOC .....	1272
HTTP/S-Based Provisioning using the Automatic Update Feature .....	1272
File Provisioning .....	1272
Files Provisioned by Automatic Update .....	1273
File Location for Automatic Update .....	1274
MAC Address Placeholder in URL and File Name .....	1275
Downloading TLS-Related Files for a Specific TLS Context .....	1275
Downloading TLS-related Files for All TLS Contexts .....	1276
File Template for Automatic Provisioning .....	1277
Triggers for Automatic Update .....	1279
Applying Downloaded ini File after Graceful Timeout .....	1280
Assigning IP Interface for Auto-Update Mechanism .....	1281
Access Authentication with HTTP Server .....	1281
Querying Provisioning Server for Updated Files .....	1282
File Download Sequence .....	1285

Cyclic Redundancy Check on Downloaded Configuration Files .....	1286
Automatic Update Configuration Examples .....	1287
Automatic Update for Single Device .....	1287
Automatic Update from Remote Servers .....	1289
Automatic Update for Mass Deployment .....	1291
<b>47 USB Storage Capabilities .....</b>	<b>1294</b>
<b>48 SBC Configuration Wizard .....</b>	<b>1295</b>
Starting the SBC Configuration Wizard .....	1296
General Setup Page .....	1297
System Page .....	1298
Interfaces Page .....	1300
IP-PBX Page .....	1301
SIP Trunk Page .....	1302
Remote Users or Users Page .....	1304
Number Manipulation Page .....	1305
Summary Page .....	1307
Finish Page .....	1307
<b>49 Restoring Factory Defaults .....</b>	<b>1308</b>
Restoring Factory Defaults through CLI .....	1308
Restoring Factory Defaults through Web Interface .....	1309
Restoring Defaults using Hardware Reset Button .....	1310
Restoring Defaults through ini File .....	1310
<b>Part IX .....</b>	<b>1311</b>
<b>Status, Performance Monitoring and Reporting .....</b>	<b>1311</b>
<b>50 System Status .....</b>	<b>1312</b>
Viewing Device Information .....	1312
Viewing Device Status on Monitor Page .....	1314
Viewing Voice Channel Information .....	1318
<b>51 Viewing Carrier-Grade Alarms .....</b>	<b>1323</b>
Viewing Active Alarms .....	1323
Viewing History Alarms .....	1324
Deleting Alarm History Table .....	1326
Storing Alarms History on Flash .....	1326
<b>52 Viewing Management User Activity Logs .....</b>	<b>1328</b>
<b>52 Performance Monitoring .....</b>	<b>1329</b>
Configuring Alarm Thresholds for Performance Monitoring .....	1329
Configuring Performance Monitoring for Short and Long Calls .....	1335
Performance Monitoring Graphs .....	1337
Configuring KPI Layouts .....	1337
Adding Performance Monitoring Graphs to KPI Layouts .....	1340

Editing Performance Monitoring Graphs .....	1347
Deleting Performance Monitoring Graphs .....	1347
Viewing Options for Performance Monitoring Graphs .....	1348
Printing Performance Monitoring Graphs .....	1350
Downloading Performance Monitoring Graphs .....	1350
<b>54 Configuring PacketSmart Agent for Network Monitoring .....</b>	<b>1352</b>
<b>55 Viewing VoIP Status .....</b>	<b>1354</b>
Viewing SBC Registered Users .....	1354
Viewing Proxy Set Status .....	1357
Viewing Registration Status .....	1358
Viewing IP Connectivity .....	1360
Viewing Gateway CDR History .....	1361
Viewing CDR History of SBC and Test Calls .....	1363
<b>56 Viewing PSTN Status .....</b>	<b>1365</b>
Viewing Trunks & Channels Status .....	1365
Viewing NFAS Groups and D-Channel Status .....	1368
<b>57 Viewing Network Status .....</b>	<b>1370</b>
Viewing Active IP Interfaces .....	1370
Viewing Ethernet Device Status .....	1370
Viewing Ethernet Port Information .....	1370
Viewing Static Routes Status .....	1371
Viewing IDS Active Blocked List .....	1372
<b>58 Reporting Information to External Party .....</b>	<b>1374</b>
Configuring RTCP XR .....	1374
Call Detail Records .....	1381
Enabling CDR Generation and Configuring the CDR Server Address .....	1382
Configuring CDR Filters and Report Level .....	1382
Configuring CDR Reporting to REST Server .....	1383
Miscellaneous CDR Configuration .....	1384
Storing CDRs Locally on the Device .....	1384
CDR Field Description .....	1387
Customizing CDRs for Gateway Calls .....	1440
Customizing CDRs for SBC Calls and Test Calls .....	1446
CDR Customization using Call Variables Example .....	1453
Customizing CDR Indication for Call Success or Failure based on Responses .....	1454
Configuring RADIUS Accounting .....	1456
Querying Device Channel Resources using SIP OPTIONS .....	1466
<b>59 Remote Monitoring of Device behind NAT .....</b>	<b>1467</b>
<b>Part X .....</b>	<b>1469</b>
<b>Diagnostics .....</b>	<b>1469</b>

<b>60 Syslog and Debug Recording</b>	<b>1470</b>
Configuring Logging Filter Rules	1470
Filtering IP Network Traces using Wireshark-Like Expressions	1478
Filtering IP Network Traces by Ethernet Port or VLAN	1480
Debugging PSTN Calls through CLI	1481
Configuring Syslog	1482
Syslog Message Format	1482
Event Representation in Syslog Messages	1487
Syslog Fields for Answering Machine Detection (AMD)	1489
SNMP Alarms in Syslog Messages	1489
Enabling Syslog	1490
Configuring the Primary Syslog Server Address	1490
Configuring Secondary Syslog Servers	1492
Configuring Syslog Message Severity Level	1499
Configuring Syslog Debug Level	1501
Reporting Management User Activities	1502
Viewing Syslog Messages	1504
Syslog Message Description for CPU Overload	1507
Packet Loss Indication in Syslog	1509
Configuring Debug Recording	1510
Configuring Debug Recording Server Address	1511
Starting and Stopping Debug Recording	1512
Collecting Debug Recording Messages	1513
Debug Capturing on Physical VoIP Interfaces	1516
Debug Capturing on VoIP Interfaces	1517
Configuring Wireshark Packet Capturing using RPCAP	1519
<b>61 Creating Core Dump and Debug Files upon Device Crash</b>	<b>1524</b>
Enabling Core Dump File Generation	1524
Downloading the Debug (and Core Dump) File	1525
Deleting the Debug (and Core Dump) File	1526
Debug (and Core Dump) File Contents	1527
<b>61 Downloading the DSP Core Dump File</b>	<b>1529</b>
<b>62 Debugging Web Services</b>	<b>1530</b>
<b>63 Enabling SIP Call Flow Diagrams in OVOC</b>	<b>1531</b>
<b>64 Enabling Same Call Session ID over Multiple Devices</b>	<b>1533</b>
<b>65 Testing SIP Signaling Calls</b>	<b>1534</b>
Configuring Test Call Endpoints	1534
Using SIP INVITE to Specify Test Call Duration	1545
Starting and Stopping Test Calls	1546
Viewing Test Call Status	1546
Viewing Test Call Statistics	1546
Configuring DTMF Tones for Test Calls	1549

Configuring Basic Incoming Test Calls .....	1550
Test Call Rules Configuration Examples .....	1551
<b>66 Pinging a Remote Host or IP Address .....</b>	<b>1555</b>
<b>67 Accessing Device's File System through SFTP for File Download .....</b>	<b>1556</b>
<b>Part XI .....</b>	<b>1558</b>
<b>Appendix .....</b>	<b>1558</b>
<b>68 Patterns for Denoting Phone Numbers and SIP URIs .....</b>	<b>1559</b>
<b>69 Configuration Parameters Reference .....</b>	<b>1563</b>
Management Parameters .....	1563
General Parameters .....	1563
Web Parameters .....	1568
Telnet and CLI Parameters .....	1575
SNMP Parameters .....	1577
WebSocket Tunneling with OVOC Parameters .....	1584
Serial Parameters .....	1587
Auxiliary and Configuration File Name Parameters .....	1588
License Parameters .....	1590
Automatic Update Parameters .....	1593
Networking Parameters .....	1611
Ethernet Parameters .....	1612
Multiple VoIP Network Interfaces and VLAN Parameters .....	1612
ICMP Parameters .....	1612
Quality of Service Parameters .....	1613
NAT and STUN Parameters .....	1614
DNS Parameters .....	1617
DHCP Parameters .....	1618
Clock (Date and Time) Synchronization Parameters .....	1619
Debugging and Diagnostics Parameters .....	1623
General Parameters .....	1623
SIP Test Call Parameters .....	1624
Syslog, CDR and Debug Parameters .....	1624
Heartbeat Packet Parameters .....	1651
Resource Allocation Indication Parameters .....	1651
PacketSmart Parameters .....	1653
HA Parameters .....	1653
Security Parameters .....	1658
General Security Parameters .....	1658
HTTPS Parameters .....	1661
SRTP Parameters .....	1662
TLS Parameters .....	1669
SSH Parameters .....	1673
IDS Parameters .....	1675

OCSP Parameters .....	1676
Proxy, Registration and Authentication Parameters .....	1677
Network Application Parameters .....	1701
General SIP Parameters .....	1702
Channel Parameters .....	1753
Voice Parameters .....	1753
Coder Parameters .....	1756
DTMF Parameters .....	1758
RTP, RTCP and T.38 Parameters .....	1760
Gateway Application Parameters .....	1769
Fax and Modem Parameters .....	1769
DTMF and Hook-Flash Parameters .....	1781
Digit Collection and Dial Plan Parameters .....	1787
Voice Mail Parameters .....	1790
Supplementary Services Parameters .....	1797
Caller ID Parameters .....	1797
Call Waiting Parameters .....	1801
Call Forwarding Parameters .....	1801
Call Hold Parameters .....	1802
Call Transfer Parameters .....	1804
MLPP and Emergency Call Parameters .....	1806
Call Cut-through Parameters .....	1815
PSTN Parameters .....	1815
General Parameters .....	1815
TDM Bus and Clock Timing Parameters .....	1820
CAS Parameters .....	1823
ISDN Parameters .....	1826
ISDN and CAS Interworking Parameters .....	1830
Tone Parameters .....	1853
Telephony Tone Parameters .....	1853
Tone Detection Parameters .....	1859
Metering Tone Parameters .....	1861
Trunk Group and Routing Parameters .....	1863
IP Connectivity Parameters .....	1872
Alternative Routing Parameters .....	1874
Number Manipulation Parameters .....	1876
Answer and Disconnect Supervision Parameters .....	1890
SBC Parameters .....	1896
Supplementary Services .....	1925
IP Media Parameters .....	1926
Services .....	1937
SIPREC Parameters .....	1937
RADIUS and LDAP Parameters .....	1938
General Parameters .....	1938
RADIUS Parameters .....	1940

LDAP Parameters .....	1943
HTTP-based Services .....	1946
HTTP Proxy Parameters .....	1949
<b>70 Capacity for Signaling, Media and User Registrations .....</b>	<b>1952</b>
<b>71 Technical Specifications .....</b>	<b>1953</b>



# 1 Introduction

This User's Manual describes how to configure and manage your AudioCodes Mediant 500 Gateway and E-SBC (hereafter, referred to as *device*).

## Product Overview

AudioCodes Mediant 500 Gateway and E-SBC (hereafter referred to as *device*) is a compact, high performance VoIP connectivity solution for small enterprises and branch office locations. The device connects IP-PBXs and unified communications platforms to any SIP trunking service provider, scaling up to 250 concurrent SBC sessions. It offers superior performance in connecting any SIP to SIP environment, legacy TDM-based PBX systems to IP networks and IP-PBXs to the PSTN, supporting a single E1/T1 interface with 30 voice channels in a 1U platform. It also ensures secure and reliable communications for branch offices in distributed enterprise communications deployments.

The device includes comprehensive media security and SIP normalization capabilities. It offers full interoperability with an extensive list of IP-PBXs, unified communications solutions and SIP trunking provider networks.

The device provides robust protection for the IP communications infrastructure, preventing Denial of Service, fraud and service theft and guarding against cyber-attacks and other service-impacting events.

The device offers active/standby high availability and maintains high voice quality to deliver reliable enterprise VoIP communications. Advanced call routing mechanisms, network voice quality monitoring and branch survivability capabilities result in minimum communications downtime.

The device can be used in the following typical applications:



- SIP trunking
- Hosted PBX & UC as a Service
- IP contact centers
- Remote and mobile worker support
- SIP mediation between UC and IP-PBX systems

## Typographical Conventions

This document uses the following typographical conventions:

**Table 1-1: Typographical Conventions**

Convention	Description	Example
Text enclosed by a	Indicates Web interface parameters.	From the 'Debug

Convention	Description	Example
single quotation mark ('...')		Level' drop-down list, select <b>Basic</b> .
<b>Boldface font</b>	Indicates one of the following Web-based management interface elements: <ul style="list-style-type: none"> <li>■ A button</li> <li>■ A selectable value</li> <li>■ The navigational path to a Web page</li> </ul>	Click the <b>Add</b> button.
Text enclosed by double quotation marks ("...")	Indicates values that you need to enter (type) in the Web interface.	In the 'IP Address' field, enter "10.10.1.1".
Courier font	Indicates CLI commands or ini-based file configuration.	At the CLI prompt, type the following: <div># configure system</div>
Text enclosed by square brackets [...]	Indicates ini file parameters and values.	Configure the [GWDebugLevel] parameter to [1].
	Indicates a note bulletin providing important or useful information.	-
	Indicates a warning bulletin alerting you to potentially serious problems if a specific action is not taken.	-

## Configuration Concepts and Terminology

Before using your device, it is recommended that you familiarize yourself with the basic configuration concepts and terminology. An understanding of the basic concepts and terminology will help you configure and manage your device more effectively and easily.

### SBC Application Concepts and Terms

The objective of your configuration is to enable the device to forward calls between telephony endpoints in the SIP-based Voice-over-IP (VoIP) network. The endpoints (SIP entities) can be servers such as SIP proxy servers and IP PBXs, or end users such as IP phones. In the SIP world, the endpoints are referred to as SIP user agents (UA). The UA that initiates the call is referred to

as the user agent client (UAC); the UA that accepts the call is referred to as the user-agent server (UAS).

The following table describes the main configuration concepts and terminology.

**Table 1-2: Configuration Concepts and Terminology**


Configuration Terms	Description
IP Group	An IP Group is a logical representation of the SIP entity (UA) with which the device receives and sends calls. The SIP entity can be a server (e.g., IP PBX or SIP Trunk) or it can be a group of users (e.g., LAN IP phones). For servers, the IP Group is typically used to define the address of the entity (by its associated Proxy Set). IP Groups are used in IP-to-IP routing rules to denote the source and destination of the call.
Proxy Set	A Proxy Set defines the actual address (IP address or FQDN) of SIP entities that are servers (e.g., IP PBX). As the IP Group represents the SIP entity, to associate an address with the SIP entity, the Proxy Set is assigned to the IP Group. You can assign the same Proxy Set to multiple IP Groups (belonging to the same SRD).
SIP Interface	A SIP Interface represents a Layer-3 network. It defines a local listening port for SIP signaling traffic on a local, logical IP network interface. The term <i>local</i> implies that it's a logical port and network interface on the device. The SIP Interface is used to receive and send SIP messages with a specific SIP entity (IP Group). Therefore, you can create a SIP Interface for each SIP entity in the VoIP network with which your device needs to communicate. For example, if your VoIP network consists of three SIP entities -- a SIP Trunk, a LAN IP PBX, and remote WAN users -- a SIP Interface can be created for each of these Layer-3 networks. The SIP Interface is associated with the SIP entity, by assigning it to an SRD that is in turn, assigned to the IP Group of the SIP entity.
Media Realm	A Media Realm defines a local UDP port range for RTP (media) traffic on any one of the device's logical IP network interfaces. The Media Realm is used to receive and send media traffic with a specific SIP entity (IP Group). The Media Realm can be associated with the SIP entity, by assigning the Media Realm to the IP Group of the SIP entity, or by assigning it to the SIP Interface associated with the SIP entity.
SRD	An SRD is a logical representation of your entire SIP-based VoIP network (Layer 5) containing groups of SIP users and servers. The SRD is in effect, the foundation of your configuration to which all other previously mentioned configuration entities are associated. For

Configuration Terms	Description
	<p>example, if your VoIP network consists of three SIP entities -- a SIP Trunk, a LAN IP PBX, and remote WAN users -- the three SIP Interfaces defining these Layer-3 networks would all assigned to the same SRD. Typically, only a single SRD is required and this is the recommended configuration topology. As the device provides a default SRD, in a single SRD topology, the device automatically assigns the SRD to newly created configuration entities. Thus, in such scenarios, there is no need to get involved with SRD configuration.</p> <p>Multiple SRDs are required only for multi-tenant deployments, where it "splits" the device into multiple logical devices. For multiple SRDs, the SRD can be configured with a Sharing Policy. The Sharing Policy simply means whether the SRD's resources (SIP Interfaces, IP Groups, and Proxy Sets) can be used by other SRDs. For example, if all tenants route calls with the same SIP Trunking service provider, the SRD of the SIP Trunk would be configured as a <i>Shared</i> Sharing Policy. SRDs whose resources are not shared, would be configured with an <i>Isolated</i> Sharing Policy.</p>
IP Profile	<p>An IP Profile is an optional configuration entity that defines a wide range of call settings for a specific SIP entity (IP Group). The IP Profile includes signaling and media related settings, for example, jitter buffer, silence suppression, voice coders, fax signaling method, SIP header support (local termination if not supported), and media security method. The IP Profile is in effect, the interoperability "machine" of the device, enabling communication between SIP endpoints that "speak" different call "languages".</p> <p>The IP Profile is associated with the SIP entity, by assigning the IP Profile to the IP Group of the SIP entity.</p>
Classification	<p>Classification is the process that identifies the incoming call (SIP dialog request) as belonging to a specific SIP entity (IP Group).</p> <p>There are three chronological classification stages, where each stage is done only if the previous stage fails. The device first attempts to classify the SIP dialog by checking if it belongs to a user that is already registered in the device's registration database. If this stage fails, the device checks if the source IP address is defined for a Proxy Set and if yes, it classifies it to the IP Group associated with the Proxy Set. If this fails, the device classifies the SIP dialog using the Classification table, which defines various characteristics of the incoming dialog that if matched, classifies the call to a specific IP Group. The main characteristics of the incoming call is the SIP Interface that is associated with the SRD for which the Classification rule is configured.</p>


Configuration Terms	Description
IP-to-IP Routing	<p>IP-to-IP routing rules define the routes for routing calls between SIP entities. As the SIP entities are represented by IP Groups, the routing rules typically employ IP Groups to denote the source and destination of the call. For example, to route calls from the IP PBX to the SIP Trunk, the routing rule can be configured with the IP PBX as the source IP Group and the SIP Trunk as the destination IP Group.</p> <p>Instead of IP Groups, various other source and destination methods can be used. For example, the source can be a source host name while the destination can be an IP address or based on an LDAP query.</p>
Inbound and Outbound Manipulation	<p>Inbound and Outbound Manipulation lets you manipulate the user part of the SIP URI in the SIP message for a specific entity (IP Group). Inbound manipulation is done on messages received from the SIP entity; outbound manipulation is done on messages sent to the SIP entity.</p> <p>Inbound manipulation lets you manipulate the user part of the SIP URI for source (e.g., in the SIP From header) and destination (e.g., in the Request-URI line) in the incoming SIP dialog request. Outbound manipulation lets you manipulate the user part of the Request-URI for source (e.g., in the SIP From header) or destination (e.g., in the SIP To header) or calling name, in outbound SIP dialog requests.</p> <p>The Inbound and Outbound manipulation are associated with the SIP entity, by configuring the rules with incoming characteristics such as source IP Group and destination host name. The manipulation rules are also assigned a Routing Policy, which in turn, is assigned to IP-to-IP routing rules. As most deployments require only one Routing Policy, the default Routing Policy is automatically assigned to the manipulation rules and to the routing rules.</p>
Routing Policy	<p>Routing Policy logically groups routing and manipulation (inbound and outbound) rules to a specific SRD. It also enables Least Cost Routing (LCR) for routing rules and associates an LDAP server for LDAP-based routing. However, as multiple Routing Policies are required only for multi-tenant deployments, for most deployments only a single Routing Policy is required. When only a single Routing Policy is required, handling of this configuration entity is not required as a default Routing Policy is provided, which is automatically associated with all relevant configuration entities.</p>
Call Admission Control	<p>Call Admission Control (CAC) lets you configure the maximum number of permitted concurrent calls (SIP dialogs) per IP Group, SIP Interface, SRD, or user.</p>

Configuration Terms	Description
Accounts	Accounts are used to register or authenticate a "served" SIP entity (e.g., IP PBX) with a "serving" SIP entity (e.g., a registrar or proxy server). The device does this on behalf of the "served" IP Group. Authentication (SIP 401) is typically relevant for INVITE messages forwarded by the device to a "serving" IP Group. Registration is for REGISTER messages, which are initiated by the device on behalf of the "serving" SIP entity.

The associations between the configuration entities are summarized in the following figure:



The main configuration entities and their involvement in the call processing is summarized in following figure. The figure is used only as an example to provide basic understanding of the configuration terminology. Depending on configuration and network topology, the call process may include additional stages or a different order of stages.



1. The device determines the SIP Interface on which the incoming SIP dialog is received and thus, determines its associated SRD.

2. The device classifies the dialog to an IP Group (origin of dialog), using a specific Classification rule that is associated with the dialog's SRD and that matches the incoming characteristics of the incoming dialog defined for the rule.
3. IP Profile and inbound manipulation can be applied to incoming dialog.
4. The device routes the dialog to an IP Group (destination), using the IP-to-IP Routing table. The destination SRD (and thus, SIP Interface and Media Realm) is the one assigned to the IP Group. Outbound manipulation can be applied to the outgoing dialog.

## Gateway Application Concepts and Terms

The objective of your configuration is to enable the device to forward calls between the IP-based endpoints and PSTN-based endpoints. The PSTN-based endpoints can be or digital endpoints such as ISDN trunks. The IP-based endpoints (SIP entities) can be servers such as SIP proxy servers and IP PBXs, or end users such as LAN IP phones. In the SIP world, the endpoints are referred to as SIP user agents (UA). The UA that initiates the call is referred to as the user agent client (UAC); the UA that accepts the call is referred to as the user-agent server (UAS).

The following table describes the main configuration concepts and terminology.

**Table 1-3: Configuration Concepts and Terminology**


Configuration Terms	Description
IP Groups	An IP Group is a logical representation of the SIP entity (UA) with which the device receives and sends calls. The SIP entity can be a server (e.g., IP PBX or SIP Trunk) or it can be a group of users (e.g., LAN IP phones). For servers, the IP Group is typically used to define the address of the entity (by its associated Proxy Set). IP Groups are typically used in Tel-to-IP routing rules to denote the destination of the call.
Proxy Sets	A Proxy Set defines the actual address (IP address or FQDN) of SIP entities that are servers (e.g., IP PBX). As the IP Group represents the SIP entity, to associate an address with the SIP entity, the Proxy Set is assigned to the IP Group.
SIP Interfaces	<p>A SIP Interface represents a Layer-3 network for the IP-based SIP entity. It defines a local listening port for SIP signaling traffic on a local, logical IP network interface. The term <i>local</i> implies that it's a logical port and network interface on the device. The SIP Interface is used to receive and send SIP messages with a specific SIP entity (IP Group). Therefore, you can create a SIP Interface for each SIP entity in the VoIP network with which your device needs to communicate.</p> <p>The SIP Interface is associated with the SIP entity, by assigning the SIP Interface to an SRD that is in turn, assigned to the IP</p>

Configuration Terms	Description
	Group of the SIP entity.
Media Realms	<p>A Media Realm defines a local UDP port range for RTP (media) traffic on any one of the device's logical IP network interfaces. The Media Realm is used to receive and send media traffic with a specific SIP entity (IP Group).</p> <p>The Media Realm can be associated with the SIP entity, by assigning the Media Realm to the IP Group of the SIP entity, or by assigning it to the SIP Interface associated with the SIP entity.</p>
SRDs	<p>An SRD is a logical representation of your entire VoIP network. The SRD is in effect, the foundation of your configuration to which all other previously mentioned configuration entities are associated.</p> <p>Typically, only a single SRD is required and this is the recommended configuration topology. As the device provides a default SRD, in a single SRD topology, the device automatically assigns the SRD to newly created configuration entities. Thus, in such scenarios, there is no need to get involved with SRD configuration.</p> <p>Multiple SRDs are required only for multi-tenant deployments.</p>
IP Profiles	<p>An IP Profile is an optional configuration entity that defines a wide range of call settings for a specific SIP entity (IP Group). The IP Profile includes signaling and media related settings, for example, jitter buffer, silence suppression, voice coders, fax signaling method, SIP header support (local termination if not supported), and media security method. The IP Profile is in effect, the interoperability "machine" of the device, enabling communication with SIP endpoints supporting different call "languages".</p> <p>The IP Profile is associated with the SIP entity, by assigning the IP Profile to the IP Group of the SIP entity.</p>
Tel Profiles	<p>A Tel Profile is an optional configuration entity that defines a wide range of call settings for a specific PSTN-based endpoint. The IP Profile includes settings such as message waiting indication (MWI), input gain, voice volume and fax signaling method.</p> <p>The Tel Profile is associated with the PSTN-based endpoint, by assigning it to the Trunk Group belonging to the endpoint.</p>
Tel-to-IP Routing Rules	Tel-to-IP routing rules are used to route calls from PSTN-based



Configuration Terms	Description
	endpoints to an IP destination (SIP entity). The PSTN side can be denoted by a specific Trunk Group, or calling or called telephone number prefix and suffix. The SIP entity can be denoted by an IP Group or other IP destinations such as IP address, FQDN, E.164 Telephone Number Mapping (ENUM service), and Lightweight Directory Access Protocol (LDAP).
IP-to-Tel (Trunk Group) Routing Rules	An IP-to-Tel Routing rule is used to route specific incoming IP calls to a specific Trunk Group. The specific channel pertaining to the Trunk Group to which the call is routed can also be configured.
Accounts	An Account is used to register or authenticate PSTN-based endpoints with a SIP entity (e.g., a registrar or proxy server). The device does this on behalf of the PSTN-based endpoint. Authentication (SIP 401) is typically relevant for INVITE messages forwarded by the device to a SIP entity. Registration is for REGISTER messages, which are initiated by the device on behalf of the PSTN-based endpoint.

The following figure shows the main configuration entities and their involvement in call processing. The figure is used only as an example to provide basic understanding of the configuration terminology. Depending on configuration and network topology, the call process may include additional stages or a different order of stages.



# Part I

## Getting Started with Initial Connectivity

## 2 Overview

This part describes how to initially access the device's management interface and change its default IP address to correspond with your networking scheme.

### 3 Default IP Address

The device is shipped with a factory default networking address for operations, administration, maintenance, and provisioning (OAMP), through its LAN interface, as listed in the table below. You can use this address to initially access the device from any of its management tools (embedded Web server, REST API, OVOC, or Telnet/SSH). You can also access the device through the console CLI, by connecting the device's serial (RS-232) port to a PC.

**Table 3-1: Default VoIP LAN IP Address for OAMP**

IP Address	Value
IP Address	192.168.0.2
Prefix Length	24 (255.255.255.0)
Default Gateway	0.0.0.0
VLAN	1
Ethernet Group	GROUP_1
Port	GE_1_1

## 4 Configuring OAMP Interface

You can change the device's default OAMP IP address to suit your networking scheme. You can configure up to two OAMP interfaces, each with a different IP version (IPv4 or IPv6).

You can change the device's default OAMP IP address, using any of the following methods:

- Embedded HTTP/S-based Web server (see [Changing OAMP Address through Web Interface](#) below)
- Embedded CLI (see [Changing OAMP Address through CLI](#) on the next page)
- ini file (see [Changing OAMP Address through ini File](#) on page 16)




If you are implementing the High Availability feature, see also [Overview of High Availability Mode](#) on page 1176 for initial setup.

### Changing OAMP Address through Web Interface

You can change the device's default OAMP networking address through the Web-based management tool (Web interface). The default IP address is used to initially access the device.

#### ➤ To change the default OAMP network address through Web interface:

1. Connect Port 1 (left-most LAN port) located on the front panel directly to the network interface of your computer, using a straight-through Ethernet cable.



2. Change the IP settings of your computer to correspond with the default OAMP IP address and subnet mask of the device.
3. Access the Web interface:
  - a. On your computer, start a Web browser and in the URL address field, enter the default IP address of the device; the Web interface's Web Login screen appears:


- b. In the 'Username' and 'Password' fields, enter the case-sensitive, default login username ("Admin") and password ("Admin").
  - c. Click **Log In**.
4. Configure the Ethernet port(s) that you want to use for the OAMP interface:
  - a. In the Ethernet Groups table, configure an Ethernet Group by assigning it up to two ports (two ports provide optional, port-pair redundancy). For more information, see [Configuring Physical Ethernet Ports](#) on page 149.
  - b. In the Physical Ports table, configure port settings such as speed and duplex mode (see [Configuring Physical Ethernet Ports](#) on page 149).
  - c. In the Ethernet Devices table, configure an Ethernet Device by assigning it the Ethernet Group and a VLAN ID (see [Configuring Underlying Ethernet Devices](#) on page 154).
5. Modify the OAMP interface address to suite your network environment:
  - a. Open the IP Interfaces table (see [Configuring IP Network Interfaces](#) on page 157).
  - b. Select the OAMP interface ("O+M+C"), and then click **Edit**.
  - c. From the 'Ethernet Device' drop-down list, select the Ethernet Device that you configured in the previous step.
  - d. Under the **IP Address** group, change the IP address to correspond with your network IP addressing scheme.
  - e. Under the **DNS** group, configure the DNS server, if required.
  - f. Click **Apply**; the new OAMP address is applied to the device and your connectivity to the device's Web interface at its previous OAMP address is now lost.
6. Change the IP settings of your computer to correspond with the new OAMP IP address and subnet mask that you assigned the device.
7. Access the device using the new OAMP IP address, and then on the Web interface's toolbar, click the **Save** button.
8. Re-cable the device to the desired network. You can now access the device's management interfaces using the new OAMP address.

## Changing OAMP Address through CLI

You can change the default OAMP IP address through the device's CLI. The procedure uses the regular CLI commands. Alternatively, you can use the CLI Wizard utility to set up your device with the initial OAMP settings. The utility provides a fast-and-easy method for initial configuration of the device through CLI. For more information, refer to the document *CLI Reference Guide*.

➤ **To configure the OAMP IP address through CLI:**

1. Connect the RS-232 port of the device to the serial communication port on your computer. For more information, refer to the device's *Hardware Installation Manual*.



2. Establish serial communication with the device using a terminal emulator program such as HyperTerminal, with the following communication port settings:
  - Baud Rate: 115,200 bps
  - Data Bits: 8
  - Parity: None
  - Stop Bits: 1
  - Flow Control: None
3. At the CLI prompt, type the username (default is "Admin" - case sensitive):

```
Username: Admin
```

4. At the prompt, type the password (default is "Admin" - case sensitive):

```
Password: Admin
```

5. At the prompt, type the following:

```
enable
```

6. At the prompt, type the password again:

```
Password: Admin
```

7. Access the Network configuration mode:

```
# configure network
```

8. Access the IP Interfaces table:

```
(config-network)# interface network-if 0  
(network-if-0)#
```

9. Configure the IP address:

```
(network-if-0)# ip-address <IP address>
```

10. Configure the prefix length:

```
(network-if-0)# prefix-length <prefix length / subnet mask, e.g., 16>
```

11. Configure the Default Gateway address:

```
(network-if-0)# gateway <IP address>
```

12. Apply your settings:

```
(network-if-0)# activate
```

13. Cable the device to your network. You can now access the device's management interface using this new OAMP IP address.

## Changing OAMP Address through ini File

You can change the device's default OAMP networking address by loading an ini file with the new OAMP address, through the device's Web interface.

### ➤ To change the default OAMP network address through ini file:

1. Create an ini file using a regular text-based editor program (such as Notepad) and save it with the file extension name **.ini** (e.g., myfile.ini).
2. Copy-and-paste the below ini file table parameter (InterfaceTable) into the ini file:

```
[ InterfaceTable ]  
FORMAT Index = ApplicationTypes, InterfaceMode, IPAddress, PrefixLength,  
Gateway, InterfaceName, PrimaryDNSServerIPAddress,
```



```
SecondaryDNSServerIPAddress, UnderlyingDevice;  
InterfaceTable 0 = 6, 10, <IP Address>, <Prefix Length>, <Default Gateway>,  
"O+M+C", 0.0.0.0, 0.0.0.0, "vlan 1";  
[ \InterfaceTable ]
```

3. Modify the <IP Address>, <Prefix Length>, and <Default Gateway> parameters (but remove the angle brackets).
4. Save the file.
5. Connect to the device's Web interface using the default OAMP address (see [Changing OAMP Address through Web Interface](#) on page 13).
6. Open the Configuration File page (**Setup** menu > **Administration** tab > **Maintenance** folder > **Configuration File**).
7. Under the INI File group, click the **Choose File** button to select the file, and then click **Upload INI File**; the device uploads the file and saves the configuration to flash memory with a device restart.
8. Disconnect the device from your PC and re-connect it to your network.
9. Access the device using the new OAMP interface address.

# Part II

## Management Tools

## 5 Overview

This part describes the various management tools that you can use to configure the device:

- Embedded HTTP/S-based Web server - see [Web-Based Management](#) on page 20
- Embedded Command Line Interface (CLI) - see [CLI-Based Management](#) on page 91
- Simple Network Management Protocol (SNMP) - see [SNMP-Based Management](#) on page 107
- Configuration *ini* file - see [INI File-Based Management](#) on page 126
- REST API - see [REST-Based Management](#) on page 131



- Some configuration settings can only be done using a specific management tool.
- For a list and description of all the configuration parameters, see [Configuration Parameters Reference](#) on page 1563.

## 6 Web-Based Management

The device provides an embedded Web server (hereafter referred to as *Web interface*), supporting fault management, configuration, accounting, performance, and security (FCAPS). The Web interface provides a user-friendly, graphical user interface (GUI), which can be accessed using any standard Web browser. Access to the Web interface can be controlled by various security mechanisms such as login username and password, read-write privileges, and limiting access to specific IP addresses.



- The Web interface allows you to configure most of the device's settings. However, additional configuration parameters may exist that are not available in the Web interface and which can only be configured using other management tools.
- Some Web interface pages and parameters are available only for certain hardware configurations or software features. The software features are determined by the installed License Key (see [License Key](#) on page 1233).

### Getting Acquainted with Web Interface

This section provides a description of the Web interface's graphical user interface (GUI).

#### Computer Requirements

The client computer accessing the device's Web interface requires the following prerequisites:

- A network connection to the device.
- One of the following Web browsers:
  - Microsoft® Edge (Version 100.0.1185.50 or later)
  - Mozilla Firefox® (Version 99.0.1 or later)
  - Google Chrome (Version 100.0.4896.127 or later)



The Web browser must be JavaScript-enabled.

- Recommended screen resolution: 1280 x 1024 pixels, or 1366 x 768 pixels


#### Logging into the Web Interface

The following procedure describes how to access the Web interface.

##### ➤ To log into Web interface:

1. Open a standard Web browser.

2. In the Web browser, enter the device's OAMP IP address (e.g., <http://10.1.10.10>); the Web interface's Web Login window appears:

The image shows a 'Web Login' form. At the top, the title 'Web Login' is centered. Below it, there is a 'Username' label followed by a text input field containing the text 'Admin'. Below the username field is a 'Password' label followed by an empty password input field. At the bottom left, there is a 'Remember Username' label followed by a checked checkbox. At the bottom right, there is a 'Log In' button.

3. In the 'Username' and 'Password' fields, enter your username and password, respectively.
4. If you want the Web browser to remember your username for future logins, select the 'Remember Username' check box. On your next login attempt, the 'Username' field will be automatically populated with your username.
5. Click **Log In**.


By default, autocompletion of the login username is enabled, whereby the 'Username' field predicts the rest of the username while you are typing, by displaying a drop-down list with previously entered usernames. To disable autocompletion, use the [WebLoginBlockAutoComplete] ini file parameter.



- The default login username and password is **Admin** and **Admin**, respectively. To change the login credentials, see [Configuring Local Management User Accounts](#) on page 54.
- The username and password is case-sensitive.
- You can only access the device's Web (and REST) interfaces through a configured Web Interface (see [Configuring Web Interfaces](#) on page 51).
- Depending on your Web browser's settings, a security warning box may be displayed. The reason for this is that the device's certificate is not trusted by your PC. The browser may allow you to install the certificate, thus skipping the warning box the next time you connect to the device. If you are using Windows Internet Explorer, click **View Certificate**, and then **Install Certificate**. The browser also warns you if the host name used in the URL is not identical to the one listed in the certificate. To resolve this, add the IP address and host name (ACL\_nnnnnn, where nnnnnn is the serial number of the device) to your hosts file, located at /etc/hosts on UNIX or C:\Windows\System32\Drivers\ETC\hosts on Windows; then use the host name in the URL (e.g., https://ACL\_280152). Below is an example of a host file:  
127.0.0.1 localhost  
10.31.4.47 ACL\_280152

## Areas of Web Interface


The main areas of the device's Web interface are shown in the figure below and described in the subsequent table:




**Table 6-1: Description of the Web GUI Areas**

Item#	Description
1	Company logo. To customize the logo, see <a href="#">Corporate Logo</a> on page 43. If you click the logo, the Topology View page opens (see <a href="#">Building and Viewing SIP Entities in Topology View</a> on page 643).
2	Menu bar with the following menus:

Item#	Description
	<ul style="list-style-type: none"> <li>■ <b>Setup</b> - access to pages concerned with device configuration.</li> <li>■ <b>Monitor</b> - access to pages concerned with status and performance monitoring.</li> <li>■ <b>Troubleshoot</b> - access to pages concerned with troubleshooting such as logs, debug recording, and call detail records.</li> </ul>
3	<p>Tab bar with tabs pertaining to the selected menu on the Menu bar:</p> <ul style="list-style-type: none"> <li>■ <b>Setup</b> menu: <ul style="list-style-type: none"> <li>✓ <b>IP Network</b> tab</li> <li>✓ <b>Signaling &amp; Media</b> tab</li> <li>✓ <b>Administration</b> tab</li> </ul> </li> <li>■ <b>Monitor</b> menu: <b>Monitor</b> tab</li> <li>■ <b>Troubleshoot</b> menu: <b>Troubleshoot</b> tab</li> </ul>
4	<p>Toolbar providing frequently required commands:</p> <ul style="list-style-type: none"> <li>■ <b>Save:</b> Saves configuration to the device's flash memory (without a restart). When you make a configuration change, the button is displayed with a red border, indicating that you need to save configuration.</li> <li>■ <b>Restart:</b> Opens the Maintenance Actions page, which is used for restarting the device (see <a href="#">Basic Maintenance</a> on page 1203) and for gracefully locking or unlocking the device (see <a href="#">Locking and Unlocking the Device</a> on page 1205). If you make a configuration change that takes effect only after a device restart, the button is displayed with a red border, indicating that you need to restart the device.</li> <li>■ <b>Actions:</b> Drop-down menu containing the following commands: <ul style="list-style-type: none"> <li>✓ <b>Configuration File:</b> Opens the Configuration File page, which is used for uploading or downloading ini, CLI Script, CLI Startup Script, and Configuration Package files (see <a href="#">Downloading and Uploading Configuration Files</a> on page 1257).</li> <li>✓ <b>Auxiliary Files:</b> Opens the Auxiliary Files page, which is used for uploading Auxiliary files (see <a href="#">Uploading Auxiliary Files through Web Interface</a> on page 1221).</li> <li>✓ <b>License Key:</b> Opens the License Key page, which is used for installing a new License Key file (see <a href="#">Installing License Key through Web Interface</a> on page 1235).</li> <li>✓ <b>Software Upgrade:</b> Starts the Software Upgrade Wizard for</li> </ul> </li> </ul>

Item#	Description
	<p>upgrading the device's software file (see <a href="#">Upgrading the Device's (.cmp) Software</a> on page 1213).</p> <ul style="list-style-type: none"> <li>✓ <b>Switchover:</b> Opens the High Availability Maintenance page, which is used for switching between Active and Redundant devices (see <a href="#">Initiating an HA Switchover</a> on page 1197).</li> <li>✓ <b>Configuration Wizard:</b> Opens the SBC Configuration Wizard, which is used for quick-and-easy device configuration (see <a href="#">SBC Configuration Wizard</a> on page 1295).</li> </ul> <p><b>Note:</b> If you have configured any IPv6 interfaces in the IP Interfaces table, the SBC Configuration Wizard is not supported and the <b>Configuration Wizard</b> command is not listed in the <b>Actions</b> menu.</p>
5	<p>Alarm bell icon displaying the number of currently active alarms sent by the device. The color of the number indicates the highest severity of all the active alarms. If you click the icon, the Active Alarms page opens (see <a href="#">Viewing Active Alarms</a> on page 1323). If the device is in HA mode, the icon displays the number of currently active alarms sent by both Active and Redundant devices as well as the highest severity of these active alarms.</p>
6	<p>Button displaying the username of the currently logged-in user. If you click the button, the following drop-down box appears:</p> <div data-bbox="491 1160 1375 1592">  </div> <ul style="list-style-type: none"> <li>■ Displays information of the logged-in user (see <a href="#">Viewing Currently Logged-In User Information</a> on page 72).</li> <li>■ <b>Change Password</b> button changes your login password (see <a href="#">Changing Login Password</a> on page 67).</li> <li>■ <b>Log Out</b> button logs you out of the Web session (see <a href="#">Logging Out the Web Interface</a> on page 42).</li> </ul>




Item#	Description
7	The  icon provides a drop-down list of links to documents related to your device (e.g., Installation Manual, User's Manual, Security Guidelines, and Release Notes). For private labeling (customizing Web interface), this icon is automatically hidden from the toolbar (see <a href="#">Displaying Referenced Document List</a> on page 51).
8	Product name of your device. <b>Note:</b> <ul style="list-style-type: none"> <li>■ If you configure a hostname for the device (see <a href="#">Configuring a Hostname for the Device</a> on page 143), the hostname is displayed instead of the product name.</li> <li>■ You can customize the product name, as described in <a href="#">Customizing the Product Name</a> on page 47.</li> </ul>
9	Navigation pane displaying the Navigation tree containing the commands (items) for opening the configuration pages (see <a href="#">Accessing Configuration Pages from Navigation Tree</a> below).
10	Search box for searching parameters and values (see <a href="#">Searching for Configuration Parameters</a> on page 40).
11	Work pane where configuration pages are displayed and configuration is done.


## Accessing Configuration Pages from Navigation Tree

Accessing configuration pages is a three-fold process that consists of selecting a menu on the menu bar, a tab on the tab bar, and then a page item in the Navigation pane. The Navigation pane provides the Navigation tree, which is a tree-like structure of folders and page items that open configuration pages in the Work pane. The hierarchical structure and organization of the items in the Navigation tree allow you to easily drill-down and locate the required item.

The Navigation tree consists of the following areas:

- **Home**  : (#1 in figure) First ("home") page displayed when a menu-tab combination is initially selected. For example, the home page of the **Setup** menu - **Administration** tab combination is the Time & Date page.
- **Folders:** (#2 in figure) Folders group items of similar functionality. To open and close a folder, simply click the folder name.
- **Items:** (#3 in figure) Items open configuration pages. In some cases, an item may be listed under a sub-item. An item can open a page containing stand-alone parameters or a table. If it opens a page with stand-alone parameters, the item is displayed in italics. If it opens a

page with a table, the item is displayed in regular font, or bold font to indicate an item that is commonly required.



The items of the Navigation tree depend on the menu-tab combination, selected from the menu bar and tab bar, respectively. The menus and their respective tabs are listed below:

■ **Setup menu:**

- IP Network tab
- Signaling & Media tab
- Administration tab

■ **Monitor menu:** Monitor tab

■ **Troubleshoot menu:** Troubleshoot tab

When you open the Navigation tree, folders containing commonly required items are opened by default, allowing quick access to their pages.

Items that open pages containing tables provide the following indications in the Navigation tree:

- **Number of configured rows.** For example, the item below indicates that two rows have been configured:

**Ethernet Groups (2)**

If you have filtered the Web interface display by SRD, the number reflects only the rows that are associated with the filtered SRD.

- **Invalid row configuration.** If you have configured a row with at least one invalid value, a red-colored icon is displayed next to the item, as shown in the following example:

Ethernet Groups (2) ●

If you hover your cursor over the icon, it displays the number of invalid rows (*lines*).

- **Association with an invalid row:** If you have associated a parameter of a row with a row of a different table that has an invalid configuration, the item appears with an arrow and a red-colored icon, as shown in the following example:

Ethernet Devices (2) ➔●

If you hover your cursor over the icon, it displays the number of rows in the table that are associated with invalid rows.

- **Folder containing an item with an invalid row:** If a folder contains an item with an invalid row (or associated with an invalid row), the closed folder displays a red-colored icon, as shown in the following example:

▶ CORE ENTITIES ●

If you hover your cursor over the icon, it displays the names of the items that are configured with invalid values. If you have filtered the Web interface display by SRD, only items with invalid rows that are associated with the filtered SRD are displayed.

#### ➤ To open a configuration page:

1. On the menu bar, click the required menu.
2. On the tab bar, click the required tab; the Navigation tree displays the items pertaining to the selected menu-tab combination.
3. In the Navigation pane, open the folder in which the required item is located. The folders are opened and closed by clicking the title of the folder. When opened, the folder's arrow is displayed as ▲; when closed, the arrow is displayed as ▶.
4. In the folder, click the required item; the page is displayed in the Work pane.




Depending on the access level (e.g., Monitor level) of your Web user account, certain pages may not be accessible or may be read-only (see [Configuring Local Management User Accounts](#) on page 54). For read-only privileges:

- Read-only pages with stand-alone parameters: "Read Only Mode" is displayed at the bottom of the page.
- Read-only pages with tables: Configuration buttons (e.g., **New** and **Edit**) are missing.


## Configuring Global Parameters

Parameters that are not contained in a table are referred to as *global* parameters.

- When entering a value for a parameter, the parameter's field is highlighted and a pop-up box appears, providing a short description of the parameter, for example, valid values.




- When you enter an invalid value, the field is displayed with a red border and a pop-up box describes the problem. In such cases, do one of the following:
  - Click the **Cancel** button (located at the bottom of the page) so that the parameter reverts to its previous value.
  - Enter a valid value.




- When you change a parameter's value from default and then click **Apply**, a dot is displayed next to the parameter's field or check box. In other words, if a dot isn't displayed, the parameter is at its default value.



- When you change a value of a parameter that is displayed with a lightning-bolt icon (see below), you need to save your settings to flash memory with a device **restart** for changes to take effect.



When you change such a parameter and then click **Apply**, the **Restart** button on the toolbar is displayed in a red border, indicating you that you need to restart the device, which you can do by clicking the button:



- Common parameters are displayed in bold font.
- Fields of parameters that configure passwords provide a toggle icon that shows (eye) or hides (eye crossed out) the password when you type it in the field:



The Web interface always hides (by asterisks \*or dots) passwords once they have been configured (i.e., you've clicked **Apply**). Therefore, the toggle eye icon doesn't show them even when clicked.

- Parameters that enable or disable a functionality provide a check box. When selected (i.e., marked), functionality is enabled; when cleared (empty), functionality is disabled. The following shows an example of an enabled functionality:



- Parameters with numerical values provide a field with a spin box. Clicking the up arrow increases the number while clicking the down arrow decreases it.

- To get help on a parameter, hover your mouse over the parameter's field or check box to display a pop-up box with a brief description of the parameter.

The following procedure describes how to configure stand-alone parameters.

➤ **To configure a stand-alone parameter:**

1. Modify the parameter's value as desired.
2. Click **Apply**; the changes are saved to the device's volatile memory (RAM).
3. Save the changes to the device's non-volatile memory (flash):
  - If a device restart is not required:
    - i. On the toolbar, click **Save**; a confirmation message box appears:

*Save Configuration*



Configuration will be saved. Do you wish to continue?

No

Yes

- ii. Click **Yes** to confirm.
- If a device restart is required:
  - i. On the toolbar, click **Restart**; the Maintenance Actions page opens.

- ii. Click **Restart**; the device saves the changes to flash and then restarts.

For more information, see [Restarting the Device](#) on page 1203.



When you click **Apply**, changes are saved only to the device's volatile memory. If the device later undergoes a hardware reset, a software restart (without saving to flash), or powers down, the changes revert to their previous settings. Therefore, make sure that you save your configuration to the device's flash memory.





## Configuring Tables

A typical configuration table is shown below and subsequently described:

The screenshot shows the 'Proxy Sets' configuration page. It includes a table with columns: INDEX, NAME, SRD, GATEWAY IPv4 SIP INTERFACE, PROXY KEEP-ALIVE TIME [SEC], REDUNDANCY MODE, and PROXY HOT SWAP. Below the table, there are configuration details for a selected proxy set, including GENERAL, REDUNDANCY, KEEP ALIVE, and ADVANCED sections. Numbered callouts 1 through 8 highlight specific UI elements as described in the text.

Table 6-2: General Description of Configuration Tables

Item#	Button	Description
1	-	Page title (i.e., name of table). The page title also displays the number of configured rows as well as the number of invalid rows. For more information on invalid rows, see <a href="#">Invalid Value Indications</a> on page 34.
2	+ New	Adds a new row to the table (see <a href="#">Adding Table Rows</a> on the next page).
	Edit	Modifies the selected row (see <a href="#">Editing Table Rows</a> on page 33).

Item#	Button	Description
		Adds a new row with similar settings as the selected row (i.e., clones the row). For more information, see <a href="#">Cloning SRDs</a> on page 559. <b>Note:</b> The button appears only in the SRDs table.
		Deletes the selected row (see <a href="#">Deleting Table Rows</a> on page 33).
		Changes the index position of a selected row (see <a href="#">Changing Table Row Position</a> on page 37).
	<b>Action</b>	Drop-down menu providing commands (e.g., <b>Register</b> and <b>Un-Register</b> ). <b>Note:</b> The button appears only in certain tables (e.g., Accounts table).
<b>3</b>	-	Added table rows displaying only some of the table parameters (columns).
<b>4</b>	-	Detailed view of a selected row, displaying all parameters.
<b>5</b>	-	Link to open the "child" table of the "parent" table. A link appears only if the table has a "child" table. The "child" table is opened for the selected row.
<b>6</b>	-	Navigation bar for scrolling through the table's pages (see <a href="#">Viewing Table Rows</a> on page 36).
<b>7</b>	-	Search tool for searching parameters and values (see <a href="#">Searching Values in Tables</a> on page 38).
<b>8</b>		Modifies the selected row (see <a href="#">Editing Table Rows</a> on page 33).

### Adding Table Rows

The following procedure describes how to add table rows, using the table's **New** button. By default, the row is added to the end of the table and assigned the next available index number (see note in Step 2).

#### ➤ To add a row using the **New** button:

1. On the table's toolbar, click the **New** button; a dialog box appears, displaying the parameters of the table.

2. Configure the parameters as desired, and then click **Apply**; the row is added at the end of the table.




If you don't configure an index number ('Index' parameter), the row is automatically assigned the next available index number in the table. If you configure an index number, use the next available index number, or any subsequent number up to the table's maximum index (capacity).

For example, assume the last existing row is at index 4 and the table's capacity is 10 rows (i.e., indices 0-9):

- If you add a row without specifying an index number, the row is automatically assigned index 5.
- If you want to specify an index number, you can use 5 through 9.
- If you added the row and assigned it index 8, the next time you add a row, it's automatically assigned index 5 or you can specify one of the following the index numbers: 5, 6, 7, or 9.

3. If the **Save** button on the Web interfaces toolbar is surrounded by a red border (see figure below), save your settings to flash memory. If you don't save to flash, your configuration is discarded after the device restarts (without a save to flash) or powers off.



- Commonly required parameters are displayed in **bold font**.
- If you change the value of a parameter (before clicking **Apply**), the parameter's field is highlighted, as shown in the example below:

6010

- If you configure a parameter to an invalid value, the device indicates this using special display properties, as described in [Invalid Value Indications](#) on page 34.
- For configuring parameters that reference rows from other tables, see [Parameter Values Referencing Table Rows](#) on page 39.

## Inserting Table Rows


Some tables (e.g., the Firewall table in [Configuring Firewall Rules](#) on page 248) allow you to insert a new row anywhere in the table, using the table's **Insert** button. Unlike the table's **New** button, which by default, adds the row at the next available index number (see [Adding Table Rows](#) on the previous page), inserting a row allows you to add the row anywhere in the table.

### ➤ To insert a new row:

1. Click the 'Index' column header so that the table rows are sorted in ascending or descending order; the **Insert** button on the table's toolbar becomes available.
2. Select an existing row in the table before which you want to insert the new row.
3. On the table's toolbar, click the **Insert** button; a dialog box appears, displaying the parameters belonging to the table.



4. Configure the parameters as desired, and then click **Apply**; the row is added to the table before the row that you selected in Step 2. The new row adopts the index number of the selected row, and the index numbers of all the subsequent rows are incremented by one. For example, inserting a new row at index 2 shifts the existing row at index 2 to index 3, the previous index 3 to index 4, and so on.
5. If the **Save** button on the Web interfaces toolbar is surrounded by a red border (see figure below), save your settings to flash memory. If you don't save to flash, your configuration is discarded after the device restarts (without a save to flash) or powers off.



### Editing Table Rows

The following procedure describes how to modify (edit) the configuration of an existing table row. Remember that a gray-colored dot icon displayed next to a parameter's value (as shown in the example below), indicates that it was changed from its default value:



#### ➤ To edit a table row:


1. Select the row that you want to edit.
2. Click the **Edit** button, located on the table's toolbar; a dialog appears displaying the current configuration settings of the row.
3. Make your changes as desired, and then click **Apply**; the dialog box closes and your new settings are applied.
4. If the **Save** button is surrounded by a red border, you must save your settings to flash memory, otherwise they are discarded if the device restarts (without a save to flash) or powers off.

### Deleting Table Rows

The following procedure describes how to delete a row from a table.

#### ➤ To delete a table row:

1. Select the row that you want to delete.
2. Click the delete icon, located on the table's toolbar; a confirmation message box appears requesting you to confirm deletion, as shown in the example below:



3. Click **Yes, Delete**; the row is removed from the table and the total number of configured rows that is displayed next to the page title and page item in the Navigation tree is updated to reflect the deletion.



If the deleted row (e.g., a Proxy Set) was referenced in another table (e.g., IP Group), the reference is removed and replaced with an empty field. In addition, if the reference in the other table is for a mandatory parameter, the invalid ● icon is displayed where relevant. For example, if you delete a SIP Interface that you have assigned to a Proxy Set, the invalid icon appears alongside the **Proxy Sets** item in the Navigation tree as well as on the Proxy Sets page.

### Invalid Value Indications

The Web interface provides the following indications of invalid values when configuring table rows:


- **Parameters configured with invalid values:** An invalid value is a value that is not permissible for the parameter. This can include incorrect syntax (string, numeral, or character) or an out-of-range value. If you enter an invalid value and then click **Apply**, the field is surrounded by a colored border, as shown in the example below.

60000000

If you hover your mouse over the field, a pop-up message appears providing the valid values. If you enter a valid value, the colored border is removed from the field. If you leave the parameter at the invalid value and click **Apply**, the parameter reverts to its previous value.


- **Mandatory parameters that reference rows of other configuration tables:**

- **Adding a row:** If you do not configure the parameter and you click **Apply**, an error message is displayed at the bottom of the dialog box. If you click **Cancel**, the dialog box closes and the row is not added to the table. For example, if you do not configure the 'SIP Interface' field (mandatory) for a Proxy Set (in the Proxy Sets table), the below message appears:



- **Editing a row:** If you modify the parameter so that it's no longer referencing a row of another table (i.e., blank value), when you close the dialog box, the **Invalid Line** ● icon appears in the following locations:
  - ◆ 'Index' column of the row.
  - ◆ Page title of the table. The total number of invalid rows in the table is also displayed with the icon.
  - ◆ Item in the Navigation tree that opens the table.


For example, if you do not configure the 'SIP Interface' field (mandatory) for Proxy Set #0, the **Invalid Line** ● icon is displayed for the Proxy Sets table, as shown below:



- **Parameters that reference rows of other configuration tables that are configured with invalid values:** If a row has a parameter that references a row of another table that has a parameter with an invalid value, the **Invalid Reference Line** ➔● icon is displayed in the following locations:

- 'Index' column of the row.
- Page title of the table. The total number of invalid rows in the table is also displayed with the icon.
- Item in the Navigation tree that opens the table.



For example, if you configure IP Group #0 (in the IP Groups table) with a parameter that references Proxy Set #0, which is configured with an invalid value, **Invalid Reference Line** ➔● icons are displayed for the IP Groups table, as shown below:




- **Invalid icon display in drop-down list items of parameters that reference rows of other tables:**

- If the row has an invalid line (see description above), the **Invalid Line** ● icon appears along side the item.

- If the row has an invalid reference line (see description above), the **Invalid Reference Line** icon appears along side it.


For example, when configuring an IP Group, the 'Proxy Set' parameter's drop-down list displays items: Proxy Set #0 with  indicating that it has an invalid parameter value, and Proxy Set #1 with  indicating that it has a parameter that is referenced to a row of another table that has an invalid value:





If you assign a non-mandatory parameter with a referenced row and then later delete the referenced row (in the table in which the row is configured), the parameter's value automatically changes to an empty field (i.e., no row assigned). Therefore, make sure that you are aware of this and if necessary, assign a different referenced row to the parameter. Only if the parameter is mandatory is the **Invalid Line** icon displayed for the table in which the parameter is configured.



### Viewing Table Rows

Tables display a certain number of rows per page. If you have configured more than this number, you can use the table's navigation bar to scroll through the table pages, as shown below and described in the subsequent table:



**Table 6-3: Table Navigation Bar Description**


Item	Description
1	Navigation buttons to view previous table rows:
	 << Displays the previous table page
	 < Displays the first table page (i.e., page with at least the first index row)

Item	Description
2	Navigation buttons to view the next table rows:  Displays the next table page  Displays the last table page (i.e., page with last index row)
3	Currently displayed table page. To open a specific table page, enter the page number and then press the Enter key.
4	Total number of table pages.

### Sorting Tables Rows

You can sort table rows by any column and in ascending order (e.g., 1, 2 and 3 / a, b, and c) or descending order (e.g., 3, 2, and 1 / c, b, and a). By default, most tables are sorted by the Index column and in ascending order.

#### ➤ To sort table rows by column:



1. Click the name of the column by which you want to sort the table rows; the up-down  arrows appear alongside the column name and the up button is displayed in a darker shade of color, indicating that the column is sorted in ascending order:

INDEX 
0
1
2
3
4

2. To sort the column in descending order, click the column name again; only the down arrow is displayed in a darker shade of color, indicating that the column is sorted in descending order:

INDEX 
4
3
2
1
0

### Changing Table Row Position

You can change the position (index) of rows in some tables. This is done by using the up-down   arrows located on the table's toolbar.



- You can only change a row's position when the table is sorted by the 'Index' column in ascending order; otherwise, the ↑ ↓ buttons are grayed out. For sorting table columns, see [Sorting Tables Rows](#) on the previous page.
- Changing row position is supported only by certain tables (e.g., IP-to-IP Routing table).

➤ **To change the position of a table row:**

1. Click the 'Index' column header so that the rows are sorted in ascending order (e.g., 0, 1, 2, and so on).
2. Select the row that you want to move, and then do one of the following:
  - **To move row one or more indexes up:** Click the up ↑ arrow; the row moves one index up in the table (e.g., from Index #3 to #2) and the row that originally occupied the index is moved one index down (e.g., from Index #2 to #3). Continue clicking the arrow until the row has moved up to the desired position (index) in the table.
  - **To move row one or more indexes down:** Click the down ↓ arrow; the row moves one index down in the table (e.g., from Index #3 to #4) and the row that originally occupied the index is moved one index up (e.g., from Index #4 to #3). Continue clicking the arrow until the row has moved down to the desired position (index) in the table.

## Searching Values in Tables

Tables provide a search tool that allows you to search for parameter values.

Your search string can be partial or complete. The searched result displays only the table rows (indexes) in which the value appears. The number of rows in which the searched string appears is shown next to the table name. If the search is unsuccessful, no rows are displayed.

The following figure shows an example of searching the IP Groups table for IP Groups (rows) with parameter values containing the string "itsp". In this example, a match is found in the 'Name' parameter of two rows.

IP Groups (2)

+ New

Edit

Page 1

of 1

Show 10 records per page

itsp

X

INDEX	NAME	SRD	TYPE	SBC OPERATION MODE	PROXY SET	IP PROFILE	MEDIA REALM	SIP GROUP NAME	CLASSIFY BY PROXY SET	INBOUND MESSAGE MANIPULATION SET	OUTBOUND MESSAGE MANIPULATION SET
4	ITSP-A	DefaultSRD	Server	Not Configured	--	--	--		Enable	-1	-1
5	ITSP-B	DefaultSRD	Server	Not Configured	--	--	--		Enable	-1	-1



- The search string is case-insensitive.
- For searching parameters in the Web interface, see [Searching for Configuration Parameters](#) on page 40.

➤ **To search for a parameter value:**

1. In the search box located in the top-right side above the table, enter the value for which you want to search.
2. Click the magnifying-glass icon to run the search.
3. To quit the search tool, click the **x** icon located in the search box.

## Parameter Values Referencing Table Rows

Some parameters reference rows in configuration tables. These parameters can be global parameters or parameters in configuration tables that reference rows in a different configuration table.

For example, the IP Groups table contains the 'Proxy Set' parameter whose value is an assigned Proxy Set, configured in the Proxy Sets table. These parameter types provide a drop-down list for selecting the value and a **View** button, as shown in the example below:



You can assign a referenced-row using one of the following methods:

■ **Selecting a referenced-row from the drop-down list:**

- Scroll down to the desired item and click it.
- Search for the item by entering in the field the first few characters of the desired row, and then clicking it. The figure below shows an example of searched results for items (Proxy Sets) that begin with the letter "i":



■ **Selecting an existing referenced-row directly from the referenced-table:**

- a. Click **View**; the table (e.g., IP Groups table) and dialog box in which the button was clicked is minimized to the bottom-left corner of the Web interface and the referenced-table (e.g., Proxy Sets table) opens.
- b. Add a new row, if required; otherwise, skip this step.
- c. Select the desired row in the row-referenced table, and then click **Use selected row** located on the top-right of the table, as shown in the example below:

↓  
Use selected row


Proxy Sets (3)

+ New Edit [trash icon] Page 1 of 1 Show 10 records per page [search icon]

INDEX	NAME	SRD	GATEWAY IPv4 SIP INTERFACE	SBC IPv4 SIP INTERFACE	PROXY KEEP-ALIVE TIME [SEC]	REDUNDANCY MODE	PROXY HOT SWAP
0	ProxySet_0	DefaultSRD	--	SIPInterface_0	60		Disable
1	ITSP	DefaultSRD	--	ITSP	60		Disable
2	IP-PBX	DefaultSRD	--	IP-PBX	60		Disable

### ■ Adding a new referenced-row:

- a. From the drop-down list, select the **Add new** option; as shown in the example below:



The table (e.g., IP Groups table) and dialog box in which the **Add new** option was selected is minimized to the bottom-left corner of the Web interface and a dialog box appears for adding a new row in the referenced-table (e.g., Proxy Sets table).

- b. Configure the referenced-row and click **Apply**; the referenced-table (e.g., Proxy Sets table) closes and you are returned to the dialog box in which you selected the **Add new** option (e.g., IP Groups table), where the newly added row now appears selected.

You may want to access the referenced-table (e.g., Proxy Sets table) to simply view all its configured rows and their settings, without selecting one. To do this, click the **View** button. To return to the dialog box of the table (e.g., IP Groups table) in which you are making your configuration, click the arrow icon on the minimized dialog box to restore it to its previous size.

## Searching for Configuration Parameters

The Web interface provides a search tool that allows you to search for the following:

- Parameters - standalone parameters and parameters (column headings) in tables
- Tables (by title)
- Pages (by title)

Your search can be based on the Web interface parameter name, ini file parameter name, or CLI command name.



You can search using the full parameter name or a partial string. If you use a partial string, the results include all parameter names and descriptions that contain the string. For example, to search for the 'Secured Web Connection (HTTPS)' parameter, you can use any of the following search strings:

- Partial string: "http"
- Full Web parameter name: "Secured Web Connection (HTTPS)"
- Full ini file parameter name: "HTTPSOnly"
- Full CLI command name: "secured-connection"

When the device completes the search, it displays a list of found results based on the search query. Each possible result, when clicked, opens the page on which the parameter or value is located.




- The search string can include only alphanumeric characters, periods, and spaces.
- The search string is not case-sensitive.
- For searching manually typed values in tables (e.g., IP address or row name), see [Searching Values in Tables](#) on page 38.

➤ **To search for a parameter:**

1. In the search box, enter the search string, for example "https":



2. Click the search  icon; a Search Result window pops up, listing found parameters based on your search query. Searched results for standalone parameters are listed under the **Search by name** group; searched results for parameters in tables are listed under **Search by table**.

Each searched result displays the following:

- Navigation path (link) to the page on which the parameter appears.
- Parameter's Web interface name, where the searched string is displayed in **orange**.
- Parameter description, where the searched string is displayed in **orange**.


Search results for: https		
Search by name:		
Page	Parameter	Description
<a href="#">Administration-&gt;WEB &amp; CLI-&gt;Web Settings</a>	Secured Web Connection ( <b>HTTPS</b> )	Defines secure access (HTTP/S) to the device's Web and REST management interfaces
<a href="#">IP-Network-&gt;HTTP Proxy-&gt;HTTP Proxy Settings</a>	Secondary DNS Server IP	Defines the Secondary DNS server IP address for the HTTP proxy.
<a href="#">Troubleshoot-&gt;Call Detail Record-&gt;Call Detail Record Settings</a>		Defines the name of REST HTTP SERVER from HTTP Remote Services table
SEARCH BY TABLE		
Page	Parameter	Description
<a href="#">IP-Network-&gt;HTTP Proxy-&gt;HTTP Proxy Servers</a>	<b>HTTPS</b> Listening Port	<b>HTTPS</b> Listening Port
<a href="#">Administration-&gt;WEB &amp; CLI-&gt;Web Interfaces</a>	<b>HTTPS</b> Only	<b>HTTPS</b> only indication
<a href="#">Administration-&gt;WEB &amp; CLI-&gt;Web Interfaces</a>	<b>HTTPS</b> Port	Interface <b>HTTPS</b> Port
Close		


- Click the link of the navigation path corresponding to the required found parameter to open the page on which the parameter appears.

## Getting Help

The Web interface provides you with the following options for getting help:

- Tooltip:** When you hover your mouse over a parameter's field, a pop-up appears (tooltip) with a short description of the parameter, as shown in the following example:




- Technical documentation:** If you click the  icon on the toolbar, a drop-down list of document names appear (e.g., Release Notes, Installation Manual and User's Manual). Simply click the required document to view it on AudioCodes website. For private labeling (customizing Web interface), this icon is hidden from the toolbar. However, you can display it, as described in [Displaying Referenced Document List](#) on page 51.

## Logging Out the Web Interface

The following procedure describes how to log out of the device's Web interface.

### ➤ To log out of Web interface:

- On the menu bar, from the 'Admin' drop-down list, click **Log Out**:



A confirmation message box appears.

2. Click **Yes** to confirm; you are logged out the Web session and the Web Login window is displayed, enabling you to log in again if you want.

## Customizing the Web Interface

You can customize the following elements of the device's Web interface (GUI):

- Corporate logo (see [Corporate Logo](#) below)
- Device's (product) name (see [Customizing the Product Name](#) on page 47)
- Web browser tab label (see [Web Browser's Tab Title](#) on page 46)
- Web browser Favicon (see [Customizing the Browser Favicon](#) on page 49)
- Login welcome message (see [Creating a Login Welcome Message](#) on page 50)




- The product name also affects other management interfaces.
- In addition to Web-interface customization, you can also customize the following:
  - ✓ **SIP Messages:** User-Agent header (see the UserAgentDisplayInfo parameter), SDP "o" line (see the SIPSDPSessionOwner parameter), and Subject header (see the SIPSubject parameter).

## Corporate Logo

You can replace the default corporate logo image (i.e., AudioCodes logo) that is displayed in the Web interface. The logo appears in the following Web areas:

- **Web Login screen:**



#### ■ Menu bar:

You can replace the logo with one of the following:

- A different image (see [Replacing the Corporate Logo with an Image](#) below)
- Text (see [Replacing Corporate Logo with Text](#) on the next page)

### Replacing the Corporate Logo with an Image


You can replace the default corporate logo with a different image.



- The logo image file type can be GIF, PNG, JPG, or JPEG.
- The logo image must have a fixed height of 24 pixels. The width can be up to 199 pixels (default is 145).
- The maximum size of the image file can be 64 Kbytes.

#### ➤ To replace the logo:

1. Save your new logo image file to a folder on the same PC that you are using to access the device's Web interface.
2. In your browser's URL address field, append the case-sensitive suffix "/AdminPage" to the device's IP address (e.g., <http://10.1.229.17/AdminPage>).
3. If you're not logged in already, log in with your credentials; the Admin page appears.
4. On the left pane, click **Logo/Favicon Load**; the right pane displays the following:



5. Use the **Browse** (or **Choose File**, depending on your browser) button to select your logo file, and then click **Send File**; the device uploads the file.
6. On the left pane, click **Back to Main** to exit the Admin page.
7. Restart the device with a save-to-flash for your settings to take effect.

### Replacing Corporate Logo with Text

You can replace the logo that is displayed on the Web interface's toolbar with text, as shown in the following example ("My Device"):



#### ➤ To replace Web interface logo with text:

1. Create an ini file that includes the following parameter settings:

```
UseWebLogo = 1
WebLogoText = <text to replace logo, for example, My Device>
```

2. Upload the ini file to the device as an incremental ini file, using the Auxiliary Files page (see [Uploading Auxiliary Files](#) on page 1220).
3. Restart the device with a save-to-flash for your settings to take effect.



Make sure that the [LogoFileName] parameter is not configured to any value. If [LogoFileName] is configured, it overrides [UseWebLogo] and an image will always be displayed.

### Replacing Text with Corporate Logo

If you have replaced the logo with text (as described in [Replacing Corporate Logo with Text](#) above), you can return the logo as described below.

#### ➤ To replace text with logo:

1. Create an ini file that includes the following parameter settings:

```
UseWebLogo = 0
```

2. Load the ini file as an incremental ini file, using the Auxiliary Files page (see [Uploading Auxiliary Files](#) on page 1220).
3. Restart the device with a save-to-flash for your settings to take effect.

## Web Browser's Tab Title

By default, the title (name) of the tab of the web browser that you use to access the device's Web interface displays "AudioCodes". However, you can customize this tab to display one of the following:

- device's IP address - see [Customizing Browser Tab to Display Device's IP Address](#) below
- User-defined text - see [Customizing Browser Tab to Display Text](#) below

### Customizing Browser Tab to Display Device's IP Address

You can customize the tab of the web browser that you use to access the device's Web interface to display the device's IP address.



You can customize the tab to display the device's IP address only if a logo image is used in the Web interface (see [Replacing the Corporate Logo with an Image](#) on page 44).

#### ➤ To display device's IP address on browser tab:

1. Create an ini file that includes the following parameter settings:

```
UseWebLogo = 1
WebLogoText =
```



If you have never configured the [WebLogoText] parameter, you can omit it from the ini file. If you have configured it, then set it to an empty value, as shown above.

2. Upload the ini file as an incremental ini file, using the Auxiliary Files page (see [Uploading Auxiliary Files](#) on page 1220).
3. Restart the device with a save-to-flash for your settings to take effect.

### Customizing Browser Tab to Display Text

You can customize the tab of the web browser that you use to access the device's Web interface to display any user-defined text.



- If you are using the default corporate logo image (AudioCodes) in the Web interface, you can only customize the tab to display "AudioCodes" (default) or the device's IP address (see [Customizing Browser Tab to Display Device's IP Address](#) on the previous page).
- You can customize the tab to display text other than "AudioCodes" only if you are using a non-AudioCodes logo image in the Web interface.
- If you have replaced the corporate logo image with text (see [Replacing Corporate Logo with Text](#) on page 45), the same text is used for the tab.

➤ **To customize browser tab with title text:**

1. Create an ini file that includes the following parameter settings:

- To replace the default text:

```
UseWebLogo = 1
WebLogoText = <your text, for example, Hello>
```

- To restore the tab title to default (i.e., "AudioCodes"):

```
UseWebLogo = 0
```

2. Upload the ini file as an incremental ini file, using the Auxiliary Files page (see [Uploading Auxiliary Files](#) on page 1220).
3. Restart the device with a save-to-flash for your settings to take effect.

## Customizing the Product Name

You can customize the device's product name. The name is displayed in various places in the management interfaces, as shown below using the example of the customized product name "Product":

■ **Web Login screen:**



 A screenshot of the 'Web Login' form. The form is titled 'Web Login' and contains the following elements: a 'Username' label above a text input field containing 'Admin'; a 'Password' label above an empty password input field; a 'Remember Username' checkbox which is checked; and a blue 'Log In' button.

#### ■ Web tab bar:



#### ■ ini file "Board" field:

```
;Board: My Product
```

#### ■ CLI prompt:

```
My Product(config-voip)#
```

### ➤ To customize device's product name:

1. Create a text file using a text editor (e.g., Notepad) with the following parameter settings:

```
UseProductName = 1
UserProductName = <Your Product Name>
```


2. Save the file as a .ini file (e.g., productname.ini).
3. Upload the file to the device as an incremental ini file (see [Uploading Auxiliary Files](#) on page 1220).
4. On the toolbar, click the **Save** button to save your settings to flash memory.
5. Log out of the Web interface; the new product name is now applied.



## Customizing the Browser Favicon

You can replace the default favicon with your own personalized favicon.


Depending on the browser, the favicon is displayed in various areas. For example, it could be displayed in the URL address bar, on the page tab, or when bookmarked.



- The logo image file type can be ICO, GIF, or PNG.
- The maximum size of the image file can be 16 Kbytes.

### ➤ To customize the favicon:

1. Save your new favicon file in a folder on the same PC that you are using to access the device's Web interface.
2. In your browser's URL address field, append the case-sensitive suffix `"/AdminPage"` to the device's IP address (e.g., `http://10.1.229.17/AdminPage`).
3. Log in with your credentials; the Admin page appears.
4. On the left pane, click **Logo/Favicon Load**; the right pane displays the following:



5. Use the **Browse**(or **Choose File**, depending on your browser) button to select your favicon file.
6. Click **Send File**; the device uploads the image file.
7. On the left pane, click **Back to Main** to exit the Admin page.
8. Restart the device with a save-to-flash for your settings to take effect.

## Creating a Login Welcome Message

You can create a personalized welcome message, which is displayed on the Web Login page when you first browse to the device, as shown in the following example:



**Note**  
Welcome!  
This is My SBC  
\*\*\*\*\*

### Web Login

**Username**

**Password**

Remember Username ☒

### ➤ To create a login welcome message:

1. Use a text-based editor (e.g., Notepad) to create an ini file that includes **only** the [WelcomeMessage] table parameter. Each index row is a line in your message. Each message line must be enclosed by double quotation marks ("...") and end with a semicolon (;).

Example:

```
[WelcomeMessage ]
FORMAT Index = Text;
WelcomeMessage 1 = "Welcome";
WelcomeMessage 2 = "This is My SBC";
WelcomeMessage 3 = "*****",
[WelcomeMessage]
```

2. Upload the file to the device as an incremental ini file (see [Uploading Auxiliary Files](#) on page 1220).
3. Save your configuration to flash.



Uploading an ini file through the Auxiliary Files page doesn't require a device restart.


➤ **To remove the welcome message:**


1. Download the device's configuration as an ini file (see [Downloading or Uploading ini File](#) on page 1257).
2. Open the file in a text-based editor.
3. Delete the [WelcomeMessage] table, and then save the file.
4. Upload the file to the device.



After the file is uploaded, the device restarts to apply your new configuration.

## Displaying Referenced Document List

By default, the question mark  icon is displayed on the Web interface's toolbar, and when clicked provides a drop-down list of documents that can be referenced.

If you change the Web interface's logo to a non-default logo, the  icon isn't displayed on the toolbar. However, you can make it re-appear, by adding a forward slash ("/") at the end of the following parameter's value:

```
ExternalDocumentsBaseURL = 'https://acredirect.azurewebsites.net/api/'
```

## Configuring Web Interfaces

The Web Interfaces table lets you configure up to 20 Web interfaces, which are used for accessing the device's Web and REST management interfaces. You can only access these management interfaces through the configured Web Interfaces.

A Web Interface is associated with an IP Interface in the IP Interfaces table. The IP Interface can be of any type (e.g., OAMP, Media, or Control). For each Web Interface, you can also configure secure HTTPS-based remote access, using TLS certificates (TLS Contexts).



Before deleting any Web Interface in the Web Interfaces table, make sure that you have configured **at least one** other Web Interface through which you can access the device's Web / REST management interface. If you delete all the Web Interfaces, you



will not be able to access these management interfaces.



- The Web Interfaces table is applicable only to the device's Web and REST management interfaces.
- The device provides a default Web Interface (Index #0), which is assigned the default IPv4 OAMP IP Interface ("O+M+C", Index 0).
- It's highly recommended to configure a hostname for accessing the device's Web interface, as described in [Configuring a Hostname for Device's Web Interface](#) on page 86. Accessing the device with a hostname helps to protect the device against HTTP Host header attacks and DNS rebinding attacks.

The following procedure describes how to configure Web interfaces through the Web interface. You can also configure it through ini file [WebInterfaces] or CLI (`configure system > web > web-if`).

➤ **To configure Web interfaces:**

1. Open the Web Interfaces table (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Web Interfaces**).
2. Click **New**; the following dialog box is displayed:

Web Interfaces - x

GENERAL

Index	0
Interface Name	#0 [O+M+C] <span style="float: right;">▼ View</span>
HTTP Port	80
HTTPS Port	443
TLS Context Name	#0 [default] <span style="float: right;">▼ View</span>
Require Client Certificate	No ▼
HTTPS Only	Use global definition ▼

3. Configure a Web Interface according to the parameters described in the table below.
4. Click **Apply**, and then save your settings to flash memory.

**Table 6-4: Web Interfaces Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.

Parameter	Description
'Interface Name' network-source [InterfaceName]	<p>Assigns an IP Interface (IPv4 or IPv6) from the IP Interfaces table (see <a href="#">Configuring IP Network Interfaces</a> on page 157) through which the Web / REST management interfaces can be accessed. The IP Interface can be any Application Type (e.g., Media, Control, or OAMP).</p> <p>By default, the IPv4 OAMP interface is assigned.</p>
'HTTP Port' http-port [HTTPPort]	<p>Defines the device's HTTP port for remote management access.</p> <p>The valid range is 1 to 65535. The default is 80.</p>
'HTTPS Port' https-port [HTTPSPort]	<p>Defines the device's HTTPS port for secured remote management access.</p> <p>The valid range is 1 to 65535 (other restrictions may apply within this range). The default is 443.</p>
'TLS Context Name' tls-context-name [TLSContextName]	<p>Assigns a TLS Context, which is configured in the TLS Contexts table (see <a href="#">Configuring TLS Certificate Contexts</a> on page 224). A TLS Context provides secured TLS-based management access.</p> <p>By default, no value is defined.</p> <p><b>Note:</b> The parameter is applicable if you are using HTTPS for remote management access.</p>
'Require Client Certificate' require-client-certificate [HTTPSRequireClientCertificate]	<p>Enables the requirement of client certificates for HTTPS connection.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) Client certificates are not required.</li> <li>■ [1] <b>Enable</b> = Enables the requirement of client certificates for HTTPS connection. This enables two-way authentication whereby both management client and server are authenticated using X.509 certificates.</li> </ul> <p>For more information on implementing client certificates, see <a href="#">Configuring Secured (HTTPS) Web and REST Access</a> on page 74.</p> <p><b>Note:</b> The parameter is applicable if you are using HTTPS for remote management access.</p>
'HTTPS Only'	Defines the protocol required for accessing the

Parameter	Description
https-only-val [HTTPOnly]	<p>device's management interface.</p> <ul style="list-style-type: none"> <li>■ [0] <b>HTTP and HTTPS</b> = The management interface can be accessed over a secured (HTTPS) and an unsecured (HTTP) connection.</li> <li>■ [1] <b>HTTPS Only</b> = The management interface can be accessed only over a secured (HTTPS) connection.</li> </ul>

## Configuring Local Management User Accounts

The Local Users table lets you configure up to 20 management user accounts for the device's management interfaces (Web interface, CLI, and REST API).

The table below lists the different types of user levels.

**Table 6-5: Management User Levels**

User Level	Numeric Representation in RADIUS	Privileges
<b>Security Administrator</b>	200	<p>This user level has the following privileges:</p> <ul style="list-style-type: none"> <li>■ Read-write to all Web pages.</li> <li>■ Read-write (access) to the CLI's Basic mode and Privileged User mode (&gt; enable).</li> <li>■ Access to all the device's folders (e.g., <i>/debug</i> and <i>/configuration</i>) through SFTP.</li> <li>■ Create all other user levels.</li> </ul> <p><b>Note:</b> At least one Security Administrator user must exist.</p>
<b>Administrator</b>	100	<p>This user level has the following privileges:</p> <ul style="list-style-type: none"> <li>■ Read-write to all Web pages, except security-related pages (including Local Users table) where this user has read-only privileges.</li> <li>■ Access to only the CLI's Basic User mode.</li> </ul>
<b>Monitor</b>	50	<p>This user level has the following privileges:</p> <ul style="list-style-type: none"> <li>■ Read-only to all Web pages, except security-related pages (including Local Users table and</li> </ul>

User Level	Numeric Representation in RADIUS	Privileges
		<p>Configuration Wizard) which are blocked to this user.</p> <ul style="list-style-type: none"> <li>■ Access to only the CLI's Basic User mode.</li> <li>■ Access blocked to the device's folders through SFTP.</li> </ul>



- Only **Security Administrator** users can configure users in the Local Users table.
- For the device's REST API user levels, refer to the document [REST API for SBC-Gateway-MSBR Devices](#).
- All users, regardless of user level, can change their login password (see [Changing Login Password](#) on page 67).
- You can change the read-write and read-only privileges per Web page for **Monitor**, **Administrator**, and **Security Administrator** user levels. For more information, see [Customizing Access Levels per Web Page](#) on page 82.
- If the LDAP/RADIUS response doesn't include an access level attribute for determining the user's management access level, the device assigns the access level according to the settings of the 'Default Access Level' parameter.

The device provides the following two default user accounts:

**Table 6-6: Default User Accounts**

User Level	Username (case-sensitive)	Password (case-sensitive)
<b>Security Administrator</b>	<b>Admin</b>	<b>Admin</b>
<b>Monitor</b>	<b>User</b>	<b>User</b>



- For security, it's recommended that you change the default username and password of the default users.
- To restore the device to the default users (with their default usernames and passwords), configure the [ResetWebPassword] parameter to [1]. All other configured accounts are deleted.
- If you want to use the same Local Users table configuration for another device, before uploading this device's configuration file (.ini) to the other device, you **must** edit the file so that the passwords are in plain text.
- If you modify any parameter in the Local Users table of an existing user or delete the user, and the user is currently logged into the device's management interface (i.e., active session), after clicking **Apply** the device immediately logs the user out of the management interface.
- If you delete a user who is currently in an active Web session, the user is immediately logged off the device.
- Web sessions capacity:
  - ✓ The device supports up to 10 concurrent Web interface sessions (regardless of which users are logged in). For example, if user "Sue" and user "Joe" are each currently running 5 sessions (i.e., a total of 10), no more Web sessions can be established with the device, by any user.
  - ✓ Up to five users can be concurrently logged in to the Web interface.
  - ✓ You can define the maximum number of concurrent Web interface (and REST) sessions allowed for a specific user, accessed from different management stations / computers (IP addresses) or different Web browsers. For more information, see the '[Web Session Limit](#)' parameter below.
- You can set the entire Web interface to read-only (regardless of Web user access levels), using the [DisableWebConfig] parameter (see [Management Parameters](#) on page 1563).
- You can configure additional Web user accounts using a RADIUS server (see [RADIUS-based User Login Authentication](#) on page 365).

The following procedure describes how to configure user accounts through the Web interface. You can also configure it through ini file [WebUsers] or CLI (`configure system > user`).

➤ **To configure management user accounts:**

1. Open the Local Users table (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Local Users**).
2. Click **New**; the following dialog box is displayed:



3. Configure a user account according to the parameters described in the table below.
4. Click **Apply**, and then save your settings to flash memory.

**Table 6-7: Local Users Table Parameter Descriptions**

Parameter	Description
<b>General</b>	
'Index' [Index]	<p>Defines an index number for the new table row.</p> <p><b>Note:</b> Each row must be configured with a unique index.</p>
'Username' user [Username]	<p>Defines a username for the user.</p> <p>The valid value is a string of up to 100 characters (without spaces):</p> <ul style="list-style-type: none"> <li>■ Alphanumeric characters (a-z, A-Z, and 0-9)</li> <li>■ Period "."</li> <li>■ Underscore "_"</li> <li>■ Hyphen "-"</li> <li>■ At "@"</li> </ul> <p><b>Note:</b> You can enforce username complexity. For more information, see <a href="#">Configuring Login Username and Password Complexity</a> on page 64.</p>
'Password' password [Password]	<p>Defines a password for the user.</p> <p>The valid value is a string of 8 to 100 ASCII characters, and can't contain the following:</p> <ul style="list-style-type: none"> <li>■ Wide characters</li> <li>■ Spaces</li> <li>■ Backslashes "\"</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ You can enforce password complexity (strong passwords). For more information, see <a href="#">Configuring Login Username and Password Complexity</a> on page 64.</li> <li>■ To enforce password history policy so that users can't reuse any of their four previous (old) passwords, see the <a href="#">[configure system &gt; web &gt; check-password-history</a> on page 1566] parameter.</li> <li>■ For security, the password is not displayed in the Web interface or ini file. In the Web interface, passwords are</li> </ul>

Parameter	Description
	<p>displayed as dots when you enter the password and then once applied, they are displayed as an asterisk (*) in the table. In the ini file, they are displayed as an encrypted string.</p> <ul style="list-style-type: none"> <li>■ To enforce obscured (encrypted) passwords when configuring the Local Users table through CLI, see the <a href="#">[configure system &gt; mgmt-auth &gt; obscure-password-mode on page 1577]</a> parameter.</li> <li>■ You can configure a list of weak passwords (in the Weak Passwords List table) and if the user's password also appears in this list, the device raises an SNMP alarm. For more information, see <a href="#">Detection of Weak Login Passwords on page 66</a>.</li> </ul>
'Confirm Password'	Retype the password that you configured in the 'Password' field (above).
'User Level' privilege [UserLevel]	<p>Defines the user's access level.</p> <ul style="list-style-type: none"> <li>■ <b>Monitor</b> = (Default) Read-only user. This user can only view Web pages and access to security-related pages is denied.</li> <li>■ <b>Administrator</b> = Read/write privileges for all pages except security-related pages including the Local Users table where this user has read-only privileges.</li> <li>■ <b>Security Administrator</b> = Full read/write privileges for all pages.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ At least one <b>Security Administrator</b> user must exist. You can't delete the last remaining <b>Security Administrator</b> user.</li> <li>■ Only <b>Security Administrator</b> users can add, edit, and delete <b>Administrator</b> and <b>Monitor</b> users.</li> </ul>
'SSH Public Key' public-key [SSHPublicKey]	<p>Defines a Secure Socket Shell (SSH) public key for RSA or ECDSA public-key authentication (PKI) of the remote user when logging into the device's CLI through SSH. Connection to the CLI is established only when a successful handshake with the user's private key occurs.</p> <p>The valid value is a string of up to 512 characters. By default, no value is defined.</p> <p><b>Note:</b></p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ For more information on SSH and for enabling SSH, see <a href="#">Configuring CLI over SSH using Public Key Authentication</a> on page 92.</li> <li>■ To configure whether SSH public keys are optional or mandatory, use the [SSHRequirePublicKey] parameter.</li> </ul>
'Confirm SSH Public Key'	Retype the SSH public key that you configured in the 'SSH Public Key' field (above).
'TLS Subject Name' tls-subject-name	<p>Defines the Subject Name of the TLS certificate used for the TLS connection with the user.</p> <p>If this value matches the Subject Name in the certificate in the incoming HTTPS request from the user, the device accepts the login request. If there is no match and the Subject Alternative Name (SAN) is marked "critical", the device blocks the request. If there is no match but the SAN isn't marked "critical", the device checks if the parameter's value matches the certificate's Common Name (CN) and allows login if there is a match.</p> <p>By default, no value is defined.</p> <p>For more information, see <a href="#">Configuring Secured (HTTPS) Web and REST Access</a> on page 74.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The TLS Subject Name must be unique (i.e., two users can't have the same value).</li> <li>■ If you configure this parameter, password configuration ('Password' parameter) is not mandatory.</li> </ul>
'Status' status [Status]	<p>Defines the status of the user.</p> <ul style="list-style-type: none"> <li>■ <b>New</b> = (Default) The user is required to change the password upon the next login. When the user logs in to the Web interface or CLI, the user is immediately prompted to change the current password (see the figure for the 'Password Age' parameter below).</li> <li>■ <b>Valid</b> = User can log in to the Web interface as normal.</li> <li>■ <b>Failed Login</b> = The state is automatically set for users that exceed a user-defined number of failed login attempts, set by the 'Deny Access on Fail Count' parameter (see <a href="#">Configuring Web Session Timeouts</a> on page 73). These users can log in only after a user-defined timeout configured by</li> </ul>

Parameter	Description
	<p>the 'Block Duration' parameter (see below) or if their status is changed (to New or Valid) by a <b>Security Administrator</b> user.</p> <ul style="list-style-type: none"> <li>■ <b>Inactivity</b> = The state is automatically set for users that have not accessed the Web interface for a user-defined number of days, configured by the 'User Inactivity Timer' parameter (see <a href="#">Configuring Web Session Timeouts</a> on page 73). These users can only log in to the Web interface if their status is changed (to <b>New</b> or <b>Valid</b>) by a <b>Security Administrator</b> user.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The <b>Inactivity</b> option is applicable only to <b>Administrator</b> and <b>Monitor</b> users; <b>Security Administrator</b> users can be inactive indefinitely.</li> <li>■ If there is only one Security Administrator user, you cannot configure it to <b>Inactivity</b>; at least one Security Administrator must be <b>Valid</b>.</li> <li>■ For security, it is recommended to configure the status of a newly added user to <b>New</b> in order to enforce password change.</li> <li>■ If you have configured LDAP- or RADIUS-based user authentication, users in the Local Users table whose 'Status' is <b>New</b> are blocked from logging into the device.</li> </ul>
<b>Security</b>	
'Password Age' password-age [PwAgeInterval]	<p>Defines the duration (in days) of the validity of the password. When the duration elapses (i.e., password expires) and you try to log in to the device, you're blocked from logging in and prompted to change the password (as shown below). Configure a new password, and then log in again but with the new password.</p>

Parameter	Description
	<div data-bbox="737 280 1291 770"> <p><b>Change Password</b></p> <p>You must change your password to continue</p> <p>Current Password</p> <input type="password"/> <p>New Password</p> <input type="password"/> <p>Confirm Password</p> <input type="password"/> <p>Cancel Change</p> </div> <p>The valid value is 0 to 10000, where 0 means that the password is always valid (unlimited). The default is 90.</p> <p><b>Note:</b> After logging in with your new password, save your settings by clicking the <b>Save</b> button on the Web interface's toolbar. If not, the next time you attempt to log in, you'll be prompted again to change the expired password.</p>
'Password Expiration Date'	<p>Read-only field that displays the date and time when your login password will expire.</p> <p><b>Note:</b> The field displays an expiration date only if you've configured the 'Password Age' field (above).</p>
'Password status'	<p>Read-only field that displays the status of your login password:</p> <ul style="list-style-type: none"> <li>■ [0] <b>Unlimited</b> = The password hasn't been configured with an expiry date ( see 'Password Age' field above).</li> <li>■ [1] <b>Valid</b> = The password is still valid (i.e., hasn't expired).</li> <li>■ [2] <b>Expired</b> = The password has expired (i.e., reached or exceeded expiration date).</li> </ul>
'Web Session Limit' session-limit [SessionLimit]	<p>Defines the maximum number of concurrent Web interface and REST sessions allowed for the specific user, from different management stations / computers (IP addresses) or different Web browsers.</p> <p>For example, if configured to 2, the user account can be logged into the device's Web interface (i.e., same username-password combination) from two different management stations (i.e., IP addresses), or from two different Web browsers (e.g., Google Chrome and Microsoft Edge) at the same time.</p>

Parameter	Description
	<p>Once the user logs in to the device, the session is active until the user logs off or until the session expires if the user is inactive for a user-defined duration (see the 'Web Session Timeout' parameter below).</p> <p>The valid value is 0 to 10. The default is 5. A value of 0 means that no sessions are allowed (see note below regarding REST).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you configure the parameter, you're automatically logged out of the Web session (and can log in again if configured to any value other than 0) after you click <b>Apply</b>.</li> <li>■ Closing the Web browser's window (by clicking the window's <b>x</b> button) doesn't end the session. Therefore, whenever you finish using the Web interface, it's recommended to log out of the Web interface to end your session.</li> <li>■ If the number of concurrently logged-in users is at maximum, the device allows an additional user to log in through REST.</li> </ul>
'CLI Session Limit' cli-session-limit [CliSessionLimit]	<p>Defines the maximum number of concurrent CLI sessions allowed for the specific user. For example, if configured to 2, the same user account can be logged into the device's CLI (i.e., same username-password combination) from two different management stations (i.e., IP addresses) at any one time. Once the user logs in, the session is active until the user logs off or until the session expires if the user is inactive for a user-defined duration (see the 'Web Session Timeout' parameter below).</p> <p>The valid value is -1, or 0 to 100. The default is -1, which means that the limit is according to the global parameters, 'Maximum Telnet Sessions' (TelnetMaxSessions) or 'Maximum SSH Sessions' (SSHMaxSessions).</p>
'Web Session Timeout' session-timeout [SessionTimeout]	<p>Defines the duration (in minutes) of inactivity of a logged-in user in the Web interface, after which the user is automatically logged off the Web session. In other words, the session expires when the user has not performed any operations (activities) in the Web interface for the configured timeout duration.</p> <p>The valid value is 0, or to 100000. A value of 0 means no timeout. The default value is according to the settings of the [WebSessionTimeout] global parameter (see <a href="#">Configuring Web</a></p>

Parameter	Description
	<a href="#">Session Timeouts</a> on page 73).
'Block Duration' block-duration [BlockTime]	<p>Defines the duration (in seconds) for which the user is blocked when the user exceeds the maximum number of allowed failed login attempts, configured by the global parameter, 'Deny Access On Fail Count' [DenyAccessOnFailCount] parameter (see <a href="#">Configuring Web Session Timeouts</a> on page 73).</p> <p>The valid value is 0 to 100000, where 0 means that the user can do as many login failures without getting blocked. The default is according to the settings of the global parameter, 'Deny Authentication Timer' [DenyAuthenticationTimer] parameter (see <a href="#">Configuring Web Session Timeouts</a> on page 73).</p> <p><b>Note:</b> The 'Deny Authentication Timer' parameter relates only to failed Web logins from specific IP addresses (management stations), which configures the interval (in seconds) that the user needs to wait before logging into the device from the same IP address after reaching the maximum number of failed login attempts.</p>

## Deleting All Users in Local Users Table

When using an external, third-party service (e.g., RADIUS, LDAP, or OAuth 2.0) to authenticate and authorize users attempting to log in to the device, you may want to increase security by ensuring that the device doesn't use its Local Users table to locally authenticate users. To do this, you can remove all from the local Users table.

### ➤ To delete all users in Local Users table:

1. Open the Authentication Server page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Authentication Server**).
2. Select the 'Local Users Table can be Empty' check box:

Local Users Table can be Empty



3. Open the Local Users table (see [Configuring Local Management User Accounts](#) on page 54), and then delete all the users.



Only the **Security Administrator** can delete the last **Security Administrator** user.

## Configuring Login Username and Password Complexity

You can configure the device to enforce username or password complexity. When enforced, the device checks that the configured username or password meets the complexity requirements. If they don't, the device displays an error message indicating invalid configuration.

Username and password complexity is applicable to the following:

- Local users (see [Configuring Local Management User Accounts](#) on page 54)
- SNMP Community Strings (see [Configuring SNMP Community Strings](#) on page 108)
- SNMPv3 users (see [Configuring SNMPv3 Users](#) on page 115)

The device's implementation of username and password complexity depends on configuration:

### ■ Username:

- **'Enforce Username Complexity' is disabled:** The device enforces the default complexity requirements: Can contain up to 100 alphanumeric characters (without spaces), and can contain only the symbols ".", "\_", "-", and "@".
- **'Enforce Username Complexity' is enabled:** The device enforces complexity depending on the following configuration:
  - ◆ 'Username Complexity Check By Regex' is configured: The device enforces username complexity based on the configured regex.
  - ◆ 'Username Complexity Check By Regex' is empty: The device enforces the default username complexity requirements (see 'Enforce Username Complexity' is disabled).

### ■ Password:

- **'Enforce Password Complexity' is disabled:** The device doesn't enforce any password complexity and you can configure the password to whatever you want.
- **'Enforce Password Complexity' is enabled:** The device enforces password complexity depending on whether or not you've configured complexity using regex:
  - ◆ 'Password Complexity Check By Regex' is configured: The device enforces password complexity according to the configured regex.
  - ◆ 'Password Complexity Check By Regex' is empty: The device enforces the default password complexity requirements:
    - At least eight characters
    - At least two uppercase letters (A to Z)
    - At least two lowercase letters (a to z)
    - At least two numbers (0 to 9)
    - At least two symbols (non-alphanumeric characters, e.g., \$, #, %)
    - At least four new characters that weren't used in the previous password





- If you enable password complexity, you can also configure the minimum length (number of characters) of the password, using the [\[configure system > web > min-web-password-len](#) on page 1566] parameter.
- To enforce password history policy so that users can't reuse an old password (can't change password to any of the four previous passwords), see the [\[configure system > web > check-password-history](#) on page 1566] parameter.
- You can configure a list of weak passwords (in the Weak Passwords List table) and if the user's password appears in this list, the device raises an SNMP alarm. For more information, see [Detection of Weak Login Passwords](#) on the next page.
- For the device's CLI, password complexity applies to both Basic and Privileged command mode (> enable). In addition to the default complexity rules listed previously, password complexity for CLI also includes the following requirements:
  - ✓ The username and password must be different.
  - ✓ The username and password can't be the opposite of each other (e.g., "admin" and "nimda").

➤ **To configure username and password complexity:**

1. Open the Local Users Settings table (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Local Users Settings**):

USERNAME COMPLEXITY	
Enforce Username Complexity	<input checked="" type="checkbox"/>
Username Complexity Check By Regex	<input type="text" value="^[A-Za-z0-9.\-_\@]{1,100}\$"/>

PASSWORD COMPLEXITY	
Enforce Password Complexity	<input checked="" type="checkbox"/>
Password Complexity Check By Regex	<input type="text"/>

2. To enforce username complexity by regex, do the following under the **Username Complexity** group:
  - a. Select the 'Enforce Username Complexity' check box (EnforceUsernameComplexity).
  - b. In the 'Username Complexity Check By Regex' field (UsernameComplexityCheckByRegex), type a regex for username complexity.
3. To enforce password complexity, do the following under the **Password Complexity** group:
  - a. Select the 'Enforce Password Complexity' check box (EnforcePasswordComplexity).
  - b. In the 'Password Complexity Check By Regex' field (PasswordComplexityCheckByRegex), either type a regex for password complexity or

leave this field empty to enforce the default password complexity policy (described above).

4. Click **Apply**.

## Detection of Weak Login Passwords

You can configure the device to detect if a management user in the Local Users table has been configured with a weak password. The device detects this by checking if the user's password also appears in the list of defined weak passwords in the Weak Passwords List table. If the device finds a matching entry in the Weak Passwords List table, it raises the SNMP alarm `acWeakPasswordAlarm` (OID 1.3.6.1.4.1.5003.9.10.1.21.2.0.156), which indicates the user (username) for which the weak password was configured.

To configure this feature, you need to do the following:

1. Enable weak password detection - see [Enabling Detection of Weak Password](#) below
2. Configure a list of weak passwords - see [Configuring the Weak Passwords List](#) below

### Enabling Detection of Weak Password

The following procedure describes how to enable the weak password detection feature. Once you have enabled the feature, you can configure in the Weak Passwords List table (see [Configuring the Weak Passwords List](#) below) a list of passwords that you want the device to consider as weak.

#### ➤ To enable weak password detection:

1. Open the Web Settings page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Web Settings**).
2. Select the 'Check Weak Passwords' check box:

Check Weak Passwords ☒

3. Click **Apply**.

### Configuring the Weak Passwords List

The Weak Passwords List table lets you configure up to 150 passwords that you want the device to consider as weak. If a user's password in the Local Users table also appears in the Weak Passwords List table, the device raises the SNMP alarm `acWeakPasswordAlarm` (OID 1.3.6.1.4.1.5003.9.10.1.21.2.0.156), indicating that a weak password was configured for the specific user (Username). The alarm is cleared if the user's password is reconfigured to a password that is not considered weak (i.e., not in the Weak Passwords List table), or if the user is deleted from the Local Users table (see [Configuring Local Management User Accounts](#) on page 54).



- Before you can use the device's weak password detection feature, you need to enable the feature (see [Enabling Detection of Weak Password](#) on the previous page.)
- By default, the Weak Passwords List table contains six weak passwords: "Admin", "mindA", "password", "Password", "123456", and "12345678". You can modify or delete these entries.

The following procedure describes how to configure the weak password list through the Web interface. You can also configure it through ini file [WeakPasswordsList] or CLI (`configure system > web > weak-passwords-list`).

➤ **To configure a list of weak passwords:**

1. Open the Weak Passwords List table (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Weak Passwords List**).
2. Click **New**; the following dialog box is displayed:

3. Configure a weak password according to the parameters described in the table below.
4. Click **Apply**, and then save your settings to flash memory.

**Table 6-8: Weak Passwords List Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Weak Password' weak-pass [WeakPassword]	Defines a weak password. The valid value is a string of up to 39 characters.

## Changing Login Password


Regardless of your user level (e.g., Monitor or Administrator), you can change your login password through the Change Password dialog box, accessed from the Web interface's top bar.



- Security Administrator users can also change passwords for themselves and for other user levels in the Local Users table (see [Configuring Local Management User Accounts](#) on page 54).
- For valid passwords, see the 'Password' parameter in the Local Users table.
- You can only change the password if the duration, configured by the 'Password Change Interval' parameter (Web Settings page - **Setup** menu > **Administration** tab > **Web & CLI** folder > **Web Settings**), has elapsed since the last password change.

➤ **To change the login password:**

1. On the top bar of the Web interface, click the username that is displayed for the currently logged-in user (e.g., "Admin"); a drop-down box appears:



2. Click **Change Password**; the following appears:

3. In the 'Current Password' field, enter your current login password.
4. In the 'New Password' field, enter your new password, and then in the 'Confirm Password' field, enter your new password again.
5. Click **Change**; you are logged off the Web session and prompted to log in again with your new password.

## Configuring Login Password Expiration Alarm

By default, the device sends the SNMP alarm `acExpiredPasswordAlarm` (OID 1.3.6.1.4.1.5003.9.10.1.21.2.0.161) 14 days before your login password is about to expire. This reminds you to change your password (as described in [Changing Login Password](#) on page 67). The alarm is sent with minor severity level and is automatically cleared when you successfully change the password.

You can configure when you want the device to send the alarm before password expiration.

### ➤ To configure when password expiration alarm sent:

1. Open the Web Settings page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Web Settings**).
2. Under the **Security** group, in the 'Password Expired Alarm' field, type the number of days before password expiration when you want the device to send the alarm:

Password Expired Alarm [days]



A value of 0 disables this alarm from being sent.

3. Click **Apply**.

## User Login Authentication Methods

The device supports the following methods for the authentication (username-password combination) and authorization (privilege level) of users when logging into the device:

- Locally, using the device's Local Users table (see [Configuring Local Management User Accounts](#) on page 54)
- Externally, using any of the following protocols:
  - RADIUS-based authentication, using a third-party RADIUS server (see [RADIUS-based User Login Authentication](#) on page 365)
  - LDAP-based authentication, using a third-party LDAP server (see [LDAP-based Services](#) on page 369)
  - OAuth 2.0 based authentication, using Microsoft Azure Active Directory (see [OAuth-based User Login Authentication and Authorization](#) on page 408)

## Denying Access for Failed Login Attempts

You can configure the device to block users or management stations (IP addresses) from accessing the web interface if the user enters incorrect login credentials for a user-defined number of successive login attempts.



Only **Security Administrator** users can perform the configuration described in this section. For more information, see [Configuring Local Management User Accounts](#) on page 54.

➤ To configure deny access upon failed login attempts:

1. Open the Web Settings page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Web Settings**).
2. Under the **Security** group, configure the following parameters:

#### SECURITY

Deny Authentication Timer	<input type="text" value="60"/>
Blocking Duration Factor	<input type="text" value="1"/>
Valid time of Deny Access counting	<input type="text" value="60"/>
Deny Access On Fail Count (0 = No Deny)	<input type="text" value="3"/> 

- 'Deny Authentication Timer' [DenyAuthenticationTimer]: Define the duration (in seconds) for which login to the Web interface is denied from a specific IP address (management station) for **all** users, when the number of failed login attempts has exceeded the maximum. To configure the blocked duration **per user**, use the 'Block Duration' parameter in the Local Users table (see [Configuring Local Management User Accounts](#) on page 54).
- 'Blocking Duration Factor' [BlockDurationFactor]: Define the number to multiple the previous blocking time for blocking the IP address or the user upon the next failed login scenario.
- 'Value time of Deny Access counting' [DenyAccessCountingValidTime]: Defines the maximum time interval (in seconds) between failed login attempts to be included in the count of failed login attempts for denying access to the user.
- 'Deny Access On Fail Count' [DenyAccessOnFailCount]: Define the maximum number of failed login attempts, after which the requesting IP address (management station) for all users is blocked.



For a detailed description of the parameters mentioned above, see [Web Parameters](#) on page 1568.

3. Click **Apply**.

## Displaying Login Information upon Login

You can enable the device to display login information each time you log in to the device's Web interface. This information is displayed in the pop-up Login Information window, as shown in the example below. To close the window, click **Close**.

Login Information <span>x</span>	
Last Login Privilege	Security Administrator
Last Failed Login Date and Time	2025-03-18T03:17:02
Last Failed Login IP	10.11.2.2
Login Attempts Since Last Success	0
Last Successful Login Date and Time	2025-03-23T03:14:39
Last Success Login IP	10.11.2.2
Number Of Other Sessions	1

The window displays the following information:

Field	Description
'Last Login Privilege'	The user level (e.g., <b>Security Administrator</b> ) of the user that was last logged into the Web interface.
'Last Failed Login Date and Time'	The date and time of the most recent failed login attempt.
'Last Failed Login IP'	The IP address of the remote management (client) from which the last failed login attempt was made.
'Login Attempts Since Last Success'	The total number of failed login attempts since the last successful login.
'Last Successful Login Date and Time'	The date and time of the most recent successful login attempt.
'Last Success Login IP'	The IP address of the remote management (client) from which the last successful login was made.
'Number of Other Sessions'	The number of currently active web sessions for the same user (e.g., "John") with the same user level (e.g., <b>Security Administrator</b> ). A value of "0" indicates no other active web sessions. <b>Note:</b> If other active sessions exist, you can

Field	Description
	end them as described in <a href="#">Terminating Other Active Web Sessions of User</a> on the next page.

➤ **To enable display of user login information upon login:**

1. Open the Web Settings page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Web Settings**).
2. Select the 'Display Last Login Information' check box:

Display Last Login Information ☒


3. Click **Apply**.

## Viewing Currently Logged-In User Information

You can quick-and-easily view brief information about the currently logged-in user.

➤ **To view information of currently logged in user:**

- On the menu bar, click the displayed username (e.g., **Admin**); the following drop-down window appears:



The following information is displayed:

- Username of the currently logged-in user (e.g., "Admin").
- User level of the currently logged-in user (e.g., **Security Administrator**).
- Duration of the current Web session (since logging in).
- Number of other active Web sessions of the same user and with the same user level. To end other sessions, see [Terminating Other Active Web Sessions of User](#) on the next page.



The following buttons are also displayed:


- **Change Password:** Allows you to change your login password (see [Changing Login Password](#) on page 67).
- **Log Out:** Logs you out of the Web session (see [Logging Out the Web Interface](#) on page 42).

## Terminating Other Active Web Sessions of User

You can end other established (active) Web sessions belonging to the same logged-in user (e.g., "Admin") and with the same user level (e.g., Administrator Security). These other sessions may be logged in from different computers or web browsers.

### ➤ To end other Web sessions of user:

1. On the menu bar, click the displayed username (e.g., **Admin**); the following drop-down window appears, displaying the number of other active sessions of the user in the 'Number Of Other Sessions' field (e.g., 1 other session):



2. Click the delete icon corresponding to the 'Number Of Other Sessions' field; the other session(s) are immediately terminated and logged out of the Web interface.

## Configuring Web Session Timeouts

You can configure the following timeouts for the device's Web interface:

- **Logged-in timeout:** The user is blocked from logging into the Web interface if the user has not logged in within a user-defined duration.
- **Session timeout:** The user is logged out of the Web interface if inactive for a user-defined duration.



Only **Security Administrator** users can perform the configuration described in this section.

➤ **To configure Web user sessions and access security:**

1. Open the Web Settings page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Web Settings**).
2. Under the **Session** group, configure the following parameters:

SESSION	
Password Change Interval (minutes)	<input type="text" value="1440"/>
User Inactivity Timeout (days)	<input type="text" value="90"/>
Session Timeout (minutes)	<input type="text" value="60"/>

- 'User Inactivity Timeout': If the user has not logged into the Web interface within this duration, the status of the user becomes inactive and the user can no longer access the Web interface. The user can only log in to the Web interface if its status is changed (to **New** or **Valid**) by a **Security Administrator** user.
- 'Session Timeout': Defines the duration (in minutes) of inactivity (i.e., no actions are performed in the Web interface) of a logged-in user, after which the Web session expires and the user is automatically logged out of the Web interface and needs to log in again to continue the session. You can also configure this timeout per user in the Local Users table (see [Configuring Local Management User Accounts](#) on page 54), which overrides this global setting.

3. Click **Apply**.

For a detailed description of the above parameters, see [Web Parameters](#) on page 1568.

## Configuring Secured (HTTPS) Web and REST Access

By default, the device allows remote management (client) to the device's Web and REST interfaces through both HTTP and HTTPS. However, you can enforce secure (HTTPS) access so that the device allows only HTTPS requests.

By default, servers using TLS provide one-way authentication. The client is certain that the identity of the server (i.e., device) is authentic.

When an organizational Public Key Infrastructure (PKI) is used, two-way authentication (mutual TLS authentication or mTLS) may be desired; both client and server (i.e., device) are authenticated using X.509 certificates. This is achieved by installing a client certificate on the client side (e.g., management computer, web browser, or REST-management tool) and uploading the Certification Authority's (CA) root certificate to the device's Trusted Root Certificates table (certificate root store). The Trusted Root Certificate file may contain more than one CA certificate (combined using a text editor).

The device's REST-based management interface supports mTLS that also conditions access based on the certificate's subject name—Subject Alternative Name (SAN) or Common Name

(CN). When a user attempts to connect to the REST interface, the device verifies whether the subject name in the client's certificate matches the 'TLS Subject Name' parameter value configured for any user in the Local Users table. If a match is found, the client is automatically authenticated, without needing to enter a username or password. The authenticated client is granted the user permission level associated with the corresponding user in the Local Users table.

When a user attempts to connect to the device's secured Web or REST interface:

- If the user has a client certificate from a CA that is listed in the device's Trusted Root Certificate store, the device accepts the connection and prompts the user for the login password.
- If both the client certificate and CA certificate are in the Trusted Root Certificate store, the user is not prompted for a password. This provides a single sign-on (SSO) experience; authentication is performed only using the X.509 digital signature.
- If the user's client certificate isn't from a listed CA or doesn't have a client certificate, the device rejects connection.



- For secure management through the device's default management network interface (i.e., **OAMP** Application Type in the IP Interfaces table), the device uses the default TLS Context (Index #0 and named "default"). However, for secure Web- and REST-based management using additional management interfaces configured in the Web Interfaces table (see [Configuring Web Interfaces](#) on page 51), you can use any TLS Context.
- The 'Secured Web Connection (HTTPS)' parameter (mentioned below) is applicable to both Web- and REST-based management.

You can enforce HTTPS access to the Web and REST interfaces through the default management IP interface (#0) by configuring either a global parameter or the Web Interfaces table. However, using the Web Interfaces table is recommended, as it provides greater flexibility. In addition to configuring the Web Interface for the default IP interface, the table allows you to create additional management interfaces and offers enhanced functionality.

➤ **To configure HTTPS for Web and REST using global parameter:**

1. Open the Web Settings page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Web Settings**), and then do the following.
2. From the 'Secured Web Connection (HTTPS)' drop-down list, select **HTTPS Only**:

Secured Web Connection (HTTPS) • HTTPS Only ▼

3. Click **Apply**.

The following procedure describes how to configure HTTPS and mTLS for accessing the Web and REST interfaces.

➤ **To configure HTTPS and mTLS for Web and REST:**

1. **(mTLS)** Add client TLS certificates to your third-party REST management tool or web browser. For examples, see the following sections:
  - [Adding Client Certificate to Web Browser Client](#) on page 80
  - [Adding TLS Certificates to REST Client](#) on page 79
2. Open the Web Interfaces table (see [Configuring Web Interfaces](#) on page 51), and then configure the default Web Interface which uses the default IP network interface (**#0**) or configure a new Web Interface:
  - a. From the 'TLS Context Name' drop-down list, select a TLS Context in the TLS Contexts table.
  - b. **(mTLS)** From the 'Require Client Certificates' drop-down list, select **Yes**.
  - c. From the 'HTTPS Only' drop-down list, select **HTTPS only**.
  - d. Click **Apply**.


The screenshot shows a web browser window titled "Web Interfaces". Inside, there's a "GENERAL" tab. The form contains the following fields and values:

Field	Value
Index	0
Name	
Interface Name	#0 [O+M+C] (with a "View" link)
HTTP Port	80
HTTPS Port	443
TLS Context Name	#0 [default]
Require Client Certificate	Yes
HTTPS Only	HTTPS only

3. **(mTLS)** Import the client's certificate file that was issued by the CA into the device's Trusted Root Certificates store:
  - a. Open the TLS Contexts table (see [Configuring TLS Certificate Contexts](#) on page 224).
  - b. Select the required TLS Context, and then click the **Trusted Root Certificates** link located below the table; the Trusted Root Certificates table appears.
  - c. Click **Import**, and then select the certificate file to import.
4. **(mTLS for REST)** To use the TLS subject name as a matching criteria between the client's certificate and a user in the Local Users table:


- a. Open the Local Users table (see [Configuring Local Management User Accounts](#) on page 54).
- b. For the required user, configure the 'TLS Subject Name' parameter with the Subject Alternative Name or Common Name of the client's certificate.
- c. Click **Apply**.

The example below shows the configured 'TLS Subject Name' as "rest\_usr1":



GENERAL		SECURITY	
Index	2	Password Age [days]	90
Username	Admin2	Password Expiration Date	2025-06-09 06:19:35
Password	*	Password status	Valid
Confirm Password	*	Web Session Limit	5
User Level	Administrator	CLI Session Limit	-1
SSH Public Key		Web Session Timeout [min]	30
Confirm SSH Public Key		Block Duration [sec]	60
TLS Subject Name	rest_usr1		
Status	Valid		

The TLS subject name can be found in the Common Name (CN) or Subject Alternative Name fields of the client's certificate. Below shows "rest\_usr1" in the Subject Alternative Name field:



- The value of the 'TLS Subject Name' parameter for each user in the Local Users table must be unique.
- If you configure the 'TLS Subject Name' parameter, password configuration for the user is not mandatory.

5. Restart the device with a save-to-flash for your settings to take effect.



- Installing a client certificate on your computer is beyond the scope of this document. For more information, refer to your operating system documentation and consult with your security administrator.
- You can also upload the root certificate using the device's Auto-Update mechanism (see the [HTTPSRootFileName] parameter).
- You can enable the device to verify if a peer's certificate has been revoked by an OCSP server per TLS Context (see [Configuring TLS Certificate Contexts](#) on page 224).

## Adding TLS Certificates to REST Client

The following procedure describes how to add a client certificate in Postman, the third-party REST tool. This is required when using Mutual TLS (mTLS) authentication with the device's REST API.

➤ **To add client certificate in Postman:**


1. Start your Postman application.
2. On the toolbar, click the grid icon, and then from the drop-down menu, choose **Settings**.
3. Select the **Certificates** tab.
4. Click **Add Certificates**, and then do the following:
  - a. In the 'Host' field, type the device's IP address (or hostname).
  - b. Select the **CRT file** and the **Key file** for your certificate.
  - c. Click **Add**.

The screenshot shows the 'Add certificate' dialog in Postman. On the left, a sidebar lists settings: General, Themes, Shortcuts, Data, Add-ons, Certificates (selected), Proxy, Update, and About. The main panel is titled 'Add certificate' and contains the following fields:

- Host (required):** A text field containing 'https://' and a port field containing '443'.
- CRT file:** A field containing 'certificate.crt' with a close button.
- KEY file:** A field containing 'certKey.key' with a close button.
- PFX file:** A field with a 'Select File' button.
- Passphrase:** An empty text field with a toggle icon.

At the bottom, there are 'Add' and 'Cancel' buttons, and a link that says 'Learn more about [working with certificates](#)'.

5. For your URL endpoint:
  - a. Make sure that the URL endpoint is "https" (not "http").
  - b. Click the **Authorization** tab, and then from the 'Auth Type' drop-down list, select **No Auth**.



Once you've add the trusted root certificate to the device, your REST requests through Postman are seamless, eliminating any need to provide username and password.


## Adding Client Certificate to Web Browser Client

The following procedure describes how to add a client certificate to your web browser (e.g., Google Chrome). This is required when using Mutual TLS (mTLS) authentication with the device's REST API or Web interface.

### ➤ To add client certificate to web browser (e.g., Google Chrome):


1. Open your Chrome web browser.
2. In the top-right corner, click the ellipsis button, and then choose **Settings**.
3. Select **Privacy and security**, and then click **Security**.
4. Under 'Advanced', select **Manage certificates**, and then click **Manage imported certificates from Windows**:





5. Click **Import**, and then use the wizard to import your .pfx certificate file.

Once you've add the trusted root certificate to the device, your REST requests through the web browser are seamless, **eliminating** the need to provide user credentials (username and password). However, upon initial connection, your browser may prompt you to select the new certificate that you imported into the browser:



## Enabling CSRF Protection

The device's embedded Web server provides support for cross-site request forgery (CSRF) protection. CSRF prevents malicious exploits of a website, whereby unauthorized commands are transmitted from a user that the website trusts (i.e., authenticated user). Whenever a user opens (i.e., GET method) one of the device's Web pages, the device automatically generates a CSRF "token" (unique number). When the user performs actions (i.e., POST method) on that page (e.g., configures parameters), the token is included to verify that the authenticated user is the one performing the actions.

To enable CSRF protection, use the ini file parameter [CSRFProtection] or CLI command `configure system > web > csrf-protection`.

## Customizing Access Levels per Web Page

The Customize Access Level table lets you configure up to 100 Customize Access Level rules. These rules assign read-write (view and configure) and read-only (view) privileges to Web interface pages based on management user levels (**Monitor**, **Administrator**, and **Security Administrator**).

The user level you assign for a page applies to that level and all higher levels. For example, if you grant read-write access for the RADIUS Servers page to the **Administrator** user level, the **Security Administrator** user level also inherits read-write access. You can restrict (block) access for a page by specifying a high user level for read-only access. For example, if you grant read-only access to the RADIUS Servers page to the **Administrator** user level, it means that **Monitor** users won't be able to access this page.

If you try to open a page for which you don't have access privileges because of your user level, the page displays the following message: "Your access level doesn't allow you to view this page".



- Customized Access Level rules override the default read-write and read-only privileges assigned to the user levels (see [Configuring Local Management User Accounts](#) on page 54).
- The highest user level is **Security Administrator** and the lowest is the **Monitor** user level.
- Read-only access level must be the same or lower than the read-write access level. For example:
  - ✓ Read-Write Access Level = **Security Administrator**
  - ✓ Read-Only Access Level = **Administrator**
- For parent-child tables, the access level of the child table must be the same or higher than the parent table. For example:
  - ✓ Parent table:
    - Read-Write Access Level = **Administrator**
    - Read-Only Access Level = **Administrator**
  - ✓ Child table:
    - Read-Write Access Level = **Security Administrator**
    - Read-Only Access Level = **Administrator**

The following table provides configuration examples to facilitate your understanding of assigning read-write and read-only privileges to user levels per Web page.

Index	Page Name	Read-Write Access Level	Read-Only Access Level	Description
0	RADIUS Servers	Monitor	Monitor	Assigns read-write (and read-only) privileges for the RADIUS Servers page to <b>Monitor</b> users. As this is the lowest user level, it means that all higher user levels (i.e., <b>Administrator</b> and <b>Security Administrator</b> ) also have read-write access.
1	Firewall	Security Administrator	Monitor	Assigns read-write privileges for the Firewall page to <b>Security Administrator</b> users. As this is the highest user level, only <b>Security Administrator</b> users have write privileges for this page. This rule also assigns read-only privileges to <b>Monitor</b> users, which means that all higher user levels (i.e., <b>Administrator</b> ) also have read-

Index	Page Name	Read-Write Access Level	Read-Only Access Level	Description
				only privileges.
2	SNMP Community Strings	Security Administrator	Administrator	Assigns read-write privileges for the SNMP Community Strings page to <b>Security Administrator</b> users. As this is the highest user level, only <b>Security Administrator</b> users have write privileges for this page. This rule also assigns read-only privileges to <b>Administrator</b> users, which means that <b>Monitor</b> users can't access this page.
3	TLS Contexts	Security Administrator	Security Administrator	Assigns read-write (and read-only) privileges for the TLS Contexts page to <b>Security Administrator</b> users. As this is the highest user level, no other user level can access (read) or configure (write) this page.

The following procedure describes how to configure customized access level rules through the Web interface. You can also configure it through ini file [WebPagesAccessLevel].

➤ **To customize access levels:**

1. Open the Customize Access Level table (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Customize Access Level**).
2. Click **New**; the following dialog box is displayed:

3. Configure the rule according to the parameters described in the table below.
4. Click **Apply**, and then save your settings to flash memory.

**Table 6-9: Customize Access Level Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Page Name' [PageNameFromTree]	Defines the Web page whose access level you want to customize. <b>Note:</b> For security reasons, some pages are not listed under this parameter and therefore, cannot be customized.
'Read-Write Access Level' [RWAccessLevel]	Defines the <b>minimum</b> user level to which you want to assign read-write access privileges for the selected Web page.  <div> <div></div> [50] <b>Monitor</b> </div> <div> <div></div> [100] <b>Administrator</b> (default) </div> <div> <div></div> [200] <b>Security Administrator</b> </div>
'Read-Only Access Level' [ROAccessLevel]	Defines the <b>minimum</b> user level to which you want to assign read-only access privileges for the selected Web page.

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [50] <b>Monitor</b> (default)</li> <li>■ [100] <b>Administrator</b></li> <li>■ [200] <b>Security Administrator</b></li> </ul> <p><b>Note:</b> The user level must be the same or lower than the user level you configured in the 'Read-Write Access Level' parameter. For example, you can't assign read-only privileges to the <b>Security Administrator</b> if you assigned read-write privileges to the <b>Administrator</b>.</p>

## Configuring a Hostname for Device's Web Interface

You can configure a hostname (FQDN) for the device's Web interface. This means that you can access the Web interface using the device's hostname (e.g., `http://mysbc.com`) instead of its IP address. You can also enforce (default) access only through the device's hostname, blocking any access attempts using its IP address.

If you configure a hostname, you also need to define it on a DNS server. When you try to access the Web interface with the hostname, a query is first sent to the DNS server to resolve the hostname into the device's IP address.

If you access the device's Web interface using its hostname, the toolbar displays the hostname (first 16 characters only) instead of the device type.



It's recommended to configure a hostname for accessing the device's Web interface because it helps protect the device against HTTP Host header attacks and DNS rebinding attacks.

### ➤ To configure a hostname for Web interface:

1. Open the Web Settings page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Web Settings**).
2. In the 'Web Server Name' field [WebHostname], type a hostname:

Web Server Name

• sbcols1.eastus.12345.com

3. To enforce access to the device's Web interface **only** through the hostname (not IP address), select the 'Enforce Web Host Name' check box:

Enforce Web Host Name



4. Click **Apply**.



Due to a known issue, the following OVOC features do **not** function when the 'Enforce Web Host Name' parameter is enabled:

- OVOC Single Sign-On (SSO)
- OVOC Performance Monitoring (PM)
- OVOC Service Availability

If you need to use any of these OVOC features, make sure that the 'Enforce Web Host Name' parameter is disabled.



- If you disable the 'Enforce Web Host Name' parameter, or you leave the 'Web Server Name' parameter empty (regardless of the 'Enforce Web Host Name' parameter's setting), the Web interface can be accessed through its hostname or IP address.
- If you're upgrading the device from version 7.4.500-2 (7.40A.500.775) or later to version 7.4.500-5 or later and have configured the 'Web Server Name' parameter and use the device's IP address to access the Web interface, access to the device through the IP address will be denied. If you want to retain such capability, disable the 'Enforce Web Host Name' parameter.
- When the device operates in High-Availability mode, the active and redundant units share the same hostname.
- To configure a hostname that is used for the CLI prompt name, SNMP interface's SysName object value, and communication with OVOC, see [Configuring a Hostname for the Device](#) on page 143.

## Configuring Management Access List

The Management Access List table lets you control access to the device's management interfaces (Web, REST API, SSH, and Telnet). You can define up to 50 rules, where each rule defines a management station (client) by IP address (IPv4 or IPv6) and the management interface that the client can access. You can select a specific management interface or you can select the **All** option to allow access to all management interfaces.

By default (i.e., Management Access List table is empty), any client (IP address) can access all the device's management interfaces. Once you configure access rules for a specific management interface, the device blocks all undefined clients to that specific management interface (rejects with an HTTP 403 Forbidden response).



- If you want to configure management access list rules, the **first** rule must allow access to the current management interface from the IP address of the computer from which you are currently logged into the device. If you don't configure this rule first, after you configure an access rule for any other IP address, the device immediately blocks your access.
- If you configure network firewall rules in the Firewall table (see [Configuring Firewall Rules](#) on page 248), you must configure a firewall rule that allows traffic from IP addresses that you configured in the Management Access List table.
- If you have configured management access list rules and you no longer want to restrict access to the management interfaces, you need to delete all the rules in the table. However, make sure that you delete the rule **last** that allows access from the computer (IP address) from which you are currently logged into the device; otherwise, access from your computer will be immediately denied.
- If you downgrade the device to a version earlier than 7.6, the access list is deleted.

The following procedure describes how to configure the Management Access List table through the Web interface. You can also configure it through ini file [WebAccessList] or CLI (configure system > management-access-list).

➤ **To restrict access to a management interface:**

1. Open the Management Access List table (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Management Access List**).
2. Click **New**; the following dialog box is displayed:

3. Configure a management access list rule according to the parameters described in the table below.
4. Click **Apply**, and then save your settings to flash memory.

**Table 6-10: Management Access List Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'IP Address' ip-	Defines the management station (client) as an IP address (IPv4 or IPv6) that is allowed to access the specified management interface (see the



Parameter	Description
address [IpAddress]	'Type' parameter below) . <b>Note:</b> <ul style="list-style-type: none"> <li>■ If you configure an IPv6 address, use the shortened address format and without square brackets (e.g., 2010:31::2:56).</li> <li>■ You can configure multiple rules with the same IP address as long as you configure each with a different management interface type.</li> </ul>
'Type' type [Type]	Defines the type of device's management interface that the client is allowed to access. <ul style="list-style-type: none"> <li>■ [0] <b>All</b> (default)</li> <li>■ [1] <b>Web</b></li> <li>■ [2] <b>REST</b></li> <li>■ [3] <b>SSH</b></li> <li>■ [4] <b>Telnet</b></li> </ul>

## Viewing Active Web Interface and CLI Users

You can view all users that are currently logged in to the device's Web interface and CLI.

### ➤ To view active users:

- Open the Active Users page (**Monitor** menu > **Monitor** tab > **Summary** folder > **Active Users**).

ACTIVE WEB USERS TABLE

Web Users

#	USERNAME	IP ADDRESS	LEVEL	MODE	STATUS	SESSION TIME
0	Admin	10.11.2.2	Security Administrator	WEB	Active	32 Min, 52 Sec

Items per page: 10 1 - 1 of 1 |< < 1 > >|

ACTIVE CLI USERS TABLE

CLI Users

#	USERNAME	IP ADDRESS
0	Admin	10.11.2.2

The Active Users table is described below:

Parameter	Description
<b>Active Web Users Table</b>	
'Username'	Displays the user's login username.
'IP Address'	Displays the IP address of the management station from where the user accessed the device's Web interface.
'Level'	Displays the user's privilege level (e.g., <b>Security Administrator</b> or <b>Monitor</b> ).
'Mode'	<p>Displays the method of how the user accessed the device's Web interface:</p> <ul style="list-style-type: none"> <li>■ "WEB" = Accessed directly through the Web Login page.</li> <li>■ "OSN" = Accessed from the OSN server.</li> <li>■ "CCE" = Accessed from Cloud Connector Edition (CCE).</li> <li>■ "OVOC" = Accessed from OVOC (Single-Sign On).</li> <li>■ "OAUTH" = Accessed through OAuth-based login authentication (Azure AD).</li> </ul>
'Status'	Displays the status of the user (always "Active").
'Session Time'	<p>Displays the time remaining until the user's session expires due to inactivity in the Web interface and is logged out of the Web interface. To obtain the time in minutes, divide the displayed time by three.</p> <p>The timer starts counting down whenever the user is inactive. As soon as the user becomes active, the timer resets to the full session inactivity time, configured by the 'Web Session Timeout' parameter in the Local Users table (see <a href="#">Configuring Local Management User Accounts</a> on page 54).</p>
<b>Active CLI Users Table</b>	
'Username'	Displays the user's login username.
'IP Address'	Displays the IP address of the management station from where the user accessed the device's CLI.

## 7 CLI-Based Management

This section provides an overview of the CLI-based management and provides configuration relating to CLI management.



- By default, CLI is disabled for security purposes.
- The CLI provides two access modes - Basic mode (basic commands) and Privileged mode (all commands). Access to these modes depends on management user level:
  - ✓ Monitor user level: Basic mode only
  - ✓ Administrator user level: Basic mode only
  - ✓ Security Administrator user level: Basic and Privileged modes
- For a description of the CLI commands, refer to the document *SBC-Gateway CLI Reference Guide* by clicking [here](#).

### Configuring Telnet for CLI

The device provides an embedded Telnet server, which allows you to access its CLI from a remote Telnet client using the Telnet application protocol. By default, the Telnet server is disabled.

If you enable secured Telnet connectivity, the device uses the TLS security protocol, whereby information is transmitted encrypted (instead of in clear text). For TLS, the device uses the TLS settings of the TLS Context at Index #0 ("default"). A special Telnet client is required on your PC to connect to the Telnet interface over the TLS connection, for example, C-Kermit for UNIX and Kermit-95 for Windows. For more information on TLS, see [TLS Certificates](#) on page 224.

For security, some organizations require the display of a proprietary notice upon starting a Telnet session. To configure such a message, see [Creating a Login Welcome Message](#) on page 50.

To assign IP interfaces for Telnet sessions, see [Configuring Telnet Interface](#) on page 97.

#### ➤ To configure Telnet:

1. Open the Administration Settings page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Administration Settings**).
2. From the 'Enable Telnet Server' drop-down list, select **Enable Unsecured** or **Enable Secured** (i.e., TLS) to enable Telnet.

Enable Telnet Server

Enable Unsecured ▼

3. In the 'Idle Timeout' field, enter the duration of inactivity in the Telnet session after which the session is automatically terminated.

Telnet Server Idle Timeout [minutes] •

4. In the 'Default Terminal Window Height' field, enter the maximum number of output lines to display in the CLI terminal window.

Default terminal window height

5. Click **Apply**, and then restart the device with a save-to-flash for your settings to take effect.

For a detailed description of the Telnet parameters, see [Telnet and CLI Parameters](#) on page 1575.

## Configuring CLI over SSH using Public Key Authentication

When using a Secure Shell (SSH) connection for secure access to the device's CLI, the device uses the username-password method for authenticating users, by default. To increase security, you can use RSA or ECDSA public keys for user authentication instead of passwords. In this setup, when establishing an SSH connection, the device checks that the SSH private key of the client (user) matches the public key configured for the user on the device.

This section describes how to enable SSH for public key authentication (see [Enabling SSH for Public Key Authentication](#) below) and how to configure SSH public key authentication on the following operating systems:

- Windows using PuTTY (see [Configuring SSH Public Key Authentication on Windows](#) on the next page)
- Linux using OpenSSH (see [Configuring SSH Public Key Authentication on Linux](#) on page 96)



The device's embedded SSH server supports SHA-256 (rsa-sha2-256) and SHA-512 (rsa-sha2-512) signature algorithms for public-key client authentication that utilizes RSA keys:

- Server host key algorithms (refer to RFC 4253 Section 7.1)
- Algorithm for client authentication (refer to RFC 8303 Section 3.1, and RFC 8332 Section 3.2)

## Enabling SSH for Public Key Authentication

This section describes how to enable SSH public key authentication for accessing the device's CLI.

### ➤ To enable SSH for public key authentication:

1. Open the Administration Settings page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Administration Settings**).
2. Select the 'Enable SSH Server' check box to enable SSH:

**Enable SSH Server**

3. Select the 'Public Key' check box to enforce SSH access with a username and SSH public key (not username and password):

**Public Key**

4. Configure the key algorithm string, cipher string, or MAC string:

**Kex Algorithms String**

- diffie-hellman-group1-sha1:diffie-hellma

**Ciphers String**

- aes128-ctr:aes128-cbc:aes256-ctr:aes256

**MACs String**

- hmac-sha1:hmac-sha2-256

5. Click **Apply**, and then save your settings to flash memory.

For a detailed description of the all SSH parameters, see [SSH Parameters](#) on page 1673.



To configure IP network interfaces for the SSH application, see [Configuring SSH Interfaces](#) on page 98.

## Configuring SSH Public Key Authentication on Windows

This section describes how to configure SSH public key authentication on Windows, using PuTTY.



The public key cannot be configured with wide characters.

### ➤ To configure SSH public key authentication on Windows using PuTTY:

1. Generate private-public keys using PuTTY:
  - a. Download the PuTTY application (free and open-source terminal emulator).
  - b. Start the PuTTYgen (PuTTY Key Generator) tool.
  - c. Under the **Parameters** group, do the following:
    - i. Select the **RSA** or **ECDSA** option.
    - ii. In the 'Number of bits in a generated key' field, enter the bit size.
  - d. Under the **Actions** group, do the following:
    - i. Click **Generate** and then follow the on-screen instructions to generate the public-private key pair.

- ii. Click **Save private key** to save the generated private key to a file (\*.ppk) on your PC.
- e. Under the **Key** group, copy the generated public key string to your clipboard, from after the first space to before the last space, for example:

**PuTTY Key Generator**

File Key Conversions Help

**Key**

Public key for pasting into OpenSSH authorized\_keys file:

```
ecdsa-sha2-nistp256
AAAAE2VjZHNhLXNoYTItbmlzdHAyNTYAAAAIbmlzdHAyNTYAAABBBNtQi8CXwEfh9EfPBeaQnFKc5fivuO6ZR
GUUpOlx3g7KkwM2EWLmvCazbhcP0BoHTFBey92gS7QPJRkzxiNiLo= ecdsa-key-20220711
```

Key fingerprint: ecdsa-sha2-nistp256 256 SHA256:nkOqsh/jCrU6snOJj9FBzPbUr1F4Pgxc87sXcYrJeQ

Key comment: ecdsa-key-20220711

Key passphrase:

Confirm passphrase:

**Actions**

Generate a public/private key pair Generate

Load an existing private key file Load

Save the generated key Save public key Save private key

**Parameters**

Type of key to generate:

☐ RSA ☐ DSA ☒ ECDSA ☐ EdDSA ☐ SSH-1 (RSA)

Curve to use for generating this key: nistp256

2. Configure the required user with the generated public key:
  - a. Open the Local Users table (see [Configuring Local Management User Accounts](#) on page 54).
  - b. Select the required user, and then click **Edit**.
  - c. In the 'SSH Public Key' field, paste the public key that you copied previously, as shown in the following example:

**Local Users**

**GENERAL**

Index: 0

Username: Admin

Password: \*

User Level: Security Administrator

SSH Public Key: AAAAE2VjZHNhLXNoYTItbmlzdHAyNTYAAAAIbmlzdHAyNTYAAABBBNtQi8CXwEfh9EfPBeaQnFKc5fivuO6ZR GUUpOlx3g7KkwM2EWLmvCazbhcP0BoHTFBey92gS7QPJRkzxiNiLo=

Status: Valid

**SECURITY**

Password Age (days): 0


Web Session Limit: 5

CLI Session Limit: -1

Web Session Timeout (min): 120

Block Duration (sec): 60

- d. Click **Apply**, and then save your settings to flash memory. If you are editing the user that you are currently logged in as, then you are logged out of the Web interface after clicking **Apply** and need to log in again.
3. Establish an SSH connection with the device:
    - a. Start the PuTTY application.
    - b. In the navigation tree, drill down to **Connection > SSH > Auth**.
    - c. Under the **Authentication parameters** group, click **Browse** to select the private key file (\*.ppk) that you generated and then saved in Step 1:




- d. In the navigation tree, click **Session**, and then establish an SSH connection with the device.



When defining the session in PuTTY, make sure that you don't select a saved session that is not associated with the \*.ppk key; otherwise, SSH with public key authentication will fail.

- e. Log in with your username only (e.g., "Admin"); public-private key negotiation occurs for user authentication and if successful, you are logged into the CLI, as shown in the following example:



```

10.15.7.96 - PuTTY
login as: Admin
Pre-authentication banner message from server:
| Welcome to AudioCodes CLI
End of banner message from server
Authenticating with public key "ecdsa-key-20220711"
Mike>

```

## Configuring SSH Public Key Authentication on Linux

This section describes how to configure SSH public key authentication on Linux, using OpenSSH.




The public key cannot be configured with wide characters.

### ➤ To configure SSH public key authentication on Linux using OpenSSH 9.0:

1. Create a new key in the admin.key file and save the public portion to the admin.key.pub file, using the following command:

```
ssh-keygen -f admin.key -t [ecdsa|rsa]
```

2. Open the admin.key.pub file, and then copy the public key string to your clipboard from after the first space to before the last space, for example:



```

ecdsa-sha2-nistp256
AAAAE2VjZHNhLXNoYTItbmlzdHAyNTYAAAAIbmlzdHAyNTYAAABBBKByVKFU0aSY3L
7XNt05kwUGbE5/a5qfzncRRWiPdLWyOzcHpmfQHwJTa/wjxmG7HuRXUeQpduT5WPdt
noeDvIU= miked@au-miked-lp

```

3. Configure the required user with the generated public key:
  - a. Open the Web interface's Local Users table (see [Configuring Local Management User Accounts](#) on page 54).
  - b. Select the required user, and then click **Edit**.
  - c. In the 'SSH Public Key' field, paste the public key that you copied previously, as shown in the following example:



- d. Click **Apply**, and then save your settings to flash memory. If you are editing the user that you are currently logged in as, then you are logged out of the Web interface after clicking **Apply** and need to log in again.

4. Establish an SSH connection with the device, using the following command:

```
ssh -i admin.key <username>@<IP address>
```

For example:

```
ssh -i admin.key Admin@10.4.30.215
```

Key negotiation occurs for user authentication and if successful, you are logged into the CLI.

## Configuring Telnet Interface

The Telnet Interfaces table lets you configure up to 16 Telnet interfaces, which are used to access the device's CLI over Telnet.



The device provides a default Telnet Interface (Index 0), which is assigned the IP Interface for IPv4 OAMP ("O+M+C", Index 0).

The following procedure describes how to configure Telnet interfaces through the Web interface. You can also configure it through ini file [TelnetInterfaces] or CLI (`configure system > cli-settings > telnet-if`).

### ➤ To configure Telnet interfaces:

1. Open the Telnet Interfaces table (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Telnet Interfaces**).
2. Click **New**; the following dialog box is displayed:

Telnet Interfaces
— x

**GENERAL**

Index	<input style="width: 90%;" type="text" value="1"/>
Name	<input style="width: 90%;" type="text"/>
Interface Name	<input style="width: 90%;" type="text" value="#1 [HA]"/> <span style="float: right; color: #003366; font-size: 0.8em;">View</span>
Port	<input style="width: 90%;" type="text" value="23"/>

3. Configure the row according to the parameters described in the table below.
4. Click **Apply**, and then save your settings to flash memory.

**Table 7-1: Telnet Interfaces Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [Name]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 19 characters. <b>Note:</b> Configure each row with a unique name.
'Interface Name' interface-name [InterfaceName]	Assigns an IP Interface (IPv4 or IPv6) from the IP Interfaces table (see <a href="#">Configuring IP Network Interfaces</a> on page 157) for communication with the embedded Telnet server. The IP Interface can be any Application Type (e.g., Media, Control, or OAMP). By default, the OAMP interface (Index 0 "O+M+C") is assigned. <b>Note:</b> The parameter is mandatory.
'Port' port [Port]	Defines the local port to use for Telnet application. The valid range is 1 to 65535. The default is 23. <b>Note:</b> The parameter is mandatory.

## Configuring SSH Interfaces

The SSH Interfaces table lets you configure up to 16 SSH interfaces, which are used to access the device's CLI over SSH.



The device provides a default SSH Interface (Index 0), which is assigned the IP Interface for IPv4 OAMP ("O+M+C", Index 0).

The following procedure describes how to configure SSH interfaces through the Web interface. You can also configure it through ini file [SshInterfaces] or CLI (`configure system > cli-settings > ssh-if`).

➤ **To configure SSH interfaces:**

1. Open the SSH Interfaces table (**Setup** menu > **Administration** tab > **Web & CLI** folder > **SSH Interfaces**).
2. Click **New**; the following dialog box is displayed:

3. Configure the row according to the parameters described in the table below.
4. Click **Apply**, and then save your settings to flash memory.

**Table 7-2: SSH Interfaces Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [Name]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 19 characters. <b>Note:</b> Configure each row with a unique name.
'Interface Name' interface-name [InterfaceName]	Assigns an IP Interface (IPv4 or IPv6) from the IP Interfaces table (see <a href="#">Configuring IP Network Interfaces</a> on page 157) for communication with the SSH application. The IP Interface can be any Application Type (e.g., Media, Control, or OAMP). By default, the OAMP interface (Index 0 "O+M+C") is assigned. <b>Note:</b> The parameter is mandatory.
'Port' port [Port]	Defines the local port to use for the SSH application. The valid range is 1 to 65535. The default is 22. <b>Note:</b> The parameter is mandatory.

## Establishing a CLI Session

You can access the device's CLI using any of the following methods:

- **RS-232:** The device's CLI can be accessed through its RS-232 serial port, by connecting a VT100 terminal to it or using a terminal emulation program (e.g., HyperTerminal) with a PC. For connecting to the CLI through RS-232, see [Changing OAMP Address through CLI](#) on page 14.
- **Secure SHell (SSH):** The device's CLI can be accessed through its Ethernet interface by the SSH protocol using SSH client software. A popular and freeware SSH client software is PuTTY, which can be downloaded from <https://www.putty.org>.
- **Telnet:** The device's CLI can be accessed through its Ethernet interface by the Telnet protocol using Telnet client software.

The following procedure describes how to access the CLI through Telnet/SSH.



- The CLI login credentials are the same as all the device's other management interfaces (such as Web interface). The default username and password is "Admin" and "Admin" (case-sensitive), respectively. To configure login credentials and management user accounts, see [Configuring Local Management User Accounts](#) on page 54.
- After three consecutive failed login attempts because of incorrect credentials, the device ends the CLI session and you will need to re-establish it.

### ➤ To establish a CLI session through Telnet or SSH:

1. Connect the device to the network.
2. Establish a Telnet or SSH session using the device's OAMP IP address.
3. Log in to the session using the username and password assigned to the Admin user of the Web interface:
  - a. At the Username prompt, type the username, and then press Enter:

```
Username: Admin
```

- b. At the Password prompt, type the password, and then press Enter:

```
Password: Admin
```

- c. At the prompt, type the following, and then press Enter:

```
> enable
```

- d. At the prompt, type the password again, and then press Enter:

Password: Admin

## Configuring Maximum Telnet and SSH Sessions

You can configure the maximum number of concurrent Telnet and SSH sessions allowed by the device.



- Before changing the setting, make sure that not more than the number of sessions that you want to configure are currently active; otherwise, the new setting will not take effect.
- The device supports up to five concurrent Telnet and SSH sessions.

### ➤ To configure maximum number of concurrent Telnet and SSH sessions:

1. Open the Administration Settings page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Administration Settings**).
2. In the 'Maximum Telnet Sessions' field, enter the maximum number of concurrent **Telnet** sessions:

Maximum Telnet Sessions •

3. In the 'Maximum SSH Sessions' field, enter the maximum number of concurrent **SSH** sessions:

Maximum SSH Sessions

4. Click **Apply**.

## Running Multiple Non-Interactive SSH Commands from Command Line

You can configure the device with multiple, non-interactive SSH (CLI) commands from a command-line connection, instead of using a terminal emulator program (e.g., PuTTY). Unlike terminal emulator programs, the command line has no user prompts and is similar to Unix SSH. This feature may be useful, for example, if you want to run a batch of SSH commands via automated connections.

As an SSH client, you can run the command-line connection tool (e.g., PuTTY Link or Plink) from a computer's command prompt. For computers running Windows, this can be done using the Command Prompt command-line app. When you enter a command, it's executed on the device instead of through a login shell.

You can enter multiple commands on the **single** command line, including standalone commands and command sequences. Separate each command with a semicolon (;).

The command-line syntax depends on the command-line connection tool that you are using to connect to the device. The following are examples using the Plink command-line connection tool:

- To display network interfaces and CPU status (i.e., `show` commands):

```
C:\projects\tftp>plink.exe -no-antispooof -ssh 10.4.30.11 -l Admin -pwd Admin  
"sh run ne int; sh sys util"
```

- To configure the syslog server's IP address:

```
C:\projects\tftp>plink.exe -no-antispooof -ssh 10.4.30.11 -l Admin -pwd Admin  
"conf tr; sys; syslog-ip 10.4.2.11; act"
```

- To configure commands that are located in two different CLI paths:

```
C:\projects\tftp>plink.exe -no-antispooof -ssh 10.4.30.11 -l Admin -pwd Admin  
"conf voip; sip-definition settings; 100-to-18x-timeout 100; exit; exit; show  
system utilization"
```



- This feature is applicable only to non-interactive commands.
- This feature is not supported for async commands (e.g., `ping`).
- You can enter up to 8,000 characters on the command line (input).
- When using the command line, no other SSH connections (sessions) can be established with the device.
- The device's Activity Log (see [Reporting Management User Activities](#) on page 1502) also logs the commands executed from the command line (which are indicated in syslog as "Activity Log: Executing multiple CLI commands").

## Viewing Current CLI and Web Sessions

You can view users that are currently logged in to the device's CLI and Web interface. For CLI, This applies to users logged in to the CLI through RS-232 (console), Telnet, or SSH. For each logged-in user, the following is displayed: the type of interface (console, Telnet, SSH, or Web), username, remote IP address from where the user logged in, and the duration (days and time) of the session. Each user is displayed with a unique index (session ID).

### ➤ To view currently logged-in CLI users:

1. Establish a CLI session with the device.
2. Run the following command:

```
# show users
[0]* ssh      Admin  10.11.2.2    0d00h17m55s
[0]  WEB      Admin  10.11.2.2    0d00h01m44s
```

The current session from which this show command was run is displayed with an asterisk (\*).



The device can display management sessions of up to 24 hours. After this time, the duration counter is reset.

## Terminating a User's CLI Session

You can terminate users that are currently logged in to the device's CLI. This applies to users logged in to the CLI through RS-232 (console), Telnet, or SSH.

### ➤ To terminate the CLI session of a specific CLI user:

1. Establish a CLI session with the device.
2. Run the following command:

```
# clear user <session ID>
```

Where *<session ID>* is a unique identification of each currently logged in user. You can view the session ID by running the **show users** command (see [Viewing Current CLI and Web Sessions](#) on the previous page).



The session in which the command is run cannot be terminated.

## Configuring CLI Command Aliases

The CLI Aliases table lets you configure up to 100 CLI Alias rules. A CLI command alias is a shortcut or abbreviation of a command. Instead of typing the command, you can type the alias name.

Aliases may be useful for commands that you frequently use. For example, if you often use the command `copy firmware from`, you can configure an alias called "CopyF" for it and then whenever you want to type the command, you can simply type `CopyF` instead.



To use an alias, you must access the relevant CLI command path where the command that it represents is located. Using the example above, to use the alias "CopyF" for the `copy firmware from` command, you must be at the root prompt.

The following procedure describes how to configure CLI command aliases through the Web interface. You can also configure it through ini file [CliAlias] or CLI (`configure system > cli-settings > cli-alias`).

➤ **To configure CLI command aliases:**

1. Open the CLI Aliases table (**Setup** menu > **Administration** tab > **Web & CLI** folder > **CLI Aliases**).
2. Click **New**; the following dialog box appears:

3. Configure a CLI Alias rule according to the parameters described in the table below.
4. Click **Apply**.

**Table 7-3: CLI Aliases Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Alias' alias-name [AliasName]	Defines the alias name for the CLI command. The valid value is a string of up to 255 characters. <b>Note:</b> <ul style="list-style-type: none"> <li>■ The alias name must be unique.</li> <li>■ The alias name is case-sensitive.</li> <li>■ The alias name cannot contain spaces.</li> </ul>
'Command' alias-command [AliasCommand]	Defines the CLI command (or command sequence) for which the alias represents. The valid value is a string of up to 500 characters.



## Configuring Maximum Number of Displayed CLI Output Lines

You can configure the maximum number of lines (height) displayed in the terminal window for the output of CLI commands (Telnet and SSH). The number of displayed lines can be from 0 to 65,535, or determined by re-sizing the terminal window by mouse-dragging the window's border.

➤ **To configure maximum number of displayed output lines:**

1. Establish a CLI session with the device.
2. Access the System menu:

```
# configure system
```

3. At the prompt, type the following command:

```
(config-system)# cli-terminal
```

4. At the prompt, type the following command:

```
<cli-terminal># window-height [0-65535]
```

If window-height is set to 0, the entire command output is displayed. In other words, even if the output extends beyond the visible terminal window length, the --MORE-- prompt is not displayed.

➤ **To configure number of displayed output lines by dragging terminal window:**

1. Establish a CLI session with the device.
2. Access the System menu:

```
# configure system
```

3. At the prompt, type the following command:

```
(config-system)# cli-terminal
```

4. At the prompt, type the following command:

```
<cli-terminal># window-height automatic
```

When this mode is configured, each time you change the height of the terminal window using your mouse (i.e., dragging one of the window's borders or corners), the number of displayed output command lines is changed accordingly.

## Idle CLI Session Timeout for RS-232 Connections

If you have established a CLI session (successfully logged in) with the device through an RS-232 serial interface and you don't perform any actions in the CLI session for five minutes, the device automatically logs you out the session. In such a scenario, you need to log in to the CLI again if you want to continue using the CLI. This idle session timeout is not configurable.

## 8 SNMP-Based Management

The device provides an embedded SNMP agent that lets you manage it using AudioCodes One Voice Operations Center (OVOC) or a third-party SNMP manager. The SNMP agent supports standard and proprietary Management Information Base (MIBs). All supported MIB files are supplied to customers as part of the release. The SNMP agent can send unsolicited SNMP trap events to the SNMP manager.



- The device supports SNMPv1, SNMPv2, and SNMPv3.
- SNMPv2 or SNMPv3 is required to query 64-bit counters because SNMPv1 doesn't support 64-bit counters (per RFC 2233). Therefore, to ensure that your SNMP Get requests (e.g., especially for performance monitoring parameters) are successful, it's recommended to use SNMPv2 or SNMPv3.
- For more information on SNMP trap alarms, refer to the [SBC-Gateway Series SNMP Alarm Reference Guide](#).
- For more information on OVOC, refer to the *OVOC User's Manual* (click [here](#)).

### Enabling or Disabling SNMP

By default, management of the device through SNMP is enabled.

#### ➤ To enable or disable SNMP:

1. Open the SNMP Settings page (**Setup** menu > **Administration** tab > **SNMP** folder > **SNMP Settings**).
2. From the 'Disable SNMP' drop-down list (DisableSNMP parameter), select one of the following:
  - **Yes** to disable SNMP.
  - **No** to enable SNMP.

Disable SNMP

3. Click **Apply**.



If you want the device to be managed by the One Voice Operations Center (OVOC) tool, you must enable SNMP.

### Configuring SNMP Get / Set Port

By default, the device uses UDP port 161 for SNMP Get and Set request commands. You can change the port number (100 to 3999), as described below.

➤ **To configure the SNMP port:**

1. Open the SNMP Settings page (**Setup** menu > **Administration** tab > **SNMP** folder > **SNMP Settings**).
2. In the 'SNMP Port' field (SNMPPort parameter), type the port number:

SNMP Port

161



3. Click **Apply**, and then restart the device with a burn-to-flash for your settings to take effect.

## Configuring SNMP Community Strings

SNMP community strings determine the access privileges (read-only and read-write) of SNMP clients with the device's SNMP agent for SNMPv1 and SNMPv2 users. You can configure up to 10 SNMP community strings. The device's SNMP agent accepts SNMP Get (read-only) and Set (read-write) requests only if the correct community string is used in the request.



- SNMP community strings are applicable only to SNMPv1 and SNMPv2c. SNMPv3 uses username-password authentication along with an encryption key (see [Configuring SNMPv3 Users](#) on page 115).
- If you configure SNMPv3 users (see [Configuring SNMPv3 Users](#) on page 115), the device automatically deletes all configured SNMP community strings in the SNMP Community Strings table. In addition, the device ignores all SNMP requests (Get and Set operations) from SNMPv2 users, sending the authenticationFailure SNMP trap.
- If you don't configure any community strings, the default community strings are "public" and "private".
- The read-only community strings must be different to the read-write community strings.
- You can enhance security by configuring Trusted Managers (see [Configuring SNMP Trusted Managers](#) on page 114). A Trusted Manager is an address from which the SNMP agent accepts Get and Set requests.

The following procedure describes how to configure SNMP Community Strings through the Web interface. You can also configure it through ini file [SNMPCommunityStrings] or CLI (configure system > snmp settings > community-strings).

➤ **To configure SNMP Community Strings:**

1. Open the SNMP Community Strings table (**Setup** menu > **Administration** tab > **SNMP** folder > **SNMP Community Strings**).
2. Click **New**; the following dialog box appears:

3. Configure an SNMP community string according to the parameters described in the table below.
4. Click **Apply**, and then reset the device with a save-to-flash for your settings to take effect.

**Table 8-1: SNMP Community Strings Table Parameter Descriptions**

Parameter	Description
'Index' [SNMPCommunityStrings_Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [SNMPCommunityStrings_Name]	Defines a descriptive name for the SNMP community string. The valid value is a string of up to 31 characters.
'Password' password [SNMPCommunityStrings_Password]	Defines a password (string) for the SNMP community string. The valid value is a string of up to 30 characters that can include only the following: <ul style="list-style-type: none"> <li>■ Uppercase letters (A to Z)</li> <li>■ Lowercase letters (a to z)</li> <li>■ Numbers (0 to 9)</li> <li>■ Hyphen (-)</li> <li>■ Underline (_)</li> </ul> For example: "Public-comm_string1". <b>Note:</b> <ul style="list-style-type: none"> <li>■ The parameter cannot be configured with wide characters.</li> <li>■ The password cannot contain spaces.</li> <li>■ To enforce the use of strong passwords (password complexity), configure the <a href="#">[EnforcePasswordComplexity]</a> on page 1565]</li> </ul>

Parameter	Description
	parameter to [1]. <ul style="list-style-type: none"> <li>The read-only community strings must be different to the read-write community strings.</li> </ul>
'Group' group [SNMPCommunityStrings_Group]	Defines the access privilege of the SNMP community string. <ul style="list-style-type: none"> <li>[0] <b>Read-Only</b></li> <li>[1] <b>Read-Write</b> (default)</li> </ul>

## Configuring SNMP Trap Destinations

The SNMP Trap Destinations table lets you configure up to five SNMP Trap Managers for receiving traps sent by the device. Trap Managers are defined by IP address or FQDN (IPv4 and/or IPv6).

You can associate a trap destination with SNMPv2 users or a specific SNMPv3 users. Associating a trap destination with an SNMPv3 user sends encrypted and authenticated traps to the SNMPv3 destination. By default, traps are sent unencrypted using SNMPv2.

The following procedure describes how to configure SNMP trap destinations through the Web interface. You can also configure it through ini file [SNMPTrapDestinations] or CLI (`configure system > snmp settings > trap-destinations`).

### ➤ To configure SNMP trap destinations:

1. Open the SNMP Trap Destinations table (**Setup** menu > **Administration** tab > **SNMP** folder > **SNMP Trap Destinations**).
2. Click **New**; the following dialog box appears:

The screenshot shows a configuration window titled "SNMP Trap Destinations". It has a "GENERAL" tab. The fields are as follows:

- Index:** 0
- Name:** (empty text field)
- Address:** 0.0.0.0
- Port:** 162
- SNMP Version:** SNMPv2 (dropdown menu)
- SNMPv3 User:** .. (dropdown menu with a "View" link)
- Enable:** Enable (dropdown menu)

3. Configure the SNMP Trap Manager according to the table below.

4. Click **Apply**.**Table 8-2: SNMP Trap Destinations Table Parameters Description**

Parameter	Description
'Index' [SNMPTrapDestinations_ Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [SNMPTrapDestinations_ Name]	Defines a descriptive name for the SNMP trap manager. The valid value is a string of up to 31 characters.
'Address' address [SNMPTrapDestinations_ Address]	<p>Defines the address of the remote host used as the SNMP trap manager where the device sends the traps. The valid value can be one of the following:</p> <ul style="list-style-type: none"> <li>■ IPv4 address in dotted-decimal notation (e.g., 108.10.1.255).</li> <li>■ IPv6 address in colon-separated hexadecimal (e.g., 3ffe:1900:4545:3:200:f8ff:fe21:67cf).</li> <li>■ Hostname or FQDN (e.g., mngr.corp.mycompany.com). The device sends traps to the DNS-resolved IP address.</li> </ul> <p>The default is 0.0.0.0 (i.e., not defined). <b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Depending on IP version (IPv4 or IPv6), the device uses the corresponding IP Interface (in the IP Interfaces table), assigned in <a href="#">Configuring SNMP Interfaces</a> on page 113.</li> <li>■ If you configure the address as an FQDN: <ul style="list-style-type: none"> <li>✓ The IP address version (IPv4 or IPv6) of the FQDN and IP Interface (in the IP Interfaces table) must be the same. For assigning IP Interfaces for SNMP, see <a href="#">Configuring SNMP Interfaces</a> on page 113.</li> <li>✓ To resolve the FQDN into an IP address, the device uses the DNS server configured in the IP Interfaces table of the corresponding IP Interface.</li> <li>✓ If the DNS response contains multiple DNS-resolved IP addresses, the device uses only the first IP address in the list.</li> </ul> </li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>If you are using a WebSocket tunnel connection between the device and OVOC, configure the parameter to the IP address mentioned in <a href="#">Configuring WebSocket Tunnel with OVOC</a> on page 122</li> </ul>
'Port' port [SNMPTrapDestinations_ Port]	<p>Defines the port number of the remote SNMP trap manager. The device sends SNMP traps to this port. The valid value range is 100 to 4000. The default is 162.</p>
'SNMP Version' snmp-version [SNMPTrapDestinations_ Version]	<p>Defines the SNMP version of the SNMP trap manager (user).</p> <ul style="list-style-type: none"> <li>[2] <b>SNMPv2</b> = (Default) Defines the trap manager as an SNMPv2 user.</li> <li>[3] <b>SNMPv3</b> = Defines the trap manager as an SNMPv3 user.</li> </ul> <p><b>Note:</b> If you configure the parameter to <b>SNMPv3</b>, you need to select the user in the 'SNMPv3 User' parameter (below).</p>
'SNMPv3 User' snmpv3-user [SNMPTrapDestinations_ User]	<p>Assigns an SNMPv3 user from the SNMPv3 Users table (see <a href="#">Configuring SNMPv3 Users</a> on page 115) to this SNMP trap destination.</p> <p>By default, no user is assigned.</p> <p><b>Note:</b> The parameter is applicable only if you configured the 'SNMP Version' parameter (above) to <b>SNMPv3</b>.</p>
'Enable' enable [SNMPTrapDestinations_ Enable]	<p>Enables the SNMP trap manager to receive traps.</p> <ul style="list-style-type: none"> <li>[0] <b>Disable</b></li> <li>[1] <b>Enable</b> (default)</li> </ul>

## Configuring SNMP Community String for Traps

You can configure a unique password-like community string for SNMP traps. The device sends the traps with this community string.

The valid value is a string of up to 30 characters that can include only the following:

- Uppercase letters (A to Z)
- Lowercase letters (a to z)
- Numbers (0 to 9)
- Hyphen (-)



### ■ Underline ( \_ )



- The community string value cannot contain the following:
  - ✓ Wide characters
  - ✓ Spaces
- If you don't configure a trap community string, the default community string is "trapuser".

### ➤ To configure community string for traps:

1. Open the SNMP Settings page (**Setup** menu > **Administration** tab > **SNMP** folder > **SNMP Settings**).
2. In the 'Trap Community String' field, type a community string:

Trap Community String

3. Click **Apply**.

## Enabling SNMP Traps for Web Activity

You can enable the device to send SNMP traps to notify of management users' activities in the Web interface. A trap is sent each time an activity is done by a user. To configure the types of Web activities that you want reported, see [Reporting Management User Activities](#) on page 1502.

### ➤ To enable traps to SNMP manager for Web activity:

1. Open the SNMP Settings page (**Setup** menu > **Administration** tab > **SNMP** folder > **SNMP Settings**).
2. Select the 'Activity Trap' check box (EnableActivityTrap):

Activity Trap



3. Click **Apply**.

## Configuring SNMP Interfaces

You can assign IP Interfaces (configured in the IP Interfaces table - see [Configuring IP Network Interfaces](#) on page 157) to the device's SNMP application. You can assign an IPv4 IP Interface for SNMP over IPv4, and/or an IPv6 IP Interface for SNMP over IPv6. By default, the device uses the IPv4 OAMP IP Interface for SNMP.

➤ **To configure IP Interfaces for SNMP:**

1. Open the SNMP Settings page (**Setup** menu > **Administration** tab > **SNMP** folder > **SNMP Settings**).
2. From the 'IPv4 Interface Name' drop-down list, select an IP Interface from the IP interfaces table for SNMP over IPv4.
3. From the 'IPv6 Interface Name' drop-down list, select an IP Interface from the IP interfaces table for SNMP over IPv6.

IPv4 Interface Name	<input type="text" value="O+M+C"/>
IPv6 Interface Name	<input type="text" value="IPv6-Interface"/>

4. Click **Apply**.

## Configuring SNMP Trusted Managers

The SNMP Trusted Managers table lets you configure up to five SNMP Trusted Managers. By default, the SNMP agent accepts SNMP Get and Set requests from any IP address as long as the correct community string is used in the request (see [Configuring SNMP Community Strings](#) on page 108). You can enhance security by configuring Trusted Managers, which is an IP address from which the device's SNMP agent accepts and processes SNMP requests. If no SNMP Trusted Manager is configured, any SNMP manager can access the device (as long as the community string is correct).

The following procedure describes how to configure SNMP Trusted Managers through the Web interface. You can also configure it through ini file [SNMPTrustedManagers] or CLI (configure system > snmp settings > trusted-manager).

➤ **To configure SNMP Trusted Managers:**

1. Open the SNMP Trusted Managers table (**Setup** menu > **Administration** tab > **SNMP** folder > **SNMP Trusted Managers**).

SNMP Trusted Managers

GENERAL

Index	<input type="text" value="0"/>
Name	<input type="text"/>
IP Address	<input type="text" value="0.0.0.0"/>

2. Configure an SNMP Trusted Manager according to the table below.

3. Click **Apply**, and then restart the device with a save-to-flash for your settings to take effect.

**Table 8-3: SNMP Trusted Managers Table Parameter Descriptions**

Parameter	Description
'Index' [SNMPTrustedManagers_Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [SNMPTrustedManagers_TrustedManagerName]	Defines a descriptive name for the SNMP Trusted Manager. The valid value is a string of up to 31 characters.
'IP Address' ip-address [SNMPTrustedManagers_IpAddress]	Define the IP address of the SNMP Trusted Manager. The valid value is an IPv4 address in dotted-decimal notation. The default is 0.0.0.0.

## Configuring SNMPv3 Users

The SNMPv3 Users table lets you configure up to 10 SNMPv3 users for authentication and privacy.



- If you delete an SNMPv3 user that is associated with a trap destination (see [Configuring SNMP Trap Destinations](#) on page 110), the trap destination becomes disabled and the trap user reverts to default (i.e., SNMPv2).
- If you want to use the same SNMPv3 Users table configuration for another device, before uploading this device's configuration file (.ini) to the other device, you **must** edit the file so that the passwords ('Authentication Key' and 'Privacy Key' parameters) are in plain text.
- If you configure an SNMPv3 user(s), the device automatically deletes all configured SNMP community strings in the SNMP Community Strings table (see [Configuring SNMP Community Strings](#) on page 108). In addition, the device ignores all SNMP requests (Get and Set operations) from SNMPv2 users, sending the authenticationFailure SNMP trap.

The following procedure describes how to configure SNMPv3 users through the Web interface. You can also configure it through ini file [SNMPUsers] or CLI (`configure system > snmp settings > v3-users`).

### ➤ To configure an SNMPv3 user:

1. Open the SNMPv3 Users table (**Setup** menu > **Administration** tab > **SNMP** folder > **SNMPv3 Users**).
2. Click **New**; the following dialog box appears:

SNMPv3 Users - x

GENERAL

Index

User Name

Authentication Protocol

None ▼

Privacy Protocol

None ▼

Authentication Key

•

Confirm Authentication Key

Privacy Key

•

Confirm Privacy Key

Group

Read-Write ▼

3. Configure the SNMPv3 parameters according to the table below.

4. Click **Apply**.

**Table 8-4: SNMPv3 Users Table Parameters Description**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'User Name' username [Username]	Defines a name for the SNMPv3 user. <b>Note:</b> The name must be unique.
'Authentication Protocol' auth-protocol [AuthProtocol]	Defines the authentication protocol for the SNMPv3 user. <ul style="list-style-type: none"> <li>■ [0] <b>None</b> (default)</li> <li>■ [1] <b>MD5</b></li> <li>■ [2] <b>SHA-1</b></li> <li>■ [3] <b>SHA-2-224</b></li> <li>■ [4] <b>SHA-2-256</b></li> <li>■ [5] <b>SHA-2-384</b></li> <li>■ [6] <b>SHA-2-512</b></li> </ul>
'Privacy Protocol' priv-	Defines the privacy (encryption) protocol for the SNMPv3 user. <ul style="list-style-type: none"> <li>■ [0] <b>None</b> (default)</li> </ul>

Parameter	Description
protocol [PrivProtocol]	<ul style="list-style-type: none"> <li>■ [1] <b>DES</b></li> <li>■ [2] <b>3DES</b></li> <li>■ [3] <b>AES-128</b></li> <li>■ [4] <b>AES-192</b></li> <li>■ [5] <b>AES-256</b></li> </ul>
'Authentication Key' auth-key [AuthKey]	<p>Defines the authentication key (password).</p> <p>You can configure keys in the form of a text password or long hex string. Keys are always persisted as long hex strings and keys are localized.</p> <p>The value must be at least six characters (preferably 8 characters).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter cannot be configured with wide characters.</li> <li>■ To enforce the use of strong passwords (password complexity), configure the <a href="#">[[EnforcePasswordComplexity]</a> on page 1565] parameter to [1].</li> </ul>
'Confirm Authentication Key'	Retype the authentication key that you configured in the 'Authentication Key' field (above).
'Privacy Key' priv-key [PrivKey]	<p>Defines the privacy key (password).</p> <p>You can configure keys in the form of a text password or long hex string. Keys are always persisted as long hex strings and keys are localized.</p> <p><b>Note:</b> To enforce the use of strong passwords (password complexity), configure the <a href="#">[[EnforcePasswordComplexity]</a> on page 1565] parameter to [1].</p>
'Confirm Privacy Key'	Retype the privacy key that you configured in the 'Privacy Key' field (above).
'Group' group [Group]	<p>The group with which the SNMPv3 user is associated.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Read-Only</b></li> <li>■ [1] <b>Read-Write</b> (default)</li> <li>■ [2] <b>Trap</b></li> </ul> <p><b>Note:</b> All groups can be used to send traps.</p>

## Customizing SNMP Alarm Severity

The Alarms Customization table lets you configure up to 150 Alarm Customization rules. The table allows you to customize the severity levels of the device's SNMP trap alarms.

The table also allows you to disable (*suppress*) specific alarms all together, suppress an alarm with a specific severity level, or suppress a specific alarm sent from a specific entity (e.g., IP Group 2).

For example, by default, when an alarm cannot be entered in the Active Alarms table due to it being full, the device sends the `acActiveAlarmTableOverflow` alarm with major severity level. By using this table, you can customize this alarm and change the severity level to warning.



- When you add a rule to the table, it's immediately applied to all relevant active alarms in the Active Alarms table (see [Viewing Active Alarms](#) on page 1323).
- If you added a rule and it affected currently active alarms (i.e., changed their severity level) and you then later delete the rule, the customized severity level of these active alarms remain.
- If you have customized an alarm that has subsequently been raised by the device and you then delete the rule when the alarm is still active, the device doesn't send the alarm again for that instance. For example, assume that you customize the severity of the `acBoardEthernetLinkAlarm` alarm to **Warning** and the Ethernet cable is subsequently disconnected. If you then delete the rule while this condition still exists (i.e., cable still disconnected), the device doesn't re-send the `acBoardEthernetLinkAlarm` alarm (with the default severity level -- Major or Minor).
- If you configure multiple Alarm Customization rules for the **same** alarm, out of all these same rules the device applies only the rule that you configured first (i.e., listed highest in the table -- with lowest index) and ignores the others.
- After an HA switchover, all disabled (**Suppressed**) alarms are restored (not suppressed).

The following procedure describes how to customize alarm severity levels through the Web interface. You can also configure it through ini file [AlarmSeverity] or CLI (`configure system > snmp alarm-customization`).

### ➤ To customize SNMP alarm severity levels:

1. Open the Alarms Customization table (**Setup** menu > **Administration** tab > **SNMP** folder > **Alarm Customization**).

## Alarms Customization [acACDThresholdAlarm]

## GENERAL

Index	<input type="text" value="q"/>
Name	<input type="text" value="acACDThresholdAlarm"/>
Entity ID	<input type="text"/>
Original Severity	<input type="text" value="Default"/>
Customized Severity	<input type="text" value="Indeterminate"/>

2. Configure a rule according to the parameters described in the table below.
3. Click **Apply**.

Table 8-5: Alarms Customization Parameter Descriptions

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [Name]	Defines the SNMP alarm that you want to customize. <b>Note:</b> The CLI and ini file use the last digits of the alarm's OID as the name. For example, configure the parameter to "12" for the acActiveAlarmTableOverflow alarm (OID is 1.3.6.1.4.15003.9.10.1.21.2.0.12). For more information on alarm OIDs, refer to the document <a href="#">SBC-Gateway Series SNMP Alarm Reference Guide</a> .
'Entity ID' entity-id [EntityID]	Defines the specific entity (e.g., port number or IP Group index) for which the alarm was sent. The entity ID appears in the alarm source after the hash (#) symbol. For example, "2" in the Board#1/IPGroup#2 alarm indicates that the alarm was sent for IP Group index 2 in the IP Groups table.  The valid value can be a single number (e.g., 4), multiple numbers separated by commas (e.g., 4,5,8), or a number range (e.g., 4-8). The value can be a combination of single numbers and ranges (e.g., 4,5,6-20).  <b>Note:</b> If not configured, the rule applies to all alarms of the type specified using the 'Name' parameter (above), regardless of entity.
'Original Severity' alarm-original-severity [OriginalSeverity]	Defines the original severity level of the alarm, according to the MIB.  ■ [0] <b>Default</b> = (Default) All supported severity levels of

Parameter	Description
	<p>the alarm. If you select this option, the alarm and its severity depends on the settings of the 'Original Severity' parameter:</p> <ul style="list-style-type: none"> <li>✓ If configured to <b>Suppressed</b>, the device doesn't send the alarm at all.</li> <li>✓ If configured to any value other than <b>Suppressed</b>, the device always sends the alarm with the configured severity (regardless of condition).</li> </ul> <ul style="list-style-type: none"> <li>■ [1] <b>Indeterminate</b></li> <li>■ [2] <b>Warning</b></li> <li>■ [3] <b>Minor</b></li> <li>■ [4] <b>Major</b></li> <li>■ [5] <b>Critical</b></li> </ul>
<p>'Customized Severity' alarm-customized-severity [CustomizedSeverity]</p>	<p>Defines the new (customized) severity of the alarm. This severity replaces the alarm's original severity that you specified using the 'Original Severity' parameter. For example, if you want to change the severity of the acCertificateExpiryAlarm alarm from minor to major, then configure the 'Original Severity' parameter to <b>Minor</b> and the 'Customized Severity' parameter to <b>Major</b>.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Suppressed</b> = Disables (suppresses) the alarm or a specified severity, depending on the 'Original Severity' parameter:</li> <li>✓ To suppress an alarm: Configure the 'Original Severity' parameter to <b>Default</b>, or if the alarm has only one severity level, configure the 'Original Severity' parameter to this severity. For example, as the acBoardConfigurationError alarm is only sent with critical severity, configure the 'Original Severity' parameter to <b>Critical</b>.</li> <li>✓ To suppress the sending of a specific alarm severity: If the alarm has multiple severity levels (based on conditions), configure the 'Original Severity' parameter to the severity that you don't want the device to send. For example, if you don't want the device to send the acProxyConnectionLost alarm when its' severity is</li> </ul>



Parameter	Description
	<p>minor, configure the 'Original Severity' parameter to <b>Minor</b>.</p> <ul style="list-style-type: none"> <li>■ [1] <b>Indeterminate</b> (default)</li> <li>■ [2] <b>Warning</b></li> <li>■ [3] <b>Minor</b></li> <li>■ [4] <b>Major</b></li> <li>■ [5] <b>Critical</b></li> </ul>

## Configuring SNMP for OVOC Connectivity

Connection between the device and OVOC is through SNMP. Once connected, the device can send SNMP traps to OVOC, and OVOC can perform various operations on the device such as maintenance actions, and fault and performance management.



- Make sure that the SNMP settings on the device and on OVOC are **identical**.
- OVOC uses the following default settings:
  - ✓ Trap port: **162**.
  - ✓ SNMPv2: **public** for the read-community string, **private** for read-write community string, and **trapuser** for the trap community string.
  - ✓ SNMPv3: **OVOCUser** for user name; **SHA-1** for authentication protocol; **AES-128** for privacy protocol; **123456789** for the 'Authentication Key' and 'Privacy Key' password.
- If the device is located behind NAT and you have added it to OVOC by serial number or by auto-detection, you also need to configure (through ini file) the device to send NAT keep-alive traps to the OVOC port to keep the NAT pinhole open for SNMP messages sent from OVOC to the device:
  - ✓ [SendKeepAliveTrap] = [1]
  - ✓ [KeepAliveTrapPort] = [161]
  - ✓ [NatBindingDefaultTimeout] = [30]
- When the device operates in High-Availability (HA) mode and it sends alarms to OVOC, the name of the device as configured by the 'HA Device Name' parameter is displayed at the beginning of the alarm description in OVOC, for example, "(SBCSITE01): Proxy lost. looking for another proxy". However, the name is not displayed for the alarms retrieved (from the device's Active Alarms table) when OVOC **initially** connects to the device.

### ➤ To configure SNMP for device-OVOC connectivity:

1. Make sure that SNMP is enabled (see [Enabling or Disabling SNMP](#) on page 107).
2. Configure the local SNMP port (for Get/Set commands) on the device to 161 (default), as described in [Configuring SNMP Get / Set Port](#) on page 107.

3. Configure an SNMPv2 or SNMPv3 user:
  - **For SNMPv2 user:**
    - i. Configure read-only and read-write community strings ([Configuring SNMP Community Strings](#) on page 108).
    - ii. Configure the community string for traps (see [Configuring SNMP Community String for Traps](#) on page 112).
  - **For SNMPv3 users:** Configure an SNMPv3 user (see [Configuring SNMPv3 Users](#) on page 115).
4. Configure the device to send its traps to OVOC acting as an SNMP Manager (see [Configuring SNMP Trap Destinations](#) on page 110).
5. If the device is located behind NAT and you have added the device to OVOC by its serial number or using auto-detection, you also need to configure (through ini file) the device to send NAT keep-alive traps to the OVOC port to keep the NAT pinhole open for SNMP messages sent from OVOC to the device:
  - a. Enable the sending of NAT keep-alive traps to OVOC, by configuring the [SendKeepAliveTrap] parameter to [1].
  - b. Define the OVOC port to where the device sends the NAT keep-alive traps, by using the [KeepAliveTrapPort] parameter.
  - c. Define the interval between each sent NAT keep-alive trap, by using the [NatBindingDefaultTimeout] parameter.
6. Restart the device with a save-to-flash for your settings to take effect.

## Configuring WebSocket Tunnel with OVOC

When OVOC is deployed in a public cloud environment (e.g., Amazon Web Services), it can manage devices that are located **behind NAT**, by implementing WebSocket tunneling (over HTTP/S). All communication and management traffic (e.g., HTTP-based file download, NTP, syslog, debug recording, and SNMP) between the device and OVOC flows through this WebSocket tunnel. In this tunneling application, the device is the WebSocket client and OVOC is the WebSocket server.

WebSocket tunneling has many advantages over the alternative method for connecting OVOC to the device when located behind NAT (refer to the document [One Voice Operations Center IOM Manual](#) for more information). WebSocket tunneling easily resolves NAT traversal problems and requires minimal amount of configuration (e.g., no need for port forwarding and no need for firewall settings to allow certain traffic).

The WebSocket tunnel connection between the device and OVOC is secure (HTTPS). When the device initiates a WebSocket tunnel connection, it verifies that the TLS certificate presented by OVOC is signed by one of the CAs in the trusted root store of its default TLS Context (ID #0). The device authenticates itself with OVOC using a username and password. These must be the same credentials as configured on OVOC.

By default, the device establishes the WebSocket connection through its default IPv4 OAMP IP interface, but if you want you can associate a different IP Interface. The device keeps the WebSocket tunnel connection open (i.e., persistent), allowing it to send and receive future management traffic through it. The connection only closes before the device (or OVOC) restarts.



- WebSocket tunneling with OVOC for that is Microsoft Azure, Amazon AWS, VMware, or Microsoft Hyper-V cloud platforms To check if other cloud platforms are supported, refer to the [OVOC documentation](#).
- If you configure the address of the WebSocket tunnel server (see the 'OVOC WebSocket Tunnel Server Address' parameter below) as a domain name, you also need to configure the address of the DNS server that you want to use for resolving the domain name into an IP address. This is configured in the IP Interfaces table for the associated IP Interface (see [Configuring IP Network Interfaces](#) on page 157).
- If you configure WebSocket tunneling with OVOC, the IP address **169.254.0.1** must not be configured for any IP Interface in the IP Interfaces table (see [Configuring IP Network Interfaces](#) on page 157).
- If you configure WebSocket tunneling with OVOC, the SBC Configuration Wizard (see [SBC Configuration Wizard](#) on page 1295) is not supported (and not available in the Web interface).
- To configure WebSocket tunneling on OVOC, refer to the document [One Voice Operations Center IOM Manual](#).

The following procedure describes how to configure WebSocket tunneling on the device through the Web interface. You can also configure it through CLI (`configure network > ovoc-tunnel-settings`).

➤ **To configure WebSocket tunneling with OVOC on the device:**

1. Configure an SNMP trap manager with IP address 169.254.0.1 (see [Configuring SNMP Trap Destinations](#) on page 110).



IP address 169.254.0.1 represents the OVOC server in the WebSocket tunnel overlay network.

2. For sending Quality of Experience (QoE) voice metric reports to OVOC, open the Quality of Experience Settings table (see [Reporting QoE to OVOC](#) on page 514), and then configure the 'Primary OVOC Address' parameter to IP address 169.254.0.1.
3. Obtain the OVOC server's default certificate (trusted root certificate) for Managed Devices, and then import (see [Importing Certificates into Trusted Root CA Certificate Store](#) on page 241) the certificate into the device's Trusted Root store of the default TLS Context (ID #0).
4. Open the Web Service Settings page (**Setup** menu > **IP Network** tab > **Web Services** folder > **Web Service Settings**), and then under the OVOC Tunnel group, configure the following parameters:

OVOC TUNNEL	
OVOC WebSocket Tunnel Server Address	<input type="text" value="0.0.0.0"/> ⚡
Interface Name	<input type="text" value="--"/> View ⚡
Path	• <input type="text" value="tun"/> ⚡
Username	• <input type="text" value="VPN"/> ⚡
Password	<input type="password" value="....."/> ⚡
Secured (HTTPS)	<input checked="" type="checkbox"/> ⚡
Verify Certificate	• <input type="checkbox"/> ⚡
Tunnel Connected	Not Configured
Tunnel IP Address	Not Applicable

- a. In the 'OVOC WebSocket Tunnel Server Address' field [WSTunServer], enter the IP address or hostname (FQDN) of the OVOC server. If you configure the parameter to a hostname, the device uses the DNS server configured in [Configuring a DNS Server for HTTP Services](#) on page 462 to resolve it into an IP address. If you use a hostname, the device checks that the hostname matches the certificate's Subject Name.
  - b. From the 'Interface Name' drop-down list [WSTunInterfaceName], select the device's IP Interface for the WebSocket tunnel. If not specified, the device uses the default OAMP IP Interface.
  - c. In the 'Path' [WSTunServerPath] field, enter "tun" (without quotation marks) to match the default OVOC configuration.
  - d. In the 'Username' [WSTunUsername] field, enter the WebSocket Tunnel username configured in OVOC. The default username is "VPN" (without quotation marks).
  - e. In the 'Password' [WSTunPassword] field, enter the WebSocket Tunnel password configured in OVOC. The default password is "123456" (without quotation marks).
  - f. Select the 'Secured (HTTPS)' check box [WSTunSecured] to enable secure (HTTPS) transport for the WebSocket tunnel connection.
  - g. Select the 'Verify Certificate' check box [WSTunVerifyPeer] to enable the device to verify the TLS certificate presented by OVOC during the establishment of the WebSocket tunnel connection.
5. Restart the device with a save-to-flash for your settings to take effect.

You can view the status of the WebSocket connection in the following read-only fields on the Web Service Settings page (see Step 4):

■ **'Tunnel Connected':** Displays the connection status of the WebSocket tunnel:

- "Not Configured"
- "Not Connected"

- "Connected"
  - "Re-Connected"
- **'Tunnel IP Address':** Displays the IP address allocated to the device by OVOC through the WebSocket tunnel.

## 9 INI File-Based Management

You can configure the device through an ini file, which is a text-based file with an \*.ini file extension name, created using any standard text-based editor such as Notepad. Once you have created an ini file with all your configuration settings, you need to install (upload) it to the device to apply the configuration. For a list of the *ini* file parameters, see [Configuration Parameters Reference](#) on page 1563.

### INI File Format

There are two types of *ini* file parameters:

- Individual parameters - see [Configuring Individual ini File Parameters](#) below
- Table parameters - see [Configuring Table ini File Parameters](#) below

### Configuring Individual ini File Parameters

The syntax for configuring individual *ini* file parameters in the ini file is as follows:

- An optional, subsection name (or group name) enclosed in square brackets "[...]". This is used to conveniently group similar parameters by their functionality.
- Parameter name, followed by an equal "=" sign and then its value.
- Comments must be preceded by a semicolon ";".

```
[optional subsection name]
parameter name = value
parameter name = value
; this is a comment line
```

```
; for example:
[System Parameters]
SyslogServerIP = 10.13.2.69
EnableSyslog = 1
```

For general *ini* file formatting rules, see [Syntax Rules for the ini File](#) on page 128.

### Configuring Table ini File Parameters

Table ini file parameters allow you to configure tables, which include multiple parameters (*columns*) and row entries (*indices*). The table ini file parameter is composed of the following elements:

- **Table title:** The name of the table in square brackets, e.g., [MY\_TABLE\_NAME].

- **Format line:** Specifies the columns of the table (by their string names) that are to be configured.
  - The first word of the Format line must be "FORMAT", followed by the Index field name and then an equal "=" sign. After the equal sign, the names of the columns are listed.
  - Columns must be separated by a comma ",".
  - The Format line must only include columns that can be modified (i.e., parameters that are not specified as read-only). An exception is Index fields, which are mandatory.
  - The Format line must end with a semicolon ";".
- **Data line(s):** Contain the actual values of the columns (parameters). The values are interpreted according to the Format line.
  - The first word of the Data line must be the table's string name followed by the Index field.
  - Columns must be separated by a comma ",".
  - A Data line must end with a semicolon ";".
- **End-of-Table Mark:** Indicates the end of the table. The same string used for the table's title, preceded by a backslash "\", e.g., [\MY\_TABLE\_NAME].

The following displays an example of the structure of a table ini file parameter:

```
[Table_Title]
; This is the title of the table.
FORMAT Index = Column_Name1, Column_Name2, Column_Name3;
; This is the format line.
Index 0 = value1, value2, value3;
Index 1 = value1, value 2, value3;
; These are the data lines.
[\Table_Title]
; This is the end-of-the-table-mark.
```

- The table ini file parameter formatting rules are listed below:
- Indices (in both the Format and the Data lines) must appear in the same order. The Index field must never be omitted.
- The Format line can include a subset of the configurable fields in a table. In this case, all other fields are assigned with the pre-defined default values for each configured line.
- The order of the fields in the Format line isn't significant (as opposed to the Index fields). The fields in the Data lines are interpreted according to the order specified in the Format line.
- The order of the Data lines is insignificant.

- Data lines must match the Format line, i.e., it must contain exactly the same number of Indices and Data fields and must be in exactly the same order.
- A row in a table is identified by its table name and Index field. Each such row may appear only once in the *ini* file.
- Table dependencies: Certain tables may depend on other tables. For example, one table may include a field that specifies an entry in another table. This method is used to specify additional attributes of an entity, or to specify that a given entity is part of a larger entity. The tables must appear in the order of their dependency (i.e., if Table X is referred to by Table Y, Table X must appear in the *ini* file before Table Y).

The table below displays an example of a table ini file parameter:

```
[ SNMPUsers ]
FORMAT Index = Username, AuthProtocol, PrivProtocol, AuthKey, PrivKey,
Group;
SNMPUsers 0 = "John", 0, 0, "$1$rIE=", "$1$rIE=", 1;
SNMPUsers 1 = "Sue", 0, 0, "$1$rIE=", "$1$rIE=", 1;
[ \SNMPUsers ]
```



Don't include read-only parameters in table ini file parameters. This may cause an error when uploading the file to the device.

## Syntax Rules for the ini File

The *ini* file must adhere to the following formatting rules:

- The *ini* file name must not include hyphens "-" or spaces; if necessary, use an underscore "\_" instead.
- Lines beginning with a semi-colon ";" are ignored. These can be used for adding remarks in the *ini* file.
- A carriage return (i.e., Enter) must be done at the end of each line.
- The number of spaces before and after the equals sign "=" is irrelevant.
- Subsection names for grouping parameters are optional.
- If there is a syntax error in the parameter name, the value is ignored.
- Syntax errors in the parameter's value can cause unexpected errors (parameters may be set to the incorrect values).
- Parameter string values that denote file names (e.g., CallProgressTonesFileName) must be enclosed with inverted commas, e.g., CallProgressTonesFileName = 'cpt\_usa.dat'.
- The parameter name is not case-sensitive.
- The parameter value is not case-sensitive, except for coder names.



- The *ini* file must end with at least one carriage return.

## Methods for Configuring an ini File

There are different methods that you can use for configuring an ini file before you upload it to the device.

- Modifying the device's current ini file: This method is recommended if you mainly need to change the settings of parameters that you have previously configured.
  - a. Save the device's current configuration as an *ini* file on your computer, using the Web interface (see [Saving Configuration](#) on page 1206).
  - b. Open the file using a text file editor, and then modify the *ini* file as required.
  - c. Save and close the file.
  - d. Upload the file to the device.
- Creating a new ini file that includes only updated configuration:
  - a. Open a text file editor such as Notepad.
  - b. Add only the required parameters and their settings.
  - c. Save the file with the ini file extension name (e.g., myconfiguration.ini).
  - d. Upload the file to the device.

For uploading ini files to the device, see [Uploading an ini File to Device](#) below.



- If you save an ini file from the device and a table row is configured with invalid values, the ini file displays the row prefixed with an exclamation mark (!), for example:

!CpMediaRealm 1 = "ITSP", "Voice", "", 60210, 2, 6030, 0, "", "";

- To restore the device to default settings through the *ini* file, see [Restoring Factory Defaults](#) on page 1308.

## Uploading an ini File to Device

You can upload an *ini* file to the device using the following methods:

### ■ CLI:

- Configuration:
  - ◆ To apply the parameter settings of the file and restore parameters that are not included in the file to default settings:

```
# copy ini-file from <URL>
```

- ◆ To apply the parameter settings of the file and keep the current settings of parameters that are not included in the file:

```
# copy incremental-ini-file from <URL>
```

#### ■ Web interface:

- Auxiliary Files page (see [Uploading Auxiliary Files](#) on page 1220): The device updates its configuration according to the loaded ini file while preserving the remaining current configuration.
- Configuration File page (see [Downloading and Uploading Configuration Files](#) on page 1257): The device updates its configuration according to the loaded ini file and applies default values to parameters that were not included in the loaded ini file.

When you upload an ini file, its configuration settings are saved to the device's non-volatile memory (flash).



Before you upload an *ini* file, make sure that the file extension name is *\*.ini*.

## Secured Encoded ini File

The *ini* file contains sensitive information that is required for the functioning of the device. The file may be uploaded to the device using HTTP. These protocols are not secure and are vulnerable to potential hackers. To overcome this security threat, the AudioCodes DConvert utility allows you to binary-encode (encrypt) the *ini* file before uploading it to the device. For more information, refer to the [DConvert Utility User's Guide](#).



If you save an ini file from the device to a folder on your PC, an *ini* file that was uploaded to the device encoded is saved as a regular *ini* file (i.e., unencoded).

## INI Viewer and Editor Utility

AudioCodes INI Viewer & Editor utility simplifies viewing and editing of the device's downloaded Configuration file (\*.ini). You can download the utility from AudioCodes [website](#). Once installed, every time you download the Configuration file (see [Downloading or Uploading ini File](#) on page 1257), it's automatically opened by this utility.

For more information, refer to the *INI Viewer & Editor User's Guide*, by clicking [here](#).

## 10 REST-Based Management

You can manage the device through the Representational State Transfer (REST) architecture. REST is a Web-based access service, allowing you to access the device's management interface over HTTP/S. Developers can use the device's REST API to integrate the device into their solution and allow administrators to perform management and configuration tasks through automation scripts. The REST API also displays performance monitoring counters.


The REST API relies on a simple pre-defined URL path (**<device's OAMP IP address>/api/v1**) through which device resources can be accessed. Each resource represents a specific device management element (e.g., file upload), state object (e.g., alarms), or maintenance action (e.g., restart). The REST API uses the standard HTTP/1.1 protocol. Standard HTTP methods (GET, PUT, POST and DELETE) are used to read the resource's state and to create, update, and delete the resources, respectively. Resource state is described in JSON format and included in the HTTP request or response bodies.

Basic authentication using your login username and password can be used to access the device's REST interface. However, for security, it's recommended to secure REST traffic using HTTPS. For more information, see [Configuring Secured \(HTTPS\) Web and REST Access](#) on page 74.

### ➤ To access device's REST API interface:

#### 1. Use one of the following methods:

- **Third-party REST API client (e.g., Postman):**
  - i. Configure the top-most endpoint or collection with device's base URL (e.g., `https://10.15.7.96/api/v1/`).
  - ii. Configure the required authorization (e.g., basic authentication, bearer token, or mTLS).
- **Web browser:**
  - i. Start your web browser, and then in the URL field, enter the device's address followed by `"/api/v1"` (e.g., `10.15.7.96/api/v1`); you're prompted to log in with your username and password:



**Sign in**

http://10.15.7.96

Your connection to this site is not private

Username


Password

**Sign in** Cancel




When using mTLS, you're not prompted for your credentials.


- a. Enter your credentials, and then click **Sign in**; the device's REST interface appears, showing the URL paths of the different resource items:



2. Access the required resource item using the shown URL. For example, to access the device's alarms resource, append `/alarms` to the URL (i.e. `10.15.7.96/api/v1/alarms`). Some items have sub-resources such as the alarms item. When you access the alarms item, the URLs to the active and history alarms resources are shown.



3. To access a sub-resource (e.g., active alarms) if exists, use the shown URL. For example, to access the active alarms resource, append `/active` to the URL (i.e. `10.15.7.96/api/v1/alarms/active`).



```
{
  "alarms": [
    {
      "id": 1,
      "description": "IP Group is temporarily blocked. IP Group (IPGroup_2) Blocked Reason: No Working Proxy",
      "url": "/api/v1/alarms/active/1"
    },
    {
      "id": 2,
      "description": "IP Group is temporarily blocked. IP Group (Bruce) Blocked Reason: No Working Proxy",
      "url": "/api/v1/alarms/active/2"
    },
    {
      "id": 3,
      "description": "Ethernet link alarm. LAN port number 2 is down.",
      "url": "/api/v1/alarms/active/3"
    },
    {
      "id": 4,
      "description": "Ethernet link alarm. LAN port number 3 is down.",
      "url": "/api/v1/alarms/active/4"
    },
    {
      "id": 5,
      "description": "Ethernet link alarm. LAN port number 4 is down.",
      "url": "/api/v1/alarms/active/5"
    },
    {
      "id": 6,
      "description": "Rsa keys mismatch: CTX 4: Private key and Certificate do not match",
      "url": "/api/v1/alarms/active/6"
    },
    {
      "id": 7,
      "description": "Rsa keys mismatch: CTX 5: Private key and Certificate do not match",
      "url": "/api/v1/alarms/active/7"
    }
  ],
  "cursor": {
    "after": 7,
    "before": -1
  }
}
```



- If you know the URL of the resource, instead of accessing each resource menu, you can access it directly using the full URL path (e.g., **/api/v1/alarms/active**).
- For more information on REST API, refer to the document [REST API for SBC-Gateway-MSBR Devices](#).

# Part III

## General System Settings

# 11 Date and Time

The device's internal clock (date and time) can be set using one of the following methods:

- Manually (see [Configuring Date and Time Manually](#) on the next page)
- Automatically synchronized using a third-party, remote Simple Network Time Protocol (SNTP) server (see [Synchronizing Date and Time through SNTP](#) on page 137)
- Automatically synchronized using the SIP Date header (see [Synchronizing Date and Time through SIP](#) on page 139)



For automatic synchronization, NTP takes highest preference, and then SIP Date header. For example, if you enable NTP, the device ignores the SIP Date header settings. If you do enable multiple synchronization methods, the device sends the SNMP alarm acClockConfigurationAlarm to notify you of this configuration scenario.

## Viewing Date and Time

You can view the date and time of the device and the method that it uses to obtain or synchronize its date and time.

### ➤ To view date and time:

1. Open the Time & Date page (**Setup** menu > **Administration** tab > **Time & Date**).
2. Under the Time group, the following read-only fields are displayed:

#### TIME

Local Time	18 Dec, 2022 11:41:46
UTC Time	18 Dec, 2022 10:41:46
Time Synchronization Source	Manual

- 'Local Time': Displays the date and time of the geographical location in which the device is deployed.
- 'UTC Time': Displays the UTC time (without offset time or daylight saving), or date and time automatically synchronized through NTP or SIP Date header.
- 'Time Synchronization Source': Indicates the method used by the device to obtain and synchronize its date and time:
  - ◆ "Manual": Date and time is configured manually (see [Configuring Date and Time Manually](#) on the next page).

- ◆ "NTP": Date and time is automatically obtained and synchronized from an Simple Network Time Protocol (SNTP) server (see [Synchronizing Date and Time through SNTP](#) on the next page).
- ◆ "Date Header": Date and time is automatically obtained and synchronized from the SIP Date header (see [Synchronizing Date and Time through SIP](#) on page 139).

## Configuring Date and Time Manually

You can manually configure the date and time of the device instead of using an NTP server (as described in [Synchronizing Date and Time through SNTP](#) on the next page).

### ➤ To manually configure date and time through Web interface:

1. Open the Time & Date page (**Setup** menu > **Administration** tab > **Time & Date**).
2. Under the Set Time group, click **Set Local Time**; the following calendar and time dialog box appears:



A date and time selection dialog box. At the top, it shows navigation arrows, the month 'Dec, 2022', and another navigation arrow. Below is a calendar grid with days of the week (Sun, Mon, Tue, Wed, Thu, Fri, Sat) in red. The dates are arranged in rows: 27-3, 4-10, 11-17, 18-24, 25-31. The date '18' is highlighted with a blue square. Below the calendar is a 'Time' section with three input boxes containing '10', '08', and '17', separated by colons. To the right of the time boxes are up and down arrow icons. At the bottom are three buttons: 'Clear', 'Today', and 'OK'.

3. If you want the current date and time, click **Today**; otherwise, select a specific date and time (HH:MM:SS).
4. Click **OK**; the dialog box closes.
5. Click **Apply**; the date and time is displayed in the 'Local Time' read-only field under the Time group.



If you do a hardware restart, the date and time are returned to default values and therefore, you should update the date and time.

## Synchronizing Date and Time through SNTP

The device's Simple Network Time Protocol (SNTP) client functionality generates requests and reacts to the resulting responses using the NTP Version 3 protocol definitions (according to RFC 1305). Through these requests and responses, the device (acting as an NTP client), synchronizes its date and time to a time source within the network, thereby eliminating any potential issues

should the local clock "drift" during operation. The NTP client follows a simple process in managing system time: 1) the NTP client requests an NTP update, 2) receives an NTP response and then 3) updates the local clock based on an NTP server within the network. The client requests a time update from the user-defined NTP server (IP address or FQDN) at a user-defined update interval. Typically, the update interval is every 24 hours based on when the device was restarted.

You can also configure the device to authenticate and validate NTP messages received from the NTP server. Authentication is done using an authentication key with the MD5 cryptographic hash algorithm. If you enable this feature, the device ignores NTP messages received without authentication.

The following procedure describes how to configure SNTP through the Web interface. For detailed descriptions of the configuration parameters, see [Clock \(Date and Time\) Synchronization Parameters](#) on page 1619.

➤ **To configure SNTP through the Web interface:**

1. Open the Time & Date page (**Setup** menu > **Administration** tab > **Time & Date**), and then scroll down to the NTP Server group:

**NTP SERVER**

<b>Enable NTP</b>	<input checked="" type="checkbox"/>
<b>NTP Interface</b>	<div style="display: flex; align-items: center;"> <span style="margin-right: 5px;">•</span> <div style="border: 1px solid #ccc; padding: 2px 5px; flex-grow: 1;">#0 [O+M+C]</div> <div style="margin-left: 5px; color: #007bff; font-size: 0.8em;">View</div> </div>
<b>Primary NTP Server Address (IP or FQDN)</b>	<div style="border: 1px solid #ccc; padding: 2px 5px;">0.0.0.0</div>
<b>Secondary NTP Server Address (IP or FQDN)</b>	<div style="border: 1px solid #ccc; padding: 2px 5px;">0.0.0.0</div>
<b>NTP Update Interval</b>	<div style="display: flex; align-items: center;"> <div style="margin-right: 10px;">Hours:</div> <div style="border: 1px solid #ccc; padding: 2px 5px; width: 40px; text-align: center;">24</div> <div style="margin: 0 10px;">Minutes:</div> <div style="border: 1px solid #ccc; padding: 2px 5px; width: 40px; text-align: center;">0</div> </div>
<b>NTP Authentication Key Identifier</b>	<div style="border: 1px solid #ccc; padding: 2px 5px;">0</div>
<b>NTP Authentication Secret Key</b>	<div style="border: 1px solid #ccc; padding: 2px 5px; display: flex; align-items: center;"> <span style="flex-grow: 1;">.....</span> <div style="width: 20px; height: 20px; background-color: #007bff; color: white; display: flex; align-items: center; justify-content: center; margin-left: 5px;"> <span style="font-size: 0.8em;">🔑</span> </div> </div>

2. Select the 'Enable NTP' check box to enable SNTP.
3. From the 'NTP Interface' drop-down list, select an IP Interface from the IP Interfaces table (see [Configuring IP Network Interfaces](#) on page 157) that you want to use for NTP communication. By default, the IPv4 OAMP interface is assigned.
4. Configure the NTP server address:
  - In the 'Primary NTP Server Address' [NTPServerIP] field, configure the primary NTP server's address (IPv4 or IPv6, or FQDN).
  - (Optional) In the 'Secondary NTP Server Address' [NTPSecondaryServerIP] field, configure the address of the backup NTP server.
5. In the 'NTP Updated Interval' [NTPUpdateInterval] field, configure the periodic time to synchronize the date and time with the NTP server.

6. Configure NTP message authentication:
  - In the 'NTP Authentication Key Identifier' field, configure the NTP authentication key identifier.
  - In the 'NTP Authentication Secret Key' field, configure the secret authentication key shared between the device and the NTP server.
7. Click **Apply**.
8. Verify that the device has received the correct date and time from the NTP server. The date and time is displayed in the 'UTC Time' read-only field under the Time group (see [Viewing Date and Time](#) on page 135).



- The IP address version (IPv4 or IPv6) of the assigned IP Interface and the NTP server's address must be the same.
- If the device doesn't receive a response from the NTP server, it polls the NTP server for 10 minutes. If there is still no response after this duration, the device declares the NTP server as unavailable and sends the SNMP alarm acNTPServerStatusAlarm. The failed response could be due to incorrect configuration.
- Synchronization by NTP takes highest preference, then by SIP Date header, and only then by PTP. For example, if you enable NTP, the device ignores the SIP Date header and PTP settings. If you do enable multiple synchronization methods, the device sends the SNMP alarm acClockConfigurationAlarm to notify you of this configuration scenario.

## Synchronizing Date and Time through SIP

You can configure the device to synchronize its internal clock (date and time) with a remote SIP endpoint (according to RFC 3261). When enabled, the device obtains the date and time from the Date header in the incoming 200 OK message received in response to a REGISTER request sent by the device. This can be any REGISTER request sent for normal SIP traffic handling (i.e., it's not a specific REGISTER message that is sent to a specific SIP server or endpoint). An example of a SIP Date header with date and time is shown below:

Date: Sat, 12 Mar 2020 23:29:00 GMT

### ➤ To configure clock synchronization through SIP:

1. Open the Time & Date page (**Setup** menu > **Administration** tab > **Time & Date**), and then scroll down to the Date Header Time Sync group:

**DATE HEADER TIME SYNC**Synchronize Time from SIP Date Header • ☒Time Synchronization Interval [sec] 

2. Select the 'Synchronize Time from SIP Date Header' [DateHeaderTimeSync] check box to enable the feature.
3. In the 'Time Synchronization Interval' [DateHeaderTimeSyncInterval] field, enter the minimum time (in seconds) between synchronization updates. For example, if configured to 8640 (24 hours) and the device receives within this 24-hour interval a SIP response to a REGISTER with the Date header, it ignores the date. Only if it receives such a header after this interval does it update its clock according to the header, and then does the next update 24 hours later.
4. Click **Apply**. When the device receives a SIP response with the Date header, it updates its clock and the date and time is displayed in the 'UTC Time' read-only field under the Time group (see [Viewing Date and Time](#) on page 135).



- The device only uses the date and time in the SIP Date header if its value is year 2016 or later.
- If you have enabled clock synchronization using an NTP server (see [Synchronizing Date and Time through SNTP](#) on page 137) and using the SIP Date header, synchronization using the NTP server takes precedence (i.e., device ignores received Date headers). When both are enabled, the device sends the SNMP alarm acClockConfigurationAlarm.
- Once a week, the device stores the clock's date and time in its flash memory. If the device is restarted, its clock is set to this stored date and time, and updated once it receives a Date header in a SIP response to a sent REGISTER message.
- Synchronization by NTP takes highest preference, and then by SIP Date header. For example, if you enable NTP, the device ignores the SIP Date header settings. If you do enable multiple synchronization methods, the device sends the SNMP alarm acClockConfigurationAlarm to notify you of this configuration scenario.

## Configuring UTC Offset or Time Zone

You can configure the time zone in which the device is deployed. This is referred to as the Coordinated Universal Time (UTC) time offset and defines how many hours the device is from Greenwich Mean Time (GMT). For example, Germany Berlin is one hour ahead of GMT (UTC/GMT +1 hour) and therefore, you would configure the offset to "1". USA New York is five hours behind GMT (UTC/GMT offset -5 hours) and therefore, you would configure the offset as a minus value "-5".

➤ **To configure UTC time zone:**

1. Open the Time & Date page (**Setup** menu > **Administration** tab > **Time & Date**), and then scroll down to the Time Zone group:

**TIME ZONE**

UTC Offset      Hours:       Minutes:

2. In the 'UTC Offset' fields (NTPServerUTCOffset), configure the time offset in relation to the UTC. For example, if your region is GMT +1 (an hour ahead), enter "1" in the 'Hours' field.
3. Click **Apply**; the updated time is displayed in the 'UTC Time' read-only field under the Time group (see [Viewing Date and Time](#) on page 135).

## Configuring Daylight Saving Time

You can apply daylight saving time (DST) to the date and time of the device. DST defines a date range in the year (summer) where the time is brought forward so that people can experience more daylight. DST applies an offset of up to 60 minutes (default) to the local time. For example, Germany Berlin has DST from 30 March to 26 October, where the time is brought forward by an hour (e.g., 02:00 to 03:00 on 30 March). Therefore, you would configure the DST offset to 60 minutes (one hour).

➤ **To configure DST through the Web interface:**

1. Open the Time & Date page (**Setup** menu > **Administration** tab > **Time & Date**), and then scroll down to the Time Zone group:

**Daylight Saving Time**     

**DST Mode**     

**Start Time**         :

**End Time**         :

**Offset [min]**     

**Day of Month Start**          :

**Day of Month End**          :

**Daylight Saving Time**



**DST Mode**

**Start Time**

**End Time**

2. Select the 'Daylight Saving Time' (DayLightSavingTimeEnable) check box to enable daylight saving.
3. From the 'DST Mode' drop-down list, select the range type for configuring the start and end dates for DST:
  - **Day of year:** The range is configured by exact date (day number of month), for example, from March 30 to October 30. If 'DST Mode' is set to **Day of year**, in the 'Start Time' (DayLightSavingTimeStart) and 'End Time' (DayLightSavingTimeEnd) drop-down lists, configure the period for which DST is relevant.
  - **Day of month:** The range is configured by month and day type, for example, from the last Sunday of March to the last Sunday of October. If 'DST Mode' is set to **Day of month**, in the 'Start Time' and 'End Time' drop-down lists, configure the period for which DST is relevant.
4. In the 'Offset' (DayLightSavingTimeOffset) field, configure the DST offset in minutes.
5. If the current date falls within the DST period, verify that it has been successful applied to the device's current date and time. You can view the device's date and time in the 'UTC Time' read-only field under the Time group (see [Viewing Date and Time](#) on page 135).

## 12 Configuring a Hostname for the Device

You can configure a hostname (FQDN) for the device, which affects the following:

- **CLI:** The device's CLI (remotely using Telnet/SSH) can be accessed (logged in) using the hostname (instead of the OAMP IP address). The CLI prompt displays the hostname instead of the device type.
- **SNMP:** The device's SNMP interface's SysName object (under MIB-2) is set to the hostname.
- **OVOC:** TLS certificates used by the device for HTTPS-based communication with AudioCodes OVOC are issued with a hostname (instead of an IP address). For certificate signing requests (CSR) with a Certification Authority (CA), the hostname is used as the Common Name (CN or Subject Name) and Subject Alternative Name (SAN). For configuring CSRs, see [Assigning CSR-based Certificates to TLS Contexts](#) on page 231.

If you configure a hostname, you also need to define it on a DNS server so that when queried, the DNS server can resolve the hostname into the device's OAMP IP address.

➤ **To configure a hostname for the device:**

1. Open the Network Settings page (**Setup** menu > **IP Network** tab > **Advanced** folder > **Network Settings**).
2. In the 'Hostname' field [Hostname], enter the hostname.

Hostname

Site44

3. Click **Apply**.



- To configure a hostname for accessing the device's Web interface, see [Configuring a Hostname for Device's Web Interface](#) on page 86.
- For HA systems, the device-pair share the same hostname.

# Part IV

## General VoIP Configuration



## 13 Network

This section describes network-related configuration.


### Building and Viewing your Network Topology

The Network view lets you easily build and view your voice network topology entities, including IP network interfaces, Ethernet Devices (VLANs), Ethernet Groups, and physical Ethernet ports. The Network view graphically displays these entities and the associations between them, giving you a better understanding of your network topology and configuration. You can use the Network view as an alternative to configuring the entities in their respective Web pages or you can use it in combination.

#### ➤ To access the Network view:



- Click the Network View home  icon (**Setup** menu > **IP Network** tab > **Network View**).




The areas of the Network view are shown in the example below and described in the subsequent table.





The figure above is used only as an example; your device may show different Ethernet Groups and Ethernet ports.

**Table 13-1: Description of Network View**

Item	Description
1	<p>Displays IP Interfaces that you configured in the IP Interfaces table (see <a href="#">Configuring IP Network Interfaces</a> on page 157). IP Interfaces appear as icons, showing the application type ("OCM" for OAMP, "C" for Control, and "M" for Media), row index number, name, and IP address, for example:</p>  <ul style="list-style-type: none"> <li>■ <b>Edit:</b> Opens a dialog box in the IP Interfaces table to modify the IP Interface.</li> <li>■ <b>Show List:</b> Opens the IP Interfaces table, allowing you to configure IP Interfaces.</li> <li>■ <b>Delete:</b> Opens the IP Interfaces table where you are prompted to confirm deletion of the IP Interface.</li> </ul> <p><b>To add an IP Interface:</b></p> <ol style="list-style-type: none"> <li>1. Click  <b>Add IP Interface</b>; the IP Interfaces table opens with a new dialog box for adding an IP Interface to the next available index row.</li> <li>2. Configure the IP Interface as desired, and then click <b>Apply</b>; the IP Interfaces table closes and you are returned to the Network View, displaying the newly added IP Interface.</li> </ol>
2	<p>Displays configured Ethernet Devices (see <a href="#">Configuring Underlying Ethernet Devices</a> on page 154). The Ethernet Device appears as an icon, displaying the row index number, name, VLAN ID and if its tagged or untagged. If you click the icon, a drop-down menu appears, listing commands:</p>

Item	Description
	<div data-bbox="692 280 1128 728">  </div> <ul style="list-style-type: none"> <li>■ <b>Edit:</b> Opens a dialog box in the Ethernet Devices table to modify the Ethernet Device.</li> <li>■ <b>Show List:</b> Opens the Ethernet Devices table, allowing you to configure all Ethernet Devices.</li> <li>■ <b>Delete:</b> Opens the Ethernet Devices table where you are prompted to confirm deletion of the Ethernet Device.</li> </ul> <p><b>To add an Ethernet Device:</b></p> <ol style="list-style-type: none"> <li>1. Click  <b>Add VLAN</b>; the Ethernet Devices table opens with a new dialog box for adding an Ethernet Device to the next available index row.</li> <li>2. Configure the Ethernet Devices as desired, and then click <b>Apply</b>; the Ethernet Devices table closes and you are returned to the Network View, displaying the newly added Ethernet Device.</li> </ol>
3	<p>Displays configured Ethernet Groups (see <a href="#">Configuring Ethernet Port Groups</a> on page 151). The Ethernet Groups appear as icons, displaying the row index number, and name. Ethernet ports associated with Ethernet Groups are indicated by lines connecting between them, as shown in the example below:</p> <div data-bbox="646 1527 1171 1975">  </div>


Item	Description
	<p><b>To edit an Ethernet Group:</b></p> <ol style="list-style-type: none"> <li>1. Click the Ethernet Group icon, and then from the drop-down menu, choose <b>Edit</b>; the Ethernet Groups table opens with a dialog box for editing the Ethernet Group.</li> <li>2. Configure the Ethernet Group as desired, and then click <b>Apply</b>; the Ethernet Groups table closes and you are returned to the Network View.</li> </ol> <p>To open the Ethernet Groups table, click any Ethernet Group icon, and then from the drop-down menu, choose <b>Show List</b>. You can then view and edit all the Ethernet Groups in the table.</p>
4	<p>Configures and displays the device's Ethernet ports.</p> <p><b>To configure an Ethernet port:</b></p> <ol style="list-style-type: none"> <li>1. Click the required port icon, and then from the drop-down menu, choose <b>Edit</b>; the Physical Ports table opens with a dialog box for editing the Ethernet port.</li> <li>2. Configure the Ethernet Port as desired, and then click <b>Apply</b>; the Physical Ports table closes and you are returned to the Network View.</li> </ol> <p>For more information on configuring Ethernet ports, see <a href="#">Configuring Underlying Ethernet Devices</a> on page 154.</p> <p>The Ethernet ports appear as icons, displaying the row index number, description, and port string number, as shown in the example below:</p> <div data-bbox="858 1234 963 1352" data-label="Image"> </div> <p>The connectivity status of the port is indicated by the color of the icon:</p> <ul style="list-style-type: none"> <li>■  Green: Network connectivity exists through port (port connected to network).</li> <li>■  Red: No network connectivity through port (e.g., cable disconnected).</li> </ul> <p>To refresh the status indication, click the <b>Refresh Network View</b> button (described below in Item #5).</p> <p>To open the Physical Ports table, click any port icon, and then from the drop-down menu, choose <b>View List</b>. You can then view and edit all the ports in the table.</p>
5	<p>If you keep the Network view page open for a long time, you may want to click the <b>Refresh Network View</b> button to refresh the connectivity status display of the Ethernet ports.</p>

## Configuring Physical Ethernet Ports

The Physical Ports table lets you configure the device's Ethernet ports. This includes configuring port speed and duplex mode (half or full), and a brief description of the port. The table also displays the status of the port as well as the port group (*Ethernet Group*) to which the port belongs. For more information on Ethernet Groups, see [Configuring Ethernet Port Groups](#) on page 151.

The names of the ports displayed in the device's management tools (e.g., Web interface) are different to the labels of the physical ports on the chassis. The figure below shows the mapping between the two:

**Figure 13-1: Ethernet Port String Names**



You can also view the mapping of the ports, using the following CLI command:

```
# show network physical-port
```




- All LAN ports have the same MAC address, which is the MAC address of the device.
- Each Ethernet Group must have a unique VLAN ID in scenarios where the ports of multiple Ethernet Groups are connected to the same switch.

The following procedure describes how to configure Ethernet ports through the Web interface. You can also configure it through ini file [PhysicalPortsTable] or CLI (`configure network > physical-port`).

### ➤ To configure the physical Ethernet ports:

1. Open the Physical Ports table (**Setup** menu > **IP Network** tab > **Core Entities** folder > **Physical Ports**).
2. Select a port that you want to configure, and then click **Edit**; the following dialog box appears:



**Physical Ports [GE\_1\_1]**

GENERAL		ETHERNET GROUP	
Index	0	Member of Ethernet Group	GROUP 1
Name	GE 1_1	Group Status	Active
Description	User Port #0		
Mode	Enable		
Speed and Duplex	Auto Negotiation		

3. Configure the port according to the parameters described in the table below.
4. Click **Apply**, and then restart the device with a save-to-flash for your settings to take effect.

**Table 13-2: Physical Ports Table Parameter Descriptions**

Parameter	Description
<b>General</b>	
'Index'	(Read-only) Displays the index number for the table row.
'Name' port [Port]	(Read-only) Displays the Ethernet port number. See the figure in the beginning of this section for the mapping between the GUI port number and the physical port on the chassis.
'Description' port- description [PortDescription]	Defines a description of the port. By default, the value is "User Port #<row index>". <b>Note:</b> Configure each row with a unique name.
'Mode' mode [Mode]	(Read-only) Displays the mode of the port. <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b></li> <li>■ [1] <b>Enable</b> (default)</li> </ul>
'Speed and Duplex' speed-duplex [SpeedDuplex]	Defines the speed and duplex mode of the port. <ul style="list-style-type: none"> <li>■ [0] <b>10BaseT Half Duplex</b></li> <li>■ [1] <b>10BaseT Full Duplex</b></li> <li>■ [2] <b>100BaseT Half Duplex</b></li> <li>■ [3] <b>100BaseT Full Duplex</b></li> <li>■ [4] <b>Auto Negotiation</b> (default)</li> <li>■ [6] <b>1000BaseT Half Duplex</b></li> <li>■ [7] <b>1000BaseT Full Duplex</b></li> </ul>

Parameter	Description
<b>Ethernet Group</b>	
'Member of Ethernet Group' group-member [GroupMember]	(Read-only) Displays the Ethernet Group to which the port belongs. To assign the port to a different Ethernet Group, see <a href="#">Configuring Ethernet Port Groups</a> below.
'Group Status' group-status [GroupStatus]	(Read-only) Displays the status of the port: <ul style="list-style-type: none"> <li>■ "Active": Active port. When the Ethernet Group includes two ports and their transmit / receive mode is configured to <b>REDUN_2RX_1TX</b> or <b>REDUN_2RX_2TX</b>, both ports show "Active".</li> <li>■ "Redundant": Standby (redundant) port.</li> </ul>

## Configuring Ethernet Port Groups

The Ethernet Groups table lets you configure Ethernet Groups. An Ethernet Group represents a physical Ethernet port(s) on the device. You can assign an Ethernet Group with one, two, or no ports (*members*). When two ports are assigned to an Ethernet Group, 1+1 Ethernet port redundancy can be implemented in your network. In such a configuration, one port can be active while the other standby or both ports can be active, depending on the ports' transmit (Tx) and receive (Rx) settings. This provides port redundancy within the Ethernet Group, whereby if a port is disconnected the device switches over to the other port in the Ethernet Group. If you configure an Ethernet Group with only one port, the Ethernet Group operates as a single port (no redundancy).

The Ethernet Groups table lets you configure the transmit (Tx) and receive (Rx) settings of the Ethernet ports per Ethernet Group. The Tx/Rx setting is applicable only to Ethernet Groups that contain two ports. This setting determines if both ports or only one of the ports can receive and transmit traffic.

The maximum number of Ethernet Groups that you can configure is the same as the number of Ethernet ports provided by the device. Thus, the device supports up to four Ethernet Groups. You can assign one or two ports to an Ethernet Group. By default, each Ethernet Group is assigned twoports (Ethernet Group 2 which is assigned only port 0/3); the other Ethernet Groups are empty. For default port assignment to Ethernet Groups, see [Configuring Physical Ethernet Ports](#) on page 149.

You can assign Ethernet ports to IP network interfaces. This is done by first configuring an Ethernet Device with the required Ethernet Group containing the port or ports (see [Configuring Ethernet Port Groups](#)). Then by assigning the Ethernet Device to the IP network interface in the IP Interfaces table (see [Configuring IP Network Interfaces](#) on page 157). This enables physical separation of network interfaces, providing a higher level of segregation of sub-networks. Equipment connected to different physical ports is not accessible to one another; the only

connection between them can be established by cross connecting them with media streams (VoIP calls).

The port names (strings) displayed in the Ethernet Groups table represent the physical ports on the device. For the mapping of these strings to the physical ports, see [Configuring Physical Ethernet Ports](#) on page 149.



- If you want to assign a port to a different Ethernet Group, you must first remove the port from its current Ethernet Group. To remove the port, configure the 'Member' field so that no port is selected or select a different port.
- As all ports have the same MAC address, you must connect each port to a different Layer-2 switch.
- When implementing 1+1 Ethernet port redundancy, each port in the Ethernet Group (port pair) must be connected to a different switch (but in the same subnet).

The following procedure describes how to configure Ethernet Groups through the Web interface. You can also configure it through ini file [EtherGroupTable] or CLI (`configure network > ether-group`).

#### ➤ To configure Ethernet Groups:

1. Open the Ethernet Groups table (**Setup** menu > **IP Network** tab > **Core Entities** folder > **Ethernet Groups**).
2. Select the Ethernet Group that you want to configure, and then click **Edit**; the following dialog box appears:

Ethernet Groups [GROUP\_1] - x

GENERAL	
Index	0
Name	GROUP_1
Mode	REDUN_1RX_1TX
Member 1	#0 [GE_4_1] <a href="#">View</a>
Member 2	#1 [GE_4_2] <a href="#">View</a>
Active Port	GE_4_1

3. Configure the Ethernet Group according to the parameters described in the table below.
4. Click **Apply**, and then restart the device with a save-to-flash for your settings to take effect.

**Table 13-3: Ethernet Groups Table Parameter Descriptions**

Parameter	Description
'Index'	(Read-only) Displays the index number for the table row.



Parameter	Description
'Name' group [EtherGroupTable_ Group]	(Read-only) Displays the Ethernet Group number.
'Mode' mode [EtherGroupTable_Mode]	<p>Defines the mode of operation of the ports in the Ethernet Group. This applies only to Ethernet Groups containing two ports.</p> <ul style="list-style-type: none"> <li>■ [0] <b>NONE</b> = Select this option to remove all ports from the Ethernet Group.</li> <li>■ [1] <b>SINGLE</b> = Select this option if the Ethernet Group contains only one port.</li> <li>■ [2] <b>REDUN_1RX_1TX</b> = (Default) At any given time, only one of the ports in the Ethernet Group transmits and receives packets. If a link exists on both ports, the active one is either the first to have a link up or the lower-numbered port if both have the same link up from start.</li> <li>■ [3] <b>REDUN_2RX_1TX</b> = Both ports in the Ethernet Group can receive packets, but only one port can transmit. The transmitting port is determined arbitrarily by the device. If the selected port fails at a later stage, a switchover to the redundant port is done, which begins to transmit and receive.</li> <li>■ [4] <b>REDUN_2RX_2TX</b> = Both ports in the Ethernet Group can receive and transmit packets. This option is applicable only to the Maintenance interface when the device operates in High-Availability (HA) mode. For more information, see <a href="#">Network Topology Types and Rx/Tx Ethernet Port Group Settings</a> on page 1181.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ When implementing High Availability: <ul style="list-style-type: none"> <li>✓ It's recommended to use <b>REDUN_2RX_1TX</b> for the Maintenance interface.</li> <li>✓ When the Ethernet cables are connected back-to-back between the two devices, don't use <b>REDUN_1RX_1TX</b> for the Maintenance interface. This is because both sides may choose different ports, resulting in disconnected traffic.</li> </ul> </li> </ul>

Parameter	Description
	For more information on Ethernet Group settings for HA, see <a href="#">Network Topology Types and Rx/Tx Ethernet Port Group Settings</a> on page 1181.
'Member 1' member1 [EtherGroupTable_ Member1]	Assigns the first port to the Ethernet Group. To assign no port, set this field to <b>NONE</b> .  <b>Note:</b> Before you can re-assign a port to a different Ethernet Group, you must first remove the port from its current Ethernet Group. To remove the port, either set this field to <b>NONE</b> or to a different port.
'Member 2' member2 [EtherGroupTable_ Member2]	Assigns the second port to the Ethernet Group. To assign no port, set this field to <b>NONE</b> .  <b>Note:</b> Before you can re-assign a port to a different Ethernet Group, you must first remove the port from its current Ethernet Group. To remove the port, either set this field to <b>NONE</b> or to a different port.
'Active Port'	(Read-only) Displays the currently active port of the Ethernet Group.  If the 'Mode' is <b>SINGLE</b> or <b>REDUN_1RX_1TX</b> , the field displays the name of the active port. If the 'Mode' is <b>REDUN_2RX_1TX</b> or <b>REDUN_2RX_2TX</b> , the field displays "Both". If there are no port members in the Ethernet Group, the field displays "None".

## Configuring Underlying Ethernet Devices

The Ethernet Devices table lets you configure up to 16 *Ethernet Devices*. An Ethernet Device represents a Layer-2 bridging device and is assigned a VLAN ID and an Ethernet Group (Ethernet port group). Multiple Ethernet Devices can be associated with the same Ethernet Group. The Ethernet Device (VLAN) can be configured with a VLAN tagging policy, which determines whether the Ethernet Device accepts tagged or untagged packets received on the Ethernet port associated with the Ethernet Device.

Once configured, assign the Ethernet Device to an IP network interface in the IP Interfaces table ('Underlying Device' field) and/or with a static route in the Static Routes table ('Ethernet Output Device' field). You can assign the same Ethernet Device to multiple IP network interfaces and thereby, implement multi-homing (multiple addresses on the same interface/VLAN).

By default, the device provides a pre-configured Ethernet Device at Index 0 with the following settings:

- Name: "vlan 1"

- VLAN ID: 1
- Ethernet Group: GROUP 1
- Tagging Policy: Untagged
- MTU: 1500

The pre-configured Ethernet Device is associated with the default IP network interface (ie., OAMP) in the IP Interfaces table. The Untagged policy of the pre-configured Ethernet Device enables you to connect to the device using the default OAMP interface.

You can view configured Ethernet Devices that have been successfully applied to the device (saved to flash) in the Ethernet Device Status table. This page is accessed by clicking the **Ethernet Device Status Table** button located at the bottom of the Ethernet Devices table. The Ethernet Device Status table can also be accessed from the Navigation tree (see [Viewing Ethernet Device Status](#) on page 1370).



You cannot delete an Ethernet Device that is associated with an IP network interface (in the IP Interfaces table). You can only delete it after you've disassociated it from the IP network interface.

The following procedure describes how to configure Ethernet Devices through the Web interface. You can also configure it through ini file [DeviceTable] or CLI (`configure network > network-dev`).

➤ **To configure an Ethernet Device:**

1. Open the Ethernet Devices table (**Setup** menu > **IP Network** tab > **Core Entities** folder > **Ethernet Devices**).
2. Click **New**; the following dialog box appears:

3. Configure an Ethernet Device according to the parameters described in the table below.

4. Click **Apply**.**Table 13-4: Ethernet Devices Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [DeviceName]	Defines a name for the Ethernet Device. The name is used to associate the Ethernet Device with an IP network interface in the IP Interfaces table ('Underlying Device' field - see <a href="#">Configuring IP Network Interfaces</a> on the next page) and/or with a static route in the Static Routes table ('Ethernet Output Device' field - see <a href="#">Configuring Static IP Routes</a> on page 174).
'VLAN ID' vlan-id [VlanID]	Defines a VLAN ID for the Ethernet Device. The valid value is 1 to 3999. The default is 1. <b>Note:</b> Each Ethernet Device must be configured with a unique VLAN ID.
'Underlying Interface' underlying-if [UnderlyingInterface]	Assigns an Ethernet Group to the Ethernet Device. To configure Ethernet Groups, see <a href="#">Configuring Ethernet Port Groups</a> on page 151. <b>Note:</b> The parameter is mandatory.
'Tagging' tagging [Tagging]	Defines VLAN tagging for the Ethernet Device. <ul style="list-style-type: none"><li>■ [0] <b>Untagged</b> = (Default for pre-configured Ethernet Device) The Ethernet Device accepts untagged packets and packets with the same VLAN ID as the Ethernet Device. Incoming untagged packets are assigned the VLAN ID of the Ethernet Device. The Ethernet Device sends these VLAN packets untagged (i.e., removes the VLAN ID).</li><li>■ [1] <b>Tagged</b> = (Default for new Ethernet Devices) The Ethernet Device accepts packets that have the same VLAN ID as the Ethernet Device and sends packets with this VLAN ID. For all Ethernet Devices that are associated with the same Ethernet Group (see 'Underlying Interface' parameter above) and configured to <b>Tagged</b>, incoming untagged packets received on this Ethernet Group are discarded.</li></ul> <b>Note:</b> Only one Ethernet Device can be configured as Untagged per associated Ethernet Group. In other words, if multiple Ethernet Devices are associated with the same Ethernet Group, only one of these Ethernet Devices can be configured to <b>Untagged</b> ; all the others must be configured to <b>Tagged</b> .

Parameter	Description
'MTU' mtu [MTU]	<p>Defines the Maximum Transmission Unit (MTU) in bytes per VLAN (Ethernet Device).</p> <p>The valid value is 68 to 1,500. The default is 1,500.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ MTU is not applicable to SBC Direct Media traffic and to debug recording traffic.</li> <li>■ If your first Ethernet Device is configured with an untagged VLAN, its MTU value is the maximum MTU that can be configured for all other Ethernet Devices that are associated with the same Ethernet Group. In other words, if you configure additional Ethernet Devices (tagged VLANs) that are associated with the same Ethernet Group, their MTUs must be equal to or less than the MTU of the first Ethernet Device (untagged VLAN). For example, if the untagged VLAN is configured with MTU of 100 bytes, you can configure a tagged VLAN with an MTU value of either 100 bytes or less.</li> <li>■ If your first Ethernet Device is configured with a tagged VLAN and you later configure an additional Ethernet Device with an untagged VLAN that is associated with the same Ethernet Group, the MTU of the untagged VLAN must be equal to or greater than the highest MTU value configured out of all the Ethernet Devices (VLANs) associated with the Ethernet Group. For example, if VLAN 1 is configured with the highest MTU (100 bytes) out of all your VLANs, you can configure an untagged VLAN with an MTU value of either 100 bytes or greater.</li> </ul>

## Configuring IP Network Interfaces

The IP Interfaces table lets you configure up to 16 IP Interfaces.

The device is shipped with a default IP Interface (Index #0 and named "O+M+C") that has an IPv4 address (see [Default IP Address](#) on page 12). This default IP Interface can be used for all types of traffic (*Application Types*) - Operations, Administration, Maintenance and Provisioning (OAMP), *Media* (RTP or voice) and *Control* (SIP signaling).



- The default IPv4 OAMP IP Interface is **used by default by many of the device's features**. For example, management access (Web, REST, CLI over Telnet, CLI over SSH, and SNMP) uses the default IP Interface. In addition, if you don't specify an IP Interface for features (e.g., syslog), the device uses the default IP Interface.



Some features (e.g., WebSocket tunneling and OVOC-managed licensing such as Floating License) don't allow you to specify an IP Interface and always use the default IP Interface. In addition, the device uses the default IP Interface for DNS if the IP Interface that you have associated with a feature is not configured with a DNS server (see the 'Primary DNS' parameter in this section for more information).

Therefore, it's recommended **not** to delete the default IPv4 OAMP interface. If removal is necessary (e.g., for an all-IPv6 deployment), make sure that you've assigned valid IP Interfaces to all required features.

- If you're using WebSocket tunneling for any of the device's features, the IP address **169.254.0.1** must not be configured for any IP Interface in the IP Interfaces table. WebSocket tunneling is used, for example, for OVOC (see [Configuring WebSocket Tunnel with OVOC](#) on page 122) or WebRTC (see [Configuring WebRTC](#)).

You can configure IP Interfaces for specific traffic (*Application Type*):

■ **OAMP:** The default IP Interface is used for accessing the device's management interfaces - Web, CLI (Telnet and SSH), REST, and SNMP. However, you can configure different IP Interfaces for management interfaces (with any Application Type) and then assign them to the relevant management interface:

- For Web- and REST-based management, use the Web Interfaces table (see [Configuring Web Interfaces](#) on page 51).
- For Telnet-based management, use the Telnet Interfaces table (see [Configuring Telnet Interface](#) on page 97).
- For SSH-based management, use the SSH Interfaces table (see [Configuring SSH Interfaces](#) on page 98).
- For SNMP-based management, see [Configuring SNMP Interfaces](#) on page 113.



- You can configure IP Interfaces for management interfaces with any Application Type (OAMP, Media, Control, or any combination). However, at least one OAMP IP Interface must be configured in the IP Interfaces table.
- By default, the Web Interfaces, Telnet Interfaces, and SSH Interfaces tables all provide a pre-configured interface that is associated with the default IP Interface (IPv4 OAMP).


■ **Media:** This Application Type is used for media (RTP or voice) traffic.

■ **Control:** This Application Type is used for SIP signaling traffic (messaging).

■ **MAINTENANCE:** This Application Type is used for HA maintenance traffic when the device operates in High-Availability (HA) mode.

You can configure the device with a single IP Interface (default) for all Application Types. Alternatively, you can configure multiple logical, IP Interfaces for these applications. You may need to logically separate network segments for these applications for administration and

security. This can be achieved by employing Layer-2 VLANs and Layer-3 subnets. The figure below illustrates a typical network architecture where the device is configured with three IP Interfaces, each representing the OAMP, Control, and Media applications. The device is connected to a VLAN-aware switch for directing traffic from and to the device to the three separated Layer-3 broadcast domains according to VLAN tags (middle pane).



Prior to configuring your IP Interfaces, please adhere to the following guidelines:


- **At least one** OAMP interface must be configured (IPv4 or IPv6).
- Up to **two** OAMP interfaces can be configured, each with a different IP version (IPv4 or IPv6).
- OAMP interfaces can be combined with Media and Control type interfaces.
- At least one Media interface **must** be configured (IPv4 or IPv6). The Media interface can be combined with OAMP and/or Control type interfaces.
- At least one Control interface **must** be configured (IPv4 or IPv6). The Control interface can be combined with OAMP and/or Media type interfaces.
- Multiple Control and Media interfaces can be configured and they can have overlapping IP addresses and subnets.
- The prefix length replaces the dotted-decimal subnet mask presentation and **must** have a value of 0-31 for IPv4 addresses, and a value of 64 for IPv6 addresses.
- IP Interface types (OAMP, Media, and Control) can be combined:
  - Example 1:
    - ◆ One combined OAMP-Media-Control interface with an IPv4 address.
    - ◆ One combined OAMP-Media-Control interface with an IPv6 address.

- Example 2:
  - ◆ One OAMP interface with an IPv4 address.
  - ◆ One or more Control interfaces with IPv4 addresses.
  - ◆ One or more Media interfaces with IPv4 addresses.
- Example 3:
  - ◆ One OAMP interface with an IPv4 address.
  - ◆ One combined Media-Control interface with an IPv4 address.
  - ◆ One combined Media-Control interface with an IPv6 address.
- Multiple IP Interfaces that are assigned to the same Ethernet Device can't be configured with different Default Gateways. If you need to use a different Default Gateway for one of the subnets defined on this Ethernet Device to reach a specific network (and not a default destination route), configure a Static Route rule.
- The address of the Default Gateway **must** be in the same subnet as the associated IP Interface. Additional static routing rules can be configured in the Static Routes table.
- The IP Interface name **must** be configured (mandatory) and must be unique for each interface.
- Each IP Interface must be assigned an Ethernet Device. You can assign the same Ethernet Device to multiple IP Interfaces. However, for IP Interfaces that are assigned the same Ethernet Device (VLAN), only one of the IP Interfaces can be configured for dynamic IPv6 addressing.

The following procedure describes how to configure IP network interfaces through the Web interface. You can also configure it through ini file [InterfaceTable] or CLI (`configure network > interface network-if`).

### ➤ To configure IP Interfaces:

1. Open the IP Interfaces table (**Setup** menu > **IP Network** tab > **Core Entities** folder > **IP Interfaces**).
2. Click **New**; the following dialog box appears:



GENERAL		IP ADDRESS	
Index	2	Interface Mode	IPv6 Manual
Name		IP Address	0.0.0.0
Application Type	OAMP + Media + Control	Prefix Length	16
Ethernet Device	--	Default Gateway	0.0.0.0

DNS	
Primary DNS	0.0.0.0
Secondary DNS	0.0.0.0
Overwrite Dynamic DNS Servers	Disable

3. Configure the IP network interface according to the parameters described in the table below.
4. Click **Apply**.



- On the toolbar, click **Save** to save your settings to flash memory.



- If you change the address of the OAMP interface through which you are currently connected to the device and then click **Apply**, connectivity with the device is lost. You then need to re-access the device with the new OAMP address, and then click the **Save** button on the toolbar for the new address to take effect.
- If you edit or delete an IP Interface, current calls using the interface are immediately terminated.
- If you delete an IP Interface, rows configured in other tables (e.g., Media Realms table) that are associated with the deleted IP Interface, lose their association with the IP Interface ('Interface Name' field displays "None") and the rows become invalid.
- The SBC Configuration Wizard isn't supported and isn't available in the Web interface (see [SBC Configuration Wizard](#) on page 1295) if you configure any IPv6 interfaces in the IP Interfaces table.
- To view currently active IP Interfaces, click the **IP Interface Status Table** link located at the bottom of the table. For more information, see [Viewing Active IP Interfaces](#) on page 1370.
- Upon device start up, the IP Interfaces table is parsed and passes a comprehensive validation test. If any errors occur during this validation phase, the device sends an error message to the syslog server and falls back to a "safe mode", using a single interface without VLANs. It's recommended that you view the syslog messages that the device sends at startup to see if any errors occurred.
- Complementing the IP Interfaces table is the Static Routes table, which lets you configure static routing rules for non-local hosts/subnets. For more information, see [Configuring Static IP Routes](#) on page 174.

**Table 13-5: IP Interfaces Table Parameters Description**

Parameter	Description
<b>General</b>	
'Index' network-if [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [InterfaceName]	Defines a name for the interface. The valid value is a string of up to 16 characters. The default (if no name is configured) is "Interface_n", where <i>n</i> is the row index number. <b>Note:</b> <ul style="list-style-type: none"> <li>Configure each row with a unique name.</li> <li>The parameter value cannot contain a forward slash (/).</li> </ul>

Parameter	Description
'Application Type' application-type [ApplicationTypes]	<p>Defines the type of application (traffic) for which you want to use the IP Interface (see note below).</p> <ul style="list-style-type: none"> <li>■ [0] <b>OAMP</b> = This IP Interface type is the device's Operations, Administration, Maintenance and Provisioning (OAMP) management interface, which is used for device management through Web, CLI (Telnet and SSH), SNMP, and REST. The device is shipped with a default OAMP (and Media and Control) interface which has an IPv4 address (see <a href="#">Default IP Address</a> on page 12). By default, this IPv4 OAMP interface is also used for various device applications such as syslog and debugging (but you can configure the device to use different IP Interfaces for these applications).</li> <li>■ [1] <b>Media</b> = This IP Interface type is typically used for media (i.e., RTP streams of voice).</li> <li>■ [2] <b>Control</b> = This IP Interface is typically used for the SIP call control application.</li> <li>■ [3] <b>OAMP + Media</b> = Combined OAMP and Media applications.</li> <li>■ [4] <b>OAMP + Control</b> = Combined OAMP and Call Control applications.</li> <li>■ [5] <b>Media + Control</b> = Combined Media and Call Control applications.</li> <li>■ [6] <b>OAMP + Media + Control</b> = Combined All application types are allowed on the interface.</li> <li>■ [99] <b>MAINTENANCE</b> = This IP Interface is used when the device is in High-Availability (HA) mode and is for HA maintenance traffic. This IP Interface represents one of the LAN interfaces or Ethernet Groups on each device in the HA system, used for the Ethernet connectivity between the two devices. For more information on HA and the Maintenance interface, see on page 1175.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ You can configure up to <b>two</b> OAMP interfaces (dedicated or combined with Media and/or</li> </ul>

Parameter	Description
	<p>Control), but each must have a different IP version (IPv4 or IPv6). At least one OAMP interface must exist in the IP Interfaces table.</p> <ul style="list-style-type: none"> <li>■ If you edit or delete the MAINTENANCE interface (for HA mode), you must restart the device for your changes to take effect.</li> </ul>
'Ethernet Device' underlying-dev [UnderlyingDevice]	<p>Assigns an Ethernet Device (see <a href="#">Configuring Underlying Ethernet Devices</a> on page 154) to the IP interface.</p> <p>An Ethernet Device is a Layer-2 bridging device, which is a VLAN that is associated with a physical Ethernet port (Ethernet Group). This is useful for setting trusted and untrusted networks on different physical Ethernet ports. You can assign the same Ethernet Device to multiple IP Interfaces, providing multi-homing IP configuration (i.e., multiple IP addresses on the same interface / VLAN).</p> <p>By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> <li>■ For IP Interfaces that are assigned the same Ethernet Device (VLAN), only one of the IP Interfaces can be configured for dynamic IPv6 addressing (i.e., 'Interface Mode' parameter below configured to <b>IPv6 Stateless</b> or <b>IPv6 DHCP</b>).</li> <li>■ For IP Interfaces that are assigned the same Ethernet Device (VLAN), only one of the IP Interfaces can be configured for dynamic IPv4 addressing (i.e., 'Interface Mode' parameter below configured to <b>IPv4 DHCP</b>).</li> </ul>
<b>IP Address</b>	
'Interface Mode' mode [InterfaceMode]	<p>Defines the method to configure the IP address of the IP Interface.</p> <ul style="list-style-type: none"> <li>■ [0] <b>IPv6 Stateless</b> = This option dynamically acquires an IPv6 address for the IP Interface, using the IPv6 Stateless Address</li> </ul>

Parameter	Description
	<p>Autoconfiguration (SLAAC) method. This auto-configures the IP Interface with an IPv6 address without the need for the device to manage a DHCP server. The device generates the IPv6 address using local and non-local information. The non-local information is the prefix advertised by routers, which forms the first 64-bit segment (network part) of the 128-bit address. The local information is generated by the device using an algorithm based on the device's MAC address, which forms the second 64-bit segment (client ID). The device ensures that a unique IPv6 address is generated for the IP Interface. This option can also be used to acquire the addresses for the DNS servers through DHCP (see 'Primary DNS' and 'Secondary DNS' parameters below), and the address for the Default Gateway through Router Advertisement (RA) messages (see 'Default Gateway' parameter below).</p> <ul style="list-style-type: none"> <li>■ [3] <b>IPv6 Manual Prefix</b> = This option is used if you want to manually configure an IPv6 prefix (higher 64 bits) while the interface ID (the lower 64 bits) is derived from the device's MAC address.</li> <li>■ [4] <b>IPv6 Manual</b> = This option is used if you want to manually configure an IPv6 address (128 bits).</li> <li>■ [10] <b>IPv4 Manual</b> = (Default) This option is used if you want to manually configure an IPv4 address (32 bits).</li> <li>■ [13] <b>IPv6 DHCP</b> = This option dynamically acquires an IPv6 address for the IP Interface, using the Stateful (DHCPv6) Autoconfiguration method. The device acts as a DHCP client to obtain the IPv6 address(es) from an external DHCP server. The device sends a DHCP request once you have configured the IP Interface and upon every device restart. The DHCP server can also provide the addresses for the DNS servers (see 'Primary DNS' and 'Secondary DNS' parameters below) and the address for the Default Gateway (see 'Default Gateway'</li> </ul>

Parameter	Description
	<p>parameter below). Based on the DHCP lease time, the device renews its lease over the IP address(es) with the DHCP server.</p> <ul style="list-style-type: none"> <li>■ <b>[11] IPv4 DHCP</b> = This option dynamically acquires an IPv4 address for the IP Interface. The device acts as a DHCP client to obtain the IPv4 address from an external DHCP server. The device sends a DHCP request once you have configured the IP Interface and upon every device restart. The DHCP server can also provide the addresses for the DNS servers (see 'Primary DNS' and 'Secondary DNS' parameters below) and the address for the Default Gateway (see 'Default Gateway' parameter below). Based on the DHCP lease time, the device renews its lease over the IP address(es) with the DHCP server.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you configure the parameter to <b>IPv6 Stateless</b>, <b>IPv6 DHCP</b>, or <b>IPv4 DHCP</b>, the following parameters become read-only: 'IP Address', 'Prefix Length', 'Default Gateway', 'Primary DNS', and 'Secondary DNS'.</li> <li>■ Dynamic IPv6 addressing (i.e., <b>IPv6 Stateless</b>, <b>IPv6 DHCP</b>, and <b>IPv4 DHCP</b>) is not supported in High-Availability (HA) mode.</li> </ul>
<p>'IP Address'</p> <p><code>ip-address</code></p> <p>[IPAddress]</p>	<p>Defines an IP address.</p> <p>The valid value is an IPv4 address (in dotted-decimal notation) or an IPv6 address (see RFC 4291). By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you configure the 'Interface Mode' parameter (see above) to <b>IPv6 Manual Prefix</b>, <b>IPv6 Manual</b>, or <b>IPv4 Manual</b>, the 'IP Address' parameter is mandatory.</li> <li>■ For IPv6, instead of configuring a static address using this parameter, you can use dynamic IPv6 addressing (stateless or stateful) to autoconfigure the IP Interface with an IPv6 address (and optionally, with DNS addresses and</li> </ul>

Parameter	Description
	<p>the Default Gateway address). Therefore, if you configure the 'Interface Mode' parameter (see above) to <b>IPv6 Stateless</b> or <b>IPv6 DHCP</b>, the 'IP Address' parameter is read-only and automatically populated with the dynamic IPv6 address after you apply your IP Interface settings.</p> <ul style="list-style-type: none"> <li>■ For IPv4, instead of configuring a static address using this parameter, you can use DHCP to autoconfigure the IP Interface with an IPv4 address (and optionally, with DNS addresses and the Default Gateway address). Therefore, if you configure the 'Interface Mode' parameter (see above) to <b>IPv4 DHCP</b>, the 'IP Address' parameter is read-only and automatically populated with the dynamic IPv4 address after you apply your IP Interface settings.</li> </ul>
'Prefix Length' prefix-length [PrefixLength]	<p>Defines the prefix length of the related IP address. This is a Classless Inter-Domain Routing (CIDR)-style representation of a dotted-decimal subnet notation. The CIDR-style representation uses a suffix indicating the number of bits which are set in the dotted-decimal format. For example, 192.168.0.0/16 is synonymous with 192.168.0.0 and subnet 255.255.0.0. This CIDR lists the number of '1' bits in the subnet mask (i.e., replaces the standard dotted-decimal representation of the subnet mask for IPv4 interfaces). For example, a subnet mask of 255.0.0.0 is represented by a prefix length of 8 (i.e., 11111111 00000000 00000000 00000000) and a subnet mask of 255.255.255.252 is represented by a prefix length of 30 (i.e., 11111111 11111111 11111111 11111100).</p> <p>The prefix length is a Classless Inter-Domain Routing (CIDR) style presentation of a dotted-decimal subnet notation. The CIDR-style presentation is the latest method for interpretation of IP addresses. Specifically, instead of using eight-bit address blocks, it uses the variable-length subnet masking technique to allow allocation on arbitrary-length prefixes.</p> <p>The valid value of the prefix length depends on the IP address version:</p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ <b>IPv4:</b> 0 to 31</li> <li>■ <b>IPv6:</b> Depends on the settings of the 'Interface Mode' parameter (above): <ul style="list-style-type: none"> <li>✓ <b>IPv6 Manual Prefix:</b> 64</li> <li>✓ <b>IPv6 Manual:</b> Up to 126</li> </ul> </li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For IPv6, instead of configuring a static prefix length using this parameter, you can use dynamic IPv6 addressing (stateless or stateful) to autoconfigure the IP Interface with an IPv6 address and prefix (and optionally, with DNS addresses and the Default Gateway address). Therefore, if you configure the 'Interface Mode' parameter (see above) to <b>IPv6 Stateless</b> or <b>IPv6 DHCP</b>, the 'Prefix Length' parameter is read-only and automatically populated with the dynamic IPv6 address after you apply your IP Interface settings.</li> <li>■ For IPv4, instead of configuring a static address using this parameter, you can use DHCP to autoconfigure the IP Interface with an IPv4 address and prefix (and optionally, with DNS addresses and the Default Gateway address). Therefore, if you configure the 'Interface Mode' parameter (see above) to <b>IPv4 DHCP</b>, the 'Prefix Length' parameter is read-only and automatically populated with the dynamic IPv4 address after you apply your IP Interface settings.</li> </ul>
'Default Gateway' gateway [Gateway]	<p>Defines the IP address of the Default Gateway for the IP Interface. When the device sends traffic from this IP Interface to an unknown destination (i.e., not in the same subnet and not defined for any static routing rule), it forwards the traffic to this Default Gateway.</p> <p>By default, no value is defined.</p> <p>When configuring a prefix length value of 31 (for IPv4 point-to-point connections), configure the peer IP address as the Default Gateway IP address.</p> <p><b>Note:</b></p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ For IPv6, instead of configuring a static address using this parameter, you can use dynamic IPv6 addressing (stateless or stateful) to autoconfigure the IP Interface with a Default Gateway IPv6 address. Therefore, if you configure the 'Interface Mode' parameter (see above) to <b>IPv6 Stateless</b> or <b>IPv6 DHCP</b>, the 'Default Gateway' parameter becomes read-only. However, it's not populated with the obtained IPv6 address. To view the obtained Default Gateway address, use the CLI command <code>show network route</code> or view it in the Static Routes Status table (see <a href="#">Viewing Static Routes Status</a> on page 1371).</li> <li>■ For IPv4, instead of configuring a static address using this parameter, you can use DHCP to autoconfigure the IP Interface with a Default Gateway IPv4 address. Therefore, if you configure the 'Interface Mode' parameter (see above) to <b>IPv4 DHCP</b>, the 'Default Gateway' parameter becomes read-only. However, it's not populated with the obtained IPv4 address. To view the obtained Default Gateway address, use the CLI command <code>show network route</code> or view it in the Static Routes Status table (see <a href="#">Viewing Static Routes Status</a> on page 1371).</li> </ul>
<b>DNS</b>	
'Primary DNS' <code>primary-dns</code> [PrimaryDNSServerIPAddress]	<p>Defines the primary DNS server's IP address (IPv4 or IPv6), which is used for translating (resolving) domain names (FQDNs) into IP addresses for applications that are associated with the IP Interface.</p> <p>By default, no IP address is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For IPv6, instead of configuring a static DNS address using this parameter, you can use dynamic IPv6 addressing (stateless or stateful) to obtain the address through DHCP. Therefore, if you configure the 'Interface Mode' parameter (see above) to <b>IPv6 Stateless</b> or <b>IPv6 DHCP</b>, the</li> </ul>



Parameter	Description
	<p>'Primary DNS' parameter becomes read-only and is automatically populated with the dynamic IPv6 address after you apply your IP Interface settings. You can also manually overwrite the obtained address, by using the 'Overwrite Dynamic DNS Servers' parameter (below).</p> <ul style="list-style-type: none"> <li>■ For IPv4, instead of configuring a static DNS address using this parameter, you can obtain the address through DHCP. Therefore, if you configure the 'Interface Mode' parameter (see above) to <b>IPv4 DHCP</b>, the 'Primary DNS' parameter becomes read-only and is automatically populated with the dynamic IPv4 address after you apply your IP Interface settings. You can also manually overwrite the obtained address, by using the 'Overwrite Dynamic DNS Servers' parameter (below).</li> <li>■ If you assign an IP Interface to one of the device's configuration entities (e.g., Proxy Set) or services (e.g., LDAP) that require DNS functionality, but the IP Interface is not configured with a DNS server or the configured DNS server is unreachable, the device performs DNS fallback. The DNS fallback is according to a customized DNS fallback policy (see <a href="#">Configuring DNS Fallback Policy</a> on page 201). If you haven't configured a DNS Fallback Policy, the device's default DNS fallback sequence is used (see <a href="#">Configuring Default DNS Servers</a> on page 195).</li> <li>■ The DNS servers that are configured for IP Interfaces are not used for HTTP services (see <a href="#">HTTP-based Proxy Services</a> on page 459). To configure DNS servers for HTTP services, see <a href="#">Configuring a DNS Server for HTTP Services</a> on page 462.</li> </ul>
'Secondary DNS' secondary-dns [SecondaryDNSServerIPAddress]	<p>Defines the secondary DNS server's IP address (IPv4 or IPv6), which is used for translating domain names into IP addresses for applications that are associated with the IP interface.</p> <p>By default, no IP address is defined.</p>

Parameter	Description
	<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For IPv6, instead of configuring a static DNS address using this parameter, you can use dynamic IPv6 addressing (stateless or stateful) to obtain the address through DHCP. Therefore, if you configure the 'Interface Mode' parameter (see above) to <b>IPv6 Stateless</b> or <b>IPv6 DHCP</b>, the 'Secondary DNS' parameter becomes read-only and is automatically populated with the dynamic IPv6 address after you apply your IP Interface settings. You can also manually overwrite the obtained address, by using the 'Overwrite Dynamic DNS Servers' parameter (below).</li> <li>■ For IPv4, instead of configuring a static DNS address using this parameter, you can obtain the address through DHCP. Therefore, if you configure the 'Interface Mode' parameter (see above) to <b>IPv4 DHCP</b>, the 'Secondary DNS' parameter becomes read-only and is automatically populated with the dynamic IPv4 address after you apply your IP Interface settings. You can also manually overwrite the obtained address, by using the 'Overwrite Dynamic DNS Servers' parameter (below).</li> </ul>
<p>'Overwrite Dynamic DNS Servers'</p> <p>overwrite-dynamic-dn-servers</p> <p>[OverwriteDynamicDNSServers]</p>	<p>Enables you to overwrite the DNS addresses that are obtained through DHCP for the 'Primary DNS' and 'Secondary DNS' parameters (above).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) The DNS addresses that are obtained from the DNS server and automatically used as the values for the 'Primary DNS' and 'Secondary DNS' parameters can't be overwritten (i.e., read-only).</li> <li>■ [1] <b>Enable</b> = The DNS addresses that are obtained from the DNS server and automatically used as the values for the 'Primary DNS' and 'Secondary DNS' parameters can be overwritten (i.e., you can manually configure the addresses instead).</li> </ul> <p><b>Note:</b> This parameter is applicable only if you are implementing dynamic IPv4 addressing (i.e.,</p>

Parameter	Description
	'Interface Mode' parameter configured to <b>IPv4 DHCP</b> ) or dynamic IPv6 addressing (i.e., 'Interface Mode' parameter configured to <b>IPv6 Stateless</b> or <b>IPv6 DHCP</b> ).

## Networking Configuration Examples

Examples of IP network interface configuration are listed below:

### ■ Single IP network interface for all applications:

The IP Interfaces table is configured with a single interface for OAMP, Media and Control:

Index	Name	Application Type	Ethernet Device	Interface Mode	IP Address	Prefix Length	Default Gateway
0	myInterface	OAMP + Media + Control	1	IPv4 Manual	192.168.0.2	16	192.168.0.1

Two routes are configured in the **Static Routes table** for directing traffic for subnet 201.201.0.0/16 to 192.168.11.10, and all traffic for subnet 202.202.0.0/16 to 192.168.11.1:

Index	Destination	Prefix Length	Gateway
0	201.201.0.0	16	192.168.11.10
1	202.202.0.0	16	192.168.11.1

The NTP applications remain with their default application types.

### ■ Multiple interfaces, one per application type:

The IP Interfaces table is configured with three interfaces, each for a different application type (one for OAMP, one for Call Control, and one for RTP Media), and each with a different VLAN ID and default gateway:

Index	Name	Application Type	Ethernet Device	Interface Mode	IP Address	Prefix Length	Default Gateway
0	ManagementIF	OAMP	1	IPv4 Manual	192.168.0.2	16	192.168.0.1

Index	Name	Application Type	Ethernet Device	Interface Mode	IP Address	Prefix Length	Default Gateway
1	myControlIF	Control	200	IPv4 Manual	200.200.85.14	24	200.200.85.1
2	myMediaIF	Media	211	IPv4 Manual	211.211.85.14	24	211.211.85.1

A routing rule in the Static Routes table is required to allow remote management from a host in 176.85.49.0/24:

Index	Destination	Prefix Length	Gateway
0	176.85.49.0	24	192.168.11.1

All other parameters are set to their respective default values. The NTP application remains with its default application types.

#### ■ Multiple interfaces with combined application types:

- A single interface for OAMP.
- Interfaces for Call Control and Media applications, where two of them are IPv4 interfaces and one is an IPv6 interface.

The IP Interfaces table is configured as follows:

Index	Name	Application Type	Ethernet Device	Interface Mode	IP Address	Prefix Length	Default Gateway
0	Mgmt	OAMP	1	IPv4 Manual	192.168.0.2	16	192.168.0.1
1	MediaCtrl1	Media + Control	201	IPv4 Manual	200.200.85.14	24	200.200.85.1
2	MediaCtrl2	Media + Control	202	IPv4 Manual	200.200.86.14	24	200.200.86.1
3	V6CtrlMedia2	Media + Control	202	IPv6 Manual	2000::1:200:200:86:14	64	::

Index	Name	Application Type	Ethernet Device	Interface Mode	IP Address	Prefix Length	Default Gateway
				I			

1. A routing rule in the Static Routes table is required to allow remote management from a host in 176.85.49.0/24:

Index	Destination	Prefix Length	Gateway
0	176.85.49.0	24	192.168.0.10

The NTP application is configured (through the ini file) to serve as OAMP applications:

```
EnableNTPasOAM = 1
```

Configure Layer-2 QoS mapping in the QoS Mapping table. Packets sent with the configured DiffServ get the configured VLAN priority:

Index	Differentiated Services	VLAN Priority
0	46	6
1	40	6
2	26	4
3	10	2

Configure Layer-3 QoS in the QoS Settings table:

- 'Media Premium QoS' - the default DiffServ value is 46
- 'Control Premium QoS' - the default DiffServ value is 24
- 'Gold QoS' - the default DiffServ value is 26
- 'Bronze QoS' - the default DiffServ value is 10

#### ■ IP Network Interfaces and Multiple Default Gateways:

This example includes a different Default Gateway per IP network interface. The Default Gateway of the OAMP interface is 192.168.0.1 and of the Media and Control is 200.200.85.1. The configuration in the IP Interfaces table is shown below:

Index	Name	Application Type	Ethernet Device	Interface Mode	IP Address	Prefix Length	Default Gateway
0	Mgmt	OAMP	100	IPv4 Manual	192.168.0.2	16	192.168.0.1
1	CntrlMedia	Media & Control	200	IPv4 Manual	200.200.85.14	24	200.200.85.1

Configuring the following static routing rules in the Static Routes table enables OAMP applications to access peers on subnet 17.17.0.0 through the Default Gateway 192.168.10.1 and Media + Control applications to access peers on subnet 171.79.39.0 through Default Gateway 200.200.85.10 (which is not the default gateway of the interface).

Index	Destination	Prefix Length	Ethernet Output Device	Gateway
0	17.17.0.0	16	100	192.168.10.1
1	171.79.39.0	24	200	200.200.85.10

## Configuring Static IP Routes

The Static Routes table lets you configure up to 30 static IP routing rules. Static routes let you communicate with LAN networks that are not located behind the Default Gateway that is specified for an IP network interface in the IP Interfaces table, from which the packets are sent. Before sending an IP packet, the device searches the Static Routes table for an entry that matches the requested destination host/network. If an entry is found, the device sends the packet to the gateway that is configured for the static route. If no explicit entry is found, the packet is sent to the Default Gateway as configured for the IP interface in the IP Interfaces table.

You can view the status of configured static routes in the IP Routing Status table. This table can be accessed by clicking the **Static Routes Status Table** link located at the bottom of the Static Routes table (see [Viewing Static Routes Status](#) on page 1371).

The following procedure describes how to configure static routes through the Web interface. You can also configure it through ini file [StaticRouteTable] or CLI (`configure network > static`).

### ➤ To configure static IP routes:

1. Open the Static Routes table (**Setup** menu > **IP Network** tab > **Core Entities** folder > **Static Routes**).
2. Click **New**; the following dialog box appears:

Static Routes - x

GENERAL

Index	<input style="width: 90%;" type="text" value="4"/>
Destination	<input style="width: 90%;" type="text" value="0.0.0.0"/>
Prefix Length	<input style="width: 90%;" type="text" value="16"/>
Ethernet Output Device	<input style="width: 90%;" type="text" value="--"/> <a href="#" style="color: #0070C0; text-decoration: none; font-size: small;">View</a>
Gateway	<input style="width: 90%;" type="text" value="0.0.0.0"/>
Description	<input style="width: 90%;" type="text"/>

3. Configure a static route according to the parameters described in the table below. The address of the host/network you want to reach is determined by an AND operation that is applied to the fields 'Destination' and 'Prefix Length'. For example, to reach network 10.8.x.x, enter "10.8.0.0" in the 'Destination' field and "16" in the 'Prefix Length'. As a result of the AND operation, the value of the last two octets in the 'Destination' field are ignored. To reach a specific host, enter its IP address in the 'Destination' field and "32" in the 'Prefix Length' field.
4. Click **Apply**, and then save your settings to flash memory.



- You can only delete Static Route rules that are inactive.
- You can configure only one Static Route rule with the same 'Destination' and 'Ethernet Output Device'.

**Table 13-6: Static Routes Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. The valid value is 0 to 29. <b>Note:</b> Each row must be configured with a unique index.
'Destination' destination [Destination]	Defines the IP address of the destination host/network. The destination can be a single host or a whole subnet, depending on the prefix length configured for this routing rule.
'Prefix Length' prefix-length [PrefixLength]	Defines the Classless Inter-Domain Routing (CIDR)-style representation of a dotted-decimal subnet notation of the destination host/network. The CIDR-style representation uses a suffix indicating the number of bits that are set in the dotted-decimal format. For example, the value 16 represents subnet 255.255.0.0

Parameter	Description
	<p>The valid value depends on the IP address version:</p> <ul style="list-style-type: none"> <li>■ IPv4: 0 to 32</li> <li>■ IPv6: 0 to 128</li> </ul>
'Ethernet Output Device' device-name [DeviceName]	<p>Associates an IP network interface through which the static route's Gateway is reached. The association is done by assigning the parameter the same Ethernet Device that is assigned to the IP network interface in the IP Interfaces table ('Ethernet Device' parameter). To configure IP network interface, see <a href="#">Configuring IP Network Interfaces</a> on page 157. To configure Ethernet Devices, see <a href="#">Configuring Underlying Ethernet Devices</a> on page 154.</p>
'Gateway' gateway [Gateway]	<p>Defines the IP address of the Gateway (next hop) used for traffic destined to the subnet/host configured in the 'Destination' and 'Prefix Length' parameters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The Gateway's address must be in the same subnet as the IP address of the network interface that is associated with the static route (using the 'Ethernet Output Device' parameter - see above).</li> <li>■ The IP network interface associated with the static route must be of the same IP address family (IPv4 or IPv6).</li> </ul>
'Description' description [Description]	<p>Defines a name for the rule.</p> <p>The valid value is a string of up to 20 characters.</p>

## Configuration Example of Static IP Routes


An example of the use for static routes is shown in the figure below. In the example, the device needs to communicate with a softswitch at IP address 10.1.1.10. However, the IP network interface from which packets destined for 10.1.1.10 is sent, is configured to send the packets to a Default Gateway at 10.15.0.1. Therefore, the packets do not reach the softswitch. To resolve



this problem, a static route is configured to specify the correct gateway (10.15.7.22) in order to reach the softswitch.

Note the following configuration:

- The static route is configured with a subnet mask of 24 (255.255.255.0), enabling the device to use the static route to send all packets destined for 10.1.1.x to this gateway and therefore, to the network in which the softswitch resides.
- The static route in the Static Routes table must be associated with the IP network interface in the IP Interfaces table. This is done by configuring the 'Ethernet Output Device' field in the Static Routes table to the same value as configured in the 'Ethernet Device' field in the IP Interfaces table.
- The static route's Gateway address in the Static Routes table is in the same subnet as the IP address of the IP network interface in the IP Interfaces table.



#### No Static Route:

The device sends packets to 10.15.0.1, which is the Default Gateway defined for this IP network interface in the IP Interfaces table. Therefore, the device will not succeed in reaching the softswitch.

INDEX	NAME	APPLICATION TYPE	INTERFACE MODE	IP ADDRESS	PREFIX LENGTH	DEFAULT GATEWAY	PRIMARY DNS	SECONDARY DNS	ETHERNET DEVICE
0	O+M+C	OAMP + Media	IPv4 Manual	10.15.7.95	16	10.15.0.1	0.0.0.0	0.0.0.0	vlan 1

#### Static Route Configured:

A static route with the correct gateway is needed for routing to the softswitch. The device communicates with the softswitch (10.1.1.0/24) using the gateway 10.15.7.22. Note that the device first searches for a matching route in the Static Routes table. If not found, it uses the default gateway defined in the IP Interfaces table.

INDEX	DESTINATION	PREFIX LENGTH	ETHERNET OUTPUT DEVICE	GATEWAY	DESCRIPTION
0	10.1.1.0	24	vlan 1	10.15.7.22	Softswitch

## Troubleshooting the Static Routes Table

When adding a new static route to the Static Routes table, the added rule passes a validation test. If errors are found, the static route is rejected and not added to the table. Failed static route validations may result in limited connectivity (or no connectivity) to the destinations specified in the incorrect static route. For any error found in the Static Routes table or failure to configure a static route, the device sends a notification message to the syslog server reporting the problem.

Common static routing configuration errors may include the following:

- The IP address specified in the 'Gateway' field is unreachable from the IP network interface associated with the static route.
- The same destination has been configured in two different static routing rules.
- More than 30 static routes have been configured.



If a static route is required to access OAMP applications (for remote management, for example) and the route is not configured correctly, the route is not added and the device is not accessible remotely. To restore connectivity, the device must be accessed locally from the OAMP subnet and the required routes be configured.

## Network Address Translation Support

Network Address Translation (NAT) is a mechanism that maps internal IP addresses (and ports) used within a private network to global IP addresses and vice versa, providing transparent routing to end hosts. The primary advantages of NAT include (1) reduction in the number of global IP addresses required in a private network (global IP addresses are only used to connect to the Internet) and (2) better network security by hiding the internal architecture.

The design of SIP creates a problem for VoIP traffic to pass through NAT. SIP uses IP addresses and port numbers in its message body. However, the NAT server is unable to modify the SIP messages and thus, can't change local addresses to global addresses.

This section discusses the device's solutions for overcoming NAT traversal issues.


### Device Located behind NAT

Two different streams of traffic traverse through NAT - signaling and media. A device located behind NAT that initiates a signaling path has problems receiving incoming signaling responses, as they are blocked by the NAT server. Therefore, the initiating device must inform the receiving device where to send the media. To resolve this NAT problem, the device provides the following solutions (listed in priority of the method used):

- (Gateway Application Only) If configured, uses the single Static NAT IP address for all interfaces - see [Configuring a Static NAT IP Address for All Interfaces](#) on the next page
- NAT Translation table, which configures NAT per IP network interface - see [Configuring NAT per IP Interface](#) on the next page.

If NAT is not configured, the device sends the packet according to its IP address configured in the IP Interfaces table.

The figure below illustrates the NAT problem faced by SIP networks when the device is located behind a NAT:



### Configuring a Static NAT IP Address for All Interfaces

You can configure a global (public) IP address of the router to enable static NAT between the device and the Internet for all network interfaces. The device replaces the source IP address for media of all outgoing SIP messages sent on any of its network interfaces to this public IP address.

The following procedure describes how to configure a static NAT address through the Web interface. You can also configure it through ini file [StaticNATIP] or CLI (`configure voip > sip-definition settings > nat-ip-addr`).

#### ➤ To configure a single static NAT IP address:

1. Open the Gateway General Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Gateway General Settings**).
2. In the 'NAT IP Address' field, enter the NAT IP address in dotted-decimal notation.

**Figure 13-2: Configuring Static NAT IP Address**

**NAT IP Address**

3. Click **Apply**.



The feature is applicable only to the Gateway application.

### Configuring NAT per IP Interface

The NAT Translation table lets you configure up to 32 network address translation (NAT) rules for translating source IP addresses into NAT IP addresses (*global - public*) when the device is located behind NAT.

The device's NAT traversal mechanism replaces the source IP address of SIP messages sent from a specific IP Interface (Control or Media) in the IP Interfaces table to a public IP address. This allows, for example, the separation of VoIP traffic between different ITSPs and topology hiding of internal IP addresses from the “public” network. Each IP Interface (configured in the IP Interfaces table) can be associated with a NAT rule, translating the source IP address and port of the outgoing packet into the NAT address (IP address and port range).

The following procedure describes how to configure NAT translation rules through the Web interface. You can also configure it through ini file [NATTranslation] or CLI (`configure network > nat-translation`).

➤ **To configure NAT translation rules:**

1. Open the NAT Translation table (**Setup** menu > **IP Network** tab > **Core Entities** folder > **NAT Translation**).
2. Click **New**; the following dialog box appears:

3. Configure a NAT translation rule according to the parameters described in the table below.
4. Click **Apply**, and then save your settings to flash memory.

**Table 13-7: NAT Translation Table Parameter Descriptions**

Parameter	Description
<b>Source</b>	
'Index' index [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Source Interface' src-interface-name [SrcIPInterfaceName]	Assigns an IP Interface (configured in the IP Interfaces table) to the rule. Outgoing packets sent from the specified network interface are NAT'ed. By default, no value is defined. To configure IP Interfaces, see <a href="#">Configuring IP Network Interfaces</a> on page 157.

Parameter	Description
'Source Start Port' src-start-port [SourceStartPort]	Defines the optional starting port range (0-65535) of the IP interface, used as matching criteria for the NAT rule. If not configured, the match is done on the entire port range. Only IP addresses and ports of matched source ports will be replaced.
'Source End Port' src-end-port [SourceEndPort]	Defines the optional ending port range (0-65535) of the IP interface, used as matching criteria for the NAT rule. If not configured, the match is done on the entire port range. Only IP addresses and ports of matched source ports will be replaced.
Target	
'Target IP Address' target-ip-address [TargetIPAddress]	Defines the global (public) IP address. The device adds the address in the outgoing packet to the SIP Via header, Contact header, 'o=' SDP field, and 'c=' SDP field.
'Target Start Port' target-start-port [TargetStartPort]	Defines the optional starting port range (0-65535) of the global address. If not configured, the ports are not replaced. Matching source ports are replaced with the target ports. This address is set in the SIP Via and Contact headers and in the 'o=' and 'c=' SDP fields.
'Target End Port' target-end-port [TargetEndPort]	Defines the optional ending port range (0-65535) of the global address. If not configured, the ports are not replaced. Matching source ports are replaced with the target ports. This address is set in the SIP Via and Contact headers and in the 'o=' and 'c=' SDP fields.

## SIP User Agent Located behind NAT

This section describes configuration for scenarios where the device sends signaling and media packets to a remote SIP user agent (UA) that is located behind NAT.

### Enabling SIP NAT Detection when UA Located behind NAT

By default, the device resolves NAT issues for SIP signaling, using its NAT Detection mechanism. The NAT Detection mechanism checks whether the endpoint is located behind NAT by comparing the source IP address of the incoming UDP/TCP packet (in which the SIP message is received) with the IP address in the SIP Contact header. If the packet's source IP address is a public address and the Contact header's IP address is a local address, the device considers the endpoint as located behind NAT. In this case, the device sends the SIP messages to the

endpoint using the packet's source IP address. Otherwise (or if you have disabled the NAT Detection mechanism), the device sends the SIP messages according to the SIP standard (RFC 3261), where requests within the SIP dialog are sent using the IP address in the Contact header and responses to INVITEs are sent using the IP address in the Via header.

If necessary, you can also configure the device to always consider incoming SIP INVITE messages as sent from endpoints that are located behind NAT. When this is enabled, the device sends responses to the INVITE (to the endpoint) using the source IP address of the packet (INVITE) initially received from the endpoint. This is useful in scenarios where the endpoint is located behind a NAT firewall and the device (for whatever reason) is unable to identify NAT using its regular NAT Detection mechanism. This feature is enabled per specific calls using the 'Always Use Source Address' parameter in the IP Groups table (see [Configuring IP Groups](#) on page 581). If this feature is disabled, the device's NAT detection is according to the settings of the global parameter, 'SIP NAT Detection' parameter (see below procedure).

➤ **To enable NAT Detection feature (global):**

1. Open the Transport Settings page (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **Transport Settings**).
2. Select the 'SIP NAT Detection' check box (SIPNatDetection):

SIP NAT Detection ☒


3. Click **Apply**.

### **Media (RTP/RTCP/T.38)**

When a remote UA initiates a call and is not located behind a NAT server, the device sends the media (RTP, RTCP, and T.38) packets to the remote UA using the IP address:port (UDP) indicated in the SDP body of the SIP message received from the UA. However, if the UA is located behind NAT, the device sends the RTP with the IP address of the UA (i.e., private IP address) as the destination instead of that of the NAT server. Thus, the RTP will not reach the UA. To resolve this NAT traversal problem, the device offers the following features:

- First Incoming Packet Mechanism - see [First Incoming Packet Mechanism](#) on the next page
- RTP No-Op packets according to the avt-rtp-noop draft - see [No-Op Packets](#) on the next page

The figure below illustrates a typical network architecture where the remote UA is located behind NAT:



### First Incoming Packet Mechanism

In scenarios where the remote user agent (UA) resides behind a NAT server, it's possible that the device, if not configured for NAT traversal, will send the media (RTP, RTCP and T.38) streams to an invalid IP address and UDP port. In other words, it will send the media to the private IP address:port of the UA and not the public address (of the NAT server) and therefore, the media will not reach the UA. When the UA is located behind NAT, although the UA sends its private IP address:port in the original SIP message (INVITE), the device receives the media packets with a source address of a public IP address:port (i.e., allocated by the NAT server). Therefore, to ensure that the media reaches the UA, the device must send it to the public address.

The device identifies whether the UA is located behind NAT by comparing the source IP address of the first received media packet with the IP address and UDP port of the first received SIP message (INVITE) when the SIP session was started. This is done for each media type--RTP, RTCP and T.38--and therefore, they can have different destination IP addresses and UDP ports than one another.

The device supports various NAT traversal methods, which you can configure using the 'NAT Traversal' (NATMode) parameter. For more information on the different options provided by this parameter, see [NAT and STUN Parameters](#) on page 1614.

#### ➤ To enable NAT resolution using the First Incoming Packet mechanism:

1. Open the Media Settings page (**Setup** menu > **Signaling & Media** tab > **Media** folder > **Media Settings**).
2. From the 'NAT Traversal' drop-down list (NATMode), select the required NAT option.

**NAT Traversal**

• **NAT by Signaling Restricted** ▼

3. Click **Apply**.

### No-Op Packets

The device can send No-Op packets to verify Real-Time Transport Protocol (RTP) and T.38 connectivity, and to keep NAT bindings and Firewall pinholes open. The No-Op packets can be sent in RTP and T.38 formats:

- **RTP No-Op:** The RTP No-Op support complies with IETF Internet-Draft draft-wing-avt-rtp-noop-03 ("A No-Op Payload Format for RTP"). The IETF document defines a No-Op payload format for RTP. The draft defines the RTP payload type as dynamic. You can configure the payload type as described in the following procedure (default is 120).
- **T.38 No-Op:** T.38 No-Op packets are sent only while a T.38 session is activated. Sent packets are a duplication of the previously sent frame (including duplication of the sequence number).

➤ **To configure the No-Op packet feature:**

1. Enable the feature, using the [NoOpEnable] parameter. You can also enable this feature per IP Profile (for SBC calls only), using the 'Generate No-Op Packets' parameter (see [Configuring IP Profiles](#) on page 664).
2. Configure the interval between each No-Op packet sent by the device during the silence period (i.e., no RTP or T.38 traffic), using the [NoOpInterval] parameter.
3. For RTP No-Op packets, configure the payload type of the No-Op packets, using the [RTPNoOpPayloadType] parameter.



The receipt of No-Op packets is always supported.

### Fax Transmission behind NAT

The device supports transmission from fax machines (connected to the device) located inside (behind) NAT. Generally, the firewall blocks T.38 (and other) packets received from the WAN, unless the device behind the NAT sends at least one IP packet from the LAN to the WAN through the firewall. If the firewall blocks T.38 packets sent from the termination IP fax, the fax fails. To overcome this problem, the device sends No-Op ("no-signal") packets to open a pinhole in the NAT for the answering fax machine. The originating fax doesn't wait for an answer, but immediately starts sending T.38 packets to the terminating fax machine upon receipt of a re-INVITE with T.38 only in the SDP, or T.38 and audio media in the SDP. This feature is configured using the [T38FaxSessionImmediateStart] parameter. The No-Op packet feature is enabled using the [NoOpEnable] and [NoOpInterval] parameters.

### Implementing ICE for Media Sessions

The device supports Interactive Connectivity Establishment (ICE) for SBC calls. ICE is a methodology for NAT traversal, enabling VoIP interoperability across networks to work better across NATs and firewalls. It employs Session Traversal Utilities for NAT (STUN) and Traversal Using Relays around NAT (TURN) protocols to provide a peer with a public IP address and port that can be used to connect to a remote peer. Therefore, for some applications such as when the device operates in Microsoft Teams Direct Routing (media bypass) environments, ICE is required.






ICE is applicable only to the SBC application.

For clients behind NATs and/or firewalls to send media (RTP) between one another, they need to discover each others IP address and port as seen by the "outside" world. If both peers are in different private networks behind a NAT, the peers must coordinate to determine the best communication path between them.

ICE first tries to make a connection using the client's private local address. If that fails (which it will for clients behind NAT), ICE obtains an external (public) address using a STUN server. If that fails, traffic is routed through a TURN relay server (which has a public address).

These addresses:ports (local, STUN, TURN and any other network address) of the client are termed "candidates". Each client sends its' candidates to the other in the SDP body of the SIP message (e.g., INVITE). Peers then perform connectivity checks per candidate of the other peer, using STUN binding requests sent on the RTP and RTCP ports. ICE tries each candidate and selects the one that works (i.e., media can flow between the clients).


The following figure provides a simple illustration of ICE:



The device supports ICE-Lite and ICE-Full (or ICE Full):


- **ICE-Lite:** When configured for ICE-Lite, the device doesn't initiate the ICE process. Instead, it supports remote endpoints that initiate ICE to discover their workable public IP address with the device. Therefore, the device supports the receipt of STUN binding requests for connectivity checks of ICE candidates and responds with STUN responses. Note that in the response to the INVITE message received from the remote endpoint, the device sends only a single candidate for its' IP address. This is the IP address of the device that the client uses.

The following figure shows an example of using ICE-Lite when the device communicates with a WebRTC client:



- **ICE-Full:** When configured for ICE-Full, the device can play the role as ICE controlled or ICE controlling. The device initiates STUN negotiation for all candidate pairs. The device sends the candidates with its local IP address, and a public IP address if configured in the NAT Translation table (see [Configuring NAT per IP Interface](#) on page 179). The device sends keep-alive messages to keep NAT bindings open for media sessions using ICE-Full.

The following figure shows an example of using ICE-Full, whereby the SBC device sends two candidates, one with its local IP address and one with its public IP address, according to its NAT Translation table.



To support ICE, the device's leg interfacing with the ICE-enabled client (SIP entity) must be enabled for ICE. This is done by using the IP Profile parameter 'ICE Mode' (see [Configuring IP Profiles](#) on page 664), which can be configured to **Lite** or **Full**.

## Media Latching for Robust Receipt of Media Streams

The device's Robust Media feature (or media latching) filters out unwanted media (RTP, RTCP, SRTP, SRTCP, and T.38) streams that are sent to the same port number of the device. Media ports may receive additional multiple unwanted media streams (from multiple sources of traffic) as result of traces of previous calls, call control errors, or deliberate malicious attacks (e.g., Denial of Service). When the device receives more than one media stream on the same port, the Robust Media mechanism detects the valid media stream and ignores the rest. Thus, this can prevent an established call been stolen by a malicious attacker on the media stream.

For the involved voice channel, the device latches on to the first stream of the first received packet. All packets (of any media type) received from the same IP address and SSRC are accepted (for T.38 packets, the device considers only the IP address). If the channel receives subsequent packets from a non-latched source, the device can either ignore this new stream and remain latched to the first original stream (IP address:port) or it can latch on to this new stream. The media latch mode is configured using the InboundMediaLatchMode parameter. If this mode is configured to latch on to new streams, you also need to configure the following:

- Minimum number of continuous media packets that need to be received from a different source(s) before the channel can latch onto this new incoming stream.
- Period (msec) during which if no packets are received from the current stream, the channel latches onto the next packet received from any other stream.

Depending on media latch mode, if the device has latched on to a new stream and a packet from the original (first latched onto) IP address:port is received at any time, the device latches on to this original stream.

Latching on to a new T.38 stream is reported in CDR using the CDR fields, LatchedT38Ip (new IP address) and LatchedT38Port (new port). In addition, the SIP PUBLISH message updates the latched RTP SSRC, for example:

RemoteAddr: IP=10.33.2.55 Port=4000 SSRC=0x66d510ec

### ➤ To configure media latching:

1. Open the Media Settings page (**Setup** menu > **Signaling & Media** tab > **Media** folder > **Media Settings**), and then from the 'Inbound Media Latch Mode' drop-down list (InboundMediaLatchMode), configure the media latch mode:

Inbound Media Latch Mode      Dynamic ▼

2. If you configure Step 1 to **Dynamic** or **Dynamic-Strict**:
  - Configure the minimum number of continuous media (RTP, RTCP, SRTP, and SRTCP) packets that need to be received by the channel before it can latch onto this new incoming stream:
    - ◆ 'New RTP Stream Packets'
    - ◆ 'New RTCP Stream Packets'

- ◆ 'New SRTP Stream Packets'
- ◆ 'New SRTCP Stream Packets'
- Configure a period (msec) after which if no packets are received from the current media session, the channel can re-latch onto another stream:
  - ◆ 'Timeout To Relatch RTP'
  - ◆ 'Timeout To Relatch SRTP'
  - ◆ 'Timeout To Relatch Silence'
  - ◆ 'Timeout To Relatch RTCP'
  - ◆ 'Fax Relay Rx/Tx Timeout'

#### ROBUSTNESS

New RTP Stream Packets	<input type="text" value="3"/>
New RTCP Stream Packets	<input type="text" value="3"/>
New SRTP Stream Packets	<input type="text" value="3"/>
New SRTCP Stream Packets	<input type="text" value="3"/>
Timeout To Relatch RTP (msec)	<input type="text" value="200"/>
Timeout To Relatch SRTP (msec)	<input type="text" value="200"/>
Timeout To Relatch Silence (msec)	<input type="text" value="10000"/>
Timeout To Relatch RTCP (msec)	<input type="text" value="10000"/>

3. Click **Apply**, and then save your settings to flash memory.

## Configuring Static ARP Table

The Static ARP table lets you configure up to 30 static Address Resolution Protocol (ARP) entries for mapping IP addresses to Media Access Control (MAC) addresses. Instead of dynamically mapping the Layer-3 address to a Layer-2 address, the device uses this table for mapping between these addresses.



- This table is for both IPv4 and IPv6 addresses. Neighbor Discovery Protocol (NDP) is the IPv6 equivalent of ARP.
- To view the device's cached and static ARP entries, use the CLI command `show network arp`. The command's output displays static ARP mappings as "permanent" and dynamic ARP mappings as "reachable".

The following procedure describes how to configure the ARP table through the Web interface. You can also configure it through ini file [StaticArp] or CLI (`configure network > static-arp-table`).

➤ **To configure static ARP table:**

1. Open the Static ARP table (**Setup** menu > **IP Network** tab > **Core Entities** folder > **Static ARP**).
2. Click **New**; the following dialog box appears:

The screenshot shows a configuration window titled "Static ARP Table". It has a "GENERAL" tab. The fields are as follows:

Field	Value
Index	0
Destination Address	0.0.0.0
MAC Address	
Ethernet Device	--

There is a "View" link next to the Ethernet Device dropdown.

3. Configure a static ARP entry according to the parameters described in the table below.
4. Click **Apply**.

**Table 13-8: Static ARP Table Parameter Descriptions**

Parameter	Description
'Index'	Defines an index number for the table row. <b>Note:</b> Each row must be configured with a unique index.
'Destination Address' dest-addr [DestAddress]	Defines the IP address of the destination host or network. By default, no value is defined. <b>Note:</b> <ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> <li>■ The IP address must be in the same subnet as the specified 'Ethernet Device' (below).</li> </ul>
'MAC Address' mac-addr [MacAddr]	Defines the MAC address that is mapped to the IP address specified in the 'Destination Address' parameter. The valid value is in hexadecimal bytes in the format nn:nn:nn:nn:nn:nn (e.g., 00:90:8f:12:13:df). By default, no value is defined. <b>Note:</b> The parameter is mandatory.
'Ethernet Device' eth-dev [EthDev]	Assigns an Ethernet Device from the Ethernet Devices table (see <a href="#">Configuring Underlying Ethernet Devices</a> on page 154), which is a VLAN associated with a specific IP interface in the IP Interfaces table. The ARP mapping rule is for packets that the device sends through this Ethernet Device to the specified destination address.

## Configuring Quality of Service

This section describes how to configure Layer-2 and Layer-3 Quality of Service (QoS).

### Configuring Class-of-Service QoS

The QoS Settings page lets you configure Layer-3 Class-of-Service Quality of Service (QoS). This configures Differentiated Services (DiffServ) values for each CoS. DiffServ is an architecture providing different types or levels of service for IP traffic. DiffServ (according to RFC 2474), prioritizes certain traffic types based on priority, accomplishing a higher-level QoS at the expense of other traffic types. By prioritizing packets, DiffServ routers can minimize transmission delays for time-sensitive packets such as VoIP packets.

You can assign DiffServ to the following class of services (CoS):

- Media Premium: RTP packets sent to the LAN
- Control Premium: Control protocol (SIP) packets sent to the LAN
- Gold: HTTP streaming packets sent to the LAN
- Bronze: OAMP packets sent to the LAN

The mapping of an application to its CoS and traffic type is shown in the table below:

**Table 13-9: Traffic/Network Types and Priority**

Application	Traffic / Network Types	Class-of-Service (Priority)
Debugging interface	Management	Bronze
Telnet	Management	Bronze
Web server (HTTP)	Management	Bronze
SNMP GET/SET	Management	Bronze
Web server (HTTPS)	Management	Bronze
RTP traffic	Media	Media Premium
RTCP traffic	Media	Media Premium
T.38 traffic	Media	Media Premium
SIP	Control	Control Premium
SIP over TLS (SIPS)	Control	Control Premium
Syslog	Management	Bronze

Application	Traffic / Network Types	Class-of-Service (Priority)
SNMP Traps	Management	Bronze
DNS client	Varies according to DNS settings: <div> <div></div> OAMP <div></div> Control </div>	Depends on traffic type: <div> <div></div> Control: Control Premium <div></div> Management: Bronze </div>
NTP	Varies according to the interface type associated with NTP (see Assigning NTP Services to Application Types): <div> <div></div> OAMP <div></div> Control </div>	Depends on traffic type: <div> <div></div> Control: Control Premium <div></div> Management: Bronze </div>

➤ **To configure DiffServ (Layer-3 QoS) values per CoS:**

1. Open the QoS Settings page (**Setup** menu > **IP Network** tab > **Quality** folder > **QoS Settings**).
2. Click **New**; the following dialog box appears:

GENERAL	
Media Premium QoS	<input type="text" value="46"/>
Control Premium QoS	<input type="text" value="40"/>
Gold QoS	<input type="text" value="26"/>
Bronze QoS	<input type="text" value="10"/>

3. Configure DiffServ values per CoS according to the parameters described in the table below.
4. Click **Apply**, and then save your settings to flash memory.

**Table 13-10:QoS Settings Parameter Descriptions**

Parameter	Description
'Media Premium QoS' media-qos	Defines the DiffServ value for Premium Media CoS content.

Parameter	Description
[PremiumServiceClassMediaDiffServ]	The valid range is 0 to 63. The default is 46. <b>Note:</b> You can also configure the parameter per IP Profile ('RTP IP DiffServ' parameter) or Tel Profile ('RTP IP DiffServ' parameter).
'Control Premium QoS' control-qos [PremiumServiceClassControlDiffServ]	Defines the DiffServ value for Premium Control CoS content (Call Control applications). The valid range is 0 to 63. The default is 24. <b>Note:</b> You can also configure the parameter per IP Profile ('Signaling DiffServ' parameter) or Tel Profile ('Signaling DiffServ' parameter).
'Gold QoS' gold-qos [GoldServiceClassDiffServ]	Defines the DiffServ value for Gold CoS content (streaming applications). The valid range is 0 to 63. The default is 26.
'Bronze QoS' bronze-qos [BronzeServiceClassDiffServ]	Defines the DiffServ value for Bronze CoS content (OAMP applications). The valid range is 0 to 63. The default is 10.

## Configuring DiffServ-to-VLAN Priority Mapping

The QoS Mapping table lets you configure up to 64 DiffServ-to-VLAN priority mapping for Layer 3 and Layer-2 Quality of Service (QoS). For each packet sent to the LAN, the VLAN Priority of the packet is set according to the DiffServ value in the IP header of the packet. Layer-2 802.1Q frames have a 2-byte field called Tag Control Information. The three most significant bits of this 2-byte field represents the Class of Service (CoS) value. Layer-2 QoS is represented by this CoS value which is from 0 to 7 (thus 8 values). Layer-2 QoS parameters define the values for the 3 priority bits in the VLAN tag according to the value of the DiffServ field in the packet IP header (according to the IEEE 802.1p standard). Differentiated Services (DiffServ) is an architecture providing different types or levels of service for IP traffic. DiffServ (according to RFC 2474), prioritizes certain traffic types based on priority, accomplishing a higher-level QoS at the expense of other traffic types. By prioritizing packets, DiffServ routers can minimize transmission delays for time-sensitive packets such as VoIP packets.

The following procedure describes how to configure DiffServ-to-VLAN priority mapping through the Web interface. You can also configure it through ini file [DiffServToVlanPriority] or CLI (configure network > qos vlan-mapping).

### ➤ To configure DiffServ-to-VLAN priority mapping:

1. Open the QoS Mapping table (Setup menu > IP Network tab > Quality folder > QoS Mapping).



- Click **New**; the following dialog box appears:

The screenshot shows a 'QoS Mapping' dialog box. It has a title bar with the text 'QoS Mapping' and standard window controls (minimize, maximize, close). The main area contains a tab labeled 'GENERAL'. Below the tab, there are three input fields: 'Index' with the value '1', 'Differentiated Services' with the value '0', and 'VLAN Priority' with the value '0'.

- Configure a DiffServ-to-VLAN priority mapping rule according to the parameters described in the table below.
- Click **Apply**, and then save your settings to flash memory.

**Table 13-11:QoS Mapping Table Parameter Descriptions**

Parameter	Description
'Index'	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Differentiated Services' diff-serv [DiffServToVlanPriority_DiffServ]	Defines a DiffServ value. The valid value is 0 to 63. The default is 0.
'VLAN Priority' vlan-priority [DiffServToVlanPriority_VlanPriority]	Defines the VLAN priority level. The valid value is 0 to 7. The default is 0.

## Configuring ICMP Message Handling

Internet Control Message Protocol (ICMP) is one of the core protocols of the Internet Protocol suite. It's used by network devices such as routers to send error messages indicating, for example, that a requested service is unavailable.

You can configure the device to handle ICMP messages as follows:

- Send and receive ICMP Redirect messages.
- Send ICMP Destination Unreachable messages. The device sends this message in response to a packet that cannot be delivered to its destination for reasons other than congestion. The device sends these messages upon any of the following:
  - Address unreachable

- Port unreachable

This feature is applicable to IPv4 and IPv6 addressing schemes.

➤ **To configure ICMP message handling:**

1. Open the Network Settings page (**Setup** menu > **IP Network** tab > **Advanced** folder > **Network Settings**).
2. Under the ICMP group, do the following:
  - To enable sending and receipt of ICMP Redirect messages, configure the 'Send and Received ICMP Redirect Messages' [DisableICMPRedirects] parameter to **Yes**.
  - To enable sending of ICMP Destination Unreachable messages, configure the 'Don't Send ICMP Unreachable Messages' [DisableICMPUnreachable] parameter to **No**.

ICMP	
Send and Receive ICMP Redirect Messages	• Yes ▼
Don't Send ICMP Unreachable Messages	No ▼

3. Click **Apply**.

## DNS

If you are using fully qualified domain names (FQDN) instead of IP addresses for some of your device configuration, the domain names need to be resolved into IP addresses by Domain Name System servers. The device provides various ways to do this:

- External, third-party DNS servers:
  - DNS servers configured in the IP Interfaces table for the associated IP network interface (see [Configuring IP Network Interfaces](#) on page 157)
  - Default DNS servers (see [Configuring Default DNS Servers](#) on the next page)
- Device's embedded DNS (and SRV) server:
  - Internal DNS table (see [Configuring the Internal DNS Table](#) on page 197)
  - Internal SRV table ([Configuring the Internal SRV Table](#) on page 199)

## Default DNS Fallback Sequence

The device has a default DNS fallback sequence which is used if you don't configure customized DNS fallback policies in the DNS Fallback Policy table (see [Configuring DNS Fallback Policy](#) on page 201).

The device's default DNS fallback sequence for choosing which DNS server to query for DNS resolution depends on traffic type (IPv4 or IPv6) and is as follows:

■ **IPv4 traffic:**

- a. (Call Routing Only) The device checks the Internal DNS table or Internal SRV table for a matching FQDN and queries the corresponding DNS server (see [Configuring the Internal DNS Table](#) on page 197). If no matching FQDN is found, the device proceeds to the next DNS fallback priority (below).
- b. The device queries the DNS server of the associated IP Interface configured in the IP Interfaces table (see [Configuring IP Network Interfaces](#) on page 157).
- c. If no DNS server is configured for the associated IP Interface (or DNS failure occurs), the device queries the DNS server of the default IPv4 OAMP ("O+M+C") IP Interface.
- d. If no DNS server is configured for the default OAMP IP Interface (or DNS failure occurs), the device queries the default IPv4 DNS servers (see [Configuring Default DNS Servers](#) below).

■ **IPv6 traffic:**

- a. The device queries the DNS server of the associated IP Interface configured in the IP Interfaces table (see [Configuring IP Network Interfaces](#) on page 157).
- b. If no DNS server is configured for the associated IP Interface (or DNS failure occurs), the device queries the DNS server of the default IPv6 OAMP ("O+M+C\_6") IP Interface.
- c. If no DNS server is configured for the default IPv6 OAMP IP Interface (or DNS failure occurs), the device queries the DNS server of the default IPv4 OAMP ("O+M+C") IP Interface.
- d. If no DNS server is configured for the default IPv4 OAMP IP Interface, the device queries the default IPv6 DNS servers (see [Configuring Default DNS Servers](#) below).
- e. If there are no default IPv6 DNS servers, the device queries the default IPv4 DNS servers (see [Configuring Default DNS Servers](#) below).



The device uses the default DNS servers only for specific applications, for example, SBC Configuration Wizard, CLI `ping` command, and Automatic Update. The device doesn't use the default DNS servers for call routing.

## Configuring Default DNS Servers

The device provides default DNS server addresses for IPv4 and IPv6 networks. Each IP address scheme (IPv4 and IPv6) has a primary and a secondary default DNS server. The default DNS servers ensure that applications (for example, Automatic Update feature or pinging a destination) which may need DNS lookups, run seamlessly if you haven't configured any DNS servers in the Internal DNS table and IP Interfaces table. In other words, the device uses the default DNS server as the last resort. For more information on when the device uses these

default DNS servers for its default DNS fallback sequence, see [Default DNS Fallback Sequence](#) on page 194.

The default IP addresses, which you can modify as described later in this section, of these default DNS servers are listed in the following table:

IP Addressing Scheme	Default Primary DNS Server	Default Secondary DNS Server
IPv4	8.8.8.8	8.8.4.4
IPv6	2001:4860:4860::8888	2001:4860:4860::8844



The device uses the default DNS servers only for specific applications, for example, SBC Configuration Wizard, CLI `ping` command, and Automatic Update feature. The device doesn't use the default DNS servers for call routing.

You can modify the IP addresses of the default DNS servers, as described below.

➤ **To modify default DNS server addresses:**

1. Open the DNS Settings page (**Setup** menu > **IP Network** tab > **DNS** folder > **DNS Settings**).

Default Primary DNS Server IP	<input type="text" value="8.8.8.8"/>
Default Secondary DNS Server IP	<input type="text" value="8.8.4.4"/>
Default Primary DNS Server IPv6	<input type="text" value="2001:4860:4860::8888"/>
Default Secondary DNS Server IPv6	<input type="text" value="2001:4860:4860::8844"/>

2. **For IPv4 DNS servers:**

- a. In the 'Default Primary DNS Server IP' field, configure the IPv4 address of the default primary DNS server.
- b. In the 'Default Secondary DNS Server IP' field, configure the IPv4 address of the default secondary DNS server.

3. **For IPv6 DNS servers:**

- a. In the 'Default Primary DNS Server IPv6' field, configure the IPv6 address of the default primary DNS server.
- b. In the 'Default Secondary DNS Server IPv6' field, configure the IPv6 address of the default secondary DNS server.

4. Click **Apply**.

## Configuring the Internal DNS Table

The Internal DNS table, similar to a DNS resolution can translate up to 20 host (domain) names into IP addresses. This functionality can be used when a domain name (FQDN) is configured as an IP destination in a routing rule. For the Gateway application, this is typically used for alternative Tel-to-IP call routing. Up to three different IP addresses can be assigned to the same host name.

The device attempts to resolve a domain name into an IP address in the following order:

1. The device first checks the Internal DNS table for a matching domain name and if found, resolves the domain name into the corresponding IP address(es).
2. If no matching domain name exists in the Internal DNS table, the device performs a DNS query with an external third-party DNS server whose address is configured for the associated IP network interface in the IP Interfaces table (see [Configuring IP Network Interfaces](#) on page 157).
3. If the associated IP interface is not configured with a DNS server or DNS resolution fails, DNS fallback is according to a configured DNS Fallback Policy (see [Configuring DNS Fallback Policy](#) on page 201) or the device's default DNS fallback sequence (see [Default DNS Fallback Sequence](#) on page 194) if you haven't configured a DNS Fallback Policy.



The device uses the Internal DNS table only for call routing, for example:

- Call routing according to a SIP Request-URI that contains a hostname.
- Call routing by destination address that is configured as a hostname.
- Call routing by ENUM and the result of the ENUM query is a hostname.
- DNS resolution of proxy servers in a Proxy Set that are configured with an FQDN.
- Registering a user agent whose REGISTER message has a Contact header that is a hostname.

The following procedure describes how to configure the DNS table through the Web interface. You can also configure it through ini file [DNS2IP] or CLI (`configure network > dns dns-to-ip`).

### ➤ To configure the device's DNS table:

1. Open the Internal DNS table (**Setup** menu > **IP Network** tab > **DNS** folder > **Internal DNS**).
2. Click **New**; the following dialog box appears:

The screenshot shows a window titled "Internal DNS" with a "GENERAL" tab. The configuration fields are as follows:

Parameter	Value
Index	0
Domain Name	
First IP Address	0.0.0.0
Second IP Address	0.0.0.0
Third IP Address	0.0.0.0

3. Configure a DNS rule according to the parameters described in the table below.
4. Click **Apply**.

**Table 13-12: Internal DNS Table Parameter Description**

Parameter	Description
'Index'	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Domain Name' domain-name [Dns2Ip_ DomainName]	Defines the host name to be translated. The valid value is a string of up to 31 characters.
'First IP Address' first-ip- address [Dns2Ip_ FirstIpAddress]	Defines the first IP address (in dotted-decimal format notation) to which the host name is translated. The IP address can be configured as an IPv4 and/or IPv6 address.
'Second IP Address' second-ip- address [Dns2Ip_ SecondIpAddress]	Defines the second IP address (in dotted-decimal format notation) to which the host name is translated.
'Third IP Address' third-ip- address [Dns2Ip_	Defines the third IP address (in dotted-decimal format notation) to which the host name is translated.

Parameter	Description
ThirdIpAddress]	

## Configuring the Internal SRV Table

The Internal SRV table lets you configure up to 10 SRV rows. The table is used to resolve hostnames into DNS A-Records. You can assign three different A-Records per hostname, where each A-Record includes the hostname, priority, weight, and port.

The device attempts to resolve a domain name into an IP address in the following order:

1. The device first checks the Internal SRV table for a matching domain name and if found, resolves the domain name into the corresponding IP address(es).
2. If no matching domain name exists in the Internal SRV table, the device performs a DNS query with an external third-party DNS server whose address is configured for the associated IP network interface in the IP Interfaces table (see [Configuring IP Network Interfaces](#) on page 157).
3. If the associated IP interface is not configured with a DNS server or DNS resolution fails, DNS fallback is according to a configured DNS Fallback Policy (see [Configuring DNS Fallback Policy](#) on page 201), or the device's default DNS fallback sequence (see [Default DNS Fallback Sequence](#) on page 194) if you haven't configured a DNS Fallback Policy.

The following procedure describes how to configure the Internal SRV table through the Web interface. You can also configure it through ini file [SRV2IP] or CLI (`configure network > dns srv2ip`).

### ➤ To configure the device's SRV table:

1. Open the Internal SRV table (**Setup** menu > **IP Network** tab > **DNS** folder > **Internal SRV**).
2. Click **New**; the following dialog box appears:

**Internal SRV**

**GENERAL**

Index: 0

Domain Name:

Transport Type: UDP

**1ST ENTRY**

DNS Name 1:

Priority 1: 0

Weight 1: 0

Port 1: 0

**2ND ENTRY**

DNS Name 2:

Priority 2: 0

Weight 2: 0

Port 2: 0

**3RD ENTRY**

DNS Name 3:

Priority 3: 0

Weight 3: 0

Port 3: 0

3. Configure an SRV rule according to the parameters described in the table below.
4. Click **Apply**, and then save your settings to flash memory.

**Table 13-13: Internal SRV Table Parameter Descriptions**

Parameter	Description
<b>General</b>	
'Index'	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Domain Name' domain-name [Srv2Ip_ InternalDomain]	Defines the hostname to be translated. The valid value is a string of up to 31 characters. By default, no value is defined.
'Transport Type' transport-type [Srv2Ip_ TransportType]	Defines the transport type. <ul style="list-style-type: none"> <li>■ [0] <b>UDP</b> (default)</li> <li>■ [1] <b>TCP</b></li> <li>■ [2] <b>TLS</b></li> </ul>
<b>1st/2nd/3rd Entry</b>	
'DNS Name (1-3)' dns-name- 1   2   3 [Srv2Ip_Dns1/2/3]	Defines the first, second or third DNS A-Record to which the hostname is translated. By default, no value is defined.



Parameter	Description
'Priority (1-3)' priority-1 2 3 [Srv2Ip_Priority1/2/3]	Defines the priority of the target host. A lower value means that it is more preferred.  By default, no value is defined.
'Weight (1-3)' weight-1 2 3 [Srv2Ip_Weight1/2/3]	Defines a relative weight for records with the same priority.  By default, no value is defined.
'Port (1-3)' port-1 2 3 [Srv2Ip_Port1/2/3]	Defines the TCP or UDP port on which the service is to be found.  By default, no value is defined.

## Configuring DNS Fallback Policy

The DNS Fallback Policy table lets you configure up to two DNS fallback policies, each for a different traffic type - IPv4 and IPv6. The policy defines a DNS fallback sequence (priority), specifying which DNS server to use if a DNS server fails (unreachable). This table allows you to fully customize the DNS fallback sequence.

Each DNS Fallback policy allows you to prioritize (*rule*) the sequence ("chain") of DNS fallback between the following DNS servers:

- DNS server configured for the OAM IPv4 interface in the IP Interfaces table (see [Configuring IP Network Interfaces](#) on page 157).
- DNS server configured for the OAM IPv6 interface in the IP Interfaces table (see [Configuring IP Network Interfaces](#) on page 157).
- Device's Default IPv4 DNS servers, configured in [Configuring Default DNS Servers](#) on page 195.
- Device's Default IPv6 DNS servers, configured in [Configuring Default DNS Servers](#) on page 195.



- If you don't configure the DNS Fallback Policy table for a specific traffic type, the device's default DNS fallback sequence is applied, as described in [Default DNS Fallback Sequence](#) on page 194.
- Currently, the DNS fallback Policy can't be configured per IP Interface. It only uses the IPv4 and IPv6 OAM interfaces.
- If the device is restored to factory defaults, the DNS Fallback Policy table doesn't return to default, but maintains its current configuration.
-

The following procedure describes how to configure DNS fallback policies through the Web interface. You can also configure it through ini file [DnsFallbackPolicy] or CLI (`configure network > dns-fallback-policy`).

➤ **To configure a DNS fallback policy:**

1. Open the DNS Fallback Policy table (**Setup** menu > **IP Network** tab > **DNS** folder > **DNS Fallback Policy**).
2. Select either the IPv4 or IPv6 pre-configured row, depending on the traffic type for which you want to configure a DNS Fallback policy, and then click **Edit**; the following dialog box appears (e.g., for IPv4 traffic):

3. Configure a DNS Fallback policy according to the parameters described in the table below.
4. Click **Apply**.

**Table 13-14:DNS Fallback Policy Table Parameter Description**

Parameter	Description
'Index'	(Read-only) Index number of the table row. <b>Note:</b> The table supports only two rows (index 0 and 1), each with a different IP version—one for IPv4 and one for IPv6.
'Type' type [Type]	Defines the type of traffic (IP version) for which you want to apply the DNS Fallback policy.  <div> <div></div> [0] <b>IPv4</b> (Default) </div> <div> <div></div> [1] <b>IPv6</b> </div> <b>Note:</b> The table supports only two rows, each with a different IP version—one for IPv4 and one for IPv6.

Parameter	Description
'Rule1' rule1 [Rule1]	<p>Defines the first DNS fallback rule.</p> <ul style="list-style-type: none"> <li>■ [0] <b>None</b> (Default)</li> <li>■ [1] <b>OAM Interface IPv4</b></li> <li>■ [2] <b>OAM Interface IPv6</b></li> <li>■ [3] <b>Global DNS IPv4</b></li> <li>■ [4] <b>Global DNS IPv6</b></li> </ul> <p><b>Note:</b> The value <b>None</b> can appear in multiple rules, but the other values can only appear in one rule. For example, configuring both 'Rule1' and 'Rule2' to <b>Global DNS IPv4</b> is not allowed.</p>
'Rule2' rule2 [Rule2]	<p>Defines the second DNS fallback rule if rule 1 fails (or configured to <b>None</b>).</p> <ul style="list-style-type: none"> <li>■ [0] <b>None</b> (Default)</li> <li>■ [1] <b>OAM Interface IPv4</b></li> <li>■ [2] <b>OAM Interface IPv6</b></li> <li>■ [3] <b>Global DNS IPv4</b></li> <li>■ [4] <b>Global DNS IPv6</b></li> </ul> <p><b>Note:</b> The value <b>None</b> can appear in multiple rules, but the other values can only appear in one rule. For example, configuring both 'Rule1' and 'Rule2' to <b>Global DNS IPv4</b> is not allowed.</p>
'Rule3' rule3 [Rule3]	<p>Defines the third DNS fallback rule if rule 2 fails (or configured to <b>None</b>).</p> <ul style="list-style-type: none"> <li>■ [0] <b>None</b> (Default)</li> <li>■ [1] <b>OAM Interface IPv4</b></li> <li>■ [2] <b>OAM Interface IPv6</b></li> <li>■ [3] <b>Global DNS IPv4</b></li> <li>■ [4] <b>Global DNS IPv6</b></li> </ul> <p><b>Note:</b> The value <b>None</b> can appear in multiple rules, but the other values can only appear in one rule. For example, configuring both 'Rule1' and 'Rule2' to <b>Global DNS IPv4</b> is not allowed.</p>
'Rule4' rule4 [Rule4]	<p>Defines the fourth DNS fallback rule if rule 3 fails (or configured to <b>None</b>).</p> <ul style="list-style-type: none"> <li>■ [0] <b>None</b> (Default)</li> <li>■ [1] <b>OAM Interface IPv4</b></li> <li>■ [2] <b>OAM Interface IPv6</b></li> </ul>

Parameter	Description
	<ul style="list-style-type: none"><li>■ [3] <b>Global DNS IPv4</b></li><li>■ [4] <b>Global DNS IPv6</b></li></ul> <p><b>Note:</b> The value <b>None</b> can appear in multiple rules, but the other values can only appear in one rule. For example, configuring both 'Rule1' and 'Rule2' to <b>Global DNS IPv4</b> is not allowed.</p>

## IP Multicasting

The device supports IP Multicasting level 1, according to RFC 2236 (i.e., IGMP version 2) for RTP channels. The device is capable of transmitting and receiving multicast packets.

## 14 Security

This section describes the VoIP security-related configuration.

### Overview of GDPR

AudioCodes is committed to supporting the European Union's (EU) General Data Protection Regulation (GDPR), by protecting and respecting personal data processed by the device.

To help you comply with GDPR, the device provides a tool as well as parameters that delete or mask (hide) personally identifiable information (PII), as described in this section:

- [Masking PII from Syslog Files using PII Log Scrubber Tool](#) below
- [Masking PII in CDRs](#) on the next page
- [Masking Digits in Syslog Messages](#) on page 208
- [Deleting Locally Stored CDRs](#) on page 209

### Masking PII from Syslog Files using PII Log Scrubber Tool

You can use the AudioCodes PII Log Scrubber tool (Python script) to remove (mask) all personally identifiable information (PII) from syslog files created by the device. You can run the tool on any laptop, PC, or server that has Python 3 installed.

A summary of the PII that the tool scrubs (masks) is listed below. For a full list, refer to the *history.txt* file that is downloaded with the tool (see procedure below).

- IP addresses
- SIP URIs - hostnames, numbers, and display names
- urn:uuid
- Hostnames in Host header
- Usernames in Authentication header
- MAC addresses
- Registration logs - AOR, URI, user-part, XML elements `phoneNumber` / `extension` / `alias`
- tel: URIs
- Gateway logs - caller and callee numbers, collected digits, and dialed digits

The tool replaces IP addresses with "0.0.0.0", user parts with "USER", host parts with "HOST", authentication usernames with "USERNAME", numbers with "NUM", AORs with "VALUE", and MACs with "MAC". An example of a scrubbed syslog file is shown below with some of these masks (scrubbed data highlighted in yellow):

```
08:47:51.97 local3.notice [S=2850846] [SID=f124e3:49:83278] (N
1 0.0.0.0 1062346) ---- Outgoing SIP Message to 0.0.0.0:61694
```

```

from SIPInterface #0 (IPP) TLS TO(#0) SocketID
(2669) ---- [Time:09-05@08:47:51.214]
08:47:51.97 local3.notice [S=2850847] [SID=f124e3:49:83278]
1 0.0.0.0 SIP/2.0 200 OK
Via: SIP/2.0/TLS
0.0.0.0:61694;branch=z9hG4bK64e15480A617E7F9
From: NAME sip:NUM@HOST;tag=8CD3F3E0-11A66CD9
To: sip:NUM@HOST;tag=1c2029910788
Call-ID: a916eeaec1214e3192dfcb30976b34b9
CSeq: 304 REGISTER
Contact:
sip:NUM@HOST:61694;transport=tls;expires=60;
methods="INVITE,ACK,BYE,CANCEL,OPTIONS,INFO,MESSAG
E, SUBSCRIBE,NOTIFY,PRACK,UPDATE,REFER"
Expires: 60
Content-Length: 0
[Time:09-05@08:47:51.214]

```

➤ **To remove PII using PII Log Scrubber:**

1. Make sure that you have Python 3 installed on your computer. For instructions on installing Python, got to <https://www.python.org/downloads>.
2. Download the PII Log Scrubber tool from <https://tools.audiocodes.com/install>.
3. Locate the PII Log Scrubber tool in the same folder in which the syslog file that you want to mask is located, and then run the Python script from the command line:

```
<Directory and folder> python log_scrub.py <syslog filename> <new masked
syslog filename>
```

## Masking PII in CDRs

For GDPR compliance, you can configure the device to mask personally identifiable information (PII) in CDRs that are created by the device. This includes CDRs that the device displays in the Web interface and CLI, as well as CDRs that it sends to syslog, REST, RADIUS, Local Storage, or OVOC (depending on configuration).

Depending on configuration, the PII that the device masks includes telephone numbers, URI user parts, display names, IP addresses, hostnames, and URI host parts.



The device masks PII in all CDR fields, except the following (based on destination):

- **OVOC:** SrcIP, DestIP, SigSrcIP, SigDstIP, SigRmtIP, OldDestIP, and NewRemIP.
- **Non-OVOC:** SourceIP, DestIP, IngressCallSourceIP, EgressCallDestIP, EgressLocalRtpIP, EgressRemoteRtpIP, IngressLocalRtpIP, IngressRemoteRtpIP, RemoteRtpIP, LocalRtpIP, LatchedRtpIP, and LatchedT38IP.

➤ **To mask PII in CDRs:**

1. Open the SIP Definitions General Settings page (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **SIP Definitions General Settings**).
2. From the 'Mask PII in CDRs' drop-down list, select one of the following:
  - **Disable:** No PII masking is done in management interfaces (Web and CLI), syslog, REST, Local Storage, and RADIUS.
  - **Mark PII in Web or CLI:** The device masks (by a single asterisk \* symbol) private information (caller and callee) in the Web interface's SBC CDR History table (see [Viewing CDR History of SBC and Test Calls](#) on page 1363) and Gateway CDR History table (see [Viewing Gateway CDR History](#) on page 1361), and CLI (e.g., `show voip calls`). For example, the device masks the URI "name@domain.com" as "\*".
  - **Mask PII in Detailed Records:** The device masks (by multiple asterisks \*) private information in CDRs. This applies to all destinations to where the device sends these records (i.e., syslog, REST, Local Storage, and RADIUS), except ARM and OVOC. This option also affects PII in the Web interface's SBC CDR History table and Gateway CDR History table, and CLI (e.g., `show voip calls`). For URIs, only the user part is masked when this option is selected.

Mask PII in CDRs

• Mask PII in Web or CLI ▼



If you enable the 'Mask URI Host Part in CDRs' parameter (see below), the device also masks IP addresses, hostnames, and URI host parts.

3. If you configure the above parameter to **Mask PII in Detailed Records**, you can configure which characters in the masked element (e.g., phone number) to mask:
  - a. In the 'Number of Unmasked Characters in PII' field, enter the number of characters to show. The rest of the characters are masked. To mask all characters, configure the parameter to "0".
  - b. In the 'Location in PII of Unmasked Characters' field, define from where in the PII element to show (not mask):

- ◆ **Last Characters:** The device shows the number of characters specified by the 'Number of Unmasked Characters in PII' parameter (above) starting from the end of the PII element. For example, if the original number is 97216789 and the 'Number of Unmasked Characters in PII' parameter is configured to "4", the device masks the number as "\*\*\*\*6789".
- ◆ **First Characters:** The device shows the number of characters specified by the 'Number of Unmasked Characters in PII' parameter (above) starting from the beginning of the PII element. For example, if the original number is 97216789 and the 'Number of Unmasked Characters in PII' parameter is configured to "4", the device masks the number as "9721\*\*\*\*".

Number of Unmasked Characters in PII

4

Location in PII of Unmasked Characters

Last Characters



4. Select the 'Mask PII in CDRs for OVOC' check box to mask (with asterisks) phone numbers, URI user part, and display names that appear in CDRs that the device sends to OVOC:

Mask PII in CDRs for OVOC



If you enable the 'Mask URI Host Part in CDRs' parameter, the device also masks IP addresses and hostnames in CDRs sent to OVOC.

5. Select the 'Mask URI Host Part in CDRs' check box to mask (with asterisks) the host part of URIs (including IP addresses) in CDRs that the device sends to Web, CLI, syslog, REST, RADIUS, and Local Storage (depending on the 'Mask PII in CDRs' parameter - see Step 2), or to OVOC if the 'Mask PII in CDRs for OVOC' parameter is enabled (see Step 4):

Mask URI Host Part in CDRs



The parameter is applicable only if you enable the 'Mask PII in CDRs' or 'Mask PII in CDRs for OVOC' parameters for the targets (i.e., this is an additional modifier of PII masking for these targets).

6. Click **Apply**.

## Masking Digits in Syslog Messages

You can mask digits (typically, in-band DTMF) that are sent as events and detected by the device, including SIP messages (INFO and NOTIFY) in syslog and Debug Recording (message body) generated by the device.



➤ **To mask digits:**

1. Open the SIP Definitions General Settings page (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **SIP Definitions General Settings**).
2. Select the 'Mask Digits' check box:

Mask Digits ☒

3. Click **Apply**.

## Deleting Locally Stored CDRs

If you have enabled local storage of CDRs (see [Storing CDRs Locally on the Device](#) on page 1384), you can delete them from storage at any time through the device's CLI:

- To delete all stored CDR files:

```
# clear storage-history cdr-storage-history all
```

- To delete all unused stored CDR files:

```
# clear storage-history cdr-storage-history unused
```

## Concealing Configured Passwords

For security, the device offers you various methods to conceal configured passwords:

- Password obfuscation using an encryption key - see [Password Obfuscation in CLI Script and ini Files](#) below
- Obscured passwords in CLI - see [Enabling or Disabling Password Obscured for CLI](#) on page 214

## Password Obfuscation in CLI Script and ini Files

You can enhance security by obfuscating passwords in the downloaded ini and CLI Script files. Password encryption is achieved using the AES-256 algorithm with a 16-bit random CFB initialization vector (IV) cipher mode, using an encryption key. This method offers robust protection of sensitive data.

Obscured passwords are displayed in the following syntax:

- **ini File:**

Syntax: `$2$<obfuscated password>`

Example:

```
WSTunPassword = $2$8EGYm+FG+JJT/p8ZOytU64upIPMKcw==
```

#### ■ CLI Script File:

Syntax: *<obscured password>== encrypted*

Example:

```
password B55osyLT1t7+oorwkaNB3bxEX4BI8g== encrypted
```

To configure an encryption key for password obfuscation, see [Configuring Password Obfuscation](#) below. To disable password obfuscation (by clearing encryption key), see [Disabling Password Obfuscation](#) on page 213



- If you need to downgrade the device to an earlier version that doesn't support password obfuscation, you must **clear** the encryption key (see [Disabling Password Obfuscation](#) on page 213).
- The encryption key remains unaffected even when the device is restored to factory defaults.
- If you configure password obfuscation by encryption key as described in this section, the device automatically disables the CLI password obscured feature (see [Enabling or Disabling Password Obscured for CLI](#) on page 214).

### Configuring Password Obfuscation

For password obfuscation, you need to configure the encryption key. You can manually define the encryption key or you can trigger the device to automatically generate a key.

If you want to manually configure the key, it must be exactly **32** characters long and can contain a combination of the following characters:

- Lowercase and uppercase letters (a-z and A-Z)
- Numbers (0-9)
- Special characters: !, #, \$, %, &, (, ), \*, +, ,, -, ., /, <, =, >, ?, @, [, ], ^, \_ ` {, }, ~

#### ➤ To configure encryption key for password obfuscation:

##### ■ Web interface:

- a. Open the Security Settings page (**Setup** menu > **IP Network** tab > **Security** folder > **Security Settings**).
- b. Scroll down the page to the **Encryption Key** group:

**ENCRYPTION KEY**

Encryption Key	<input type="text"/>
Generate Encryption Key	<b>Generate Encryption Key</b>
Clear Encryption Key	<b>Clear Encryption Key</b>

- c. Configure the encryption key, using one of the following methods:


- ◆ **Manually:** In the 'Encryption Key' field, enter your encryption key.
- ◆ **Automatically Generated by Device:** Click the **Generate Encryption Key** button; a message is displayed at the bottom of the page indicating that the key was successfully generated and copied to your clipboard. In addition, the key is partially displayed in the 'Encryption Key' field, showing the first four characters followed by three asterisks (\*), for example, "F/sZ\*\*\*". For future use, you can paste the key from your clipboard to a safe location.

■ **CLI:**


- **Manually:** `configure network > security-settings > encryption-key assign <your key>`
- **Automatically Generated by Device:** `configure network > security-settings > encryption-key generate`

**■ Configuration Package File (manually):**

- a. Download the Configuration Package file as password-protected (see [Downloading or Uploading Configuration Package File](#) on page 1260).
- b. Unzip the downloaded file (you'll be prompted for the password).
- c. Open the unzipped file folder, and then create a file with the name "encryption.key" using any text editor (e.g., Notepad).
- d. Add an encryption key to the *encryption.key* file, and then save the file. The following shows an example of an unzipped Configuration Package file with a created encryption file:



- e. Compress all the files in the unzipped folder into a 7-Zip archive file:
  - i. Select all the files in the unzipped folder, right-click, and then from the drop-down menu, choose **7-Zip > Add to archive**; the Add to Archive dialog box appears.
  - ii. In the 'Enter password' and 'Reenter password' fields, enter the password that you used to encrypt the downloaded Configuration Package file, and then select the 'Encrypt file names' check box:



- iii. Click **OK**; the Configuration Package file is compressed into a 7-Zip archive file.
- f. Upload the zipped Configuration Package file to the device (you'll be prompted for the password used to encrypt it). For more information, see [Downloading or Uploading Configuration Package File](#) on page 1260.

### Disabling Password Obfuscation

If you want to disable password obfuscation, you need to delete (clear) the encryption key. You can do this using various methods.

#### ➤ To clear (disable) password obfuscation:

##### ■ Web interface:

- a. Open the Security Settings page (**Setup** menu > **IP Network** tab > **Security** folder > **Security Settings**).
- b. Scroll down the page to the **Encryption Key** group:

ENCRYPTION KEY	
Encryption Key	<input type="text"/>
Generate Encryption Key	<button>Generate Encryption Key</button>
Clear Encryption Key	<button>Clear Encryption Key</button>

- c. Click the **Clear Encryption Key** button.

■ **CLI:** `configure network > security-settings > encryption-key clear`

■ **Configuration Package File:**

- a. Download the encrypted Configuration Package file and unzip it (see [Downloading or Uploading Configuration Package File](#) on page 1260).
- b. Open the encryption.key file, delete the key, and then save the empty file.
- c. Compress all the files in the unzipped folder into a 7-Zip archive file, and then upload it to the device encrypted.

## Enabling or Disabling Password Obscured for CLI

You can enable the device to display passwords encrypted (obscured) instead of in plain text for the following CLI areas:

- Output of the `show running-config` CLI command.
- Downloaded CLI Script file.

When passwords are displayed in the obscured mode, the string "obscured" is displayed after the encrypted password, as shown in the following example:

```
password tIWWhYONjw== obscured
```

➤ **To enable or disable password obscured for CLI:**

```
(config-system)# cli-settings
(cli-settings)# password-obscurity on|off
```



- The password obscured feature is enabled by default.
- If you configure password obfuscation by encryption key (see [Password Obfuscation in CLI Script and ini Files](#) on page 209), the password obscured feature is automatically disabled.

## Default Password Obscured in Ini File

By default, the device displays passwords obscured (encrypted) instead of in plain text in the downloaded ini file. Passwords are displayed encoded in the ini file using the following format:

*\$1\$<obscured password>*

For example:

```
WSTunPassword = $1$tIWWhYONjw==
```



- When you upload an ini file to the device containing obscured passwords, the passwords are parsed and applied to the device.
- The View and Text modes in the INI Viewer & Editor utility display passwords in plain text in parenthesis, as shown in the following example:

```
WSTunPassword = $1$tIWWhYONjw== (123456)
```

## Approved FIPS 140-3 Operation Modes

This section describes the approved FIPS 140-3 operation modes.

### Security Rules

The following security guidelines must be adhered to in order to maintain the approved mode of operation:

- Telnet must be disabled.
- HTTPS must always be used instead of HTTP.
- A TLS session must be enabled for SIP.
- SNMPv3 keys must be entered in hexadecimal (password derivation must not be used).
- Keys must only be imported through a dedicated physical link or a secure tunnel.
- Configured passwords must contain at least eight characters.
- The configured RADIUS secret must contain at least eight characters.
- The module must be configured to restrict the number of failed authentication attempts to three per minute.
- MD5, HMAC MD5, and 3DES are not to be used, unless mandated by an Acceptable Key Establishment Protocol.
- TLS Context configuration:
  - Ciphers of Server/Client should be configured not to use specific ciphers, as follows:  
DEFAULT:!RC4:!aNULL:!eNULL:!AECDH:!ADH:!CAMELLIA:!ARIA128:!SEED:!kRSA:!3DES.
  - TLS1.3 Cipher of Server/Client should not use TLS\_HACHA20\_POLY1305\_SHA256.

- Key Exchange Groups should not use X25519 and X448 group.
  - DH Key size should be 2048.
  - PKEY file should not be encrypted with a passphrase.
  - PKEY file of PKCS12 format should not be used.
- Only the following algorithms are allowed:
- KexAlgorithms = "diffie-hellman-group-exchange-sha256:diffie-hellman-group14-sha1"
  - Ciphers = "aes128-ctr:aes128-cbc:aes256-ctr:aes256-cbc"
  - MAC = "hmac-sha1:hmac-sha2-256"

## User Roles

The Crypto Officer (CO) role as defined by FIPS is allowed for all types of configuration (including security settings). The equivalent user levels on the device are:

■ **Security Administrator**

- **Administrator** (Administrator user level requires an additional password to enter privileged commands and settings)



SNMPv3 access is also defined as CO access.

The User role, as defined by FIPS, can only view configuration. The equivalent user level on the device for User role is "Monitor" user level.

## FIPS Cryptographic Algorithms

This section lists the approved and non-approved algorithms for FIPS.

### Approved Algorithms

In FIPS mode, the cryptographic device supports the following approved algorithms:

- [Cryptographic Library](#)
- [Cryptographic Accelerator Module](#)
- [KDF](#)
- [Cryptographic Accelerator KDF](#)
- [Entropy Library](#)

### Non-Approved Applications in FIPS mode

User should not save information on external USB storage.



## Enabling FIPS Mode

This section provides step-by-step instructions on how to configure the device for FIPS 140 Approved mode.

### Prerequisites

Prior to configuring the device for FIPS, perform the steps described in this section.

### Obtaining PKI Files

Obtain from your organization's public key infrastructure (PKI) administrator three files per context:

- RSA private key file of 2048/3072/4096 bit, encoded in plaintext Base64 format or ECDSA private key files of 256/384/521 bit encoded in plaintext Base64 format. In this document, the name given to this file is `dev_pkey.pem`.
- X509 certificate file, encoded in plaintext Base64 format, containing the matching RSA/ECDSA public key. In this document, the name given to this file is `dev_cert.pem`.
- X509 certificate file, encoded in plaintext Base64 format, containing trusted chain(s) of certificates to be trusted by the device. In this document, the name given to this file is `root.pem`.

It is assumed that these certificates have been configured appropriately in the user's web browsers and that the environment has been secured.

### Initial Device Setup

If the device is in factory-default state, perform the following initial steps; otherwise, skip to [Change the Default Admin Password](#) below.

#### ➤ To perform initial device setup:

1. Connect to the device's management interface.
2. Change the device's default OAMP address (see [Configuring OAMP Interface](#) on page 13).

### Enabling HA Mode

If the target system needs to operate as a High Availability (HA) system, then complete configuration of the system as an HA system (see [Overview of High Availability Mode](#) on page 1176).

### Change the Default Admin Password

The default Administrator login username and password should be changed for security. The password should be at least 8 characters, containing at least two characters from each of the following four groups:

- Uppercase
- Lowercase
- Digits
- Special characters

For changing the password, see [Changing Login Password](#) on page 67.

By default, the module allows only three failed authentication attempts per minute, which ensures that the probability of multiple random authentication attempts being successful is less than 1/100,000.

### Upgrading Device Software to FIPS-Enabled Version

Before configuring the system to operate in FIPS mode, you need to upgrade it to a software version (.cmp file) that supports FIPS and includes the FIPS signature (2048-bit / SHA-256 digital signature).

If the current version doesn't include the FIPS signature, after moving to the FIPS mode, the device will fail to load and returns to the non-FIPS mode. The device performs authentication on the .cmp image file upon every restart. If authentication fails, the device performs zeroization and disables the FIPS mode.

### Initial FIPS Mode Settings

After configuring the OAMP IP address, the following changes must be done through the device's Web interface or CLI to comply with FIPS requirements.

### Setting Modes of Operations

The following table lists the relevant configuration parameters and the values permitted for FIPS mode.

**Table 14-1: Configuration Parameters and Values for FIPS Mode**

INI File Parameter	Permitted Value	Comment
[EnforcePasswordComplexity]	1	Enforces device validation that passwords are composed of at least two characters from each of the four groups (uppercase, lowercase, digits and special characters). This also means that passwords must be at least eight characters in size.
[HTTPSOnly]	1	Enforces only HTTPS connectivity with the device's management interface

INI File Parameter	Permitted Value	Comment
		(Web and REST API).
[TelnetServerEnable]	0	Enables SSH access to the device's CLI on port 22 (default). Telnet access must be blocked.
[HASecuredConnectivityMode]	1	When the device is configured to operate as an HA system (1+1), the Maintenance link must be configured to be secured.

➤ **To apply these parameter settings to the device:**

1. Create a text file (using any text-based tool such as Notepad) with the configuration settings, as shown below:

```
; Setting Password Complexity
EnforcePasswordComplexity = 1

; Secured WEB/REST access
HTTPSOnly = 1

; Allow only secured CLI access (SSH)
TelnetServerEnable = 0

; Set Maintenance Interface to be secured (for HA systems only)
HASecuredConnectivityMode = 1
```

2. Save the file as an .ini file (e.g., device.ini).
3. Upload the file to the device through the Web interface (see [Downloading or Uploading ini File](#) on page 1257).

Once the file is uploaded, the device restarts and is accessible only through HTTPS / SSH.

### Configuring NTP Server and UTC Offset

To ensure that certification is validated correctly, it is essential to configure an NTP server (see [Date and Time](#) on page 135).

### Enabling FIPS Mode

When you first enable the FIPS mode, the device automatically performs *zeroization*, which eventually causes a restart. Zeroization completely wipes out all sensitive content stored on the

device (but retains configuration):

- Security secrets (e.g., private keys for SSH and TLS)
- Debug and Core dump files

When operating in FIPS mode, the device removes all secret keys from generated syslog and debug recording messages. It also performs many internal security tests during runtime. As soon as any one of these tests fail, connection to the device is lost and the device automatically performs zeroization, disables FIPS mode, and then restarts.



- After the device performs zeroization, it automatically generates new secrets (private key) for the self-signed certificate. You can then use this certificate to connect to the device over HTTPS, if needed.
- If the device is operating in FIPS mode and you disable FIPS, the device automatically performs zeroization and then restarts.

➤ **To enable FIPS mode:**

■ **Web Interface:**

- a. Open the Security Settings page (**Setup** menu > **IP Network** tab > **Security** folder > **Security Setting**).
- b. Click the **Enable FIPS** button:



A message appears warning you that a device restart, and private key zeroization, debug file deletion will occur.

- c. Confirm to enable FIPS mode.

■ **CLI (privileged mode):**

```
# fips on
```

After enabling the FIPS mode, the device performs zeroization and then restarts. When the restart is completed, verify that FIPS mode is enabled:

■ **Web Interface:**

- a. Open the Security Settings page (**Setup** menu > **IP Network** tab > **Security** folder > **Security Setting**).
- b. The text next to the button that enables and disables FIPS (**Enable FIPS** or **Disable FIPS**) indicates the FIPS mode:

- ◆ 'FIPS Mode is Enabled'
- ◆ 'FIPS Mode is Disabled'

■ **CLI:**

```
show system security status
```

### Updating the TLS Contexts

Once FIPS is enabled, all previous TLS Contexts and keys are zeroized, and should be updated with the organization's files, as described previously in [Prerequisites](#) on page 217.

➤ **To update TLS Contexts:**

1. Open the TLS Contexts table (see [Configuring TLS Certificate Contexts](#) on page 224), select the TLS Context, and then click the **Change Certificate** link (located below the table).
2. Under the **Upload Certificate Files From Your Computer** group, click the **Load Device Certificate File** button, and then upload the file *dev\_cert.pem* as the device's server/client self-certificate.
3. Click the **Load Private Key File** button, and then upload the file *dev\_pkey.pem* as the device's private key.
4. Navigate back to the the TLS Contexts table, and then click the **Change Certificate** link (located below the table).
5. Click **Import** to upload the file *root.pem* as the trusted root certificate.
6. Click the **Restart** button to save configuration to flash memory.

### Ongoing FIPS Settings

This section describes ongoing FIPS settings.

### Configuring SIP Entities

Perform the following for each SIP Interface, Proxy Set, or IP Profile:

- **SIP Interfaces:** To enforce only SIP over TLS, configure only the TLS port and change all other SIP ports (UDP, TCP and SCTP) to 0.
- **Proxy Sets:** When adding a Proxy Address for a Proxy Set, select **TLS** for the required transport type.
- **IP Profiles:** When adding an IP Profile, configure the 'SBC Media Security Mode' parameter to **SRTP**.

## Adding Management Interfaces

If you add management interfaces (Web, Telnet, or SSH), configure them to use **only** HTTPS. For example, to add Web interfaces, see [Configuring Web Interfaces](#) on page 51.

## Adding HTTP Proxy Servers

When adding HTTP Proxy Servers (see [Configuring HTTP Proxy Servers](#) on page 463), do the following:

- Configure the 'HTTPS Listening Port' field only (i.e. leave the 'HTTP Listening Port' field empty).
- Configure the 'TLS Context' field to the required TLS Context.
- Configure the 'Verify Client Certificate' field to **Yes**.

## Secured Quality of Experience Reports

If you are using OVOC to monitor SIP messages (SIP Ladder or SIP call flow), open the Quality of Experience Settings table (see [Reporting QoE to OVOC](#) on page 514), and then for each entry, enforce secured transport to OVOC:

- Configure the 'Use TLS' field to **Enable**.
- Configure the 'TLS Context' field to the required TLS context.

## Adding RADIUS Servers

If you're configuring RADIUS servers (see [Configuring RADIUS Servers](#) on page 360), the shared secret size must contain at least 8 characters. However, at least 16 characters are recommended.

## Adding SNMP Users

If SNMP is not being used, you should disable it (see [Enabling or Disabling SNMP](#) on page 107).

If you're using SNMP, SNMPv3 must be enforced by adding at least one SNMPv3 user (see [Configuring SNMP Community Strings](#) on page 108). When adding SNMPv3 users, configure the following:

- Configure the 'Authentication Protocol' field to **SHA-1**.
- Configure the 'Privacy Protocol' field to **AES-128**.
- Configure the 'Authentication Key' and 'Privacy Key' fields with values containing at least two characters from each of the four groups (uppercase, lowercase, digits and special characters). In other words, a minimum of eight characters in size.

## Create Default Snapshot

After you have completed FIPS configuration, it is recommended to create at least one snapshot and set it as default (see Rescue Options using System Snapshots). If you don't create a snapshot, the default snapshot remains non-FIPS and if the system ever returns to the default non-FIPS snapshot, all TLS Contexts will be zeroized before.

## Replacing a Faulty Device in HA System

When replacing a faulty device in a High-Availability (HA) system, the new (second) device should first be configured in an isolated network to be the same as the first device. For step-by-step instructions, refer to the User's Manual (see [Step 2: Configure the Second Device](#) on page 1185).

Before connecting the Maintenance interface of the new (second) device to the network, make sure that the [HASecuredConnectivityMode] ini file parameter is enabled (i.e., set to 1) on both devices.

## FIPS-Related CLI Commands

The device's CLI commands for FIPS include the following:

**Table 14-2: FIPS-Related CLI Commands**

CLI Command	Description
<code>clear security-files</code>	<p>Performs zeroization, which does the following chronologically listed actions:</p> <ol style="list-style-type: none"> <li>1. Wipes all secrets.</li> <li>2. Wipes the core dump file.</li> <li>3. Wipes all snapshots.</li> <li>4. Restarts the device .</li> </ol> <p>Manually triggering zeroization can be useful, for example, when taking the device out of deployment for service (Return of Merchandise or RMA).</p>
<code>fips on</code>	<p>Enables the FIPS Mode, and does the following:</p> <ol style="list-style-type: none"> <li>1. Sets the FIPS mode to "enabled".</li> <li>2. Triggers zeroization.</li> </ol> <p>After the device restarts, it runs in FIPS mode until it is manually disabled or until a security-test fails (which also causes zeroization of the device).</p>
<code>fips off</code>	<p>Disables the FIPS Mode, and does the following:</p>

CLI Command	Description
	<ol style="list-style-type: none"> <li>1. Sets the FIPS mode to "disabled".</li> <li>2. Triggers zeroization.</li> </ol>
<code>show system security status</code>	Displays the FIPS mode status (enable or disable).



When running in FIPS mode, the device performs the following:

- All boot and runtime security tests (as required by FIPS).
- Prevents the display of any secrets in system logs and captures.
- Allows only algorithms approved by FIPS (see [Approved Algorithms](#) on page 216), with exceptions as described in [Non-Approved Applications in FIPS mode](#) on page 216.

## TLS Certificates

The TLS Contexts table lets you configure X.509 certificates which are used for secure management of the device, secure SIP transactions, and other security applications.



- The device is shipped with an active, default TLS setup (TLS Context ID 0, named "default"). Therefore, configure certificates only if required.
- Since X.509 certificates have an expiration date and time, you must configure the device to use Network Time Protocol (NTP) to obtain the current date and time from an NTP server. Without the correct date and time, client certificates cannot work. To configure NTP, see [Synchronizing Date and Time through SNTP](#) on page 137.
- Only **Base64 (PEM)** encoded X.509 certificates can be loaded to the device.
- Modifying TLS Contexts doesn't require a device restart and therefore is not service affecting.

## Configuring TLS Certificate Contexts

The TLS Contexts table lets you configure up to 12 TLS Contexts. A TLS Context defines Transport Layer Security (TLS) settings (e.g., TLS certificates). The TLS protocol provides confidentiality, integrity, and authenticity between two communicating applications over TCP/IP.

You can use TLS for the following:

- To secure device management communication, for example, HTTPS-based Web sessions, Telnet sessions and SSH sessions.
- To secure SIP signaling connections, referred to as SIP Secure (SIPS) or SIP over TLS.



- To secure various other network applications supported by the device, for example, communication with a remote LDAP server used for LDAP-based user management authentication and authorization.

The device is shipped with a default TLS Context (Index #0 and named "default"), which includes a self-generated random private key and a self-signed server certificate. The Common Name (CN or subject name) of the default certificate is "ACL\_nnnnnnn", where *nnnnnn* denotes the serial number of the device.



- The default TLS Context cannot be deleted.
- For secure management through the default management network interface (i.e., **OAMP** Application Type in the IP Interfaces table), the device uses the default TLS Context. However, for secure Web and REST access using the additional management interfaces configured in the Web Interfaces table (see [Configuring Web Interfaces](#) on page 51), you can use any TLS Context.
- If a TLS Context for an existing TLS connection is changed during the call by the user agent, the device ends the connection.
- For more information on secured management, see [Configuring Secured \(HTTPS\) Web and REST Access](#) on page 74.

You can configure each TLS Context with the following TLS settings:

- TLS version (TLS 1.0, TLS 1.1, TLS 1.2, and TLS 1.3).
- DTLS version (DTLS 1.0 and DTLS 1.2).
- TLS cipher suites for server and client roles (per OpenSSL syntax).
- Diffie-Hellman (DH) key size used by the device if it acts as a TLS server and DH is used for key exchange.
- Online Certificate Status Protocol (OCSP). Some Public-Key Infrastructures (PKI) can revoke a certificate after it has been issued. You can configure the device to check if a peer's certificate has been revoked, using OCSP. When OCSP is enabled, the device queries the OCSP server for revocation information whenever a peer certificate is received (TLS client mode, or TLS server mode with mutual authentication).



- The device doesn't query OCSP for its own certificate.
- Some PKIs do not support OCSP, but generate Certificate Revocation Lists (CRLs). For such scenarios, set up an OCSP server such as OCSPD.

- Private key - externally created and then uploaded to device.
- Different levels of security strength (key size) per TLS certificate.
- X.509 certificates - self-signed certificates or signed as a result of a certificate signing request (CSR).
- Trusted root certificate authority (CA) store (for validating certificates).



- When creating a TLS Context, you should create a certificate as described in [Creating Self-Signed Certificates for TLS Contexts](#) on page 240, and then check that the certificate is "Ok" as described in [Viewing Certificate Information](#) on page 236.
- For secure SIP messaging (SIP Secure or SIPS) using TLS, see [TLS for SIP Clients](#) on page 247 (two-way authentication) and [Configuring TLS for Secured SIP](#) on page 245.
- To map an SNI (hostname in 'server\_name' extension of "client hello" message) to a TLS Context, see [Configuring SNI-to-TLS Mapping](#) on page 244.
- To configure the device to periodically check the validation date of installed TLS server certificates of TLS Contexts, see [Configuring TLS Server Certificate Expiry Check](#) on page 243.

The following procedure describes how to configure a TLS Context through the Web interface. You can also configure it through ini file [TLSContexts] or CLI (`configure network > tls`).

➤ **To configure a TLS Context:**

1. Open the TLS Contexts table (**Setup** menu > **IP Network** tab > **Security** folder > **TLS Contexts**).
2. Click **New** to add a new TLS Context or **Edit** to modify the default TLS Context at Index 0; the following dialog box appears:

3. Configure the TLS Context according to the parameters described in the table below.
4. Click **Apply**.

**Table 14-3: TLS Contexts Parameter Descriptions**

Parameter	Description
<b>General</b>	
'Index' tls	Defines an index number for the new table row. <b>Note:</b>

Parameter	Description
[Index]	<ul style="list-style-type: none"> <li>Each row must be configured with a unique index.</li> <li>Index 0 ("default") is the default TLS Context.</li> </ul>
'Name' name [Name]	<p>Defines a descriptive name, which is used when associating the row in other tables.</p> <p>The valid value is a string of up to 31 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The parameter value cannot contain a forward slash (/).</li> <li>The default TLS Context (Index 0) is named "default".</li> </ul>
'TLS Version' tls-version [TLSVersion]	<p>Defines the supported TLS protocol version. Clients attempting to communicate with the device using a different TLS version are rejected.</p> <ul style="list-style-type: none"> <li>[0] <b>Any TLS1.x</b> = TLSv1.0, TLSv1.1, TLSv1.2, and TLSv1.3 are supported.</li> <li>[1] <b>TLSv1.0</b> = Only TLS 1.0.</li> <li>[2] <b>TLSv1.1</b> = Only TLS 1.1.</li> <li>[3] <b>TLSv1.0 and TLSv1.1</b> = Only TLS 1.0 and TLS 1.1.</li> <li>[4] <b>TLSv1.2</b> = Only TLS 1.2.</li> <li>[6] <b>TLSv1.1 and TLSv1.2</b> = Only TLS 1.1 and TLS 1.2.</li> <li>[7] <b>TLSv1.0 TLSv1.1 and TLSv1.2</b> = Only TLS 1.0, TLS 1.1, and TLS 1.2.</li> <li>[8] <b>TLSv1.3</b> = Only TLS 1.3.</li> <li>[12] <b>TLSv1.2 and TLSv1.3</b> = (Default) Only TLS 1.2 and TLS 1.3.</li> <li>[14] <b>TLSv1.1 TLSv1.2 and TLSv1.3</b> = Only TLS 1.1, TLS 1.2, and TLS 1.3.</li> <li>[15] <b>TLSv1.0 TLSv1.1 TLSv1.2 and TLSv1.3</b> = Only TLS 1.0, TLS 1.1, TLS 1.2, and TLS 1.3.</li> </ul>
'DTLS Version' [DTLSVersion]	<p>Defines the Datagram Transport Layer Security (DTLS) version, which is used to negotiate keys for WebRTC calls.</p> <ul style="list-style-type: none"> <li>[0] <b>DTLSv1.0 and DTLSv1.2</b> (default)</li> <li>[1] <b>DTLSv1.0</b></li> </ul>

Parameter	Description
	<p>■ [2] <b>DTLSv1.2</b></p> <p>For more information on WebRTC, see Configuring TLS Certificate Contexts.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
'Cipher Server' <code>ciphers-server</code> [ServerCipherString]	<p>Defines the supported cipher suite for the TLS server (in OpenSSL cipher list format) when the TLS version is 1.2 or earlier.</p> <p>For possible values and additional details, visit the <a href="#">OpenSSL website</a>. The default is "DEFAULT".</p> <p><b>Note:</b> The parameter is applicable only to TLS 1.2 and earlier.</p>
'Cipher Client' <code>ciphers-client</code> [ClientCipherString]	<p>Defines the supported cipher suite for TLS clients when the TLS version is 1.2 or earlier.</p> <p>For possible values and additional details, visit the <a href="#">OpenSSL website</a>. The default is "DEFAULT".</p> <p><b>Note:</b> The parameter is applicable only to TLS 1.2 and earlier.</p>
'Cipher Server TLS1.3' <code>ciphers-server-tls13</code> [ServerCipherTLS13String]	<p>Defines the supported cipher suite for the TLS 1.3 server (in OpenSSL cipher list format).</p> <p>For possible values and additional details, visit the <a href="#">OpenSSL website</a>. The default is "TLS_AES_256_GCM_SHA384:TLS_CHACHA20_POLY1305_SHA256:TLS_AES_128_GCM_SHA256".</p> <p><b>Note:</b> The parameter is applicable only to TLS 1.3.</p>
'Cipher Client TLS1.3' <code>ciphers-client-tls13</code> [ClientCipherTLS13String]	<p>Defines the supported cipher suite for TLS 1.3 clients.</p> <p>For possible values and additional details, visit the <a href="#">OpenSSL website</a>. The default is "TLS_AES_256_GCM_SHA384:TLS_CHACHA20_POLY1305_SHA256:TLS_AES_128_GCM_SHA256".</p> <p><b>Note:</b> The parameter is applicable only to TLS 1.3.</p>
'Key Exchange Groups' <code>key-exchange-groups</code> [KeyExchangeGroups]	<p>Defines the groups that are supported for key exchange, ordered from most preferred to least preferred.</p> <p>The valid value is any combination of the following strings:</p> <ul style="list-style-type: none"> <li>■ X25519</li> <li>■ P-256</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ P-384</li> <li>■ X448</li> </ul> <p>The default is "X25519:P-256:P-384:X448" (without quotation marks).</p> <p>When configuring the parameter with multiple values, separate each with a colon. In addition, the order of the values determines the group preference. For example, the value "P-384:P-256:X25519" (without quotation marks) gives preference to P-384. The TLS client uses the first configured value (e.g., P-384) as its group trial, while the TLS server uses the whole list to try and match the client's trial.</p> <p><b>Note:</b> The parameter is applicable to all TLS versions.</p>
'Strict Certificate Extension Validation' require-strict-cert [RequireStrictCert]	<p>Enables the validation of the extensions (keyUsage and extendedKeyUsage) of peer certificates. The validation ensures that the signing CA is authorized to sign certificates and that the end-entity certificate is authorized to negotiate a secure TLS connection.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul>
'DH Key Size' dh-key-size [DHKeySize]	<p>Defines the Diffie-Hellman (DH) key size (in bits). DH is an algorithm used mainly for exchanging cryptography keys used in symmetric encryption algorithms such as AES.</p> <ul style="list-style-type: none"> <li>■ [1024] <b>1024 - Not Recommended</b></li> <li>■ [2048] <b>2048</b> (default)</li> </ul> <p><b>Note:</b> 1024-bit key size is not recommended.</p>
'TLS Renegotiation' tls-renegotiation [TlsRenegotiation]	<p>Enables TLS renegotiations (handshakes) initiated by the client (peer) with the device.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = The device blocks client-initiated TLS renegotiations and allows only one TLS handshake process. This is useful, for example, for preventing Denial-of-Service (DoS) attacks on the device caused by multiple TLS renegotiations per second by an attacker.</li> <li>■ [1] <b>Enable</b> (default)</li> </ul>
OCSP	

Parameter	Description
'OCSP Server' ocsp-server [OcspEnable]	<p>Enables certificate checking using Online Certificate Status Protocol (OCSP).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul>
'OCSP Interface' ocsp-interface [OcspInterface]	<p>Assigns an IP Interface for communication with the OCSP server.</p> <p>By default, the OAMP interface is assigned (Index 0 "O+M+C").</p> <p>To configure IP Interfaces, see <a href="#">Configuring IP Network Interfaces</a> on page 157.</p> <p><b>Note:</b> The addresses of the IP Interface and the OCSP servers (see 'Primary OCSP Server' and 'Secondary OCSP Server' parameters below) must be of the same IP version (IPv4 or IPv6).</p>
'Primary OCSP Server' ocsp-server-primary [OcspServerPrimary]	<p>Defines the address (IPv4 or IPv6, or FQDN) of the primary OCSP server.</p> <p>The default is 0.0.0.0.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The address configured for the 'Primary OCSP Server' parameter and the optional 'Secondary OCSP Server' parameter must be of the same IP version (IPv4 or IPv6).</li> <li>■ An FQDN address is supported only by TLS Contexts that are used for SIP connections. If you configure the parameter with an FQDN and the TLS Context is used for non-SIP connections, the certificate is not checked by the OCSP server.</li> </ul>
'Secondary OCSP Server' ocsp-server-secondary [OcspServerSecondary]	<p>Defines the address (IPv4 or IPv6, or FQDN) of the secondary OCSP server (optional).</p> <p>The default is 0.0.0.0.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The address configured for the 'Primary OCSP Server' parameter and the 'Secondary OCSP Server' parameter must be of the same IP version (IPv4 or IPv6).</li> <li>■ An FQDN address is supported only by TLS Contexts that are used for SIP connections. If you configure the parameter with an FQDN and the TLS Context is used</li> </ul>

Parameter	Description
	for non-SIP connections, the certificate is not checked by the OCSP server.
'OCSP Port' ocsp-port [OcspServerPort]	Defines the OCSP server's TCP port number. The default port is 2560.
'OCSP Default Response' ocsp-default-response [OcspDefaultResponse]	Defines if the device allows or rejects peer certificates if it cannot connect to the OCSP server.  ■ [0] <b>Reject</b> (default) ■ [1] <b>Allow</b>

## Assigning CSR-based Certificates to TLS Contexts

You can request a digitally signed certificate from a Certification Authority (CA) for a TLS Context. This process is referred to as a certificate signing request (CSR) and is required if your organization employs a Public Key Infrastructure (PKI) system. The CSR contains information identifying the device such as a Distinguished Name (DN) or subject alternative names in the case of an X.509 certificate.

### ➤ To assign a CSR-based certificate to a TLS Context:

1. Open the TLS Contexts table (see [Configuring TLS Certificate Contexts](#) on page 224).
2. Select the required TLS Context, and then click the **Change Certificate** link located below the table; the Change Certificates page appears.
3. Under the **Certificate Signing Request/ Generate Self-Signed Certificate Request** group, fill in the following fields **according to your security provider's instructions**:

**CERTIFICATE SIGNING REQUEST / GENERATE SELF-SIGNED CERTIFICATE REQUEST**

Common Name [CN]	<input style="width: 90%;" type="text"/>	
Organizational Unit [OU]	<input style="width: 90%;" type="text"/>	
Company name [O]	<input style="width: 90%;" type="text"/>	
Locality or city name [L]	<input style="width: 90%;" type="text"/>	
State [ST]	<input style="width: 90%;" type="text"/>	
Country code [C]	<input style="width: 90%;" type="text"/>	
1st Subject Alternative Name [SAN]	EMAIL ▼	<input style="width: 80%;" type="text"/>
2nd Subject Alternative Name [SAN]	EMAIL ▼	<input style="width: 80%;" type="text"/>
3rd Subject Alternative Name [SAN]	EMAIL ▼	<input style="width: 80%;" type="text"/>
4th Subject Alternative Name [SAN]	EMAIL ▼	<input style="width: 80%;" type="text"/>
5th Subject Alternative Name [SAN]	EMAIL ▼	<input style="width: 80%;" type="text"/>
Subject Key Identifier	<input style="width: 90%;" type="text"/>	
Key Usage	<input style="width: 70%;" type="text"/>	Critical <input type="checkbox"/>
Extended Key Usage	<input style="width: 70%;" type="text"/>	Critical <input type="checkbox"/>
Signature Algorithm	SHA-256 ▼	
Authority Information Access	<input style="width: 90%;" type="text"/>	

- a. Distinguished Name (DN) fields (uniquely identifies the device):
  - ◆ In the 'Common Name [CN]' field, enter the common name. If you leave this field empty, the device generates the CSR with the default CN "CN=ACL\_<device's 6-digit serial number>".
  - ◆ In the 'Organizational Unit [OU]' field, enter the section of the organization.
  - ◆ In the 'Company name [O]' field, enter the legal name of your organization.
  - ◆ In the 'Locality or city name [L]' field, enter the city where your organization is located.
  - ◆ In the 'State [ST]' field, enter the state or province where your organization is located.
  - ◆ In the 'Country code [C]' field, enter the two-letter ISO abbreviation for your country.
- b. If you want to generate a CSR for SAN (with multiple subject alternate names), then from the 'Subject Alternative Name [SAN]' drop-down list, select the type of SAN (e-mail address, DNS hostname, URI, or IP address), and then enter the relevant value. You can configure multiple SAN names, using the 1st to 5th 'Subject Alternative Name [SAN]' fields.
- c. From the 'Subject Key Identifier' drop-down list, configure the subject key identifier (SKI) X.509 field:
  - ◆ User-defined hex value (max. 128 characters), without "0x, for example, "00D06F00D4D06746"



- ◆ **hash-SHA1** (sets SKI to 160 bits of SHA-1 digest on public key)
  - ◆ **hash-SHA1-60lsb** (sets SKI to 0100 followed by least significant 60 bits of SHA-1 digest on public key)
- d. From the 'Key Usage' drop-down list, select the key usage X.509 field values:
- ◆ **Digital Signature** (Certificate can be used to apply a digital signature)
  - ◆ **Non Repudiation** (Certificate can be used to sign data as above, but the certificate's public key may be used to provide non-repudiation services, preventing the signing entity from falsely denying some action)
  - ◆ **Key Encipherment** (Certificate may be used by the subject to encrypt a symmetric key which is then transferred to the target, decrypted, and subsequently used to encrypt and decrypt data sent between the two entities)
  - ◆ **Data Encipherment** (Certificate can be used by the subject to encrypt and decrypt actual application data)
  - ◆ **Key Agreement** (Certificate's subject can use a key agreement protocol such as Diffie-Hellman to establish a symmetric key with a target that may then be used to encrypt and decrypt data sent between the two entities)
  - ◆ **Key Certificate Sign** (Certificate's subject can use public key for verifying Digital Signature on Public Key certificates)
  - ◆ **Certificate Revocation List Sign** (Certificate's subject can use public key for verifying signatures on Certificate Revocation List lists, e.g., CRLs)
  - ◆ **Encipher Only** (Certificate's subject can use public key only for enciphering data while performing Key agreement)
  - ◆ **Decipher Only** (Certificate's subject can use public key only for deciphering data while performing Key agreement)

You can define the key as critical (mandatory), by selecting the 'Critical' check box.

- e. From the 'Extended Key Usage' drop-down list, select the extended key usage X.509 field values:
- ◆ **Server Authentication**
  - ◆ **Client Authentication**

You can define the key as critical (mandatory), by selecting the 'Critical' check box.

- f. From the 'Signature Algorithm' drop-down list, select the hash function algorithm (**SHA-256** or **SHA-512**) with which to sign the certificate.
- g. In the 'Authority Information Access - OCSP URI' field, configure the Authority Information Access (AIA) extension field with the URL of the server where the client can check the validity of the device's certificate during the TLS handshake. For example, the AIA extension can contain one of the following:


- ◆ CA Issuers URL to the issuing CA's certificate, allowing clients to download and validate the full certificate chain. This can be used if the client doesn't have the intermediate or root CA certificate in its trusted store.
  - ◆ OCSP Responder URL, allowing the client to verify if the certificate is still valid or has been revoked.
4. Click the **Create CSR** button; a textual certificate signing request is displayed below the button:

Create CSR

After creating the CSR, copy the text below (including the BEGIN/END lines) and send it to your Certification Authority for signing.

-----BEGIN CERTIFICATE REQUEST-----

```
MIICVjCCAT4CAQAwADCCASIwDQYJKoZIhvcNAQEBBQADggEPADCCAQoCggEBAKS6
ipGbZ9pe808La4mApWuo1ZPLKa6mGB5FcK3AU2c8JoLEAkymmpR5+OIy1uoe1u3
WxXSJMqx+n6LQKxpOc52Fxr5aHyzVJaRDzr100NpMKMZOP6mhuaJOLqhkubgie7
LDBD7wLOxDbQ4f0/Nf/zp/q11kuMYXZyJWoS2FvV6I5cYI3Hp20T0ZGXfb2K0E0j
1ngX3N1bzaSK3W6SYMUb7Bbqqn6QLng9Pc5du+vZ7uVP4XlWEg9go0bF6/M/2vhd
MqaIIcIvuq9nNV0AYso95s5gGJk91Zxh++ERC25M9x4i1b1JLfkv5Mr3wUugqEZs
R8PHfpLHP6X9WrtSynECAwEAAARMA8GCSqGSIb3DQEJDDjECMAAwDQYJKoZIhvcN
AQELBQADggEBADh1My2NxrFNFRfHNYZRGrreJw+e/sTACrLCRixGE0Je2rauES/k
fH4dUshsV+JrFwX2uVdAYpFk3WrybFRhw9h5ynMcF1bFkeRjmIvfVz1DxAV23kh/
RTppC/+6hpOQwGG1nreWkz1bg6m2yoJ13qL3+R/gvTIEvRUkIoV3KJKUOuAaTo20
5LYSw6F48CL30gPrPwLB5SezWdn6sLe9EvPHWAfft5M991s1aD2I2qq078uUqh9v0
WAQ1um+cE80Uto11bIAAcWnmSpj5W0DtVODpJWRJp2CirUoRkk3jy6o1WU1FXTIr
axBK1Y3oe9Ihb1LN4DcQ5WaeRuPbWgm+UNY=
-----END CERTIFICATE REQUEST-----
```

5. Click the  icon to copy the CSR text to your clipboard. The CSR text is copied from the "BEGIN CERTIFICATE REQUEST" line to the "END CERTIFICATE REQUEST" line.
6. Send the copied CSR text to your security provider (CA) to sign this request.
7. When the CA sends you a server certificate, save the certificate to a file (e.g., cert.txt). Make sure that the file is a plain-text file containing the "BEGIN CERTIFICATE" header.
8. Scroll down to the **Upload Certificates Files From Your Computer** group, and then select and upload the cert.txt file, by clicking **Load Device Certificate File**:

Send Device Certificate file from your computer to the device.  
The file must be in textual PEM format.

Load Device Certificate File

9. Wait for the certificate to successfully upload to the device.
10. Save configuration.
11. Verify that the private key is correct:
  - a. Open the TLS Contexts table, and then select the TLS Context.
  - b. Click the **Certificate Information** link located below the table.
  - c. Make sure that the 'Status' field displays "OK"; otherwise, consult with your security administrator:

**PRIVATE KEY**

Key size: 2048 bits

Status: OK



- The certificate replacement process can be repeated whenever necessary (e.g., when the new certificate expires).
- You can also upload the certificate through the device's Automatic Provisioning mechanism, using the [HTTPSCertFileName] parameter.

**TLS Context Parameters Relevancy per Application**

The following table shows the parameters of the TLS Context table that are used when establishing a TLS connection per SBC application.

Application	TLS Contexts Table Parameter								
	'TLS Version'	'Cipher Server'	'Cipher Client'	'Cipher Server TLS1.3'	'Cipher Client TLS1.3'	'Key Exchange Groups'	'Strict Certificate Extension Validation'	'DH key Size'	'TLS Renegotiation'
Web / REST Server	✓	✓	✓	✓	✓	✓	✓	✓	✓
Automatic Update	✓	-	✓	-	✓	-	-	-	-
CLI copy Commands	✓	-	✓	-	✓	-	-	-	-
Sending CDRs to Remote Server	✓	-	✓	-	✓	-	-	-	-
HTTPS Proxy	✓	✓	✓	✓	✓	✓	✓	✓	-

Application	TLS Contexts Table Parameter								
	'TLS Version'	'Cipher Server'	'Cipher Client'	'Cipher Server TLS1.3'	'Cipher Client TLS1.3'	'Key Exchange Groups'	'Strict Certificate Extension Validation'	'DH key Size'	'TLS Renegotiation'
Secure Communication with OVOC	✓	✓	✓	✓	✓	✓	✓	✓	✓
WebSocket Tunnel with OVOC	✓	-	✓	-	✓	✓	✓	-	-
Secured LDAP Client	✓	✓	✓	✓	✓	✓	✓	✓	✓
Secured SCTP	✓	✓	✓	✓	✓	✓	✓	✓	✓
TR-069	✓	✓	✓	✓	✓	✓	✓	✓	✓
ZeroConf Provisioning	✓	✓	✓	✓	✓	✓	✓	✓	✓

## Viewing Certificate Information

You can view information of TLS certificates installed on the device per TLS Context.

### ➤ To view certificate information:

1. Open the TLS Contexts table (see [Configuring TLS Certificate Contexts](#) on page 224).
2. Select a TLS Context, and then click the **Certificate Information** link located below the table; the Certificate Information page appears, showing certificate information, as shown in the following example (cropped for convenience):

CERTIFICATE	PRIVATE KEY
Certificate: Data: Version: 1 (0x0) Serial Number: 0 (0x0) Signature Algorithm: sha256WithRSAEncryption Issuer: CN=ACL_5967925 Validity Not Before: Aug 13 12:23:58 2020 GMT Not After : Aug 8 12:23:58 2040 GMT Subject: CN=ACL_5967925 Subject Public Key Info: Public Key Algorithm: rsaEncryption RSA Public-Key: (2048 bit) Modulus: 00:a4:ba:8a:91:9b:67:da:5e:f3:4f:0b:6b:89:80: a5:6b:a8:95:93:cb:29:ae:a6:18:1e:45:70:ad:c0: 53:67:3e:76:87:ca:02:4a:86:ca:6a:51:a7:a3:88:	Key size: 2048 bits Status: OK
	<b>CERTIFICATE (BASE64 ENCODING)</b>  -----BEGIN CERTIFICATE----- MIICoDCCAygCAQAwDQYJKoZIhvcNAQELBQAwFjEUMBIGA1UEAwwLQUNN MjUwHhcNMjAwODEzMTIyMzU4WncNNDAwODA4MTIyMzU4WjAwwMRQwl Q0xfNTk2NzkyNTCCASlwdQYJKoZIhvcNAQEBBQADggEPADCCAQoCggEBAI Z9pe808La4mApWuolZPLKa6mGB5FcK3AU2c8JoLEAkymypR5+Oly1uoe1 JMQx+n6LQKxpOc52fxHr5aHyzVJaRDzr1O0NpKMKZOP6mhuaJOLqhkgbie 7wLOxDbQ4fO/Nf/zp/ql1kuMYXZyJWoS2FvV6I5cYI3Hp20T0ZGXfb2K0E0JlNg 3N1bzaSK3W6SYMUb7Bbqqn6QLng9Pc5du+vZ7uVP4XIWEg9go0bF6/M/2v/ lclvuq9nNV0AYso95s5gGJk9IZxh++ERC25M9x4i1bJLfkv5Mr3wQugqEZsR8P

## Assigning Externally Created Private Keys to TLS Contexts

You can assign externally created private keys to TLS Contexts.

### ➤ To assign an externally created private key to a TLS Context:

1. Obtain a private key in either textual PEM (PKCS #7) or PFX (PKCS #12) format (typically provided by your security administrator). The file may be encrypted with a short pass-phrase.
2. Open the TLS Contexts table (see [Configuring TLS Certificate Contexts](#) on page 224).
3. Select the required TLS Context, and then click the **Change Certificate** link located below the table; the Change Certificates page appears.
4. Scroll down to the **Upload Certificate Files From Your Computer** group.
  - a. (Optional) In the 'Private key pass-phrase' field, enter the password (passphrase) of the encrypted private key file. If there is no passphrase, leave the field blank.

Private key pass-phrase (optional)



- The passphrase can contain up to 32 characters, but can't contain wide characters.
- The default passphrase is "audc".

- b. Select and upload the private key file (mentioned in Step 1), by clicking **Load Private Key File**:

Send **Private Key** file from your computer to the device.  
The file must be in either PEM or PFX (PKCS#12) format.

**Note:** Replacing the private key is not recommended but if it's done, it should be over a physically-secure network link.

Load Private Key File

- c. If your security administrator has provided you with a device certificate file, select and upload it by clicking **Load Device Certificate File**:

Send **Device Certificate** file from your computer to the device.  
The file must be in textual PEM format.

**Load Device Certificate File**



The loaded private key file must match the loaded device certificate file.

5. After the files have successfully loaded to the device, save the configuration.
6. Verify that the private key is correct:
  - a. Open the TLS Contexts table.
  - b. Select the required TLS Context index row, and then click the **Certificate Information** link located below the table.
  - c. Make sure that the 'Status' field displays "OK"; otherwise (i.e., displays "Does not match certificate"), contact your security administrator:

#### PRIVATE KEY

Key size: 2048 bits

Status: OK

## Generating Private Keys for TLS Contexts

You can configure the device to generate private keys for TLS Contexts. You can generate the private keys for certificate signing requests (CSR) or self-signed certificates. You can choose to generate the keys in different formats - RSA or Elliptic Curve Digital Signature Algorithm (ECDSA) encryption algorithm.

### ➤ To generate private keys for TLS Contexts:

1. Open the TLS Contexts table (see [Configuring TLS Certificate Contexts](#) on page 224).
2. Select the required TLS Context index row, and then click the **Change Certificates** link located below the table; the Change Certificates page appears.
3. Scroll down to the **Generate New Private Key** group:

**GENERATE NEW PRIVATE KEY**

Private Key Format

RSA

Private Key Size

2048

Important: generation of private key is a lengthy operation during which the device service may be affected.

**Generate Private Key**

4. From the 'Private Key Format' drop-down list, select the encryption algorithm for the private key:
  - **RSA**
  - **ECDSA**
5. From the 'Private Key Size' drop-down list, select the size of the private key (in bits):
  - **RSA:**
    - ◆ **2048** (default)
  - **ECDSA:**
    - ◆ **256**
    - ◆ **384**
    - ◆ **521**
6. Click **Generate Private Key**; the following confirmation message appears:

**Generate Private-Key** x

Warning: Generating a Private-Key will overwrite the currently installed private key. Are you sure you want to generate a new key?

No

**Yes**

7. Click **Yes** to confirm key generation; the device starts generating a new private key (may take a few minutes):

**Generate Private-Key**

Generating Private-Key..... this might take a while.



When the key is successfully generated, the following message appears (e.g., for 2048-bit key):

**Generate Private-Key**

A new 2048-bits Private-Key was generated for Context-ID: 0  
Please save the configuration.



8. Click **OK** to close the message box.
9. Continue with certificate configuration by creating a CSR or generating a new self-signed certificate.
10. On the toolbar, click the **Save** button to save your configuration to flash memory.

## Creating Self-Signed Certificates for TLS Contexts

You can assign a certificate that is digitally signed by the device itself to a TLS Context (i.e., self-signed certificate). In other words, the device acts as a CA. The Issuer (e.g., "Issuer: CN=ACL\_5967925") and Subject (e.g., " Subject: CN=ACL\_5967925") fields of the self-signed certificate have the same value.



- The device is shipped with a default TLS Context (Index 0 and named "default"), which includes a self-generated random private key and a self-signed server certificate. The Common Name (CN or subject name) of the default certificate is "ACL\_#####", where ##### denotes the serial number of the device.
- Creating a self-signed certificate is traffic affecting.

### ➤ To create and assign a self-signed certificate to a TLS Context:

1. Make sure that you have a unique DNS name for the device (e.g., dns\_name.corp.customer.com). The name is used to access the device and therefore, must be listed in the server certificate.
2. Open the TLS Contexts table (see [Configuring TLS Certificate Contexts](#) on page 224).
3. Select the required TLS Context index row, and then click the **Change Certificate** link located below the table; the Change Certificates page appears.
4. Under the **Certificate Signing Request / Generate Self-Signed Certificate Request** group, in the 'Common Name [CN]' field, enter the fully-qualified DNS name (FQDN) as the certificate subject. Alternatively (or in addition), if you want to generate a self-signed SAN certificate (with multiple subject alternate names), then from the 'Subject Alternative Name [SAN]' drop-down list, select the type of SAN (**EMAIL**, **DNS**, **URI**, or **IP**), and then enter the corresponding value. You can configure multiple SANs, using the 1st to 5th 'Subject Alternative Name [SAN]' fields.




For a description of additional (optional) parameters that you can configure such as 'Subject Key Identifier', 'Key Usage', and 'Extended Key Usage', see [Assigning CSR-based Certificates to TLS Contexts](#) on page 231. (The parameters under this group are applicable to both self-signed and CSR certificates.)

5. Click **Generate Self-Signed Certificate**; the following confirmation message appears:

**Generate Self-Signed Certificate** x

Warning: Generating a self-signed key will overwrite the currently installed certificate. Are you sure you want to generate a new self-signed certificate?

No **Yes**

 The self-signed certificate overwrites the currently installed certificate for the specific TLS Context.

*A new self-signed certificate was generated* x

TLS Context ID: 3  
Subject name:  
To complete the certificate replacement process, close this current browser session and then open a new session.

**Close**


7. Click **Close**, and then quit your current web browser session and open a new browser session with the device.
8. Save the configuration.

## Importing Certificates into Trusted Root CA Certificate Store

The device provides its own Trusted Root Certificate Authority (CA) Certificate store. This lets you manage certificate trust. Depending on certificate size, you can import up to approximately 150 certificates into the Trusted Root CA Certificate per TLS Context.

The Trusted Root CA Certificate store can also be used for certificate chains. A certificate chain is a sequence of certificates where each certificate in the chain is signed by the subsequent certificate. The last certificate in the list of certificates is the Root CA certificate, which is self-signed. The purpose of a certificate chain is to establish a chain of trust from a child certificate to the trusted root CA certificate. The CA vouches for the identity of the child certificate by signing it. A client certificate is considered trusted if one of the CA certificates up the certificate

chain is found in the server certificate directory. For the device to trust a whole chain of certificates per TLS Context, you need to import them into the device's Trusted Root CA Certificate, as described below.



You can also import multiple TLS root certificates in bulk from a single file. Each certificate in the file must be Base64 encoded (PEM). When copying-and-pasting the certificates into the file, each Base64 ASCII encoded certificate string must be enclosed between "**-----BEGIN CERTIFICATE-----**" and "**-----END CERTIFICATE-----**".



- You can import only Base64 (PEM) encoded X.509 certificates into the Trusted Root CA Certificate store.
- When importing certificates into the trusted root CA store through CLI, make sure you add a blank line containing a period (.) after the 'END CERTIFICATE' line, as shown in the following example:

```

M500(tls-5)*# trusted-root import
Enter data below. Type a period (.) on an empty line to finish.

-----BEGIN CERTIFICATE-----
MIID...5Njc5
MjU...DDAtB
Q0x...6ipGb
Z9f...3WxXS
JMQ...7LDBD
7wI...jlngX
3NI...dMqaI
IcI...sR8PH
fpI...pdNwI
tu4...nXUEm
5c9...8lEWD
N2I...vfZNN
+mI...Fol0b
gWv...TlgLq
FFKsqw==
-----END CERTIFICATE-----
.
  
```

➤ **To import certificates into Trusted Root CA Certificate store:**

1. Open the TLS Contexts table (see [Configuring TLS Certificate Contexts](#) on page 224).

2. Select the required TLS Context, and then click the **Trusted Root Certificates** link located below the table; the Trusted Certificates table appears.
3. Click the **Import** button, and then select the certificate file.
4. Click **OK**; the certificate is imported into the Trusted Root CA Certificate store:

⊕ TLS Context [#0] > Trusted Root Certificates

<b>View</b>		Page 1 of 14	View 1 - 10 of 138	<b>Import</b>	<b>Export</b>	<b>Remove</b>
INDEX	SUBJECT	ISSUER	EXPIRES			
0	AAA Certificate Services	AAA Certificate Services	12/31/2028			

In addition to the **Import** button, the Trusted Root CA Certificate store provides the following buttons:

- **Remove:** Deletes the selected certificate.
- **Export:** Downloads the selected certificate to your computer.

## Configuring TLS Server Certificate Expiry Check

You can configure the device to periodically check the validation date of installed TLS server certificates of TLS Contexts (configured in [Configuring TLS Certificate Contexts](#) on page 224). You can also configure the device to send an SNMP alarm (acCertificateExpiryAlarm) at a user-defined number of days before the installed TLS server certificate is to expire. The alarm indicates the TLS Context to which the certificate belongs.



- When a TLS certificate expires, services using the certificate may be discontinued (depending on the remote side's security configuration). Therefore, best practice is to replace (renew) the certificate as soon as possible with a valid certificate.
- This feature applies to all TLS Contexts.

### ➤ To configure TLS certificate expiry checks and notification:

1. Open the Security Settings page (**Setup** menu > **IP Network** tab > **Security** folder > **Security Settings**).
2. In the 'TLS Expiry Check Start' field, enter the number of days before the installed TLS server certificate is to expire when the device sends an SNMP trap event to notify of this.
3. In the 'TLS Expiry Check Period' field, enter the periodical interval (in days) for checking the TLS server certificate expiry date. By default, the device checks the certificate every 7 days.

## TLS GENERAL

TLS Expiry Check Start (days)

60

TLS Expiry Check Period (days)

7

4. Click **Apply**.

## Configuring SNI-to-TLS Mapping

The SNI-to-TLS Context Mapping table lets you configure up to 12 rules for mapping the 'server\_name' (Server Name Indication or SNI) received in the (extended) "client hello" message, to a specific TLS Context configured on the device (see [Configuring TLS Certificate Contexts](#) on page 224).

TLS doesn't provide a mechanism for a client to tell a server (i.e., the device) the name of the server it is contacting. It may be desirable for clients to provide this information to facilitate secure connections, for example, to servers that host multiple virtual servers at a single underlying IP network address. To provide any of the server names (hostnames or domain names), clients may include an extension of type called 'server\_name' in the (extended) "client hello" message during the TLS handshake. The SNI-to-TLS Context Mapping table lets you map this 'server\_name' to a specific TLS Context, configured in the TLS Contexts table. In this way, each hostname can have its own TLS certificate (TLS Context), which the device sends to the client in the "server hello" message.

When a match is found between the 'server\_name' extension in the "client hello" message and a row in the SNI-to-TLS Context Mapping table, the TLS connection is established using the TLS certificate (i.e., certificate and key) of the mapped TLS Context. However, the TLS connection continues using the configuration settings (e.g., TLS version, ciphers, and key exchange groups) of the TLS Context that was originally used to establish the connection. Any modification to the mapped TLS Context or the original TLS Context triggers an online update of the TLS connection according to the TLS Contexts modifications.



It's recommended to configure the mapped TLS Context and the TLS Context that is used to initially establish the connection with the **same parameter settings**, but **different certificates**.

The following procedure describes how to configure SNI-to-TLS Context mapping rules through the Web interface. You can also configure it through ini file [SNI2TLSMapping] or CLI (configure network > sni-to-tls-mapping).

➤ **To configure SNI-to-TLS Context mapping rules:**

1. Open the SNI-to-TLS Context Mapping table (**Setup** menu > **IP Network** tab > **Security** folder > **SNI-to-TLS Context**).
2. Click **New**; the following dialog box appears:

1. Configure an SNI-to-TLS Context mapping rule according to the parameters described in the table below.
2. Click **Apply**, and then save your settings to flash memory.

**Table 14-4: SNI-to-TLS Context Mapping Rules Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table record.
'Host Name' host-name [HostName]	Defines the 'server_name' in the "client hello" message. The valid value is a string of up to 255 characters (case-insensitive).
'TLS Context' tls-context [TLSContext]	Assigns a TLS Context, listed in the TLS Contexts table, to this rule. If the incoming "client hello" message includes a 'server_name' extension type whose value is the same as configured in the 'Host Name' parameter (above), then the device uses this TLS Context. By default, no TLS Context is assigned.

## Configuring TLS for Secured SIP

The device uses TLS over TCP to encrypt and optionally, authenticate SIP messages. This is referred to as SIP Secure (SIPS). SIPS uses the X.509 certificate exchange process. For configuring TLS (TLS Context), see [TLS Certificates](#) on page 224.

To use a TLS Context for SIPS, you need to assign it to a Proxy Set or SIP Interface (or both) that is associated with the IP Group for which you want to employ TLS. When the device establishes a TLS connection (handshake) with a SIP user agent (UA), the TLS Context is determined as follows:

■ **Incoming calls:**

- a. Proxy Set: If the incoming call is successfully classified to an IP Group based on Proxy Set (i.e., IP address of calling party) and the Proxy Set is configured for TLS ('Transport Type' parameter is set to **TLS**), the TLS Context assigned to the Proxy Set is used. To configure Proxy Sets, see [Configuring Proxy Sets](#) on page 622.
- b. SIP Interface: If the Proxy Set is either not configured for TLS (i.e., the 'Transport Type' parameter is set to **UDP**) or not assigned a TLS Context, and/or classification to a Proxy Set fails, the device uses the TLS Context assigned to the SIP Interface used for the call. To configure SIP Interfaces, see [Configuring SIP Interfaces](#) on page 561.
- c. Default TLS Context (Index #0): If the SIP Interface is not assigned a TLS Context or no SIP Interface is used for the call, the device uses the default TLS Context.

#### ■ Outgoing calls:

- a. Proxy Set: If the outgoing call is sent to an IP Group associated with a Proxy Set that is assigned a TLS Context and the Proxy Set is configured for TLS (i.e., 'Transport Type' parameter is set to **TLS**), the TLS Context is used. If the 'Transport Type' parameter is set to **UDP**, the device uses UDP to communicate with the proxy and no TLS Context is used.
- b. SIP Interface: If the Proxy Set is not assigned a TLS Context, the device uses the TLS Context assigned to the SIP Interface used for the call.
- c. Default TLS Context (Index #0): If the SIP Interface is not assigned a TLS Context or no SIP Interface is used for the call, the device uses the default TLS Context.



- When a TLS connection with the device is initiated by a SIP client, the device also responds using TLS, regardless of whether or not TLS was configured.
- The device regulates the number of new concurrent TLS connections that can be established per second. This protects the device from flooding (avalanches) of new TLS connections which may be caused from TLS-based malicious attacks or distributed denial-of-service (DDoS) attacks.
- To configure two-way (mutual) TLS authentication, see [TLS for SIP Clients](#) on the next page.

#### ➤ To configure SIPs:

1. Configure a TLS Context (see [Configuring TLS Certificate Contexts](#) on page 224).
2. Assign the TLS Context to a Proxy Set or SIP Interface (see [Configuring Proxy Sets](#) on page 622 and [Configuring SIP Interfaces](#) on page 561, respectively).
3. Configure the SIP Interface with a TLS port number.
4. Open the Security Settings page (**Setup** menu > **IP Network** tab > **Security** folder > **Security Settings**), and then configure the following SIPs parameters:
  - a. Select the 'TLS Mutual Authentication' check box [SIPSRequireClientCertificate]:

TLS Mutual Authentication



- b. Configure the other parameters as desired. For a description of the TLS parameters, see [TLS Parameters](#) on page 1669.
  - c. Click **Apply**.
- 5. By default, the device initiates a TLS connection only for the next network hop. To enable TLS all the way to the destination (**over multiple hops**):
  - a. Open the Transport Settings page (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **Transport Settings**).
  - b. Select the 'SIPS' check box [EnableSIPS]:

SIPS • ☒

- c. Click **Apply**.

## Configuring Mutual TLS Authentication

This section describes how to configure mutual (two-way) TLS authentication.

### TLS for SIP Clients

When Secure SIP (SIPS) is implemented using TLS, it is sometimes required to use two-way (mutual) authentication between the device and a SIP user agent (client). When the device acts as the TLS server in a specific connection, the device demands the authentication of the SIP client's certificate. Both the device and the client use certificates from a CA to authenticate each other, sending their X.509 certificates to one another during the TLS handshake. Once the sender is verified, the receiver sends its' certificate to the sender for verification. SIP signaling starts when authentication of both sides completes successfully.

TLS mutual authentication can be configured for all calls (globally), or for specific calls by enabling mutual authentication for the associated SIP Interface. The TLS Context associated with the SIP Interface or Proxy Set belonging to these calls are used.

#### ➤ To configure mutual TLS authentication for SIP messaging:

1. Enable two-way authentication:
  - **Globally (for all calls):**
    - i. Open the Security Settings page (**Setup** menu > **IP Network** tab > **Security** folder > **Security Settings**).
    - ii. Select the 'TLS Mutual Authentication' check box [SIPSRequireClientCertificate]:

TLS Mutual Authentication • ☒

- **For specific SIP Interface:**
  - i. Open the SIP Interfaces table (see [Configuring SIP Interfaces](#) on page 561).
  - ii. Configure the 'TLS Mutual Authentication' parameter to **Enable**.

## 2. Configure a TLS Context with the following certificates:

- Import the certificate of the CA that signed the certificate of the SIP client into the Trusted Certificates table (certificate root store) so that the device can authenticate the client (see [Importing Certificates into Trusted Root CA Certificate Store](#) on page 241).
- Make sure that the TLS certificate is signed by a CA that the SIP client trusts so that the client can authenticate the device.

## TLS for Remote Device Management

For a description of secured device management by mutual TLS authentication, see [Configuring Secured \(HTTPS\) Web and REST Access](#) on page 74.

## Reliable (TCP/TLS) Connections

For the maximum number of concurrent TLS connections supported by the device, refer to the [Release Notes](#).

Reliable connection reuse depends on the [EnableTCPConnectionReuse] parameter. For incoming connections, reuse also depends on SIP message characteristics (presence of Via header's 'alias' parameter in initial request) and the [FakeTCPAlias] parameter.

Persistent connections are determined by the [ReliableConnectionPersistentMode] parameter. However, if the destination is a Proxy server (configured in the Proxy Sets table), the connection is always persistent, regardless of the parameter's settings.

The device releases unnecessary persistent TLS connections to prevent them from accumulating and reaching the device's maximum number of supported TLS connections. If the number of incoming TLS connections exceeds 80% of the maximum, the device closes incoming TLS connections that aren't in use and that are kept open only because they are persistent. Similarly, the device releases reliable (TCP/TLS) connections that aren't in use (i.e., no active SIP dialogs and not associated with a registered user) and are kept open only because they are persistent, when exceeding 80% of the maximum number of supported reliable connections.

The device sends the SNMP alarm acTLSSocketsLimitAlarm (OID 1.3.6.1.4.1.5003.9.10.1.21.2.0.159) when the number of incoming TLS connections exceeds 95% of the maximum TLS connections supported by the device.

## Configuring Firewall Rules

The Firewall table lets you configure up to 50 firewall rules, which define network traffic filtering rules (*access list*) for incoming (ingress) traffic. The access list offers the following firewall possibilities:

- Blocking traffic from known malicious sources
- Allowing traffic only from known "friendly" sources, while blocking all other traffic
- Mixing allowed and blocked network sources



- Limiting traffic to a user-defined rate (blocking the excess)
- Limiting traffic to specific protocols and specific port ranges on the device

For each packet received on the IP network interface, the device searches the table from top to bottom until the first matching rule is found. The matched rule can permit (*allow*) or deny (*block*) the packet. Once a rule in the table is located, subsequent rules further down the table are ignored. If the end of the table is reached without a match, the packet is accepted.



- Only **Security Administrator** users can configure firewall rules.
- The rules configured by the Firewall table apply to a very low-level network layer and overrides all other security-related configuration. Thus, if you have configured higher-level security features (e.g., on the Application level), you must also configure firewall rules to permit this necessary traffic. For example, if you have configured IP addresses to access the device's Web and Telnet management interfaces in the Management Access List table (see [Configuring Management Access List](#) on page 87), you must configure a firewall rule that permits traffic from these IP addresses.
- The device supports dynamic firewall pinholes for media (RTP/RTCP) traffic negotiated in the SDP offer-answer of SIP calls. The pinhole allows the device to ignore its firewall and accept the traffic on the negotiated port. The device automatically closes the pinhole once the call terminates. Therefore, it is unnecessary to configure specific firewall rules to allow traffic through specific ports. For example, if you have configured a firewall rule to block all media traffic in the port range 6000 to 7000 and a call is negotiated to use the local port 6010, the device automatically opens port 6010 to allow the call.
- Setting the 'Prefix Length' field to **0** means that the rule applies to **all** packets, regardless of the defined IP address in the 'Source IP' field. Thus, it is highly recommended to set the parameter to a value other than 0.
- It is recommended to add a rule at the end of your table that blocks all traffic and to add firewall rules above it that allow required traffic (with bandwidth limitations). To block all traffic, use the following firewall rule:
  - ✓ Source IP: 0.0.0.0
  - ✓ Prefix Length: 0 (i.e., rule matches all IP addresses)
  - ✓ Start Port - End Port: 0-65535
  - ✓ Protocol: **Any**
  - ✓ Action Upon Match: **Block**
- The Firewall table supports up to 500 IP addresses (manually configured IP addresses or DNS-resolved IP addresses).
- If the device needs to communicate with AudioCodes OVOC, you must also add rules to allow incoming traffic from OVOC. For more information, see [Configuring Firewall Rules to Allow Incoming OVOC Traffic](#) on page 256.

The following procedure describes how to configure firewall rules through the Web interface. You can also configure it through ini file [AccessList] or CLI (`configure network > access-list`).

#### ➤ To configure a firewall rule:

1. Open the Firewall table (**Setup** menu > **IP Network** tab > **Security** folder> **Firewall**).

- On the table's toolbar, click **New** to add the row at the next available index number, or select a row before which you want to add the row and then click **Insert**; the following dialog box appears:

- Configure a firewall rule according to the parameters described in the table below.
- Click **Apply**, and then restart the device with a save-to-flash for your settings to take effect.

**Table 14-5: Firewall Table Parameter Descriptions**

Parameter	Description
<b>Match</b>	
'Index'	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Description' description [AccessList_Description]	Defines an arbitrary name to easily identify the row.
'Source IP' source-ip [AccessList_Source_IP]	Defines the IP address (or DNS name) or a specific host name of the source network from where the device receives the incoming packet. The default is 0.0.0.0.
'DNS Query Type' dns-query-type [AccessList_DnsQueryType]	Defines the DNS query (request) type used by the device to query the DNS server to resolve the domain name into an IP address(es). This is applicable only if you have configured the 'Source IP' parameter with an FQDN.  <div> <div></div> [1] <b>A</b> = (Default) The device performs an A-record DNS query, which is resolved into an IPv4 address(es). </div> <div> <div></div> [2] <b>AAAA</b> = The device performs an AAAA-record DNS query, which is resolved into an IPv6 address(es). </div> <div> <div></div> [3] <b>CNAME A</b> = The device performs a canonical name A-record query, which is resolved into an IPv4 address (es). A CNAME query is followed by an A-record </div>

Parameter	Description
	<p>address query and the resultant IP address is used.</p> <ul style="list-style-type: none"> <li>■ [4] <b>CNAME AAAA</b> = The device performs a canonical name query, which is resolved into an IPv6 address (es). A CNAME query is followed by an AAAA-record address query and the resultant IP address is used.</li> <li>■ [5] <b>SRV A</b> = The device performs an SRV A-record query, which is resolved into an IPv4 address(es). An SRV query is followed by an A-record address query and the resultant IP address is used. The firewall rule is active only if all the hostnames received from the SRV query were successfully resolved.</li> <li>■ [6] <b>SRV AAAA</b> = The device performs an SRV AAAA-record query, which is resolved into an IPv6 address (es). An SRV query is followed by an AAAA-record address query and the resultant IP address is used. The firewall rule is active only if all the hostnames received from the SRV query were successfully resolved.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For DNS resolutions, you also need to configure a DNS server: <ul style="list-style-type: none"> <li>✓ Third-party (external) DNS server: If you select an IP Interface for the firewall rule (see the 'Interface Name' parameter below), the device uses the DNS server configured for the IP Interface.</li> <li>✓ Device's integrated DNS server: You can configure domain name to IP address mapping in the device's Internal DNS table (see <a href="#">Configuring the Internal DNS Table</a> on page 197) and Internal SRV table (see <a href="#">Configuring the Internal SRV Table</a> on page 199).</li> </ul> </li> <li>■ The device performs DNS resolution periodically (i.e., resolved addresses are not persistent).</li> <li>■ You can do an nslookup to query the DNS server to obtain domain name or IP address mapping, using the CLI command <code>nslookup</code>.</li> </ul>
'Source Port' <code>src-port</code>	Defines the source UDP/TCP ports of the remote host from where the device receives the incoming packet.

Parameter	Description
[AccessList_Source_Port]	<p>The valid range is 0 to 65535. The default is 0.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ When set to 0, this field is ignored and any source port matches the rule.</li> <li>■ The source ports used for outgoing TCP and TLS connections are not configurable and are dynamically determined by the device in the range of 32,768-61,000.</li> </ul>
'Prefix Length' prefixLen [AccessList_PrefixLen]	<p>Defines the IP network mask (prefix length) of the IP address configured in the 'Source IP' parameter (above).</p> <ul style="list-style-type: none"> <li>■ IPv4: 0-32. For example: <ul style="list-style-type: none"> <li>✓ A value of 8 corresponds to IPv4 subnet class A (network mask of 255.0.0.0).</li> <li>✓ A value of 16 corresponds to IPv4 subnet class B (network mask of 255.255.0.0).</li> <li>✓ A value of 24 corresponds to IPv4 subnet class C (network mask of 255.255.255.0).</li> <li>✓ A value of 32 represents a single host (i.e., the specific IPv4 address configured in the 'Source IP' parameter).</li> </ul> </li> <li>■ IPv6: 0-128. For example: <ul style="list-style-type: none"> <li>✓ A value of 64 corresponds to subnet xxxx:xxxx:xxxx:xxxx::.</li> <li>✓ A value of 128 represents a single host (i.e., the specific IPv6 address configured in the 'Source IP' parameter).</li> </ul> </li> </ul> <p>The default is 32. A value of 0 means that the rule applies to all packets.</p> <p>The IP address of the sender of the incoming packet is trimmed in accordance with the prefix length (in bits) and then compared to the parameter 'Source IP'.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ A value of 0 applies to <b>all</b> packets, regardless of the configured IP address (in the 'Source IP' parameter). Therefore, you <b>must</b> configure the parameter to a value other than 0.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> </ul>
'Start Port' start-port [AccessList_Start_Port]	<p>Defines the first UDP/TCP port in the range of ports on the device on which the incoming packet is received. From the perspective of the remote IP entity, this is the destination port. To configure the last port in the range, see the 'End Port' parameter (below).</p> <p>The valid range is 0 to 65535. The default is 0.</p> <p><b>Note:</b> When the protocol type isn't TCP or UDP, the entire range must be provided.</p>
'End Port' end-port [AccessList_End_Port]	<p>Defines the last UDP/TCP port in the range of ports on the device on which the incoming packet is received. From the perspective of the remote IP entity, this is the destination port. To configure the first port in the range, see the 'Start Port' parameter (above).</p> <p>The valid range is 0 to 65535. The default is 65535.</p> <p><b>Note:</b> When the protocol type isn't TCP or UDP, the entire range must be provided.</p>
'Protocol' protocol [AccessList_Protocol]	<p>Defines the protocol type (e.g., <b>UDP</b>, <b>TCP</b>, <b>ICMP</b>, <b>ESP</b> or <b>Any</b>) or the IANA protocol number in the range of 0 (Any) to 255.</p> <p>The default is <b>Any</b>.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter also accepts the string value "HTTP", which implies selection of the TCP or UDP protocols and the appropriate port numbers as defined on the device.</li> <li>■ To specify SIP ports, configure rules with the UDP and TCP protocols for the required SIP Interfaces.</li> </ul>
'Use Specific Interface' use-specific-interface [AccessList_Use_Specific_Interface]	<p>Defines if you want to apply the rule to all IP interfaces or only a specific IP interface, configured in the IP Interfaces table (see <a href="#">Configuring IP Network Interfaces</a> on page 157). In other words, the rule applies to packets that are received from the configured IP address ('Source IP' parameter) and received on this IP interface(s).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = The rule applies to all IP Interfaces.</li> <li>■ [1] <b>Enable</b> = (Default) The rule applies to a specific IP Interface only, which you assign using the 'Interface</li> </ul>

Parameter	Description
	Name' parameter (below).
'Interface Name' network-interface-name [AccessList_Interface_x]	Assigns an IP Interface (see <a href="#">Configuring IP Network Interfaces</a> on page 157) to the rule. By default, no value is defined. <b>Note:</b> The parameter is applicable only if you configure the 'Use Specific Interface' parameter (above) to <b>Enable</b> .
Action	
'Action Upon Match' allow-type [AccessList_Allow_Type]	Defines the firewall action if the rule is matched. <ul style="list-style-type: none"> <li>■ <b>Allow</b> = (Default) Permits the packets.</li> <li>■ <b>Block</b> = Rejects the packets</li> </ul>
'Packet Size' packet-size [AccessList_Packet_Size]	Defines the maximum allowed packet size. The valid range is 0 to 65535. The default is 0. <b>Note:</b> When filtering fragmented IP packets, this parameter relates to overall (re-assembled) packet size (and not to the size of each fragment).
'Byte Rate' byte-rate [AccessList_Byte_Rate]	Defines the expected traffic rate (bytes per second). This is the allowed bandwidth for the specified protocol. The default is 0. In addition to this parameter, the 'Burst Bytes' parameter provides additional allowance such that momentary bursts of data may utilize more than the configured byte rate, without being interrupted. For example, if 'Byte Rate' is configured to 40000 and 'Burst Bytes' to 50000, then this implies the following: the allowed bandwidth is 40000 bytes/sec with extra allowance of 50000 bytes. If, for example, the actual traffic rate is 45000 bytes/sec, this allowance would be consumed within 10 seconds, after which all traffic exceeding the allocated 40000 bytes/sec is dropped. If the actual traffic rate then slowed to 30000 bytes/sec, the allowance would be replenished within 5 seconds.
'Burst Bytes' byte-burst [AccessList_Byte_Burst]	Defines the tolerance of traffic rate limit (number of bytes). The default is 0.
Statistics	

Parameter	Description
'Match Count' [AccessList_MatchCount]	(Read-only) Displays the number of packets accepted or rejected by the rule.

The table below provides an example of configured firewall rules:

**Table 14-6: Configuration Example of Firewall Rules**

Parameter	Firewall Rule				
	1	2	3	4	5
'Source IP'	12.194.231.76	12.194.230.7	0.0.0.0	192.0.0.0	0.0.0.0
'Prefix Length'	16	16	0	8	0
'Start Port and End Port'	0-65535	0-65535	0-65535	0-65535	0-65535
'Protocol'	Any	Any	icmp	Any	Any
'Use Specific Interface'	<b>Enable</b>	<b>Enable</b>	<b>Disable</b>	<b>Enable</b>	<b>Disable</b>
'Interface Name'	WAN	WAN	None	Voice-Lan	None
'Byte Rate'	0	0	40000	40000	0
'Burst Bytes'	0	0	50000	50000	0
'Action Upon Match'	<b>Allow</b>	<b>Allow</b>	<b>Allow</b>	<b>Allow</b>	<b>Block</b>

The firewall rules in the above configuration example do the following:

- **Rules 1 and 2:** Typical firewall rules that allow packets ONLY from specified IP addresses (e.g., proxy servers). Note that the prefix length is configured.
- **Rule 3:** A more "advanced" firewall rule - bandwidth rule for ICMP, which allows a maximum bandwidth of 40,000 bytes/sec with an additional allowance of 50,000 bytes. If, for example, the actual traffic rate is 45,000 bytes/sec, then this allowance would be consumed within 10 seconds, after which all traffic exceeding the allocated 40,000

bytes/sec is dropped. If the actual traffic rate then slowed to 30,000 bytes/sec, the allowance would be replenished within 5 seconds.

■ **Rule 4:** Allows traffic from the LAN voice interface and limits bandwidth.

■ **Rule 5:** Blocks all other traffic.

## Configuring Firewall Rules to Allow Incoming OVOC Traffic

If the device needs to communicate with AudioCodes OVOC, and you have configured at least one rule in the device's Firewall table, you also need to add firewall rules that permit (allow) incoming traffic from OVOC.



These OVOC-related firewall rules are required only if have configured other firewall rules in the Firewall table. If you haven't configured any rules, the device allows all incoming traffic (including from OVOC) by default and the below firewall configuration is not required.

**Table 14-7: Firewall Rules to Allow Traffic from OVOC**

Index	Source IP	Source Port	Prefix Length	Start Port	End Port	Protocol	Use Specific Interface	Interface Name	Action Upon Match	Packet Size	Byte Rate	Byte Burst
0	Various rules for basic traffic.											
...												
N												
N+1 (SNMP)	<OVOC IP address>	1161	32	161	161	udp	Enable	OAM_IF	Allow	0	0	0
N+2 (NTP)	<OVOC IP address>	123	32	0	0	udp	Enable	<interface configured for NTP>	Allow	0	0	0
N+3 (HTTP)	<OVOC IP address>	80	32	0	0	tcp	Enable	<interface>	Allow	0	0	0



Index	Source IP	Source Port	Prefix Length	Start Port	End Port	Protocol	Use Specific Interface	Interface Name	Action Upon Match	Packet Size	Byte Rate	Byte Burst
	ess>							configured for file transfer>				
N+4 (HTT PS)	<OV OC IP address>	443	32	0	0	tcp	Enable	<interface configured for file transfer>	Allow	0	0	0
N+5 (Qo E)	<OV OC IP address>	5000	32	0	0	tcp	Enable	<interface configured for QoE>	Allow	0	0	0
N+6 (Qo E-secured)	<OV OC IP address>	5001	32	0	0	tcp	Enable	<interface configured for QoE>	Allow	0	0	0
N+7 (default - drop)	0.0.0.0	0	0	0	65535	Any	Disable	--	Block	0	0	0

## Intrusion Detection System

The device's Intrusion Detection System (IDS) feature detects malicious attacks on the device and reacts accordingly. A remote host is considered malicious if it reaches or exceeds a user-defined threshold (counter) of specified malicious attack types.

If malicious activity is detected, the device can do the following:

- Block remote hosts (IP addresses / ports) considered by the device as malicious. The device automatically blocks the malicious source for a user-defined period, after which it is removed from the IDS Active Blocked List (see [Viewing IDS Active Blocked List](#) on page 1372).
- Send SNMP traps to notify of malicious activity and/or whether an attacker has been added to or removed from the IDS blocked list. For more information, see [Viewing IDS Alarms](#) on page 268.

IDS is an important feature as it ensures legitimate calls are not being adversely affected by attacks, and prevents Theft of Service and unauthorized access.

There are many types of malicious attacks, the most common being:

- **Denial of service:** This can be Denial of Service (DoS) where an attacker wishing to prevent a server from functioning correctly directs a large amount of requests – sometimes meaningless and sometimes legitimate, or it can be Distributed Denial of Service (DDoS) where the attacker controls a large group of systems to coordinate a large scale DoS attack against a system:
  - Message payload tampering: Attacker may inject harmful content into a message, e.g., by entering meaningless or wrong information, with the goal of exploiting a buffer overflow at the target. Such messages can be used to probe for vulnerabilities at the target.
  - Message flow tampering: This is a special case of DoS attacks. These attacks disturb the ongoing communication between users. An attacker can then target the connection by injecting fake signaling messages into the communication channel (such as CANCEL messages).
  - Message Flooding: The most common DoS attack is where an attacker sends a huge amount of messages (e.g., INVITEs) to a target. The goal is to overwhelm the target's processing capabilities, thereby rendering the target inoperable.
- **SPAM over Internet Telephony (SPIT):** VoIP spam is unwanted, automatically dialed, pre-recorded phone calls using VoIP. It is similar to e-mail spam.
- **Theft of Service (ToS):** Service theft can be exemplified by phreaking, which is a type of hacking that steals service (i.e., free calls) from a service provider, or uses a service while passing the cost to another person.

The IDS configuration is based on IDS Policies, where each policy can be configured with a set of IDS rules. Each rule defines a type of malicious attack to detect and the number of attacks

during an interval (threshold) before an SNMP trap is sent. Each policy is then applied to a target under attack (SIP Interface) and/or source of attack (Proxy Set and/or subnet address).

## Enabling IDS

By default, IDS is disabled. You can enable it, as described below.

### ➤ To enable IDS:

1. Open the IDS General Settings page (**Setup** menu > **Signaling & Media** tab > **Intrusion Detection** folder > **IDS General Settings**).
2. Select the 'Intrusion Detection System (IDS)' check box:

Intrusion Detection System (IDS) ☒

3. Click **Apply**.

## Configuring IDS Policies

An IDS Policy is configured using two tables with "parent-child" type relationship:

- **IDS Policies table ("parent"):** Defines a name and provides a description for the IDS Policy. You can configure up to 20 IDS Policies.
- **IDS Rules table ("child"):** Defines the actual rules for the IDS Policy. Each IDS Policy can be configured with up to 20 rules.



A maximum of 100 IDS rules can be configured (regardless of how many rules are assigned to each policy).

For your convenience, the device provides default IDS Policies which you can use in your deployment if they meet your requirements:

- "DEFAULT\_FEU" - typically suited for far-end users in the WAN.
- "DEFAULT\_PROXY" - typically suited for proxy servers.
- "DEFAULT\_GLOBAL" - with global thresholds.

The following table shows the IDS rules per default IDS Policy:

Default IDS Policies and Rules	Default Values		
	'Threshold Scope'	'Threshold Window'	'Minor-Alarm Threshold'
DEFAULT_FEU			
Connection abuse	IP	30	5

Default IDS Policies and Rules	Default Values		
	'Threshold Scope'	'Threshold Window'	'Minor-Alarm Threshold'
Malformed message	IP	30	15
Authentication failure	IP	600	20
Dialog establish failure	IP	300	30
Abnormal flow	IP	30	15
<b>DEFAULT_PROXY</b>			
Connection abuse	IP	3	5
Malformed message	IP	3	50
Authentication failure	IP	5	30
Dialog establish failure	IP	3	50
Abnormal flow	IP	3	50
<b>DEFAULT_GLOBAL</b>			
Connection abuse	Global	3	15
Malformed message	Global	3	50
Authentication failure	Global	5	30
Dialog establish failure	Global	3	50
Abnormal flow	Global	3	50



- You can edit and delete the default IDS Policies.
- If the IDS Policies table is empty (i.e., you have deleted all IDS Policies) and you want to restore the default IDS Policies, disable and then enable the IDS feature (see [Enabling IDS](#) on the previous page).

The following procedure describes how to configure IDS Policies through the Web interface. You can also configure it through ini file or CLI:

- IDS Policy table: IDSPolicy (ini file) or `configure voip > ids policy` (CLI)
- IDS Rules table: IDSRule (ini file) or `configure voip > ids rule` (CLI)

➤ **To configure an IDS Policy:**

1. Open the IDS Policies table (**Setup** menu > **Signaling & Media** tab > **Intrusion Detection** folder > **IDS Policies**); the table displays the pre-configured IDS policies:

INDEX ↕	NAME	DESCRIPTION
0	DOS	dos-attacks
1	DEFAULT_FEU	Default policy for FEU
2	DEFAULT_PROXY	Default policy for proxies
3	DEFAULT_GLOBAL	Default policy for global scope

2. Click **New**; the following dialog box appears:

3. Configure an IDS Policy name according to the parameters described in the table below.
4. Click **Apply**.

**Table 14-8: IDS Policies Table Parameter Descriptions**

Parameter	Description
'Index' policy [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' rule [Name]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 40 characters. <b>Note:</b> <ul style="list-style-type: none"> <li>■ The parameter value can't contain a forward slash (/).</li> <li>■ The parameter value can't be configured with the character string "any" (upper or lower case).</li> </ul>
'Description' description [Description]	Defines a brief description for the IDS Policy. The valid value is a string of up to 100 characters.

5. In the IDS Policies table, select the required IDS Policy row, and then click the **IDS Rule** link located below the table; the IDS Rule table opens.
6. Click **New**; the following dialog box appears:

The screenshot shows the 'IDS Rule' configuration window. It has a title bar with 'IDS Rule' and standard window controls. The window is divided into two main sections: 'GENERAL' and 'ALARMS'. The 'GENERAL' section includes fields for 'Index' (set to 1), 'Reason' (a dropdown menu showing 'Malformed message'), 'Threshold Scope' (a dropdown menu showing 'IP'), and 'Threshold Window' (set to 30). The 'ALARMS' section includes three threshold fields: 'Minor-Alarm Threshold' (15), 'Major-Alarm Threshold' (20), and 'Critical-Alarm Threshold' (25). Below these sections is a 'DENY' section with 'Deny Threshold' (25) and 'Deny Period' (60).

The figure above shows a configuration example: If 15 malformed SIP messages ('Reason') are received within a period of 30 seconds ('Threshold Window'), a minor alarm is sent ('Minor-Alarm Threshold'). Every 30 seconds, the rule's counters are cleared ('Threshold Window'). If more than 25 malformed SIP messages are received within this period, the device blocks for 60 seconds the remote IP host ('Deny Threshold') from where the messages were received.

7. Configure an IDS Rule according to the parameters described in the table below.
8. Click **Apply**, and then save your settings to flash memory.

**Table 14-9: IDS Rule Table Parameter Descriptions**

Parameter	Description
<b>General</b>	
'Index' rule-id [IDSRule_RuleID]	Defines an index number for the new table record.
'Reason' reason [IDSRule_Reason]	<p>Defines the type of intrusion attack (malicious event).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Any</b> = All events listed below are considered as attacks and are counted together.</li> <li>■ [1] <b>Connection abuse</b> = (Default) Connection failures, which includes the following: <ul style="list-style-type: none"> <li>✓ Incoming TLS authentication (handshake) failure</li> <li>✓ Incoming WebSocket connection establishment</li> </ul> </li> </ul>

Parameter	Description
	<p>failure</p> <ul style="list-style-type: none"> <li>■ [2] <b>Malformed message</b> = Malformed SIP messages, which includes the following: <ul style="list-style-type: none"> <li>✓ Message exceeds a user-defined maximum message length (50K)</li> <li>✓ Any SIP parser error</li> <li>✓ Message Policy match (see <a href="#">Configuring SIP Message Policy Rules</a> on page 840)</li> <li>✓ Basic headers not present</li> <li>✓ Content length header not present (for TCP)</li> <li>✓ Header overflow</li> </ul> </li> <li>■ [3] <b>Authentication failure</b> = SIP authentication failure, which includes the following: <ul style="list-style-type: none"> <li>✓ Local authentication ("Bad digest" errors)</li> <li>✓ Remote authentication (SIP 401/407 is sent if original message includes authentication)</li> </ul> </li> <li>■ [4] <b>Dialog establish failure</b> = SIP dialog establishment (e.g., INVITE) failure, which includes the following: <ul style="list-style-type: none"> <li>✓ Classification failure (see <a href="#">Configuring Classification Rules</a> on page 1061).</li> <li>✓ Call Admission Control (CAC) threshold exceeded (see <a href="#">Configuring Call Admission Control</a> on page 1054)</li> <li>✓ Routing failure (i.e., no routing rule was matched)</li> <li>✓ Local reject by device (prior to SIP 180 response): REGISTER not allowed due to IP Group's 'Registration Mode' parameter, or SIP requests rejected based on a registered users policy (configured by the SRD parameter 'User Security Mode' or SIP Interface parameter 'User Security Mode').</li> <li>✓ No user found when routing to a User-type IP Group (similar to a SIP 404)</li> <li>✓ Remote rejects (prior to SIP 18x response). To specify SIP response codes to exclude from the IDS count, see <a href="#">Configuring SIP Response Codes to Exclude from</a></li> </ul> </li> </ul>

Parameter	Description
	<p>IDS.</p> <ul style="list-style-type: none"> <li>✓ Malicious signature pattern detected (see <a href="#">Configuring Malicious Signatures</a> on page 1137)</li> <li>■ [5] <b>Abnormal flow</b> = SIP call flow that is abnormal, which includes the following: <ul style="list-style-type: none"> <li>✓ Requests and responses without a matching transaction user (except ACK requests)</li> <li>✓ Requests and responses without a matching transaction (except ACK requests)</li> </ul> </li> </ul>
<p>'Threshold Scope'</p> <p>threshold-scope</p> <p>[IDSRule_ThresholdScope]</p>	<p>Defines the source of the attacker to consider in the device's detection count.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Global</b> = All attacks regardless of source are counted together during the threshold window.</li> <li>■ [2] <b>IP</b> = Attacks from each specific IP address are counted separately during the threshold window.</li> <li>■ [3] <b>IP+Port</b> = Attacks from each specific IP address:port are counted separately during the threshold window. This option is useful for NAT servers, where numerous remote machines use the same IP address but different ports. However, it is not recommended to use this option as it may degrade detection capabilities.</li> </ul>
<p>'Threshold Window'</p> <p>threshold-window</p> <p>[IDSRule_ThresholdWindow]</p>	<p>Defines the threshold interval (in seconds) during which the device counts the attacks to check if a threshold is crossed. The counter is automatically reset at the end of the interval. The valid range is 1 to 1,000,000. The default is 1.</p>
<b>Alarms</b>	
<p>'Minor-Alarm Threshold'</p> <p>minor-alm-thr</p> <p>[IDSRule_MinorAlarmThreshold]</p>	<p>Defines the threshold that if crossed a minor severity alarm is sent.</p> <p>The valid range is 1 to 1,000,000. A value of 0 or -1 means not defined.</p>
<p>'Major-Alarm Threshold'</p> <p>major-alm-thr</p> <p>[IDSRule_MajorAlarmThreshold]</p>	<p>Defines the threshold that if crossed a major severity alarm is sent.</p> <p>The valid range is 1 to 1,000,000. A value of 0 or -1 means not defined.</p>



Parameter	Description
'Critical-Alarm Threshold' critical-alm-thr [IDSRule_ CriticalAlarmThreshold]	Defines the threshold that if crossed a critical severity alarm is sent.  The valid range is 1 to 1,000,000. A value of 0 or -1 means not defined.
Deny	
'Deny Threshold' deny-thr [IDSRule_DenyThreshold]	Defines the threshold that if crossed, the device blocks the remote host (attacker).  The default is -1 (i.e., not configured).  To view the IDS blocked list, see <a href="#">Viewing IDS Active Blocked List</a> on page 1372.  <b>Note:</b> The parameter is applicable only if the 'Threshold Scope' parameter is set to <b>IP</b> or <b>IP+Port</b> .
'Deny Period' deny-period [IDSRule_DenyPeriod]	Defines the duration (in sec) to keep the attacker on the blocked list, if configured using the 'Deny Threshold' parameter.  The valid range is 0 to 1,000,000. The default is -1 (i.e., not configured).  To view the IDS blocked list, see <a href="#">Viewing IDS Active Blocked List</a> on page 1372.  <b>Note:</b> The parameter is applicable only if the 'Threshold Scope' parameter is set to <b>IP</b> or <b>IP+Port</b> .

## Assigning IDS Policies

The IDS Matches table lets you implement your configured IDS Policies. You do this by assigning IDS Policies to any, or a combination of the following configuration entities:

- **SIP Interface:** For detection of malicious attacks on specific SIP Interface(s). To configure SIP Interfaces, see [Configuring SIP Interfaces](#) on page 561.
- **Proxy Sets:** For detection of malicious attacks from specified Proxy Set(s). To configure Proxy Sets, see [Configuring Proxy Sets](#) on page 622.
- **Subnet addresses:** For detection of malicious attacks from specified subnet addresses.

You can configure up to 20 IDS Policy-Matching rules.

The following procedure describes how to configure the IDS Match table through the Web interface. You can also configure it through ini file [IDSMatch] or CLI (`configure voip > ids match`).

➤ **To configure an IDS Policy-Matching rule:**

1. Open the IDS Matches table (**Setup** menu > **Signaling & Media** tab > **Intrusion Detection** folder > **IDS Matches**).
2. Click **New**; the following dialog box appears:

The screenshot shows the 'IDS Matches' configuration window. Under the 'GENERAL' tab, the following values are entered:

- Index:** 1
- SIP Interface IDs:** 1-2
- Proxy Set IDs:** (empty)
- Subnet:** !10.1.0.0/16 & !10.2.2.2
- Policy:** #3 [SIP Trunk] (with a 'View' button next to it)

The figure above shows a configuration example where the IDS Policy "SIP Trunk" is applied to SIP Interfaces 1 and 2, and to all source IP addresses outside of subnet 10.1.0.0/16 and IP address 10.2.2.2.

3. Configure a rule according to the parameters described in the table below.
4. Click **Apply**, and then save your settings to flash memory.

**Table 14-10:IDS Matches Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table record.
'SIP Interface IDs' sip-interface [SIPInterface]	<p>Assigns a SIP Interface(s) to the IDS Policy. This indicates the SIP Interfaces that are being attacked.</p> <p>The valid value is the ID of the SIP Interface. The following syntax is supported:</p> <ul style="list-style-type: none"> <li>■ A comma-separated list of SIP Interface IDs (e.g., 1,3,4)</li> <li>■ A hyphen (-) indicates a range of SIP Interfaces (e.g., 3,4-7 means IDs 3, and 4 through 7)</li> <li>■ A prefix of an exclamation mark (!) means negation of the set (e.g., !3,4-7 means all indexes excluding 3, and excluding 4 through 7)</li> </ul>
'Proxy Set IDs' proxy-set [ProxySet]	<p>Assigns a Proxy Set(s) to the IDS Policy. This indicates the Proxy Sets from where the attacks are coming from. The following syntax is supported:</p> <ul style="list-style-type: none"> <li>■ A comma-separated list of Proxy Set IDs (e.g., 1,3,4)</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ A hyphen (-) indicates a range of Proxy Sets (e.g., 3,4-7 means IDs 3, and 4 through 7)</li> <li>■ A prefix of an exclamation mark (!) means negation of the set (e.g., !3,4-7 means all indexes excluding 3, and excluding 4 through 7)</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Only the IP address of the Proxy Set is considered (not port).</li> <li>■ If a Proxy Set has multiple IP addresses, the device considers the Proxy Set as one entity and includes all its IP addresses in the same IDS count.</li> </ul>
'Subnet' subnet [Subnet]	<p>Defines the subnet to which the IDS Policy is assigned. This indicates the subnets from where the attacks are coming from. The following syntax can be used:</p> <ul style="list-style-type: none"> <li>■ Basic syntax is a subnet in CIDR notation (e.g., 10.1.0.0/16 means all sources with IP address in the range 10.1.0.0–10.1.255.255)</li> <li>■ An IP address can be specified without the prefix length to refer to the specific IP address.</li> <li>■ Each subnet can be negated by prefixing it with (!), which means all IP addresses outside that subnet.</li> <li>■ Multiple subnets can be specified by separating them with "&amp;" (and) or " " (or) operations (without quotation marks), for example: <ul style="list-style-type: none"> <li>✓ 10.1.0.0/16   10.2.2.2: includes subnet 10.1.0.0/16 and IP address 10.2.2.2.</li> <li>✓ !10.1.0.0/16 &amp; !10.2.2.2: includes all addresses except those of subnet 10.1.0.0/16 and IP address 10.2.2.2. Note that the exclamation mark (!) appears before each subnet.</li> <li>✓ 10.1.0.0/16 &amp; !10.1.1.1: includes subnet 10.1.0.0/16, except IP address 10.1.1.1.</li> </ul> </li> </ul>
'Policy' policy [Policy]	<p>Assigns an IDS Policy (configured in <a href="#">Configuring IDS Policies</a> on page 259).</p>

## Viewing IDS Alarms

The device sends the following SNMP traps for the IDS feature:

■ Traps that notify the detection of malicious attacks:

- **acIDSPolicyAlarm:** The device sends this alarm whenever a threshold of a specific IDS Policy rule is crossed. The trap displays the crossed severity threshold (Minor or Major), IDS Policy and IDS Rule, and the IDS Policy-Match index.
- **acIDSThresholdCrossNotification:** The device sends this event for each scope (IP address) that crosses the threshold. In addition to the crossed severity threshold (Minor or Major) of the IDS Policy-Match index, this event shows the IP address (or IP address:port) of the malicious attacker.

If the severity level is raised, the alarm of the former severity is cleared and the device sends a new alarm with the new severity. The alarm is cleared after a user-defined timeout during which no thresholds have been crossed.

➤ **To configure IDS alarm cleared timeout:**

1. Open the IDS General Settings page (**Setup** menu > **Signaling & Media** tab > **Intrusion Detection** folder > **IDS General Settings**).
2. From the 'IDS Alarm Clear Period' field (IDSAlarmClearPeriod), enter the timeout (in seconds) after which the alarm is cleared if no IDS thresholds have been crossed during the timeout.

**IDS Alarm Clear Period [sec]**

3. Click **Apply**.

This "quiet" timeout period must be at least twice the 'Threshold Window' value (configured in [Configuring IDS Policies](#) on page 259). For example, if you configure 'IDS Alarm Clear Period' to 20 sec and 'Threshold Window' to 15 sec, the 'IDS Alarm Clear Period' parameter is ignored and the alarm is cleared only after 30 seconds (2 x 15 sec).

The figure below displays an example of IDS alarms in the Active Alarms table ([Viewing Active Alarms](#) on page 1323). In this example, a Minor threshold alarm is cleared and replaced by a Major threshold alarm:

17	Minor	Board#1/IDSMatch#2/IDSRule#0	Policy 2 (Proxy): minor threshold (5) of signaling-msg cross in ip scope	24.10.2012, 9:48:53
18	cleared	Board#1/IDSMatch#2/IDSRule#0	Alarm cleared: Policy 2 (Proxy): minor threshold (5) of signaling-msg cross in ip scope	24.10.2012, 9:48:53
19	Major	Board#1/IDSMatch#2/IDSRule#0	Policy 2 (Proxy): major threshold (10) of signaling-msg cross in ip scope	24.10.2012, 9:48:53

- **acIDSBlacklistNotification** event: The device sends this event whenever an attacker (remote host at IP address and/or port) is added to or removed from the blocked list. To view the IDS blocked list, see [Viewing IDS Active Blocked List](#) on page 1372.

You can also view IDS alarms through CLI:

- To view all active IDS alarms:

```
# show voip ids active-alarm all
```

- To view all IP addresses that have crossed the threshold for an active IDS alarm:

```
# show voip ids active-alarm match <IDS Match Policy ID> rule <IDS Rule ID>
```

The IP address is displayed only if the 'Threshold Scope' parameter is set to IP or IP+Port; otherwise, only the alarm is displayed.

The device also sends IDS notifications and alarms in syslog messages to a syslog server. This occurs only if you have configured syslog (see [Enabling Syslog](#) on page 1490). An example of a syslog message with IDS alarms and notifications is shown below:

```
[S=92159] [SID:438286865] ( lgr_ids)(97420 ) IDS Event: reason=establish-fail,event=14003(establish-classify-fail),ip=10.13.45.200:5060(SII),transport=udp
[S=92160] [SID:438286865] ( lgr_ids)(97421 ) IDS Counter (0,19995): IDSMATCH#0/IDSRULE#0,policy=3(TEST),reason=establish-fail,scope=ip,scope-val=10.13.45.200(SII),value=6
[S=92161] [SID:438286865] ( lgr_ids)(97422 ) ?? [WARNING] IDS Rule (0): Threshold cross. IDSMATCH#0/IDSRULE#0,policy=3(TEST),value=6,severity=2(major)
[S=92162] [SID:438286865] ( lgr_ids)(97423 ) ?? [WARNING] IDS Rule (0): Threshold cross. IDSMATCH#0/IDSRULE#0,policy=3(TEST),value=6,severity=4(blacklist)
[S=92163] [SID:438286865] ( lgr_ids)(97424 ) ?? [WARNING] IDS Blacklist: Added IP 10.13.45.200(NI0) to blacklist
[S=92164] [SID:438286865] ( lgr_psrdrif)(97425 ) SNMP EVENT: IDS_BLACKLIST_NOTIFY "Added IP 10.13.45.200(NI0) to blacklist"
[S=92165] RAISE-ALARM:acIDSBlacklistNotification: Textual Description: Added IP 10.13.45.200(NI0) to blacklist; Severity:indeterminate; Source; Unique ID:30;
[S=92166] [SID:438286865] ( lgr_psrdrif)(97426 ) InsertBoardEvent- event ADD BLACKLIST EV inserted channel -100
```

The table below lists the syslog text messages per malicious event:

**Table 14-11:Types of Malicious Events and Syslog Text String**

Reason	
Description	Syslog String
<b>Connection Abuse</b>	
TLS authentication failure	abuse-tls-auth-fail
WebSocket establishment failure	abuse-websocket-fail
<b>Malformed Messages</b>	
Message exceeds a user-defined maximum message length (50K)	malformed-invalid-msg-len
Any SIP parser error	malformed-parse-error
Message policy match	malformed-message-policy
Basic headers not present	malformed-miss-header
Content length header not present (for TCP)	malformed-miss-content-len
Header overflow	malformed-header-overflow

Reason	
Description	Syslog String
<b>Authentication Failure</b>	
Local authentication ("Bad digest" errors)	auth-establish-fail
Remote authentication (SIP 401/407 is sent if original message includes authentication)	auth-reject-response
<b>Dialog Establishment Failure</b>	
Classification failure	establish-classify-fail
Routing failure (no matched routing rule)	establish-route-fail
Other local rejects (prior to SIP 180 response)	establish-local-reject
Remote rejects (prior to SIP 180 response)	establish-remote-reject
Malicious signature pattern detected	establish-malicious-signature-db-reject
CAC threshold exceeded	establish-cac-reject
<b>Abnormal Flow</b>	
Requests and responses without a matching transaction user (except ACK requests)	flow-no-match-tu
Requests and responses without a matching transaction (except ACK requests)	flow-no-match-transaction

## Configuring SIP Response Codes to Exclude from IDS

You can specify SIP response codes (reject reasons) that you want the IDS mechanism to ignore in its' count as reasons for SIP-dialog establishment failures.

### ➤ To configure SIP responses to exclude from IDS:

1. Open the IDS General Settings page (**Setup** menu > **Signaling & Media** tab > **Intrusion Detection** folder > **IDS General Settings**).
2. In the 'Excluded Response Codes' field, enter the SIP response codes that you want ignored by IDS.

**Figure 14-1: Configuring SIP Response Codes to Exclude from IDS**

Excluded Response Codes

3. Click **Apply**.



- The parameter applies only to rejected responses received from the upstream server; not rejected responses generated by the device (except for 404).
- The response codes 401 and 407 are considered authentication failures and thus, are not applicable to this parameter.

## Configuring SIP Header Value Encryption

For enhanced security, you can configure the device to encrypt the value of a specific SIP header. Encryption is done using the AES-256 key encryption algorithm.

This feature is typically used between two AudioCodes devices, where one encrypts the SIP header value before sending the SIP message, while the other decrypts the value when it receives the SIP message.



This feature is intended for SIP headers that are not used by the device for classification or routing. For example, you may want to encrypt the value of a proprietary SIP header called "P-Access-Network-Info" that may contain sensitive information.

➤ **To configure SIP header value encryption:**

1. Configure the AES-256 encryption key:
  - a. Open the SIP Definitions General Settings page (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **SIP Definitions General Settings**).
  - b. In the 'AES-256 Encryption Key' parameter, enter the encryption key:

### SIP HEADERS ENCRYPTION

AES-256 Encryption Key



- The key must be 32 characters.
- Configure both devices with the same key.

2. Configure a Message Manipulation rule to specify the SIP header to encrypt:
  - a. Open the Message Manipulations table (see [Configuring SIP Message Manipulation](#) on page 829).
  - b. Click **New**, and then configure the rule as follows:
    - ◆ 'Name': Assign a name.

- ◆ 'Manipulation Set ID': Configure an ID.
- ◆ 'Message Type': Configure the type of SIP message (e.g., **Invite**).
- ◆ 'Action Subject': Configure the SIP header whose value you want to encrypt (e.g., **P-Access-Network-Info**).
- ◆ 'Action Type': Select **Modify**.
- ◆ 'Action Value': Use the **Funct.Encrypt** option to encrypt the SIP header (e.g., **Funct.Encrypt(P-Access-Network-Info)**).



On the device that decrypts the SIP header value, configure the 'Action Value' parameter to **Funct.Decrypt(P-Access-Network-Info)** for the relevant Message Manipulation rule.

3. Open the IP Groups table (see [Configuring IP Groups](#) on page 581), and then assign the Manipulation Set ID (configured in the previous step) to the relevant IP Group.



## 15 Media

This section describes media-related configuration.

### Voice Settings

The section describes various voice-related configuration such as voice volume, silence suppression, and DTMF transport type. For a detailed description of these parameters, see [Configuration Parameters Reference](#) on page 1563.

### Configuring Voice Gain (Volume) Control

The device allows you to configure the level of the received (input gain) Tel-to-IP or IP-to-IP signal and the level of the transmitted (output gain) IP-to-Tel or IP-to-IP signal. The gain can be set between -32 and 31 decibels (dB).

➤ **To configure gain control through the Web interface:**

1. Open the Voice Settings page (**Setup** menu > **Signaling & Media** tab > **Media** folder > **Voice Settings**).

Voice Volume (-32 to 31 dB)	<input type="text" value="0"/>
Input Gain (-32 to 31 dB)	<input type="text" value="0"/>

2. Configure the following parameters:
  - 'Voice Volume' (*VoiceVolume*): Defines the voice gain control (in decibels) of the transmitted signal.
  - 'Input Gain' (*InputGain*): Defines the PCM input gain control (in decibels) of the received signal.
3. Click **Apply**.

### Configuring Echo Cancellation

The device supports adaptive linear (line) echo cancellation according to G.168-2002. Echo cancellation is a mechanism that removes echo from the voice channel. Echoes are reflections of the transmitted signal.

In this line echo, echoes are generated when two-wire telephone circuits (carrying both transmitted and received signals on the same wire pair) are converted to a four-wire circuit. Echoes are reflections of the transmitted signal, which result from impedance mismatch in the hybrid (bi-directional 2-wire to 4-wire converting device).

An estimated echo signal is built by feeding the decoder output signal to an RLS-like adaptive filter, which adapts itself to the characteristics of the echo path. The 'estimated echo signal' (the output of this filter) is then subtracted from the input signal (which is the sum of the

desired input signal and the undesired echo) to provide a clean signal. To suppress the remaining residual echo, a Non Linear Processor (NLP) is used, as well as a double-talk (two people speak at the same time) detector that prevents false adaptation during near-end speech.

The following procedure describes how to configure echo cancellation through the Web interface:

➤ **To configure echo cancellation:**

1. Configure line echo cancellation:
  - a. Open the Voice Settings page (**Setup** menu > **Signaling & Media** tab > **Media** folder > **Voice Settings**), and then select the 'Echo Canceller' check box (EnableEchoCanceller):

Echo Canceller



The following additional echo cancellation parameters are configurable only through *ini* file:

- *ECHybridLoss* - defines the four-wire to two-wire worst-case Hybrid loss
- *ECNLPMODE* - defines the echo cancellation Non-Linear Processing (NLP) mode
- *EchoCancellerAggressiveNLP* - enables Aggressive NLP at the first 0.5 second of the call

## Fax and Modem Capabilities

This section describes the device's fax and modem capabilities and corresponding configuration. Fax and modem configuration is done on the Fax/Modem/CID Settings page.



- Unless otherwise specified, parameters mentioned in this section are available on this page. For a detailed description of these fax and modem parameters, see [Configuration Parameters Reference](#) on page 1563.
- Some SIP parameters override these fax and modem parameters. For example, the [IsFaxUsed] parameter and V.152 parameters in Section [V.152 Support](#) on page 289.

➤ **To access the fax and modem parameters:**

- Open the Fax/Modem/CID Settings page (**Setup** menu > **Signaling & Media** tab > **Media** folder > **Fax/Modem/CID Settings**).

GENERAL		FAX RELAY	
Fax Transport Mode	T.38 Relay	Fax Relay Redundancy Depth	0
T.38 Version	T.38 version 0	Fax Relay Enhanced Redundancy Depth	4
Caller ID Transport Type	Mute	Fax Relay ECM Enable	Enable
Caller ID Type	Standard Bellcore	Fax Relay Max Rate (bps)	14400bps
V.21 Modem Transport Type	Disable	Fax Relay Rx/Tx Timeout (sec)	10
V.22 Modem Transport Type	Enable Bypass		
V.23 Modem Transport Type	Enable Bypass		
V.32 Modem Transport Type	Enable Bypass		
V.34 Modem Transport Type	Enable Bypass		
Fax CNG Mode	Doesn't send T.38 re-INV		
CNG Detector Mode	Disable		

FAX/MODEM BYPASS	
Fax/Modem Bypass Coder Type	G711Alaw_64
Fax/Modem Bypass Packing Factor	1
Fax Bypass Output Gain	0
Modem Bypass Output Gain	0

## Fax and Modem Operating Modes

The device supports two modes of operation:

- Fax/modem negotiation that is **not** performed during call establishment.
- Voice-band data (VBD) mode for V.152 implementation (see [V.152 Support](#) on page 289): Fax/modem capabilities are negotiated between the device and the remote endpoint during call establishment. During a call, when a fax/modem signal is detected, transition from voice to VBD (or T.38) is automatically performed and no additional SIP signaling is required. If negotiation fails (i.e., no match is achieved for any of the transport capabilities), fallback to existing logic occurs (according to the parameter `IsFaxUsed`).

## Fax and Modem Transport Modes

The device supports the following transport modes for fax per modem type (V.22/V.23/Bell/V.32/V.34):

- T.38 fax relay (see [T.38 Fax Relay Mode](#) on the next page)
- G.711 Transport: switching to G.711 when fax/modem is detected (see [G.711 Fax and Modem Transport Mode](#) on page 279)
- Fax fallback to G.711 if T.38 is not supported (see [Fax Fallback](#) on page 279)
- Fax and modem bypass: a proprietary method that uses a high bit rate coder (see [Fax and Modem Bypass Mode](#) on page 280)
- NSE Cisco's Pass-through bypass mode for fax and modem (see [Fax and Modem NSE Mode](#) on page 282)
- Transparent with events: passing the fax / modem signal in the current voice coder with adaptations (see [Fax and Modem Transparent with Events Mode](#) on page 283)
- Transparent: passing the fax / modem signal in the current voice coder (see [Fax / Modem Transparent Mode](#) on page 284)

- RFC 2833 ANS Report upon Fax/Modem Detection (see [RFC 2833 ANS Report upon Fax and Modem Detection](#) on page 285)

'Adaptations' refer to automatic reconfiguration of certain DSP features for handling fax/modem streams differently than voice.

### T.38 Fax Relay Mode

In Fax Relay mode, fax signals are transferred using the T.38 protocol. T.38 is the ITU standard for sending fax across IP networks in real-time mode. The device currently supports only the T.38 UDP syntax.

T.38 can be configured in the following ways:

- Switching to T.38 mode using SIP re-INVITE messages (see [Switching to T.38 Mode using SIP re-INVITE](#) below)
- Automatically switching to T.38 mode without using SIP re-INVITE messages (see [Automatically Switching to T.38 Mode without SIP re-INVITE](#) on the next page)

When fax transmission ends, the reverse switching from fax relay to voice is automatically performed at both the local and remote endpoints.

You can change the fax rate declared in the SDP, using the 'Fax Relay Max Rate' parameter [FaxRelayMaxRate]. The parameter doesn't affect the actual transmission rate. You can also enable or disable Error Correction Mode (ECM) fax mode using the 'Fax Relay ECM Enable' parameter [FaxRelayECMEnable].

When using T.38 mode, you can define a redundancy feature to improve fax transmission over congested IP networks. This feature is activated using the 'Fax Relay Redundancy Depth' parameter [FaxRelayRedundancyDepth] and the 'Fax Relay Enhanced Redundancy Depth' parameter [FaxRelayEnhancedRedundancyDepth]. Although this is a proprietary redundancy scheme, it should not create problems when working with other T.38 decoders.

#### Switching to T.38 Mode using SIP re-INVITE

In the Switching to T.38 mode using the SIP re-INVITE, upon detection of a fax signal, the terminating device negotiates T.38 capabilities using a re-INVITE message. If the far-end device doesn't support T.38, the fax fails. In this mode, the 'Fax Transport Mode' parameter [FaxTransportMode] is ignored.

#### ➤ To configure T.38 mode using SIP re-INVITE messages:

1. Open the Gateway General Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Gateway General Settings**), and then from the 'Fax Signaling Method' drop-down list [IsFaxUsed], select **T.38 Relay**:

Fax Signaling Method T.38 Relay ▼

2. On the Fax/Modem/CID Settings page, configure the following optional parameters:

- 'Fax Relay Redundancy Depth' [FaxRelayRedundancyDepth]
- 'Fax Relay Enhanced Redundancy Depth' [FaxRelayEnhancedRedundancyDepth]
- 'Fax Relay ECM Enable' [FaxRelayECMEnable]
- 'Fax Relay Max Rate' [FaxRelayMaxRate]



The terminating gateway sends T.38 packets immediately after the T.38 capabilities are negotiated in SIP. However, the originating device by default, sends T.38 (assuming the T.38 capabilities are negotiated in SIP) only after it receives T.38 packets from the remote device. This default behavior cannot be used when the originating device is located behind a firewall that blocks incoming T.38 packets on ports that have not yet received T.38 packets from the internal network. To resolve this problem, you should configure the device to send CNG packets in T.38 upon CNG signal detection [CNGDetectorMode = 1].

### Automatically Switching to T.38 Mode without SIP re-INVITE

In the Automatically Switching to T.38 mode without SIP re-INVITE, when a fax signal is detected, the channel automatically switches from the current voice coder to answer tone mode and then to T.38-compliant fax relay mode.

#### ➤ To configure Automatic T.38 mode:

1. Open the Gateway General Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Gateway General Settings**), and then from the 'Fax Signaling Method' drop-down list (IsFaxUsed), select **No Fax**:

Fax Signaling Method No Fax ▼

2. On the Fax/Modem/CID Settings page, configure the 'Fax Transport Mode' parameter to **T.38 Relay** [FaxTransportMode = 1].
3. Configure the following optional parameters:
  - 'Fax Relay Redundancy Depth' [FaxRelayRedundancyDepth]
  - 'Fax Relay Enhanced Redundancy Depth' [FaxRelayEnhancedRedundancyDepth]
  - 'Fax Relay ECM Enable' [FaxRelayECMEnable]
  - 'Fax Relay Max Rate' [FaxRelayMaxRate]

### Fax over IP using T.38 Transmission over RTP

The device supports Fax-over-IP (FoIP) transmission using T.38 over RTP, whereby the T.38 payload is encapsulated in the RTP packet instead of being sent in dedicated T.38 packets (out-of-band). To support this feature, configure the coder type to T.38 Over RTP.

To indicate T.38 over RTP, the SDP body uses "udptl" (Facsimile UDP Transport Layer) in the 'a=fmtp' line. The device supports T.38 over RTP according to this standard and according to the AudioCodes proprietary method:

- **Call Parties belong to AudioCodes Devices:** T.38-over-RTP method is used, whereby the device encapsulates the entire T.38 packet (payload with all its headers) in the sent RTP. For T.38 over RTP, the devices use the proprietary identifier "AcUdpTl" in the 'a=fmtp' line of the SDP. For example:

```
v=0
o=AudioCodesGW 1357424688 1357424660 IN IP4 10.8.6.68
s=Phone-Call
c=IN IP4 10.8.6.68
t=0 0
m=audio 6080 RTP/AVP 18 100 96
a=ptime:20
a=sendrecv
a=rtpmap:18 G729/8000
a=fmtp:18 annexb=no
a=rtpmap:100 t38/8000
a=fmtp:100 T38FaxVersion=0
a=fmtp:100 T38MaxBitRate=0
a=fmtp:100 T38FaxMaxBuffer=3000
a=fmtp:100 T38FaxMaxDatagram=122
a=fmtp:100 T38FaxRateManagement=transferredTCF
a=fmtp:100 T38FaxUdpEC=t38UDPRedundancy
a=fmtp:100 AcUdpTl
a=rtpmap:96 telephone-event/8000
a=fmtp:96 0-15
```

- **AudioCodes Call Party with non-AudioCodes Party:** The device uses the standard T.38-over-RTP method, which encapsulates the T.38 payload only, without its headers (i.e., includes only fax data) in the sent RTP packet (RFC 4612).

The T.38-over-RTP method also depends on the initiator of the call:

- **Device initiates a call:** The device always sends the SDP offer with the proprietary token "AcUdpTI" in the 'fmtp' attribute. If the SDP answer includes the same token, the device employs the proprietary T.38-over-RTP mode; otherwise, the standard mode is used.
- **Device answers a call:** If the SDP offer from the remote party contains the 'fmtp' attribute with "AcUdpTI", the device answers with the same attribute and employs the proprietary T.38-over-RTP mode; otherwise, the standard mode is used.



If both T.38 (regular) and T.38 Over RTP coders are negotiated between the call parties, the device uses T.38 Over RTP.

### G.711 Fax and Modem Transport Mode

In this mode, when the terminating device detects fax or modem signals (CED or AnsAM), it sends a re-INVITE message to the originating device, requesting it to re-open the channel in G.711 VBD with the following adaptations:

- Echo Canceller = off
- Silence Compression = off
- Echo Canceller Non-Linear Processor Mode = off
- Dynamic Jitter Buffer Minimum Delay = 40
- Dynamic Jitter Buffer Optimization Factor = 13

After a few seconds upon detection of fax V.21 preamble or super G3 fax signals, the device sends a second re-INVITE enabling the echo canceller (the echo canceller is disabled only on modem transmission).

A 'gpmd' attribute is added to the SDP according to the following format:

- **For G.711 A-law:**

```
a=gpmd:8 vbd=yes;ecan=on (or off for modems)
```

- **For G.711  $\mu$ -law:**

```
a=gpmd:0 vbd=yes;ecan=on (or off for modems)
```

The following parameters are ignored and automatically set to **Events Only**:

- 'Fax Transport Mode' [FaxTransportMode]
- 'Vxx ModemTransportType' [VxxModemTransportType]

#### ➤ To configure fax / modem transparent mode:

1. Open the Gateway General Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Gateway General Settings**), and then from the 'Fax Signaling Method' drop-down list (IsFaxUsed), select **G.711 Transport**:

Fax Signaling Method G.711 Transport ▼

2. Click **Apply**.

### Fax Fallback

In this mode, when the terminating device detects a fax signal, it sends a re-INVITE message to the originating device with T.38. If the remote device doesn't support T.38 (replies with SIP

response 415 "Media Not Supported"), the device sends a new re-INVITE with G.711 VBD with the following adaptations:

- Echo Canceller = on
- Silence Compression = off
- Echo Canceller Non-Linear Processor Mode = off
- Dynamic Jitter Buffer Minimum Delay = 40
- Dynamic Jitter Buffer Optimization Factor = 13



This section is applicable only to the Gateway application.

When the device initiates a fax session using G.711, a 'gpmd' attribute is added to the SDP according to the following format:

■ **For G.711A-law:**

```
a=gpmd:8 vbd=yes;ecan=on
```

■ **For G.711  $\mu$ -law:**

```
a=gpmd:0 vbd=yes;ecan=on
```

In this mode, the 'Fax Transport Mode' [FaxTransportMode] parameter is ignored and automatically set to **Disable** (transparent mode).

➤ **To configure fax fallback mode:**

1. Open the Gateway General Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Gateway General Settings**), and then from the 'Fax Signaling Method' drop-down list (IsFaxUsed), select **Fax Fallback**:

Fax Signaling Method

Fax Fallback



2. Click **Apply**.

### Fax and Modem Bypass Mode

In this proprietary mode, when fax or modem signals are detected, the channel automatically switches from the current voice coder to a high bit-rate coder, according to the 'Fax/Modem Bypass Coder Type' parameter [FaxModemBypassCoderType]. The channel is also automatically reconfigured with the following fax / modem adaptations:

- Disables silence suppression
- Enables echo cancellation for fax



- Disables echo cancellation for modem
- Performs certain jitter buffering optimizations

The network packets generated and received during the bypass period are regular voice RTP packets (per the selected bypass coder), but with a different RTP payload type according to the following parameters:

- 'Fax Bypass Payload Type' [FaxBypassPayloadType]
- [ModemBypassPayloadType]

During the bypass period, the coder uses the packing factor, configured by the 'Fax/Modem Bypass Packing Factor' parameter [FaxModemBypassM]. The packing factor determines the number of coder payloads (each the size of [FaxModemBypassBasicRTTPacketInterval]) that are used to generate a single fax/modem bypass packet. When fax/modem transmission ends, the reverse switching, from bypass coder to regular voice coder is performed.

➤ **To configure fax / modem bypass mode:**

1. Open the Gateway General Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Gateway General Settings**), and then from the 'Fax Signaling Method' drop-down list [IsFaxUsed], select **No Fax**.
2. On the Fax/Modem/CID Settings page, do the following:
  - Configure the 'Fax Transport Mode' parameter to **Bypass** [FaxTransportMode = 2].
  - Configure the 'V.21 Modem Transport Type' parameter to **Enable Bypass** [V21ModemTransportType = 2].
  - Configure the 'V.22 Modem Transport Type' parameter to **Enable Bypass** [V22ModemTransportType = 2].
  - Configure the 'V.23 Modem Transport Type' parameter to **Enable Bypass** [V23ModemTransportType = 2].
  - Configure the 'V.32 Modem Transport Type' parameter to **Enable Bypass** [V32ModemTransportType = 2].
  - Configure the 'V.34 Modem Transport Type' parameter to **Enable Bypass** [V34ModemTransportType = 2].
3. Configure the [BellModemTransportType] parameter to 2 (Bypass).
4. Configure the following optional parameters:
  - 'Fax/Modem Bypass Coder Type' [FaxModemBypassCoderType]
  - 'Fax Bypass Payload Type' [FaxBypassPayloadType]
  - [ModemBypassPayloadType]
  - [FaxModemBypassBasicRTTPacketInterval]
  - [FaxModemBypasDJBufMinDelay]



- When the device is configured for modem bypass and T.38 fax, V.21 low-speed modems are not supported and fail as a result.
- When the remote (non-AudioCodes) gateway uses the G.711 coder for voice and doesn't change the coder payload type for fax or modem transmission, it is recommended to use the Bypass mode with the following configuration:
  - ✓ [EnableFaxModemInbandNetworkDetection = 1].
  - ✓ 'Fax/Modem Bypass Coder Type' = same coder used for voice.
  - ✓ 'Fax/Modem Bypass Packing Factor'[FaxModemBypassM] = same interval as voice.
  - ✓ [ModemBypassPayloadType = 8] if voice coder is A-Law or 0 if voice coder is Mu-Law.

### Fax and Modem NSE Mode

In this mode, fax and modem signals are transferred using Cisco-compatible Pass-through bypass mode. Upon detection of fax or modem answering tone signal, the terminating device sends three to six special NSE RTP packets (configured by the [NSEpayloadType] parameter; usually to 100). These packets signal the remote device to switch to G.711 coder, according to the 'Fax/Modem Bypass Packing Factor' parameter. After a few NSE packets are exchanged between the devices, both devices start using G.711 packets with standard payload type (8 for G.711 A-Law and 0 for G.711 Mu-Law). In this mode, no re-INVITE messages are sent. The voice channel is optimized for fax/modem transmission (same as for usual bypass mode).

The following parameters that configure the payload type for the AudioCodes proprietary Bypass mode are not used with NSE Bypass: 'Fax Bypass Payload Type' and [ModemBypassPayloadType].

When configured for NSE mode, the device includes the following line in the SDP, where *100* is the NSE payload type:

```
a=rtpmap:100 X-NSE/8000
```

The Cisco gateway must include the following definition:

```
modem passthrough nse payload-type 100 codec g711alaw
```

#### ➤ To configure NSE mode:

1. Open the Gateway General Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Gateway General Settings**), and then from the 'Fax Signaling Method' drop-down list (IsFaxUsed), select **No Fax**.
2. On the Fax/Modem/CID Settings page, do the following:
  - Configure the 'Fax Transport Mode' parameter to **Bypass** [FaxTransportMode = 2].

- Configure the 'V.21 Modem Transport Type' parameter to **Enable Bypass** [V21ModemTransportType = 2].
  - Configure the 'V.22 Modem Transport Type' parameter to **Enable Bypass** [V22ModemTransportType = 2].
  - Configure the 'V.23 Modem Transport Type' parameter to **Enable Bypass** [V23ModemTransportType = 2].
  - Configure the 'V.32 Modem Transport Type' parameter to **Enable Bypass** [V32ModemTransportType = 2].
  - Configure the 'V.34 Modem Transport Type' parameter to **Enable Bypass** [V34ModemTransportType = 2].
3. Configure the [BellModemTransportType] parameter to [2] (Bypass).
  4. Configure the [NSEMode] parameter to [1] (enables NSE).
  5. parameter the [NSEPayloadType] parameter to [100].

### Fax and Modem Transparent with Events Mode

In this mode, fax and modem signals are transferred using the current voice coder with the following automatic adaptations:

- Echo Canceller = on (or off for modems)
- Echo Canceller Non-Linear Processor Mode = off
- Jitter buffering optimizations

#### ➤ To configure fax / modem transparent with events mode:

1. Open the Gateway General Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Gateway General Settings**), and then from the 'Fax Signaling Method' drop-down list (IsFaxUsed), select **No Fax**.
2. On the Fax/Modem/CID Settings page, do the following:
  - Configure the 'Fax Transport Mode' parameter to **Events Only** [FaxTransportMode = 3].
  - Configure the 'V.21 Modem Transport Type' parameter to **Events Only** [V21ModemTransportType = 3].
  - Configure the 'V.22 Modem Transport Type' parameter to **Events Only** [V22ModemTransportType = 3].
  - Configure the 'V.23 Modem Transport Type' parameter to **Events Only** [V23ModemTransportType = 3].
  - Configure the 'V.32 Modem Transport Type' parameter to **Events Only** [V32ModemTransportType = 3].

- Configure the 'V.34 Modem Transport Type' parameter to **Events Only** [V34ModemTransportType = 3].
3. Configure the [BellModemTransportType] parameter to [3] (transparent with events).

### Fax / Modem Transparent Mode

In this mode, fax and modem signals are transferred using the current voice coder without notifications to the user and without automatic adaptations. It's possible to use Profiles (see [Coders and Profiles](#) on page 651) to apply certain adaptations to the channel used for fax / modem. For example, to use the coder G.711, to set the jitter buffer optimization factor to 13, and to enable echo cancellation for fax and disable it for modem.

#### ➤ To configure fax / modem transparent mode:

1. Open the Gateway General Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Gateway General Settings**), and then from the 'Fax Signaling Method' drop-down list (IsFaxUsed), select **No Fax**.
2. On the Fax/Modem/CID Settings page, do the following:
  - Configure the 'Fax Transport Mode' parameter to **Disable** (FaxTransportMode = 0).
  - Configure the 'V.21 Modem Transport Type' parameter to **Disable** [V21ModemTransportType = 0].
  - Configure the 'V.22 Modem Transport Type' parameter to **Disable** [V22ModemTransportType = 0].
  - Configure the 'V.23 Modem Transport Type' parameter to **Disable** [V23ModemTransportType = 0].
  - Configure the 'V.32 Modem Transport Type' parameter to **Disable** [V32ModemTransportType = 0].
  - Configure the 'V.34 Modem Transport Type' parameter to **Disable** [V34ModemTransportType = 0].
3. Configure the [BellModemTransportType] parameter to [0] (transparent mode).
4. Configure the following optional parameters:
  - Coders in the Coders table - see [Configuring Coders Groups](#) on page 651.
  - 'Dynamic Jitter Buffer Optimization Factor' [DJBufOptFactor] - [Configuring the Dynamic Jitter Buffer](#) on page 290.
  - 'Echo Cancellor' [EnableEchoCancellor] - see [Configuring Echo Cancellation](#) on page 273.



This mode can be used for fax, but is not recommended for modem transmission. Instead, use the Bypass (see [Fax and Modem Bypass Mode](#) on page 280) or Transparent with Events modes (see [Fax and Modem Transparent with Events Mode](#) on page 283) for modem.

### RFC 2833 ANS Report upon Fax and Modem Detection

The device (terminator gateway) sends RFC 2833 ANS/ANSam events upon detection of fax and/or modem answer tones (i.e., CED tone). This causes the originator to switch to fax/modem. The parameter is applicable only when the fax or modem transport type is set to bypass, Transparent-with-Events, V.152 VBD, or G.711 transport. When the device is located on the originator side, it ignores these RFC 2833 events.

#### ➤ To configure RFC 2833 ANS Report upon fax/modem detection:

1. Open the Gateway General Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Gateway General Settings**), and then from the 'Fax Signaling Method' drop-down list (IsFaxUsed), select **No Fax** or **Fax Fallback**.
2. On the Fax/Modem/CID Settings page, do the following:
  - Configure the 'Fax Transport Mode' parameter to **Bypass** [FaxTransportMode = 2].
  - Configure the 'V.xx Modem Transport Type' parameters to **Enable Bypass** [VxxModemTransportType = 2].
3. Configure the [FaxModemNTEMode] parameter to [1] (enables this feature).

### V.34 Fax Support

V.34 fax machines can transmit data over IP to the remote side using various methods. The device supports the following modes for transporting V.34 fax data over IP:

- T.38 Version 3 - V.34 fax relay mode
- Bypass mechanism for V.34 fax transmission (see [Bypass Mechanism for V.34 Fax Transmission](#) on the next page)
- T.38 Version 0 relay mode, i.e., fallback to T.38 (see [Relay Mode for T.30 and V.34 Faxes](#) on page 287)

To configure whether to pass V.34 over T.38 fax relay, or use Bypass over the High Bit Rate coder (e.g. PCM A-Law), use the 'V.34 Fax Transport Type' parameter (V34FaxTransportType).

You can use the 'SIP T.38 Version' parameter (SIPT38Version) to configure:

- Pass V.34 over T.38 fax relay using bit rates of up to 33,600 bps ('SIP T.38 Version' is set to Version 3).
- Use Fax-over-T.38 fallback to T.30, using up to 14,400 bps ('SIP T.38 Version' is set to Version 0).



- Interworking of T.38 Version 3 is supported only for Gateway calls. For SBC calls, the device forwards T.38 Version 3 transparently (as is) to the other leg (no transcoding).
- The CNG detector is disabled in all the subsequent examples. To disable the CNG detector, set the 'CNG Detector Mode' parameter (CNGDetectorMode) to **Disable**.

### Bypass Mechanism for V.34 Fax Transmission

In this proprietary scenario, the device uses bypass (or NSE) mode to transmit V.34 faxes, enabling the full utilization of its speed.

#### ➤ To use bypass mode for T.30 and V.34 faxes:

1. On the Fax/Modem/CID Settings page, do the following:
  - Set the 'Fax Transport Mode' parameter to **Bypass** [FaxTransportMode = 2].
  - Set the 'V.22 Modem Transport Type' parameter to **Enable Bypass** [V22ModemTransportType = 2].
  - Set the 'V.23 Modem Transport Type' parameter to **Enable Bypass** [V23ModemTransportType = 2].
  - Set the 'V.32 Modem Transport Type' parameter to **Enable Bypass** [V32ModemTransportType = 2].
  - Set the 'V.34 Modem Transport Type' parameter to **Enable Bypass** [V34ModemTransportType = 2].
2. Configure the [V34FaxTransportType] parameter to [2] (Bypass).

#### ➤ To use bypass mode for V.34 faxes, and T.38 for T.30 faxes:

1. On the Fax/Modem/CID Settings page, do the following:
  - Set the 'Fax Transport Mode' parameter to **T.38 Relay** [FaxTransportMode = 1].
  - Set the 'V.22 Modem Transport Type' parameter to **Enable Bypass** [V22ModemTransportType = 2].
  - Set the 'V.23 Modem Transport Type' parameter to **Enable Bypass** [V23ModemTransportType = 2].
  - Set the 'V.32 Modem Transport Type' parameter to **Enable Bypass** [V32ModemTransportType = 2].
  - Set the 'V.34 Modem Transport Type' parameter to **Enable Bypass** [V34ModemTransportType = 2].
2. Configure the [V34FaxTransportType] parameter to [2] (Bypass).

## Relay Mode for T.30 and V.34 Faxes

In this scenario, V.34 fax machines are forced to use their backward compatibility with T.30 faxes and operate in the slower T.30 mode.

### ➤ To use T.38 mode for V.34 and T.30 faxes:

1. On the Fax/Modem/CID Settings page, do the following:
  - Set the 'Fax Transport Mode' parameter to **T.38 Relay** (FaxTransportMode = 1).
  - Set the 'V.22 Modem Transport Type' parameter to **Disable** (V22ModemTransportType = 0).
  - Set the 'V.23 Modem Transport Type' parameter to **Disable** (V23ModemTransportType = 0).
  - Set the 'V.32 Modem Transport Type' parameter to **Disable** (V32ModemTransportType = 0).
  - Set the 'V.34 Modem Transport Type' parameter to **Disable** (V34ModemTransportType = 0).
2. Configure the [V34FaxTransportType] parameter to [1] (Relay).

### ➤ To allow V.34 fax relay over T.38:

- Set the 'SIP T.38 Version' parameter to Version 3 (SIPT38Version = 3).

### ➤ To force V.34 fax machines to use their backward compatibility with T.30 faxes and operate in the slower T.30 mode:

- Set the 'SIP T.38 Version' parameter to Version 0 (SIPT38Version = 0).



Interworking of T.38 Version 3 is supported only for Gateway calls. For SBC calls, the device forwards T.38 Version 3 transparently (as is) to the other leg (i.e., no transcoding).

## V.34 Fax Relay for SG3 Fax Machines

Super Group 3 (SG3) is a standard for fax machines that support speeds of up to 33.6 kbps through V.34 half duplex (HD) modulation. The following procedure describes how to configure V.34 (SG3) fax relay support based on ITU Specification T.38 Version 3.

### ➤ To enable support for V.34 fax relay (T.38) at SG3 speed:

1. In the IP Profiles table (see [Configuring IP Profiles](#) on page 664), add an IP Profile with the 'Fax Signaling Method' parameter configured to **T.38 Relay**.

2. In the Coders Groups table (see [Configuring Coders Groups](#) on page 651) set the coder used by the device to G.729 (or any other supported codec).
3. On the Fax/Modem/CID Settings page, do the following settings:
  - 'SIP T.38 Version' to **Version 3** (SIPT38Version = 3).
  - 'Fax Relay Max Rate' (RelayMaxRate) to **33,600bps** (default).
  - 'CNG Detector Mode' (CNGDetectorMode) to **Disable** (default).
  - 'V.21 Modem Transport Type' to **Disable** (V21ModemTransportType = 0).
  - 'V.22 Modem Transport Type' to **Disable** (V22ModemTransportType = 0).
  - 'V.23 Modem Transport Type' to **Disable** (V23ModemTransportType = 0).
  - 'V.32 Modem Transport Type' to **Disable** (V32ModemTransportType = 0).
  - 'V.34 Modem Transport Type' to **Disable** (V34ModemTransportType = 0).
  - 'CED Transfer Mode' to Fax Relay or VBD (CEDTransferMode = 0).
4. Set the ini file parameter, V34FaxTransportType to 1 (i.e., relay).
5. Set the ini file parameter, T38MaxDatagramSize to 560 (default).



- The T.38 negotiation should be completed at call start according to V.152 procedure (as shown in the INVITE example below).
- T.38 mid-call Re-INVITEs are supported.
- If the remote party supports only T.38 Version 0, the device "downgrades" the T.38 Version 3 to T.38 Version 0.

For example, the device sends or receives the following INVITE message, negotiating both audio and image media:

```
INVITE sip:2001@10.8.211.250;user=phone SIP/2.0
Via: SIP/2.0/UDP 10.8.6.55;branch=z9hG4bKac1938966220
Max-Forwards: 70
From: <sip:318@10.8.6.55>;tag=1c1938956155
To: <sip:2001@10.8.211.250;user=phone>
Call-ID: 193895529241200022331@10.8.6.55
CSeq: 1 INVITE
Contact: <sip:318@10.8.6.55:5060>
Supported: em,100rel,timer,replaces,path,resource-priority,sdp-anat
Allow:
REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
Remote-Party-ID:
<sip:318@10.8.211.250>;party=calling;privacy=off;screen=no;screen-ind=0;npi=1;ton=0
Remote-Party-ID: <sip:2001@10.8.211.250>;party=called;npi=1;ton=0
```



```
User-Agent: AudioCodes-Sip-Gateway-/7.60A.100.022
Content-Type: application/sdp
Content-Length: 433
```

```
v=0
o=AudioCodesGW 1938931006 1938930708 IN IP4 10.8.6.55
s=Phone-Call
c=IN IP4 10.8.6.55
t=0 0
m=audio 6010 RTP/AVP 18 97
a=rtpmap:18 G729/8000
a=fmtp:18 annexb=no
a=rtpmap:97 telephone-event/8000
a=fmtp:97 0-15
a=ptime:20
a=sendrecv
m=image 6012 udptl t38
a=T38FaxVersion:3
a=T38MaxBitRate:33600
a=T38FaxMaxBuffer:1024
a=T38FaxMaxDatagram:122
a=T38FaxRateManagement:transferredTCF
a=T38FaxUdpEC:t38UDPRedundancy
```

## V.152 Support

The device supports the ITU-T recommendation V.152 (Procedures for Supporting Voice-Band Data over IP Networks). Voice-band data (VBD) is the transport of modem, facsimile, and text telephony signals over a voice channel of a packet network with a codec appropriate for such signals.

For V.152 capability, the device supports T.38 as well as VBD codecs (i.e., G.711 A-law and G.711  $\mu$ -law). The selection of capabilities is performed using the Coders Groups table (see [Configuring Coders Groups](#) on page 651).

When in VBD mode for V.152 implementation, support is negotiated between the device and the remote endpoint at the establishment of the call. During this time, initial exchange of call capabilities is exchanged in the outgoing SDP. These capabilities include whether VBD is supported and associated RTP payload types ('gpmd' SDP attribute), supported codecs, and packetization periods for all codec payload types ('ptime' SDP attribute). After this initial negotiation, no Re-INVITE messages are necessary as both endpoints are synchronized in terms of the other side's capabilities. If negotiation fails (i.e., no match was achieved for any of the transport capabilities), fallback to existing logic occurs (according to the parameter `IsFaxUsed`).

Below is an example of media descriptions of an SDP indicating support for V.152. In the example, V.152 implementation is supported (using the dynamic payload type 96 and G.711 u-law as the VBD codec) as well as the voice codecs G.711  $\mu$ -law and G.729.

```
v=0
o=- 0 0 IN IPV4 <IPAddressA>
s=-
t=0 0
p=+1
c=IN IP4 <IPAddressA>
m=audio <udpPort A> RTP/AVP 18 0
a=ptime:10
a=rtpmap:96 PCMU/8000
a=gpmid: 96 vbd=yes
```

Instead of using VBD transport mode, the V.152 implementation can use alternative relay fax transport methods (e.g., fax relay over IP using T.38). The preferred V.152 transport method is indicated by the SDP 'pmft' attribute. Omission of this attribute in the SDP content means that VBD mode is the preferred transport mechanism for voice-band data.

## RTP and RTCP Settings

This section describes configuration relating to Real-Time Transport Protocol (RTP) and RTP Control Protocol (RTCP).

### Configuring the Dynamic Jitter Buffer

Voice frames are transmitted at a fixed rate. If the frames arrive at the other end at the same rate, voice quality is perceived as good. However, some frames may arrive slightly faster or slower than the other frames. This is called jitter (delay variation) and degrades the perceived voice quality. To minimize this problem, the device uses a jitter buffer. The jitter buffer collects voice packets, stores them and sends them to the voice processor in evenly spaced intervals.

The device uses a dynamic jitter buffer that can be configured with the following:

- **Minimum delay:** Defines the starting jitter capacity of the buffer. For example, at 0 msec, there is no buffering at the start. At the default level of 10 msec, the device always buffers incoming packets by at least 10 msec worth of voice frames.
- **Optimization Factor:** Defines how the jitter buffer tracks to changing network conditions. When set at its maximum value of 12, the dynamic buffer aggressively tracks changes in delay (based on packet loss statistics) to increase the size of the buffer and doesn't decay back down. This results in the best packet error performance, but at the cost of extra delay. At the minimum value of 0, the buffer tracks delays only to compensate for clock drift and quickly decays back to the minimum level. This optimizes the delay performance but at the expense of a higher error rate.

The default settings of 10 msec Minimum delay and 10 Optimization Factor should provide a good compromise between delay and error rate. The jitter buffer 'holds' incoming packets for 10 msec before making them available for decoding into voice. The coder polls frames from the buffer at regular intervals in order to produce continuous speech. As long as delays in the network do not change (jitter) by more than 10 msec from one packet to the next, there is always a sample in the buffer for the coder to use. If there is more than 10 msec of delay at any time during the call, the packet arrives too late. The coder tries to access a frame and is not able to find one. The coder must produce a voice sample even if a frame is not available. It therefore compensates for the missing packet by adding a Bad-Frame-Interpolation (BFI) packet. This loss is then flagged as the buffer being too small. The dynamic algorithm then causes the size of the buffer to increase for the next voice session. The size of the buffer may decrease again if the device notices that the buffer is not filling up as much as expected. At no time does the buffer decrease to less than the minimum size configured by the Minimum delay parameter.

In certain scenarios, the **Optimization Factor is set to 13**: One of the purposes of the Jitter Buffer mechanism is to compensate for clock drift. If the two sides of the VoIP call are not synchronized to the same clock source, one RTP source generates packets at a lower rate, causing under-runs at the remote Jitter Buffer. In normal operation (optimization factor 0 to 12), the Jitter Buffer mechanism detects and compensates for the clock drift by occasionally dropping a voice packet or by adding a BFI packet.

Fax and modem devices are sensitive to small packet losses or to added BFI packets. Therefore, to achieve better performance during modem and fax calls, the Optimization Factor should be set to 13. In this special mode the clock drift correction is performed less frequently - only when the Jitter Buffer is completely empty or completely full. When such condition occurs, the correction is performed by dropping several voice packets simultaneously or by adding several BFI packets simultaneously, so that the Jitter Buffer returns to its normal condition.

The following procedure describes how to configure the jitter buffer using the Web interface.

➤ **To configure jitter buffer using the Web interface:**

1. Open the RTP/RTCP Settings page (**Setup** menu > **Signaling & Media** menu > **Media** folder > **RTP/RTCP Settings**). The relevant parameters are listed under the General group, as shown below:

Dynamic Jitter Buffer Minimum Delay	<input type="text" value="10"/>
Dynamic Jitter Buffer Optimization Factor	<input type="text" value="10"/>

2. Set the 'Dynamic Jitter Buffer Minimum Delay' parameter (DJBufMinDelay) to the minimum delay (in msec) for the Dynamic Jitter Buffer.
3. Set the 'Dynamic Jitter Buffer Optimization Factor' parameter (DJBufOptFactor) to the Dynamic Jitter Buffer frame error/delay optimization factor.
4. Click **Apply**.

## Enabling Comfort Noise Generation

The device can generate artificial background noise, known as *comfort noise*, in the voice channel during periods of silence when no one on the call is speaking. This feature helps reassure participants that the call remains connected, preventing the perception of sudden disconnections.

The device detects silence using its Voice Activity Detection (VAD) mechanism. When Comfort Noise Generation is enabled and silence is detected, the device transmits Silence Identifier Descriptors (SIDs), which allow the receiving side to reproduce local background noise.

The Comfort Noise Generation functionality also depends on the Silence Suppression (SCE) setting of the voice codec (G.711 or G.726) used in the voice channel. Voice coders are configured in the Coders Groups table (see [Configuring Coders Groups](#) on page 651).

The use of comfort noise is indicated by including a payload type for CN on the media ('m=') description line in the SDP. The device can use CN with a codec whose RTP time stamp clock rate is 8,000 Hz (G.711 / G.726). The static payload type 13 is used.

CN is negotiated between the call parties. If the remote side doesn't support CN, it's not used. Regardless of the device's settings, the device always attempts to adapt to the remote side's request for Comfort Noise Generation.

If you enable Comfort Noise Generation (see below procedure), the following occurs:

- If the device is the initiator, it sends a 'CN' in the SDP only if the SCE of the codec is enabled. If the remote UA responds with a 'CN' in the SDP, then CNG occurs; otherwise, CNG doesn't occur.
- If the device is the receiver and the remote SIP UA doesn't send a 'CN' in the SDP, then no CNG occurs. If the remote side sends a 'CN', the device attempts to be compatible with the remote side and even if the codec's SCE is disabled, CNG occurs.

If you disable Comfort Noise Generation, the device doesn't send 'CN' in the SDP. However, if the codec's SCE is enabled, the device performs Comfort Noise Generation.



This feature is applicable only to the Gateway application.

### ➤ To enable Comfort Noise Generation:

1. Open the RTP/RTCP Settings page (**Setup** menu > **Signaling & Media** menu > **Media** folder > **RTP/RTCP Settings**).
2. Select the 'Comfort Noise Generation Negotiation' check box (ComfortNoiseNegotiation):

Comfort Noise Generation Negotiation ☒

3. Click **Apply**.

## Configuring DTMF Transport Types

The device supports various methods for transporting DTMF digits over the IP network to the remote endpoint for Gateway calls.



This feature is applicable only to the Gateway application.

The methods and their configuration can be configured on the DTMF & Dialing page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **DTMF & Supplementary** > **DTMF & Dialing**):

Declare RFC 2833 in SDP	Yes
1st Tx DTMF Option	
2nd Tx DTMF Option	
RFC 2833 Payload Type	96

- **Using INFO message according to Nortel IETF draft:** DTMF digits are sent to the remote side in INFO messages. To enable the mode:

- Configure the 'Declare RFC 2833 in SDP' parameter to **No** (RxDTMFOption = 0).
- Configure the 'First Tx DTMF Option' parameter to **INFO Nortel** (FirstTxDTMFOption = 1).



DTMF digits are removed from the audio stream (and the 'DTMF Transport Type' parameter is automatically set to **Mute DTMF**).

- **Using INFO message according to Cisco's mode:** DTMF digits are sent to the remote side in INFO messages. To enable the mode:

- Configure the 'Declare RFC 2833 in SDP' parameter to **No** (RxDTMFOption = 0).
- Configure the 'First Tx DTMF Option' parameter to **INFO Cisco** (FirstTxDTMFOption = 3).



DTMF digits are removed from the audio stream (and the 'DTMF Transport Type' parameter is automatically set to **Mute DTMF**).

- **Using NOTIFY messages according to IETF Internet-Draft draft-mahy-sipping-signaled-digits-01:** DTMF digits are sent to the remote side using NOTIFY messages. To enable the mode:

- Configure the 'Declare RFC 2833 in SDP' parameter to **No** (RxDTMFOption = 0).
- Configure the 'First Tx DTMF Option' parameter to **NOTIFY** (FirstTxDTMFOption = 2).



DTMF digits are removed from the audio stream (and the 'DTMF Transport Type' parameter is automatically set to **Mute DTMF**).

- **Using RFC 2833 relay with Payload type negotiation:** DTMF digits are sent to the remote side as part of the RTP stream according to RFC 2833. To enable the mode:

- a. Configure the 'Declare RFC 2833 in SDP' parameter to **Yes** (RxDTMFOption = 3).
- b. Configure the 'First Tx DTMF Option' parameter to **RFC 2833** (FirstTxDTMFOption = 4).



To set the RFC 2833 payload type with a value other than its default, use the RFC2833PayloadType parameter. The device negotiates the RFC 2833 payload type using local and remote SDP and sends packets using the payload type from the received SDP. The device expects to receive RFC 2833 packets with the same payload type as configured by the parameter. If the remote side doesn't include 'telephony-event' in its SDP, the device sends DTMF digits in transparent mode (as part of the voice stream).

- **Sending DTMF digits (in RTP packets) as part of the audio stream (DTMF Relay is disabled):** This method is typically used with G.711 coders. With other low-bit rate (LBR) coders, the quality of the DTMF digits is reduced. To enable the mode:
  - a. Configure the 'Declare RFC 2833 in SDP' parameter to **No** (RxDTMFOption = 0).
  - b. Configure the 'First Tx DTMF Option' parameter to **Not Supported** (FirstTxDTMFOption = 0).
  - c. Configure the ini file parameter [DTMFTransportType] to [2] (i.e., transparent).
- **Using INFO message according to Korea mode:** DTMF digits are sent to the remote side in INFO messages. To enable this mode:
  - a. Configure the 'Declare RFC 2833 in SDP' parameter to **No** (RxDTMFOption = 0).
  - b. Configure the 'First Tx DTMF Option' parameter to **INFO Cisco** (FirstTxDTMFOption = 3).



DTMF digits are removed from the audio stream (and the 'DTMF Transport Type' parameter is automatically set to **Mute DTMF**).



- The device is always ready to receive DTMF packets over IP in all possible transport modes: INFO messages, NOTIFY, and RFC 2833 (in proper payload type) or as part of the audio stream.
- To exclude RFC 2833 Telephony event parameter from the device's SDP, configure the 'Declare RFC 2833 in SDP' parameter to **No**.
- You can use the following parameters to configure DTMF digit handling:
  - ✓ [FirstTxDTMFOption], [SecondTxDTMFOption], [RxDTMFOption], [RFC2833TxPayloadType], and [RFC2833RxPayloadType]
  - ✓ [MGCPDTMFDetectionPoint], [DTMFVolume], [DTMFTransportType], [DTMFDigitLength], and [DTMFInterDigitInterval]

## Configuring RFC 2833 Payload

You can configure the RFC 2833 payload.

### ➤ To configure RFC 2833 payload:

1. Open the RTP/RTCP Settings page (**Setup** menu > **Signaling & Media** tab > **Media** folder > **RTP/RTCP Settings**).
2. Configure the following parameters:
  - 'RTP Redundancy Depth' (RTPRedundancyDepth) - enables the device to generate RFC 2198 redundant packets.
  - **For Gateway application only:** 'Enable RTP Redundancy Negotiation' (EnableRTPRedundancyNegotiation) - enables the device to include the RTP redundancy dynamic payload type in the SDP, according to RFC 2198.
  - 'RFC 2833 TX Payload Type' (RFC2833TxPayloadType) - defines the Tx RFC 2833 DTMF relay dynamic payload type.
  - 'RFC 2833 RX Payload Type' (RFC2833RxPayloadType) - defines the Rx RFC 2833 DTMF relay dynamic payload type.
  - 'RFC 2198 Payload Type' (RFC2198PayloadType) - defines the RTP redundancy packet payload type according to RFC 2198.
3. Click **Apply**.

## Configuring RTP Base UDP Port

You can configure the range (pool) of local UDP ports from which the device allocates ports to media (RTP, RTCP, and T.38) channels (legs). The range limit of UDP ports is from 6,000 through to 65,535.

The consecutive port offset from the RTP port for RTCP and T.38 traffic is one and two, respectively (i.e., RTCP port = RTP port + 1; T.38 port = RTP port + 2). For example, if the voice session uses RTP port 6000, the device allocates port 6001 for RTCP and port 6002 for T.38.

However, you can configure the device to use the same port for RTP and T.38 packets, by configuring the [T38UseRTPPort] parameter to 1.

Within the port range, the device allocates the UDP ports per media channel (leg) in "jumps" (spacing) of 2 (see below note), 4, 5, or 10, which is configured by the [UdpPortSpacing] parameter. For example, if the port range starts at 6000 and the UDP port spacing is 10, the available ports are 6000, 6010, 6020, 6030, and so on. Within the port range, the device assigns these ports **randomly** to the different media channels. For example, it allocates port 6000 to leg 1, port 6030 to leg 2, and port 6010 to leg 3.



For UDP port spacing of 2, you must configure the device to use the same port for RTP and T.38, by configuring the [T38UseRTPPort] ini file parameter to 1. In this case, if for example the UDP port range starts at 6000 and the port spacing is 2, the available ports are 6000 (port 6000 for RTP/T.38 and port 6001 for RTCP), 6002 (port 6002 for RTP/T.38 and port 6003 for RTCP), 6004 (port 6004 for RTP/T.38 and port 6005 for RTCP), and so on.

You can configure the starting port (lower boundary) of the port range (default is 6000), using the 'RTP Base UDP Port' [BaseUDPPort] parameter. Once configured, the port range is according to the following equation:

<'RTP Base UDP Port' parameter value> to 65,535

For example: If you configure the 'RTP Base UDP Port' parameter to 6000, the port range is 6000 to 65,535.

You can also configure specific port ranges for specific SIP user agents (UAs), using Media Realms (see [Configuring Media Realms](#) on page 539). You can configure each Media Realm with a different UDP port range and then assign the Media Realm to a specific IP Group, for example. However, the port range of the Media Realm **must be within the range** configured by the 'RTP Base UDP Port' parameter.

The following procedure describes how to configure the RTP base UDP port through the Web interface.

➤ **To configure the RTP base UDP port:**

1. Open the RTP/RTCP Settings page (**Setup** menu > **Signaling & Media** tab > **Media** folder > **RTP/RTCP Settings**).
2. In the 'RTP Base UDP Port' field, configure the lower boundary of the UDP port range.

RTP Base UDP Port



3. Click **Apply**, and then restart the device with a save-to-flash for your settings to take effect.





- The RTP port must be different from ports configured for SIP signaling traffic (i.e., ports configured for SIP Interfaces). For example, if the RTP port range is 6000 to 6999, the SIP port must either be less than 6000 or greater than 6999.

## Event Detection and Notification using X-Detect Header

The device can detect certain events in the media stream and notify of their detection to a remote application server, using the SIP X-Detect header. The request for event notification is done by the application server when establishing a SIP dialog (i.e., INVITE message) or during an already established call using a re-INVITE message. The device can detect the following event types:

- **Answering Machine Detection (AMD):** Detects events that are related to the AMD feature. AMD detects whether an answering machine or live voice has answered the call. It can also be used to detect silence, or the beep sound played by an answering machine to indicate the end of the greeting message after which a voice message can be left. For more information on AMD, see [Answering Machine Detection \(AMD\)](#) on page 304.
- **Call Progress Tone (CPT):** Detects whether a specific tone, defined in the installed CPT file is received from the call. It can be used to detect the beep sound played by an answering machine (as mentioned above), Special Information Tones (SIT) which indicate call failure with a recorded announcement describing the call failure (Gateway application only), and the busy, reorder and ring tones.
- **Fax/modem machine (Gateway application only):** Detects whether a fax has answered the call (preamble, CED, CNG, and modem).
- **PTT (Gateway application only):** Detects the start and end of voice.



- Currently, PTT is supported only for Gateway calls.
- Fax and SIT event detection is applicable only to Gateway calls.
- Event detection on SBC calls for CPT is supported only for calls using the G.711 coder.

The X-Detect header is used for event detection as follows:

- X-Detect header in the INVITE message received from the application server requesting a specific event detection:

X-Detect: Request=[event type to detect]

- X-Detect header in the SIP response message -- SIP 183 (for early dialogs) or 200 OK (for confirmed dialogs) -- sent by the device to the application server specifying which of the requested events it can detect (absence of the X-Detect header indicates that the device cannot detect any of the events):

X-Detect: Response=[supported event types]

- Each time the device detects the supported event, it sends an INFO message to the remote party with the following message body:

Content-Type: Application/X-Detect  
 Type = [event type]  
 Subtype = [subtype of each event type]

The table below lists the event types and subtypes that can be detected by the device. The text shown in the table are the strings used in the X-Detect header. The table also provides a summary of the required configuration.

For SBC calls, event detection is enabled using the IP Profile parameter 'Handle X-Detect' (see [Configuring IP Profiles](#) on page 664).

**Table 15-1: Supported X-Detect Event Types**

Event Type	Subtype	Description and Required Configuration
AMD	<ul style="list-style-type: none"> <li>■ Voice (live voice)</li> <li>■ Automata (answering machine)</li> <li>■ Silence (no voice)</li> <li>■ Unknown</li> <li>■ Beep (greeting message of answering machine)</li> </ul>	Event detection using the AMD feature. For more information, see <a href="#">Answering Machine Detection (AMD)</a> on page 304.
CPT	<ul style="list-style-type: none"> <li>■ SIT-NC</li> <li>■ SIT-IC</li> <li>■ SIT-VC</li> <li>■ SIT-RO</li> <li>■ Busy</li> <li>■ Reorder</li> <li>■ Ringtone</li> <li>■ Beep (greeting</li> </ul>	<p>Event detection of tones using the CPT file.</p> <ol style="list-style-type: none"> <li>1. Create a CPT file with the required tone types of the events that you want to detect.</li> <li>2. Install the CPT file on the device.</li> <li>3. For SIT detection:               <ul style="list-style-type: none"> <li>✓ Set the SITDetectorEnable parameter to 1.</li> <li>✓ Set the UserDefinedToneDetectorEnable parameter to 1.</li> </ul> </li> </ol>

Event Type	Subtype	Description and Required Configuration
	message of answering message)	<b>Note:</b> <ul style="list-style-type: none"> <li>■ For more information on SIT detection, see <a href="#">SIT Event Detection</a> below.</li> <li>■ To configure beep detection, see <a href="#">Detecting Answering Machine Beeps</a> on page 301.</li> </ul>
FAX	CED	<ul style="list-style-type: none"> <li>■ Set the IsFaxUsed parameter to any value other than 0.</li> <li>- or -</li> <li>■ Set the IsFaxUsed parameter to 0 and the FaxTransportMode parameter to any value other than 0.</li> </ul> <b>Note:</b> Applicable only to the Gateway application.
	modem	Set the VxxModemTransportType parameter to 3. <b>Note:</b> Applicable only to the Gateway application.
PTT	<ul style="list-style-type: none"> <li>■ voice-start</li> <li>■ voice-end</li> </ul>	Set the EnableDSIPMDetectors parameter to 1.

## SIT Event Detection

The device can detect and report the following Special Information Tones (SIT) types from the PSTN:

- SIT-NC (No Circuit found)
- SIT-IC (Operator Intercept)
- SIT-VC (Vacant Circuit - non-registered number)
- SIT-RO (Reorder - System Busy)

There are additional three SIT tones that are detected as one of the above SIT tones:

- The NC\* SIT tone is detected as NC
- The RO\* SIT tone is detected as RO
- The IO\* SIT tone is detected as VC

The device can map these SIT tones to a Q.850 cause and then map them to SIP 5xx/4xx responses, using the parameters SITQ850Cause, SITQ850CauseForNC, SITQ850CauseForIC, SITQ850CauseForVC, and SITQ850CauseForRO.



This feature is applicable only to the Gateway application.

**Table 15-2: SIT Reported by the Device**

Special Information Tones (SITs) Name	Description	First Tone Frequency Duration		Second Tone Frequency Duration		Third Tone Frequency Duration	
		(Hz)	(ms)	(Hz)	(ms)	(Hz)	(ms)
NC1	No circuit found	985.2	380	1428.5	380	1776.7	380
IC	Operator intercept	913.8	274	1370.6	274	1776.7	380
VC	Vacant circuit (non registered number)	985.2	380	1370.6	274	1776.7	380
RO1	Reorder (system busy)	913.8	274	1428.5	380	1776.7	380
NC*	-	913.8	380	1370.6	380	1776.7	380
RO*	-	985.2	274	1370.6	380	1776.7	380
IO*	-	913.8	380	1428.5	274	1776.7	380

The following example shows a SIP INFO message sent by the device to a remote application server notifying it that SIT detection has been detected:

```
INFO sip:5001@10.33.2.36 SIP/2.0
Via: SIP/2.0/UDP 10.33.45.65;branch=z9hG4bKac2042168670
Max-Forwards: 70
From: <sip:5000@10.33.45.65;user=phone>;tag=1c1915542705
To: <sip:5001@10.33.2.36;user=phone>;tag=WQJNIDDPCKAPIDSCOTG
Call-ID: AIFHPETLLMVFWPDXUHD@10.33.2.36
CSeq: 1 INFO
Contact: <sip:2206@10.33.45.65>
Supported: em,timer,replaces,path,resource-priority
Content-Type: application/x-detect
Content-Length: 28
```

```
Type= CPT
SubType= SIT-IC
```

## Detecting Answering Machine Beeps

The device can detect the "beep" sound played by an answering machine that indicates the end of the answering machine's greeting message. This is useful in that the device can then notify, for example, a third-party, application server that it can now leave a voice message on the answering machine. The device supports the following methods for detecting and reporting beeps:

- **AMD-based Detection:** The device uses its beep detector that is integrated in the AMD feature. You can configure the beep detection timeout and beep detection sensitivity level (for more information, see [Configuring AMD](#) on page 308). To enable the AMD beep detection, the received INVITE message must contain an X-Detect header with the value "Request=AMD",

```
X-Detect: Request=AMD
```

and the [AMDBeepDetectionMode] parameter must be configured to [1] or [2]. If configured to [1], the beep is detected only after the answering machine is detected. If configured to [2], the beep is detected even if the answering machine was not detected.

- **Tone-based Detection (Call Progress Tone):** The device detects the beep according to a call progress tone (CPT). This is enabled if the device receives a specific beep tone (Tone Type #46) that is also defined in the installed CPT file and the received INVITE message contains an X-Detect header with the value "Request=CPT":

```
X-Detect: Request=CPT
```

For more information on the CPT file, see [Call Progress Tones File](#) on page 1224.

The device reports beep detections to application servers, by sending a SIP INFO message that contains a body with one of the following values, depending on the method used for detecting the beep:

- **AMD-detected Beep:**

```
Type= AMD
SubType= Beep
```

- **CPT-detected Beep:**

```
Type= CPT
SubType=Beep
```

## SIP Call Flow Examples of Event Detection and Notification

Two SIP call flow examples are provided below of event detection and notification:

- **Example 1:** This example shows a SIP call flow of the device's AMD and event detection feature, whereby the device detects an answering machine and the subsequent start and end of the greeting message, enabling the third-party application server to know when to play a recorded voice message to an answering machine:

- a. Upon detection of the answering machine, the device sends the following SIP INFO message to the application server:

```
INFO sip:sipp@172.22.2.9:5060 SIP/2.0
Via: SIP/2.0/UDP 172.22.168.249;branch=z9hG4bKac1566945480
Max-Forwards: 70
From: sut <sip:3000@172.22.168.249:5060>;tag=1c1505895240
To: sipp <sip:sipp@172.22.2.9:5060>;tag=1
Call-ID: 1-29758@172.22.2.9
CSeq: 1 INFO
Contact: <sip:56700@172.22.168.249>
Supported: em,timer,replaces,path,resource-priority
Allow:
REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REF
ER,INFO,SUBSCRIBE,UPDATE
User-Agent: AudioCodes-Sip-Gateway/7.60A.100.022
Content-Type: application/x-detect
Content-Length: 30
Type= AMD
SubType= AUTOMATA
```

- b. Upon detection of the start of voice (i.e., the greeting message of the answering machine), the device sends the following INFO message to the application server:

```
INFO sip:sipp@172.22.2.9:5060 SIP/2.0
Via: SIP/2.0/UDP 172.22.168.249;branch=z9hG4bKac482466515
Max-Forwards: 70
From: sut <sip:3000@172.22.168.249:5060>;tag=1c419779142
To: sipp <sip:sipp@172.22.2.9:5060>;tag=1
Call-ID: 1-29753@172.22.2.9
CSeq: 1 INFO
Contact: <sip:56700@172.22.168.249>
Supported: em,timer,replaces,path,resource-priority
Allow:
REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REF
ER,INFO,SUBSCRIBE,UPDATE
User-Agent: AudioCodes-Sip-Gateway/7.60A.100.022
```

```
Content-Type: application/x-detect
Content-Length: 34
Type= PTT
SubType= SPEECH-START
```

- c. Upon detection of the end of voice (i.e., end of the greeting message of the answering machine), the device sends the following INFO message to the application server:

```
INFO sip:sipp@172.22.2.9:5060 SIP/2.0
Via: SIP/2.0/UDP 172.22.168.249;branch=z9hG4bKac482466515
Max-Forwards: 70
From: sut <sip:3000@172.22.168.249:5060>;tag=1c419779142
To: sipp <sip:sipp@172.22.2.9:5060>;tag=1
Call-ID: 1-29753@172.22.2.9
CSeq: 1 INFO
Contact: <sip:56700@172.22.168.249>
Supported: em,timer,replaces,path,resource-priority
Allow:
REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REF
ER,INFO,SUBSCRIBE,UPDATE
User-Agent: AudioCodes-Sip-Gateway/7.60A.100.022
Content-Type: application/x-detect
Content-Length: 34
Type= PTT
SubType= SPEECH-END
```

- d. The application server sends its message to leave on the answering message.

■ **Example 2:** This example shows a SIP call flow for event detection and notification of the beep of an answering machine:

- a. The device receives a SIP message containing the X-Detect header from the remote application requesting beep detection:

```
INVITE sip:101@10.33.2.53;user=phone SIP/2.0
Via: SIP/2.0/UDP 10.33.2.53;branch=z9hG4bKac5906
Max-Forwards: 70
From: "anonymous" <sip:anonymous@anonymous.invalid>;tag=1c25298
To: <sip:101@10.33.2.53;user=phone>
Call-ID: 11923@10.33.2.53
CSeq: 1 INVITE
Contact: <sip:100@10.33.2.53>
X-Detect: Request=AMD,CPT
```

- b. The device sends a SIP response message to the remote party, listing the events in the X-Detect header that it can detect:

```
SIP/2.0 200 OK
Via: SIP/2.0/UDP 10.33.2.53;branch=z9hG4bKac5906
From: "anonymous" <sip:anonymous@anonymous.invalid>;tag=1c25298
To: <sip:101@10.33.2.53;user=phone>;tag=1c19282
Call-ID: 11923@10.33.2.53
CSeq: 1 INVITE
Contact: <sip:101@10.33.2.53>
X-Detect: Response=AMD,CPT
```

- c. The device detects the beep of an answering machine and sends an INFO message to the remote party:

```
INFO sip:101@10.33.2.53;user=phone SIP/2.0
Via: SIP/2.0/UDP 10.33.2.53;branch=z9hG4bKac5906
Max-Forwards: 70
From: "anonymous" <sip:anonymous@anonymous.invalid>;tag=1c25298
To: <sip:101@10.33.2.53;user=phone>
Call-ID: 11923@10.33.2.53
CSeq: 1 INVITE
Contact: <sip:100@10.33.2.53>
X-Detect: Response=AMD,CPT
Content-Type: Application/X-Detect
Content-Length: xxx
Type = CPT
Subtype = Beep
```

## Answering Machine Detection (AMD)

The device's Answering Machine Detection (AMD) feature can detect if an outbound call has been answered by a human (including fax) or an answering machine. It analyzes the sound patterns (speech) received during the initial seconds of the call to determine what answered the call. Typically, when a human answers, there is a brief "hello" followed by silence, waiting for the other party's response. In contrast, when an answering machine answers the call, there is constant speech (i.e., answering message) followed by a beep, indicating the start of voicemail recording.

AMD is useful, for example, for outbound calling centers that implement automatic dialing applications. When the calling center establishes a call with a specific target and an answering machine is detected, the call is automatically connected to a recorded message. Once the device detects what answered the call (human or machine), it can notify a third-party application server used for automatic dialing applications. The X-Detect SIP header is used for



requesting event (live voice, answering machine, silence, or beep at the end of answering machine message) detection and notification. For more information, see [Event Detection and Notification using X-Detect Header](#) on page 297. For more information on detection of beeps at the end of an answering machine's greeting message, see [Detecting Answering Machine Beeps](#) on page 301.

For the Gateway application, you can also configure the device to disconnect IP-to-Tel calls upon detection of an answering machine on the Tel side. For more information, see [Enabling IP-to-Tel Call Disconnection upon Detection of Answering Machine](#) on page 310.

### Default AMD

By default, the device's AMD feature is based on voice detection for North American English (see note below). It uses sophisticated speech detection algorithms that are derived from hundreds of real-life recordings of answered calls by live voices and answering machines in English. The algorithms detect whether it's human or machine, based on voice and silence duration, as well as speech patterns. The algorithms of the language-based recordings are compiled into an *AMD Sensitivity* file, which is pre-installed on the device.



Because the main factor (algorithm) for determining if its human or machine is the voice pattern and silence duration, the language on which the detection algorithm is based is in most cases not important as these factors are similar across most languages. Therefore, the default, pre-installed AMD Sensitivity file, which is based on North American English should suffice for your deployment even if the device is located in a region where a language other than English is used.

However (despite note above), if you need to implement AMD in a different language or region, or if you wish to fine-tune the default AMD algorithms to suit your specific deployment, contact your AudioCodes sales representative for more information on this service. You may be required to provide AudioCodes with a database of recorded voices (calls) in the language on which the device's AMD feature can base its voice detector algorithms. The data needed for an accurate calibration should be recorded under the following guidelines:

- **Statistical accuracy:** The number of recorded calls should be as high as possible (at least 100) and varied. The calls must be made to different people. The calls must be made in the specific location in which the device's AMD feature is to operate.
- **Real-life recording:** The recordings should simulate real-life answering of a called person picking up the phone, and without the caller speaking.
- **Normal environment interferences:** The environment in which the recordings are done should simulate real-life scenarios, in other words, not sterile but not too noisy either. Interferences could include, for example, background noises of other people talking, spikes, and car noises.

Once you provide AudioCodes with your database of recordings, AudioCodes compiles it into a loadable file, which can be installed on the device. For a brief description on file format and installation, see [Uploading an AMD Sensitivity File](#) on page 1231.



The AMD Sensitivity file always includes the default Parameter Suites 0 and 1, even if customized Parameter Suites (2 to 7) are created.

The device can support up to eight AMD algorithm suites, referred to as *Parameter Suites*. Each Parameter Suite provides a range of detection sensitivity levels for detecting whether a call is answered by a human or a machine. Sensitivity levels determine how precisely (accurately) the device distinguishes between a live voice and an answering machine. A lower sensitivity level favors detection of answering machines while a higher level favors detection of live voice. In deployments where the likelihood of a call being answered by an answering machine is low, it would be advisable to configure a high sensitivity level (which is more sensitive to human than machine). This also allows you to tweak sensitivity to comply with local regulations, such as rules designed to protect consumers when answering automated calls (for example, consumer answers and hears silence).

Parameter Suite 0 supports 8 sensitivity levels (0 to 7), while all the other Parameter Suites (1 through 7) support 16 sensitivity levels (0 to 15).

The default, pre-installed AMD Sensitivity file (based on North American English) includes two Parameter Suites:

■ **Parameter Suite 0 (normal sensitivity):** 8 sensitivity levels

■ **Parameter Suite 1 (high sensitivity):** 16 sensitivity levels

Because Parameter Suite 1 provides a greater range of detection sensitivity levels (i.e., higher detection resolution), it may be more suitable for your deployment, providing greater flexibility in tuning the sensitivity.

The following tables show the success rates of the default, pre-installed AMD Sensitivity file (based on North American English) for accurately detecting "live" human voices and answering machines. The detected AMD type (human or machine) and the success of correctly detecting the type are sent in CDRs and syslog messages. For more information, see [Syslog Fields for Answering Machine Detection \(AMD\)](#) on page 1489.

**Table 15-3: Approximate AMD Normal Detection Sensitivity - Parameter Suite 0 (Based on North American English)**

AMD Detection Sensitivity	Performance	
	Success Rate for Live Calls	Success Rate for Answering Machine
<b>0</b> (Best for Answering Machine)	-	-
<b>1</b>	82.56%	97.10%

AMD Detection Sensitivity	Performance	
<b>2</b>	85.87%	96.43%
<b>3</b>	88.57%	94.76%
<b>4</b>	88.94%	94.31%
<b>5</b>	90.42%	91.64%
<b>6</b>	90.66%	91.30%
<b>7</b> (Best for Live Calls)	94.72%	76.14%

**Table 15-4: Approximate AMD High Detection Sensitivity - Parameter Suite 1 (Based on North American English)**

AMD Detection Sensitivity	Performance	
	Success Rate for Live Calls	Success Rate for Answering Machine
<b>0</b> (Best for Answering Machine)	72%	97%
<b>1</b>	77%	96%
<b>2</b>	79%	95%
<b>3</b>	80%	95%
<b>4</b>	84%	94%
<b>5</b>	86%	93%
<b>6</b>	87%	92%
<b>7</b>	88%	91%
<b>8</b>	90%	89%
<b>9</b>	90%	88%
<b>10</b>	91%	87%
<b>11</b>	94%	78%

AMD Detection Sensitivity	Performance	
<b>12</b>	94%	73%
<b>13</b>	95%	65%
<b>14</b>	96%	62%
<b>15</b> (Best for Live Calls)	97%	46%

## Configuring AMD

You can configure AMD for all calls using global AMD parameters, or for specific calls using IP Profiles. The procedure below describes how to configure AMD for all calls. To configure AMD for specific calls, use the AMD parameters in the IP Profiles table (see [Configuring IP Profiles](#) on page 664)



For the Gateway application, you can configure AMD per call based on the called number or Trunk Group. This is done by configuring AMD for a specific IP Profile and then assigning the IP Profile to a Trunk Group in the IP-to-Tel Routing table (see [Configuring IP-to-Tel Routing Rules](#) on page 928).

### ➤ To configure AMD for all calls:

1. Open the DSP Settings page (**Setup** menu > **Signaling & Media** tab > **Media** folder > **DSP Settings**).
2. Select the 'IPMedia Detectors' check box [EnabledDSIPMDetectors]:

IPMedia Detectors



3. Scroll down to the Answer Machine Detector group:

#### ANSWER MACHINE DETECTOR

Answer Machine Detector Sensitivity Parameter Suite	0	▼
Answer Machine Detector Sensitivity	3	
Answer Machine Detector Sensitivity Level	8	
Answer Machine Detector Beep Detection Timeout	200	
Answer Machine Detector Beep Detection Sensitivity	0	



It's **highly recommended** to use the device's default AMD settings, which is suitable for most deployments.

4. Configure the detection sensitivity tradeoff between live voice over answering machine:

- a. From the 'Answer Machine Detector Sensitivity Parameter Suite' drop-down list (AMDSensitivityParameterSuit), select the required Parameter Suite in the installed AMD Sensitivity file.

Each Parameter Suite contains a table with sensitivity levels. Some Parameter Suites are more sensitive to live voice while others are more sensitive to answering machines. The available Parameter Suites depends on the installed AMD Sensitivity file. The default, pre-installed AMD Sensitivity file, which is based on North American English, includes two Parameter Suites:

- ◆ **Parameter Suite #0:** Provides normal sensitivity and has 8 sensitivity levels (0-8). (See note below.)
- ◆ **Parameter Suite #1:** Provides high sensitivity and has 16 sensitivity levels (0-15).



If you configure the [AMDDetectionSensitivity] parameter to 3 (default), the device ignores Parameter Suite #0 sensitivity table. In this case, the [AMDSensitivityLevel] parameter is not relevant and sensitivity is hard-coded and similar to sensitivity level 3 of Parameter Suite #0.

If you configure the [AMDDetectionSensitivity] parameter to any value other than 3, use the [AMDSensitivityLevel] parameter to specify the sensitivity level of Parameter Suite #0.

- b. In the 'Answer Machine Detector Sensitivity' field (AMDDetectionSensitivity), configure the sensitivity level (0 to 7; default 3) of the device's core voice answer detector (VAD) that is used by the AMD algorithm to distinguish between voice and silence.

A lower value increases sensitivity, allowing detection of low-level speech parts, but may also lead to more false detections due to background noise. Conversely, a higher value decreases sensitivity and reduces the likelihood of false detections caused by background noise but may cause quieter speech parts to go undetected. It's recommended to keep the parameter at its default (unless your deployment requires a specific adjustment).

- c. In the 'Answer Machine Detector Sensitivity Level' field (AMDSensitivityLevel), configure the sensitivity level of the selected Parameter Suite (see 'Answer Machine Detector Sensitivity Parameter Suite' above) for detecting live voice over answering machine (tradeoff between them). A lower sensitivity level favors detection of answering machines while a higher level favors detection of live voice. For sensitivity levels and their tradeoff between live voice and answering machine detection, see the tables in [Answering Machine Detection \(AMD\)](#) on page 304.



The 'Answer Machine Detector Sensitivity Level' field (AMDSensitivityLevel) is not relevant for Parameter Suite #0.

5. Configure the answering machine beep detection:
    - a. In the 'Answer Machine Detector Beep Detection Timeout' field [AMDBeepDetectionTimeout], configure the maximum duration that the device takes to detect a beep played at the end of an answering machine message.
    - b. In the 'Answer Machine Detector Beep Detection Sensitivity' field [AMDBeepDetectionSensitivity], configure the AMD beep detection sensitivity level for detecting beeps at the end of an answering machine message. The higher the value, the more sensitive.
  6. Click **Apply**, and then restart the device with a save-to-flash for your settings to take effect.
- For a complete list of AMD-related parameters, see [IP Media Parameters](#) on page 1926.

## Enabling IP-to-Tel Call Disconnection upon Detection of Answering Machine

The device can disconnect an IP-to-Tel (ISDN) call upon detection of an answering machine on the Tel side. Once detected, the device disconnects the call after the receipt of an ISDN Connect from the Tel side and then sends a SIP BYE message to the IP side to disconnect the call. You can enable this feature for all calls (globally) using the [AMDmode] parameter (see procedure below) or for specific calls using IP Profiles where the IP Profile parameter 'AMD Mode' is configured to **Disconnect on AMD** (see [Configuring IP Profiles](#) on page 664).



This feature can also be used for SBC calls (e.g., when the device interfaces with VoiceAI Connect ).

### ➤ To enable disconnection of IP-to-Tel call upon detection of answering machine:

1. Open the SIP Definitions General Settings page (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **SIP Definitions General Settings**).
2. From the 'AMD Mode' drop-down list, select **Disconnect on AMD**:

AMD Mode

Disconnect on AMD ▼

3. Click **Apply**.

## Configuring the Answer Detector Feature

The device's Answer Detect (AD) feature detects voice activity in a call. The AD feature detects the following events:

- Speech - speech is detected.

- End of speech - silence (no speech) for the configured duration (see below) is detected.

➤ **To configure AD:**

1. Open the DSP Settings page (**Setup** menu > **Signaling & Media** tab > **Media** folder > **DSP Settings**).
2. Scroll down to the Answer Detector group:

ANSWER DETECTOR	
Enable Answer Detector	<input checked="" type="checkbox"/>
Answer Detector Activity Delay	<input type="text" value="2"/>
Answer Detector Silence Time	<input type="text" value="10"/>
Answer Detector Redirection	<input type="text" value="No"/>
Answer Detector Sensitivity	<input type="text" value="0"/>

3. Select the 'Enable Answer Detector' check box to enable the feature.
4. In the 'Answer Detector Activity Delay' field, enter the time (in 100-msec resolution) between when the device activates the Answer Detector feature and when it actually starts to detect. This delay may increase the device's immunity to noises and non-speech signals at the beginning of a conversation.
5. In the 'Answer Detector Silence Time' field, enter the silence duration from when no speech input is detected until the device reports an End Of Speech event.
6. From the 'Answer Detector Redirection' drop-down list, select if the Answer Detector is applied to the IP network side (**Yes**) instead of the PSTN side (**No**).
7. In the 'Answer Detector Sensitivity' field, enter the Answer Detector's sensitivity, where 0 is the highest and 7 the lowest.
8. Click **Apply**.

## Automatic Gain Control (AGC)

Automatic Gain Control (AGC) adjusts the energy of the output signal to a required level (volume). This feature compensates for near-far gain differences. AGC estimates the energy of the incoming signal from the IP or Tel side, determined by the 'AGC Redirection' parameter, calculates the essential gain, and then performs amplification. Feedback ensures that the output signal is not clipped. You can configure the required Gain Slope in decibels per second using the 'AGC Slope' parameter and the required signal energy threshold using the 'AGC Target Energy' parameter.

When the AGC first detects an incoming signal, it begins operating in Fast Mode, which allows the AGC to adapt quickly when a conversation starts. This means that the Gain Slope is 8 dB/sec

for the first 1.5 seconds. After this period, the Gain Slope is changed to the user-defined value. You can disable or enable the AGC's Fast Mode feature, using the 'AGC Disable Fast Adaptation' parameter. After Fast Mode is used, the signal should be off for two minutes in order to have the feature turned on again.

➤ **To configure AGC:**

1. Open the DSP Settings page (**Setup** menu > **Signaling & Media** tab > **Media** folder > **DSP Settings**).
2. Select the 'IPMedia Detectors' check box [EnabledDSPIPMDetectors]:

IPMedia Detectors ☒ ⚡

3. Under the AGC group, configure the following AGC parameters:
  - 'Enable AGC' [EnableAGC] - enables the AGC mechanism.
  - 'AGC Slope' [AGCGainSlope] - defines the AGC convergence rate.
  - 'AGC Redirection' [AGCRedirection] - defines the AGC direction.
  - 'AGC Target Energy' - defines the signal energy value (dBm) that the AGC attempts to attain.
  - 'AGC Minimum Gain' [AGCMinGain] - defines the minimum gain (in dB) by the AGC when activated.
  - 'AGC Maximum Gain' [AGCMaxGain] - defines the maximum gain (in dB) by the AGC when activated.
  - 'AGC Disable Fast Adaptation' [AGCDisableFastAdaptation] - enables the AGC Fast Adaptation mode.

AGC	
Enable AGC	<input checked="" type="checkbox"/> ⚡
AGC Slope	<input type="text" value="3"/>
AGC Redirection	<input type="text" value="0"/> ▼
AGC Target Energy	<input type="text" value="19"/>
AGC Minimum Gain	<input type="text" value="20"/> ⚡
AGC Maximum Gain	<input type="text" value="15"/> ⚡
AGC Disable Fast Adaptation	<input type="checkbox"/> ⚡



4. Configure the 'Transcoding Mode' [TranscodingMode] parameter to **Force** when using AGC for SBC calls. You can configure this using the global parameter or per IP Profile.
5. Click **Apply**, and then restart the device with a burn-to-flash for your settings to take effect.

## Media Security

This section describes configuration for securing the media.

### Configuring SRTP

The device supports Secured RTP (SRTP) according to RFC 3711. SRTP is used to encrypt RTP and RTCP transport for protecting VoIP traffic. SRTP requires a cryptographic key exchange mechanism to negotiate the keys. To negotiate the keys, the device supports the Session Description Protocol Security Descriptions (SDS) protocol (according to RFC 4568).

Key exchange is done by adding the 'a=crypto' attribute to the SDP. This attribute is used (by both sides) to declare the various supported cipher suites and to attach the encryption key. If negotiation of the encryption data is successful, the call is established. Typically, 'a=crypto' is included in secured media (RTP/SAVP). However, there is also support for including 'a=crypto' in non-secured media (RTP/AVP). In such cases, the media is handled as if the device received two identical media: one secured and one not.

SRTP supports the following cipher suites (all other suites are ignored):

- AES\_CM\_128\_HMAC\_SHA1\_32
- AES\_CM\_128\_HMAC\_SHA1\_80
- ARIA\_CM\_128\_HMAC\_SHA1\_80
- ARIA\_CM\_192\_HMAC\_SHA1\_80
- AES\_256\_CM\_HMAC\_SHA1\_32 (RFC 6188)
- AES\_256\_CM\_HMAC\_SHA1\_80 (RFC 6188)

When the device is the offering side (SDP offer), it can generate a Master Key Identifier (MKI). You can configure the MKI size globally, using the [SRTPTxPacketMKISize] parameter, or per SIP entity, using the IP Profile parameter 'MKI Size'. The length of the MKI is limited to four bytes. If the remote side sends a longer MKI, the key is ignored.



- Gateway application: The device only initiates the MKI size.
- SBC application: The device can forward MKI size transparently for SRTP-to-SRTP media flows or override the MKI size during negotiation (inbound or outbound leg).

The key lifetime field is not supported. However, if it is included in the key it is ignored and the call doesn't fail. For SBC calls belonging to a specific SIP entity, you can configure the device to remove the lifetime field in the 'a=crypto' attribute, using the IP Profile parameter 'SBC Remove Crypto Lifetime in SDP'.

For SDES, the keys are sent in the SDP body ('a=crypto') of the SIP message and are typically secured using SIP over TLS (SIPS). The encryption of the keys is in plain text in the SDP. The device supports the following session parameters:

- UNENCRYPTED\_SRTP
- UNENCRYPTED\_SRTCP
- UNAUTHENTICATED\_SRTP

Session parameters should be the same for the local and remote sides. When the device is the offering side, the session parameters are configured by the following parameters - 'Authentication on Transmitted RTP Packets', 'Encryption on Transmitted RTP Packets, and 'Encryption on Transmitted RTCP Packets'. When the device is the answering side, the device adjusts these parameters according to the remote offering. Unsupported session parameters are ignored, and do not cause a call failure.

Below is an example of crypto attributes usage:

```
a=crypto:1 AES_CM_128_HMAC_SHA1_80
inline:PsKoMpHICg+b5X0YLuSvNrlmEh/dAe
a=crypto:2 AES_CM_128_HMAC_SHA1_32
inline:lsPtLoGkBf9a+c6XVzRuMqHIDnEiAd
```

The device also supports symmetric MKI negotiation, whereby it can forward the MKI size received in the SDP offer 'a=crypto' line in the SDP answer. You can enable symmetric MKI globally, using the global parameter [EnableSymmetricMKI], or per SIP entity, using the IP Profile parameter 'Symmetric MKI' and for SBC calls 'SBC Enforce MKI Size'. For more information on symmetric MKI, see [Configuring IP Profiles](#) on page 664.

You can configure the enforcement policy of SRTP, by the [EnableMediaSecurity] parameter and IP Profile parameter 'SBC Media Security Mode' parameter for SBC calls. For example, if negotiation of the cipher suite fails or if incoming calls exclude encryption information, the device can be configured to reject the calls.

You can also enable the device to validate the authentication of packets for SRTP tunneling for RTP and RTCP. This applies only to SRTP-to-SRTP SBC calls and where the endpoints use the same key. This is enabled using the 'SRTP Tunneling Authentication for RTP' and 'SRTP Tunneling Authentication for RTCP' parameters.



- For a detailed description of the SRTP parameters, see [Configuring IP Profiles](#) on page 664 and [SRTP Parameters](#) on page 1662.
- When SRTP is used, channel capacity may be reduced.
- To configure specific SRTP cipher suites for an IP Profile, see [Configuring SRTP Crypto Suite Groups](#) on the next page.

The procedure below describes how to configure SRTP through the Web interface.

➤ **To enable SRTP globally (for all calls):**

1. Open the Media Security page (**Setup** menu > **Signaling & Media** tab > **Media** folder > **Media Security**).

GENERAL		AUTHENTICATION & ENCRYPTION	
Media Security	<input checked="" type="checkbox"/>	Authentication on Transmitted RTP Packets	Active
Media Security Behavior	Preferable	Encryption on Transmitted RTP Packets	Active
Offered SRTP Cipher Suites	All	Encryption on Transmitted RTCP Packets	Active
		SRTP Tunneling Authentication for RTP	<input type="checkbox"/>
		SRTP Tunneling Authentication for RTCP	<input type="checkbox"/>
MASTER KEY IDENTIFIER		GATEWAY SETTINGS	
Master Key Identifier (MKI) Size	0	Enable Rekey After 181	<input type="checkbox"/>
Symmetric MKI	<input type="checkbox"/>		

GENERAL		AUTHENTICATION & ENCRYPTION	
Media Security	<input checked="" type="checkbox"/>	Authentication on Transmitted RTP Packets	Active
Media Security Behavior	Preferable	Encryption on Transmitted RTP Packets	Active
Offered SRTP Cipher Suites	All	Encryption on Transmitted RTCP Packets	Active
ARIA Protocol Support	<input type="checkbox"/>	SRTP Tunneling Authentication for RTP	<input type="checkbox"/>
		SRTP Tunneling Authentication for RTCP	<input type="checkbox"/>
MASTER KEY IDENTIFIER		GATEWAY SETTINGS	
Master Key Identifier (MKI) Size	0	Enable Rekey After 181	<input type="checkbox"/>
Symmetric MKI	<input type="checkbox"/>		

2. Select the 'Media Security' check box [EnableMediaSecurity] to enable SRTP.
3. From the 'Offered SRTP Cipher Suites' drop-down list [SRTPofferedSuites], select the supported cipher suite.
4. Configure the other SRTP parameters as required.
5. Click **Apply**.

## Configuring SRTP Crypto Suite Groups

The SBC Crypto Suite Groups table lets you configure groups of SRTP crypto suites, which you can then assign to IP Profiles. Therefore, instead of configuring a single crypto suite for all calls using the global parameter 'Offered SRTP Cipher Suites' (as described in [Configuring SRTP](#) on page 313), you can use the SBC Crypto Suite Groups table to configure specific crypto suites for specific calls (IP Profiles). To assign an SBC Crypto Suite Group to an IP Profile, use the IP Profile's 'Crypto Suites Group' parameter (see [Configuring IP Profiles](#) on page 664).

You configure an SBC Crypto Suite Group using two tables with "parent-child" relationship:

- **SBC Crypto Suite Groups table ("parent"):** Defines the name of the SBC Crypto Suite Group. You can configure up to 10 SBC Crypto Suite Groups.
- **Crypto Suites table ("child"):** Defines the crypto suites for the SBC Crypto Suite Group. You can configure each SBC Crypto Suite Group with up to 4 crypto suites.



This feature is applicable only to the SBC application.

The following procedure describes how to configure SBC Crypto Suite Groups through the Web interface. You can also configure it through other management platforms:

- **SBC Crypto Suite Groups table:** *ini* file [CryptoSuitesGroups] or CLI (`configure voip > media crypto-suites-groups`)
- **Crypto Suites table:** *ini* file [CryptoSuites] or CLI (`configure voip > media crypto-suites-groups > crypto-suites`)

➤ **To configure an SBC Crypto Suite Group:**

1. Open the SBC Crypto Suite Groups table (**Setup** menu > **Signaling & Media** tab > **Media** folder > **SBC Crypto Suite Groups**).
2. Click **New**; the following dialog box appears:

3. Configure a name for the SBC Crypto Suite Group according to the parameters described in the table below.
4. Click **Apply**.

**Table 15-5: SBC Crypto Suite Groups Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' crypto-suites-group-name [Name]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 40 characters. <b>Note:</b> The parameter value must be unique.

5. In the SBC Crypto Suite Groups table, select the row for which you want to configure crypto suites, and then click the **Crypto Suites** link located below the table; the Crypto Suites table appears.
6. Click **New**; the following dialog box appears:

The screenshot shows a dialog box titled "Crypto Suites". It has a "GENERAL" tab. Inside the tab, there are two fields: "Index" with a text input containing "0", and "Supported Crypto Suite" with a dropdown menu currently showing "All".

7. Configure a rule according to the parameters described in the table below.
8. Click **New**, and then save your settings to flash memory.

**Table 15-6: Crypto Suites Table Parameter Descriptions**

Parameter	Description
General	
'Index' crypto-suites <index/index> [CryptoSuiteIndex]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Supported Crypto Suite' crypto-suite [CryptoSuite]	Defines the SRTP crypto suite. <ul style="list-style-type: none"> <li>■ [63] <b>All</b></li> <li>■ [1] <b>AES-CM-128-HMAC-SHA1-80</b></li> <li>■ [2] <b>AES-CM-128-HMAC-SHA1-32</b></li> <li>■ [16] <b>AES-256-CM-HMAC-SHA1-80</b></li> <li>■ [32] <b>AES-256-CM-HMAC-SHA1-32</b></li> </ul> <b>Note:</b> You can configure up to four crypto suites in the Crypto Suites table (i.e., per SBC Crypto Suite Groups). Therefore, if you configure the parameter to <b>All</b> (which means all four crypto suites), no additional table rows can be added to the table.

## 16 Services

This section describes configuration for various supported services.

### DHCP Server Functionality

The device can serve as a Dynamic Host Configuration Protocol (DHCP) server that assigns and manages IP addresses from a user-defined address pool for DHCP clients. The DHCP server can also be configured to supply additional information to the requesting client such as the IP address of the TFTP server, DNS server, NTP server, and default router (gateway). The DHCP server functionality complies with IETF RFC 2131 and RFC 2132.

The DHCP server can service up to 800 DHCP clients. The DHCP clients are typically IP phones that are connected to the device's LAN port.

The DHCP server is activated when you configure a valid entry in the DHCP Servers table (see [Configuring the DHCP Server](#) below) and associate it with an active IP network interface listed in the IP Interfaces table. When an IP phone on the LAN requests an IP address, the DHCP server allocates one from the address pool. In scenarios of duplicated IP addresses on the LAN (i.e., an unauthorized network device using one of the IP addresses of the DHCP address pool), the DHCP server detects this condition using an Address Resolution Protocol (ARP) request and temporarily blacklists the duplicated address.

You can also configure the DHCP server to respond **only** to DHCPDiscover requests from DHCP clients that contain a specific value for Option 60 (Vendor Class Identification). For more information, see [Configuring the Vendor Class Identifier](#) on page 324.

### Configuring the DHCP Server

The DHCP Servers table lets you configure the device's DHCP server (only one). The DHCP Server table configures the DHCP server implementation. This includes configuring the DHCP IP address pool from where IP addresses are allocated to requesting DHCP clients, as well as configuring other information such as IP addresses of the DNS server, NTP server, default router (gateway), and SIP proxy server. The DHCP server sends the information in DHCP Options. The table below lists the DHCP Options that the DHCP server sends to the DHCP client and which are configurable in the DHCP Servers table.

**Table 16-1: Configurable DHCP Options in DHCP Servers Table**

DHCP Option Code	DHCP Option Name
Option 53	DHCP Message Type
Option 54	DHCP Server Identifier
Option 51	IP Address Lease Time

DHCP Option Code	DHCP Option Name
Option 1	Subnet Mask
Option 3	Router
Option 6	Domain Name Server
Option 44	NetBIOS Name Server
Option 46	NetBIOS Node Type
Option 42	Network Time Protocol Server
Option 2	Time Offset
Option 66	TFTP Server Name
Option 67	Boot file Name
Option 120	SIP Server

Once you have configured the DHCP server, you can configure the following:

- DHCP Vendor Class Identifier names (DHCP Option 60) - see [Configuring the Vendor Class Identifier](#) on page 324
- Additional DHCP Options - see [Configuring Additional DHCP Options](#) on page 325
- Static IP addresses for DHCP clients - see [Configuring Static IP Addresses for DHCP Clients](#) on page 328



If you configure additional DHCP Options in the DHCP Option table, they override the default ones, which are configured in the DHCP Servers table. For example, if you configure Option 67 in the DHCP Option table, the device uses the value configured in the DHCP Option table instead of the value configured in the DHCP Servers table.

To view and delete currently serviced DHCP clients, see [Viewing and Deleting DHCP Clients](#) on page 329.

The following procedure describes how to configure the DHCP server through the Web interface. You can also configure it through ini file [DhcpServer] or CLI (`configure network > dhcp-server server <index>`).

➤ **To configure the device's DHCP server:**

1. Open the DHCP Servers page (**Setup** menu > **IP Network** tab > **Advanced** folder > **DHCP Servers**).
2. Click **New**; the following dialog box appears:

**DHCP Servers**

**GENERAL**

Index: 0

Interface Name: -- [View](#)

Start IP Address: 192.168.0.100

End IP Address: 192.168.0.149

Subnet Mask: 255.255.255.0

Lease Time: 1440

**TIME AND DATE**

NTP Server 1: 0.0.0.0

NTP Server 2: 0.0.0.0

Time Offset: 0

**DNS**

DNS Server 1: 0.0.0.0

DNS Server 2: 0.0.0.0

**BOOT FILE**

TFTP Server Name:

Boot File Name:

Expand Boot-File Name: Yes

**ROUTER**

Override Router: 0.0.0.0

3. Configure a DHCP server according to the parameters described in the table below.

4. Click **Apply**.

**Table 16-2: DHCP Servers Table Parameter Descriptions**

Parameter	Description
<b>General</b>	
'Index' dhcp server <index>	<p>Defines an index number for the new table row.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>Each row must be configured with a unique index.</li> <li>Currently, only one index row can be configured.</li> </ul>
'Interface Name' network-if [DhcpServer_ InterfaceName]	<p>Associates an IP network interface on which the DHCP server operates. The IP interfaces are configured in the IP Interfaces table (see <a href="#">Configuring IP Network Interfaces</a> on page 157). By default, no value is defined.</p>
'Start IP Address' start-address [DhcpServer_ StartIPAddress]	<p>Defines the starting IP address (IPv4 address in dotted-decimal format) of the IP address pool range used by the DHCP server to allocate addresses.</p> <p>The default value is 192.168.0.100.</p> <p><b>Note:</b> The IP address must belong to the same subnet as the associated interface's IP address.</p>



Parameter	Description
'End IP Address' end-address [DhcpServer_ EndIPAddress]	<p>Defines the ending IP address (IPv4 address in dotted-decimal format) of the IP address pool range used by the DHCP server to allocate addresses.</p> <p>The default value is 192.168.0.149.</p> <p><b>Note:</b> The IP address must belong to the same subnet as the associated interface's IP address and must be "greater or equal" to the starting IP address defined in 'Start IP Address'.</p>
'Subnet Mask' subnet-mask [DhcpServer_ SubnetMask]	<p>Defines the subnet mask (for IPv4 addresses) for the DHCP client. The value is sent in DHCP Option 1 (Subnet Mask).</p> <p>The default value is 0.0.0.0.</p> <p><b>Note:</b> The value must be "narrower" or equal to the subnet mask of the associated interface's IP address. If set to "0.0.0.0", the subnet mask of the associated interface is used.</p>
'Lease Time' lease-time [DhcpServer_ LeaseTime]	<p>Defines the duration (in minutes) of the lease time to a DHCP client for using an assigned IP address. The client needs to request a new address before this time expires. The value is sent in DHCP Option 51 (IP Address Lease Time).</p> <p>The valid value range is 0 to 214,7483,647. The default is 1440. When set to 0, the lease time is infinite.</p>
DNS	
'DNS Server 1' dns-server-1 [DhcpServer_ DNSServer1]	<p>Defines the IP address (IPv4) of the primary DNS server that the DHCP server assigns to the DHCP client. The value is sent in DHCP Option 6 (Domain Name Server).</p> <p>The default value is 0.0.0.0.</p>
'DNS Server 2' dns-server-2 [DhcpServer_ DNSServer2]	<p>Defines the IP address (IPv4) of the secondary DNS server that the DHCP server assigns to the DHCP client. The value is sent in DHCP Option 6 (Domain Name Server).</p> <p>The default value is 0.0.0.0.</p>
NetBIOS	
'NetBIOS Name Server' netbios-server [DhcpServer_ NetbiosNameServer]	<p>Defines the IP address (IPv4) of the NetBIOS WINS server that is available to a Microsoft DHCP client. The value is sent in DHCP Option 44 (NetBIOS Name Server).</p> <p>The default value is 0.0.0.0.</p>
'NetBIOS Node Type' netbios-node-	<p>Defines the node type of the NetBIOS WINS server for a Microsoft DHCP client. The value is sent in DHCP Option 46</p>

Parameter	Description
<code>type</code> <code>[DhcpServer_</code> <code>NetbiosNodeType]</code>	<p>(NetBIOS Node Type).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Broadcast</b> (default)</li> <li>■ [1] <b>peer-to-peer</b></li> <li>■ [4] <b>Mixed</b></li> <li>■ [8] <b>Hybrid</b></li> </ul>
Time and Date	
<p>'NTP Server 1'</p> <code>ntp-server-1</code> <code>[DhcpServer_</code> <code>NTPServer1]</code>	<p>Defines the IP address (IPv4) of the primary NTP server that the DHCP server assigns to the DHCP client. The value is sent in DHCP Option 42 (Network Time Protocol Server).</p> <p>The default value is 0.0.0.0.</p>
<p>'NTP Server 2'</p> <code>ntp-server-2</code> <code>[DhcpServer_</code> <code>NTPServer2]</code>	<p>Defines the IP address (IPv4) of the secondary NTP server that the DHCP server assigns to the DHCP client. The value is sent in DHCP Option 42 (Network Time Protocol Server).</p> <p>The default value is 0.0.0.0.</p>
<p>'Time Offset'</p> <code>time-offset</code> <code>[DhcpServer_</code> <code>TimeOffset]</code>	<p>Defines the Greenwich Mean Time (GMT) offset (in seconds) that the DHCP server assigns to the DHCP client. The value is sent in DHCP Option 2 (Time Offset).</p> <p>The valid range is -43200 to 43200. The default is 0.</p>
Boot File	
<p>'TFTP Server Name'</p> <code>tftp-server-name</code>  <code>[DhcpServer_</code> <code>TftpServer]</code>	<p>Defines the IP address or name of the TFTP server that the DHCP server assigns to the DHCP client. The TFTP server typically stores the boot file image, defined in the 'Boot file name' parameter (see below). The value is sent in DHCP Option 66 (TFTP Server Name).</p> <p>The valid value is a string of up to 80 characters. By default, no value is defined.</p>
<p>'Boot File Name'</p> <code>boot-file-name</code> <code>[DhcpServer_</code> <code>BootFileName]</code>	<p>Defines the name of the boot file image for the DHCP client. The boot file stores the boot image for the client. The boot image is typically the operating system the client uses to upload (from a boot server). The value is sent in DHCP Option 67 (Bootfile Name). To define the server storing the file, use the 'TFTP Server' parameter (see above).</p> <p>The valid value is a string of up to 256 characters. By default, no value is defined.</p>

Parameter	Description
	<p>The name can also include the following case-sensitive placeholder strings that are replaced with actual values if the 'Expand Boot-file Name' parameter is set to <b>Yes</b>:</p> <ul style="list-style-type: none"> <li>■ <b>&lt;MAC&gt;</b>: Replaced by the MAC address of the client (e.g., <i>boot_&lt;MAC&gt;.ini</i>). The MAC address is obtained in the client's DHCP request.</li> <li>■ <b>&lt;IP&gt;</b>: Replaced by the IP address assigned by the DHCP server to the client.</li> </ul>
'Expand Boot-File Name' expand-boot-file-name [DhcpServer_ExpandBootfileName]	<p>Enables the use of the placeholders in the boot file name, defined in the 'Boot file name' parameter.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b></li> <li>■ [1] <b>Yes</b> (default)</li> </ul>
<b>Router</b>	
'Override Router' override-router-address [DhcpServer_OverrideRouter]	<p>Defines the IP address (IPv4 in dotted-decimal notation) of the default router that the DHCP server assigns the DHCP client. The value is sent in DHCP Option 3 (Router).</p> <p>The default value is 0.0.0.0. If not specified (empty or "0.0.0.0"), the IP address of the default gateway configured in the IP Interfaces table for the IP network interface that you associated with the DHCP server (see the 'Interface Name' parameter above) is used.</p>
<b>SIP</b>	
'SIP Server' sip-server [DhcpServer_SipServer]	<p>Defines the IP address or DNS name of the SIP server that the DHCP server assigns the DHCP client. The client uses this SIP server for its outbound SIP requests. The value is sent in DHCP Option 120 (SIP Server). After defining the parameter, use the 'SIP server type' parameter (see below) to define the type of address (FQDN or IP address).</p> <p>The valid value is a string of up to 256 characters. The default is 0.0.0.0.</p>
'SIP Server Type' sip-server-type [DhcpServer_SipServerType]	<p>Defines the type of SIP server address. The actual address is defined in the 'SIP server' parameter (see above). Encoding is done per SIP Server Type, as defined in RFC 3361.</p> <ul style="list-style-type: none"> <li>■ [0] <b>DNS names</b> = (Default) The 'SIP server' parameter is configured with an FQDN of the SIP server.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [1] <b>IP address</b> = The 'SIP server' parameter configured with an IP address of the SIP server.</li> </ul>

## Configuring the Vendor Class Identifier

The DHCP Vendor Class table lets you configure up to 10 Vendor Class Identifier (VCI) names (DHCP Option 60). When the table is configured, the device's DHCP server responds only to DHCPDiscover requests that contain Option 60 and that match one of the DHCP VCIs configured in the table. If you have not configured any entries in the table, the DHCP server responds to all DHCPDiscover requests, regardless of the VCI.

The VCI is a string that identifies the vendor and functionality of a DHCP client to the DHCP server. For example, Option 60 can show the unique type of hardware (e.g., "AudioCodes 440HD IP Phone") or firmware of the DHCP client. The DHCP server can then differentiate between DHCP clients and process their requests accordingly.

The following procedure describes how to configure the DHCP VCIs through the Web interface. You can also configure it through ini file [DhcpVendorClass] or CLI (`configure network > dhcp-server vendor-class`).

### ➤ To configure DHCP Vendor Class Identifiers:

1. Open the DHCP Servers table (see [Configuring the DHCP Server](#) on page 318).
2. Select the row of the desired DHCP server for which you want to configure VCIs, and then click the **DHCP Vendor Class** link located below the table; the DHCP Vendor Class table opens.
3. Click **New**; the following dialog box appears:

4. Configure a VCI for the DHCP server according to the parameters described in the table below.
5. Click **Apply**.

**Table 16-3: DHCP Vendor Class Table Parameter Descriptions**

Parameter	Description
'Index' dhcp vendor- class <index> [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'DHCP Server Index' dhcp-server- number [DhcpServerIndex]	Associates the VCI table entry with a DHCP server that you configured in <a href="#">Configuring the DHCP Server</a> on page 318. <b>Note:</b> You can configure only one DHCP server (Index 0) and therefore, the parameter value is always 0.
'Vendor Class Identifier' vendor-class [VendorClassId]	Defines the value of the VCI DHCP Option 60. The valid value is a string of up to 80 characters. By default, no value is defined.

## Configuring Additional DHCP Options

The DHCP Option table lets you configure up to 10 additional DHCP Options that the DHCP server can use to service the DHCP client. These DHCP Options are included in the DHCP Offer response sent by the DHCP server.

The following procedure describes how to configure DHCP Options through the Web interface. You can also configure it through ini file [DhcpOption] or CLI (`configure network > dhcp-server option`).



The additional DHCP Options configured in the DHCP Option table override the default ones, which are configured in the DHCP Servers table. In other words, if you configure Option 67 in the DHCP Option table, the device uses the value configured in the DHCP Option table instead of the value configured in the DHCP Servers table.

### ➤ To configure DHCP Options:

1. Open the DHCP Servers table (see [Configuring the DHCP Server](#) on page 318).
2. Select the row of the desired DHCP server for which you want to configure additional DHCP Options, and then click the **DHCP Option** link located below the table; the DHCP Option table opens.
3. Click **New**; the following dialog box appears:

DHCP Option
— x

GENERAL

Index

DHCP Server Index

View

Option

Type

▼

Value

Expand Value

▼

4. Configure additional DHCP Options for the DHCP server according to the parameters described in the table below.
5. Click **Apply**.

Table 16-4: DHCP Option Table Parameter Descriptions

Parameter	Description
'Index' dhcp option [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'DHCP Server Index' dhcp-server-number [DhcpServerIndex]	Associates the DHCP Option table entry with a DHCP server that you configured in <a href="#">Configuring the DHCP Server</a> on page 318. <b>Note:</b> Currently, only one DHCP server (Index 0) can be configured and therefore, the parameter is always set at 0.
'Option' option [Option]	Defines the code of the DHCP Option. The valid value is 1 to 254. The default is 159. For example, for DHCP Option 150 (Cisco proprietary for defining multiple TFTP server IP addresses), enter the value 150.
'Type' type [Type]	Defines the format (type) of the DHCP Option value that is configured in the 'Value' parameter (see below).  ■ [0] <b>ASCII</b> = (Default) Plain-text string (e.g., when the value is a domain name).

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [1] <b>IP address</b> = IPv4 address.</li> <li>■ [2] <b>Hexadecimal</b> = Hexadecimal-encoded string.</li> </ul> <p>For example, if you configure the 'Value' parameter to "company.com" (without quotation marks), you need to configure the 'Type' parameter to <b>ASCII</b>.</p>
'Value' value [Value]	<p>Defines the value of the DHCP Option. For example, if you are using Option 66, the parameter is used for specifying the TFTP provisioning server (e.g., <code>http://192.168.3.155:5000/provisioning/</code>).</p> <p>The valid value is a string of up to 256 characters. By default, no value is defined. For IP addresses, the value can be one or more IPv4 addresses, each separated by a comma (e.g., <code>192.168.10.5,192.168.10.20</code>). For hexadecimal values, the value is a hexadecimal string (e.g., <code>c0a80a05</code>).</p> <p>You can also configure the parameter with case-sensitive placeholder strings that are replaced with actual values if the 'Expand Value' parameter (see below) is set to <b>Yes</b>:</p> <ul style="list-style-type: none"> <li>■ <b>&lt;MAC&gt;</b>: Replaced by the MAC address of the client. The MAC address is obtained from the client's DHCP request. For example, the parameter can be set to:  <code>http://192.168.3.155:5000/provisioning/cfg_&lt;MAC&gt;.txt</code></li> <li>■ <b>&lt;IP&gt;</b>: Replaced by the IP address assigned by the DHCP server to the client. For example, the parameter can be set to:  <code>http://192.168.3.155:5000/provisioning/cfg_&lt;IP&gt;.txt</code></li> </ul>
'Expand Value' expand-value [ExpandValue]	<p>Enables the use of the special placeholder strings, "&lt;MAC&gt;" and "&lt;IP&gt;" for configuring the 'Value' parameter (see above).</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b></li> <li>■ [1] <b>Yes</b> (default)</li> </ul> <p><b>Note:</b> The parameter is applicable only to values of type ASCII (see the 'Type' parameter, above).</p>

## Configuring Static IP Addresses for DHCP Clients

The DHCP Static IP table lets you configure up to 100 DHCP clients with static IP addresses. The static IP address is a "reserved" IP address for a specified DHCP client defined by MAC address. In other words, instead of assigning the DHCP client with a different IP address upon each IP address lease renewal request, the DHCP server assigns the client the same IP address. For DHCP clients that are not listed in the table, the DHCP server assigns a random IP address from its address pool, as in normal operation.

The following procedure describes how to configure static IP addresses for DHCP clients through the Web interface. You can also configure it through ini file [DhcpStaticIP] or CLI (configure network > dhcp-server static-ip <index>).

➤ **To configure static IP addresses for DHCP clients:**

1. Open the DHCP Servers table (see [Configuring the DHCP Server](#) on page 318).
2. Select the row of the desired DHCP server for which you want to configure static IP addresses for DHCP clients, and then click the **DHCP Static IP** link located below the table; the DHCP Static IP table opens.
3. Click **New**; the following dialog box appears:

4. Configure a static IP address for a specific DHCP client according to the parameters described in the table below.
5. Click **Apply**.

**Table 16-5: DHCP Static IP Table Parameter Descriptions**

Parameter	Description
'Index' dhcp static-ip <index>	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.



Parameter	Description
[Index]	
'DHCP Server Index' dhcp-server-number [DhcpServerIndex]	Associates the DHCP Static IP table entry with a DHCP server that you configured in <a href="#">Configuring the DHCP Server</a> on page 318. <b>Note:</b> Currently, only one DHCP server (Index 0) can be configured and therefore, the parameter value is always 0.
'IP Address' ip-address [IPAddress]	Defines the "reserved", static IP address (IPv4) to assign the DHCP client. The default is 0.0.0.0.
'MAC Address' mac-address [MACAddress]	Defines the DHCP client by MAC address (in hexadecimal format). The valid value is a string of up to 20 characters. The format includes six groups of two hexadecimal digits, each separated by a colon. The default MAC address is 00:90:8f:00:00:00.

## Viewing and Deleting DHCP Clients

The DHCP Clients table lets you view currently serviced DHCP clients by the DHCP server. The table also lets you delete DHCP clients. If you delete a client, the DHCP server ends the lease of the IP address to the client and the IP address becomes available for allocation by the DHCP server to another client.

The following procedure describes how to view DHCP clients through the Web interface. You can also view this through CLI:

- To view DHCP clients:

```
# show network dhcp clients
```

- To view DHCP clients according to IP address:

```
# show network dhcp ip
```

- To view DHCP clients according to MAC address:

```
# show network dhcp mac
```

- To view DHCP clients that have been blacklisted from DHCP implementation (due to duplicated IP addresses in the network, where another device is using the same IP address as the one assigned to the client):

```
# show network dhcp black-list
```

➤ **To view or delete DHCP clients:**

1. Open the DHCP Servers table (see [Configuring the DHCP Server](#) on page 318).
2. Select the row of the desired DHCP server for which you want to view DHCP clients, and then click the **DHCP Clients** link located below the table; the DHCP Clients table opens:

INDEX ↕	DHCP SERVER INDEX	IP ADDRESS	MAC ADDRESS	LEASE EXPIRATION
---------	-------------------	------------	-------------	------------------

The table displays the following per client:

- **Index:** Table index number.
  - **DHCP Server Index:** The index number of the configured DHCP server scope in the DHCP Server table (see [Configuring the DHCP Server](#) on page 318) with which the client is associated.
  - **IP Address:** IP address assigned to the DHCP client by the DHCP server.
  - **MAC Address:** MAC address of the DHCP client.
  - **Lease Expiration:** Date on which the lease of the DHCP client's IP address obtained from the DHCP server expires.
3. To delete a client:
    - a. Select the table row index of the DHCP client that you want to delete.
    - b. Click the **Action** button, and then from the drop-down menu, choose **Delete**; a confirmation message appears.
    - c. Click **OK** to confirm deletion.

## SIPREC SIP-based Media Recording

This section describes the device's support for SIPREC.

### SIPREC Overview

The device can record SIP-based media (RTP/SRTP) call sessions traversing it. The device can record not only audio streams, but also video streams for audio-video calls. The media recording support is in accordance with the Session Recording Protocol (SIPREC), which describes architectures for deploying session recording solutions and specifies requirements for extensions to SIP that will manage delivery of RTP media to a recording device. The device's SIPREC feature is in compliance with the following:

- RFC 6341 (Use Cases and Requirements for SIP-Based Media Recording)
- Session Recording Protocol (draft-ietf-siprec-protocol-02)

- Architecture (draft-ietf-siprec-architecture-03)
- RFC 7865 (Session Initiation Protocol (SIP) Recording Metadata)




**Warning for Deployments in France:** The device supports SIPREC according to RFC 6341. As such, you must adhere to the Commission Nationale Informatique et Liberté's (CNIL) [directive](#) and be aware that article R226-15 applies penalties to the malicious interception, diversion, use or disclosure of correspondence sent, transmitted or received by means of telecommunication, or the setting up of a device designed to produce such interceptions.



- The SIPREC feature is available only if your device is installed with a License Key (see [License Key](#) on page 1233) that includes this feature. The License Key specifies the maximum number of supported SIPREC sessions. For audio-video calls, video recording needs additional SBC media channel resources.
- For maximum concurrent SIPREC sessions, refer to the device's *Release Notes* (click [here](#)).
- The device can record the following media streams: audio only, text only, audio and video, or audio and text.
- You can view active and historical SIPREC call information, using the CLI command `show voip calls`.
- You can customize SBC CDRs generated by the device to include the field "Is Recorded", which indicates if the SBC leg was recorded or not. For more information, see [Customizing CDRs for SBC Calls and Test Calls](#) on page 1446.

Session recording is a critical requirement in many business communications environments such as call centers and financial trading floors. In some of these environments, all calls must be recorded for regulatory and compliance reasons. In others, calls may be recorded for quality control or business analytics. Recording is typically performed by sending a copy of the session media to the recording devices.

The SIPREC protocol specifies the use of SIP, SDP, and RTP to establish a Recording Session (RS) from the Session Recording Client (SRC), which is on the path of the Communication Session (CS), to a Session Recording Server (SRS) at the recording equipment. The device functions as the SRC, sending recording sessions to a third-party SRS, as shown in the figure below.



The device can record calls between two IP Groups, or between an IP Group and a Trunk Group for Gateway calls. The type of calls to record can be specified by source and/or destination prefix number or SIP Request-URI, as well as by call initiator. The side ("leg") on which the recording is done must be specified. Specifying the leg is important as it determines the various call media attributes of the recorded RTP (or SRTP) such as coder type.

### SIP Message Flow for SIPREC

The device initiates a recording session by sending an INVITE message to the SRS when the call to be recorded is connected. The SIP From header contains the identity of the SRC and the To header contains the identity of the SRS. The SIP message body of the INVITE contains the following:

#### ■ SDP body:

- Two 'm=' lines that represent the two RTP/SRTP streams (Rx and Tx).
- Two 'a=label:' lines that identify the streams.

If the recorded leg includes a video stream, the SDP not only includes the two audio streams ('m=audio'), but also two video streams ('m=video') in send-only RTP mode ('a=sendonly') - one for Tx and one for Rx.

#### ■ XML body (also referred to as metadata), which provides information on the participants of the call session:

- <group id>: Logging Session ID (displayed as [SID:nnnnn] in syslog), converted to hex (or Base64 format). This number remains the same even if the call is forwarded or transferred. This is important for recorded calls.

- <session id>: SIP Call-ID header value of the recorded leg, which the device represents as a unique hashed number.
- <group-ref>: Same as <group id>.
- <participant id>: SIP From / To user.
- <nameID aor>: From/To user@host.
- <send> and <recv>: IDs for the RTP/SRTP streams in hex (or Base64 format) - bits 0-31 are the same as group, bits 32-47 are the RTP port.
- <stream id>: Same as <send> for each participant.
- <label>: 1 and 2 (same as in the SDP's 'a=label:' line).
- RFC 7865 only:
  - ◆ <sessionrecordingassoc>: Session association data.
  - ◆ <participantsessionassoc>: Data for association between participant and session.
  - ◆ <participantstreamassoc>: Data for association between participant and stream.

If the recorded leg includes a video stream, the metadata body contains two additional <stream> sections, which denote the Tx and Rx recording streams of the video payload. When RFC 7865 is chosen as the metadata format, the <participantstreamassoc> sections also contain this additional pair of streams.

You can configure the format of the recording metadata (i.e., based on RFC 7865 or "legacy") generated by the device. For more information, see [Configuring Format of SIPREC Metadata](#) on page 346.

The SRS can respond with 'a=recvonly' for immediate recording or 'a=inactive' if recording is not yet needed, and send a re-INVITE at any later stage with the desired RTP/SRTP mode change. If a re-INVITE is received in the original call (e.g., when a call is on hold), the device sends another re-INVITE with two 'm=' lines to the SRS with the updated RTP/SRTP data. If the recorded leg uses SRTP, the device can send the media streams to the SRS as SRTP; otherwise, the media streams are sent as RTP to the SRS.

Below is an example of an INVITE sent by the device to the SRS, showing the legacy and RFC 7865 metadata formats (only one of these is generated in real-life scenarios):

```
INVITE sip:VSRP@1.9.64.253 SIP/2.0
Via: SIP/2.0/UDP 192.168.241.44:5060;branch=z9hG4bKac505782914
Max-Forwards: 10
From: <sip:192.168.241.44>;tag=1c505764207
To: <sip:VSRP@1.9.64.253>
Call-ID: 505763097241201011157@192.168.241.44
CSeq: 1 INVITE
Contact: <sip:192.168.241.44:5060>;src
Supported: replaces,resource-priority
Allow:
```

REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE

Require: siprec

User-Agent: Device /7.60A.100.022

Content-Type: multipart/mixed;boundary=boundary\_ac1ffff85b

Content-Length: 1832

--boundary\_ac1ffff85b

Content-Type: application/sdp

v=0

o=AudioCodesGW 921244928 921244893 IN IP4 10.33.8.70

s=SBC-Call

c=IN IP4 10.33.8.70

t=0 0

m=audio 6020 RTP/AVP 8 96

c=IN IP4 10.33.8.70

a=ptime:20

a=sendonly

a=label:1

a=rtpmap:8 PCMA/8000

a=rtpmap:96 telephone-event/8000

a=fmtp:96 0-15

m=audio 6030 RTP/AVP 8 96

c=IN IP4 10.33.8.70

a=ptime:20

a=sendonly

a=label:2

a=rtpmap:8 PCMA/8000

a=rtpmap:96 telephone-event/8000

a=fmtp:96 0-15

--boundary\_ac1ffff85b

Content-Type: application/rs-metadata

Content-Disposition: recording-session

#### ■ Legacy XML metadata:

```
<?xml version="1.0" encoding="UTF-8"?>
<recording xmlns='urn:ietf:params:xml:ns:recording'>
  <datamode>complete</datamode>
  <group id="00000000-0000-0000-0000-00003a36c4e3">
    <associate-time>2010-01-24T01:11:57Z</associate-time>
  </group>
  <session id="0000-0000-0000-0000-00000000d0d71a52">
    <group-ref>00000000-0000-0000-0000-00003a36c4e3</group-ref>
```

```

<start-time>2010-01-24T01:11:57Z</start-time>
  <ac:AvayaUCID
xmlns="urn:ietf:params:xml:ns:Avaya">FA080030C4E34B5B9E59</ac:Avaya
UCID>
</session>
<participant id="1056" session="0000-0000-0000-0000-
00000000d0d71a52">
  <nameID aor="1056@192.168.241.20"></nameID>
  <associate-time>2010-01-24T01:11:57Z</associate-time>
  <send>00000000-0000-0000-0000-1CF23A36C4E3</send>
  <recv>00000000-0000-0000-0000-BF583A36C4E3</recv>
</participant>
  <participant id="182052092" session="0000-0000-0000-0000-
00000000d0d71a52">
  <nameID aor="182052092@voicelab.local"></nameID>
  <associate-time>2010-01-24T01:11:57Z</associate-time>
  <recv>00000000-0000-0000-0000-1CF23A36C4E3</recv>
  <send>00000000-0000-0000-0000-BF583A36C4E3</send>
</participant>
  <stream id="00000000-0000-0000-0000-1CF23A36C4E3" session="0000-
0000-0000-0000-00000000d0d71a52">
    <label>1</label>
  </stream>
  <stream id="00000000-0000-0000-0000-BF583A36C4E3" session="0000-
0000-0000-0000-00000000d0d71a52">
    <label>2</label>
  </stream>
</recording>
--boundary_ac1ffff85b--

```

- **RFC 7865 XML metadata:**

```

<?xml version="1.0" encoding="UTF-8"?>
<recording xmlns="urn:ietf:params:xml:ns:recording" xmlns:ac="http://abc">
  <datamode>complete</datamode>
  <group group_id="4gAAAC9YRUBDQDw">
    <associate-time>2018-04-17T09:35:41</associate-time>
  </group>
  <session session_id="OWc4Md2PHao">
    <group-ref>4gAAAC9YRUBDQDw</group-ref>
  </session>
  <participant participant_id="MjAw">
    <nameID aor="200@10.33.8.52">
      <name xml:lang="en">Bob</name>
    </nameID>
  </participant>
</recording>

```

```

    </nameID>
  </participant>
  <participant participant_id="MTAw">
    <nameID aor="100@10.33.8.52"></nameID>
  </participant>
  <stream stream_id="mBfiAAAAAL1hFQENAPA=" session_
id="OWc4Md2PHao=">
    <label>1</label>
  </stream>
  <stream stream_id="hBfiAAAAAL1hFQENAPA=" session_
id="OWc4Md2PHao=">
    <label>2</label>
  </stream>
  <sessionrecordingassoc session_id="OWc4Md2PHao=">
    <associate-time>2018-04-17T09:35:41</associate-time>
  </sessionrecordingassoc>
  <participantsessionassoc participant_id="MjAw" session_
id="OWc4Md2PHao=">
    <associate-time>2018-04-17T09:35:41</associate-time>
  </participantsessionassoc>
  <participantsessionassoc participant_id="MTAw" session_
id="OWc4Md2PHao=">
    <associate-time>2018-04-17T09:35:41</associate-time>
  </participantsessionassoc>
  <participantstreamassoc participant_id="MjAw">
    <send>mBfiAAAAAL1hFQENAPA=</send>
    <recv>hBfiAAAAAL1hFQENAPA=</recv>
  </participantstreamassoc>
  <participantstreamassoc participant_id="MTAw">
    <send>hBfiAAAAAL1hFQENAPA=</send>
    <recv>mBfiAAAAAL1hFQENAPA=</recv>
  </participantstreamassoc>
</recording>

```

### SIPREC for SRTP Calls

The device can also record SRTP calls and send it to the SRS in RTP, or vice versa. For this functionality, configure the 'SBC Media Security Mode' parameter of the IP Profile that is associated with the SRS's IP Group to **Secured** or **Not Secured**, respectively. If you need to record the call in a coder that is different to the coder used in the call, the device can also be located between an SRS and an SRC to perform coder transcoding. In this setup, the device receives SIP recording sessions from the SRC and transcodes the media between the SRC and SRS, and then forwards the recording to the SRS in the transcoded media format.



## SIPREC for Real-Time Text

The device can record real-time text (RTT) in SBC sessions. RTT is carried in RTP and allows text to be sent immediately as it's created through wireless handsets that use IP-based technology on networks that support RTT.

For recording audio with RTT calls (i.e., two media streams), additional SBC media channel resources are required. For example, recording 100 SBC sessions of which 30 contain RTT, the following licenses are required: "SIPREC Streams" = 100, "SBC Sessions" = 100, and "SBC Media" = 60 (30 for the RTT sessions + 30 for the RTT sessions sent to SRS).




Recording of RTT is applicable only to the SBC application.

## Sending SIPREC to Multiple SRSs

The device can send recorded SBC calls to multiple SRSs. To achieve this, you need to configure groups of SRSs, where each group can contain one SRS (standalone) or two SRSs operating in an active-standby (1+1) mode for SRS redundancy. For the maximum number of supported SRSs, see the note below.

For standalone SRSs, the device sends both SIP signaling and RTP to all SRSs. For SRS redundancy, the device sends SIP signaling to all SRSs (active and standby), but sends RTP only to the active SRSs. If during a recorded call session, the standby SRS detects that the active SRS has gone offline, the standby SRS sends a re-INVITE to the device and the device then sends the recorded RTP to the standby SRS instead (which now becomes the active SRS). For new calls, if the device receives no response or a reject response from the active SRS to its' sent INVITE message, the device sends the recorded call to the standby SRS.





- For Gateway calls, the device can send recordings of a call to only one SRS.
- For SIPREC that is triggered by the device's REST API, the device can send recordings of a call to only one SRS.
- The device can send recordings (media) to up to six active SRSs. In other words, any one of the following configurations are supported:
  - ✓ Up to six standalone (active) SRSs.
  - ✓ Up to six active-standby SRS pairs (i.e., 12 SRSs, but recordings are sent to the six active SRSs only).
  - ✓ Combination of standalone SRSs and active-standby SRS pairs, for example:
    - > One standalone (active) SRS and five active-standby SRS pairs.
    - > Five standalone (active) SRSs and one active-standby SRS pair.
- SRS active-standby functionality must also be supported by the third-party SRS. For supported third-party SRS vendors, contact your AudioCodes sales representative.
- SRS active-standby redundancy is a license-dependent feature and is available only if it is included in the License Key installed on the device (see [Viewing the License Key](#) on page 1233). Therefore, the SIPREC feature can require two licenses – the regular license ("SIPREC Streams") for standalone (active) SRSs and a license for SRS active-standby redundancy ("SIPREC Redundancy Streams"). If you are implementing only standalone SRSs, you only need the "SIPREC Streams" license. If you are implementing SRS active-standby redundancy, you need both licenses.
- The "SIPREC Streams" license defines the maximum number of sessions for active SRSs (standalone SRS and the active SRS in the active-standby redundancy pair). The "SIPREC Redundancy Streams" license defines the maximum number of SIPREC sessions for the standby SRS in the active-standby redundancy pair. For example, if you want to support 10 SIPREC sessions per SRS, the required licenses for various scenarios are as follows:
  - ✓ One standalone SRS: "SIPREC Streams" = 10
  - ✓ Two standalone SRSs: "SIPREC Streams" = 20
  - ✓ One active-standby redundancy pair: "SIPREC Streams" = 10; "SIPREC Redundancy Streams" = 10
  - ✓ Two active-standby redundancy pairs: "SIPREC Streams" = 20; "SIPREC Redundancy Streams" = 20
  - ✓ One standalone SRS and two active-standby redundancy pairs: "SIPREC Streams" = 30; "SIPREC Redundancy Streams" = 20

### Load Balancing SIPREC SRSs using IP Group Set

The device can send SIPREC sessions to a group of IP Groups (SRSs) that are defined by an IP Group Set. An IP Group Set is a group of IP Groups and is used for load balancing of calls (configured in [Configuring IP Group Sets](#) on page 1113). Each time the device sends a SIPREC session, it chooses the IP Group (SRS) based on the IP Group Set's load-balancing policy (i.e., round-robin, homing, or random weight).

When you configure a SIP Recording rule (see [Configuring SIP Recording Rules](#) on the next page), the IP Group Set is defined by the 'Recording Server (SRS) IP Group Set' parameter.



This feature is applicable only to the SBC application.

## Configuring SIP Recording Rules

The SIP Recording Rules table lets you configure up to 30 SIP-based media recording (SIPREC) rules. A SIP Recording rule defines call routes that you want to record. For an overview of the feature, see [SIPREC SIP-based Media Recording](#) on page 330.



- To configure the device's timestamp format (local or UTC) in SIP messages sent to the SRS, see the [SIPRecTimeStamp] parameter.
- When recording SRTP-to-SRTP calls, if you want to send the recorded media to the SRS as RTP (i.e., decrypted), add an IP Profile for the SRS and configure its 'SBC Media Security Mode' parameter to **Not Secured** (see [Configuring IP Profiles](#) on page 664).
- If you configure a SIP Recording rule for calls that have also been configured for direct media (media bypass) by a SIP Interface ('Direct Media' parameter) or an IP Profile ('Direct Media Tag' parameter), the device automatically disables direct media for these calls (during their SIP signaling setup). This ensures that media traverses the device so that it can be recorded and sent to the SRS. However, if you enable direct media using the [SBCDirectMedia] global parameter (i.e., all calls), or calls whose incoming SIP dialog-initiating request contain the proprietary header X-AC-Action with the value 'direct-media' (i.e., 'X-AC-Action: direct-media'), direct media is always enforced and calls aren't recorded.
- To view the number of currently active SIPREC signaling sessions, use the CLI command `show voip calls statistics siprec`. For more information, refer to the document [CLI Reference Guide](#).

The following procedure describes how to configure SIP Recording rules through the Web interface. You can also configure it through ini file [SIPRecRouting] or CLI (`configure voip > sip-definition sip-recording sip-rec-routing`).

### ➤ To configure a SIP Recording rule:

1. Open the SIP Recording Rules table (**Setup** menu > **Signaling & Media** tab > **SIP Recording** folder > **SIP Recording Rules**).
2. Click **New**; the following dialog box appears:

SIP Recording Rules

GENERAL		RECORDING SERVER	
Index	0	Recording Server (SRS) IP Group	-- View
Recorded IP Group	Any View	Redundant Recording Server (SRS) IP Group	-- View
Recorded Source Pattern	*	Recording Server (SRS) IP Group Set	-- View
Recorded Destination Pattern	*		
Condition	-- View		
Peer IP Group	Any View		
Peer Trunk Group ID	-1		
Caller	Both		
Trigger	Call Connect		
Recording Server Role			

The following configuration records calls made by IP Group "ITSP" to IP Group "IP-PBX" that have the destination number prefix "1800". The device records the calls from the leg interfacing with IP Group "IP PBX" (peer) and sends the recorded media to IP Group "SRS-1". SRS redundancy has also been configured, where IP Group "SRS-1" is the active SRS and IP Group "SRS-2" the standby SRS.

- 'Recorded IP Group': "ITSP"
- 'Recorded Destination Pattern': "1800"
- 'Peer IP Group': "IP-PBX"
- 'Caller': **Peer Party**
- 'Recording Server (SRS) IP Group': "SRS-1"
- 'Redundant Recording Server (SRS) IP Group': "SRS-2"

1. Configure a SIP recording rule according to the parameters described in the table below.
2. Click **Apply**, and then save your settings to flash memory.

**Table 16-6: SIP Recording Rules Table Parameter Descriptions**

Parameter	Description
General	
'Index' [Index]	Defines an index number for the new table record.
'Recorded IP Group' recorded-ip-group-name [RecordedIPGroupName]	<p>Assigns an IP Group from the IP Groups table (see <a href="#">Configuring IP Groups</a> on page 581) to represent the entity participating in the call. Recording is done on the leg interfacing with this IP Group.</p> <p>The default is <b>Any</b> (i.e., all IP Groups).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> <li>■ For an SBC RTP-SRTP session, the recorded IP Group must be set to the RTP leg if recording is required to be RTP, or set to the SRTP leg if recording is required to be SRTP.</li> </ul>
'Recorded Source Pattern' recorded-src-pattern [RecordedSourcePrefix]	<p>Defines calls to record based on source number or SIP URI.</p> <p>You can use special patterns (notations) to denote the number or URI. For example, if you want to match this rule to user parts whose last four digits (i.e., suffix) are 4 followed by any three digits (e.g., 4008), then configure this parameter to "(4xxx)". For available</p>

Parameter	Description
	<p>patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The default value is the asterisk (*) symbol, meaning any source number or URI.</p>
'Recorded Destination Pattern' recorded-dst-prefi [RecordedDestinationPrefix]	<p>Defines calls to record based on destination number or URI.</p> <p>You can use special patterns (notations) to denote the number or URI. For example, if you want to match this rule to user parts whose last four digits (i.e., suffix) are 4 followed by any three digits (e.g., 4008), then configure this parameter to "(4xxx)". For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The default value is the asterisk (*) symbol, meaning any destination number or URI.</p>
'Condition' condition-name [ConditionName]	<p>Assigns a Message Condition rule from the Message Conditions table ( see <a href="#">Configuring Message Condition Rules</a> on page 838) to the rule, which starts (activates) call recording upon a specific condition.</p> <p>For more information on using conditions with SIPREC, see <a href="#">Starting a SIPREC Session using Message Conditions</a> on page 345.</p>
'Peer IP Group' peer-ip-group-name [PeerIPGroupName]	<p>Assigns an IP Group from the IP Groups table (see <a href="#">Configuring IP Groups</a> on page 581) to represent the peer IP Group that is participating in the call.</p> <p>The default is <b>Any</b> (i.e., all IP Groups).</p>
'Peer Trunk Group ID' peer-trunk-group-id [PeerTrunkGroupID]	<p>Defines the peer Trunk Group that is participating in the call. To configure Trunk Groups, see <a href="#">Configuring Trunk Groups</a> on page 903.</p> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
'Caller' caller [Caller]	<p>Defines which calls to record according to which party is the caller.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Both</b> = (Default) Caller can be peer or recorded side</li> <li>■ [1] <b>Recorded Party</b> (in Gateway, IP-to-Tel call)</li> <li>■ [2] <b>Peer Party</b> (in Gateway, Tel-to-IP call)</li> </ul>

Parameter	Description
'Trigger' trigger [RecordingTrigger]	<p>Defines what triggers (starts) the device to record the call for this rule.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Call Connect</b> = (Default) Call recording is triggered when the call is established (200 OK or ACK received).</li> <li>■ [1] <b>REST</b> = Call recording is triggered when the device receives a REST request. For more information on SIPREC triggered by REST, see <a href="#">On-Demand SIPREC using REST</a> on page 352.</li> <li>■ [2] <b>Media Start</b> = Call recording is triggered upon the start of media. This can include early media (18x response prior to 200 OK, e.g., to play ring tone) or media after connect.</li> </ul> <p><b>Note:</b> For alternate call routing or forking scenarios, if SIPREC was triggered due to early media and another SIP 183/200 OK changes the destination which is not configured for recording, the device continues recording the call.</p>
'Recording Server Role' srs-role [SRSRole]	<p>Defines a condition (optional) based on role value for matching the rule when the recording is triggered by a REST request. For this rule to be chosen, the 'role' field in the incoming REST request message must contain this same value.</p> <p>The valid value is a string of up to 20 characters. By default, no value is defined.</p> <p>For more information on SIPREC triggered by REST, see <a href="#">On-Demand SIPREC using REST</a> on page 352.</p> <p><b>Note:</b> The parameter is applicable only when you configure the 'Trigger' parameter to <b>REST</b>.</p>
Recording Server	
'Recording Server (SRS) IP Group' srs-ip-group-name [SRSIPGroupName]	<p>Assigns an IP Group from the IP Groups table (see <a href="#">Configuring IP Groups</a> on page 581) to represent the SRS.</p> <p>By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you configure the parameter, use the default settings (i.e., not configured) for the 'Recording</li> </ul>

Parameter	Description
	<p>Server (SRS) IP Group Set' parameter.</p> <ul style="list-style-type: none"> <li>■ The SIP Interface for communicating with the SRS is according to the SRD that is assigned to the SRS IP Group (in the IP Groups table). If two SIP Interfaces are associated with the SRD - one for "SBC" and one for "GW" – the device uses the "SBC" SIP Interface. If no SBC SIP Interface type is configured, the device uses the "GW" interface (which means that SRS redundancy isn't supported).</li> </ul>
<p>'Redundant Recording Server (SRS) IP Group'</p> <p><code>srs-red-ip-group-name</code></p> <p>[SRSRedundantIPGroupName]</p>	<p>Assigns an IP Group from the IP Groups table (see <a href="#">Configuring IP Groups</a> on page 581) to represent the redundant SRS in the active-standby pair for SRS redundancy.</p> <p>By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ SRS redundancy is applicable only to the SBC application.</li> <li>■ The IP Group of the redundant SRS must be different to the IP Group of the main SRS (see the 'Recording Server (SRS) IP Group' parameter).</li> <li>■ If you configure the parameter, use the default settings (i.e., not configured) for the 'Recording Server (SRS) IP Group Set' parameter.</li> </ul>
<p>'Recording Server (SRS) IP Group Set'</p> <p><code>srs-ip-group-set-name</code></p> <p>[SRSIPGroupSetName]</p>	<p>Assigns an IP Group Set from the IP Group Set table (see <a href="#">Configuring IP Group Sets</a> on page 1113) to represent a group of SRSs (IP Groups) for load balancing. Each time the device sends SIPREC, it chooses a specific IP Group based on the IP Group Set's policy (i.e., round-robin, homing, or random weight).</p> <p>By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ This parameter is applicable only to the SBC application.</li> <li>■ If you configure this parameter, use the default settings (i.e., not configured) for the 'Recording Server (SRS) IP Group' and 'Redundant Recording Server (SRS) IP Group' parameters.</li> </ul>



## Starting a SIPREC Session using Message Conditions

You can start and stop the recording of calls (SIPREC) based on user-defined conditions. The condition is configured as a Message Condition rule in the Message Conditions table, which is then assigned to the SIP Recording rule in the SIP Recording Rules table. Only if the condition is met will the device start recording the call. The feature is typically configured using Message Condition rules together with Call Setup rules.

For this feature, you can use only the following keywords for the syntax of the Message Condition rule:

- var.global
- var.session.0
- srctags/dsttags

For more information on using the above syntax for message manipulation, refer to the *Syntax for SIP Message Manipulation Reference Guide*.

The following procedure provides a SIP Recording configuration example for using a condition with the "srctags" keyword to start recording a call for IP Group "ITSP" if the incoming SIP message contains the header, "X-Record:yes".

### ➤ To use conditions for SIPREC:

1. In the Call Setup Rules table (see [Configuring Call Setup Rules](#) on page 782), click **New**, and then configure a Call Setup rule with the following properties:
  - 'Index': 0
  - 'Rules Set ID': 1
  - 'Condition': header.X-Record=='yes'
  - 'Action Subject': srctags
  - 'Action Type': Modify
  - 'Action Value': 'record'
1. In the IP Groups table (see [Configuring IP Groups](#) on page 581), assign the Call Setup rule that you configured in the previous step to the IP Group that you want to record (i.e., the "Recorded IP Group"):
  - 'Call Setup Rules Set ID': 1
2. In the Message Conditions table (see [Configuring Message Condition Rules](#) on page 838), click **New**, and then configure a Message Condition rule with the following properties:
  - 'Index': 0
  - 'Name': CallRec
  - 'Condition': srctags == 'record'

3. In the SIP Recording Rules table, configure a SIP Recording rule as desired and assign it the Message Condition rule that you configured in the previous step:
  - 'Recorded IP Group': ITSP
  - 'Condition': CallRec

## Configuring Format of SIPREC Metadata

You can configure the format of the XML-based recording metadata that the device generates and includes in the SIP messages that it sends to the recording server (SRS). It is important that the device generates the metadata in a format that is acceptable by the SRS.


The device supports the following formats:

- **RFC 7865** - the device generates the recording metadata in a format that is according to RFC 7865, whereby all IDs (e.g., participant ID) are in Base64 format. This metadata format also includes additional XML tags with association information (e.g., "<participantsessionassoc>").
- **Legacy** (default) - The device generates the recording metadata in a "legacy" format, whereby the user part of the participant URI (source or destination) is used as the ID.

### ➤ To configure the format of the metadata:

1. Open the SIP Recording Settings page (**Setup** menu > **Signaling & Media** tab > **SIP Recording** folder > **SIP Recording Settings**).

**Figure 16-1: Configuring SIPREC Metadata Format**



2. From the 'SIP Recording Metadata Format' drop-down list, select the desired format.
3. Click **Apply**.

## Configuring Video Recording Synchronization

If you also want to record the video stream of audio-video calls, you need to configure a video synchronization timeout. When the video stream is also recorded, the device operates as follows:

1. Once the call is answered by the called UA (i.e., connected), the UAs' audio streams are connected and the device sends a SIP INVITE to the SRS. However, for correct video synchronization, the UAs' video streams are not yet connected at this stage.
2. When a SIP 200 OK response is received from the SRS and the UAs' ports have been negotiated, the device connects all video streams - the UAs' video stream and the recorded video stream (the recorded audio stream is also sent to the SRS at this stage). However, if the 200 OK from the SRS is not received within a user-defined video synchronization timeout, the device connects the video stream between the UAs.

➤ **To configure video synchronization timeout:**

1. Open the SIP Recording Settings page (**Setup** menu > **Signaling & Media** tab > **SIP Recording** folder > **SIP Recording Settings**).

**Figure 16-2: Configuring Video Recording Synchronization**



2. In the 'Video Recording Sync Timeout' field, enter a timeout for receiving the SIP 200 OK from the SRS.
3. Click **Apply**.

## On-demand SIPREC

The device supports on-demand SIPREC sessions that can be triggered by the following:

- SIP INFO messages - see [On-Demand SIPREC using SIP INFO Messages](#) below
- SIP 200 OK responses - see [On-Demand SIPREC using SIP 200 OK Responses](#) on page 350
- REST API - see [On-Demand SIPREC using REST](#) on page 352

### On-Demand SIPREC using SIP INFO Messages

The device supports on-demand SIPREC sessions that are triggered by the receipt of SIP INFO messages. The device can be triggered to start, pause, resume, or stop recording at any stage of a connected call. Therefore, this allows the device to do multiple recordings of a call.



- This feature doesn't require any configuration in the SIP Recording Rules table.
- The device can also be triggered to start a SIPREC session by the receipt of a SIP 200 OK response. For more information, see [On-Demand SIPREC using SIP 200 OK Responses](#) on page 350.
- The feature is applicable only to the SBC application.

The device starts, pauses, resumes, or stops recording upon the receipt of a SIP INFO message that contains AudioCodes proprietary X-AC-Action header. The syntax of the X-AC-Action header for SIPREC is shown below:

```
X-AC-Action: <Recording Action>;<SRS Type>=<SRS Entity>;recorded-
side=peer;call-recording-dest-username=<User Part>
```

Where:

- *<Recording Action>* specifies the recording action:
  - **start-siprec**: Starts recording.
  - **pause-siprec**: Pauses recording.

- **resume-siprec**: Resumes recording after it was paused.
  - **stop-siprec**: Stops recording.
- **<SRS Type>** indicates the device entity used to represent the SRS:
- **recording-ip-group**: SRS is defined by individual IP Groups (see [Configuring IP Groups](#) on page 581).
  - **recording-ip-group-set**: SRS is defined by IP Group Sets (see [Configuring IP Group Sets](#) on page 1113).
- **<SRS Entity>** specifies the SRS as an IP Group or IP Group Set by name or index number. Use a comma-separated list (without spaces) to specify multiple IP Groups or IP Group Sets.
- **recorded-side=peer** is an optional parameter, which you can use to indicate that recording be done on the peer side (i.e., not the side receiving this X-AC-Action header). This parameter is applicable only to the **start-siprec** recording action.
- **call-recording-dest-username** is an optional parameter, which defines the SIP user part of the Request-URI in the INVITE message (To header) that the sends to the SRS. The field can contain up to 60 characters. If this field is present, its value overrides the 'Recording Server (SRS) Destination Username' parameter settings, as described in [Configuring SIP User Part for SRS](#) on page 354.

The following shows an example of an incoming SIP INFO message that triggers the device to start a SIPREC session for the call and using IP Groups "SRS-SiteA" and "SRS-SiteB" as the SRSs:

```
INFO sip:alice@pc33.example.com SIP/2.0
Via: SIP/2.0/UDP 192.0.2.2:5060;branch=z9hG4bKnabcdef
To: Bob <sip:bob@example.com>;tag=a6c85cf
From: Alice <sip:alice@example.com>;tag=1928301774
Call-Id: a84b4c76e66710@pc33.example.com
CSeq: 314333 INFO
X-AC-Action: start-siprec;recording-ip-group="SRS-SiteA,SRS-SiteB";call-
recording-dest-username=username_abc
Content-Length: 0
```



If a parameter's value contains one or more spaces (e.g., `recording-ip-group="SIPREC SRS"`) or the parameter has multiple values, which must be separated by commas (e.g., `recording-ip-group="SRS-SiteA,SRS-SiteB"`), enclose the value in double quotation marks ("...").

You can specify different SRS IP Groups or IP Group Sets per recording action for the same call. For example, the SIPREC session can be started (`start-siprec`) on SRS IP Groups *x*, *y* and *z*, and then later paused (`pause-siprec`) on SRS IP Group *y* only.

If the X-AC-Action header contains only **start-siprec**, use the device's Message Manipulation feature (see [Configuring SIP Message Manipulation](#) on page 829) to add 'recording-ip-

group="<SRS IP Groups or IP Group Sets>" and optionally, 'recorded-side=peer' to indicate if recording should be done on the peer sided. Assign the Message Manipulation Set ID to the IP Group of the sender of the SIP INFO message (i.e., not the SRS IP Group). The following shows an example of such a Message Manipulation rule:

- 'Name': SRS IP Group for Start SIPREC
- 'Manipulation Set ID': 0
- 'Message Type': **Info**
- 'Condition': **Header.X-AC-Action contains 'start-siprec'**
- 'Action Subject': **Header.X-AC-Action**
- 'Action Type': **Modify**
- 'Action Value': **'start-siprec;recording-ip-group="IPGroup\_2"'**



The manipulated parameters of the X-AC-Action header in the incoming INFO message are not reflected in the message of the outgoing leg.



- For stopping recordings, if the X-AC-Action header contains the **recording-ip-group** or **recording-ip-group-set** parameter, only recording towards the specified SRS IP Group(s) / IP Group Set(s) is stopped. If the header doesn't contain these parameters, all recordings that were triggered by INFO messages are stopped.
- The device rejects the INFO message (with a 500 response) if any of the following scenarios exist (**call is not affected**):
  - ✓ The **recording-ip-group** or **recording-ip-group-set** parameter doesn't exist.
  - ✓ The X-AC-Action header contains no parameters.
  - ✓ Starting, pausing, resuming, or stopping recording were not all triggered by SIP INFO messages (as described in this section). For example, if starting recording was triggered by the normal SIP Recording Rules table and stopping recording was triggered by a SIP INFO message containing the X-AC-Action header with the **stop-siprec** parameter, the device rejects the INFO message.
  - ✓ The X-AC-Action header contains the **stop-siprec**, **pause-siprec**, or **resume-siprec** parameter even though SIP recording wasn't started.
  - ✓ The X-AC-Action header contains the **resume-siprec** parameter even though SIP recording wasn't paused.
  - ✓ The X-AC-Action header contains the **start-siprec** parameter on a recorded-side while there is an active SIPREC session on the other side.
  - ✓ The X-AC-Action header contains the **recorded-side=peer** parameter when triggered to pause, resume or stop recording. In this scenario, the trigger (e.g., pause) is activated even though a SIP 500 is sent.
  - ✓ Six recording sessions are already in progress (maximum).
- The device forwards information in SIP INFO messages such as the transcript of the call from the SRS to the initiator of the on-demand SIPREC session.

## On-Demand SIPREC using SIP 200 OK Responses

The device supports on-demand SIPREC sessions that are triggered (started) by the receipt of SIP 200 OK responses. The 200 OK response must contain AudioCodes proprietary X-AC-Action header with the value 'start-siprec' to initiate recording.

Once the device is triggered by a 200 OK response to start a SIPREC session, it can then be triggered to pause, resume, or stop recording at any stage of the call by the receipt of SIP INFO messages. For more information, see [On-Demand SIPREC using SIP INFO Messages](#) on page 347.



- This feature applies only to SIP 200 OK messages received in response to **initial** SIP INVITE requests.
- This feature doesn't require any configuration in the SIP Recording Rules table.
- Upon the receipt of a SIP 200 OK response with the X-AC-Action header, the device doesn't trigger SIPREC in the following scenarios:
  - ✓ The X-AC-Action header doesn't contain any parameters.
  - ✓ The X-AC-Action header contains the 'start-siprec' parameter, but not the 'recording-ip-group' or 'recording-ip-group-set' parameter.
  - ✓ Six SIPREC sessions are currently active (maximum).
  - ✓ The X-AC-Action header contains the 'start-siprec' parameter on a recorded-side while there is an active SIPREC session on the other side.
- The feature is applicable only to the SBC application.

The X-AC-Action header in the incoming SIP 200 OK response can also indicate the IP Group representing the SIPREC Session Recording Server (SRS), and the leg of the call to record. This information is provided in the X-AC-Action header using the following parameters and syntax:

X-AC-Action: start-siprec;<SRS Type>=<SRS Name>;recorded-side=peer;call-recording-dest-username=<User Part>

where:

- <SRS Type> indicates if the SRS is an IP Group or IP Group Set:
  - **recording-ip-group** - SRS is defined by an IP Group(s). For configuring IP Groups, see [Configuring IP Groups](#) on page 581.
  - **recording-ip-group-set** - SRS is defined by an IP Group Set(s). For configuring IP Group Sets, see [Configuring IP Group Sets](#) on page 1113.
- <SRS Name> specifies the name or index number of the IP Group or IP Group Set. To specify multiple IP Groups or IP Group Sets, separate each with a comma (without spaces).
- **recorded-side=peer** is an optional parameter indicating that recording must be done on the peer side. If this parameter is absent, the device records the side that received the X-AC-Action header.
- **call-recording-dest-username** is an optional parameter, which defines the SIP user part of the Request-URI in the INVITE message (To header) that the sends to the SRS. The field can

contain up to 60 characters. If this field is present, its value overrides the 'Recording Server (SRS) Destination Username' parameter settings, as described in [Configuring SIP User Part for SRS](#) on page 354.

The following shows an example of an incoming SIP 200 OK response that triggers the device to start a SIPREC session for the call and uses IP Group "SIPREC SRS" as the SRS:

```
SIP/2.0 200 OK
Via: SIP/2.0/UDP 127.0.0.1;branch=z9hG4bKac1275750210
From: <sip:100@127.0.0.1;user=phone>;tag=1c232314132
To: <sip:200@127.0.0.1;user=phone>;tag=KQFIDPYDOBRHFIBVVBVE
Call-ID: 179268804129202415845@127.0.0.1CSeq: 1 INVITE
Contact: <sip:100@127.0.0.1>
X-AC-Action: start-siprec;recording-ip-group="SIPREC SRS";call-recording-
dest-username=username_abc
Supported: em,100rel,timer,replaces
Allow:
REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE
Server: Sip Message Generator V2.2.2.0
Content-Type: application/sdp
Content-Length: 214
```



- If a parameter's value contains one or more spaces (e.g., recording-ip-group="SIPREC SRS") or the parameter has multiple values, which must be separated by commas (e.g., recording-ip-group="SRS-SiteA,SRS-SiteB"), you must enclose the value in double quotation marks ("...").
- If you want to record calls whose incoming SIP 200 OK responses lack the 'X-AC-Action: start-siprec' header, use SIP Message Manipulation rules to add the header.

If the X-AC-Action header contains only **start-siprec**, use the device's Message Manipulation feature (see [Configuring SIP Message Manipulation](#) on page 829) to add the parameters 'recording-ip-group' and optionally, 'recorded-side=peer'. The following shows an example of a Message Manipulation rule that indicates the use of a specific IP Group:

- 'Name': SRS for Start SIPREC by 200 OK
- 'Manipulation Set ID': 0
- 'Message Type': **Message.Response.200**
- 'Condition': **Header.X-AC-Action contains 'start-siprec'**
- 'Action Subject': **Header.X-AC-Action**
- 'Action Type': **Modify**
- 'Action Value': **'start-siprec;recording-ip-group="SIPREC SRS"'**

Once configured, assign the Manipulation Set ID to the IP Group that sends the SIP 200 OK responses (i.e., not IP Group of SRS).



- The manipulated parameters of the X-AC-Action header in the incoming 200 OK response are not reflected in the message of the outgoing leg.
- If you want to record calls whose incoming SIP 200 OK responses lack the 'X-AC-Action: start-siprec' header, you can also use SIP Message Manipulation rules to add the header.

### On-Demand SIPREC using REST

The device supports on-demand SIPREC sessions that are triggered through the device's REST API (in HTTP POST requests) at the REST URL <device's IP address>/api/v1/sip/sipRecording. This method can trigger the device to start or stop recording a call (beginning of the call or during the call).

The incoming REST message for triggering SIPREC includes the following fields:

- **command:** (Mandatory) This field tells the device to start ("start") or stop ("stop") recording.
- **callKey:** (Mandatory) This field contains a "Call Key" value that the device uses to determine which call to record. This is required because REST messages are sent out of call context (i.e., not in SIP messages).

To associate a "Call Key" value with incoming calls belonging to a specific IP Group for which you want to record (according to the rules in the SIP Recording Rules table), you need to use SIP message manipulation to obtain this value from some element in the incoming SIP INVITE message (for example, from a specific header). The "Call Key" is specified in message manipulation using the syntax variable *Param.Call.HashKey* or *Param.Peer-Call.HashKey* in the 'Action Subject' parameter. If the device receives a REST request whose "CallKey" field contains the same value as the "Call Key" value obtained by message manipulation, then the device records this call.

The usage of the syntax variable *Param.Call.HashKey* and *Param.Peer-Call.HashKey* in message manipulation rules depends on the following:

- If the rule is assigned using the 'Inbound Message Manipulation Set' parameter for the source IP Group:
  - ◆ *Param.Call.HashKey* represents the incoming call leg.
  - ◆ *Param.Peer-Call.HashKey* represents the outgoing call leg.
- If the rule is assigned using the 'Outbound Message Manipulation Set' parameter for the destination IP Group:
  - ◆ *Param.Call.HashKey* represents the outgoing call leg.
  - ◆ *Param.Peer-Call.HashKey* represents the incoming call leg.





Such rules are used internally **only** by the device (to store the "Call Key" value) and don't modify the outgoing INVITE message.

- **role:** (Optional) This field is used by the device as an additional condition in the SIP Recording Rules table ('Recording Server Role' parameter) for finding a matching rule. If the value of this field is the same as that configured in the SIP Recording Rules table, the device uses the rule. The field can contain up to 20 characters.
- **callRecordingDestUsername:** (Optional) This field defines the SIP user part of the Request-URI in the INVITE message (To header) that the device sends to the SRS. The field can contain up to 60 characters. If this field is present, its value overrides the 'Recording Server (SRS) Destination Username' parameter settings, as described in [Configuring SIP User Part for SRS](#) on the next page.
- **headers:** (Optional and applicable only to Command: "start") This is an array of objects that defines up to 10 additional headers (**name** field) and their values (**value** field) to include in the SIP INVITE message that the device sends to the SRS.



When the REST request contains the "Command: stop":

- If it also contains **only** the "callKey" field, the device stops the recording of all REST-triggered SIPREC sessions that have the same call key value and that don't have a role defined for them.
- If it also contains the "callKey" and "role: <a value>" fields, the device stops the recording of all REST-triggered SIPREC sessions that have the same call key value and whose rule in the SIP Recording Rules table was matched by the same role value ('Recording Server Role' parameter).
- If it also contains **only** the "callKey" and "callRecordingDestUsername" fields, the device stops the recording of all REST-triggered SIPREC sessions that have the same call key value, had an empty "role" field, and used the same destination username as specified by "callRecordingDestUsername".
- If it also contains the "callKey" and "role: <a value>", and "callRecordingDestUsername", the device stops the recording of all REST-triggered SIPREC sessions that have the same call key value, had the same "role" value, and same destination username as specified by "callRecordingDestUsername".

The following are examples of REST requests for triggering SIPREC:

- REST request to start recording, containing only mandatory fields:

```
{
  "command": "start"
  "callKey": "aaa",
}
```

- REST request to start recording, containing all fields:

```
{
  "command": "start",
  "callKey": "aaa",
  "role": "agent_assist",
  "callRecordingDestUsername": "username_abc",
  "headers": [
    {
      "name": "x1-header",
      "value": "x1-header_value"},
    {
      "name": "x2-header",
      "value": "x2-header_value"
    }
  ]
}
```

➤ **To configure SIPREC triggered by REST:**

1. Open the SIP Recording Rules table (see [Configuring SIP Recording Rules](#) on page 340), and then add a rule that is also configured with the following parameters:
  - 'Trigger' = **REST**
  - (Optional) 'Recording Server Role' = <same value as will be in the "role" field of REST requests>
2. Configure SIP message manipulation rule to obtain the "Call Key" value, using the syntax *Param.Call.HashKey* or *Param.Peer-Call.HashKey*. For example, the following rule in the Message Manipulations table obtains the call key value from the SIP header "X-ConversationId":

The screenshot shows the 'Message Manipulations' configuration window. It is divided into two main sections: 'GENERAL' and 'ACTION'.

**GENERAL Section:**

- Index: 0
- Name: SIPREC: CallKey
- Manipulation Set ID: 0
- Row Role: Use Current Condition

**MATCH Section:**

- Message Type: Invite Request
- Condition: Header:X-ConversationId exists

**ACTION Section:**

- Action Subject: Param.Call.HashKey
- Action Type: Modify
- Action Value: Header:X-ConversationId

3. Assign the Message Manipulation rule (Set ID) to the IP Group (see beginning of this section regarding inbound and outbound manipulation).

## Configuring SIP User Part for SRS

You can configure the SIP user part of the Request-URI for the recording server (SRS). The device inserts this user part in the SIP To header of the INVITE message sent to the SRS.

➤ **To configure the SIP user part for SRS:**

1. Open the SIP Recording Settings page (**Setup** menu > **Signaling & Media** tab > **SIP Recording** folder > **SIP Recording Settings**).
2. In the 'Recording Server (SRS) Destination Username' field, enter a user part value (string of up to 50 characters).

Recording Server (SRS) Destination Username

3. Click **Apply**.



When SIPREC is triggered by REST, the incoming REST message may also specify the user part name. If this occurs, the above 'Recording Server (SRS) Destination Username' parameter is ignored. For more information on REST-triggered SIPREC, see [On-Demand SIPREC using REST](#) on page 352.

## **Sending DTMF Digits Notifications using SIP INFO Messages to SRS**

You can configure the device to send DTMF digits notifications to the SIPREC SRS. These notifications are sent using SIP INFO messages. On the incoming leg (caller), all DTMF formats (i.e., RFC 2833, INFO, or in-band) are supported; on the outgoing leg (callee), only DTMF digits from SIP INFO messages are supported.

For example (assuming "A" is the caller):

- "A" sends DTMF (any format): The device sends an INFO message to the SRS and to "B" (which must support sending and receiving INFO messages).
- "B" sends DTMF in INFO message: The device forwards the INFO message to the SRS and sends the DTMF to "A" in the required format.

➤ **To send SIP INFO messages with DTMF to SRS:**

1. Open the SIP Recording Settings page (**Setup** menu > **Signaling & Media** tab > **SIP Recording** folder > **SIP Recording Settings**).
2. From the 'Forward Signaling to SIPREC' drop-down list, select **DTMF SIP INFO**:

Forward Signaling to SIPREC

DTMF SIP INFO



3. Click **Apply**.



- The device adds the Remote-Party-ID header to the SIP INFO message that is sent to the SRS. The header's value is the URI of the sender of the DTMF digits.
- This feature is applicable only to the SBC application.

## Interworking SIP-based Media Recording with Third-Party Vendors

The device can interwork the SIP-based Media Recording feature with third-party vendors, as described in the following subsections.

### SIPREC with Genesys Equipment

The device's SIP-based media recording can interwork with Genesys' equipment. Genesys sends its proprietary X-Genesys-CallUUID header (which identifies the session) in the first SIP message, typically in the INVITE and the first 18x response. If the device receives a SIP message with Genesys SIP header, it adds the header's information to the AudioCodes' proprietary tag in the XML metadata of the SIP INVITE that it sends to the recording server, as shown below:

```
<ac:GenesysUUID  
xmlns="urn:ietf:params:xml:ns:Genesys">4BOKLLA3VH66JF112M1CC9VHKS14  
F0KP</ac:GenesysUUID>
```

No configuration is required for this support.

### SIPREC with Avaya Equipment

The device's SIP-based media recording can interwork with Avaya equipment. The Universal Call Identifier (UCID) is Avaya's proprietary call identifier used to correlate call records between different systems and identifies sessions. Avaya generates this in outgoing calls. If the device receives a SIP INVITE from Avaya, it adds the UCID value, received in the User-to-User SIP header to the AudioCodes proprietary tag in the XML metadata of the SIP INVITE that it sends to the recording server. For example, if the received SIP header is:

```
User-to-User: 00FA080019001038F725B3;encoding=hex
```

the device includes the following in the XML metadata:

```
xml metadata:  
<ac:AvayaUCID xmlns="urn:ietf:params:xml:ns:Avaya">  
FA080019001038F725B3</ac:AvayaUCID>
```



For calls sent from the device to Avaya equipment, the device can generate the Avaya UCID, if required. To configure this support, use the following parameters:

- 'UUI Format' in the IP Groups table - enables Avaya support.
- 'Network Node ID' - defines the Network Node Identifier of the device for Avaya UCID.

## Customizing Recorded SIP Messages Sent to SRS

The original SIP headers of recorded legs are not included in the INVITE messages that the device sends to the SRS. If you need to include SIP headers, you can use Message Manipulation rules (see [Configuring SIP Message Manipulation](#) on page 829) to add them to these INVITE messages. The following examples describe how to configure this using Message Manipulation rules:

- **Example 1** - Adding a specific SIP header called "My-header" to the INVITE that is sent to the SRS:
  - a. The example uses two Message Manipulation rules - one for storing the header by using manipulation syntax for session variables, and one for adding the header to the INVITE.

Parameter	Value
Index	0
Name	Store My-header in var.session
Manipulation Set ID	11
Message Type	Any
Condition	Header.My-header exists And Header.My-header != "
Action Subject	Var.Session.0
Action Type	Modify
Action Value	Header.My-header
Index	1
Name	Send My-header to SRS
Manipulation Set ID	12
Message Type	Invite.Request
Condition	Var.Session.0 != "
Action Subject	Header.My-header
Action Type	Add
Action Value	Var.Session.0

- b. Assign the above manipulation rules to the relevant IP Groups:

- ◆ In the IP Group of the recorded call leg which sends this header, configure the 'Inbound Message Manipulation Set' parameter to 11 (i.e., rule configured in Index 0).
- ◆ In the IP Group of the SRS, configure the 'Outbound Message Manipulation Set' parameter to 12 (i.e., rule configured in Index 1).

■ **Example 2** - Adding multiple (three) SIP headers called "My-header1", "My-header2" and "My-header3" to the INVITE that is sent to the SRS:

- a. The example uses regex (regular expression) with manipulation rules for extracting each header (a comma is used to separate headers).

Parameter	Value
Index	0
Name	Store headers in var.session
Manipulation Set ID	11
Message Type	Any
Condition	Header.My-header1 exists And Header.My-header2 exists And Header.My-header3 exists
Action Subject	Var.Session.0
Action Type	Modify
Action Value	Header.My-header1+', '+ Header.My-header2+', '+ Header.My-header3
Row Rule	Use Current Condition
Index	1
Name	Send My-header1 to SRS
Manipulation Set ID	12
Message Type	Invite.Request
Condition	Var.Session.0 regex (.*),(.*),(.*)
Action Subject	Header.My-header1
Action Type	Add
Action Value	\$1

Parameter	Value
Row Rule	Use Current Condition
Index	2
Name	Send My-header2 to SRS
Manipulation Set ID	12
Message Type	Invite.Request
Condition	Var.Session.0 regex (.*),(.*),(.*)
Action Subject	Header.My-header2
Action Type	Add
Action Value	\$2
Row Rule	Use Previous Condition
Index	3
Name	Send My-header3 to SRS
Manipulation Set ID	12
Message Type	Invite.Request
Condition	Var.Session.0 regex (.*),(.*),(.*)
Action Subject	Header.My-header3
Action Type	Add
Action Value	\$3
Row Rule	Use Previous Condition

**b.** Assign the above manipulation rules to the relevant IP Groups:

- ◆ In the IP Group of the recorded call leg which sends this header, configure the 'Inbound Message Manipulation Set' parameter to 11 (i.e., rule configured in Index 0).
- ◆ In the IP Group of the SRS, configure the 'Outbound Message Manipulation Set' parameter to 12 (i.e., rules configured in Index 1, 2 and 3).

## RADIUS-based Services

The device supports Remote Authentication Dial In User Service (RADIUS) by acting as a RADIUS client. You can use RADIUS for the following:

- Authentication and authorization of management users (login username and password) to gain access to the device's management interface.
- Accounting where the device sends accounting data of SIP calls as call detail records (CDR) to a RADIUS Accounting server (for third-party billing purposes).



The device also supports the following user login authentication methods:

- LDAP-based authentication (see [LDAP-based Services](#) on page 369)
- OAuth-based authentication (see [OAuth-based User Login Authentication and Authorization](#) on page 408)

## Enabling RADIUS Services

Before you can implement any RADIUS services, you must enable the RADIUS feature, as described in the procedure below.

### ➤ To enable RADIUS:

1. Open the Authentication Server page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Authentication Server**).
2. Select the 'Enable RADIUS Access Control' check box:

Enable RADIUS Access Control



3. Click **Apply**, and then restart the device with a save-to-flash for your settings to take effect.

## Configuring RADIUS Servers

The RADIUS Servers table lets you configure up to three RADIUS servers. You can use RADIUS servers for RADIUS-based management-user login authentication and/or RADIUS-based accounting (sending of SIP CDRs to the RADIUS server).

When multiple RADIUS servers are configured, RADIUS server redundancy can be implemented. When the primary RADIUS server is offline, the device sends a RADIUS request twice (one retransmission) by default. If both requests fail (i.e., no response), the device considers the server as offline and attempts to send requests to the next server. The device continues sending RADIUS requests to the redundant RADIUS server even if the primary server returns to service later on. However, if a device restart occurs or an HA switchover occurs in a High-Availability (HA) system, the device sends RADIUS requests to the primary RADIUS server. By default, the device waits for up to two seconds (i.e., timeout) for a response from the RADIUS server for RADIUS requests and retransmission before it considers the server as offline.





You can configure the number of retransmission attempts with the RADIUS server before the device considers it as offline. For more information, see [Configuring RADIUS Packet Retransmission](#) on page 364.

For each RADIUS server, an IP address, IP Interface, port, and shared secret can be configured. Each RADIUS server can be defined for RADIUS-based login authentication and/or RADIUS-based accounting. By setting the relevant port (authentication or accounting) to "0" disables the corresponding functionality. If both ports are configured, the RADIUS server is used for authentication and accounting. All servers configured with non-zero Authorization ports form an Authorization redundancy group and the device sends authorization requests to one of them, depending on their availability. All servers configured with non-zero Accounting ports form an Accounting redundancy group and the device sends accounting CDRs to one of them, depending on their availability. Below are example configurations:

- Only one RADIUS server is configured and used for authorization and accounting purposes (no redundancy). Therefore, both the Authorization and Accounting ports are defined.
- Three RADIUS servers are configured:
  - Two servers are used for authorization purposes only, providing redundancy. Therefore, only the Authorization ports are defined, while the Accounting ports are set to 0.
  - One server is used for accounting purposes only (i.e., no redundancy). Therefore, only the Accounting port is defined, while the Authorization port is set to 0.
- Two RADIUS servers are configured and used for authorization and accounting purposes, providing redundancy. Therefore, both the Authorization and Accounting ports are defined.

The status of the RADIUS servers can be viewed through CLI:

```
# show system radius servers status
```

The example below shows the status of two RADIUS servers in redundancy mode for authorization and accounting:

```
servers 0
ip-address 10.4.4.203
auth-port 1812
auth-ha-state "ACTIVE"
acc-port 1813
acc-ha-state "ACTIVE"
servers 1
ip-address 10.4.4.202
auth-port 1812
auth-ha-state "STANDBY"
acc-port 1813
acc-ha-state "STANDBY"
```

Where *auth-ha-state* and *acc-ha-state* display the authentication and accounting redundancy status respectively. "ACTIVE" means that the server was used for the last sent authentication or accounting request; "STANDBY" means that the server was not used in the last sent request.



- To configure RADIUS-based accounting, see [Configuring RADIUS Accounting](#) on page 1456.
- The device can send up to 201 concurrent RADIUS requests per RADIUS service type (Accounting or Authentication), per RADIUS server (up to three servers per service type), and per local port (up to 1 local port).

The following procedure describes how to configure a RADIUS server through the Web interface. You can also configure it through ini file [RadiusServers] or CLI (`configure system > radius servers`).

➤ **To configure a RADIUS server:**

1. Open the RADIUS Servers table (**Setup** menu > **IP Network** tab > **AAA Servers** folder > **RADIUS Servers**).
2. Click **New**; the following dialog box appears:

3. Configure a RADIUS server according to the parameters described in the table below.
4. Click **Apply**.

**Table 16-7: RADIUS Servers Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'IP Address' ip-address [IPAddress]	Defines the IP address (IPv4 or IPv6) of the RADIUS server. By default, no value is defined (i.e., 0.0.0.0). <b>Note:</b> The IP address version (IPv4 or IPv6) of the

Parameter	Description
	RADIUS server's address and the assigned IP Interface (see 'Interface Name' parameter) must be the same.
'Authentication Port' auth-port [AuthenticationPort]	<p>Defines the port of the RADIUS Authentication server for authenticating the device with the RADIUS server. When set to any value other than 0, the RADIUS server is used by the device for RADIUS-based management-user login authentication. When set to 0, RADIUS-based login authentication is not implemented.</p> <p>The valid value is 0 to any integer. The default is 1645.</p>
'Accounting Port' acc-port [AccountingPort]	<p>Defines the port of the RADIUS Accounting server to where the device sends accounting data of SIP calls as call detail records (CDR). When set to any value other than 0, the RADIUS server is used by the device for RADIUS-based accounting (CDR). When set to 0, RADIUS-based accounting is not implemented.</p> <p>The valid value is 0 to any integer. The default is 1646.</p>
'Shared Secret' shared-secret [SharedSecret]	<p>Defines the shared secret (password) for authenticating the device with the RADIUS server. This should be a cryptically strong password. The shared secret is also used by the RADIUS server to verify the authentication of the RADIUS messages sent by the device (i.e., message integrity).</p> <p>The valid value is up to 48 characters. By default, no value is defined.</p> <p><b>Note:</b> The password cannot be configured with wide characters.</p>
'Interface Name' network-interface [InterfaceName]	<p>Assigns an IP Interface from the IP Interfaces table (see <a href="#">Configuring IP Network Interfaces</a> on page 157) for RADIUS communication.</p> <p>By default, no value is defined.</p> <p><b>Note:</b> The IP address version (IPv4 or IPv6) of the IP Interface and the RADIUS server's address (see 'IP Address' parameter above) must be the same.</p>

## Configuring RADIUS Packet Retransmission

You can configure the device to resend packets to the RADIUS server if no response is received from the server. This functionality is applicable to RADIUS-based user authentication and RADIUS-based accounting.

### ➤ To configure RADIUS packet retransmission:

1. Open the Authentication Server page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Authentication Server**).

RADIUS Response Timeout [sec]	<input type="text" value="2"/>
RADIUS Packets Retransmission	<input type="text" value="1"/>

2. Under the RADIUS group, do the following:
  - In the 'RADIUS Packets Retransmission' field (RADIUSRetransmission), enter the maximum number of RADIUS retransmissions that the device performs if no response is received from the RADIUS server.
  - In the 'RADIUS Response Time Out' field (RadiusTO), enter the interval (in seconds) that the device waits for a response before sending a RADIUS retransmission.
3. Click **Apply**.

## Configuring the RADIUS Vendor ID

The vendor-specific attribute (VSA) identifies the device to the RADIUS server using the Vendor ID (as registered with the Internet Assigned Numbers Authority or IANA). The device's default vendor ID is 5003 which can be changed, as described in the following procedure. For an example of using the Vendor ID, see [Setting Up a Third-Party RADIUS Server](#) on page 366. The procedure is applicable to both RADIUS-based user authentication and RADIUS-based accounting.



The Vendor ID must be the same as the Vendor ID set on the third-party RADIUS server. See the example for setting up a third-party RADIUS server in [Setting Up a Third-Party RADIUS Server](#) on page 366.

### ➤ To configure the RADIUS Vendor ID:

1. Open the Authentication Server page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Authentication Server**).

RADIUS VSA Vendor ID	<input type="text" value="5003"/>
----------------------	-----------------------------------

2. Under the RADIUS group, in the 'RADIUS VSA Vendor ID' field, enter the **same** vendor ID number as set on the third-party RADIUS server.

3. Click **Apply**.

## Securing RADIUS Messages with Message-Authenticator Attribute

For RADIUS-based user authentication, you can configure the device to secure RADIUS messages, using RADIUS attribute 80 (Message-Authenticator). This attribute ensures the integrity of RADIUS packets, safeguarding against unauthorized access (login) to the device (e.g., "man-in-the-middle" attacks).

You can configure this feature for incoming and outgoing RADIUS messages:

- **Outgoing RADIUS Messages:** You can enable the device (acting as a Network Access Server / NAS or RADIUS client) to include the Message-Authenticator attribute in all Access-Request RADIUS packets that it sends to the RADIUS server. This is applicable only to the Password Authentication Protocol (PAP) user authentication method. To enable this functionality, use the ini file parameter [RadiusPapRequireMsgAuthTx] or CLI command `rad-pap-req-msg-auth-tx`.



For RADIUS-based SIP message authentication, this parameter is not needed as it uses the digest protocol, which inherently includes the Message-Authenticator attribute.

- **Incoming RADIUS Messages:** You can enable the device to require the presence of the Message-Authenticator attribute in incoming Accept-Accept RADIUS messages received from the RADIUS server. If the attribute is not present, the device rejects the message and denies user login. This functionality is applicable to Digest or PAP authentication methods. To enable this functionality, use the ini file parameter [RadiusRequireMsgAuthRx] or CLI command `rad-req-msg-auth-rx`.

## RADIUS-based User Login Authentication

You can enhance security for your device by implementing Remote Authentication Dial-In User Service (RADIUS per RFCs 2865) for authenticating multiple management user accounts of the device's embedded Web and Telnet (CLI) servers. RADIUS also prevents unauthorized access to your device.

When RADIUS authentication is not used, the user's login username and password are locally authenticated by the device using the Local Users table (see [Configuring Local Management User Accounts](#) on page 54). However, you can configure the device to use the Local Users table as a fallback mechanism if the RADIUS server doesn't respond.




Both RADIUS and LDAP (see [Enabling LDAP-based User Login Authentication](#) on page 372) based login methods can't be used together; configure only one of them as the login method.



If you enable RADIUS-based user login authentication, when users with Security Administrator privilege level log in to the device's CLI, they are automatically given access to the CLI privileged mode (“#”). For all other user privilege levels, the user needs to run the **enable** command and then enter the password to access the CLI privileged mode.

When RADIUS authentication is used, the RADIUS server stores the user accounts - usernames, passwords, and access levels (authorization). When a management user (client) tries to access the device, the device sends the RADIUS server the user's username and password for authentication. The RADIUS server replies with an acceptance or a rejection notification. During the RADIUS authentication process, the device's Web interface is blocked until an acceptance response is received from the RADIUS server. Communication between the device and the RADIUS server is done using a shared secret, which is not transmitted over the network.



To implement RADIUS, you need to do the following:

- Set up a RADIUS server (third-party) to communicate with the device - see [Setting Up a Third-Party RADIUS Server](#) below
- Configure the device as a RADIUS client for communication with the RADIUS server - see [Configuring RADIUS-based User Authentication](#) on page 368

### Setting Up a Third-Party RADIUS Server

The following procedure provides an example for setting up a third-party RADIUS sever, *FreeRADIUS* which can be downloaded from [www.freeradius.org](http://www.freeradius.org). Follow the instructions on this Web site for installing and configuring the server. If you use a RADIUS server from a different vendor, refer to its appropriate documentation.

#### ➤ To set up a third-party RADIUS server (e.g., *FreeRADIUS*):

1. Define the device as an authorized client of the RADIUS server, with the following:

- Predefined *shared secret* (password used to secure communication between the device and the RADIUS server)
- Vendor ID (configured on the device in [Configuring the RADIUS Vendor ID](#) on page 364)

Below is an example of the *clients.conf* file (FreeRADIUS client configuration):

```
#
# clients.conf - client configuration directives
#
client 10.31.4.47 {
    secret      = FutureRADIUS
    shortname    = my_device
}
```

2. If access levels are required, set up a Vendor-Specific Attributes (VSA) dictionary for the RADIUS server and select an attribute ID that represents each user's access level. The example below shows a dictionary file for FreeRADIUS that defines the attribute "ACL-Auth-Level" with "ID=35". For the device's user access levels and their corresponding numeric representation in RADIUS servers, see [Configuring Local Management User Accounts](#) on page 54.

```
#
# AudioCodes VSA dictionary
#
VENDOR AudioCodes 5003
ATTRIBUTE ACL-Auth-Level 35 integer AudioCodes
VALUE ACL-Auth-Level ACL-Auth-UserLevel 50
VALUE ACL-Auth-Level ACL-Auth-AdminLevel 100
VALUE ACL-Auth-Level ACL-Auth-SecurityAdminLevel 200
```

3. Define the list of users authorized to use the device, using one of the password authentication methods supported by the server implementation. The example below shows a user configuration file for FreeRADIUS using a plain-text password:

```
# users - local user configuration database
john  Auth-Type := Local, User-Password == "qwerty"
      Service-Type = Login-User,
      ACL-Auth-Level = ACL-Auth-SecurityAdminLevel
sue   Auth-Type := Local, User-Password == "123456"
      Service-Type = Login-User,
      ACL-Auth-Level = ACL-Auth-UserLevel
```

4. Record and retain the IP address, port number, shared secret code, vendor ID, and VSA access level identifier (if access levels are implemented) used by the RADIUS server.

## Configuring RADIUS-based User Authentication

The following procedure describes how to configure RADIUS-based login authentication. For a detailed description of the RADIUS parameters, see [RADIUS Parameters](#) on page 1940.

### ➤ To configure RADIUS-based login authentication:

1. Open the Authentication Server page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Authentication Server**).
2. From the 'Use RADIUS for Web/Telnet Login' drop-down list, select **Enable** to enable RADIUS authentication for Web and Telnet login:
3. When implementing Web user access levels, do one of the following:
  - **If the RADIUS server response includes the access level attribute:** In the 'RADIUS VSA Access Level Attribute' field, enter the code that indicates the access level attribute in the VSA section of the received RADIUS packet. For defining the RADIUS server with access levels, see [Setting Up a Third-Party RADIUS Server](#) on page 366.

RADIUS VSA Access Level Attribute

35

- **If the RADIUS server response doesn't include the access level attribute:** From the 'Default Access Level' drop-down list, select the default access level that is applied to these users authenticated by the RADIUS server.

Default Access Level

Security Administrator

4. Configure RADIUS timeout handling:
  - a. From the 'Behavior upon Authentication Server Timeout' drop-down list, select the option if the RADIUS server doesn't respond within five seconds:
    - ◆ **Deny Access:** device denies user login access.
    - ◆ **Verify Access Locally:** device checks the username and password configured locally for the user in the Local Users table (see [Configuring Local Management User Accounts](#) on page 54), and if correct, allows access.
  - b. In the 'Password Local Cache Timeout' field, enter a time limit (in seconds) after which the username and password verified by the RADIUS server becomes invalid and a username and password needs to be re-validated with the RADIUS server.
  - c. From the 'Password Local Cache Mode' drop-down list, select the option for the local RADIUS password cache timer:
    - ◆ **Reset Timer Upon Access:** upon each access to a Web page, the timer resets (reverts to the initial value configured in the previous step).



- ◆ **Absolute Expiry Timer:** when you access a Web page, the timer doesn't reset, but continues its count down.

5. Configure when the Local Users table is used to authenticate users. From the 'Use Local Users Table for Authentication' drop-down list, select one of the options (for a description, see ['Use Local Users Table for Authentication'](#) on page 1939):

Use Local Users Table for Authentication

When No Auth Server Defined ▼

6. Click **Apply**, and then restart the device with a save-to-flash for your settings to take effect.

### Securing RADIUS Communication

RADIUS authentication requires HTTP basic authentication (according to RFC 2617). However, this is insecure as the usernames and passwords are transmitted in clear text over plain HTTP. Thus, as digest authentication is not supported with RADIUS, it is recommended that you use HTTPS with RADIUS so that the usernames and passwords are encrypted. To enable the device to use HTTPS, configure the 'Secured Web Connection (HTTPS)' parameter to **HTTPS Only** (see [Configuring Secured \(HTTPS\) Web and REST Access](#) on page 74).

### RADIUS-based User Authentication in URL

RADIUS authentication of the management user is typically done after the user accesses the Web interface by entering only the device's IP address in the Web browser's URL field (for example, <http://10.13.4.12/>) and then entering the username and password credentials in the Web interface's login screen. However, authentication with the RADIUS server can also be done immediately after the user enters the URL, if the URL also contains the login credentials. For example:

<http://10.4.4.112/Form-s/RadiusAuthentication?WSBackUserName=John&WSBackPassword=1234>.



This feature allows up to five simultaneous users only.

### RADIUS-based CDR Accounting

Once you have configured a RADIUS server(s) for accounting in [Configuring RADIUS Servers](#) on page 360, you need to enable and configure RADIUS-based CDR accounting (see [Configuring RADIUS Accounting](#) on page 1456).

### LDAP-based Services

The device supports the Lightweight Directory Access Protocol (LDAP) application protocol and can operate with third-party, LDAP-compliant servers such as Microsoft Active Directory (AD).

You can use LDAP for the following LDAP services:

- **SIP-related (Control) LDAP Queries:** LDAP can be used for routing and manipulation (e.g., calling name and destination address).

The device connects and binds to the remote LDAP server (IP address or DNS/FQDN) during the service's initialization (at device start-up) or whenever you change the LDAP server's IP address and port. Binding to the LDAP server is based on username and password (Bind DN and Password). Service makes 10 attempts to connect and bind to the remote LDAP server, with a timeout of 20 seconds between attempts. If connection fails, the service remains in disconnected state until the LDAP server's IP address or port is changed. If connection to the LDAP server later fails, the service attempts to reconnect.

For the device to run a search, the path to the directory's subtree, known as the distinguished name (DN), where the search is to be done must be configured (see [Configuring LDAP DNs \(Base Paths\) per LDAP Server](#) on page 383). The search key (filter), which defines the exact DN to search and one or more attributes whose values must be returned to the device must also be configured. For more information on configuring these attributes and search filters, see [Routing for Microsoft Teams or Skype for Business using Microsoft Entra ID](#) on page 397.

The device can store recent LDAP queries and responses in its local cache. The cache is used for subsequent queries and/or in case of LDAP server failure. For more information, see [Configuring the Device's LDAP Cache](#) on page 387.

If connection with the LDAP server disconnects (broken), the device sends the SNMP alarm, `acLDAPLostConnection`. Upon successful reconnection, the alarm clears. If connection with the LDAP server is disrupted during the search, all search requests are dropped and an alarm indicating a failed status is sent to client applications.

- **Management-related LDAP Queries:** LDAP can be used for authenticating and authorizing management users (Web and CLI) and is based on the user's login username and password (credentials) when attempting login to one of the device's management platforms. When configuring the login username (LDAP Bind DN) and password (LDAP Password) to send to the LDAP server, you can use templates based on the dollar (\$) sign, which the device replaces with the actual username and password entered by the user during the login attempt. You can also configure the device to send the username and password in clear-text format or encrypted using TLS (SSL).

The device connects to the LDAP server (i.e., an LDAP session is created) only when a login attempt occurs. The LDAP Bind operation establishes the authentication of the user based on the username-password combination. The server typically checks the password against the `userPassword` attribute in the named entry. A successful Bind operation indicates that the username-password combination is correct; a failed Bind operation indicates that the username-password combination is incorrect.

Once the user is successfully authenticated, the established LDAP session may be used for further LDAP queries to determine the user's management access level and privileges (Operator, Admin, or Security Admin). This is known as the user authorization stage. To determine the access level, the device searches the LDAP directory for groups of which the user is a member, for example:

```
CN=\# Support Dept,OU=R&D
Groups,OU=Groups,OU=APC,OU=Japan,OU=ABC,DC=corp,DC=abc,DC=com
CN=\#AllCellular,OU=Groups,OU=APC,OU=Japan,OU=ABC,DC=corp,DC=abc,DC=com
```

The device then assigns the user the access level configured for that group (in [Configuring Access Level per Management Groups Attributes](#) on page 385). The location in the directory where you want to search for the user's member group(s) is configured using the following:

- Search base object (distinguished name or DN, e.g., "ou=ABC,dc=corp,dc=abc,dc=com"), which defines the location in the directory from where the LDAP search begins and is configured in [Configuring LDAP DN's \(Base Paths\) per LDAP Server](#) on page 383.
- Search filter, for example, (&(objectClass=person)(sAMAccountName=JohnD)), which filters the search in the subtree to include only the specific username. The search filter can be configured with the dollar (\$) sign to represent the username, for example, (sAMAccountName=\$). To configure the search filter, see [Configuring the LDAP Search Filter Attribute](#) on page 384.
- Management attribute (e.g., memberOf), from where objects that match the search filter criteria are returned. This shows the user's member groups. The attribute is configured in the LDAP Servers table (see [Configuring LDAP Servers](#) on page 376).

If the device finds a group, it assigns the user the corresponding access level and permits login; otherwise, login is denied. Once the LDAP response has been received (success or failure), the device ends the LDAP session.

■ **LDAP-based Management services:** This LDAP service works together with the LDAP-based management account (described above), allowing you to use different LDAP service accounts for user authentication and user authorization:

- **Management-type LDAP server:** This LDAP server account is used only for user authentication. For more information about how it works, see [Management-related LDAP Queries](#), above.
- **Management Service-type LDAP server:** This LDAP server account is used only for user authorization (i.e., the user's management access level and privileges). The device has an always-on connection with the LDAP server and uses a configured (fixed) LDAP username (Bind Name) and password. Only if user authentication succeeds, does the device query this **Management Service-type** LDAP server account for user authorization. Thus, management groups and DN's are configured only for this LDAP server account (instead of for the regular LDAP-based management account).

Therefore, user authorization is done only by a specific LDAP "administrator", which has a fixed username and password. In contrast, user authentication is done by the user itself (i.e., binding to the LDAP account with each user's username and password). Having a

dedicated LDAP account for user authorization may provide additional security to the network by preventing users from accessing the authorization settings in the LDAP server.



The device also supports the following user login authentication methods:

- RADIUS-based authentication (see [RADIUS-based User Login Authentication](#) on page 365)
- OAuth-based authentication (see [OAuth-based User Login Authentication and Authorization](#) on page 408)

For all the previously discussed LDAP services, the following additional LDAP functionality is supported:

- Search method for searching DN object records between LDAP servers and within each LDAP server (see [Configuring LDAP Search Methods](#)).
- Default access level that is assigned to the user if the queried response doesn't contain an access level.
- Local Users table for authenticating users instead of the LDAP server (for example, when a communication problem occurs with the server). For more information, see [Configuring Fallback Options to Local Users Table](#) on page 391.

## Enabling the LDAP Service

Before you can configure LDAP support, you need to enable the LDAP service.

### ➤ To enable LDAP:

1. Open the LDAP Settings page (**Setup** menu > **IP Network** tab > **AAA Servers** folder > **LDAP Settings**).
2. Select the 'LDAP Service' check box:

LDAP service



3. Click **Apply**, and then restart the device with a save-to-flash for your settings to take effect.

## Enabling LDAP-based User Login Authentication

The LDAP service can be used for authenticating and authorizing device management users (Web and CLI) based on the user's login username and password (credentials). At the same, it can also be used to determine users' management access levels (privileges). Before you can configure LDAP-based login authentication, you must enable this type of LDAP service.



Both LDAP and RADIUS (see [RADIUS-based User Login Authentication](#) on page 365) based login methods can't be used together; configure only one of them as the login method.



If you enable LDAP-based user login authentication, when users with Security Administrator privilege level log in to the device's CLI, they are automatically given access to the CLI privileged mode (“#”). For all other user privilege levels, the user needs to run the **enable** command and then enter the password to access the CLI privileged mode.

➤ **To enable LDAP-based login authentication:**

1. Open the Authentication Server page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Authentication Server**).
2. Select the 'Use LDAP for Web/Telnet Login' check box:

Use LDAP for Web/Telnet Login



3. Click **Apply**, and then restart the device with a save-to-flash for your settings to take effect.

## Configuring LDAP Server Groups

The LDAP Server Groups table lets you configure up to 41 LDAP Server Groups. An LDAP Server Group is a logical configuration entity that contains up to two LDAP servers. LDAP servers are assigned to LDAP Server Groups in the LDAP Servers table (see [Configuring LDAP Servers](#) on page 376). To use a configured LDAP server, you must assign it to an LDAP Server Group.

You can configure the following types of LDAP Server Groups (configured by the 'Type' parameter described below):

- **Control:** To use an LDAP server for call routing, you need to configure the LDAP Server Group as a **Control** type, and then assign the LDAP Server Group to a Routing Policy. The Routing Policy in turn needs to be assigned to the relevant routing rule(s). You can assign a Routing Policy to only one LDAP Server Group. Therefore, for multi-tenant deployments where multiple Routing Policies are employed, each tenant can be assigned a specific LDAP Server Group through its unique Routing Policy.
- **Management:** To use an LDAP server for management where it does user login authentication and user authorization, you need to configure the LDAP Server Group as a **Management** type. Additional LDAP-based management parameters need to be configured, as described in [Enabling LDAP-based User Login Authentication](#) on the previous page and [Configuring LDAP Servers](#) on page 376.
- **Management Service:** To use two different LDAP server accounts for management, where one LDAP account does user authentication and the other LDAP account does user authorization, you need to configure two LDAP Server Groups. Configure the LDAP Server Group for user authentication as a **Management** type and the LDAP Server Group for user authorization as a **Management Service** type. In this setup, configure all the user-authorization settings (i.e., Management LDAP Groups and LDAP Server Search Base DN)

for the **Management Service**-type LDAP Server Group only, instead of for the **Management**-type LDAP Server Group.

The following procedure describes how to configure an LDAP Server Group through the Web interface. You can also configure it through ini file [LDAPServerGroups] or CLI (`configure system > ldap ldap-server-groups`).



The device provides a preconfigured LDAP Server Group ("DefaultCTRLServersGroupin") in the LDAP Server Groups table, which can be modified or deleted.

➤ **To configure an LDAP Server Group:**

1. Open the LDAP Server Groups table (**Setup** menu > **IP Network** tab > **AAA Servers** folder > **LDAP Server Groups**).
2. Click **New**; the following dialog box appears:

3. Configure an LDAP Server Group according to the parameters described in the table below.
4. Click **Apply**.

**Table 16-8: LDAP Server Groups Table Parameter Descriptions**

Parameter	Description
<b>General</b>	
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [Name]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 20 characters. <b>Note:</b> ■ Configure each row with a unique name.

Parameter	Description
	<ul style="list-style-type: none"> <li>The parameter value cannot contain a forward slash (/).</li> </ul>
'Type' server-type [ServerType]	<p>Defines whether the servers in the group are used for SIP-related LDAP queries (Control) or management login authentication-related LDAP queries (Management).</p> <ul style="list-style-type: none"> <li>[0] <b>Control</b> (default)</li> <li>[1] <b>Management</b></li> <li>[2] <b>Management Service</b></li> </ul> <p>For more information on the different optional LDAP services, see <a href="#">LDAP-based Services</a> on page 369.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>For table row Index #0, the parameter can only be configured to <b>Control</b>.</li> <li>Only one LDAP Server Group can be configured for management.</li> </ul>
'Server Search Method' server-search-method [SearchMethod]	<p>Defines the method for querying between the two LDAP servers in the group.</p> <ul style="list-style-type: none"> <li>[0] <b>Parallel</b> = (Default) The device queries the LDAP servers at the same time.</li> <li>[1] <b>Sequential</b> = The device first queries one of the LDAP servers and if the DN object is not found or the search fails, it queries the second LDAP server.</li> </ul>
'DN Search Method' search-dn-method [SearchDnsMethod]	<p>Defines the method for querying the Distinguished Name (DN) objects within each LDAP server.</p> <ul style="list-style-type: none"> <li>[0] <b>Sequential</b> = (Default) The query is done in each DN object, one by one, until a result is returned. For example, a search for the DN object record "JohnD" is first run in DN object "Marketing" and if a result is not found, it searches in "Sales", and if not found, it searches in "Administration", and so on.</li> <li>[1] <b>Parallel</b> = The query is done in all DN objects at the same time. For example, a search for the DN object record "JohnD" is done at the same time in the "Marketing", "Sales" and "Administration" DN objects.</li> </ul>

Parameter	Description
<b>Cache</b> To refresh the LDAP cache, see <a href="#">Refreshing LDAP Cache for LDAP Server Groups</a> on page 390. To clear the LDAP cache, see <a href="#">Clearing LDAP Cache</a> on page 391.	
'Cache Entry Timeout' cache-entry-timeout [LdapServersGroups_ CacheEntryTimeout]	Defines the duration (in minutes) that an entry in the device's LDAP cache is valid. If the timeout expires, the cached entry is used only if there is no connectivity with the LDAP server.  The valid range is 0 to 35791. The default is 1200. The value 0 means that the LDAP entry is always valid.
'Cache Entry Removal Timeout' cache-entry-removal-timeout [CacheEntryRemovalTimeout]	Defines the duration (in hours) after which the LDAP entry is deleted from the device's LDAP cache.  The valid range is 0 to 596. The default is 0 (i.e., entry is never deleted).

## Configuring LDAP Servers

The LDAP Servers table lets you configure up to 82 LDAP servers. The table defines the address and connectivity settings of the LDAP server. The LDAP server can be configured for SIP-related queries (e.g., routing and manipulation) or LDAP-based management user login authentication and authorization (username-password).

The following procedure describes how to configure an LDAP server through the Web interface. You can also configure it through ini file [LdapConfiguration] or CLI (`configure system > ldap-configuration`).




When you configure an LDAP server, you need to assign it an LDAP Server Group. Therefore, before you can configure an LDAP server in the table, you must first configure at least one LDAP Server Group in the LDAP Server Groups table (see [Configuring LDAP Server Groups](#) on page 373).

### ➤ To configure an LDAP server:

1. Open the LDAP Servers table (**Setup** menu > **IP Network** tab > **AAA Servers** folder > **LDAP Servers**).
2. Click **New**; the following dialog box appears:





3. Configure an LDAP server according to the parameters described in the table below.

4. Click **Apply**.

**Table 16-9: LDAP Servers Table Parameter Descriptions**

Parameter	Description
<b>General</b>	
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'LDAP Servers Group' server-group [Group]	Assigns the LDAP server to an LDAP Server Group, configured in the LDAP Server Groups table (see <a href="#">Configuring LDAP Server Groups</a> on page 373). <b>Note:</b> <ul style="list-style-type: none"> <li>The parameter is mandatory and must be set before configuring the other parameters in the table.</li> <li>You can assign up to two LDAP servers to the same LDAP Server Group.</li> </ul>
'LDAP Network Interface' interface-type [Interface]	Assigns one of the device's IP Interfaces (see <a href="#">Configuring IP Network Interfaces</a> on page 157) through which communication with the LDAP server is done. By default, no value is defined and the device uses the IPv4 OAMP interface. <b>Note:</b> <ul style="list-style-type: none"> <li>The parameter is mandatory.</li> <li>The IP address version (IPv4 or IPv6) of the assigned IP Interface and the LDAP server's address (see 'LDAP Server IP' parameter below)</li> </ul>

Parameter	Description
	must be the same.
'Use TLS' use-tls [useTLS]	<p>Enables the device to encrypt the username and password (for Control and Management related queries) using TLS when sending them to the LDAP server.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) Username and password are sent in clear-text format.</li> <li>■ [1] <b>Yes</b></li> </ul>
'TLS Context' tls-context [ContextName]	<p>Assigns a TLS Context (TLS configuration) for the connection with the LDAP server.</p> <p>By default, no value is defined and the device uses the default TLS Context (ID 0).</p> <p>To configure TLS Contexts, see <a href="#">TLS Certificates</a> on page 224.</p> <p><b>Note:</b> The parameter is applicable only if the 'Use TLS' parameter is configured to <b>Yes</b>.</p>
'Verify Certificate' verify-certificate [VerifyCertificate]	<p>Enables certificate verification when the connection with the LDAP server uses TLS.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) No certificate verification is done.</li> <li>■ [1] <b>Yes</b> = The device verifies the authentication of the certificate received from the LDAP server. The device authenticates the certificate against the trusted root certificate store associated with the associated TLS Context (see 'TLS Context' parameter above) and if ok, allows communication with the LDAP server. If authentication fails, the device denies communication (i.e., handshake fails). The device can also authenticate the certificate by querying with an Online Certificate Status Protocol (OCSP) server whether the certificate has been revoked. This is also configured for the associated TLS Context.</li> </ul> <p><b>Note:</b> The parameter is applicable only if the 'Use TLS' parameter is configured to <b>Yes</b>.</p>
'Verify Certificate Subject Name'	Enables the verification of the TLS certificate subject

Parameter	Description
verify-subject-Name [VerifySubjectName]	<p>name (Common Name / CN or Subject Alternative Name / SAN) that is used in the incoming connection request from the LDAP server.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) No verification is done.</li> <li>■ [1] <b>Enable</b> = The device verifies the subject name of the certificate received from the LDAP server with the hostname or IP address configured for the LDAP server. If authentication fails, the device denies communication (i.e., handshake fails).</li> </ul> <p><b>Note:</b> The parameter is applicable only if the 'Use TLS' parameter is configured to <b>Yes</b>.</p>
<b>Connection</b>	
'LDAP Server IP' server-ip [LdapConfServerIp]	<p>Defines the IP address (IPv4 or IPv6) of the LDAP server.</p> <p>By default, no IP address is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> <li>■ If you want to use an FQDN for the LDAP server, leave the parameter undefined and configure the FQDN in the 'LDAP Server Domain Name' parameter (see below).</li> <li>■ The IP address version (IPv4 or IPv6) of the LDAP server's address and the assigned IP Interface (see 'LDAP Network Interface' parameter above) must be the same.</li> </ul>
'LDAP Server Port' server-port [LdapConfServerPort]	<p>Defines the port number of the LDAP server.</p> <p>The valid value range is 0 to 65535. The default port number is 389.</p>
'LDAP Server Max Respond Time' max-respond-time [LdapConfServerMaxRespondTime]	<p>Defines the duration (in msec) that the device waits for LDAP server responses.</p> <p>The valid value range is 0 to 86400. The default is 3000.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If the response time expires, you can configure</li> </ul>

Parameter	Description
	<p>the device to use the Local Users table for authenticating the user. For more information, see <a href="#">Configuring Fallback Options to Local Users Table</a> on page 391.</p> <ul style="list-style-type: none"> <li>■ Activation of this timeout depends on connection type: <ul style="list-style-type: none"> <li>✓ Normal TCP connection: The device starts the timer when it sends the LDAP request. If no response is received from the LDAP server within the configured time, the device closes the connection.</li> <li>✓ TLS connection: The device first performs the TLS handshake and once negotiation completes, it sends the LDAP request. The device starts the timer only from the first TLS message sent during the handshake (and not from the LDAP request).</li> </ul> </li> </ul>
<p>'LDAP Server Domain Name'</p> <p>domain-name</p> <p>[LdapConfServerDomainName]</p>	<p>Defines the domain name (FQDN) of the LDAP server. The device tries to connect to the LDAP server according to the IP address listed in the received DNS query. If there is no connection to the LDAP server or the connection to the LDAP server fails, the device tries to connect to the LDAP server with the next IP address in the DNS query list.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you configure the 'LDAP Server IP' parameter, the 'LDAP Server Domain Name' parameter is ignored. Therefore, if you want to use an FQDN, leave the 'LDAP Server IP' parameter undefined.</li> <li>■ The IP address version (IPv4 or IPv6) of the DNS-resolved IP addresses and the assigned IP Interface (see 'LDAP Network Interface' parameter above) must be the same.</li> </ul>
<p>'Server's Connection Status'</p> <p>connection-status</p> <p>[ConnectionStatus]</p>	<p>(Read-only) Displays the connection status with the LDAP server.</p> <ul style="list-style-type: none"> <li>■ "Not Applicable"</li> <li>■ "LDAP Connection Broken"</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ "Connecting"</li> <li>■ "Connected"</li> </ul> <p>For more information about a disconnected LDAP connection, see your syslog messages generated by the device.</p> <p><b>Note:</b> When the LDAP server is assigned to an LDAP Server Group that is for management (see <a href="#">Configuring LDAP Server Groups</a> on page 373), the connection status of the LDAP server is always "Not Applicable".</p>
<b>Query</b>	
'LDAP Password' password [LdapConfPassword]	<p>Defines the user password for accessing the LDAP server during connection and binding operations. The valid value of the parameter depends on the type of LDAP Server Group (defined by the 'Type' parameter in the LDAP Server Groups table):</p> <ul style="list-style-type: none"> <li>■ <b>Control:</b> (LDAP-based SIP queries) The parameter is the password used by the device to authenticate itself (as a client) to obtain LDAP service from the LDAP server.</li> <li>■ <b>Management or Management Service:</b> (LDAP-based user login authentication) The parameter represents the login password entered by the user during a login attempt. You <b>must</b> configure the parameter to the dollar sign (\$). This triggers the device to automatically replace the \$ with the user's login password in the search filter which it sends to the LDAP server for authenticating the user's username-password combination.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> <li>■ By default, the device sends the password in clear-text format. You can enable the device to encrypt the password using TLS (see the 'Use TLS' parameter in this table).</li> <li>■ The password cannot be configured with wide characters.</li> </ul>

Parameter	Description
'LDAP Bind DN' bind-dn [LdapConfBindDn]	<p>Defines the LDAP server's bind Distinguished Name (DN) or username.</p> <ul style="list-style-type: none"> <li>■ LDAP-based SIP queries: The DN is used as the username during connection and binding to the LDAP server. The DN is used to uniquely name an AD object. Below are example parameter settings:               <ul style="list-style-type: none"> <li>✓ cn=administrator,cn=Users,dc=domain,dc=com</li> <li>✓ administrator@domain.com</li> <li>✓ domain\administrator</li> </ul> </li> <li>■ LDAP-based user login authentication: The parameter represents the login username entered by the user during a login attempt. You can use the \$ (dollar) sign in this value to enable the device to automatically replace the \$ sign with the user's login username in the search filter, which it sends to the LDAP server for authenticating the user's username-password combination. An example configuration for the parameter is \$@sales.local, where the device replaces the \$ with the entered username, for example, JohnD@sales.local. The username can also be configured with the domain name of the LDAP server.</li> </ul> <p><b>Note:</b> By default, the device sends the username in clear-text format. You can enable the device to encrypt the username using TLS (see the 'Use TLS' parameter in this table).</p>
'Management Attribute' mgmt-attr [MngmAuthAtt]	<p>Defines the LDAP attribute name to query, which contains a list of groups to which the user is a member. For Active Directory, this attribute is typically "memberOf". The attribute's values (groups) are used to determine the user's management access level; the group's corresponding access level is configured in <a href="#">Configuring Access Level per Management Groups Attributes</a> on page 385.</p> <p><b>Note:</b></p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ The parameter is applicable only to LDAP-based login authentication and authorization (i.e., the 'Type' parameter is set to <b>Management</b>).</li> <li>■ If this functionality is not used, the device assigns the user the configured default access level. For more information, see <a href="#">Configuring Access Level per Management Groups Attributes</a> on page 385.</li> </ul>
'No Op Timeout' noop-timeout [NoOpTimeout]	<p>Defines the timeout (in minutes) of inactivity in the connection between the device and the LDAP server, after which the device sends an LDAP "abandon" request to keep the LDAP connection alive (i.e., LDAP persistent connection).</p> <p>The valid value to enable this feature is any value greater than 0. The default is 0 (i.e., if there is no activity on the connection, the device doesn't send "abandon" requests and the LDAP server may disconnect).</p> <p><b>Note:</b> The parameter is applicable only to LDAP connections that are used for routing (i.e., the 'Type' parameter is configured to <b>Control</b>).</p>

## Configuring LDAP DN (Base Paths) per LDAP Server

The LDAP Search DN table lets you configure LDAP base paths. The table is a "child" of the LDAP Servers table (see [Configuring LDAP Servers](#) on page 376) and configuration is done per LDAP server. For the device to run a search using the LDAP service, the base path to the directory's subtree, referred to as the distinguished name object (or DN), where the search is to be done must be configured. For each LDAP server, you can configure up to three base paths.

The following procedure describes how to configure DN per LDAP server through the Web interface. You can also configure it through ini file [LdapServersSearchDNs] or CLI (`configure system > ldap-configuration > ldap-servers-search-dns`).

### ➤ To configure an LDAP base path per LDAP server:

1. Open the LDAP Servers table (**Setup** menu > **IP Network** tab > **AAA Servers** folder > **LDAP Servers**).
2. In the table, select the row of the LDAP server for which you want to configure DN base paths, and then click the **LDAP Servers Search Based DN** link located below the table; the LDAP Server Search Base DN table opens.
3. Click **New**; the following dialog box appears:

4. Configure an LDAP DN base path according to the parameters described in the table below.
5. Click **Apply**, and then save your settings to flash memory.

**Table 16-10:LDAP Server Search Base DN Table Parameter Descriptions**

Parameter	Description
'Index' set internal- index [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Base DN' set base- path [Base_Path]	Defines the full path (DN) to the objects in the AD where the query is done. The valid value is a string of up to 256 characters. For example: OU=NY,DC=OCSR2,DC=local. In this example, the DN path is defined by the LDAP names, OU (organizational unit) and DC (domain component).

## Configuring the LDAP Search Filter Attribute

When the LDAP-based login username-password authentication succeeds, the device searches the LDAP server for all groups of which the user is a member. The LDAP query is based on the following LDAP data structure:

- **Search base object (distinguished name or DN, e.g., "ou=ABC,dc=corp,dc=abc,dc=com"):**  
The DN defines the location in the directory from which the LDAP search begins and is configured in [Configuring LDAP DN \(Base Paths\) per LDAP Server](#) on the previous page.
- **Filter (e.g., "(&(objectClass=person)(sAMAccountName=johnd))"):** This filters the search in the subtree to include only the login username (and excludes others). This is configured by the 'LDAP Authentication Filter' parameter, as described in the following procedure. You must use the dollar (\$) sign to represent the username. For example, when configured to "(sAMAccountName=\*)" and the user attempts to log in with the username "SueM", the LDAP search is done only for the attribute sAMAccountName that equals "SueM".



- **Attribute (e.g., "memberOf") to return from objects that match the filter criteria:** The attribute is configured by the 'Management Attribute' parameter in the LDAP Servers table (see [Configuring LDAP Servers](#) on page 376).

Therefore, the LDAP response includes only the groups of which the specific user is a member.



- The search filter is applicable only to LDAP-based login authentication and authorization queries.
- The search filter is a global setting that applies to all LDAP-based login authentication and authorization queries, across all configured LDAP servers.

➤ **To configure the LDAP search filter for management users:**

1. Open the LDAP Settings page (**Setup** menu > **IP Network** tab > **AAA Servers** folder > **LDAP Settings**).
2. In the 'LDAP Authentication Filter' field, enter the LDAP search filter attribute for searching the login username for user authentication:

LDAP Authentication Filter

3. Click **Apply**.

## Configuring Access Level per Management Groups Attributes

The Management LDAP Groups table lets you configure LDAP group objects and their corresponding management user access level. The table is a "child" of the LDAP Servers table (see [Configuring LDAP Servers](#) on page 376) and configuration is done per LDAP server. For each LDAP server, you can configure up to three row entries of LDAP group(s) with their corresponding access level (only one row can be configured for each level).



- The Management LDAP Groups table is applicable only to LDAP-based login authentication and authorization queries.
- If the LDAP response received by the device includes multiple groups of which the user is a member and you have configured different access levels for some of these groups, the device assigns the user the highest access level. For example, if the user is a member of two groups where one has access level **Monitor** and the other **Admin**, the device assigns the user the **Admin** access level.
- When the access level is unknown, the device assigns the default access level to the user, configured by the 'Default Access Level' parameter as used also for RADIUS (see [Configuring RADIUS-based User Authentication](#) on page 368). This can occur in the following scenarios:
  - ✓ The user is not a member of any LDAP group.
  - ✓ The group of which the user is a member is not configured on the device (as described in this section).
  - ✓ The device is not configured to query the LDAP server for a management attribute (see [Configuring LDAP Servers](#) on page 376).

Group objects represent groups in the LDAP server of which the user is a member. The access level represents the user account's permissions and rights in the device's management interface (e.g., Web and CLI). The access level can either be **Monitor**, **Admin**, or **Security Admin**. For an explanation on the privileges of each level, see [Configuring Local Management User Accounts](#) on page 54.

When the username-password authentication with the LDAP server succeeds, the device searches the LDAP server for all groups of which the user is a member. The LDAP query is based on the following LDAP data structure:

- Search base object (distinguished name or DN, e.g., "ou=ABC,dc=corp,dc=abc,dc=com"), which defines the location in the directory from which the LDAP search begins. This is configured in [Configuring LDAP DN \(Base Paths\) per LDAP Server](#) on page 383.
- Filter (e.g., "(&(objectClass=person)(sAMAccountName=johnd))"), which filters the search in the subtree to include only the login username (and excludes others). For configuration, see [Configuring the LDAP Search Filter Attribute](#) on page 384.
- Attribute (e.g., "memberOf") to return from objects that match the filter criteria. This attribute is configured by the 'Management Attribute' parameter in the LDAP Servers table.

The LDAP response includes all the groups of which the specific user is a member, for example:

```
CN=\# Support Dept,OU=R&D Groups,OU-
U=Groups,OU=APC,OU=Japan,OU=ABC,DC=corp,DC=abc,DC=com
CN=\#AllCellular,OU=Groups,OU=APC,OU=Japan,OU=ABC,DC=corp,DC=abc,DC=com
```

The device searches this LDAP response for the group names that you configured in the Management LDAP Groups table to determine the user's access level. If the device finds a group name, the user is assigned the corresponding access level and login is permitted; otherwise, login is denied. Once the LDAP response has been received (success or failure), the LDAP session terminates.

The following procedure describes how to configure an access level per management groups through the Web interface. You can also configure it through ini file [MgmtLDAPGroups] or CLI (configure system > ldap-configuration > mgmt-ldap-groups).

➤ **To configure management groups and corresponding access level:**

1. Open the LDAP Servers table (**Setup** menu > **IP Network** tab > **AAA Servers** folder > **LDAP Servers**).
2. In the table, select the row of the LDAP server for which you want to configure management groups with a corresponding access level, and then click the **Management LDAP Groups** link located below the table; the Management LDAP Groups table opens.
3. Click **New**; the following dialog box appears:

**Management LDAP Groups**

**GENERAL**

Index: 1

Level: Monitor

Groups:

4. Configure a group name(s) with a corresponding access level according to the parameters described in the table below.
5. Click **Apply**, and then save your settings to flash memory.

**Table 16-11: Management LDAP Groups Table Parameter Descriptions**

Parameter	Description
'Index' [MgmntLDAPGroups_ GroupIndex]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Level' level [MgmntLDAPGroups_ Level]	Defines the access level of the group(s). <ul style="list-style-type: none"> <li>■ [0] <b>Monitor</b> (Default)</li> <li>■ [1] <b>Admin</b></li> <li>■ [2] <b>Security Admin</b></li> </ul> <b>Note:</b> You can configure only one row in the Management LDAP Groups table per access level.
'Groups' groups [MgmntLDAPGroups_ Group]	Defines the attribute names of the groups in the LDAP server. The valid value is a string of up to 256 characters. To define multiple groups, separate each group name with a semicolon (;). <b>Note:</b> The value is case-insensitive.


## Configuring the Device's LDAP Cache

The device can optionally store LDAP queries of LDAP Attributes for a searched key with an LDAP server and the responses (results) in its local cache. The cache is used for subsequent queries or in case of LDAP server failure. The benefits of this feature include the following:

- Improves routing decision performance by using local cache for subsequent LDAP queries

- Reduces number of queries performed on an LDAP server and corresponding bandwidth consumption
- Provides partial survivability in case of intermittent LDAP server failure (or network isolation)

The handling of LDAP queries using the device's LDAP cache is shown in the flowchart below:



If an LDAP query is required for an Attribute of a key that is already cached with that same Attribute, instead of sending a query to the LDAP server, the device uses the cache. However, if an LDAP query is required for an Attribute that doesn't appear for the cached key, the device queries the LDAP server, and then saves the new Attribute (and response) in the cache for that key.

If the device queries the LDAP server for different Attributes for a cached key, the device also includes already cached Attributes of the key, while adhering to the maximum number of allowed saved Attributes (see note below), with preference to the different Attributes. In other words, if the cached key already contains the maximum Attributes and an LDAP query is required for a different Attribute, the device sends an LDAP query to the server for the different Attribute and for the five **most recent** Attributes already cached with the key. Upon the LDAP response, the new Attribute replaces the **oldest** cached Attribute while the values of the other Attributes are refreshed with the new response.

The following table shows an example of different scenarios of LDAP queries of a cached key whose cached Attributes include *a*, *b*, *c*, and *d*, where *a* is the oldest and *d* the most recent Attribute:

Table 16-12:Example of LDAP Query for Cached Attributes

Attributes Requested in New LDAP Query for Cached Key	Attributes Sent in LDAP Query to LDAP Server	Attributes Saved in Cache after LDAP Response
e	e, a, b, c, d	e, a, b, c, d
e, f	e, f, a, b, c, d	e, f, a, b, c, d
e, f, g, h,i	e, f, g, h, i, d	e, f, g, h,i, d
e, f, g, h, i, j	e, f, g, h, i, j	e, f, g, h, i, j



- The LDAP Cache feature is applicable only to LDAP-based SIP queries (Control).
- The maximum LDAP cache size is 10,000 entries.
- The device can save up to six LDAP Attributes in the cache per searched LDAP key.
- The device also saves in the cache queried Attributes that do not have any values in the LDAP server.

The following procedure describes how to configure the device's LDAP cache globally.



- You can also configure LDAP caching per LDAP Server Group (see [Configuring LDAP Server Groups](#) on page 373).
- Before enabling LDAP caching, you must first enable the LDAP service (see [Enabling the LDAP Service](#) on page 372).
- To clear the LDAP cache, see [Clearing LDAP Cache](#) on page 391.

➤ **To enable and configure LDAP cache:**

1. Open the LDAP Settings page (**Setup** menu > **IP Network** tab > **AAA Servers** folder > **LDAP Settings**).
2. Select the 'LDAP Cache Service' check box to enable LDAP cache.

LDAP Cache Service



3. Configure the following LDAP caching settings:
  - a. In the 'LDAP Cache Entry Timeout' field, enter the duration (in minutes) that an entry in the device's LDAP cache is valid. If the timeout expires, the cached entry is used only if there is no connectivity with the LDAP server.
  - b. In the 'LDAP Cache Entry Removal Timeout' field, enter the duration (in hours) after which the LDAP entry is removed from the device's LDAP cache.


LDAP Cache Entry Timeout [min]	<input type="text" value="1200"/>
LDAP Cache Entry Removal Timeout [hrs]	<input type="text" value="0"/>

- Click **Apply**, and then restart the device with a burn-to-flash for your settings to take effect.

### Refreshing LDAP Cache for LDAP Server Groups

You can refresh values of LDAP Attributes associated with a specified LDAP search key that are stored in the device's LDAP cache. The device sends an LDAP query to the LDAP server for the cached Attributes of the specified search key and replaces the old values in the cache with the new values received in the LDAP response.


For example, assume the cache contains a previously queried LDAP Attribute "telephoneNumber=1004" whose associated Attributes include "displayName", "mobile" and "ipPhone". If you perform a cache refresh based on the search key "telephoneNumber=1004", the device sends an LDAP query to the server requesting values for the "displayName", "mobile" and "ipPhone" Attributes of this search key. When the device receives the LDAP response, it replaces the old values in the cache with the new values received in the LDAP response.



➤ **To refresh LDAP cache:**

1. Open the LDAP Server Groups table (see [Configuring LDAP Server Groups](#) on page 373).
2. Refresh the cache of a specific LDAP Server Group or all of them:
  - **Refresh specific LDAP Server Group:** Select the LDAP Server Group row, click **Action**, and then from the drop-down menu, choose **Refresh Line**.
  - **Refresh all LDAP Server Groups:** Click **Action**, and then from the drop-down menu, choose **Refresh All Cache**.

The following dialog appears:



3. In the 'Insert Key to Refresh' field, enter the LDAP search key that you want to refresh (e.g., telephoneNumber=1004).
4. Click **OK**; if a request with the specified key exists in the cache, a request is sent to the LDAP server for the attributes associated in the cache with the search key.

### Clearing LDAP Cache

You can clear the entire cache of LDAP queries of attributes for searched keys with the configured LDAP Server Groups and the responses (results).

➤ **To clear LDAP cache:**

1. Open the LDAP Server Groups table (see [Configuring LDAP Server Groups](#) on page 373).
2. Click **Action**, and then from the drop-down menu, choose **Clear Cache**.

### Configuring Fallback Options to Local Users Table

When you are using an Authentication server to authenticate users, you can configure when or if the device uses the Local Users table (see [Configuring Local Management User Accounts](#) on page 54). By default, the device uses the Local Users table if you haven't configured an Authentication server.



- This feature is applicable to LDAP and RADIUS.
- This feature is applicable only to user management authentication.

➤ **To configure when Local Users table used for user authentication:**

1. Open the Authentication Server page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Authentication Server**).

2. Under the General group, do the following:
  - a. Configure when the Local Users table is used to authenticate users. From the 'Use Local Users Table for Authentication' drop-down list, select one of the options (for a description, see ['Use Local Users Table for Authentication'](#) on page 1939).
  - b. Configure whether the Local Users table is to be used to authenticate users upon connection timeout with the server. From the 'Behavior upon Authentication Server Timeout' drop-down list, select one of the following:
    - ◆ **Deny Access:** User is denied access.
    - ◆ **Verify Access Locally:** The device verifies the user's credentials in the Local Users table.

Use Local Users Table for Authentication

When No Auth Server Defined ▼

Behavior upon Authentication Server Timeout

Verify Access Locally ▼

3. Click **Apply**, and then restart the device with a save-to-flash for your settings to take effect.

## LDAP-based Login Authentication Example

To facilitate your understanding on LDAP entry data structure and how to configure the device to use and obtain information from this LDAP directory, a brief configuration example is described in this section. The example applies to LDAP-based user login authentication and authorization (access level), and assumes that you are familiar with other aspects of LDAP configuration (e.g., LDAP server's address).

The LDAP server's entry data structure schema in the example is as follows:

- **DN (base path):** OU=testMgmt,OU=QA,DC=testqa,DC=local. The DN path to search for the username in the directory is shown below:




Path: CN=John Doe,OU=testMgmt,OU=QA,DC=testqa,DC=local,10.3.9.93 [testqa.testqa.local]


The screenshot shows the Active Directory Explorer window. The left pane displays the directory tree with the path **CN=John Doe,OU=testMgmt,OU=QA,DC=testqa,DC=local** selected. The right pane shows a list of attributes for this user.

Attribute	Syntax	Count	Value(s)
accountExpires	Integer8	1	0x7FFFFFFFFFFFFFFF
badPasswordTime	Integer8	1	06-Mar-14 10:03:18 AM
badPwdCount	Integer	1	0
cn	DirectoryString	1	John Doe
codePage	Integer	1	0
countryCode	Integer	1	0
description	DirectoryString	1	10600
displayName	DirectoryString	1	John Doe
distinguishedName	DN	1	CN=John Doe,OU=testMgmt,OU=QA,DC=testqa,DC=local
givenName	DirectoryString	1	John
instanceType	Integer	1	4
lastLogoff	Integer8	1	0x0
lastLogon	Integer8	1	06-Mar-14 10:03:41 AM
logonCount	Integer	1	0
memberOf	DN	1	CN=mySecAdmin,OU=testMgmt,OU=QA,DC=testqa,DC=local
name	DirectoryString	1	John Doe
ntSecurityDescriptor	NTSecurityDescriptor	1	D:AI(A;;CCDCLCSWRPWPDT...
objectCategory	DN	1	CN=Person,CN=Schema,CN=...
objectClass	OID	4	top;person;organizationalPe...
objectGUID	OctetString	1	{7F1E3B8C-3D90-47BC-A9E...
objectSid	Sid	1	S-1-5-21-2341986137-2970...
primaryGroupID	Integer	1	513
pwdLastSet	Integer8	1	25-Feb-14 5:32:45 PM
sAMAccountName	DirectoryString	1	John Doe
sAMAccountType	Integer	1	805306368
sn	DirectoryString	1	Doe
userAccountControl	Integer	1	512
userPrincipalName	DirectoryString	1	John.Doe@testqa.local
uSNChanged	Integer8	1	0x87212
uSNCreated	Integer8	1	0x8311F
whenChanged	GeneralizedTime	1	25-Feb-14 5:32:45 PM
whenCreated	GeneralizedTime	1	06-Oct-02 5:27:51 AM


■ **Search Attribute Filter:** (sAMAccountName=). The login username is found based on this attribute (where the attribute's value equals the username):



- **Management Attribute:** `memberOf`. The attribute contains the member groups of the user:




- **Management Group:** `mySecAdmin`. The group to which the user belongs, as listed under the `memberOf` attribute:




The configuration to match the above LDAP data structure schema is as follows:


- LDAP-based login authentication (management) is enabled in the LDAP Server Groups table (see [Configuring LDAP Server Groups](#) on page 373):



- The DN is configured in the LDAP Server Search Base DN table (see [Configuring LDAP DNS \(Base Paths\) per LDAP Server](#) on page 383):








- The search attribute filter based on username is configured by the 'LDAP Authentication Filter' parameter (see [Configuring the LDAP Search Filter Attribute](#) on page 384):

GENERAL	
<b>LDAP Service</b>	• Enable 
<b>LDAP Authentication Filter</b>	(\$AMAccountName=*)

- The group management attribute is configured by the 'Management Attribute' parameter in the LDAP Servers table:

LDAP Servers ✖


LDAP Servers Group #1 [login-auth] 

GENERAL		CONNECTION	
Index	0	LDAP Server IP	10.3.9.93
LDAP Network Interface	#0 [O+M+C]  <a href="#">View</a>	LDAP Server Port	389
Use TLS	No 	LDAP Server Max Respond Time [msec]	3000
TLS Context	--  <a href="#">View</a>	LDAP Server Domain Name	
		Connection Status	
		Verify Certificate	No 

QUERY	
LDAP Password	
LDAP Bind DN	\$@testqa.local
Management Attribute	memberOf

- The management group and its corresponding access level is configured in the Management LDAP Groups table (see [Configuring Access Level per Management Groups Attributes](#) on page 385):

Management LDAP Groups ✖

GENERAL	
Index	0
Level	Security Admin 
Groups	mySecAdmin

## Enabling LDAP Searches for Numbers with Characters

Typically, the device performs LDAP searches in the AD for complete numbers where the digits are adjacent to one another (e.g., 5038234567). However, if the number is defined in the AD with characters (such as spaces, hyphens and periods) separating the digits (e.g., 503-823 4567), the LDAP query returns a failed result.

To enable the device to search the AD for numbers that may contain characters between its digits, you need to specify the Attribute (up to five) for which you want to apply this functionality, using the [LDAPNumericAttributes] parameter. For example, the telephoneNumber Attribute could be defined in AD with the telephone number "503-823-4567" (i.e., hyphens), "503.823.4567" (i.e., periods) or "503 823 4567" (i.e., spaces). If the device performs an LDAP search on this Attribute for the number 5038234567, the LDAP query will return results only if you configure the [LDAPNumericAttributes] parameter with the telephoneNumber Attribute (e.g., [LDAPNumericAttributes] configured to telephoneNumber). To search for the number with characters, the device inserts the asterisk (\*) wildcard between all digits in the LDAP query (e.g., telephoneNumber = 5\*0\*3\*8\*2\*3\*4\*5\*6\*7). As the AD server recognizes the \* wildcard as representing any character, it returns all possible results to the device. Note that the wildcard represents only a character; a query result containing a digit in place of a wildcard is discarded and the device performs another query for the same Attribute. For example, it may return the numbers 533-823-4567 (second digit "3" and hyphens) and 503-823-4567. As the device discards query results where the wildcard results in a digit, it selects 503-823-4567 as the result. The correct query result is cached by the device for subsequent queries and/or in case of LDAP server failure.

## Routing for Microsoft Teams or Skype for Business using Microsoft Entra ID

Typically, companies wishing to deploy Microsoft® Teams or Skype for Business are faced with a complex, call routing dial plan when migrating users from their existing PBX or IP PBX to the Teams / Skype for Business environment. As more and more end-users migrate to the new voice system, dialing plan management and PBX link capacity can be adversely impacted. To resolve this issue, companies can employ Microsoft Entra ID (formerly, Microsoft Active Directory), which provides a central database to manage and maintain information regarding user's availability, presence, and location.

The device supports outbound IP call routing decisions based on information stored on Microsoft Entra ID. Based on queries sent to Microsoft Entra ID, the device can route the call to one of the following IP domains:

- Teams / Skype for Business client - users connected to Teams / Skype for Business
- PBX or IP PBX - users not yet migrated to Teams / Skype for Business
- Mobile - mobile number
- Private - private telephone line for Teams / Skype for Business users (in addition to the primary telephone line)



This section describes an earlier implementation for configuring routing based on Microsoft Entra ID. For new deployments, it's **recommended** to use Call Setup Rules (see [Configuring Call Setup Rules](#) on page 782). Call Setup Rules provide more flexibility and easier implementation. You can view examples in [Examples of Call Setup Rules](#) on page 793.

## Querying Microsoft Entra ID and Routing Priority

The device queries Microsoft Entra ID using the initial destination number (i.e., called number). The query can return up to four user phone numbers, each pertaining to one of the IP domains (i.e., private number, Skype for Business number, PBX / IP PBX number, and mobile number). The configuration parameters listed in the table below are used to configure the query attribute keys that defines the Microsoft Entra ID attribute that you wish to query Microsoft Entra ID:

**Table 16-13:Parameters for Configuring Query Attribute Key**

Parameter	Queried User Domain (Attribute) in Microsoft Entra ID	Query or Query Result Example
<b>MSLDAPPBXNumAttributeName</b>	PBX or IP PBX number (e.g., "telephoneNumber" - default)	telephoneNumber= +3233554447
<b>MSLDAPOCSNumAttributeName</b>	Mediation Server / Skype for Business client number (e.g., "msRTCSIP-Line")	msRTCSIP-Line=john.smith@company.com
<b>MSLDAPMobileNumAttributeName</b>	Mobile number (e.g., "mobile")	mobile=+3247647156
<b>MSLDAPPrivateNumAttributeName</b>	Any attribute (e.g., "msRTCSIP-PrivateLine") <b>Note:</b> Used only if set to same value as Primary or Secondary key.	msRTCSIP-PrivateLine= +3233554480
<b>MSLDAPPrimaryKey</b>	Primary Key query search instead of PBX key - can be any Microsoft Entra ID attribute	msRTCSIP-PrivateLine= +3233554480
<b>MSLDAPSecondaryKey</b>	Secondary Key query key search if Primary Key fails - can be any attribute	-

The process for querying Microsoft Entra ID and subsequent routing based on the query results is as follows:

1. If the Primary Key is configured, it uses the defined string as a primary key instead of the one defined in `MSLDAPPBXNumAttributeName`. It requests the attributes which are described below.
2. If the primary query is not found in Microsoft Entra ID and the Secondary Key is configured, it does a second query for the destination number using a second Microsoft Entra ID attribute key name, configured by the `MSLDAPSecondaryKey` parameter.
3. If none of the queries are successful, it routes the call to the original dialed destination number according to the routing rule matching the "LDAP\_ERR" destination prefix number value, or rejects the call with a SIP 404 "Not Found" response.
4. For each query (primary or secondary), it queries the following attributes (if configured):
  - `MSLDAPPBXNumAttributeName`
  - `MSLDAPOCSNumAttributeName`
  - `MSLDAPMobileNumAttributeName`

In addition, it queries the special attribute defined in `MSLDAPPrivateNumAttributeName`, only if the query key (primary or secondary) is equal to its value.

5. If the query is found: Microsoft Entra ID returns up to four attributes - Skype for Business, PBX / IP PBX, private (only if it equals Primary or Secondary key), and mobile.
6. The device adds unique prefix keywords to the query results in order to identify the query type (i.e., IP domain). These prefixes are used as the prefix destination number value in the Tel-to-IP Routing table to denote the IP domains:
  - "PRIVATE" (PRIVATE:<private\_number>): used to match a routing rule based on query results of the private number (`MSLDAPPrivateNumAttributeName`).
  - "OCS" (OCS:<Skype for Business\_number>): used to match a routing rule based on query results of the Skype for Business client number (`MSLDAPOCSNumAttributeName`).
  - "PBX" (PBX:<PBX\_number>): used to match a routing rule based on query results of the PBX / IP PBX number (`MSLDAPPBXNumAttributeName`).
  - "MOBILE" (MOBILE:<mobile\_number>): used to match a routing rule based on query results of the mobile number (`MSLDAPMobileNumAttributeName`).
  - "LDAP\_ERR": used to match a routing rule based on a failed query result when no attribute is found in Microsoft Entra ID.



These prefixes are involved only in the routing and manipulation processes; they are not used as the final destination number.


7. The device uses the Tel-to-IP Routing table to route the call based on the LDAP query result. The device routes the call according to the following priority:
  - a. **Private line:** If the query is done for the private attribute and it's found, the device routes the call according to this attribute.
  - b. **Mediation Server SIP address (Skype for Business):** If the private attribute doesn't exist or is not queried, the device routes the call to the Mediation Server (which then routes the call to the Skype for Business client).
  - c. **PBX / IP PBX:** If the Skype for Business client is not found in Microsoft Entra ID, it routes the call to the PBX / IP PBX.
  - d. **Mobile number:** If the Skype for Business client (or Mediation Server) is unavailable (e.g., SIP response 404 "Not Found" upon INVITE sent to Skype for Business client), and the PBX / IP PBX is also unavailable, the device routes the call to the user's mobile number (if exists in Microsoft Entra ID).
  - e. **Alternative route:** If the call routing to all the above fails (e.g., due to unavailable destination - call busy), the device can route the call to an alternative destination if an alternative routing rule is configured.
  - f. **"Redundant" route:** If the query failed (i.e., no attribute found in Microsoft Entra ID), the device uses the routing rule matching the "LDAP\_ERR" prefix destination number value.



For digital interfaces (Gateway application): For Enterprises implementing a PBX / IP PBX system, but yet to migrate to Skype for Business, if the PBX / IP PBX system is unavailable or has failed, the device uses the Microsoft Entra ID query result for the user's mobile phone number, routing the call through the PSTN to the mobile destination.

The flowchart below summarizes the device's process for querying Microsoft Entra ID and routing the call based on the query results:





### Configuring Routing Rules based on Microsoft Entra ID

The following procedure describes how to configure outbound IP routing based on LDAP queries.

#### ➤ To configure LDAP-based IP routing for Skype for Business:

1. Configure the LDAP server parameters, as described in [Configuring LDAP Servers](#) on page 376.
2. Configure the Microsoft Entra ID attribute names used in the LDAP query:

- a. Open the LDAP Settings page (**Setup** menu > **IP Network** tab > **AAA Servers** folder > **LDAP Settings**).

ACTIVE DIRECTORY	
<b>LDAP Numeric Attributes</b>	<input type="text"/>
LDAP OCS Number Attribute Name	<input type="text" value="msRTCSIP-Line"/>
MS LDAP PBX Number Attribute Name	<input type="text" value="telephoneNumber"/>
LDAP MOBILE Number Attribute Name	<input type="text" value="mobile"/>
LDAP DISPLAY Name Attribute Name	<input type="text" value="displayName"/>
LDAP PRIVATE Number Attribute Name	<input type="text" value="msRTCSIP-PrivateLine"/>
LDAP Primary Key	• <input type="text" value="telephoneNumber"/>
LDAP Secondary Key	<input type="text"/>

- b. Configure the LDAP attribute names as desired.
3. **Gateway application:** Configure Tel-to-IP routing rules:
    - a. Open the Tel-to-IP Routing table (see [Configuring Tel-to-IP Routing Rules](#) on page 914).
    - b. Configure query-result routing rules for each IP domain (private, PBX / IP PBX, Teams / Skype for Business clients, and mobile), using the LDAP keywords (case-sensitive) for the prefix destination number:
      - ◆ PRIVATE: Private number
      - ◆ OCS: Skype for Business client number
      - ◆ PBX: PBX / IP PBX number
      - ◆ MOBILE: Mobile number
      - ◆ LDAP\_ERR: LDAP query failure
    - c. Configure a routing rule for routing the initial Tel call to the LDAP server, using the value "LDAP" (without quotation marks) for denoting the IP address of the LDAP server.
    - d. For alternative routing, enable the alternative routing mechanism and configure corresponding SIP reasons for alternative routing. For this feature, alternative routing starts from the table row located under the LDAP query row.
  4. **SBC application:** Configure IP-to-IP routing rules:
    - a. Open the IP-to-IP Routing table (see [Configuring SBC IP-to-IP Routing Rules](#) on page 1076).
    - b. Configure query-result routing rules for each IP domain (private, PBX / IP PBX, Teams / Skype for Business clients, and mobile), using the LDAP keywords (case-sensitive) in the 'Destination Username Pattern' field:
      - ◆ PRIVATE: Private number

- ◆ OCS: Skype for Business client number
  - ◆ PBX: PBX / IP PBX number
  - ◆ MOBILE: Mobile number
  - ◆ LDAP\_ERR: LDAP query failure
- c. Configure a routing rule for routing the initial call (LDAP query) to the LDAP server, by setting the 'Destination Type' field to LDAP for denoting the IP address of the LDAP server.
  - d. For alternative routing, enable the alternative routing mechanism and configure corresponding SIP reasons for alternative routing. For this feature, alternative routing starts from the table row located under the LDAP query row.

The table below shows an example for configuring Tel-to-IP routing rules based on Microsoft Entra ID in the Tel-to-IP Routing table:

**Table 16-14: Examples of Tel-to-IP Routing Rules based on Microsoft Entra ID**

Index	Destination Phone Prefix	Destination IP Address
1	PRIVATE:	10.33.45.60
2	PBX:	10.33.45.65
3	OCS:	10.33.45.68
4	MOBILE:	10.33.45.100
5	LDAP_ERR	10.33.45.80
6	*	LDAP
7	*	10.33.45.72

The table below shows an example for configuring SBC routing rules based on Microsoft Entra ID in the IP-to-IP Routing Table:

**Table 16-15: Examples of SBC IP-to-IP Routing Rules based on Microsoft Entra ID**

Index	Destination Username Pattern	Destination Type	Destination Address
1	PRIVATE:	Dest Address	10.33.45.60
2	PBX:	Dest Address	10.33.45.65
3	OCS:	Dest Address	10.33.45.68
4	MOBILE:	Dest Address	10.33.45.100

Index	Destination Username Pattern	Destination Type	Destination Address
5	LDAP_ERR	Dest Address	10.33.45.80
6	*	LDAP	-
7	*	Dest Address	10.33.45.72

The configured routing rule example is explained below:

- **Rule 1:** Sends call to private telephone line (at 10.33.45.60) upon successful Microsoft Entra ID query result for the private attribute.
- **Rule 2:** Sends call to IP PBX (at 10.33.45.65) upon successful Microsoft Entra ID query result for the PBX attribute.
- **Rule 3:** Sends call to the client (i.e., Mediation Server at 10.33.45.68) upon successful Microsoft Entra ID query result for the Skype for Business attribute.
- **Rule 4:** Sends call to user's mobile phone number (to PSTN through the device's IP address at 10.33.45.100) upon Microsoft Entra ID query result for the Mobile attribute.
- **Rule 5:** Sends call to IP address of device (10.33.45.80) upon Microsoft Entra ID query failure (e.g., no response from LDAP server or attribute not found).
- **Rule 6:** Sends query for original destination number of received call to the LDAP server.
- **Rule 7:** Alternative routing rule that sends the call of original dialed number to IP destination 10.33.45.72. This rule is applied in any of the following cases
  - LDAP functionality is disabled.
  - LDAP query is successful but call fails (due to, for example, busy line) to all the relevant attribute destinations (private, Skype for Business, PBX, and mobile), and a relevant Tel-to-IP Release Reason (see [Alternative Routing for Tel-to-IP Calls](#) on page 937) or SBC Alternative Routing Reason (see [Configuring SIP Response Codes for Alternative Routing Reasons](#) on page 1104) has been configured.

Once the device receives the original incoming call, the first rule that it uses is Rule 6, which queries Microsoft Entra ID. When Microsoft Entra ID replies, the device searches the table, from the first rule down, for the matching destination phone prefix (i.e., "PRIVATE:", "PBX:", "OCS:", "MOBILE:", and "LDAP\_ERR:"), and then sends the call to the appropriate destination.

### Querying Microsoft Entra ID for Calling Name

The device can retrieve the calling name (display name) from an LDAP-compliant server (for example, Microsoft Entra ID) for Tel-to-IP calls that are received without a calling name.

The device uses the calling number (PBX or mobile number) for the LDAP query. Upon an incoming INVITE, the device queries Microsoft Entra ID based on the Calling Number search key (tries to match the calling number with the appropriate "telephoneNumber" or "mobile" number Microsoft Entra ID attribute entry). It then searches for the corresponding calling name

attribute, configured by the `MSLDAPDisplayNameAttributeName` parameter (e.g., "displayName"). The device uses the resultant calling name as the display name parameter in the SIP From header of the outgoing INVITE message.

To configure this feature, the following keywords are used in the Calling Name Manipulation for Tel-to-IP Calls table for the 'Prefix/Suffix to Add' fields, which can be combined with other characters:

- "\$LDAP-PBX": LDAP query using the `MSLDAPPBXAttrName` parameter as the search key
- "\$LDAP-MOBILE": LDAP query using `MSLDAPMobileAttrName` parameter as the search key

If the source (calling) number of the Tel-to-IP call matches the PBX / MOBILE (e.g., "telephoneNumber" and "mobile") number in Microsoft Entra ID, the device uses the resultant Display Name instead of the keyword(s).

For example, assume the following configuration in the Calling Name Manipulation for Tel-to-IP Calls table:

- 'Source Phone Pattern' field is set to "4".
- 'Prefix to Add' field is set to "\$LDAP-PBX Office".

If the calling number is 4046 and the resultant LDAP query display name is "John Doe", the device sends the INVITE message with the following From header:

From: John Doe <sip:4064@company.com>



- The Calling Name Manipulation for Tel-to-IP Calls table uses the numbers before manipulation, as inputs.
- The LDAP query uses the calling number after source number manipulation, as the search key value.
- This feature is applicable only to the Gateway application.

## OAuth 2.0 Based Authentication Services

You can configure the device to use the OAuth 2.0 authentication protocol for authenticating the following:

- Incoming SIP messages - see [OAuth 2.0 Based SIP Message Authentication](#) on page 424
- device management users - [OAuth-based User Login Authentication and Authorization](#) on page 408

## Configuring OAuth 2.0 Servers

The OAuth Servers table lets you configure a single OAuth server. You can use the OAuth server for OAuth-based login authentication of users and authentication of incoming SIP message authentication.

The following procedure describes how to configure the OAuth server through the Web interface. You can also configure it through ini file [OAuthServers] or CLI (`configure system > oauth-servers`).

➤ **To configure an OAuth server:**

1. Open the OAuth Servers table (**Setup** menu > **IP Network** tab > **AAA Servers** folder > **OAuth Servers**).
2. Click **New**; the following dialog box appears:

GENERAL	
Index	0
Name	
Server Type	Azure
Base URL	https://login.microsoftonline.com/common
Authorization Endpoint	/oauth2/v2.0/authorize
Device Code Endpoint	/oauth2/v2.0/devicecode
Token Endpoint	/oauth2/v2.0/token
Keys Endpoint	/discovery/v2.0/keys
Logout Endpoint	/oauth2/v2.0/logout
Keys Refresh Time (min)	720
Application ID	
REST API 'aud' Prefix	api://

3. Configure the OAuth server according to the parameters described in the table below.
4. Click **Apply**.

**Table 16-16: OAuth Servers Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' server-name [OAuthServerName]	Defines an arbitrary name to easily identify the row. The valid value is a string of up to 20 characters. <b>Note:</b> <ul style="list-style-type: none"> <li>■ Configure each row with a unique name.</li> <li>■ The parameter is mandatory.</li> </ul>
'Server Type' server-type [OAuthServerType]	Defines the provider of the OAuth service. <ul style="list-style-type: none"> <li>■ [0] <b>Azure</b> (default)</li> </ul>

Parameter	Description
	<b>Note:</b> The parameter is mandatory.
'Base URL' base-url [OAuthBaseURL]	Defines the base URL. The endpoints configured by the below parameters follow this base URL. For example, the full URL path of the default authorization endpoint is "https://login.microsoftonline.com/common/oauth2/v2.0/authorize". The default is "https://login.microsoftonline.com/common". <b>Note:</b> The parameter is mandatory.
'Authorization Endpoint' authorization-endpoint [OAuthAuthorizeEndpoint]	Defines the authorization endpoint URL path (which follows the base URL). The default is "/oauth2/v2.0/authorize".
'Device Code Endpoint' devicecode-endpoint [OAuthDeviceCodeEndpoint]	Defines the device code endpoint URL. The default is "/oauth2/v2.0/devicecode".
'Token Endpoint' token-endpoint [OAuthTokenEndpoint]	Defines the token endpoint URL. The default is "/oauth2/v2.0/token".
'Keys Endpoint' keys-endpoint [OAuthKeysEndpoint]	Defines the key endpoint. The default is "/discovery/v2.0/keys". <b>Note:</b> The parameter is mandatory.
'Logout Endpoint' logout-endpoint [OAuthLogoutEndpoint]	Defines the logout endpoint URL. The default is "/oauth2/v2.0/logout".
'Keys Refresh Time' keys-refresh-time [OAuthKeysRefreshTime]	Defines the periodic time (in minutes) to refresh the public keys (by requesting them from Azure Microsoft Entra ID). The valid value range is 360 to 1440. The default is 720. <b>Note:</b> The parameter is mandatory.
'Application ID' application-id [OAuthAppId]	Defines the Application (client) ID assigned by your Azure Microsoft Entra ID account for the app created (registered) for the device in Microsoft Entra ID.

Parameter	Description
	By default, no value is defined. <b>Note:</b> The parameter is mandatory.
'REST API 'aud' Prefix' rest-api-aud-prefix [RestApiAudPrefix]	Defines the REST API 'aud' prefix. This is used when validating the 'aud' specified when the validation request is from the REST API. The default is "api://".
'TLS Context' tls-context [TLSContext]	Assigns a TLS Context from the TLS Contexts table (see <a href="#">Configuring TLS Certificate Contexts</a> on page 224). By default, no value is defined (and TLS Context #0 is used).
'Verify Certificate' verify-certificate [VerifyCertificate]	Enables the verification of the TLS certificate that is used in the incoming connection request from the OAuth server. <ul style="list-style-type: none"><li>■ [0] <b>Disable</b> = (Default) No certificate verification is done.</li><li>■ [1] <b>Enable</b> = The device verifies the authentication of the certificate received from OVOC. The device authenticates the certificate against the trusted root certificate store associated with the assigned TLS Context (see 'TLS Context' parameter above) and if ok, allows communication with the server. If authentication fails, the device denies communication (i.e., handshake fails). The device can also authenticate the certificate by querying an Online Certificate Status Protocol (OCSP) server if the certificate has been revoked. This is also configured for the associated TLS Context.</li></ul>
'Network Interface' network-interface [NetworkInterface]	Assigns an IP network interface from the IP Interfaces table (see <a href="#">Configuring IP Network Interfaces</a> on page 157) for communication with the OAuth server. By default, no value is defined (and OAMP interface is used). <b>Note:</b> The parameter is mandatory.

## OAuth-based User Login Authentication and Authorization

You can use Microsoft Entra ID (formerly, Azure Active Directory) to authenticate and authorize users that are logging in to the device. This can be implemented for the Web interface, CLI, and REST API management interfaces.

Authentication of a user verifies that the combination of username and password (login credentials) is correct. Authorization of a user determines the user's privilege level (e.g., Security Administrator or Monitor).





The device also supports the following user login authentication methods:

- RADIUS-based authentication (see [RADIUS-based User Login Authentication](#) on page 365)
- LDAP-based authentication (see [LDAP-based Services](#) on page 369)

### Setting Up Microsoft Entra ID for User Login OAuth Authentication



To allow OAuth-based user login authentication using Microsoft Entra ID, you need to set up your Microsoft Entra ID account (<https://portal.azure.com>). Below summarizes the required steps. For a detailed description, contact AudioCodes support.


1. Register a new application (e.g., called "SBC") and define the 'Redirect URI', which is the URL (i.e., device's IP address or host name) to where Microsoft Entra ID sends its authentication response after successfully authenticating the user.
2. Create App Roles, which represent the device's user privilege levels (i.e., Administrator and Monitor).
3. Assign each User (or Group) to the desired Role (privilege level).
4. Note down the values of the following fields, which are required when you configure the Microsoft Entra ID on the device:
  - Application (client) ID
  - Directory (tenant) ID
  - Redirect URI
5. To support CLI user login authentication, contact AudioCodes support.
6. To support REST API client login authentication, contact AudioCodes support.

### Registering Application in Microsoft Entra ID


To enable login through Microsoft Entra ID, you need to first register an application for the device's authentication login feature in your Microsoft Entra ID portal.

#### ➤ To register an app in Microsoft Entra ID:


1. Sign in to the [Azure portal](#) using your organization's Microsoft account.
2. If your account gives you access to more than one tenant, click the **Directories + subscriptions** filter  icon on the toolbar to select the tenant in which you want to register an application.
3. Search for and select the **Microsoft Entra ID** service  icon:




4. From the Navigation pane, select  **App registrations**, and then click **New registration**:





The Register an application page appears:




5. Do the following:
- Under the Name group, enter a meaningful name for the application (e.g., "SBC Manager").
  - Under the Supported account types group, select which accounts you would like your application to support:
    - ◆ If you want to allow users from your organization only to access the application, choose **Accounts in this organizational directory only**.

- ◆ If you want to allow users from any organization to access the application, choose **Accounts in any organizational directory**.
  - c. Under the Redirect URI group, select **Single-page application (SPA)** from the drop-down list, and then enter the redirect URI in the format, `https://<FQDN or IP address of device>`. Upon successful authentication, this is the address to which the user is redirected (i.e., the device).
  - d. Click **Register**; Microsoft Entra ID assigns a unique application (client) ID to your app.
6. From the Navigation menu, select  **Authentication**, and then under the **Implicit grant and hybrid flows** group, select the **ID tokens** check box, and then click **Save**:



7. From the Navigation menu, select  **App roles**, and then click **Create app role**; the Create app role page appears:




8. Create the roles you have in your device (Monitor, Administrator, and Security Administrator):


- 'Display name': Define a meaningful display name for each role
- 'Allowed member types': For each role, select **Both (Users/Groups + Applications)**
- 'Value': Enter the following value for the appropriate role:
  - ◆ **Monitor**
  - ◆ **Administrator**
  - ◆ **Security\_Administrator**
- 'Description': Define a meaningful description for each role

Select the **Do you want to enable this app role** check box, and then click **Apply**.





The following step enables programmatic access to the device through REST API. If you don't need such access, skip this step.

- From the Navigation menu, select  **Expose an API**. If an Application ID URI is not configured yet, click **Set**, and then enter the following value: **api://<client ID>** (replace <client ID> with Entra ID application's 'Application (client) ID', which you can obtain from the Overview page), and then click **Save**:




The following step enables CLI access to the device through the serial console or SSH. If you don't need such access, skip this step.

- From the Navigation menu, select  **Authentication**, and then under the **Allow public client flows** group, enable the mobile and desktop flows, by clicking **Yes**, and then clicking **Save**:



- From the Navigation menu, select **Overview**, and then make a note of the 'Application (client) ID' and 'Directory (tenant) ID' values; you will need them when you configure the device.





## Assigning Access to Application for User-Groups


Once you have registered the application in Azure (see [Registering Application in Microsoft Entra ID](#) on page 409), you can grant access for specific users and groups.

### ➤ To grant access to user/groups:

- From the Navigation pane, select **Enterprise applications**, and then search for your registered application (e.g. "SBC Manager") by setting 'Application type' to **All applications** and typing the application name into the search field:



2. Click searched for application, and then from the Navigation pane, select  **Users and groups**:



3. For each user or group that you want to grant access to the application:
  - a. Click **Add user/group**.
  - b. Select the user or group.
  - c. Select the role (**Monitor**, **Administrator**, or **Security\_Administrator**).
  - d. Click **Assign**.

## Device Configuration Summary

This section provides a summary of the required configuration of the device for OAuth-based user login authentication using Microsoft Entra ID.

1. Configure a TLS certificate:
  - a. Open the TLS Contexts table (see [Configuring TLS Certificate Contexts](#) on page 224), and then select TLS Context #0.
  - b. Click the **Change Certificate** link at the bottom of the page, and then in the load a proper device certificate (see [Assigning CSR-based Certificates to TLS Contexts](#) on page 231).
  - c. Navigate back to the TLS Contexts table, and click the **Trusted Root Certificates** link at the bottom of the page, and then import the [TLS certificates used by Azure](#).
2. Open the Web Settings page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Web Settings**), and then configure the following:
  - a. Select the 'Local Users Table Can Be Empty' check box:

**Local Users Table can be Empty** ☒

- b. From the 'Secured Web Connection (HTTPS)' drop-down list, select **HTTPS Only** or **HTTPS Redirect**.

Secured Web Connection (HTTPS)

• HTTPS Only ▼

- c. In the 'Web Server Name' field, enter the FQDN assigned to the device's management IP address (assigned to eth0 front-end IP on Internal Load Balancer).


Web Server Name

• sbcols1.eastus.12345.com

3. Open the OAuth Servers table (see [Configuring OAuth 2.0 Servers](#) on page 405), and then configure an OAuth Server with the following settings:
  - 'Name': Microsoft Entra ID
  - 'Base URL': https://login.microsoftonline.com/<tenant-id>  
 The <tenant-id> should be the 'Directory (tenant) ID' value from the registered application in Microsoft Entra ID (see [Registering Application in Microsoft Entra ID](#) on page 409) if it is configured to allow access only for users from its organization (single-tenant). The <tenant-id> should be "common" if the application is configured to allow access only for users from all organizations (multi-tenant).
  - 'Application ID': The 'Application (client) ID' value of the registered application in Microsoft Entra ID (see [Registering Application in Microsoft Entra ID](#) on page 409)
  - 'Network Interface': Select the network interface that has the public IP address (e.g., eth2)
  - 'Verify Certificate': **Enable** (requires that you load Microsoft Entra ID CA certificates as trusted roots for TLS Context #0 as described in Step 1 above, or other TLS context configured in TLS Context table)
4. Open the Login OAuth Servers table (see [Configuring OAuth Servers for User Login Authentication](#) on page 420), and then configure a Login OAuth Server with the following settings:
  - 'Name': Microsoft Entra ID
  - 'OAuth Server': Select **Microsoft Entra ID** (created in previous step)
  - 'Service Activation': **Enable**
5. Open the Authentication Server page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Authentication Server**), and then from the 'Use OAuth for Login' drop-down list, select **Enable with local login**.
6. Restart the device to activate the new configuration.

After the device restarts, the Web Login page also displays the **Login with Azure AD** button. You may log in using your Microsoft Entra ID credentials by clicking this button, or log in using your local (device) credentials by entering your username and password in the 'Username' and 'Password' fields respectively.

## Web Login

 Login with Azure AD

OR

**Username**

Admin

**Password**

Remember Username ☒

Log In

7. Verify that you can log in through Microsoft Entra ID.
8. (Optional) If your login through Microsoft Entra ID is successful, you can disable the login method using local credentials (Local Users table):
  - Open the Authentication Server page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Authentication Server**), and then from the 'Use OAuth for Login' drop-down list, select **Enable without local login**. Upon the next log in, the Web Login page only displays the **Login with Azure AD** button.
  - (Optional) Delete all users in the Local Users table (see [Deleting All Users in Local Users Table](#) on page 63).



## Microsoft Entra ID Login to Device's Web Interface

If you configure the device to enable login through Microsoft Entra ID, the Web Login page includes both the **Login with Azure AD** button, and the 'Username' and 'Password' fields for local login using the Local Users table (or using RADIUS or LDAP).


If you configure the device to enable login **only** through Microsoft Entra ID, the Web Login page only displays the **Login with Azure AD** button.

If you click **Login with Azure AD**, you are prompted to enter your Microsoft Entra ID credentials (which may include two-factor authentication). When login authentication completes successfully you are redirected back to the device's Web interface and logged in with the access level according to the Role assigned to you by Microsoft Entra ID.

## Microsoft Entra ID Login to Device's CLI

When you log in to the device through CLI (SSH or serial console), you should enter any string that contains the "@" sign as the username. For example, you may enter your Microsoft Entra ID User ID (email) such as user@contorso.com.

You are prompted to open your Web browser and go to <https://microsoft.com/devicelogin>, and then enter the authentication code shown in the CLI:



```
20.69.77.75 - KiTTY
login as: some@contorso.com
Pre-authentication banner message from server:
| Welcome to AudioCodes CLI
End of banner message from server

To sign in, use a web browser to open the page https://microsoft.com/devicelogin
and enter the code SRJ6S6KMK to authenticate.

Med#
```

When the authentication process completes, you will be logged in to the CLI session.

## Microsoft Entra ID Login to Device's REST API





This section describes the login to the device's REST API through Microsoft Entra ID.


### Creating Microsoft Entra ID Application for REST Client

To log in to the device through REST API, you need to create a Microsoft Entra ID Application that represents your REST client and grant this application access to the Microsoft Entra ID Application that represents device.

#### ➤ To create a Microsoft Entra ID Application for REST client:

1. Sign in to the [Azure portal](#) using your organization's Microsoft account.

2. If your account gives you access to more than one tenant, click the **Directories + subscriptions** filter  icon on the toolbar to select the tenant in which you want to register an application.
3. From the Navigation pane, select  **App registrations**, and then click **New registration**.
4. Under the Name group, enter a meaningful name for the application (e.g., "My REST Client"), leave 'Redirect URI' empty, and then click **Register**.
5. From the Navigation menu, select **Overview**, and then make a note of the 'Application (client) ID' and 'Directory (tenant) ID' values; you will need them later.
6. From the Navigation pane, select  **Certificates & secrets**, and then click **New client secret**.
7. Enter a description for the new secret, select the expiration time, and then click **Add**.
8. Copy the value of the generated client secret and store it for future use.
9. From the Navigation pane, select  **API permissions**, and then click **Add a permission** to add new permission.
10. Click the **My APIs** tab, and then select the Azure application that represents the device (e.g., "SBC Manager"):



11. Select **Application permissions**, choose an appropriate role (e.g., Administrator), and then click **Add permissions**.
12. Request from your Microsoft Entra ID administrator to grant admin consent to your app permissions.
13. Wait until your Microsoft Entra ID administrator completes the task and then verify that the status of your application permissions changes to "Granted".

### Acquiring the Access Token

Prior to accessing the device's REST API, you need to acquire the access token using the REST Client application credentials.

➤ **To acquire access token:**

1. Send a POST request to Microsoft identity platform's token endpoint:

```
// Line breaks are for legibility only
POST https://login.microsoftonline.com/<tenant_id>/oauth2/v2.0/token
FORM DATA: {
grant_type=client_credentials
client_id=<rest_client_id>
client_secret=<rest_client_secret>
scope=api://<sbcm_manager_client_id>/default
}
```

Replace the following:

- <tenant\_id> with your tenant ID.
- <rest\_client\_id> and <rest\_client\_secret> with the client ID and secret of the REST Client application.
- <sbcm\_manager\_client\_id> with the client ID of the device's application (e.g., "SBC manager").

Example:

```
curl --location --request POST 'https://login.microsoftonline.com/1911c65c-893b-42f9-83fa-66c1b86fdf85/oauth2/v2.0/token'
--form grant_type="client_credentials"
--form client_id="a26aff59-0bba-42bc-b0a0-87c1e292ef89"
--form client_secret="HMMx3_.pb6XQ26gwiHY45BttS7~Axt_yBH"
--form scope="api://faea2ec7-659a-4c46-8d2a-83436882fdd7/default"
```

2. A successful response contains the access token:

```
200 OK
Content-Type: application/json
{
  "token_type": "Bearer",
  "expires_in": 3599,
  "ext_expires_in": 3599,
  "access_token": "eyJ0eXAiOiJKV1QiLCJhbGciOiJSUzI1NiIs..."
}
```

### Accessing REST API using Access Token

To access the device's REST API, you need to use the access token that you acquired in [Acquiring the Access Token](#) on the previous page as the Bearer token.

1. Include the access token in the Authorization header when accessing the device's (e.g., "SBC manager") REST API endpoints:

```
GET https://<sbcmgr>/api/v1/status
Authorization: Bearer eyJ0eXAiOiJKV1QiLCJhbGciOiJSUzI1NiIs...
```

2. If you need to send multiple REST API requests, use the session cookie returned in the response to the first request, in the next requests.

### Configuring OAuth Servers for User Login Authentication

The Login OAuth Servers table lets you configure a single interface (Microsoft Entra ID tenant) with the OAuth 2.0 server for OAuth-based user login authentication. OAuth-based login authentication is applicable to the device's Web interface, CLI, and REST API.

The following procedure describes how to configure the OAuth server through the Web interface. You can also configure it through ini file [LoginOAuthServers] or CLI (`configure system > login-oauth-servers`).

#### ➤ To configure an OAuth server for user login authentication:

1. Open the Login OAuth Servers table (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Login OAuth Servers**).
2. Click **New**; the following dialog box appears:

3. Configure the login OAuth server according to the parameters described in the table below.
4. Click **Apply**.

**Table 16-17: Login OAuth Servers Table Parameter Descriptions**


Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name'	Defines an arbitrary name to easily identify the row (tenant ID).

Parameter	Description
server-name [Name]	The valid value is a string of up to 20 characters. By default, no value is defined. <b>Note:</b> Configure each row with a unique name.
'OAuth Server' oauth-server [OAuthServer]	Assigns an OAuth server, which is configured in the OAuth Servers table (see <a href="#">Configuring OAuth 2.0 Servers</a> on page 405). By default, no value is defined.
'Service Activation' service-activation [ServiceActivation]	Enables this OAuth-based login authentication rule.  ■ [0] <b>Disable</b> (default) ■ [1] <b>Enable</b>
'Max Response Time' max-resp-time [MaxRespTime]	Defines the maximum time (in seconds) that the device waits for a response from the OAuth server. If no response is received within this period, the device considers it a response timeout (and no retries are done).  The valid value is 1 to 30. The default is 3.

### Enabling OAuth-based User Login Authentication


In addition to configuring the OAuth 2.0 server for user login authentication based on the OAuth 2.0 protocol (see [Configuring OAuth Servers for User Login Authentication](#) on the previous page and [Configuring OAuth 2.0 Servers](#) on page 405, you need to enable OAuth-based login authentication.

You can enable OAuth-based login authentication only. In this configuration setup, the Web Login page is displayed as below. To log in, click **Login with Azure AD**. You are redirected to Microsoft login page to start the login process. If login fails, you are redirected to the Web Login page and a failure message is displayed.



Alternatively, you can enable OAuth-based login authentication with local (or RADIUS or LDAP) login authentication. Local authentication uses the Local Users table (see [Configuring Local Management User Accounts](#) on page 54) to authenticate the user's login credentials (username and password). This means that the user can choose to log in to the device using any one of these authentication methods. In this configuration setup, the Web Login page is displayed as below:

## Web Login

 Login with Azure AD

OR

**Username**

**Password**

Remember Username ☒

Log In

To log in using OAuth 2.0 authentication, click **Login with Azure AD**. To log in using local (or RADIUS or LDAP) authentication, enter your username and password, and then click **Log In**.



For OAuth user login authentication, you also need to enable the OAuth server used for login authentication ('Service Activation' parameter) in the Login OAuth Servers table (see [Configuring OAuth Servers for User Login Authentication](#) on page 420).

➤ **To enable OAuth-based login authentication:**

1. Open the Authentication Settings page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Authentication Settings**).
2. From the 'Use OAuth for Web Login' drop-down list, select one of the following:

- **Disable:** Disables OAuth-based login authentication
- **Enable with local login:** Enables both OAuth-based login authentication and local login authentication (using the Local Users table)
- **Enable without local login:** Enables OAuth-based login authentication only

Use OAuth for Web Login

■ Enable with local login ▼

Redirect URI

https://10.15.7.96

The 'Redirect URI' read-only field displays the URL (i.e., device's IP address, or hostname if configured) that the user is redirected to (e.g., by Microsoft Entra ID) after it has been successfully authenticated (and is then logged in).

3. Click **Apply**.

## OAuth 2.0 Based SIP Message Authentication

You can use the following methods to authenticate incoming SIP messages using the OAuth 2.0 protocol:

- [Authenticating SIP Messages using Device's OAuth 2.0 Server with Microsoft Entra ID](#) below
- [Authenticating SIP Messages with External OAuth 2.0 Server](#) on the next page

### Authenticating SIP Messages using Device's OAuth 2.0 Server with Microsoft Entra ID

You can configure the device to use Microsoft Entra ID (formerly, Azure Active Directory) to authenticate incoming SIP messages based on the OAuth 2.0 protocol. Microsoft Entra ID is a cloud-based identity and access management service, designed for Internet-based applications.

As Microsoft Entra ID doesn't support OAuth Token Introspection, the device validates the received token using its embedded NGINX server, which simulates an OAuth 2.0 Introspection endpoint.

The SIP UA obtains its token using the Microsoft Entra ID APIs for identification and token generation, in JSON Web Token (JWT) format, which is a secure signed and encrypted JSON document identifying the user, and includes it in the Authorization header of SIP requests sent to the device. For the device to validate the JWT, it needs the public keys from Microsoft Entra ID, which it downloads periodically (Microsoft Entra ID refreshes keys daily).

When the device receives a SIP request that needs validation, it extracts the token from the 'Authorization: Bearer <token>' header of the SIP message and sends it the NGINX server. NGINX then decrypts the token using the public keys and validates them.



➤ **To configure OAuth 2.0 authentication with Microsoft Entra ID:**

1. Make sure that the settings of your Microsoft Entra ID are appropriately defined to operate with the device. For more information, contact your AudioCodes sales representative.
2. Configure a Remote Web Service to represent the device's embedded NGINX server, acting as the OAuth 2.0 Introspection endpoint:
  - a. Open the Remote Web Services table (see [Configuring Remote Web Services](#) on page 429), and then configure a Remote Web Service with the following settings:
    - ◆ 'Name': "InternalOauth"
    - ◆ 'Type': **General**
    - ◆ 'Path': "introspect"
  - b. Select the Remote Web Service that you configured, click the **HTTP Remote Hosts** link located below the table, and then configure an HTTP Remote Host to represent the device's embedded NGINX (OAuth) server, with the following settings:
    - ◆ 'Address': "127.0.0.1"
    - ◆ 'Port': "321"
    - ◆ 'Transport Type': **HTTP**
3. Open the IP Groups table (see [Configuring IP Groups](#) on page 581), and then configure an IP Group for the source of the incoming SIP messages with the following settings:
  - 'Authentication Mode': **SBC as Server**
  - 'Authentication Method List': "register/setup-invite"
  - 'SBC Server Authentication Type': **Authenticate with OAuth Server**
  - 'OAuth HTTP Service': **Internal Oauth** (i.e., Remote Web Service that you configured previously)
4. Make sure that you have configured a DNS server for the local IP network interface in the IP Interfaces table (see [Configuring IP Network Interfaces](#) on page 157).
5. Open the OAuth Servers table (see [Configuring OAuth 2.0 Servers](#) on page 405), and then configure the OAuth 2.0 server for Microsoft Entra ID with the following settings:
  - 'Base URL': "https://login.microsoftonline.com/<tenant ID, obtained from your Microsoft Entra ID account>"
  - 'Application ID': Copy-and-paste the Application (client) ID, obtained from your Microsoft Entra ID account.

### **Authenticating SIP Messages with External OAuth 2.0 Server**

The device supports the OAuth 2.0 authentication protocol (RFC 7662 and Internet Draft "draft-ietf-sipcore-sip-authn-02"), allowing it to authenticate any specified incoming SIP request (e.g.,

REGISTER and INVITE) with a third-party OAuth 2.0 authorization server over HTTP/S.



OAuth-based authentication is applicable only to the SBC application.



To authenticate SIP messages using the device's embedded NGINX server (acting as the Introspection endpoint) with Microsoft Entra ID, see [Authenticating SIP Messages using Device's OAuth 2.0 Server with Microsoft Entra ID](#).

OAuth authorization consists of the following main stages:

1. (This stage doesn't involve the device.) The client application requires an OAuth Access Token for the user. There are multiple schemes to do this. For example, it may use the Authorization Code method, whereby the client application refers the user to the OAuth Authorization server to request an Authorization Code. The client application then uses the received Authorization Code to request an Access Token (and a Refresh Token) for the user from the Authorization server.
2. When the user wants to register with the device or make a call, the client application (e.g., Web browser for the WebRTC application) through which the user communicates with the device, sends a SIP REGISTER or INVITE request that includes the user's Access Token in the SIP Authorization header ("Bearer" value), as shown in the following REGISTER message example:

```
REGISTER sip:server.com SIP/2.0
Via: SIP/2.0/WSS 9rihbeck4vat.invalid;branch=z9hG4bK2426139
Max-Forwards: 69
To: <sip:alice@example.com>
From: "alice" <sip:alice@example.com>;tag=mstg4hpof6
Call-ID: 0il6hahess4ndc1pdlleqj
CSeq: 1 REGISTER
```


```
Authorization: Bearer eyJhbGciOiJSUzI1...
...zLbbMmZ06JA
```

```
Contact: <sip:lnumvv6i@9rihbeck4vat.invalid;transport=ws>;+sip.ice;reg-id=1;
+sip.instance="<urn:uuid:1007ed30-98a3-492e-966f
67b6f6eb99c5>";expires=600
Expires: 600
Allow:
INVITE,ACK,CANCEL,BYE,UPDATE,MESSAGE,OPTIONS,REFER,INFO
Supported: path,gruu,outbound
User-Agent: Example WebRTC phone
Content-Length: 0
```

3. The device authenticates the SIP request, by sending (HTTP POST) an HTTP Introspection request with the user's Access Token to the OAuth Authorization server, as shown in the following example:

```
POST /realms/demo/protocol/openid-connect/token/introspect HTTP/1.1
Host: authorizationhost.com
Content-Type: application/x-www-form-urlencoded
Content-Length:...
Authorization: Basic
dGVzdEludHJvc3BIY3Q6NTliZDA4NGUtMTJlNi00N2I5LWJmNz
token=<Access Token from Bearer in SIP Authorization header>
```

4. The OAuth Authorization server checks (*introspects*) if the token is currently active (or if it has expired or revoked). Upon a successful introspection, the OAuth Authorization server sends to the device a 200 OK response containing a JSON body ("application/ json").
5. The device checks the following attributes in the received JSON body:
  - "active": A "true" value indicates a valid token and the device allows the user access to its resources and continues with the regular handling and processing of the SIP request (e.g., registers user or processes the call). A "false" value indicates an invalid token and the device responds to the SIP request with a 401 (Unauthorized) response containing the header 'WWW-Authenticate: Bearer error="invalid-token"', indicating authentication failure.
  - "username": (Optional attribute) When it exists, the device compares it to the AOR of the SIP message. For REGISTER requests, the AOR is taken from the To header; for all other requests, the AOR is taken from the From header. If the username includes a "@" character, the entire AOR is compared; otherwise, only the user-part of the AOR is compared. If comparison fails, the device responds to the SIP request with a 401 (Unauthorized) response containing the header 'WWW-Authenticate: Bearer error="invalid\_request"', indicating authentication failure.



The main configuration required for OAuth-based authentication, includes the following:

- Configuring a Remote Web Service to represent the OAuth Authentication server

- Configuring the source IP Group (client) to authenticate by an OAuth Authorization server

The following provides a step-by-step example of configuring OAuth authentication.

➤ **To configure OAuth-based authentication:**

1. Open the Remote Web Services table (see [Configuring Remote Web Services](#) on the next page), and then configure a Remote Web Service to represent the OAuth Authentication server:

Parameter	Value	Comment
'Name'	"OAuth-Server"	Any descriptive name.
'Type'	<b>General</b>	-
'Path'	"realms/demo/protocol/openid-connect/token/introspect"	Relative URL for the introspection service on the server.
'Username'	"device234"	Username that the device uses for authenticating the HTTP POST introspection request which it sends to the OAuth server.
'Password'	"12abMt"	Password that the device uses for authenticating the HTTP POST introspection request which it sends to the OAuth server. <b>Note:</b> The password cannot be configured with wide characters.

2. Select the Remote Web Service that you configured in Step 1, click the **HTTP Remote Hosts** link located below the table, and then configure an HTTP Remote Host:

Parameter	Value	Comment
'Address'	"oauth.example.com"	Address of the Authentication server.
'Port'	"443"	Port number of the Authentication server.
'Transport Type'	<b>HTTPS</b>	Secured HTTP.

3. Configure OAuth-based authentication for the source IP Group (client that the device needs to authenticate):

Parameter	Value	Comment
'Authentication Mode'	<b>SBC as Server</b>	The device authenticates as a server.
'Authentication Method List'	"register/setup-invite"	The SIP methods that the device needs to authenticate.
'SBC Server Authentication Type'	<b>Authenticate with OAuth Server</b>	The device authenticates the SIP requests with an OAuth Authentication server.
'OAuth HTTP Service'	<b>OAuth-Server</b>	Assigns the Remote Web Service that you configured (in Step 1) for the OAuth Authentication server.

## Remote Web Services

This section describes configuration for remote Web services.



To debug remote Web services, see [Debugging Web Services](#) on page 1530.

## Configuring Remote Web Services

The Remote Web Services table lets you configure up to seven Web-based (HTTP/S) services (*Remote Web Services*) provided by third-party, remote HTTP/S hosts (*HTTP Remote Hosts*). The following types of services can be offered by the remote hosts: Routing service, Call Status service, Topology Status service, QoS service, General service, and Registration Status service. For more information on these services, see the description of the 'Type' parameter below.

Remote Web Services are configured using two tables with "parent-child" relationship:

- **Remote Web Services table ("parent"):** Defines the name of the Remote Web Service as well as other settings (e.g., type of service). This table is described below.
- **HTTP Remote Hosts table ("child"):** Defines remote HTTP hosts (e.g., IP address) per Remote Web Service. For more information, see [Configuring Remote HTTP Hosts](#) on page 438.



- You can configure only **one** Remote Web Service for each of the following service types: **Routing, Call Status, Topology Status, QoS, Registration Status, and Remote Monitoring**.
- The Routing service also includes the Call Status and Topology Status services.
- The device supports HTTP redirect responses (3xx) only during connection establishment with the host. Upon receipt of a redirect response, the device attempts to open a new socket with the host and if this is successful, closes the current connection.

The following procedure describes how to configure Remote Web Services through the Web interface. You can also configure it through ini file [HTTPRemoteServices] or CLI (`configure system > http-services > http-remote-services`).

➤ **To configure a remote Web service:**

1. Open the Remote Web Services table (**Setup** menu > **IP Network** tab > **Web Services** folder > **Remote Web Services**).
2. Click **New**; the following dialog box appears:

3. Configure a remote Web service according to the parameters described in the table below.
4. Click **Apply**, and then save your settings to flash memory.

**Table 16-18: Remote Web Services Table Parameter Descriptions**

Parameter	Description
<b>General</b>	
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> <ul style="list-style-type: none"> <li>■ Each row must be configured with a unique index.</li> <li>■ The parameter is mandatory.</li> </ul>
'Name'	Defines a descriptive name, which is used when

Parameter	Description
rest-name [Name]	<p>associating the row in other tables.</p> <p>The valid value is a string of up to 40 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Configure each row with a unique name.</li> <li>■ The parameter is mandatory.</li> <li>■ The parameter value cannot contain a forward slash (/).</li> </ul>
'Type' rest-message-type [HTTPType]	<p>Defines the type of service provided by the HTTP remote host:</p> <ul style="list-style-type: none"> <li>■ [0] <b>Routing</b> = (Default) This option provides a call routing service, whereby the host (ARM) determines the next hop of an incoming call on the path to its final destination. For more information on routing by ARM, see <a href="#">Centralized Routing by ARM (AudioCodes Routing Manager)</a> on page 442. This option also includes the services provided by the <b>Call Status</b> and <b>Topology Status</b> options.</li> <li>■ [1] <b>Call Status</b> = This option provides a call status service for calls processed by the device. The device provides call status to the host by sending CDRs.</li> <li>■ [2] <b>Topology Status</b> = This option provides a topology status service, which refers to all device configuration changes (add, edit and delete actions). The device sends topology status to the HTTP host, using the REST API command, TopologyStatus. For this service to be functional, you also need to enable the Topology Status service as described in <a href="#">Enabling Topology Status Services</a> on page 441.</li> </ul> <p>Topology status includes the following:</p> <ul style="list-style-type: none"> <li>✓ IP Group Connectivity: Status is reported when the keep-alive mechanism, enabled for the associated Proxy Set, detects that the IP Group is unavailable, or when CAC thresholds (configured in the Admission Control table) associated with the IP Group are crossed.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>✓ Trunk Group Availability: Status is reported when the trunk's physical state indicates that the trunk is unavailable. (Applicable only to the Gateway application.)</li> <li>✓ Configuration Status: Status is reported when IP Groups, Trunk Groups, (Gateway application only) or SIP Interfaces that are configured to be used by remote Web-based services (i.e., the UsedByRoutingServer parameter is set to 1 - Used) are created or deleted. If you subsequently change the settings of the UsedByRoutingServer parameter or the 'Name' parameter, the device reports the change as a creation or deletion of the corresponding configuration entity.</li> <li>■ [5] <b>QoS</b> = This option provides a call routing service based on Quality of Service (QoS). For more information on routing by ARM, see <a href="#">Centralized Routing by ARM (AudioCodes Routing Manager)</a> on page 442.</li> <li>■ [8] <b>General</b> = This option can be used for the following services: <ul style="list-style-type: none"> <li>✓ Generating and sending CDRs to a REST server through REST API. The REST server is configured as an HTTP-based server (Remote Web Service). For more information, see <a href="#">Configuring CDR Reporting to REST Server</a> on page 1383.</li> <li>✓ Querying (GET) HTTP servers using Call Setup Rules. The response from the server can be used for various functionality such as tag-based classification and routing. When configuring the Call Setup Rule, you need to configure the 'Request Target' parameter to the name of this Remote Web Service. For more information on Call Setup Rules, see <a href="#">Configuring Call Setup Rules</a> on page 782.</li> <li>✓ Requesting a Push Notification Server to wake a SIP user agent (typically, a mobile device)</li> </ul> </li> </ul>



Parameter	Description
	<p>that is registered with the server for Push Notification Service, through REST API. The REST server (Push Notification Server) is configured as an HTTP-based server (Remote Web Service). For more information, see <a href="#">Configuring Push Notification Service</a> on page 1167.</p> <ul style="list-style-type: none"> <li>■ [9] <b>Registration Status</b> = This option provides a call routing service based on registration status. The device periodically synchronizes its database of registered user agents (endpoints) with ARM (HTTP host) to keep it up to date, enabling ARM to use this information to perform correct and optimal routing decisions. For this service to be functional, you also need to enable the Registration Status service as described in <a href="#">Enabling Registration Status Services</a> on page 441.</li> <li>■ [10] <b>Remote Monitoring</b> = This option provides a remote monitoring of the device service when the device is located behind a NAT. The device sends its monitoring reports to this Remote Web Service (HTTP host). To enable remote monitoring and to select the report types that you want sent, see <a href="#">Remote Monitoring of Device behind NAT</a> on page 1467.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ You can configure only one Remote Web Service for each of the following service types: <b>Routing</b>, <b>Call Status</b>, <b>Topology Status</b>, <b>QoS</b>, <b>Registration Status</b>, and <b>Remote Monitoring</b>.</li> <li>■ The <b>Routing</b> option also includes the Call Status and Topology Status services.</li> <li>■ If you don't configure the parameter to <b>QoS</b>, the device sends QoS reports to the Topology server.</li> <li>■ For the Registration Status service, if you have not configured the parameter to <b>Registration Status</b> for any Remote Web Service, the device provides the service to the Remote Web Service for which you have configured the parameter to <b>Topology Status</b>.</li> </ul>

Parameter	Description
'Path' rest-path [Path]	Defines the path (prefix) to the REST APIs. The valid value is a string of up to 80 characters. The default is "api".
'Number of Connections' http-num-connections [NumOfSockets]	Defines the number of sockets that the device opens per HTTP remote host. The valid value is 3. The default is 1.
Policy	
'Policy in Group' http-policy [Policy]	<p>Defines the mode of operation between hosts in a group, which are configured in the HTTP Remote Hosts table for the specific remote Web service.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Round Robin</b> = (Default) The device does load balancing of traffic across all the hosts in the group. Every consecutive message is sent to the next available host. The priority of the hosts determines the order in which the device sends the traffic.</li> <li>■ [1] <b>Sticky Primary</b> = The device always attempts to send traffic to the host that has the highest priority in the group. If the host doesn't respond, the device sends the traffic to the next available host that has the highest priority. If the host that has the highest priority becomes available again, the device sends the traffic to this host.</li> <li>■ [2] <b>Sticky Next</b> = The device initially attempts to send traffic to the host that has the highest priority in the group. If this host becomes unavailable (or is initially unavailable), the device sends the traffic to the next available host that has the highest priority and continues sending traffic to this host even if the highest-priority host later becomes available again.</li> </ul> <p><b>Note:</b> If you have configured multiple hosts with the same priority, their priority is determined by their order of appearance in the HTTP Remote Hosts table. For example, if two hosts are configured in rows Index 0 and Index 1 with priority 0, the host in Index 0 is considered higher priority.</p>

Parameter	Description
'Policy between Groups' <code>http-policy-between-groups</code> <code>[BetweenGroupsPolicy]</code>	<p>Defines the mode of operation between groups of hosts, which are configured in the HTTP Remote Hosts table for the specific remote Web service.</p> <ul style="list-style-type: none"> <li>■ [1] <b>Sticky Primary</b> = (Default) The device always attempts to send traffic to the group that has the highest priority (e.g., Group 0). If none of the hosts in this group respond, the device attempts to send traffic to a host in a group that has the next highest priority (e.g., Group 1), and so on. Whenever a host in the group that has the highest priority (e.g., Group 0) becomes available again, the device sends the traffic to the host in this group.</li> <li>■ [2] <b>Sticky Next</b> = The device initially attempts to send traffic to the group of hosts that has the highest priority (e.g., Group 0). If none of the hosts in the group respond, the device attempts to send traffic to a host in a group that has the next highest priority (e.g., Group 1). Even if the group of hosts that has the highest priority (e.g., Group 0) becomes available again, the device continues sending traffic to this lower priority group (e.g., Group 1) .</li> </ul>
'Automatic Reconnect' <code>http-persistent-connection</code> <code>[PersistentConnection]</code>	<p>Defines whether the HTTP connection with the host remains open or is only opened per request.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = The HTTP connection is created per client (user) request and remains connected until the server closes the connection.</li> <li>■ [1] <b>Enable</b> = (Default) The device creates the HTTP connection once you have configured the service. If the server closes the connection, the device re-opens it. If the keep-alive timeout is configured, the device uses HTTP keep-alive messages to keep the connection open all the time.</li> </ul>
Login Needed <code>http-login-needed</code> <code>[LoginNeeded]</code>	<p>Enables the use of the AudioCodes proprietary REST API Login and Logout commands for connecting to the remote host. The commands verify specific information (e.g., software version) before allowing connectivity with the device.</p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = Commands are not used.</li> <li>■ [1] <b>Enable</b> (default)</li> </ul> <p><b>Note:</b> The parameter is applicable only if you configure the 'Type' parameter to any value other than <b>General</b>.</p>
Authentication	
'Username' rest-user-name [AuthUserName]	Defines the username for HTTP authentication. The valid value is a string of up to 80 characters. The default is "user".
'Password' rest-password [AuthPassword]	Defines the password for HTTP authentication. The valid value is a string of up to 80 characters. The default is "password". <p><b>Note:</b> The password cannot be configured with wide characters.</p>
Security	
'TLS Context' rest-tls-context [TLSContext]	Assigns a TLS Context (TLS configuration) for connection with the remote host. By default, no value is defined. To configure TLS Contexts, see <a href="#">TLS Certificates</a> on page 224. <p><b>Note:</b> The parameter is applicable only if the connection is HTTPS.</p>
'Verify Certificate' rest-verify-certificates [VerifyCertificate]	Enables certificate verification when connection with the host is based on HTTPS. <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) No certificate verification is done.</li> <li>■ [1] <b>Enable</b> = The device verifies the authentication of the certificate received from the HTTPS peer. The device authenticates the certificate against the trusted root certificate store associated with the associated TLS Context (see 'TLS Context' parameter above) and if ok, allows communication with the HTTPS peer. If authentication fails, the device denies communication (i.e., handshake fails). The device can also authenticate the</li> </ul>

Parameter	Description
	<p>certificate by querying with an Online Certificate Status Protocol (OCSP) server whether the certificate has been revoked. This is also configured for the associated TLS Context.</p> <p><b>Note:</b> The parameter is applicable only if the connection is HTTPS.</p>
'Verify Certificate Subject Name' verify-cert-subject-name [VerifyCertificateSubjectName]	<p>Enables the verification of the TLS certificate subject name (Common Name / CN or Subject Alternative Name / SAN) when connection with the host is based on HTTPS.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Off</b> = (Default) No verification is done.</li> <li>■ [1] <b>On</b> = The device verifies the subject name of the certificate received from the HTTPS peer. If the server's URL contains a hostname, it verifies the certificate against the hostname; otherwise, it verifies the certificate against the server's IP address. If authentication fails, the device denies communication (i.e., handshake fails).</li> </ul> <p><b>Note:</b> The parameter is applicable only if the connection is HTTPS.</p>
Timeouts	
'Response Timeout' rest-timeout [TimeOut]	<p>Defines the TCP response timeout (in seconds) from the remote host. If one of the remote hosts doesn't respond to a request (e.g., HTTP GET method) within the specified timeout, the device closes the corresponding socket and attempts to connect to the next remote host.</p> <p>The valid value is 1 to 65535. The default is 5.</p> <p><b>Note:</b> The global parameter for response timeout is described in <a href="#">Configuring a Routing Response Timeout</a> on page 1104.</p>
'Keep-Alive Timeout' rest-ka-timeout [KeepAliveTimeOut]	<p>Defines the duration/timeout (in seconds) in which HTTP-REST keep-alive messages are sent by the device if no other messages are sent. Keep-alive messages may be required for HTTP services that expire upon inactive sessions. For Remote Web Service whose 'Type' is <b>Routing</b>, <b>Call Status</b>, <b>Topology Status</b>, or</p>

Parameter	Description
	<p><b>QoS</b>, proprietary keep-alive messages are sent. For 'Type' that is <b>General</b>, HTTP OPTIONS keep-alive messages are sent.</p> <p>The valid value is 0 to 65535. The default is 0 (i.e., no keep-alive messages are sent).</p>
Status	
'Status'	<p>(Read-only) Displays the status of the host associated with the Web service.</p> <ul style="list-style-type: none"> <li>■ "Connected": At least one of the hosts is connected.</li> <li>■ "Disconnected": All hosts are disconnected.</li> </ul>
'Active Group'	<p>(Read-only) Displays the currently active Group (by ID) that is associated with the Web service. This is the host group to where the device is currently sending traffic.</p>
'Active Host'	<p>(Read-only) Displays the currently active host (by name) that is associated with the Web service. This is the host (within the active group) to where the device is currently sending traffic.</p> <p><b>Note:</b> If traffic is sent to the hosts in a round-robin fashion (i.e., 'Policy in Group' parameter is configured to <b>Round Robin</b>), then this field displays "NA".</p>

## Configuring Remote HTTP Hosts

The HTTP Remote Hosts table lets you configure up to 10 remote HTTP hosts per Remote Web Service. The HTTP Remote Hosts table is a "child" of the Remote Web Services table (configured in [Configuring Remote Web Services](#) on page 429).

The following procedure describes how to configure HTTP Remote hosts through the Web interface. You can also configure it through ini file [HTTPRemoteHosts] or CLI (`configure system > http-services > http-remote-hosts`).

### ➤ To configure a remote HTTP host:

1. Open the Remote Web Services table (**Setup** menu > **IP Network** tab > **Web Services** folder > **Remote Web Services**).
2. In the table, select the required remote Web service index row, and then click the **HTTP Remote Hosts** link located below the table; the HTTP Remote Hosts table appears.

3. Click **New**; the following dialog box appears:

The screenshot shows a configuration window titled "HTTP Remote Hosts". It contains four sections: **GENERAL** with fields for Index (0), Name, Address (0.0.0.0), Port (80), Interface (dropdown), and Transport Type (HTTP); **GROUPING** with Group ID (0) and Priority in Group (0); and **STATUS** with a Status field.

4. Configure an HTTP remote host according to the parameters described in the table below.
5. Click **Apply**, and then save your settings to flash memory.

**Table 16-19: HTTP Remote Hosts Table Parameter Descriptions**

Parameter	Description
<b>General</b>	
'Index' <code>rest-servers</code> [HTTPRemoteHosts_ RemoteHostindex]	<p>Defines an index number for the new table row.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>Each row must be configured with a unique index.</li> <li>The parameter is mandatory.</li> </ul>
'Name' [HTTPRemoteHosts_ Name]	<p>Defines a descriptive name, which is used when associating the row in other tables.</p> <p>The valid value is a string of up to 40 characters. By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>Configure each row with a unique name.</li> <li>The parameter is mandatory.</li> </ul>
<b>Transport</b>	
'Address' <code>rest-address</code> [HTTPRemoteHosts_ Address]	<p>Defines the address (IPv4 or IPv6 address, or FQDN) of the remote host.</p> <p>The valid value is a string of up to 80 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>If the address is an FQDN and the DNS resolution results in multiple IP addresses, the device attempts to establish multiple connections (sessions) for each IP address. Only the first 10 resolved IP addresses are used regardless of the</li> </ul>

Parameter	Description
	<p>number of hosts.</p> <ul style="list-style-type: none"> <li>■ DNS resolution is also performed (immediately) when connection is subsequently "closed" (by timeout or by the remote host) and connections are updated accordingly. In addition, the device periodically (every 15 minutes) performs DNS name resolution to ensure that the list of resolved IP addresses has not changed. If a change is detected, the device updates its' list of IP addresses and re-establishes connections accordingly.</li> <li>■ In addition to multiple HTTP sessions, the device establishes multiple (TCP) connections per session, thereby enhancing data exchange capabilities with the host.</li> </ul>
'Port' rest-port [HTTPRemoteHosts_ Port]	<p>Defines the port of the host.</p> <p>The valid value is 0 to 65535. The default is 80.</p>
'Interface' rest-interface [HTTPRemoteHosts_ Interface]	<p>Assigns one of the device's IP network interfaces (configured in <a href="#">Configuring IP Network Interfaces</a> on page 157) through which communication with the remote host is done.</p> <p>By default, no value is defined and the IPv4 OAMP interface is used.</p> <p><b>Note:</b> The address version (IPv4 or IPv6) of the IP Interface and the HTTP remote host (see 'Address' field above) must be the same.</p>
'Transport Type' rest-transport- type [HTTPRemoteHosts_ HTTPTransportType]	<p>Defines the protocol for communicating with the remote host:</p> <ul style="list-style-type: none"> <li>■ [0] <b>HTTP</b> (default)</li> <li>■ [1] <b>HTTPS</b></li> </ul>
Grouping	
'Group ID' group-id [HTTPRemoteHosts_ GroupID]	<p>Defines the host's group ID. The group number (ID) reflects the priority of the group. The device sends traffic to host groups according to the configuration of the 'Policy between Groups' parameter in the Remote Web Services table.</p> <p>The valid value is 0 to 4, where 0 is the highest priority and 4 the lowest. The default is 0.</p>



Parameter	Description
'Priority in Group' host-priority-in-group [HTTPRemoteHosts_ PriorityInGroup]	<p>Defines the priority level of the host within the assigned group. The device sends traffic to hosts within the group according to the configuration of the 'Policy in Group' parameter in the Remote Web Services table.</p> <p>The valid value is 0 to 9, where 0 is the highest priority and 9 the lowest. The default is 0.</p> <p><b>Note:</b> If you have configured multiple hosts in the group with the same priority, their priority is determined by their order of appearance in the table. For example, if two hosts are configured in rows Index 0 and Index 1 with priority 0, the host in Index 0 is considered higher priority.</p>
Status	
'Status'	<p>(Read-only) Displays the status of the connection with the remote host.</p> <ul style="list-style-type: none"> <li>■ "Connected": The host is connected.</li> <li>■ "Disconnected": The host is disconnected.</li> </ul>

## Enabling Topology Status Services

You can enable the device to send device configuration (topology) status (add, edit and delete) for Web-based services (Remote Web Services). Once enabled, you need to add a Remote Web Service with the 'Type' parameter configured to **Topology Status** (see [Configuring Remote Web Services](#) on page 429).

### ➤ To enable Topology Status services:

1. Open the Web Service Settings page (**Setup** menu > **IP Network** tab > **Web Services** folder > **Web Service Settings**).
2. Select the 'Topology Status' check box [RoutingServerGroupStatus]:

Topology Status



3. Click **Apply**.

## Enabling Registration Status Services

You can enable the device to periodically synchronize its registration database of SIP user agents (endpoints) with ARM (Remote Web Service). ARM can then use this information for routing decisions. Once enabled, you need to add a Remote Web Service with the 'Type'

parameter configured to **Registration Status** (see [Configuring Remote Web Services](#) on page 429).

For more information on routing by ARM, see [Centralized Routing by ARM \(AudioCodes Routing Manager\)](#) below.

➤ **To enable Registration Status services:**

1. Open the Web Service Settings page (**Setup** menu > **IP Network** tab > **Web Services** folder > **Web Service Settings**).
2. Select the 'Routing Server Registration Status' check box [RoutingServerRegistrationStatus]:

Routing Server Registration Status • ☒

3. Click **Apply**.

## Centralized Routing by ARM (AudioCodes Routing Manager)

You can employ ARM (AudioCodes Routing Manager) -- *Remote Web Service* configuration entity -- to handle call routing decisions in deployments consisting of multiple AudioCodes devices. ARM can be used to handle SBC, Tel-to-IP, and IP-to-Tel calls. ARM replaces the need for the device's routing tables--IP-to-IP Routing table for SBC calls, and Tel-to-IP Routing table and IP-to-Tel Routing table for Tel-to-IP and IP-to-Tel calls respectively--to determine call destination.



For more information on ARM, refer to the documents *ARM User's Manual* and *ARM Installation Manual*, which can be downloaded from AudioCodes [website](#).

For SBC calls, when the device receives an incoming call (SIP INVITE, NOTIFY or MESSAGE), it searches the IP-to-IP Routing table for a matching routing rule. If the routing rule is configured to use ARM ('Destination Type' parameter configured to **Routing Server**), the device sends a request to ARM for an appropriate destination.

For Gateway calls, when the device receives an incoming call (SIP INVITE, NOTIFY or MESSAGE), it disregards the routing tables and instead, immediately sends a request to ARM for an appropriate destination.

The request is sent to ARM using an HTTP Get Route message. The request contains information about the call (SIP message) and for IP-to-Tel calls, the source IP Group based on the associated Proxy Set.

ARM uses its own algorithms and logic in determining the best route path. ARM manages the call route between devices in "hops", which may be spread over different geographical locations. The destination to each hop (device) can be an IP address (with a port) or IP Group or Trunk Group. If the destination is an IP address, even though the destination type (in the IP-to-IP Routing table) is an IP Group, the device only uses the IP Group for profiling (i.e., associated


IP Profile etc.). If multiple devices exist in the call routing path, ARM sends the IP address only to the last device ("node") in the path.

Once the device receives the resultant destination hop from ARM, it sends the call to that destination. ARM can provide the device with an appropriate route or reject the call. However, if for the **initial** request (first sent Get Route request for the call), ARM cannot find an appropriate route for the call or it doesn't respond, for example, due to connectivity loss (i.e., ARM sends an HTTP 404 "Not Found" message), the device routes the call using its routing tables. If the Get Route request is not the first one sent for the call (e.g., in call forwarding or alternative routing) and ARM responds with an HTTP 404 "Not Found" message, the device rejects the call.

This HTTP request-response transaction for the routing path occurs between ARM and each device in the route path (hops) as the call traverses the devices to its final destination. Each device in the call path connects to ARM, which responds with the next hop in the route path. Each device considers the call as an incoming call from an IP Group or Trunk Group. The session ID (SID) is generated by the first device in the path and then passed unchanged down the route path, enabling ARM to uniquely identify requests belonging to the same call session.

Communication between the device and ARM is through the device's embedded Representational State Transfer (RESTful) API. The RESTful API is used to manage the routing-related information exchanged between ARM (RESTful server) and the device (RESTful client). When you have configured the device with connection settings of the routing sever or ARM and the device starts-up, it connects to ARM and activates the RESTful API, which triggers the routing-related API commands.

The following figure provides an example of information exchange between devices and ARM for routing calls:



ARM can also manipulate call data such as calling name, if required. It can also create new IP Groups and associated configuration entities (e.g., IP Profiles), if necessary for routing. Multiple ARM instances can also be employed, whereby each device in the chain path can use a specific

ARM instance. Alternatively, a single ARM can be employed and used for all devices ("stateful" ARM server).

The device automatically updates (sends) ARM with its' configuration topology regarding SIP routing-related entities (Trunk Groups, SRDs, SIP Interfaces, IP Profiles, and IP Groups) that have been configured for use by ARM. For example, if you add a new IP Group and enable it for use by ARM, the device sends this information to ARM. Routing of calls associated with routing-related entities that are disabled for use by ARM (default) are handled only by the device.

In addition to regular routing, ARM also supports the following:

- **Alternative Routing:** If a call fails to be established, the device "closest" to the failure and configured to send "additional" routing requests (through REST API - "additionalRoute" attribute in HTTP Get Route request) to ARM, sends a new routing request to ARM. ARM may respond with a new route destination, thereby implementing alternative routing. Alternatively, it may enable the device to return a failure response to the previous device in the route path chain and respond with an alternative route to this device. Therefore, alternative routing can be implemented at any point in the route path. If ARM sends an HTTP 404 "Not Found" message for an alternative route request, the device rejects the call. If ARM is configured to handle alternative routing, the device doesn't make any alternative routing decisions based on its alternative routing tables.

If the device sends an HTTP Get Route request and ARM responds with a REST API attribute "action" that is set to the value 'continue', the device routes the call using its IP-to-IP Routing table. It uses the routing rule located after the original routing rule used to query ARM ('Destination Type' set to **Routing Server**) whose 'Alternative Route Options' parameter is configured to **Route Row**. This routing can be used at any stage of the call (e.g., after alternative routing failure by ARM, or after receiving a REFER/3xx).

- **Call Forking:** The device can fork calls according to ARM. When the device finds a matching routing rule in the IP-to-IP Routing table that is configured with the **Routing Server** destination, it sends an HTTP Get Route request to ARM. When it receives a successful response from the server or ARM, the device sends an INVITE message to a destination based on the response. If the routingMethod in the response from ARM is "fork", the device sends another HTTP Get Route request to the server or ARM and upon a successful response, sends another INVITE to another destination based on the response, and so on. This call forking process continues until no routingMethod is received from the server or ARM, or it is set to "seq", or there is a failed response from the server or ARM. If all the contacts fail (4xx), the device falls back to an alternative route, if exists, from ARM. If 3xx is received for any of the forked destinations, the device handles it after all the forked INVITEs have been terminated.

ARM can also provide the device with a "no-answer timeout" in the response. If the called IP party doesn't answer the call within this interval, the device disconnects the session or forks the call (*delayed call forking*). If provided, this value overrides the [SBCAlertTimeout] parameter for SBC calls and [PSTNAlertTimeout] parameter for Gateway calls.

- **Call Status:** The device can report call status to ARM to indicate whether a call has successfully been established or failed (disconnected). The device can also report when an

IP Group (Proxy Set) is unavailable, detected by the keep-alive mechanism, or when the CAC thresholds permitted per IP Group have been crossed. For Trunk Groups, the device reports when the trunk's physical state indicates that the trunk is unavailable.

- **Credentials for Authentication:** ARM can provide user (e.g., IP Phone caller) credentials (username-password) in the Get Route response, which can be used by the device to authenticate outbound SIP requests if challenged by the outbound peer, for example, Microsoft Skype for Business (per RFC 2617 and RFC 3261). If multiple devices exist in the call routing path, ARM sends the credentials only to the last device ("node") in the path.

Alternatively, the device can authenticate incoming SIP requests (INVITE or REGISTER) from User-type IP Groups, by first obtaining (REST-based API query) the user's password from ARM where it is stored. When this feature is enabled and the device receives an incoming SIP dialog-initiating request, it sends the REST API command `getCredentials` in the Get request to ARM. The name of the user whose credentials are requested is obtained from the SIP From header when authenticating an INVITE message, and from the To header when authenticating a REGISTER message. ARM sends a 200 response to the device containing the password (if the requested user exists). The device then sends the challenge back to the user. The user resends the request with a SIP Authorization header (containing a response to the challenge), and the authentication process continues in the usual manner. If the device doesn't receive a password, it rejects the incoming dialog (SIP 404). To enable this authentication type, you need to configure the IP Group's 'SBC Server Authentication Type' parameter to **ARM Authentication** (see [Configuring IP Groups](#) on page 581). Note that ARM doesn't authenticate users, but only helps the device to process the SIP Digest authentication by providing the user credentials.

- **QoS:** The device can report QoS metrics per IP Group to ARM which it can use to determine the best route (i.e., QoS-based routing). For more information, see [Configuring QoS-based Routing by ARM](#) on the next page.
- **Call Preemption for Emergency Calls:** If you enable call preemption for emergency calls (e.g., 911) on the device, ARM determines whether or not the incoming call is an emergency call and if so, handles the routing decision accordingly (i.e., preempts a non-emergency call if the maximum call capacity of the device is reached in order to allow the emergency call to be routed). To enable call preemption for emergency calls, use the [SBCPreemptionMode] parameter for SBC calls and the [CallPriorityMode] parameter for Gateway calls.
- **Registration status:** The device can periodically synchronize its registration database of SIP user agents (endpoints) with ARM to keep it up to date, enabling ARM to use this information to perform correct and optimal routing decisions. To enable this functionality, see [Enabling Registration Status Services](#) on page 441.

➤ **To configure routing based on ARM:**

1. For each configuration entity (e.g., IP Group or IP Profile) that you want routing done by ARM, configure the entity's 'Used By Routing Server' parameter to **Used**:

Used By Routing Server Used

2. Configure an additional Security Administrator user account in the Local Users table (see [Configuring Local Management User Accounts](#) on page 54) that is used by ARM (REST client) to log in to the device's management interface.
3. Configure the address and connection settings of ARM, referred to as a *Remote Web Service* and an HTTP remote host (see [Configuring Remote Web Services](#) on page 429). You must configure the 'Type' parameter of the Remote Web Service to **Routing**, as shown in the example:

Remote Web Services

GENERAL	
Index	<input style="width: 90%;" type="text" value="0"/>
Name	<input style="width: 90%;" type="text" value="Routing Server"/>
Type	<span style="border: 1px solid #ccc; padding: 2px 10px;">Routing</span>

4. (SBC Application Only) In the IP-to-IP Routing table, configure the 'Destination Type' parameter of the routing rule to **Routing Server** (see [Configuring SBC IP-to-IP Routing Rules](#) on page 1076):

ACTION	
Destination Type	<span style="border: 1px solid #ccc; padding: 2px 10px;">Routing Server</span>

5. (Gateway Application Only) Open the Routing Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Routing** > **Routing Settings**), and then enable routing by ARM, by selecting the 'Gateway Routing Server' check box (GWRoutingServer):

Gateway Routing Server ☒

## Configuring QoS-based Routing by ARM

You can configure the device to allow ARM to route calls based on QoS metrics (media and signaling). The device collects QoS metrics per IP Group that you have configured to operate with ARM ('Used by Routing Server' parameter configured to **Used** in the IP Groups table). The metrics include the following:

- **Signaling:** ASR, NER, and ACD
- **Media:** Packet loss (Rx/Tx), packet delay (local/remote), jitter (local/remote), MOS (local/remote), audio bandwidth (Rx/Tx), video bandwidth (Rx/Tx), and total bandwidth (Rx/Tx)

The device collects QoS metrics for both incoming call traffic and outgoing traffic from the remote endpoint. It sends the QoS reports to ARM, where each report can contain the status of up to 100 IP Groups. If more than 100 IP Groups exist, the device sends multiple QoS reports (sequentially) to ARM. The device sends the reports every user-defined period. The routing logic of where to route calls based on QoS ("good", "fair", and "bad") is configured on ARM.



For media metrics calculations, the device's License Key must include voice quality monitoring and RTCP XR.

➤ **To configure QoS-based routing by ARM:**

1. Open the Web Service Settings page (**Setup** menu > **IP Network** tab > **Web Services** folder > **Web Service Settings**), and then do the following:
    - a. Select the 'Quality Status' check box [RoutingServerQualityStatus] to enable QoS-based routing.
    - b. In the 'Quality Status Rate' field (RoutingServerQualityStatusRate), enter the rate (in sec) at which the device sends QoS reports.
- Quality Status ☒

Quality Status Rate
- c. Click **Apply**.
  2. Open the Remote Web Services table (see [Configuring Remote Web Services](#) on page 429), and then for the Remote Web Service entry that you configured for ARM, do the following:
    - a. From the 'Type' drop-down list, select **QoS**.
    - b. Click **Apply**.
  3. Enable voice quality monitoring and RTCP XR, using the 'Enable RTCP XR' [VQMonEnable] parameter (see [Configuring RTCP XR](#) on page 1374).

## Configuring an HTTP GET Web Service

You can query (HTTP GET) an HTTP server and use the response for various functionality such as routing or saving it, for example, as a session variable in order to use it in SIP message manipulations.

You need to configure a Remote Web Service to represent the HTTP server and a Call Setup Rule to define the search query and the action you want done based on the HTTP response. The following example queries an HTTP server (at IP address 52.7.189.10) using the caller's (source) user name in the server's path */v3/phone*. When a response is received from the HTTP server, the device adds the value of the HTTP response body ("Alice") to the From header in the outgoing SIP message.

➤ **To configure an HTTP GET operation:**

1. Open the Remote Web Services table, and then configure a Remote Web Service for the HTTP server:
  - 'Name': **MyHTTP**
  - 'Type': **General**
  - 'Path': **v3/phone**
  - 'Username': **adminuser1**
  - 'Password': **1234**
2. Open the HTTP Remote Hosts table of the Remote Web Service that you configured in Step 1, and then configure the following:
  - 'Name': **MyHTTPHost**
  - 'Address': **52.7.189.10**
3. Open the Call Setup Rules table, and then configure the following rule:
  - 'Rule Set ID': **1**
  - 'Request Type': **HTTP GET**
  - 'Request Target': **MyHTTP**
  - 'Request Key': **Param.Call.Src.User+'?account\_sid=SID&auth\_token=TOKEN'**
  - 'Action Subject': **Param.Call.Src.Name**
  - 'Action Type': **Modify**
  - 'Action Value': **HTTP.Response.Body**
4. Assign your Call Setup Rule to the relevant SIP Interface, for example.

An example of the HTTP and SIP messages of the above configuration is shown below:

1. Incoming SIP message:

```
INVITE sip:2000@10.7.7.246;user=phone SIP/2.0
Via: SIP/2.0/UDP 10.7.2.15;branch=z9hG4bKLRGQTOQHILSSMGAQJQSU
From: <sip:
15551234567
@10.7.2.15;user=phone>;tag=RJFNXMKDOHELDUMEWWGH
To: <sip:2000@10.7.7.246;user=phone>
Call-ID: UBBKFKBCXFPESMYOPDTB@10.7.2.15
CSeq: 1 INVITE
Contact: <sip:1000@10.7.2.15>
Supported: em,100rel,timer,replaces
Allow:
```



```
REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,I
NFO,SUBSCRIBE
User-Agent: Sip Message Generator V1.0.0.5
```

2. Outgoing HTTP GET:

```
Header=GET /v3/phone/15551234567?account_sid=SID&auth_
token=TOKEN HTTP/1.1
Content-Type: html/text
Host: 52.7.189.114
Connection: keep-alive
Content-Length: 0
Cache-Control: no-cache
User-Agent: 1
```

3. Incoming HTTP response:

```
HTTP/1.1 200 OK
Access-Control-Allow-Origin: *
Cache-Control: max-age=0
Content-Type: text/html
Date: Thu, 07 Dec 2017 14:35:21 GMT
Server: nginx/1.8.1
Content-Length: 6
Connection: keep-alive
```

**Alice**

4. Outgoing SIP message:

```
INVITE sip:2000@10.7.7.246;user=phone SIP/2.0
Via: SIP/2.0/UDP 10.7.7.246:5060;branch=z9hG4bKac1693897511
Max-Forwards: 70
From: Alice
<sip:+15551234567@10.7.2.15;user=phone>;tag=1c1900944531
To: <sip:2000@10.7.7.246;user=phone>
Call-ID: 17651812441120101654@10.7.7.246
CSeq: 1 INVITE
Contact: <sip:1000@10.7.7.246:5060>
Supported: em,100rel,timer,replaces,sdp-anat
```

## Configuring HTTP POST Web Service

You can use HTTP POST messages to simply notify an HTTP server about a call, and use HTTP POST messages for querying information like HTTP GET messages. The example provided in this section describes how to configure the device to send HTTP POSTs to notify an HTTP server of incoming 911 calls. You need to configure a Remote Web Service to represent the HTTP server (IP address 52.7.189.10). You also need to configure Call Setup Rules that instruct the device to send an HTTP POST message, containing the 911 caller's user name and host name, to the server (at path */path/query/notify-emergency-call*) if a 911 call is received.

### ➤ To configure an HTTP POST notification operation:

1. Open the Remote Web Services table, and then configure a Remote Web Service for the HTTP server:
  - 'Name': **MyHTTP**
  - 'Type': **General**
  - 'Username': **adminuser1**
  - 'Password': **1234**
2. Open the HTTP Remote Hosts table of the Remote Web Service that you configured in Step 1, and then configure the following:
  - 'Name': **MyHTTPHost**
  - 'Address': **52.7.189.10**
3. Open the Call Setup Rules table, and then configure the following rules (Rule Set ID 1):
  - If the destination number of the incoming call is not 911, then don't process these Call Setup Rules:
    - ◆ 'Index': **1**
    - ◆ 'Rule Set ID': **1**
    - ◆ 'Condition': **Param.Call.Dst.User != '911'**
    - ◆ 'Action Type': **Exit**
    - ◆ 'Action Value': **True**
  - Set the Content-Type header in the HTTP POST message to the value "application/json":
    - ◆ 'Index': **2**
    - ◆ 'Rule Set ID': **1**
    - ◆ 'Action Subject': **HTTP.Request.Content-Type**
    - ◆ 'Action Type': **Modify**
    - ◆ 'Action Value': **'application/json'**

- Add JSON parameters to the body of the HTTP POST message so that it includes the 911 caller's (source) number and host name:
  - ◆ 'Index': **3**
  - ◆ 'Rule Set ID': **1**
  - ◆ 'Action Subject': **HTTP.Request.Body**
  - ◆ 'Action Type': **Add**
  - ◆ 'Action Value': **{ "user": ""+Param.Call.Src.User+"", "host": ""+Param.Call.Src.Host+""}'**
- Send the HTTP POST message to the specified server and folder path:
  - ◆ 'Index': **4**
  - ◆ 'Rule Set ID': **1**
  - ◆ 'Request Type': **HTTP POST Notification**
  - ◆ 'Request Target': **MyHTTP**
  - ◆ 'Request Key': **'/path/query/notify-emergency-call'**

**4.** Assign your Call Setup Rules (i.e., Rule Set ID 1) to the relevant SIP Interface (for example).

An example of the HTTP and SIP messages of the above configuration is shown below:

**1.** Incoming SIP message from 911 caller:

```
INVITE sip:911@10.7.7.246;user=phone SIP/2.0
Via: SIP/2.0/UDP 10.7.2.15;branch=z9hG4bKLRGQTOQHILSSMGAQJQSU
From: <sip:15551234567@10.7.2.15;user=phone>;tag=RJFNXMKDOHELDUMEWG
To: <sip:911@10.7.7.246;user=phone>
Call-ID: UBBKFKBCXFPESMYOPDTB@10.7.2.15
CSeq: 1 INVITE
Contact: <sip:1000@10.7.2.15>
Supported: em,100rel,timer,replaces
Allow:
REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE
User-Agent: Sip Message Generator V1.0.0.5
```

**2.** Outgoing HTTP POST message notifying server of 911 call:

```
Header=POST /path/query/notify-emergency-call HTTP/1.1
Content-Type: application/json
Host: 52.7.189.114
Connection: keep-alive
```

```
Content-Length: 47
Cache-Control: no-cache
User-Agent: 1
```

```
{ "user": "15551234567", "host": "10.7.2.15" }
```

## Least Cost Routing

This section describes the device's Least Cost Routing (LCR) feature.

### Overview of LCR

The LCR feature enables the device to choose the outbound IP destination routing rule based on lowest call cost. This is useful in that it enables service providers to optimize routing costs for customers. For example, you may wish to define different call costs for local and international calls or different call costs for weekends and weekdays (specifying even the time of call). The device sends the calculated cost of the call to a syslog server (as Information messages), thereby enabling billing by third-party vendors.

LCR is implemented by defining Cost Groups and assigning them to routing rules in the Tel-to-IP Routing table (for Gateway calls) or IP-to-IP Routing table (for SBC calls). The device searches the routing table for matching routing rules and then selects the rule with the lowest call cost. If two routing rules have identical costs, the rule appearing higher up in the table is used (i.e., first-matched rule). If the selected route is unavailable, the device selects the next least-cost routing rule.

Even if a matched routing rule is not assigned a Cost Group, the device can select it as the preferred route over other matched rules that are assigned Cost Groups. This is determined according to the settings of the 'Default Call Cost' parameter configured for the Routing Policy (associated with the routing rule for SBC calls). To configure the Routing Policy, see [Configuring a Gateway Routing Policy Rule](#) on page 934 for Gateway calls and [Configuring SBC Routing Policies](#) on page 1108 for SBC calls.

The Cost Group defines a fixed connection cost (*connection cost*) and a charge per minute (*minute cost*). Cost Groups can also be configured with time segments (*time bands*), which define connection cost and minute cost based on specific days of the week and time of day (e.g., from Saturday through Sunday between 6:00 and 18:00, and Monday through Sunday between 18:00 and 5:00). If multiple time bands are configured per Cost Group and a call spans multiple time bands, the call cost is calculated according to minute cost per time band and the connection cost of the time band in which the call was initially established.

In addition to Cost Groups, the device can calculate the call cost using an optional, user-defined average call duration value. The logic in using this option is that a Cost Group may be cheap if the call duration is short, but due to its high minute cost, may prove very expensive if the duration is lengthy. Thus, together with Cost Groups, the device can use this option to determine least cost routing. The device calculates the Cost Group call cost as follows:

*Total Call Cost = Connection Cost + (Minute Cost \* Average Call Duration)*

The below table shows an example of call cost when taking into consideration call duration. This example shows four defined Cost Groups and the total call cost if the average call duration is 10 minutes:

**Table 16-20: Call Cost Comparison between Cost Groups for different Call Durations**

Cost Group	Connection Cost	Minute Cost	Total Call Cost per Duration	
			1 Minute	10 Minutes
A	1	6	7	61
B	0	10	10	100
C	0.3	8	8.3	80.3
D	6	1	7	16

If four matching routing rules are located in the routing table and each one is assigned a different Cost Group as listed in the table above, then the rule assigned Cost Group "D" is selected. Note that for one minute, Cost Groups "A" and "D" are identical, but due to the average call duration, Cost Group "D" is cheaper. Therefore, average call duration is an important factor in determining the cheapest routing role.

Below are a few examples of how you can implement LCR:

- **Example 1:** This example uses two different Cost Groups for routing local calls and international calls:

Two Cost Groups are configured as shown below:

Cost Group	Connection Cost	Minute Cost
1. "Local Calls"	2	1
2. "International Calls"	6	3

The Cost Groups are assigned to routing rules for local and international calls:

Routing Index	Dest Phone Prefix	Destination IP	Cost Group ID
1	2000	x.x.x.x	1 "Local Calls"
2	00	x.x.x.x	2 "International Calls"

- **Example 2:** This example shows how the device determines the cheapest routing rule in the Tel-to-IP Routing table:

The 'Default Call Cost' parameter in the Routing Policy rule is configured to **Lowest Cost**, meaning that if the device locates other matching routing rules (with Cost Groups assigned), the routing rule without a Cost Group is considered the lowest cost route.

- The following Cost Groups are configured:

Cost Group	Connection Cost	Minute Cost
1. "A"	2	1
2. "B"	6	3

- The Cost Groups are assigned to routing rules:

Routing Index	Dest Phone Prefix	Destination IP	Cost Group
1	201	x.x.x.x	"A"
2	201	x.x.x.x	"B"
3	201	x.x.x.x	0
4	201	x.x.x.x	"B"

The device calculates the optimal route in the following index order: 3, 1, 2, and then 4, due to the following logic:


- Index 1 - Cost Group "A" has the lowest connection cost and minute cost
- Index 2 - Cost Group "B" takes precedence over Index 4 entry based on the first-matched method rule
- Index 3 - no Cost Group is assigned, but as the 'Default Call Cost' parameter is configured to **Lowest Cost**, it is selected as the cheapest route
- Index 4 - Cost Group "B" is only second-matched rule (Index 1 is the first)

■ **Example 3:** This example shows how the cost of a call is calculated if the call spans over multiple time bands:

Assume Cost Group "CG Local" is configured with two time bands, as shown below:

Cost Group	Time Band	Start Time	End Time	Connection Cost	Minute Cost
CG Local	TB1	16:00	17:00	2	1
	TB2	17:00	18:00	7	2

Assume that the call duration is 10 minutes, occurring between 16:55 and 17:05. In other words, the first 5 minutes occurs in time band "TB1" and the next 5 minutes occurs in "TB2", as illustrated below:



The device calculates the call cost as follows:

- For the first 5 minutes of the call (16:55 to 17:00), the call is in time band "TB1" and the call cost for this period is calculated as follows:

$$\text{Connection Cost of "TB1"} + [\text{Minute Cost of "TB1"} \times \text{call duration}] = 2 + [1 \times 5 \text{ min}] = 7$$

- For the next 5 minutes of the call (17:00 to 17:05), the call is in time band "TB2" and the call cost for this period is calculated as follows:

$$\text{Minute Cost of "TB2"} \times \text{call duration} = 2 \times 5 \text{ min} = 10$$

- Therefore, the total call cost is the summation of above:

$$\text{"TB1" call cost} + \text{"TB2" call cost} = 7 + 10 = 17$$

## Configuring LCR

To configure LCR, perform the following main steps:

1. Enable LCR:
  - Gateway application: see [Configuring a Gateway Routing Policy Rule](#) on page 934
  - SBC application: [Configuring SBC Routing Policies](#) on page 1108
2. Configure Cost Groups - see [Configuring Cost Groups](#) below.
3. Configure Time Bands for a Cost Group - see [Configuring Time Bands for Cost Groups](#) on page 457.
4. Assign Cost Groups to outbound IP routing rules - see [Assigning Cost Groups to Routing Rules](#) on page 459.

## Configuring Cost Groups

The Cost Groups table lets you configure up to 10 Cost Groups. A Cost Group defines a fixed call connection cost and a call rate (charge per minute). Once configured, you can configure Time Bands per Cost Group (see [Configuring Time Bands for Cost Groups](#) on page 457).

The following procedure describes how to configure Cost Groups through the Web interface. You can also configure it through ini file [CostGroupTable] or CLI (`configure voip > sip-definition least-cost-routing cost-group`).

➤ **To configure a Cost Group:**

1. Open the Cost Groups table (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **Least Cost Routing** > **Cost Groups**).
2. Click **New**; the following dialog box appears:

3. Configure a Cost Group according to the parameters described in the table below.
4. Click **Apply**, and then save your settings to flash memory.

**Table 16-21:Cost Groups Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' cost-group-name [CostGroupName]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 40 characters. <b>Note:</b> <ul style="list-style-type: none"> <li>■ Each row must have a unique name.</li> <li>■ The parameter value can't contain a forward slash (/).</li> <li>■ The parameter value can't be configured with the character string "any" (upper or lower case).</li> </ul>
'Default Connection Cost' default-connection-cost [DefaultConnectionCost]	Defines the call connection cost (added as a fixed charge to the call) for a call outside the time bands. The valid value range is 0-65533. The default is 0. <b>Note:</b> When calculating the cost of a call, if the current time of the call is not within a time band configured for the Cost Group, then this default connection cost is used.



Parameter	Description
'Default Minute Cost' default-minute-cost [DefaultMinuteCost]	<p>Defines the call charge per minute for a call outside the time bands.</p> <p>The valid value range is 0-65533. The default is 0.</p> <p><b>Note:</b> When calculating the cost of a call, if the current time of the call is not within a time band configured for the Cost Group, then this default charge per minute is used.</p>

### Configuring Time Bands for Cost Groups

The Time Band table lets you configure Time Bands per Cost Group. A Time Band defines a day and time range (e.g., from Saturday 05:00 to Sunday 24:00) and a fixed call connection charge and call rate per minute for this interval. You can configure up to 70 Time Bands, where up to 21 Time Bands can be assigned to each Cost Group.



- You cannot configure overlapping Time Bands.
- If a Time Band is not configured for a specific day and time range, the default connection cost and default minute cost configured for the Cost Group in the Cost Groups table is applied.
- To configure Cost Groups, see [Configuring Cost Groups](#) on page 455.

The following procedure describes how to configure Time Bands per Cost Group through the Web interface. You can also configure it through ini file [CostGroupTimebands] or CLI (configure voip > sip-definition least-cost-routing cost-group-time-bands).

#### ➤ To configure a Time Band per Cost Group:

1. Open the Cost Groups table (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **Least Cost Routing** > **Cost Groups**).
2. Select a Cost Group for which you want to assign Time Bands, and then click the **Time Band** link located below the table; the Time Band table for the selected Cost Group appears.
3. Click **New**; the following dialog box appears:

Time Band
— ✕

GENERAL

Index	<input style="width: 90%;" type="text" value="0"/>
Start Time (ddd:hh:mm)	<input style="width: 90%;" type="text"/>
End Time (ddd:hh:mm)	<input style="width: 90%;" type="text"/>
Connection Cost	<input style="width: 90%;" type="text" value="0"/>
Minute Cost	<input style="width: 90%;" type="text" value="0"/>

4. Configure a Time Band according to the parameters described in the table below.
5. Click **Apply**, and then save your settings to flash memory.

Table 16-22:Time Band Table Description

Parameter	Description
'Index' timeband-index [CostGroupTimebands_ TimebandIndex]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Start Time' start-time [CostGroupTimebands_ StartTime]	Defines the day and time of day from when this time band is applicable. The format is ddd:hh:mm, where: <ul style="list-style-type: none"> <li>■ <i>ddd</i> is the day of the week, represented by the first three letters (case-insensitive) of the day (i.e., mon, tue, wed, thu, fri, sat, or sun).</li> <li>■ <i>hh</i> and <i>mm</i> denote the time of day, where <i>hh</i> is the hour (00-23) and <i>mm</i> the minutes (00-59)</li> </ul> For example, sat:22:00 denotes Saturday at 10 pm.
'End Time' end-time [CostGroupTimebands_ EndTime]	Defines the day and time of day until when this time band is applicable. For a description of the valid values, see the parameter above.
'Connection Cost' connection-cost [CostGroupTimebands_ ConnectionCost]	Defines the call connection cost during the time band. This is added as a fixed charge to the call. The valid value range is 0-65533. The default is 0. <b>Note:</b> The entered value must be a whole number (i.e., not a decimal).

Parameter	Description
'Minute Cost' minute-cost [CostGroupTimebands_ MinuteCost]	Defines the call cost per minute charge during the time band. The valid value range is 0-65533. The default is 0.  <b>Note:</b> The entered value must be a whole number (i.e., not a decimal).

### Assigning Cost Groups to Routing Rules

To use your configured Cost Groups, you need to assign them to routing rules:

- Gateway application: Tel-to-IP Routing table - see [Configuring Tel-to-IP Routing Rules](#) on page 914
- SBC application: IP-to-IP Routing table - see [Configuring SBC IP-to-IP Routing Rules](#) on page 1076

## HTTP-based Proxy Services

The device can be configured as an HTTP Proxy (or a non-HTTP Proxy) to intermediate between clients (e.g., HTTP requests) and servers (hosts). The client sends an HTTP GET request specifying the destination (URL), and the device (acting as an HTTP Proxy), forwards it to the host, and vice versa.


This feature integrates the NGINX platform, which is an open source proxy server. When you enable the HTTP Proxy application, the NGINX daemon is launched. When you then configure the various HTTP Proxy tables, the configuration is reflected in the NGINX configuration file (nginx.conf). Each parameter has its own NGINX Directive notation syntax, which is shown in the nginx.conf file. For example, if you have configured an Upstream Host (discussed later in this section), it is displayed in the NGINX file as "server host:port". You can also configure and apply additional NGINX Directives that do not have any corresponding parameters in the device's Web interface. For more information, see [Configuring HTTP Directive Sets](#) on page 478.

The device supports the following proxy services:

- **HTTP Reverse Proxy for managing equipment behind NAT:** You can configure the device to function as a Reverse HTTP Proxy server. You can use this for many HTTP-based applications. For example, you can use it to intermediate between REST API clients and a REST server.

Another example is to use the HTTP Proxy to intermediate between IP Phones and remote servers for file download. The figure below illustrates this example where IP Phones (clients) retrieve their configuration and firmware files from remote file servers (Upstream Hosts) and where the device (HTTP Proxy) intermediates between the two. The HTTP hosts are located in the cloud and the clients are located behind NAT. The HTTP Proxy listens for incoming HTTP requests (Listening Interface and HTTP/S Listening Port) from the clients and then forwards the requests to the relevant HTTP host, based on the URL (HTTP Location) in the incoming HTTP GET request. If the URL matches the pattern "/firmware/",

the HTTP Proxy sends the request to the firmware file server; if the URL matches the pattern `"/ipp/*.cfg"`, the requests are sent to the configuration file server. In addition, customized NGINX directives have been configured for each HTTP Location to define the maximum time to wait for an HTTP connection.



A summary of the required configuration for this example is listed below:

- a. Enable the HTTP Proxy application (see [Enabling the HTTP Proxy Application](#) on the next page).
  - b. Configure two Upstream Groups, where each is configured with an Upstream Host that defines the IP address of the HTTP host (i.e., firmware and configuration file servers). See [Configuring Upstream Groups](#) on page 474.
  - c. Configure two NGINX directives for proxy timeout connection (see [Configuring HTTP Directive Sets](#) on page 478).
  - d. Configure a local, listening IP network interface for the leg interfacing with the HTTP clients (see [Configuring IP Network Interfaces](#) on page 157) or use the default.
  - e. Configure a local, IP network interface for the outbound leg interfacing with the HTTP hosts (or use the default).
  - f. Configure the HTTP Proxy server, by assigning it the listening IP network interface and configuring a listening HTTP/S port (see [Configuring HTTP Proxy Servers](#) on page 463).
  - g. Configure two HTTP Locations for the HTTP Proxy server, where each is configured with a URL pattern to match the incoming HTTP requests for determining the destination host (Upstream Group-Upstream Host). In addition, assign it the relevant HTTP Directive Set. See [Configuring HTTP Locations](#) on page 466.
- **Non-HTTP Proxy (referred to as TCP/UDP Proxy Server):** The device can serve as a proxy for other applications that are not based on HTTP. For example, it can be used to intermediate between clients and a DNS server for DNS lookup, or between clients and an

NTP server for clock synchronization. For more information, see [Configuring TCP-UDP Proxy Servers](#) on page 470.

- **HTTP-based OVOC service for AudioCodes equipment located behind NAT that are managed by the AudioCodes OVOC server:** For more information, see [Configuring an HTTP-based OVOC Service](#) on page 481

## Enabling the HTTP Proxy Application

Before you can configure HTTP-based proxy services, you must enable the HTTP Proxy application, as described in the following procedure. Once enabled, the Web interface displays menus in the Navigation pane that are relevant to the HTTP Proxy application.



The HTTP Proxy application is a license-based feature and is available only if it is included in the License Key installed on the device. For ordering the feature, please contact the sales representative of your purchased device. For installing a new License Key, see [License Key](#) on page 1233.

### ➤ To enable the HTTP Proxy application:

1. Open the HTTP Proxy Settings page (**Setup** menu > **IP Network** tab > **HTTP Proxy** folder > **HTTP Proxy Settings**)
2. Select the 'HTTP Proxy Application' check box:

HTTP Proxy application



3. Click **Apply**, and then restart the device with a save-to-flash for your settings to take effect.

## Debugging Remote HTTP Services

You can enable the device to generate debug messages for remote Web (HTTP) services and have them sent to a syslog server.

### ➤ To enable debugging of HTTP services:

1. Open the HTTP Proxy Settings page (**Setup** menu > **IP Network** tab > **HTTP Proxy** folder > **HTTP Proxy Settings**)
2. From the 'HTTP Proxy Debug Level' drop-down list, select a debug level:

GENERAL

HTTP Proxy Debug Level

• Basic ▼

3. Click **Apply**.

## Caching HTTP Responses

You can enable the device to cache all received HTTP responses. This reduces the need for the device to request the same information (responses) repeatedly from a remote upstream server.

### ➤ To enable caching of HTTP responses:

1. Open the HTTP Proxy Settings page (**Setup** menu > **IP Network** tab > **HTTP Proxy** folder > **HTTP Proxy Settings**).
2. Select the 'HTTP Cache Enable' check box:

HTTP Cache Enable ☒

3. Click **Apply**.

## Configuring a DNS Server for HTTP Services

You can configure the DNS server (primary and secondary for redundancy) that you want to use for your HTTP services. If you configure a proxy server with an FQDN, this is the DNS server that the device uses for resolving the domain name into an IP address.

### ➤ To configure DNS servers for HTTP services:

1. Open the HTTP Proxy Settings page (**Setup** menu > **IP Network** tab > **HTTP Proxy** folder > **HTTP Proxy Settings**):
2. In the 'Primary DNS Server IP' field, enter the IP address of your main DNS server.
3. (Optional) In the 'Secondary DNS Server IP' field, enter the IP address of the secondary DNS server.

#### DNS

Primary DNS Server IP

Secondary DNS Server IP

4. Click **Apply**.



- The DNS servers that are configured for IP Interfaces (see [Configuring IP Network Interfaces](#) on page 157) are not used for HTTP services. Only the DNS servers configured in this section are used for HTTP services.
- When generating the NGINX configuration file, the device includes the resolver directive, specifying the primary and secondary DNS servers, as configured above. However, NGINX supports optional parameters that allow you to fine-tune the behavior of the DNS resolution. You can include these additional parameters using the ini file parameter [NginxResolverParams], which is added to the resolver directive when the device generates the NGINX configuration file. For more information on these optional parameters, go to [http://nginx.org/en/docs/http/nginx\\_http\\_core\\_module.html#resolver](http://nginx.org/en/docs/http/nginx_http_core_module.html#resolver).

## Configuring HTTP Proxy Servers

The HTTP Proxy Servers table lets you configure up to 10 HTTP Proxy servers. Once configured, you can configure HTTP Locations for the HTTP Proxy Server (see [Configuring HTTP Locations](#) on page 466).

The following procedure describes how to configure HTTP Proxy Servers through the Web interface. You can also configure it through ini file [HTTPServer] or CLI (`configure network > http-proxy > http-server`).

### ➤ To configure an HTTP Proxy Server:

1. Enable the HTTP Proxy application, as described in [Enabling the HTTP Proxy Application](#) on page 461.
2. Open the HTTP Proxy Server table (**Setup** menu > **IP Network** tab > **HTTP Proxy** folder > **HTTP Proxy Servers**).
3. Click **New**; the following dialog box appears:

GENERAL	
Index	1
Name	
Domain Name	
Listening Interface	-- View
HTTP Listening Port	
HTTPS Listening Port	
TLS Context	-- View
Bind To Device	Enable
Verify Client Certificate	No
Additional Directive Set	-- View

4. Configure an HTTP Proxy server according to the parameters described in the table below.
5. Click **Apply**, and then save your settings to flash memory.

**Table 16-23:HTTP Proxy Servers Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	<p>Defines an index number for the new table row.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>Each row must be configured with a unique index.</li> <li>The parameter is mandatory.</li> </ul>
'Name' name [ServiceName]	<p>Defines a descriptive name, which is used when associating the row in other tables.</p> <p>The valid value is a string of up to 40 characters. By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>Configure each row with a unique name.</li> <li>The parameter is mandatory.</li> <li>The parameter value cannot contain a forward slash (/).</li> </ul>
'Domain Name' domain-name [DomainName]	<p>Defines a domain name (FQDN). This is configured only when multiple DNS domains share the same IP address.</p> <p><b>Note:</b> The NGINX directive for this parameter is "server_name".</p>
'Listening Interface' listening-int [ListeningInterface]	<p>Assigns an IP Interface to the HTTP Proxy service. To configure IP Interfaces, see <a href="#">Configuring IP Network Interfaces</a> on page 157.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The parameter is mandatory.</li> <li>The NGINX directive for this parameter is "listen ip".</li> </ul>
'HTTP Listening Port' http-port [HTTPListeningPort]	<p>Defines the HTTP listening port, which is the local port for incoming packets for the HTTP service.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The port number must not conflict with the ports used for the Web interface, which is usually 80 for HTTP and 443 for HTTPS.</li> <li>You must configure at least one port (HTTP or HTTPS port).</li> <li>The NGINX directive for this parameter is "listen ip:port".</li> </ul>
'HTTPS Listening Port'	<p>Defines the HTTPS listening port, which is the local port for</p>



Parameter	Description
https-port [HTTPSListeningPort]	<p>incoming packets for the HTTP service.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The port number must not conflict with the ports used for the Web interface, which is usually 80 for HTTP and 443 for HTTPS.</li> <li>■ You must configure at least one port (HTTP or HTTPS port).</li> <li>■ The NGINX directive for this parameter is "listen ip:port ssl".</li> </ul>
'TLS Context' tls-context [TLSContext]	<p>Assigns a TLS Context (TLS configuration). This is required if you have specified an HTTPS listening port (see the 'HTTPS Listening Port' parameter above). To configure TLS Contexts, see <a href="#">Configuring TLS Certificate Contexts</a> on page 224.</p> <p><b>Note:</b> The NGINX directives for this parameter is "tls-context", "ssl_certificate", "ssl_certificate_key", "ssl_ciphers", "ssl_protocols", and "ssl_password_file".</p>
'Bind To Device' bind-to-device [BindToDevice]	<p>Enables the NGINX to bind the HTTP Proxy interface to a specific device network interface.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b></li> <li>■ [1] <b>Enable</b> (default)</li> </ul>
'Verify Client Certificate' verify-client-cert [VerifyCertificate]	<p>Enables the verification of the client TLS certificate, where the client is the device or user that issues the HTTPS request.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) No certificate verification is done.</li> <li>■ [1] <b>Yes</b> = The device verifies the authentication of the certificate received from the HTTPS client. The device authenticates the certificate against the trusted root certificate store associated with the assigned TLS Context (see 'TLS Context' parameter above) and if ok, allows communication with the HTTPS client. If authentication fails, the device denies communication (i.e., handshake fails). The device can also authenticate the certificate by querying with an Online Certificate Status Protocol (OCSP) server whether the certificate has been revoked. This is also configured for the associated TLS Context.</li> </ul>
'Additional Directive Set' directive-set	<p>Assigns an NGINX Directive Set for the HTTP service. To configure HTTP Directive Sets, see <a href="#">Configuring HTTP Directive</a></p>

Parameter	Description
[AdditionalDirectiveSet]	<a href="#">Sets</a> on page 478.

## Configuring HTTP Locations

The HTTP Locations table lets you configure up to 40 HTTP Locations. Locations are specified for each HTTP proxy server to map the incoming requests received by that server. Mapping is based on matching the URL in the request. Each location specifies the URL prefix or pattern to match and the target Upstream Group to which the request is to be forwarded to.

The HTTP Locations table is a "child" of the HTTP Proxy Servers table (see [Configuring HTTP Proxy Servers](#) on page 463), reflecting the nesting of Location contexts within Server contexts in the NGINX configuration file. This may be used to specify unique handling of URLs by file type (using a regex pattern) or by pathname (using a Prefix or Exact Match pattern).

The following procedure describes how to configure HTTP Locations through the Web interface. You can also configure it through ini file [HTTPLocation] or CLI (`configure network > http-proxy > location`).

### ➤ To configure an HTTP Location:

1. Enable the HTTP Proxy application, as described in [Enabling the HTTP Proxy Application](#) on page 461.
2. Open the HTTP Proxy Servers table (**Setup** menu > **IP Network** tab > **HTTP Proxy** folder > **HTTP Proxy Servers**).
3. In the table, select the required HTTP Proxy Server, and then click the **HTTP Locations** link located below the table; the HTTP Locations table appears.
4. Click **New**; the following dialog box appears:

The screenshot shows the 'HTTP Locations' configuration window. It has two main sections: 'GENERAL' and 'SSL'.  
**GENERAL Section:**  
 - Index: 0  
 - URL Pattern: /  
 - URL Pattern Type: Prefix (dropdown)  
 - Upstream Scheme: HTTP (dropdown)  
 - Upstream Group: -- (dropdown with a 'View' link)  
 - Upstream Path: (empty text field)  
 - Outbound Interface: -- (dropdown with a 'View' link)  
 - Additional Directive Set: -- (dropdown with a 'View' link)  
 - Cache: Yes (checkbox)  
**SSL Section:**  
 - TLS Context: -- (dropdown with a 'View' link)  
 - Verify Certificate: No (checkbox)

5. Configure an HTTP Location according to the parameters described in the table below.
6. Click **Apply**, and then save your settings to flash memory.

**Table 16-24:HTTP Locations Table Parameter Descriptions**

Parameter	Description
General	
'Index' [Index]	<p>Defines an index number for the new table row.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Each row must be configured with a unique index.</li> <li>■ The parameter is mandatory.</li> </ul>
'URL Pattern' url-pattern [URLPattern]	<p>Defines the URL pattern. Received GET or POST requests are matched against the locations in the HTTP Locations table by matching the URL in the received request to the URL configured by this parameter. If there is a match, the prefix is stripped from the request and then forwarded in the outgoing HTTP request.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The pattern must be based on the pattern type configured in the 'URL Pattern Type' parameter (see below).</li> <li>■ The NGINX directive for this parameter is "location modifier pattern".</li> </ul>
'URL Pattern Type' url-pattern-type [URLPatternType]	<p>Defines the type of URL pattern used for configuring the 'URL Pattern' parameter (see above).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Prefix</b> = For Example, "/" matches any URL beginning with a forward slash "/". For NGINX, this option has no modifier.</li> <li>■ [1] <b>Exact</b> = Defines an exact pattern to match, for example, "/abc/def" matches only the file "/abc/def". For NGINX, this option is specified using the "=" modifier.</li> <li>■ [2] <b>Regex</b> = Regex-based pattern (case sensitive), for example, "/files/*.img" matches all files ending in .img in the directory /files. For NGINX, this option is specified using the "~" modifier.</li> <li>■ [3] <b>Case-Insensitive Regex</b> = Regex-based pattern that is case-insensitive, for example, "*.img" matches abc.IMG as well as xyz.img. For NGINX, this option is specified using the "~*" modifier.</li> <li>■ [4] <b>Prefix Ignore Regex</b> = For NGINX, this option is specified using the "^~" modifier.</li> </ul>

Parameter	Description
	<p>For example, assume that you have configured the following URL patterns for four HTTP Locations:</p> <ul style="list-style-type: none"> <li>■ 1) /files – <b>Prefix</b> pattern type</li> <li>■ 2) /files/phone – <b>Prefix</b> pattern type</li> <li>■ 3) /files/firmware -- <b>Prefix-Ignore-Regex</b> pattern type</li> <li>■ 4) *.jpg – <b>Regex</b> pattern type</li> </ul> <p>Therefore, the request URL "/files/phone/aaa" matches Location 2 and the request URL "/files/phone/logo.jpg" matches Location 4. The request URL "/files/firmware/logo.jpg" matches Location 3 (and not Location 4).</p> <p><b>Note:</b> The NGINX directive for this parameter is "location modifier pattern". For more information on NGINX modifiers, see <a href="http://nginx.org/en/docs/http/ngx_http_core_module.html">ngx_http_core_module.html</a>.</p>
'Upstream Scheme' upstream-scheme [UpstreamScheme]	<p>Defines the protocol for sending requests to the Upstream Group.</p> <ul style="list-style-type: none"> <li>■ [0] HTTP (default)</li> <li>■ [1] HTTPS</li> </ul> <p><b>Note:</b> The NGINX directive for this parameter is "proxy_pass scheme://upstream".</p>
'Upstream Group' upstream-group [UpstreamGroup]	<p>Assigns a group of servers (Upstream Group) to handle the HTTP requests. To configure Upstream Groups, see <a href="#">Configuring Upstream Groups</a> on page 474.</p> <p><b>Note:</b> The NGINX directive for this parameter is "proxy_pass scheme://upstream".</p>
'Upstream Path' upstream-path [UpstreamPath]	<p>Defines a path to prepend to the URL before sending the request to the Upstream Group.</p> <p><b>Note:</b> The NGINX directive for this parameter is "proxy_pass scheme://upstream/path".</p>
'Outbound Interface' outbound-intfc [OutboundInterface]	<p>Assigns a local, IP network interface for sending requests to the Upstream Group. To configure IP network interfaces, see <a href="#">Configuring IP Network Interfaces</a> on page 157.</p> <p>By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ The NGINX directive for this parameter is "proxy_bind".</li> </ul>
'Additional Directive Set' directive-set [AdditionalDirectiveSet]	<p>Assigns an NGINX directive set for the HTTP location. To configure NGINX directives, see <a href="#">Configuring HTTP Directive Sets</a> on page 478.</p>
'Cache' cache [Cache]	<p>Enables the caching of files in this location.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b></li> <li>■ [1] <b>Yes</b> (default)</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Currently, this feature is not supported.</li> <li>■ The NGINX directive for this parameter is "proxy_cache zone off".</li> </ul>
<b>SSL</b>	
'TLS Context' tls-context [TLSContext]	<p>Assigns a TLS Context for the TLS connection with the HTTP location.</p> <p>To configure TLS Contexts, see <a href="#">TLS Certificates</a> on page 224.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if the connection protocol is HTTPS (configured in the 'Upstream Scheme' parameter, above).</li> <li>■ The NGINX directives for this parameter are "proxy_ssl_certificate", "proxy_ssl_certificate_key", "proxy_ssl_ciphers", "proxy_ssl_protocols", and "proxy_ssl_password_file".</li> </ul>
'Verify Certificate' verify-cert [VerifyCertificate]	<p>Enables TLS certificate verification when the connection with the location is based on HTTPS. It verifies the certificate of the incoming connection request from the Upstream Group.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) No certificate verification is done.</li> <li>■ [1] <b>Yes</b> = The device verifies the authentication of the certificate received from the HTTPS location. The device authenticates the certificate against the trusted root certificate store associated with the assigned TLS Context (see 'TLS Context' parameter above) and if ok, allows communication with the HTTPS location. If authentication fails, the device denies communication (i.e., handshake</li> </ul>

Parameter	Description
	<p>fails). The device can also authenticate the certificate by querying with an Online Certificate Status Protocol (OCSP) server whether the certificate has been revoked. This is also configured for the associated TLS Context.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if the connection protocol is HTTPS (configured in the 'Upstream Scheme' parameter, above).</li> <li>■ The NGINX directive for this parameter is "proxy_ssl_verify".</li> </ul>

## Configuring TCP-UDP Proxy Servers

The TCP/UDP Proxy Servers table lets you configure up to 10 TCP/UDP proxy servers. This table allows you to configure the device as a proxy for other applications that are not based on HTTP. For example, it can be used to intermediate between clients and a DNS server for DNS lookup, or between clients and an NTP server for clock synchronization.

The following procedure describes how to configure a TCP-UDP Proxy Server through the Web interface. You can also configure it through ini file [TcpUdpServer] or CLI (`configure network > http-proxy > tcp-udp-server`).

### ➤ To configure a TCP/UDP Proxy Server:

1. Enable the HTTP Proxy application, as described in [Enabling the HTTP Proxy Application](#) on page 461.
2. Open the TCP/UDP Proxy Servers table (**Setup** menu > **IP Network** tab > **HTTP Proxy** folder > **TCP/UDP Proxy Servers**).
3. Click **New**; the following dialog box appears:

4. Configure a TCP/UDP Proxy Server according to the parameters described in the table below.
5. Click **Apply**, and then save your settings to flash memory.

**Table 16-25:TCP/UDP Proxy Servers Table Parameter Descriptions**

Parameter	Description
General	
'Index' [Index]	<p>Defines an index number for the new table row.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Each row must be configured with a unique index.</li> <li>■ The parameter is mandatory.</li> </ul>
'Name' name [Name]	<p>Defines a descriptive name, which is used when associating the row in other tables.</p> <p>The valid value is a string of up to 40 characters. By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Configure each row with a unique name.</li> <li>■ The parameter is mandatory.</li> </ul>
'Additional Directive Set' directive-set [AdditionalDirectiveSet]	<p>Assigns an NGINX Directive Set for the HTTP service. To configure HTTP Directive Sets, see <a href="#">Configuring HTTP Directive Sets</a> on page 478.</p>
Listen Parameters	
'Listening Interface' listen-interface [ListeningInterface]	<p>Assigns a local IP network interface for the listening (source) interface for communication with the TCP-UDP proxy server. To configure IP Interfaces, see <a href="#">Configuring IP Network Interfaces</a> on page 157.</p> <p>By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> <li>■ The NGINX directive for this parameter is "listen ip".</li> </ul>
'TCP Listening Port' tcp-port [TCPListeningPort]	<p>Defines the TCP port of the listening interface.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ You must configure a TCP and/or UDP port.</li> <li>■ The NGINX directive for this parameter is "listen ip:port".</li> <li>■ The source ports used for outgoing TCP connections are not configurable and are dynamically determined by the device in the range of 32,768-61,000.</li> </ul>

Parameter	Description
'UDP Listening Port' udp-port [UDPListeningPort]	<p>Defines the TCP port of the listening interface.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ You must configure a TCP and/or UDP port.</li> <li>■ The NGINX directive for this parameter is "listen ip:port udp".</li> </ul>
'Listen Side SSL' listen-use-ssl [ListenUseSSL]	<p>Enables TLS on the listening side (i.e., listening to incoming connection requests).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p><b>Note:</b> The NGINX directive for this parameter is "listen ip:port ssl".</p>
'Listen TLS Context' listen-tls-context [ListenTLSContext]	<p>Assigns a TLS Context (TLS certificate) for the listening side. This is required if you have configured the 'Listen Side SSL' parameter to <b>Enable</b> (see above). To configure TLS Contexts, see <a href="#">Configuring TLS Certificate Contexts</a> on page 224.</p> <p><b>Note:</b> The NGINX directives for this parameter is "ssl_certificate", "ssl_certificate_key", "ssl_ciphers", "ssl_protocols", and "ssl_password_file".</p>
Upstream Parameters	
'Upstream Group' upstream-group [UpstreamGroup]	<p>Assigns a group of servers (Upstream Group) to which to forward connection requests. To configure Upstream Groups, see <a href="#">Configuring Upstream Groups</a> on page 474.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Only Upstream Groups with TCP/UDP interfaces can be assigned.</li> <li>■ The NGINX directive for this parameter is "proxy_pass upstream".</li> </ul>
'Outbound Interface' outbound-interface [OutboundInterface]	<p>Assigns a local, IP network interface for communicating with the Upstream Group. To configure IP network interfaces, see <a href="#">Configuring IP Network Interfaces</a> on page 157.</p> <p>By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> </ul>



Parameter	Description
	<ul style="list-style-type: none"> <li>■ The NGINX directive for this parameter is "proxy_bind".</li> </ul>
'Upstream Side SSL' upstream-use-ssl [UpstreamUseSSL]	<p>Enables TLS for securing connection requests with the Upstream Group.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If configured to <b>Enable</b>, you must assign a TLS Context (see the 'Upstream TLS Context' parameter below).</li> <li>■ The NGINX directive for this parameter is "proxy_ssl on".</li> </ul>
'Upstream TLS Context' upstream-tls-context [UpstreamTLSContext]	<p>Assigns a TLS Context for the TLS connection with the HTTP location. To configure TLS Contexts, see <a href="#">Configuring TLS Certificate Contexts</a> on page 224.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if the 'Upstream Side SSL' parameter is configured to <b>Enable</b> (see above).</li> <li>■ The NGINX directives for this parameter are "proxy_ssl_certificate", "proxy_ssl_certificate_key", "proxy_ssl_ciphers", "proxy_ssl_protocols", and "proxy_ssl_password_file".</li> </ul>
'Upstream Verify Certificate' upstream-verify-cert [UpstreamVerifyCertificate]	<p>Enables TLS certificate verification of the Upstream Host on outgoing connection requests to the Upstream Group, when the connection is TLS.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) No certificate verification is done.</li> <li>■ [1] <b>Yes</b> = The device verifies the authentication of the certificate received from the host. The device authenticates the certificate against the trusted root certificate store associated with the assigned TLS Context (see 'Upstream TLS Context' parameter above) and if ok, allows communication with the host. If authentication fails, the device denies communication (i.e., handshake fails). The device can also authenticate the certificate by querying with an Online Certificate Status Protocol (OCSP) server whether the certificate has been revoked. This is also</li> </ul>

Parameter	Description
	<p>configured for the associated TLS Context.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if the 'Upstream Side SSL' parameter is configured to <b>Enable</b> (see above).</li> <li>■ The NGINX directive for this parameter is "proxy_ssl_verify".</li> </ul>

## Configuring Upstream Groups

The Upstream Groups table lets you configure up to 10 Upstream Groups. Once configured, you can configure Upstream Hosts for the Upstream Group (see [Configuring Upstream Hosts](#) on page 476).

An Upstream Group is a set of one or more hosts (*Upstream Host*) that can serve a particular set of data. The HTTP Proxy distributes the requests among the members (hosts) of the Upstream Group according to the specified load balancing mode.

The Upstream Group may be made up of one or more primary hosts and zero or more backup hosts. HTTP requests for the Upstream Group are distributed among all the primary hosts. Backup hosts do not receive requests unless all the primary hosts are down.

The following procedure describes how to configure Upstream Groups through the Web interface. You can also configure it through ini file [UpstreamGroup] or CLI (`configure network > http-proxy > upstream-group`).

### ➤ To configure an Upstream Group:

1. Enable the HTTP Proxy application, as described in [Enabling the HTTP Proxy Application](#) on page 461.
2. Open the Upstream Groups table (**Setup** menu > **IP Network** tab > **HTTP Proxy** folder > **Upstream Groups**).
3. Click **New**; the following dialog box appears:

Upstream Groups

GENERAL

Index

0

Name

Protocol

HTTP/HTTPS

Load Balancing Mode

Round Robin

Max Connections

0

4. Configure an Upstream Group according to the parameters described in the table below.

5. Click **Apply**, and then save your settings to flash memory.

**Table 16-26:Upstream Groups Table Parameter Descriptions**

Parameter	Description
General	
'Index' [Index]	<p>Defines an index number for the new table row.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Each row must be configured with a unique index.</li> <li>■ The parameter is mandatory.</li> </ul>
'Name' name [Name]	<p>Defines a descriptive name, which is used when associating the row in other tables.</p> <p>The valid value is a string of up to 40 characters. By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Configure each row with a unique name.</li> <li>■ The NGINX directive for this parameter is "upstream name { ... }".</li> <li>■ The parameter is mandatory.</li> <li>■ The parameter value cannot contain a forward slash (/).</li> </ul>
'Protocol' protocol [Protocol]	<p>Defines the protocol.</p> <ul style="list-style-type: none"> <li>■ [0] <b>HTTP/HTTPS</b> (default)</li> <li>■ [1] <b>TCP/UDP</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ To assign the Upstream Group to a TCP/UDP Proxy Server, configure the parameter to TCP/UDP. To configure TCP/UDP Proxy Servers, see <a href="#">Configuring TCP-UDP Proxy Servers</a> on page 470.</li> <li>■ To assign the Upstream Group to an HTTP Proxy Server, configure the parameter to HTTP/HTTPS. To configure HTTP Proxy Servers, see <a href="#">Configuring HTTP Proxy Servers</a> on page 463.</li> <li>■ For NGINX, the parameter determines nesting within the "http" or "stream" context.</li> </ul>
'Load Balancing Mode' load-balancing-	<p>Defines the load-balancing of traffic method for the hosts belonging to the Upstream Group.</p>

Parameter	Description
mode [LoadBalancingMode]	<ul style="list-style-type: none"> <li>■ [0] <b>Round Robin</b> = (Default) Traffic requests are balanced across all hosts. Every consecutive request is sent to the next available host.</li> <li>■ [1] <b>IP Hash</b> = All requests from a given client (by IP address) is sent to the same host, regardless of current load.</li> <li>■ [2] <b>Least Connections</b> = New requests are sent to the host with the fewest active connections.</li> </ul> <p><b>Note:</b> The NGINX directive for this parameter is "ip-hash (1)", "least-conn (2)", and "round-robin (0)".</p>
'Max Connections' max-connections [MaxConnections]	<p>Defines the maximum number of simultaneous active connections to the proxied Upstream Host server. Configuring the parameter to a non-zero value activates connection re-use and limits the number of connections towards the upstream server.</p> <p>The default is 0, meaning unlimited connections (i.e., a new upstream connection is opened for every incoming HTTP or HTTPS request).</p> <p><b>Note:</b> To fully utilize the connection re-use capability, you must also include the following directives at the HTTP Location level:</p> <pre>proxy_http_version 1.1; proxy_set_header Connection "";</pre> <p>For more information on adding directives, see <a href="#">Configuring HTTP Directives</a> on page 480.</p>

## Configuring Upstream Hosts

The Upstream Hosts table lets you configure up to 50 Upstream Hosts. The Upstream Hosts table is a "child" of the Upstream Group table (see [Configuring Upstream Groups](#) on page 474) and therefore, Upstream Hosts are configured per Upstream Group. Up to 5 Upstream Hosts can be configured per Upstream Group.

The following procedure describes how to configure Upstream Hosts through the Web interface. You can also configure it through ini file [UpstreamHost] or CLI (`configure network > http-proxy > upstream-host`).



The device activates a keep-alive mechanism to ensure that the hosts configured in the Upstream Hosts table are accessible through HTTP. If an HTTP server goes offline, the device raises an alarm. The device also notifies this event in syslog messages if you have configured the 'HTTP Proxy Debug Level' parameter to **Info** or **Notice**.

➤ **To configure an Upstream Host:**

1. Enable the HTTP Proxy application, as described in [Enabling the HTTP Proxy Application](#) on page 461.
2. Open the Upstream Groups table (**Setup** menu > **IP Network** tab > **HTTP Proxy** folder > **Upstream Groups**).
3. In the table, select the required Upstream Group index row, and then click the **Upstream Hosts** link located below the table; the Upstream Hosts table appears.
4. Click **New**; the following dialog box appears:

Upstream Hosts - x

GENERAL

Index	<input style="width: 80%;" type="text" value="q"/>
Host	<input style="width: 80%;" type="text"/>
Port	<input style="width: 80%;" type="text"/>
Weight	<input style="width: 80%;" type="text" value="1"/>
Backup	<input style="width: 80%;" type="text" value="Disable"/>

5. Configure an Upstream Host according to the parameters described in the table below.
6. Click **Apply**, and then save your settings to flash memory.

**Table 16-27: Upstream Hosts Table Parameter Descriptions**

Parameter	Description
'Index' [UpstreamHost_HostIndex]	<p>Defines an index number for the new table row.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Each row must be configured with a unique index.</li> <li>■ The parameter is mandatory.</li> </ul>
'Host' host [UpstreamHost_Host]	<p>Defines the address of the host as an FQDN or IP address (in dotted-decimal notation).</p> <p><b>Note:</b> The NGINX directive for this parameter is "server host:port".</p>

Parameter	Description
'Port' port [UpstreamHost_Port]	Defines the port number. <b>Note:</b> <ul style="list-style-type: none"> <li>■ If the Upstream Group to which the host belongs is configured to use the TCP/UDP protocol, then this parameter must be configured.</li> <li>■ The NGINX directive for this parameter is "server ip:port". If not configured, NGINX defaults to 80 for HTTP and 443 for HTTPS.</li> </ul>
'Weight' weight [UpstreamHost_Weight]	Defines the weight for the load balancer. The load balancer distributes the requests among the hosts in the Upstream Group based on the weight of each host. For example, if host A is configured with a weight of 3, host B with a weight of 1, and host C with a weight of 1, then in each cycle, the load balancer will send three requests to host A, one request to host B and one request to host C. The valid range is 1 to 100. The default is 1 (i.e., each host in the Upstream Group has equal weight). <b>Note:</b> The NGINX directive for this parameter is "server ip:port weight=n".
'Backup' backup [UpstreamHost_Backup]	Enables the host to serve as a backup host. The backup host doesn't receive any requests unless all the primary hosts in the Upstream Group are down. <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <b>Note:</b> The NGINX directive for this parameter is "server ip:port backup".

## Configuring HTTP Directive Sets

The HTTP Directive Sets table lets you configure up to 30 HTTP Directive Sets. The table lets you configure additional custom directives to HTTP Proxy server configuration. These directives are reflected in the configuration file generated for the NGINX HTTP Proxy. The directives of each HTTP Directive Set is configured in the HTTP Directives table (see [Configuring HTTP Directives](#) on page 480), which is a "child" of the HTTP Directive Sets table.

Directives are grouped into Directive Sets, which you can then assign to HTTP Proxy Servers (see [Configuring HTTP Proxy Servers](#) on page 463), HTTP Locations (see [Configuring HTTP Locations](#)

on page 466), and TCP/UDP Proxy Servers (see [Configuring TCP-UDP Proxy Servers](#) on page 470), using the 'Additional Directive Set' parameter in their respective tables.

For example, to control behavior of specific encoding and communication parameters relating to a particular location, you can configure the following NGINX directives:

```
chunked_transfer_encoding off;
keepalive_timeout 50s;
```



- The device doesn't validate Directive Sets, which it passes directly to the NGINX configuration file. If the configured directives are not entered using the correct syntax, NGINX rejects the new configuration. For more information, refer to the NGINX documentation at <http://nginx.org/en/docs>. An alphabetical index to all directives can be found at <http://nginx.org/en/docs/dirindex.html>.
- By default, the device is configured with an HTTP Directive Set for rate limiting. This directive ensures that priority is given to network traffic carrying SIP signaling and media over HTTP traffic. It is highly recommended to configure these limitations on the HTTP Proxy. This HTTP Directive Set includes the following directives:
  - ✓ "limit\_conn": Specifies the maximum number of simultaneous client connections (default 100).
  - ✓ "limit\_rate": Specifies the bandwidth limit per connection (bytes per second). This syntax supports a suffix of "k" for kilobytes and "m" for megabytes. The default is 0.

The following procedure describes how to configure HTTP Directive Sets through the Web interface. You can also configure it through ini file [HTTPODirectiveSets] or CLI (`configure network > http-proxy > directive-sets`).

#### ➤ To configure an HTTP Directive Set:

1. Enable the HTTP Proxy application, as described in [Enabling the HTTP Proxy Application](#) on page 461.
2. Open the HTTP Directive Sets table (**Setup** menu > **IP Network** tab > **HTTP Proxy** folder > **HTTP Directive Sets**).
3. Click **New**; the following dialog box appears:

GENERAL	
Index	0
Set Name	
Description	

4. Configure an HTTP Directive Set according to the parameters described in the table below.
5. Click **Apply**, and then save your settings to flash memory.

6. Configure directives for the HTTP Directive Set (see [Configuring HTTP Directives](#) below).

**Table 16-28: HTTP Directive Sets Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	<p>Defines an index number for the new table row.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>Each row must be configured with a unique index.</li> <li>The parameter is mandatory.</li> </ul>
'Set Name' set-name [SetName]	<p>Defines a descriptive name, which is used when associating the row in other tables.</p> <p>The valid value is a string of up to 40 characters. By default, no value is defined.</p> <p><b>Note:</b> The parameter value cannot contain a forward slash (/).</p>
'Description' set-description [Description]	<p>Defines a brief description for the HTTP Directive Set.</p> <p>The valid value is a string of up to 100 characters. By default, no value is defined.</p>

### Configuring HTTP Directives

The HTTP Directives table lets you configure up to 500 HTTP Directives. The table is a "child" of the HTTP Directive Sets table (see [Configuring HTTP Directive Sets](#) on page 478).



When generating the NGINX configuration file, the device includes the resolver directive, specifying the primary and secondary DNS servers, as configured in [Configuring a DNS Server for HTTP Services](#) on page 462. However, NGINX supports optional parameters that allow you to fine-tune the behavior of the DNS resolution. You can include these additional parameters using the ini file parameter [NginxResolverParams), which is added to the resolver directive when the device generates the NGINX configuration file. For more information on these optional parameters, go to the [NGINX forum](#).

The following procedure describes how to configure HTTP Directives through the Web interface. You can also configure it through ini file [HTTPEndirectives] or CLI (`configure network > http-proxy > directives`).

#### ➤ To configure an HTTP Directive:

1. Enable the HTTP Proxy application, as described in [Enabling the HTTP Proxy Application](#) on page 461.



2. Open the HTTP Directive Sets table (**Setup** menu > **IP Network** tab > **HTTP Proxy** folder > **HTTP Directive Sets**).
3. In the table, select the required HTTP Directive Set index row, and then click the **HTTP Directives** link located below the table; the HTTP Directives table appears.
4. Click **New**; the following dialog box appears:

5. Configure an HTTP Directive according to the parameters described in the table below.
6. Click **Apply**, and then save your settings to flash memory.

**Table 16-29: HTTP Directives Table Parameter Descriptions**

Parameter	Description
'Index' [HTTPOirectives_ RowIndex]	Defines an index number for the new table row. <b>Note:</b> <ul style="list-style-type: none"> <li>■ Each row must be configured with a unique index.</li> <li>■ The parameter is mandatory.</li> </ul>
' Directive' directive [HTTPOirectives_ Directive]	Defines an NGINX directive. <b>Note:</b> <ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> <li>■ Make sure that you end the directive with a semicolon (;).</li> </ul>

## Configuring an HTTP-based OVOC Service

The OVOC Services table lets you configure a single HTTP-based AudioCodes One Voice Operations Center (OVOC) service. You can configure the device to act as an HTTP Proxy that enables OVOC to manage AudioCodes equipment (such as IP Phones) over HTTP when the equipment is located behind NAT (e.g., in the LAN) and OVOC is located in a public domain (e.g., in the WAN). This setup resolves NAT traversal issues. The IP Phones register with the device to allow communication between the IP Phones and OVOC. Once setup, the OVOC administrator can access the Web-based management interfaces of each IP Phone .

A summary of the steps required to configure an HTTP Proxy for this OVOC service is listed below:

1. Enable the HTTP Proxy application (see [Enabling the HTTP Proxy Application](#) on page 461).

2. Configure two local, listening IP network interfaces - one for OVOC and one for the IP Phones (see [Configuring IP Network Interfaces](#) on page 157).
3. Configure the OVOC service in the OVOC Services table (described below). This entails specifying the IP network interfaces as well as the port number within each interface to which the HTTP Proxy must listen to.
4. Configure the device's firewall (Firewall table) to allow incoming traffic from OVOC. For more information, see [Configuring Firewall Rules to Allow Incoming OVOC Traffic](#) on page 256.



- It is recommended **not** to use port 80 as this is the default port used by IP Phones for their Web-based management interface.
- No special configuration is required on the managed equipment.

The following procedure describes how to configure an OVOC service through the Web interface. You can also configure it through ini file [OVOCService] or CLI (`configure network > http-proxy > ovoc-serv`).

➤ **To configure an OVOC Service:**

1. Enable the HTTP Proxy application, as described in [Enabling the HTTP Proxy Application](#) on page 461.
2. Open the OVOC Services table (**Setup** menu > **IP Network** tab > **HTTP Proxy** folder > **OVOC Services**).
3. Click **New**; the following dialog box appears:

4. Configure an OVOC Service according to the parameters described in the table below.
5. Click **Apply**, and then save your settings to flash memory.

**Table 16-30:OVOC Services Table Parameter Descriptions**

Parameter	Description
<b>General</b>	
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b>

Parameter	Description
	<ul style="list-style-type: none"> <li>Each row must be configured with a unique index.</li> <li>The parameter is mandatory.</li> </ul>
'Name' service-name [ServiceName]	<p>Defines a descriptive name, which is used when associating the row in other tables.</p> <p>The valid value is a string of up to 40 characters. By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>Configure each row with a unique name.</li> <li>The parameter is mandatory.</li> </ul>
<b>Device</b>	
'Device Login Interface' device-login-interface [DeviceLoginInterface]	<p>Assigns an IP network interface (local, listening HTTP interface:port) for communication with the client. To configure IP Interfaces, see <a href="#">Configuring IP Network Interfaces</a> on page 157.</p> <p>By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The parameter is mandatory.</li> <li>The NGINX directive for this parameter is "proxy_bind".</li> </ul>
'Device Login Port' device-login-port [DeviceLoginPort]	<p>Defines the login port of the requesting client.</p> <p><b>Note:</b> The NGINX directive for this parameter is "proxy_bind".</p>
'Device Scheme' device-scheme [DeviceScheme]	<p>Defines the protocol for communication with the requesting client.</p> <ul style="list-style-type: none"> <li>[0] HTTP (default)</li> <li>[1] HTTPS</li> </ul> <p><b>Note:</b> If configured to <b>HTTPS</b>, you must assign a TLS Context (see the 'Device Login TLS Context' parameter, below).</p>
'Device Login TLS Context' device-login-tls-context	<p>Assigns a TLS Context (TLS configuration) for the interface with the requesting client. This is required if you have configured the 'Device Scheme'</p>

Parameter	Description
[LoginInterfaceTLSContext]	<p>parameter to <b>HTTPS</b> (see above). To configure TLS Contexts, see <a href="#">Configuring TLS Certificate Contexts</a> on page 224.</p> <p><b>Note:</b> The NGINX directive for this parameter is "proxy_ssl_certificate", "proxy_ssl_certificate_key", "proxy_ssl_ciphers", and "proxy_ssl_protocols".</p>
'Device Login Interface Verify Certificate' device-interface-verify-cert [LoginInterfaceVerifyCert]	<p>Enables the verification of the TLS certificate that is used in the incoming client connection request.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) No certificate verification is done.</li> <li>■ [1] <b>Yes</b> = The device verifies the authentication of the certificate received from the client. The device authenticates the certificate against the trusted root certificate store associated with the assigned TLS Context (see 'Device Login TLS Context' parameter above) and if ok, allows communication with the client. If authentication fails, the device denies communication (i.e., handshake fails). The device can also authenticate the certificate by querying with an Online Certificate Status Protocol (OCSP) server whether the certificate has been revoked. This is also configured for the associated TLS Context.</li> </ul> <p><b>Note:</b> The NGINX directive for this parameter is "proxy_ssl_verify".</p>
<b>OVOC</b>	
'OVOC Listening Interface' ovoc-interface [OVOCListeningInterface]	<p>Assigns an IP network interface (local, listening HTTP interface:port) for communication with OVOC. To configure IP Interfaces, see <a href="#">Configuring IP Network Interfaces</a> on page 157.</p> <p>By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> <li>■ The NGINX directive for this parameter is "proxy_bind".</li> </ul>
'OVOC Listening Port' ovoc-port	<p>Defines the listening port for the OVOC interface.</p> <p><b>Note:</b> The NGINX directive for this parameter is</p>

Parameter	Description
[OVOCListeningPort]	"proxy_bind".
'OVOC Scheme' ovoc-scheme [OVOCScheme]	<p>Defines the security scheme for the connection with OVOC.</p> <ul style="list-style-type: none"> <li>■ [0] <b>HTTP</b> (default)</li> <li>■ [1] <b>HTTPS</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If configured to <b>HTTPS</b>, you must assign a TLS Context (see the 'OVOC Interface TLS Context' parameter, below).</li> <li>■ The NGINX directive for this parameter is "proxy_pass scheme://upstream".</li> </ul>
'OVOC Interface TLS Context' ovoc-interface-tls-context [OVOCInterfaceTLSContext]	<p>Assigns a TLS Context (TLS configuration) for the OVOC listening interface. This is required if you have configured the 'OVOC Scheme' parameter to <b>HTTPS</b> (see above). To configure TLS Contexts, see <a href="#">Configuring TLS Certificate Contexts</a> on page 224.</p> <p><b>Note:</b> The NGINX directive for this parameter is "proxy_ssl_certificate", "proxy_ssl_certificate_key", "proxy_ssl_ciphers", and "proxy_ssl_protocols".</p>
'OVOC Interface Verify Certificate' ovoc-verify-cer [OVOCInterfaceVerifyCert]	<p>Enables the verification of the TLS certificate that is used in the incoming connection request from OVOC.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) No certificate verification is done.</li> <li>■ [1] <b>Yes</b> = The device verifies the authentication of the certificate received from OVOC. The device authenticates the certificate against the trusted root certificate store associated with the assigned TLS Context (see 'OVOC Interface TLS Context' parameter above) and if ok, allows communication with OVOC. If authentication fails, the device denies communication (i.e., handshake fails). The device can also authenticate the certificate by querying with an Online Certificate Status Protocol (OCSP) server whether the certificate has been revoked. This is also configured for the associated TLS Context.</li> </ul>

Parameter	Description
	<p><b>Note:</b> The NGINX directive for this parameter is "proxy_ssl_verify".</p>
'OVOC Primary Server' primary-server [PrimaryServer]	<p>Defines the address (IPv4 or IPv6) of the primary OVOC server.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ This parameter is mandatory.</li> <li>■ When you configure this parameter, an Upstream Group is automatically added (see <a href="#">Configuring Upstream Groups</a> on page 474).</li> <li>■ The NGINX directive for this parameter is "upstream ems { addr1, addr2 backup }" and "proxy_pass scheme://ems".</li> <li>■ The IP address version (IPv4 or IPv6) of the OVOC address and the IP Interface (see 'OVOC Listening Interface' field above) must be the same.</li> </ul>

## Troubleshooting NGINX Configuration

Troubleshooting may be necessary when configuring your HTTP or TCP/UDP proxy services with NGINX directives. Due to the large and complex dictionary of directives supported by NGINX and their complex grammatical structure, the device assists you by validating your configured directives. It does this only once you have applied them (i.e., clicked the **Apply** button) in the HTTP Directives table (see [Configuring HTTP Directives](#) on page 480).

In addition, the device generates the following NGINX configuration files:

- **nginx.conf:** This file contains the currently active configuration, which is valid.
- **temp\_nginx.conf:** This file is generated if you have invalid configuration (directive errors). It is a temporary file and contains your new configuration, which is invalid. It is applied only if the device is restarted.
- **nginx.errors:** This file is generated if you have invalid configuration (directive errors). This file contains all the error messages, indicating the line on which the error exists in the temp\_nginx.conf file.

If you have modified your configuration and errors occur, the device continues running with the previous, valid NGINX configuration, unless the device is restarted, in which case it applies and uses the modified configuration.

In addition, if an NGINX validation error exists during configuration or if the device restarts with an invalid NGINX configuration, the device indicates this by the following:

- Sends an alarm to the Active Alarms table ("NGINX configuration file is not valid")

- Sends the error to syslog, which is marked with "http\_app"

To send the NGINX files to a remote destination in tar file format (.tar), use the following CLI command:

```
# copy nginx-conf-files to <Protocol>://<Address>/<filename>.tar
```

To view the NGINX files in CLI, use the following command:

```
show network http-proxy conf active|errors|new
```

## Configuring a Public IP Address for NGINX NAT Traversal

When the device is located behind NAT, OVOC can only communicate with the device's embedded NGINX HTTP-based proxy using the device's public static NAT address. However, by default, the device sends its private address to OVOC. The device's address (private or public) appears in the proprietary X-AC-Proxy-URL header in HTTP requests that the device sends to OVOC.

### ➤ To configure a public IP address for HTTP Proxy:

1. Open the HTTP Proxy Settings page (**Setup** menu > **IP Network** tab > **HTTP Proxy** folder > **HTTP Proxy Settings**).
2. In the 'HTTP Proxy Global Address' [HttpProxyGlobalAddress] field, enter the public IP address:

HTTP Proxy Global Address

3. Click **Apply**.

## Configuring LDAP Authentication for NGINX HTTP Reverse Proxy

You can configure the device's HTTP Reverse Proxy to authenticate HTTP requests with an LDAP server. This is done using the device's integrated NGINX add-on module "nginx-auth-ldap-module".

### ➤ To configure LDAP authentication for HTTP Reverse Proxy:

1. Configure one or more LDAP servers in an HTTP Directive Set. Note that the declaration may include the optional "require group", "require valid\_user", or "require group" clauses.

```
ldap_server ad_1 {
# User search base
url "ldap://<YOUR LDAP
```

```

SERVER>:3268/,DC=company,DC=com?sAMAccountName?sub?
(objectClass=person)\";
# bind as
binddn \"CN=Operator,OU=Service Accounts,DC=company,DC=com\";
# bind pw
binddn_passwd <PUT Operator's PASSWORD HERE>;
# group attribute name which contains member object
group_attribute member;
# search for full DN in member object
group_attribute_is_dn on;
# matching algorithm (any / all)
satisfy any;
# optional list of allowed groups
require group \"CN=Admins,OU=My Security
Groups,DC=company,DC=com\";
require group \"CN=New York Users,OU=My Security
Groups,DC=company,DC=com\";

# optional list of allowed users
# require 'valid_user' cannot be used together with 'user' as valid user is a
superset
require valid_user;\"
# require user \"<YOUR LDAP QUERY>\";
}

```

2. Customize the url, DN password, and any other attributes of the query, as needed. Details of the syntax supported for the LDAP server declarations can be found [here](#).
3. Reference this new declaration in the “HTTP Context Directives”. For example, if in the previous step, you named the HTTP Directive Set “My LDAP Server”, then add the following line to the “HTTP Context Directives”:

```
<@Include My LDAP Server@>;
```

4. Activate LDAP authentication on the HTTP Servers and/or Locations:
  - a. Add the following lines to an HTTP Directive Set:

```

auth_ldap "Forbidden";
auth_ldap_servers ad_1;
# additional ldap servers as required...
# auth_ldap_servers ad_2;

```

- b. Set this HTTP Directive Set as the Additional Directive set for any HTTP servers or HTTP Locations for which you wish to authenticate using LDAP:



**HTTP Proxy Servers (1)**

+ New Edit | Page 1 of 1 Show 10 records per page

INDEX	NAME	DOMAIN NAME	LISTENING INTERFACE	HTTP LISTENING PORT	HTTPS LISTENING PORT	TLS CONTEXT	BIND TO DEVICE	VERIFY CLIENT CERTIFICATE	ADDITIONAL DIRECTIVE SET
0	HTTPServer_0		O+M+C	800		--	Enable	No	LDAP Auth

---

**#0[HTTPServer\_0]** Edit

GENERAL	
Name	• HTTPServer_0
Domain Name	
Listening Interface	• O+M+C <a href="#">View</a>
HTTP Listening Port	• 800
HTTPS Listening Port	
TLS Context	-- <a href="#">View</a>
Bind To Device	Enable
Verify Client Certificate	No
Additional Directive Set	• LDAP Auth <a href="#">View</a>

## E9-1-1 Support for Microsoft Teams and Skype for Business

The Enhanced 9-1-1 (E9-1-1) service is becoming the mandatory emergency service required in many countries around the world. The E9-1-1 service, based on its predecessor 911, enables emergency operators to pinpoint the location (granular location) of callers who dial the 9-1-1 emergency telephone number.

Today, most companies implement an IP-based infrastructure providing a VoIP network with fixed and nomadic users, allowing connectivity anywhere with any device. This, together with an often deployed multi-line telephone system (MLTS) poses a challenge for E9-1-1 due to the difficulty in accurately locating the E9-1-1 caller.

This section describes the E9-1-1 solution provided by Microsoft Teams / Skype for Business and AudioCodes' device's ELIN interworking capabilities, which provides the SIP Trunk or ISDN (or CAMA) connectivity to the E9-1-1 emergency service provider. This section also describes the configuration of the device for interoperating between the Teams / Skype for Business environment and the E9-1-1 emergency provider.




- The ELIN feature for E9-1-1 is a license-based feature and is available only if it is included in the License Key installed on the device. For ordering the feature, please contact the sales representative of your purchased device. For installing a new License Key, see [License Key](#) on page 1233.
- The ELIN feature for E9-1-1 is applicable to the SBC application and the Gateway application (digital PSTN interfaces only).

## About E9-1-1 Services

E9-1-1 is a national emergency service for many countries, enabling E9-1-1 operators to automatically identify the geographical location and phone number of a 911 caller. In E9-1-1, the 911 caller is routed to the nearest E9-1-1 operator, termed *public safety answering point* (PSAP) based on the location of the caller. Automatic identification of the caller's location and phone number reduces the time spent on requesting this information from the 911 caller. Therefore, the E9-1-1 service enables the PSAP to quickly dispatch the relevant emergency services (for example, fire department or police) to the caller's location. Even if the call prematurely disconnects, the operator has sufficient information to call back the 911 caller.

The figure below illustrates the routing of an E9-1-1 call to the PSAP:



1. The VoIP user dials 9-1-1.
2. The AudioCodes' ELIN device sends the call to the emergency service provider over the PSTN or SIP Trunk (PSAP server).
3. The emergency service provider identifies the call is an emergency call and sends it to an E9-1-1 Selective Router in the Emergency Services provider's network.
4. The E9-1-1 Selective Router determines the geographical location of the caller by requesting this information from an Automatic Location Identification (ALI) database based on the phone number or Automatic Number Identifier (ANI) of the 911 caller. Exact location information is also supplied by the Master Street Address Guide (MSAG) database, which is a companion database to the ALI database. Phone companies and public safety agencies collaborate beforehand to create master maps that match phone numbers, addresses and cross streets to their corresponding PSAP. This MSAG is the official record of valid streets (with exact spelling), street number ranges, and other address elements with which the service providers are required to update their ALI databases.
5. The E9-1-1 Selective Router sends the call to the appropriate PSAP based on the retrieved location information from the ALI.

6. The PSAP operator dispatches the relevant emergency services to the E9-1-1 caller.


## Microsoft Skype for Business and E9-1-1

Microsoft Skype for Business enables Enterprise voice users to access its unified communications platform from virtually anywhere and through many different devices. This, together with a deployed MLTS, poses a challenge for E9-1-1 due to the difficulty in accurately locating the E9-1-1 caller. However, Skype for Business offers an innovative solution to solving Enterprises E9-1-1 location problems.

### Gathering Location Information of Skype for Business Clients for 911 Calls

When a Microsoft Skype for Business client is enabled for E9-1-1, the location data that is stored on the client is sent during an emergency call. This stored location information is acquired automatically from the Microsoft Location Information Server (LIS). The LIS stores the location of each network element in the enterprise. Immediately after the Skype for Business client registration process or when the operating system detects a network connection change, each Skype for Business client submits a request to the LIS for a location. If the LIS is able to resolve a location address for the client request, it returns the address in a location response. Each client then caches this information. When the Skype for Business client dials 9-1-1, this location information is then included as part of the emergency call and used by the emergency service provider to route the call to the correct PSAP.

The gathering of location information in the Skype for Business network is illustrated in the figure below:



1. The Administrator provisions the LIS database with the location of each network element in the Enterprise. The location is a civic address, which can include contextual in-building and company information. In other words, it associates a specific network entity (for example, a WAP) with a physical location in the Enterprise (for example, Floor 2, Wing A, and the Enterprise's street address). For more information on populating the LIS database, see [Adding ELINs to the Location Information Server](#) on page 493.

2. The Administrator validates addresses with the emergency service provider's MSAG—a companion database to the ALI database. This ensures that the civic address is valid as an official address (e.g., correct address spelling).
3. The Skype for Business client initiates a location request to the LIS under the following circumstances:

- Immediately after startup and registering the user with Skype for Business
- Approximately every four hours after initial registration
- Whenever a network connection change is detected (such as roaming to a new WAP)

The Skype for Business client includes in its location request the following known network connectivity information:

- Always included:
  - ◆ IPv4 subnet
  - ◆ Media Access Control (MAC) address
- Depends on network connectivity:
  - ◆ Wireless access point (WAP) Basic Service Set Identifier (BSSID)
  - ◆ Link Layer Discovery Protocol-Media Endpoint Discovery (LLDP-MED) chassis ID and port ID

For a Skype for Business client that moves inside the corporate network such as a soft phone on a laptop that connects wirelessly to the corporate network, Skype for Business can determine which subnet the phone belongs to or which WAP / SSID is currently serving the soft-client.

4. The LIS queries the published locations for a location and if a match is found, returns the location information to the client. The matching order is as follows:
  - WAP BSSID
  - LLDP switch / port
  - LLDP switch
  - Subnet
  - MAC address

This logic ensures that for any client that is connected by a wireless connection, a match is first attempted based on the hardware address of its connected access point. The logic is for the match to be based on the most detailed location. The subnet generally provides the least detail. If no match is found in the LIS for WAP BSSID, LLDP switch / port, LLDP switch, or subnet, the LIS proxies the MAC address to an integrated Simple Network Management Protocol (SNMP) scanning application. Using SNMP may benefit some organizations for the following reasons:

- LLDP is not supported by Skype for Business so this provides a mechanism for soft phones to acquire detailed location information.
- Installed Layer-2 switches may not support LLDP.

If there is no match and the LIS cannot determine the location, the user may be prompted to manually enter the location. For example, the client may be located in an undefined subnet, at home, in a coffee shop or anywhere else outside the network. When a user manually provides a location, the location is mapped based on the MAC address of the default gateway of the client's network and stored on the client. When the client returns to any previously stored location, the client is automatically set to that location. A user can also manually select any location stored in the local users table and manage existing entries.

### Adding ELINs to the Location Information Server

As mentioned in the previous section, the administrator needs to populate the Location Information Server (LIS) database with a network wire map, which maps the company's network elements to civic addresses. Once done, it can automatically locate clients within a network. You can add addresses individually to the LIS or in a batch using a comma-separated value (CSV) file containing the column formats for the network elements, as listed below:

#### ■ **Wireless access point:**

<BSSID>,<Description>,<Location>,<**CompanyName**>,<HouseNumber>,<HouseNumberSuffix>,<PreDirectional>,<StreetName>,<StreetSuffix>,<PostDirectional>,<City>,<State>,<PostalCode>,<Country>

#### ■ **Subnet:** <Subnet>,<Description>,<Location>,<CompanyName>,<HouseNumber>,<HouseNumberSuffix>,<PreDirectional>,<StreetName>,<StreetSuffix>,<PostDirectional>,<City>,<State>,<PostalCode>,<Country>

#### ■ **Port:** <ChassisID>,<PortIDSubType>,<PortID>,<Description>,<Location>,<CompanyName>,<HouseNumber>,<HouseNumberSuffix>,<PreDirectional>,<StreetName>,<StreetSuffix>,<PostDirectional>,<City>,<State>,<PostalCode>,<Country>

#### ■ **Switch:** <ChassisID>,<Description>,<Location>,<CompanyName>,<HouseNumber>,<HouseNumberSuffix>,<PreDirectional>,<StreetName>,<StreetSuffix>,<PostDirectional>,<City>,<State>,<PostalCode>,<Country>

For the ELIN number to be included in the SIP INVITE (XML-based PIDF-LO message) sent by the Mediation Server to the ELIN device, the administrator must add the ELIN number to the <CompanyName> column (shown in the table above in bold typeface). As the ELIN device supports up to five ELINs per PIDF-LO, the <CompanyName> column can be populated with up to this number of ELINs, each separated by a semicolon. The digits of each ELIN can be separated by hyphens (xxx-xxx-xxx) or they can be adjacent (xxxxxxxxx). When the ELIN device receives the SIP INVITE message, it extracts the ELINs from the ELIN field in the PIDF-LO (e.g., <ca:ELIN>1111-222-333; 1234567890 </ca:ELIN>), which corresponds to the <CompanyName> column of the LIS.



For backward compatibility, if the ELIN field doesn't appear in the PIDF-LO, the device extracts the ELINs from the NAM field.

If you do not populate the location database and the Skype for Business location policy, and Location Required is set to **Yes** or **Disclaimer**, the user is prompted to enter a location manually.


### Passing Location Information to the PSTN Emergency Provider

When a Skype for Business client, enabled for E9-1-1 emergency services, dials 9-1-1, the location data and callback information stored on the client is sent with the call through the Mediation Server to a SIP Trunk-based or PSTN-based emergency service provider. The emergency service provider then routes the call to the nearest and most appropriate PSAP based on the location information contained within the call.

Skype for Business passes the location information of the Skype for Business client in an IETF-standard format - Presence Information Data Format - Location Object (PIDF-LO)—in a SIP INVITE message. However, this content cannot be sent on the SIP Trunk or PSTN since they do not support such a content. To overcome this, Enterprises deploying the device can divide their office space into Emergency Response Locations (ERLs) and assign a dedicated Emergency Location Identification Number (ELIN) to each ERL (or zone). When Skype for Business sends a SIP INVITE message with the PIDF-LO to the device, it can parse the content and translate the calling number to an appropriate ELIN. The device then sends the call to the SIP Trunk or PSTN with the ELIN number as the calling number. The ELIN number is sent to the emergency service provider, which sends it on to the appropriate PSAP according to the ELIN address match in the ALI database lookup.

The ERL defines a specific location at a street address, for example, the floor number of the building at that address. The geographical size of an ERL is according to local or national regulations (for example, less than 7000 square feet per ERL). Typically, you would have an ERL for each floor of the building. The ELIN is used as the phone number for 911 callers within this ERL.

The figure below illustrates the use of ERLs and ELINs, with an E9-1-1 call from floor 2 at the branch office:



The table below shows an example of designating ERLs to physical areas (floors) in a building and associating each ERL with a unique ELIN.

**Table 16-31: Designating ERLs and Assigning to ELINs**

ERL Number	Physical Area	IP Address	ELIN
1	Floor 1	10.13.124.xxx	503 972-4410
2	Floor 2	10.15.xxx.xxx	503 972-4411
3	Floor 3	10.18.xxx.xxx	503 972-4412


In the table above, a unique IP subnet is associated per ERL. This is useful if you implement different subnets between floors. Therefore, IP phones, for example, on a specific floor are in the same subnet and therefore, use the same ELIN when dialing 9-1-1.

## AudioCodes ELIN Device for Teams / Skype for Business E9-1-1 Calls to PSTN

Microsoft Mediation Server sends the location information of the E9-1-1 caller in the XML-based PIDF-LO body contained in the SIP INVITE message. However, this content cannot be sent on the SIP Trunk or PSTN since they do not support such content. To solve this issue, Skype for Business requires a ELIN SBC or Gateway to send the E9-1-1 call to the SIP Trunk or PSTN. When Skype for Business sends the PIDF-LO to the ELIN device, it parses the content and translates

the calling number to an appropriate ELIN. This ensures that the call is routed to an appropriate PSAP based on ELIN-address match lookup in the emergency service provider's ALI database.

The figure below illustrates an AudioCodes ELIN device deployed in the Skype for Business environment for handling E9-1-1 calls between the company and the emergency service provider.



## Detecting and Handling E9-1-1 Calls

The ELIN device identifies E9-1-1 calls and translates their incoming E9-1-1 calling numbers into ELIN numbers, which are sent to the PSAP. The device handles the received E9-1-1 calls as follows:

1. The device identifies E9-1-1 calls if the incoming SIP INVITE message contains a PIDF-LO XML message body. This is indicated in the SIP *Content-Type* header, as shown below:

```
Content-Type: application/pdf+xml
```

2. The device extracts the ELIN number(s) from the ELIN field in the XML message. The ELIN field corresponds to the <CompanyName> column in the Location Information Server (LIS). The device supports up to five ELIN numbers per XML message. The ELINs are separated by a semicolon. The digits of the ELIN number can be separated by hyphens (xxx-xxx-xxx) or they can be adjacent (xxxxxxxx), as shown below:

```
<ca:ELIN>1111-222-333; 1234567890 </ca:ELIN>
```





For backward compatibility, if the ELIN field doesn't appear in the PIDF-LO, the device extracts the ELINs from the NAM field.

3. The device saves the From header value of the SIP INVITE message in its ELIN database table ('Call From' field). The ELIN table is used for PSAP callback, as discussed later in [PSAP Callback for Dropped E9-1-1 Calls](#) on page 499. The ELIN table also stores the following information:

- **ELIN:** ELIN number
- **Time:** Time at which the original E9-1-1 call was terminated with the PSAP
- **Count:** Number of E9-1-1 calls currently using the ELIN

An example of the ELIN database table is shown below:

ELIN	Time	Count	Index	Call From
4257275678	22:11:52	0	2	4258359333
4257275999	22:11:57	0	3	4258359444
4257275615	22:12:03	0	0	4258359555
4257275616	22:11:45	0	1	4258359777

The ELIN table stores this information for a user-defined period (see [Configuring the E9-1-1 Callback Timeout](#) on page 502), starting from when the E9-1-1 call, established with the PSAP, terminates. After this time expires, the table entry with its ELIN is disregarded and no longer used (for PSAP callback). Therefore, table entries of only the most recently terminated E9-1-1 callers are considered in the ELIN table. The maximum entries in the ELIN table is 100.

4. The device uses the ELIN number as the E9-1-1 calling number and sends it in the SIP INVITE or ISDN Setup message (as an ANI / Calling Party Number) to the SIP Trunk or PSTN.

An example of a SIP INVITE message received from an E9-1-1 caller is shown below. The SIP Content-Type header indicating the PIDF-LO and the ELIN field listing the ELINs are shown in **bold** typeface.

```
INVITE sip:911;phone-context=Redmond@192.168.1.12;user=phone SIP/2.0
From: "voip_911_user1"<sip:voip_911_
user1@contoso.com>;epid=1D19090AED;tag=d04d65d924
To: <sip:911;phone-context=Redmond@192.168.1.12;user=phone>
CSeq: 8 INVITE
Call-ID: e6828be1-1cdd-4fb0-bdda-cda7faf46df4
VIA: SIP/2.0/TLS 192.168.0.244:57918;branch=z9hG4bK528b7ad7
CONTACT: <sip:voip_911_
```

```

user1@contoso.com;opaque=user:epid:R4bCDaUj51a06PUBkraS0QAA;gruu>;te
xt;audio;video;image
PRIORITY: emergency
CONTENT-TYPE: multipart/mixed; boundary= -----=_NextPart_000_4A6D_
01CAB3D6.7519F890
geolocation: <cid:voip_911_user1@contoso.com>;inserted-by="sip:voip_911_
user1@contoso .com"

```

**Message-Body:**

```

-----=_NextPart_000_4A6D_01CAB3D6.7519F890
Content-Type: application/sdp ; charset=utf-8
v=0
o=- 0 0 IN IP4 Client
s=session
c=IN IP4 Client
t=0 0
m=audio 30684 RTP/AVP 114 111 112 115 116 4 3 8 0 106 97
c=IN IP4 172.29.105.23
a=rtcp:60423
a=label:Audio
a=rtpmap:3 GSM/8000/1
a=rtpmap:101 telephone-event/8000
a=fmtp:101 0-16
a=rtpmap:0 PCMU/8000
a=rtpmap:8 PCMA/8000
aptime:20-----=_NextPart_000_4A6D_01CAB3D6.7519F890

```

**Content-Type: application/pidf+xml**

Content-ID: <voip\_911\_user1@contoso.com>

```
<?xml version="1.0" encoding="utf-8"?>
```

```

<presence xmlns="urn:ietf:params:xml:ns:pidf"
xmlns:gp="urn:ietf:params:xml:ns:pidf:geopriv10"
xmlns:bp="urn:ietf:params:xml:ns:pidf:geopriv10:basicPolicy"
xmlns:ca="urn:ietf:params:xml:ns:pidf:geopriv10:civicAddr"
xmlns:ms="urn:schema:Rtc.LIS.msftE911PidfExtn.2008" entity="sip:voip_911_
user1@contoso.com"><tuple id="0"><status><gp:geopriv><gp:location-
info><ca:civicAddress><ca:country>US</ca:country><ca:A1>WA</ca:A1><ca:A3
>Redmond</ca:A3><ca:RD>163rd</ca:RD><ca:STS>Ave</ca:STS><ca:POD>N
E</ca:POD><ca:HNO>3910</ca:HNO><ca:LOC>40/4451</ca:LOC>
<ca:ELIN>1111-222-333; 1234567890 </ca:ELIN>

```

```
<ca:PC>98052</ca:PC></ca:civicAddress></gp:location-info><gp:usage-
rules><bp:retransmission-allowed>true</bp:retransmission-allowed></gp:usage-
rules></gp:geopriv><ms:msftE911PidfExtn><ms:ConferenceUri>sip:+142555501
99@contoso.com;user=phone</ms:ConferenceUri><ms:ConferenceMode>twowa
y</ms:ConferenceMode><LocationPolicyTagID
xmlns="urn:schema:Rtc.Lis.LocationPolicyTagID.2008">user-
tagid</LocationPolicyTagID
></ms:msftE911PidfExtn></status><timestamp>1991-09-
22T13:37:31.03</timestamp></tuple></presence>
```

```
-----=_NextPart_000_4A6D_01CAB3D6.7519F890--
```

### Pre-empting Existing Calls for E9-1-1 Calls

If the ELIN device receives an E9-1-1 call from the IP network and there are unavailable channels (for example, all busy), the device immediately terminates one of the non-E9-1-1 calls (arbitrary) and accepts the E9-1-1 call on the freed-up channel:

- SBC application: Preemption is done only on a call belonging to the same source IP Group from which the E9-1-1 call is received, or the same destination IP Group (i.e., PSAP Server).
- Gateway application: Preemption is done only on a channel belonging to the same Trunk Group for which the E9-1-1 call was initially destined. For example, if an E9-1-1 call is destined for Trunk Group #2 and all the channels belonging to this group are busy, the device terminates one of the calls in this group to free a channel for accepting the E9-1-1 call.

This feature is initiated only if the received SIP INVITE message contains a Priority header set to "emergency", as shown below:

```
Priority: emergency
```

### PSAP Callback for Dropped E9-1-1 Calls

As the E9-1-1 service automatically provides all the contact information of the E9-1-1 caller to the PSAP, the PSAP operator can call back the E9-1-1 caller. This is especially useful in cases where the caller disconnects prematurely. However, as the Enterprise sends ELINs to the PSAP for E9-1-1 calls, a callback can only reach the original E9-1-1 caller using the device to translate the ELIN number back into the E9-1-1 caller's extension number.

In the ELIN table of the device, the temporarily stored *From* header value of the SIP INVITE message originally received from the E9-1-1 caller is used for PSAP callback. When the PSAP makes a callback to the E9-1-1 caller, the device translates the called number (i.e., ELIN) received from the PSAP to the corresponding E9-1-1 caller's extension number as matched in the ELIN table.

The handling of PSAP callbacks by the device is as follows:

1. When the device receives a call from the emergency service provider, it searches the ELIN table for an ELIN that corresponds to the received called party number in the incoming message.
2. If a match is found in the ELIN table, it routes the call to the Mediation Server by sending a SIP INVITE, where the values of the *To* and *Request-URI* are taken from the value of the original *From* header that is stored in the ELIN table (in the **Call From** column).
3. The device updates the 'Time' field in the ELIN table (the 'Count' field is not affected).

The PSAP callback can be done only within a user-defined period (see [Configuring the E9-1-1 Callback Timeout](#) on page 502), started from after the original E9-1-1 call, established with the PSAP is terminated. After this time expires, the table entry with its ELIN is disregarded and no longer used (for PSAP callback). Therefore, table entries of only the most recently terminated E9-1-1 callers are considered in the ELIN table. If the PSAP callback is done after this timeout expires, the device is unable to route the call to the E9-1-1 caller and instead, either sends it as a regular call or most likely, rejects it if there are no matching routing rules. However, if another E9-1-1 caller has subsequently been processed with the same ELIN number, the PSAP callback is routed to this new E9-1-1 caller.

In scenarios where the same ELIN number is used by multiple E9-1-1 callers, upon receipt of a PSAP callback, the device sends the call to the most recent E9-1-1 caller. For example, if the ELIN number "4257275678" is being used by three E9-1-1 callers, as shown in the table below, then when a PSAP callback is received, the device sends it to the E9-1-1 caller with phone number "4258359555".

**Table 16-32: Choosing Caller of ELIN**

ELIN	Time	Call From
4257275678	11:00	4258359333
4257275678	11:01	4258359444
4257275678	11:03	<b>4258359555</b>

### Selecting ELIN for Multiple Calls within Same ERL

The device supports the receipt of up to five ELIN numbers in the XML message of each incoming SIP INVITE message. As discussed in the preceding sections, the device sends the ELIN number as the E9-1-1 calling number to the emergency service provider. If the XML message contains more than one ELIN number, the device chooses the ELIN according to the following logic:

- If the first ELIN in the list is not being used by other active calls, it chooses this ELIN.
- If the first ELIN in the list is being used by another active call, the device skips to the next ELIN in the list, and so on until it finds an ELIN that is not being used and sends this ELIN.

- If all the ELINs in the list are in use by active calls, the device selects the ELIN number as follows:
  - a. The ELIN with the lowest count (i.e., lowest number of active calls currently using this ELIN).
  - b. If the count between ELINs is identical, the device selects the ELIN with the greatest amount of time passed since the original E9-1-1 call using this ELIN was terminated with the PSAP. For example, if E9-1-1 caller using ELIN 4257275678 was terminated at **11:01** and E9-1-1 caller using ELIN 4257275670 was terminated at **11:03**, then the device selects ELIN 4257275678.

In this scenario, multiple E9-1-1 calls are sent with the same ELIN.

### Location Based Emergency Routing

The device supports location-based emergency routing (E-911) in Teams / Skype for Business environments. This ensures that E-911 calls from remote branches are routed to emergency providers that are relevant to the geographical area in which the remote branch callers are physically located. To support this, the device enables routing and SIP header / number manipulation of such emergency calls based on the geographical location of the caller. The device manipulates the received destination number (i.e., 911) from the remote branch callers, into a destination number of an emergency provider that is relevant to the geographical area in which the remote branch office is located.

For an example on location-based emergency call routing, see [Configuring Location-Based Emergency Routing](#) on page 503.



Location-based emergency routing is applicable only to the Gateway application.

### Configuring AudioCodes ELIN Device

This section describes E9-1-1 configuration of the AudioCodes ELIN Gateway deployed in the Microsoft Teams / Skype for Business environment.

#### Enabling the E9-1-1 Feature

By default, the ELIN device feature for E9-1-1 emergency call handling in a Microsoft Teams / Skype for Business environment is disabled.

#### ➤ To enable ELIN feature for the SBC application:

- For the IP Group through which you want to communicate with the public-safety answering point (PSAP), configure the 'SBC PSAP Mode' parameter to **Enable**. For more information, see [Configuring IP Groups](#) on page 581.

➤ **To enable ELIN feature for the Gateway application:**

1. Open the Priority & Emergency page (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **Priority and Emergency**).
2. From the 'E911 Gateway' drop-down list (E911Gateway), select **NG911 Callback Gateway**.

E911 Gateway

NG911 Callback Gateway ▼

3. Click **Apply**.

### Configuring the E9-1-1 Callback Timeout

If the initial established call between the E9-1-1 caller and the PSAP is prematurely terminated, the PSAP can use the ELIN to call back the E9-1-1 caller within a user-defined time interval (in minutes) from when the call was terminated. By default, an ELIN can be used for PSAP callback within 30 minutes after the call terminates. You can change this to any value between 0 and 60. For more information on PSAP callback for dropped E9-1-1 calls, see [PSAP Callback for Dropped E9-1-1 Calls](#) on page 499.

➤ **To configure the E9-1-1 callback timeout**

1. Open the Priority & Emergency page (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **Priority and Emergency**).
2. In the 'E911 Callback Timeout' field (E911CallbackTimeout), enter the required callback timeout.

E911 Callback Timeout

30

3. Click **Apply**.

### Enabling SIP Release Cause Code Response for Failed E9-1-1 Calls

When a Teams client makes an emergency call, the call is routed through the Microsoft Mediation Server to the ELIN device, which sends it to the PSTN. In some scenarios, the call may not be established due to the destination (for example, busy or not found) or the ELIN device (for example, lack of resources or an internal error). In such a scenario, the Mediation Server requires that the ELIN device "reject" the call with a SIP release cause code 503 "Service Unavailable" (instead of the designated release call). Such a release cause code enables the Mediation Server to issue a failover to another entity (for example, another ELIN device), instead of retrying the call or returning the release call to the user.

To support this requirement, you can configure the ELIN device to send a 503 "Service Unavailable" release cause code instead of SIP 4xx if an emergency call cannot be established.



The feature is applicable only to the Gateway application and for digital interfaces.

➤ **To enable SIP response 503 upon failed E9-1-1:**

1. Open the Advanced Parameters page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Gateway Advanced Parameters**).
2. Select the 'Emergency Special Release Cause' check box [EmergencySpecialReleaseCause]:

Emergency Special Release Cause ☒

3. Click **Apply**.

### Configuring SBC IP-to-IP Routing Rule for E9-1-1

To route incoming Teams / Skype for Business E9-1-1 calls to the emergency service provider's PSAP server, you need to configure routing rules in the IP-to-IP Routing table for routing between the emergency callers' IP Group and the PSAP server's IP Group. The only special configuration is to define the emergency number (e.g., 911) in the 'Destination Username Pattern' parameter of the IP Group belonging to the E9-1-1 callers. The following example shows IP-to-IP routing rules for E9-1-1:

INDEX	NAME	ROUTING POLICY	ALTERNATIVE ROUTE OPTIONS	SOURCE IP GROUP	REQUEST TYPE	SOURCE USERNAME PREFIX	DESTINATION USERNAME PREFIX	DESTINATION TYPE	DESTINATION IP GROUP
0	E911 > PSAP	Default_SBCRou	Route Row	LAN IP PBX	All	*	911	IP Group	PSAP Server
1	PSAP > E911	Default_SBCRou	Route Row	PSAP Server	All	*	*	IP Group	LAN IP PBX



This feature is applicable only to the SBC application.

### Configuring Location-Based Emergency Routing

The device identifies the geographical location of emergency callers by their ELIN numbers, which is present in the PIDF-LO XML body of received SIP INVITE messages. Therefore, you need to configure the device to route emergency calls to a destination (i.e., emergency center such as the police) that is appropriate to the caller's ELIN number. As the destination of incoming calls is the emergency number (e.g., 999), the device needs to manipulate the destination number to a number that represents the caller's **local** emergency center (e.g., +4420999 for London police).



Location-based emergency routing is applicable only to the Gateway application.

To add manipulation rules for location-based emergency routing, you need to use the Destination Phone Number Manipulation for IP-to-Tel Calls table. In this table, you need to use the ELIN number (e.g., 5000) as the source prefix, with the "ELIN" string value added in front of it (e.g., ELIN5000) which is used by the device to identify the number as an ELIN number (and **not** used for any other routing processes etc.). For each corresponding ELIN source number prefix entry, you need to configure the manipulation action required on the destination number so that the call is routed to the appropriate destination.

Following is an example of how to configure location-based emergency routing:

#### ■ Assumptions:

- Company with offices in different cities -- London and Manchester.
- Each city has its local police department.
- In an emergency, users need to dial 999.
- Company employs Microsoft Skype for Business for communication between employers, and between employers and the external telephone network (PSTN). In other words, all employers are seemingly (virtual) in the same location in respect to the IP network.
- ELIN numbers are used to identify the geographical location of emergency calls dialed by users:
  - ◆ London ELIN is 5000.
  - ◆ Manchester ELIN is 3000.

#### ■ Configuration Objectives:

- Emergency calls received from London office users are routed by the device to the London police department (+4420999).
- Emergency calls received from Manchester office users are routed by the device to the Manchester police department (+44161999).

The international code, +44 for England is used for IP routing considerations, but can be omitted depending on your specific deployment.

The above scenario is configured as follows:

1. Enable location-based emergency routing, by loading an ini file to the device with the following parameter setting:
  - a. Open the Gateway Advanced Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Gateway Advanced Settings**).
  - b. From the 'E911 Gateway' drop-down list [E911Gateway], select **Location Based Manipulations**.



2. In the Destination Phone Number Manipulation for IP-to-Tel Calls table (see [Configuring Source-Destination Number Manipulation Rules](#) on page 950), add the following two rules for manipulating the destination number of incoming emergency calls, based on ELIN numbers:

INDEX	NAME	SOURCE IP ADDRESS	DESTINATION PREFIX	STRIPPED DIGITS FROM LEFT	STRIPPED DIGITS FROM RIGHT	NUMBER OF DIGITS TO LEAVE	PREFIX TO ADD
0	Emergency London	*	*	0	0	255	+4420
1	Emergency Manchester	*	*	0	0	255	+44161



Index 0 manipulates the destination number for London emergency callers; Index 1 manipulates the destination number for Manchester emergency callers.

### Viewing the ELIN Table

To view the ELIN table:

- CLI:

```
# show voip e911
ELIN      Time    Count Index Call From
-----
4257275678    22:11:52 0   2  4258359333
4257275999    22:11:57 0   3  4258359444
257275615     22:12:03 0   0  4258359555
4257275616    22:11:45 0   1  4258359777
----- Current Time: 22:12:40
```

- Syslog, by invoking the following Web command shell:

```
SIP / GateWay / E911Dump
```

## Microsoft Skype for Business Presence of Third-Party Endpoints

Microsoft presence capability allows Skype for Business users to know the status (e.g., "Available" or "Do Not Disturb") of their contacts. Presence status of contacts is displayed on the user's Skype for Business endpoint. Presence information of Skype for Business endpoints (such as Skype for Business desktop client) is handled solely by the Skype for Business Server, without any intervention of the device. However, when third-party (non-Skype for Business) endpoint devices (e.g., mobile phone or PBX phone) are used by the Skype for Business users, presence status information can only be reported to the Skype for Business Server by the device. For example, if John and Alice are Skype for Business users and John makes or receives a call on a mobile device, Alice is able to see that John is in a call, even though the call is not on a native Skype for Business endpoint. Once the device reports the presence status, the Skype for Business Server sends this status change to the Skype for Business users in the network.



- Currently, the device reports the following presence status:
  - ✓ "On the Phone" - user is busy (in a call or doesn't want to be disturbed)
  - ✓ "Clear" - cancels the "On the Phone" status (returning the user's presence to its previous state)
- The feature supports Skype for Business Server 2015 and Lync Server version 5.0.8308.866 and later.
- The feature is applicable to the SBC application and the Gateway application (Tel-to-IP calls only).
- This is a license-based feature and is available only if it is included in the License Key installed on the device. For ordering the feature, please contact the sales representative of your purchased device.

The device notifies the Skype for Business Server of a user's presence status, by using SIP PUBLISH messages. The message transactions between the device and Skype for Business Server is as follows:

1. The device routes a call between two Skype for Business users and when connected, sends a PUBLISH message with the Event header set to "presence", Expires header set to "600", Content-Type header set to "application/pidf+xml", and where the XML body's "activity" is set to "on-the-phone", as shown in the following example for user John Doe:

```
PUBLISH sip:john.doe@sfb.example SIP/2.0
From: <sip:john.doe@sfb.example>;tag=1c537837102
To: <sip:john.doe@sfb.example>
CSeq: 1 PUBLISH
Event: presence
Expires: 600
Content-Type: application/pidf+xml
Content-Length: 489
```

```
<?xml version="1.0" encoding="utf-8"?>
<presence xmlns="urn:ietf:params:xml:ns:pidf"
xmlns:ep="urn:ietf:params:xml:ns:pidf:status:rp-id-status"
xmlns:et="urn:ietf:params:xml:ns:pidf:rp-id-tuple"
xmlns:ci="urn:ietf:params:xml:ns:pidf:cipid"
entity="sip:john.doe@sfb.example">
  <tuple id="0">
    <status>
      <basic>open</basic>
      <ep:activities>
        <ep:activity>on-the-phone</ep:activity>
      </ep:activities>
    </status>
  </tuple>
```

```
<ci:display-name>John Doe</ci:display-name>
</presence>
```


2. The Skype for Business Server responds to the device with a SIP 200 OK. The message is sent with a SIP-ETag header which identifies the entity (and Expires header set to 600 seconds), as shown in the following example:

```
SIP/2.0 200 OK
From: "John Doe"<sip:john.doe@sfb.example>;tag=1c537837102
To:
<sip:john.doe@sfb.example>;tag=0E4324A4B27040E4A167108D4FAD27E3
Call-ID: 1284896643279201635736@10.33.221.57
CSeq: 1 PUBLISH
Via: SIP/2.0/TLS 10.33.221.57:5061;alias;...received=10.33.221.57;ms-
received port=48093;ms-received-cid=4900
SIP-ETag: 2545777538-1-1
Expires: 600
Content-Length: 0
```

3. If the call lasts longer than 600 seconds, the device sends another PUBLISH message with the same SIP-ETag value and with an Expires header value of 600 seconds. The Skype for Business Server responds with another 200 OK, but with a new SIP-ETag value (and Expires header set to 600 seconds). This scenario occurs for each 600-second call interval.
4. When the call ends, the device sends a PUBLISH message to cancel the user's online presence status (and the user's previous presence state is restored). The message is sent with a SIP-If-Match header set to the matching entity tag (SIP-ETag) value (i.e., SIP-ETag value of last 200 OK) and Expires header value set to "0", as shown in the following example:

```
PUBLISH sip:john.doe@sfb.example SIP/2.0
From: <sip:john.doe@sfb.example>;tag=1c1654434948
To: <sip:john.doe@sfb.example>
CSeq: 1 PUBLISH
Contact: <sip:john.doe@10.33.221.57:5061;transport=tls>
Event: presence
Expires: 0
User-Agent: sur1-vg1.ecarecenters.net/v.7.20A.001.080
SIP-If-Match: 2545777538-1-1
Content-Length: 0
```

The following figure shows a basic illustration of the device's integration into Microsoft Skype for Business Presence feature for third-party endpoints.



## Configuring Skype for Business Server for Presence

On the Skype for Business Server side, you need to define the device in the Skype for Business Topology as a Trusted Application.



- Detailed configuration of Skype for Business Server is beyond the scope of this document.
- Before performing the below procedure, make sure that you have defined the device in the PSTN Gateway node of the Skype for Business Server Topology (using the Topology Builder).

Using the Skype for Business Server Management Shell, perform the following steps:

### 1. Obtain the Site ID

Run the following cmdlet to retrieve the SiteId property of the site:

```
Get-CsSite
```

### 2. Create a Trusted Application Pool

Run the following cmdlet to create a new pool to host the presence application:

```
New-CsTrustedApplicationPool -Identity <Pool FQDN> -Registrar <Registrar FQDN> -Site <Site Id>
```

where:

- *Identity* is the FQDN of the device, which sends the SIP PUBLISH messages with the presence status to Skype for Business Server
- *Registrar* is the FQDN of the Registrar service for the pool
- *Site* is the Site Id

For example:

```
New-CsTrustedApplicationPool -Identity sbcgw.example.com -Registrar  
skypepool.example.com -Site Portland
```

### 3. Add the Trusted Application (Presence) to the Pool

```
New-CsTrustedApplication-ApplicationId <String> -  
TrustedApplicationPoolFqdn <String> -Port <Port Number>
```

where:

- *ApplicationId* is the name of the application
- *TrustedApplicationPoolFqdn* is the FQDN of the trusted application pool
- *Port* is the port number on which the application will run (5061)

For example:

```
New-CsTrustedApplication -ApplicationId MSpresence -  
TrustedApplicationPoolFqdn sbcgw.example.com -Port 5061
```

Make sure the port number matches the port number configured on the device.

### 4. Enable and Publish the Skype for Business Server 2015 Topology

Run the following cmdlet to publish and enable your new topology:

```
Enable-CsTopology
```

## Configuring the Device for Microsoft Teams Presence

The following procedure describes how to configure the device for notifying Teams of presence status of Teams users when making and receiving calls using third-party, endpoint devices. To help you understand the configuration, the following lists in chronological order the main processing steps:

1. The device receives an incoming call.
2. The device uses a Call Setup Rule to perform LDAP queries on Microsoft Entra ID to retrieve Teams usernames (Request URIs) for the corresponding calling (source) and/or called (destination) number. For SBC calls, the Call Setup Rule is associated with the classified

source IP Group (in the IP Groups table). For Tel-to-IP Gateway calls, the Call Setup Rule is associated with the destination IP Group (in the Tel-to-IP Routing table).

3. The device routes the call to the required destination, according to the normal routing rules.
4. When the call is connected, the device sends a SIP PUBLISH message to Teams server, indicating that the users' presence status is now "On-the-Phone".
5. When the call ends, the device sends another SIP PUBLISH message to the Teams server, clearing the users' "On-the-Phone" status (the presence status changes to what it was before the call was connected).

➤ **To configure device for Teams presence:**

1. Configure a TLS Context (TLS certificate) for secured communication (mutual authentication) between the device and Teams (see [Configuring TLS Certificate Contexts](#) on page 224).
2. Configure a Proxy Set to define the address of the Teams (see [Configuring Proxy Sets](#) on page 622). Make sure you configure the following:
  - 'TLS Context Name': Assign the TLS Context that you configured in Step 2 (above).
  - 'Proxy Address': Configure the address (FQDN or IP address).
  - 'Transport Type': **TLS**
3. Configure an IP Group to represent Teams server (see [Configuring IP Groups](#) on page 581). Make sure that you assign it with the Proxy Set that you configured in Step 3 (above).
4. Open the SIP Definitions General Settings page (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **SIP Definitions General Settings**):
  - a. From the 'Presence Publish IP Group ID' drop-down list, select the IP Group of the Teams server that you configured (above) as the destination (presence gateway) to where the device sends the SIP PUBLISH messages.
  - b. Select the 'Microsoft Presence Status' check box to enable the Microsoft presence feature.

**MICROSOFT PRESENCE**

Presence Publish IP Group ID	<div style="display: flex; align-items: center;"> <span style="margin-right: 5px;">•</span> <div style="border: 1px solid #ccc; padding: 2px 5px; display: flex; align-items: center;"> <span>#0 [Default_IPG]</span> <span style="font-size: 0.8em; margin-left: 5px;">▼</span> </div> </div>	<a href="#" style="color: #0070c0; text-decoration: none;">View</a>
Microsoft Presence Status	<div style="display: flex; align-items: center;"> <span style="margin-right: 5px;">•</span> <input checked="" type="checkbox"/> </div>	

5. Configure the Teams' LDAP server (Entra ID) to query for the Teams users' SIP URIs (see [Configuring LDAP Servers](#) on page 376).
6. Configure Call Setup Rules to perform LDAP queries in Microsoft Entra ID for the SIP URI of the caller (source) and called (destination) parties (see [Configuring Call Setup Rules](#) on

page 782). The device first needs to search Entra ID for the caller or called number of the third-party endpoint device. For example, to search for a called mobile number, the searched LDAP Attribute would be "mobile" set to the value of the destination number (e.g., 'mobile=+' + param.call.dst.user). If the entry exists, the query searches for the Attribute (e.g., ipPhone) where the SIP URI is defined for the corresponding mobile user. If found, the query returns the Attribute's value (i.e., URI) to the device (instructed using the special 'Condition' string "presence.dst" or "presence.src"). This is the URI that the device uses as the Request-URI in the PUBLISH message that it sends to the Teams server. The configuration of the example used in this step is shown below:

Parameter	Rule 1	Rule 2
'Request Type'	<b>LDAP</b>	<b>LDAP</b>
'Request Key'	'mobile=+' + param.call.dst.user	'mobile=+' + param.call.src.user
'Attributes To Get'	ipPhone	ipPhone
'Condition'	ldap.attr.ipPhone exists	ldap.attr.ipPhone exists
'Action Subject'	presence.dst	presence.src
'Action Type'	<b>Add</b>	<b>Add</b>
'Action Value'	ldap.attr.ipPhone	ldap.attr.ipPhone

7. Configure routing rules to route the calls in the network.
8. (SBC application) Configure IP Groups to represent your call party entities, and assign them the group of Call Setup Rules (Set ID) that you configured in Step 7 (above). For configuring IP Groups, see [Configuring IP Groups](#) on page 581.
9. (Gateway application) Assign the group of Call Setup Rules (Set ID) that you configured in Step 7 (above) to your Tel-to-IP Routing rules (see [Configuring Tel-to-IP Routing Rules](#) on page 914).

## Microsoft Teams with Local Media Optimization

The device can be configured to support the Local Media Optimization feature when deployed in a Microsoft Teams environment. This feature is intended for complex environments consisting of a central SBC device (i.e., this device that you are configuring), which is referred to by Microsoft as the *Proxy SBC*, integrated in the Teams environment, and multiple remote SBCs or Gateways (referred to by Microsoft as *remote site SBCs*). In this environment, the central SBC determines the optimal path for connecting calls between the Teams clients, based on network connectivity (good or bad) and voice quality. The device path selection is based on supplementary information provided by Microsoft using their proprietary headers that are included in the SIP messages during call setup between Teams clients:

Microsoft SIP Header	Value	Description
X-MS-UserLocation	Internal or External	Indicates if the Teams client is located in the internal or external network with respect to the central SBC. Based on the header value, the device selects the Media Realm, using the IP Group's 'Internal Media Realm' or 'Media Realm' parameters, respectively.
X-MS-MediaPath	sbc1.contoso.com sbc2.contoso.com ...	Indicates the order of remote SBCs that should be used for the media path between the Teams clients. If the first address is the central SBC itself, the media traverses the device (non-direct media).
X-MS-UserSite	usersiteID	Indicates the name of the Teams site in which the Teams client is located.

Configuration of the device for Local Media Optimization is done on the IP Group of the Teams client, using the following IP Group table parameters:

- 'Teams Local Media Optimization Handling': Enables Local Media Optimization and defines how the device handles the Teams call based on the Microsoft proprietary SIP headers.
- 'Internal Media Realm': Assigns a Media Realm which is used if the X-MS-UserLocation header value is "Internal". If the header value is "External" (or not present), the Media Realm assigned by the 'Media Realm' parameter is used.
- 'Teams Local Media Optimization Initial Behavior': Defines how the central SBC device initially sends the received INVITE message with the SDP Offer to Teams.
- 'Teams Local Media Optimization Site' : Defines the name of the Teams site (e.g., "Singapore") to which the IP Group (Teams client) belongs. The Teams site is indicated in the SIP header, X-MS-UserSite of the incoming SIP message received from the Teams client. The device searches the Dial Plan, specified by the 'Regions Connectivity Dial Plan' parameter, to check if this IP Group's Teams site and the Teams site of the destination IP Group share a common group number. If they do share a group number, the device processes the call as a direct media (bypass) call. For more information, see [Using Dial Plans for Microsoft Local Media Optimization](#) on page 825.

For more information on the above parameters, see their descriptions in [Configuring IP Groups](#) on page 581.

For detailed technical information on deploying the device in a Microsoft Teams environment with Local Media Optimization, contact your AudioCodes sales representative.





- For detailed configuration of Microsoft Teams Direct Routing for enterprises with AudioCodes SBC, refer to [Connecting AudioCodes' SBC to Microsoft Teams Direct Routing Enterprise Model](#).
- This section is applicable only to the SBC application.

## 17 Quality of Experience

This chapter describes how to configure the Quality of Experience feature.

### Reporting Voice Quality of Experience to OVOC

The device can be configured to report voice (media) Quality of Experience (QoE) to AudioCodes' One Voice Operations Center (OVOC). The reports include real-time metrics of the quality of the call experience, which are then processed by OVOC.

OVOC is also a VoIP-quality monitoring and analysis tool. It provides comprehensive details on voice traffic quality, allowing system administrators to quickly identify, fix and prevent issues that could affect the voice calling experience in enterprise and service provider VoIP networks. IT and administrators can employ OVOC in their VoIP networks to guarantee effective utilization, smooth performance, reliable QoS levels, and SLA fulfillment.



- For information on OVOC, refer to the *OVOC User's Manual*.
- For configuring the SNMP connection between the device and OVOC, see [Configuring SNMP for OVOC Connectivity](#) on page 121.

### Reporting QoE to OVOC

The Quality of Experience Settings table lets you configure the address (and other connectivity parameters) of AudioCodes One Voice Operations Center (OVOC) server to where the device sends Quality of Experience (QoE) voice metric reports.

You can also configure the device to use a TLS connection with OVOC. Before you can do this, configure a TLS Context (certificate) in the TLS Contexts table (see [Configuring TLS Certificate Contexts](#) on page 224). If no TLS Context is specified, the device uses the default TLS Context (ID 0). You can also configure at what stage of the call the device sends the QoE report to OVOC. The report can be sent during the call or only at the end of the call. Reporting at the end of the call may be beneficial when there is network congestion as this reduces bandwidth usage over time.

You can configure at what stage (during or end) of the call to send the QoE report. You can also enable the filtering of the report, and then use the Logging Filters table to configure the actual filter (e.g., by a specific IP Group).



If a QoE traffic overflow occurs between OVOC and the device, the device sends the QoE data only at the end of the call, regardless of your settings.

The following procedure describes how to configure the OVOC server for QoE through the Web interface. You can also configure it through ini file [QOESettings] or CLI (`configure voip > qoe qoe-settings`).

➤ **To configure OVOC for QoE:**

1. Open the Quality of Experience Settings table (**Setup** menu > **Signaling & Media** tab > **Media** folder > **Quality of Experience** > **Quality of Experience Settings**).

2. Configure the OVOC server according to the parameters described in the table below.
3. Click **Apply**, and then restart the device with a save-to-flash for your settings to take effect.

**Table 17-1: Quality of Experience Settings Parameter Descriptions**

Parameter	Description
<b>General</b>	
'Index' tls [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Primary OVOC Address' server-name [ServerName]	Defines the address of the OVOC server to where the device sends the QoE reports. The valid value is an IP address (IPv4 or IPv6) or an FQDN (hostname). <b>Note:</b> <ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> <li>■ The IP address version (IPv4 or IPv6) of the OVOC address and the IP Interface (see 'QoE Network Interface' parameter below) must be the same.</li> <li>■ If you are using a WebSocket tunnel connection between the device and OVOC, then configure the parameter to the IP address mentioned in <a href="#">Configuring WebSocket Tunnel with OVOC</a> on page 122.</li> </ul>
'Secondary OVOC Address'	<b>Note:</b> This parameter is currently not supported and

Parameter	Description
secondary-server-name [SecondaryServerName]	therefore, can be ignored.
'QoE Network Interface' interface [Interface]	<p>Assigns an IP network interface (IPv4 or IPv6) from which the device sends the QoE reports.</p> <p>The default is the IPv4 OAMP interface (<b>O+M+C</b>).</p> <p>To configure IP network interfaces, see <a href="#">Configuring IP Network Interfaces</a> on page 157.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> <li>■ The IP address version (IPv4 or IPv6) of the IP Interface and the OVOC address (see 'Primary OVOC Address' field above) must be the same.</li> </ul>
'Keep Alive Time Interval' keep-alive-time [KeepAliveTime]	<p>Defines the interval (in seconds) between every consecutive keep-alive message that the device sends to the OVOC server. Keep-alive messages can be useful to keep the communication link between the device and OVOC open when there is no other traffic flow between them.</p> <p>The default is 1. A value of 0 disables the keep-alive feature.</p>
<b>TLS</b>	
'Use TLS' tls [EnableTls]	<p>Enables a TLS connection with the OVOC server.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul>
'TLS Context' tls-context-name [ContextName]	<p>Assigns a TLS Context (certificate) for the TLS connection with the OVOC server.</p> <p>The default is the default TLS Context (ID 0).</p> <p><b>Note:</b> The parameter is applicable only if the 'Use TLS' parameter is configured to <b>Enable</b>.</p>
'Verify Certificate' verify-certificate [VerifyCertificate]	<p>Enables the verification of the TLS certificate that is used in the incoming connection request from the OVOC server.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) No certificate verification is done.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [1] <b>Enable</b> = The device verifies the authentication of the certificate received from the OVOC server. The device authenticates the certificate against the trusted root certificate store associated with the assigned TLS Context and if ok, allows communication with OVOC. If authentication fails, the device denies communication (i.e., handshake fails). The device can also authenticate the certificate by querying with an Online Certificate Status Protocol (OCSP) server whether the certificate has been revoked. This is configured for the assigned TLS Context.</li> </ul> <p><b>Note:</b> The parameter is applicable only if the 'Use TLS' parameter is configured to <b>Enable</b>.</p>
'Verify Certificate Subject Name' verify-certificate-subject-name [VerifyCertificateSubjectName]	<p>Enables the verification of the TLS certificate subject name (Common Name / CN or Subject Alternative Name / SAN) that is used in the incoming connection request from the OVOC server.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) No verification is done.</li> <li>■ [1] <b>Enable</b> = The device verifies the subject name of the certificate received from the OVOC server with the hostname or IP address configured for OVOC (in the 'Primary OVOC Address' above). If authentication fails, the device denies communication (i.e., handshake fails).</li> </ul> <p><b>Note:</b> The parameter is applicable only if the 'Use TLS' parameter is configured to <b>Enable</b>.</p>
<b>QoE Report</b>	
'QoE Report Mode' report-mode [ReportMode]	<p>Defines at what stage of the call the device sends the call's QoE data to the OVOC server.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Report QoE During Call</b> (default)</li> <li>■ [1] <b>Report QoE at End of Call</b></li> </ul> <p><b>Note:</b> If a QoE traffic overflow between OVOC and the device occurs, the device sends the QoE data only at the end of the call, regardless of the parameter's settings.</p>

Parameter	Description
'Filter Reports' filter-reports [FilterReports]	<p>Enables the filtering (e.g., by IP Group #2) of the QoE reports that the device sends to OVOC.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p>Log filtering is configured in the Logging Filters table (see <a href="#">Configuring Logging Filter Rules</a> on page 1470). When configuring a rule for QoE filtering, make sure that it also includes the following settings:</p> <ul style="list-style-type: none"> <li>■ 'Log Destination': <b>OVOC (QoE)</b></li> <li>■ 'Log Type': <b>CDR</b></li> </ul>

## Configuring Clock Synchronization between Device and OVOC

To ensure accurate call quality statistics and analysis by OVOC, you must configure the device and the OVOC server with the same clock source for clock synchronization. In other words, you need to configure them with the same NTP server (same address).

The NTP server can be one of the following:

- OVOC server (also acting as an NTP server)
- Third-party, external NTP server

To configure, the NTP server's address on the device, see [Synchronizing Date and Time through SNTP](#) on page 137.

## Configuring Firewall Rules for OVOC Traffic

To allow incoming traffic from OVOC, you need to configure the device's firewall (Firewall table) with additional "Allow" firewall rules, as described in [Configuring Firewall Rules to Allow Incoming OVOC Traffic](#) on page 256.

## Enabling RTCP XR Reporting to OVOC

For the device to be able to send voice metric reports to AudioCodes OVOC, you need to enable the RTP Control Protocol Extended Reports (RTCP XR) VoIP management protocol. RTCP XR defines a set of voice metrics that contain information for assessing VoIP call quality and diagnosing problems. Enabling RTCP XR means that the device can send RTCP XR messages, containing the call-quality metrics, to OVOC.

For enabling RTCP XR reporting, see [Configuring RTCP XR](#) on page 1374. To configure what to report to OVOC, see [Configuring Quality of Experience Profiles](#) on the next page.

## Configuring Interval for QoE Report Collection and Generation

By default, the device generates QoE reports based on 30-second collection intervals of voice metrics obtained from RTCP / RTCP-XR packets. However, as packets are typically sent and received every 5 seconds, the QoE report reflects an average of these multiple packet sampling intervals (i.e., typically 6 collection intervals). Therefore, you might want to shorten the device's QoE collection and generation interval to get the following benefits:

- More reports generated for the call.
- Faster initial reports - first report is available soon after the call starts, providing valuable insights even for short calls.
- Capturing subtle changes in call quality throughout the call.

To configure the QoE collection and generation interval, see the [\[\[QoEMediaStatisticTimer\]](#) on page 1766] ini file parameter.

## Configuring Quality of Experience Profiles

Quality of Experience Profiles enable you to effectively monitor the quality of voice calls traversing the device in your network. Quality of Experience Profiles define severity thresholds for voice metrics monitored by the device, which if crossed can result in various actions (discussed later in the section).

Quality of Experience is configured using two tables with parent-child relationship. The Quality of Experience Profile table is the parent, which defines the name of the Quality of Experience Profile. The Quality of Experience Color Rules table is the child, which defines severity thresholds per voice metric for the specific Quality of Experience Profile. You can configure up to 256 Quality of Experience Profiles and up to 256 Quality of Experience Color Rules.

Once configured, you can apply the Quality of Experience Profiles to specific calls (network links), by assigning them to any of the following configuration entities:

- IP Groups (see [Configuring IP Groups](#) on page 581)
- Media Realms (see [Configuring Media Realms](#) on page 539)
- Remote Media Subnets (see [Configuring Remote Media Subnets](#) on page 543)

The Quality of Experience Profile allows you to configure thresholds for the following monitored voice metrics:

- **Mean Opinion Score (MOS):** MOS is the average grade on a quality scale, expressed as a single number in the range of 1 to 5, where 1 is the lowest audio quality and 5 the highest audio quality.
- **Delay (or latency):** Time it takes for information to travel from source to destination (round-trip time).
- **Packet Loss:** Lost packets are RTP packets that are not received by the voice endpoint. Packet loss can result in choppy voice transmission.

- **Jitter:** Jitter can result from uneven delays between received voice packets. To space evenly, the device's jitter buffer adds delay. The higher the measurement, the greater the impact of the jitter buffer's delay on audio quality.
- **Residual Echo Return Loss (RERL):** An echo is a reflection of sound arriving at the listener at some time after the sound was initiated (often by the listener). Echo is typically caused by delay.

At any given time during a call, a voice metric can be in one of the following color-coded quality states (as displayed in OVOC):


- **Green:** Indicates good call quality
- **Yellow:** Indicates fair call quality
- **Red:** Indicates poor call quality

When the threshold of a voice metric is crossed, the device changes the alarm severity and corresponding color-coded quality state of the call:

- **Minor Threshold (Yellow):** Lower threshold that indicates changes from Green or Red to Yellow.
- **Major Threshold (Red):** Higher threshold that indicates changes from Green or Yellow to Red.

The device also uses hysteresis to determine whether the threshold has indeed been crossed. Hysteresis defines the amount of fluctuation from the threshold in order for the threshold to be considered as crossed (i.e., change in color state). Hysteresis is used to avoid false reports being sent by the device. Hysteresis is used only for threshold crossings toward a lesser severity (i.e., from Red to Yellow, Red to Green, or Yellow to Green).

The following example is used to explain how the device considers threshold crossings. The example is based on the MOS of a call, where the Major threshold is configured to 2, the Minor threshold to 4 and the hysteresis for both thresholds to 0.1:





**Table 17-2: Threshold Crossings based on Threshold and Hysteresis**

Threshold Crossing	Calculation	Threshold based on Example
Green to Yellow (Minor alarm)	The change occurs if the measured metric crosses the configured Minor threshold only (i.e., hysteresis is not used).	4
Green to Red (Major alarm)	The change occurs if the measured metric crosses the configured Major threshold only (i.e., hysteresis is not used).	2
Yellow to Red (Major alarm)	The change occurs if the measured metric crosses the configured Major threshold only (i.e., hysteresis is not used).	2
Red to Yellow (Minor alarm)	The change occurs if the measured metric crosses the configured Major threshold with hysteresis configured for the Major threshold.	2.1 (i.e., 2 + 0.1)
Red to Green (alarm cleared)	The change occurs if the measured metric crosses the configured Minor threshold with hysteresis configured for the Minor threshold.	4.1 (i.e., 4 + 0.1)
Yellow to Green (alarm cleared)	The change occurs if the measured metric crosses the configured Minor threshold with hysteresis configured for the Minor threshold.	4.1 (i.e., 4 + 0.1)

Each time a voice metric threshold is crossed (i.e., color changes), the device can do the following depending on configuration:

- Report the change in the measured metrics to AudioCodes' OVOC. OVOC displays this call quality status for the associated link (IP Group, Media Realm, or Remote Media Subnet). To configure the OVOC's address, see [Reporting QoE to OVOC](#) on page 514.
- Depending on the crossed threshold type, you can configure the device to reject calls to the destination IP Group or use an alternative IP Profile for the IP Group. For more information, see [Configuring Quality of Service Rules](#) on page 531.
- Alternative routing based on measured metrics. If a call is rejected because of a crossed threshold, the device generates a SIP 806 response. You can configure this SIP response

code as a reason for alternative routing (see [Configuring SIP Response Codes for Alternative Routing Reasons](#) on page 1104).



For your convenience, the device provides pre-configured Quality of Experience Profiles. One of these pre-configured profiles is the default Quality of Experience Profile, which is used if you do not configure a Quality of Experience Profile.

The following procedure describes how to configure Quality of Experience Profiles through the Web interface. You can also configure it through other management platforms:

- **Quality of Experience Profile table:** *ini* file [QoEProfile] or CLI (`configure voip > qoe qoe-profile`)
- **Quality of Experience Color Rules table:** *ini* file [QOECOLORRules] or CLI (`configure voip > qoe qoe-color-rules`)

➤ **To configure a QoE Profile:**

1. Open the Quality of Experience Profile table (**Setup** menu > **Signaling & Media** tab > **Media** folder > **Quality of Experience** > **Quality of Experience Profile**).
2. Click **New**; the following dialog box appears:

3. Configure a QoE Profile according to the parameters described in the table below.
4. Click **Apply**.

**Table 17-3: Quality of Experience Profile Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Profile Name' name [Name]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 20 characters.

Parameter	Description
	<b>Note:</b> The parameter value cannot contain a forward slash (/).
'Sensitivity Level' sensitivity-level [SensitivityLevel]	<p>Defines the pre-configured threshold profile to use.</p> <ul style="list-style-type: none"> <li>■ [0] <b>User Defined</b> = Need to define thresholds per monitored parameter in the Quality of Experience Color Rules table.</li> <li>■ [1] <b>Low</b> = Pre-configured low sensitivity thresholds.</li> <li>■ [2] <b>Medium</b> = (Default) Pre-configured medium sensitivity thresholds.</li> <li>■ [3] <b>High</b> = Pre-configured high sensitivity thresholds. Reporting is done for small fluctuations in parameter values.</li> </ul>

- In the Quality of Experience Profile table, select the row for which you want to configure QoE thresholds, and then click the **Quality of Experience Color Rules** link located below the table; the Quality of Experience Color Rules table appears.
- Click **New**; the following dialog box appears:

- Configure a rule according to the parameters described in the table below.
- Click **New**, and then save your settings to flash memory.

**Table 17-4: Quality of Experience Color Rules Table Parameter Descriptions**

Parameter	Description
<b>General</b>	
'Index' index [QOECOLORRules_ ColorRuleIndex]	<p>Defines an index number for the new table row.</p> <p><b>Note:</b> Each row must be configured with a unique index.</p>
'Monitored Parameter'	Defines the parameter to monitor and report.

Parameter	Description
monitored-parameter [QOECOLORRules_monitoredParam]	<ul style="list-style-type: none"> <li>■ [0] <b>MOS</b> (default)</li> <li>■ [1] <b>Delay</b></li> <li>■ [2] <b>Packet Loss</b></li> <li>■ [3] <b>Jitter</b></li> <li>■ [4] <b>RERL [Echo]</b></li> </ul>
'Direction' direction [QOECOLORRules_direction]	<p>Defines the monitoring direction.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Device Side</b> (default)</li> <li>■ [1] <b>Remote Side</b></li> </ul>
'Sensitivity Level' sensitivity-level [QOECOLORRules_profile]	<p>Defines the sensitivity level of the thresholds.</p> <ul style="list-style-type: none"> <li>■ [0] <b>User Defined</b> = Need to define the thresholds in the parameters described below.</li> <li>■ [1] <b>Low</b> = Pre-configured low sensitivity threshold values. Thus, reporting is done only if changes in parameters' values are significant.</li> <li>■ [2] <b>Medium</b> = (Default) Pre-configured medium sensitivity threshold values.</li> <li>■ [3] <b>High</b> = Pre-configured high sensitivity threshold values. Thus, reporting is done for small fluctuations in parameter values.</li> </ul>
Thresholds	
'Minor Threshold (Yellow)' minor-threshold-yellow [QOECOLORRules_MinorThreshold]	<p>Defines the Minor threshold value, which is the lower threshold located between the Yellow and Green states. To consider a threshold crossing:</p> <ul style="list-style-type: none"> <li>■ <b>Increase in severity (i.e., Green to Yellow):</b> Only this value is used.</li> <li>■ <b>Decrease in severity (Red to Green, or Yellow to Green):</b> This value is used with the hysteresis, configured by the 'Minor Hysteresis (Yellow)' parameter (see below).</li> </ul> <p>The valid threshold values are as follows:</p> <ul style="list-style-type: none"> <li>■ MOS values are in multiples of 10. For example, to denote a MOS of 3.2, the value 32 (i.e., 3.2*10) must be entered.</li> <li>■ Delay values are in msec.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ Packet Loss values are in percentage (%).</li> <li>■ Jitter is in msec.</li> <li>■ Echo measures the Residual Echo Return Loss (RERL) in dB.</li> </ul>
'Minor Hysteresis (Yellow)' minor-hysteresis-yellow [QOECOLORRules_MinorHysteresis]	<p>Defines the amount of fluctuation (hysteresis) from the Minor threshold, configured by the 'Minor Threshold (Yellow)' parameter in order for the threshold to be considered as crossed. The hysteresis is used only to determine threshold crossings to Green (i.e., from Yellow to Green, or Red to Green). In other words, the device considers a threshold crossing to Green only if the measured voice metric crosses the Minor threshold and the hysteresis.</p> <p>For example, if you configure the 'Minor Threshold (Yellow)' parameter to 4 and the 'Minor Hysteresis (Yellow)' parameter to 0.1 (for MOS), the device considers a threshold crossing to Green only if the MOS crosses 4.1 (i.e., <math>4 + 0.1</math>).</p>
'Major Threshold (Red)' major-threshold-red [QOECOLORRules_MajorThreshold]	<p>Defines the Major threshold value, which is the upper threshold located between the Yellow and Red states. To consider a threshold crossing:</p> <ul style="list-style-type: none"> <li>■ <b>Increase in severity (i.e., Yellow to Red):</b> Only this value is used.</li> <li>■ <b>Decrease in severity (Red to Yellow):</b> This value is used with the hysteresis, configured by the 'Major Hysteresis (Red)' parameter (see below).</li> </ul> <p>The valid threshold values are as follows:</p> <ul style="list-style-type: none"> <li>■ MOS values are in multiples of 10. For example, to denote a MOS of 3.2, the value 32 (i.e., <math>3.2 \times 10</math>) must be entered.</li> <li>■ Delay values are in msec.</li> <li>■ Packet Loss values are in percentage (%).</li> <li>■ Jitter is in msec.</li> <li>■ Echo measures the Residual Echo Return Loss (RERL) in dB.</li> </ul>
'Major Hysteresis (Red)' major-hysteresis-red [QOECOLORRules_MajorHysteresis]	<p>Defines the amount of fluctuation (hysteresis) from the Major threshold, configured by the 'Major Threshold (Red)' parameter in order for the threshold to be considered as crossed. The hysteresis is used only to determine threshold crossings from Red to Yellow. In other words, the device considers a threshold crossing to Yellow only if the measured voice metric crosses the</p>

Parameter	Description
	<p>Major threshold and the hysteresis.</p> <p>For example, if you configure the 'Major Threshold (Red)' parameter to 2 and the 'Major Hysteresis (Red)' parameter to 0.1 (for MOS), the device considers a threshold crossing to Yellow only if the MOS crosses 2.1 (i.e., 2 + 0.1).</p>

## Configuring Bandwidth Profiles

The Bandwidth Profile table lets you configure up to 486 Bandwidth Profiles. A Bandwidth Profile defines bandwidth utilization thresholds for audio and video traffic (incoming and outgoing), which if crossed can result in various actions (discussed later in the section). Bandwidth Profiles enhance the device's monitoring of bandwidth utilization.

Once configured, you can apply Bandwidth Profiles to specific calls, by assigning them to any of the following configuration entities:

- IP Groups (see [Configuring IP Groups](#) on page 581)
- Media Realms (see [Configuring Media Realms](#) on page 539)
- Remote Media Subnets (see [Configuring Remote Media Subnets](#) on page 543)

Each time a configured bandwidth threshold is crossed, the device can do the following, depending on configuration:

- Reject calls destined to the IP Group or use an alternative IP Profile for the IP Group. For more information, see [Configuring Quality of Service Rules](#) on page 531.
- Use an alternative routing rule for alternative routing. If a call is rejected due to a crossed threshold, the device generates a SIP 806 response. You can configure the SIP response code as a reason for alternative routing (see [Configuring SIP Response Codes for Alternative Routing Reasons](#) on page 1104).
- Send an SNMP alarm (acMediaRealmBWThresholdAlarm). The device clears the alarm when bandwidth utilization returns to normal (Green).

AudioCodes One Voice Operations Center (OVOC) displays bandwidth utilization using color-coded states:


- **Green:** Indicates bandwidth utilization is within normal range.
- **Yellow:** Indicates bandwidth utilization is encroaching on "total" bandwidth, serving as a warning (or it could also mean that bandwidth utilization has dropped below the red state).
- **Red:** Indicates that bandwidth utilization has exceeded total bandwidth.

Bandwidth Profiles let you configure bandwidth thresholds, which when crossed changes the color-coded state for bandwidth utilization:

- **Green-Yellow (Minor) Threshold:** Lower threshold configured as a percentage of the configured major (total) bandwidth threshold. When bandwidth goes over the threshold, the device considers it a Yellow state (Minor alarm severity); when it goes below the threshold, it considers it a Green state (cleared alarm).
- **Yellow-Red (Major) Threshold:** Upper threshold configured by the major (total) bandwidth threshold. When bandwidth goes over the threshold, the device considers it a Red state (Major alarm severity); when it goes below the threshold, it considers it a Yellow state (Minor alarm severity).

The device also uses hysteresis to determine whether the threshold has indeed being crossed. Hysteresis defines the amount of fluctuation from the threshold in order for the threshold to be considered as crossed (i.e., change in color state). Hysteresis is used to avoid false reports being sent by the device. Hysteresis is used only for threshold crossings toward a lesser severity (i.e., from Red to Yellow, Red to Green, or Yellow to Green). Hysteresis is configured as a percentage of the configured major (total) bandwidth threshold.

The following example is used to explain how the device considers threshold crossings. The example is based on a setup where the Major (total) bandwidth threshold is configured to 64,000 Kbps, the Minor threshold to 50% (of the total) and the hysteresis to 10% (of the total):



**Table 17-5: Threshold Crossings based on Threshold and Hysteresis**

Threshold Crossing	Calculation	Threshold based on Example
Green to Yellow (Minor alarm)	The change occurs if the current bandwidth crosses the configured Minor threshold only (i.e., hysteresis is not used).	32,000 Kbps
Green to Red (Major alarm)	The change occurs if the current bandwidth crosses the configured Major threshold only (i.e., hysteresis is not used).	64,000 Kbps
Yellow to Red (Major alarm)	The change occurs if the current bandwidth crosses the	64,000 Kbps

Threshold Crossing	Calculation	Threshold based on Example
	configured Major threshold only (i.e., hysteresis is not used).	
Red to Yellow (Minor alarm)	The change occurs if the current bandwidth crosses the configured Major threshold with hysteresis.	57,600 Kbps [64,000 - (10% x 64,000)]
Yellow to Green (alarm cleared)	The change occurs if the current bandwidth crosses the configured Minor threshold with hysteresis.	25,600 Kbps [32,000 - (10% x 64,000)]
Red to Green (alarm cleared)	The change occurs if the current bandwidth crosses the configured Minor threshold with hysteresis.	25,600 Kbps [32,000 - (10% x 64,000)]

The following procedure describes how to configure Bandwidth Profiles through the Web interface. You can also configure it through ini file [BWProfile] or CLI (`configure voip > qoe bw-profile`).

➤ **To configure a Bandwidth Profile:**

1. Open the Bandwidth Profile table (**Setup** menu > **Signaling & Media** tab > **Media** folder > **Quality of Experience** > **Bandwidth Profile**).
2. Click **New**; the following dialog box appears:

The screenshot shows a 'Bandwidth Profile' configuration window. It is divided into two main sections: 'GENERAL' and 'THRESHOLDS'.  
 In the 'GENERAL' section, there are input fields for:  
 - Index: 0  
 - Name: (empty)  
 - Egress Audio Bandwidth [Kbps]: (empty)  
 - Ingress Audio Bandwidth [Kbps]: (empty)  
 - Egress Video Bandwidth [Kbps]: (empty)  
 - Ingress Video Bandwidth [Kbps]: (empty)  
 - Total Egress Bandwidth [Kbps]: (empty)  
 - Total Ingress Bandwidth [Kbps]: (empty)  
 In the 'THRESHOLDS' section, there are:  
 - A 'Minor Threshold [%]' field set to 70.  
 - A 'Hysteresis [%]' field set to 5.  
 - A 'Generate Alarm' dropdown menu set to 'Disable'.

3. Configure a rule according to the parameters described in the table below.
4. Click **Apply**, and then restart the device with a save to flash memory.



**Table 17-6: Bandwidth Profile Table Parameter Descriptions**

Parameter	Description
<b>General</b>	
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [Name]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 20 characters. <b>Note:</b> The parameter value cannot contain a forward slash (/).
'Egress Audio Bandwidth' egress-audio-bandwidth [EgressAudioBandwidth]	Defines the major (total) threshold for outgoing audio traffic (in Kbps).
'Ingress Audio Bandwidth' ingress-audio-bandwidth [IngressAudioBandwidth]	Defines the major (total) threshold for incoming audio traffic (in Kbps).
'Egress Video Bandwidth' egress-video-bandwidth [EgressVideoBandwidth]	Defines the major (total) threshold for outgoing video traffic (in Kbps).
'Ingress Video Bandwidth' ingress-video-bandwidth [IngressVideoBandwidth]	Defines the major (total) threshold for incoming video traffic (in Kbps).
'Total Egress Bandwidth' total-egress-bandwidth [TotalEgressBandwidth]	Defines the major (total) threshold for video and audio outgoing bandwidth (in Kbps).
'Total Ingress Bandwidth' total-ingress-bandwidth [TotalIngressBandwidth]	Defines the major (total) threshold for video and audio incoming bandwidth (in Kbps).

Parameter	Description
<b>Thresholds</b>	
'Minor Threshold' minor-threshold [MinorThreshold]	<p>Defines the Minor threshold value, which is the lower threshold located between the Yellow and Green states. The parameter is configured as a percentage of the major (total) bandwidth threshold (configured by the above bandwidth parameters). For example, if you configure the parameter to 50 and the 'Egress Audio Bandwidth' parameter to 64,000, the Minor threshold for outgoing audio bandwidth is 32,000 (i.e., 50% of 64,000).</p> <p>To consider a threshold crossing:</p> <ul style="list-style-type: none"> <li>■ <b>Increase in severity (i.e., Green to Yellow):</b> Only this value is used.</li> <li>■ <b>Decrease in severity (Red to Green, or Yellow to Green):</b> This value is used with the hysteresis, configured by the 'Hysteresis' parameter (see below).</li> </ul> <p><b>Note:</b> The parameter applies to all your configured bandwidths.</p>
'Hysteresis' hysteresis [Hysteresis]	<p>Defines the amount of fluctuation (hysteresis) from the configured bandwidth threshold in order for the threshold to be considered as crossed (i.e., avoids false reports of threshold crossings). The hysteresis is used only to determine threshold crossings when severity is reduced (i.e., from Red to Yellow, Yellow to Green, or Red to Green). The parameter is configured as a percentage of the Major (total) bandwidth threshold.</p> <p>For example, if you configure the parameter to 10 and the 'Egress Audio Bandwidth' parameter to 64,000, the hysteresis is 6,400 (10% of 64,000) and threshold crossings are considered at the following bandwidths:</p> <ul style="list-style-type: none"> <li>■ Red-to-Yellow (Yellow-Minor alarm severity): 57,600 Kbps [64,000 - (10% x 64,000)]</li> <li>■ Yellow-to-Green (Green-alarm cleared): 25,600 Kbps [32,000 - (10% x 64,000)]</li> </ul>
'Generate Alarm' generate-alarms [GenerateAlarms]	<p>Enables the device to send an SNMP alarm if a bandwidth threshold is crossed.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul>

## Configuring Quality of Service Rules

The Quality of Service Rules table lets you configure up to 510 Quality of Service rules. A Quality of Service rule defines an action to perform when the threshold (major or minor) of a specific performance monitoring call metric is crossed for a specific IP Group. The call metric can be voice quality (i.e., MOS), bandwidth, Answer-seizure ratio (ASR), Network Effectiveness Ratio (NER), or Average Call Duration (ACD).



The section is applicable only to the SBC application.

Depending on the call metric, you can configure the following actions to be performed if the threshold is crossed:

- Reject calls to the IP Group for a user-defined duration. Rejection of calls can also trigger alternative routing. When the device rejects a call due to an ASR, NER or ACD threshold crossing, it generates the SIP response code 850 (Signaling Limits Exceeded). When the device rejects a call due to Voice Quality and Bandwidth threshold crossing, it generates the SIP response code 806 (Media Limits Exceeded). If you configure these SIP response codes for an Alternative Reasons Set (see [Configuring SIP Response Codes for Alternative Routing Reasons](#) on page 1104) that is assigned to the IP Group ('SBC Alternative Routing Reasons Set' parameter) and the device rejects a call, it searches in the IP-to-IP Routing table for an alternative routing rule.

When the device rejects calls to an IP Group based on a Quality of Service rule, it raises an SNMP alarm (acIpGroupNoRouteAlarm). The alarm is also raised upon a keep-alive failure with the IP Group. For more information, refer to the document [SBC-Gateway Series SNMP Alarm Reference Guide](#).

- Use a different IP Profile for the IP Group or current call. This action can be useful, for example, when poor quality occurs due to packet loss and the device can then switch to an IP Profile configured with a higher RTP redundancy level or lower bit-rate coder.

To learn more about which actions are supported per call metric, see the description of the 'Rule Action' parameter below.

To configure thresholds, see the following sections:

- Voice Quality (MOS) - [Configuring Quality of Experience Profiles](#) on page 519
- Bandwidth - [Configuring Bandwidth Profiles](#) on page 526
- ASR, ACD and NER - See Alarm Thresholds

The following procedure describes how to configure Quality of Service rules through the Web interface. You can also configure it through ini file [QualityOfServiceRules] or CLI (`configure voip > qoe quality-of-service-rules`).

➤ **To configure a Quality of Service rule:**

1. Open the Quality of Service Rules table (**Setup** menu > **Signaling & Media** tab > **Media** folder > **Quality of Service Rules**).
2. Click **New**; the following dialog box appears:

*Quality Of Service Rules*

MATCH		ACTION	
Index	2	Rule Action	Reject Calls
IP Group	-- <a href="#">View</a>	Calls Reject Duration	5
Rule Metric	Voice Quality	Alternative IP Profile Name	-- <a href="#">View</a>
Severity	Major		

3. Configure a rule according to the parameters described in the table below.
4. Click **Apply**, and then restart the device with a save-to-flash for your settings to take effect.

**Table 17-7: Quality of Service Rules Table Parameter Descriptions**

Parameter	Description
Match	
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'IP Group' ip-group-name [IPGroupName]	Assigns an IP Group. The rule applies to all calls belonging to the IP Group. <b>Note:</b> This parameter is mandatory.
'Rule Metric' rule-metric [RuleMetric]	Defines the performance monitoring call metric to which the rule applies if the metric's threshold is crossed. <ul style="list-style-type: none"> <li>■ [0] <b>Voice Quality</b> = (Default) The device calculates MOS of calls and if the threshold is crossed (i.e., poor quality), the configured action (see 'Rule Action' parameter below) is done for all <b>new</b> calls and for the <b>entire</b> IP Group.</li> <li>■ [1] <b>Bandwidth</b></li> <li>■ [2] <b>ACD</b></li> <li>■ [3] <b>ASR</b></li> <li>■ [4] <b>NER</b></li> <li>■ [5] <b>Poor InVoice Quality</b> = The device calculates MOS (and</li> </ul>

Parameter	Description
	<p>TMMBR) of the call and if the threshold is crossed (i.e., poor quality), the device uses a different IP Profile (see 'Rule Action' parameter below) for the <b>current call only</b> (not the entire IP Group). This option is also used for voice quality for unregistered users (see <a href="#">Configuring Voice Quality for Unregistered Users</a> on page 537).</p> <ul style="list-style-type: none"> <li>■ [6] <b>Registered User Voice Quality</b> = The device calculates the MOS of calls belonging to users that are registered with the device. For more information on this feature, see <a href="#">Configuring Voice Quality for Registered Users</a> on page 535.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>✓ When this option is selected, a User-type IP Group must be selected in the 'IP Group' parameter (above).</li> <li>✓ This option is applicable only to the SBC application.</li> </ul>
'Severity' severity [Severity]	<p>Defines the alarm severity level. When the configured severity occurs, the device performs the action of the rule.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Major</b> (Default)</li> <li>■ [1] <b>Minor</b></li> </ul> <p><b>Note:</b> If you configure the 'Rule Metric' parameter to <b>ACD</b>, <b>ASR</b> or <b>NER</b>, you must configure the parameter to <b>Major</b>. For all other 'Rule Metric' parameter values, you can configure the parameter to any value.</p>
Action	
'Rule Action' rule-action [RuleAction]	<p>Defines the action to be done if the rule is matched.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Reject Calls</b> = (Default) New calls destined to the specified IP Group are rejected for a user-defined duration. To configure the duration, use the 'Calls Reject Duration' parameter (see below).</li> <li>■ [1] <b>Alternative IP Profile</b> = A different IP Profile is used for the IP Group or call (depending on the 'Rule Metric' parameter). To specify the IP Profile, use the 'Alternative IP Profile Name' parameter (see below).</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you configure the 'Rule Metric' parameter to <b>ACD</b>, <b>ASR</b> or <b>NER</b>, you must configure the parameter to <b>Reject Calls</b>.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ If you configure the 'Rule Metric' parameter to <b>Voice Quality</b> or <b>Bandwidth</b>:               <ul style="list-style-type: none"> <li>✓ If you configure the 'Severity' parameter to <b>Minor</b>, you must configure the parameter to <b>Alternative IP Profile</b>.</li> <li>✓ If you configure the 'Severity' parameter to <b>Major</b>, you can configure the parameter to any option.</li> </ul> <p>When configured to <b>Alternative IP Profile</b> and the threshold is crossed, the device changes the IP Profile for the entire IP Group for all new calls.</p> </li> <li>■ If you configure the 'Rule Metric' parameter to <b>Poor InVoice Quality</b>, you must configure the parameter to <b>Alternative IP Profile</b>. If the threshold is crossed (i.e., poor call quality), the device changes the IP Profile for the specific call <b>only</b> (during the call).</li> <li>■ If you configure the 'Rule Metric' parameter to <b>Registered User Voice Quality</b>:               <ul style="list-style-type: none"> <li>✓ If you configure the 'Severity' parameter to <b>Minor</b>, you must configure the parameter to <b>Alternative IP Profile</b>. If the threshold is crossed (i.e., poor MOS), the device changes the IP Profile (from the original IP Profile configured with the G.711 coder to the alternative IP Profile configured with the Opus coder)during the call. As soon as the device detects an improvement in the network (based on packet loss), it returns to the original IP Profile.</li> <li>✓ If you configure the 'Severity' parameter to <b>Major</b>, you can configure the parameter to any option.</li> <li>✓ If you configure the parameter to <b>Alternative IP Profile</b>, new calls will initially use the coder that was last used in the previous call (regardless of MOS).</li> <li>✓ If you configure the parameter to <b>Alternative IP Profile</b>, this feature is not supported for HA switchover (e.g., if coder changed to Opus before switchover, after switchover the call remains with Opus until it ends, regardless of MOS level).</li> <li>✓ If you configure the parameter to <b>Alternative IP Profile</b> and the device supports other media types (e.g., video) in addition to audio, at least one of the peers must</li> </ul> </li> </ul>

Parameter	Description
	support re-INVITE without SDP.
'Calls Reject Duration' calls-reject-duration [CallsRejectDuration]	Defines the duration (in minutes) for which the device rejects calls to the IP Group if the rule is matched. The default is 5. <b>Note:</b> The parameter is applicable only if the 'Rule Action' parameter is configured to <b>Reject Calls</b> .
'Alternative IP Profile Name' alt-ip-profile-name [AltIPProfileName]	Assigns a different IP Profile to the IP Group or call (depending on the 'Rule Metric' parameter) if the rule is matched. By default, no value is defined. <b>Note:</b> The parameter is applicable only if the 'Rule Action' parameter is configured to <b>Alternative IP Profile</b> .

## Configuring Voice Quality for Registered Users

You can configure the device to measure the mean opinion score (MOS) of calls belonging to users that are registered with the device.

During the call, the device measures MOS every 30 seconds. The device provides MOS measurements as values (MOS \* 10, i.e., 0 to 50), and colors (green, yellow, or red) according to your Quality of Experience Color rules (see [Configuring Quality of Experience Profiles](#) on page 519). Whenever a change in MOS color occurs, the device reports this to the registered user, by sending an out-of-dialog SIP NOTIFY message containing the proprietary SIP header 'x-VoiceQuality: <Value> <Color>', as shown in the following example (MOS 3.2 and red color):

```
x-VoiceQuality: 32 red
```

You can configure the device (see [Configuring Quality of Service Rules](#) on page 531) to take one of the following actions if it detects a low MOS level during a call:

- Reject new calls (destined to the IP Group) for a user-defined time.
- Change the IP Profile during the call. Using an alternative IP Profile is especially useful if you want to use a different voice coder that is more efficient (e.g., Opus) than the coder (e.g., G.711) currently used for the call. In this scenario, if the device measures low MOS, it immediately uses the alternative IP Profile, switching to the more efficient coder (e.g., Opus). If at any stage during the call, the device detects an improvement in the network (based on packet loss), it uses the original IP Profile, switching back to the original coder associated with this IP Profile (e.g., G.711).



- This feature is applicable only to the SBC application.
- When implementing the alternative IP Profile method for Quality of Service:
  - ✓ New calls will initially use the coder that was last used in the previous call (regardless of MOS).
  - ✓ This feature is not supported for HA switchover (e.g., if coder changed to Opus before switchover, after switchover the call remains with Opus until it ends, regardless of MOS level).
  - ✓ If the device supports other media types (e.g., video) in addition to audio, at least one of the peers must support re-INVITE without SDP.

In addition to real-time MOS measurements discussed above, the device performs average MOS calculations per registered user. The device measures MOS in an "observation window" that is comprised of 12 intervals, where each interval can be configured as one hour (i.e., total of 12 hours in the window) or two hours (total of 24 hours in the window). Based on these intervals, the device provides the following MOS measurements:

- Average MOS of the 12 intervals (i.e., average MOS is calculated per interval - this is the average of these 12 MOS average measurements)
- Minimum average MOS of the 12 intervals (i.e., lowest MOS average measured for an interval)

The average MOS of each interval is calculated by "weight" of call duration relative to total call duration in the interval. For example, If the observation interval is 1 hour and two calls occurred in an interval, one that lasted 10 minutes with MOS of 4.2 and another call that lasted 20 minutes with MOS of 3.7, the average MOS is calculated as follows:  $4.2 * 10 / 30 + 3.7 * 20 / 30 = 3.86$

You can view MOS measurements per registered user in the SBC Registered Users table (see [Viewing SBC Registered Users](#) on page 1354).



The device calculates MOS based on RTCP-XR reports received from the user. However, for WebRTC users, which typically don't send RTCP-XR reports, the device calculates MOS based on RTCP packets. For more information on WebRTC, see [Configuring Voice Quality for Registered Users](#).

#### ➤ To configure MOS measurement of registered users:

1. Open the Registered User Voice Quality page (**Setup** menu > **Signaling & Media** tab > **Media** folder > **Quality of Experience** > **Registered User Voice Quality**); the following appears:

Registered User MOS Observation Window (hours)	<input type="text" value="1"/>
MOS Stored Timeout For No Calls (min)	<input type="text" value="60"/>

2. Configure the following:



- In the 'Registered User MOS Observation Window' field, enter the duration (in hours) of each of the 12 intervals for measuring MOS.
  - In the 'MOS Stored Timeout For No Calls' field, enter the time (in minutes) of no calls for a registered user after which the MOS measurement for that user is deleted (reset to zero).
3. Configure a QoE Profile to define the severity-color thresholds for MOS (see [Configuring Quality of Experience Profiles](#) on page 519).
  4. (Optional) Configure a Quality of Service rule to define what action to take (reject future calls or use an alternative IP Profile) when a specific MOS severity level occurs (see [Configuring Quality of Service Rules](#) on page 531). Make sure that you configure the 'Rule Metric' parameter to **Registered User Voice Quality**.
  5. (See note below) In the IP Group of the registered user, configure the 'User Voice Quality Report' parameter to **Enable**:

User Voice Quality Report

Enable



If you configure a Quality of Service rule (in Step 4), it's unnecessary to enable the MOS calculation and reporting feature in the IP Groups table (Step 5). If you don't configure a Quality of Service rule, then you need to enable the feature in the IP Groups table.

## Configuring Voice Quality for Unregistered Users

You can configure the device to dynamically switch voice coders to improve voice quality during a call with an unregistered user.

If it detects poor voice quality (based on MOS), it switches coders from G.711 to Opus for the unregistered user side. If it subsequently detects an improvement in the network (based on packet loss) during the same call, it switches back to G.711. The device switches coders, by changing between two IP Profiles - one associated with G.711, and the other associated with Opus.



- This feature is applicable only to the SBC application.
- This feature is for **Server**-type IP Groups.
- When the device operates in HA mode, this feature is not supported for HA switchover (e.g., if coder changed to Opus before switchover, after switchover the call remains with Opus until it ends, even if voice quality improves).

### ➤ To configure voice quality for unregistered users:

1. Open the Allowed Audio Coders Group table (see [Configuring Allowed Audio Coder Groups](#) on page 659), and then add two groups - one with G.711 only and the other with Opus

only.

2. Open the IP Profiles table (see [Configuring IP Profiles](#) on page 664), and then add two IP Profiles:

- Main IP Profile:
  - ◆ 'Allowed Audio Coders': Assign the Allowed Audio Coders Group with G.711
  - ◆ 'Switch Coder Upon Voice Quality': **Enable**

Switch Coder Upon Voice Quality

Enable



- Alternative IP Profile:
    - ◆ 'Allowed Audio Coders': Assign the Allowed Audio Coders Group with Opus
3. Open the IP Groups table (see [Configuring IP Groups](#) on page 581), and then make sure that you assign the IP Group (**Server-Type**) to which the user belongs, with the main IP Profile associated with G.711.
  4. Open the Quality of Experience Profile table (see [Configuring Quality of Experience Profiles](#) on page 519), and then configure a rule with severity-color thresholds for MOS.
  5. Open the Quality of Service Rules table (see [Configuring Quality of Service Rules](#) on page 531), and then configure a rule that changes the IP Profile upon poor voice quality:
    - 'IP Group': Assign the IP Group of the user (see Step 3)
    - 'Rule Metric': **Poor InVoice Quality**
    - 'Rule Action': **Alternate IP Profile**
    - 'Alternative IP Profile Name': Assign the alternative IP Profile that is associated with the Opus coder (see Step 2)

## 18 Core Entities

This section describes configuration of core SIP entities.

### Configuring Media Realms

The Media Realms table lets you configure a pool of up to 12 SIP media interfaces, termed *Media Realms*. Media Realms lets you divide a Media-type interface (configured in the IP Interfaces table) into several media realms, where each realm is specified by a UDP port range. Media Realms also define the maximum number of permitted media sessions.

Once configured, to apply Media Realms to specific calls, you need to assign them to any of the following configuration entities:

- IP Groups (see [Configuring IP Groups](#) on page 581)
- SIP Interfaces (see [Configuring SIP Interfaces](#) on page 561)

You can also apply the device's Quality of Experience feature to Media Realms:

- **Quality of Experience Profile:** Call quality monitoring based on thresholds for voice metrics (e.g., MOS) can be applied per Media Realm. For example, if MOS is considered poor, calls on this Media Realm can be rejected. To configure Quality of Experience Profiles, see [Configuring Quality of Experience Profiles](#) on page 519.
- **Bandwidth Profile:** Bandwidth utilization thresholds can be applied per Media Realm. For example, if bandwidth thresholds are crossed, the device can reject any new new calls on this Media Realm. To configure Bandwidth Profiles, see [Configuring Bandwidth Profiles](#) on page 526.

The Media Realms table provides the following "child" tables:

- Remote Media Subnets: Defines remote destination subnets per Media Realm and assigns each subnet a Quality of Experience Profile and Bandwidth Profile. For more information, see [Configuring Remote Media Subnets](#) on page 543.
- Media Realm Extensions: Defines port ranges for multiple Media-type interfaces per Media Realm. For more information, see [Configuring Media Realm Extensions](#) on page 546.



- The Media Realm assigned to an IP Group overrides any other Media Realm assigned to any other configuration entity associated with the call.
- If you modify a Media Realm that is currently being used by a call, the device doesn't perform Quality of Experience for the call.
- If you delete a Media Realm that is currently being used by a call, the device maintains the call until the call parties end the call.
- The device provides a default Media Realm ("DefaultRealm"), which you can modify or delete.

The following procedure describes how to configure Media Realms through the Web interface. You can also configure it through ini file [CpMediaRealm] or CLI (`configure voip > realm`).

➤ **To configure a Media Realm:**

1. Open the Media Realms table (**Setup** menu > **Signaling & Media** tab > **Core Entities** folder > **Media Realms**).
2. Click **New**; the following dialog box appears:

The screenshot shows a web-based configuration interface for Media Realms. It consists of two main sections: GENERAL and QUALITY OF EXPERIENCE. The GENERAL section includes fields for Index, Name, Topology Location, IPv4 Interface Name, IPv6 Interface Name, UDP Port Range Start, Number Of Media Session Legs, UDP Port Range End, Default Media Realm, and Used By Routing Server. The QUALITY OF EXPERIENCE section includes fields for QoS Profile and Bandwidth Profile. Each field has a dropdown menu or text input, and some have a 'View' link.

3. Configure the Media Realm according to the parameters described in the table below.
4. Click **Apply**.

**Table 18-1: Media Realms Table Parameter Descriptions**

Parameter	Description
<b>General</b>	
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [MediaRealmName]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 39 characters. <b>Note:</b> <ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> <li>■ Configure each row with a unique name.</li> <li>■ The parameter value can't contain a forward slash (/).</li> <li>■ The parameter value can't be configured with the character string "any" (upper or lower case).</li> </ul>
'Topology Location'	Defines the display location of the Media Realm in the

Parameter	Description
<code>topology-location</code> [TopologyLocation]	<p>Topology view.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Down</b> = (Default) The Media Realm element is displayed on the lower border of the view.</li> <li>■ [1] <b>Up</b> = The Media Realm element is displayed on the upper border of the view.</li> </ul> <p>For more information on the Topology view, see <a href="#">Building and Viewing SIP Entities in Topology View</a> on page 643.</p>
'IPv4 Interface Name' <code>ipv4</code> [IPv4IF]	<p>Assigns an IPv4 interface to the Media Realm.</p> <p>By default, no value is defined.</p> <p>To configure IP network interfaces, see <a href="#">Configuring IP Network Interfaces</a> on page 157.</p>
'IPv6 Interface Name' <code>ipv6if</code> [IPv6IF]	<p>Assigns an IPv6 interface to the Media Realm.</p> <p>By default, no value is defined.</p> <p>To configure IP network interfaces, see <a href="#">Configuring IP Network Interfaces</a> on page 157.</p>
'UDP Port Range Start' <code>port-range-start</code> [PortRangeStart]	<p>Defines the starting port for the range of media interface UDP ports.</p> <p>By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ You must configure <b>all</b> your Media Realms with port ranges or all without; not some with and some without.</li> <li>■ The available UDP port range is according to the [BaseUDPport] parameter. For more information, see <a href="#">Configuring RTP Base UDP Port</a> on page 295.</li> <li>■ The port number <b>must</b> be different from ports configured for SIP traffic (i.e., ports configured for SIP Interfaces) that use the same IP Interface. For example, if the RTP port range is 6000 to 6999, the SIP port can be less than 6000 or greater than 6999.</li> <li>■ Media Realms associated with the same IP Interface must not have overlapping port ranges.</li> <li>■ Media Realms and Media Realm Extensions associated with the same IP Interface must not</li> </ul>


Parameter	Description
	have overlapping port ranges.
'Number of Media' Session Legs session-leg [MediaSessionLeg]	Defines the number of media sessions for the configured port range. By default, no value is defined.
'UDP Port Range End' port-range-end [PortRangeEnd]	<p>(Read-only field) Displays the ending port for the range of media interface UDP ports. The device automatically populates the parameter with a value, calculated by the summation of the 'UDP Port Range Start' parameter and 'Number of Media Session Legs' parameter (multiplied by the port chunk size) minus 1:</p> $\text{start port} + (\text{sessions} * \text{port spacing}) - 1$ <p>For example, a port starting at 6,000, 5 sessions and 10 port spacing:</p> $6,000 + (5 * 10) - 1 = 6,000 + (50) - 1 = 6,000 + 49 = 6,049$ <p>For more information on UDP port allocation and spacing, see <a href="#">Configuring RTP Base UDP Port</a> on page 295.</p>
'Default Media Realm' is-default [IsDefault]	<p>Defines the Media Realm as the default Media Realm. The default Media Realm is used for SIP Interfaces and IP Groups for which you have not assigned a Media Realm.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> (default)</li> <li>■ [1] <b>Yes</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ You can configure the parameter to <b>Yes</b> for only <b>one</b> Media Realm; all the other Media Realms must be configured to <b>No</b>.</li> <li>■ If you do not configure the parameter (i.e., the parameter is <b>No</b> for all Media Realms), the device uses the first Media Realm in the table as the default.</li> <li>■ If the table is not configured, the default Media Realm includes all configured media interfaces.</li> </ul>

Parameter	Description
'Used By Routing Server' used-by-routing-server [UsedByRoutingServer]	<p>Enables the Media Realm to be used by ARM for call routing decisions.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Not Used</b> (default)</li> <li>■ [1] <b>Used</b></li> </ul> <p>For more information on routing by ARM, see <a href="#">Centralized Routing by ARM (AudioCodes Routing Manager)</a> on page 442.</p>
Quality of Experience	
'QoE Profile' qoe-profile [QoeProfile]	<p>Assigns a QoE Profile to the Media Realm.</p> <p>By default, no value is defined.</p> <p>To configure QoE Profiles, see <a href="#">Configuring Quality of Experience Profiles</a> on page 519.</p>
'BW Profile' bw-profile [BWProfile]	<p>Assigns a Bandwidth Profile to the Media Realm.</p> <p>By default, no value is defined.</p> <p>To configure Bandwidth Profiles, see <a href="#">Configuring Bandwidth Profiles</a> on page 526.</p>

## Configuring Remote Media Subnets

Remote Media Subnets define destination subnets for media (RTP/SRTP) traffic on a specific Media Realm. Each Remote Media Subnet can be assigned different call quality (Quality of Experience Profile) and bandwidth utilization (Bandwidth Profile) profiles. These profiles are configured in [Configuring Quality of Experience Profiles](#) on page 519 and [Configuring Bandwidth Profiles](#) on page 526, respectively. Thus, you can apply these profiles to remote media subnets instead of Media Realms or IP Groups. You can configure up to five Remote Media Subnets per Media Realm.

The figure below illustrates an example for implementing Remote Media Subnets. IP Group #2 represents a SIP Trunk which routes international (USA and India) and local calls. As international calls are typically more prone to higher delay than local calls, different Quality of Experience Profiles are assigned to them. This is done by creating Remote Media Subnets for each of these call destinations and assigning each Remote Media Subnet a different Quality of Experience Profile. A Quality of Experience Profile that defines a packet delay threshold is assigned to the international calls, which if crossed, a different IP Profile is used that defines higher traffic priority to voice over other traffic. In addition, IP Group #2 has a 10-Mbps bandwidth threshold and a "tighter" bandwidth limitation (e.g., 1 Mbps) is allocated to local calls. If this limit is exceeded, the device rejects new calls to this Remote Media Subnet.



The following procedure describes how to configure Remote Media Subnets through the Web interface. You can also configure it through ini file [RemoteMediaSubnet] or CLI (`configure voip > remote-media-subnet`).

➤ **To configure a Remote Media Subnet:**

1. Open the Media Realms table (see [Configuring Media Realms](#) on page 539).
2. Select the Media Realm row for which you want to add Remote Media Subnets, and then click the **Remote Media Subnet** link located below the table; the Remote Media Subnet table appears.
3. Click **New**; the following dialog box appears:

Remote Media Subnet

GENERAL	
Index	0
Name	
Prefix Length	16
Address Family	IPv4
Destination IP	0.0.0.0
QoE Profile	-- View
BW Profile	-- View

4. Configure the Remote Media Subnet according to the parameters described in the table below.




5. Click **Apply**.**Table 18-2: Remote Media Subnet Table Parameter Descriptions**

Parameter	Description
'Index' [RemoteMediaSubnet_ RemoteMediaSubnetIndex]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [RemoteMediaSubnet_ RemoteMediaSubnetName]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 20 characters. <b>Note:</b> Configure each row with a unique name.
'Prefix Length' prefix-length [RemoteMediaSubnet_ PrefixLength]	Defines the subnet mask in Classless Inter-Domain Routing (CIDR) notation. For example, 16 denotes 255.255.0.0. The default is 16.
'Address Family' address-family [RemoteMediaSubnet_ AddressFamily]	Defines the IP address protocol. <ul style="list-style-type: none"> <li>■ [2] <b>IPv4</b> (default)</li> <li>■ [10] <b>IPv6</b></li> </ul>
'Destination IP' dst-ip-address [RemoteMediaSubnet_ DstIPAddress]	Defines the IP address of the destination. The default is 0.0.0.0.
'QoE Profile' qoe-profile [RemoteMediaSubnet_ QOEProfileName]	Assigns a Quality of Experience Profile to the Remote Media Subnet. By default, no value is defined. To configure QoE Profiles, see <a href="#">Configuring Quality of Experience Profiles</a> on page 519.
'BW Profile' bw-profile [RemoteMediaSubnet_ BWProfileName]	Assigns a Bandwidth Profile to the Remote Media Subnet. By default, no value is defined. To configure Bandwidth Profiles, see <a href="#">Configuring Bandwidth Profiles</a> on page 526.

## Configuring Media Realm Extensions

The Media Realm Extension table lets you configure up to 24 Media Realm Extensions. A Media Realm Extension is associated with a specific Media Realm and defines a port range and the number of media sessions for a specific Media-type network interface (configured in the IP Interfaces table). Therefore, a Media Realm Extension enhances a Media Realm by allowing you to define different port ranges, media sessions, and network interface than is defined by the associated Media Realm (i.e., the Media Realm is distributed across multiple interfaces).

Media Realm Extensions can be useful, for example, to overcome limitations of the maximum number of media ports supported per interface. Instead of configuring only a single Media Realm in the Media Realms table (see [Configuring Media Realms](#) on page 539), you can also configure additional "Media Realms" in the Media Realm Extensions table associated with the single Media Realm. An IP Group that is associated with a Media Realm configured with Media Realm Extensions, allocates its media sessions / ports between the different interfaces, as configured by the Media Real and its associated Media Realm Extensions. For example, two Media Realm Extensions could be configured, whereby one allocates 25 media sessions on interface "LAN-1" and another, 10 sessions on interface "LAN-2". The Media Realm associated with these Media Realm Extensions would be assigned to the relevant IP Group.



The following procedure describes how to configure Media Realm Extensions through the Web interface. You can also configure it through ini file [MediaRealmExtension] or CLI (`configure voip > voip-network realm-extension`).

### ➤ To configure a Media Realm Extension:

1. Open the Media Realms table (see [Configuring Media Realms](#) on page 539).
2. Select the Media Realm for which you want to add Remote Media Extensions, and then click the **Media Realm Extension** link located below the table; the Media Realm Extension table appears.
3. Click **New**; the following dialog box appears:

4. Configure the Media Realm Extension according to the parameters described in the table below.
5. Click **Apply**.

**Table 18-3: Media Realm Extension Table Parameter Descriptions**

Parameter	Description
'Index' [MediaRealmExtension_ExtensionIndex]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'IPv4 Interface Name' [MediaRealmExtension_IpV4IF]	Assigns an IPv4 network interface (configured in the IP Interfaces table) to the Media Realm Extension. By default, no value is defined. To configure IP network interfaces, see <a href="#">Configuring IP Network Interfaces</a> on page 157. <b>Note:</b> <ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> <li>■ You must configure the Media Realm Extension with an IP network interface that has the same IP version(s) as the Media Realm to which the Media Realm Extension is associated. If the associated Media Realm is assigned both an IPv4 and IPv6 network interface, you also need to assign the Media Realm Extension with both an IPv4 and IPv6 network interface. For example, if the associated Media Realm is assigned only an IPv4 network interface, you also need to assign the Media Realm Extension with an IPv4 network interface.</li> </ul>
'IPv6 Interface Name'	Assigns an IPv6 network interface (configured in the IP

Parameter	Description
[MediaRealmExtension_IpV6IF]	<p>Interfaces table) to the Media Realm Extension.</p> <p>By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> <li>■ You must configure the Media Realm Extension with an IP network interface that has the same IP version(s) as the Media Realm to which the Media Realm Extension is associated. If the associated Media Realm is assigned both an IPv4 and IPv6 network interface, you also need to assign the Media Realm Extension with both an IPv4 and IPv6 network interface. For example, if the associated Media Realm is assigned an IPv6 network interface, you also need to assign the Media Realm Extension with an IPv6 network interface.</li> </ul>
'Port Range Start' [MediaRealmExtension_PortRangeStart]	<p>Defines the first (lower) port in the range of media UDP ports for the Media Realm Extension.</p> <p>By default, no value is defined.</p> <p><b>Notes:</b></p> <ul style="list-style-type: none"> <li>■ You must either configure all your Media Realms with port ranges or all without; not some with and some without.</li> <li>■ The available UDP port range is according to the [BaseUDPport] parameter (see <a href="#">Configuring RTP Base UDP Port</a> on page 295).</li> <li>■ The port range must not overlap with any other media port range configured for other Media Realm Extensions, Media Realms, or SIP Interfaces that are associated with the same IP network interface.</li> </ul>
'Port Range End' [MediaRealmExtension_PortRangeEnd]	<p>Defines the last (upper) port in the range of media UDP ports for the Media Realm Extension.</p> <p><b>Note:</b> It is unnecessary to configure the parameter. The device automatically populates the parameter with a value, calculated by the summation of the 'Number of Media Session Legs' parameter (multiplied by the port chunk size) and the 'Port Range Start' parameter. After you have added the Media Realm Extension row to the table, the parameter is displayed with the calculated value.</p>

Parameter	Description
'Number Of Media Session Legs' [MediaRealmExtension_MediaSessionLeg]	<p>Defines the number of media sessions for the port range. For example, 100 ports correspond to 10 media sessions, since ports are allocated in chunks of 10.</p> <p>By default, no value is defined.</p> <p><b>Note:</b> The parameter is mandatory.</p>

## Configuring SRDs

The SRDs table lets you configure up to 20 signaling routing domains (SRD). The SRD is a logical representation of an entire SIP-based VoIP network (Layer 5) consisting of groups of SIP users and servers. The SRD is associated with all the configuration entities (e.g., SIP Interfaces and IP Groups) required for routing calls within the network. Typically, only a **single** SRD is required (recommended) for most deployments. Multiple SRDs are only required for multi-tenant deployments, where the physical device is "split" into multiple logical devices. For more information on multi-tenant architecture, see [Multiple SRDs for Multi-tenant Deployments](#) on page 557.


As the device is shipped with a default SRD ("DefaultSRD" at Index 0), if your deployment requires only one SRD, you can use the default SRD instead of creating a new one. When only one SRD is employed and you create other related configuration entities (e.g., SIP Interfaces), the default SRD is automatically assigned to the new configuration entity. Therefore, when employing a single-SRD configuration topology, there is no need to handle SRD configuration (i.e., transparent).

You can assign SRDs to the following configuration entities:

- SIP Interface (mandatory) - see [Configuring SIP Interfaces](#) on page 561
- IP Group (mandatory) - see [Configuring IP Groups](#) on page 581
- Proxy Set (mandatory) - see [Configuring Proxy Sets](#) on page 622
- (SBC application only) Classification rule - see [Configuring Classification Rules](#) on page 1061

As mentioned previously, if you use only a single SRD, the device automatically assigns it to the above-listed configuration entities.

As each SIP Interface defines a different Layer-3 network (see [Configuring SIP Interfaces](#) on page 561 for more information) on which to route or receive calls and as you can assign multiple SIP Interfaces to the same SRD, for most deployment scenarios (even for multiple Layer-3 network environments), you only need to employ a single SRD to represent your VoIP network (Layer 5). For example, if your VoIP deployment consists of an corporate IP PBX (LAN), a SIP Trunk (WAN), and far-end users (WAN), you would only need a single SRD. The single SRD would be assigned to three different SIP Interfaces, where each SIP Interface would represent a specific Layer-3 network (IP PBX, SIP Trunk, or far-end users) in your environment. The following figure provides an example of such a deployment:



- It is recommended to use a single-SRD configuration topology, unless you are deploying the device in a multi-tenant environment, in which case multiple SRDs are required.
- Each SIP Interface, Proxy Set, and IP Group can be associated with only one SRD.
- If you have upgraded your device to Version 7.0 and your device was configured with multiple SRDs but not operating in a multi-tenant environment, it is recommended to gradually change your configuration to a single SRD topology.
- If you upgrade the device from an earlier release to Version 7.0, your previous SRD configuration is fully preserved regarding functionality. The same number of SRDs is maintained, but the configuration elements are changed to reflect the configuration topology of Version 7.0. Below are the main changes in configuration topology when upgrading to Version 7.0:
  - ✓ The SIP Interface replaces the associated SRD in several tables (due to support for multiple SIP Interfaces per SRD).
  - ✓ Some fields in the SRDs table were duplicated or moved to the SIP Interfaces table.
  - ✓ Indices used for associating configuration entities in tables are changed to row pointers (using the entity's name).
  - ✓ Some tables are now associated (mandatory) with an SRD (SIP Interface, IP Group, Proxy Set, and Classification).
  - ✓ Some fields used for associating configuration entities in tables now have a value of **Any** to distinguish between **Any** and **None** (deleted entity or not associated).

The following procedure describes how to configure SRDs through the Web interface. You can also configure it through ini file [SRD] or CLI (`configure voip > srd`).

#### ➤ To configure an SRD:

1. Open the SRDs table (**Setup** menu > **Signaling & Media** tab > **Core Entities** folder > **SRDs**).

2. Click **New**; the following dialog box appears:

The screenshot shows a dialog box titled "SRDs" with two tabs: "GENERAL" and "REGISTRATION".

**GENERAL Tab:**

- Index: Text input field containing "1f".
- Name: Text input field.
- Sharing Policy: Dropdown menu set to "Shared".
- SBC Operation Mode: Dropdown menu set to "B2BUA".
- SBC Routing Policy: Dropdown menu set to "#0 [Default\_SBCRoutingPolicy]" with a "View" link.
- Used By Routing Server: Dropdown menu set to "Not Used".
- Dial Plan: Dropdown menu set to "--" with a "View" link.

**REGISTRATION Tab:**

- Max. Number of Registered Users: Text input field containing "-1".
- User Security Mode: Dropdown menu set to "Accept All".
- Enable Un-Authenticated Registrations: Dropdown menu set to "Enable".

3. Configure an SRD according to the parameters described in the table below.

4. Click **Apply**.

**Table 18-4: SRDs table Parameter Descriptions**

Parameter	Description
<b>General</b>	
'Index' [Index]	Defines an index for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [Name]	Defines a descriptive name, which is used when associating the row in other tables. The valid value can be a string of up to 40 characters. <b>Note:</b> <ul style="list-style-type: none"> <li>The parameter is mandatory.</li> <li>Configure each row with a unique name.</li> <li>The parameter value can't contain a forward slash (/).</li> <li>The parameter value can't be configured with the character string "any" (upper or lower case).</li> </ul>
'Sharing Policy' type [SharingPolicy]	Defines the sharing policy of the SRD, which determines whether the SRD shares its SIP resources (SIP Interfaces, Proxy Sets, and IP Groups) with all other SRDs (Shared and

Parameter	Description
	<p>Isolated).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Shared</b> = (Default) SRD shares its resources with other SRDs (Isolated and Shared) and calls can thus be routed between the SRD and other SRDs.</li> <li>■ [1] <b>Isolated</b> = SRD doesn't share its resources with other SRDs and calls cannot be routed between the SRD and other Isolated SRDs. However, calls can be routed between the SRD and other Shared SRDs.</li> </ul> <p>For more information on SRD Sharing Policy, see <a href="#">Multiple SRDs for Multi-tenant Deployments</a> on page 557.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<p>'SBC Operation Mode'</p> <p>sbc-operation-mode</p> <p>[SBCOperationMode]</p>	<p>Defines the device's operational mode for the SRD.</p> <ul style="list-style-type: none"> <li>■ [0] <b>B2BUA</b> = (Default) Device operates as a back-to-back user agent (B2BUA), changing the call identifiers and headers between the inbound and outbound legs.</li> <li>■ [1] <b>Call Stateful Proxy</b> = Device operates as a Stateful Proxy, passing the SIP message transparently between inbound and outbound legs. In other words, the same SIP dialog identifiers (tags, Call-Id and CSeq) occur on both legs (as long as no other configuration disrupts the CSeq compatibility).</li> </ul> <p>For more information on B2BUA and Stateful Proxy modes, see <a href="#">B2BUA and Stateful Proxy Operating Modes</a> on page 1021.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The settings of the parameter also determines the default behavior of related parameters in the IP Profiles table (SBCRemoteRepresentationMode,</li> </ul>



Parameter	Description
	<p>SBCKeepVIAHeaders, SBCKeepUserAgentHeader, SBCKeepRoutingHeaders, SBCRemoteMultipleEarlyDialogs).</p> <ul style="list-style-type: none"> <li>■ If the 'SBC Operation Mode' parameter is configured in the IP Groups table, the 'SBC Operation Mode' parameter in the SRDs table is ignored.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
<p>'SBC Routing Policy'</p> <p>sbc-routing-policy-name</p> <p>[SBCRoutingPolicyName]</p>	<p>Assigns a Routing Policy to the SRD.</p> <p>By default, no value is defined if you have configured multiple Routing Policies. If you have configured only one Routing Policy, the device assigns it to the SRD by default.</p> <p>For more information on Routing Policies, see <a href="#">Configuring SBC Routing Policies</a> on page 1108.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you have assigned a Routing Policy to a Classification rule that is associated with the SRD, the Routing Policy assigned to the SRD is ignored.</li> <li>■ You can assign the same Routing Policy to multiple SRDs.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
<p>'Used By Routing Server'</p> <p>used-by-routing-server</p> <p>[UsedByRoutingServer]</p>	<p>Enables the SRD to be used by ARM for call routing decisions.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Not Used</b> (default)</li> <li>■ [1] <b>Used</b></li> </ul> <p>For more information on routing by ARM, see <a href="#">Centralized Routing by ARM (AudioCodes Routing Manager)</a> on page 442.</p>
<p>'Dial Plan'</p> <p>sbc-dial-plan-name</p>	<p>Assigns a Dial Plan to the SRD. The device searches the Dial Plan for a dial plan rule that</p>

Parameter	Description
[SBCDialPlanName]	<p>matches the source number and if not found, for a rule that matches the destination number. If a matching dial plan rule is found, the rule's tag is used in the routing and/or manipulation processes as source and/or destination tags.</p> <p>To configure Dial Plans, see <a href="#">Configuring Dial Plans</a> on page 798.</p>
'CAC Profile' cac-profile [AdmissionProfile]	<p>Assigns a Call Admission Control Profile (CAC rules) to the SRD.</p> <p>By default, no value is defined.</p> <p>To configure CAC Profiles, see <a href="#">Configuring Call Admission Control</a> on page 1054.</p>
Registration	
'Max. Number of Registered Users' max-reg-users [MaxNumOfRegUsers]	<p>Defines the maximum number of users belonging to the SRD that can register with the device.</p> <p>The default is -1, which means that the number of allowed user registrations is unlimited.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
'User Security Mode' block-un-reg-users [BlockUnRegUsers]	<p>Defines the blocking (reject) policy for incoming SIP dialog-initiating requests (e.g., INVITE messages) from registered and unregistered users belonging to the SRD.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Accept All</b> = (Default) Accepts requests from registered and unregistered users.</li> <li>■ [1] <b>Accept Registered Users</b> = Accepts requests only from users registered with the device. Requests from users not registered are rejected.</li> <li>■ [2] <b>Accept Registered Users from Same Source</b> = Accepts requests only from registered users whose source address is the same as that registered with the device (during the REGISTER message process). All</li> </ul>

Parameter	Description
	<p>other requests are rejected. If the transport protocol is UDP, the verifies the IP address and port; otherwise, it verifies only the IP address. The verification is performed before any of the device's call handling processes (i.e., Classification, Manipulation and Routing).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to calls belonging to User-type IP Groups.</li> <li>■ The feature is not applicable to REGISTER requests.</li> <li>■ The option, Accept Registered Users from Same Source [2] doesn't apply to registration refreshes. These requests are accepted even if the source address is different to that registered with the device.</li> <li>■ When the device rejects a call, it sends a SIP 500 "Server Internal Error" response to the user. In addition, it reports the rejection (Dialog establish failure - Classification failure) using the Intrusion Detection System (IDS) feature (see <a href="#">Configuring IDS Policies</a> on page 259), by sending an SNMP trap.</li> <li>■ When the corresponding parameter in the SIP Interfaces table ('User Security Mode') is configured to any value other than <b>Not Configured</b> for a SIP Interface that is associated with the SRD, the parameter in the SRDs table is ignored for calls belonging to the SIP Interface.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
'Enable Un-Authenticated Registrations' enable-un-auth-registrs [EnableUnAuthenticatedRegistrations]	Enables the device to accept REGISTER requests and register them in its registration database from new users that have not been authenticated by a proxy/registrar server (due

Parameter	Description
	<p>to proxy down) and thus, re-routed to a User-type IP Group.</p> <p>In normal operation scenarios in which the proxy server is available, the device forwards the REGISTER request to the proxy and if authenticated by the proxy (i.e., device receives a success response), the device adds the user to its registration database. The routing to the proxy is according to the SBC IP-to-IP Routing table where the destination is the proxy's IP Group. However, when the proxy is unavailable (e.g., due to network connectivity loss), the device can accept REGISTER requests from new users if a matching alternative routing rule exists in the SBC IP-to-IP Routing table where the destination is the user's User-type IP Group (i.e., call survivability scenarios) and if the parameter is enabled.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = The device rejects REGISTER requests from new users that were not authenticated by a proxy server.</li> <li>■ [1] <b>Enable</b> = (Default) The device accepts REGISTER requests from new users even if they were not authenticated by a proxy server, and registers the user in its registration database.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Regardless of the parameter, the device always accepts registration refreshes from users that are already registered in its database.</li> <li>■ For a SIP Interface that is associated with the SRD, if the corresponding parameter in the SIP Interfaces table ('Enable Un-Authenticated Registrations') is configured to <b>Disable</b> or <b>Enable</b>, the parameter in the SRD is ignored for calls belonging to the SIP Interface.</li> <li>■ The parameter is applicable only to the SBC</li> </ul>

Parameter	Description
	application.

## Multiple SRDs for Multi-tenant Deployments

The device can be deployed in a multi-tenant architecture, serving multiple customers (tenants) from a single, shared physical entity. The device's multi-tenant feature is fully scalable, offering almost “non-bleeding” partition per tenant, whereby users of one tenant can't infringe on the space of users of another tenant. The device provides per tenant configuration, monitoring, reporting, analytics, alarms and interfacing. The device is a real-time multi-tenant system that provides each tenant with optimal real-time performance, as each session received by the device is classified and processed only through the tenant's “orbit”.

While some enterprises are large enough to justify a dedicated standalone device, many enterprises require only a fraction of the device's capacity and capabilities. Service providers offering SIP Trunking services can funnel multiple enterprises into a single device and thereby, reap significant cost improvements over a device-per-customer model. Tenant size in a multi-tenant architecture can vary and therefore, the instance CPU, memory and interface allocations should be optimized so as not to waste resources for small-sized tenants on the one hand, and not to allocate too many instances for a single tenant/customer on the other. For example, it would be a waste to allocate a capacity of 100 concurrent sessions to a small tenant for which 10 concurrent sessions suffice.

In a multi-tenant deployment, each tenant is represented by a dedicated SRD. The different Layer-3 networks (e.g., LAN IP-PBX users, WAN SIP Trunk, and WAN far-end users) of the tenant are represented by SIP Interfaces, which are all associated with the tenant's SRD. As related configuration entities (SIP Interfaces, IP Groups, Proxy Sets, Classification rules, and IP-to-IP Routing rules) are associated with the specific SRD, each SRD has its own logically separated configuration tables (although configured in the same tables). Therefore, full logical separation (on the SIP application layer) between tenants is achieved by SRD.

To create a multi-tenant configuration topology that is as non-bleeding as possible, you can configure an SRD (tenant) as *Isolated* and *Shared*:


- **Isolated SRD:** An Isolated SRD has its own dedicated SIP resources (SIP Interfaces, Proxy Sets, and IP Groups). No other SRD can use the SIP resources of an Isolated SRD. Thus, call traffic of an Isolated SRD is kept separate from other SRDs (tenants), preventing any risk of traffic “leakage” with other SRDs.

Isolated SRDs are more relevant when each tenant needs its own separate (dedicated) routing “table” for non-bleeding topology. Separate routing tables are implemented using Routing Policies. In such a non-bleeding topology, routing between Isolated SRDs is not possible. This enables accurate and precise routing per SRD, eliminating any possibility of erroneous call routing between SRDs, restricting routing to each tenant's (SRD's) sphere. Configuring only one Routing Policy that is shared between Isolated SRDs is not best practice for non-bleeding environments, since it allows routing between these SRDs.

- **Shared SRD:** Isolated SRDs have their own dedicated SIP resources (SIP Interfaces, Proxy Sets, and IP Groups). This may not be possible in some deployments. For example, in deployments where all tenants use the same SIP Trunking service, or use the same SIP Interface due to limited SIP interface resources (e.g., multiple IP addresses cannot be allocated and SIP port 5060 must be used). In contrast to Isolated SRDs, a Shared SRD can share its' SIP resources with all other SRDs (Shared and Isolated). This is typically required when tenants need to use common resources. In the SIP Trunk example, the SIP Trunk would be associated with a Shared SRD, enabling all tenants to route calls with the SIP Trunk.

Another configuration entity that can be used for multi-tenant deployments is the Routing Policy. Routing Policies allow each SRD (or tenant) to have its own routing rules, manipulation rules, Least Cost Routing (LCR) rules, and/or LDAP-based routing configuration. However, not all multi-tenant deployments need multiple Routing Policies and typically, their configuration is not required. Isolated SRDs are more relevant only when each tenant requires its own dedicated Routing Policy to create separate, dedicated routing "tables"; for all other scenarios, SRDs can be Shared. For more information on Routing Policies, see [Configuring SBC Routing Policies](#) on page 1108.

The figure below illustrates a multi-tenant architecture with Isolated SRD tenants ("A" and "B") and a Shared SRD tenant ("Data Center") serving as a SIP Trunk:



To facilitate multi-tenant configuration through CLI, you can access a specific tenant "view". Once in a specific tenant view, all configuration commands apply only to the currently viewed tenant. Only table rows (indexes) belonging to the viewed tenant can be modified. New table rows are automatically associated with the viewed tenant (i.e., SRD name). The display of tables and show running-configuration commands display only rows relevant to the viewed tenant (and shared tenants). The show commands display only information relevant to the viewed tenant. To support this CLI functionality, use the following commands:

- To access a specific tenant view:

```
# srd-view <SRD name>
```

Once accessed, the tenant's name (i.e., SRD name) forms part of the CLI prompt, for example:

```
# srd-view datacenter  
(srd-datacenter)#
```

- To exit the tenant view:

```
# no srd-view
```

## Cloning SRDs

You can clone (duplicate) existing SRDs. This is especially useful when operating in a multi-tenant environment and you need to add new tenants (SRDs). The new tenants can quickly and easily be added by simply cloning one of the existing SRDs. Once cloned, all you need to do is tweak configuration entities associated with the SRD clone.

When an SRD is cloned, the device adds the new SRD clone to the next available index row in the SRDs table. The SRD clone is assigned a unique name in the following syntax format: <unique clone ID>\_<original SRD index>\_CopyOf\_<name, or index if no name, of original SRD>. For example, if you clone SRD "SIP-Trunk" at index 2, the new SRD clone is assigned the name, "36454371\_2\_CopyOf\_SIP-Trunk".

The SRD clone has identical settings as the original SRD. In addition, all configuration entities associated with the original SRD are also cloned and these clones are associated with the SRD clone. The naming convention of these entities is the same as the SRD clone (see above) and all have the same unique clone ID ("36454371" in the example above) as the cloned SRD. These configuration entities include IP Groups, SIP Interfaces, Proxy Sets (without addresses), Classification rules, and Call Admission Control profiles. If the Routing Policy associated with the original SRD is not associated with any other SRD, the Routing Policy is also cloned and its' clone is associated with the SRD clone. All configuration entities associated with the original Routing Policy are also cloned and these clones are associated with the Routing Policy clone. These configuration entities include IP-to-IP Routing rules, Inbound Manipulation rules, and Outbound Manipulation rules.

When any configuration entity is cloned (e.g., an IP-to-IP Routing rule) as a result of a cloned SRD, all fields of the entity's row which "point" to other entities (e.g., SIP Interface, Source IP Group, and Destination IP Group) are replaced by their corresponding clones.



For some cloned entities such as SIP Interfaces, some parameter values may change. This occurs in order to avoid the same parameter having the same value in more than one table row (index), which would result in invalid configuration. For example, a SIP Interface clone will have an empty Network Interface setting. After the clone process finishes, you thus need to update the Network Interface for valid configuration.





#### ➤ To clone an SRD:

- Web interface: In the SRDs table, select an SRD to clone, and then click the **Clone** button.
- CLI:

```
(config-voip)# srd clone <SRD index that you want cloned>
```

### Color-Coding of SRDs in Web Interface

To easily identify your configured SRDs, the Web interface displays each SRD in a unique color. The color is automatically and randomly assigned to new SRDs and is displayed in a box alongside the name of the SRD in tables where the SRD is configured or assigned. This is applied throughout the Web interface. The following example shows SRDs assigned with unique color codes.

INDEX ↕	NAME
0	 DefaultSRD (#0)
1	 Comp-A (#1)
2	 Comp-B (#2)
3	 Comp-C (#3)

↑  
|  
|

### Automatic Configuration based on SRD

To facilitate configuration and eliminate possible flaws in configuration due to invalid associations between configuration entities, the Web interface automatically configures configuration entities based on SRD:

- If you delete an SRD (in the SRDs table) that is associated with other configuration entities in other tables, the device automatically deletes the associated table rows. For example, if you delete an SRD that is associated with a Proxy Set, the device automatically deletes the Proxy Set.



- If you associate an SRD with a configuration entity in another table (i.e., other than the SRDs table), the device automatically configures certain parameters of the configuration entity according to the SRD or associated SRD. For example, if you add a rule in the IP-to-IP Routing table and you select a Routing Policy, the 'Source IP Group' and 'Destination IP Group' parameters list only IP Groups that are associated with the SRD to which the Routing Policy is assigned (and IP Groups belonging to a Shared SRD, if exists).
- If your configuration setup includes only a single SRD, the device automatically selects the SRD when adding related configuration entities. For example, when adding an IP Group, the single SRD is automatically selected in the Add Row dialog box.

## Configuring SIP Interfaces

The SIP Interfaces table lets you configure up to 80 SIP Interfaces. A SIP Interface represents a Layer-3 network in your deployment environment, by defining a local, listening port number and type (e.g., UDP), and assigning an IP network interface for SIP signaling traffic. For example, if your deployment consists of an IP PBX in the LAN, a SIP Trunk in the WAN, and remote far-end users in the WAN, you would need to configure a SIP Interface for each of these SIP entities. You can configure SIP Interfaces for the different types of applications (SBC and Gateway). You can also configure various optional features for the SIP Interface such as assigning it a Media Realm, blocking calls received on the SIP Interface from users not registered with the device, and enabling direct media (media bypass).

Each SIP Interface can be associated with only one SRD. As the SRD configuration entity represents your VoIP deployment SIP network (Layer 5), you need to associate your SIP Interfaces with a specific SRD in order to represent your Layer-3 networks. For most deployments (except multi-tenant deployments), your SRD represents your entire network and thus, only one SRD is required. The device provides a default SRD and in such scenarios where only a single SRD is required, your SIP Interfaces are automatically assigned to the default SRD. Therefore, there is no need to even handle SRD configuration entity.

Once configured, you can apply SIP Interfaces to calls, by assigning them to the following configuration entities in their respective tables:

- (Mandatory) Proxy Set to specify the SIP Interface for communication with the proxy server (i.e., IP Group). For more information, see [Configuring Proxy Sets](#) on page 622.
- Intrusion Detection System (IDS) for applying the IDS policy to a specific SIP Interface. For more information, see [Configuring IDS Policies](#) on page 259.
- (SBC application only) IP-to-IP Routing rules for specifying the destination SIP Interface to where you want to route the call. For more information, see [Configuring SBC IP-to-IP Routing Rules](#) on page 1076.
- (SBC application only) Classification rules for specifying the SIP Interface as a matching characteristic of the incoming call. This is especially useful for the single SRD-configuration topology, where each SIP Interface represents a Layer-3 network (SIP entity). Therefore, classification of calls to IP Groups (SIP entities) can be based on SIP Interface.

The SIP Interface can also be used for tag-based classification of incoming SIP dialogs if the SIP Interface is configured with a Call Setup Rule Set ID that determines the source tag. For more information, see [Configuring Classification Based on Tags](#) on page 1073.

For more information on classification, see [Configuring Classification Rules](#) on page 1061.

- (Gateway application only) Tel-to-IP Routing rules for specifying the destination SIP Interface to where you want to route Tel-to-IP calls. For more information, see [Configuring Tel-to-IP Routing Rules](#) on page 914.
- (Gateway application only) IP-to-Trunk Group Routing rules for specifying the SIP Interface as a matching characteristics for the incoming IP call.



The device terminates active calls associated with a SIP Interface if you do one of the following:

- Delete the associated SIP Interface.
- Edit any of the following fields of the associated SIP Interface: 'Application Type', 'UDP Port', 'TCP Port', 'TLS Port' or 'SRD' fields.
- Edit or delete a network interface in the IP Interfaces table that is associated with the SIP Interface.

The following procedure describes how to configure SIP interfaces through the Web interface. You can also configure it through ini file [SIPInterface] or CLI (`configure voip > sip-interface`).

#### ➤ To configure a SIP Interface:

1. Open the SIP Interfaces table (**Setup** menu > **Signaling & Media** tab > **Core Entities** folder > **SIP Interfaces**).
2. Click **New**; the following dialog box appears:

3. Configure a SIP Interface according to the parameters described in the table below.
4. Click **Apply**.

**Table 18-5: SIP Interfaces table Parameter Descriptions**

Parameter	Description
'SRD' srd-name [SRDName]	<p>Assigns an SRD to the SIP Interface.</p> <p>If only one SRD is configured in the SRDs table, the SRD is assigned to the SIP Interface by default. If multiple SRDs are configured in the SRDs table, no value is defined and you must assign an SRD.</p> <p>To configure SRDs, see <a href="#">Configuring SRDs</a> on page 549.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> <li>■ You can assign the same SRD to multiple SIP Interfaces (SBC and Gateway).</li> </ul>
General	
'Index' [Index]	<p>Defines an index for the new table row.</p> <p><b>Note:</b> Each row must be configured with a unique index.</p>
'Name' interface-name [InterfaceName]	<p>Defines a descriptive name, which is used when associating the row in other tables.</p> <p>The valid value is a string of up to 40 characters. By default, if you do not configure a name, the device automatically assigns the name "&lt;row index&gt;" (e.g., "SIPInterface_1" when added to Index 1).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter value can't contain a forward slash (/).</li> <li>■ The parameter value can't be configured with the character string "any" (upper or lower case).</li> </ul>
'Topology Location' topology-location [TopologyLocation]	<p>Defines the display location of the SIP Interface in the Topology view in the Web interface.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Down</b> = (Default) The SIP Interface element is displayed on the lower border of the view.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [1] <b>Up</b> = The SIP Interface element is displayed on the upper border of the view.</li> </ul> <p>For more information on the Topology view, see <a href="#">Building and Viewing SIP Entities in Topology View</a> on page 643.</p>
'Network Interface' network-interface [NetworkInterface]	<p>Assigns an IP Interface to the SIP Interface. By default, no value is defined. To configure IP Interfaces, see <a href="#">Configuring IP Network Interfaces</a> on page 157.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> <li>■ The 'Application Type' parameter of the assigned IP Interface must at least include "Control".</li> </ul>
'Application Type' application-type [ApplicationType]	<p>Defines the application for which the SIP Interface is used.</p> <ul style="list-style-type: none"> <li>■ [0] <b>GW</b> = (Default) Gateway application.</li> <li>■ [2] <b>SBC</b> = SBC application.</li> </ul>
'UDP Port' udp-port [UDPPort]	<p>Defines the device's listening and source port for SIP signaling traffic over UDP. The valid range is 1 to 65534. The default is 5060.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The port number <b>must</b> be different from ports configured for RTP traffic (i.e., ports configured for Media Realms and Media Realm Extensions) using the same IP network interface. For example, if the RTP port range is 6000 to 6999, the SIP port can either be less than 6000 or greater than 6999.</li> <li>■ Each SIP Interface must have a unique UDP signaling port within its underlying network interface (i.e., no port overlapping between such SIP Interfaces). For example:</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>✓ Valid configuration: <ul style="list-style-type: none"> <li>• SIP Interface #0: 'UDP Port' = 6010; 'Network Interface' = #0</li> <li>• SIP Interface #1: 'UDP Port' = 6010; 'Network Interface' = #1</li> </ul> </li> <li>✓ Invalid configuration: <ul style="list-style-type: none"> <li>• SIP Interface #0: 'UDP Port' = 6010; 'Network Interface' = #0</li> <li>• SIP Interface #1: 'UDP Port' = 6010; 'Network Interface' = #0</li> </ul> </li> </ul>
'TCP Port' tcp-port [TCPPort]	<p>Defines the device's listening port for SIP signaling traffic over TCP.</p> <p>The valid range is 1 to 65534. The default is 5060.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the specific SIP Interface, the TCP port number must be different from the TLS port number (configured by the 'TLS Port' parameter below).</li> <li>■ The port must be different from the TCP port configured for Media Realms and Media Realm Extensions that use the same IP Interface.</li> <li>■ The source ports used for outgoing TCP connections are not configurable and are dynamically determined by the device in the range of 32,768-61,000.</li> <li>■ Each SIP Interface must have a unique TCP signaling port within its underlying network interface (i.e., no port overlapping between such SIP Interfaces). For example: <ul style="list-style-type: none"> <li>✓ Valid configuration: <ul style="list-style-type: none"> <li>• SIP Interface #0: 'TCP Port' = 6010; 'Network Interface' = #0</li> <li>• SIP Interface #1: 'TCP Port' =</li> </ul> </li> </ul> </li> </ul>

Parameter	Description
	<p>6010; 'Network Interface' = #1</p> <p>✓ Invalid configuration:</p> <ul style="list-style-type: none"> <li>• SIP Interface #0: 'TCP Port' = 6010; 'Network Interface' = #0</li> <li>• SIP Interface #1: 'TCP Port' = 6010; 'Network Interface' = #0</li> </ul>
<p>'TLS Port'</p> <p>tls-port</p> <p>[TLSPort]</p>	<p>Defines the device's listening port for SIP signaling traffic over TLS.</p> <p>The valid range is 1 to 65534. The default is 5061.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the specific SIP Interface, the TLS port number must be different from the TCP port number (configured by the 'TCP Port' parameter above).</li> <li>■ The port must be different from the TCP port configured for Media Realms and Media Realm Extensions that use the same IP Interface.</li> <li>■ The source ports used for outgoing TLS connections are not configurable and are dynamically determined by the device in the range of 32,768-61,000.</li> <li>■ Each SIP Interface must have a unique TLS signaling port within its underlying network interface (i.e., no port overlapping between such SIP Interfaces). For example:</li> </ul> <p>✓ Valid configuration:</p> <ul style="list-style-type: none"> <li>• SIP Interface #0: 'TLS Port' = 6020; 'Network Interface' = #0</li> <li>• SIP Interface #1: 'TLS Port' = 6020; 'Network Interface' = #1</li> </ul> <p>✓ Invalid configuration:</p> <ul style="list-style-type: none"> <li>• SIP Interface #0: 'TLS Port' = 6020; 'Network Interface' = #0</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>• SIP Interface #1: 'TLS Port' = 6020; 'Network Interface' = #0</li> </ul>
'Additional UDP Ports' additional-udp-ports [AdditionalUDPPorts]	<p>Defines a port range for the device's local, listening and source ports for SIP signaling traffic over UDP. The parameter can be used for the following features:</p> <ul style="list-style-type: none"> <li>■ Assigning a unique port per registered user (User-type IP Group) on the leg interfacing with the proxy server (Server-type IP Group). For enabling this feature and for more information, see the 'User UDP Port Assignment' parameter in the IP Groups table.</li> <li>■ Assigning a specific local port to each SIP entity (e.g., PBX) communicating with a common SIP entity (e.g., proxy server). This is the port on the leg interfacing with the proxy server. In other words, the SIP Interface associated with the proxy server. For more information, see <a href="#">Configuring Specific UDP Ports using Tag-based Routing</a> on page 1098</li> <li>■ Assigning a unique port for each Account registering with the same Serving IP Group (registrar server). For more information, see <a href="#">Configuring Registration Accounts</a> on page 750.</li> </ul> <p>The valid range is 1,025 to 65535. The range is configured using the syntax x-y, where x is the starting port and y the ending port of the range (e.g., 6000-7000). By default, the parameter is not configured.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the SBC application.</li> <li>■ To configure whether the device keeps the configured ports (sockets) open or opens them only when needed, use the SIP Interface's 'Additional UDP Ports</li> </ul>

Parameter	Description
	<p>Mode' parameter (below).</p> <ul style="list-style-type: none"> <li>■ The parameter's port range value must not overlap with the UDP port, which is configured by the 'UDP Port' parameter. For example, if the 'UDP Port' parameter is configured to 5070, you cannot configure the 'Additional UDP Ports' parameter with a range of 5060-6000.</li> <li>■ The parameter's port range value must not overlap with UDP port ranges of Media Realms and Media Realm Extensions that are configured on the same network interface. For example, if the RTP port range is 6000-6999, you must configure the 'Additional UDP Ports' parameter to a range that is less than 6000 or greater than 6999.</li> <li>■ The maximum number of ports in the range is limited to the maximum number of licensed registered SBC users as specified in the License Key installed on the device, or the maximum number of IP Groups that can be configured (see <a href="#">Configuring IP Groups</a> on page 581) - the higher of the two determines it. For example, if the License Key allows 20 users and the maximum IP Groups that can be configured is 10, then the maximum number of ports is 20.</li> </ul>
'Additional UDP Ports Mode' additional-udp-ports-mode [AdditionalUDPPortsMode]	<p>Enables the device to open sockets (ports) for signaling only when needed. The parameter applies to the Additional UDP Port feature with dynamic port allocation (see the 'Additional UDP Ports' parameter, above). This allows you to configure the additional UDP port range without having to make sure that the total number of configured ports are within the maximum, as defined by the device's License Key.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Always Open</b> = (Default) The device</li> </ul>



Parameter	Description
	<p>keeps the ports (sockets) that are configured in the SIP Interface's 'Additional UDP Ports' parameter, open all the time.</p> <ul style="list-style-type: none"> <li>■ <b>[1] Open When Used</b> = For the ports (sockets) that are configured in the SIP Interface's 'Additional UDP Ports' parameter, the device opens a port only when it is used. A port is needed when the device initiates registration with an external SIP entity for a SIP Account (sent to the Account's Serving IP Group), or forwards a registration request from a user (IP Group) to a proxy (Server-type IP Group). This option is applicable only to dynamic port allocation, where a port is allocated on the outgoing REGISTER message and closed when the registration expires. For HA systems, upon a switchover, all the ports used in the active device are also opened on the redundant device (now active), so that the SIP entity is reachable. Ports that are not configured by the SIP Interface's 'Additional UDP Ports' parameter are closed. The option is applicable only when the SIP Interface's 'Additional UDP Ports' parameter is configured and enabled for a Server-type IP Group (IP Group's 'User UDP Port Assignment' parameter) and/or SIP Account (Account's 'UDP Port Assignment' parameter).</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the SBC application.</li> <li>■ For static port allocation (i.e., using additional UDP ports feature for assigning a specific local port to each SIP entity), configure the parameter to <b>Always Open</b>.</li> </ul>

Parameter	Description
'Enable TCP Keepalive' <code>tcp-keepalive-enable</code> [TCPKeepaliveEnable]	<p>Enables the TCP Keep-Alive mechanism with the IP entity on this SIP Interface. TCP keep-alive can be used, for example, to keep a NAT entry open for clients located behind a NAT server, or simply to check that the connection to the IP entity is available.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p><b>Note:</b> To configure TCP keepalive, use the following parameters: [TCPKeepAliveTime], [TCPKeepAliveInterval], and [TCPKeepAliveRetry].</p>
'Used By Routing Server' <code>used-by-routing-server</code> [UsedByRoutingServer]	<p>Enables the SIP Interface to be used by ARM for call routing decisions.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Not Used</b> (default)</li> <li>■ [1] <b>Used</b></li> </ul> <p>For more information on routing by ARM, see <a href="#">Centralized Routing by ARM (AudioCodes Routing Manager)</a> on page 442.</p>
'Pre-Parsing Manipulation Set' <code>pre-parsing-man-set</code> [PreParsingManSetName]	<p>Assigns a Pre-Parsing Manipulation Set to the SIP Interface. This lets you apply pre-parsing SIP message manipulation rules on any incoming SIP message received on this SIP Interface.</p> <p>By default, no Pre-Parsing Manipulation Set is assigned.</p> <p>To configure Pre-Parsing Manipulation Sets, see <a href="#">Configuring Pre-Parsing Manipulation Rules</a> on page 843.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Pre-Parsing Manipulation is done only on incoming calls.</li> <li>■ The device performs Pre-Parsing Manipulation before Pre-Classification Manipulation and Classification.</li> </ul>

Parameter	Description
'CAC Profile' cac-profile [AdmissionProfile]	<p>Assigns a Call Admission Control Profile (CAC rules) to the SIP Interface.</p> <p>By default, no value is defined.</p> <p>To configure CAC Profiles, see <a href="#">Configuring Call Admission Control</a> on page 1054.</p>
Classification	
'Classification Failure Response Type' classification-fail-response-type [ClassificationFailureResponseType]	<p>Defines the SIP response code that the device sends if a received SIP request (OPTIONS, REGISTER, or INVITE) fails the SBC Classification process.</p> <p>The valid value can be a SIP response code from 400 through 699, or it can be set to 0 to not send any response at all. The default response code is 500 (Server Internal Error).</p> <p>This feature is important for preventing Denial of Service (DoS) attacks, typically initiated from the WAN. Malicious attackers can use SIP scanners to detect ports used by SIP devices. These scanners scan devices by sending UDP packets containing a SIP request to a range of specified IP addresses, listing those that return a valid SIP response. Once the scanner finds a device that supports SIP, it extracts information from the response and identifies the type of device (IP address and name) and can execute DoS attacks. A way to defend the device against such attacks is to not send a SIP reject response to these unclassified "calls" so that the attacker assumes that no device exists at such an IP address and port.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if you configure the device to reject unclassified calls, which is done using the 'Unclassified Calls' parameter (see <a href="#">Configuring Classification Rules</a> on page 1061).</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>

Parameter	Description
'Pre Classification Manipulation Set ID' preclassification-manset [PreClassificationManipulationSet]	<p>Assigns a Message Manipulation Set ID to the SIP Interface. This lets you apply SIP message manipulation rules on incoming SIP initiating-dialog request messages (not in-dialog), received on this SIP Interface, prior to the Classification process.</p> <p>By default, no Message Manipulation Set ID is defined.</p> <p>To configure Message Manipulation rules, see <a href="#">Configuring SIP Message Manipulation</a> on page 829.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The Message Manipulation Set assigned to a SIP Interface that is associated with an outgoing call, is ignored. Only the Message Manipulation Set assigned to the associated IP Group is applied to the outgoing call.</li> <li>■ If both the SIP Interface and IP Group associated with the incoming call are assigned a Message Manipulation Set, the one assigned to the SIP Interface is applied first.</li> <li>■ If Classification fails or the request is rejected prior to the Classification stage, then manipulation rules according to this parameter are applied to the reject response. In this case, the device adds a Reason header to the reject response. If routing fails, manipulation on the reject response is according to the 'Outbound Message Manipulation Set' parameter of the classified IP Group. When a Reason header is added to the reject response, its value is according to the type of failure: <ul style="list-style-type: none"> <li>✓ Routing failure: "General Routing Failure"</li> <li>✓ Classification failure: "Classification Failure"</li> </ul> </li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>✓ Pre-Classification rejection due to device overload: "Board In Overload"</li> <li>✓ Pre-Classification rejection due to locked device: "Board Is Locked"</li> <li>✓ Pre-Classification rejection due to too many SIP headers in the request: "Header Overflow"</li> <li>✓ Post-Classification failure of a REGISTER request when the source IP Group doesn't allow registers from the IP Group: "IPGroup Registration Mode Configuration"</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
'Call Setup Rules Set ID' call-setup-rules-set-id [CallSetupRulesSetId]	<p>Assigns a Call Setup Rules Set ID to the SIP Interface. The Call Setup Rule is run before the Classification stage.</p> <p>By default, no Call Setup Rules Set ID is defined.</p> <p>To configure Call Setup Rules, see <a href="#">Configuring Call Setup Rules</a> on page 782.</p> <p>Call Setup Rules can be used for Classification of incoming calls to IP Groups based on tags (source), as described in <a href="#">Configuring Classification Based on Tags</a> on page 1073.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Call Setup Rules that are triggered from the SIP Interfaces table are done after identifying the incoming SIP Interface, but before classification, manipulation and routing. Call Setup Rules can run asynchronous queries for services such as LDAP, ENUM, and HTTP, as well as synchronous queries such as Dial Plan queries. For example, an asynchronous query can be sent to an external HTTP server (AudioCodes ARM) for a source tag, which can then be used to classify</li> </ul>

Parameter	Description
	<p>the incoming SIP INVITE request to a source IP Group.</p> <ul style="list-style-type: none"> <li>■ Call Setup Rules can be used to generated source and destination tags. For classification, only source tags are used.</li> <li>■ Using Call Setup Rules with the SIP Interface is suitable for actions that affect the source and the Classification of SIP dialog requests (such as modifying source tags or modifying the From header). It's not suitable for actions that affect the destination of the request and its routing (such as modifying the Request-URI header) because it might conflict with other features.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
'Classify By Registration DB' classify-by-reg-db [ClassifyByRegDB]	<p>Enables classification to IP Groups of incoming SIP dialog-initiating requests (e.g., INVITE) by the device's users registration database.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = Disables classification of incoming dialog-initiating SIP requests by the users registration database. The device skips this classification stage and attempts to classify the SIP request by Proxy Set. If this classification stage fails, the device attempts classification by the Classification table (see <a href="#">Configuring Classification Rules</a> on page 1061).</li> <li>■ [1] <b>Enable</b> = (Default) Enables classification of incoming dialog-initiating SIP requests by the users registration database.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
Media	

Parameter	Description
'Media Realm' media-realm-name [MediaRealm]	<p>Assigns a Media Realm to the SIP Interface. By default, no value is defined.</p> <p>To configure Media Realms, see <a href="#">Configuring Media Realms</a> on page 539.</p>
'Direct Media' sbc-direct-media [SBCDirectMedia]	<p>Enables direct media (RTP/SRTP) flow or media bypass (i.e., no Media Anchoring) between endpoints associated with the SIP Interface for SBC calls.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) Media Anchoring is employed, whereby the media stream traverses the device (and each leg uses a different coder or coder parameters).</li> <li>■ [1] <b>Enable</b> = Direct Media is enabled (i.e., no Media Anchoring). Media stream flows directly between the endpoints (i.e., doesn't traverse the device).</li> <li>■ [2] <b>Enable when Same NAT</b> = Direct Media is enabled (i.e., no Media Anchoring). Media stream flows directly between the endpoints if they are located behind the same NAT.</li> </ul> <p>For more information on direct media, see <a href="#">Direct Media Calls</a> on page 1033.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If the parameter is enabled for direct media and the two endpoints belong to the same SIP Interface, calls cannot be established if the following scenario exists: <ul style="list-style-type: none"> <li>✓ One of the endpoints is defined as a foreign user (for example, “follow me service”)</li> <li>✓ and one endpoint is located on the WAN and the other on the LAN.</li> </ul> </li> </ul> <p>The reason for the above is that in direct media, the device doesn't interfere in the SIP signaling such as manipulation of IP addresses, which is necessary for calls</p>

Parameter	Description
	<p>between LAN and WAN.</p> <ul style="list-style-type: none"> <li>■ To enable direct media for all calls, use the global parameter [SBCDirectMedia]. If the global parameter is enabled but the SIP Interface is disabled for direct media, direct media is employed for calls belonging to the SIP Interface. If the global parameter is disabled and the SIP Interface is enabled for direct media, direct media is employed for calls belonging to the SIP Interface.</li> <li>■ If you enable direct media for the SIP Interface, make sure that your Media Realm provides sufficient ports, as media may traverse the device for mid-call services (e.g., call transfer).</li> <li>■ If you have configured a SIP Recording rule (see <a href="#">SIPREC SIP-based Media Recording</a> on page 330) for calls associated with this SIP Interface, the device automatically disables direct media for these calls (during their SIP signaling setup). This ensures that the media passes through the device so that it can be recorded and sent to the SRS. However, if you enable direct media using the [SBCDirectMedia] global parameter (i.e., for all calls), direct media is always enforced and calls will not be recorded.</li> <li>■ Regardless of this parameter's settings, the device always handles calls whose incoming SIP dialog-initiating request (e.g., INVITE message) contains the proprietary SIP header 'X-AC-Action' with the value 'direct-media' (i.e., 'X-AC-Action: direct-media'), as direct media calls. These calls remain as direct media calls until they end.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>



Parameter	Description
'MSRP TCP Port' <code>msrp-tcp-port</code> [MSRPTCPPort]	<p>Defines the listening TCP port for MSRP sessions.</p> <p>The valid range is 4000 to 32768. The default is 0.</p> <p>The port number is used in the SDP's 'a=path' line.</p> <p>For more information on MSRP, see <a href="#">Configuring Message Session Relay Protocol</a> on page 1141.</p> <p><b>Note:</b> The port number must be unique for the SIP Interface (i.e., different to 'MSRP TLS Port', 'UDP Port', 'TCP Port' and 'TLS Port' parameters).</p>
'MSRP TLS Port' <code>msrp-tls-port</code> [MSRPTLSPort]	<p>Defines the listening TLS port for secured MSRP sessions (MSRPS).</p> <p>The valid range is 4000 to 32768. The default is 0.</p> <p>The port number is used in the SDP body's 'a=path' line.</p> <p>For more information on MSRP, see <a href="#">Configuring Message Session Relay Protocol</a> on page 1141.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The port number must be unique for the SIP Interface (i.e., different to 'MSRP TCP Port', 'UDP Port', 'TCP Port' and 'TLS Port' parameters).</li> <li>■ For MSRPS, you also need to assign a TLS Context to the SIP Interface (see 'TLS Context Name' parameter below).</li> </ul>
Security	
'TLS Context Name' <code>tls-context-name</code> [TLSContext]	<p>Assigns a TLS Context (TLS configuration) to the SIP Interface.</p> <p>The default TLS Context ("default" at Index 0) is assigned to the SIP Interface by default.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For incoming calls: The assigned TLS</li> </ul>

Parameter	Description
	<p>Context is used if no TLS Context is configured for the Proxy Set associated with the call or classification to an IP Group based on Proxy Set fails.</p> <ul style="list-style-type: none"> <li>■ For outgoing calls: The assigned TLS Context is used if no TLS Context is configured for the Proxy Set associated with the call.</li> <li>■ To configure TLS Contexts, see <a href="#">TLS Certificates</a> on page 224.</li> </ul>
'TLS Mutual Authentication' tls-mutual-auth [TLSMutualAuthentication]	<p>Enables TLS mutual authentication for the SIP Interface (when the device acts as a server).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = Device doesn't request the client certificate for TLS connection on the SIP Interface.</li> <li>■ [1] <b>Enable</b> = Device requires receipt and verification of the client certificate to establish the TLS connection on the SIP Interface.</li> </ul> <p>By default, no value is defined and the global 'TLS Mutual Authentication' parameter [SIPSRequireClientCertificate] is applied.</p>
'Message Policy' message-policy-name [MessagePolicyName]	<p>Assigns a SIP message policy to the SIP interface.</p> <p>To configure SIP Message Policy rules, see <a href="#">Configuring SIP Message Policy Rules</a> on page 840.</p>
'User Security Mode' block-un-reg-users [BlockUnRegUsers]	<p>Defines the blocking (reject) policy for incoming SIP dialog-initiating requests (e.g., INVITE messages) from registered and unregistered users belonging to the SIP Interface.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> = (Default) The corresponding parameter in the SRDs table ('User Security Mode') of the SRD that is associated with the SIP Interface is applied.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [0] <b>Accept All</b> = Accepts requests from registered and unregistered users.</li> <li>■ [1] <b>Accept Registered Users</b> = Accepts requests only from users registered with the device. Requests from users not registered are rejected.</li> <li>■ [2] <b>Accept Registered Users from Same Source</b> = Accepts requests only from registered users whose source address is the same as that registered with the device (during the REGISTER message process). All other requests are rejected. If the transport protocol is UDP, the device verifies the IP address and port; otherwise, it verifies only the IP address. The verification is performed before any of the device's call handling processes (i.e., Classification, Manipulation and Routing).</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to calls belonging to User-type IP Groups.</li> <li>■ The feature is not applicable to REGISTER requests.</li> <li>■ The option, Accept Registered Users from Same Source [2] doesn't apply to registration refreshes. These requests are accepted even if the source address is different to that registered with the device.</li> <li>■ When the device rejects a call, it sends a SIP 500 "Server Internal Error" response to the user. In addition, it reports the rejection (Dialog establish failure - Classification failure) using the Intrusion Detection System (IDS) feature (see <a href="#">Configuring IDS Policies</a> on page 259), by sending an SNMP trap.</li> <li>■ If you configure the parameter to any</li> </ul>

Parameter	Description
	value other than default [-1], it overrides the corresponding parameter in the SRDs table ('User Security Mode') for the SRD associated with the SIP Interface.
'Enable Un-Authenticated Registrations' enable-un-auth-registrs [EnableUnAuthenticatedRegistrations]	<p>Enables the device to accept REGISTER requests and register them in its registration database from new users that have not been authenticated by a proxy/registrar server (due to proxy down) and thus, re-routed to a User-type IP Group.</p> <p>In normal operation scenarios in which the proxy server is available, the device forwards the REGISTER request to the proxy and if authenticated by the proxy (i.e., device receives a success response), the device adds the user to its registration database. The routing to the proxy is according to the SBC IP-to-IP Routing table where the destination is the proxy's IP Group. However, when the proxy is unavailable (e.g., due to network connectivity loss), the device can accept REGISTER requests from new users if a matching alternative routing rule exists in the SBC IP-to-IP Routing table where the destination is the user's User-type IP Group (i.e., call survivability scenarios) and if the parameter is enabled.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> = (Default) The corresponding parameter in the SRDs table ('Enable Un-Authenticated Registrations') of the SRD associated with the SIP Interface is applied.</li> <li>■ [0] <b>Disable</b> = The device rejects REGISTER requests from new users that were not authenticated by a proxy server.</li> <li>■ [1] <b>Enable</b> = The device accepts REGISTER requests from new users even if they were not authenticated by a proxy server, and registers the user in its registration database.</li> </ul>

Parameter	Description
	<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Regardless of the parameter, the device always accepts registration refreshes from users that are already registered in its database.</li> <li>■ If configured to Disable or Enable, the parameter overrides the 'Enable Un-Authenticated Registrations' parameter settings of the SRD (in the SRDs table) that is associated with the SIP Interface.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
'Max. Number of Registered Users' max-reg-users [MaxNumOfRegUsers]	<p>Defines the maximum number of users belonging to the SIP Interface that can register with the device.</p> <p>By default, no value is defined (i.e., the number of allowed user registrations is unlimited).</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>

## Configuring IP Groups

The IP Groups table lets you configure up to 80 IP Groups. An IP Group represents a SIP entity in the network with which the device communicates. This can be a server (e.g., IP PBX or ITSP) or a group of users (e.g., LAN IP phones). For servers, the address of the IP Group is typically defined by associating it with a Proxy Set (see [Configuring Proxy Sets](#) on page 622).

You can use IP Groups for the following:

- (SBC Application ) Classifying incoming SIP dialog-initiating requests (e.g., INVITE messages) to IP Groups based on Proxy Set. If the source address of the incoming SIP dialog is defined for a Proxy Set, the device assigns ("bonds") the SIP dialog to the IP Group associated with the Proxy Set. The feature is configured using the IP Groups table's 'Classify by Proxy Set' parameter.
- (SBC Application ) Classifying incoming SIP dialog-initiating requests (e.g., INVITE messages) to IP Groups based on source tags of the incoming dialog. Tag-based classification occurs only if Classification based on user registration and on Proxy Set fail. For more information, see [Configuring Classification Based on Tags](#) on page 1073.

- (SBC Application) Representing the source and destination of calls in IP-to-IP Routing rules (see [Configuring SBC IP-to-IP Routing Rules](#) on page 1076).
- SIP dialog registration and authentication (digest user/password) of specific IP Groups (Served IP Group, e.g., corporate IP-PBX) with other IP Groups (Serving IP Group, e.g., ITSP). This is configured in the Accounts table (see [Configuring Registration Accounts](#) on page 750).
- (Gateway Application) Call routing rules:
  - Tel-to-IP calls: The IP Group is used as the destination of the outgoing IP call and is used in Tel-to-IP call routing rules (see [Configuring Tel-to-IP Routing Rules](#) on page 914).
  - IP-to-Tel calls: The IP Group identifies the source of the IP call and is used in IP-to-Tel call routing rules (see [Configuring IP-to-Tel Routing Rules](#) on page 928).
  - Number manipulation: The IP Group can be associated with a number manipulation rule (see [Configuring Source-Destination Number Manipulation Rules](#) on page 950).
- Included in routing decisions by ARM. If necessary for routing, ARM can even create an IP Group. For more information, see [Centralized Routing by ARM \(AudioCodes Routing Manager\)](#) on page 442.

You can also apply the device's Quality of Experience feature to IP Groups:

- **Quality of Experience Profile:** Call quality monitoring based on thresholds for voice metrics (e.g., MOS) can be applied per IP Group. For example, if MOS is considered poor, calls belonging to this IP Group can be rejected. To configure Quality of Experience Profiles, see [Configuring Quality of Experience Profiles](#) on page 519.
- **Bandwidth Profile:** Bandwidth utilization thresholds can be applied per IP Group. For example, if bandwidth thresholds are crossed, the device can reject any new calls on this IP Group. To configure Bandwidth Profiles, see [Configuring Bandwidth Profiles](#) on page 526.



- For the Gateway application, regarding table row index #0:
  - ✓ it is recommended to **not** configure any IP Group in table row index #0. This index number entity is not supported by certain device functionality (e.g., not counted in performance monitoring).
  - ✓ IP Group in row index #0 cannot be associated with Proxy Set row index #0.
  - ✓ If no IP Group exists in the IP Groups table, the device rejects all Gateway calls. Even if you are not using IP Groups to route calls, IP Group row index #0 (default) must exist for the device to route calls.
- If you delete an IP Group or modify the 'Type' or 'SRD' parameters, the device immediately terminates currently active calls that are associated with the IP Group. In addition, all users belonging to the IP Group are removed from the device's users database.

The following procedure describes how to configure IP Groups through the Web interface. You can also configure it through ini file [IPGroup] or CLI (`configure voip > ip-group`).

➤ **To configure an IP Group:**

1. Open the IP Groups table (**Setup** menu > **Signaling & Media** tab > **Core Entities** folder > **IP Groups**).
2. Click **New**; the following dialog box appears:

3. Configure an IP Group according to the parameters described in the table below.
4. Click **Apply**.

**Table 18-6: IP Groups Table Parameter Descriptions**

Parameter	Description
'SRD' srd-name [SRDName]	<p>Assigns an SRD to the IP Group.</p> <p>If only one SRD is configured in the SRDs table, the SRD is assigned by default. If multiple SRDs are configured in the SRDs table, no value is assigned by default and you must assign one.</p> <p>To configure SRDs, see <a href="#">Configuring SRDs</a> on page 549.</p> <p><b>Note:</b> The parameter is mandatory.</p>
<b>General</b>	
'Index' [Index]	<p>Defines an index for the new table row.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the Gateway application, regarding table row index <b>#0</b>: <ul style="list-style-type: none"> <li>✓ It is recommended to <b>not</b> configure any IP Group in table row index <b>#0</b> (even though it is considered valid configuration). This index number is not supported by certain device functionality (e.g., not counted in performance monitoring).</li> <li>✓ IP Group in row index <b>#0</b> cannot be associated with Proxy Set row index <b>#0</b>.</li> </ul> </li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>✓ If no IP Group exists in the IP Groups table, the device <b>rejects</b> all Gateway calls. Even if you are not using IP Groups to route calls, IP Group row index #0 (default) must exist for the device to route calls. However, if you have deleted all IP Groups, the device returns IP Group #0 after a device restart.</li> <li>■ Each row must be configured with a unique index.</li> </ul>
'Name' name [Name]	<p>Defines a descriptive name, which is used when associating the row in other tables.</p> <p>The valid value is a string of up to 40 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Configure each row with a unique name.</li> <li>■ The parameter value can't contain a forward slash (/).</li> <li>■ The parameter value can't be configured with the character string "any" (upper or lower case).</li> </ul>
'Topology Location' topology-location [TopologyLocation]	<p>Defines the display location of the IP Group in the Topology view of the Web interface.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Down</b> = (Default) The IP Group element is displayed on the lower border of the view.</li> <li>■ [1] <b>Up</b> = The IP Group element is displayed on the upper border of the view.</li> </ul> <p>For more information on the Topology view, see <a href="#">Building and Viewing SIP Entities in Topology View</a> on page 643.</p>
'Type' type [Type]	<p>Defines the type of IP Group.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Server</b> = Applicable when the destination address of the IP Group (e.g., ITSP, Proxy, IP-PBX, or Application server) is known. The address is configured by the Proxy Set that is associated with the IP Group.</li> <li>■ [1] <b>User</b> = Represents a group of users such as IP phones and softphones where their location is dynamically obtained by the device when REGISTER requests and responses traverse (or are terminated) by the device. These users are considered remote (far-end).</li> </ul> <p>Typically, this IP Group is configured with a Serving IP</p>



Parameter	Description
	<p>Group that represents an IP-PBX, Application or Proxy server that serves this <b>User</b>-type IP Group. Each SIP request sent by a user of this IP Group is proxied to the Serving IP Group. For registrations, the device updates its registration database with the AOR and contacts of the users.</p> <p>Digest authentication using SIP 401/407 responses (if needed) is performed by the Serving IP Group. The device forwards these responses directly to the SIP users.</p> <p>To route a call to a registered user, a rule must be configured in the Tel-to-IP Routing table or SBC IP-to-IP Routing table. The device searches the dynamic database (by using the Request-URI) for an entry that matches a registered AOR or Contact. Once an entry is found, the IP destination is obtained from this entry and a SIP request is sent to the destination.</p> <p>The device also supports NAT traversal for the SIP clients located behind NAT. In this case, the device must be defined with a global IP address.</p> <p>■ [2] <b>Gateway</b> = (Applicable only to the SBC application)</p> <p>In scenarios where the device receives requests to and from a gateway representing multiple users. This IP Group type is necessary for any of the following scenarios:</p> <ul style="list-style-type: none"> <li>✓ The IP Group cannot be defined as a <b>Server</b>-type since its address is initially unknown and therefore, a Proxy Set cannot be configured for it.</li> <li>✓ The IP Group cannot be defined as a <b>User</b>-type since the SIP Contact header of the incoming REGISTER doesn't represent a specific user. The Request-URI user part can change and therefore, the device is unable to identify an already registered user and therefore, adds an additional record to the database.</li> </ul> <p>The IP address of the Gateway-type IP Group is obtained dynamically from the host part of the Contact header in the REGISTER request received from the IP Group. Therefore, routing to this IP Group is possible only once a REGISTER request is received (i.e., IP Group is registered with the device). If a REGISTER refresh</p>

Parameter	Description
	<p>request arrives, the device updates the new location (i.e., IP address) of the IP Group. If the REGISTER fails, no update is performed. If an UN-REGISTER request arrives, the IP address associated with the IP Group is deleted and therefore, no routing to the IP Group is done.</p> <p>You can view the registration status of the Gateway-type IP Group in the 'GW Group Registered Status' field, and view the IP address of the IP Group in the 'GW Group Registered IP Address' field if it is registered with the device.</p>
'Proxy Set' proxy-set-name [ProxySetName]	<p>Assigns a Proxy Set to the IP Group. All INVITE messages destined to the IP Group are sent to the IP address configured for the Proxy Set.</p> <p>To configure Proxy Sets, see <a href="#">Configuring Proxy Sets</a> on page 622.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the Gateway application, IP Group ID 0 cannot be associated with Proxy Set ID 0.</li> <li>■ The Proxy Set must be associated with the same SRD as that assigned to the IP Group.</li> <li>■ You can assign the same Proxy Set to multiple IP Groups.</li> <li>■ For the SBC application: Proxy Sets are used for <b>Server</b>-type IP Groups, but may in certain scenarios also be used for <b>User</b>-type IP Groups. For example, this is required in deployments where the device mediates between an IP PBX and a SIP Trunk, and the SIP Trunk requires SIP registration for each user that requires service. In such a scenario, the device must register all the users to the SIP Trunk on behalf of the IP PBX. This is done by using the SBC User Information table, where each user is associated with the source IP Group (i.e., the IP PBX). To configure the SBC User Information table, see <a href="#">Configuring SBC User Information</a> on page 775.</li> <li>■ For the Gateway application, Proxy Sets are applicable only to Server-type IP Groups.</li> </ul>
'IP Profile'	Assigns an IP Profile to the IP Group.

Parameter	Description
ip-profile-name [ProfileName]	<p>By default, no value is defined.</p> <p>To configure IP Profiles, see <a href="#">Configuring IP Profiles</a> on page 664.</p>
'Media Realm' media-realm-name [MediaRealm]	<p>Assigns a Media Realm to the IP Group. The Media Realm determines the UDP port range and maximum sessions on a specific IP interface for media traffic associated with the IP Group.</p> <p>By default, no value is defined.</p> <p>To configure Media Realms, see <a href="#">Configuring Media Realms</a> on page 539.</p> <p><b>Note:</b> If you delete a Media Realm in the Media Realms table that is assigned to the IP Group, the parameter value reverts to undefined.</p>
'Internal Media Realm' internal-media-realm-name [InternalMediaRealm]	<p>Assigns an "internal" Media Realm to the IP Group. This is applicable when the device is deployed in a Microsoft Teams environment. The device selects this Media Realm (instead of the Media Realm assigned by the 'Media Realm' parameter above) if the value of the X-MS-UserLocation header in the incoming SIP message is "Internal" and the 'Teams Local Media Optimization Handling' parameter (see below) is configured to any value other than <b>None</b>.</p> <p>The Media Realm determines the UDP port range and maximum sessions on a specific IP interface for media traffic associated with the IP Group.</p> <p>By default, no value is defined.</p> <p>To configure Media Realms, see <a href="#">Configuring Media Realms</a> on page 539.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if you have configured the 'Teams Local Media Optimization Handling' parameter (see below) to any value other than <b>None</b>.</li> <li>■ If you delete a Media Realm in the Media Realms table that is assigned to the IP Group, the parameter value reverts to undefined.</li> <li>■ If you don't configure the parameter, the device uses the Media Realm that you assigned by the 'Media Realm' parameter.</li> </ul>
'Contact User'	Defines the user part of the From, To, and Contact headers

Parameter	Description
contact-user [ContactUser]	<p>of SIP REGISTER messages, and the user part of the Contact header of INVITE messages received from this IP Group and forwarded by the device to another IP Group.</p> <p>The valid value is a string of up to 60 characters. By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to <b>Server</b>-type IP Groups.</li> <li>■ The parameter is overridden by the 'Contact User' parameter in the Accounts table (see <a href="#">Configuring Registration Accounts</a> on page 750).</li> </ul>
'SIP Group Name' sip-group-name [SIPGroupName]	<p>Defines the hostname (e.g., 194.90.179.0) which the device uses to overwrite the original host part of the URI in certain SIP headers. Therefore, the parameter allows you to implement topology hiding in SIP messages, by concealing the host part of the communicating UAs from each another.</p> <p>For the SBC application: The affected SIP headers depend on whether the IP Group is the destination or source of the call:</p> <ul style="list-style-type: none"> <li>■ <b>Destination IP Group:</b> The device overwrites the host part of the following SIP headers for messages sent (outgoing) to this IP Group:               <ul style="list-style-type: none"> <li>✓ For all requests: Request-URI header (if the destination of the request isn't a registered user or Trunk Group, and the URL in the Request-URI is not GRUU) and P-Called-Party-ID header.</li> <li>✓ For all non-REGISTER requests (e.g., INVITE and SUBSCRIBE): To header and Remote-Party-ID header (only the first Remote-Party-ID header whose type is "called" in the message).</li> <li>✓ For INVITE requests only: If the 'Destination URI Input' parameter is configured for the source IP Group, the header type configured by the 'Destination URI Input' parameter is also modified according to the 'SIP Group Name' parameter of the destination IP Group.</li> </ul> </li> <li>■ <b>Source IP Group:</b> The device overwrites the host part of the following SIP headers for messages received</li> </ul>

Parameter	Description
	<p>(incoming) from this IP Group.</p> <ul style="list-style-type: none"> <li>✓ For all types of requests: From header.</li> <li>✓ For REGISTER requests: To header.</li> <li>✓ For all non-REGISTER requests (e.g., INVITE and SUBSCRIBE): P-Preferred-Identity (only first P-Preferred-Identity header in message), P-Asserted-Identity (only first P-Asserted-Identity header in message), Remote-Party-ID (only the first Remote-Party-ID header whose type is "calling" in the message).</li> <li>✓ For INVITE requests only: If the 'Source URI Input' parameter is configured for the source IP Group, the header type configured by the 'Source URI Input' parameter is also overwritten according to the 'SIP Group Name' parameter of the source IP Group.</li> </ul> <p>The valid value is a string of up to 100 characters. By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the SBC application: When the IP Group is the source of the call, if you configure the destination IP Group's 'SIP Source Host Name' parameter (see below), the device ignores the 'SIP Group Name' parameter of the source IP Group. (The 'SIP Source Host Name' parameter also defines a URI host part to overwrite the original source host part, but it affects many more source-related SIP headers.)</li> <li>■ When the parameter is configured for the source or destination IP Group, it overrides Inbound Message Manipulation rules (assigned by the 'Inbound Message Manipulation Set' parameter to the source IP Group) that manipulate the host part in the Request-URI, To, and From SIP headers. If you configure the parameter and you want to manipulate the host part in any of these SIP headers, assign your Message Manipulation rules to the destination IP Group using the 'Outbound Message Manipulation Set' parameter.</li> <li>■ For the Gateway application: The parameter is not applicable when the IP Group is the source of the call.</li> </ul>

Parameter	Description
	<p>When the parameter is configured for the destination IP Group, the device uses the configured value to overwrite the host part in the Request-URI and To headers of INVITE requests, and the Request-URI of REGISTER requests sent (outgoing) to this IP Group.</p> <ul style="list-style-type: none"> <li>■ For the Gateway application: If the IP Group is of User type, the parameter is used internally as a host name in the Request-URI for Tel-to-IP initiated calls. For example, if an incoming call from the device's trunk is routed to a <b>User</b>-type IP Group, the device first creates the Request-URI (&lt;destination_number&gt;@&lt;SIP Group Name&gt;), and then it searches the registration database for a match.</li> </ul>
'Created By Routing Server' [CreatedByRoutingServer]	<p>(Read-only) Indicates if the IP Group was created by ARM:</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b></li> <li>■ [1] <b>Yes</b></li> </ul> <p>For more information on routing by ARM, see <a href="#">Centralized Routing by ARM (AudioCodes Routing Manager)</a> on page 442.</p>
'Used By Routing Server' used-by-routing-server [UsedByRoutingServer]	<p>Enables the IP Group to be used by ARM for call routing decisions.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Not Used</b> (default)</li> <li>■ [1] <b>Used</b></li> </ul> <p>For more information on routing by ARM, see <a href="#">Centralized Routing by ARM (AudioCodes Routing Manager)</a> on page 442.</p>
'Proxy Set Connectivity' show voip proxy sets status [ProxySetConnectivity]	<p>(Read-only field) Displays the connectivity status with <b>Server</b>-type IP Groups. As the Proxy Set defines the address of the IP Group, the connectivity check (keep-alive) by the device is done to this address.</p> <ul style="list-style-type: none"> <li>■ "NA": Functionality is not applicable due to one of the following: <ul style="list-style-type: none"> <li>✓ <b>User</b>-type IP Group.</li> <li>✓ <b>Server</b>-type IP Group, but the keep-alive mechanism of its' associated Proxy Set is disabled.</li> </ul> </li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ "Not Connected": Keep-alive failure (i.e., no connectivity with the IP Group).</li> <li>■ "Connected": Keep-alive success (i.e., connectivity with the IP Group).</li> </ul> <p>The connectivity status is also displayed in the Topology View page (see <a href="#">Building and Viewing SIP Entities in Topology View</a> on page 643).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The feature is applicable only to <b>Server</b>-type IP Groups.</li> <li>■ To support the feature, you must enable the keep-alive mechanism of the Proxy Set that is associated with the IP Group (see <a href="#">Configuring Proxy Sets</a> on page 622).</li> <li>■ If the Proxy Set is configured with multiple proxies (addresses) and at least one of them is "alive", the displayed status is "Connected". To view the connected proxy server, see <a href="#">Viewing Proxy Set Status</a> on page 1357.</li> <li>■ The "Connected" status also applies to scenarios where the device rejects calls with the IP Group due to low QoE (e.g., low MOS), despite connectivity.</li> </ul>
SBC General	
'Classify By Proxy Set' classify-by-proxy-set [ClassifyByProxySet]	<p>Enables the classification of incoming SIP dialog messages to a <b>Server</b>-type IP Group based on Proxy Set.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b></li> <li>■ [1] <b>Enable</b> = (Default) Enables classification by Proxy Set of all types of incoming SIP dialog messages (e.g., INVITE, OPTIONS, and REGISTER) to a <b>Server</b>-type IP Group.</li> </ul> <p>By default, the device checks if the <b>source IP address</b> (ISO Layer 3) of the incoming SIP dialog matches an IP address in the Proxy Set that is associated with the IP Group (see the 'Proxy Set' parameter). If the Proxy Set is configured with a hostname, the device checks if the source IP address matches one of the dynamically DNS-resolved IP addresses. If such a Proxy Set exists, the device classifies the SIP dialog to the IP Group associated with this Proxy Set.</p>

Parameter	Description
	<p>You can also configure classification by Proxy Set whereby the device checks if the IP address in the <b>SIP Contact header</b> of the incoming SIP dialog matches an IP address in the Proxy Set that is associated with the IP Group. If the header contains a SIP URI that has an IP address (not hostname) in the host part and it matches an IP address in the Proxy Set, the call is classified to the IP Group. This mode is useful, for example, when the source IP address is an internal address.</p> <p>To specify which IP address to use (source IP address or SIP Contact header's IP address) in the incoming SIP message for classification by Proxy Set, use the global parameter 'Classify By Proxy Set Mode' (<b>Setup</b> menu &gt; <b>Signaling &amp; Media</b> tab &gt; <b>SIP Definitions</b> folder &gt; <b>SIP Definitions General Settings</b>). When configured to <b>Both</b>, the device first checks if the source IP address matches an IP address in the Proxy Set. Only if there is no match, does it check if the IP address in the SIP Contact header matches an IP address in the Proxy Set.</p> <ul style="list-style-type: none"> <li>■ [2] <b>Enable for OPTIONS</b> = Enables classification by Proxy Set of incoming SIP OPTIONS (only) messages to a <b>Server</b>-type IP Group. For a detailed description of this option, see the description of the <b>Enable</b> value (above).</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to <b>Server</b>-type IP Groups.</li> <li>■ For security, it's recommended to classify SIP dialogs based on Proxy Set only if the IP address of the IP Group is unknown (i.e., if the Proxy Set associated with the IP Group is configured with an FQDN). In such cases, the device classifies incoming SIP dialogs to the IP Group based on the DNS-resolved IP address.</li> </ul> <p>If the IP address is known, it's recommended to use Classification rules instead (and disable the Classify by Proxy Set feature), where the rules are configured with not only the IP address, but also with SIP message characteristics to increase the strictness of the classification process (see <a href="#">Configuring Classification Rules</a> on page 1061).</p> <p>The reason for preferring classification based on Proxy</p>



Parameter	Description
	<p>Set when the IP address is unknown is that IP address forgery (commonly known as IP spoofing) is more difficult than malicious SIP message tampering and therefore, using a Classification rule without an IP address offers a weaker form of security. When classification is based on Proxy Set, the Classification table for the specific IP Group is ignored.</p> <ul style="list-style-type: none"> <li>■ If you have assigned the same Proxy Set to multiple IP Groups, disable the parameter and use Classification rules instead to classify incoming SIP dialogs to these IP Groups (see <a href="#">Configuring Classification Rules</a> on page 1061). If the parameter is enabled, the device is unable to correctly classify incoming INVITEs to their appropriate IP Groups.</li> <li>■ Classification by Proxy Set occurs only if classification based on the device's registration database fails (i.e., INVITE isn't from a registered user).</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
'Validate Source IP' validate-source-ip [ValidateSourceIP]	<p>Enables the device to validate the source IP address of incoming SIP dialog-initiating requests (e.g., INVITE messages) by checking that it matches an IP address (or DNS-resolved IP address) in the Proxy Set that is associated with the IP Group.</p> <p>The feature applies both to messages that were classified to IP Groups by Proxy Set (i.e., by configuring the IP Group's 'Classify By Proxy Set' parameter to <b>Enable</b>), as well as to messages classified by rules in the Classification table (see <a href="#">Configuring Classification Rules</a> on page 1061).</p> <p>This feature is especially useful when you need to classify SIP dialogs originating from the same Proxy Set, into multiple IP Groups, where Classification table rules are necessary to produce the desired mapping to the different IP Groups.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Validation is done after Classification, but before Manipulation and Routing.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ Validation is done for the IP address only (not port, transport, or SIP Interface).</li> <li>■ Upon validation failure, the device rejects the incoming SIP dialog with a 500 SIP response (Reason header value is "Source IP doesn't match Proxy Set").</li> <li>■ Don't enable this parameter if the global 'Classify By Proxy Set Mode' parameter is configured to <b>Contact Header</b> or <b>Both</b>, as in most cases, the source IP address of the SIP message will not be a member of the Proxy Set.</li> <li>■ This feature is typically used for <b>Server</b>-type IP Groups. However, you can also use it for <b>User</b>-type IP Groups.</li> </ul>
'SBC Operation Mode' sbc-operation-mode [SBCOperationMode]	<p>Defines the device's operational mode for the IP Group.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> = (Default)</li> <li>■ [0] <b>B2BUA</b> = Device operates as a back-to-back user agent (B2BUA), changing the call identifiers and headers between the inbound and outbound legs.</li> <li>■ [1] <b>Call Stateful Proxy</b> = Device operates as a Stateful Proxy, passing the SIP message transparently between inbound and outbound legs. In other words, the same SIP dialog identifiers (tags, Call-Id and CSeq) occur on both legs (as long as no other configuration disrupts the CSeq compatibleness).</li> </ul> <p>■</p> <p>For more information on B2BUA and Stateful Proxy modes, see <a href="#">B2BUA and Stateful Proxy Operating Modes</a> on page 1021.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If configured, the parameter overrides the 'SBC Operation Mode' parameter in the SRDs table.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
'SBC Client Forking Mode' sbc-client-forking-mode [EnableSBCCClientForking]	<p>Defines call forking of INVITE messages to up to five separate SIP outgoing legs for <b>User</b>-type IP Groups. This occurs if multiple contacts are registered under the same AOR in the device's registration database.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Sequential</b> = (Default) Sequentially sends the INVITE</li> </ul>

Parameter	Description
	<p>to each contact. If there is no answer from the first contact, it sends the INVITE to the second contact, and so on until a contact answers. If no contact answers, the call fails or is routed to an alternative destination, if configured.</p> <ul style="list-style-type: none"> <li>■ [1] <b>Parallel</b> = Sends the INVITE simultaneously to all contacts. The call is established with the first contact that answers.</li> <li>■ [2] <b>Sequential Available Only</b> = Sequentially sends the INVITE only to available contacts (i.e., not busy). If there is no answer from the first available contact, it sends the INVITE to the second contact, and so on until a contact answers. If no contact answers, the call fails or is routed to an alternative destination, if configured.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The device can also fork INVITE messages received for a Request-URI of a specific contact (user) registered in the database to all other users located under the same AOR as the specific contact. This is configured by the [SBCSendInviteToAllContacts] parameter.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
'CAC Profile' cac-profile [AdmissionProfile]	<p>Assigns a Call Admission Control Profile (CAC rules) to the IP Group.</p> <p>By default, no value is defined.</p> <p>To configure CAC Profiles, see <a href="#">Configuring Call Admission Control</a> on page 1054.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
'SIP Source Host Name' sip-source-host-name [SIPSourceHostName]	<p>Defines a hostname, which the device uses to overwrite the hostname of the URI in certain SIP headers. The parameter allows you to implement topology hiding for the source of SIP messages, by concealing the hostname of the source UA.</p> <p>The valid value is a string of up to 100 characters. By default, no value is defined.</p> <p>When the device forwards a SIP message to this IP Group, the configured hostname overwrites the host part in SIP headers (see below) that are concerned with the source of</p>

Parameter	Description
	<p>the message:</p> <ul style="list-style-type: none"> <li>■ From, P-Asserted-Identity, P-Preferred-Identity, Referred-By, P-Charge-Info, Remote-Party-ID, P-Associated-URI, Diversion, and History-info headers.</li> <li>■ If you configure the global parameter 'SIP Topology Hiding Mode' parameter to <b>Fallback to IP Addresses</b> and the 'Remote REFER Mode' parameter to <b>Regular</b> (default), the host part in the Refer-To header is also overwritten.</li> <li>■ For REGISTER requests, the host part in the To header is also overwritten.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only when the IP Group is the destination of the call (not source).</li> <li>■ This parameter has higher priority than the 'SIP Group Name' parameter (see above) of the source IP Group. When this parameter is configured, the device ignores the value of the 'SIP Group Name' parameter that is configured for the source IP Group.</li> <li>■ The parameter is applicable only to SIP dialog-initiating requests and in-dialog REFER requests.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
<b>Advanced</b>	
<p>'Local Host Name'</p> <p><code>local-host-name</code></p> <p>[ContactName]</p>	<p>Defines the host name (string) that the device uses in the SIP message's Via and Contact headers. This is typically used to define an FQDN as the host name. The device uses this string for Via and Contact headers in outgoing INVITE messages sent to a specific IP Group, and the Contact header in SIP 18x and 200 OK responses for incoming INVITE messages received from a specific IP Group. The IP-to-Tel Routing table can be used to identify the source IP Group from where the INVITE message was received.</p> <p>If the parameter is not configured, these headers are populated with the device's dotted-decimal IP address of the network interface on which the message is sent.</p> <p>By default, no value is defined.</p> <p><b>Note:</b> To ensure proper device handling, the parameter</p>

Parameter	Description
	should be a valid FQDN.
'UI Format' uui-format [UIFormat]	<p>Enables the generation of the Avaya UCID value, adding it to the outgoing INVITE sent to this IP Group.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disabled</b> (default)</li> <li>■ [1] <b>Enabled</b></li> </ul> <p>This provides support for interworking with Avaya equipment by generating Avaya's UCID value in outgoing INVITE messages sent to Avaya's network. The device adds the UCID in the User-to-User SIP header.</p> <p>Avaya's UCID value has the following format (in hexadecimal): 00 + FA + 08 + node ID (2 bytes) + sequence number (2 bytes) + timestamp (4 bytes)</p> <p>This is interworked in to the SIP header as follows:</p> <p>User-to-User: 00FA080019001038F725B3;encoding=hex</p> <p><b>Note:</b> To define the Network Node Identifier of the device for Avaya UCID, use the 'Network Node ID' (NetworkNodeId) parameter.</p>
'Always Use Src Address' always-use-source-addr [AlwaysUseSourceAddr]	<p>Enables the device to always send SIP requests and responses, within a SIP dialog, to the source IP address received in the previous SIP message packet. This feature is especially useful in scenarios where the IP Group endpoints are located behind a NAT firewall (and the device is unable to identify this using its regular NAT mechanism).</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) The device sends SIP requests according to the settings of the global parameter, SIPNatDetection.</li> <li>■ [1] <b>Yes</b> = The device sends SIP requests and responses to the source IP address received in the previous SIP message packet.</li> </ul> <p>For more information on NAT traversal, see <a href="#">SIP User Agent Located behind NAT</a> on page 181.</p>
SBC Advanced	
'Source URI Input' src-uri-input [SourceUriInput]	<p>Defines the SIP header in the incoming INVITE that is used for call matching characteristics based on source URIs.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> (default)</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [0] <b>From</b></li> <li>■ [1] <b>To</b></li> <li>■ [2] <b>Request-URI</b></li> <li>■ [3] <b>P-Asserted - First Header</b></li> <li>■ [4] <b>P-Asserted - Second Header</b></li> <li>■ [5] <b>P-Preferred</b></li> <li>■ [6] <b>Route</b></li> <li>■ [7] <b>Diversion</b></li> <li>■ [8] <b>P-Associated-URI</b></li> <li>■ [9] <b>P-Called-Party-ID</b></li> <li>■ [10] <b>Contact</b></li> <li>■ [11] <b>Referred-by</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the SBC application.</li> <li>■ The parameter is applicable only when classification is done according to the Classification table (see <a href="#">Configuring Classification Rules</a> on page 1061).</li> <li>■ Once classified, the device uses the URI of the selected header for the following SIP headers in the outgoing INVITE: From, P-Asserted (if exists), P-Preferred (if exists), and Remote-Party-ID (if exists).</li> <li>■ If the configured SIP header doesn't exist in the incoming INVITE message, the classification of the message to a source IP Group fails.</li> <li>■ If the device receives an INVITE as a result of a REFER request or a 3xx response, then the incoming INVITE is routed according to the Request-URI. The device identifies such INVITEs according to a specific prefix in the Request-URI header, configured by the SBCXferPrefix parameter. Therefore, in this scenario, the device ignores the parameter setting.</li> </ul>
'Destination URI Input' dst-uri-input [DestUriInput]	Defines the SIP header in the incoming INVITE to use as a call matching characteristic based on destination URIs. The parameter is used for classification and routing purposes.

Parameter	Description
	<p>The device first uses the parameter's settings as a matching characteristic (input) to classify the incoming INVITE to an IP Group (source IP Group) in the Classification table. Once classified, the device uses the parameter for routing the call. For example, if set to To, the URI in the To header of the incoming INVITE is used as a matching characteristic for classifying the call to an IP Group in the Classification table. Once classified, the device uses the URI in the To header as the destination.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> (default)</li> <li>■ [0] <b>From</b></li> <li>■ [1] <b>To</b></li> <li>■ [2] <b>Request-URI</b></li> <li>■ [3] <b>P-Asserted - First Header</b></li> <li>■ [4] <b>P-Asserted - Second Header</b></li> <li>■ [5] <b>P-Preferred</b></li> <li>■ [6] <b>Route</b></li> <li>■ [7] <b>Diversion</b></li> <li>■ [8] <b>P-Associated-URI</b></li> <li>■ [9] <b>P-Called-Party-ID</b></li> <li>■ [10] <b>Contact</b></li> <li>■ [11] <b>Referred-By</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the SBC application.</li> <li>■ The parameter can be configured for an IP Group regardless of the way in which SIP requests are classified to the IP Group (by Classification table, by Proxy Set or by the Registration database).</li> <li>■ The Request-URI in the outbound side is modified according to the header selected by this parameter (if this parameter is configured), unless the Request-URI is overridden again by some other feature (e.g., Outbound Message Manipulations).</li> <li>■ If the configured SIP header doesn't exist in the incoming INVITE message, the classification of the</li> </ul>

Parameter	Description
	<p>message to a source IP Group fails.</p> <ul style="list-style-type: none"> <li>■ If the device receives an INVITE as a result of a REFER request or a 3xx response, the incoming INVITE is routed according to the Request-URI. The device identifies such INVITEs according to a specific prefix in the Request-URI header, configured by the SBCXferPrefix parameter. Therefore, in this scenario, the device ignores the parameter setting.</li> </ul>
'SIP Connect' sip-connect [SIPConnect]	<p>Defines the IP Group as representing multiple registering servers, each of which may use a single registration, yet represent multiple users. In addition, it defines how the device saves registration information for REGISTER messages received from the IP Group, in its registration database. For requests routed to the IP Group's users, the device replaces the Request-URI header with the incoming To header (which contains the remote phone number).</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) Disables the SIP Connect feature. No extra key based on source IP address is added to the registration database and registration is done by Contact and Address of Record (AoR).</li> <li>■ [1] <b>Yes</b> = Enables the SIP Connect feature. For initial registrations that are received from the IP Group, the device attempts to add two keys representing the user to its registration database: <ul style="list-style-type: none"> <li>✓ Key 1: The first key contains the incoming REGISTER message's source IP address, port (only if UDP), and SIP Interface ID (e.g., "10.33.3.3:5010#1").</li> <li>✓ Key 2: The second key contains the incoming REGISTER message's URI (user@host) of the Contact header, source IP address, port (only if UDP), and SIP Interface ID (e.g., "user@host.com#10.33.3.3:5010#1").</li> </ul> </li> </ul> <p>The device classifies incoming non-REGISTER SIP dialog requests (e.g., INVITEs) from this IP Group, by first using the regular user search method in the registration database by Contact-AoR pair matching. If unsuccessful, the device searches the registration database for a matching Key 2 (i.e., Contact URI, source IP address, and port if the transport type is UDP). If no matching Key 2 exists,</p>



Parameter	Description
	<p>the device then searches for a matching Key 1 (i.e., source IP address only and port if the transport type is UDP). If no key is found at all, the device continues with the next Classification stage (e.g., by Proxy Set).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to <b>User</b>-type IP Groups.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
'SBC PSAP Mode' sbc-psap-mode [SBCPSAPMode]	<p>Enables E9-1-1 emergency call routing in a Microsoft Skype for Business environment.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p>For more information, see <a href="#">E9-1-1 Support for Microsoft Teams and Skype for Business</a> on page 489.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
'Route Using Request URI Port' use-requri-port [SBCRouteUsingRequestURI Port]	<p>Enables the device to use the port indicated in the Request-URI of the incoming message as the destination port when routing the message to the IP Group. The device uses the IP address (and not port) that is configured for the Proxy Set associated with the IP Group. The parameter thus allows the device to route calls to the same server (IP Group), but different port.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) The port configured for the associated Proxy Set is used as the destination port.</li> <li>■ [1] <b>Enable</b> = The port indicated in the Request-URI of the incoming message is used as the destination port.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
'Media TLS Context' dtls-context [DTLSContext]	<p>Assigns a TLS Context (TLS configuration) to the IP Group that is used for secured media sessions with the IP Group. The default is the default TLS Context ("default" at Index 0). To configure TLS Contexts, see <a href="#">TLS Certificates</a> on page 224.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>

Parameter	Description
'Keep Original Call-ID' sbc-keep-call-id [SBCKeepOriginalCallID]	<p>Enables the device to use the same call identification (SIP Call-ID header value) received in incoming messages for the call identification in outgoing messages. The call identification value is contained in the SIP Call-ID header.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) The device creates a new Call-ID value for the outgoing message.</li> <li>■ [1] <b>Yes</b> = The device uses the same Call-ID value received in the incoming message for the Call-ID in the outgoing message.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the SBC application.</li> <li>■ When the device sends an INVITE as a result of a REFER/3xx termination, the device always creates a new Call-ID value and ignores the parameter's settings.</li> </ul>
'Dial Plan' sbc-dial-plan-name [SBCDialPlanName]	<p>Assigns a Dial Plan to the IP Group.</p> <p>The device searches the Dial Plan for a dial plan rule that matches the prefix of the source number and if not found, it searches for a rule that matches the prefix of the destination number. If a matching Dial Plan rule is found, the rule's tag is used in the routing or manipulation processes as the source or destination tag.</p> <p>To configure Dial Plans, see <a href="#">Configuring Dial Plans</a> on page 798.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the SBC application.</li> <li>■ For destination tag-based routing (i.e., 'Destination Type' parameter of IP-to-IP Routing rules configured to <b>Destination Tag</b>): <ul style="list-style-type: none"> <li>✓ The parameter is applicable only to the source IP Group. The device searches the Dial Plan for a dial plan rule that matches the prefix of the destination number only.</li> <li>✓ If a destination tag is determined during the routing stage by a Call Setup Rule (i.e., Call Setup Rule Set assigned to the IP-to-IP Routing rule's 'Pre Route Call Setup Rules Set ID' parameter), the tag overrides any other determined tag (i.e., from the Dial Plan or Call Setup Rule Set of the SIP Interface).</li> </ul> </li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>✓ For more information on tag-based routing, see <a href="#">Using Destination Tags for Choosing Routing Destinations</a> on page 815.</li> </ul>
'Call Setup Rules Set ID' call-setup-rules-set-id [CallSetupRulesSetId]	<p>Assigns a Call Setup Rule Set ID to the IP Group. The device runs the Call Setup rule immediately before the routing stage (i.e., only after the classification and manipulation stages).</p> <p>By default, no value is assigned.</p> <p>To configure Call Setup Rules, see <a href="#">Configuring Call Setup Rules</a> on page 782.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Call Setup Rules that are triggered from the IP Groups table (incoming IP Group) are done after identifying the incoming SIP Interface and after classification and manipulation for identifying the incoming IP Group, but before the routing stage (IP-to-IP Routing table). This supports all types of queries (Dial Plan, LDAP, ENUM, and HTTP).</li> <li>■ For destination tag-based routing (i.e., 'Destination Type' parameter of IP-to-IP Routing rules configured to <b>Destination Tag</b>):               <ul style="list-style-type: none"> <li>✓ If a destination tag is determined during the routing stage by a Call Setup Rule (i.e., Call Setup Rule Set assigned to the IP-to-IP Routing rule's 'Pre Route Call Setup Rules Set ID' parameter), the tag overrides any other determined tag (i.e., from the Dial Plan or Call Setup Rule Set of the SIP Interface).</li> <li>✓ For more information on tag-based routing, see <a href="#">Using Destination Tags for Choosing Routing Destinations</a> on page 815.</li> </ul> </li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
'Tags' tags [Tags]	<p>Defines tags (name=value or value only), which can be implemented in one of the following ways:</p> <ul style="list-style-type: none"> <li>■ <b>Classification based on source tags:</b> If the tag (name=value or value only) is the same tag as that of the incoming SIP dialog (obtained from the Call Setup Rule associated with the SIP Interface on which the dialog is received) and configured in the Classification</li> </ul>

Parameter	Description
	<p>table, then the incoming dialog is classified to this IP Group. For more information, see <a href="#">Configuring Classification Based on Tags</a> on page 1073.</p> <ul style="list-style-type: none"> <li>■ <b>Routing based on destination tags:</b> If this tag is matched, the device sends the incoming SIP dialog to this IP Group. The parameter is used when IP-to-IP Routing rules are configured for destinations-based on tags (i.e., 'Destination Type' parameter configured to <b>Destination Tag</b>). For more information on tag-based routing, see <a href="#">Using Destination Tags for Choosing Routing Destinations</a> on page 815.</li> </ul> <p>The valid value is:</p> <ul style="list-style-type: none"> <li>■ A string of up to 70 characters.</li> <li>■ Up to five tags, where each tag is separated by a semicolon (;).</li> <li>■ Up to four tags containing a name with a value (e.g., Country=Ireland).</li> <li>■ Only <b>one</b> tag containing a value only (e.g., Ireland).</li> <li>■ You can configure multiple tags with the same name (e.g., Country=Ireland;Country=Scotland).</li> </ul> <p>The following example configures the maximum number of tags (i.e., four name=value tags and one value-only tag): Country=Ireland;Country=Scotland;Country=RSA;Country=Canada;USA.</p> <p><b>Note:</b> For tag-based classification, if multiple IP Groups are configured with the same tag, the device classifies the incoming SIP dialog to the first matching IP Group.</p>
'SBC Alternative Routing Reasons Set' sbc-alt-route-reasons-set [SBCAltRouteReasonsSetName]	<p>Assigns an Alternative Reasons Set to the IP Group. This defines SIP response codes, which if received by the device from the IP Group, triggers alternative routing. Alternative routing could mean trying to send the SIP message to another online proxy (address) that is configured for the Proxy Set associated with the IP Group, or sending it to an alternative IP-to-IP Routing rule. For configuring Alternative Reasons Sets and for more information on how the device performs alternative routing, see <a href="#">Configuring SIP Response Codes for Alternative Routing Reasons</a> on page 1104.</p> <p>By default, no value is defined.</p>

Parameter	Description
	<p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<p>'Teams Local Media Optimization Handling'</p> <p>teams-local-media-optimization-handling</p> <p>[TeamsLocalMediaOptimization]</p>	<p>Enables and defines Local Media Optimization handling when the central SBC device (proxy SBC scenario) is deployed in a Microsoft Teams environment. Handling is based on supplementary information provided in the SIP message by Microsoft proprietary SIP headers, X-MS-UserLocation, X-MS-MediaPath and X-MS-UserSite.</p> <ul style="list-style-type: none"> <li>■ [0] <b>None</b> = (Default) The device ignores the proprietary Microsoft headers for Teams in the SIP message and uses the "regular" Media Realm assigned by the IP Group's 'Media Realm' parameter for the call (i.e., regular call processing).</li> <li>■ [1] <b>Teams Decides</b> or [2] <b>SBC Decides</b> = The device's call handling depends on Teams headers and call direction: <ul style="list-style-type: none"> <li>✓ Inbound calls to Teams (PSTN-to-Teams): The device sends the initial INVITE message using the settings of the 'Teams Local Media Optimization Initial Behavior' parameter. When a SIP 200 OK is received in response, the device uses the X-MS-MediaPath header to determine if it's a direct media call. For these calls, the device never uses the Dial Plan Region Connectivity feature (see <a href="#">Using Dial Plans for Microsoft Local Media Optimization</a> on page 825).</li> <li>✓ Outbound calls from Teams (Teams-to-PSTN): If the parameter is configured to <b>Teams Decides</b> and the call is the primary (initial) route, the device uses the X-MS-MediaPath header to determine if it is a direct media call. For secondary routes (e.g., 3xx, alternative route, call forking, or transfer) or if the parameter is configured to <b>SBC Decides</b>, the device uses the X-MS-UserLocation and X-MS-UserSite headers together with the 'Regions Connectivity Dial Plan' parameter to determine if it's a direct media call (see <a href="#">Using Dial Plans for Microsoft Local Media Optimization</a> on page 825).</li> </ul> </li> </ul> <p>The X-MS-UserLocation and X-MS-MediaPath headers can change upon re-INVITE messages (such as for conference calls).</p>

Parameter	Description
	<p>If the call is a <b>non-primary</b> route (e.g., alternative route, 3xx, or forking), the device only uses the X-MS-UserLocation header in the incoming INVITE message, which it uses to select the appropriate Media Realm (as explained previously for primary routes). For non-primary routes, the media traverses the device (i.e., no direct media).</p> <p>For an overview of Microsoft Teams Local Media Optimization feature, see <a href="#">Microsoft Teams with Local Media Optimization</a> on page 511.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<p>'Teams Local Media Optimization Initial Behavior'</p> <p>teams-local-mo-initial-behavior</p> <p>[TeamsLocalMOInitialBehavior]</p>	<p>Defines how the central SBC device (proxy SBC scenario) initially sends the received INVITE message with the SDP Offer to Teams when the device is deployed in a Microsoft Teams environment for its Local Media Optimization feature. The parameter is applicable when the device receives the SDP Offer from a remote site SBC and the 'Teams Local Media Optimization Handling' parameter is configured to <b>Teams Decides</b> or <b>SBC Decides</b>.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Direct Media</b> = (Default) The device sends the SDP Offer as is to Teams, indicating that the call is intended to be a direct media call (i.e., doesn't traverse the device).</li> <li>■ [1] <b>Internal</b> = The device sends the SDP Offer using the internal Media Realm (see the IP Group's 'Internal Media Realm' parameter) to Teams, indicating that the call is intended to be a non-direct media call (i.e., media traverses the central SBC device).</li> <li>■ [2] <b>External</b> = The device sends the SDP Offer using the external (regular) Media Realm (see the IP Group's 'Media Realm' parameter) to Teams, indicating that the call is intended to be a non-direct media call (i.e., media traverses the central SBC device).</li> </ul> <p>For an overview of Microsoft Teams Local Media Optimization feature, see <a href="#">Microsoft Teams with Local Media Optimization</a> on page 511.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>

Parameter	Description
<p>'Teams Local Media Optimization Site'</p> <p>teams-local-mo-site</p> <p>[TeamsLocalMOSite]</p>	<p>Defines the name of the Teams site (e.g., "Singapore") within which the Teams client is located, when the device is deployed in a Microsoft Teams environment for its Local Media Optimization feature. The Teams site is indicated in the Microsoft proprietary SIP header, X-MS-UserSite of the incoming SIP message received from the Teams client.</p> <p>The device searches the Dial Plan, specified by the 'Regions Connectivity Dial Plan' parameter, to check if this IP Group's Teams site and the Teams site of the destination IP Group share a common group number. If they do share a group number, it means that the path between them is good for high quality voice and the device considers the call as intended for direct media (bypass). For more information, see <a href="#">Using Dial Plans for Microsoft Local Media Optimization</a> on page 825.</p> <p>For an overview of Microsoft Teams Local Media Optimization feature, see <a href="#">Microsoft Teams with Local Media Optimization</a> on page 511.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to Teams-to-PSTN calls.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
<p>'Teams Direct Routing Mode'</p> <p>teams-direct-routing-mode</p> <p>[TeamsDirectRoutingMode]</p>	<p>Enables the device to include Microsoft's proprietary X-MS-SBC header in outgoing SIP INVITE and OPTIONS messages in a Microsoft Teams Direct Routing environment. The header is used by Microsoft Teams to identify vendor equipment (e.g., AudioCodes SBC).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) The device doesn't include the header in the outgoing SIP message.</li> <li>■ [1] <b>Enable</b> = The device includes the header in the outgoing SIP message. The header's value is displayed in the format 'AudioCodes/&lt;model&gt;/&lt;firmware&gt;', where: <ul style="list-style-type: none"> <li>✓ <i>model</i> is the product name of your AudioCodes device (valid values are listed by Microsoft at <a href="https://docs.microsoft.com/en-us/microsoftteams/direct-routing-border-controllers">https://docs.microsoft.com/en-us/microsoftteams/direct-routing-border-controllers</a>).</li> <li>✓ <i>firmware</i> is the software version running on the device.</li> </ul> </li> </ul>

Parameter	Description
	<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>You can't modify or remove the header using Message Manipulation.</li> <li>The parameter is applicable only to the SBC application.</li> </ul>
'Metering Remote Type' metering-remote-type [MeteringRemoteType]	<p>Defines if the IP Group represents the VoiceAI Connect entity.</p> <ul style="list-style-type: none"> <li>[0] <b>Regular</b> = (Default) The IP Group represents a normal SIP proxy entity.</li> <li>[1] <b>VAIC</b> = The IP Group represents VoiceAI Connect.</li> </ul> <p><b>Note:</b> Leave the parameter at its default setting (i.e., <b>Regular</b>). The parameter is used only by AudioCodes support.</p>
Quality of Experience	
'QoE Profile' qoe-profile [QOEProfile]	<p>Assigns a Quality of Experience Profile rule.</p> <p>By default, no value is defined.</p> <p>To configure Quality of Experience Profiles, see <a href="#">Configuring Quality of Experience Profiles</a> on page 519.</p>
'Bandwidth Profile' bandwidth-profile [BWProfile]	<p>Assigns a Bandwidth Profile rule.</p> <p>By default, no value is defined.</p> <p>To configure Bandwidth Profiles, see <a href="#">Configuring Bandwidth Profiles</a> on page 526.</p>
'User Voice Quality Report' user-voice-quality-report [UserVoiceQualityReport]	<p>Enables MOS calculation and reporting of calls belonging to users that are registered with the device.</p> <ul style="list-style-type: none"> <li>[0] <b>Disable</b> (Default)</li> <li>[1] <b>Enable</b></li> </ul> <p>For more information on this feature, see <a href="#">Configuring Voice Quality for Registered Users</a> on page 535.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>This parameter is applicable only to <b>User</b>-type IP Groups.</li> <li>If you have configured a Quality of Service rule for rejecting calls or using an alternative IP Profile if MOS levels become low (see <a href="#">Configuring Quality of Service</a></li> </ul>



Parameter	Description
	<p><a href="#">Rules</a> on page 531), it's unnecessary to enable this parameter because you need to select an IP Group when configuring the rule. If you don't configure a Quality of Service rule, then you need to enable this parameter.</p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
Message Manipulation	
<p>'Inbound Message Manipulation Set'</p> <p><code>inbound-mesg-manipulation-set</code></p> <p>[InboundManSet]</p>	<p>Assigns a Message Manipulation Set (rule) to the IP Group for SIP message manipulation on the inbound leg.</p> <p>By default, no value is defined.</p> <p>To configure Message Manipulation rules, see <a href="#">Configuring SIP Message Manipulation</a> on page 829.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the SBC application.</li> <li>■ The 'SIP Group Name' parameter overrides inbound message manipulation rules (assigned to the 'Inbound Message Manipulation Set' parameter) that manipulate the host name in Request-URI, To, and/or From SIP headers. If you want to manipulate the host name using message manipulation rules in any of these SIP headers, you must apply your manipulation rule (Manipulation Set ID) to the IP Group as an Outbound Message Manipulation Set (see the 'Outbound Message Manipulation Set' parameter) when the IP Group is the destination of the call.</li> </ul>
<p>'Outbound Message Manipulation Set'</p> <p><code>outbound-mesg-manipulation-set</code></p> <p>[OutboundManSet]</p>	<p>Assigns a Message Manipulation Set (rule) to the IP Group for SIP message manipulation on the outbound leg.</p> <p>By default, no value is defined.</p> <p>To configure Message Manipulation rules, see <a href="#">Configuring SIP Message Manipulation</a> on page 829.</p> <p><b>Note:</b> If you assign a Message Manipulation Set ID that includes rules for manipulating the host name in the Request-URI, To, and/or From SIP headers, the parameter overrides the 'SIP Group Name' parameter.</p>
<p>'Message Manipulation User-Defined String 1'</p> <p><code>msg-man-user-</code></p>	<p>Defines a value for the SIP user part that can be used in Message Manipulation rules configured in the Message Manipulations table. The Message Manipulation rule</p>

Parameter	Description
defined-string1 [MsgManUserDef1]	<p>obtains this value from the IP Group, by using the following syntax:</p> <pre>param.ipg.&lt;src dst&gt;.user-defined.&lt;0&gt;.</pre> <p>The valid value is a string of up to 30 characters. By default, no value is defined.</p> <p>To configure Message Manipulation rules, see <a href="#">Configuring SIP Message Manipulation</a> on page 829.</p>
'Message Manipulation User-Defined String 2' msg-man-user-defined-string2 [MsgManUserDef2]	<p>Defines a value for the SIP user part that can be used in Message Manipulation rules configured in the Message Manipulations table. The Message Manipulation rule obtains this value from the IP Group, by using the following syntax: <code>param.ipg.&lt;src dst&gt;.user-defined.&lt;1&gt;</code>.</p> <p>The valid value is a string of up to 30 characters. By default, no value is defined.</p> <p>To configure Message Manipulation rules, see <a href="#">Configuring SIP Message Manipulation</a> on page 829.</p>
'Proxy Keep-Alive using IP Group Settings' proxy-keepalive-use-ipg [ProxyKeepAliveUsingIPG]	<p>Enables the device to apply certain IP Group settings to keep-alive SIP OPTIONS messages that are sent by the device to the proxy server. The parameter is applicable only if you have enabled proxy keep-alive for the Proxy Set that is associated with the IP Group (see <a href="#">Configuring Proxy Sets</a> on page 622).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) The IP Group's settings are not applied to the OPTIONS messages.</li> <li>■ [1] <b>Enable</b> = The following IP Group settings are applied (if configured) to the proxy keep-alive SIP OPTIONS messages: <ul style="list-style-type: none"> <li>✓ The IP Group's 'SIP Group Name' parameter (see above) value is used in the OPTIONS messages.</li> <li>✓ The IP Group's 'Outbound Message Manipulation Set' parameter (see above) is applied to the OPTIONS messages (instead of manipulations configured by the [GWOutboundManipulationSet] parameter). You can also use the manipulation syntax "param.ipg.dst" for denoting the IP Group's parameters.</li> <li>✓ When filtering logs (configured in the Logging Filters table), the OPTIONS messages are filtered by</li> </ul> </li> </ul>

Parameter	Description
	<p>IP Group. For more information on log filtering, see <a href="#">Configuring Logging Filter Rules</a> on page 1470.</p> <p><b>Note:</b> When multiple IP Groups are associated with the same Proxy Set, the parameter can be enabled only on <b>one</b> of them.</p>
SBC Registration and Authentication	
<p>'Max. Number of Registered Users'</p> <p>max-num-of-reg-users</p> <p>[MaxNumOfRegUsers]</p>	<p>Defines the maximum number of users in this IP Group that can register with the device.</p> <p>The default is -1, meaning that no limitation exists for registered users.</p> <p><b>Note:</b> The parameter is applicable only to <b>User</b>-type IP Groups.</p>
<p>'Registration Mode'</p> <p>registration-mode</p> <p>[RegistrationMode]</p>	<p>Defines the registration mode for the IP Group.</p> <ul style="list-style-type: none"> <li>■ [0] <b>User Initiates Registration</b> (default)</li> <li>■ [1] <b>SBC Initiates Registration</b> = Used when the device serves as a client (e.g., with an IP PBX). This functions only with the SBC User Information table (see <a href="#">Configuring SBC User Information Table through Web Interface</a> on page 776).</li> <li>■ [2] <b>Registrations not Needed</b> = The device adds users to its database in active state.</li> </ul>
<p>'Dedicated Connection Mode'</p> <p>dedicated-connection-mode</p> <p>[DedicatedConnectionMode]</p>	<p>Enables the device to establish and use a dedicated TCP (TLS) connection with the SIP registrar server (proxy) for each user that is defined in the SBC User Information table.</p> <p>The dedicated connection is established when the device initially registers (SIP REGISTER) the user with the server. All subsequent SIP dialogs (e.g., INVITE) originating from the user are sent to the server over this dedicated connection.</p> <p>If you enable this feature and there is no valid dedicated connection when the user sends a SIP dialog-initiating request, the device rejects the SIP dialog. This also triggers the device to refresh registration with the server for the specific user.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) The same connection may be used for all users, depending on the [EnableTCPConnectionReuse] parameter settings.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [1] <b>Per User in SBC User Information Table</b> = The device establishes a dedicated connection per user.</li> <li><b>Note:</b></li> <li>■ The parameter is applicable only to <b>User</b>-type IP Groups.</li> <li>■ To support this feature, you also need to do the following: <ul style="list-style-type: none"> <li>✓ Configure the 'Registration Mode' parameter (above) to <b>SBC Initiates Registration</b> for this <b>User</b>-type IP Group.</li> <li>✓ Configure each relevant user in the SBC User Information table so that they are associated with this <b>User</b>-type IP Group (see <a href="#">Configuring SBC User Information Table through Web Interface</a> on page 776).</li> <li>✓ Configure the Proxy Set that is associated with the <b>Server</b>-type IP Group representing the registrar server, for TCP (or TLS) transport type (see <a href="#">Configuring Proxy Sets</a> on page 622).</li> <li>✓ Configure the associated IP-to-IP Routing rule (see <a href="#">Configuring SBC IP-to-IP Routing Rules</a> on page 1076) to send all SIP messages from the <b>User</b>-type IP Group to 'Destination Type' IP Group and the 'Destination IP Group' should be the <b>Server</b>-type IP Group (i.e., the registrar server).</li> </ul> </li> <li>■ If you modify configuration relating to the user (e.g., IP-to-IP Routing rule) at any time after this feature has been configured, the device may no longer have a valid, dedicated connection until it's time to send a refresh REGISTER message for the user.</li> <li>■ This feature poses the following constraints: <ul style="list-style-type: none"> <li>✓ The maximum number of users that can have a dedicated TLS connection is less than the maximum number of rows (users) that you can configure in the SBC User Information table (see <a href="#">Configuring SBC User Information Table through Web Interface</a> on page 776).</li> </ul> </li> </ul>

Parameter	Description
	<p>✓ When the device needs to open a new TLS connection for a user (SBC User Information entry), it only establishes the connection if the number of currently established TLS connections (incoming and outgoing) is less than the maximum number of supported TLS connections by the device. If the maximum is exceeded, it doesn't open the TLS connection and doesn't send a registration request to the proxy server for the user. For the maximum number of concurrent TLS connections supported by the device, refer to 'Capacity per Feature' in the <i>Release Notes</i>.</p>
<p>'User Stickiness' sbc-user-stickiness  [SBCUserStickiness]</p>	<p>Enables user "stickiness" (binding) to a specific registrar server. The registrar server is one of the IP addresses of the Proxy Set associated with this <b>Server</b>-type IP Group. This feature applies to users belonging to a <b>User</b>-type IP Group that are routed to this destination <b>Server</b>-type IP Group.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = After a successful initial registration of the user to a registrar, whenever the device receives a SIP request or registration refresh from the user, the device sends the request to whichever registrar (IP address of the Proxy Set) is currently active. In the case of proxy load-balancing, there is no certainty to which IP address the request is routed.</li> <li>■ [1] <b>Enable</b> = The device always routes SIP requests (INVITEs, SUBSCRIBEs and REGISTER refreshes) received from the user to the same registrar server to which the last successful REGISTER request for that user was routed. In other words, once initial registration of the user to one of the IP addresses of the Proxy Set associated with this destination <b>Server</b>-type IP Group is successful (i.e., 200 OK), binding occurs to this specific address (registrar) and all future SIP requests from the user are routed (based on matched routing rule) only to this specific registrar.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to <b>Server</b>-type IP Groups</li> <li>■ The Proxy Set associated with the <b>Server</b>-type IP Group must be configured with multiple IP addresses (or an</li> </ul>

Parameter	Description
	<p>FQDN that resolves into multiple IP addresses).</p> <ul style="list-style-type: none"> <li>■ This feature is also applicable to IP Group Sets (see <a href="#">Configuring IP Group Sets</a> on page 1113). If a user is bound to a registrar associated with this <b>Server</b>-type IP Group which also belongs to an IP Group Set, IP Group Set logic of choosing an IP Group is ignored and instead, the device always routes requests from this user to this specific registrar.</li> <li>■ A user's "stickiness" to a specific registrar ends upon the following scenarios: <ul style="list-style-type: none"> <li>✓ If you modify the Proxy Set.</li> <li>✓ If the Proxy Set is configured with an FQDN and a DNS resolution refresh removes the IP address to which the user is bound.</li> <li>✓ User registration expires or the user initiates an unregister request.</li> </ul> </li> <li>■ The Proxy Set's Hot-Swap feature (for proxy redundancy) is not supported for users that are already bound to a registrar. However, you can achieve proxy "hot-swap" for failed initial (non-bounded) REGISTER requests. If the device receives a failure response for the initial REGISTER request and you have configured this response code for the Alternative Reasons Set associated (by the 'SBC Alternative Routing Reasons Set' parameter below) with the IP Group (see <a href="#">Configuring SIP Response Codes for Alternative Routing Reasons</a> on page 1104), "hot-swap" to the other IP addresses of the Proxy Set is done until a success response is received from one of the addresses. For failed REGISTER refresh requests from users that are already bound to a registrar, no "hot-swap" occurs for that request; only for subsequent refresh requests.</li> <li>■ When using the SBC User Information table (see <a href="#">Configuring SBC User Information</a> on page 775), registrar "stickiness" is supported only when the user initiates the REGISTER request. Therefore, you must configure the 'Registration Mode' parameter of the IP Group (<b>User</b>-type) to which the user belongs, to <b>User Initiates Registration</b>.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>This feature is also supported when the device operates in HA mode; registrar "stickiness" is retained even after an HA switchover.</li> </ul>
'User UDP Port Assignment' user-udp-port-assignment [UserUDPPortAssignment]	<p>Enables the device to assign a unique, local UDP port (for SIP signaling) per registered user (<b>User</b>-type IP Group) on the leg interfacing with the proxy server (<b>Server</b>-type IP Group). The port is used for incoming (from the proxy to the user) and outgoing (from the user to the proxy) SIP messages. Therefore, the parameter must be enabled for the IP Group of the proxy server.</p> <ul style="list-style-type: none"> <li>[0] <b>Disable</b> = (Default) The device uses the same local UDP port for all the registered users. This single port is configured for the SIP Interface ('UDP Port' parameter) associated with the Proxy Set of the proxy server.</li> <li>[1] <b>Enable</b> = The device assigns each registered user a unique local port, chosen from a configured UDP port range. The port range is configured for the SIP Interface ('Additional UDP Ports' parameter) associated with the proxy server.</li> </ul> <p>The device assigns a unique port upon the first REGISTER request received from the user. Subsequent SIP messages other than REGISTER messages (e.g., INVITE) from the user are sent to the proxy server on this unique local port. The device rejects the SIP request if there is no available unique port for use (due to the number of registered users exceeding the configured port range). The same unique port is also used for registration refreshes. The device de-allocates the port for registration expiry. For SIP requests from the proxy server, the local port on which they are received is irrelevant (unique port or any other port); the device doesn't use this port to identify the registered user.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>This feature doesn't apply to SIP requests received from non-registered users. For these users, the device sends all requests to the proxy server on the single port configured for the SIP Interface ('UDP Port' parameter).</li> <li>For HA systems, the unique port assigned to a registered user is also used after an HA switchover.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ This feature is applicable only if the user initiates registration (i.e., user sends the REGISTER request). In other words, the 'Registration Mode' parameter of the IP Group of the user must be configured to <b>User Initiates Registration</b>.</li> </ul>
'Authentication Mode' authentication-mode  [AuthenticationMode]	<p>Defines the authentication mode.</p> <ul style="list-style-type: none"> <li>■ [0] <b>User Authenticates</b> = (Default) The device doesn't handle authentication, but simply forwards the authentication messages between the SIP user agents.</li> <li>■ [1] <b>SBC as Client</b> = The device authenticates as a client. When the device receives a SIP 401/407 response from the proxy requesting authentication for the outgoing SIP request, it sends the proxy its credentials (i.e., username and password), which it obtains from one of the following (listed in order of preference):               <ol style="list-style-type: none"> <li>If an Account exists in the Accounts table (see <a href="#">Configuring Registration Accounts</a> on page 750) for the Served IP Group and the Serving IP Group (i.e., IP Group you are now configuring), the device obtains the credentials from the Account (only if authenticating a <b>Server</b>-type IP Group).</li> <li>The device obtains the credentials from the SBC User Information table (see <a href="#">Configuring SBC User Information</a> on page 775).</li> <li>The device obtains the credentials configured for this IP Group in the IP Groups table ('Username As Client' and 'Password As Client' parameters).</li> <li>The device obtains the credentials from the global username and password parameters (only if authenticating a <b>Server</b>-type IP Group).</li> <li>If no applicable credentials are found, the device forwards the SIP 401/407 response to the SIP UA.</li> </ol> </li> <li>■ [2] <b>SBC as Server</b> = The device acts as an Authentication server:               <ul style="list-style-type: none"> <li>✓ Authenticates SIP clients: The device challenges (authenticates) incoming SIP requests from users belonging to this IP Group. When the 'SBC Server</li> </ul> </li> </ul>



Parameter	Description
	<p>Authentication Type' parameter (see below) is configured to <b>Authentication is performed locally</b>, the device authenticates the users based on the username and password configured for this IP Group ('Username As Server' and 'Password As Server' parameters). However, if a user appears in the SBC User Information table and is configured with a username and password, the device authenticates the user with the credentials in the SBC User Information table (see <a href="#">Configuring SBC User Information</a> on page 775). If you have not configured a username and password, the device rejects the incoming SIP request.</p> <ul style="list-style-type: none"> <li>✓ Authenticates SIP servers (applicable only to <b>Server-type</b> IP Groups).</li> </ul> <p><b>Note:</b> Configure the SIP request (method) types (e.g., INVITE) that the device must challenge when acting as an authentication server, using the IP Group's 'Authentication Method List' parameter.</p> <ul style="list-style-type: none"> <li>■ [3] <b>SBC as Both Client and Server</b> = The device authenticates both as a client and an authentication server. For a description of each mode, see the optional values <b>SBC as Client</b> and <b>SBC as Server</b>.</li> </ul>
'Authentication Method List' authentication-method-list [MethodList]	<p>Defines SIP methods received from the IP Group that must be challenged by the device when the device acts as an Authentication server. If no methods are configured, the device doesn't challenge any methods.</p> <p>By default, no value is defined. To define multiple SIP methods, use the backslash (\) to separate each method (e.g., INVITE\REGISTER). To authenticate only setup INVITE requests (and not re-INVITE requests), configure the parameter to "setup-invite" (without quotation marks).</p> <p><b>Note:</b> The parameter is applicable only if you configure the device to act as an Authentication server (i.e., 'Authentication Mode' parameter is <b>SBC as Server</b> or <b>SBC as Both Client and Server</b>).</p>
'SBC Server Authentication Type' sbc-server-auth-	<p>Defines the authentication method when the device, as an Authentication server, authenticates SIP requests from the IP Group.</p>

Parameter	Description
type [TypeSBCServerAuthType]	<ul style="list-style-type: none"> <li>■ [-1] <b>According to Global Parameter</b> = (Default) Authentication is according to the [SBCServerAuthMode] parameter.</li> <li>■ [0] <b>Authentication is performed locally</b> = The device authenticates incoming SIP requests locally. For more information, see <a href="#">SIP Authentication Server Functionality</a> on page 1039.</li> <li>■ [2] <b>According to draft-sterman-aaa-sip-01</b> = The device authenticates incoming SIP requests using a remote RADIUS server, based on Internet Draft "draft-sterman-aaa-sip-01". For more information, see <a href="#">RADIUS-based Authentication of SIP User Agents</a> on page 1040.</li> <li>■ [3] <b>Authenticate with OAuth Server</b> = The device authenticates incoming SIP requests according to token-based authentication with an OAuth 2.0 authorization server (internal or external). The OAuth 2.0 server is configured as a Remote Web Service. The server is assigned to the IP Group using the IP Group's 'OAuth HTTP Service' parameter. For more information, see <a href="#">OAuth 2.0 Based SIP Message Authentication</a> on page 424.</li> <li>■ [4] <b>ARM Authentication</b> = The device authenticates incoming SIP requests (INVITE or REGISTER) from <b>User</b>-type IP Groups, by first obtaining (REST-based API query) the user's password from ARM where the password is stored. Once the password is supplied, the device continues with the regular SIP digest authentication process (challenge) with the user. For more information on routing by ARM, see <a href="#">Centralized Routing by ARM (AudioCodes Routing Manager)</a> on page 442.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you configure the parameter to any option except <b>Authentication is performed locally</b>, you also need to configure the device to act as an Authentication server (i.e., 'Authentication Mode' parameter is <b>SBC as Server</b> or <b>SBC as Both Client and Server</b>).</li> <li>■ If you configure the parameter to <b>ARM Authentication</b>, you also need to configure the IP Group's 'Authentication Method List' parameter to authenticate</li> </ul>

Parameter	Description
	INVITE or REGISTER messages.
'OAuth HTTP Service' oauth-http-service [OAuthHTTPService]	<p>Assigns a Remote Web Service to the IP Group. The Remote Web Service represents the OAuth 2.0 authorization server (internal or external), which the device uses to authenticate incoming SIP requests as a server. The device sends the OAuth token received from the client to the OAuth 2.0 server for authentication.</p> <p>To configure Remote Web Services, see <a href="#">Configuring Remote Web Services</a> on page 429. For more information on OAuth-based authentication, see <a href="#">OAuth 2.0 Based SIP Message Authentication</a> on page 424.</p> <p><b>Note:</b> The parameter is applicable only if the IP Group's 'SBC Server Authentication' parameter is configured to <b>Authenticate with OAuth Server</b>.</p>
'Username As Client' username-as-client [UsernameAsClient]	<p>Defines the username that is used when the device is challenged (SIP 401/407) by this IP Group for retrying the outgoing SIP request toward this IP Group.</p> <p>The valid value is a string of up to 60 characters. By default, no username is defined.</p> <p><b>Note:</b> The parameter is applicable only if you configure the device to authenticate as a client (i.e., 'Authentication Mode' parameter is <b>SBC as Client</b> or <b>SBC as Both Client and Server</b>).</p>
'Password As Client' password-as-client [PasswordAsClient]	<p>Defines the password that is used when the device is challenged (SIP 401/407) by this IP Group for retrying the outgoing SIP request toward this IP Group.</p> <p>The valid value is a string of up to 64 characters. By default, no password is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if you configure the device to authenticate as a client (i.e., 'Authentication Mode' parameter is <b>SBC as Client</b> or <b>SBC as Both Client and Server</b>).</li> <li>■ The password cannot include wide characters.</li> </ul>
'Username As Server' username-as-server [UsernameAsServer]	<p>Defines the username that is used when the device challenges (authenticates) incoming SIP requests from users belonging to this IP Group (for <b>User</b>-type IP Groups), or challenges SIP servers (for <b>Server</b>-type IP Groups).</p>

Parameter	Description
	<p>The valid value is a string of up to 60 characters. By default, no username is defined.</p> <p><b>Note:</b> The parameter is applicable only if you configure the device to act as an Authentication server (i.e., 'Authentication Mode' parameter is <b>SBC as Server</b> or <b>SBC as Both Client and Server</b>).</p>
'Password As Server' password-as-server [PasswordAsServer]	<p>Defines the password that is used when the device challenges (authenticates) incoming SIP requests from users belonging to this IP Group (for <b>User</b>-type IP Groups), or challenges SIP servers (for <b>Server</b>-type IP Groups).</p> <p>The valid value is a string of up to 64 characters. By default, no password is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if you configure the device to act as an Authentication server (i.e., 'Authentication Mode' parameter is <b>SBC as Server</b> or <b>SBC as Both Client and Server</b>).</li> <li>■ The password cannot include wide characters.</li> </ul>
Gateway	
'SIP Re-routing Mode' re-routing-mode [SIPReRoutingMode]	<p>Defines the routing mode after a call redirection (i.e., a 3xx SIP response is received) or transfer (i.e., a SIP REFER request is received).</p> <ul style="list-style-type: none"> <li>■ [-1] = Not Configured (Default)</li> <li>■ [0] <b>Standard</b> = INVITE messages that are generated as a result of Transfer or Redirect are sent directly to the URI, according to the Refer-To header in the REFER message or Contact header in the 3xx response.</li> <li>■ [1] <b>Proxy</b> = Sends a new INVITE to the Proxy. This is applicable only if a Proxy server is used and the parameter [AlwaysSendtoProxy] is set to [0].</li> <li>■ [2] <b>Routing Table</b> = Uses the Routing table to locate the destination and then sends a new INVITE to this destination.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ When the parameter is configured to [1] and the INVITE sent to the Proxy fails, the device re-routes the call</li> </ul>

Parameter	Description
	<p>according to the Standard mode [0].</p> <ul style="list-style-type: none"> <li>■ When the parameter is configured to [2] and the INVITE fails, the device re-routes the call according to the Standard mode [0]. If DNS resolution fails, the device attempts to route the call to the Proxy. If routing to the Proxy also fails, the Redirect / Transfer request is rejected.</li> <li>■ When the parameter is set to [2], the [XferPrefix] parameter can be used to define different routing rules for redirected calls.</li> <li>■ The parameter is ignored if the parameter [AlwaysSendToProxy] is set to [1].</li> </ul>
'Always Use Route Table' always-use-route-table [AlwaysUseRouteTable]	<p>Defines the Request-URI host name in outgoing INVITE messages.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> (default).</li> <li>■ [1] <b>Yes</b> = The device uses the IP address (or domain name) defined in the Tel-to-IP Routing table (see <a href="#">Configuring Tel-to-IP Routing Rules</a> on page 914) as the Request-URI host name in outgoing INVITE messages, instead of the value configured in the 'SIP Group Name' field.</li> </ul> <p><b>Note:</b> The parameter is applicable only to <b>Server</b>-type IP Groups.</p>
GW Group Status	
'GW Group Registered IP Address'	<p>(Read-only field) Displays the IP address of the IP Group entity (gateway) if registered with the device; otherwise, the field is blank.</p> <p><b>Note:</b> The field is applicable only to <b>Gateway</b>-type IP Groups (i.e., the 'Type' parameter is configured to <b>Gateway</b>). For <b>User</b>-type and <b>Server</b>-type IP Groups, the field displays "NA".</p>
'GW Group Registered Status'	<p>(Read-only field) Displays if the IP Group entity (gateway) is registered with the device ("Registered" or "Not Registered").</p> <p><b>Note:</b> The field is applicable only to <b>Gateway</b>-type IP Groups (i.e., the 'Type' parameter is configured to <b>Gateway</b>). For <b>User</b>-type and <b>Server</b>-type IP Groups, the</p>

Parameter	Description
	field displays "NA".

## Configuring Proxy Sets

The Proxy Sets table lets you configure up to 80 Proxy Sets. A Proxy Set defines the address (IP address or FQDN) and transport type (e.g., UDP or TCP) of a SIP server (e.g., SIP proxy and SIP registrar server). The Proxy Set represents the destination of the IP Group configuration entity.



- The maximum number of addresses that you can configure in the Proxy Address table ("child" of the Proxy Sets table) per Proxy Set is 10 . The address can be an IP address in dotted-decimal notation or a DNS hostname (FQDN).
- The maximum number of supported DNS-resolved IP addresses **per** Proxy Set is 15.
- The maximum number of supported DNS-resolved IP addresses for **all** Proxy Sets combined is 500. If the DNS resolution provides more than this number, it ignores the extra addresses.
- An SRV query sent by the device can return up to 50 hostnames. For each hostname, the subsequent DNS A-record query sent by the device can resolve into up to 50 IP addresses.

Multiple proxy servers enables you to implement proxy load balancing and redundancy. These features are supported by the device's proxy keep-alive feature, which when enabled, sends keep-alive messages (SIP OPTIONS) to all configured proxy servers to determine their connectivity status (offline or online). You can also configure the device to consider the proxy as offline if specific SIP response codes are received in response to the keep-alive messages. You can configure the number of required consecutive successful keep-alive messages before the device considers a previously offline proxy as online. This mechanism avoids the scenario in which the device falsely detects a proxy as being online when it is actually offline, resulting in call routing failure.

You can assign each Proxy Set a specific TLS Context (TLS configuration), enabling you to use different TLS settings (including certificates) per SIP entity (IP Group).

You can also enable the device to classify incoming SBC SIP dialogs to IP Groups, based on Proxy Set. If the source address of the incoming SIP dialog is the same as the address of a Proxy Set, the device classifies the SIP dialog as belonging to the IP Group that is associated with the Proxy Set.

To use a configured Proxy Set, you need to assign it to an IP Group in the IP Groups table (see [Configuring IP Groups](#) on page 581). When the device sends INVITE messages to an IP Group, it sends it to the address configured for the Proxy Set. You can assign the same Proxy Set to multiple IP Groups (belonging to the same SRD).



- It is recommended to classify incoming SIP dialogs to IP Groups based on Classification rules (see [Configuring Classification Rules](#) on page 1061) instead of based on Proxy Sets.
- For the Gateway application, you can view the device's connectivity status with proxy servers in the Tel-to-IP Routing table for Tel-to-IP routing rules whose destination is an IP Group that is associated with a Proxy Set. The status is only displayed for Proxy Sets enabled with the Proxy Keep-Alive feature.
- To view connectivity status of Proxy Sets, see [Viewing Proxy Set Status](#) on page 1357.

The Proxy Set is configured using two tables with parent-child relationship:

- Proxy Sets table (parent): Defines the attributes of the Proxy Set such as associated SIP Interface and redundancy features - ini file parameter [ProxySet] or CLI command, `configure voip > proxy-set`
- Proxy Set Address table (child): Defines the addresses of the Proxy Set - table ini file parameter [ProxyIP] or CLI command, `configure voip > proxy-ip > proxy-set-id`

#### ➤ To configure a Proxy Set:

1. Open the Proxy Sets table (**Setup** menu > **Signaling & Media** tab > **Core Entities** folder > **Proxy Sets**).
2. Click **New**; the following dialog box appears (screenshot has been cropped due to page size):

3. From the 'SRD' drop-down list, select an SRD.
4. Configure a Proxy Set according to the parameters described in the table below.
5. Click **Apply**.
6. Configure proxy addresses for the Proxy Set:
  - a. Select the index row of the Proxy Set that you added, and then click the **Proxy Address** link located below the table; the Proxy Address table opens.
  - b. Click **New**; the following dialog box appears:

Proxy Address - x

GENERAL

Index

**Proxy Address**

**Transport Type**

v

Proxy Priority

Proxy Random Weight

- c. Configure the address of the Proxy Set according to the parameters described in the table below.

- d. Click **Apply**.

**Table 18-7: Proxy Sets Table and Proxy Address Table Parameter Description**

Parameter	Description
'SRD' voip-network proxy-set > srd- id [SRDName]	Assigns an SRD to the Proxy Set. <b>Note:</b> <ul style="list-style-type: none"> <li>The parameter is mandatory and must be configured first before you can configure the other parameters in the table.</li> <li>To configure SRDs, see <a href="#">Configuring SRDs</a> on page 549.</li> </ul>
General	
'Index' configure voip > voip-network proxy-set [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' proxy-name [ProxyName]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 40 characters. <b>Note:</b> <ul style="list-style-type: none"> <li>Configure each row with a unique name.</li> <li>The parameter value can't contain a forward slash (/).</li> <li>The parameter value can't be configured with the character string "any" (upper or lower case).</li> </ul>



Parameter	Description
'Gateway IPv4 SIP Interface' gwipv4-sip-int-name [GWIPv4SIPInterfaceName]	Assigns an IPv4-based SIP Interface for Gateway calls to the Proxy Set. <b>Note:</b> <ul style="list-style-type: none"> <li>The parameter appears only if you have configured an IPv4 network interface in the IP Interfaces table (see <a href="#">Configuring IP Network Interfaces</a> on page 157).</li> <li>At least one SIP Interface must be assigned to the Proxy Set.</li> <li>All SIP Interfaces assigned to the Proxy Set must be either IPv4 addresses or IPv6 addresses (not both).</li> <li>To configure SIP Interfaces, see <a href="#">Configuring SIP Interfaces</a> on page 561.</li> </ul>
'SBC IPv4 SIP Interface' sbcipv4-sip-int-name [SBCIPv4SIPInterfaceName]	Assigns an IPv4-based SIP Interface for SBC calls to the Proxy Set. <b>Note:</b> <ul style="list-style-type: none"> <li>The parameter appears only if you have configured an IPv4 network interface in the IP Interfaces table (see <a href="#">Configuring IP Network Interfaces</a> on page 157).</li> <li>At least one SIP Interface must be assigned to the Proxy Set.</li> <li>All SIP Interfaces assigned to the Proxy Set must be either IPv4 addresses or IPv6 addresses (not both).</li> <li>To configure SIP Interfaces, see <a href="#">Configuring SIP Interfaces</a> on page 561.</li> </ul>
'Gateway IPv6 SIP Interface' gwipv6-sip-int-name [GWIPv6SIPInterfaceName]	Assigns an IPv6-based SIP Interface for Gateway calls to the Proxy Set. <b>Note:</b> <ul style="list-style-type: none"> <li>The parameter appears <b>only</b> if you have configured an IPv6 network interface in the IP Interfaces table.</li> <li>At least one SIP Interface must be assigned to the Proxy Set.</li> <li>All SIP Interfaces assigned to the Proxy Set must be either IPv4 addresses or IPv6 addresses (not both).</li> </ul>
'SBC IPv6 SIP Interface' sbcipv6-sip-int-name	Assigns an IPv6-based SIP Interface for SBC calls to the Proxy Set. <b>Note:</b>

Parameter	Description
[SBCIPv6SIPInterfaceName]	<ul style="list-style-type: none"> <li>■ The parameter appears only if you have configured an IPv6 network interface in the IP Interfaces table.</li> <li>■ At least one SIP Interface must be assigned to the Proxy Set.</li> <li>■ All SIP Interfaces assigned to the Proxy Set must be either IPv4 addresses or IPv6 addresses (not both).</li> </ul>
'TLS Context Name' tls-context-name  [TLSContextName]	<p>Assigns a TLS Context (TLS configuration) to the Proxy Set. By default, no TLS Context is assigned. If you assign a TLS Context, the TLS Context is used as follows:</p> <ul style="list-style-type: none"> <li>■ Incoming calls: If the 'Transport Type' parameter (in this table) is set to <b>TLS</b> and the incoming call is successfully classified to an IP Group based on the Proxy Set, this TLS Context is used. If the 'Transport Type' parameter is set to <b>UDP</b> or classification to this Proxy Set fails, the TLS Context is not used. Instead, the device uses the TLS Context configured for the SIP Interface (see <a href="#">Configuring SIP Interfaces</a> on page 561) used for the call; otherwise, the default TLS Context (ID 0) is used.</li> <li>■ Outgoing calls: If the 'Transport Type' parameter is set to <b>TLS</b> and the outgoing call is sent to an IP Group that is associated with this Proxy Set, this TLS Context is used. Instead, the device uses the TLS Context configured for the SIP Interface used for the call; otherwise, the default TLS Context (ID 0) is used. If the 'Transport Type' parameter is set to <b>UDP</b>, the device uses UDP to communicate with the proxy and no TLS Context is used.</li> </ul> <p>To configure TLS Contexts, see <a href="#">TLS Certificates</a> on page 224.</p>
Keep Alive	
'Proxy Keep-Alive' proxy-enable-keep-alive  [EnableProxyKeepAlive]	<p>Enables the device's Proxy Keep-Alive feature, which checks connectivity with all the proxy servers of the Proxy Set, by sending keep-alive messages.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default).</li> <li>■ [1] <b>Using OPTIONS</b> = Enables the Proxy Keep-Alive feature using SIP OPTIONS messages. The device sends an OPTIONS message every user-defined interval, configured by the 'Proxy Keep-Alive Time' parameter (in this table). If the device receives a SIP response code that is configured in the</li> </ul>

Parameter	Description
	<p>'Keep-Alive Failure Responses' parameter (in this table), the device considers the proxy as offline. You can also configure if the device uses its IP address, the proxy's IP address, or the device's name in the OPTIONS message, using the [UseGatewayNameForOptions] parameter.</p> <ul style="list-style-type: none"> <li>■ [2] <b>Using REGISTER</b> = Enables the Proxy Keep-Alive feature using SIP REGISTER messages. The device sends a REGISTER message every user-defined interval, configured by the [RegistrationTime] parameter (Gateway application) or [SBCProxyRegistrationTime] parameter (SBC application). Any SIP response from the proxy - success (200 OK) or failure (4xx response) - is considered as if the proxy is online. If the proxy doesn't respond to INVITE messages sent by the device, the proxy is considered as offline. The device sends keep-alive REGISTER messages only to one proxy. Only if the proxy fails to respond to the keep-alive, does the device send the keep-alive REGISTER message to the next proxy.</li> <li>■ [3] <b>Using OPTIONS on Active Server</b> = Enables the Proxy Keep-Alive feature using SIP OPTIONS messages (similar to the <b>Using OPTIONS</b> value), except that the proxy servers to which the keep-alive messages are sent depend on the settings of the Proxy Set's 'Redundancy Mode' parameter (see below): <ul style="list-style-type: none"> <li>✓ <b>Parking:</b> The device sends keep-alive OPTIONS messages only to the currently active proxy server (to which it is connected and using).</li> <li>✓ <b>Homing:</b> The device sends keep-alive OPTIONS messages to the currently active proxy server and to all proxy servers with higher priority (according to the 'Proxy Priority' parameter in this table) than the active server. Once a higher priority server goes online, the device stops sending the keep-alive OPTIONS messages to the previously active server and connects to the higher priority server. The device now sends keep-alive messages to this newly active server and all other servers with higher priority.</li> <li>✓ If the 'Redundancy Mode' parameter is not configured (empty) and the Proxy Set's 'Proxy Load Balancing Method' parameter (in this table) is configured to any</li> </ul> </li> </ul>

Parameter	Description
	<p>value other than <b>Disable</b>, the device sends the keep-alive OPTIONS messages to all proxy servers (same behavior as when you configure the 'Proxy Keep-Alive' parameter to <b>Using OPTIONS</b>).</p> <ul style="list-style-type: none"> <li>■ [4] <b>Using Fake REGISTER</b> = Enables the Proxy Keep-Alive feature using SIP REGISTER messages. The device sends a REGISTER message every user-defined interval, configured by the 'Proxy Keep-Alive Time' parameter (in this table). The name in the Contact header of the REGISTER message is a fake name. Therefore, the REGISTER request is expected to fail and the device considers the proxy server as online if it receives a SIP 404 response. If the device receives a SIP response code that is configured in the 'Keep-Alive Failure Responses' parameter (in this table), the device considers the proxy as offline. You can also configure if the device uses its IP address, the proxy's IP address, or the device's name in the REGISTER message, using the [UseGatewayNameForOptions] parameter.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Proxy keep-alive using REGISTER messages (<b>Using REGISTER</b>) is applicable only to the Parking redundancy mode ('Redundancy Mode' parameter configured to <b>Parking</b>).</li> <li>■ If you enable the Proxy Keep-Alive feature, the device can operate with multiple proxy servers (addresses) for redundancy and load balancing (see the 'Proxy Load Balancing Method' parameter).</li> <li>■ For Survivability mode for User-type IP Groups, you must enable the Proxy Keep-Alive feature.</li> <li>■ If you enable the Proxy Keep-Alive feature and the proxy uses the TCP/TLS transport type, you can enable the CRLF Keep-Alive feature, using the [UsePingPongKeepAlive] parameter.</li> <li>■ If you enable proxy keep-alive using SIP OPTIONS messages (<b>Using OPTIONS</b> or <b>Using OPTIONS on Active Server</b>) or using fake REGISTER requests (<b>Using Fake REGISTER</b>), you can also enable the device to apply various settings (e.g., SIP message manipulation) of the IP Group that is associated with the Proxy Set, to these SIP messages. For more information, see the 'Proxy Keep-Alive using IP Group</li> </ul>

Parameter	Description
	<p>Settings' parameter in the IP Groups table.</p> <ul style="list-style-type: none"> <li>If you enable proxy keep-alive using SIP OPTIONS messages (<b>Using OPTIONS</b> or <b>Using OPTIONS on Active Server</b>) or using fake REGISTER requests (<b>Using Fake REGISTER</b>), you can also configure how long the device waits before re-sending a keep-alive OPTIONS message once the device considers the proxy as offline (i.e., after all retransmissions, configured by the 'Failure Detection Retransmissions' have failed). This feature is configured by the [FailedOptionsRetryTime] parameter.</li> </ul>
'Proxy Keep-Alive Time' proxy-keep-alive-time [ProxyKeepAliveTime]	<p>Defines the interval (in seconds) between keep-alive messages sent by the device when the Proxy Keep-Alive feature is enabled (see the 'Proxy Keep-Alive' parameter in this table). The valid range is 5 to 2,000,000. The default is 60.</p> <p><b>Note:</b> The parameter is applicable only if you configure the 'Proxy Keep-Alive' parameter to <b>Using OPTIONS</b>, <b>Using OPTIONS on Active Server</b> or <b>Using Fake REGISTER</b>.</p>
'Keep-Alive Failure Responses' keepalive-fail-resp [KeepAliveFailureResp]	<p>Defines SIP response codes that if any is received in response to a keep-alive message using SIP OPTIONS (<b>Using OPTIONS</b> or <b>Using OPTIONS on Active Server</b>) or using fake REGISTER requests (<b>Using Fake REGISTER</b>), the device considers the proxy as offline.</p> <p>Up to three response codes can be configured, where each code is separated by a comma (e.g., 407,404). By default, no response code is defined. If no response code is configured, or if response codes received are not those configured, the proxy is considered online.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The SIP 200 response code is not supported for this feature.</li> <li>The parameter is applicable only if you configure the 'Proxy Keep-Alive' parameter to <b>Using OPTIONS</b>, <b>Using OPTIONS on Active Server</b> or <b>Using Fake REGISTER</b>.</li> </ul>
'Success Detection Retries' success-detect-retries [SuccessDetectionRetrie s]	<p>Defines the minimum number of consecutive, successful keep-alive messages that the device sends to an offline proxy, before the device considers the proxy as online. The interval between the sending of each consecutive successful keep-alive is configured by the 'Success Detection Interval' parameter (see below). For an example of using this parameter, see the</p>

Parameter	Description
	<p>'Success Detection Interval' parameter.</p> <p>The valid range is 1 to 100. The default is 1.</p> <p><b>Note:</b> The parameter is applicable only if you configure the 'Proxy Keep-Alive' parameter to <b>Using OPTIONS, Using OPTIONS on Active Server</b> or <b>Using Fake REGISTER</b>.</p>
<p>'Success Detection Interval'</p> <p>success-detect-int</p> <p>[SuccessDetectionInterval]</p>	<p>Defines the interval (in seconds) between each successful keep-alive retries (as configured by the 'Success Detection Retries' parameter) that the device performs for offline proxies.</p> <p>The valid range is 1 to 200. The default is 10.</p> <p>For example, assume that the 'Success Detection Retries' parameter is configured to 3 and the 'Success Detection Interval' parameter to 5 (seconds). When connectivity is lost with the proxy, the device sends keep-alive messages to the proxy. If the device receives a successful response from the proxy, it sends another (1st) keep-alive after 5 seconds, and if successful, sends another (2nd) keep-alive after 5 seconds, and if successful, sends another (3rd) keep-alive after 5 seconds, and if successful, considers connectivity with the proxy as being restored.</p> <p><b>Note:</b> The parameter is applicable only if you configure the 'Proxy Keep-Alive' parameter to <b>Using OPTIONS, Using OPTIONS on Active Server</b> or <b>Using Fake REGISTER</b>.</p>
<p>'Failure Detection Retransmissions'</p> <p>fail-detect-rtx</p> <p>[FailureDetectionRetransmissions]</p>	<p>Defines the maximum number of UDP retransmissions that the device sends to an offline proxy before the device considers the proxy as offline.</p> <p>The valid range is -1 to 255. The default is -1, which means that the setting of the global parameter [SIPMaxRtx] is applied.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if you configure the 'Proxy Keep-Alive' parameter to <b>Using OPTIONS, Using OPTIONS on Active Server</b> or <b>Using Fake REGISTER</b>.</li> <li>■ If the device receives an ICMP error response (which indicates Host Unreachable or Network Unreachable) as opposed to a timeout, it may be desirable to abandon additional retries in favor of trying the next IP address (proxy) in the Proxy Set (typically required when Proxy Hot Swap is enabled). To enable this, configure the [AbortRetriesOnICMPError] parameter to 1.</li> </ul>
Redundancy	

Parameter	Description
'Redundancy Mode' proxy- redundancy-mode [ProxyRedundancyMode]	<p>Enables proxy redundancy.</p> <ul style="list-style-type: none"> <li>■ [-1] = (Default) Not configured. Proxy redundancy method is according to the settings of the global parameter [ProxyRedundancyMode].</li> <li>■ [0] <b>Parking</b> = If the device operates with a proxy server that has the highest priority and the proxy goes offline, the device attempts to connect and operate with a different proxy that has the highest priority of all currently online proxies. However, once the device starts operating with this new proxy, it remains operating with it even if a previously offline proxy that has higher priority becomes online again.</li> <li>■ [1] <b>Homing</b> = The device always attempts to operate with the proxy that has the highest priority of all currently online proxies. For example, if the device is currently operating with proxy server 200.10.1.1 that has priority 4, and then a previously offline proxy 200.10.1.2 that has priority 0 (i.e., a higher priority) becomes online again, the device attempts to connect and operate with proxy 200.10.1.2.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For proxy redundancy, you also need to enable the proxy keep-alive feature (see the 'Proxy Keep-Alive' parameter, above). The <b>Homing</b> redundancy mode is applicable only to proxy keep-alive using SIP OPTIONS (i.e., 'Proxy Keep-Alive' parameter configured to <b>Using OPTIONS</b> or <b>Using OPTIONS on Active Server</b>) or using fake REGISTER requests (i.e., 'Proxy Keep-Alive' parameter configured to <b>Using Fake REGISTER</b>). The <b>Parking</b> redundancy mode is applicable to all proxy keep-alive methods (SIP OPTIONS and SIP REGISTER).</li> <li>■ From Version 7.20A.204, if you configure the parameter to <b>Parking</b> and the proxy keep-alive is done using REGISTER messages, when the proxy goes offline, the device arbitrarily chooses the next proxy to operate with.</li> <li>■ To configure proxy priority, see the 'Proxy Priority' parameter in the Proxy Address table (below).</li> </ul>
'Proxy Hot Swap Mode' is-proxy-hot- swap [IsProxyHotSwap]	<p>Enables the Proxy Hot-Swap feature, whereby if the device sends a SIP message (INVITE or REGISTER) to the proxy and the message fails, the device re-sends the same message to a redundant proxy in the Proxy Set. The redundant proxy is</p>

Parameter	Description
	<p>determined by your Proxy Set configuration (i.e., redundancy mode and load balancing).</p> <ul style="list-style-type: none"> <li>■ <b>[0] Enable Only Before Alternative Routing</b> = If the device sends a SIP message (INVITE or REGISTER) to the proxy and the proxy rejects it or there is no response from the proxy for a user-defined number of re-transmissions (configured by the [SIPMaxRtx] parameter), the device doesn't attempt to connect to any other proxy in the Proxy Set, and the SIP message fails.</li> </ul> <p>However, if you've configured an SBC Alternative Routing Reasons Set for the IP Group (see <a href="#">Configuring SIP Response Codes for Alternative Routing Reasons</a> on page 1104), the device tries up to four online proxies in the Proxy Set. If it successfully connects to one of the redundant proxies, it re-sends the message to this proxy. This functionality doesn't apply to REGISTER requests initiated by the device (e.g., for Accounts).</p> <ul style="list-style-type: none"> <li>■ <b>[1] Enable</b> = If the device sends a SIP message (INVITE or REGISTER) to the proxy with which it is currently operating and any of the following occurs, the device re-sends the message to a redundant, online proxy: <ul style="list-style-type: none"> <li>✓ No response is received from the proxy each time the device re-sends it. The number of retransmissions is configured by the [HotSwapRtx] parameter. In this scenario, the device sends itself the SIP response code 408 (Request Timeout).</li> <li>✓ (SBC Application) The proxy rejects the message with a SIP response code that you have configured for the Alternative Reasons Set that is assigned to the IP Group ('SBC Alternative Routing Reasons Set' parameter) associated with the Proxy Set (see <a href="#">Configuring SIP Response Codes for Alternative Routing Reasons</a> on page 1104).</li> <li>✓ (Gateway Application) The proxy rejects the message with a SIP response code that is configured in the Reasons for Tel-to-IP Alternative Routing table (see <a href="#">Alternative Tel-to-IP Routing Based on SIP Responses</a> on page 940).</li> </ul> </li> </ul> <p><b>Note:</b>For the SBC application: You can employ alternative</p>



Parameter	Description
	<p>routing with this option. If no response is received from any of the redundant (online) proxies or the proxies reject the message with a SIP response code that you have configured for the Alternative Reasons Set that is assigned to the IP Group ('SBC Alternative Routing Reasons Set' parameter) associated with the Proxy Set, the device searches the IP-to-IP Routing table for an alternative routing rule and if found, sends the message to the rule's destination. For more information on the Proxy Hot Swap feature and alternative routing based on SIP response codes, see <a href="#">Configuring SIP Response Codes for Alternative Routing Reasons</a> on page 1104.</p> <ul style="list-style-type: none"> <li>■ [2] <b>Disable</b> = (Default) Disables the Proxy Hot-Swap feature. If the device sends a SIP message (INVITE or REGISTER) to the proxy and the proxy rejects it or there is no response from the proxy for a user-defined number of re-transmissions (configured by the [SIPMaxRtx] parameter), the device doesn't attempt to connect to any other proxy in the Proxy Set, and the SIP message fails.</li> </ul>
<p>'Proxy Load Balancing Method'</p> <p>proxy-load-balancing-method</p> <p>[ProxyLoadBalancingMethod]</p>	<p>Enables load balancing between proxy servers in the Proxy Set.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) Disables proxy load balancing.</li> <li>■ [1] <b>Round Robin</b> = The device sends outgoing SIP messages to the online proxy servers of the Proxy Set in a round-robin fashion. The order of the round-robin is determined by the listed order of the IP addresses in the Proxy Address table and their priority. You can configure the priority for each IP address using the 'Proxy Priority' parameter (see below).</li> </ul> <p>For DNS-resolved IP addresses for proxy servers configured with an FQDN (including NAPTR and SRV, if configured), the priority is received from the DNS. The IP address list is refreshed every user-defined interval, configured by the [ProxyIPListRefreshTime] parameter. If a change in the order of the IP address entries in the list occurs, all load statistics are erased and balancing starts over again.</p> <p>For the Gateway application, REGISTER messages are also distributed in a round-robin fashion, unless you have configured a specific IP address of a registrar server (using the [RegistrarIP] parameter).</p> <ul style="list-style-type: none"> <li>■ [2] <b>Random Weights</b> = The outgoing requests are not</li> </ul>

Parameter	Description
	<p>distributed equally among the proxy servers. The distribution is determined by the weight of the proxy servers. You can configure the weight per proxy server, using the 'Proxy Random Weight' parameter in the Proxy Address table (see below).</p> <p>For proxy servers configured with an FQDN, the weight of each DNS-resolved IP address is received from the DNS server (using SRV records). However, if you have configured the weight for the FQDN in the 'Proxy Random Weight' parameter, this parameter's value overrides the weight from the DNS server. The device sends the requests in such a fashion that each proxy receives a percentage of the requests according to its' weight.</p>
'Min. Active Servers for Load Balancing' min-active-serv-lb [MinActiveServersLB]	<p>Defines the minimum number of proxies in the Proxy Set that must be online for the device to consider the Proxy Set as online, when proxy load balancing is used.</p> <p>The valid value is 1 to 15. The default is 1.</p> <p><b>Note:</b> The parameter is applicable only if proxy load balancing is enabled (see the 'Proxy Load Balancing Method' parameter, above).</p>
Advanced	
'Classification Input' classification-input [ClassificationInput]	<p>Defines how the device classifies incoming IP calls to the Proxy Set.</p> <ul style="list-style-type: none"> <li>■ [0] <b>IP Address only</b> = (Default) Classifies calls to the Proxy Set according to IP address only.</li> <li>■ [1] <b>IP Address, Port &amp; Transport Type</b> = Classifies calls to the Proxy Set according to IP address, port, and transport type.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the SBC application.</li> <li>■ The parameter is applicable only if the IP Groups table's parameter 'Classify by Proxy Set' is configured to <b>Enable</b> (see <a href="#">Configuring IP Groups</a> on page 581).</li> <li>■ If multiple Proxy Sets are configured with the same IP address and associated with the same SIP Interface, the device may classify the SIP dialog (based on Proxy Set) to an incorrect IP Group. In such a scenario, the device uses the</li> </ul>

Parameter	Description															
	<p>Proxy Set with the lowest Index number (e.g., Proxy Set ID #1 over Proxy Set ID #4). A syslog warning message is generated in such scenarios. Therefore, it is recommended to configure each Proxy Set with a unique IP address.</p> <p>If multiple Proxy Sets are configured with the same IP address but associated with different SIP Interfaces, then classification based on Proxy Set can be correctly achieved. If multiple Proxy Sets are configured with the same IP address and SIP Interface, but with different ports (e.g., 10.1.1.1:5060 and 10.1.1.1:5070) and the parameter is configured to <b>IP Address, Port &amp; Transport Type</b>, classification to the correct IP Group is achieved. Therefore, when classification is by Proxy Set, pay attention to the configured IP addresses and this parameter. When multiple Proxy Sets are configured with the same IP address, the device selects the matching Proxy Set in the following order:</p> <ul style="list-style-type: none"><li>✓ Selects the Proxy Set whose IP address, port, and transport type match the source of the incoming SIP request (regardless of the settings of this parameter).</li><li>✓ If no match is found for above, it selects the Proxy Set whose IP address and transport type match the source of the incoming SIP request (if the parameter is configured to <b>IP Address Only</b>).</li><li>✓ If no match is found for above, it selects the Proxy Set whose IP address match the source of the incoming SIP request (if the parameter is configured to <b>IP Address Only</b>).</li></ul> <p>For example:</p> <table><tr><th>Index</th><th>Classification Input</th><th>Proxy Address (IP:Port;Transport Type)</th></tr><tr><td>1</td><td><b>IP Address, Port &amp; Transport Type</b></td><td>10.10.10.10:5060;UDP</td></tr><tr><td>2</td><td><b>IP Address only</b></td><td>10.10.10.10:5060;UDP</td></tr><tr><td>3</td><td><b>IP Address only</b></td><td>10.10.10.10:5070;UDP</td></tr><tr><td>4</td><td><b>IP Address only</b></td><td>10.10.10.10:5060;TCP</td></tr></table> <ul style="list-style-type: none"><li>✓ <b>Incoming SIP request from 10.10.10.10:5060;UDP:</b> Best match is #1 and #2 (same priority); second best match is #3 (due to transport type); third best match is</li></ul>	Index	Classification Input	Proxy Address (IP:Port;Transport Type)	1	<b>IP Address, Port &amp; Transport Type</b>	10.10.10.10:5060;UDP	2	<b>IP Address only</b>	10.10.10.10:5060;UDP	3	<b>IP Address only</b>	10.10.10.10:5070;UDP	4	<b>IP Address only</b>	10.10.10.10:5060;TCP
Index	Classification Input	Proxy Address (IP:Port;Transport Type)														
1	<b>IP Address, Port &amp; Transport Type</b>	10.10.10.10:5060;UDP														
2	<b>IP Address only</b>	10.10.10.10:5060;UDP														
3	<b>IP Address only</b>	10.10.10.10:5070;UDP														
4	<b>IP Address only</b>	10.10.10.10:5060;TCP														

Parameter	Description
	<p>#4.</p> <ul style="list-style-type: none"> <li>✓ <b>Incoming SIP request from 10.10.10.10:5080;TLS:</b> Best match is #2, #3 and #4 (same priority).</li> <li>✓ <b>Incoming SIP request from 10.10.10.10:5070;TCP:</b> Best match is #4 (due to transport type); second best match is #2 and #3 (same priority).</li> </ul>
<p>'DNS Resolve Method'</p> <p>dns-resolve-method</p> <p>[DNSResolveMethod]</p>	<p>Defines the DNS query record type for resolving the proxy server's hostname / domain name (FQDN) into an IP address (es).</p> <ul style="list-style-type: none"> <li>■ [-1] = Not configured. DNS resolution method is according to the settings of the global parameter [ProxyDNSQueryType].</li> <li>■ [0] <b>A-Record</b> = (Default) The device performs a DNS A-record query to resolve the FQDN into an IP address(es).</li> <li>■ [1] <b>SRV</b> = If the proxy address is configured with a domain name without a port (e.g., domain.com), the device performs an SRV query. The SRV query returns the host names (and their weights). The device then performs DNS A-record queries per host name (according to the received weights). If the configured proxy address contains an FQDN with a port (e.g., domain.com:5080), the device performs a regular DNS A-record query.</li> <li>■ [2] <b>NAPTR</b> = The device performs a NAPTR query. If successful, the device sends an SRV query according to the information received in the NAPTR response (in preference order). The SRV response is resolved to obtain one or more FQDNs, which are then resolved with A-record queries. If no online servers are found, the resolution process returns to the next SRV record in the NAPTR response, and so on. If the NAPTR query fails, the device performs a SRV query according to the configured transport type. If the configured proxy address contains an domain name with a port (e.g., domain.com:5080), the device performs a regular DNS A-record query. If the transport type is configured for the proxy address, a NAPTR query is not performed.</li> <li>■ [3] <b>Microsoft Skype for Business</b> = The device performs an SRV query as required by Microsoft when the device is deployed in a Microsoft Skype for Business environment. The device sends a special SRV query to the DNS server</li> </ul>

Parameter	Description
	<p>according to the transport protocol configured in the 'Transport Type' parameter (described later in this section):</p> <ul style="list-style-type: none"> <li>✓ <b>TLS</b></li> <li>✓ <b>TCP:</b> "_sipinternal._tcp.&lt;domain&gt;" and "_sip_tcp.&lt;domain&gt;".</li> <li>✓ <b>Undefined:</b> "_sipinternaltls_tcp.&lt;domain&gt;", "_sipinternal_tcp.&lt;domain&gt;", "_sip_tls.&lt;domain&gt;" and "_sip_tcp.&lt;domain&gt;".</li> </ul> <p>The SRV query returns the host names (and their weights). The device then performs DNS A-record queries per host name (according to the received weights) to resolve into IP addresses.</p> <p><b>Note:</b> The device caches the DNS-resolved IP addresses of the last successful DNS query of a Proxy Set. The device uses the cache if the DNS server goes offline. This functionality occurs regardless of the setting of the [DNSCache] parameter.</p>
<p>'Accept DHCP Proxy List'</p> <p>accept-dhcp-proxy-list</p> <p>[AcceptDHCPProxyList]</p>	<p>Enables the device to obtain the Proxy Set's address(es) from a DHCP server. When enabled, it sends a DHCP request with Option 120 (SIP server address) to a DHCP server. This occurs upon a DHCP refresh (lease renewal). When the device receives the list of IP addresses (or DNS) from the server, it adds them to the Proxy Set (replaces any existing IP addresses or DNS).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p><b>Note:</b> When enabled, the device uses UDP and port 5060.</p>
<p>'TLS Remote Subject Name'</p> <p>tls-remote-subject-name</p> <p>[TLSRemoteSubjectName]</p>	<p>Defines the Subject Name of the TLS certificate received from the remote side when establishing a TLS connection with the Proxy Set.</p> <p>When the device receives a certificate from the remote side, it validates the certificate by comparing the certificate's Subject Alternative Names (SAN) with the Proxy Set's addresses (IP address and FQDN) and the parameter's value. If a SAN matches an address or the parameter's value, the device considers the certificate as valid and establishes the TLS connection and allows the call.</p> <p>If there is no match and the SAN is marked as "critical", the device doesn't establish a TLS connection and rejects the call. If</p>

Parameter	Description
	<p>there is no match and the SAN isn't marked as "critical", the device compares the Proxy Set's addresses (IP address and FQDN) and the parameter's value with the certificate's Common Name (CN). If any of them match, the device establishes a TLS connection and allows the call; otherwise, it doesn't establish a TLS connection and rejects the call.</p> <p>The valid value is a string of up to 100 characters. By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if you configure the Proxy Set's parameter 'Peer Host Name Verification Mode' (or global parameter [PeerHostNameVerificationMode]) to <b>Server Only</b> or <b>Server &amp; Client</b>.</li> <li>■ If you configure the parameter, it overrides the global parameter [TLSRemoteSubjectName].</li> <li>■ For incoming messages, the 'TLS Mutual Authentication' parameter (global or per SIP Interface) must be enabled.</li> <li>■ For outgoing messages, either the 'TLS Mutual Authentication' parameter (global or per SIP Interface) or the 'TLS Client Verify Server Certificate' parameter must be enabled.</li> <li>■ A certificate may include multiple SAN types (e.g., Email, DNS, URI, and IP). The only SAN types that the device compares for matching are DNS and IP.</li> </ul>
<p>'Peer Host Name Verification Mode'</p> <p>peer-host-name-verification-mode</p> <p>[PeerHostNameVerificationMode]</p>	<p>Enables the device to verify the Subject Name of the TLS certificate received from the remote side for authentication and establishing a TLS connection.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Use Global Settings</b> = (Default) The settings of the global parameter ['<a href="#">Peer Host Name Verification Mode</a>' on page 1670] is applied.</li> <li>■ [0] <b>Disable</b> = No certificate verification is done.</li> <li>■ [1] <b>Server Only</b> = The device verifies the certificate's Subject Name only when it acts as a client for the TLS connection.</li> <li>■ [2] <b>Server &amp; Client</b> = The device verifies the certificate's Subject Name when it acts as a server or client for the TLS connection.</li> </ul>

Parameter	Description
	<p>If the device receives a certificate from a SIP entity (IP Group) and the parameter is configured to <b>Server Only</b> or <b>Server &amp; Client</b> (or global parameter is used and configured to one of these options), it attempts to authenticate the certificate based on the certificate's address:</p> <ol style="list-style-type: none"> <li>1. If the connection was classified to a Proxy Set, the device compares the certificate's Subject Alternative Names (SANs) with the Proxy Set's addresses (IP address or FQDN) and the 'TLS Remote Subject Name' parameter's value. The device checks the FQDN itself and not the DNS-resolved IP addresses.</li> <li>2. If a SAN matches an address or the 'TLS Remote Subject Name' parameter's value, the device considers the certificate as valid and establishes the TLS connection and allows the call.</li> <li>3. If there is no match and the SAN is marked as "critical", the device doesn't establish a TLS connection and rejects the call. If there is no match and the SAN isn't marked as "critical", the device compares the Proxy Set's addresses (IP address or FQDN) and the 'TLS Remote Subject Name' parameter's value with the certificate's Common Name (CN). If any of them match, the device establishes a TLS connection and allows the call; otherwise, the device doesn't establish a TLS connection and rejects the call.</li> </ol> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you configure the parameter to <b>Server &amp; Client</b>, enable the global 'TLS Mutual Authentication' parameter [SIPSRequireClientCertificate].</li> <li>■ If you configure the parameter to <b>Server Only</b>, enable the 'TLS Client Verify Server Certificate' [VerifyServerCertificate] global parameter.</li> <li>■ For FQDN, the certificate may use wildcards (*) to replace parts of the domain name.</li> </ul>
'TCP/TLS Connection Reuse' connection-reuse [ConnectionReuse]	<p>Enables the reuse of the initially established TCP or TLS connection between the device and the proxy server for all subsequent SIP requests sent to the proxy server. New out-of-dialog requests (e.g., INVITE or REGISTER) use the same secured connection. One of the benefits of enabling the parameter is that it may improve performance by eliminating</p>

Parameter	Description
	<p>the need for additional TCP/TLS handshakes with the proxy, allowing sessions to be established rapidly.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = The device establishes a new TCP or TLS connection with the proxy for each SIP request.</li> <li>■ [1] <b>Enable</b> = The device uses the same TCP or TLS connection for all SIP requests with the proxy.</li> <li>■ [2] <b>Use Global Settings</b> = (Default) This feature is according to the global parameter [<a href="#">TCP/TLS Connection Reuse</a>] on page 1716].</li> </ul> <p><b>Note:</b> For SIP responses, the device always uses the TCP/TLS connection of the corresponding incoming SIP request, regardless of the parameter's setting.</p>
<p>'In-Call Route Mode' in-call-route-mode [InCallRouteMode]</p>	<p>Enables the device to send in-call SIP messages (e.g., re-INVITE and BYE) to the currently active proxy if the proxy to which the dialog-initiating INVITE message was sent is currently offline. This is applicable when the Proxy Set has multiple proxies (IP addresses). This feature occurs even if the currently active proxy was offline when the call was established.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) The device sends in-call SIP messages to the currently active proxy if it was online upon call establishment. If it was offline upon call establishment, the device sends the in-dialog message to a different proxy in the Proxy Set. If no additional proxies exist, the device doesn't send the message.</li> <li>■ [1] <b>Enable</b> = The device sends in-call SIP messages to the currently active proxy, regardless of its state (i.e., online or offline) when the call was established.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ When enabling this feature, it's recommended to configure the Proxy Set's 'Proxy Keep-Alive' parameter to <b>Enable</b>.</li> <li>■ When enabling this feature, make sure to configure all proxies in the Proxy Set with the same transport type (e.g., all TCP). Otherwise, unexpected behavior (even call failure) may occur.</li> <li>■ The device's generated CDR displays only the proxy used for the dialog-initiating INVITE message.</li> </ul>



Parameter	Description
Proxy Address Table	
'Index' proxy-ip-index [ProxyIp_ProxyIpIndex]	<p>Defines an index number for the new table row.</p> <p><b>Note:</b> Each row must be configured with a unique index.</p>
'Proxy Address' proxy-address [ProxyIp_IpAddress]	<p>Defines the address of the proxy server (Proxy Set). The address can be defined as an IP address in dotted-decimal notation (e.g., 201.10.8.1) or FQDN. You can also specify the port using the following format:</p> <ul style="list-style-type: none"> <li>■ IPv4 address: &lt;IP address&gt;:&lt;port&gt; (e.g., 201.10.8.1:5060)</li> <li>■ IPv6 address: &lt;[IPV6 address]&gt;:&lt;port&gt; (e.g., [2000::1:200:200:86:14]:5060)</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ When configured with an FQDN: <ul style="list-style-type: none"> <li>✓ You can configure the periodic interval at which the device performs DNS queries to resolve the FQDN into IP addresses. For more information, see the [ProxyIPListRefreshTime] parameter.</li> <li>✓ The device caches the DNS-resolved IP addresses of the last successful DNS query of a Proxy Set, which is used if the DNS server goes offline. This functionality occurs regardless of the setting of the [DNSCache] parameter.</li> <li>✓ You can configure the method (e.g., A-record) for resolving the domain name into an IP address, using the 'DNS Resolve Method' parameter in this table (see above).</li> </ul> </li> <li>■ For the SBC application: You can configure the device to use the port indicated in the Request-URI of the incoming message, instead of the port configured for the parameter. To enable this, use the 'Route Using Request URI Port' parameter for the IP Group that is associated with the Proxy Set (<a href="#">Configuring IP Groups</a> on page 581).</li> <li>■ If you are configuring the Proxy Sets with IP addresses, it is highly recommended to configure each Proxy Set with a unique IP address. Configuring multiple Proxy Sets with the same IP address can cause problems classifying incoming SIP requests to source IP Groups based on Proxy Set. If you have configured multiple Proxy Sets with the same IP</li> </ul>


Parameter	Description
	<p>address, the device uses the Proxy Set with lowest Index number. For example, if you have configured Proxy Set ID #1 and Proxy Set ID #4 with the same IP address, the device uses Proxy Set ID #1 to classify the incoming SIP request to an IP Group.</p> <p>However, configuring multiple Proxy Sets with the same IP address, but with different SIP Interfaces is acceptable for classifying incoming SIP requests to source IP Groups based on Proxy Set.</p> <p>For more information on determining the Proxy Set, see the 'Classification Input' parameter (above) parameter .</p>
'Transport Type' transport-type [ProxyIp_ TransportType]	<p>Defines the transport type for communicating with the proxy.</p> <ul style="list-style-type: none"> <li>■ [-1] = (Default) Not configured. The transport type is according to the settings of the global parameter [SIPTransportType].</li> <li>■ [0] UDP</li> <li>■ [1] TCP</li> <li>■ [2] TLS</li> </ul>
'Proxy Priority' priority [ProxyIp_Priority]	<p>Defines the priority of the proxy. When a proxy server goes offline, the device attempts to connect to an online proxy server that has the highest priority.</p> <p>The valid value is 0 to 65535, where 0 is the highest priority and 65535 the lowest. The default is 0.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ You must configure both priority and weight (or none of them). In other words, if you configure this parameter, you must also configure the 'Proxy Random Weight' parameter. If you don't configure this parameter, you must also not configure the 'Proxy Random Weight' parameter.</li> <li>■ If weight and priority are not configured for any of the proxy servers of the Proxy Set, the order in which the addresses (IP addresses and FQDNs) are listed in the table determine their priority (i.e., top-listed address has the highest priority).</li> <li>■ For FQDNs, weight and priority of DNS-resolved IP addresses are determined by the DNS server. However, this parameter's value overrides the priority received from the</li> </ul>

Parameter	Description
	<p>DNS.</p> <ul style="list-style-type: none"> <li>■ If you have configured at least one of the proxy servers of the Proxy Set with weight and priority, the device prioritizes all the configured proxy servers according to weight and priority. In this case, proxy servers that are not configured with priority (i.e., 0) are considered as proxy servers with the highest priority.</li> <li>■ The parameter is applicable to load balancing (see the 'Proxy Load Balancing Method' parameter), and homing and parking redundancy (see the 'Redundancy Mode' parameter).</li> </ul>
'Proxy Random Weight' weight [ProxyIp_Weight]	<p>Defines the weight of the proxy.</p> <p>The valid value is 0 to 65535, where 0 is the highest weight and 65535 the lowest. The default is 0.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if you configure the 'Proxy Load Balancing Method' parameter to <b>Random Weights</b>. For more information on weights, see this parameter.</li> <li>■ You must configure both priority and weight (or none of them). In other words, if you configure this parameter, you must also configure the 'Proxy Priority' parameter. If you don't configure this parameter, you must also not configure the 'Proxy Priority' parameter.</li> <li>■ For proxy servers configured with FQDNs, this parameter's value overrides the weight received for DNS-resolved IP addresses from the DNS server.</li> </ul>


## Building and Viewing SIP Entities in Topology View

The Topology view lets you easily build and view your main SIP entities, including trunks and ports, Trunk Groups, IP Groups, SIP Interfaces, and Media Realms. The Topology view graphically displays these entities and the associations between them, giving you a better understanding of your SIP topology and configuration. The Topology view also lets you configure additional SIP settings that are important to your deployment such as routing and manipulation. You can use the Topology view as an alternative to configuring the entities in their respective Web pages or you can use it in combination.

To access the Topology view, do one of the following:





- Click the Topology View home  icon (**Setup** menu > **Signaling & Media** tab > **Topology View**).
- Click the logo, which is located in the top-left corner of the Web interface.







The main areas of the Topology view is shown below and described in the subsequent table.














**Table 18-8: Description of Topology View**

Item #	Description
1	<p>Demarcation area of the topology. By default, the Topology view displays the following names to represent the different demarcations of your voice configuration:</p> <ul style="list-style-type: none"> <li>■ "PSTN": Indicates the PSTN side</li> <li>■ "WAN": Indicates the external network side</li> <li>■ "LAN": Indicates the internal network (e.g., inside the company)</li> </ul> <p>To modify a demarcation name, do the following:</p> <ol style="list-style-type: none"> <li>1. Click the demarcation name; the name becomes editable in a text box, as shown in the example below:</li> </ol> <div data-bbox="790 1641 1029 1686" data-label="Image"> </div> <ol style="list-style-type: none"> <li>2. Type a name as desired, and then click anywhere outside of the text box to apply the name.</li> </ol> <p>You can use demarcation to visually separate your voice network to provide a clearer understanding of your topology. This is especially useful for IP Groups, SIP Interfaces, and Media Realms, where you can display them on the top or bottom border of the Topology view (as shown in the figure below for callouts</p>





Item #	Description
	<p>#1 and #2, respectively). For example, on the top border you can position all entities relating to WAN, and on the bottom border all entities relating to LAN.</p>  <p>By default, configuration entities are displayed on the bottom border. To define the position, use the 'Topology Location' parameter when configuring the entity, where <b>Down</b> is the bottom border and <b>Up</b> the top border:</p> <p>Topology Location <input data-bbox="826 969 1272 1010" type="text" value="Down"/></p>
2	<p>Configured SIP Interfaces. Each SIP Interface is displayed using the following "SIP Interface"-titled icon, which includes the name and row index number:</p>  <p>If you hover your mouse over the icon, a pop-up appears displaying the following basic information (example):</p>  <p>If you click the icon, a drop-down menu appears listing the following commands:</p>  <p>■ <b>Edit:</b> Opens a dialog box in the SIP Interfaces table to modify the SIP Interface.</p>

Item #	Description
	<ul style="list-style-type: none"> <li>■ <b>Show List:</b> Opens the SIP Interfaces table.</li> <li>■ <b>Delete:</b> Opens the SIP Interfaces table where you are prompted to confirm deletion of the SIP Interface.</li> </ul> <p>To add a SIP Interface, do the following:</p> <ol style="list-style-type: none"> <li>1. Click the <b>Add SIP Interface</b>  plus icon. The icon appears next to existing SIP Interfaces, or as  when no SIP Interfaces exist on a topology border, or as  when there are no SIP Interfaces at all. The SIP Interfaces table opens with a new dialog box for adding a SIP Interface to the next available index row.</li> <li>2. Configure the SIP Interface as desired, and then click <b>Apply</b>; the SIP Interfaces table closes and you are returned to the Topology View, displaying the new SIP Interface.</li> </ol> <p>For more information on configuring SIP Interfaces, see <a href="#">Configuring SIP Interfaces</a> on page 561.</p>
3	<p>Configured Media Realms. Each Media Realm is displayed using the following "Media Realm"-titled icon, which includes the name and row index number:</p>  <p>If you hover your mouse over the icon, a pop-up appears displaying the following basic information (example):</p>  <p>If you click the icon, a drop-down menu appears listing the following commands:</p>  <ul style="list-style-type: none"> <li>■ <b>Edit:</b> Opens a dialog box in the Media Realms table to modify the Media Realm.</li> <li>■ <b>Show List:</b> Opens the Media Realms table.</li> <li>■ <b>Delete:</b> Opens the Media Realms table where you are prompted to confirm</li> </ul>

Item #	Description
	<p>deletion of the Media Realm.</p> <p>To add a Media Realm, do the following:</p> <ol style="list-style-type: none"> <li>1. Click the <b>Add Media Realm</b>  plus icon. The icon appears next to existing Media Realms, or as  when no Media Realms exist on a topology border, or as  when there are no Media Realms at all.</li> </ol> <p>The Media Realms table opens with a new dialog box for adding a Media Realm to the next available index row.</p> <ol style="list-style-type: none"> <li>2. Configure the Media Realm as desired, and then click <b>Apply</b>; the Media Realms table closes and you are returned to the Topology View, displaying the new Media Realm.</li> </ol> <p>For more information on configuring Media Realms, see <a href="#">Configuring Media Realms</a> on page 539.</p>
4	<p>Configured IP Groups. Each IP Group is displayed using the following "IP Group [Server]" or "IP Group [User]" titled icon (depending on whether it's a Server- or User-type IP Group respectively), which includes the name and row index number (example of a Server-type):</p>  <p>If you hover your mouse over the icon, a pop-up appears displaying the following basic information (example):</p>  <p>If you click the icon, a drop-down menu appears listing the following commands:</p>  <ul style="list-style-type: none"> <li>■ <b>Edit:</b> Opens a dialog box in the IP Groups table to modify the IP Group.</li> <li>■ <b>Show List:</b> Opens the IP Groups table.</li> <li>■ <b>Delete:</b> Opens the IP Groups table where you are prompted to confirm deletion of the IP Group.</li> </ul>

Item #	Description
	<p>To add an IP Group, do the following:</p> <ol style="list-style-type: none"> <li>Click the <b>Add IP Group</b>  plus icon. The icon appears next to existing IP Groups, or as  when no IP Groups exist on a topology border, or as  when there are no IP Groups at all. The IP Groups table opens with a new dialog box for adding a IP Group to the next available index row.</li> <li>Configure the IP Group as desired, and then click <b>Apply</b>; the IP Groups table closes and you are returned to the Topology View, displaying the new IP Group.</li> </ol> <p>For more information on configuring IP Groups, see <a href="#">Configuring IP Groups</a> on page 581.</p> <p>IP Group icons also display connectivity status with Server-type IP Groups:</p> <ul style="list-style-type: none"> <li> (Green with check mark): Keep-alive is successful and connectivity exists with IP Group.</li> <li> (Red with "x"): Keep-alive has failed and there is a loss of connectivity with the IP Group.</li> </ul> <p>The line type connecting between an IP Group and a SIP Interface indicates whether a routing rule has been configured for the IP Group. A solid line indicates that you have configured a routing rule for the IP Group; a dashed line indicates that you have yet to configure a routing rule.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>You can also view connectivity status in the IP Groups table.</li> <li>To support the connectivity status feature, you must enable the keep-alive mechanism for the Proxy Set that is associated with the IP Group (see <a href="#">Configuring Proxy Sets</a> on page 622).</li> <li>The green-color state also applies to scenarios where the device rejects calls with the IP Group due to low QoE (e.g., low MOS), despite connectivity.</li> </ul>
5	<p>Links to Web pages relating to commonly required SBC configuration:</p> <ul style="list-style-type: none"> <li><b>Classification:</b> Opens the Classification table where you can configure Classification rules (see <a href="#">Configuring Classification Rules</a> on page 1061).</li> <li><b>Number Manipulation:</b> Opens the Outbound Manipulations table where you can configure manipulation rules on SIP Request-URI user parts (source or</li> </ul>



Item #	Description
	<p>destination) or calling names in outbound SIP dialog requests (see <a href="#">Configuring IP-to-IP Outbound Manipulations</a> on page 1126).</p> <ul style="list-style-type: none"> <li>■ Routing: Opens the IP-to-IP Routing table where you can configure IP-to-IP routing rules (see <a href="#">Configuring SBC IP-to-IP Routing Rules</a> on page 1076).</li> <li>■ SBC Settings: Opens the SBC General Settings page where you can configure miscellaneous settings.</li> </ul>
6	<p>Configured Trunk Groups. Each Trunk Group is displayed using the following "Trunk Group"-titled icon, which includes the row index number:</p>  <p>To edit or delete the Trunk Group, click the icon, and then from the drop-down menu, choose <b>Show List</b> to open the Trunk Groups table.</p> <p>To add a Trunk Group, do the following:</p> <ol style="list-style-type: none"> <li>1. Click the <b>Add Trunk Group</b>  plus icon. The icon appears next to existing Trunk Groups or as  when there are no Trunk Groups. The Trunk Groups table opens, allowing you to configure a Trunk Group.</li> <li>2. Configure the Trunk Group as desired, and then click <b>Apply</b>; the Trunk Groups table closes and you are returned to the Topology View, displaying the new Trunk Group and a line connecting it to the associated port, as shown in the example below:</li> </ol>  <p>For more information on configuring Trunk Groups, see <a href="#">Configuring Trunk Groups</a> on page 903.</p>
7	<p>Displays the device's hardware configuration concerning telephony (Tel/PSTN) trunks and ports. It also displays the number of ports. The ports are displayed as round icons, as shown in Item #6 above.</p> <p>To configure a digital trunk, do the following:</p> <ol style="list-style-type: none"> <li>1. Click the icon, and then from the drop-down menu, choose <b>Trunk Settings</b>; the Trunk Settings page appears.</li> </ol>

Item #	Description
	<p><b>2.</b> Configure the trunk as desired.</p> <p>For more information on configuring trunk settings, see <a href="#">Configuring Trunk Settings</a> on page 850.</p>
8	<p>Links to Web pages relating to commonly required Gateway configuration:</p> <ul style="list-style-type: none"><li>■ <b>Number Manipulation:</b> Opens the Destination Phone Number Manipulation for IP-to-Tel Calls table where you can configure destination phone number manipulation rules for IP-to-Tel calls (see <a href="#">Configuring Source-Destination Number Manipulation Rules</a> on page 950).</li><li>■ <b>Routing:</b> Opens the IP-to-Tel Routing table where you can configure IP-to-Tel routing rules (see <a href="#">Configuring IP-to-Tel Routing Rules</a> on page 928).</li><li>■ <b>DTMF &amp; Dialing:</b> Opens the DTMF &amp; Dialing page where you can configure DTMF and dialing related settings.</li><li>■ <b>GW Settings:</b> Opens the Gateway General Settings page where you can configure general gateway related settings.</li></ul>

## 19 Coders and Profiles

This section describes configuration of coders and SIP profiles.

### Configuring Coders Groups

The Coders Groups table lets you configure Coders Groups, which determines the audio (voice) coders used for calls.

Coders Groups are configured using two tables with parent-child relationship:

- **Coders Groups table (parent):** This table defines the name of the Coders Group. You can configure up to 11 Coders Groups.
- **Coders table (child):** This table defines the coders of the selected Coders Group. You can configure up to 10 coders per Coders Group. Each coder can be configured with a packetization time (ptime), bit rate, payload type, and silence suppression. The first coder listed in the Coders table has the highest priority and is used by the device whenever possible. If the remote side cannot use the first coder, the device attempts to use the next coder in the list, and so on.

The Coders Groups table provides a default Coder Group called "AudioCodersGroups\_0" (index 0), which includes the G.711 A-law coder. If you don't configure any other Coder Groups, the device uses this default Coder Group (which you can modify) for all calls.

If you want to use specific coders or coder settings (e.g., packetization time) for specific calls (IP Groups), you can configure different Coders Groups and then assign them to the Tel Profiles (see [Configuring Tel Profile](#) on page 738) or IP Profiles (see [Configuring IP Profiles](#) on page 664) associated with the IP Groups. If an IP Group isn't associated with a Coders Group, the default Coders Group is used for the IP Group.



- For supported audio coders, see [Supported Audio Coders](#) on page 655.
- Some coders are license-based and are available only if included in the device's License Key. For more information, contact the sales representative of your purchased device.
- Only the packetization time of the first coder listed in the Coder Group is declared in INVITE/200 OK SDP even if multiple coders are configured. The device always uses the packetization time requested by the remote side for sending RTP packets. If not specified, the packetization time is assigned the default value.
- The value of some fields is hard-coded according to common standards (e.g., payload type of G.711 U-law is always 0).
- The G.722 coder provides Packet Loss Concealment (PLC) capabilities, which ensures higher voice quality.
- Opus coder:
  - ✓ For SBC calls: If one leg uses a narrowband coder (e.g., G.711) and the other leg uses the Opus coder, the device maintains the narrowband coder flavor by using the narrowband Opus coder. Alternatively, if one leg uses a wideband coder (e.g., G.722) and the other leg uses the Opus coder, the device maintains the wideband coder flavor by using the wideband Opus coder.
  - ✓ Gateway calls always use the narrowband Opus coder.
- For more information on V.152 and implementation of T.38 and VBD coders, see [V.152 Support](#) on page 289.
- The G.729 coder refers to G.729A if silence suppression is disabled, or to G.729AB if silence suppression is enabled.

The following procedure describes how to configure Coders Groups through the Web interface. You can also configure them through other management platforms:

- **Coders Groups table (parent):** ini file [AudioCodersGroups] or CLI (`configure voip > coders-and-profiles audio-coders-groups`)
- **Coders table (child):** ini file [AudioCoders] or CLI (`configure voip > coders-and-profiles audio-coders-groups > audio-coders`)

#### ➤ To configure a Coders Group:

1. Open the Coders Groups table (**Setup** menu > **Signaling & Media** tab > **Coders & Profiles** folder > **Coders Groups**).
2. Click **New**; the following dialog box appears:

GENERAL	
Index	2
Name	

3. Configure a name for the Coders Group according to the parameters described in the table below.

4. Click **Apply**.**Table 19-1: Coders Groups Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' coders- group-name [Name]	Defines a descriptive name for the Coder Group, which is used when associating the row in other tables. The valid value is a string of up to 40 characters.

5. Select the Coders Group that you configured, and then click the **Coders Table** link located below the table; the Coders table appears.6. Click **New**; the following dialog box appears:

*Coders Table [99]* - x

GENERAL

Index	<input type="text" value="1"/>
Name	<input type="text" value="G.723.1"/>
pTime	<input type="text" value="30"/>
Rate	<input type="text" value="5.3"/>
Payload Type	<input type="text" value="4"/>
Silence Suppression	<input type="text" value="Disable"/>
Coder Specific	<input type="text"/>

## 7. Configure a coder for the Coders Group according to the parameters described in the table below.

8. Click **Apply**, and then save your settings to flash memory.**Table 19-2: Coders Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [Name]	Defines the coder type. For supported coders, see <a href="#">Supported Audio Coders</a> on page 655. <b>Note:</b> Each coder type (e.g., G.729) can be configured only once per Coder Group.
'pTime'	Defines the packetization time (in msec) of the coder.

Parameter	Description
p-time [pTime]	The packetization time determines how many coder payloads are combined into a single RTP packet. For ptime, see <a href="#">Supported Audio Coders</a> on the next page.
'Rate' rate [rate]	Defines the bit rate (in kbps) of the coder. For rates, see <a href="#">Supported Audio Coders</a> on the next page.
'Payload Type' payload-type [PayloadType]	Defines the payload type if the payload type (i.e., format of the RTP payload) of the coder is dynamic. For payload types, see <a href="#">Supported Audio Coders</a> on the next page.
'Silence Suppression' silence-suppression [Sce]	<p>Enables silence suppression for the coder.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (Default)</li> <li>■ [1] <b>Enable</b></li> <li>■ [2] <b>Enable No-Adaptation</b> = Enables silence suppression using the proprietary noise adaptation mechanism. This is applicable only when the call uses one of the following coders: <ul style="list-style-type: none"> <li>✓ G.711: The device sends only one SID packet during periods of silence.</li> </ul> </li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you disable silence suppression for G.729, the device includes 'annexb=no' in the SDP of the relevant SIP messages. If you enable silence suppression, 'annexb=yes' is included. For the Gateway application, an exception is when the remote gateway is Cisco equipment (IsCiscoSCEMode).</li> </ul>
'Coder Specific' coder-specific [CoderSpecific]	<p>Defines additional settings specific to the AMR coder.</p> <ul style="list-style-type: none"> <li>■ [0] <b>0</b> = Bandwidth Efficient</li> <li>■ [1] <b>1</b> = Octet Aligned (default)</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the AMR coder and configures the payload format type.</li> <li>■ The AMR payload type can be configured globally using the [AmrOctetAlignedEnable] parameter.</li> </ul>

Parameter	Description
	Coders Group configuration overrides the global parameter.

## Supported Audio Coders

The table below lists the coders supported by the device.

**Table 19-3: Supported Audio Coders**

Coder Name	Packetization Time (msec) [1] 10, [2] 20, [3] 30, [4] 40, [5] 50, [6] 60, [8] 80, [9] 90, [10] 100, [12] 120	Rate (kbps)	Payload Type	Silence Suppression
<b>AMR</b> amr [14]	20 (default)	<input type="checkbox"/> [4] 4.75 <input type="checkbox"/> [6] 5.15 <input type="checkbox"/> [9] 5.90 <input type="checkbox"/> [14] 6.70 <input type="checkbox"/> [16] 7.40 <input type="checkbox"/> [18] 7.95 <input type="checkbox"/> [27] 10.2 <input type="checkbox"/> [30] 12.2 (default)	Dynamic	<input type="checkbox"/> [0] <b>Disable</b> <input type="checkbox"/> [1] <b>Enable</b>
<b>AMR-WB</b> amr-wb [15]	20 (default)	<input type="checkbox"/> [13] 6.6 <input type="checkbox"/> [21] 8.85 <input type="checkbox"/> [32] 12.65 <input type="checkbox"/> [37] 14.25 <input type="checkbox"/> [41] 15.85 <input type="checkbox"/> [48] 18.25 <input type="checkbox"/> [49] 19.85 <input type="checkbox"/> [53] 23.05 <input type="checkbox"/> [55] 23.8 (default)	Dynamic	<input type="checkbox"/> [0] <b>Disable</b> <input type="checkbox"/> [1] <b>Enable</b>

Coder Name	Packetization Time (msec) [1] 10, [2] 20, [3] 30, [4] 40, [5] 50, [6] 60, [8] 80, [9] 90, [10] 100, [12] 120	Rate (kbps)	Payload Type	Silence Suppression
<b>G.711A-law</b> g711-alaw [1]	10, 20 (default), 30, 40, 50, 60, 80, 100, 120	[90] 64	8	<input type="checkbox"/> [0] Disable (default) <input type="checkbox"/> [1] Enable
<b>G.711A-law_VBD</b> g711a-law-vbd [23]	10, 20 (default), 30, 40, 50, 60, 80, 100, 120	[90] 64	8 or Dynamic (default 118)	n/a (Disabled)
<b>G.711U-law</b> g711-ulaw [2]	10, 20 (default), 30, 40, 50, 60, 80, 100, 120	[90] 64	0	<input type="checkbox"/> [0] Disable (default) <input type="checkbox"/> [1] Enable
<b>G.711U-law_VBD</b> g711u-law-vbd [24]	10, 20 (default), 30, 40, 50, 60, 80, 100, 120	[90] 64	0 or Dynamic (default 110)	n/a (Disabled)
<b>G.723.1</b> g723-1 [0]	30 (default), 60, 90, 120, 150	<input type="checkbox"/> [7] 5.3 (default) <input type="checkbox"/> [11] 6.3	4	<input type="checkbox"/> [0] Disable (default) <input type="checkbox"/> [1] Enable
<b>G.726</b> g726 [5]	10, 20 (default), 30, 40, 50, 60, 80	<input type="checkbox"/> [43] 16 <input type="checkbox"/> [57] 24 <input type="checkbox"/> [64] 32 (default) <input type="checkbox"/> [70] 40	Dynamic (default 2)	<input type="checkbox"/> [0] Disable (default) <input type="checkbox"/> [1] Enable



Coder Name	Packetization Time (msec) [1] 10, [2] 20, [3] 30, [4] 40, [5] 50, [6] 60, [8] 80, [9] 90, [10] 100, [12] 120	Rate (kbps)	Payload Type	Silence Suppression
<b>G.729</b> g729 [3]	10, 20 (default), 30, 40, 50, 60, 80, 100	[19] 8	18	<input type="checkbox"/> [0] Disable (default) <input type="checkbox"/> [1] Enable <input type="checkbox"/> [2] Enable No-Adaptation
<b>G.722</b> g722 [20]	10 (default), 20, 30, 40, 50, 60, 80, 100, 120	<input type="checkbox"/> [90] 64 (default) <input type="checkbox"/> [74] 48 <input type="checkbox"/> [80] 56	<input type="checkbox"/> 9 (only for rate 64 kbps) <input type="checkbox"/> 66 (default and only for rate 48 kbps) - payload can be changed <input type="checkbox"/> 67 (default and only for rate 56 kbps) - payload can be changed	n/a (Disabled)
<b>Opus</b> opus [40]	20 (default), 40, 60, 80, 120	n/a	Dynamic (default 111)	n/a
<b>SILK-NB</b> silk-nb [35]	20 (default), 40, 60, 80, and 100	[19] 8	Dynamic (default 76)	n/a
<b>SILK-WB</b> silk-wb	20 (default), 40, 60, 80, and 100	[43] 16	Dynamic (default 77)	n/a

Coder Name	Packetization Time (msec) [1] 10, [2] 20, [3] 30, [4] 40, [5] 50, [6] 60, [8] 80, [9] 90, [10] 100, [12] 120	Rate (kbps)	Payload Type	Silence Suppression
[36]				
<b>T.38</b> t-38 [4]	n/a	n/a	n/a	n/a (Disabled)
<b>T.38 Over RTP</b> t-38-over-rtp [43]	n/a	n/a	Dynamic (default 106)	n/a
<b>iLBC</b> ilbc [19]	20 (default), 40, 60, 80, 100, 120	[39] 15 (default)	Dynamic (default 65)	<div><input type="checkbox"/> [0] Disable</div> <div><input type="checkbox"/> [1] Enable</div>
	30 (default), 60, 90, 120	[34] 13		

## Configuring Various Codec Attributes

The following procedure describes how to configure various coder attributes such as bit rate.

### ➤ To configure codec attributes:

1. Open the Coder Settings page (**Setup** menu > **Signaling & Media** tab > **Coders & Profiles** folder > **Coder Settings**).
2. Configure the following parameters:
  - AMR coder:
    - ◆ 'AMR Payload Format' (AmrOctetAlignedEnable): Defines the AMR payload format type:

AMR CODER

AMR Payload Format

Octet Aligned

- SILK coder (Skype's default audio codec):

- ◆ 'SILK Tx Inband FEC': Enables forward error correction (FEC) for the SILK coder.
- ◆ 'SILK Max Average Bit Rate': Defines the maximum average bit rate for the SILK coder.

SILK CODER	
SILK Tx Inband FEC	Disable
SILK Max Average Bit Rate	50000

- Opus coder:
  - ◆ 'Opus Max Average Bitrate' (OpusMaxAverageBitRate): Defines the maximum average bit rate (in bps) for the Opus coder.

OPUS CODER	
Opus Max Average Bit Rate [bps]	50000

3. Click **Apply**.

## Configuring Allowed Audio Coder Groups

The Allowed Audio Coders Groups table lets you configure up to 10 Allowed Audio Coders Groups for SBC calls. For each Allowed Audio Coders Group, you can configure up to 10 audio coders. The coders can include pre-defined coders and user-defined (string) coders for non-standard or unknown coders.

Allowed Audio Coders Groups restrict coders for SIP entities. Only coders listed in the Allowed Audio Coders Group (i.e., allowed coders) that is associated with the SIP entity can be used. If the coders in the SDP offer ('a=rtpmap' field) of the incoming SIP message are not listed in the Allowed Audio Coders Group, the device rejects the calls. If the SDP offer contains some coders that are listed in the Allowed Audio Coders Group, the device manipulates the SDP offer by removing the coders that are not listed in the Allowed Audio Coders Group, before routing the SIP message to its destination. Thus, only coders that are common between the coders in the SDP offer and the coders in the Allowed Audio Coders Group are used. For more information on coder restriction, see [Restricting Audio Coders](#) on page 1036.

For example, assume the following:

- The SDP offer in the incoming SIP message contains the G.729, G.711, and G.723 coders.
- The allowed coders configured for the SIP entity include G.711 and G.729.

The device removes the G.723 coder from the SDP offer, re-orders the coder list so that G.711 is listed first, and sends the SIP message containing only the G.711 and G.729 coders in the SDP.

To apply an Allowed Audio Coders Group for restricting coders to a SIP entity:

1. Configure an Allowed Audio Coders Group in the Allowed Audio Coders Groups table (see description below).
2. In the IP Profile associated with the SIP entity (see [Configuring IP Profiles](#) on page 664):
  - Assign the Allowed Audio Coders Group, using the 'Allowed Audio Coders' parameter.
  - Enable the use of Allowed Audio Coders Groups, by configuring the 'Allowed Coders Mode' parameter to **Restriction** or **Restriction and Preference**.

The device also re-orders (prioritizes) the coder list in the SDP according to the order of appearance of the coders listed in the Allowed Audio Coders Group. The first listed coder has the highest priority and the last coder has the lowest priority. For more information, see [Prioritizing Coder List in SDP Offer](#) on page 1037.



- The Allowed Audio Coders Groups table is applicable only to the SBC application.
- The Allowed Audio Coders Group for coder restriction takes precedence over the Coder Group for extension coders. In other words, if an extension coder is not listed as an allowed coder, the device doesn't add the extension coder to the SDP offer.

The following procedure describes how to configure Allowed Audio Coders Groups through the Web interface. You can also configure it through ini file [AllowedAudioCodersGroups] and [AllowedAudioCoders] or CLI (`configure voip > coders-and-profiles allowed-audio-coders-groups; configure voip > coders-and-profiles allowed-audio-coders < group index/coder index>`).

➤ **To configure an Allowed Audio Coders Group:**

1. Open the Allowed Audio Coders Groups table (**Setup** menu > **Signaling & Media** tab > **Coders & Profiles** folder > **Allowed Audio Coders Groups**).
2. Click **New**; the following dialog box appears:

3. Configure a name for the Allowed Audio Coders Group according to the parameters described in the table below.
4. Click **Apply**.

5. Select the new row that you configured, and then click the **Allowed Audio Coders** link located below the table; the Allowed Audio Coders table opens.
6. Click **New**; the following dialog box appears:

The screenshot shows a dialog box titled "Allowed Audio Coders". It has a dark blue header bar with a close button (X) and a maximize button. Below the header, there is a tab labeled "GENERAL". Under the tab, there are three input fields: "Index" with the value "0", "Coder" with a dropdown arrow, and "User-defined Coder" which is empty.

7. Configure coders for the Allowed Audio Coders Group according to the parameters described in the table below.
8. Click **Apply**.

**Table 19-4: Allowed Audio Coders Groups and Allowed Audio Coders Tables Parameter Descriptions**

Parameter	Description
<b>Allowed Audio Coders Groups Table</b>	
'Index' allowed-audio-coders-groups <index> [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' coders-group-name [Name]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 40 characters. <b>Note:</b> <ul style="list-style-type: none"> <li>■ Configure each row with a unique name.</li> <li>■ The parameter value cannot contain a forward slash (/).</li> </ul>
<b>Allowed Audio Coders Table</b>	
'Index' allowed-audio-coders <group index > coder index> [AllowedAudioCodersIndex]	Defines an index number for the new table row. For a list of supported coders, see <b>Note:</b> Each row must be configured with a unique index.

Parameter	Description
'Coder' coder [CoderID]	Defines a coder from the list of coders. <b>Note:</b> Each coder can be configured only once per Allowed Audio Coders Group.
'User-defined Coder' user-define-coder [UserDefineCoder]	Defines a user-defined coder. The valid value is a string of up to 24 characters (case-insensitive). For example, "HD.123" (without quotation marks). <b>Note:</b> Each coder can be configured only once per Allowed Audio Coders Group.

## Configuring Allowed Video Coder Groups

The Allowed Video Coders Groups table lets you configure up to five Allowed Video Coders Groups for SBC calls. Each Allowed Video Coders Group can be configured with up to 10 user-defined (string) video coders. An Allowed Video Coders Group defines a list of video coders that can be used when forwarding video streams to a specific SIP entity.

Allowed Video Coders Groups are assigned to SIP entities, using IP Profiles (see [Configuring IP Profiles](#) on page 664). The video coders appear in the SDP media type "video" ('m=video' line). Coders that are not listed in the Allowed Video Coders Group are removed from the SDP offer that is sent to the SIP entity. Only coders that are common between the coders in the SDP offer and the coders listed in the Allowed Video Coders Group are used. Thus, Allowed Video Coders Groups enable you to enforce the use of only specified coders. For more information, see [Restricting Audio Coders](#) on page 1036.

The order of appearance of the coders listed in the Allowed Video Coders Group determines the priority (preference) of the coders in the SDP offer. The device arranges the SDP offer's coder list according to their order in the Allowed Video Coders Group. The priority is in descending order, whereby the first coder in the list is given the highest priority and the last coder, the lowest priority. For more information, see [Prioritizing Coder List in SDP Offer](#) on page 1037.



The Allowed Audio Coders Groups table is applicable only to the SBC application.

The following procedure describes how to configure Allowed Video Coders Groups through the Web interface. You can also configure it through ini file [AllowedVideoCodersGroups] and [AllowedVideoCoders] or CLI (`configure voip > coders-and-profiles allowed-video-coders-groups; configure voip > coders-and-profiles allowed-video-coders < group index/coder index>`).

➤ **To configure an Allowed Video Coders Group:**

1. Open the Allowed Video Coders Groups table (**Setup** menu > **Signaling & Media** tab > **Coders & Profiles** folder > **Allowed Video Coders Groups**).
2. Click **New**; the following dialog box appears:

3. Configure a name for the Allowed Video Coders Group according to the parameters described in the table below.
4. Click **Apply**.
5. Select the new row that you configured, and then click the **Allowed Video Coders** link located below the table; the Allowed Video Coders table opens.
6. Click **New**; the following dialog box appears:

7. Configure coders for the Allowed Video Coders Group according to the parameters described in the table below.
8. Click **Apply**.

**Table 19-5: Allowed Video Coders Groups and Allowed Video Coders Tables Parameter Descriptions**

Parameter	Description
<b>Allowed Video Coders Groups Table</b>	
'Index' allowed-video-coders-groups <index>	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.

Parameter	Description
[Index]	
'Name' coders-group-name [Name]	<p>Defines a descriptive name, which is used when associating the row in other tables.</p> <p>The valid value is a string of up to 40 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Configure each row with a unique name.</li> <li>■ The parameter value cannot contain a forward slash (/).</li> </ul>
<b>Allowed Video Coders Table</b>	
'Index' allowed-video-coders <group index > coder index> [AllowedVideoCodersIndex]	<p>Defines an index number for the new table row.</p> <p><b>Note:</b> Each row must be configured with a unique index.</p>
'User Define Coder' user-define-coder [UserDefineCoder]	<p>Defines a user-defined coder.</p> <p>The valid value is a string of up to 24 characters (case-insensitive). For example, "HD.123" (without quotation marks).</p> <p><b>Note:</b> Each coder can be configured only once per Allowed Video Coders Group.</p>

## Configuring IP Profiles

The IP Profiles table lets you configure up to 20 IP Profiles. An IP Profile is a set of parameters with user-defined settings relating to signaling (e.g., SIP message terminations such as REFER) and media (e.g., coder type). An IP Profile can later be assigned to specific IP calls (inbound and/or outbound). Thus, IP Profiles provide high-level adaptation when the device interworks between different SIP user agents (UA), each of which may require different handling by the device. For example, if a specific SIP UA uses the G.711 coder only, you can configure an IP Profile with G.711 for this UA.

Many parameters in the IP Profiles table have a corresponding "global" parameter, whose settings apply to all calls that are not associated with an IP Profile. The default value of these IP Profile parameters is the same as the default value of their corresponding global parameters. However, if you change a global parameter from its default value, the value of its corresponding IP Profile parameter inherits its value for all subsequently created (new) IP Profiles. For example, the IP Profile parameter for configuring maximum call duration is 'Max Call Duration'. Its corresponding global parameter is [SBCMaxCallDuration]. The default of the global



parameter is "0" and therefore, the default of this IP Profile parameter is also "0". However, if you configure the global parameter to "10", the value of this IP Profile parameter for all subsequently created (new) IP Profiles is also "10".

To use your IP Profile for specific calls, you need to assign it to any of the following:

- IP Groups - see [Configuring IP Groups](#) on page 581
- (Gateway application only) Tel-to-IP routing rules (see [Configuring Tel-to-IP Routing Rules](#) on page 914)
- (Gateway application only) IP-to-Tel routing rules (see [Configuring IP-to-Tel Routing Rules](#) on page 928)

For the Gateway application, the device selects the IP Profile as follows:

- If you assign different IP Profiles (not default) to the same specific calls in all of the above-mentioned tables, the device uses the IP Profile that has the highest preference level (as set in the 'Profile Preference' parameter). If these IP Profiles have the same preference level, the device uses the IP Profile that you assigned in the IP Groups table.
- If you assign different IP Profiles to all of the above-mentioned tables and one table is set to the default IP Profile, the device uses the IP Profile that is not the default.



You can also use IP Profiles when using a Proxy server (when the AlwaysUseRouteTable parameter is set to 1).

The following procedure describes how to configure IP Profiles through the Web interface. You can also configure it through ini file [IPProfile] or CLI (`configure voip > coders-and-profiles ip-profile`).

#### ➤ To configure an IP Profile:

1. Open the IP Profiles table (**Setup** menu > **Signaling & Media** tab > **Coders & Profiles** folder > **IP Profiles**).
2. Click **New**; the following dialog box appears:

3. Configure an IP Profile according to the parameters described in the table below.
4. Click **Apply**.

Table 19-6: IP Profiles Table Parameter Descriptions

Parameter	Description
<b>General</b>	
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' profile-name [ProfileName]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 40 characters. <b>Note:</b> <ul style="list-style-type: none"> <li>■ Configure each row with a unique name.</li> <li>■ The parameter value can't contain a forward slash (/).</li> <li>■ The parameter value can't be configured with the character string "any" (upper or lower case).</li> </ul>
'Created By Routing Server' created-by-routing-server [CreatedByRoutingServer]	(Read-only) Indicates whether the IP Profile was created by ARM: <ul style="list-style-type: none"> <li>■ [0] <b>No</b></li> <li>■ [1] <b>Yes</b></li> </ul> For more information on routing by ARM, see <a href="#">Centralized Routing by ARM (AudioCodes Routing Manager)</a> on page 442.
'Used By Routing Server' used-by-routing-server [UsedByRoutingServer]	Enables the IP Profile to be used by ARM for call routing decisions. <ul style="list-style-type: none"> <li>■ [0] <b>Not Used</b> (default)</li> <li>■ [1] <b>Used</b></li> </ul> For more information on routing by ARM, see <a href="#">Centralized Routing by ARM (AudioCodes Routing Manager)</a> on page 442.
<b>Media Security</b>	
'SBC Media Security Mode' sbc-media-security-behaviour [SBCMediaSecurityBehaviour]	Defines the handling of RTP/SRTP, and MSRP/MSRPS for the SIP UA associated with the IP Profile. <ul style="list-style-type: none"> <li>■ [0] <b>As is</b> = (Default) No special handling for RTP/SRTP and MSRP/MSRPS is done.</li> <li>■ [1] <b>Secured</b> = SBC legs negotiate only SRTP/MSRPS</li> </ul>

Parameter	Description
	<p>media lines, and RTP/MSRP media lines are removed from the incoming SDP offer-answer.</p> <ul style="list-style-type: none"> <li>■ [2] <b>Not Secured</b> = SBC legs negotiate only RTP/MSRP media lines, and SRTP/MSRPS media lines are removed from the incoming offer-answer.</li> <li>■ [3] <b>Both</b> = Each offer-answer is extended (if not already) to two media lines - one RTP/MSRP and the other SRTP/MSRPS.</li> <li>■ [4] <b>Offer Both - Answer Prefer Secured</b> = The device prefers secured media on the outgoing SDP answer. If the incoming SDP offer contains secured media, the device sends the outgoing SDP answer with secured media, regardless of the incoming SDP answer (media secured or not). The device's handling for secured media on the SDP offer side is the same as the <b>Both</b> option.</li> </ul> <p>If two SBC legs (after offer-answer negotiation) use different security types (i.e., one RTP/MSRP and the other SRTP/MSRPS), the device performs RTP-SRTP/MSRP-MSRPS transcoding. For such transcoding, the following prerequisites must be met:</p> <ul style="list-style-type: none"> <li>■ At least one supported SDP "crypto" attribute and parameters.</li> <li>■ The [EnableMediaSecurity] parameter must be configured to [1].</li> </ul> <p>If one of the above prerequisites is not met, then:</p> <ul style="list-style-type: none"> <li>■ any value other than <b>As is</b> is discarded.</li> <li>■ if the incoming offer is SRTP/MSRPS, forced transcoding, coder transcoding, and DTMF extensions are not applied.</li> </ul> <p><b>Note:</b> For secured MSRP (MSRPS), configure the parameter to <b>Secured</b> or <b>Both</b>. For more information on MSRP, see <a href="#">Configuring Message Session Relay Protocol</a> on page 1141.</p>
'Gateway Media Security Mode' media-security-	<p>Defines the handling of SRTP for the SIP UA associated with the IP Profile.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> = Applies the settings of the</li> </ul>

Parameter	Description
behaviour [MediaSecurityBehaviour]	<p>corresponding global parameter [MediaSecurityBehaviour].</p> <ul style="list-style-type: none"> <li>■ [0] <b>Preferable</b> = (Default) The device initiates encrypted calls to this SIP UA. However, if negotiation of the cipher suite fails, an unencrypted call is established. The device accepts incoming calls received from the SIP UA that don't include encryption information.</li> <li>■ [1] <b>Mandatory</b> = The device initiates encrypted calls to this SIP UA, but if negotiation of the cipher suite fails, the call is terminated. The device rejects incoming calls received from the SIP UA that don't include encryption information.</li> <li>■ [2] <b>Disable</b> = This SIP UA doesn't support encrypted calls (i.e., SRTP).</li> <li>■ [3] <b>Preferable - Single Media</b> = The device sends SDP with a single media ('m=') line only (e.g., m=audio 6000 RTP/AVP 4 0 70 96) with RTP/AVP and crypto keys. The SIP UA can respond with SRTP or RTP parameters: <ul style="list-style-type: none"> <li>✓ If the SIP UA doesn't support SRTP, it uses RTP and ignores the crypto lines.</li> <li>✓ If the device receives an SDP offer with a single media (as shown above) from the SIP UA, it responds with SRTP (RTP/SAVP) if you configure the [EnableMediaSecurity] parameter to [1]. If SRTP is not supported (i.e., [EnableMediaSecurity] is configured to [0]), it responds with RTP.</li> <li>✓ If two 'm=' lines are received in the SDP offer, the device prefers the SAVP (secure audio video profile), regardless of the order in the SDP.</li> </ul> </li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Gateway application.</li> <li>■ The parameter is applicable only if you configure the [EnableMediaSecurity] parameter to [1].</li> <li>■ The corresponding global parameter is [MediaSecurityBehaviour].</li> </ul>

Parameter	Description
'Symmetric MKI' enable-symmetric-mki  [EnableSymmetricMKI]	<p>Enables symmetric MKI negotiation.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) The device includes the MKI in its SIP 200 OK response according to the [SRTPTxPacketMKISize] parameter (if set to 0, it is not included; if set to any other value, it is included with this value).</li> <li>■ [1] <b>Enable</b> = The answer crypto line contains (or excludes) an MKI value according to the selected crypto line in the offer. For example, assume that the device receives an INVITE containing the following two crypto lines in SDP:               <pre>a=crypto:2 AES_CM_128_HMAC_SHA1_80 inline:TAaxNnQt8/qLQMnDuG4vxYfWl6K7eBK/ufk04pR4 2^31 1:1 a=crypto:3 AES_CM_128_HMAC_SHA1_80 inline:bnuYZnMxSfUiGitviWJZmzr7OF3AiRO0l5Vnh0kH 2^31</pre> <p>The first crypto line includes the MKI parameter "1:1". In the 200 OK response, the device selects one of the crypto lines (i.e., '2' or '3'). Typically, it selects the first line that supports the crypto suite. However, for SRTP-to-SRTP in SBC sessions, it can be determined by the remote side on the outgoing leg. If the device selects crypto line '2', it includes the MKI parameter in its answer SDP, for example:</p> <pre>a=crypto:2 AES_CM_128_HMAC_SHA1_80 inline:R1VyA1xV/qwBjkEkl4kSJyl3wCtYeZLq1/QFuxw 2^31 1:1</pre> <p>If the device selects a crypto line that doesn't contain the MKI parameter, then the MKI parameter is not included in the crypto line in the SDP answer (even if the [SRTPTxPacketMKISize] parameter is set to any value other than 0).</p> <p><b>Note:</b> The corresponding global parameter is [EnableSymmetricMKI].</p> </li> </ul>
'MKI Size' mki-size  [MKISize]	<p>Defines the size (in bytes) of the Master Key Identifier (MKI) in SRTP Tx packets.</p> <p>The valid value is 0 to 4. The default is 0 (i.e., new keys are generated without MKI).</p> <p><b>Note:</b></p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ Gateway application: The device only initiates the MKI size.</li> <li>■ SBC application: The device can forward MKI size as is for SRTP-to-SRTP flows or override the MKI size during negotiation. This can be done on the inbound or outbound leg.</li> <li>■ The corresponding global parameter is <code>SRTPTxPacketMKISize</code>.</li> </ul>
'SBC Enforce MKI Size' <code>sbc-enforce-mki-size</code>  <code>[SBCEnforceMKISize]</code>	<p>Enables negotiation of the Master Key Identifier (MKI) length for SRTP-to-SRTP flows between SIP networks (i.e., IP Groups). This includes the capability of modifying the MKI length on the inbound or outbound SBC call leg for the SIP UA associated with the IP Profile.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Don't enforce</b> = (Default) Device forwards the MKI size as is.</li> <li>■ [1] <b>Enforce</b> = Device changes the MKI length according to the settings of the IP Profile parameter, <code>MKISize</code>.</li> </ul>
'SBC Media Security Method' <code>sbc-media-security-method</code>  <code>[SBCMediaSecurityMethod]</code>	<p>Defines the media security protocol for SRTP, for the SIP UA associated with the IP Profile.</p> <ul style="list-style-type: none"> <li>■ [0] <b>SDES</b> = (Default) The device secures RTP using the Session Description Protocol Security Descriptions (SDES) protocol to negotiate the cryptographic keys (RFC 4568). The keys are sent in the SDP body ('a=crypto') of the SIP message and are typically secured using SIP over TLS (SIPS). The encryption of the keys is in plain text in the SDP. SDES implements TLS over TCP.</li> <li>■ [1] <b>DTLS</b> = The device uses Datagram Transport Layer Security (DTLS) protocol to secure UDP-based media streams (RFCs 5763 and 5764). For more information on DTLS, see <a href="#">Configuring IP Profiles</a>.</li> <li>■ [2] <b>Both</b> = SDES and DTLS protocols are supported.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ To support DTLS, you must also configure the following for the SIP UA:               <ul style="list-style-type: none"> <li>✓ TLS Context for DTLS (see <a href="#">Configuring TLS</a>)</li> </ul> </li> </ul>

Parameter	Description
	<p><a href="#">Certificate Contexts</a> on page 224). The server cipher ('Cipher Server') must be configured to All.</p> <ul style="list-style-type: none"> <li>✓ 'SBC Media Security Mode' parameter to <b>Secured</b> or <b>Both</b>.</li> <li>✓ 'RTCP Mux' parameter to <b>Supported</b>. The setting is required as the DTLS handshake is done for the port used for RTP. Therefore, RTCP and RTP should be multiplexed over the same port.</li> <li>■ The device doesn't support forwarding of DTLS transparently between SIP UAs.</li> <li>■ As DTLS has been defined by the WebRTC standard as mandatory for encrypting media channels for SRTP key exchange, the support is important for deployments implementing WebRTC. For more information on WebRTC, see Configuring IP Profiles.</li> </ul>
<p>'Reset SRTP Upon Re-key'</p> <pre>configure voip &gt; media security &gt; reset-srtp-upon- re-key</pre> <p>[ResetSRTPStateUponRekey]</p>	<p>Enables synchronization of the SRTP state between the device and a server when a new SRTP key is generated upon a SIP session expire. This feature ensures that the roll-over counter (ROC), one of the parameters used in the SRTP encryption/decryption process of the SRTP packets is synchronized on both sides for transmit and receive packets.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) ROC is not reset on the device side.</li> <li>■ [1] <b>Enable</b> = If the session expires causing a session refresh through a re-INVITE, the device or server generates a new key and the device resets the ROC index (and other SRTP fields) as done by the server, resulting in a synchronized SRTP.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If this feature is disabled and the server resets the ROC upon a re-key generation, one-way voice may occur.</li> <li>■ The corresponding global parameter is [ResetSRTPStateUponRekey].</li> <li>■ The parameter resets the SRTP stream on both legs. If you want the device to reset the SRTP stream only</li> </ul>

Parameter	Description
	with the leg (call party) that changed the crypto key, enable this parameter and the global parameter <a href="#">[configure voip &gt; media security &gt; srtp-reset-tx-rx-separately</a> on page 1668].
'Generate SRTP Keys Mode' generate-srtp-keys [GenerateSRTPKeys]	<p>Enables the device to generate (or not) a new SRTP key upon receipt of a re-INVITE from the SIP UA associated with the IP Profile. The key appears in the SDP's 'a=crypto' line.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Only If Required</b> = (Default) The device generates an SRTP key only if necessary.</li> <li>■ [1] <b>Always</b> = The device always generates a new SRTP key.</li> <li>■ [2] <b>Keep Original</b> = The device doesn't generate a new key, but preserves (uses) the original SRTP key from the SIP dialog-initiating INVITE message for the dialog's transactions.</li> </ul>
'SBC Remove Crypto Lifetime in SDP' sbc-sdp-remove-crypto-lifetime [SBCRemoveCryptoLifetimeInSDP]	<p>Defines the handling of the lifetime field in the 'a=crypto' attribute of the SDP for the SIP UA associated with the IP Profile. The SDP field defines the lifetime of the master key as measured in maximum number of SRTP or SRTCP packets using the master key.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) The device retains the lifetime field (if present) in the SDP.</li> <li>■ [1] <b>Yes</b> = The device removes the lifetime field from the 'a=crypto' attribute.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you configure the parameter to <b>Yes</b>, the following IP Profile parameters must be configured as follows: <ul style="list-style-type: none"> <li>✓ 'Symmetric MKI' to <b>Enable</b>.</li> <li>✓ 'MKI Size' to 0.</li> <li>✓ 'SBC Enforce MKI Size' to <b>Enforce</b>.</li> </ul> </li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
'SBC Remove Unknown Crypto'	Defines whether the device keeps or removes unknown cryptographic suites (encryption and authentication



Parameter	Description
<code>sbc-remove-unknown-crypto</code> [SBCTRemoveUnKnownCrypto]	<p>algorithms) that are present in the SDP 'a=crypto' attribute in the incoming SIP message, before forwarding the message to the SIP UA associated with this IP Profile.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) The device keeps all unknown cryptographic suites that are in the SDP's 'a=crypto' attribute.</li> <li>■ [1] <b>Yes</b> = The device removes all unknown cryptographic suites that are in the SDP's 'a=crypto' attribute.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The feature is applicable only to SRTP-to-SRTP calls and calls that do not require transcoding.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
'Crypto Suites Group' <code>crypto-suites-group</code> [SBCCryptoGroupName]	<p>Assigns an SBC Crypto Suite Group to the IP Profile, which defines the supported SRTP crypto suites.</p> <p>By default, the parameter is undefined and the crypto suite used by the IP Profile is according to the global parameter [SRTPofferedSuites].</p> <p>For configuring SBC Crypto Suite Groups, see <a href="#">Configuring SRTP Crypto Suite Groups</a> on page 315.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
'Encryption on RTCP Packets' <code>rtcp-encryption</code> [RTCPEncryption]	<p>Defines the encryption of RTCP packets (i.e., SRTCP).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Active</b> = <ul style="list-style-type: none"> <li>✓ Incoming leg (SRTP-SRTP / SRTP-RTP calls): SRTP cryptos in the incoming SDP offer with the UNENCRYPTED_SRTCP flag are rejected.</li> <li>✓ Outgoing leg (SRTP-SRTP / RTP-SRTP calls): The device removes the UNENCRYPTED_SRTCP from all cryptos in the outgoing SDP offer.</li> </ul> </li> <li>■ [1] <b>InActive</b> = <ul style="list-style-type: none"> <li>✓ Incoming leg (SRTP-SRTP / SRTP-RTP calls): SRTP cryptos in the incoming SDP offer without the UNENCRYPTED_SRTCP flag are rejected.</li> <li>✓ Outgoing leg (SRTP-SRTP / RTP-SRTP calls): The</li> </ul> </li> </ul>

Parameter	Description
	<p>device adds the UNENCRYPTED_SRTCP to all cryptos in the outgoing SDP offer.</p> <ul style="list-style-type: none"> <li>■ [2] <b>As Is</b> = (Default)</li> <li>✓ Incoming leg (SRTP-SRTP / SRTP-RTP calls): The device does nothing.</li> <li>✓ Outgoing leg: Cryptos that are received in the incoming leg are not modified. For new cryptos generated by device the encryption flag is set according to the global parameter [RTCPEncryptionDisableTx].</li> </ul> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<b>SBC Early Media</b>	
<p>'Remote Early Media'</p> <p>sbc-rmt-early-media-supp</p> <p>[SBCRemoteEarlyMediaSupport]</p>	<p>Defines whether the remote side can accept early media or not.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Not Supported</b> = Early media is not supported.</li> <li>■ [1] <b>Supported</b> = (Default) Early media is supported.</li> </ul>
<p>'Remote Multiple 18x'</p> <p>sbc-rmt-multiple-18x-supp</p> <p>[SBCRemoteMultiple18xSupport]</p>	<p>Defines whether multiple 18x responses including 180 Ringing, 181 Call is Being Forwarded, 182 Call Queued, and 183 Session Progress are forwarded to the caller, for the SIP UA associated with the IP Profile.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Not Supported</b> = Only the first 18x response is forwarded to the caller.</li> <li>■ [1] <b>Supported</b> = (Default) Multiple 18x responses are forwarded to the caller.</li> </ul>
<p>'Remote Early Media Response Type'</p> <p>sbc-rmt-early-media-resp</p> <p>[SBCRemoteEarlyMediaResponseType]</p>	<p>Defines the SIP provisional response type - 180 or 183 - for forwarding early media to the caller, for the SIP UA associated with the IP Profile.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Transparent</b> = (Default) All early media response types are supported; the device forwards all responses as is (unchanged).</li> <li>■ [1] <b>180</b> = Early media is sent as 180 response only.</li> <li>■ [2] <b>183</b> = Early media is sent as 183 response only.</li> </ul>

Parameter	Description
<p>'Remote Multiple Early Dialogs'</p> <p>sbc-multi-early-dialogs</p> <p>[SBCRemoteMultipleEarlyDialogs]</p>	<p>Defines the device's handling of To-header tags in call forking responses (i.e., multiple SDP answers) sent to the SIP UA associated with the IP Profile.</p> <p>When the SIP UA initiates an INVITE that is subsequently forked (for example, by a proxy server) to multiple UAs, the endpoints respond with a SIP 183 containing an SDP answer. Typically, each endpoint's response has a different To-header tag. For example, a call initiated by the SIP UA (100@A) is forked and two endpoints respond with ringing, each with a different tag:</p> <p>■ Endpoint "tag 2":</p> <pre>SIP/2.0 180 Ringing From: &lt;sip:100@A&gt;;tag=tag1 To: sip:200@B;tag=tag2 Call-ID: c2</pre> <p>■ Endpoint "tag 3":</p> <pre>SIP/2.0 180 Ringing From: &lt;sip:100@A&gt;;tag=tag1 To: sip:200@B;tag=tag3 Call-ID: c2</pre> <p>In non-standard behavior (when the parameter is configured to Disable), the device forwards all the SDP answers with the same tag. In the example, endpoint "tag 3" is sent with the same tag as endpoint "tag 2" (i.e., To: sip:200@B;tag=tag2).</p> <p>■ [-1] <b>According to Operation Mode</b> = (Default) Depends on the setting of the 'Operation Mode' parameter in the IP Group or SRDs table:</p> <ul style="list-style-type: none"> <li>✓ B2BUA: Device operates as if the parameter is set to Disable [0].</li> <li>✓ Call State-full Proxy: Device operates as if the parameter is set to Enable [1]. In addition, the device preserves the From tags and Call-IDs of the endpoints in the SDP answer sent to the SIP UA.</li> </ul> <p>■ [0] <b>Disable</b> = Device sends the multiple SDP answers with the same To-header tag, to the SIP UA. In other words, this option is relevant if the SIP UA doesn't support multiple dialogs (and multiple tags). However, non-standard, multiple answer support may</p>

Parameter	Description
	<p>still be configured by the <code>SBCRemoteMultipleAnswersMode</code> parameter.</p> <ul style="list-style-type: none"> <li>■ [1] <b>Enable</b> = Device sends the multiple SDP answers with different To-header tags, to the SIP UA. In other words, the SIP UA supports standard multiple SDP answers (with different To-header tags). In this case, the <code>SBCRemoteMultipleAnswersMode</code> parameter is ignored.</li> </ul> <p><b>Note:</b> If the parameter and the <code>SBCRemoteMultipleAnswersMode</code> parameter are disabled, multiple SDP answers are not reflected to the SIP UA (i.e., the device sends the same SDP answer in multiple 18x and 200 responses).</p>
<p>'Remote Multiple Answers Mode'</p> <p><code>sbc-multi-answers</code></p> <p>[<code>SBCRemoteMultipleAnswersMode</code>]</p>	<p>Enables interworking multiple SDP answers within the same SIP dialog (non-standard). The parameter enables the device to forward multiple answers to the SIP UA associated with the IP Profile. The parameter is applicable only when the 'Remote Multiple Early Dialogs' parameter is disabled.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) Device always sends the same SDP answer, which is based on the first received answer that it sent to the SIP UA, for all forked responses (even if the 'Forking Handling Mode' parameter is <b>Sequential</b>), and thus, may result in transcoding.</li> <li>■ [1] <b>Enable</b> = If the 'Forking Handling Mode' parameter is configured to <b>Sequential</b>, the device sends multiple SDP answers.</li> </ul>
<p>'Remote Early Media RTP Detection Mode'</p> <p><code>sbc-rmt-early-media-rtp</code></p> <p>[<code>SBCRemoteEarlyMediaRTP</code>]</p>	<p>Defines whether the destination UA sends RTP immediately after it sends a 18x response.</p> <ul style="list-style-type: none"> <li>■ [0] <b>By Signaling</b> = (Default) Remote client sends RTP immediately after it sends 18x response with early media. The device forwards 18x and RTP as is.</li> <li>■ [1] <b>By Media</b> = After sending 18x response, the remote client waits before sending RTP (e.g., Microsoft Skype for Business environment). For the device's handling of this remote UA support, see <a href="#">Interworking SIP Early Media</a> on page 1046.</li> </ul>

Parameter	Description
'Remote RFC 3960 Support' sbc-rmt-rfc3960-supp  [SBCRemoteSupportsRFC3960]	Defines whether the destination UA is capable of receiving 18x messages with delayed RTP. <ul style="list-style-type: none"> <li>■ [0] <b>Not Supported</b> = (Default) UA doesn't support receipt of 18x messages with delayed RTP. For the device's handling of this remote UA support, see <a href="#">Interworking SIP Early Media</a> on page 1046.</li> <li>■ [1] <b>Supported</b> = UA is capable of receiving 18x messages with delayed RTP.</li> </ul>
'Remote Can Play Ringback' sbc-rmt-can-play-ringback [SBCRemoteCanPlayRingback]	Defines whether the destination UA can play a local ringback tone. <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = UA doesn't support local ringback tone. The device sends 18x with delayed SDP to the UA.</li> <li>■ [1] <b>Yes</b> = (Default) UA supports local ringback tone. For the device's handling of this remote UA support, see <a href="#">Interworking SIP Early Media</a> on page 1046.</li> </ul>
'Generate RTP' sbc-generate-rtsp [SBCGenerateRTP]	Enables the device to generate "silence" RTP packets to the SIP UA until it detects audio RTP packets from the SIP UA. The parameter provides support for interworking with SIP entities that wait for the first incoming packets before sending RTP (e.g., early media used for ringback tone or IVR) during media negotiation. <ul style="list-style-type: none"> <li>■ [0] <b>None</b> = (Default) Silence packets are not generated.</li> <li>■ [1] <b>Until RTP Detected</b> = The device generates silence RTP packets to the SIP UA upon receipt of a SIP response (183 with SDP) from the SIP UA. In other words, these packets serve as the first incoming packets for the SIP UA. The device stops sending silence packets when it receives RTP packets from the peer side (which it then forwards to the SIP UA).</li> </ul> <p><b>Note:</b> To generate silence packets, DSP resources are required (except for calls using the G.711 coder).</p>
<b>SBC Media</b>	
'SDP Subsequent Responses Mode' sdp-origin-same-	Defines which incoming SIP responses to SIP dialog-initiating INVITE requests are SDPs processed (handled) by the device.

Parameter	Description
session-ver [SDPSubsequentResponses]	<ul style="list-style-type: none"> <li>■ [0] <b>Handle All</b> = (Default) The device processes the SDPs of all subsequent SIP responses.</li> <li>■ [1] <b>Handle Only First</b> = The device processes only the SDP in the first SIP response to the initial INVITE message, ignoring the SDPs in all the other subsequent SIP responses.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
'Allowed Audio Coders' allowed-audio-coders-group-name [SBCAllowedAudioCodersGroupName]	<p>Assigns an Allowed Audio Coders Group, which defines audio (voice) coders that can be used for the SIP UA associated with the IP Profile.</p> <p>To configure Allowed Audio Coders Groups, see <a href="#">Configuring Allowed Audio Codec Groups</a> on page 659. For a description of the Allowed Coders feature, see <a href="#">Restricting Audio Coders</a> on page 1036.</p>
'Allowed Coders Mode' sbc-allowed-coders-mode [SBCAllowedCodersMode]	<p>Defines the mode of the Allowed Coders feature for the SIP UA associated with the IP Profile.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Restriction</b> = In the incoming SDP offer, the device uses only Allowed coders; the rest are removed from the SDP offer (i.e., only coders common between those in the received SDP offer and the Allowed coders are used).</li> <li>■ [1] <b>Preference</b> = The device re-arranges the priority (order) of the coders in the incoming SDP offer according to their order of appearance in the Allowed Audio Coders Group or Allowed Video Coders Group. The coders in the original SDP offer are listed after the Allowed coders.</li> <li>■ [2] <b>Restriction and Preference</b> = Performs both Restriction and Preference.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if Allowed coders are assigned to the IP Profile (see the 'Allowed Audio Coders' or 'Allowed Video Coders' parameters).</li> <li>■ For more information on the Allowed Coders feature, see <a href="#">Restricting Audio Coders</a> on page 1036.</li> </ul>

Parameter	Description
'Allowed Video Coders' allowed-video-coders-group-name [SBCAllowedVideoCodersGroup pName]	<p>Assigns an Allowed Video Coders Group. This defines permitted video coders when forwarding video streams to the SIP UA associated with the IP Profile. The video coders are listed in the "video" media type in the SDP (i.e., 'm=video' line). For this SIP UA, the device uses only video coders that appear in both the SDP offer and the Allowed Video Coders Group.</p> <p>By default, no Allowed Video Coders Group is assigned (i.e., all video coders are allowed).</p> <p>To configure Allowed Video Coders Groups, see <a href="#">Configuring Allowed Video Coder Groups</a> on page 662.</p>
'Allowed Media Types' sbc-allowed-media-types [SBCAllowedMediaTypes]	<p>Defines media types permitted for the SIP UA associated with the IP Profile. The media type appears in the SDP 'm=' line (e.g., 'm=audio'). The device permits only media types that appear in both the SDP offer and this configured list. If no common media types exist between the SDP offer and this list, the device drops the call.</p> <p>The valid value is a string of up to 64 characters. To configure multiple media types, separate the strings with a comma, e.g., " audio, text" (without quotation marks). By default, no media types are configured (i.e., all media types are permitted).</p>
'Direct Media Tag' sbc-dm-tag [SBCDirectMediaTag]	<p>Defines an identification tag for enabling direct media or media bypass (i.e., no Media Anchoring) of SBC calls for the SIP UA associated with the IP Profile. Direct media occurs between all UAs whose IP Profiles have the same tag value (non-empty value). For example, if you configure the parameter to "direct-rtp" for two IP Profiles "IP-PBX-1" and "IP-PBX-2", the device employs direct media for calls of UAs associated with IP Profile "IP-PBX-1", for calls of UAs associated with IP Profile "IP-PBX-2", and for calls between UAs associated with IP Profile "IP-PBX-1" and IP Profile "IP-PBX-2".</p> <p>The valid value is a string of up to 16 characters. By default, no value is defined.</p> <p>For more information on direct media, see <a href="#">Direct Media Calls</a> on page 1033.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you enable direct media for the IP Profile, make sure that your Media Realm provides enough ports, as</li> </ul>

Parameter	Description
	<p>media may traverse the device for mid-call services (e.g., call transfer).</p> <ul style="list-style-type: none"> <li>■ If you have configured a SIP Recording rule (see <a href="#">SIPREC SIP-based Media Recording</a> on page 330) for calls associated with this IP Profile, the device automatically disables direct media for these calls (during their SIP signaling setup). This ensures that the media passes through the device so that it can be recorded and sent to the SRS. However, if you enable direct media using the [SBCDirectMedia] global parameter (i.e., for all calls), direct media is always enforced and calls will not be recorded.</li> <li>■ Regardless of this parameter's settings, the device always handles calls whose incoming SIP dialog-initiating request (e.g., INVITE message) contains the proprietary SIP header 'X-AC-Action' with the value 'direct-media' (i.e., 'X-AC-Action: direct-media'), as direct media calls. These calls remain as direct media calls until they end.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
<p>'RFC 2833 DTMF Payload Type'</p> <p>sbc-2833dtmf-payload</p> <p>[SBC2833DTMFPayloadType]</p>	<p>Defines the payload type of DTMF digits for the SIP UA associated with the IP Profile. The parameter enables the interworking of the DTMF payload type for RFC 2833 between different SBC call legs. For example, if two entities require different DTMF payload types, the SDP offer received by the device from one UA is forwarded to the destination UA with its payload type replaced with the configured payload type, and vice versa.</p> <p>The value range is 0 to 200. The default is 0 (i.e., the device forwards the received payload type as is).</p> <ul style="list-style-type: none"> <li>■ <b>For non-terminated calls:</b> <ul style="list-style-type: none"> <li>✓ Outgoing SDP offer: The payload type configured for the parameter is used. If not configured, the device uses the payload type of the incoming offer.</li> <li>✓ Outgoing SDP answer: If the payload type is configured for one of the IP Profiles, the payload type of the SDP offer is used. Otherwise, the</li> </ul> </li> </ul>



Parameter	Description
	<p>payload type of the incoming SDP answer is used.</p> <ul style="list-style-type: none"> <li>■ <b>For terminated calls:</b> <ul style="list-style-type: none"> <li>✓ <b>Outgoing SDP offer:</b> The payload type configured for the parameter is used. If not configured and there is a peer leg, the payload of the SDP created by the peer leg is used. Otherwise, the device uses a default payload type.</li> <li>✓ <b>Outgoing SDP answer:</b> If the payload type is configured for one of the IP Profiles, the payload type of the SDP offer is used. Otherwise, the payload type of the peer incoming stream is used.</li> </ul> </li> </ul>
<p>'Send Multiple DTMF Methods'</p> <p>sbc-send-multiple-dtmf-methods</p> <p>[SBCSupportMultipleDTMFMethods]</p>	<p>Enables the device to send DTMF digits out-of-band (not with audio stream) using both the SIP INFO and RFC 2833 methods for the same call on the leg to which this IP Profile is associated. The RFC 2833 method sends out-of-band DTMF digits using the RTP protocol while the SIP INFO method sends the digits using the SIP protocol.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) The device sends DTMF digits using only one method (either SIP INFO, RFC 2833, or in-band).</li> <li>■ [1] <b>Enable</b> = The device sends DTMF digits using both methods - SIP INFO and RFC 2833.</li> </ul> <p>If you have enabled the parameter, you can also configure the device to stop sending DTMF digits using the SIP INFO method if the device receives a SIP re-INVITE (or UPDATE) from the SIP UA to where the SIP INFO is being sent (and keep sending the DTMF digits using the RFC 2833 method). This is done using the AudioCodes proprietary SIP header X-AC-Action and a Message Manipulation rule (inbound) to instruct the device to switch to a different IP Profile that is configured to disable the sending of DTMF digits using both methods (i.e., 'Send Multiple DTMF Methods' is configured to Disable):</p> <p>X-AC-Action: 'switch-profile;profile-name=&lt;IP Profile Name&gt;'</p> <p>If the IP Profile name contains one or more spaces, you must enclose the name in double quotation marks, for example:</p>

Parameter	Description
	<p>X-AC-Action: 'switch-profile;profile-name="My IP Profile"'</p> <p>The Message Manipulation rule adds the proprietary header with the value of the new IP Profile to the incoming re-INVITE or UPDATE message and as a result, the device uses the new IP Profile for the SIP UA and stops sending it SIP INFO messages. You can also configure an additional Message Manipulation rule to re-start the sending of the SIP INFO. For example, you can configure two Message Manipulation rules where the sending of both SIP INFO and RFC 2833 depends on the negotiated media port -- the device stops sending SIP INFO if the SDP of the re-INVITE or UPDATE message contains port 7550 and re-starts sending if the port is 8660. The rule that re-starts the SIP INFO switches the IP Profile back to the initial IP Profile that enables the sending of DTMF digits using both methods (i.e., 'Send Multiple DTMF Methods' is configured to Enable). The configured Message Manipulation rules for this example are shown below:</p> <ul style="list-style-type: none"> <li>■ Index 1 <ul style="list-style-type: none"> <li>✓ Message Type: reinvite.request</li> <li>✓ Condition: body.sdp regex (.*)(m=audio 7550 RTP/AVP)(.*)</li> <li>✓ Action Subject: header.X-AC-Action</li> <li>✓ Action Type: Add</li> <li>✓ Action Value: 'switch-profile;profile-name=ITSP-Profile-2'</li> </ul> </li> <li>■ Index 2 <ul style="list-style-type: none"> <li>✓ Message Type: reinvite.request</li> <li>✓ Condition: body.sdp regex (.*)(m=audio 8660 RTP/AVP)(.*)</li> <li>✓ Action Subject: header.X-AC-Action</li> <li>✓ Action Type: Add</li> <li>✓ Action Value: 'switch-profile;profile-name=ITSP-Profile-1'</li> </ul> </li> </ul> <p>The Message Manipulation rules must be assigned to the</p>

Parameter	Description
	<p>SIP UA's IP Group, using the 'Inbound Message Manipulation Set' parameter.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ To send DTMF digits using both methods (i.e., when the parameter is enabled), you need to also configure the following: <ul style="list-style-type: none"> <li>✓ Configure the 'Alternative DTMF Method' parameter to one of the SIP INFO options (<b>INFO – Cisco</b>, <b>INFO – Nortel</b>, or <b>INFO – Lucent</b>).</li> <li>✓ Enable the sending of DTMF digits using the RFC 2833 method, by configuring the 'RFC 2833 Mode' parameter to <b>As Is</b> or <b>Extend</b>.</li> </ul> </li> <li>■ When using the X-AC-Action header to switch IP Profiles, it is recommended that the settings of the switched IP Profile are identical (except for the 'Send Multiple DTMF Methods' parameter) to the initial IP Profile in order to avoid any possible call handling errors.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
<p>'Receive Multiple DTMF Methods'</p> <p>sbc-receive-multiple-dtmf-methods</p> <p>[ReceiveMultipleDTMFMethods]</p>	<p>Enables the device to receive DTMF digits out-of-band (not with audio stream) using both the SIP INFO and RFC 2833 methods, but forwards the DTMF only using RFC 2833.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) The device receives DTMF digits only by the RFC 2833 method, if negotiated. Otherwise, the device uses the DTMF method according to the IP Profile's 'Alternative DTMF Method' parameter (see above). In other words, it receives DTMF digits using only one method only.</li> <li>■ [1] <b>Enable</b> = The device receives DTMF digits using the SIP INFO message method even if both sides successfully negotiated the RFC 2833 method. In other words, both SIP INFO and RFC 2833 are used to detect DTMF digits by the device. However, the device forwards the DTMF using RFC 2833 only.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>

Parameter	Description
'Adapt RFC2833 BW to Voice coder BW' sbc-adapt-rfc2833-bw-voice-bw [SBCAdaptRFC2833BWToVoiceCoderBW]	<p>Defines the 'telephone-event' type (8000 or 16000) in the SDP that the device sends in the outgoing SIP 200 OK message for DTMF payload negotiation (sampling rate).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) The device always sends the 'telephone-event' as 8000 in the outgoing SIP 200 OK, even if the SDP of the incoming INVITE contains multiple telephone-event types (e.g., 8000 and 16000).</li> <li>■ [1] <b>Enable</b> = The type of 'telephone-event' that the device sends in the outgoing SIP 200 OK message is according to the coder type (narrowband or wideband). If narrowband, it sends the 'telephone-event' as 8000; if wideband, it sends it as 16000.</li> </ul> <p>An example when the parameter is configured to <b>Enable</b> is shown below, whereby the 'telephone-event' is "16000" in the outgoing message due to the wideband coder:</p> <p><b>SDP in incoming INVITE:</b></p> <pre>a=rtpmap:97 AMR-WB/16000/1 a=fmtp:97 mode-change-capability=2 a=rtpmap:98 AMR-WB/16000/1 a=fmtp:98 octet-align=1; mode-change-capability=2 a=rtpmap:100 AMR/8000/1 a=fmtp:100 mode-change- capability=2 a=rtpmap:99 telephone- event/16000/1 a=fmtp:99 0-15 a=rtpmap:102 telephone-event/8000/1 a=fmtp:102 0-15</pre> <p><b>SDP in outgoing 200 OK:</b></p> <pre>m=audio 6370 RTP/AVP 97 99 a=rtpmap:99 telephone-event/<b>16000</b>/1 a=fmtp:99 0-15 a=sendrecv a=ptime:20 a=maxptime:120 a=rtpmap:97 AMR-WB/16000 a=fmtp:97 mode-change- capability=2;mode-set=0,1,2,3,4,5,6,7,</pre> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
'SDP Ptime Answer'	Defines the packetization time (ptime) of the coder in

Parameter	Description
sbc-sdp-ptime-ans [SBCSDPPtimeAnswer]	<p>RTP packets for the SIP UA associated with the IP Profile. This is useful when implementing transrating.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Remote Answer</b> = (Default) Use ptime according to SDP answer.</li> <li>■ [1] <b>Original Offer</b> = Use ptime according to SDP offer.</li> <li>■ [2] <b>Preferred Value</b> = Use the ptime according to the 'Preferred Ptime' parameter (see below) if it is configured to a non-zero value.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Regardless of the settings of this parameter, if a non-zero value is configured for the 'Preferred Ptime' parameter (see below), it is used as the ptime in the SDP offer.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
'Preferred Ptime' sbc-preferred-ptime [SBCPreferredPTime]	<p>Defines the packetization time (ptime) in msec for the SIP UA associated with the IP Profile, in the outgoing SDP offer.</p> <p>If the 'SDP Ptime Answer' parameter (see above) is configured to Preferred Value [2] and the 'Preferred Ptime' parameter is configured to a non-zero value, the configured ptime is used (enabling ptime transrating if the other side uses a different ptime).</p> <p>If the 'SDP Ptime Answer' parameter is configured to Remote Answer [0] or Original Offer [1] and the 'Preferred Ptime' parameter is configured to a non-zero value, the configured value is used as the ptime in the SDP offer.</p> <p>The valid range is 0 to 200. The default is 0 (i.e., a preferred ptime is not used).</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
'Use Silence Suppression' sbc-use-silence-supp [SBCUseSilenceSupp]	<p>Defines silence suppression support for the SIP UA associated with the IP Profile</p> <ul style="list-style-type: none"> <li>■ [0] <b>Transparent</b> = (Default) Forward as is.</li> <li>■ [1] <b>Add</b> = Enable silence suppression for each relevant coder listed in the SDP.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [2] <b>Remove</b> = Disable silence suppression for each relevant coder listed in the SDP.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ This feature requires DSP resources.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
'RTP Redundancy Mode' sbc-rtsp-red-behav [SBCRTPRedundancyBehavior]	<p>Enables interworking RTP redundancy negotiation support between SIP entities in the SDP offer-answer exchange (according to RFC 2198). The parameter defines the device's handling of RTP redundancy for the SIP UA associated with the IP Profile. According to the RTP redundancy SDP offer/answer negotiation, the device uses or discards the RTP redundancy packets. The parameter enables asymmetric RTP redundancy, whereby the device can transmit and receive RTP redundancy packets to and from a specific SIP UA, while transmitting and receiving regular RTP packets (no redundancy) for the other SIP UA involved in the voice path.</p> <p>The device can identify the RTP redundancy payload type in the SDP for indicating that the RTP packet stream includes redundant packets. RTP redundancy is indicated in SDP using the "red" coder type, for example:</p> <pre>a=rtpmap:&lt;payload type&gt; red/8000/1</pre> <p>RTP redundancy is useful when there is packet loss; the missing information may be reconstructed at the receiver side from the redundant packets.</p> <ul style="list-style-type: none"> <li>■ [0] <b>As Is</b> = (Default) The device doesn't interfere in the RTP redundancy negotiation and forwards the SDP offer/answer (incoming and outgoing calls) as is without interfering in the RTP redundancy negotiation.</li> <li>■ [1] <b>Enable</b> = The device always adds RTP redundancy capabilities in the outgoing SDP offer sent to the SIP UA. Whether RTP redundancy is implemented depends on the subsequent incoming SDP answer from the SIP UA. The device doesn't modify the incoming SDP offer received from the SIP UA, but if RTP redundancy is offered, it will support it in the outgoing SDP answer. Select the option if the SIP UA</li> </ul>

Parameter	Description
	<p>requires RTP redundancy.</p> <ul style="list-style-type: none"> <li>■ [2] <b>Disable</b> = The device removes the RTP redundancy payload (if present) from the SDP offer/answer for calls received from or sent to the SIP UA. Select the option if the SIP UA doesn't support RTP redundancy.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ To enable the device to generate RFC 2198 redundant packets, use the 'RTP Redundancy Depth' parameter.</li> <li>■ To configure the payload type in the SDP offer for RTP redundancy, use the [RFC2198PayloadType] parameter.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
<p>'RTCP Mode'</p> <p>sbc-rtcp-mode</p> <p>[SBCRTCPMode]</p>	<p>Defines how the device handles RTCP packets during call sessions for the SIP UA associated with the IP Profile. This is useful for interworking RTCP between SIP entities. For example, this may be necessary when incoming RTCP is not compatible with the destination SIP UA's (this IP Profile) RTCP support. In such a scenario, the device can generate the RTCP and send it to the SIP UA.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Transparent</b> = (Default) RTCP is forwarded as is.</li> <li>■ [1] <b>Generate Always</b> = Generates RTCP packets during active and inactive (e.g., during call hold) RTP periods (i.e., media is 'a=recvonly' or 'a=inactive' in the INVITE SDP).</li> <li>■ [2] <b>Generate only if RTP Active</b> = Generates RTCP packets only during active RTP periods. In other words, the device doesn't generate RTCP when there is no RTP traffic (such as when a call is on hold).</li> </ul> <p><b>Note:</b> The corresponding global parameter is [SBCRTCPMode].</p>
<p>'Jitter Compensation'</p> <p>sbc-jitter-compensation</p> <p>[SBCJitterCompensation]</p>	<p>Enables the on-demand jitter buffer for SBC calls. The jitter buffer is useful when incoming packets are received at inconsistent intervals (i.e., packet delay variation). The jitter buffer stores the packets and sends them out at a constant rate (according to the coder's settings).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [1] <b>Enable</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The jitter buffer parameters, 'Dynamic Jitter Buffer Minimum Delay' (DJBufMinDelay) and 'Dynamic Jitter Buffer Optimization Factor' (DJBufOptFactor) can be used to configure minimum packet delay only when transcoding is employed.</li> </ul>
'ICE Mode' ice-mode [SBCIceMode]	<p>Enables Interactive Connectivity Establishment (ICE) for the SIP UA associated with the IP Profile. ICE is a methodology for NAT traversal, employing the Session Traversal Utilities for NAT (STUN) and Traversal Using Relays around NAT (TURN) protocols to provide a peer with a public IP address and port that can be used to connect to a remote peer. The device supports ICE-Full and ICE-Lite, but ICE-Lite is a limited implementation where the device can't initiate the ICE process.</p> <p>ICE is typically required, for example, when the device operates in a Microsoft Teams Direct Routing (media bypass) environment.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Lite</b> = Enables ICE-Lite.</li> <li>■ [2] <b>Full</b> = Enables ICE-Full.</li> </ul> <p>For more information on ICE , see <a href="#">Implementing ICE for Media Sessions</a> on page 184.</p>
'SDP Handle RTCP' sbc-sdp-handle-rtcp [SBCSDPHandleRTCPAttribute]	<p>Enables the interworking of the RTCP attribute, 'a=rtcp' (RTCP) in the SDP, for the SIP UA associated with the IP Profile. The RTCP attribute is used to indicate the RTCP port for media when that port is not the next higher port number following the RTP port specified in the media line ('m=').</p> <p>The parameter is useful for SIP entities that either require the attribute or do not support the attribute. For example, Google Chrome and Web RTC do not accept calls without the RTCP attribute in the SDP. In Web RTC, Chrome (SDES) generates the SDP with 'a=rtcp', for example:</p> <pre>m=audio 49170 RTP/AVP 0 a=rtcp:53020 IN IP6</pre>



Parameter	Description
	<p>2001:2345:6789:ABCD:EF01:2345:6789:ABCD</p> <ul style="list-style-type: none"> <li>■ [0] <b>Don't Care</b> = (Default) The device forwards the SDP as is without interfering in the RTCP attribute (regardless if present or not).</li> <li>■ [1] <b>Add</b> = The device adds the 'a=rtcp' attribute to the outgoing SDP offer sent to the SIP UA if the attribute was not present in the original incoming SDP offer.</li> <li>■ [2] <b>Remove</b> = The device removes the 'a=rtcp' attribute, if present in the incoming SDP offer received from the other SIP UA, before sending the outgoing SDP offer to the SIP UA.</li> </ul>
'RTCP Mux' sbc-rtcp-mux [SBCRTCPMux]	<p>Enables interworking of multiplexing of RTP and RTCP onto a single local port, between SIP entities. The parameter enables multiplexing of RTP and RTCP traffic onto a single local port, for the SIP UA associated with the IP Profile.</p> <p>Multiplexing of RTP data packets and RTCP packets onto a single local UDP port is done for each RTP session (according to RFC 5761). If multiplexing is not enabled, the device uses different (but adjacent) ports for RTP and RTCP packets.</p> <p>With the increased use of NAT and firewalls, maintaining multiple NAT bindings can be costly and also complicate firewall administration since multiple ports must be opened to allow RTP traffic. To reduce these costs and session setup times, support for multiplexing RTP data packets and RTCP packets onto a single port is advantageous.</p> <p>For multiplexing, the initial SDP offer must include the "a=rtcp-mux" attribute to request multiplexing of RTP and RTCP onto a single port. If the SDP answer wishes to multiplex RTP and RTCP, it must also include the "a=rtcp-mux" attribute. If the answer doesn't include the attribute, the offerer must not multiplex RTP and RTCP packets. If both ICE and multiplexed RTP-RTCP are used, the initial SDP offer must also include the "a=candidate:" attribute for both RTP and RTCP along with the "a=rtcp:" attribute, indicating a fallback port for RTCP in case the answerer doesn't support RTP and RTCP multiplexing.</p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [0] <b>Not Supported</b> = (Default) RTP and RTCP packets use different ports.</li> <li>■ [1] <b>Supported</b> = Device multiplexes RTP and RTCP packets onto a single port.</li> </ul>
'RTCP Feedback' sbc-rtcp-feedback [SBCRTCPFeedback]	<p>Enables RTCP-based feedback indication in outgoing SDPs sent to the SIP UA associated with the IP Profile.</p> <p>The parameter supports indication of RTCP-based feedback, according to RFC 5124, during RTP profile negotiation between two communicating SIP entities. RFC 5124 defines an RTP profile (S)AVPF for (secure) real-time communications to provide timely feedback from the receivers to a sender. For more information on RFC 5124, see <a href="http://tools.ietf.org/html/rfc5124">http://tools.ietf.org/html/rfc5124</a>.</p> <p>Some SIP entities may require RTP secure-profile feedback negotiation (AVPF/SAVPF) in the SDP offer/answer exchange, while other SIP entities may not support it. The device indicates whether or not feedback is supported on behalf of the SIP UA. It does this by adding an "F" or removing the "F" from the SDP media line ('m=') for AVP and SAVP. For example, the following shows "AVP" appended with an "F", indicating that the SIP UA is capable of receiving feedback</p> <pre>m=audio 49170 RTP/SAVPF 0 96</pre> <ul style="list-style-type: none"> <li>■ [0] <b>Feedback Off</b> = (Default) The device doesn't send the feedback flag ("F") in SDP offers/answers that are sent to the SIP UA. If the SDP 'm=' attribute of an incoming message that is destined to the SIP UA includes the feedback flag, the device removes it before sending the message to the SIP UA.</li> <li>■ [1] <b>Feedback On</b> = The device includes the feedback flag ("F") in the SDP offer sent to the SIP UA. The device includes the feedback flag in the SDP answer sent to the SIP UA only if it was present in the SDP offer received from the other SIP UA.</li> <li>■ [2] <b>As Is</b> = The device doesn't involve itself in the feedback, but simply forwards any feedback indication as is.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ As RTCP-based feedback has been defined by the</li> </ul>

Parameter	Description
	<p>WebRTC standard as mandatory, the support is important for deployments implementing WebRTC. For more information on WebRTC, see <a href="#">Configuring IP Profiles</a>.</p>
<p>'Re-number MID'</p> <p><code>sbc-renumber-mid</code></p> <p>[SBCRenumberMID]</p>	<p>Enables the device to change the value of the 'a=mid:n' attribute (where <i>n</i> is a unique value) in the outgoing SDP offer so that in the first media ('m=' line) the value will be 0, the next media the value will be 1, and so on. This is done only if the 'a=mid' attribute is present in the incoming SDP offer.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
<p>'Switch Coder Upon Voice Quality'</p> <p><code>switch-coder-upon-voice-quality</code></p> <p>[SwitchCoderUponVoiceQuality]</p>	<p>Enables the device to detect poor voice quality during a call for an unregistered user, and then to change IP Profiles so that the coder switches between G.711 and Opus.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p>For more information, see <a href="#">Configuring Voice Quality for Unregistered Users</a> on page 537.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<p>'Generate No-Op Packets'</p> <p><code>sbc-generate-noop</code></p> <p>[SBCGenerateNoOp]</p>	<p>Enables the device to send RTP or T.38 No-Op packets during RTP or T.38 silence periods.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p>For more information on No-Op packets, see <a href="#">No-Op Packets</a> on page 183.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For configuring the Tx payload type for No-Op packets, use the [RTPNoOpPayloadType] parameter.</li> <li>■ The parameter is applicable only to the SBC</li> </ul>

Parameter	Description
	application.
<p>'SBC Multiple Coders'</p> <pre>configure voip &gt; coders-and-profiles ip-profile &gt; sbc- multiple-coders [SBCMultipleCoders]</pre>	<p>Defines if the UA associated with this IP Profile supports multiple coders in the SDP answer that is received from the peer side.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Not Supported</b> = (Default) If multiple coders ('m=' line) are present in the SDP answer received from the peer side, the device uses only the first supported coder in the list for the RTP media.</li> <li>■ [1] <b>Supported</b> = If multiple coders ('m=' line) are present in the SDP answer received from the peer side, the device does one of the following, depending on whether DSP resources are required (e.g., for DTMF transcoding): <ul style="list-style-type: none"> <li>✓ DSP resources required: Upon receipt of the SDP answer, the device sends a re-INVITE message with only a single coder (first supported coder in the list) to the UA associated with this IP Profile. In other words, the device “forces” the UAs to negotiate only a single coder for the RTP media.</li> <li>✓ DSP resources not required: The device supports multiple coders in the SDP answer, allowing the RTP media to use any one of the listed coders (doesn't send a re-INVITE).</li> </ul> </li> </ul> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<p>'SBC Allow Only Negotiated PT'</p> <pre>configure voip &gt; coders-and-profiles ip-profile &gt; sbc- allow-only- negotiated-pt [SBCAllowOnlyNegotiatedPT]</pre>	<p>Enables the device to allow only media (RTP) packets, from the UA associated with this IP Profile, using the single coder (payload type) that was negotiated during the SDP offer/answer exchange (e.g., 'm=audio 53456 RTP/AVP 0' for G.711). The device drops all other packets from the UA using any other coder.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> =(Default) The device allows packets with multiple negotiated coders.</li> <li>■ [1] <b>Enable</b> = The device allows only packets with the single negotiated coder.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>

Parameter	Description
'Remove CSRC' sbc-remove-csrc [SBCRemoveCSRC]	<p>Enables the device to remove the contributing source (CSRC) identifiers (CC field) from the RTP header in RTP packets sent to the UA associated with this IP Profile.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (Default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
'SBC Precondition' sbc-precondition [SBCPrecondition]	<p>Defines if the UA associated with this IP Profile supports SIP session preconditions according to RFC 3312.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Not Supported</b> = (Default) If the Require header in the incoming SIP message contains the value 'precondition', the device rejects the message (420 Bad Extension response). The device never adds the value 'precondition' to the Supported header (or Require header) in outgoing messages.</li> <li>■ [1] <b>Supported</b> = The device always adds the value 'precondition' to the Supported header in the outgoing SIP message (unless it has to add it to the Require header according to RFC 3312).</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For this functionality, you must also do the following: <ul style="list-style-type: none"> <li>✓ Configure the IP Profile's 'Remote Can Play Ringback' parameter to <b>No</b> because according to the RFC, the 'precondition' must be done during the early media stage.</li> <li>✓ Configure the IP Profile's 'SIP UPDATE Support' parameter to <b>Supported</b> because using the SIP UPDATE message is mandatory according to the RFC.</li> </ul> </li> <li>■ The device doesn't initiate precondition attributes in the SDP.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
'BFCP IP from Audio Media' bfcp-ip-from-audio [SBCBFCPNatFromAudio]	<p>Enables the handling of calls with voice and Binary Floor Control Protocol (BFCP) media streams that are received from behind a NAT. The device latches onto the first</p>

Parameter	Description
	<p>incoming voice packet to determine the IP address and applies it to the BFCP stream. This allows the device to forward the BFCP packets to the remote side.</p> <p>The BFCP, as defined in RFC 8855, manages access to shared resources in multiparty conferencing environments. BFCP allows users to share presentations or desktops within an ongoing video conversation. The desktop sharing video stream runs in addition to the actual call which already has audio and video streams.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>According to Global Parameter</b> = (Default) According to the settings of the global parameter [BFCPNatFromAudio].</li> <li>■ [0] <b>Disable</b></li> <li>■ [1] <b>Enable</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ This feature assumes that both the voice and BFCP streams originate from the <b>same</b> source.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
'Remove EXTMAP' sbc-remove-extmap [SBCRemoveEXTMAP]	<p>Enables the device to remove the 'a=extmap' SDP line in outgoing SIP-initiating INVITE requests.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<b>Quality of Service</b>	
'RTP IP DiffServ' rtp-ip-diffserv [IPDiffServ]	<p>Defines the DiffServ value for Premium Media class of service (CoS) content.</p> <p>The valid range is 0 to 63. The default is 46.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The corresponding global parameter is [PremiumServiceClassMediaDiffServ].</li> <li>■ In addition to audio, the parameter applies to video media if the 'RTP Video DiffServ' is configured to -1 (default).</li> </ul>

Parameter	Description
'RTP Video DiffServ' rtp-video-diffserv [VideoDiffServ]	Defines the DiffServ value for video media. The valid range is -1, or 0 to 63. The default is -1, which means the DiffServ value for video is according to the 'RTP IP DiffServ' parameter.
'Signaling DiffServ' signaling-diffserv [SigIPDiffServ]	Defines the DiffServ value for Premium Control CoS content (Call Control applications). The valid range is 0 to 63. The default is 40. <b>Note:</b> The corresponding global parameter is [PremiumServiceClassControlDiffServ].
'Data DiffServ' data-diffserv [DataDiffServ]	Defines the DiffServ value of MSRP traffic in the IP header's DSCP field. The valid range is 0 to 63. The default is 0. For more information on MSRP, see <a href="#">Configuring Message Session Relay Protocol</a> on page 1141. <b>Note:</b> The parameter is applicable only to the SBC application.
<b>Jitter Buffer</b>	
'Dynamic Jitter Buffer Minimum Delay' jitter-buffer-minimum-delay [JitterBufMinDelay]	Defines the minimum delay (in msec) of the device's dynamic Jitter Buffer. The valid range is 0 to 150. The default delay is 10. For more information on Jitter Buffer, see <a href="#">Configuring the Dynamic Jitter Buffer</a> on page 290. <b>Note:</b> The corresponding global parameter is [DJBufMinDelay].
'Dynamic Jitter Buffer Optimization Factor' jitter-buffer-optimization-factor [JitterBufOptFactor]	Defines the Dynamic Jitter Buffer frame error/delay optimization factor. The valid range is 0 to 12. The default factor is 10. For more information on Jitter Buffer, see <a href="#">Configuring the Dynamic Jitter Buffer</a> on page 290. <b>Note:</b> <ul style="list-style-type: none"> <li>■ For data (fax and modem) calls, set the parameter to 12.</li> <li>■ The corresponding global parameter is [DJBufOptFactor].</li> </ul>
'Jitter Buffer Max Delay'	Defines the maximum delay and length (in msec) of the

Parameter	Description
jitter-buffer-max-delay [JitterBufMaxDelay]	Jitter Buffer. The valid range is 150 to 2,000. The default is 250.
<b>Voice</b>	
'Echo Canceler' echo-canceller [EnableEchoCanceller]	Enables the device's Echo Cancellation feature (i.e., echo from voice calls is removed).  ■ [0] <b>Disable</b>  ■ [1] <b>Line</b> (default)  For a detailed description of the Echo Cancellation feature, see <a href="#">Configuring Echo Cancellation</a> on page 273. <b>Note:</b> The corresponding global parameter is [EnableEchoCanceller].
'Input Gain' input-gain [InputGain]	Defines the pulse-code modulation (PCM) input gain control (in decibels). For the Gateway application: Defines the level of the received signal for Tel-to-IP calls. The valid range is -32 to 31 dB. The default is 0 dB. <b>Note:</b> The corresponding global parameter is [InputGain].
'Voice Volume' voice-volume [VoiceVolume]	Defines the voice gain control (in decibels). For the Gateway application: Defines the level of the transmitted signal for IP-to-Tel calls. The valid range is -32 to 31 dB. The default is 0 dB. <b>Note:</b> The corresponding global parameter is [VoiceVolume].
<b>SBC Signaling</b>	
'PRACK Mode' sbc-prack-mode [SbcPrackMode]	Defines the device's handling of SIP PRACK messages for the SIP UA associated with the IP Profile.  ■ [0] <b>Disabled</b> = The device doesn't allow PRACK: <ul style="list-style-type: none"> <li>✓ For SIP requests (INVITE) and responses (18x), the device removes the '100rel' option from the SIP Supported header (if present). In other words, the device disables PRACK with this SIP UA.</li> <li>✓ If the device receives an INVITE message containing the header and value 'Require: 100rel', it rejects the message (with a SIP 420 response).</li> </ul>



Parameter	Description
	<ul style="list-style-type: none"> <li>✓ If the device receives a SIP 18x response containing the RSeq header and the '100rel' option, it sends a CANCEL message to cancel the SIP dialog.</li> <li>■ [1] <b>Optional</b> = PRACK is optional. If required, the device performs the PRACK process on behalf of the SIP UA.</li> <li>■ [2] <b>Mandatory</b> = PRACK is required for this SIP UA. Calls from UAs that do not support PRACK are rejected. Calls destined to these UAs are also required to support PRACK.</li> <li>■ [3] <b>Transparent</b> = (Default) The device doesn't intervene with the PRACK process and forwards the request as is.</li> <li>■ [4] <b>Optional With Adaptations</b> = This option may be useful, for example, to prevent PRACK congestion caused by the flooding of the device with 18x messages without body.</li> <li>✓ Outgoing INVITE messages (sent to SIP UA): <ul style="list-style-type: none"> <li>- The device adds the header 'Supported: 100rel' to the INVITE message. If the message included the header and value 'Require: 100rel', it removes the '100rel' option.</li> <li>- If the device adds the '100rel' option, it terminates and fully handles PRACK; otherwise, the device forwards the message transparently.</li> </ul> </li> <li>✓ Incoming INVITE messages (from SIP UA): <ul style="list-style-type: none"> <li>- If the message doesn't contain the '100rel' option, the device doesn't handle PRACK.</li> <li>- If the message contains the header and value 'Require: 100rel', the device processes PRACK as described for the <b>Mandatory</b> optional value above (and terminates PRACK, if necessary).</li> <li>- If the message contains the header and value 'Supported: 100rel', the device activates PRACK Extensions as follows: <ul style="list-style-type: none"> <li>&gt;&gt; If the device sends an outgoing 18x responses with body (e.g., SDP), the device processes PRACK as described for the <b>Mandatory</b> optional value above (and terminates PRACK, if necessary).</li> </ul> </li> </ul> </li> </ul>

Parameter	Description
	<p>&gt;&gt; If the device sends an outgoing 18x responses without body, the device removes the '100rel' option and the RSeq header (if present). If the RSeq header was present, the device sends a terminated PRACK to the incoming leg without Optional With Adaptations outgoing leg involvement.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
'P-Asserted-Identity Header Mode' sbc-assert-identity [SBCAssertIdentity]	<p>Defines the device's handling of the SIP P-Asserted-Identity header for the SIP UA associated with the IP Profile. This header indicates how the outgoing SIP message asserts identity.</p> <ul style="list-style-type: none"> <li>■ [0] <b>As Is</b> = (Default) P-Asserted Identity header is not affected and the device uses the same P-Asserted-Identity header (if present) in the incoming message for the outgoing message.</li> <li>■ [1] <b>Add</b> = Adds a P-Asserted-Identity header. The header's values are taken from the source URL.</li> <li>■ [2] <b>Remove</b> = Removes the P-Asserted-Identity header.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter affects only initial INVITE requests.</li> <li>■ The corresponding global parameter is [SBCAssertIdentity].</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
'Diversion Header Mode' sbc-diversion-mode [SBCDiversionMode]	<p>Defines the device's handling of the SIP Diversion header for the SIP UA associated with the IP Profile.</p> <ul style="list-style-type: none"> <li>■ [0] <b>As Is</b> = (Default) Diversion header is not handled.</li> <li>■ [1] <b>Add</b> = History-Info header is converted to a Diversion header.</li> <li>■ [2] <b>Remove</b> = Removes the Diversion header and the conversion to the History-Info header depends on the SBCHistoryInfoMode parameter.</li> </ul> <p>For more information on interworking of the History-Info</p>

Parameter	Description
	<p>and Diversion headers, see <a href="#">Interworking SIP Diversion and History-Info Headers</a> on page 1043.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If the Diversion header is used, you can specify the URI type (e.g., "tel:") to use in the header, using the [SBCDiverionUriType] parameter.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
<p>'History-Info Header Mode'</p> <p>sbc-history-info-mode</p> <p>[SBCHistoryInfoMode]</p>	<p>Defines the device's handling of the SIP History-Info header for the SIP UA associated with the IP Profile.</p> <ul style="list-style-type: none"> <li>■ [0] <b>As Is</b> = (Default) History-Info header is not handled.</li> <li>■ [1] <b>Add</b> = Diversion header is converted to a History-Info header.</li> <li>■ [2] <b>Remove</b> = History-Info header is removed from the SIP dialog and the conversion to the Diversion header depends on the SBCDiverionMode parameter.</li> </ul> <p>For more information on interworking of the History-Info and Diversion headers, see <a href="#">Interworking SIP Diversion and History-Info Headers</a> on page 1043.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<p>'Session Expires Mode'</p> <p>sbc-session-expires-mode</p> <p>[SBCSessionExpiresMode]</p>	<p>Defines the required session expires mode for the SIP UA associated with the IP Profile.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Transparent</b> = (Default) The device doesn't interfere with the session expires negotiation.</li> <li>■ [1] <b>Observer</b> = If the SIP Session-Expires header is present, the device doesn't interfere, but maintains an independent timer for each leg to monitor the session. However, if the session is not refreshed on time, the device disconnects the call. The timer duration is configured by the global parameter [SipSessionExpiresObserverMode].</li> <li>■ [2] <b>Not Supported</b> = The device doesn't allow a session timer with this SIP UA.</li> </ul>

Parameter	Description
	<p>■ [3] <b>Supported</b> = The device enables the session timer with this SIP UA. If the incoming SIP message doesn't include any session timers, the device adds the session timer information to the sent message. You can configure the value of the Session-Expires and Min-SE headers, using the [SBCSessionExpires] and [SBCMinSE] parameters, respectively.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<p>'SIP UPDATE Support' sbc-rmt-update-supp [SBCRemoteUpdateSupport]</p>	<p>Defines if the SIP UA associated with this IP Profile supports the receipt of SIP UPDATE messages.</p> <p>■ [0] <b>Not Supported</b> = The UA doesn't support the receipt of UPDATE messages.</p> <p>■ [1] <b>Supported Only After Connect</b> = The UA supports the receipt of UPDATE messages, but only after the call is connected.</p> <p>■ [2] <b>Supported</b> = (Default) The UA supports the receipt of UPDATE messages during call setup and after call establishment.</p> <p>■ [3] <b>According Remote Allow</b> = The UA support for SIP UPDATE messages depends on the presence of the "update" capability in the Allow header in the last SIP message received from the UA. When the UA indicates UPDATE support:</p> <ul style="list-style-type: none"> <li>✓ If session refresh is used, the device sends session refreshes to the UA using UPDATE messages.</li> <li>✓ If an UPDATE message is received from a peer UA, the device forwards the UPDATE message to this supporting UA.</li> <li>✓ If a re-INVITE message containing an SDP is received from a peer UA, the device sends it as an UPDATE message to the supporting UA. If an INVITE message without an SDP is received from a peer UA, the device forwards the INVITE message to the supporting UA.</li> </ul> <p>If the Allow header doesn't indicate UPDATE support, the device sends INVITE messages instead of UPDATE messages to the UA.</p>

Parameter	Description
	<p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<p>'Remote re-INVITE'</p> <p>sbc-rmt-re-invite-supp</p> <p>[SBCRemoteReinviteSupport]</p>	<p>Defines if the SIP UA associated with this IP Profile supports the receipt of SIP re-INVITE messages.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Not Supported</b> = The UA doesn't support the receipt of re-INVITE messages. If the device receives a re-INVITE from another UA that is destined to this UA, the device "terminates" the re-INVITE and sends a SIP response to the UA that sent it, which can be a success or a failure, depending on whether the device can bridge the media between the UAs.</li> <li>■ [1] <b>Supported only with SDP</b> = The UA supports the receipt of re-INVITE messages, but only if they contain an SDP body. If the incoming re-INVITE from another UA doesn't contain SDP, the device creates and adds an SDP body to the re-INVITE that it forwards to the UA.</li> <li>■ [2] <b>Supported</b> = (Default) The UA supports the receipt of re-INVITE messages with or without SDP.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<p>'Remote Delayed Offer Support'</p> <p>sbc-rmt-delayed-offer</p> <p>[SBCRemoteDelayedOfferSupport]</p>	<p>Defines if the remote UA supports delayed offer (i.e., initial INVITE requests without an SDP offer).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Not Supported</b></li> <li>■ [1] <b>Supported</b> (default)</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
<p>'MSRP re-INVITE/UPDATE'</p> <p>sbc-msrp-re-invite-update-supp</p> <p>[SBCMSRPReinviteUpdateSupport]</p>	<p>Defines if the SIP UA (MSRP endpoint) associated with this IP Profile supports the receipt of re-INVITE and UPDATE SIP messages.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Not Supported</b> = The device doesn't send re-INVITE or UPDATE messages to the UA. If the device receives any of these messages from the peer UA, the device "terminates" the messages, and then sends a SIP response to the peer UA on behalf of the UA</li> </ul>

Parameter	Description
	<p>associated with this IP Profile.</p> <ul style="list-style-type: none"> <li>■ [1] <b>Supported</b> (default)</li> </ul> <p>For more information on MSRP, see <a href="#">Configuring Message Session Relay Protocol</a> on page 1141.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<p>'MSRP Offer Setup Role'</p> <p>sbc-msrp-offer-setup-role</p> <p>[SBCMSRPOfferSetupRole]</p>	<p>Defines the device's preferred MSRP role, which is indicated in the initial SDP offer that it sends to the destination MSRP endpoint ('a=setup' line) associated with this IP Profile. However, this is only a preferred role; the actual role that the device takes on depends on the destination MSRP endpoint's desired role, which is indicated in the SDP answer in its reply to the device:</p> <ul style="list-style-type: none"> <li>■ If 'a=setup:active', the device takes the passive role.</li> <li>■ If 'a=setup:passive', the device takes the active role.</li> <li>■ If 'a=setup' (i.e., empty) or no 'a=setup', the device takes the active role.</li> </ul> <p>The possible values include:</p> <ul style="list-style-type: none"> <li>■ [0] <b>Active</b> = The device prefers the active role and includes 'a=setup:active' in the outgoing SDP offer sent to the endpoint associated with the IP Profile.</li> <li>■ [1] <b>Passive</b> = The device prefers the passive role and includes 'a=setup:passive' in the outgoing SDP offer sent to the endpoint associated with the IP Profile.</li> <li>■ [2] <b>ActPass</b> = (Default) The device has no role preference and includes 'a=setup:actpass' in the outgoing SDP offer sent to the endpoint associated with the IP Profile</li> </ul> <p>For more information on MSRP, see <a href="#">Configuring Message Session Relay Protocol</a> on page 1141.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<p>'MSRP Empty Message Format'</p> <p>sbc-msrp-empty-message-format</p>	<p>On an active MSRP leg, enables the device to add the Content-Type header to the first empty (i.e., no body) MSRP message that is used to initiate the MSRP connection.</p>

Parameter	Description
[SBCMSRPEmpMsg]	<ul style="list-style-type: none"> <li>■ [0] <b>Default</b> = (Default) Sends the empty message with regular headers, according to the RFC for MSRP.</li> <li>■ [1] <b>With Content Type</b> = Adds the Content-Type header to the empty message (in addition to the regular headers according to the RFC for MSRP).</li> </ul> <p>For more information on MSRP, see <a href="#">Configuring Message Session Relay Protocol</a> on page 1141.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
'Remote Representation Mode' sbc-rmt-rprntation [SBCRemoteRepresentationMode]	<p>Enables interworking SIP in-dialog, Contact and Record-Route headers between SIP entities. The parameter defines the device's handling of in-dialog, Contact and Record-Route headers for messages sent to the SIP UA associated with the IP Profile.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>According to Operation Mode</b> = (Default) Depends on the setting of the 'Operation Mode' parameter in the IP Groups or SRDs table: <ul style="list-style-type: none"> <li>✓ B2BUA: Device operates as if the parameter is set to Replace Contact [0].</li> <li>✓ Call State-full Proxy: Device operates as if the parameter is set to Add Routing Headers [1].</li> </ul> </li> <li>■ [0] <b>Replace Contact</b> = The URI host part in the Contact header of the received message (from the other side) is replaced with the device's address or with the value of the 'SIP Group Name' parameter (configured in the IP Groups table) in the outgoing message sent to the SIP UA.</li> <li>■ [1] <b>Add Routing Headers</b> = Device adds a Record-Route header for itself to outgoing messages (requests/responses) sent to the SIP UA in dialog-setup transactions. The Contact header remains unchanged.</li> <li>■ [2] <b>Transparent</b> = Device doesn't change the Contact header and doesn't add a Record-Route header for itself. Instead, it relies on its' own inherent mechanism to remain in the route of future requests in the dialog (for example, relying on the way the endpoints are set up or on TLS as the transport type).</li> </ul>

Parameter	Description
	<p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<p>'Keep Incoming Via Headers'</p> <p>sbc-keep-via-headers</p> <p>[SBCKeepVIAHeaders]</p>	<p>Enables interworking SIP Via headers between SIP entities. The parameter defines the device's handling of Via headers for messages sent to the SIP UA associated with the IP Profile.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>According to Operation Mode</b> = Depends on the setting of the 'Operation Mode' parameter in the IP Groups table or SRDs table: <ul style="list-style-type: none"> <li>✓ B2BUA: Device operates as if the parameter is set to Disable [0].</li> <li>✓ Call State-full Proxy: Device operates as if the parameter is set to Enable [1].</li> </ul> </li> <li>■ [0] <b>Disable</b> = Device removes all Via headers received in the incoming SIP request from the other leg and adds a Via header identifying only itself, in the outgoing message sent to the SIP UA.</li> <li>■ [1] <b>Enable</b> = Device retains the Via headers received in the incoming SIP request and adds itself as the top-most listed Via header in the outgoing message sent to the SIP UA.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<p>'Keep Incoming Routing Headers'</p> <p>sbc-keep-routing-headers</p> <p>[SBCKeepRoutingHeaders]</p>	<p>Enables interworking SIP Record-Route headers between SIP entities. The parameter defines the device's handling of Record-Route headers for request/response messages sent to the SIP UA associated with the IP Profile.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>According to Operation Mode</b> = (Default) Depends on the setting of the 'Operation Mode' in the IP Group or SRDs table: <ul style="list-style-type: none"> <li>✓ B2BUA: Device operates as if the parameter is set to Disable [0].</li> <li>✓ Call State-full Proxy: Device operates as if the parameter is set to Enable [1].</li> </ul> </li> <li>■ [0] <b>Disable</b> = Device removes the Record-Route headers received in requests and responses from the other side, in the outgoing SIP message sent to the SIP</li> </ul>



Parameter	Description
	<p>UA. The device creates a route set for that side of the dialog based on these headers, but doesn't send them to the SIP UA.</p> <ul style="list-style-type: none"> <li>■ [1] <b>Enable</b> = Device retains the incoming Record-Route headers received in requests and non-failure responses from the other side, in the following scenarios: <ul style="list-style-type: none"> <li>✓ The message is part of a SIP dialog-setup transaction.</li> <li>✓ The messages in the setup and previous transaction didn't include the Record-Route header, and therefore hadn't set the route set.</li> </ul> </li> </ul> <p><b>Note:</b> Record-Routes are kept only for SIP INVITE, UPDATE, SUBSCRIBE and REFER messages.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
'Keep User-Agent Header' sbc-keep-user-agent [SBCKeepUserAgentHeader]	<p>Enables interworking SIP User-Agent headers between SIP entities. The parameter defines the device's handling of User-Agent headers for response/request messages sent to the SIP UA associated with the IP Profile.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>According to Operation Mode</b> = (Default) Depends on the setting of the 'Operation Mode' parameter in the IP Group or SRDs table: <ul style="list-style-type: none"> <li>✓ B2BUA: Device operates as if this parameter is set to Disable [0].</li> <li>✓ Call State-full Proxy: Device operates as if this parameter is set to Enable [1].</li> </ul> </li> <li>■ [0] <b>Disable</b> = Device removes the User-Agent/Server headers received in the incoming message from the other side, and adds its' own User-Agent header in the outgoing message sent to the SIP UA.</li> <li>■ [1] <b>Enable</b> = Device retains the User-Agent/Server headers received in the incoming message and sends the headers as is in the outgoing message to the SIP UA.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>

Parameter	Description
'Use Initial Incoming INVITE for re-INVITE' use-initial-incoming-invite-for-reinvite [KeepInitialIncomingINVITE]	<p>Enables the device to use the initial (first) incoming SIP INVITE message of the dialog session, for creating a re-INVITE message. For example, if the device receives a REFER message (call transfer), it terminates the message locally, creates a re-INVITE based on the initial INVITE, and then sends it to the peer side. This may be useful if the initial incoming SIP INVITE includes customized headers or bodies that you want to preserve for the outgoing INVITE.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the SBC application.</li> <li>■ This parameter doesn't apply to outgoing re-INVITE messages that are initiated by the SIP session-expires mechanism.</li> <li>■ Enabling this parameter may reduce the device's performance by up to 10%.</li> </ul>
'Handle X-Detect' sbc-handle-xdetect [SBCHandleXDetect]	<p>Enables the detection and notification of events (AMD, CPT, and fax), using the X-Detect SIP header.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> (default)</li> <li>■ [1] <b>Yes</b></li> </ul> <p>For more information, see <a href="#">Event Detection and Notification using X-Detect Header</a> on page 297.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
'ISUP Body Handling' sbc-isup-body-handling [SBCISUPBodyHandling]	<p>Defines the handling of ISUP data for interworking SIP and SIP-I endpoints.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Transparent</b> = (Default) ISUP data is passed transparently (as is) between endpoints (SIP-I to SIP-I calls).</li> <li>■ [1] <b>Remove</b> = ISUP body is removed from INVITE messages.</li> <li>■ [2] <b>Create</b> = ISUP body is added to outgoing INVITE messages.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [3] <b>Create If Not Exists</b> = ISUP body is added to outgoing INVITE messages if it doesn't exist in the incoming leg. If it exists, unknown fields and messages by the device are passed transparently, while known fields can be manipulated using Message Manipulation rules. For known fields, some values that are "reserved for national use" may be changed to default.</li> </ul> <p>For more information on interworking SIP and SIP-I, see <a href="#">Enabling Interworking of SIP and SIP-I Endpoints</a> on page 1152.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
'ISUP Variant' sbc-isup-variant [SBCISUPVariant]	<p>Defines the ISUP variant for interworking SIP and SIP-I endpoints.</p> <ul style="list-style-type: none"> <li>■ [0] <b>itu92</b> = (Default) ITU 92 variant</li> <li>■ [1] <b>Spirou</b> = SPIROU (ISUP France)</li> </ul> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
'Max Call Duration' sbc-max-call-duration [SBCMaxCallDuration]	<p>Defines the maximum duration (in minutes) per SBC call that is associated with the IP Profile. If the duration is reached, the device ends the call.</p> <p>The valid range is 0 to 35,791, where 0 means unlimited call duration. The default is the value configured for the global parameter [SBCMaxCallDuration].</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the SBC application.</li> <li>■ You can also configure maximum call duration, using Message Manipulation rules with the call variables <code>Var.Call.Dst.MaxDuration</code> or <code>Var.Call.Src.MaxDuration</code>. For more information, refer to the document <i>SIP Message Manipulation Syntax Reference Guide</i>, by clicking <a href="#">here</a>.</li> </ul>
'Disconnect In-Dialog Subscribe Failure'	<p>Defines if the device disconnects the call if a subscription request (SIP SUBSCRIBE) sent during the call (in-dialog)</p>

Parameter	Description
disconnect-in-dialog-subscribe-failure [DisconnectInDialogSubscribeFailure]	<p>fails. Maintaining the call (by disabling this parameter) may be useful, for example, to preserve active 911 emergency calls even if in-dialog subscription requests fail.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = If an in-dialog SUBSCRIBE request fails, the device maintains the call.</li> <li>■ [1] <b>Enable</b> = (Default) If an in-dialog SUBSCRIBE request fails, the device disconnects the call.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ When enabled, this feature applies to the IP Group (to which the IP Profile is assigned) that initiated the in-dialog subscription request (regardless of whether it's the inbound or outbound leg).</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
'Broken Signaling Connection Mode' disconnect-on-broken-signaling-connection [DisconnectOnBrokenSignalingConnection]	<p>Defines the handling of established calls when the device detects a disconnection in the associated SIP signaling path (socket).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Ignore</b> = (Default) The device maintains the call despite loss in SIP signaling path (and ends the call when signaling ends it by a SIP BYE message). The device will try to re-establish a signaling connection when the next SIP signaling message needs to be sent.</li> <li>■ [1] <b>Disconnect</b> = The device immediately ends the call.</li> <li>■ [2] <b>Reroute</b> = The device immediately ends the call and then searches the IP-to-IP Routing table (see <a href="#">Configuring SBC IP-to-IP Routing Rules</a> on page 1076) for a matching rule. If found, the device sends a new SIP INVITE message to the new destination. You can also configure a main routing rule whose matching characteristics is explicitly for calls that have broken SIP signaling connections. You do this by configuring the 'Call Trigger' parameter in the IP-to-IP Routing table to <b>Broken Connection</b>.</li> <li>■ [3] <b>Reroute with Original SIP Headers</b> = The device immediately ends the call and then searches the IP-</li> </ul>

Parameter	Description
	<p>to-IP Routing table (see <a href="#">Configuring SBC IP-to-IP Routing Rules</a> on page 1076) for a matching rule. If found, the device sends a new SIP INVITE message to the new destination, but with the original SIP headers and non-SDP bodies (XML only of multipart SDP bodies). The SDP body is not copied but re-generated by the device. You can also configure a main routing rule whose matching characteristics is explicitly for calls that have broken SIP signaling connections. You do this by configuring the 'Call Trigger' parameter in the IP-to-IP Routing table to <b>Broken Connection</b>.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only for calls whose SIP signaling is over TCP.</li> <li>■ The optional values <b>Reroute</b> and <b>Reroute with Original SIP Headers</b> are applicable only to the outgoing leg. If you've configured one of these options for the incoming leg, the device handles the call according to the <b>Disconnect</b> option.</li> <li>■ If during a call, the source IP address (from where the packets are received by the device) is changed without notifying the device, the device rejects the packets. To overcome this, configure the parameter to <b>Ignore</b>. With this configuration, the device doesn't detect packets arriving from the original source IP address and switches (after 300 msec) to the packets arriving from the new source IP address.</li> </ul>
<b>SBC Registration</b>	
'User Registration Time' sbc-usr-reg-time [SBCUserRegistrationTime]	<p>Defines the registration time (in seconds) that the device responds to SIP REGISTER requests from users belonging to the SIP UA associated with the IP Profile. The registration time is inserted in the Expires header in the outgoing response sent to the user.</p> <p>The Expires header determines the lifespan of the registration. For example, a value of 3600 means that the registration will timeout in one hour and at that point, the user will not be able to make or receive calls.</p> <p>The valid range is 0 to 2,000,000. The default is 0. If configured to 0, the Expires header's value received in</p>

Parameter	Description
	<p>the user's REGISTER request remains unchanged. If no Expires header is received in the REGISTER message and the parameter is set to 0, the Expires header's value is set to 180 seconds, by default.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The corresponding global parameter is [SBCUserRegistrationTime].</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
<p>'NAT UDP Registration Time'</p> <p>sbc-usr-udp-nat-reg-time</p> <p>[SBCUserBehindUdpNATRegistrationTime]</p>	<p>Defines the registration time (in seconds) that the device includes in register responses, in response to SIP REGISTER requests from users belonging to the SIP UA associated with the IP Profile.</p> <p>The parameter applies only to users that are located behind NAT and whose communication type is UDP. The registration time is inserted in the Expires header in the outgoing response sent to the user.</p> <p>The Expires header determines the lifespan of the registration. For example, a value of 3600 means that the registration will timeout in one hour, unless the user sends a refresh REGISTER before the timeout. Upon timeout, the device removes the user's details from the registration database, and the user will not be able to make or receive calls through the device.</p> <p>The valid value is 0 to 2,000,000. If configured to 0, the Expires header's value received in the user's REGISTER request remains unchanged. By default, no value is defined (-1).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If the parameter is not configured, the registration time is according to the global parameter [SBCUserRegistrationTime] or IP Profile parameter 'User Registration Time'.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
<p>'NAT TCP Registration Time'</p> <p>sbc-usr-tcp-nat-reg-time</p>	<p>Defines the registration time (in seconds) that the device includes in register responses, in response to SIP REGISTER requests from users belonging to the SIP UA associated with the IP Profile.</p>

Parameter	Description
[SBCUserBehindTcpNATRegistrationTime]	<p>The parameter applies only to users that are located behind NAT and whose communication type is TCP. The registration time is inserted in the Expires header in the outgoing response sent to the user.</p> <p>The Expires header determines the lifespan of the registration. For example, a value of 3600 means that the registration will timeout in one hour, unless the user sends a refresh REGISTER before the timeout. Upon timeout, the device removes the user's details from the registration database, and the user will not be able to make or receive calls through the device.</p> <p>The valid value is 0 to 2,000,000. If configured to 0, the Expires header's value received in the user's REGISTER request remains unchanged. By default, no value is defined (-1).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If the parameter is not configured, the registration time is according to the global parameter [SBCUserRegistrationTime] or IP Profile parameter 'User Registration Time'.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
<b>SBC Forward and Transfer</b>	
<p>'Remote REFER Mode'</p> <p>sbc-rmt-refer-behavior</p> <p>[SBCRemoteReferBehavior]</p>	<p>Defines the device's handling of SIP REFER requests for the SIP UA (transferee - call party that is transferred to the transfer target) associated with the IP Profile.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Regular</b> = (Default) SIP Refer-To header value is unchanged and the device forwards the REFER message as is. However, if you configure the 'Remote Replaces Mode' parameter (see below) to any value other than <b>Keep as is</b>, the device may modify the URI of the Refer-To header to reflect the call identifiers of the leg.</li> <li>■ [1] <b>Database URL</b> = SIP Refer-To header value is changed so that the re-routed INVITE is sent through the device: <ul style="list-style-type: none"> <li>a. Before forwarding the REFER request, the device changes the host part to the device's IP address</li> </ul> </li> </ul>

Parameter	Description
	<p>and adds the prefix "T~&amp;R_" to the Contact user part.</p> <ul style="list-style-type: none"> <li><b>b.</b> The incoming INVITE is identified as a REFER-resultant INVITE according to this special prefix.</li> <li><b>c.</b> The device replaces the host part in the Request-URI with the host from the REFER contact. The special prefix remains in the user part for regular classification, manipulation, and routing. The special prefix can also be used for specific routing rules for REFER-resultant INVITES.</li> <li><b>d.</b> The special prefix is removed before the resultant INVITE is sent to the destination (transfer target).</li> </ul> <ul style="list-style-type: none"> <li>■ [2] <b>IP Group Name</b> = Changes the host part in the REFER message to the value that you configured for the 'SIP Group Name' parameter in the IP Groups table (see <a href="#">Configuring IP Groups</a> on page 581).</li> <li>■ [3] <b>Handle Locally</b> = Handles the incoming REFER request itself without forwarding the REFER. The device generates a new INVITE to the alternative destination (transfer target) according to the rules in the IP-to-IP Routing table (the 'Call Trigger' parameter must be set to <b>REFER</b>).</li> <li>■ [4] <b>Local Host</b> = In the REFER message received from the transferor, the device replaces the Refer-To header value (URL) with the IP address of the device or with the 'Local Host Name' parameter value configured for the IP Group (transferee) to where the device forwards the REFER message. This ensures that the transferee sends the re-routed INVITE back to the device which then sends the call to the transfer target.</li> <li>■ [5] <b>Keep URI (user@host)</b> = The device forwards the REFER message without changing the URI (user@host) in the SIP Refer-To header. If you configure the 'Remote Replaces Mode' parameter (see below) to any value other than <b>Keep as is</b>, the device may modify the 'replaces' parameter of the Refer-To header to reflect the call identifiers of the leg. This applies to all types of call transfers (e.g., blind and attendant transfer).</li> </ul>



Parameter	Description
	<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ You can override the parameter's settings using Message Manipulation rules configured with the AudioCodes proprietary SIP header, X-AC-Action. For more information, see <a href="#">Using Proprietary SIP X-AC-Action Header</a> on page 1134.</li> <li>■ The corresponding global parameter is [SBCReferBehavior].</li> <li>■ For MSRP sessions, the <b>Handle Locally</b> option is not applicable. For more information on MSRP sessions, see <a href="#">Configuring Message Session Relay Protocol</a> on page 1141.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
'Remote Replaces Mode' sbc-rmt-replaces-behavior [SBCRemoteReplacesBehavior]	<p>Enables the device to handle incoming INVITEs containing the Replaces header for the SIP UA (which doesn't support the header) associated with the IP Profile. The Replaces header is used to replace an existing SIP dialog with a new dialog such as in call transfer or call pickup.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Standard</b> = (Default) The SIP UA supports INVITE messages containing Replaces headers. The device forwards the INVITE message containing the Replaces header to the SIP UA. The device may change the value of the Replaces header to reflect the call identifiers of the leg.</li> <li>■ [1] <b>Handle Locally</b> = The SIP UA doesn't support INVITE messages containing Replaces headers. The device terminates the received INVITE containing the Replaces header and establishes a new call between the SIP UA and the new call party. It then disconnects the call with the initial call party, by sending it a SIP BYE request.</li> <li>■ [2] <b>Keep as is</b> = The SIP UA supports INVITE messages containing Replaces headers. The device forwards the Replaces header as is in incoming REFER and outgoing INVITE messages from/to the SIP UA (i.e., Replaces header's value is unchanged).</li> </ul> <p>For example, assume that the device establishes a call</p>

Parameter	Description
	<p>between A and B. If B initiates a call transfer to C, the device receives an INVITE with the Replaces header from C. If A supports the Replaces header, the device simply forwards the INVITE as is to A; a new call is established between A and C and the call between A and B is disconnected. However, if A doesn't support the Replaces header, the device uses this feature to terminate the INVITE with Replaces header and handles the transfer for A. The device does this by connecting A to C, and disconnecting the call between A and B, by sending a SIP BYE request to B. Note that if media transcoding is required, the device sends an INVITE to C on behalf of A with a new SDP offer.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
'Play RBT To Transferee' sbc-play-rbt-to-xferee [SBCPlayRBTTToTransferee]	<p>Enables the device to play a ringback tone to the transferred party (transferee) during a blind call transfer, for the SIP UA associated with the IP Profile (which doesn't support such a tone generation during call transfer). The ringback tone indicates to the transferee of the ringing of the transfer target (to where the transferee is being transferred).</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> (Default)</li> <li>■ [1] <b>Yes</b></li> </ul> <p>Typically, the transferee hears a ringback tone only if the transfer target sends it early media. However, if the transferee is put on-hold before being transferred, no ringback tone is heard.</p> <p>When this feature is enabled, the device generates a ringback tone to the transferee during call transfer in the following scenarios:</p> <ul style="list-style-type: none"> <li>■ Transfer target sends a SIP 180 (Ringing) to the device.</li> <li>■ For non-blind transfer, if the call is transferred while the transfer target is ringing and no early media occurs.</li> <li>■ The 'Remote Early Media RTP Behavior' parameter is set to Delayed (used in the Skype for Business environment), and transfer target sends a 183 Session</li> </ul>

Parameter	Description
	<p>Progress with SDP offer. If early media from the transfer target has already been detected, the transferee receives RTP stream from the transfer target. If it has not been detected, the device generates a ringback tone to the transferee and stops the tone generation once RTP has been detected from the transfer target.</p> <p>For any of these scenarios, if the transferee is put on-hold by the transferor, the device retrieves the transferee from hold, sends a re-INVITE if necessary, and then plays the ringback tone.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the device to play the ringback tone, it must be loaded with a Prerecorded Tones (PRT) file. For more information, see <a href="#">Uploading a Prerecorded Tones File</a> on page 1228.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
<p>'Remote 3xx Mode'</p> <p>sbc-rmt-3xx-behavior</p> <p>[SBCRemote3xxBehavior]</p>	<p>Defines the device's handling of SIP 3xx redirect responses for the SIP UA associated with the IP Profile. By default, the device's handling of SIP 3xx responses is to send the Contact header unchanged. However, some SIP entities may support different versions of the SIP 3xx standard while others may not even support SIP 3xx.</p> <p>When enabled, the device handles SIP redirections between different subnets (e.g., between LAN and WAN sides). This is required when the new address provided by the redirector (Redirect sever) may not be reachable by the far-end user (FEU) located in another subnet. For example, a far-end user (FEU) in the WAN sends a SIP request via the device to a Redirect server in the LAN, and the Redirect server replies with a SIP 3xx response to a PBX in the LAN in the Contact header. If the device sends this response as is (i.e., with the original Contact header), the FEU is unable to reach the new destination.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Transparent</b> = (Default) The device forwards the received SIP 3xx response as is, without changing the Contact header (i.e., transparent handling).</li> <li>■ [1] <b>Database URL</b> = The device changes the Contact</li> </ul>

Parameter	Description
	<p>header so that the re-route request is sent through the device. The device changes the URI in the Contact header of the received SIP 3xx response to its own URI and adds a special user prefix ("T~&amp;R_"), which is then sent to the FEU. The FEU then sends a new INVITE to the device, which the device then sends to the correct destination.</p> <ul style="list-style-type: none"> <li>■ [2] <b>Handle Locally</b> = The device handles SIP 3xx responses on behalf of the dialog-initiating UA and retries the request (e.g., INVITE) using one or more alternative URIs included in the 3xx response. The device sends the new request to the alternative destination according to the IP-to-IP Routing table (the 'Call Trigger' field must be set to <b>3xx</b>).</li> <li>■ [3] <b>IP Group Name</b> = If the 'SIP Group Name' parameter of the IP Group of the dialog-initiating UA is configured with a non-empty value, the device changes the host part of the Contact header in the 3xx response to this value, before forwarding the 3xx response to the dialog-initiating UA.</li> <li>■ [4] <b>Local Host</b> = The device changes the host part of the Contact header in the 3xx response before forwarding the 3xx response to the dialog-initiating UA. If the 'Local Host Name' parameter of the IP Group of the dialog-initiating UA is configured with a non-empty value, the device changes the host part of the Contact header to this value. If the 'Local Host Name' is empty, the device changes the host part to the device's IP address (the same IP address used in the SIP Via and Contact headers of messages sent to the IP Group).</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ When the parameter is changed from <b>Database URL</b> to <b>Transparent</b>, new 3xx Contact headers remain unchanged. However, requests with the special prefix continue using the device's database to locate the new destination.</li> <li>■ Optional values <b>IP Group Name</b> and <b>Local Host</b> are applicable only to 3xx responses received due to INVITE messages.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ Only one database entry is supported for the same host, port, and transport combination. For example, the following URLs cannot be distinguished by the device:               <ul style="list-style-type: none"> <li>✓ sip:10.10.10.10:5060;transport=tcp;param=a</li> <li>✓ sip:10.10.10.10:5060;transport=tcp;param=b</li> </ul> </li> <li>■ The database entry expires two hours after the last use.</li> <li>■ The maximum number of destinations (i.e., database entries) is 50.</li> <li>■ The corresponding global parameter is [SBC3xxBehavior].</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
'Send Header for Transfer' header-for-transfer [HeaderForTransfer]	<p>Enables the device to notify a change in the remote party (calling or called) after a call transfer (locally handled by the device).</p> <p>The updated information is provided by adding a Remote-Party-ID header to the outgoing message (INVITE, UPDATE, or 200 OK). As the From header in the SIP dialogs throughout the call transfer process contains the URI of the initial call, the inclusion of the Remote-Party-ID header resolves the problem for identifying the new party.</p> <p>The device also sets the fields in the Remote-Party-ID header to 'party=calling;privacy=off;screen=yes'.</p> <p>However, if a Remote-Party-ID header with 'party=calling' is already present in the incoming request or response, the device only updates the URI. If a Remote-Party-ID header is present in the incoming request or response, but with a different value for the 'party' parameter (e.g. 'party=called'), the device adds an additional Remote-Party-ID header as described above.</p> <ul style="list-style-type: none"> <li>■ [0] <b>None</b> = (Default) The device doesn't add the Remote-Party-ID header (as explained above).</li> <li>■ [1] <b>Remote-Party-ID</b> = The device adds the Remote-Party-ID header (as explained above).</li> </ul> <p><b>Note:</b> The parameter is applicable only to the SBC</p>

Parameter	Description
	application.
<b>SBC Hold</b>	
'Remote Hold Format' remote-hold-Format [SBCRemoteHoldFormat]	<p>Defines the format of the SDP in the SIP re-INVITE (or UPDATE) for call hold that the device sends to the held party.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Transparent</b> = (Default) Device forwards SDP as is.</li> <li>■ [1] <b>Send Only</b> = Device sends SDP with 'a=sendonly'.</li> <li>■ [2] <b>Send Only Zero Ip</b> = Device sends SDP with 'a=sendonly' and 'c=0.0.0.0'.</li> <li>■ [3] <b>Inactive</b> = Device sends SDP with 'a=inactive'.</li> <li>■ [4] <b>Inactive Zero Ip</b> = Device sends SDP with 'a=inactive' and 'c=0.0.0.0'.</li> <li>■ [5] <b>Not Supported</b> = This option can be used when the remote side doesn't support call hold. The device terminates call hold requests received on the leg interfacing with the initiator of the call hold, and replies to this initiator with a SIP 200 OK response. However, call retrieve (resume) requests received from the initiator are forwarded to the remote side. The device can play a held tone to the held party if the 'Play Held Tone' parameter is set to <b>Internal</b>.</li> <li>■ [6] <b>Hold and Retrieve Not Supported</b> = This option can be used when the remote side doesn't support call hold and retrieve (resume). The device terminates call hold and call retrieve requests received on the leg interfacing with the initiator of the call hold/retrieve, and replies to this initiator with a SIP 200 OK response. Therefore, the device doesn't forward call hold and/or retrieve requests to the remote side.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
'Reliable Held Tone Source' reliable-heldtone-source [ReliableHoldToneSource]	<p>Enables the device to consider the received call-hold request (re-INVITE/UPDATE) with SDP containing 'a=sendonly', as genuine.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) Even if the received SDP contains 'a=sendonly', the device plays a held tone to the held</li> </ul>

Parameter	Description
	<p>party. This is useful in cases where the initiator of the call hold doesn't support the generation of held tones.</p> <ul style="list-style-type: none"> <li>■ [1] <b>Yes</b> = If the received SDP contains 'a=sendonly', the device doesn't play a held tone to the held party (and assumes that the initiator of the call hold plays the held tone).</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The device plays a held tone only if the 'Play Held Tone' parameter is set to <b>Internal</b> or <b>External</b>.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
'Play Held Tone' play-held-tone [SBCPlayHeldTone]	<p>Enables the device to play Music-on-Hold (MoH) to call parties that are placed on hold. This is useful if the held party doesn't support the play of a local hold tone, or for IP entities initiating call hold that do not support the generation of hold tones.</p> <ul style="list-style-type: none"> <li>■ [0] No = (Default) The device doesn't play any tone to held call parties.</li> <li>■ [1] Internal = Plays the local default hold tone or a tone defined in the PRT file (if installed).</li> <li>■ [2] External = Plays MoH audio streams that originate from an external media source. For more information, see <a href="#">Configuring SBC MoH from External Media Source</a> on page 1154</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you configure the parameter to <b>Internal</b>, the device plays the tone only if the 'SBC Remote Hold Format' parameter is configured to one of the following: send-only, send only 0.0.0.0, not supported, or transparent (when the incoming SDP is 'sendonly').</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
<b>SBC Fax</b>	
'Fax Rerouting Mode' sbc-fax-rerouting-	<p>Enables the rerouting of incoming SBC calls that are identified as fax calls to a new IP destination.</p>

Parameter	Description
mode [SBCFaxReroutingMode]	<ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Rerouting without delay</b></li> </ul> <p>For more information, see <a href="#">Configuring Rerouting of Calls to Fax Destinations</a> on page 1096.</p> <p><b>Note:</b> Configure the parameter for the IP leg that is interfacing with the fax termination.</p>
<b>Media</b>	
'Broken Connection Mode' disconnect-on-broken-connection [DisconnectOnBrokenConnection]	<p>Defines the handling of calls when RTP or MSRP packets (media) are not received within a timeout.</p> <p>You can configure the timeout for the following call stages:</p> <ul style="list-style-type: none"> <li>■ For RTP: <ul style="list-style-type: none"> <li>✓ During call setup: Configure this timeout using the [NoRTPDetectionTimeout] global parameter.</li> <li>✓ During an established call when packet flow suddenly stops: Configure this timeout using the 'Broken Connection Timeout' global parameter.</li> </ul> </li> <li>■ For MSRP: <ul style="list-style-type: none"> <li>✓ During call setup: Configure this timeout using the 'Timeout to Establish MSRP Connection' global parameter.</li> <li>✓ During an established call when the MSRP socket is closed (no timeout configuration).</li> </ul> </li> </ul> <p>Possible values:</p> <ul style="list-style-type: none"> <li>■ [0] <b>Ignore</b> = The device maintains the call despite no media and ends the call when signaling ends it (i.e., SIP BYE).</li> <li>■ [1] <b>Disconnect</b> = (Default) The device ends the call when the timeout expires.</li> <li>■ [2] <b>Reroute</b> = (SBC application only) The device ends the call and then searches the IP-to-IP Routing table (see <a href="#">Configuring SBC IP-to-IP Routing Rules</a> on page 1076) for a matching rule. If found, the device generates a new INVITE to the new destination. You can also configure a main routing rule whose</li> </ul>



Parameter	Description
	<p>matching characteristics is explicitly for calls that have broken RTP or MSRP connections. You do this by configuring the 'Call Trigger' parameter in the IP-to-IP Routing table to <b>Broken Connection</b>.</p> <ul style="list-style-type: none"> <li>■ [3] <b>Reroute with Original SIP Headers</b> = (SBC application only) The device ends the call and then searches the IP-to-IP Routing table (see <a href="#">Configuring SBC IP-to-IP Routing Rules</a> on page 1076) for a matching rule. If found, the device generates a new INVITE, but with the original SIP headers and non-SDP bodies (XML only of multipart SDP bodies) to the new destination. The SDP body is not copied but re-generated by the device. You can also configure a main routing rule whose matching characteristics is explicitly for calls that have broken RTP or MSRP connections. You do this by configuring the 'Call Trigger' parameter in the IP-to-IP Routing table to <b>Broken Connection</b>.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The optional values <b>Reroute</b> and <b>Reroute with Original SIP Headers</b> are applicable only to the outgoing leg. If you've configured one of these options for the incoming leg, the device handles the call according to the <b>Disconnect</b> option.</li> <li>■ The device can only detect a broken RTP or MSRP connection if silence compression is disabled for the session.</li> <li>■ If during a call, the source IP address (from where the packets are received by the device) is changed without notifying the device, the device rejects the packets. To overcome this, configure the parameter to <b>Ignore</b>. With this configuration, the device doesn't detect packets arriving from the original source IP address and switches (after 300 msec) to the packets arriving from the new source IP address.</li> <li>■ The corresponding global parameter is [DisconnectOnBrokenConnection].</li> </ul>
'No RTP Mode' no-rtsp-mode	Defines the handling of calls when RTP packets (media) are not detected / received within a timeout during early

Parameter	Description
[NoRTPMode]	<p>media or upon call connect (i.e., never was RTP). The timeout is configured by the [NoRTPDetectionTimeout] parameter.</p> <ul style="list-style-type: none"> <li>■ [1] <b>Disconnect</b> = (Default) The device ends the call.</li> <li>■ [2] <b>Reroute</b> = The device ends the call and then searches the IP-to-IP Routing table (see <a href="#">Configuring SBC IP-to-IP Routing Rules</a> on page 1076) for a matching rule. If found, the device generates a new INVITE to the new destination. You can also configure a main routing rule whose matching characteristics is explicitly for calls that have no RTP. To do this, configure the 'Call Trigger' parameter in the IP-to-IP Routing table to <b>Broken Connection</b>.</li> <li>■ [3] <b>Reroute with Original SIP Headers</b> = The device ends the call and then searches the IP-to-IP Routing table (see <a href="#">Configuring SBC IP-to-IP Routing Rules</a> on page 1076) for a matching rule. If found, the device generates a new INVITE, but with the original SIP headers and non-SDP bodies (XML only of multipart SDP bodies) to the new destination. The SDP body is not copied, but re-generated by the device. You can also configure a main routing rule whose matching characteristics is explicitly for calls that have broken RTP connections. This is done by configuring the 'Call Trigger' parameter in the IP-to-IP Routing table to <b>Broken Connection</b>.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The optional values <b>Reroute</b> and <b>Reroute with Original SIP Headers</b> are applicable only to the outgoing leg. If you've configured one of these options for the incoming leg, the device handles the call according to the <b>Disconnect</b> option.</li> <li>■ The parameter is applicable only to the SBC application.</li> <li>■ The device can only detect no RTP if silence compression is disabled for the session.</li> <li>■ The parameter is not applicable to MSRP sessions.</li> <li>■ The corresponding global parameter is [NoRTPMode].</li> </ul>

Parameter	Description
'Media IP Version Preference' media-ip-version-preference [MediaIPVersionPreference]	<p>Defines the preferred RTP media IP addressing version for outgoing SIP calls (according to RFC 4091 and RFC 4092). The RFCs concern Alternative Network Address Types (ANAT) semantics in the SDP to offer groups of network addresses (IPv4 and IPv6) and the IP address version preference to establish the media stream. The IP address is indicated in the "c=" field (Connection) of the SDP.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Only IPv4</b> = (Default) SDP offer includes only IPv4 media IP addresses.</li> <li>■ [1] <b>Only IPv6</b> = SDP offer includes only IPv6 media IP addresses.</li> <li>■ [2] <b>Prefer IPv4</b> = SDP offer includes IPv4 and IPv6 media IP addresses, but the first (preferred) media is IPv4.</li> <li>■ [3] <b>Prefer IPv6</b> = SDP offer includes IPv4 and IPv6 media IP addresses, but the first (preferred) media is IPv6.</li> </ul> <p>To indicate ANAT support, the device uses the SIP Allow header or to enforce ANAT it uses the Require header: Require: sdp-anat</p> <p>In the outgoing SDP, each 'm=' field is associated with an ANAT group. This is done using the 'a=mid:' and 'a=group:ANAT' fields. Each 'm=' field appears under a unique 'a=mid:' number, for example:</p> <pre>a=mid:1 m=audio 63288 RTP/AVP 0 8 18 101 c=IN IP6 3000::290:8fff:fe40:3e21</pre> <p>The 'a=group:ANAT' field shows the 'm=' fields belonging to it, using the number of the 'a=mid:' field. In addition, the ANAT group with the preferred 'm=' fields appears first. For example, the preferred group includes 'm=' fields under 'a=mid:1' and 'a=mid:3':</p> <pre>a=group:ANAT 1 3 a=group:ANAT 2 4</pre> <p>If you configure the parameter to a "prefer" option, the outgoing SDP offer contains two medias which are the same except for the "c=" field. The first media is the preferred address type (and this type is also on the session level "c=" field), while the second media has its</p>

Parameter	Description
	<p>"c=" field with the other address type. Both medias are grouped by ANAT. For example, if the incoming SDP contains two medias, one secured and the other non-secured, the device sends the outgoing SDP with four medias:</p> <ul style="list-style-type: none"> <li>■ Two secured medias grouped in the first ANAT group, one with IPv4 and the other with IPv6. The first is the preferred type.</li> <li>■ Two non-secured medias grouped in the second ANAT group, one with IPv4 and the other with IPv6. The first is the preferred type.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only when the device offers an SDP.</li> <li>■ The IP addressing version is determined according to the first SDP "m=" field.</li> <li>■ The feature is applicable to any type of media (e.g., audio and video) that has an IP address.</li> <li>■ The corresponding global parameter is [MediaIPVersionPreference].</li> </ul>
<p>'RTP Redundancy Depth'</p> <p>rtp-redundancy-depth</p> <p>[RTPRedundancyDepth]</p>	<p>Enables the device to generate RFC 2198 redundant packets. This can be used for packet loss where the missing information (audio) can be reconstructed at the receiver's end from the redundant data that arrives in subsequent packets. This is required, for example, in wireless networks where a high percentage (up to 50%) of packet loss can be experienced.</p> <ul style="list-style-type: none"> <li>■ [0] 0 = (Default) Disable.</li> <li>■ [1] 1 = Enable - previous voice payload packet is added to current packet.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ When enabled, you can configure the payload type, using the [RFC2198PayloadType] parameter.</li> <li>■ For the Gateway application, the RTP redundancy dynamic payload type can be included in the SDP, by using the [EnableRTPRedundancyNegotiation] parameter.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ The corresponding global parameter is [RTPRedundancyDepth].</li> </ul>
<b>Gateway</b> <b>Note:</b> These parameters are applicable only to the Gateway application.	
'Early Media' early-media [EnableEarlyMedia]	<p>Enables the Early Media feature for sending media (e.g., ringing) before the call is established.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b> <ul style="list-style-type: none"> <li>✓ Digital: The device sends a SIP 18x response with SDP, allowing the media stream to be established before the call is answered.</li> </ul> </li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Digital: The inclusion of the SDP in the 18x response depends on the ISDN Progress Indicator (PI). The SDP is sent only if PI is set to 1 or 8 in the received Proceeding, Alerting, or Progress messages. See also the [ProgressIndicator2IP] parameter, which if set to 1 or 8, the device behaves as if it received the ISDN messages with the PI.</li> <li>✓ CAS: See the [ProgressIndicator2IP] parameter.</li> <li>✓ ISDN: Sending a 183 response depends on the ISDN PI. It is sent only if PI is set to 1 or 8 in the received Proceeding or Alerting messages. Sending 183 response also depends on the [ReleaseIP2ISDNCallOnProgressWithCause] parameter, which must be set to any value other than 2.</li> <li>■ See also the [IgnoreAlertAfterEarlyMedia] parameter. The parameter allows, for example, to interwork Alert with PI to SIP 183 with SDP instead of 180 with SDP.</li> <li>■ You can also configure early SIP 183 response immediately upon the receipt of an INVITE, using the [EnableEarly183] parameter.</li> <li>■ The corresponding global parameter is [EnableEarlyMedia].</li> </ul>
'Early 183'	Enables the device to send SIP 183 responses with SDP to

Parameter	Description
<p>enable-early-183</p> <p>[EnableEarly183]</p>	<p>the IP upon receipt of INVITE messages.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b> = By sending the 183 response, the device opens an RTP channel before receiving the "progress" tone from the ISDN side. The device sends RTP packets immediately upon receipt of an ISDN Progress, Alerting with Progress indicator, or Connect message according to the initial negotiation without sending the 183 response again, thereby saving response time and avoiding early media clipping.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ This parameter is applicable only to IP-to-Tel ISDN calls and applies to all calls.</li> <li>■ To enable this feature, set the [EnableEarlyMedia] parameter to [1].</li> <li>■ When the [BChannelNegotiation] parameter is set to Preferred or Any, the [EnableEarly183] parameter is ignored and a SIP 183 is not sent upon receipt of an INVITE. In such a case, you can set the [ProgressIndicator2IP] parameter to [1] (PI = 1) for the device to send a SIP 183 upon receipt of an ISDN Call Proceeding message.</li> <li>■ The corresponding global parameter is [EnableEarly183].</li> </ul>
<p>'Early Answer Timeout'</p> <p>early-answer-timeout</p> <p>[EarlyAnswerTimeout]</p>	<p>Defines the duration (in seconds) that the device waits for an ISDN Connect message from the called party (Tel side), started from when it sends a Setup message. If this timer expires, the call is answered by sending a SIP 200 OK message (to the IP side).</p> <p>The valid range is 0 to 2400. The default is 0 (i.e., disabled).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The corresponding global parameter is [EarlyAnswerTimeout].</li> </ul>
<p>'Profile Preference'</p> <p>ip-preference</p> <p>[IpPreference]</p>	<p>Defines the priority of the IP Profile, where 20 is the highest priority and 1 the lowest priority.</p> <p><b>Note:</b></p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ If an IP Profile and a Tel Profile apply to the same call, the coders and other common parameters of the profile with the highest preference are applied to the call. If the preference of the profiles is identical, the Tel Profile parameters are applied.</li> <li>■ If the coder lists of both an IP Profile and a Tel Profile apply to the same call, only the coders common to both are used. The order of the coders is determined by the preference.</li> </ul>
'Coders Group' coders-group [CodersGroupName]	<p>Assigns a Coder Group, which defines audio coders supported by the SIP UA associated with the IP Profile. The default value is the default Coder Group ("AudioCodersGroups_0").</p> <p>To configure Coder Groups, see <a href="#">Configuring Coders Groups</a> on page 651.</p>
'Play RB Tone to IP' play-rbt-to-ip [PlayRBTone2IP]	<p>Enables the device to play a ringback tone to the IP side for IP-to-Tel calls.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (Default)</li> <li>■ [1] <b>Enable</b> = Plays a ringback tone after a SIP 183 session progress response is sent.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ To enable the device to send a 183/180+SDP responses, set the [EnableEarlyMedia] parameter to 1.</li> <li>■ If the [EnableDigitDelivery] parameter is set to 1, the device doesn't play a ringback tone to IP and doesn't send 183 or 180+SDP responses.</li> <li>■ If the parameter is enabled and [EnableEarlyMedia] is set to 1, the device plays a ringback tone according to the following: <ul style="list-style-type: none"> <li>✓ CAS: The device opens a voice channel, sends a 183+SDP response, and then plays a ringback tone to IP.</li> <li>✓ ISDN: If a Progress or an Alerting message with PI (1 or 8) is received from the ISDN, the device opens a voice channel, sends a 183+SDP or 180+SDP response, but doesn't play a ringback</li> </ul> </li> </ul>

Parameter	Description
	<p>tone to IP. If PI (1 or 8) is received from the ISDN, the device assumes that ringback tone is played by the ISDN switch; otherwise, the device plays a ringback tone to IP after receiving an Alerting message from the ISDN. It sends a 180+SDP response, signaling to the calling party to open a voice channel to hear the played ringback tone.</p> <ul style="list-style-type: none"> <li>■ The corresponding global parameter is [PlayRBTone2IP].</li> </ul>
'Progress Indicator to IP' prog-ind-to-ip [ProgressIndicator2IP]	<p>Defines the Progress Indicator (PI) sent to the IP.</p> <ul style="list-style-type: none"> <li>■ [-1] = (Default) Not configured:               <ul style="list-style-type: none"> <li>✓ Digital ISDN: The PI received in ISDN Proceeding, Progress, and Alerting messages is used, as described in the options below.</li> </ul> </li> <li>■ [0] <b>No PI</b> =               <ul style="list-style-type: none"> <li>✓ Digital: For IP-to-Tel calls, the device sends 180 Ringing response to the IP after receiving an ISDN Alerting, or for CAS after placing a call to the PBX/PSTN.</li> </ul> </li> <li>■ [1] <b>PI = 1</b>:               <ul style="list-style-type: none"> <li>✓ Digital: For IP-to-Tel calls, if the parameter EnableEarlyMedia is set to 1, the device sends 180 Ringing with SDP in response to an ISDN Alerting or it sends a 183 Session Progress message with SDP in response to only the first received ISDN Proceeding or Progress message after a call is placed to PBX/PSTN over the trunk.</li> </ul> </li> <li>■ [8] <b>PI = 8: same as PI = 1.</b></li> </ul> <p><b>Note:</b> The corresponding global parameter is [ProgressIndicator2IP].</p>
'Hold' enable-hold [EnableHold]	<p>Digital: Enables the interworking of the Hold/Retrieve supplementary service from ISDN to SIP .</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b></li> <li>■ [1] <b>Enable</b> (default)</li> </ul> <p><b>Note:</b></p>



Parameter	Description
	<ul style="list-style-type: none"> <li>Digital interfaces: To interwork the Hold/Retrieve supplementary service from SIP to ISDN (QSIG and Euro ISDN), set the [EnableHold2ISDN] parameter to 1.</li> <li>The corresponding global parameter is [EnableHold].</li> </ul>
'Add IE In Setup' add-ie-in-setup [AddIEInSetup]	<p>Defines an optional Information Element (IE) data (in hex format) which is added to ISDN Setup messages. For example, to add IE '0x20,0x02,0x00,0xe1', enter the value "200200e1".</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The IE is sent from the Trunk Group IDs configured by the [SendIEonTG] parameter.</li> <li>You can configure different IE data for Trunk Groups by configuring the parameter for different IP Profiles and then assigning the required IP Profile in the IP-to-Tel Routing table (PSTNPrefix).</li> <li>The feature is similar to that of the [EnableISDNTunnelingIP2Tel] parameter. If both parameters are configured, the [EnableISDNTunnelingIP2Tel] parameter takes precedence.</li> <li>The corresponding global parameter is [AddIEInSetup].</li> </ul>
'QSIG Tunneling' enable-qsig-tunneling [EnableQSIGTunneling]	<p>Enables QSIG tunneling-over-SIP for this SIP UA. This is according to IETF Internet-Draft draft-elwell-sipping-qsig-tunnel-03 and ECMA-355 and ETSI TS 102 345.</p> <ul style="list-style-type: none"> <li>[0] <b>Disable</b> (default).</li> <li>[1] <b>Enable</b> = Enables QSIG tunneling from QSIG to SIP, and vice versa. All QSIG messages are sent as raw data in corresponding SIP messages using a dedicated message body.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>QSIG tunneling must be enabled on originating and terminating devices.</li> <li>To enable this function, configure the [ISDNDuplicateQ931BuffMode] parameter to 128 (i.e., duplicate all messages).</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ To define the format of encapsulated QSIG messages, use the [QSIGTunnelingMode] parameter.</li> <li>■ Tunneling according to ECMA-355 is applicable to all ISDN variants (in addition to the QSIG protocol).</li> <li>■ For more information on QSIG tunneling, see <a href="#">QSIG Tunneling</a> on page 894.</li> <li>■ The corresponding global parameter is [EnableQSIGTunneling].</li> </ul>
'Copy Destination Number to Redirect Number' copy-dst-to-redirect-number [CopyDest2RedirectNumber]	<p>Enables the device to copy the called number, received in the SIP INVITE message, to the redirect number in the outgoing Q.931 Setup message, for IP-to-Tel calls. Thus, even if there is no SIP Diversion or History header in the incoming INVITE message, the outgoing Q.931 Setup message will contain a redirect number.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default).</li> <li>■ [1] <b>After Manipulation</b> = Copies the called number after manipulation. The device first performs IP-to-Tel destination phone number manipulation, and only then copies the manipulated called number to the redirect number sent in the Q.931 Setup message to the Tel. Thus, the called and redirect numbers are the same.</li> <li>■ [2] <b>Before Manipulation</b> = Copies the called number before manipulation. The device first copies the original called number to the SIP Diversion header, and then performs IP-to-Tel destination phone number manipulation. Thus, the called (i.e., SIP To header) and redirect (i.e., SIP Diversion header) numbers are different.</li> </ul> <p><b>Note:</b> The corresponding global parameter is [CopyDest2RedirectNumber].</p>
'Number of Calls Limit' call-limit [CallLimit]	<p>Defines the maximum number of concurrent calls (incoming and outgoing) for the SIP UA associated with the IP Profile. If the number of concurrent calls reaches this limit, the device rejects any new incoming and outgoing calls belonging to this IP Profile.</p> <p>The parameter can also be set to the following:</p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [-1] <b>-1</b> = (Default) Unlimited calls.</li> <li>■ [0] <b>0</b> = All calls are rejected.</li> </ul>
<b>Gateway DTMF</b>	
'Is DTMF Used' [IsDTMFUsed]	<p>Enables DTMF signaling.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul>
'First Tx DTMF Option' first-tx-dtmf-option  [FirstTxDtmfOption]	<p>Defines the first preferred transmit DTMF negotiation method.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Not Supported</b> = No negotiation - DTMF digits are sent according to the parameters [DTMFTransportType] and [RFC2833PayloadType] for transmit and receive.</li> <li>■ [1] <b>INFO (Nortel)</b> = Sends DTMF digits according to IETF Internet-Draft draft-choudhuri-sip-info-digit-00.</li> <li>■ [2] <b>NOTIFY</b> = Sends DTMF digits according to IETF Internet-Draft draft-mahy-sipping-signaled-digits-01.</li> <li>■ [3] <b>INFO (Cisco)</b> = Sends DTMF digits according to the Cisco format.</li> <li>■ [4] <b>RFC 2833</b> = (Default) The device: <ul style="list-style-type: none"> <li>✓ negotiates RFC 2833 payload type using local and remote SDPs.</li> <li>✓ sends DTMF packets using RFC 2833 payload type according to the payload type in the received SDP.</li> <li>✓ expects to receive RFC 2833 packets with the same payload type as configured by the parameter [RFC2833PayloadType].</li> <li>✓ removes DTMF digits in transparent mode (as part of the voice stream).</li> </ul> </li> <li>■ [5] <b>INFO (Korea)</b> = Sends DTMF digits according to the Korea Telecom format.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ When out-of-band DTMF transfer is used ([1], [2], [3], or [5]), the [DTMFTransportType] parameter is</li> </ul>

Parameter	Description
	<p>automatically set to 0 (DTMF digits are removed from the RTP stream).</p> <ul style="list-style-type: none"> <li>■ If an ISDN phone user presses digits (e.g., for interactive voice response / IVR applications such as retrieving voice mail messages), ISDN Information messages received by the device for each digit are sent in the voice channel to the IP network as DTMF signals, according to the settings of the parameter.</li> <li>■ The corresponding global parameter is [FirstTxDTMFOption].</li> </ul>
'Second Tx DTMF Option' second-tx-dtmf-option [SecondTxDtmfOption]	<p>Defines the second preferred transmit DTMF negotiation method. For a description of the parameter, see the IP Profile's 'First Tx DTMF Option' parameter.</p> <p><b>Note:</b> The corresponding global parameter is [SecondTxDTMFOption].</p>
'Rx DTMF Option' rx-dtmf-option [RxDTMFOption]	<p>Enables the device to declare the RFC 2833 'telephony-event' parameter in the SDP.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Not Supported</b></li> <li>■ [3] <b>Supported</b> (default)</li> </ul> <p>The device is always receptive to RFC 2833 DTMF relay packets. Thus, it is always correct to include the 'telephony-event' parameter by default in the SDP. However, some devices use the absence of the 'telephony-event' in the SDP to decide to send DTMF digits in-band using G.711 coder. If this is the case, set the parameter to 0.</p> <p><b>Note:</b> The corresponding global parameter is [RxDTMFOption].</p>
<b>Gateway Fax and Modem</b>	
'Fax Signaling Method' fax-sig-method [IsFaxUsed]	<p>Defines the SIP signaling method for establishing and transmitting a fax session when the device detects a fax.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No Fax</b> = (Default) No fax negotiation using SIP signaling. The fax transport method is according to the [FaxTransportMode] parameter</li> <li>■ [1] <b>T.38 Relay</b> = Initiates T.38 fax relay.</li> <li>■ [2] <b>G.711 Transport</b> = Initiates fax/modem using the</li> </ul>

Parameter	Description
	<p>coder G.711 A-law/Mu-law with adaptations (see note below).</p> <ul style="list-style-type: none"> <li>■ [3] <b>Fax Fallback</b> = Initiates T.38 fax relay. If the T.38 negotiation fails, the device re-initiates a fax session using the coder G.711 A-law/Mu-law with adaptations (see the Note below).</li> <li>■ [4] <b>G.711 Reject T.38</b> = Initiates fax/modem using the coder G.711 A-law/Mu-law with adaptations (see Note below), but if the incoming media is of type image ('m=image'), the device rejects the re-INVITE message for T.38.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Fax adaptations (for options 2 and 3): <ul style="list-style-type: none"> <li>✓ Echo Celler = On</li> <li>✓ Silence Compression = Off</li> <li>✓ Echo Celler Non-Linear Processor Mode = Off</li> <li>✓ Dynamic Jitter Buffer Minimum Delay = 40</li> <li>✓ Dynamic Jitter Buffer Optimization Factor = 13</li> </ul> </li> <li>■ If the device initiates a fax session using G.711 (option 2 or 3), a 'gpmid' attribute is added to the SDP in the following format: <ul style="list-style-type: none"> <li>✓ For A-law: 'a=gpmid:8 vbd=yes;ecan=on'</li> <li>✓ For Mu-law: 'a=gpmid:0 vbd=yes;ecan=on'</li> </ul> </li> <li>■ When the parameter is set to 1, 2, or 3, the parameter [FaxTransportMode] is ignored.</li> <li>■ When the parameter is set to 0, T.38 might still be used without the control protocol's involvement. To completely disable T.38, set [FaxTransportMode] to a value other than 1.</li> <li>■ For more information on fax transport methods, see <a href="#">Fax and Modem Transport Modes</a> on page 275.</li> <li>■ The corresponding global parameter is [IsFaxUsed].</li> </ul>
'CNG Detector Mode' cng-mode [CNGmode]	Enables the detection of the fax calling tone (CNG) and defines the detection method.

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) The originating fax doesn't detect CNG; the device passes the CNG signal transparently to the remote side.</li> <li>■ [1] <b>Relay</b> = The originating fax detects CNG. The device sends CNG packets to the remote side according to T.38 (if IsFaxUsed is set to 1) and the fax session is started. A SIP Re-INVITE message is not sent and the fax session starts by the terminating fax. This option is useful, for example, when the originating fax is located behind a firewall that blocks incoming T.38 packets on ports that have not yet received T.38 packets from the internal network (i.e., originating fax). To also send a Re-INVITE message upon detection of a fax CNG tone in this mode, set the parameter FaxCNGMode to 1 or 2.</li> <li>■ [2] <b>Event Only</b> = The originating fax detects CNG and a fax session is started by the originating fax, using the Re-INVITE message. Typically, T.38 fax session starts when the preamble signal is detected by the answering fax. Some SIP devices do not support the detection of this fax signal on the answering fax and thus, in these cases, it is possible to configure the device to start the T.38 fax session when the CNG tone is detected by the originating fax. However, this mode is not recommended.</li> </ul> <p><b>Note:</b> The corresponding global parameter is [CNGDetectorMode].</p>
'Vxx Modem Transport Type' vxx-transport-type [VxxTransportType]	<p>Defines the modem transport type.</p> <ul style="list-style-type: none"> <li>■ [-1] = (Not Configured) The settings of the global parameters are used: <ul style="list-style-type: none"> <li>✓ V21ModemTransportType</li> <li>✓ V22ModemTransportType</li> <li>✓ V23ModemTransportType</li> <li>✓ V32ModemTransportType</li> <li>✓ V34ModemTransportType</li> </ul> </li> <li>■ [0] <b>Disable</b> = Transparent.</li> <li>■ [2] <b>Enable Bypass</b> (Default)</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [3] <b>Events Only</b> = Transparent with Events.</li> </ul> <p>For a detailed description of the parameter per modem type, see the relevant global parameter (listed above).</p>
'NSE Mode' nse-mode [NSEMode]	<p>Enables Cisco's compatible fax and modem bypass mode, Named Signaling Event (NSE) packets.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p>In NSE bypass mode, the device starts using G.711 A-Law (default) or G.711Mu-Law according to the [FaxModemBypassCoderType] parameter settings. The payload type of these G.711 coders is standard (8 for G.711 A-Law; 0 for G.711Mu-Law). The [FaxBypassPayloadType] and [ModemBypassPayloadType] parameters that configure the payload type for the "old" bypass mode are not used with NSE Bypass. The bypass packet interval is configured by the [FaxModemBypassBasicRtpPacketInterval] parameter.</p> <p>The SDP contains the following line:</p> <pre>a=rtpmap:100 X-NSE/8000</pre> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ When enabled, the following conditions must also be met:               <ul style="list-style-type: none"> <li>✓ The Cisco gateway must include the following definition: 'modem passthrough nse payload-type 100 codec g711alaw'.</li> <li>✓ Configure the modem transport type to Bypass mode ([VxxModemTransportType] is 2) for all modems.</li> <li>✓ Configure the [NSEPayloadType] parameter to 100.</li> </ul> </li> <li>■ The corresponding global parameter is [NSEMode].</li> </ul>
<b>Answer Machine Detection</b>	
'AMD Mode' amd-mode	<p>Enables the device to disconnect an IP-to-Tel call upon detection of an answering machine on the Tel side.</p>

Parameter	Description
[AmdMode]	<ul style="list-style-type: none"> <li>■ [0] <b>Don't Disconnect</b> = (Default) Device doesn't disconnect call upon detection of an answering machine.</li> <li>■ [1] <b>Disconnect on AMD</b> = Device disconnects call upon detection of an answering machine. It disconnects the call only after receipt of an ISDN Connect from the Tel side. In such a scenario, the device sends a SIP BYE message upon AMD.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Gateway application (digital interfaces).</li> <li>■ When configured to <b>Disconnect on AMD</b>, the feature can only function if you configure the [EnableEarlyAMD] parameter to any value other than [1].</li> <li>■ This feature doesn't need the receipt of the SIP X-Detect header in the incoming INVITE to activate the AMD.</li> <li>■ The corresponding global parameter is [AMDmode].</li> </ul>
'AMD Sensitivity Parameter Suite' amd-sensitivity-parameter-suite [AMDSensitivityParameterSuite]	<p>Defines the AMD Parameter Suite to use for the Answering Machine Detection (AMD) feature.</p> <ul style="list-style-type: none"> <li>■ [0] <b>0</b> = (Default) Parameter Suite 0 based on North American English with standard detection sensitivity resolution (8 sensitivity levels, from 0 to 7). This AMD Parameter Suite is provided by the AMD Sensitivity file, which is shipped pre-installed on the device.</li> <li>■ [1] <b>1</b> = Parameter Suite based 1 on North American English with high detection sensitivity resolution (16 sensitivity levels, from 0 to 15). This AMD Parameter Suite is provided by the AMD Sensitivity file, which is shipped pre-installed on the device.</li> <li>■ [2-7] <b>2 to 7</b> = Optional Parameter Suites that you can create based on any language (16 sensitivity levels, from 0 to 15). This requires a customized AMD Sensitivity file that needs to be installed on the device. For more information, contact the sales representative of your purchased device.</li> </ul> <p><b>Note:</b></p>



Parameter	Description
	<ul style="list-style-type: none"> <li>■ To configure the detection sensitivity level, use the 'AMD Sensitivity Level' parameter.</li> <li>■ For more information on the AMD feature, see <a href="#">Answering Machine Detection (AMD)</a> on page 304.</li> <li>■ The corresponding global parameter is [AMDSensitivityParameterSuite].</li> </ul>
'AMD Sensitivity Level' amd-sensitivity-level [AMDSensitivityLevel]	<p>Defines the AMD sensitivity level, of the selected AMD Parameter Suite, for detecting an answering machine versus a live call (configured by the 'AMD Sensitivity Parameter Suite' parameter, above).</p> <ul style="list-style-type: none"> <li>■ For Parameter Suite 0: The valid range is 0 to 7 (default is 0). The higher the value, the better the detection for live calls over answering machines. In other words, 0 is best detection of an answering machine; 7 is best detection of a live call.</li> <li>■ For any Parameter Suite other than 0, the valid range is 0 to 15 (default is 8). The higher the value, the better the detection for live calls over answering machines. In other words, 0 is best detection of an answering machine; 15 is best detection of a live call.</li> </ul> <p><b>Note:</b> The corresponding global parameter is [AMDSensitivityLevel].</p>
'AMD Max Greeting Time' amd-max-greeting-time [AMDMaxGreetingTime]	<p>Defines the maximum duration (in 5-msec units) that the device can take to detect a greeting message. The valid range value is 0 to 51132767. The default is 300.</p> <p><b>Note:</b> The corresponding global parameter is [AMDMaxGreetingTime].</p>
'AMD Max Post Silence Greeting Time' amd-max-post-silence-greeting-time [AMDMaxPostSilenceGreetingTime]	<p>Defines the maximum duration (in 5-msec units) of silence from after the greeting time is over, configured by [AMDMaxGreetingTime], until the device's AMD decision. The valid value is 0 to 32767. The default is 400.</p> <p><b>Note:</b> The corresponding global parameter is [AMDMaxPostGreetingSilenceTime].</p>
<b>Local Tones</b>	

Parameter	Description
'Local Ringback Tone Index' local-ringback-tone-index [LocalRingbackTone]	<p>Defines the ringback tone that you want to play from the PRT file.</p> <p>To associate a user-defined tone, configure the parameter with the tone's index number (1-80) as appears in the PRT file. By default (value of -1), the device plays the default ringback tone.</p> <p>To play user-defined tones, you need to record your tones and then install them on the device using a loadable Prerecorded Tones (PRT) file, which is created using AudioCodes DConvert utility. When you create the PRT file, each recorded tone file must be added to the PRT file with the tone type "acUserDefineTone&lt;Index&gt;". When you want to specify the ringback tone for this parameter, use the index number. For more information, see <a href="#">Uploading a Prerecorded Tones File</a> on page 1228.</p>
'Local Held Tone Index' local-held-tone-index [LocalHeldTone]	<p>Defines the held tone that you want to play from the PRT file.</p> <p>To associate a user-defined tone, configure the parameter with the tone's index number (1-80) as appears in the PRT file. By default (value of -1), the device plays the default held tone.</p> <p>To play user-defined tones, you need to record your tones and then install them on the device using a loadable Prerecorded Tones (PRT) file, which is created using AudioCodes DConvert utility. When you create the PRT file, each recorded tone file must be added to the PRT file with the tone type "acUserDefineTone&lt;Index&gt;". When you want to specify the held tone for this parameter, use the index number. For more information, see <a href="#">Uploading a Prerecorded Tones File</a> on page 1228.</p>

## Configuring Tel Profile

The Tel Profiles table lets you configure up to 9 *Tel Profiles*. A Tel Profile is a set of parameters with specific settings which can be assigned to specific calls. The Tel Profiles table includes a wide range of parameters for configuring the Tel Profile. Each of these parameters has a corresponding "global" parameter, which when configured applies to all calls. The main difference, if any, between the Tel Profile parameters and their corresponding global parameters are their default values.

Tel Profiles provide high-level adaptation when the device interworks between different equipment and protocols (at both the Tel and IP sides), each of which may require different

handling by the device. For example, if specific channels require the use of the G.711 coder, you can configure a Tel Profile with this coder and assign it to these channels.

To use your Tel Profile for specific calls, you need to assign it to specific channels (trunks or endpoints) in the Trunk Groups table (see [Configuring Trunk Groups](#) on page 903).

The following procedure describes how to configure Tel Profiles through the Web interface. You can also configure it through ini file [TelProfile] or CLI (`configure voip > coders-and-profiles tel-profile`).

➤ **To configure a Tel Profile:**

1. Open the Tel Profiles table (**Setup** menu > **Signaling & Media** tab > **Coders & Profiles** folder > **Tel Profiles**).
2. Click **New**; the following dialog box appears:

3. Configure a Tel Profile according to the parameters described in the table below. For a description of each parameter, refer to the corresponding "global" parameter.
4. Click **Apply**.

**Table 19-7: Tel Profile Table Parameter Descriptions**

Parameter	Description
<b>General</b>	
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' profile-name [ProfileName]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 40 characters. <b>Note:</b> <ul style="list-style-type: none"> <li>■ Configure each row with a unique name.</li> <li>■ The parameter value can't contain a forward slash</li> </ul>

Parameter	Description
	<p>(/).</p> <ul style="list-style-type: none"> <li>The parameter value can't be configured with the character string "any" (upper or lower case).</li> </ul>
Signaling	
'Profile Preference' tel-preference [TelPreference]	<p>Defines the priority of the Tel Profile, where <b>1</b> is the lowest priority and <b>20</b> the highest priority.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>If both the IP Profile and Tel Profile apply to the same call, the coders and common parameters of the Preferred profile are applied to the call.</li> <li>If the Preference of the Tel Profile and IP Profile are identical, the Tel Profile parameters are applied.</li> <li>If the coder lists of both the IP Profile and Tel Profile apply to the same call, only the coders common to both are used. The order of the coders is determined by the preference.</li> </ul>
'Fax Signaling Method' fax-sig-method [IsFaxUsed]	<p>Defines the SIP signaling method for establishing and transmitting a fax session when the device detects a fax.</p> <ul style="list-style-type: none"> <li>[0] <b>No Fax</b> = (Default) No fax negotiation using SIP signaling. The fax transport method is according to the FaxTransportMode parameter.</li> <li>[1] <b>T.38 Relay</b> = Initiates T.38 fax relay.</li> <li>[2] <b>G.711 Transport</b> = Initiates fax/modem using the coder G.711 A-law/Mu-law with adaptations (see Note below).</li> <li>[3] <b>Fax Fallback</b> = Initiates T.38 fax relay. If the T.38 negotiation fails, the device re-initiates a fax session using the coder G.711 A-law/Mu-law with adaptations (see the Note below).</li> <li>[4] <b>G.711 Reject T.38</b> = Initiates fax/modem using the coder G.711 A-law/Mu-law with adaptations (see Note below), but if the incoming media is of type IMAGE, the device rejects the re-INVITE message for T.38.</li> </ul> <p><b>Note:</b></p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ Fax adaptations (for options 2 and 3):               <ul style="list-style-type: none"> <li>✓ Echo Celler = On</li> <li>✓ Silence Compression = Off</li> <li>✓ Echo Celler Non-Linear Processor Mode = Off</li> <li>✓ Dynamic Jitter Buffer Minimum Delay = 40</li> <li>✓ Dynamic Jitter Buffer Optimization Factor = 13</li> </ul> </li> <li>■ If the device initiates a fax session using G.711 (option 2 or 3), a 'gpmid' attribute is added to the SDP in the following format:               <ul style="list-style-type: none"> <li>✓ For A-law: 'a=gpmid:8 vbd=yes;ecan=on'</li> <li>✓ For Mu-law: 'a=gpmid:0 vbd=yes;ecan=on'</li> </ul> </li> <li>■ When the parameter is set to 1, 2, or 3, the parameter FaxTransportMode is ignored.</li> <li>■ When the parameter is set to 0, T.38 might still be used without the control protocol's involvement. To completely disable T.38, set FaxTransportMode to a value other than 1.</li> <li>■ For more information on fax transport methods, see <a href="#">Fax and Modem Transport Modes</a> on page 275.</li> <li>■ The corresponding global parameter is [IsFaxUsed].</li> </ul>
'Enable Digit Delivery' digit-delivery [EnableDigitDelivery]	<p>Enables the Digit Delivery feature, which sends DTMF digits of the called number to the phone line (device'sdigital B-channel) after the call is answered for IP-to-Tel calls.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p>Digital interfaces: If the called number in IP-to-Tel call includes the characters 'w' or 'p', the device places a call with the first part of the called number (before 'w' or 'p') and plays DTMF digits after the call is answered. If the character 'w' is used, the device waits for detection of a dial tone before it starts playing DTMF digits. For example, if the called number is '1007766p100', the device places a call with 1007766</p>

Parameter	Description
	<p>as the destination number, then after the call is answered it waits 1.5 seconds ('p') and plays the rest of the number (100) as DTMF digits. Additional examples: 1664wpp102, 66644ppp503, and 7774w100pp200.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The corresponding global parameter is [EnableDigitDelivery].</li> </ul>
'Dial Plan Index' dial-plan-index [DialPlanIndex]	<p>Defines the Dial Plan index to use in the external Dial Plan file.</p> <p><b>Note:</b> The corresponding global parameter is [DialPlanIndex].</p>
'Digital Cut Through' digital-cut-through [DigitalCutThrough]	<p>Enables PSTN CAS channels/endpoints to receive incoming IP calls even if the B-channels are in off-hook state.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b> = When enabled, the feature operates as follows:               <ol style="list-style-type: none"> <li>A Tel-to-IP call is established (connected) by the device for a B-channel.</li> <li>The device receives a SIP BYE (i.e., IP side ends the call) and plays a reorder tone to the PSTN side for the duration configured by the CutThroughTimeForReOrderTone parameter. The device releases the call towards the IP side (sends a SIP 200 OK).</li> <li>The PSTN side, for whatever reason, remains off-hook.</li> <li>If a new IP call is received for this B-channel after the reorder tone has ended, the device “cuts through” the channel and connects the call immediately (despite the B-channel being in physical off-hook state) without playing a ring tone. If an IP call is received while the reorder tone is played, the device rejects the call.</li> </ol> </li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If the parameter is disabled and the PSTN side</li> </ul>

Parameter	Description
	<p>remains in off-hook state after the IP call ends the call, the device releases the call after 60 seconds.</p> <ul style="list-style-type: none"> <li>■ A special CAS table can be used to report call status events (Active/Idle) to the PSTN side during Cut Through mode (see <a href="#">Configuring CAS State Machines</a> on page 880).</li> <li>■ The corresponding global parameter is [DigitalCutThrough].</li> </ul>
'Call Priority Mode' call-priority-mode [CallPriorityMode]	<p>Defines call priority handling.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default).</li> <li>■ [1] <b>MLPP</b> = Enables MLPP Priority Call handling. MLPP prioritizes call handling whereby the relative importance of various kinds of communications is strictly defined, allowing higher precedence communication at the expense of lower precedence communications. Higher priority calls override less priority calls when, for example, congestion occurs in a network.</li> <li>■ [2] <b>Emergency</b> = Enables Preemption of IP-to-Tel E911 emergency calls. If the device receives an E911 call and there are unavailable channels to receive the call, the device terminates one of the channel calls and sends the E911 call to that channel. The preemption is done only on a channel belonging to the same Trunk Group for which the E911 call was initially destined and if the channel select mode, configured by the [ChannelSelectMode] parameter, is set to a value other than <b>By Dest Phone Number</b> (0).</li> </ul> <p>Preemption is done only if the device identifies the incoming IP-to-Tel call as an emergency call. The device identifies emergency calls by one of the following:</p> <ul style="list-style-type: none"> <li>✓ The destination number of the IP call matches one of the numbers configured by the [EmergencyNumbers] parameter. (For E911, you must configure the parameter to "911".)</li> <li>✓ The incoming SIP INVITE message contains the</li> </ul>

Parameter	Description
	<p>“emergency” value in the Priority header.</p> <ul style="list-style-type: none"> <li>✓ The value (URI) of the SIP Alert-Info header in the incoming INVITE message is the same as the value configured for the [EmergencyCallAlertInfoUri] parameter.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For more information, see <a href="#">Pre-empting Existing Calls for E911 IP-to-Tel Calls</a> on page 1001.</li> <li>■ The corresponding global parameter is [CallPriorityMode].</li> </ul>
<b>Behavior</b>	
<p>'Disconnect Call on Detection of Busy Tone'</p> <p>disconnect-on-busy-tone</p> <p>[DisconnectOnBusyTone]</p>	<p>Enables the device to disconnect the call upon detection of a busy or reorder (fast busy) tone.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b></li> <li>■ [1] <b>Enable</b> (default)</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to CAS.</li> <li>■ The corresponding global parameter is [DisconnectOnBusyTone].</li> </ul>
<p>'Time For Reorder Tone'</p> <p>time-for-reorder-tone</p> <p>[TimeForReorderTone]</p>	<p>Defines the duration (in seconds) that the device plays a busy or reorder tone before releasing the line. The valid range is 0 to 254. The default is 10 seconds for digital interfaces. Note that the Web interface denotes the default value as "255".</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The selected busy or reorder tone is according to the SIP release cause code received from IP.</li> <li>■ The parameter is also applicable to CAS.</li> <li>■ The parameter is applicable to ISDN when the [PlayBusyTone2ISDN] parameter is set to 2.</li> <li>■ The corresponding global parameter is [TimeForReorderTone].</li> </ul>
'Enable Voice Mail Delay'	Enables and disables voice mail services.



Parameter	Description
enable-voice-mail-delay [EnableVoiceMailDelay]	<ul style="list-style-type: none"> <li>■ [0] <b>Disable</b></li> <li>■ [1] <b>Enable</b> (default)</li> </ul> <p>The parameter is useful if you want to disable voice mail services per Trunk Group to eliminate the phenomenon of call delay on Trunks that do not implement voice mail when voice mail is configured using the global parameter, VoiceMailInterface.</p>
'Swap Tel To IP Phone Numbers' swap-teltoip-phone-numbers [SwapTelToIpPhoneNumbers]	<p>Enables the device to swap the calling and called numbers received from the Tel side (for Tel-to-IP calls). The SIP INVITE message contains the swapped numbers.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p><b>Note:</b> The corresponding global parameter is [SwapTEI2IPCalled&amp;CallingNumbers].</p>
Voice	
'DTMF Volume' dtmf-volume [DtmfVolume]	<p>Defines the DTMF gain control value (in decibels) to the Tel side.</p> <p>The valid range is -31 to 0 dB. The default is -11 dB.</p> <p><b>Note:</b> The corresponding global parameter is [DTMFVolume].</p>
'Input Gain' input-gain [InputGain]	<p>Defines the pulse-code modulation (PCM) input (received) gain control level (in decibels), which is the level of the received signal for Tel-to-IP calls.</p> <p>The valid range is -32 to 31 dB. The default is 0 dB.</p> <p><b>Note:</b> The corresponding global parameter is [InputGain].</p>
'Voice Volume' voice-volume [VoiceVolume]	<p>Defines the voice gain control (in decibels), which is the level of the transmitted signal for IP-to-Tel calls.</p> <p>The valid range is -32 to 31 dB. The default is 0 dB.</p> <p><b>Note:</b> The corresponding global parameter is [VoiceVolume].</p>
'Enable AGC' enable-agc [EnableAGC]	<p>Enables the Automatic Gain Control (AGC) feature. The AGC feature automatically adjusts the level of the received signal to maintain a steady (configurable)</p>

Parameter	Description
	<p>volume level.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For more information on AGC, see <a href="#">Automatic Gain Control (AGC)</a> on page 311.</li> <li>■ The corresponding global parameter is [EnableAGC].</li> </ul>
IP Settings	
<p>'Coders Group'</p> <p>coders-group</p> <p>[CodersGroupName]</p>	<p>Assigns a Coder Group, which defines audio (voice) coders that can be used for the endpoints associated with the Tel Profile.</p> <p>To configure Coders Groups, see <a href="#">Configuring Coders Groups</a> on page 651.</p>
<p>'RTP IP DiffServ'</p> <p>rtp-ip-diffserv</p> <p>[IPDiffServ]</p>	<p>Defines the DiffServ value for Premium Media class of service (CoS) content.</p> <p>The valid range is 0 to 63. The default is 46.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For more information on DiffServ, see <a href="#">Configuring Class-of-Service QoS</a> on page 190.</li> <li>■ The corresponding global parameter is [PremiumServiceClassMediaDiffServ].</li> </ul>
<p>'Signaling DiffServ'</p> <p>signaling-diffserv</p> <p>[SigIPDiffServ]</p>	<p>Defines the DiffServ value for Premium Control CoS content (Call Control applications).</p> <p>The valid range is 0 to 63. The default is 40.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For more information on DiffServ, see <a href="#">Configuring Class-of-Service QoS</a> on page 190.</li> <li>■ The corresponding global parameter is [PremiumServiceClassControlDiffServ].</li> </ul>
<p>'Enable Early Media'</p> <p>early-media</p> <p>[EnableEarlyMedia]</p>	<p>Enables the Early Media feature, which sends media (e.g., ringing) before the call is established.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [1] <b>Enable</b> <ul style="list-style-type: none"> <li>✓ The device sends a SIP 18x response with SDP, allowing the media stream to be established before the call is answered.</li> </ul> </li> <li><b>Note:</b></li> <li>■ The inclusion of the SDP in the 18x response depends on the ISDN Progress Indicator (PI). The SDP is sent only if PI is set to 1 or 8 in the received Proceeding, Alerting, or Progress messages. See also the ProgressIndicator2IP parameter, which if set to 1 or 8, the device behaves as if it received the ISDN messages with the PI.</li> <li>✓ CAS: See the ProgressIndicator2IP parameter.</li> <li>✓ ISDN: Sending a 183 response depends on the ISDN PI. It is sent only if PI is set to 1 or 8 in the received Proceeding or Alerting messages. Sending 183 response also depends on the ReleaseIP2ISDNCallOnProgressWithCause parameter, which must be set to any value other than 2.</li> <li>■ See also the IgnoreAlertAfterEarlyMedia parameter. The parameter allows, for example, to interwork Alert with PI to SIP 183 with SDP instead of 180 with SDP.</li> <li>■ You can also configure early SIP 183 response immediately upon the receipt of an INVITE, using the EnableEarly183 parameter.</li> <li>■ The corresponding global parameter is [EnableEarlyMedia].</li> </ul>
'Progress Indicator to IP' prog-ind-to-ip [ProgressIndicator2IP]	<p>Defines the progress indicator (PI) sent to the IP.</p> <ul style="list-style-type: none"> <li>■ [-1] = (Default) Not configured: <ul style="list-style-type: none"> <li>✓ The PI received in ISDN Proceeding, Progress, and Alerting messages is used, as described in the options below.</li> </ul> </li> <li>■ [0] <b>No PI</b> = <ul style="list-style-type: none"> <li>✓ For IP-to-Tel calls, the device sends 180 Ringing response to the IP after receiving an ISDN</li> </ul> </li> </ul>

Parameter	Description
	<p>Alerting, or for CAS after placing a call to the PBX/PSTN.</p> <ul style="list-style-type: none"> <li>■ [1] <b>PI = 1</b> = <ul style="list-style-type: none"> <li>✓ For IP-to-Tel calls, if the parameter EnableEarlyMedia is set to 1, the device sends 180 Ringing with SDP in response to an ISDN Alerting or it sends a 183 Session Progress message with SDP in response to only the first received ISDN Proceeding or Progress message after a call is placed to PBX/PSTN over the trunk.</li> </ul> </li> <li>■ [8] <b>PI = 8</b> = Same as <b>PI = 1</b>.</li> </ul> <p><b>Note:</b> The corresponding global parameter is [ProgressIndicator2IP].</p>
Echo Canceled	
<p>'Echo Canceled'</p> <p>echo-canceller</p> <p>[EnableEC]</p>	<p>Enables the device's Echo Cancellation feature (i.e., echo from voice calls is removed).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b></li> <li>■ [1] <b>Line Echo Canceller</b> (default)</li> </ul> <p>For more information on echo cancellation, see <a href="#">Configuring Echo Cancellation</a> on page 273.</p> <p><b>Note:</b> The corresponding global parameter is [EnableEchoCanceller].</p>
<p>'EC NLP Mode'</p> <p>echo-canceller-nlp-mode</p> <p>[ECNlpMode]</p>	<p>Enables Non-Linear Processing (NLP) mode for echo cancellation.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Adaptive NLP</b> = (Default) NLP adapts according to echo changes</li> <li>■ [1] <b>Disable NLP</b></li> </ul> <p><b>Note:</b> The corresponding global parameter is [ECNLPMode].</p>
Jitter Buffer	
<p>'Dynamic Jitter Buffer Minimum Delay'</p> <p>jitter-buffer-minimum-</p>	<p>Defines the minimum delay (in msec) of the device's dynamic Jitter Buffer.</p> <p>The valid range is 0 to 150. The default delay is 10.</p>

Parameter	Description
delay [JitterBufMinDelay]	For more information on Jitter Buffer, see <a href="#">Configuring the Dynamic Jitter Buffer</a> on page 290. <b>Note:</b> The corresponding global parameter is [DJBufMinDelay].
'Dynamic Jitter Buffer Maximum Delay' jitter-buffer-maximum-delay [JitterBufMaxDelay]	Defines the maximum delay (in msec) for the device's Dynamic Jitter Buffer. The default is 300.
'Dynamic Jitter Buffer Optimization Factor' jitter-buffer-optimization-factor [JitterBufOptFactor]	Defines the Dynamic Jitter Buffer frame error/delay optimization factor. The valid range is 0 to 12. The default factor is 10. For more information on Jitter Buffer, see <a href="#">Configuring the Dynamic Jitter Buffer</a> on page 290. <b>Note:</b> <ul style="list-style-type: none"><li>■ For data (fax and modem) calls, configure the parameter to 12.</li><li>■ The corresponding global parameter is [DJBufOptFactor].</li></ul>

## 20 SIP Definitions

This section describes configuration of various SIP-related functionality.

### Configuring Registration Accounts

The Accounts table lets you configure up to 102 Accounts. An Account defines information for registering and authenticating (digest) Trunk Groups (e.g., PBX) or IP Groups (e.g., IP PBX) with a "serving" IP Group (e.g., ITSP).

The device initiates registration with a "serving" IP Group on behalf of the "served" Trunk Group or IP Group. Therefore, Accounts are typically required when the "served" Trunk Group or IP Group is unable to register or authenticate itself for whatever reason. Registration information includes username, password, host name (AOR), and contact user name (AOR). The device includes this information in the REGISTER message sent to the serving IP Group. Up to 10 Accounts can be configured per "served" Trunk Group or IP Group. A Trunk Group or IP Group can register to more than one IP Group (e.g., multiple ITSPs). This is done by configuring multiple entries in the Accounts table for the same served Trunk Group or IP Group, but with different serving IP Groups, username/password, host name, and contact user values.



You cannot configure more than one Account with the same "served" Trunk Group or IP Group and "serving" IP Group combination. For example, only one Account can be configured with the 'Served IP Group' parameter set to "Users-Boston" and the 'Serving IP Group' parameter set to "ITSP".

Authentication is typically required for INVITE messages sent to the "serving" IP Group. If the device receives a SIP 401 (Unauthorized) in response to a sent INVITE, the device checks for a matching "serving" and "served" entry in the Accounts table. If a matching row exists, the device authenticates the INVITE by providing the corresponding MD5 authentication username and password to the "serving" IP Group.

If the Account is not registered and the device receives a SIP dialog request (e.g., INVITE) from the Served IP Group, the device rejects the dialog and sends the Served IP Group a SIP 400 (Bad Request) response. An Account that is not registered can be due to any of the following reasons:

- You have unregistered the Served IP Group by clicking the **Register** button (discussed later in this section).
- The Serving IP Group has rejected the registration.

However, if the Account is not registered and you have enabled the Registrar Stickiness feature ('Registrar Stickiness' parameter is configured to **Enable**) or dynamic UDP port assignment feature ('UDP Port Assignment' parameter is configured to **Enable**) and the device receives a SIP dialog request (e.g., INVITE) from the Served IP Group, the device rejects the dialog and sends the Served IP Group a SIP 500 (Server Internal Error) response. In this scenario, the Account can be not registered due to any of the reasons listed previously or for the dynamic UDP port

assignment feature, there is no available port for the Account (port used for interfacing with the Serving IP Group).



- Gateway application: If no match is found in the Accounts table for incoming or outgoing calls, the username and password is taken from:
  - ✓ 'UserName' and 'Password' parameters on the Proxy & Registration page
- SBC application: The device uses the username ('Username As Client' parameter) and password ('Password As Client' parameter) that are configured for the Serving IP Group in the IP Groups table, for user registration and authentication, in the scenarios listed below. For this mode of operation, configure the device to authenticate as a client (i.e., 'Authentication Mode' parameter in the IP Groups table for the Serving IP Group is **SBC As Client** or **SBC as Both Client and Server**).
  - ✓ If there is no Account configured for the Served IP Group and Serving IP Group in the Accounts table.
  - ✓ If there is an Account configured for the Served IP Group and Serving IP Group, but without a username and password.
- See also the following optional, related parameters:
  - ✓ [\[configure voip > sip-definition proxy-and-registration > use-rand-user](#) on page 1679] - enables the device to assign a random string to the user part of the SIP Contact header of new Accounts.
  - ✓ [\[configure voip > sip-definition settings > unreg-on-startup](#) on page 1704] - enables the device to unregister and then re-register Accounts upon a device restart.
  - ✓ [\[configure voip > sip-definition proxy-and-registration > reg-sync-mode](#) on page 1698] - enables synchronization of all Accounts (and users in the SBC User Information table - [Configuring SBC User Information Table through Web Interface](#) on page 776) that register to the same proxy server (Serving IP Group). Upon registration failure (timeout or failure response), only the Account (or SBC User Info user) that first detected the failure, continues its attempt at registering (sending REGISTER requests) to the proxy. For more information, see the parameter's description.
- Gateway application: If all trunks belonging to the Trunk Group are down, the device un-registers them. If any trunk belonging to the Trunk Group returns to service, the device registers them again. This ensures, for example, that the Proxy doesn't send SIP INVITE messages to trunks that are out of service.
- Gateway application: If registration with an IP Group fails for all Accounts of a specific Trunk Group that includes all the channels in the Trunk Group, the Trunk Group is set to Out-Of-Service if the [OOSOnRegistrationFail] parameter is set to 1 (see [Configuring Proxy and Registration Parameters](#) on page 765).
- Gateway application: To configure if the device sends a registration request to the Serving Trunk Group (SIP registrar), based on the Trunk Group's status (in-service or out-of-service) for ISDN PRI and CAS, see the [RegisterByTrunkGroupStatus] parameter.

The following procedure describes how to configure Accounts through the Web interface. You can also configure it through ini file [Account] or CLI (`configure voip > sip-definition account`).

➤ **To configure an Account:**

1. Open the Accounts table (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **Accounts**).
2. Click **New**; the following dialog box appears:

The screenshot shows the 'Accounts' dialog box with two tabs: 'GENERAL' and 'CREDENTIALS'. The 'GENERAL' tab is active, displaying various configuration fields. The 'CREDENTIALS' tab is also visible, showing 'User Name' and 'Password' fields.

GENERAL		CREDENTIALS	
Index	1	User Name	
Name		Password	
Served Trunk Group	-1		
Application Type	GW		
Served IP Group	--		
Serving IP Group	--		
Host Name			
Contact User			
Register	No		
Registrar Stickiness	Disable		
Registrar Search Mode	Current Working Server		
Re-Register on Invite Failure	Disable		

3. Configure an account according to the parameters described in the table below.
4. Click **Apply**.

Once you have configured Accounts, you can register or un-register them, as described below:

➤ **To register or un-register an Account:**

1. In the table, select the required Account entry row.
2. From the **Action** drop-down list, choose one of the following commands:
  - **Register** to register the Account.
  - **Un-Register** to un-register the Account.

**Table 20-1: Accounts Table Parameter Descriptions**

Parameter	Description
<b>General</b>	
'Index'	Defines an index for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' account-name [Account_AccountName]	Defines an arbitrary name to easily identify the row. The valid value is a string of up to 20 characters. <b>Note:</b> Configure each row with a unique name.
'Served Trunk Group' served-trunk-group [Account_ServedTrunkGroup]	Defines the Trunk Group that you want to register and/or authenticate.  ■ For Tel-to-IP calls, the served Trunk Group is the



Parameter	Description
	<p>source Trunk Group from where the call originated.</p> <ul style="list-style-type: none"> <li>■ For IP-to-Tel calls, the served Trunk Group is the Trunk Group to where the call is sent.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
'Application Type' application-type [Account_ApplicationType]	<p>Defines the application type:</p> <ul style="list-style-type: none"> <li>■ [0] <b>GW</b> = (Default) Gateway application.</li> <li>■ [2] <b>SBC</b> = SBC application.</li> </ul>
'Served IP Group' served-ip-group-name [Account_ServedIPGroupName]	<p>Defines the IP Group (e.g., IP-PBX) that you want to register and/or authenticate upon its behalf.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the SBC application.</li> <li>■ By default, all IP Groups are displayed.</li> <li>■ You can configure up to 30 Accounts per IP Group.</li> <li>■ The parameter is mandatory.</li> </ul>
'Serving IP Group' serving-ip-group-name [Account_ServingIPGroupName]	<p>Defines the IP Group (<i>Serving IP Group</i>) to where the device sends the SIP REGISTER requests (if enabled) for registration and authentication (of the Served IP Group).</p> <p>For the Gateway application:</p> <ul style="list-style-type: none"> <li>■ Tel-to-IP calls: The serving IP Group is the destination IP Group configured in the Trunk Group Settings table or Tel-to-IP Routing table (see <a href="#">Configuring Tel-to-IP Routing Rules</a> on page 914).</li> <li>■ IP-to-Tel calls: The serving IP Group is the 'Source IP Group ID' configured in the IP-to-Tel Routing table (see <a href="#">Configuring IP-to-Tel Routing Rules</a> on page 928).</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, only IP Groups associated with the SRD to which the Served IP Group is associated are displayed, as well as IP Groups of Shared SRDs.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ (Gateway application only) If the Serving IP Group is associated with Proxy Set #0, you must configure the [IsProxyUsed] parameter to [1].</li> <li>■ The parameter is mandatory.</li> </ul>
'Host Name' host-name [Account_HostName]	<p>Defines the Address of Record (AOR) host name. The host name appears in SIP REGISTER From/To headers as ContactUser@HostName. For a successful registration, the host name is also included in the URI of the INVITE From header.</p> <p>The valid value is a string of up to 49 characters.</p> <p><b>Note:</b> If the parameter is not configured or if registration fails, the 'SIP Group Name' parameter value configured in the IP Groups table is used instead.</p>
'Contact User' contact-user [Account_ContactUser]	<p>Defines the AOR username. This appears in SIP REGISTER From/To headers as ContactUser@HostName, and in INVITE/200 OK Contact headers as ContactUser@&lt;device's IP address&gt;.</p> <p>The valid value is a string of up to 60 characters. By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If the parameter is not configured, the 'Contact User' parameter in the IP Groups table is used instead.</li> <li>■ If registration is disabled for the Account, or registration fails, the user part in the SIP INVITE's Contact header contains the source party number.</li> <li>■ If the source of the message is a registered user or matches a record in the SBC User Information table (see <a href="#">Configuring SBC User Information Table through Web Interface</a> on page 776), it has higher priority than the Account's configuration in deciding the user part in the INVITE's Contact header.</li> </ul>
'Register' register [Account_Register]	<p>Enables registration.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) The device only performs authentication (not registration). Authentication is</li> </ul>

Parameter	Description
	<p>typically done for INVITE messages sent to the "serving" IP Group. If the device receives a SIP 401 (Unauthorized) in response to a sent INVITE, the device checks for a matching "serving" and "served" entry in the table. If a matching row exists, the device authenticates the INVITE by providing the corresponding MD5 authentication username and password to the "serving" IP Group.</p> <ul style="list-style-type: none"> <li>■ [1] <b>Regular</b> = The device performs regular registration. For more information, see <a href="#">Regular Registration Mode</a> on page 763.</li> <li>■ [2] <b>GIN</b> = The device performs registration for legacy PBXs, using Global Identification Number (GIN). For more information, see <a href="#">Single Registration for Multiple Phone Numbers using GIN</a> on page 763.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Gateway application: To enable registration, you also need to configure the 'Registration Mode' parameter to <b>Per Account</b> in the Trunk Group Settings table (see <a href="#">Configuring Trunk Group Settings</a> on page 906).</li> <li>■ Account registration is not affected by the [IsRegisterNeeded] parameter.</li> </ul>
'Registrar Stickiness' registrar-stickiness [Account_RegistrarStickiness]	<p>Enables the Registrar Stickiness feature.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) Disables the Registrar Stickiness feature. After a successful initial registration of the Account with a registrar (IP address), whenever the device receives a SIP request or registration refresh, the device sends the request to whichever IP address is the currently working registrar. In other words, there is no binding to a specific IP address in the Proxy Set and at any given time, requests may be sent to a different IP address, whichever is the working one. In the case of proxy load-balancing, there is no certainty as to which IP address in the Proxy Set the request is routed.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [1] <b>Enable</b> = Enables the Register Stickiness feature. The device always routes SIP requests of a registered Account to the same registrar server to where the last successful REGISTER request was routed. In other words, once initial registration of the Account to one of the IP addresses in the Proxy Set (associated with the Account's Serving IP Group) is successful (i.e., 200 OK), binding ("stickiness") occurs to this specific address (registrar). All future SIP requests (e.g., INVITEs, SUBSCRIBEs and REGISTER refreshes) whose source and destination match the Account are sent to this registrar only. This applies until the registrar is unreachable or registration refresh fails, for whatever reason</li> <li>■ [2] <b>Enable for Non-REGISTER Requests</b> = Enables the Register Stickiness feature, as described for the <b>Enable</b> option (above), except for refresh REGISTER messages. When the device initiates a refresh REGISTER message for the Account, it restarts the registration process for the Account, sending the message to one of the registrar servers according to the Proxy Set of the Account's Serving IP Group. This option can be used, for example, in scenarios where proxy keep-alive is disabled (see the 'Proxy Keep-Alive' parameter in the Proxy Sets table) and restart of registration for refresh REGISTERs is always preferred.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if you have enabled Account registration ('Register' parameter configured to <b>Regular</b> or <b>GIN</b>).</li> <li>■ If an Account is registered with a registrar server which the device no longer "knows" (e.g., it was removed from the IP address results of the DNS resolution for the related Proxy Set) and the Registrar Stickiness feature is enabled, the device immediately initiates a new registration process for the Account (toward a different server of the Proxy Set).</li> </ul>

Parameter	Description
'Registrar Search Mode' registrar-search-mode [Account_RegistrarSearchMode]	<p>Defines the method for choosing an IP address (registrar) in the Proxy Set (associated with the Serving IP Group) to which the Account initially registers and performs registration refreshes, when the Register Stickiness feature is enabled. Once chosen, the Account is binded to the IP address for subsequent SIP requests.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Current Working Server</b> = (Default) For each initial and refresh registration request, the device routes to the currently working server in the list of IP addresses (configured or DNS-resolved IP addresses) in the Proxy Set. In the case of proxy load-balancing, the chosen IP address is according to the load-balancing mechanism.</li> <li>■ [1] <b>According to IMS Specifications</b> = For the initial registration request, the device performs DNS resolution if the address of the Proxy Set is configured as an FQDN. It then attempts to register to one of the listed DNS-resolved addresses (or configured IP addresses), starting with the first listed address and then going down the list sequentially. If an address results in an unsuccessful registration, the device immediately tries the next address (without waiting any retry timeout). The device goes through the list of addresses until an address results in a successful registration. If registration is unsuccessful for all addresses, the device waits a configured retry time and then goes through the list again. Once initial registration is successful, periodic registration refreshes are performed as usual. In addition to the periodic refreshes, immediate register refreshes are done upon the following triggers according to the IMS specification:               <ul style="list-style-type: none"> <li>✓ The device receives a SIP 408, 480, or 403 response from the Serving IP Group in response to an INVITE.</li> <li>✓ The transaction timeout expires for an INVITE sent to the Serving IP Group.</li> <li>✓ The device receives an INVITE from the Serving</li> </ul> </li> </ul>

Parameter	Description
	<p>IP Group from an IP address other than the address to which it is currently registered. In this case, it also rejects the INVITE with a SIP 480 response.</p> <p>If the device's physical Ethernet link to the proxy goes down, the device re-registers this Account with the proxy when the link comes up again. Re-registration occurs even if proxy keep-alive is disabled.</p> <p><b>Note:</b> This option is applicable only if you have configured the following:</p> <ul style="list-style-type: none"> <li>✓ 'Register' parameter to <b>Regular</b> or <b>GIN</b>.</li> <li>✓ 'Registrar Stickiness' parameter to <b>Enable</b>.</li> </ul> <p>■ [2] <b>Avoid Previous Registrar Until Expiry</b> = This option prevents the device from sending REGISTER requests to a registrar server where the device previously registered, if the device also registered successfully to another server since the last successful registration to the registrar server. This can occur if the registrar server has been offline for a brief time. The device avoids attempting to register to this registrar server for a duration that is calculated according to the cumulative value of the Proxy Server's last 'Expires' time and the grace time configured by the [AccountRegistrarAvoidanceTime] global parameter.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>✓ The value of the SIP Expires header in some REGISTER requests sent by the device may be less than the configured registration time (configured by [RegistrationTime]), when this option is used. The aim is to return registration to the higher priority server, soon after the avoidance time passes.</li> <li>✓ When this option is used, the Proxy Set of the Account's 'Serving IP Group' can have a maximum of three proxies (IP addresses may be resolved from a single Proxy host name).</li> </ul>

Parameter	Description
	<p>✓ Proxy Hot Swap isn't supported when this option is used.</p> <p>For example: Assume the Account is configured with 'Registrar Search Mode' set to <b>Avoid Previous Registrar Until Expiry</b> and the global parameter [AccountRegistrarAvoidanceTime] set to 180 seconds (3 minutes). In addition, the Account's 'Serving IP Group' uses a Proxy Set with three proxy server IPs (X, Y, Z; each proxy has a different priority) and uses the Homing mode.</p> <p>The following describes the timeline sequence of events:</p> <ol style="list-style-type: none"> <li>At 12:00:00, the Account successfully registers to server X; the 200 OK received from server X includes an expiry time of 8 minutes (Expires: 480 seconds).</li> <li>At 12:01:00, the device recognizes that server X is offline (using keep-alive with OPTIONS on the Proxy Set).</li> <li>When the device needs to send the next REGISTER request (by default, after half of the registration Expires time, i.e. 4 minutes, at 12:04:00), the device registers to server Y.</li> <li>At 12:05:00, the device recognizes that server X is back online. Even though server X has a higher priority than server Y, the device doesn't re-register to server X (instead, it registers to server Y) until after 12:11:00. Since the last successful registration to server X occurred at 12:00:00, the device only re-register to server X after 12:11:00 (i.e., Expires = 8 minutes + AccountRegistrarAvoidanceTime which is 3 minutes (180 seconds)). In this way, the device avoids sending REGISTER requests to the previous (non-current) registrar.</li> </ol>
'Re-REGISTER on INVITE Failure' re-register-on- invite-failure [Account_	Enables the device to re-register an Account upon the receipt of specific SIP response codes (e.g., 403, 408, and 480) for a failed INVITE message sent to the Serving IP Group.

Parameter	Description
ReRegisterOnInviteFailure]	<ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) If the device receives a SIP response for a failed INVITE message, the device doesn't re-register the Account.</li> <li>■ [1] <b>Enable</b> = If the device receives a SIP response for a failed INVITE message and the response code is configured in the global parameter, AccountInviteFailureTriggerCodes, the device re-registers the Account according to the settings of the Proxy Set associated with the Account's Serving IP Group. Note that if the Proxy Set's 'Proxy Hot Swap Mode' parameter is configured to <b>Enable</b> and the 'Proxy Keep-Alive' parameter to <b>Using OPTIONS, Using OPTIONS on Active Server, or Using REGISTER</b>, then the registrar at which the INVITE failed is tried last in the list of servers in the Proxy Set.</li> </ul>
'Reg Event Package Subscription' reg-event-package-subscription [Account_ RegEventPackageSubscription]	<p>Enables the device to subscribe to the registration event package service (as defined in RFC 3680) with the registrar server (Serving IP Group) to which the Account is successfully registered and binded, when the Registrar Stickiness feature is enabled. The service allows the device to receive notifications of the Accounts registration state change with the registrar. The device subscribes to the service by sending a SUBSCRIBE message containing the Event header with the value "reg" (Event: reg). Whenever a change occurs in the registration binding state, the registrar notifies the device by sending a SIP NOTIFY message.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p><b>Note:</b> The parameter is applicable only if you have enabled the Registrar Stickiness feature (in this table):</p> <ul style="list-style-type: none"> <li>■ 'Register' parameter to <b>Regular</b> or <b>GIN</b>.</li> <li>■ 'Registrar Stickiness' parameter to <b>Enable</b>.</li> </ul>
'Register by Served IP Group Status' reg-by-served-ipg-status	<p>Defines the device's handling of Account registration based on the connectivity status of the Served IP Group.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Register Always</b> = (Default) Account</li> </ul>



Parameter	Description
[Account_RegByServedIPG]	<p>registration by the device doesn't depend on the connectivity status of the Served IP Group. The device sends registration requests to the Serving IP Group even if the Served IP Group is offline.</p> <p>■ [1] <b>Register Only if Online</b> = The device performs Account registration depending on the connectivity status of the Served IP Group. It sends a registration request to the Serving IP Group only if the Served IP Group is online. If the Served IP Group was registered, but then goes offline, the device unregisters it. If it becomes online again, the device re-registers it. This option is applicable only to Accounts where registration is initiated by the device (i.e., the 'Register' parameter is configured to any value other than <b>No</b>).</p> <p>The Served IP Group's connectivity status is determined by the keep-alive mechanism of its associated Proxy Set (i.e., the 'Proxy Keep-Alive' parameter is configured to <b>Using OPTIONS, Using OPTIONS on Active Server</b> or <b>Using Fake REGISTER</b>).</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
'UDP Port Assignment' udp-port-assignment [Account_UDPPortAssignment]	<p>Enables the device to dynamically allocate local SIP UDP ports to Accounts using the same Serving IP Group, where each Account is assigned a unique port on the device's leg interfacing with the Accounts' Serving IP Group.</p> <p>■ [0] <b>Disable</b> = (Default) The device uses the same specific UDP port for all registrations done for this Account (traffic between the device and the Serving IP Group). This port is the one configured for the SIP Interface ('UDP Port' parameter) that is associated with the Proxy Set of the Account's Serving IP Group.</p> <p>■ [1] <b>Enable</b> = The device assigns a unique local port for each Account for which the device initiates registration. The port is taken from a configured UDP port range. The port range is configured for the SIP Interface ('Additional UDP Ports'</p>

Parameter	Description
	<p>parameter) associated with the Proxy Set of the Account's Serving IP Group. Traffic between the Serving IP Group and device is sent from and received on the assigned unique local port. If enabled for other Accounts that are configured with the same Serving IP Group, each Account is allocated a unique UDP port from the port range. For example, if you have configured two Accounts, "PBX-1" and "PBX-2", the device could assign port 6000 to "PBX-1" and 6100 to "PBX-2".</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the SBC application.</li> <li>■ If you enable the parameter, you must also enable the device to initiate registration for the Account (i.e., configure the 'Register' parameter to any value other than <b>No</b>).</li> <li>■ If the device fails to allocate a port (e.g., insufficient ports), the device doesn't send the SIP REGISTER request, but tries again within a period configured by the RegistrationRetryTime and MaxRegistrationBackoffTime parameters.</li> <li>■ If the device receives a SIP request from the Serving IP Group for the Account, on a port that was not assigned to the Account, it rejects the request (with a SIP 404 Not Found response).</li> <li>■ If the device receives a SIP request from the Served IP Group and the Account has not been allocated a valid port, the device rejects the request (with a SIP 500 Server Internal Error response).</li> <li>■ For more information on configuring the SIP Interface's port range, see <a href="#">Configuring SIP Interfaces</a> on page 561.</li> </ul>
'Account Registration Status'	<p>(Read-only field) Displays the registration status of the Account ("Registered" or "Not Registered"). You can also view Account registration status on the Registration Status page (see <a href="#">Viewing Registration Status</a> on page 1358).</p>

Parameter	Description
<b>Credentials</b>	
'User Name' user-name [Account_Username]	Defines the digest MD5 Authentication username. The valid value is a string of up to 60 characters. By default, no value is defined.
'Password' password [Account_Password]	Defines the digest MD5 Authentication password. The valid value is a string of up to 50 characters. <b>Note:</b> <ul style="list-style-type: none"> <li>■ The password can't be configured with wide characters.</li> <li>■ If the password contains a question mark (?) and you're configuring the parameter through CLI, you must enclose the entire password in double quotation marks (e.g., "43LSyk+?").</li> </ul>

## Regular Registration Mode

When you configure the registration mode ('Register') in the Accounts table to **Regular**, the device sends REGISTER requests to the Serving IP Group. The host name (in the SIP From/To headers) and contact user (user in From/To and Contact headers) are taken from the configured Accounts table upon successful registration. See the example below:

```
REGISTER sip:xyz SIP/2.0
Via: SIP/2.0/UDP 10.33.37.78;branch=z9hG4bKac1397582418
From: <sip:ContactUser@HostName>;tag=1c1397576231
To: <sip: ContactUser@HostName >
Call-ID: 1397568957261200022256@10.33.37.78
CSeq: 1 REGISTER
Contact: <sip:ContactUser@10.33.37.78>;expires=3600
Expires: 3600
User-Agent: Sip-Gateway/7.60A.100.022
Content-Length: 0
```

## Single Registration for Multiple Phone Numbers using GIN

When you configure the registration mode in the Accounts table to **GIN**, the Global Identifiable Number (GIN) registration method is used, according to RFC 6140. The device performs GIN-based registration of users to a SIP registrar on behalf of a SIP PBX. In effect, the PBX registers with the service provider, just as a directly hosted SIP endpoint would register. However, because a PBX has multiple user agents, it needs to register a contact address on behalf of each


of these. Rather than performing a separate registration procedure for each user agents, GIN registration mode does multiple registrations using a single REGISTER transaction.

According to this mechanism, the PBX delivers to the service provider in the Contact header field of a REGISTER request a template from which the service provider can construct contact URIs for each of the AORs assigned to the PBX and thus, can register these contact URIs within its location service. These registered contact URIs can then be used to deliver to the PBX inbound requests targeted at the AORs concerned. The mechanism can be used with AORs comprising SIP URIs based on global E.164 numbers and the service provider's domain name or sub-domain name.


The SIP REGISTER request sent by the device for GIN registration with a SIP server provider contains the Require and Proxy-Require headers. These headers contain the token 'gin'. The Supported header contains the token 'path' and the URI in the Contact header contains the parameter 'bnc' without a user part:

Contact: <sip:198.51.100.3;bnc>;

The figure below illustrates the GIN registration process:



The figure below illustrates an incoming call using GIN:



## Registrar Stickiness

You can enable the Registrar Stickiness feature per Account. Registrar Stickiness binds an Account to one of the IP addresses (configured or DNS-resolved) in the Proxy Set associated with the Serving IP Group. Once an Account registers successfully to one of the IP addresses (i.e., SIP registrar server) in the Proxy Set, the device routes all subsequent SIP requests (INVITEs, SUBSCRIBEs and REGISTER refreshes) of the Account to this registrar. This applies until the registrar is unreachable or registration refresh fails, for whatever reason.

To configure the Registrar Stickiness feature, use the following parameters in the Accounts table:

- Registrar Stickiness: Enables the feature.
- Registrar Search Mode: Defines the method for choosing an IP address (registrar) in the Proxy Set to which the Account initially registers and performs registration refreshes. Once chosen, the Account is binded to this registrar.
- Reg Event Package Subscription: Enables the device to subscribe to the registration event package service (as defined in RFC 3680) with the registrar to which the Account is registered and binded. The service allows the device to receive notifications of the Accounts registration state change with the registrar.

## Configuring Proxy and Registration Parameters

The Proxy & Registration page allows you to configure the Proxy server and registration parameters. For a description of the parameters appearing on this page, see [Configuration Parameters Reference](#) on page 1563. To configure Proxy servers (Proxy Sets), see [Configuring Proxy Sets](#) on page 622.



To view the registration status of endpoints with a SIP Registrar/Proxy server, see [Viewing Registration Status](#) on page 1358.

### ➤ To configure the Proxy and registration parameters:

1. Open the Proxy & Registration page (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **Proxy & Registration**).
2. Configure the parameters as required.
3. Click **Apply**.

### ➤ To register or un-register the device to a Proxy/Registrar:

- Click the **Register** button to register.
- Click **Un-Register** button to un-register.

Instead of registering the entire device, you can register specific entities as listed below by using the **Register** button located on the page in which these entities are configured:

- Trunk Groups - Trunk Groups table (see [Configuring Trunk Groups](#) on page 903)
- Accounts - Accounts table (see [Configuring Registration Accounts](#) on page 750)

## SIP Message Authentication Example

The device supports basic and digest (MD5 or SHA-256, configured by [SIPServerDigestAlgorithm]) authentication types, according to SIP RFC 3261. A proxy server might require authentication before forwarding an INVITE message. A Registrar/Proxy server may also require authentication for client registration. A proxy replies to an unauthenticated INVITE with a 407 Proxy Authorization Required response, containing a Proxy-Authenticate header with the form of the challenge. After sending an ACK for the 407, the user agent can then re-send the INVITE with a Proxy-Authorization header containing the credentials.

User agents, Redirect or Registrar servers typically use the SIP 401 Unauthorized response to challenge authentication containing a WWW-Authenticate header, and expect the re-INVITE to contain an Authorization header.

The following example shows the Digest Authentication procedure, including computation of user agent credentials:

1. The REGISTER request is sent to a Registrar/Proxy server for registration:

```
REGISTER sip:10.2.2.222 SIP/2.0
Via: SIP/2.0/UDP 10.1.1.200
From: <sip:122@10.1.1.200>;tag=1c17940
To: <sip:122@10.1.1.200>
Call-ID: 634293194@10.1.1.200

CSeq: 1 REGISTER
Contact: sip:122@10.1.1.200:
Expires:3600
```

2. Upon receipt of this request, the Registrar/Proxy returns a 401 Unauthorized response:

```
SIP/2.0 401 Unauthorized
Via: SIP/2.0/UDP 10.2.1.200
From: <sip:122@10.2.2.222 >;tag=1c17940
To: <sip:122@10.2.2.222 >
Call-ID: 634293194@10.1.1.200
Cseq: 1 REGISTER
Date: Mon, 30 Jul 2012 15:33:54 GMT
Server: Columbia-SIP-Server/1.17
Content-Length: 0
```

```
WWW-Authenticate: Digest realm="AudioCodes.com",  
nonce="11432d6bce58ddf02e3b5e1c77c010d2",  
stale=FALSE,  
algorithm=MD5
```

3. According to the sub-header present in the WWW-Authenticate header, the correct REGISTER request is created.
4. Since the algorithm is MD5:
  - The username is equal to the endpoint phone number "122".
  - The realm return by the proxy is "AudioCodes.com".
  - The password from the *ini* file is "AudioCodes".
  - The equation to be evaluated is "122:AudioCodes.com:AudioCodes". According to the RFC, this part is called A1.
  - The MD5 algorithm is run on this equation and stored for future usage.
  - The result is "a8f17d4b41ab8dab6c95d3c14e34a9e1".
5. The par called A2 needs to be evaluated:
  - The method type is "REGISTER".
  - Using SIP protocol "sip".
  - Proxy IP from *ini* file is "10.2.2.222".
  - The equation to be evaluated is "REGISTER:sip:10.2.2.222".
  - The MD5 algorithm is run on this equation and stored for future usage.
  - The result is "a9a031cfddcb10d91c8e7b4926086f7e".
6. Final stage:
  - A1 result: The nonce from the proxy response is "11432d6bce58ddf02e3b5e1c77c010d2".
  - A2 result: The equation to be evaluated is "A1:11432d6bce58ddf02e3b5e1c77c010d2:A2".
  - The MD5 algorithm is run on this equation. The outcome of the calculation is the response needed by the device to register with the Proxy.
  - The response is "b9c45d0234a5abf5ddf5c704029b38cf".

At this time, a new REGISTER request is issued with the following response:

```
REGISTER sip:10.2.2.222 SIP/2.0  
Via: SIP/2.0/UDP 10.1.1.200  
From: <sip: 122@10.1.1.200>;tag=1c23940  
To: <sip: 122@10.1.1.200>
```

Call-ID: 654982194@10.1.1.200

CSeq: 1 REGISTER

Contact: sip:122@10.1.1.200:

Expires:3600

Authorization: Digest, username: 122,  
realm="AudioCodes.com",  
nonce="11432d6bce58ddf02e3b5e1c77c010d2",  
uri="10.2.2.222",  
response="b9c45d0234a5abf5ddf5c704029b38cf"

7. Upon receiving this request and if accepted by the Proxy, the Proxy returns a 200 OK response, completing the registration transaction:

SIP/2.0 200 OK  
Via: SIP/2.0/UDP 10.1.1.200  
From: <sip: 122@10.1.1.200>;tag=1c23940  
To: <sip: 122@10.1.1.200>  
Call-ID: 654982194@10.1.1.200  
Cseq: 1 REGISTER  
Date: Thu, 26 Jul 2012 09:34:42 GMT  
Server: Columbia-SIP-Server/1.17  
Content-Length: 0

Contact: <sip:122@10.1.1.200>; expires="Thu, 26 Jul 2012 10:34:42 GMT";  
action=proxy; q=1.00

Contact: <122@10.1.1.200:>; expires="Tue, 19 Jan 2038 03:14:07 GMT";  
action=proxy; q=0.00

Expires: Thu, 26 Jul 2012 10:34:42 GMT

## Configuring User Information

This section describes User Information configuration.

### Enabling the User Information Table

Before you can use the SBC User Information table (for SBC users) or GW User Information table(for Gateway users), you need to enable the User Information functionality.



➤ **To enable User Information table:**

1. Make sure that your device's License Key includes the far-end user license ("Far End Users"), which specifies the maximum number of supported users. To view the License Key, see [Viewing the License Key](#) on page 1233.
2. Open the Proxy & Registration page (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **Proxy & Registration**).
3. Select the 'User-Information Usage' check box [EnableUserInfoUsage]:

User-Information Usage



4. Click **Apply**, and then restart the device with a save-to-flash for your settings to take effect. The User Information table becomes available in the Web interface:

SBC Application - see [Configuring SBC User Information](#) on page 775

Gateway Application - see [Gateway User Information for PBX Extensions and "Global" Numbers](#) below

## Gateway User Information for PBX Extensions and "Global" Numbers

The GW User Information table contains information of Gateway users, which can be used for the following Gateway-related features:

- **Mapping (Manipulating) PBX Extension Numbers with Global Phone Numbers:** maps PBX extension number, connected to the device, with any "global" phone number (alphanumeric) for the IP side. In this context, the "global" phone number serves as a routing identifier for calls in the "IP world" and the PBX extension uses this mapping to emulate the behavior of an IP phone. This feature is especially useful in scenarios where unique or non-consecutive number translation per PBX is needed. This number manipulation feature supports the following call directions:

- **IP-to-Tel Calls:** Maps the called "global" number (in the Request-URI user part) to the PBX extension number. For example, if the device receives an IP call destined for "global" number 638002, it changes this called number to the PBX extension number 402, and then sends the call to the PBX extension on the Tel side.



If you have configured regular IP-to-Tel manipulation rules (see [Configuring Source-Destination Number Manipulation Rules](#) on page 950), the device applies these rules before applying the mapping rules of the GW User Information table.

- **Tel-to-IP Calls:** Maps the calling (source) PBX extension to the "global" number. For example, if the device receives a Tel call from PBX extension 402, it changes this calling number to 638002, and then sends call to the IP side with this calling number. In addition to the "global" phone number, the display name (caller ID) configured for the PBX user in the GW User Information table is used in the SIP From header.



If you have configured regular Tel-to-IP manipulation rules (see [Configuring Source-Destination Number Manipulation Rules](#) on page 950), the device applies these rules before applying the mapping rules of the GW User Information table.

- **Registering Users:** The device can register each PBX user configured in the GW User Information table. For each user, the device sends a SIP REGISTER to an external IP-based Registrar server, using the "global" number in the From/To headers. If authentication is necessary for registration, the device sends the user's username and password, configured in the GW User Information table, in the SIP MD5 Authorization header.

You can configure up to 500 mapping rules in the GW User Information table. These rules can be configured using any of the following methods:

- Web interface - see [Configuring Gateway User Information Table through Web Interface](#) below
- CLI - see [Configuring Gateway User Information Table through CLI](#) on page 772
- Loadable User Information file - see [Configuring Gateway User Information Table from a Loadable File](#) on page 774



- This section is applicable only to the Gateway application.
- To enable user registration, configure the following parameters:
  - ✓ Enable the 'Enable Registration' parameter [IsRegisterNeeded].
  - ✓ 'Registration Mode': **Per Endpoint** or [AuthenticationMode] set to 0

### Configuring Gateway User Information Table through Web Interface

You can configure the GW User Information table through the Web interface. The table allows you to do the following:

- Manually add users (described below).
- Import users from a file: From the **Action** drop-down list, choose **Import**.



- When you import a file, all previously configured entries in the table are deleted and replaced with the users from the imported file.
- For configuring users in a file for import, see [Configuring Gateway User Information Table from a Loadable File](#) on page 774

- Export the configured users to a .csv file: From the **Action** drop-down list, choose **Export** and save the file to a folder on your computer.
- Register and un-register users:
  - To register a user, select the user, and then from the **Action** drop-down list, choose **Register**.

- To un-register a user, select the user, and then from the **Action** drop-down list, choose **Un-Register**.



To configure the GW User Information table, make sure that you have enabled the feature (see [Enabling the User Information Table](#) on page 768).

The following procedure describes how to configure and register users in the GW User Information table through the Web interface.

➤ **To configure the GW User Information table through the Web interface:**

- Open the GW User Information table (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Gateway User Information**).
- Click **New**; the following dialog box appears:

The screenshot shows a web-based dialog box titled "User Information". It has a "GENERAL" tab selected. The form contains the following fields:

- Index:** A text box containing the value "0".
- PBX Extension:** An empty text box.
- Global Phone Number:** An empty text box.
- Display Name:** An empty text box.
- Username:** An empty text box.
- Password:** An empty text box.
- Status:** An empty text box.

- Configure a user according to the table below.
- Click **Apply**.

**Table 20-2: User Information Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'PBX Extension' [PBXExtension]	Defines the PBX extension number. The valid value is a string of up to 10 characters. <b>Note:</b> The parameter is mandatory.
'Global Phone Number' [GlobalPhoneNumber]	Defines the "global" phone number for the IP side.

Parameter	Description
	The valid value is a string of up to 20 characters. <b>Note:</b> The parameter is mandatory.
'Display Name' [DisplayName]	Defines the Caller ID of the PBX extension. The valid value is a string of up to 30 characters.
'Username' [Username]	Defines the username for registering the user when authentication is necessary. The valid value is a string of up to 60 characters. By default, no value is defined.
'Password' [Password]	Defines the password for registering the user when authentication is necessary. The valid value is a string of up to 20 characters. <b>Note:</b> The password cannot be configured with wide characters.
'Status'	(Read-only field) Displays the status of the user:  ■ "Registered"  ■ "Not Registered"

### Configuring Gateway User Information Table through CLI

The GW User Information table can be configured through CLI using the following commands:

- To add or modify a user (example):

```
# configure voip
(config-voip)# sip-definition proxy-and-registration
(sip-def-proxy-and-reg)# user-info gw-user-info <index, e.g., 1>
(gw-user-info-1)# username JohnDee
(gw-user-info-1)# <activate | exit>
```

- To delete a specific user, use the no command:

```
# configure voip
(config-voip)# sip-definition proxy-and-registration
(sip-def-proxy-and-reg)# no user-info gw-user-info <index, e.g., 1>
```

- To import users from a file:

```
# configure voip
(config-voip)# sip-definition proxy-and-registration
(sip-def-proxy-and-reg)# user-info gw-user-info import-csv-from <URL>
```

- To export users to a .csv file:

```
# configure voip
(config-voip)# sip-definition proxy-and-registration
(sip-def-proxy-and-reg)# user-info gw-user-info export-csv-to <URL>
```

- To view all table entries:

```
(sip-def-proxy-and-reg)# user-info gw-user-info display
---- gw-user-info-0 ----
pbx-ext (405)
global-phone-num (405)
display-name (Ext405)
username (user405)
password (0aGzoKfh5ul=)
status (not-resgistered)
```

- To view a specific entry (example):

```
(sip-def-proxy-and-reg)# user-info gw-user-info <index, e.g., 0>
(gw-user-info-0)# display
pbx-ext (405)
global-phone-num (405)
display-name (Ext405)
username (user405)
password (0aGzoKfh5ul=)
status (not-resgistered)
```

- To search a user by pbx-ext:

```
(sip-def-proxy-and-reg)# user-info find <pbx-ext e.g., 405>
405: Found at index 0 in GW user info table, not registered
```



To configure the GW User Information table, make sure that you have enabled the feature (see [Enabling the User Information Table](#) on page 768).

## Configuring Gateway User Information Table from a Loadable File

You can configure users in a file and then upload (import) it to the GW User Information table. The users must be configured in comma-separated value (CSV) file format. You can create the file using any standard text-based editor such as Notepad, or alternatively a CSV-based program such as Microsoft Excel. The file can have any filename extension (e.g., .csv or .txt).



When you import a file, all previously configured entries in the table are deleted and replaced with the users from the imported file.

When adding users to the file, use the following syntax:

- For text-based editors:

```
PBXExtension,GlobalPhoneNumber,DisplayName,Username>Password
```

For example:

```
PBXExtension,GlobalPhoneNumber,DisplayName,Username>Password
4040,7362400,John,johnd,2798
4041,7362401,Sue,suep,1234
```

- For CSV-based programs:

```
PBXExtension,GlobalPhoneNumber,DisplayName,Username>Password
```

For example:

A	B	C	D	E
PBXExtension	GlobalPhoneNumber	DisplayName	Username	Password
4040	73682400	John	johnd	1234
4041	73682401	Sue	suep	2224

You can upload the User Information file using any of the following methods:

- Web interface - GW User Information table (see [Configuring Gateway User Information Table through Web Interface](#) on page 770)
- CLI - **gateway user-info-table import-csv-from** (see [Configuring Gateway User Information Table through CLI](#) on page 772)
- Automatic Update mechanism - [GWUserInfoFileUrl] parameter



For **backward compatibility only**, upload the User Information file using the Auxiliary Files page. Configure users with the following syntax:

[GW]

FORMAT PBXExtensionNum,GlobalPhoneNum,DisplayName,UserName>Password

For example:

[GW]

FORMAT PBXExtensionNum,GlobalPhoneNum,DisplayName,UserName>Password

4040,7362400,John,johnd,2798

4041,7362401,Sue,suep,1234

Make sure that the last line in the file ends with a carriage return (i.e., press the Enter key).

When you upload the file, the device automatically populates the GW User Information table with the file's contents and deletes all previous entries in the table.

## Configuring SBC User Information

The SBC User Information table lets you configure up to 1,600 SBC users.

You can use the table for the following:

- Registering each user to an external registrar server.
- Authenticating (for any SIP request and as a client) each user if challenged by an external server.
- Authenticating as a server incoming user requests (for SBC security).

If the device registers on behalf of users and the users don't perform registration, any SIP request destined to the user is routed to the Proxy Set associated with the user's IP Group.

You can also enable the Registration Synchronization feature (see [\[configure voip > sip-definition proxy-and-registration > reg-sync-mode](#) on page 1698] parameter). This feature synchronizes the registration process for users configured in the SBC User Information table and Accounts configured in the Accounts table (see [Configuring Registration Accounts](#) on page 750) that register to the same proxy server (Serving IP Group). If an Account or user receives a timeout (configured by [SipT1Rtx], [SipT2Rtx], or [SIPMaxRtx] parameters) or response failure (e.g., SIP 403) for a sent SIP REGISTER request, the device stops sending REGISTER messages for all Accounts and users associated with this same proxy server. The Account or user that first detected the no response (or failure) is considered the lead Account or user. Only this Account or user continues registering to the proxy server. When this Account or user receives a successful response from the proxy server, the device resumes the registration process for all the other Accounts and users associated with the same proxy server.

The SBC User Information table can be configured using any of the following methods:

- Web interface (see [Configuring SBC User Information Table through Web Interface](#) on the next page)
- CLI (see [Configuring SBC User Information Table through CLI](#) on page 779)

- Loadable User Information file (see [Configuring SBC User Information Table from a Loadable File](#) on page 781)



- For the SBC User Information feature, the device's License Key must include the license "Far End Users (FEU)", which specifies the maximum number of supported far-end users. If no far-end users are licensed, then this feature cannot be used.
- If you configure the device to authenticate as a server, for incoming SIP requests from users of a specific User-type IP Group, the device authenticates the users using the username and password configured in the IP Group's 'Username As Server' and 'Password As Server' parameters. However, if the user appears in the SBC User Information table and configured with a username and/or password, then the device authenticates the user with the credentials in the table. To enable the device to authenticate as a server, configure the IP Group's 'Authentication Mode' parameter to **SBC as Server**.
- The maximum number of available rows (users) that you can add in the SBC User Information table is according to the number of far-end users ("Far End Users") that is specified in the device's License Key. However, the number of licensed users cannot exceed the maximum rows supported by the device, as stated in the beginning of this section. As an example and for simplicity sake, assume that the supported number of rows is 10 and the number of licensed users is 20. In this scenario, the maximum number of available rows will be 10. If the number of licensed users is 5, the maximum number of available rows will be 5.
- This section is applicable only to the SBC application.

### Configuring SBC User Information Table through Web Interface

You can configure the SBC User Information table with SBC users through the Web interface.



- Before you can configure the SBC User Information table, you need to enable the SBC users feature (see [Enabling the User Information Table](#) on page 768) so that it's available in the Web interface.
- The maximum number of users (rows) that can be configured in the table is according to how many far-end users ("Far End Users (FEU)") are defined in the device's License Key (see [Viewing the License Key](#) on page 1233).

You can configure users in the table, by doing the following:

- Manually adding users (described below).
- Importing users from a file: From the **Action** drop-down list, choose **Import**. To configure users in a file for import, see [Configuring SBC User Information Table from a Loadable File](#) on page 781.



When you import a file, all previously configured entries in the table are deleted and replaced with the users from the imported file.

The table also allows you to do the following:



- Export configured users to a file (.csv file format): From the **Action** drop-down list, choose **Export** and save the file to a folder on your computer.
- Register and un-register users:
  - To register a user: Select the user, and then from the **Action** drop-down list, choose **Register**.
  - To unregister a user: Select the user, and then from the **Action** drop-down list, choose **Un-Register**.



The **Register** and **Un-Register** buttons are applicable only if the user's assigned IP Group (see 'IP Group' parameter below) is configured so that the device initiates registrations (i.e., IP Group's 'Registration Mode' parameter is **SBC Initiates Registration**). The device uses the IP-to-IP Routing table (see [Configuring SBC IP-to-IP Routing Rules](#) on page 1076) to determine where to send the SIP REGISTER request for the user. It searches the table for a rule whose 'Source IP Group' parameter matches the user's assigned IP Group (below), and then sends the REGISTER to the IP Group specified in the rule's 'Destination IP Group' parameter (referred to as the *serving* IP Group).

You can also enable the device to synchronize registration between all users in the SBC User Information table and all Accounts (configured in the [Configuring Registration Accounts](#) on page 750) that register to the same proxy server (*serving* IP Group). Upon registration failure (timeout or failure response) with the proxy server, only the user or Account that first detected the failure, continues its attempt at registering (sending REGISTER requests) to the proxy server. For more information, see the [configure voip > sip-definition proxy-and-registration > reg-sync-mode](#) on page 1698.

The device also uses the SBC User Information table to classify incoming SIP dialogs from users. When it receives an incoming SIP message (e.g., INVITE), it searches the table for a matching user ('Local User' parameter below) and if found, classifies it to the IP Group assigned to the user.

➤ **To configure SBC User Information table through Web interface:**

1. Open the SBC User Information table (**Setup** menu > **Signaling & Media** tab > **SBC** folder > **SBC User Information**).
2. Click **New**; the following dialog box appears:

3. Configure a user according to the table below.

4. Click **Apply**.

**Table 20-3: SBC User Information Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	<p>Defines an index number for the new table row.</p> <p><b>Note:</b> Each row must be configured with a unique index.</p>
'Local User' [LocalUser]	<p>Defines the user and is used as the Request-URI user part for the AOR in the database.</p> <p>The valid value is a string of up to 60 characters. By default, no value is defined.</p> <p><b>Note:</b> The parameter is mandatory.</p>
'Username' [Username]	<p>Defines the username for registering the user when authentication is necessary.</p> <p>The valid value is a string of up to 60 characters. By default, no value is defined.</p> <p><b>Note:</b> To configure the device to act as an authentication server and challenge incoming SIP requests from this user, configure the 'Authentication Mode' parameter of the user's IP Group to <b>SBC as Server</b>. If the 'Username' parameter is not configured, the device uses the username configured in the IP Group's 'Username As Server' parameter.</p>
'Password' [Password]	<p>Defines the password for registering the user when authentication is necessary.</p> <p>The valid value is a string of up to 20 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The password cannot be configured with wide characters.</li> <li>■ To configure the device to act as an authentication server and challenge incoming SIP requests from this user, configure the</li> </ul>

Parameter	Description
	'Authentication Mode' parameter of the user's IP Group to <b>SBC as Server</b> . If the 'Password' parameter is not configured, the device uses the password configured in the IP Group's 'Password As Server' parameter.
'IP Group' [IPGroupName]	<p>Assigns an IP Group to the user. The IP Group is used as the Request-URI source host part for the AOR in the database.</p> <p>To configure IP Groups, see <a href="#">Configuring IP Groups</a> on page 581.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> <li>■ You must assign the user with a <b>User</b>-type IP Group.</li> </ul>
'Status' [Status]	<p>(Read-only field) Displays the status of the user:</p> <ul style="list-style-type: none"> <li>■ "Registered": Valid configuration and the user is registered.</li> <li>■ "Not Registered": Valid configuration, but the user is not registered.</li> <li>■ "N/A": Invalid configuration because the user is not assigned to a <b>User</b>-type IP Group.</li> <li>■ "Exceeds FEU FK": The number of users (rows) in the SBC User Information table exceeds the licensed capacity for far-end users specified in the License Key ('Far End Users (FEU)').</li> </ul>

### Configuring SBC User Information Table through CLI

The SBC User Information table can be configured in the CLI using the following commands:

- To add and/or modify a user (example):

```
# configure voip
(config-voip)# sip-definition proxy-and-registration
(sip-def-proxy-and-reg)# user-info sbc-user-info <index, e.g., 1>
(sbc-user-info-1)# username JohnDee
(sbc-user-info-1)# <activate | exit>
```

- To delete a specific user, use the no command:

```
(sip-def-proxy-and-reg)# no user-info sbc-user-info <index, e.g., 1>
```

- To import users from a file:

```
# configure voip
(config-voip)# sip-definition proxy-and-registration
(sip-def-proxy-and-reg)# user-info sbc-user-info import-csv-from <URL>
```

- To export users to a .csv file:

```
# configure voip
(config-voip)# sip-definition proxy-and-registration
(sip-def-proxy-and-reg)# user-info sbc-user-info export-csv-to <URL>
```

- To view all table entries:

```
(sip-def-proxy-and-reg)# user-info sbc-user-info display
---- sbc-user-info-0 ----
local-user (JohnDee)
username (userJohn)
password (s3fn+fn=)
ip-group-id (1)
status (not-resgistered)
```

```
---- sbc-user-info-1 ----
local-user (SuePark)
username (userSue)
password (t6sn+un=)
ip-group-id (1)
status (not-resgistered)
```

- To view a specific entry (example):

```
(sip-def-proxy-and-reg)# user-info sbc-user-info <index, e.g., 0>
(sbc-user-info-0)# display
local-user (JohnDee)
username (userJohn)
password (s3fn+fn=)
ip-group-id (1)
status (not-resgistered)
```

- To search a user by local-user:

```
(sip-def-proxy-and-reg)# user-info find <local-user, e.g., JohnDoe>
JohnDee: Found at index 0 in SBC user info table, not registered
```



To configure the SBC User Information table, make sure that you have enabled the feature as described in [Enabling the User Information Table](#) on page 768.

### Configuring SBC User Information Table from a Loadable File

You can configure users in a file and then upload (import) it to the SBC User Information table. The users must be configured in comma-separated value (CSV) file format. You can create the file using any standard text-based editor such as Notepad, or alternatively a CSV-based program such as Microsoft Excel. The file can have any filename extension (e.g., .csv or .txt).



- When you import a file, all previously configured entries in the table are deleted and replaced with the users from the imported file.
- If a user is configured in the file with an IP Group that doesn't exist, the user is not assigned an IP Group when you import the file.

When adding users to the file, use the following syntax:

- For text-based editors:

```
LocalUser,UserName>Password,IPGroupName
```

For example:

```
LocalUser,UserName>Password,IPGroupName
John,johnd,2798,ITSP
Sue,suep,1234,IP-PBX
```

- For CSV-based programs:

```
LocalUser,UserName>Password,IPGroupName
```

For example:

	A	B	C	D
1	LocalUser	Username	Password	IPGroupName
2	John	johnd	2798	ITSP
3	Sue	suep	1234	IP-PBX
4				

You can upload the User Information file using any of the following methods:

- Web interface - SBC User Information table (see [Configuring SBC User Information Table through Web Interface](#) on page 776)

- CLI - **sbcs user-info-table import-csv-from** (see [Configuring SBC User Information Table through CLI](#) on page 779)
- Automatic Update mechanism - [SBCUserInfoFileUrl] parameter (see [Automatic Update Mechanism](#))



For **backward compatibility** only: When configuring a User Information file to upload through the Auxiliary Files page, use the following syntax:

[SBC]

FORMAT LocalUser,UserName,Password,IPGroupID

For example:

[SBC]

FORMAT LocalUser,UserName,Password,IPGroupID

John,johnd,2798,2

Sue,suep,1234,1

## Configuring Call Setup Rules

The Call Setup Rules table lets you configure up to 100 Call Setup Rules.

Call Setup Rules define various script-like sequences that the device runs upon the receipt of an incoming SIP dialog at call setup, before the device routes the call to its destination. You can configure multiple Call Setup Rules and group them under the same *Set ID*. This lets you run multiple Call Setup Rules for the same call setup dialog.

You can configure Call Setup Rules for any call direction - IP-to-IP (SBC), Tel-to-IP, or IP-to-Tel.

Call Setup Rules provide flexibility in implementing simple or complex script-like rules that you can use for various functionality:

- **LDAP Queries:** The device can be configured to use LDAP to query Microsoft's Active Directory (AD) server for specific user details needed for routing the call. For example, it could query for the user's office extension number, mobile number, private number, or display name. Call Setup Rules provides full flexibility in AD-lookup configuration to suit just about any deployment requirement:
  - Routing based on query results.
  - Queries based on any AD attribute.
  - Queries based on any attribute value (alphanumeric), including the use of the asterisk (\*) wildcard as well as the source number, destination number, redirect number, and SBC SIP messages. For example, the following Call Setup rule queries the attribute "proxyAddresses" for the record value "WOW:" followed by source number: "proxyAddresses=WOW:12345\*"
  - Conditional LDAP queries, for example, where the query is based on two attributes (&(telephoneNumber=4064)(company=ABC)).
  - Conditions for checking LDAP query results.

- Manipulation of call parameters such as source number, destination number, and redirect number and SBC SIP messages, while using LDAP query results.
- Multiple LDAP queries.

- **Dial Plan Queries:** You can use Call Setup Rules to query the Dial Plan table (see [Configuring Dial Plans](#) on page 798) for a specified key in a specified Dial Plan, to obtain the corresponding Dial Plan tag. Call Setup Rules can also change (modify) the name of the obtained tag. The device can then route the call using an IP-to-IP Routing rule (in the IP-to-IP Routing table) that has a matching tag (source or destination).

You can also use Call Setup Rules for complex routing schemes by using multiple Dial Plan tags. This is typically required when the source or destination of the call needs to be categorized with multiple characteristics. For example, tags can be used to categorize calls by department (source user) within a company, where only certain departments are allowed to place international calls.

- **ENUM Queries:** You can use Call Setup Rules to query an ENUM server and to handle responses from the ENUM server. ENUM translates ordinary telephone numbers (E.164 telephone numbers) into Internet addresses (SIP URIs), using the ENUM's DNS NAPTR records. For example, if the device receives an INVITE message whose destination number is in E.164 format, you can configure a Call Setup rule to query the ENUM server for the corresponding URI address, which is then used in the INVITE's Request-URI.
- **HTTP Requests (Queries):** You can use Call Setup Rules to query or notify an HTTP/S server, which is configured in the Remote Web Services table ([Configuring Remote Web Services](#) on page 429). If a response is expected from the server, the query is sent as an HTTP GET or HTTP POST request (configurable). If no response is required from the server (i.e., to notify the server of a specific condition), then an HTTP POST for notifications is sent (configurable).
- **Classification:** You can use Call Setup Rules triggered from SIP Interfaces to asynchronously query an external HTTP server (AudioCodes ARM) for a source tag, which can then be used to classify the incoming SIP dialog to a source IP Group. For additional query methods on classification based on tags, see [Configuring Classification Based on Tags](#) on page 1073.
- **Manipulation:** Manipulation (similar to Message Manipulations table) of call parameters (such as source number, destination number, and redirect number) and SBC SIP messages.
- **Conditions for Routing:** Routing conditions, for example, if the source number equals a specific value, then use the call routing rule.
- **Tag-based Routing:** You can use Call Setup Rules for tag-based routing. The Call Setup Rule Set is assigned to the IP-to-IP Routing rule ('Pre Route Call Setup Rules Set ID' parameter), whose 'Destination Type' parameter is configured to **Destination Tag** and 'Routing Tag Name' parameter to the name of the tag. When the tag is obtained by the Call Setup Rules (DstTags), the device searches the IP Groups table for a destination IP Group whose 'Tags' parameter matches this tag.

To use Call Setup Rules, you need to assign their Set ID to any of the following configuration entities:

- (SBC application) IP-to-IP Routing rules, using the 'Call Setup Rules Set ID' or 'Pre Route Call Setup Rules Set ID' parameters (see [Configuring SBC IP-to-IP Routing Rules](#) on page 1076)
- (SBC application) SIP Interface rules, using the 'Call Setup Rules Set ID' parameter (see [Configuring SIP Interfaces](#) on page 561)
- (Gateway application) Tel-to-IP Routing rules, using the 'Call Setup Rules Set ID' parameter (see [Configuring Tel-to-IP Routing Rules](#) on page 914)
- (Gateway application) IP-to-Tel Routing rules, using the 'Call Setup Rules Set ID' parameter (see [Configuring IP-to-Tel Routing Rules](#) on page 928)
- (SBC application) IP Groups, using the 'Call Setup Rules Set ID' parameter (see [Configuring IP Groups](#) on page 581)



- If you assign a Call Setup rule to an IP Group, the device runs the Call Setup rule for the classified source IP Group immediately before the routing stage. If you assign the Call Setup rule to a routing rule only, the device first locates a matching routing rule for the incoming call, runs the assigned Call Setup rule, and then routes the call according to the destination of the routing rule.
- If you want a Call Setup rule to run during the routing stage to determine the destination tag (when the 'Destination Type' parameter is configured to **Destination Tag**), you must assign the Call Setup rule in the IP-to-IP Routing table using the 'Pre Route Call Setup Rules Set ID' parameter (instead of 'Call Setup Rules Set ID'). For more information of these parameters, see the [Configuring SBC IP-to-IP Routing Rules](#) on page 1076.
- You can't run Call Setup Rules on SIP OPTIONS or any SIP message without a user-part in its URL.
- Call Setup Rules support synchronous (e.g., Dial Plan) and asynchronous (e.g., LDAP, ENUM, and HTTP) queries triggered by SIP Interfaces.

For routing, the device uses the selected routing rule for routing the call, depending on whether the condition of the Call Setup rule is met or not, and according to the 'Action Value' parameter's value when the 'Action Type' parameter is configured to **Exit**. The **Exit** value is used to discontinue with the Set ID (i.e., doesn't run remaining Call Setup Rules in the Set ID). For example, if you have 10 Call Setup Rules (#1-10) in the Set ID, you can configure rule #5 with **Exit** so that if its condition is met, it's the last one to run in the Set ID (i.e., rules #6-10 aren't run). Below explains route selection depending on condition and the **Exit** value:

- **Call Setup Rule's Condition is Met:** The device runs the Call Setup rule, and then runs the next rule in the Set ID until the last rule or until a rule whose 'Action Type' parameter is **Exit**. If there is an "exit" rule, the device's logic is according to the settings of the 'Action Value' parameter:
  - **True:** The device uses the selected routing rule to route the call.
  - **False:** The device searches for the next alternative routing rule (if exists).
  - **Abort:** The device stops (aborts) any further attempts to route the call (i.e., rejects call), even if additional alternative routing rules exist.



- **Call Setup Rule's Condition not Met:** The device runs the next Call Setup rule in the Set ID, and when it finishes running all the rules in the Set ID (and no "exit" rule exists), the Set ID ends with a "true" result. However, if there is an "exit" rule (i.e., 'Action Type' parameter is **Exit** and regardless of the 'Action Value' parameter's value), the device doesn't run the next Call Setup rule, and uses the selected routing rule to route the call.



The optional values **True**, **False**, and **Abort** for the 'Action Value' parameter, used when the 'Action Type' parameter is configured to **Exit** is applicable **only** when the Call Setup rule is run from the IP-to-IP Routing table. If run from any other configuration entity (e.g., SIP Interface), the device ignores these values.

The default result of a Call Setup rule is always “true” (**True**). Therefore, it's important to understand the logic when configuring the 'Action Type' field to **Exit**.

Examples:

- **Example 1:** To exit the Set ID with "true" if the LDAP query result is found, and with "false" if the LDAP query result isn't found:

- **Incorrect Configuration:** This rule always exits with result as "true":

- ◆ 'Condition': **ldap.found exists**
- ◆ 'Action Type': **Exit**
- ◆ 'Action Value': **True**

- **Correct Configuration:**

**Single rule:**

- ◆ 'Condition': **ldap.found !exists**
- ◆ 'Action Type': **Exit**
- ◆ 'Action Value': **False**

**Multiple rules:**

- ◆ 'Condition': **ldap.found exists**
- ◆ 'Action Type': **Exit**
- ◆ 'Action Value': **True**
- ◆ 'Condition': <leave empty>
- ◆ 'Action Type': **Exit**
- ◆ 'Action Value': **False**

- **Example 2:** Assume you've configured the following IP-to-IP Routing rules in the IP-to-IP Routing table:

- Index #1: 'Alternative Route Options' = **Route Row**; 'Destination Type' = **Destination Tag**

- Index #2: 'Alternative Route Options' = **Alternative Route Ignore Inputs**; 'Destination Type' = **Destination Tag**
- Index #3: 'Alternative Route Options' = **Alternative Route Ignore Inputs**; 'Destination Type' = **Destination Tag**
- Index #4: 'Alternative Route Options' = **Alternative Route Ignore Inputs**; 'Destination Type' = **Destination Tag**
- Index #5: 'Alternative Route Options' = **Alternative Route Ignore Inputs**; 'Destination Type' = **Destination Tag**

Assume the device is unable to route the call using rules #1 and #2, and is now processing rule #3. The device handles rule #3 according to the settings of the assigned Call Setup rule:

- 'Action Type' is **Exit** and 'Action Value' is **Abort**: If the rule's Condition is met, the device discontinues its attempt to route the call (doesn't try rules #4 or #5) and aborts call routing (i.e., call fails).
- 'Action Type' is **Exit** and 'Action Value' is **False**: If the rule's Condition is met, the device attempts to route the call using the next matching routing rule (#4).
- 'Action Type' is **Exit** and 'Action Value' is **True**: If the rule's Condition is met, the device sends a SIP INVITE message to the destination, according to routing rule #3. If the device receives a failure response to the INVITE, the device tries the next rule (i.e., #5) to route the call.



- If the source or destination numbers are manipulated by Call Setup Rules, they revert to their original values if the device moves to the next routing rule.
- For examples of Call Setup Rules, see [Examples of Call Setup Rules](#) on page 793.
- For a detailed description of the syntax for Call Setup Rules, refer to the document *SIP Message Manipulation Syntax Reference Guide* (click [here](#)).

The following procedure describes how to configure Call Setup Rules through the Web interface. You can also configure it through ini file [CallSetupRules] or CLI (`configure voip > message call-setup-rules`).

➤ **To configure a Call Setup rule:**

1. Open the Call Setup Rules table (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **Call Setup Rules**).
2. Click **New**; the following dialog box appears:

3. Configure a Call Setup rule according to the parameters described in the table below.
4. Click **Apply**, and then save your settings to flash memory.

**Table 20-4: Call Setup Rules Parameter Descriptions**

Parameter	Description
General	
'Index' [Index]	Defines an index number for the new table record. <b>Note:</b> Each rule must be configured with a unique index.
'Name' rules-set-name [RulesSetName]	Defines an arbitrary name to easily identify the row. The valid value is a string of up to 20 characters. <b>Note:</b> Configure each row with a unique name.
'Rules Set ID' rules-set-id [RulesSetID]	Defines a Set ID for the rule. You can define the same Set ID for multiple rules to create a group of Call Setup Rules. You can configure up to 32 Set IDs, where each Set ID can include up to 10 rules. The Set ID is used to assign the Call Setup Rules to configuration entities (e.g., IP-to-IP Routing rules in the IP-to-IP Routing table). The valid value is 0 to 31. The default is 0. <b>Note:</b> You can configure up to 25 rules per Set ID.
'Request Type' request-type [QueryType]	Defines the type of query. <ul style="list-style-type: none"> <li>■ [0] <b>None</b> (default)</li> <li>■ [1] <b>LDAP</b> = The Call Setup rule runs an LDAP query with an LDAP server. To specify an LDAP server, use the 'Request Target' parameter (see below).</li> <li>■ [2] <b>Dial Plan</b> = The Call Setup rule runs a query with the Dial Plan. To specify a Dial Plan, use the 'Request Target' parameter (see below).</li> <li>■ [3] <b>ENUM</b> = The Call Setup rule runs a query with an ENUM (E.164 Number to URI Mapping) server for retrieving a SIP URI address for an E.164 telephone number. The ENUM</li> </ul>

Parameter	Description
	<p>server's address is the address configured for the 'Primary DNS' (and optionally, 'Secondary DNS') parameters of the IP Interface (in the IP Interfaces table) that is specified in the 'Request Target' parameter (see below). For a configuration example, see <a href="#">Examples of Call Setup Rules</a> on page 793.</p> <ul style="list-style-type: none"> <li>■ <b>[4] HTTP GET</b> = The Call Setup rule runs an HTTP GET request (query) with an HTTP/S server. To specify an HTTP server, use the 'Request Target' parameter (see below).</li> <li>■ <b>[5] HTTP POST Query</b> = The Call Setup rule runs an HTTP POST request (query) with an HTTP/S server and expects a response from the server. To specify an HTTP server, use the 'Request Target' parameter (see below).</li> <li>■ <b>[6] HTTP POST Notification</b> = The Call Setup rule runs an HTTP POST request to notify an HTTP/S server of a specific condition and doesn't expect a response from the server. For example, you can configure a rule to notify the server of a 911 emergency call. To specify an HTTP server, use the 'Request Target' parameter (see below).</li> </ul>
'Request Target' request-target [QueryTarget]	<p>Defines one of the following, depending on the value configured for the 'Request Type' parameter (above).</p> <ul style="list-style-type: none"> <li>■ <b>LDAP:</b> Defines an LDAP server (LDAP Server Group) on which to run an LDAP query for a defined key. To configure LDAP Server Groups, see <a href="#">Configuring LDAP Server Groups</a> on page 373.</li> <li>■ <b>Dial Plan:</b> Defines a Dial Plan (name) in which to search for a defined key. To configure Dial Plans, see <a href="#">Configuring Dial Plans</a> on page 798.</li> <li>■ <b>ENUM:</b> Specifies the ENUM server on which to run the ENUM query. The server is specified by IP Interface name (in the IP Interfaces table). The address of the ENUM server is the address of the 'Primary DNS' (and optionally, 'Secondary DNS') parameters that is configured for the specified IP Interface. If you don't specify an IP Interface or the specified IP Interface doesn't exist in the IP Interfaces table, the device uses the OAMP IP Interface.</li> <li>■ <b>HTTP GET, HTTP POST Query, and HTTP POST Notification:</b> Defines the HTTP server to where the device sends the HTTP request. To configure HTTP servers, see <a href="#">Configuring Remote Web Services</a> on page 429.</li> </ul>

Parameter	Description
	To configure the key, use the 'Request Key' parameter (see below).
'Request Key' request-key [AttributesToQuery]	<p>Defines the key to query.</p> <ul style="list-style-type: none"> <li>■ For LDAP, the key string is queried on the LDAP server.</li> <li>■ For Dial Plans, the key string is searched in the specified Dial Plan.</li> <li>■ For ENUM, the key string is queried on the ENUM server.</li> <li>■ For HTTP GET and HTTP POST queries, the key string is queried on the HTTP server.</li> </ul> <p>The valid value is a string of up to 100 characters. Combined strings and values can be configured like in the Message Manipulations table, using the '+' operator. Single quotation marks (') can be used for specifying a constant string (e.g., '12345').</p> <p>You can use the built-in syntax editor to help you configure the field. Click the <b>Editor</b> button located alongside the field to open the Editor, and then simply follow the on-screen instructions.</p> <p>Examples:</p> <ul style="list-style-type: none"> <li>■ To LDAP query the AD attribute "mobile" that has the value of the destination user part of the incoming call: <div>'mobile=' + param.call.dst.user</div> </li> <li>■ To LDAP query the AD attribute "telephoneNumber" that has a redirect number: <div>'telephoneNumber=' + param.call.redirect + '*'</div> </li> <li>■ To query a Dial Plan for the source number: <div>param.call.src.user</div> </li> <li>■ To query an ENUM server for the URI of the called (destination) number: <div>param.call.dst.user</div> </li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>To send an HTTP POST to notify the HTTP server of call connection status:</li> </ul> <div>'connectionStatus'</div> <p><b>Note:</b> The parameter is applicable only if the 'Request Type' parameter is configured to any value other than <b>None</b>.</p>
'Attributes To Get' attr-to-get [AttributesToGet]	<p>Defines the Attributes of the queried LDAP record that the device must handle (e.g., retrieve value).</p> <p>The valid value is a string of up to 255 characters. Up to five attributes can be defined, each separated by a comma (e.g., msRTCSIP-PrivateLine,msRTCSIP-Line,mobile).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The parameter is applicable only if you configure the 'Request Type' parameter to <b>LDAP</b>.</li> <li>The device saves the retrieved attributes' values for future use in other rules until the next LDAP query or until the call is connected. Thus, the device doesn't need to re-query the same attributes.</li> </ul>
'Row Role' row-role [RowRole]	<p>Defines which condition (as configured in the 'Condition' parameter) must be met for this rule to be run.</p> <ul style="list-style-type: none"> <li>[0] <b>Use Current Condition</b> = (Default) The Condition configured for this rule must be met to run the configured action.</li> <li>[1] <b>Use Previous Condition</b> = The Condition configured for the rule located directly above this rule in the Call Setup table must be met to run the configured action. This option lets you configure multiple actions for the same Condition.</li> </ul>
'Condition' condition [Condition]	<p>Defines the condition that must exist for the device to run the configured action of the Call Setup rule.</p> <p>The valid value is a string of up to 200 characters (case-insensitive). You can also use regular expression (regex).</p> <p>You can use the built-in syntax editor to help configure the parameter. Click the <b>Editor</b> button located next to the field to open the Editor, and then simply follow the on-screen instructions.</p> <p>Examples:</p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ LDAP: <ul style="list-style-type: none"> <li>✓ ldap.attr.mobile exists (if Attribute "mobile" exists in AD)</li> <li>✓ param.call.dst.user == ldap.attr.msRTCSIP-PrivateLine (if called number is the same as the number in the Attribute "msRTCSIP-PrivateLine")</li> <li>✓ ldap.found !exists (if LDAP record not found)</li> <li>✓ ldap.err exists (if LDAP error exists)</li> </ul> </li> <li>■ Dial Plan: <ul style="list-style-type: none"> <li>✓ dialplan.found exists (if Dial Plan exists)</li> <li>✓ dialplan.found !exists (if Dial Plan queried key not found)</li> <li>✓ dialplan.result=='uk' (if corresponding tag of the searched key is "uk")</li> </ul> </li> <li>■ ENUM: <ul style="list-style-type: none"> <li>✓ enum.found exists (if ENUM record of E.164 number exists)</li> </ul> </li> <li>■ HTTP GET or HTTP POST: <ul style="list-style-type: none"> <li>• http.response.status == '200' (if the HTTP server responds with a 200 OK)</li> </ul> </li> </ul>
Action	
'Action Subject' action-subject [ActionSubject]	<p>Defines the element (e.g., SIP header, SIP parameter, SIP body, or Dial Plan tag) upon which you want to run the action if the condition (configured in the 'Condition' parameter above) is met. The valid value is a string of up to 100 characters (case-insensitive). You can use the built-in syntax editor to help you configure the field. Click the <b>Editor</b> button located alongside the field to open the Editor, and then simply follow the on-screen instructions.</p> <p>Examples:</p> <ul style="list-style-type: none"> <li>■ header.from contains '1234' (SBC application only)</li> <li>■ param.call.dst.user (called number)</li> <li>■ param.call.src.user (calling number)</li> <li>■ param.call.src.name (calling name)</li> <li>■ param.call.redirect (redirect number)</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ param.call.src.host (source host)</li> <li>■ param.call.dst.host (destination host)</li> <li>■ srctags (source tag)</li> <li>■ dsttags (destination tag)</li> <li>■ referredbytags (tag of transferor, which initiates call transfer)</li> <li>■ header.content-type (for HTTP POST requests)</li> </ul>
'Action Type' action-type [ActionType]	<p>Defines the type of action to run.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>None</b> = No action is run. This option is typically used for HTTP POST requests that are used for notifying the HTTP server (e.g., when the 'Request Type' parameter is configured to <b>HTTP POST Notification</b>). If you configure the parameter to this option and it is the last rule in the table, the device runs the rule and then exits the table. If it is not the last rule, the device runs the rule and then checks the next rule.</li> <li>■ [0] <b>Add</b> = (Default) Adds a new message header, parameter, or body elements.</li> <li>■ [1] <b>Remove</b> = Removes a message header, parameter, or body elements.</li> <li>■ [2] <b>Modify</b> = Sets the element to the new value (all element types).</li> <li>■ [3] <b>Add Prefix</b> = Adds a value at the beginning of the string (string element only).</li> <li>■ [4] <b>Add Suffix</b> = Adds a value at the end of the string (string element only).</li> <li>■ [5] <b>Remove Suffix</b> = Removes a value from the end of the string (string element only).</li> <li>■ [6] <b>Remove Prefix</b> = Removes a value from the beginning of the string (string element only).</li> <li>■ [20] <b>Run Rules Set</b> = Runs a different Rule Set ID, which is specified in the 'Action Value' parameter (see below)</li> <li>■ [21] <b>Exit</b> = Stops running the remaining rules in the Rule Set ID and returns a result ("true", "false", or "abort").</li> </ul>
'Action Value' action-value	<p>Defines a value for the action.</p> <p>The valid value is a string of up to 300 characters (case-</p>



Parameter	Description
[ActionValue]	<p>insensitive). You can use the built-in syntax editor to help configure the field. Click the <b>Editor</b> button located next to the field to open the Editor, and then simply follow the on-screen instructions.</p> <p>Examples:</p> <ul style="list-style-type: none"> <li>■ '+9723976'+ldap.attr.alternateNumber</li> <li>■ '9764000'</li> <li>■ ldap.attr.displayName</li> <li>■ enum.result.url</li> <li>■ srctags</li> <li>■ http.response.body</li> <li>■ application/x-www-form-urlencoded (for HTTP Content-Type header in HTTP requests)</li> <li>■ <b>True</b></li> <li>■ <b>False</b></li> <li>■ <b>Abort</b></li> </ul> <p><b>Note:</b> The values <b>True</b>, <b>False</b>, and <b>Abort</b> are applicable only when the 'Action Type' parameter is configured to <b>Exit</b> and only when the Call Setup rule is run from the IP-to-IP Routing table. For a description of these values, see the first part of this section.</p>

## Examples of Call Setup Rules

Below are configuration examples of Call Setup Rules.

- **Example 1:** This example configures the device to replace (manipulate) the incoming call's source number with a number retrieved from the Microsoft Active Directory (AD) by an LDAP query. The device queries the AD server for the attribute record, "telephoneNumber" whose value is the same as the received source number (e.g., "telephoneNumber=4064"). If such an Attribute exists, the device retrieves the number of the attribute record, "alternateNumber" and uses this number as the source number.

- **Call Setup Rules Table:**
  - ◆ 'Rules Set ID': **1**
  - ◆ 'Request Type': **LDAP**
  - ◆ 'Request Target': **LDAP-DC-CORP**
  - ◆ 'Request Key': **'telephoneNumber=' + param.call.src.user**

- ◆ 'Attributes to Get': **alternateNumber**
- ◆ 'Row Role': **Use Current Condition**
- ◆ 'Condition': **ldap.attr.alternateNumber exists**
- ◆ 'Action Subject': **param.call.src.user**
- ◆ 'Action Type': **Modify**
- ◆ 'Action Value': **ldap.attr.alternateNumber**
- **IP-to-IP Routing Table:**
  - ◆ (Index 1) 'Call Setup Rules Set ID' or 'Pre Route Call Setup Rules Set ID': **1**

■ **Example 2:** This example configures the device to replace (manipulate) the incoming call's calling name (caller ID) with a name retrieved from the AD by an LDAP query. The device queries the AD server for the attribute record "telephoneNumber" whose value is the same as the received source number (e.g., "telephoneNumber=5098"). If such an attribute is found, the device retrieves the name from the attribute record "displayName" and uses it as the calling name of the incoming call.

- **Call Setup Rules Table:**
  - ◆ 'Rules Set ID': **2**
  - ◆ 'Request Type': **LDAP**
  - ◆ 'Request Target': **LDAP-DC-CORP**
  - ◆ 'Request Key': **'telephoneNumber=' + param.call.src.user**
  - ◆ 'Attributes to Get': **displayName**
  - ◆ 'Row Role': **Use Current Condition**
  - ◆ 'Condition': **ldap.attr.displayName exists**
  - ◆ 'Action Subject': **param.call.src.name**
  - ◆ 'Action Type': **Modify**
  - ◆ 'Action Value': **ldap.attr.displayName**
- **IP-to-IP Routing table:** A single routing rule is assigned the Call Setup Rule Set ID.
  - ◆ (Index 1) 'Call Setup Rules Set ID' or 'Pre Route Call Setup Rules Set ID': **2**

■ **Example 3:** This example configures the device to route the incoming call according to whether or not the source number of the incoming call also exists in the AD server. The device queries the AD server for the attribute record "telephoneNumber" whose value is the same as the received source number (e.g., telephoneNumber=4064"). If such an attribute is found, the device sends the call to Teams. If the query fails, the device sends the call to the PBX (i.e., alternative routing).

- **Call Setup Rules Table:**
  - ◆ 'Rules Set ID': **3**

- ◆ 'Request Type': **LDAP**
- ◆ 'Request Target': **LDAP-DC-CORP**
- ◆ 'Request Key': **'telephoneNumber=' + param.call.src.user**
- ◆ 'Attributes to Get': **telephoneNumber**
- ◆ 'Row Role': **Use Current Condition**
- ◆ 'Condition': **ldap.found !exists**
- ◆ 'Action Subject': **-**
- ◆ 'Action Type': **Exit**
- ◆ 'Action Value': **False**

If the attribute record is found (i.e., condition not met), the rule ends with a default exit result of "true" and uses the first routing rule (Teams). If the attribute record doesn't exist (i.e., condition met), the rule exits with a "false" result and uses the second routing rule (PBX).

- **IP-to-IP Routing Table:** Two routing rules are assigned with the same matching characteristics. Only the main routing rule is assigned a Call Setup Rules Set ID.
  - ◆ 'Index': **1**
  - ◆ 'Call Setup Rules Set ID' or 'Pre Route Call Setup Rules Set ID': **3**
  - ◆ 'Destination IP Group ID': **3** (IP Group for Teams)
  - ◆ 'Index': **2**
  - ◆ 'Destination IP Group ID': **4** (IP Group for PBX)

■ **Example 4:** This example uses the msRTCSIP-DeploymentLocator AD attribute to determine if a user has migrated to Teams or not. If the LDAP query fails (attribute doesn't exist), the call fails and the device doesn't attempt (stops / aborts) to route the call, even if alternative routing rules exist.

- **Call Setup Rules Table:**
  - ◆ 'Rules Set ID': **1**
  - ◆ 'Request Type': **LDAP**
  - ◆ 'Request Target': **LDAP-DC-CORP**
  - ◆ 'Request Key': **'(&(msRTCSIP-DeploymentLocator=SRV:)(msRTCSIP-Line=tel:'+param.call.dst.user+'\*))'**
  - ◆ 'Attributes to Get': **msRTCSIP-DeploymentLocator**
  - ◆ 'Row Role': **Use Current Condition**
  - ◆ 'Condition': **ldap.attr.msRTCSIP-DeploymentLocator !exists**
  - ◆ 'Action Type': **Exit**

- ◆ 'Action Value': **Abort**
- **IP-to-IP Routing table:**
  - ◆ (Index 1) 'Call Setup Rules Set ID' or 'Pre Route Call Setup Rules Set ID': **1**

■ **Example 5:** This example enables routing based on LDAP queries and destination tags for matching routing rules. The device queries the LDAP server for the attribute record "telephoneNumber" whose value is the destination number of the incoming call (e.g., "telephoneNumber=4064"). If the attribute-value combination is found, the device retrieves the string value of the attribute record "ofiSBCRouting" and creates a destination tag with the name of the retrieved string. The destination tag is then used as a matching characteristics in the IP-to-IP Routing table.

- **Call Setup Rules Table:**
  - ◆ 'Rules Set ID': **4**
  - ◆ 'Request Type': **LDAP**
  - ◆ 'Request Target': **LDAP-DC-CORP**
  - ◆ 'Request Key': **'telephoneNumber='+param.call.dst.user**
  - ◆ 'Attributes to Get': **ofiSBCRouting**
  - ◆ 'Row Role': **Use Current Condition**
  - ◆ 'Condition': **ldap.found exists**
  - ◆ 'Action Subject': **dsttags**
  - ◆ 'Action Type': **Modify**
  - ◆ 'Action Value': **ldap.attr.ofiSBCrouting**
- **IP Groups Table:** 'Call Setup Rules Set ID': **4**
- **IP-to-IP Routing Table:**
  - ◆ 'Index': **1**
  - ◆ 'Destination Tag': **dep-sales**
  - ◆ 'Destination IP Group': **SALES**
  - ◆ 'Index': **2**
  - ◆ 'Destination Tag': **dep-mkt**
  - ◆ 'Destination IP Group': **MKT**
  - ◆ 'Index': **3**
  - ◆ 'Destination Tag': **dep-rd**
  - ◆ 'Destination IP Group': **RD**

■ **Example 6:** This example enables routing based on LDAP queries and destination tags for matching destination IP Groups. The device queries the LDAP server for the attribute

record "telephoneNumber" whose value is the destination number of the incoming call (e.g., "telephoneNumber=4064"). If the attribute-value combination is found, the device retrieves the string value of the attribute record "CountryOfResidence" and creates a destination tag with the name of the retrieved string. The value of the destination tag name is then used as a matching characteristics of the IP Group.

- **Call Setup Rules Table:**
  - ◆ 'Rules Set ID': **4**
  - ◆ 'Request Type': **LDAP**
  - ◆ 'Request Target': **LDAP-DC-CORP**
  - ◆ 'Request Key': **'telephoneNumber='+param.call.dst.user**
  - ◆ 'Attributes to Get': **CountryOfResidence**
  - ◆ 'Row Role': **Use Current Condition**
  - ◆ 'Condition': **ldap.found exists**
  - ◆ 'Action Subject': **DstTags.Country**
  - ◆ 'Action Type': **Modify**
  - ◆ 'Action Value': **ldap.attr.CountryOfResidence**
- **IP Groups Table:**
  - ◆ 'Index': **1**
  - ◆ 'Tags': **Country=UK**
  - ◆ 'Index': **2**
  - ◆ 'Tags': **Country=FR**
- **IP-to-IP Routing Table:**
  - ◆ 'Destination Type': **Destination Tag**
  - ◆ 'Pre Route Call Setup Rules Set ID': **4**
  - ◆ 'Routing Tag Name': **Country**

■ **Example 7:** This example configures the device to run an ENUM query with an ENUM server to retrieve a SIP URI address for the called E.164 telephone number. The device then replaces (manipulates) the incoming call's E.164 destination number in the SIP Request-URI header with the URI retrieved from the ENUM server. The ENUM server's address is the address configured in the 'Primary DNS' parameter for the "ITSP-450" IP Interface in the IP Interfaces table.

- **Call Setup Rules Table:**
  - ◆ 'Index': **0**
  - ◆ 'Rules Set ID': **4**

- ◆ 'Request Type': **ENUM**
- ◆ 'Request Target': **ITSP-450**
- ◆ 'Request Key': **param.call.dst.user**
- ◆ 'Condition': **enum.found exists**
- ◆ 'Action Subject': **header.request-uri.url**
- ◆ 'Action Type': **Modify**
- ◆ 'Action Value': **enum.result.url**
- **IP Groups Table:**
  - ◆ 'Call Setup Rules Set ID': **4**

■ **Example 8:** For an example on HTTP GET operations, see [Configuring an HTTP GET Web Service](#) on page 447.

■ **Example 9:** For an example on HTTP POST (notification) operations, see [Configuring HTTP POST Web Service](#) on page 450.

## Configuring Dial Plans

Dial Plans let you categorize incoming calls (source or destination) based on source or destination number. The device categorizes them by searching in the Dial Plan for rules that match these numbers according to prefix, suffix, or whole number. The categorization result in the Dial Plan is a *tag* corresponding to the matched rule. You can then use tags to represent these calls (source or destination) as matching characteristics (source or destination tags) for various configuration entities:

- SBC application:
  - IP-to-IP Routing rules (see [Using Dial Plan Tags for SBC IP-to-IP Routing](#) on page 813)
  - Outbound Manipulations rules ([Using Dial Plan Tags for SBC Outbound Manipulation](#) on page 821)
  - Call Setup Rules ([Using Dial Plan Tags for Call Setup Rules](#) on page 821)
  - Message Manipulation ([Using Dial Plan Tags for Message Manipulation](#) on page 824)

You can assign a Dial Plan to an IP Group or SRD. After Classification and Inbound Manipulation, the device checks if a Dial Plan is associated with the incoming call. It first checks the source IP Group and if no Dial Plan is assigned, it checks the SRD. If a Dial Plan is assigned to the IP Group or SRD, the device first searches the Dial Plan for a dial plan rule that matches the source number and then it searches the Dial Plan for a rule that matches the destination number. If matching dial plan rules are found, the tags configured for these rules are used in the routing or manipulation processes as source or destination tags.



In addition to using the source tag (SrcTags) and destination tag (DstTags) in the Call Setup Rules table and Message Manipulations table, you can also use the referred-by tag (ReferredByTags). This tag represents the call party that initiated (i.e., transferor) the call transfer.

■ Gateway application:


- IP-to-Tel Routing rules (see [Configuring IP-to-Tel Routing Rules](#) on page 928)
- Tel-to-IP Routing rules (see [Configuring Tel-to-IP Routing Rules](#) on page 914)



Notes for the SBC application:

- User categorization by Dial Plan is done only after the device's Classification and Inbound Manipulation processes, and before the routing process.
- Once the device successfully categorizes an incoming call by Dial Plan, it not only uses the resultant tag in the immediate routing or manipulation process, but also in subsequent routing and manipulation processes that may occur, for example, due to alternative routing or local handling of call transfer and call forwarding (SIP 3xx\REFER).
- For manipulation, tags are applicable only to outbound manipulation.
- When tags are used in the IP-to-IP Routing table to determine destination IP Groups (i.e., 'Destination Type' parameter configured to **Destination Tag**), the device searches the Dial Plan for a matching **destination** (called) prefix number only.

The figure below shows a conceptual example of routing based on tags, where users categorized as tag "A" are routed to SIP Trunk "X" and those categorized as tag "B" are routed to SIP Trunk "Y":



The Dial Plan itself is a set of dial plan rules having the following attributes:

- **Prefix:** The prefix is matched against the source or destination number of the incoming call (e.g., SIP dialog-initiating request for IP calls).
- **Tag:** The tag corresponds to the matched prefix of the source or destination number and is the categorization result.

You can use various syntax notations to configure the prefix numbers in Dial Plan rules. You can configure the prefix as a complete number (all digits) or as a partial number using some digits and various syntax notations (patterns) to allow the device to match a Dial Plan rule for similar source or destination numbers. The device also employs a "best-match" method instead of a "first-match" method to match the source or destination numbers to the patterns configured in the Dial Plan. For more information, see the description of the 'Prefix' parameter (DialPlanRule\_Prefix) described later in this section or see [Dial Plan Notations and Priority Matching](#) on page 804.



- The maximum group of numbers (consisting of single numbers or range of numbers, or both) that can be configured for prefixes and suffixes for all the Dial Plan rules can be calculated by multiplying the maximum number of supported Dial Plan rules by six. For example, if the maximum number of Dial Plan rules is 100, then the maximum group of numbers is 600 (6\*100). The following is an example of a Dial Plan rule that is configured with six groups of numbers (each separated by a comma), consisting of ranges and single numbers: [120-125,150,160-164,170,200,210-215]
- You can forcibly disconnect calls that match a specific Dial Plan tag, using the CLI command `clear voip calls tag`.

Dial Plans are configured using two tables with "parent-child" relationship:

- Dial Plan table ("parent" table): Defines the name of the Dial Plan. You can configure up to 10 Dial Plans.
- Dial Plan Rule table ("child" table): Defines the actual dial plans (rules) per Dial Plan. You can configure up to 2,000 of Dial Plan rules in total (where all can be configured for one Dial Plan or configured between different Dial Plans).

The following procedure describes how to configure Dial Plans through the Web interface. You can also configure it through other management platforms:

- **Dial Plan table:** *ini* file [DialPlan] or CLI (`configure voip > sbc dial-plan`)
- **Dial Plan Rule table:** *ini* file (DialPlanRule) or CLI (`configure voip > sbc dial-plan-rule`)

#### ➤ To configure Dial Plans:

1. Open the Dial Plan table (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **Dial Plan**).
2. Click **New**; the following dialog box appears:

GENERAL	
Index	2
Name	
Prefix Case Sensitivity	Enable



3. Configure a Dial Plan name according to the parameters described in the table below.
4. Click **Apply**.

**Table 20-5: Dial Plan Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [Name]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 15 characters. <b>Note:</b> <ul style="list-style-type: none"> <li>■ Configure each row with a unique name.</li> <li>■ The parameter value cannot contain a forward slash (/).</li> </ul>
'Prefix Case Sensitivity' prefix-case-sensitivity [PrefixCaseSensitivity]	Enables the matching process for the Dial Plan's prefix patterns, configured for its Dial Plan rules, to take into consideration the case (upper or lower) of alphabetical letters. <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = Case-insensitive - the Dial Plan matching process ignores the case of the letters of the prefix pattern.</li> <li>■ [1] <b>Enable</b> = (Default) Case-sensitive - the Dial Plan matching process takes into consideration the case of the letters of the prefix pattern.</li> </ul> <b>Note:</b> The wildcards "n", "x", and "z" are always case-insensitive.

5. In the Dial Plan table, select the row for which you want to configure dial plan rules, and then click the **Dial Plan Rule** link located below the table; the Dial Plan Rule table appears.
6. Click **New**; the following dialog box appears:

Dial Plan Rule
— x

GENERAL

Index

1

Name

Prefix

Tag

7. Configure a dial plan rule according to the parameters described in the table below.
8. Click **New**, and then save your settings to flash memory.

**Table 20-6: Dial Plan Rule Table Parameter Descriptions**

Parameter	Description
'Index' index [DialPlanRule_RuleIndex]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [DialPlanRule_Name]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 15 characters.
'Prefix' prefix [DialPlanRule_Prefix]	Defines the pattern to match the number (source or destination number) of the incoming call. The pattern can match the number based on prefix, suffix, or entire number. The valid value is a string of up to 50 characters. For valid notations and syntax, see <a href="#">Dial Plan Notations and Priority Matching</a> on page 804. <b>Note:</b> Dial Plan patterns can be case-sensitive or case-insensitive, depending on the 'Prefix Case Sensitive' parameter settings.
'Tag' tag [DialPlanRule_Tag]	Defines a tag(s). You must configure the tag with a name (e.g., "India") and optionally, with a value (i.e., name=value), for example, "Country=India", where "Country" is the tag's name and "India" is the tag's value. For guidelines on configuring tags, see the notes below. The valid value is a string of up to 70 characters: <ul style="list-style-type: none"> <li>■ The tag's name can contain only the following characters: <ul style="list-style-type: none"> <li>✓ Alphanumeric characters (i.e., a-z, A-Z, and 0-9)</li> <li>✓ Special characters: <ul style="list-style-type: none"> <li>• - (dash or hyphen)</li> <li>• ! (exclamation)</li> <li>• % (percentage)</li> <li>• * (asterisk)</li> <li>• _ (underscore)</li> <li>• ~ (tilde)</li> </ul> </li> </ul> </li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>• @ (at sign)</li> </ul> <ul style="list-style-type: none"> <li>■ The tag's value can contain any character, except the following: <ul style="list-style-type: none"> <li>✓ = (equal)</li> <li>✓ ; (semicolon)</li> <li>✓ Spaces (including tab spaces)</li> </ul> </li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The tag is case-insensitive.</li> <li>■ You can configure a rule with multiple tags, where each is separated with a semicolon (;). For example:  "Belgium;Country1=England;Country2=India;Country3=10.1.1.1"</li> <li>■ If you configure a rule with multiple tags, you can configure only one tag that has a <b>name only</b> (i.e., without a value). All the other tags must have a name and value (name=value). For example:  "Belgium;England" is invalid as both tags have only names.  "Belgium;Country1=England;Country2=India" is valid as only one tag has only a name ("Belgium"); the others have names and values.</li> <li>■ If you configure a rule with multiple tags, for the tags that have a name and value (i.e., name=value), the name must be unique. For example:  "<b>Country</b>=England;<b>Country</b>=India" is invalid as the tag name "Country" appears twice.  "<b>Country1</b>=England;<b>Country2</b>=India" is valid.</li> <li>■ You can configure multiple rules with the same tag, but each of these rules must have a different prefix (see 'Prefix' parameter).</li> <li>■ In configuration tables that contain fields for assigning tags (e.g., IP-to-IP Routing table), if the field is left empty or configured with a single asterisk (*), any tag can match it.</li> </ul>

## Dial Plan Notations and Priority Matching

This section describes the [Dial Plan Notations](#) below you can use in your Dial Plan rules and the [Dial Plan Matching Priority](#) on page 807 between rules.

### Dial Plan Notations

The notations that you can use for configuring the 'Prefix' field in the Dial Plan Rule table are described in the table below. As this field is used in the Dial Plan to match a number pattern (source or destination) based on prefix, suffix or entire number, the notations are relevant to both prefix and suffix of the number (unless explicitly stated otherwise).

Notation	Description
<b>0-9</b>	Specific digit.
<b>a-z</b>	Lower-case letter. <b>Note:</b> Case-sensitivity of Dial Plan matching depends on the settings of the 'Prefix Case Sensitivity' parameter in the Dial Plan table.
<b>A-Z</b>	Upper-case letter. <b>Note:</b> Case-sensitivity of Dial Plan matching depends on the settings of the 'Prefix Case Sensitivity' parameter in the Dial Plan table.
<b>x</b>	Wildcard (metacharacter) that represents any single digit from 0 through 9. <b>Note:</b> <ul style="list-style-type: none"> <li>The wildcard is case-insensitive.</li> <li>To represent the character "x", precede it with the escape "\" character. For example, to represent an upper-case "X", use this syntax: \X</li> </ul>
<b>z</b>	Wildcard (metacharacter) that represents any single digit from 1 through 9. <b>Note:</b> <ul style="list-style-type: none"> <li>The wildcard is case-insensitive.</li> <li>To represent the character "z", precede it with the escape "\" character. For example, to represent a lower-case "z", use this syntax: \z</li> </ul>
<b>n</b>	Wildcard (metacharacter) that represents any single digit from 2 through 9. <b>Note:</b>

Notation	Description
	<ul style="list-style-type: none"> <li>■ The wildcard is case-insensitive.</li> <li>■ To represent the character "n", precede it with the escape "\" character. For example, to represent an upper-case "N", use this syntax: \N</li> </ul>
.	<p>(Dot) Wildcard (metacharacter) that represents any single character (letter, digit or symbol).</p> <p>To represent the dot "." character itself, precede it with the escape "\" character (see below).</p>
*	<p>(Asterisk symbol) If it is the only character in the rule, it functions as a wildcard (metacharacter) that represents any amount of digits or letters (i.e., matches everything).</p> <p>To represent the asterisk "*" symbol itself, precede it with the escape "\" character (see below).</p> <p><b>Note:</b> You can't use a non-escaped * as part of the rule. For example, the following are invalid rules: "333*" or "192\168\0\.*"</p>
\	<p>(Backslash escape character) When it prefixes the wildcard character "n", "x", "z", or ".", the character is escaped and used literally instead of the wildcard function.</p> <p>For example, "10\255\255\." represents the IP address 10.255.255.[0-9]. As each dot (.) is prefixed by a backslash, the device considers these dots as the "." character (and not the . wildcard). In addition, as the "x" at the end of the value is not prefixed by a backslash, the device considers it the x wildcard.</p>
#	<p>(Pound or hash symbol) When used at the end of the prefix, it represents the end of the number.</p> <p>Examples:</p> <ul style="list-style-type: none"> <li>■ 54324#: Represents the 5-digit number "54324".</li> <li>■ 192\168\1\.[1-9]# and 192\168\1\.[01-96]#: Represent IP addresses 192.168.1.1 to 192.168.1.96</li> </ul>
[n1-m1,n2-m2,a,b,c,...]	<p>Represents a range of numbers for the prefix. The range can include both contiguous numbers and standalone numbers.</p> <p>Examples:</p> <ul style="list-style-type: none"> <li>■ [123-130]: Represents a prefix number "123" through "130".</li> <li>■ [123-130,455,766,780-790]: Represents a prefix number from "123" through "130", "455", "766", or "780" through 790".</li> </ul>

Notation	Description
	<ul style="list-style-type: none"> <li>■ [123,125,130]: Represents a prefix number “123”, “125”, or “130”.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The range (number ranges and single numbers) must contain the same amount of digits, as shown in the examples above where the number ranges and single numbers all contain three digits.</li> <li>■ The device matches the numbers in the range and not the individual digits that make up the numbers. For example, if the rule’s pattern is “[001-130]”, the device matches strings such as “002”, “012”, “129” or “1001”; it doesn’t match strings “2”, “12”, “301” or “0002”.</li> <li>■ You can’t use an empty range (e.g., “+91[]”).</li> <li>■ Ranges can contain only digits (i.e., letters are not allowed).</li> <li>■ The mixed notation can be configured with up to 19 digits, for example, “[1234567891234567890,1234567891234567891]”.</li> <li>■ The range (start and end) cannot be greater than 2,147,483,647, as in the example (which is invalid) “[20000000001-40000000001]”.</li> </ul>
([...])	<p>Represents a range of numbers for the suffix.</p> <p>The range can include both contiguous numbers and standalone numbers.</p> <p>Examples:</p> <ul style="list-style-type: none"> <li>■ ([123-130]): Represents a suffix number “123” through “130”.</li> <li>■ ([123-130,455,766,780-790]): Represents a suffix number from “123” through “130”, “455”, “766”, or “780” through “790”.</li> <li>■ [123,125,130]: Represents a suffix number “123”, “125”, or “130”.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The range (number ranges and single numbers) must contain the same amount of digits, as shown in the examples above where the number ranges and single numbers all contain three digits.</li> <li>■ The device matches the numbers in the range and not the individual digits that make up the numbers. For example, if the rule’s pattern is “([001-130])”, the device matches strings such as “002”, “012”, “129” or “9129”; it doesn’t match strings “2”, “12”, “302” or “0200”.</li> <li>■ You can’t use an empty suffix range (e.g., “+91([])”).</li> <li>■ Ranges can contain only digits (i.e., letters are not allowed).</li> <li>■ The mixed notation can be configured with up to 19 digits, for example, “([1234567891234567890,1234567891234567891])”.</li> </ul>

Notation	Description
	<ul style="list-style-type: none"> <li>The range (start and end) cannot be greater than 2,147,483,647, as in the example (which is invalid) "[20000000001-40000000001]".</li> </ul>
(...)	<p>Represents a specific suffix, which can contain digits and letters. Examples:</p> <ul style="list-style-type: none"> <li>[123-130](456): represent a number whose prefix number is "123" through "130" and whose suffix is "456".</li> <li>123(UK): represent a number whose prefix number is "123" and whose suffix is "UK".</li> </ul> <p><b>Note:</b> You can't use an empty suffix (e.g., "+91()").</p>

### Dial Plan Matching Priority

The device employs a "best-match" method instead of a "first-match" method to match the source or destination numbers to prefixes configured in the Dial Plan.

The matching order is done digit-by-digit and from left to right.

The **best match-priority** is listed below in chronological order:

1. Specific prefix.
2. "x" wildcard, which denotes any digit (0 through 9).
3. Number range.
4. "n" wildcard, which denotes a number from 2 through 9.
5. "z" wildcard, which denotes a number from 1 through 9.
6. Suffix, where the longest digits is first matched, for example, ([001-999]) takes precedence over ([01-99]) which takes precedence over ([1-9]).
7. "." (dot), which denotes any single character.

For example, the following table shows best matching priority for an incoming call with prefix number "5234":

**Table 20-7: Dial Plan Best Match Priority**

Dial Plan Prefix	Best Match Priority (Where 1 is Highest)
5234	1
523x	2
523[2-6]	3

Dial Plan Prefix	Best Match Priority (Where 1 is Highest)
523n	4
523z	5
523(4)	6
523.	7

When number ranges are used in Dial Plan rules (comma-separated standalone numbers or hyphenated range), best match priority is as follows:

- Dial Plan rules with ranges of **multiple standalone numbers**: The device chooses the matching rule in the Dial Plan Rule table that has the lowest row index number (i.e., listed higher up in the table). For example, if the prefix number of an incoming call is "110" and you have configured the below rules, the device chooses Index #0 because it has the lowest row index number (even though more numbers match the incoming call prefix number).

Index	Prefix
0	[1,3,5]
1	[110,120]

- Dial Plan rules with ranges of **contiguous numbers and the amount of possible matched numbers is identical**: The device chooses the matching rule in the Dial Plan Rule table that has the lowest row index number (i.e., listed higher up in the table). For example, if the prefix number of an incoming call is "110" and you have configured the below rules (each rule has a range of 3 possible matching numbers), the device chooses Index #0 because it has the lowest row index number (even though more numbers match the incoming call prefix number).

Index	Prefix
0	[1-3]
1	[10-12]

- Dial Plan rules with ranges of **contiguous number and the amount of possible matched numbers is different**: The device chooses the matching rule in the Dial Plan Rule table that has the least amount of numbers. For example, if the prefix number of an incoming call is "110" and you have configured the below rules (Index #0 with 7 possible matched numbers and Index #1 with 3 possible matched numbers), the device chooses Index #1 because it has less numbers.

Index	Prefix
-------	--------



0	[1-7]
1	[10-12]

- Dial Plan rules with ranges of **contiguous number** and **multiple standalone numbers**: The device chooses the matching rule in the Dial Plan Rule table that has the standalone number range (not contiguous range). For example, if the prefix number of an incoming call is "110" and you have configured the below rules (Index #0 is a standalone number range and Index #1 a contiguous range), the device chooses Index #0 because it is the standalone number range.

Index	Prefix
0	[1,2,3,4,5]
1	[1-3]

Additional examples of best match priority for Dial Plan rules configured with a specific number and optionally followed by the "x" notation or prefix or suffix range are shown below:

- For incoming calls with prefix number "5234", the rule with tag B is chosen (more specific for digit "4"):

Index	Prefix	Tag
0	523x	A
1	5234	B

- For incoming calls with prefix number "5234", the rule with tag A is chosen (see match priority above):

Index	Prefix	Tag
0	523x	A
1	523[1-9]	B

- For incoming calls with prefix number "53211111", the rule with tag B is chosen (more specific for fourth digit):

Index	Prefix	Tag
0	532[1-9]1111	A
1	5321	B

- For incoming calls with prefix number "53124", the rule with tag B is chosen (more specific for digit "1"):

Index	Prefix	Tag
0	53([2-4])	A
1	531(4)	B

- For incoming calls with prefix number "321444", the rule with tag A is chosen and for incoming calls with prefix number "32144", the rule with tag B is chosen:

Index	Prefix	Tag
0	321xxx	A
1	321	B

- For incoming calls with prefix number "5324", the rule with tag B is chosen (prefix is more specific for digit "4"):

Index	Prefix	Tag
0	532[1-9]	A
1	532[2-4]	B

- For incoming calls with prefix number "53124", the rule with tag C is chosen (longest suffix - C has three digits, B two digits and A one digit):

Index	Prefix	Tag
0	53([2-4])	A
1	53([01-99])	B
2	53([001-999])	C

- For incoming calls with prefix number "53124", the rule with tag B is chosen (suffix is more specific for digit "4"):

Index	Prefix	Tag
0	53([2-4])	A
1	53(4)	B

## Importing Dial Plans


You can import (upload) Dial Plans and Dial Plan Rules to the device from a comma-separated value (CSV) file located on your local PC running the Web client.



- For creating Dial Plans in a CSV file, see [Creating Dial Plan Files](#) on the next page.
- You can also import (upload) Dial Plans and Dial Plan rules from a file on a remote server, using the device's CLI: `configure voip > sbc dial-plan > import-csv-from`. For more information, refer to the *CLI Reference Guide*.

### ➤ To overwrite all existing Dial Plans with imported Dial Plan:

1. Open the Dial Plan table.
2. From the 'Action' drop-down menu, choose **Import**; the following dialog box appears:



3. Use the **Browse** button to select the Dial Plan file on your PC, and then click **OK**.




- The file import feature only imports rules of Dial Plans that already exist in the Dial Plan table. If a Dial Plan in the file doesn't exist in the table, the specific Dial Plan is not imported.
- Make sure that the names of the Dial Plans in the imported file are **identical** to the existing Dial Plan names in the Dial Plan table; otherwise, Dial Plans in the file with different names are not imported.
- When importing a file, the rules in the imported file replace all existing rules of the corresponding Dial Plan. For existing Dial Plans in the Dial Plan table that are not listed in the imported file, the device deletes all their rules. For example, if the imported file contains only the Dial Plan "MyDialPlan1" and the device is currently configured with "MyDialPlan1" and "MyDialPlan2", the rules of "MyDialPlan1" in the imported file replace the rules of "MyDialPlan1" on the device, and the rules of "MyDialPlan2" on the device are deleted (the Dial Plan name itself remains).

### ➤ To import Dial Plan rules for a specific Dial Plan:

1. Open the Dial Plan table.

2. Select the required Dial Plan, and then click the **Dial Plan Rule** link; the Dial Plan Rule table opens, displaying all the rules of the selected Dial Plan.
3. From the 'Action' drop-down menu, choose **Import**; the following dialog box appears:



4. Use the **Browse** button to select the Dial Plan file on your PC, and then click **OK**.



The rules in the imported file replace **all** existing rules of the specific Dial Plan.

### Creating Dial Plan Files

You can configure Dial Plans in an external file (\*.csv) and then import them into the device, as described in [Importing Dial Plans](#) on the previous page. You can create the file using any text-based editor such as Notepad or Microsoft Excel. The file must be saved with the \*.csv file name extension.

To configure Dial Plans in a file, use the following syntax:

```
DialPlanName,Name,Prefix,Tag
```

Where:

- *DialPlanName*: Name of the Dial Plan.
- *Name*: Name of the dial plan rule belonging to the Dial Plan.
- *Prefix*: Source or destination number prefix.
- *Tag*: Result of the user categorization and can be used as matching characteristics for routing and outbound manipulation

For example:

```
DialPlanName,Name,Prefix,Tag
PLAN1,rule_100,5511361xx,A
PLAN1,rule_101,551136184[4000-9999]#,B
MyDialPlan,My_rule_200,5511361840000#,itsp_1
MyDialPlan,My_rule_201,66666#,itsp_2
```

## Exporting Dial Plans


You can export your configured Dial Plans in comma-separated value (CSV) file format to a folder on the local PC running the Web client.



The CLI lets you export Dial Plans and Dial Plan rules to a remote server, using the `export-csv-to` command under `(config-voip)# sbc dial-plan`. For more information, refer to the document *CLI Reference Guide*.

### ➤ To export all configured Dial Plans with their corresponding Dial Plan rules:

1. Open the Dial Plan table.
2. From the 'Action' drop-down menu, choose **Export**; the following dialog box appears:



3. Select the **Save File** option, and then click **OK**; the file is saved to the default folder on your PC for downloading files.

### ➤ To export Dial Plan rules of a specific Dial Plan:

1. Open the Dial Plan table.
2. Select the required Dial Plan, and then click the **Dial Plan Rule** link; the Dial Plan Rule table opens, displaying the rules of the selected Dial Plan.
3. From the 'Action' drop-down menu, choose **Export**; a dialog box appears (as shown above).
4. Select the **Save File** option, and then click **OK**; the file is saved to the default folder on your PC for downloading files.

## Using Dial Plan Tags for SBC IP-to-IP Routing

You can use Dial Plan tags with IP-to-IP Routing rules in the IP-to-IP Routing table, where tags can be used for the following:

- Matching routing rules by source and/or destination prefix numbers (see [Using Dial Plan Tags for Matching Routing Rules](#) below)
- Locating destination IP Group (see [Using Destination Tags for Choosing Routing Destinations](#) on the next page)

### Using Dial Plan Tags for Matching Routing Rules

For deployments requiring hundreds of routing rules (which may exceed the maximum number of rules that can be configured in the IP-to-IP Routing table), you can employ tags to represent the many different calling (source URI user name) and called (destination URI user name) prefix numbers in your routing rules. Tags are typically implemented when you have users of many different called and/or calling numbers that need to be routed to the same destination (e.g., IP Group or IP address). In such a scenario, instead of configuring many routing rules to match all the required prefix numbers, you need only to configure a single routing rule using the tag to represent all the possible prefix numbers.

An example scenario where employing tags could be useful is in deployments where the device needs to service calls in a geographical area that consists of hundreds of local area codes, where each area code is serviced by one of two SIP Trunks in the network. In such a deployment, instead of configuring hundreds of routing rules to represent each local area code, you can simply configure two routing rules where each is assigned a unique tag representing a group of local area codes and the destination IP Group associated with the SIP Trunk servicing them.



- Source and destination tags can be used in the same routing rule.
- The same tag can be used for source and destination tags in the same routing rule.

#### ➤ To configure IP-to-IP routing based on tags:

1. In the Dial Plan table, configure a Dial Plan (see [Configuring Dial Plans](#) on page 798). For example, the Dial Plan file below defines two tags, "LOC" and "INTL" to represent different called number prefixes for local and long distance (International) calls:

INDEX ▾	NAME	PREFIX	TAG
0	Local	42520[3-5]	LOC
1	Local	425207	LOC
2	Local	42529	LOC
3	International	425200	INTL
4	International	425100	INTL

2. For the IP Group or SRD associated with the calls for which you want to use tag-based routing, assign the Dial Plan that you configured in Step 1.
  - IP Groups table: 'Dial Plan' parameter - see [Configuring IP Groups](#) on page 581
  - SRDs table: 'Dial Plan' parameter - see [Configuring SRDs](#) on page 549

3. In the IP-to-IP Routing table (see [Configuring SBC IP-to-IP Routing Rules](#) on page 1076), configure a routing rule with the required destination and whose matching characteristics include the tag(s) that you configured in your Dial Plan in Step 1. The tags are assigned under the **Match** group, using the following parameters:
  - 'Source Tags': tag denoting the calling user
  - 'Destination Tags': tag denoting the called user

### Using Destination Tags for Choosing Routing Destinations

You can use Dial Plans (see [Configuring Dial Plans](#) on page 798) or Call Setup Rules (see [Configuring Call Setup Rules](#) on page 782) to define tags for determining destination IP Groups for routing incoming calls.

One of the benefits of using tags is that it can reduce the number of IP-to-IP Routing rules that you would normally need to configure. For example, assume that you need to route calls from IP Group "A" to two different IP Groups, "B" and "C", based on called (destination) prefix number (e.g., 102 and 103). When not using tags, you would need to configure two IP-to-IP Routing rules, where one rule sends calls with prefix number 102 to IP Group "B" and another rule sends calls with prefix number 103 to IP Group "C". When using tags, you would only need to configure a single IP-to-IP Routing rule whose destination IP Group is based on a tag.

The following briefly describes the tag-based routing process:

#### ■ Using Dial Plans for Determining Destination Tags:

- a. The device searches the Dial Plan index that is associated with the source IP Group of the incoming SIP dialog, for a Dial Plan rule whose 'Prefix' parameter is configured with the same called prefix number as the SIP dialog (e.g., 102). If found, the device inspects the tags in the Dial Plan rule's 'Tag' parameter (e.g., "Country=England;City=London;Essex").
- b. The device searches for a matching rule in the IP-to-IP Routing table and if the 'Destination Type' parameter is configured to **Destination Tag**, it checks the tag name configured in the 'Routing Tag Name' parameter and compares it with the tags found in the Dial Plan rule. If the parameter is configured to "default", the device selects the first tag name in the Dial Plan rule that is configured without a value (e.g., "Holland" in Step 1 below). If the parameter is configured with a tag name (e.g., "Country"), the device selects the tag name with its value (e.g., "Country=England") in the Dial Plan rule.
- c. The device searches the IP Groups table and IP Group Set table for an IP Group whose 'Tags' parameter is configured with the same tag as configured for the matching IP-to-IP Routing rule. If found, the device routes the call to this IP Group.


#### ■ Using Call Setup Rules for Determining Destination Tags:

- a. The device runs the Call Setup Rule Set ID that is assigned to the 'Pre Route Call Setup Rules Set ID' parameter of the matching IP-to-IP Routing rule ('Destination Type'

parameter is **Destination Tag**). The Call Setup Rule Set determines the destination tag name (e.g., DstTags.Country in the 'Action Subject' parameter of the Call Setup Rule).

- b. The device checks if the resultant tag name equals the tag name in the 'Routing Tag Name' parameter of the IP-to-IP Routing rule. If the parameter is configured to "default", the device selects the tag that only has a value (e.g., "Holland"). If the parameter is configured with a tag name (e.g., "Country"), the device selects the tag name with its value (e.g., "Country=England").
- c. The device searches the IP Groups table and IP Group Set table for an IP Group whose 'Tags' parameter is configured with the same tag (e.g., "Country=England"), as determined during the routing stage. If found, the device routes the call to the matched IP Group.

The following flow chart shows the device's SIP dialog processing when destination tags are used to determine destination IP Groups:



The following procedure provides an example of how to configure tag-based routing using a Dial Plan and is based on the following scenario:



- Calls from IP Group "HQ" with destination (called) prefix number 102 are sent to IP Group "ENG".
- Calls from IP Group "HQ" with destination (called) prefix number 103 are sent to IP Group "BEL".
- Destination IP Groups are determined by Dial Plan tags:
  - Tag "Country=England" is used to send calls to IP Group "ENG".
  - Tag "Country=Belgium" is used to send calls to IP Group "BEL".



For an example of using a Call Setup Rule for tag-based routing, click [Example 6: This example enables routing based on LDAP queries and destination tags for matching destination IP Groups. The device queries the LDAP server for the attribute record "telephoneNumber" whose value is the destination number of the incoming call \(e.g., "telephoneNumber=4064"\). If the attribute-value combination is found, the device retrieves the string value of the attribute record "CountryOfResidence" and creates a destination tag with the name of the retrieved string. The value of the destination tag name is then used as a matching characteristics of the IP Group. on page 796.](#)

➤ **To configure tag-based routing using Dial Plans:**

1. In the Dial Plan table, configure a Dial Plan with Dial Plan rules, where the 'Prefix' parameter is the **destination** (called) prefix number. In our example, a Dial Plan called "Dial Plan 1" is configured with two Dial Plan rules:

Parameter	Index 0	Index 1
'Name'	UK	Bel-Neth
'Prefix'	102	103
'Tag'	Country=England;City=London	Holland;City=Amsterdam;Country=Belgium

The following displays the configuration in the Web interface of the Dial Plan rule for Index 0:

Dial Plan Rule [UK]
— x

GENERAL

Index

Name

• UK

Prefix

• 102

Tag

• Country=England;City=London



Regarding the 'Tag' parameter:

- Only one tag name **without** a value can be configured. In the above example, "Holland" is the tag name without a value. For example, configuring "Holland;France", which is two tag names without values is invalid.
- Tag names with values (i.e., name=value) must be unique in a Dial Plan rule. In the above example, "Country=England" is a tag name with value. For example, configuring the parameter to "Country=England;Country=Scotland" is invalid. A valid configuration would be "Country=England;Country1=Scotland".

2. In the IP Groups table, configure your IP Groups. Make sure that you assign the source IP Group with the Dial Plan that you configured in Step 1 and that you configure each destination IP Group with one of the required Dial Plan tags. If the tag has a value, include it as well. In our example, we'll configure three IP Groups:

Parameter	Index 0	Index 1	Index 2
'Name '	HQ	ENG	BEL
'Dial Plan'	Dial Plan 1	-	-
'Tags'	-	Country=England	Country=Belgium

3. In the IP-to-IP Routing table (see [Configuring SBC IP-to-IP Routing Rules](#) on page 1076), add a routing rule and configure the 'Destination Type' parameter to **Destination Tag** and the 'Routing Tag Name' to one of your Dial Plan tag names. In our example, the tag "Country" is used:

Parameter	Index 0
'Name'	Europe
'Source IP Group'	HQ
'Destination Type'	<b>Destination Tag</b>
'Routing Tag Name'	Country



- Configure the 'Routing Tag Name' parameter to the name of the tag (without a value, if exists). For example, instead of "Country=England", configure it to "Country" only.
- For tag-based routing, if you want to determine the destination tag during the device's routing stage in the IP-to-IP Routing table (i.e., 'Destination Type' set to **Destination Tag**), use the 'Pre Route Call Setup Rules Set ID' parameter. The device uses the resultant tag name to find a matching IP Group (i.e., with same tag) in the IP Groups table.
- In the IP-to-IP Routing table, the device always runs the Call Setup Rules Set of the 'Pre Route Call Setup Rules Set ID' parameter before the Call Setup Rules Set of the 'Call Setup Rules Set ID' parameter (if configured). Therefore, if you're using the 'Pre Route Call Setup Rules Set ID' parameter for tag-based routing, once the Call Setup Rules Set finishes running and the tag and matching IP Group is determined, the device runs the Call Setup Rules Set of the 'Call Setup Rules Set ID' parameter. This second Call Setup Rules Set can now access the **already** matched IP Group (Param.IPG.Dst).
- If the same Dial Plan tag is configured for an IP Group in the IP Groups table and an IP Group Set in the IP Group Set table, the IP Group Set takes precedence and the device sends the SIP dialog to the IP Group(s) belonging to the IP Group Set.

### Dial Plan Backward Compatibility



This section is for backward compatibility **only**. It is recommended to migrate your Dial Plan configuration to the latest Dial Plan feature (see [Using Dial Plan Tags for SBC IP-to-IP Routing](#) on page 813).

Configure prefix tags in the Dial Plan file using the following syntax:

```
[ PLAN<index> ]
<prefix number>,0,<prefix tag>
```

where:

- *Index* is the Dial Plan index
- *prefix number* is the called or calling number prefix (ranges can be defined in brackets)
- *prefix tag* is the user-defined prefix tag of up to nine characters, representing the prefix number

Each prefix tag type - called or calling - must be configured in a dedicated Dial Plan index number. For example, Dial Plan 1 can be for called prefix tags and Dial Plan 2 for calling prefix tags.

The example Dial Plan file below defines the prefix tags "LOCL" and "INTL" to represent different called number prefixes for local and long distance calls:

```
[ PLAN1 ]
42520[3-5],0,LOCL
425207,0,LOCL
42529,0,LOCL
425200,0,INTL
425100,0,INTL
....
```



- Called and calling prefix tags can be used in the same routing rule.
- When using prefix tags, you need to configure manipulation rules to remove the tags before the device sends the calls to their destinations.

The following procedure describes how to configure IP-to-IP routing using prefix tags.

➤ **To configure IP-to-IP routing using prefix tags:**

1. Configure a Dial Plan file with prefix tags, and then upload the file to the device.
2. Add the prefix tags to the numbers of specific incoming calls using Inbound Manipulation rules:
  - a. Open the Inbound Manipulations table (see [Configuring IP-to-IP Inbound Manipulations](#) on page 1121), and then click **New**.
  - b. Configure matching characteristics for the incoming call (e.g., set 'Source IP Group' to "1").
  - c. From the 'Manipulated Item' drop-down list, select **Source** to add the tag to the calling URI user part, or **Destination** to add the tag to the called URI user part.
  - d. Configure the Dial Plan index for which you configured your prefix tag, in the 'Prefix to Add' or 'Suffix to Add' fields, using the following syntax: `$DialPlan<x>`, where *x* is the Dial Plan index (0 to 7). For example, if the called number is 4252000555, the device manipulates it to LOCL4252000555.
3. Add an SBC IP-to-IP routing rule using the prefix tag to represent the different source or destination URI user parts:
  - a. Open the IP-to-IP Routing table (see [Configuring SBC IP-to-IP Routing Rules](#) on page 1076), and then click **New**.
  - b. Configure the prefix tag in the 'Source Username Pattern' or 'Destination Username Pattern' fields (e.g., "LOCL", without the quotation marks).
  - c. Continue configuring the rule as required.
4. Configure a manipulation rule to remove the prefix tags before the device sends the message to the destination:

- a. Open the Outbound Manipulations table (see [Configuring IP-to-IP Outbound Manipulations](#) on page 1126), and then click **New**.
- b. Configure matching characteristics for the incoming call (e.g., set 'Source IP Group' to "1"), including calls with the prefix tag (in the 'Source Username Pattern' or 'Destination Username Pattern' fields, enter the prefix tag to remove).
- c. Configure the 'Remove from Left' or 'Remove from Right' fields (depending on whether you added the tag at the beginning or end of the URI user part, respectively), enter the number of characters making up the tag.

## Using Dial Plan Tags for SBC Outbound Manipulation

You can use Dial Plan tags to denote source and/or destination URI user names in Outbound Manipulation rules in the Outbound Manipulations table.

### ➤ To configure Outbound Manipulation based on tags:

1. In the Dial Plan table, configure a Dial Plan (see [Configuring Dial Plans](#) on page 798).
2. In the IP Group or SRD associated with the calls for which you want to use tag-based routing, assign the Dial Plan that you configured in Step 1.
  - IP Groups table: 'Dial Plan' parameter - see [Configuring IP Groups](#) on page 581
  - SRDs table: 'Dial Plan' parameter - see [Configuring SRDs](#) on page 549
3. In the Outbound Manipulations table (see [Configuring IP-to-IP Outbound Manipulations](#) on page 1126), configure a rule with the required manipulation and whose matching characteristics include the tag(s) that you configured in your Dial Plan in Step 1. The tags are assigned using the following parameters:
  - 'Source Tags': tag denoting the calling users
  - 'Destination Tags': tag denoting the called users

## Using Dial Plan Tags for Call Setup Rules

You can use Dial Plan tags in Call Setup rules, configured in the Call Setup Rules table (see [Configuring Call Setup Rules](#) on page 782).

You can assign the Call Setup rule to an IP Group. The device runs the Call Setup rule for the source IP Group to which the incoming SIP dialog is classified, immediately before the routing process (i.e., Classification > Manipulation > Dial Plan table > Call Setup rules > Routing). The result of the Call Setup rule (i.e., source or destination tag) can be used in the IP-to-IP Routing table for any of the following:

- As matching characteristics to find a suitable IP-to-IP Routing rule (initial route). To implement this, configure the rule's 'Source Tag' or 'Destination Tag' parameters to the resultant tag of the Call Setup rule.

- To determine the destination of the IP-to-IP Routing rule (initial route). To implement this, configure the rule's 'Destination Type' parameter to **Destination Tag** and the 'Routing Tag Name' parameter to the resultant tag of the Call Setup rule. The SIP dialog is sent to the IP Group that is configured with this same tag ('Tags' parameter in the IP Groups table).



When tags are used to determine the route's destination: If the IP-to-IP Routing rule (initial route) is also configured with a Call Setup rule ('Call Setup Rules Set ID' parameter) and it results in a different tag, and additional IP-to-IP Routing rules are configured as alternative routes ('Alternative Route Options' parameter), or the initial route is also configured with call forking ('Group Policy' is **Forking**), and the 'Destination Type' for these rules is configured to **Destination Tag**, then this new tag is used for the destination (instead of the tag used for the initial route).

You can configure Call Setup rules to query the Dial Plan table for a specified key (prefix) in a specified Dial Plan to obtain the corresponding tag. The Call Setup rule can then perform many different manipulations (based on Message Manipulation syntax), including modifying the name of the tag. The tags can be used only in the 'Condition', 'Action Subject' and 'Action Value' fields.

## Using Dial Plans for IP-to-Tel or Tel-to-IP Call Routing

For deployments requiring hundreds of routing rules (which may exceed the maximum number of rules that can be configured in the routing tables), you can employ Dial Plan tags to represent the many different calling (source) and called (destination) prefix numbers as matching input characteristics in your IP-to-Tel and Tel-to-IP routing rules. Tags are typically implemented when you have users of many different called and/or calling numbers that need to be routed to the same destination. In such a scenario, instead of configuring many routing rules to match all the required prefix numbers, you need only to configure a single routing rule using the tag to represent all the possible prefix numbers.

An example scenario where employing tags could be useful is in deployments where the device needs to service calls in a geographical area that consists of many local area codes, where the area codes are serviced by different SIP Trunks (for Tel-to-IP) and Trunk Groups (for IP-to-Tel). Another example includes routing local calls and International calls using different SIP Trunks. In such a scenario, instead of configuring hundreds of routing rules to represent each local area code and the International dialing code, you can simply configure two routing rules where one is assigned a unique tag representing the local area codes and the other is assigned a tag representing International calls.



- Source and destination tags can be used in the same routing rule.
- The same tag can be used for source and destination tags in the same routing rule.

The procedure below describes how to configure tag-based routing for Gateway calls based on the following example setup:

- **Tel-to-IP routing:** Local calls whose destination tag is "NYPSP0" are routed to IP Group "SP-0" and calls whose destination tag is "NYPSP1" are routed to IP Group "SP-1".
- **IP-to-Tel routing:** Local calls whose destination tag is "NYPSP0" are routed to Trunk Group 1 and calls whose destination tag is "NYPSP1" are routed to Trunk Group 2.

➤ **To configure tag-based routing for IP-to-Tel and Tel-to-IP calls:**

1. Open the Dial Plan table (see [Configuring Dial Plans](#) on page 798), and then configure your Dial Plan rules, for example:

Dial Plan Name	Dial Plan Rule			Comment
	Name	Prefix	Tag	
<b>TEL2IP</b>	Local1	21[2-4]	NYPSP0	Denotes local area codes with prefixes 212, 213, and 214
	Local2	332	NYPSP0	Denotes local area code with prefix 332
	Local3	34[7,9]	NYPSP1	Denotes local area codes with prefixes 347 and 349
	Local4	9[17,29]	NYPSP1	Denotes local area codes with prefixes 917 and 929
<b>IP2TEL</b>	Local1	21[2-4]	NYPSP0	See above
	Local2	332	NYPSP0	See above
	Local3	34[7,9]	NYPSP1	See above
	Local4	9[17,29]	NYPSP1	See above

2. Open the Routing Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Routing** > **Routing Settings**), and then select the Dial Plans from the Dial Plan table that you want to use for each routing table:
  - From the 'IP-to-Tel Dial Plan Name' drop-down list, select the Dial Plan (e.g., "IP2TEL") that you want to use for IP-to-Tel routing rules.
  - From the 'Tel-to-IP Dial Plan Name' drop-down list, select the Dial Plan (e.g., "TEL2IP") that you want to use for Tel-to-IP routing rules.

IP-to-Tel Dial Plan Name •  [View](#)

Tel-to-IP Dial Plan Name •  [View](#)

3. Open the Tel-to-IP Routing table (see [Configuring Tel-to-IP Routing Rules](#) on page 914), and then configure a routing rule with the required destination and whose matching characteristics include the tag(s) that you configured in your Dial Plan for Tel-to-IP routing. The tags are assigned using the 'Source Tag' and 'Destination Tag' parameters. In our example, configure two routing rules:
  - Routing rule 1:
    - ◆ 'Destination Tag': **NYPSP0**
    - ◆ 'Destination IP Group': **SP-0**
  - Routing rule 2:
    - ◆ 'Destination Tag': **NYPSP1**
    - ◆ 'Destination IP Group': **SP-1**
4. Open the IP-to-Tel Routing table (see [Configuring IP-to-Tel Routing Rules](#) on page 928), and then configure a routing rule with the required destination and whose matching characteristics include the tag(s) that you configured in your Dial Plan for IP-to-Tel routing. The tags are assigned using the 'Source Tag' and 'Destination Tag' parameters. In our example, configure two routing rules:
  - Routing rule 1:
    - ◆ 'Destination Tag': **NYPSP0**
    - ◆ 'Destination Type': **Trunk Group**
    - ◆ 'Trunk Group ID': **1**
  - Routing rule 2:
    - ◆ 'Destination Tag': **NYPSP1**
    - ◆ 'Destination Type': **Trunk Group**
    - ◆ 'Trunk Group ID': **2**

## Using Dial Plan Tags for Message Manipulation

You can use Dial Plan tags (*srctags* and *dsttags*) in Message Manipulation rules, configured in the Message Manipulations table (see [Configuring SIP Message Manipulation](#) on page 829). The tags can be used only in the 'Condition' and 'Action Value' fields. For example, you can configure a rule that adds the SIP header "City" with the value "ny" (i.e., City: ny) to all outgoing SIP INVITE messages associated with the source tag "ny":



**Message Manipulations**

GENERAL		ACTION	
Index	0	Action Subject	header.City
Name	New Header for Tag ny	Action Type	Add
Manipulation Set ID	0	Action Value	srctags
Row Role	Use Current Condition		

MATCH	
Message Type	invite.request
Condition	srctags=='ny'



Dial Plan tags cannot be modified using Message Manipulation rules.

## Using Dial Plans for Microsoft Local Media Optimization

When the device is deployed in a Microsoft Teams environment for its Local Media Optimization feature, you need to specify which Dial Plan in the Dial Plan table the device must search for common groups between Teams sites. Teams sites that share the same group number means that their communication path is considered good voice quality and calls between them are intended for direct media calls. In other words, if the source and destination Teams sites share a common group, the device processes the call as a direct media call.

The specified Dial Plan uses the 'Prefix' parameter to define the names of the Teams sites (e.g., "Singapore" and "Thailand") and the 'Tag' parameter lists the groups to which the Teams site belongs (e.g., "Group=2,7"). Microsoft's proprietary SIP header, MS-X-UserSite in the incoming SIP message received from the Teams client indicates the site to which the client belongs (e.g., "Singapore"). If the destination IP Group's 'Teams Local Media Optimization Site' parameter is configured to "Thailand", the device checks the Dial Plan if these two Teams sites share the same group (e.g., "2"). If they do belong to the same group, the device processes the call as a direct media (bypass) call. Each Teams site can belong to multiple groups.



- You can specify only one Dial Plan for this feature.
- The feature described in this section is applicable only to Teams-to-PSTN calls.
- For an overview of Microsoft's Local Media Optimization feature, see [Microsoft Teams with Local Media Optimization](#) on page 511
- This section is applicable only to the SBC application.


➤ **To use Dial Plan for Microsoft Local Media Optimization:**

1. Open the Dial Plan table (see [Configuring Dial Plans](#) on page 798), and then configure a Dial Plan containing Dial Plan rules of Teams sites and the groups they belong to. For example, a Dial Plan called "RegionsDP" is configured with rules that include the Teams sites Singapore, Thailand and Hong Kong and the groups that each belong to:

INDEX	NAME	PREFIX	TAG
0	TeamsDialPlan1	Singapore	Group=2,3
1	TeamsDialPlan2	Thailand	Group=2,5
2	TeamsDialPlan3	HongKong	Group= 5,6,7

2. Open the SIP Definitions General Settings page (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **SIP Definitions General Settings**), and then from the 'Regions Connectivity Dial Plan' drop-down list, select the Dial Plan that you configured in Step 1 (e.g., **RegionsDP**):

Regions Connectivity Dial Plan



3. Open the IP Groups table (see [Configuring IP Groups](#) on page 581), and then for each IP Group representing a Teams site, configure the 'Teams Local Media Optimization Site' parameter to the site's name. The site's name must be the same name as configured in the Dial Plan rule (configured in Step 2). For example, below shows the IP Group for the Singapore Teams site:

Teams Local Media Optimization Site

Singapore

## Configuring Push Notification Servers

The Push Notification Servers table lets you configure up to five Push Notification Servers. The device uses this table to determine which Push Notification Server to send push notification requests for a specific user. The device searches the table for a row that is configured with the user's 'pn-provider' parameter value and if located, sends the push notification request to the Push Notification Server, using the address of the associated Remote Web Service.

The Push Notification Service uses Push Notification Servers to send push notifications to "wake" end-user equipment (typically, mobile platforms) that have gone to "sleep" (e.g., to save resources such as battery life) so that they can receive traffic. The device can handle calls (and registration) for such SIP user agents (UAs), by interoperating with these third-party, Push Notification Servers (over HTTP, using RESTful APIs). For more information on Push Notification Service, see [Configuring Push Notification Service](#) on page 1167.

Before you can configure a Push Notification Server in this table, you need to configure a Remote Web Service (HTTP-based server) to represent the Push Notification Server. The Remote Web Service defines the actual address (and other required parameters) of the server.

You must configure the Remote Web Service with the 'Type' parameter set to **General**. To configure Remote Web Services, see [Configuring Remote Web Services](#) on page 429.



The Push Notification Service is applicable only to the SBC application.

The following procedure describes how to configure Push Notification Servers through the Web interface. You can also configure it through ini file [PushNotificationServers] or CLI (configure voip > sip-definition push-notification-servers).

➤ **To configure Push Notification Server:**

1. Open the Push Notification Servers table (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **Push Notification Servers**).
2. Click **New**; the following dialog box appears:

3. Configure a Push Notification Server according to the parameters described in the table below.
4. Click **Apply**.

**Table 20-8: Push Notification Servers Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Provider' provider [Provider]	Defines the type of the Push Notification Service. The type of the service provider is indicated in the SIP Contact header's 'pn-provider' parameter of the REGISTER message that is sent by the user to the device. For example, Android-based mobile phone platforms typically use Firebase Cloud Messaging (FCM) for its Push Notification Service. The value of the 'pn-provider' parameter for this service type is "fcm". Therefore, you would need to configure the 'Provider' parameter to "fcm" (without quotation marks).  The valid value is a string of up to 10 characters. By default, no value is defined. To denote any provider, use the asterisk (*)

Parameter	Description
	<p>wildcard character.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ You can configure this parameter to the * (asterisk) wildcard character for only one table row.</li> <li>■ The parameter is mandatory.</li> </ul>
<p>'Remote Web Service'</p> <p>remote-http-service</p> <p>[RemoteHTTPService]</p>	<p>Assigns a Remote Web Service, which defines the URL address (and other related parameters) of the HTTP-based Push Notification Server.</p> <p>To configure Remote Web Services, see <a href="#">Configuring Remote Web Services</a> on page 429.</p> <p><b>Note:</b> The parameter is mandatory.</p>
<p>'Protocol'</p> <p>protocol</p> <p>[Protocol]</p>	<p>Defines the protocol for exchanging information between the device and the Push Notification Server.</p> <ul style="list-style-type: none"> <li>■ [0] AC-Proprietary = (Default) The device exchanges information with the server using the JavaScript Object Notation (JSON) format.</li> </ul>

## 21 SIP Message Manipulation

This section describes SIP message manipulation.



If you have configured call routing from the device's SBC application (IP-to-IP routing) to the device's Gateway application for IP-to-Tel routing, the device uses the initial SIP message as if it's a new call. Therefore, if any manipulations were done on the SIP message by the SBC application, the device ignores them.

### Configuring SIP Message Manipulation

The Message Manipulations table lets you configure up to 100 Message Manipulation rules. A Message Manipulation rule defines a manipulation sequence for SIP messages. SIP message manipulation enables the normalization of SIP messaging fields between communicating network segments. For example, it allows service providers to design their own policies on the SIP messaging fields that must be present before a SIP call enters their network. Similarly, enterprises and small businesses may have policies for the information that can enter or leave their networks for policy or security reasons from a service provider. SIP message manipulations can also be implemented to resolve incompatibilities between SIP devices inside the enterprise network.

Each Message Manipulation rule is configured with a Manipulation Set ID. You can create groups (sets) of Message Manipulation rules by assigning each of the relevant Message Manipulation rules to the same Manipulation Set ID. The Manipulation Set ID is then used to assign the rules to specific calls:

■ **SBC application:** Message manipulation rules can be applied pre- or post-classification:

- **Pre-classification Process:** Message manipulation can be done on incoming SIP dialog-initiating messages (e.g., INVITE) prior to the classification process. You configure this by assigning the Manipulation Set ID to the SIP Interface on which the call is received (see [Configuring SIP Interfaces](#) on page 561).
- **Post-classification Process:** Message manipulation can be done on inbound and/or outbound SIP messages after the call has been successfully classified. Manipulation occurs only after the routing process - inbound message manipulation is done first, then outbound number manipulation (see [Configuring IP-to-IP Outbound Manipulations](#) on page 1126), and then outbound message manipulation. For viewing the call processing flow, see [Call Processing of SIP Dialog Requests](#) on page 1023. You configure this by assigning the Manipulation Set ID to the relevant IP Group in the IP Groups table (see [Configuring IP Groups](#) on page 581).

■ **Gateway application:** Message Manipulation rules are applied to calls as follows:

- **Manipulating Inbound SIP INVITE Messages:** Message manipulation can be applied only to all inbound calls (not specific calls). This is done by assigning a Manipulation Set ID, using the "global" parameter [GWInboundManipulationSet].

- **Manipulating Outbound SIP INVITE Messages:** Message manipulation can be done for specific calls, by assigning a Manipulation Set ID to an IP Group in the IP Groups table, using the 'Outbound Message Manipulation Set' parameter. Message manipulation can be applied to all outbound calls (except for IP Groups that have been assigned a Manipulation Set ID). This is done by assigning a Manipulation Set ID, using the "global" parameter [GWOutboundManipulationSet].
- **SIP requests initiated by the device (Gateway and SBC applications):** You can apply Message Manipulation rules to SIP requests that are initiated by the device, for example, SIP REGISTERS for certain entities (e.g., Accounts) and keep-alive by SIP OPTIONS. If the destination of the request is an IP Group, then the device uses the Inbound and Outbound Manipulation Sets that are assigned to the IP Group. If there is no IP Group for the destination or the IP Group is not assigned an Inbound or Outbound Manipulation Set, then the global parameters [GWInboundManipulationSet] or [GWOutboundManipulationSet] are used. The [GWInboundManipulationSet] parameter defines the Message Manipulation Set that is applied to incoming responses for requests that the device initiated. The [GWOutboundManipulationSet] parameter defines the Message Manipulation Set that is applied to outgoing requests that the device initiates.

The device also supports a built-in SIP message normalization feature that can be enabled per Message Manipulation rule. The normalization feature removes unknown SIP message elements before forwarding the message. These elements can include SIP headers, SIP header parameters, and SDP body fields.

The SIP message manipulation feature supports the following:

- Manipulation on SIP message type (Method, Request/Response, and Response type)
- Addition of new SIP headers
- Removal of SIP headers ("black list")
- Modification of SIP header components such as values, header values (e.g., URI value of the P-Asserted-Identity header can be copied to the From header), call's parameter values
- Deletion of SIP body (e.g., if a message body is not supported at the destination network this body is removed)
- Translating one SIP response code to another
- Topology hiding (generally present in SIP headers such as Via, Record Route, Route and Service-Route).
- Configurable identity hiding (information related to identity of subscribers, for example, P-Asserted-Identity, Referred-By, Identity and Identity-Info)
- Multiple manipulation rules on the same SIP message
- Apply conditions per rule - the condition can be on parts of the message or call's parameters
- Apply Message Manipulation Set twice on SIP REGISTER messages -- first on the initial incoming unauthenticated REGISTER, and then again on the incoming authenticated SIP


message received after the device sends a SIP 401 response for challenging the initial REGISTER request. For more information and for enabling this feature, see the [AuthenticatedMessageHandling] parameter.

- Multiple manipulation rules using the same condition. The following figure shows a configuration example where Rules #1 and #2 ('Row Rule' configured to **Use Previous Condition**) use the same condition as configured for Rule #0 ('Row Rule' configured to **Use Current Condition**). For more information, see the description of the 'Row Rule' parameter in this section.

INDEX ↕	NAME	MANIPULATION SET ID	MESSAGE TYPE	CONDITION	ACTION SUBJECT	ACTION TYPE	ACTION VALUE	ROW ROLE
0	To Header Urgent	1	Invite.Request	Header.Request-URL.URI	Header.To	Modify	Header.To + ";urgent=1"	Use Current Condition
1	Add Emergency	1			Header.Priority	Add	'emergency'	Use Previous Condition
2	User-Agent	1			Header.User-Agent	Modify	'trunk-a'	Use Previous Condition

The following figure illustrates an example of a SIP message that is manipulated by the device as follows:

1. Removes the "Unknown\_header: unknown\_value" in the incoming message.
2. Changes the P-Asserted-Identity header value to "sip:200@10.33.216.1" in the outgoing message.



This manipulation example is done by configuring two Message Manipulation rules, where Rule #1 is assigned to the source IP Group and Rule #2 to the destination IP Group.

Parameter	Rule 1	Rule 2
Message Type	Invite.request	Invite.request
Condition	Header.Unkown_header !contains 'unknown_value'	Header.P-Asserted-Identity.URL.User == 'Susan'
Action Subject	Header.Unkown_header	Header.P-Asserted-Identity



Parameter	Rule 1	Rule 2
Action Type	Remove	Modify
Action Value		'<sip:200@212.3.216.1>'



- For a detailed description of the syntax used for configuring Message Manipulation rules, refer to the document *SIP Message Manipulation Reference Guide* (click [here](#)).
- If you have configured call routing from the device's SBC application (IP-to-IP routing) to the device's Gateway application for IP-to-Tel routing, the device uses the initial SIP message as if it's a new call. Therefore, if any manipulations were done on the SIP message by the SBC application, the device ignores them.
- For the SBC application: Inbound message manipulation is done only after the Classification, inbound and outbound number manipulation, and routing processes.
- Each message can be manipulated twice - on the source leg and on the destination leg (i.e., source and destination IP Groups).
- Unknown SIP parts can only be added or removed.
- SIP manipulations do not allow you to remove or add mandatory SIP headers. They can only be modified and only on requests that initiate new dialogs. Mandatory SIP headers include To, From, Via, CSeq, Call-Id, and Max-Forwards.
- The IP Group's 'SIP Group Name' parameter overrides inbound message manipulation rules that manipulate the host name in Request-URI, To, and/or From SIP headers. If you configure a SIP Group Name for the IP Group (see [Configuring IP Groups](#) on page 581) and you want to manipulate the host name in these SIP headers, you must apply your manipulation rule (Manipulation Set ID) to the IP Group as an Outbound Message Manipulation Set ('Outbound Message Manipulation Set' parameter), when the IP Group is the destination of the call. If you apply the Manipulation Set as an Inbound Message Manipulation Set ('Inbound Message Manipulation Set' parameter), when the IP Group is the source of the call, the manipulation rule will be overridden by the SIP Group Name.
- When configuring a Message Manipulation rule for manipulating a SIP header, the maximum length (characters) of the header's value in the incoming SIP message that can be manipulated is 4,096.

The following procedure describes how to configure Message Manipulation rules through the Web interface. You can also configure it through ini file [MessageManipulations] or CLI (configure voip > message message-manipulations).

➤ **To configure SIP message manipulation rules:**

1. Open the Message Manipulations table (**Setup** menu > **Signaling & Media** tab > **Message Manipulation** folder > **Message Manipulations**).
2. Click **New**; the following dialog box appears:

3. Configure a Message Manipulation rule according to the parameters described in the table below.

4. Click **Apply**.

An example of configured message manipulation rules are shown in the figure below:

INDEX	NAME	MANIPULATION SET ID	MESSAGE TYPE	CONDITION	ACTION SUBJECT	ACTION TYPE	ACTION VALUE
0	ITSP A	0	invite.response.200		header.to.url.user	Add Suffix	'.com'
1		0	invite.response.200		header.from.url.user	Modify	header.p-asserted-id.url.user
2		0	invite.request		header.from.url.user	Modify	'200'
3		2	invite.request	header.from.url.user==Unknown	header.from.url.user	Modify	param.ipg.src.user
4		2	invite.request		header.priority	Remove	

- **Index 0:** Adds the suffix ".com" to the host part of the To header.
- **Index 1:** Changes the user part of the From header to the user part of the P-Asserted-ID.
- **Index 2:** Changes the user part of the SIP From header to "200".
- **Index 3:** If the user part of the From header equals "unknown", then it is changed according to the srcIPGroup call's parameter.
- **Index 4:** Removes the Priority header from an incoming INVITE message.

**Table 21-1: Message Manipulations Parameter Descriptions**

Parameter	Description
General	
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' manipulation-name [ManipulationName]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 40 characters.
'Manipulation Set ID' manipulation-set-id [ManSetID]	Defines a Manipulation Set ID for the rule. You can define the same Manipulation Set ID for multiple rules to create a group of rules. The Manipulation Set ID is used to assign the manipulation rules to an IP Group (in the IP Groups table) for inbound and/or outbound

Parameter	Description
	<p>messages.</p> <p>The valid value is 0 to 29. The default is 0.</p> <p><b>Note:</b> You can configure up to 200 rules per Manipulation Set ID.</p>
<p>'Row Role'</p> <p>row-role</p> <p>[RowRole]</p>	<p>Determines which message manipulation condition (configured by the 'Condition' parameter) to use for the rule.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Use Current Condition</b> = (Default) The condition configured in the table row of the rule is used.</li> <li>■ [1] <b>Use Previous Condition</b> = The condition configured in the first table row above the rule that is configured to <b>Use Current Condition</b> is used. For example, if Index 3 is configured to <b>Use Current Condition</b> and Index 4 and 5 are configured to <b>Use Previous Condition</b>, Index 4 and 5 use the condition configured for Index 3. A configuration example is shown in the beginning of this section. The option allows you to use the same condition for multiple manipulation rules.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ When configured to <b>Use Previous Condition</b>, the 'Message Type' and 'Condition' parameters are not applicable and if configured are ignored.</li> <li>■ When multiple manipulation rules apply to the same header, the next rule applies to the resultant string of the previous rule.</li> </ul>
Match	
<p>'Message Type'</p> <p>message-type</p> <p>[MessageType]</p>	<p>Defines the SIP message type that you want to manipulate.</p> <p>The valid value is a string (case-insensitive) denoting the SIP message. You can use the built-in syntax editor to help you configure the field. Click the <b>Editor</b> button located alongside the field to open the Editor, and then simply follow</p>

Parameter	Description
	<p>the on-screen instructions.</p> <p>For example:</p> <ul style="list-style-type: none"> <li>■ Empty = rule applies to all messages</li> <li>■ Invite = rule applies to all INVITE requests and responses</li> <li>■ Invite.Request = rule applies to INVITE requests</li> <li>■ Invite.Response = rule applies to INVITE responses</li> <li>■ subscribe.response.2xx = rule applies to SUBSCRIBE confirmation responses</li> </ul> <p><b>Note:</b> Currently, SIP 100 Trying messages cannot be manipulated.</p>
<p>'Condition'</p> <p>condition</p> <p>[Condition]</p>	<p>Defines the condition that must exist for the rule to be applied.</p> <p>The valid value is a string of up to 200 characters (case-insensitive). You can use the built-in syntax editor to help you configure the field. Click the <b>Editor</b> button located alongside the field to open the Editor, and then simply follow the on-screen instructions.</p> <p>For example:</p> <ul style="list-style-type: none"> <li>■ header.from.url.user== '100' (indicates that the user part of the From header must have the value "100")</li> <li>■ header.contact.param.expires &gt; '3600'</li> <li>■ header.to.url.host contains 'domain'</li> <li>■ param.call.dst.user != '100'</li> </ul>
Action	
<p>'Action Subject'</p> <p>action-subject</p> <p>[ActionSubject]</p>	<p>Defines the SIP header upon which the manipulation is performed.</p> <p>The valid value is a string (case-insensitive). You can use the built-in syntax editor to help you configure the field. Click the <b>Editor</b> button located alongside the field to open the Editor,</p>

Parameter	Description
	and then simply follow the on-screen instructions.
'Action Type' action-type [ActionType]	<p>Defines the type of manipulation.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Add</b> = (Default) Adds new header/param/body (header or parameter elements).</li> <li>■ [1] <b>Remove</b> = Removes header/param/body (header or parameter elements).</li> <li>■ [2] <b>Modify</b> = Sets element to the new value (all element types).</li> <li>■ [3] <b>Add Prefix</b> = Adds value at the beginning of the string (string element only).</li> <li>■ [4] <b>Add Suffix</b> = Adds value at the end of the string (string element only).</li> <li>■ [5] <b>Remove Suffix</b> = Removes value from the end of the string (string element only).</li> <li>■ [6] <b>Remove Prefix</b> = Removes value from the beginning of the string (string element only).</li> <li>■ [7] <b>Normalize</b> = Removes unknown SIP message elements before forwarding the message.</li> </ul>
'Action Value' action-value [ActionValue]	<p>Defines a value that you want to use in the manipulation.</p> <p>The default value is a string (case-insensitive) in the following syntax:</p> <ul style="list-style-type: none"> <li>■ string/&lt;message-element&gt;/&lt;call-param&gt; +</li> <li>■ string/&lt;message-element&gt;/&lt;call-param&gt;</li> </ul> <p>For example:</p> <ul style="list-style-type: none"> <li>■ 'itsp.com'</li> <li>■ header.from.url.user</li> <li>■ param.call.dst.user</li> <li>■ param.call.dst.host + '.com'</li> <li>■ param.call.src.user + '&lt;' + header.from.url.user + '@' + header.p-</li> </ul>

Parameter	Description
	<p>asserted-id.url.host + '&gt;'</p> <p>■ Func.To-Upper(Param.Call.Src.Host)</p> <p>You can use the built-in syntax editor to help you configure the field. Click the <b>Editor</b> button located alongside the field to open the Editor, and then simply follow the on-screen instructions.</p> <p><b>Note:</b> Only single quotation marks must be used.</p>

## Configuring Message Condition Rules

The Message Conditions table lets you configure up to 82 Message Condition rules. A Message Condition defines special conditions (requisites) for incoming SIP messages. These rules can be used as additional matching criteria for the following:

- Classification rules in the Classification table (see [Configuring Classification Rules](#) on page 1061)
- IP-to-IP routing rules in the IP-to-IP Routing table (see [Configuring SBC IP-to-IP Routing Rules](#) on page 1076)
- Outbound Manipulation rules in the Outbound Manipulations table (see [Configuring IP-to-IP Outbound Manipulations](#) on page 1126)

Message Condition rules are configured using the same syntax as that used for Conditions when configuring Message Manipulation rules in the Message Manipulations table (see [Configuring SIP Message Manipulation](#) on page 829). You can configure simple Message Condition rules, for example, "header.to.host contains company", meaning SIP messages whose To header has a host part containing the string "company". You also can configure complex rules using the "AND" or "OR" Boolean operands and also use regular expressions (regex), for example:

- "body.sdp regex pcmu" can be used to enable routing based on the offered codec (G.711 Mu) in the incoming SDP message.
- "body.sdp regex (AVP[0-9| |\s]\*\s8[\s| |\n])" can be used to enable routing based on payload type 8 in the incoming SDP message.



- The Message Condition rule is applied only to the original incoming SIP message, prior to any manipulation made by the device on the message.
- For a description on SIP message manipulation syntax, refer to the document *Syntax for SIP Message Manipulation Reference Guide*.

The following procedure describes how to configure Message Condition rules through the Web interface. You can also configure it through ini file [ConditionTable] or CLI (`configure voip > sbc routing condition-table`).

➤ **To configure a Message Condition rule:**

1. Open the Message Conditions table (**Setup** menu > **Signaling & Media** tab > **Message Manipulation** folder > **Message Conditions**).
2. Click **New**; the following dialog box appears:

3. Configure a Message Condition rule according to the parameters described in the table below.
4. Click **Apply**.

An example of configured Message Condition rules is shown in the figure below:

INDEX ↕	NAME	CONDITION
0	IP Group user	param.ipg.src.type==user
1	Contains SIP Via Header	header.via.exists
2	"101" user part in From header	header.from.url.user=="101"

- **Index 0:** Incoming SIP dialog that is classified as belonging to a User-type IP Group.
- **Index 1:** Incoming SIP dialog that contains a SIP Via header.
- **Index 2:** Incoming SIP dialog with "101" as the user part in the SIP From header.

**Table 21-2: Message Conditions Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [Name]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 59 characters. <b>Note:</b> <ul style="list-style-type: none"> <li>■ The value can't contain a forward slash (/).</li> <li>■ The value can't be configured with the character string "any" (upper or lower case).</li> </ul>
'Condition' condition	Defines the condition of the SIP message. The valid value is a string of up to 299 characters. You can use the built-

Parameter	Description
[Condition]	<p>in syntax editor to help you configure the field. Click the <b>Editor</b> button located alongside the field to open the Editor, and then simply follow the on-screen instructions.</p> <p><b>Note:</b> Enclose the user and host parts in single quotation marks ('...').</p>

## Configuring SIP Message Policy Rules

The Message Policies table lets you configure up to 20 SIP Message Policy rules. You can use SIP Message Policy rules to block (*blocklist*) unwanted incoming SIP messages or to permit (*allowlist*) the receipt of desired SIP messages. You can configure legal and illegal characteristics of SIP messages. SIP Message Policy rules are helpful against VoIP fuzzing (also known as robustness testing), which sends different types of packets to its "victims" for finding bugs and vulnerabilities. For example, the attacker might try sending a SIP message containing either an oversized parameter or too many occurrences of a parameter.

You can also enable the Message Policy to protect the device against incoming SIP messages with malicious signature patterns, which identify specific scanning tools used by attackers to search for SIP servers in a network. To configure Malicious Signatures, see [Configuring Malicious Signatures](#) on page 1137.

Each Message Policy rule can be configured with the following:

- Maximum message length
- Maximum header length
- Maximum message body length
- Maximum number of headers
- Maximum number of bodies
- Option to send 400 "Bad Request" response if message request is rejected
- Blocklist and allowlist for defined methods (e.g., INVITE)
- Blocklist and allowlist for defined bodies
- Malicious Signatures

The Message Policies table provides a default Message Policy called "Malicious Signature DB Protection" (Index 0), which is based only on Malicious Signatures and discards SIP messages identified with any of the signature patterns configured in the Malicious Signature table.

To apply a SIP Message Policy rule to calls, you need to assign it to the SIP Interface associated with the relevant IP Group (see [Configuring SIP Interfaces](#) on page 561).

The following procedure describes how to configure Message Policy rules through the Web interface. You can also configure it through ini file [MessagePolicy] or CLI (`configure voip > message message-policy`).



➤ **To configure SIP Message Policy rules:**

1. Open the Message Policies table (**Setup** menu > **Signaling & Media** tab > **Message Manipulation** folder > **Message Policies**).
2. Click **New**; the following dialog box appears:

3. Configure a Message Policy rule according to the parameters described in the table below.
4. Click **Apply**.

**Table 21-3: Message Policies Table Parameter Descriptions**

Parameter	Description
<b>General</b>	
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [Name]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 40 characters. <b>Note:</b> <ul style="list-style-type: none"> <li>■ Configure each row with a unique name.</li> <li>■ The parameter value can't contain a forward slash (/).</li> <li>■ The parameter value can't be configured with the character string "any" (upper or lower case).</li> </ul>
<b>Limits</b>	
'Max Message Length' max-message-length [MaxMessageLength]	Defines the maximum SIP message length. The valid value is up to 65,000 characters. The default is 65,000.
'Max Header Length' max-header-length	Defines the maximum SIP header length. The valid value is up to 4,096 characters. The default is

Parameter	Description
[MaxHeaderLength]	4,096.
'Max Body Length' max-body-length [MaxBodyLength]	Defines the maximum SIP message body length. This is the value of the Content-Length header. The valid value is up to 61,440 characters. The default is 61,440.
'Max Num Headers' max-num-headers [MaxNumHeaders]	Defines the maximum number of SIP headers. The valid value is any number up to 64. The default is 64. <b>Note:</b> The device supports up to 20 SIP Record-Route headers that can be received in a SIP INVITE request or a 200 OK response. If it receives more than this, it responds with a SIP 513 'Message Too Large' response.
'Max Num Bodies' max-num-bodies [MaxNumBodies]	Defines the maximum number of bodies (e.g., SDP) in the SIP message. The valid value is any number up to 64. The default is 64.
Policies	
'Send Rejection' send-rejection [SendRejection]	Defines whether the device sends a SIP response if it rejects a message request due to the Message Policy. The default response code is SIP 400 "Bad Request". To configure a different response code, use the [MessagePolicyRejectResponseType] parameter.  ■ [0] <b>Policy Reject</b> = (Default) The device discards the message and sends a SIP response to reject the request.  ■ [1] <b>Policy Drop</b> = The device discards the message without sending any response.
SIP Method Blocklist-Allowlist Policy	
'Method List' method-list [MethodList]	Defines the SIP methods for the blocklist or allowlist. Multiple methods are separated by a backslash (\), for example, "INVITE\BYE" (without quotations). The values are case-insensitive.
'Method List Type' method-list-type [MethodListType]	Defines the policy (blocklist or allowlist) for the SIP methods specified in the 'Method List' parameter (above).  ■ [0] <b>Policy Blocklist</b> = The specified methods are rejected.

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [1] <b>Policy Allowlist</b> = (Default) Only the specified methods are allowed; the others are rejected.</li> </ul>
SIP Body Blocklist-Allowlist Policy	
'Body List' body-list [BodyList]	Defines the SIP body type (i.e., value of the Content-Type header) to blocklist or allowlist. For example, application/sdp.  The values of the parameter are case-sensitive.
'Body List Type' body-list-type [BodyListType]	Defines the policy (blocklist or allowlist) for the SIP body specified in the 'Body List' parameter (above). <ul style="list-style-type: none"> <li>■ [0] <b>Policy Blocklist</b> =The specified SIP body is rejected.</li> <li>■ [1] <b>Policy Allowlist</b> = (Default) Only the specified SIP body is allowed; the others are rejected.</li> </ul>
Malicious Signature	
'Malicious Signature Database' signature-db-enable  [UseMaliciousSignatureDB]	Enables the use of the Malicious Signature database (signature-based detection). <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> To configure Malicious Signatures, see <a href="#">Configuring Malicious Signatures</a> on page 1137.  <b>Note:</b> The parameter is applicable only to the SBC application.

## Configuring Pre-Parsing Manipulation Rules

The Pre-Parsing Manipulation Set table lets you configure up to 10 Pre-Parsing Manipulation Sets. Pre-Parsing Manipulation allows you to manipulate incoming SIP messages (dialog-initiating and in-dialog) before they are parsed (as an object) by the device. In other words, messages can be manipulated in their original format (plain text) as received from the network. Pre-Parsing Manipulation may be useful, for example, to overcome parser strictness or to “allow” possible parsing errors.

To use a configured Pre-Parsing Manipulation Set, you need to assign it to a SIP Interface (see [Configuring SIP Interfaces](#) on page 561). The device performs Pre-Parsing Manipulation before Pre-Classification Manipulation and Classification.

Pre-Parsing Manipulation rules are defined by the SIP message element to manipulate (for example, INVITE), the pattern based on regular expression (regex) to search for (match) in the incoming message, and the regex pattern to replace the matched pattern.



- For a detailed description of supported regex syntax, refer to the document *Syntax for SIP Message Manipulation Reference Guide*.
- If you have configured call routing from the device's SBC application (IP-to-IP routing) to the device's Gateway application for IP-to-Tel routing, the device uses the initial SIP message as if it's a new call. Therefore, if any manipulations were done on the SIP message by the SBC application, the device ignores them.

Pre-Parsing Manipulation is configured using two tables with "parent-child" relationship:

- **Pre-Parsing Manipulation Sets table ("parent"):** Defines a descriptive name for the Pre-Parsing Manipulation Set.. You can configure up to 10 Pre-Parsing Manipulation Sets.
- **Pre-Parsing Manipulation Rules table ("child"):** Defines the actual manipulation rule. You can configure up to 30 rules in total (for all Pre-Parsing Manipulation Sets combined).

The following procedure describes how to configure Pre-Parsing Manipulation Sets through the Web interface. You can also configure it through other management platforms:

- **Pre-Parsing Manipulation Sets table:** *ini* file [PreParsingManipulationSets] or CLI (`configure voip > message pre-parsing-manip-sets`)
- **Pre-Parsing Manipulation Rules table:** *ini* file [PreParsingManipulationRules] or CLI (`configure voip > message pre-parsing-manip-rules`)

#### ➤ To configure Pre-Parsing Manipulation Sets:

1. Open the Pre-Parsing Manipulation Sets table (**Setup** menu > **Signaling & Media** tab > **Message Manipulation** folder > **Pre-Parsing Manipulation Sets**).
2. Click **New**; the following dialog box appears:

3. Configure a Pre-Parsing Manipulation Set name according to the parameters described in the table below.
4. Click **Apply**.

**Table 21-4: Pre-Parsing Manipulation Set Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [Name]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 40 characters. <b>Note:</b> <ul style="list-style-type: none"> <li>■ Configure each row with a unique name.</li> <li>■ The parameter value cannot contain a forward slash (/).</li> </ul>

- In the Pre-Parsing Manipulation Sets table, select the row, and then click the **Pre-Parsing Manipulation Rules** link located below the table; the Pre-Parsing Manipulation Rules table appears.
- Click **New**; the following dialog box appears:

The screenshot shows a dialog box titled "Pre-Parsing Manipulation Rules". It is divided into two main sections: "MATCH" and "ACTION".  
 In the "MATCH" section, there is an "Index" field with the value "0" and a "Message Type" field. An "Editor" button is located below the Message Type field.  
 In the "ACTION" section, there is a "Pattern" field and a "Replace-With" field. An "Editor" button is located below the Replace-With field.

- Configure a rule according to the parameters described in the table below.
- Click **New**, and then save your settings to flash memory.

**Table 21-5: Pre-Parsing Manipulation Rules Table Parameter Descriptions**

Parameter	Description
Match	
'Index' [PreParsingManipulationRules_ RuleIndex]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Message Type' message-type [PreParsingManipulationRules_ MessageType]	Defines the SIP message type to which you want to apply the rule. The following syntax is supported: <ul style="list-style-type: none"> <li>■ To apply the rule to any message type, leave the field empty or configure it to <b>any</b>.</li> <li>■ SIP requests:               <ul style="list-style-type: none"> <li>✓ <b>any.request:</b> The rule is applied to any request.</li> </ul> </li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>✓ <b>&lt;SIP Method&gt;.request:</b> The rule is applied to the specified SIP Method (e.g., invite.request).</li> <li>■ SIP responses: <ul style="list-style-type: none"> <li>✓ <b>any.response:</b> The rule is applied to any response.</li> <li>✓ <b>response.&lt;response code&gt;:</b> The rule is applied to messages with the specified response (e.g., response.200 for SIP 200 or response.1xx for any provisional response).</li> </ul> </li> </ul> <p>You can use the built-in syntax editor to help you configure the field. Click the <b>Editor</b> button located alongside the field to open the Editor, and then simply follow the on-screen instructions.</p>
Action	
'Pattern' pattern [PreParsingManipulationRules_ Pattern]	<p>Defines a pattern, based on regex, to search for (match) in the incoming message.</p> <p>For more information on regex, refer to the document <i>Syntax for SIP Message Manipulation Reference Guide</i>.</p>
'Replace-With' replace-with [PreParsingManipulationRules_ ReplaceWith]	<p>Defines a pattern, based on regex, to replace the matched pattern (defined above). You can use the built-in syntax editor to help you configure the field. Click the <b>Editor</b> button located alongside the field to open the Editor, and then simply follow the on-screen instructions.</p> <p>For more information on regex, refer to the document <i>Syntax for SIP Message Manipulation Reference Guide</i>.</p>

# Part V

## Gateway Application

## 22 Overview

This section describes configuration of the Gateway application. The Gateway application refers to IP-to-Tel and Tel-to-IP call routing. The term *Tel* refers to:


- Digital: PSTN

IP-to-Tel refers to calls received by the device from the IP network and then sent to the PSTN .  
Tel-to-IP refers to calls received by the device from or the PSTN and then sent to the IP network.

### Call Processing Summary


The device processes Gateway calls as shown below:

- IP-to-Tel Call:





### ■ Tel-to-IP Call:



## 23 Digital PSTN

This section describes the configuration of the device's Gateway application for its' digital interfaces (PSTN).

### Configuring Trunk Settings

The Trunk Settings page allows you to configure the device's PSTN trunks. This includes selecting the PSTN protocol and configuring related parameters. This page also lets you perform the following maintenance procedures:

- **Taking a Trunk Out of Service:** Some parameters can be configured when the trunk is in service, while others require you to take the trunk out of service. To take a trunk out of service, click the **Stop Trunk** button. Once a trunk is "stopped", all current calls are dropped and no new calls can be made on the trunk.
- **Creating a Loopback Line:** You can create (and remove) remote loopback for DS1 lines. This is done by clicking the **Create Loopback** button. To remove the loopback, click the **Remove Loopback** button.



- The parameters displayed on the Trunk Settings page depend on the configured protocol (see the 'Protocol Type' parameter).
- When modifying an already configured trunk through the Web interface, some parameters are unavailable (grayed out) until you stop the trunk.
- To delete a configured trunk, configure the 'Protocol Type' parameter to **NONE**.
- You can't configure trunks that are deactivated.
- You can't activate or deactivate a stopped trunk.
- You can't stop a trunk that is providing the device's clock. To stop such a trunk, assign a different trunk to provide the device's clock or enable the 'TDM Bus PSTN Auto Clock' parameter (see [TDM and Timing](#) on page 878).
- If you configure the 'Protocol Type' parameter to **NONE** (i.e., no protocol type) and no other trunks have been configured, after selecting a PRI protocol type, you must restart the device.
- All PRI trunks of the device must be of the same line type (E1 or T1). However, different variants of the same line type can be configured on different trunks.
- When configuring the device through ini file, if you want to configure a parameter for a specific trunk, append the parameter name with an underscore followed by the trunk's ID (i.e., <Parameter Name>\_x, where x denotes the trunk ID and 0 denotes trunk ID 1). For example, ProtocolType\_4 configures the protocol type for trunk ID 5.
- For a description of all the trunk parameters, see [PSTN Parameters](#) on page 1815.

The following procedure describes how to configure trunks through the Web interface. You can also configure trunks through ini file parameters or CLI (`configure voip > interface`).

➤ **To configure a new trunk:**

1. Open the Trunk Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Trunks & Groups** > **Trunks**).


**Trunk Settings**



GENERAL		ADVANCED SETTINGS	
Module ID	1	PSTN Alert Timeout	-1
Trunk ID	1	Out-Of-Service Behavior	Not Configured ▼
Trunk Configuration State	Not Configured	Remove Calling Name	Use Global Parameters ▼
Protocol Type	NONE ▼	Play Ringback Tone to Trunk	Not Configured ▼
		Call Rerouting Mode	None ▼
		Description	

On the top of the page, a bar with Trunk number icons displays the status of each trunk according to the following color codes:

- **Grey:** Disabled
  - **Green:** Active
  - **Yellow:** RAI alarm (also appears when you deactivate a Trunk by clicking the **Deactivate** button)
  - **Red:** LOS/LOF alarm
  - **Blue:** AIS alarm
  - **Orange:** D-channel alarm (ISDN only)
2. Select the trunk that you want to configure, by clicking the required trunk number icon. The bar initially displays the first eight trunk number icons (i.e., trunks 1 through 8), if they exist. To scroll through the trunk number icons (i.e., view the next / last or previous / first group of eight trunks), see the figure below. If the scroll bar displays all available trunks, the scroll bar buttons are unavailable.



3. To configure a new trunk:

- a. Configure the trunk parameters as required.
  - b. Click the **Apply Trunk Settings** button.
4. To modify an already configured trunk:
  - If you only need to modify parameters that don't require the trunk to be stopped (see previous note), simply modify their values, and then click **Submit**.
  - If you need to modify parameters that require the trunk to be stopped (see previous note), click the **Stop Trunk** button, modify their values, and then click the **Apply Trunk Settings** button to apply the changes to the selected trunk (or click **Apply to All Trunks** to apply the changes to all trunks); the 'Trunk Configuration State' read-only field displays "Active".
5. Restart the device with a save-to-flash for your settings to take effect.

**Table 23-1: Trunk Settings Table Parameter Descriptions**

Parameter	Description
General	
'Module ID'	(Read-only) Displays the module number to which the trunk belongs.
'Trunk ID'	(Read-only) Displays the selected trunk ID number.
'Trunk Configuration State'	(Read-only) Displays the status of the trunk: <ul style="list-style-type: none"> <li>■ "Not Configured": The trunk is not configured.</li> <li>■ "Active": The trunk is configured and currently active.</li> <li>■ "Inactive": The trunk is configured, but was stopped and is inactive (not operational).</li> </ul>
'Protocol Type' configure voip > interface e1- t1 bri > protocol [ProtocolType]	Defines the PSTN protocol for the specific trunk. <ul style="list-style-type: none"> <li>■ [0] <b>NONE</b></li> <li>■ [1] <b>E1 EURO ISDN</b> = ISDN PRI Pan-European (CTR4) protocol</li> <li>■ [2] <b>T1 CAS</b> = Common T1 robbed bits protocols including E&amp;M wink start, E&amp;M immediate start, E&amp;M delay dial/start and loop-start and ground start.</li> <li>■ [3] <b>T1 RAW CAS</b></li> <li>■ [4] <b>T1 TRANSPARENT</b> = Transparent protocol, where no signaling is provided by the device. Timeslots 1 to 24 of all trunks are mapped to DSP channels.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [5] <b>E1 TRANSPARENT 31</b> = Transparent protocol, where no signaling is provided by the device. Timeslots 1 to 31 of each trunk are mapped to DSP channels.</li> <li>■ [6] <b>E1 TRANSPARENT 30</b> = Transparent protocol, where no signaling is provided by the device. Timeslots 1 to 31, excluding time slot 16 of all trunks are mapped to DSP channels.</li> <li>■ [7] <b>E1 MFCR2</b> = Common E1 MFC/R2 CAS protocols (including line signaling and compelled register signaling).</li> <li>■ [8] <b>E1 CAS</b> = Common E1 CAS protocols (including line signaling and MF/DTMF address transfer).</li> <li>■ [9] <b>E1 RAW CAS</b></li> <li>■ [10] <b>T1 NI2 ISDN</b> = National ISDN 2 PRI protocol</li> <li>■ [11] <b>T1 4ESS ISDN</b> = ISDN PRI protocol for the Lucent™/AT&amp;T™ 4ESS switch.</li> <li>■ [12] <b>T1 5ESS 9 ISDN</b> = ISDN PRI protocol for the Lucent™/AT&amp;T™ 5ESS-9 switch.</li> <li>■ [13] <b>T1 5ESS 10 ISDN</b> = ISDN PRI protocol for the Lucent™/AT&amp;T™ 5ESS-10 switch.</li> <li>■ [14] <b>T1 DMS100 ISDN</b> = ISDN PRI protocol for the Nortel™ DMS switch.</li> <li>■ [15] <b>J1 TRANSPARENT</b></li> <li>■ [16] <b>T1 NTT ISDN</b> = ISDN PRI protocol for the Japan - Nippon Telegraph Telephone (known also as INS 1500).</li> <li>■ [17] <b>E1 AUSTEL ISDN</b> = ISDN PRI protocol for the Australian Telecom.</li> <li>■ [18] <b>E1 HKT ISDN</b> = ISDN PRI (E1) protocol for the Hong Kong - HKT.</li> <li>■ [19] <b>E1 KOR ISDN</b> = ISDN PRI protocol for Korean Operator (similar to ETSI).</li> <li>■ [20] <b>T1 HKT ISDN</b> = ISDN PRI (T1) protocol for the Hong Kong - HKT.</li> <li>■ [21] <b>E1 QSIG</b> = ECMA 143 QSIG over E1</li> <li>■ [22] <b>E1 TNZ</b> = ISDN PRI protocol for Telecom New</li> </ul>

Parameter	Description
	<p>Zealand (similar to ETSI)</p> <ul style="list-style-type: none"> <li>■ [23] <b>T1 QSIG</b> = ECMA 143 QSIG over T1</li> <li>■ [30] <b>E1 FRENCH VN6 ISDN</b> = France Telecom VN6</li> <li>■ [31] <b>E1 FRENCH VN3 ISDN</b> = France Telecom VN3</li> <li>■ [34] <b>T1 EURO ISDN</b> = ISDN PRI protocol for Euro over T1</li> <li>■ [35] <b>T1 DMS100 Meridian ISDN</b> = ISDN PRI protocol for the Nortel™ DMS Meridian switch</li> <li>■ [36] <b>T1 NI1 ISDN</b> = National ISDN 1 PRI protocol</li> <li>■ [40] <b>E1 NI2 ISDN</b> = National ISDN 2 PRI protocol over E1</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you are modifying the parameter for an already configured trunk through the Web interface, stop the trunk prior to configuring it.</li> <li>■ All PRI trunks must be configured with the same protocol type (E1 or T1). The device can support different variants of CAS and PRI protocols on different E1/T1 spans (no more than four simultaneous PRI variants).</li> </ul>
Trunk Configuration	
<p>'Clock Master'</p> <pre>configure voip &gt; interface e1-t1 &gt; clock-master [ClockMaster]</pre>	<p>Defines the Tx clock source of the E1/T1 line.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Recovered</b> = (Default) Generates the clock according to the Rx of the E1/T1 line.</li> <li>■ [1] <b>Generated</b> = Generates the clock according to the internal TDM bus.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you are modifying the parameter for an already configured trunk through the Web interface, first stop the trunk.</li> <li>■ To configure the source of the internal TDM bus clock, see the [TDMBusClockSource] parameter.</li> <li>■ The parameter is applicable only to E1/T1 interfaces.</li> </ul>
<p>'Auto Clock Trunk Priority'</p> <pre>configure voip &gt; interface e1-</pre>	<p>Defines the trunk priority for auto-clock fallback for the specific trunk.</p> <p>The valid range is 0 to 100, where 0 (default) is the highest</p>

Parameter	Description
<pre>t1 bri &gt; clock- priority clock- priority</pre> <p>[AutoClockTrunkPriority]</p>	<p>priority and 100 indicates that the device doesn't perform a fallback to the trunk (typically used to mark untrusted source of clock).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you are modifying the parameter for an already configured trunk through the Web interface, first stop the trunk.</li> <li>■ To enable auto-clock fallback, configure the [TDMBusPSTNAutoClockEnable] parameter to 1.</li> </ul>
<p>'Line Code'</p> <pre>configure voip &gt; interface e1-t1 &gt; line-code</pre> <p>[LineCode]</p>	<p>Defines the line code for the specific trunk.</p> <ul style="list-style-type: none"> <li>■ [0] <b>B8ZS</b> = (Default) B8ZS line code (applicable only to T1 trunks).</li> <li>■ [1] <b>AMI</b> = AMI line code.</li> <li>■ [2] <b>HDB3</b> = HDB3 line code (applicable only to E1 trunks).</li> </ul> <p>■ If you are modifying the parameter for an already configured trunk through the Web interface, first stop the trunk.</p> <p>■ The parameter is applicable only to E1/T1 trunks.</p>
<p>'Line Build Out Loss'</p> <pre>configure voip &gt; interface e1-t1 &gt; line-build-out- loss</pre> <p>[LineBuildOut.Loss]</p>	<p>Defines the line build out loss for the specific trunk.</p> <ul style="list-style-type: none"> <li>■ [0] <b>0 dB</b> (default)</li> <li>■ [1] <b>-7.5 dB</b></li> <li>■ [2] <b>-15 dB</b></li> <li>■ [3] <b>-22.5 dB</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you are modifying the parameter for an already configured trunk through the Web interface, first stop the trunk.</li> <li>■ The parameter is applicable only to T1 trunks.</li> </ul>
<p>'Trace Level'</p> <pre>configure voip &gt; interface e1- t1 bri &gt; trace- level</pre>	<p>Defines the trace level for the specific trunk.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No Trace</b> (default)</li> <li>■ [1] <b>Full ISDN Trace</b></li> <li>■ [2] <b>Layer 3 ISDN Trace</b></li> </ul>

Parameter	Description
[TraceLevel]	<ul style="list-style-type: none"> <li>■ [3] <b>Only ISDN Q.931 Messages Trace</b></li> <li>■ [4] <b>Layer 3 ISDN No Duplication Trace</b></li> </ul>
'Framing Method' <pre>configure voip &gt; interface e1-t1 &gt; framing</pre> [FramingMethod]	Defines the physical framing method for the specific trunk. <ul style="list-style-type: none"> <li>■ [0] <b>Extended Super Frame</b> = (Default) Depends on protocol type:               <ul style="list-style-type: none"> <li>✓ E1: E1 CRC4 MultiFrame Format extended G.706B (same as c)</li> <li>✓ T1: T1 Extended Super Frame with CRC6 (same as D)</li> </ul> </li> <li>■ [1] <b>Super Frame</b> = T1 SuperFrame Format (as B).</li> <li>■ [a] <b>E1 FRAMING DDF</b> = E1 DoubleFrame Format - CRC4 is forced to off</li> <li>■ [b] <b>E1 FRAMING MFF CRC4</b> = E1 CRC4 MultiFrame Format - CRC4 is always on</li> <li>■ [c] <b>E1 FRAMING MFF CRC4 EXT</b> = E1 CRC4 MultiFrame Format extended G.706B - auto negotiation is on. If the negotiation fails, it changes automatically to CRC4 off (ddf)</li> <li>■ [A] <b>T1 FRAMING F4</b> = T1 4-Frame multiframe.</li> <li>■ [B] <b>T1 FRAMING F12</b> = T1 12-Frame multiframe (D4).</li> <li>■ [C] <b>T1 FRAMING ESF</b> = T1 Extended SuperFrame without CRC6</li> <li>■ [D] <b>T1 FRAMING ESF CRC6</b> = T1 Extended SuperFrame with CRC6</li> <li>■ [E] <b>T1 FRAMING F72</b> = T1 72-Frame multiframe (SLC96)</li> <li>■ [F] <b>T1 FRAMING ESF CRC6 J2</b> = J1 Extended SuperFrame with CRC6 (Japan)</li> </ul>
ISDN Configuration	
'ISDN Termination Side' <pre>configure voip &gt; interface e1- t1 bri &gt; isdn- termination-side</pre> [TerminationSide]	Defines the ISDN termination side for the specific trunk. <ul style="list-style-type: none"> <li>■ [0] <b>User side</b> = (Default) ISDN User Termination Equipment (TE) side.</li> <li>■ [1] <b>Network side</b> = ISDN Network Termination (NT) side.</li> </ul> <p><b>Note:</b></p>



Parameter	Description
	<ul style="list-style-type: none"> <li>■ For clock synchronization of E1/T1 interfaces, to configure if the clock is recovered (from the line) or generated (by the device), see the 'Clock Master' parameter (above).</li> <li>✓ If the parameter is configured to <b>User side</b>, the clock is recovered from the line.</li> <li>■ If you are modifying the parameter for an already configured trunk through the Web interface, first stop the trunk.</li> <li>■ Select <b>User side</b> when the PSTN or PBX side is configured as <b>Network side</b>, and vice versa. If you don't know the device's ISDN termination side, select <b>User side</b>. If the D-channel alarm is indicated, choose <b>Network side</b>.</li> </ul>
<p>'Q.931 Layer Response Behavior'</p> <pre>configure voip &gt; interface bri e1- t1 &gt; isdn-bits-ns- behavior</pre> <p>[ISDNIBehavior]</p>	<p>Defines (by bit-field) several behavior options that influence the behavior of the Q.931 protocol.</p> <ul style="list-style-type: none"> <li>■ [0] = Disable (default).</li> <li>■ [1] <b>NO STATUS ON UNKNOWN IE</b> = Q.931 Status message isn't sent if Q.931 received message contains an unknown/unrecognized IE. By default, the Status message is sent. <b>Note:</b> This value is applicable only to ISDN variants in which sending of Status message is optional.</li> <li>■ [2] <b>NO STATUS ON INV OP IE</b> = Q.931 Status message isn't sent if an optional IE with invalid content is received. By default, the Status message is sent. <b>Note:</b> This option is applicable only to ISDN variants in which sending of Status message is optional.</li> <li>■ [4] <b>ACCEPT UNKNOWN FAC IE</b> = Accepts unknown/unrecognized Facility IE. Otherwise, the Q.931 message that contains the unknown Facility IE is rejected (default). <b>Note:</b> This option is applicable only to ISDN variants where a complete ASN1 decoding is performed on Facility IE.</li> <li>■ [128] <b>SEND USER CONNECT ACK</b> = The Connect ACK message is sent in response to received Q.931 Connect; otherwise, the Connect ACK is not sent. <b>Note:</b> This option is applicable only to Euro ISDN User</li> </ul>

Parameter	Description
	<p>side outgoing calls.</p> <ul style="list-style-type: none"> <li>■ [512] <b>EXPLICIT INTERFACE ID</b> = Enables configuration of T1 NFAS Interface ID. For more information on NFAS, see the [ISDNNFASInterfaceID_x] parameter. <b>Note:</b> This value is applicable only to 4/5ESS, DMS, NI-2 and HKT variants.</li> <li>■ [2048] <b>ALWAYS EXPLICIT</b> = Always set the Channel Identification IE to explicit Interface ID, even if the B-channel is on the same trunk as the D-channel. <b>Note:</b> This value is applicable only to 4/5ESS, DMS and NI-2 variants.</li> <li>■ [32768] <b>ACCEPT MU LAW</b> =Mu-Law is also accepted in ETSI.</li> <li>■ [65536] <b>EXPLICIT PRES SCREENING</b> = The calling party number (octet 3a) is always present even when presentation and screening are at their default. <b>Note:</b> This option is applicable only to ETSI, NI-2, and 5ESS.</li> <li>■ [131072] <b>STATUS INCOMPATIBLE STATE</b> = Clears the call on receipt of Q.931 Status with incompatible state. Otherwise, no action is taken (default).</li> <li>■ [262144] <b>STATUS ERROR CAUSE</b> = Clear call on receipt of Status according to cause value.</li> <li>■ [524288] <b>ACCEPT A LAW</b> =A-Law is also accepted in 5ESS.</li> <li>■ [2097152] <b>RESTART INDICATION</b> = Upon receipt of a Restart message, acEV_PSTN_RESTART_CONFIRM is generated.</li> <li>■ [4194304] <b>FORCED RESTART</b> = On data link (re)initialization, send RESTART (Class 7) if there is no call.</li> <li>■ [67108864] <b>NS ACCEPT ANY CAUSE</b> = Accept any Q.850 Cause IE from ISDN. <b>Note:</b> This option is applicable only to Euro ISDN.</li> <li>■ [536870912] <b>QSI ACCEPT ALCATEL FAC</b> = Alcatel coding for redirect number and display name is accepted by the device. <b>Note:</b> This option is applicable only to QSIG (and</li> </ul>

Parameter	Description
	<p>relevant for specific Alcatel PBXs such as OXE).</p> <ul style="list-style-type: none"> <li>■ [1073741824] <b>QSI ENCODE INTEGER</b> = If this bit is set, INTEGER ASN.1 type is used in operator coding (compliant to new ECMA standards); otherwise, OBJECT IDENTIFIER ASN.1 type is used. <b>Note:</b> This option is applicable only to QSIG.</li> <li>■ [2147483648] <b>5ESS National Mode For Bch Maintenance</b> = Use the National mode of AT&amp;T 5ESS for B-channel maintenance. <b>Note:</b> <ul style="list-style-type: none"> <li>■ If you are modifying the parameter for an already configured trunk through the Web interface, first stop the trunk.</li> <li>■ When configuring through the Web interface, click the arrow button and then for each required option select <b>1</b> to enable.</li> <li>■ When configuring through ini file, to support multiple behaviors, configure the parameter with a summation of the individual feature values. For example, to support both [512] and [2048] features, configure the parameter to 2560 (i.e., 512 plus 2048).</li> </ul> </li> </ul>
<p>'Outgoing Calls Behavior'</p> <pre>configure voip &gt; interface bri e1- t1 &gt; isdn-bits- outgoing-calls- behavior [ISDNOutCallsBehavior]</pre>	<p>Defines (by bit-field) several options that influence the behavior of the ISDN Stack outgoing calls. To select the options, click the arrow button, and then for each required option, select <b>1</b> to enable. The default is <b>0</b> (i.e., disabled).</p> <ul style="list-style-type: none"> <li>■ [2] <b>USER SENDING COMPLETE</b> = The default behavior of the device (when this bit is not set) is to automatically generate the Sending-Complete IE in the Setup message. This behavior is used when overlap dialing is not needed. When overlap dialing is needed, set this bit and the behavior is changed to suit the scenario, i.e., Sending-Complete IE is added when required in the Setup message for Enblock mode or in the last Digit with Overlap mode.</li> <li>■ [16] <b>USE MU LAW</b> = The device sends G.711-m-Law in outgoing voice calls. When disabled, the device sends G.711-A-Law in outgoing voice calls. <b>Note:</b> This option is applicable only to the Korean vari-</li> </ul>

Parameter	Description
	<p>ant.</p> <ul style="list-style-type: none"> <li>■ [128] <b>DIAL WITH KEYPAD</b> = The device uses the Keypad IE to store the called number digits instead of the CALLED_NB IE.</li> </ul> <p><b>Note:</b> This option is applicable only to the Korean variant (Korean network). This is useful for Korean switches that don't accept the CALLED_NB IE.</p> <ul style="list-style-type: none"> <li>■ [256] <b>STORE CHAN ID IN SETUP</b> = The device forces the sending of a Channel-Id IE in an outgoing Setup message even if it's not required by the standard (i.e., optional) and no Channel-Id has been specified in the establishment request. This is useful for improving required compatibility with switches. On PRI lines it indicates an unused channel ID, preferred only.</li> <li>■ [512] <b>USE A LAW</b> = The device sends G.711 A-Law in outgoing voice calls. When disabled, the device sends the default G.711-Law in outgoing voice calls.</li> </ul> <p><b>Note:</b> The option is applicable only to the E10 variant (T1 ISDN).</p> <ul style="list-style-type: none"> <li>■ [1024] = Numbering plan/type for T1 IP-to-Tel calling numbers are defined according to the manipulation tables or according to the RPID header (default). Otherwise, the plan/type for T1 calls are set according to the length of the calling number.</li> </ul> <p><b>Note:</b> The option is applicable only to T1 ISDN.</p> <ul style="list-style-type: none"> <li>■ [2048] = The device accepts any IA5 character in the called_nb and calling_nb strings and sends any IA5 character in the called_nb, and is not restricted to extended digits only (i.e., 0-9,*,#).</li> <li>■ [16384] <b>DLCI REVERSED OPTION</b> = Behavior bit used in the IUA interface groups to indicate that the reversed format of the DLCI field must be used.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you are modifying the parameter for an already configured trunk through the Web interface, first stop the trunk.</li> <li>■ When configuring through <i>ini</i> file, to support multiple</li> </ul>

Parameter	Description
	options, enter a summation of the individual feature values. For example, to support both [2] and [16] features: ISDNOutCallsBehavior = 18
'Incoming Calls Behavior' configure voip > interface el- t1 bri > isdn- bits-incoming- calls-behavior [ISDNInCallsBehavior]	<p>Defines (by bit-field) several options that influence how the ISDN Stack INCOMING calls behave.</p> <ul style="list-style-type: none"> <li>■ [32] <b>DATA CONN RS</b> = The device automatically sends a Q.931 Connect (answer) message on incoming Tel calls (Q.931 Setup).</li> <li>■ [64] <b>VOICE CONN RS</b> = The device sends a Connect (answer) message on incoming Tel calls.</li> <li>■ [2048] <b>CHAN ID IN FIRST RS</b> = The device sends Channel ID in the first response to an incoming Q.931 Call Setup message. If not set, the Channel ID is sent only if the device requires changing the proposed Channel ID.</li> <li>■ [4096] <b>USER SETUP ACK</b> = (Default) The Setup Ack message is sent by the SIP Gateway application layer and not automatically by the PSTN stack.</li> <li>■ [8192] <b>CHAN ID IN CALL PROC</b> = The device sends Channel ID in a Q.931 Call Proceeding message.</li> <li>■ [65536] <b>PROGR IND IN SETUP ACK</b> = (Default) The device includes Progress Indicator (PI=8) in Setup Ack message if an empty called number is received in an incoming Setup message. This option is applicable to the overlap dialing mode. The device also plays a dial tone (for TimeForDialTone) until the next called number digits are received.</li> <li>■ [2147483648] <b>USER SCREEN INDICATOR</b> = When the device receives two Calling Number IE's in the Setup message, the device, by default, uses only one of the numbers according to the following: <ul style="list-style-type: none"> <li>✓ Network provided, Network provided: first calling number is used</li> <li>✓ Network provided, User provided: first calling number is used</li> <li>✓ User provided, Network provided: second calling number is used</li> <li>✓ User provided, user provided: first calling number is</li> </ul> </li> </ul>

Parameter	Description
	<p>used</p> <p>When this bit is configured, the device behaves as follows:</p> <ul style="list-style-type: none"> <li>✓ Network provided, Network provided: first calling number is used</li> <li>✓ Network provided, User provided: second calling number is used</li> <li>✓ User provided, Network provided: first calling number is used</li> <li>✓ User provided, user provided: first calling number is used</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you are modifying the parameter for an already configured trunk through the Web interface, first stop the trunk.</li> <li>■ In the Web interface, the parameter displays the summation of the enabled optional bit values in hex format. For example, the default value is 0x11000 (69632 in decimal), which is a summation of the two bit options, USER SETUP ACK (0x01000 or 4096 in decimal) and PROGR IND IN SETUP ACK (0x10000 or 65536 in decimal) that are enabled by default (i.e., 4096 + 65536 = 69632).</li> <li>■ When configuring through <i>ini</i> file, to support multiple options, enter a summation of the individual feature values. For example, to support both [2048] and [65536] features: ISDNInCallsBehavior = 67584</li> </ul>
<p>'General Call Control Behavior'</p> <pre>configure voip &gt; interface e1- t1 bri &gt; isdn- bits-cc-behavior [ISDNGeneralCCBehavior]</pre>	<p>Defines (by bit-field) several general CC behavior options. To select the options, click the arrow button, and then for each required option, select <b>1</b> to enable. The default is <b>0</b> (i.e., disabled).</p> <ul style="list-style-type: none"> <li>■ [2] = Data calls with interworking indication use 64 kbps B-channels (physical only).</li> <li>■ [8] <b>REVERSE CHAN ALLOC ALGO</b> = Channel ID allocation algorithm.</li> <li>■ [16] = The device clears down the call if it receives a</li> </ul>

Parameter	Description
	<p>NOTIFY message specifying 'User-Suspended'. A NOTIFY (User-Suspended) message is used by some networks (e.g., in Italy or Denmark) to indicate that the remote user has cleared the call, especially in the case of a long distance voice call.</p> <ul style="list-style-type: none"> <li>■ [32] <b>CHAN ID 16 ALLOWED</b> = Applies only to ETSI E1 lines (30B+D). Enables handling the differences between the newer QSIG standard (ETS 300-172) and other ETSI-based standards (ETS 300-102 and ETS 300-403) in the conversion of B-channel ID values into timeslot values: <ul style="list-style-type: none"> <li>✓ In 'regular ETSI' standards, the timeslot is identical to the B-channel ID value, and the range for both is 1 to 15 and 17 to 31. The D-channel is identified as channel-id #16 and carried into the timeslot #16.</li> <li>✓ In newer QSIG standards, the channel-id range is 1 to 30, but the timeslot range is still 1 to 15 and 17 to 31. The D-channel is not identified as channel-id #16, but is still carried into the timeslot #16. When this bit is set, the channel ID #16 is considered as a valid B-channel ID, but timeslot values are converted to reflect the range 1 to 15 and 17 to 31. This is the new QSIG mode of operation. When this bit is not set (default), the channel_id #16 is not allowed, as for all ETSI-like standards.</li> </ul> </li> <li>■ [64] <b>USE T1 PRI</b> = PRI interface type is forced to T1.</li> <li>■ [128] <b>USE E1 PRI</b> = PRI interface type is forced to E1.</li> <li>■ [256] <b>START WITH B CHAN OOS</b> = B-channels start in the Out-Of-Service state (OOS).</li> <li>■ [512] <b>CHAN ALLOC LOWEST</b> = CC allocates B-channels starting from the lowest available B-channel id.</li> <li>■ [1024] <b>CHAN ALLOC HIGHEST</b> = CC allocates B-channels starting from the highest available B-channel id.</li> <li>■ [4096] <b>NO B CHANNEL CONTROL</b> = When this bit is set, B-channels allocation and control is left according to the application level. Call control doesn't control / allocate B-channels. The application provides the B-channel information within the appropriate ACU primitives. Call Control simply provides the received Channel-ID IE contents to the user, without checking its availability,</li> </ul>

Parameter	Description
	<p>validity or consistency with other calls in progress. This bit should be set when the B-channel can be changed in Q.931 Proceeding, Alerting, or Connect.</p> <ul style="list-style-type: none"> <li>■ [16384] <b>CC_TRANSPARENT_UUI</b> = The UUI-protocol implementation of CC is disabled allowing the application to freely send UUI elements in any primitive, regardless of the UUI-protocol requirements (UUI Implicit Service 1). This allows more flexible application control on the UUI. When this bit is not set (default behavior), CC implements the UUI-protocol as specified in the ETS 300-403 standards for Implicit Service 1.</li> <li>■ [65536] <b>GTD5 TBCT</b> = CC implements the VERIZON-GTD-5 Switch variant of the TBCT Supplementary Service, as specified in FSD 01-02-40AG Feature Specification Document from Verizon. Otherwise, TBCT is implemented as specified in GR-2865-CORE specification (default behavior).</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you are modifying the parameter for an already configured trunk through the Web interface, first stop the trunk.</li> <li>■ When configuring through <i>ini</i> file, to support multiple options, enter a summation of the individual feature values. For example, to support both [16] and [32] features: <code>ISDNGeneralCCBehavior = 48</code></li> </ul>
<p>'ISDN NS Behaviour 2'</p> <pre>configure voip &gt; interface e1- t1 bri &gt; isdn- bits-ns-extension- behavior [ISDNNSBehaviour2]</pre>	<p>Defines (by bit-field) several options that influence the behavior of the Q.931 protocol for the specific trunk.</p> <ul style="list-style-type: none"> <li>■ [8] <b>NS BEHAVIOUR2 ANY UUI</b> = Any User to User Information Element (UUIE) is accepted for any protocol discriminator. This is useful for interoperability with non-standard switches.</li> <li>■ [16] <b>NS BEHAVIOUR2 DISPLAY</b> = The Display IE is accepted even if it is not defined in the QSIG ISDN protocol standard. This is applicable only when configuration is QSI.</li> <li>■ [64] <b>NS BEHAVIOUR2 FAC REJECT</b> = When this bit is set, the device answers with a Facility IE message with the Reject component on receipt of Facility IE with</li> </ul>



Parameter	Description
	<p>unknown/invalid Invoke component. This bit is implemented in QSIG and ETSI variants.</p> <ul style="list-style-type: none"> <li>■ [256] <b>RESTART CLASS 7 IN FORCE RESTART</b> = When this bit is set, the device sends RESTART (Class 7) if there is no call, on data link (re)initialization.</li> </ul>
<p>'NFAS Group Number'</p> <pre>configure voip &gt; interface e1-t1 &gt; isdn-nfas-group- number</pre> <p>[NFASGroupNumber]</p>	<p>Defines the ISDN Non-Facility Associated Signaling (NFAS) group number (NFAS member) for the specific trunk.</p> <ul style="list-style-type: none"> <li>■ [0] 0 = (Default) Non-NFAS trunk.</li> <li>■ [1-12] 1 to 12 = NFAS group number.</li> </ul> <p>Trunks belonging to the same NFAS group have the same number. With NFAS, you can use a single D-channel to control multiple PRI interfaces.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you are modifying the parameter for an already configured trunk through the Web interface, first stop the trunk.</li> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ The parameter is applicable only to T1 ISDN protocols.</li> <li>■ For more information on NFAS, see <a href="#">ISDN Non-Facility Associated Signaling (NFAS)</a> on page 895.</li> </ul>
<p>'NFAS Interface ID'</p> <pre>configure voip &gt; interface e1-t1 &gt; isdn-nfas- interface-id</pre> <p>[ISDNNFASInterfaceID]</p>	<p>Defines a different Interface ID for the specific trunk. The valid range is 0 to 100. The default interface ID equals the trunk's ID.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you are modifying the parameter for an already configured trunk through the Web interface, first stop the trunk.</li> <li>■ To set the NFAS interface ID, configure the [ISDNBehavior_x] parameter to include '512' feature per T1 trunk.</li> <li>■ The parameter is applicable only to T1 ISDN protocols.</li> <li>■ For more information on NFAS, see <a href="#">ISDN Non-Facility Associated Signaling (NFAS)</a> on page 895.</li> </ul>
'D-channel Configuration'	Defines the specific trunk as primary, backup (optional), or

Parameter	Description
<pre>configure voip &gt; interface e1-t1 &gt; isdn-nfas- dchannel-type [DChConfig]</pre>	<p>B-channel.</p> <ul style="list-style-type: none"> <li>■ [0] <b>PRIMARY</b>= (Default) Primary Trunk - contains a D-channel that is used for signaling.</li> <li>■ [1] <b>BACKUP</b> = Backup Trunk - contains a backup D-channel that is used if the primary D-channel fails.</li> <li>■ [2] <b>NFAS</b> = NFAS Trunk - contains only 24 B-channels, without a signaling D-channel.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you are modifying the parameter for an already configured trunk through the Web interface, first stop the trunk.</li> <li>■ The parameter is applicable only to T1 ISDN protocols.</li> <li>■ For more information on NFAS, see <a href="#">ISDN Non-Facility Associated Signaling (NFAS)</a> on page 895.</li> </ul>
<b>CAS Configuration</b>	
<p>'Dial Plan'</p> <pre>configure voip &gt; interface e1-t1 &gt; cas-dial-plan-name</pre> <p>[CASTrunkDialPlanName_x]</p>	<p>Defines the CAS Dial Plan name for the specific trunk. The range is up to 11 characters.</p> <p>For example, the following configures an E1_MFCR2 trunk with a single protocol (Trunk 5):</p> <pre>ProtocolType_5 = 7 CASFileName_0='R2_Korea_CP_ANI.dat' CASTableIndex_5 = 0 DialPlanFileName = 'DialPlan_USA.dat' CASTrunkDialPlanName_5 = 'AT_T'</pre>
<p>'CAS Table per Trunk'</p> <pre>configure voip &gt; interface e1-t1 &gt; cas-table-index</pre> <p>[CASTableIndex_x]</p>	<p>Defines the CAS protocol for the specific trunk from a list of CAS protocols defined by the parameter CASFileName_x.</p> <p>For example, the below configuration specifies Trunks 0 and 1 to use the E&amp;M Winkstart CAS (E_M_WinkTable.dat) protocol, and Trunks 2 and 3 to use the E&amp;M Immediate Start CAS (E_M_ImmediateTable.dat) protocol:</p> <pre>CASFileName_0 = 'E_M_WinkTable.dat' CASFileName_1 = 'E_M_ImmediateTable.dat' CASTableIndex_0 = 0 CASTableIndex_1 = 0 CASTableIndex_2 = 1 CASTableIndex_3 = 1</pre>

Parameter	Description
	<p><b>Note:</b> To configure CAS tables per B-channel, see the [CASChannelIndex] parameter.</p>
<p>'CAS Table per Channel'</p> <pre>configure voip &gt; interface e1-t1 &gt; cas-channel-index [CASChannelIndex]</pre>	<p>Defines the loaded CAS protocol table index per B-channel pertaining to a CAS trunk. The parameter is assigned a string value and can be set in one of the following two formats:</p> <ul style="list-style-type: none"> <li>■ <b>CAS table per channel:</b> Each channel is separated by a comma and the value entered denotes the CAS table index used for that channel. The syntax is &lt;CAS index&gt;,&lt;CAS index&gt; (e.g., "1,2,1,2..."). For this format, 31 indices must be defined for E1 trunks (including dummy for B-channel 16), or 24 indices for T1 trunks. Below is an example for configuring a T1 CAS trunk (Trunk 5) with several CAS variants:</li> </ul> <pre>ProtocolType_5 = 7 CASFILENAME_0='E_M_FGBWinkTable.dat' CASFILENAME_1='E_M_FGDWinkTable.dat' CASFILENAME_2='E_M_WinkTable.txt' CasChannelIndex_5 = '0,0,0,1,1,1,2,2,2,0,0,0,1,1,1,0,1,2,0,2, 1,2,2,2' CASDelimitersPaddingUsage_5 = 1</pre> <ul style="list-style-type: none"> <li>■ <b>CAS table per channel group:</b> Each channel group is separated by a colon and each channel is separated by a comma. The syntax is &lt;x-y channel range&gt;:&lt;CAS table index&gt;, (e.g., "1-10:1,11-31:3"). Every B-channel (including 16 for E1) must belong to a channel group. Below is an example for configuring an E1 CAS trunk (Trunk 5) with several CAS variants:</li> </ul> <pre>ProtocolType_5 = 8 CASFILENAME_2='E1_R2D' CASFILENAME_7= E_M_ImmediateTable_A- Bit.txt' CasChannelIndex_5 = '1-10:2,11-20:7,21- 31:2'</pre> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ To configure the parameter, first stop the trunk.</li> <li>■ Only one of these formats can be implemented (not both).</li> <li>■ When the parameter is not configured, a single CAS</li> </ul>

Parameter	Description
	table is used for the entire trunk (configured by the [CASTableIndex] parameter).
<b>Advanced Settings</b>	
<b>'PSTN Alert Timeout'</b> <pre>configure voip &gt; interface e1- t1 bri &gt; pstn- alrt-timeout</pre> [TrunkPSTNAlertTimeout]	<p>Defines the Alert Timeout (ISDN T301 timer) in seconds for outgoing calls to PSTN for the specific trunk. This timer is used between the time that an ISDN Setup message is sent to the Tel side (IP-to-Tel call establishment) and a Connect message is received. If Alerting is received, the timer is restarted.</p> <p>The range is 1 to 600. The default is 180.</p>
<b>'Local ISDN Ringback Tone Source'</b> <pre>configure voip &gt; interface e1- t1 bri &gt; local- isdn-rbt-src</pre> [LocalISDNRBSource]	<p>Defines if the ringback tone is played to the ISDN by the PBX/PSTN or by the device for the specific trunk.</p> <ul style="list-style-type: none"> <li>■ [0] <b>PBX</b> = (Default) PBX/PSTN plays the ringback tone.</li> <li>■ [1] <b>Gateway</b> = The device plays the ringback tone.</li> </ul> <p><b>Note:</b> The parameter is used together with the [PlayRBTone2Trunk] parameter.</p>
<b>'Set PI in Rx Disconnect Message'</b> <pre>configure voip &gt; interface e1- t1 bri &gt; pi-in-rx- disc-msg</pre> [PIForDisconnectMsg]	<p>Defines the device's behavior for the specific trunk when a Disconnect message is received from the ISDN before a Connect message is received.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> = (Default) Sends a 183 SIP response according to the received progress indicator (PI) in the ISDN Disconnect message. If PI = 1 or 8, the device sends a 183 response, enabling the PSTN to play a voice announcement to the IP side. If there isn't a PI in the Disconnect message, the call is released.</li> <li>■ [0] <b>No PI</b> = Doesn't send a 183 response to IP. The call is released.</li> <li>■ [1] <b>PI = 1</b> = Sends a 183 response to IP.</li> <li>■ [8] <b>PI = 8</b> = Sends a 183 response to IP.</li> </ul>
<b>'ISDN Transfer Capabilities'</b> <pre>configure voip &gt; interface e1- t1 bri &gt; isdn- xfer-cab</pre> [ISDNTransferCapability]	<p>Defines the IP-to-ISDN Transfer Capability of the Bearer Capability IE in ISDN Setup messages for the specific trunk (where the x in the ini file parameter name denotes the trunk number and where 0 is Trunk 1).</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b></li> <li>■ [0] <b>Audio 3.1</b> (default)</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [1] <b>Speech</b></li> <li>■ [2] <b>Data</b></li> <li>■ [3] <b>Audio 7</b></li> </ul> <p><b>Note:</b> If the parameter is not configured or configured to <b>Not Configured</b>, Audio 3.1 capability is used.</p>
<p>'Progress Indicator to ISDN'</p> <pre>configure voip &gt; interface e1- t1 bri &gt; pi-to- isdn</pre> <p>[ProgressIndicator2ISDN]</p>	<p>Defines the Progress Indicator (PI) in ISDN messages that are sent to the PSTN for the specific trunk.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> = (Default) The PI in ISDN messages is set according to the [PlayRBTone2Tel] parameter.</li> <li>■ [0] <b>No PI</b> = PI is not sent to ISDN.</li> <li>■ [1] <b>PI = 1</b> = The PI value is sent to PSTN in Q.931/Proceeding and Alerting messages. Typically, the PSTN/PBX cuts through the audio channel without playing local ringback tone, enabling the originating party to hear remote Call Progress Tones or network announcements.</li> <li>■ [2] <b>PI = 2</b> = The PI value is sent to PSTN in Q.931/Proceeding and Alerting messages. The destination address is non-ISDN.</li> <li>■ [8] <b>PI = 8</b> = The PI value is sent to PSTN in Q.931/Proceeding and Alerting messages. Typically, the PSTN/PBX cuts through the audio channel without playing local ringback tone, enabling the originating party to hear remote Call Progress Tones or network announcements.</li> </ul>
<p>'Select Receiving of Overlap Receiving'</p> <pre>configure voip &gt; interface e1- t1 bri &gt; ovrlp- rcvng-type</pre> <p>[ISDNRxOverlap]</p>	<p>Defines the receiving (Rx) type of ISDN overlap dialing for Tel-to-IP calls for the specific trunk.</p> <ul style="list-style-type: none"> <li>■ [0] <b>None</b> = (Default) Disabled.</li> <li>■ [1] <b>Local receiving</b> = ISDN Overlap Dialing - the complete number is sent in the INVITE Request-URI user part. The device receives ISDN called number that is sent in the 'Overlap' mode. The ISDN Setup message is sent to IP only after the number (including the Sending Complete IE) is fully received (via Setup and/or subsequent Info Q.931 messages). In other words, the device waits until it has received all the ISDN signaling messages containing parts of the called number, and only then it</li> </ul>

Parameter	Description
	<p>sends a SIP INVITE with the entire called number in the Request-URI.</p> <ul style="list-style-type: none"> <li>■ [2] <b>Through SIP</b> = Interworking of ISDN Overlap Dialing to SIP according to RFC 3578. The device sends the first received digits from the ISDN Setup message to the IP side in the initial INVITE message. For each subsequently received ISDN Info Q.931 message, the device sends the collected digits to the IP side in re-INVITE messages.</li> <li>■ [3] <b>Through SIP INFO</b> = Interworking of ISDN Overlap Dialing to SIP according to RFC 3578. The device sends the first received digits from the ISDN Setup message to the IP side in the initial INVITE message. For each subsequently received ISDN Info Q.931 message, the device sends the collected digits to the IP side in INFO messages.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ When configured to <b>Through SIP</b> or <b>Through SIP INFO</b>, you can configure the minimum number of overlap digits to collect before sending the first SIP message for routing the call, using the [MinOverlapDigitsForRouting] parameter.</li> <li>■ When configured to <b>Through SIP</b> or <b>Through SIP INFO</b>, even if SIP 4xx responses are received during this ISDN overlap receiving, the device doesn't release the call.</li> <li>■ The [MaxDigits] parameter can be used to limit the length of the collected number for ISDN overlap dialing (if Sending Complete is not received).</li> <li>■ If a digit map pattern is defined (using the [DigitMapping] or [DialPlanIndex] parameters), the device collects digits until a match is found (e.g., for closed numbering schemes) or until a timer expires (e.g., for open numbering schemes). If a match is found (or the timer expires), the digit collection process is terminated even if Sending Complete is not received.</li> <li>■ To enable ISDN overlap dialing for IP-to-Tel calls, use the [ISDNTxOverlap] parameter.</li> <li>■ For more information on ISDN overlap dialing, see <a href="#">ISDN Overlap Dialing</a> on page 899.</li> </ul>

Parameter	Description
<p>'B-Channel Negotiation'</p> <pre>configure voip &gt; interface e1- t1 bri &gt; b- channel-nego-for- trunk</pre> <p>[BChannelNegotiationForTrunk]</p>	<p>Defines the ISDN B-channel negotiation mode for the specific trunk.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> = (Default) The negotiation mode is according to the global parameter [BChannelNegotiation].</li> <li>■ [0] <b>Preferred</b></li> <li>■ [1] <b>Exclusive</b></li> <li>■ [2] <b>Any</b></li> </ul> <p><b>Note:</b> The <b>Any</b> option is applicable only if you configure the 'ISDN Termination Side' parameter to <b>User side</b>.</p>
<p>'Out-Of-Service Behavior'</p> <pre>configure voip &gt; interface bri e1- t1 &gt; dig-oos- behavior</pre> <p>[DigitalOOSBehaviorForTrunk_x]</p>	<p>Defines the method for setting the trunk to out-of-service state for the specific trunk. The parameter is applicable to the Busy Out feature (see the [EnableBusyOut] parameter) and the Lock/Unlock per Trunk Group feature performed in the Trunk Group Settings table of the Web interface.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> = (Default) The out-of-service method is according to the global parameter [DigitalOOSBehavior].</li> <li>■ [0] <b>Default</b> = <ul style="list-style-type: none"> <li>✓ ISDN: Sends ISDN Service messages to indicate out-of-service or in-service state for ISDN variants that support Service messages. For ISDN variants that do not support Service messages, the device sends an Alarm Indication Signal (AIS) alarm.</li> <li>✓ CAS: Sends an Alarm Indication Signal (AIS) alarm.</li> </ul> </li> <li>■ [1] <b>Service</b> = (Applicable only to T1 ISDN variants that support this method)Sends ISDN Service messages indicating out-of-service or in-service state. <ul style="list-style-type: none"> <li>✓ Graceful out-of-service disabled: The device rejects new incoming calls and immediately takes all channels (idle and busy) out-of-service, by sending Service messages on the B-channels. The device disconnects busy channels before it sends out-of-service Service messages on them.</li> <li>✓ Graceful out-of-service enabled: The device rejects new incoming calls. If at least one busy channel</li> </ul> </li> </ul>

Parameter	Description
	<p>exists during the graceful period, the device immediately takes all idle channels out-of-service and sends out-of-service Service messages to the other B-channels as soon as they become idle. When graceful period ends, the device disconnects all non-idle channels and then sends out-of-service Service messages to them.</p> <p>When connectivity is restored for the Busy Out feature or the Trunk Group is unlocked, the device brings all the trunks back into service by sending in-service Service messages to all their B-channels.</p> <p>■ [2] <b>D-Channel</b> = (Applicable only to ISDN and fully configured trunks) Takes the D-channel down or brings it up.</p> <ul style="list-style-type: none"> <li>✓ Graceful out-of-service disabled: The device rejects new incoming calls and immediately takes the D-channel down.</li> <li>✓ Graceful out-of-service enabled: The device rejects new incoming calls. Only when all channels are idle (when graceful period ends or when all channels become idle before graceful period ends, whichever occurs first), does the device take the D-channel down.</li> </ul> <p>When connectivity is restored for the Busy Out feature or the Trunk Group is unlocked, the device brings the D-channels up again.</p> <p><b>Note:</b> For partially configured trunks (only some channels configured), this option only rejects new calls for the trunk; the D-channel remains up.</p> <p>■ [3] <b>Alarm</b> = Sends or clears a PSTN Alarm Indication Signal (AIS) alarm.</p> <ul style="list-style-type: none"> <li>✓ Graceful out-of-service disabled: The device rejects new incoming calls and immediately sends an AIS alarm.</li> <li>✓ Graceful out-of-service enabled: The device rejects new incoming calls and only when all channels are idle (when graceful period ends or when all channels become idle before graceful period ends, whichever occurs first), does the device send an alarm on the</li> </ul>



Parameter	Description
	<p>trunk.</p> <p>When connectivity is restored for the Busy Out feature or the Trunk Group is unlocked, the device clears the alarm.</p> <p><b>Note:</b> For partially configured trunks (only some channels configured), this option only rejects new calls for the trunk; no alarm is sent.</p> <p>■ [4] <b>Block</b> = (Applicable only to CAS) Blocks the B-channels.</p> <ul style="list-style-type: none"> <li>✓ Graceful out-of-service disabled: The device rejects new incoming calls and immediately blocks all channels (idle and busy). The device disconnects busy channels before blocking them.</li> <li>✓ Graceful out-of-service enabled: The device rejects new incoming calls. If at least one busy channel exists during the graceful period, the device immediately blocks all idle channels, and blocks the other B-channels as soon as they become idle. When graceful period ends, the device disconnects all non-idle channels and then blocks them.</li> </ul> <p>When connectivity is restored for the Busy Out feature or the Trunk Group is unlocked, the device unblocks all the B-channels.</p> <p>■ [5] <b>Service and D-Channel</b> = (Applicable only to T1 ISDN variants that support this method) Sends ISDN Service messages to indicate out-of-service or in-service state and takes the D-channel down or brings it up.</p> <ul style="list-style-type: none"> <li>✓ Graceful out-of-service disabled: <ul style="list-style-type: none"> <li>● Fully configured trunk (all channels): The device rejects new incoming calls, disconnects busy channels, and takes the D-channel down.</li> <li>● Partially configured trunk (only some channels configured): The device rejects new incoming calls, disconnects busy channels, and sends out-of-service Service messages to all the configured channels (D-channel remains up).</li> </ul> </li> <li>✓ Graceful out-of-service enabled: The device rejects new incoming calls and does the following:</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li> <p>Fully configured trunk (all channels):</p> <ul style="list-style-type: none"> <li>&gt; If all channels are idle when the graceful period begins, the device immediately takes the channels out-of-service without sending out-of-service Service messages and instead, only takes the D-channel down.</li> <li>&gt; If at least one channel is busy during the graceful period, the device immediately takes all idle channels out-of-service and sends out-of-service Service messages to these B-channels. Thus, the PSTN/PBX side can detect that these calls are in out-of-service state and doesn't send new calls to these out-of-service channels, eliminating the scenario of loss of calls due to rejection.</li> <li>&gt; If a channel is released (call ends) during the graceful period and there are still other busy channels, the device sends an out-of-service Service message to the idle channel.</li> <li>&gt; When the last channel is released in the trunk (or Trunk Group), the device takes all the channels out-of-service (locks the Trunk Group) without sending an out-of-service Service message; instead, it only takes the D-channel down. The device disconnects busy channels before it takes the D-channel down. When connectivity is restored for the Busy Out feature or the Trunk Group is unlocked, the device brings the D-channel up again without sending any Service messages to the B-channels.</li> </ul> </li> <li> <p>Partially configured trunk (only some channels configured): Same as above, but the D-channel remains up and out-of-service Service message is sent to remaining busy channels.</p> </li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li> <p>Before configuring the parameter, stop the trunk (<b>Stop Trunk</b> button in the Trunk Settings page), configure the parameter, and then restart the trunk (<b>Apply Trunk Settings</b> button in the Trunk Settings page) for the settings to take effect.</p> </li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ To configure the out-of-service method for all trunks, see the global parameter [DigitalOOSBehavior].</li> <li>■ To lock and unlock Trunk Groups in the Trunk Group Settings table, see <a href="#">Configuring Trunk Group Settings</a> on page 906.</li> <li>■ For a description of the Busy Out feature and for enabling the feature, see the [EnableBusyOut] parameter.</li> <li>■ To configure the graceful out-of-service period, see the [GracefulBusyOutTimeout] parameter.</li> <li>■ If the ISDN variant doesn't support the configured out-of-service option, the device sets the parameter to <b>Default</b>.</li> <li>■ When configuring the parameter through ini file, replace the "x" in the parameter's name with the required trunk number (where 0 is Trunk 1).</li> </ul>
'Digital Out-Of-Service Behavior' <pre>configure voip &gt; gateway digital settings &gt; dig- oos-behavior</pre> [DigitalOOSBehavior]	Defines the method for setting all digital trunks to out-of-service state. To configure the out-of-service method per trunk, see the [DigitalOOSBehaviorForTrunk_x] parameter. <ul style="list-style-type: none"> <li>■ [0] <b>Default</b> = (Default) For a detailed description, see option [0] of the [DigitalOOSBehaviorForTrunk_x] parameter (per trunk setting).</li> <li>■ [1] <b>Service</b> = Sends an ISDN Service message indicating out-of-service state (or in-service). For a detailed description, see option [1] of the [DigitalOOSBehaviorForTrunk_x] parameter (per trunk setting).</li> <li>■ [2] <b>D-Channel</b> = Takes the D-Channel down or brings it up. For a detailed description, see option [2] of the [DigitalOOSBehaviorForTrunk_x] parameter (per trunk setting).</li> <li>■ [3] <b>Alarm</b> = Sends or clears a PSTN Alarm Indication Signal (AIS) alarm. For a detailed description, see option [3] of the [DigitalOOSBehaviorForTrunk_x] parameter (per trunk setting).</li> <li>■ [4] <b>Block</b> = Blocks the trunk. For a detailed description, see option [4] of the [DigitalOOSBehaviorForTrunk_x] parameter (per trunk setting).</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [5] <b>Service and D-Channel</b> = Sends ISDN Service messages to indicate out-of-service or in-service state and takes the D-channel down or brings it up. For a detailed description, see option [5] of the [DigitalOOSBehaviorForTrunk_x] parameter (per trunk setting).</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ When using the parameter to configure out-of-service behavior for all trunks, you must restart the device for the settings to take effect.</li> <li>■ If the ISDN variant doesn't support the configured out-of-service option of the parameter, the device sets the parameter to Default [0].</li> </ul>
<p>'Remove Calling Name'</p> <pre>configure voip &gt; interface bri e1- t1 &gt; rmv-calling- name</pre> <p>[RemoveCallingNameForTrunk_x]</p>	<p>Enables the device to remove the Calling Name for SIP-to-ISDN calls for the specific trunk.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Use Global Parameter</b> = (Default) The settings are according to the global parameter [RemoveCallingName].</li> <li>■ [0] <b>Disable</b> = Does not remove Calling Name.</li> <li>■ [1] <b>Enable</b> = Remove Calling Name.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ When configuring the parameter through ini file, replace the "x" in the parameter's name with the required trunk number (where 0 is Trunk 1).</li> <li>■ The global parameter is [RemoveCallingName].</li> </ul>
<p>'Play Ringback Tone to Trunk'</p> <pre>configure voip &gt; interface e1- t1 bri &gt; play-rbt- to-trk</pre> <p>[PlayRBTone2Trunk_x]</p>	<p>Defines the playing method of the ringback tone to the trunk side for the specific trunk.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not configured</b> = (Default) The ringback tone is played according to the settings of the global ['<a href="#">Play Ringback Tone to Tel</a>'] on page 1855] parameter, which defines the ringback tone play method for all trunks that are not configured by the [PlayRBTone2Trunk] parameter.</li> <li>■ [0] <b>Don't Play</b> = (See the description of <b>Don't Play</b> for the global [PlayRBTone2Tel] parameter. )</li> <li>■ [1] <b>Play on Local</b> = (See the description of <b>Play on Local</b></li> </ul>

Parameter	Description
	<p>for the global [PlayRBTone2Tel] parameter.)</p> <ul style="list-style-type: none"> <li>■ [2] <b>Prefer IP</b> = (See the description of <b>Prefer IP</b> for the global [PlayRBTone2Tel] parameter.)</li> <li>■ [3] <b>Play Local Until Remote Media Arrive</b> = (See the description of <b>Play Local Until Remote Media Arrive</b> for the global [PlayRBTone2Tel] parameter.)</li> </ul>
<p>'Call Rerouting Mode'</p> <pre>configure voip &gt; interface e1- t1 bri &gt; call-re- rte-mode</pre> <p>[CallReroutingMode]</p>	<p>Defines if ISDN call rerouting (call forward) is performed by the PSTN instead of by the SIP side. This call forwarding is based on Call Deflection for Euro ISDN (ETS-300-207-1) and QSIG (ETSI TS 102 393).</p> <ul style="list-style-type: none"> <li>■ [0] <b>None</b> (default)</li> <li>■ [1] <b>ISDN Rerouting Enabled</b> = Enables ISDN call rerouting. When the device sends the INVITE message to the remote SIP entity and receives a SIP 302 response with a Contact header containing a URI host name that is the same as the device's IP address, the device sends a Facility message with a Call Rerouting invoke method to the ISDN and waits for the PSTN side to disconnect the call.</li> </ul> <p><b>Note:</b> When the parameter is enabled, ensure that you configure in the IP-to-Tel Routing table (see <a href="#">Configuring IP-to-Tel Routing Rules</a> on page 928) a rule to route the redirected call (using the user part from the 302 Contact header) to the same Trunk Group from where the incoming Tel-to-IP call was received.</p>
<p>'ISDN Duplicate Q931 BuffMode'</p> <p>[ISDNDuplicateQ931BuffMode]</p>	<p>Defines the activation/deactivation of delivering raw Q.931 messages.</p> <ul style="list-style-type: none"> <li>■ [0] <b>0</b> = (Default) ISDN messages aren't duplicated.</li> <li>■ [128] <b>128</b> = All ISDN messages are duplicated.</li> </ul>
<p>'Description'</p> <pre>config-voip &gt; interface bri e1- t1 &gt; port-info</pre> <p>[DigitalPortInfo_x]</p>	<p>Defines a descriptive name for the trunk port. This can be used to help you easily identify the trunk.</p> <p>The valid value is a string of up to 40 alphanumeric characters (0-9, a-z, and A-Z).</p> <p>By default, the value is undefined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Spaces between characters are not supported.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>You can also configure the port's description on the Monitor page, as described in <a href="#">Configuring a Description for Telephony Ports</a> on page 1211.</li> </ul>

## TDM and Timing

This section describes the configuration of the TDM and clock timing parameters.

### TDM Bus Clock Settings

In a traditional TDM service network such as PSTN, both ends of the TDM connection must be synchronized. If synchronization is not achieved, voice frames are either dropped (to prevent a buffer overflow condition) or inserted (to prevent an underflow condition). In both cases, connection quality and reliability is affected.

- PSTN line clock (see [Recovering Clock from PSTN Line Interface](#) below)
- Internal clock (see [Configuring Internal Clock as Clock Source](#) on the next page)






When the device is used in a 'non-span' configuration, the internal device clock must be used (as explained above).

### Recovering Clock from PSTN Line Interface

This section provides a brief description for configuring synchronization based on recovering clock from the PSTN line interface. For a full description of the clock parameters, see [PSTN Parameters](#) on page 1815.

#### ➤ To configure synchronization based on clock from PSTN line:

- Open the TDM Bus Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **TDM Bus Settings**).

TDM Bus Clock Source	Internal 
TDM Bus PSTN Auto FallBack Clock	<input type="checkbox"/> 
TDM Bus PSTN Auto Clock Reverting	<input type="checkbox"/> 
TDM Bus Local Reference	1

- From the 'TDM Bus Clock Source' drop-down list (TDMBusClockSource), select **Network** to recover the clock from the line interface.

- b. In the 'TDM Bus Local Reference' field (TDMBusPSTNLocalReference), enter the trunk from which the clock is derived.



- The E1/T1 trunk should recover the clock from the remote side (see below description of the 'Clock Master' parameter).

- c. Enable automatic switchover to the next available "slave" trunk if the device detects that the local-reference trunk is no longer capable of supplying the clock to the system:

- i. Select the 'TDM Bus PSTN Auto FallBack Clock' check box (TDMBusPSTNAutoClockEnable):

TDM Bus PSTN Auto FallBack Clock • ☒ ⚡

- ii. Select the 'TDM Bus PSTN Auto Clock Reverting' check box (TDMBusPSTNAutoClockRevertingEnable) to enable the device to switch back to a previous trunk that returns to service if it has higher switchover priority:

TDM Bus PSTN Auto Clock Reverting • ☒ ⚡

- iii. In the Trunk Settings page (see [Configuring Trunk Settings](#) on page 850), configure the priority level of the trunk for taking over as a local-reference trunk, using the 'Auto Clock Trunk Priority' parameter (AutoClockTrunkPriority). A value of 100 means that it never uses the trunk as local reference.

2. (E1/T1 Trunks Only) Configure the PSTN trunk to recover/derive clock from/to the remote side of the PSTN trunk (i.e. clock slave or clock master): In the Trunk Settings page, configure the 'Clock Master' parameter (ClockMaster) to one of the following:
  - Recovered - to recover clock (i.e. slave)
  - Generated - to transmit clock (i.e. master)


### Configuring Internal Clock as Clock Source

You can configure the device to use its internal clock source. The internal clock source is a stratum 4E-compliant clock source. When the device has no line interfaces, the device should be configured in this mode.

#### ➤ To configure internal clock as clock source:


1. Configure the clock source as the device's internal oscillator:
  - a. Open the TDM Bus Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **TDM Bus Settings**).
  - b. From the 'TDM Bus Clock Source' drop-down list [TDMBusClockSource], select **Internal**:

TDM Bus Clock Source

Internal 

2. (E1/T1 Trunks Only) Configure the line to drive the clock on all trunks:
  - a. Open the Trunk Settings page (see [Configuring Trunk Settings](#) on page 850).
  - b. From the 'Clock Master' drop-down list [ClockMaster], select **Generated** (for all trunks):

Clock Master

Generated 

3. Restart the device with a save-to-flash for your settings to take effect.

## Configuring CAS State Machines

The CAS State Machine table lets you modify various timers and other basic parameters to define the initialization of the CAS state machine without changing the state machine itself (no compilation is required). The change doesn't affect the state machine itself, but rather the configuration.

The CAS table used can be chosen in two ways (using the parameter CasChannelIndex):

- Single CAS table per trunk
- Different CAS table per group of B-channels in a trunk



- CAS is applicable only to ISDN PRI interfaces.

### ➤ To modify the CAS state machine parameters:

1. Open the CAS State Machine page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Trunks & Groups** > **CAS State Machines**).

CAS State Machine

CAS Table Name	Generate Digit On Time	Generate Inter Digit Time	DTMF Max Detection Time	DTMF Min Detection Time	Max Incoming Address Digits	Max Incoming ANI Digits	Collect ANI	Digit Signaling System	Related Trunks
Earth_Calling.dat	-1	-1	-1	-1	-1	-1	Default ▼	Default ▼	

2. Ensure that the trunk is inactive. The trunk number displayed in the 'Related Trunks' field must be green. If it is red, indicating that the trunk is active, click the trunk number to open the Trunk Settings page (see [Configuring Trunk Settings](#) on page 850), select the required Trunk number icon, and then click **Stop Trunk**.
3. In the CAS State Machine table, modify the required parameters according to the table below.
4. Once you have completed the configuration, activate the trunk if required in the Trunk Settings page, by clicking the trunk number in the 'Related Trunks' field, and in the Trunk Settings page, select the required Trunk number icon, and then click **Apply Trunk Settings**.



5. Click **Apply**, and then restart the device.



- The CAS state machine can only be configured using the Web-based management tool.
- Don't modify the default values unless you fully understand the implications of the changes and know the default values. Every change affects the configuration of the state machine parameters and the call process related to the trunk you are using with this state machine.
- You can modify CAS state machine parameters only if the following conditions are met:
  - ✓ Trunks are inactive (stopped), i.e., the 'Related Trunks' field displays the trunk number in green.
  - ✓ State machine is not in use or is in restart, or when it is not related to any trunk. If it is related to a trunk, you must delete the trunk or de-activate (*Stop*) the trunk.
- Field values displaying "-1" indicate CAS default values. In other words, CAS state machine values are used.
- The modification of the CAS state machine occurs at the CAS application initialization only for non-default values (-1).
- For more information on the CAS Protocol table, refer to the document *CAS Protocol Table Configuration Note*.

**Table 23-2: CAS State Machine Parameters Description**

Parameter	Description
'Generate Digit On Time' [CasStateMachineGenerateDigitOnTime]	Generates digit on-time (in msec). The value must be a positive value. The default is -1 (use value from CAS state machine).
'Generate Inter Digit Time' [CasStateMachineGenerateInterDigitTime]	Generates digit off-time (in msec). The value must be a positive value. The default is -1 (use value from CAS state machine).
'DTMF Max Detection Time' [CasStateMachineDTMFMaxOnDetectionTime]	Detects digit maximum on time (according to DSP detection information event) in msec units. The value must be a positive value. The default is -1 (use value from CAS state machine).
'DTMF Min Detection Time' [CasStateMachineDTMFMinOnDetectionTime]	Detects digit minimum on time (according to DSP detection information event) in msec units. The digit time length must be longer than this value to

Parameter	Description
	<p>receive a detection. Any number may be used, but the value must be less than CasStateMachineDTMFMaxOnDetection Time.</p> <p>The value must be a positive value. The default is -1 (use value from CAS state machine).</p>
'MAX Incoming Address Digits' [CasStateMachineMaxNumOfIncomingAddress Digits]	<p>Defines the limitation for the maximum address digits that need to be collected. After reaching this number of digits, the collection of address digits is stopped. The value must be an integer. The default is -1 (use value from CAS state machine).</p>
'MAX Incoming ANI Digits' [CasStateMachineMaxNumOfIncomingANIDigits]	<p>Defines the limitation for the maximum ANI digits that need to be collected. After reaching this number of digits, the collection of ANI digits is stopped. The value must be an integer. The default is -1 (use value from CAS state machine).</p>
'Collect ANI' [CasStateMachineCollectANI]	<p>In some cases, when the state machine handles the ANI collection (not related to MFCR2), you can control the state machine to collect ANI or discard ANI.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = Don't collect ANI.</li> <li>■ [1] <b>Yes</b> = Collect ANI.</li> <li>■ [-1] <b>Default</b> = Default value - use value from CAS state machine.</li> </ul>
'Digit Signaling System' [CasStateMachineDigitSignalingSystem]	<p>Defines which Signaling System to use in both directions (detection\generation).</p> <ul style="list-style-type: none"> <li>■ [0] <b>DTMF</b> = Uses DTMF signaling.</li> <li>■ [1] <b>MF</b> = (Default) Uses MF signaling.</li> <li>■ [-1] <b>Default</b> = Default value - use value from CAS state machine.</li> </ul>

## Configuring Digital Gateway Parameters

The Digital Gateway Parameters page allows you to configure miscellaneous digital parameters. For a description of these parameters, see [Configuration Parameters Reference](#) on page 1563.

➤ **To configure the digital gateway parameters:**

1. Open the Digital Gateway Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Digital Gateway** > **Digital Gateway Settings**).

GENERAL		CALLER & CALLEE	
B-channel Negotiation	Exclusive	Remove CLI when Restricted	No
MFC R2 Category	1	Remove Calling Name	Disable
Add IE in SETUP		Use EndPoint Number As Calling Number Tel2IP	Disable
ISDN Transfer on Connect	Alert	Use EndPoint Number As Calling Number IP2Tel	Disable
Trunk Groups to Send IE		ISDN SubAddress Format	ASCII
Trunk Status Reporting Mode to Proxy	Disable	Enable Calling Party Category	Disable
TDM Over IP Min Calls	0	Calling Party Category Mode	None
ISDN Facility Trace	Disable		
REDIRECT NUMBER		SCREENING INDICATOR	
Swap Redirect and Called Numbers	No	Send Screening Indicator to IP	Not Configured
		Send Screening Indicator to ISDN	Not Configured

2. Configure the parameters as required.
3. Click **Apply**.

## Tunneling Applications

This section discusses the device's support for VoIP tunneling applications.

### TDM Tunneling

The device's TDM Tunneling feature allows you to tunnel groups of digital trunk spans or timeslots (B-channels) over the IP network. TDM Tunneling uses the device's internal routing (without Proxy control) capabilities to receive voice and data streams from TDM spans or individual timeslots, convert them into packets, and then transmit them over the IP network (using point-to-point or point-to-multipoint device distributions). A device opposite it (or several devices when point-to-multipoint distribution is used) converts the IP packets back into TDM traffic. Each timeslot can be targeted to any other timeslot within a trunk in the opposite device.

When TDM Tunneling is enabled ('TDM Tunneling' parameter configured to **Enable**) on the originating device, the originating device automatically initiates SIP calls from all enabled B-channels belonging to the spans that are configured with the protocol type **Transparent** (for

ISDN trunks) or **Raw CAS** (for CAS trunks). The called number of each call is the internal phone number of the B-channel from where the call originates.

The IP-to-Tel Routing table is used to define the destination IP address of the terminating device. The terminating device automatically answers these calls if the 'Protocol Type' parameter is configured to **E1 TRANSPARENT 31** or **T1 RAW CAS** (for T1) or **E1 RAW CAS** (for E1), and the [ChannelSelectMode] parameter to 0 (**By Dest Phone Number**).



You can configure both devices to also operate in symmetric mode. To do so, configure the 'TDM Tunneling' parameter configured to **Enable** [EnableTDMOverIP] and configure the Tel-to-IP Routing table in both devices. After restarting, each device initiates calls to the other device. The first call for each B-channel is answered by the other device.

The device continuously monitors the established connections. If for some reason, one or more calls are released, the device automatically re-establishes these 'broken' connections. When a failure in a physical trunk or in the IP network occurs, the device re-establishes the tunneling connections when the network is restored.



It's recommended to use the keep-alive mechanism for each connection, by activating the 'session expires' timeout and using SIP re-INVITE messages.

The device supports the configuration (TDMoIPInitiateInviteTime and TDMoIPInviteRetryTime parameters) of the following timers for the TDM-over-IP tunneling application:

- Time between successive INVITEs sent from the same trunk.
- Time between call release and the new INVITE that is sent on the same channel. The call can be released if the device receives a 4xx or 5xx response.

By using profiles (see [Configuring Tel Profile](#) on page 738), you can configure the TDM Tunneling feature to choose different settings based on a timeslot or groups of timeslots. For example, you can use low-bit-rate vocoders to transport voice and 'Transparent' coder to transport data (e.g., for D-channel). You can also use profiles to assign ToS (for DiffServ) per source - a timeslot carrying data or signaling is assigned a higher priority value than a timeslot carrying voice.

For tunneling CAS trunks, configure the 'Protocol Type' parameter to **T1 RAW CAS** (for T1) or **E1 RAW CAS** (for E1) and enable RFC 2833 CAS relay mode ('CAS Transport Type' parameter to **CAS RFC2833 Relay**).



For TDM over IP, configure the [CallerIDTransportType] parameter to 0 (disabled), which means transparent.

Below is an example of *ini* files for two devices implementing TDM Tunneling for four E1 spans. In this example, both devices are dedicated to TDM tunneling.

#### ■ Terminating Side:

```
EnableTDMOverIP = 1
```

```
;E1_TRANSPARENT_31
```

```
ProtocolType_0 = 5
```

```
ProtocolType_1 = 5
```

```
ProtocolType_2 = 5
```

```
ProtocolType_3 = 5
```

```
[PREFIX]
```

```
FORMAT Index = RouteName, DestinationPrefix, DestAddress, SourcePrefix,  
ProfileName, MeteringCode, DestPort, DestIPGroupName, TransportType,  
SrcTrunkGroupID, DestSIPInterfaceName, CostGroup, ForkingGroup,  
CallSetupRulesSetId, ConnectivityStatus;
```

```
Prefix 1 = TunnelA, *, 10.8.24.12;
```

```
[PREFIX]
```

```
;IP address of the device in the opposite location
```

```
;Channel selection by phone number.
```

```
ChannelSelectMode = 0
```

```
;Profiles can be used to define different coders per B-channels such as  
Transparent
```

```
;coder for B-channels (timeslot 16) that carries PRI signaling
```

```
[TrunkGroup]
```

```
FORMAT Index = TrunkGroupNum, FirstTrunkId, LastTrunkId, FirstBChannel,  
LastBChannel, FirstPhoneNumber, ProfileName, Module;
```

```
TrunkGroup 1 = 0,0,0,1,31,1000,1;
```

```
TrunkGroup 1 = 0,1,1,1,31,2000,1;
```

```
TrunkGroup 1 = 0,2,2,1,31,3000,1;
```

```
TrunkGroup 1 = 0,3,3,1,31,4000,1;
```

```
TrunkGroup 1 = 0,0,0,16,16,7000,2;
```

```
TrunkGroup 1 = 0,1,1,16,16,7001,2;
```

```
TrunkGroup 1 = 0,2,2,16,16,7002,2;
```

```
TrunkGroup 1 = 0,3,3,16,16,7003,2;
```

```
[/TrunkGroup]
```

```
[ AudioCodersGroups ]
```

```
FORMAT Index = Name;
```

```
AudioCodersGroups 0 = "AudioCodersGroups_0";
```

```
AudioCodersGroups 1 = "AudioCodersGroups_1";
[ \AudioCodersGroups ]
```

```
[ AudioCoders ]
FORMAT Index = AudioCodersGroupId, AudioCodersIndex, Name, pTime,
rate, PayloadType, Sce, CoderSpecific;
AudioCoders 0 = "AudioCodersGroups_0", 0, 0, 3, 7, -1, 0, "";
AudioCoders 1 = "AudioCodersGroups_0", 0, 7, 2, 90, 56, 0, "";
[ \AudioCoders ]
```

```
[ TelProfile ]
FORMAT Index = ProfileName, TelPreference, CodersGroupName,
IsFaxUsed, JitterBufMinDelay, JitterBufOptFactor, IPDiffServ, SigIPDiffServ,
DtmfVolume, InputGain, VoiceVolume, EnableReversePolarity,
EnableCurrentDisconnect, EnableDigitDelivery, EnableEC, MWIAnalog,
MWIDisplay, FlashHookPeriod, EnableEarlyMedia, ProgressIndicator2IP,
TimeForReorderTone, EnableDIDWink, IsTwoStageDial,
DisconnectOnBusyTone, EnableVoiceMailDelay, DialPlanIndex,
Enable911PSAP, SwapTelToIpPhoneNumbers, EnableAGC, ECNIPMode,
DigitalCutThrough, EnableFXODoubleAnswer, CallPriorityMode,
FXORingTimeout, JitterBufMaxDelay, IP2TelCutThroughCallBehavior,
PlayBusyTone2Isdn, MWINotificationTimeout;
TelProfile 1 = "voice", 1, "AudioCodersGroups_0", 0, 10, 10, 46, 24, -11, 0, 0,
0, 0, 0, 1, 0, 0, 700, 0, -1, 255, 0, 1, 1, 1, -1, 0, 0, 0, 0, 0, 0, 0, 0, 300, 0, 0, 0;
TelProfile 2 = "data", 1, "AudioCodersGroups_1", 0, 10, 10, 46, 24, -11, 0, 0,
0, 0, 0, 1, 0, 0, 700, 0, -1, 255, 0, 1, 1, 1, -1, 0, 0, 0, 0, 0, 0, 0, 0, 300, 0, 0, 0;
[ \TelProfile ]
```

#### ■ Originating Side:

```
;E1_TRANSPARENT_31
ProtocolType_0 = 5
ProtocolType_1 = 5
ProtocolType_2 = 5
ProtocolType_3 = 5
```

```
;Channel selection by Phone number.
ChannelSelectMode = 0
```

```
[TrunkGroup]
FORMAT Index = TrunkGroupNum, FirstTrunkId, LastTrunkId, FirstBChannel,
LastBChannel, FirstPhoneNumber, ProfileName, Module;
TrunkGroup 0 = 0,0,0,1,31,1000,1;
```

```
TrunkGroup 0 = 0,1,1,1,31,2000,1;
TrunkGroup 0 = 0,2,2,1,31,3000,1;
TrunkGroup 0 = 0,3,1,31,4000,1;
TrunkGroup 0 = 0,0,0,16,16,7000,2;
TrunkGroup 0 = 0,1,1,16,16,7001,2;
TrunkGroup 0 = 0,2,2,16,16,7002,2;
TrunkGroup 0 = 0,3,3,16,16,7003,2;
[TrunkGroup]
```

```
[ AudioCodersGroups ]
FORMAT Index = Name;
AudioCodersGroups 0 = "AudioCodersGroups_0";
[ \AudioCodersGroups ]
```

```
[ AudioCoders ]
FORMAT Index = AudioCodersGroupId, AudioCodersIndex, Name, pTime,
rate, PayloadType, Sce, CoderSpecific;
AudioCoders 0 = "AudioCodersGroups_0", 0, 0, 3, 7, -1, 0, "";
AudioCoders 1 = "AudioCodersGroups_0", 1, 7, 2, 90, 56, 0, "";
[ \AudioCoders ]
```

```
[ TelProfile ]
FORMAT Index = ProfileName, TelPreference, CodersGroupName,
IsFaxUsed, JitterBufMinDelay, JitterBufOptFactor, IPDiffServ, SigIPDiffServ,
DtmfVolume, InputGain, VoiceVolume, EnableReversePolarity,
EnableCurrentDisconnect, EnableDigitDelivery, EnableEC, MWIAnalog,
MWIDisplay, FlashHookPeriod, EnableEarlyMedia, ProgressIndicator2IP,
TimeForReorderTone, EnableDIDWink, IsTwoStageDial,
DisconnectOnBusyTone, EnableVoiceMailDelay, DialPlanIndex,
Enable911PSAP, SwapTelTolpPhoneNumbers, EnableAGC, ECNlpMode,
DigitalCutThrough, EnableFXODoubleAnswer, CallPriorityMode,
FXORingTimeout, JitterBufMaxDelay, IP2TelCutThroughCallBehavior,
PlayBusyTone2Isdn, MWINotificationTimeout;
TelProfile 1 = "voice", 1, "AudioCodersGroups_0", 0, 10, 10, 46, 24, -11, 0, 0,
0, 0, 0, 1, 0, 0, 700, 0, -1, 255, 0, 1, 1, 1, -1, 0, 0, 0, 0, 0, 0, 0, 300, 0, 0, 0;
TelProfile 2 = "data", 1, "AudioCodersGroups_1", 0, 10, 10, 46, 24, -11, 0, 0,
0, 0, 0, 1, 0, 0, 700, 0, -1, 255, 0, 1, 1, 1, -1, 0, 0, 0, 0, 0, 0, 0, 300, 0, 0, 0;
[ \TelProfile ]
```

## DSP Pattern Detector

For TDM tunneling applications, you can use the DSP pattern detector feature to initiate the echo canceller at call start. The device can be configured to support detection of a specific one-

byte idle data pattern transmitted over digital E1/T1 timeslots. The device can be configured to detect up to four different one-byte data patterns. When the defined idle data pattern is detected, the channel resets its echo canceller.

➤ **To configure DSP pattern detector:**

1. On the DSP Settings page (**Setup** menu > **Signaling & Media** tab > **Media** folder > **DSP Settings**), do the following:
  - a. Select the 'IPMedia Detectors' check box [EnableDSIPMDetectors]:

IPMedia Detectors ☒

- b. Select the 'Enable Pattern Detector' check box [EnablePatternDetector]:

Enable Pattern Detector ☒

2. Configure the number (e.g., 5) of consecutive patterns to trigger the pattern detection event, using the ini file parameter [PDThreshold].
3. Configure the patterns that can be detected by the Pattern Detector, using the ini file parameter [PDPattern]. For example:

PDPattern = 84, 85, 212, 213 ; for idle patterns 54, 55, D4 and D5

## Configuring Private Wire Interworking

You can configure the device to interwork in a private wire system, where one side is IP (SIP) based and the other side is legacy, digital PSTN (E1/T1 CAS) based.



The feature is applicable only to IP-to-Tel calls and E1/T1 CAS.


Private wire is a generic term used to describe static point-to-point voice connections between two locations. Private Wires are typically used by a number of communities such as military, railways, emergency services, and financial services. Historically, private wire services were achieved by running direct private connections (telephone cables) between offices in the same building. In private wire services, dialing is unnecessary and there is a direct, "always on" and immediate connection.

Trading turret systems are also part of private wire services. A trading turret or dealer board is a specialized telephony key system that is generally used by financial traders on their trading desk. Trading turrets enable users to prioritize incoming call activity from customers or counterparties and make calls to these same people instantaneously by pushing a single button to access dedicated point-to-point telephone lines (commonly called Ringdown circuits). No dialing is necessary; the user simply picks up the handset or pushes a button and a dedicated line is seized. Thus, many turrets have multiple handsets and multi-channel speaker units,



allowing immediate connection with multiple parties (e.g., 30 channels). These channels remain constantly open throughout the trading day.

Today, private wire services are evolving from digital TDM architectures to IP-based architectures. The device can be used for interworking between these two architectures, where you have the PSTN switch (PBX) using the E1/T1 CAS protocol on one side, and a SIP-based private wire (turret system) trunk on the other side. The device converts the CAS channels into a SIP call with a called and calling number and if required, passes the ABCD bit state changes through SIP messages, and vice versa. The following diagram shows an example of private-wire interworking by the device:



SIP-based private wire calls are established as any other INVITE dialog, but with the addition of the following headers:

- SIP Supported header with the value "pw-info-package" (i.e., Supported: pw-info-package).
- SIP Recv-Info header with the value "pw-info-package" and with the parameter "pw-type=" with a value denoting the private wire state, which can be:

- Ring Down state:

```
Recv-Info: pw-info-package;pw-type=ringdown
```

- Hook Switch:

```
Recv-Info: pw-info-package;pw-type=hookswitch
```

- TOS:

```
Recv-Info: pw-info-package;pw-type=tos
```

The following is an example of an INVITE message for a private wire call:

```

INVITE sip:109701@10.221.108.249:5060;transport=tcp SIP/2.0
Via:SIP/2.0/TCP10.221.109.4:5060;oc-
node=101;branch=z9hG4bKqkYGTNi7Husc11Jlmw6d9g;rport
From: <sip:uas@10.221.109.4>;tag=ENvIDQ
To: <sip:109701@10.221.108.249:5060;transport=tcp>
Call-ID: WHuqvQgdIZB27ewgrhJRYw
CSeq: 835392 INVITE
Contact: <sip:10.221.109.4:5060;transport=tcp;oc-node=101>
Max-Forwards: 70
Content-Type: application/sdp
Content-Length: 635
Supported: pw-info-package
Recv-Info: pw-info-package;pw-type=ringdown

```

Once a SIP-based private wire is established, the private wire user may wish to signal any of the following private wire events to the far-end private wire user, at any time during the "always-on" call:

- **Hook Switch (On Hook and Off Hook states):** This event signals a change in the state of an electronic hook switch. An example is when the user connects a wireless headset to the phone.
- **Ring Down (Ring and No Ring states):** This event signals a ring or no ring state. An example is when the user lifts the handset or pushes a button on the phone to alert the far-end user, which instantly sends ringing to the far end (even though they are already connected). This is also known as Automatic Ring Down (ARD) or Manual Ring Down (MRD).
- **TOS (transmission only service):** If neither Ring Down or Hook Switch modes are specified in the INVITE, TOS is assumed. In this case, the device ignores all CAS signaling, replies with 200 OK and opens a media channel.

These special private wire events are signaled during a call using the SIP INFO message in association with the INFO package (per IETF draft). The INFO package is the INFO message's body, which is in XML schema. The root element of the XML is "<pwsignal>", which contains two child elements:

- "<ringDown>" - requests a local Ring Down alert
- "<hookSwitch>" - requests a Hook Switch alert:
  - ◆ "onHook" - signals that the endpoint is not in use
  - ◆ "offHook" - signals that the endpoint is in use

The following is an example of the XML for private wire signaling in the SIP INFO message:

```

<?xml version="1.0" encoding="UTF-8"?>
<xsd:schema targetNamespace="urn:bt-trs:params:xml:ns:private-wire:0"
  xmlns="urn:bt-trs:params:xml:ns:private-wire:0"
  xmlns:xsd="http://www.w3.org/2001/XMLSchema"

```

```
elementFormDefault="qualified"
version="0.1">
```

```
<xsd:annotation>
  <xsd:documentation xml:lang="en">Version 0.1 Draft XML schema
    for Private Wire Signalling in SIP INFO body
  </xsd:documentation>
</xsd:annotation>
```

```
<!-- pwSignal -->
<xsd:complexType name="pwSignallingType">
  <xsd:sequence>
    <xsd:choice>
      <xsd:element ref="ringDown" />
      <xsd:element ref="hookSwitch" />
      <xsd:any namespace="##other" minOccurs="0"
        maxOccurs="unbounded" processContents="lax" />
    </xsd:choice>
  </xsd:sequence>
  <xsd:anyAttribute namespace="##other" processContents="lax" />
</xsd:complexType>
<xsd:element name="pwSignal" type="pwSignallingType"/>
```

```
<!-- ringDown -->
<xsd:complexType name="ringDownType">
  <xsd:sequence>
    <xsd:any namespace="##other" minOccurs="0"
      maxOccurs="unbounded" processContents="lax" />
  </xsd:sequence>
  <xsd:attribute name="signal" type="ringDownSignalType" use="required"/>
  <xsd:anyAttribute namespace="##other" processContents="lax" />
</xsd:complexType>
<xsd:element name="ringDown" type="ringDownType"/>
```

```
<!-- hookSwitch -->
<xsd:complexType name="hookSwitchType">
  <xsd:sequence>
    <xsd:any namespace="##other" minOccurs="0"
      maxOccurs="unbounded" processContents="lax" />
  </xsd:sequence>
  <xsd:attribute name="signal" type="hookSwitchSignalType" use="required"/>
  <xsd:anyAttribute namespace="##other" processContents="lax" />
```


```
</xsd:complexType>
<xsd:element name="hookSwitch" type="hookSwitchType"/>
```

```
<!-- DATATYPES-->
<xsd:simpleType name="ringDownSignalType">
  <xsd:restriction base="xsd:token">
    <xsd:enumeration value="ring"/>
  </xsd:restriction>
</xsd:simpleType>
```


```
<xsd:simpleType name="hookSwitchSignalType">
  <xsd:restriction base="xsd:token">
    <xsd:enumeration value="onHook"/>
    <xsd:enumeration value="offHook"/>
  </xsd:restriction>
</xsd:simpleType>
```

```
</xsd:schema>
```

The following is an example of the message flow for the interworking private wire Ring Down state between the private wire trunk and the E1/T1 CAS trunk:



The following is an example of the message flow for interworking private wire Hook Switch states between the private wire trunk and the E1/T1 CAS trunk:



➤ **To configure private wire interworking:**

1. Enable TDM tunneling for private wire services, by doing one of the following:
  - **Globally:** Open the Digital Gateway Parameters page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Digital Gateway** > **Digital Gateway Parameters**), and then from the 'TDM Tunneling' drop-down list, select **Private Wire**:

TDM Tunneling

Private Wire

- **Per Trunk:** Configure the ini file parameter [EnableTDMOverIPforTrunk].
2. Configure the ini file parameter [EnableReansweringInfo] to 1.
  3. Upload a CAS table file that supports your private wire service. For loading files to the device, see [Uploading Auxiliary Files](#) on page 1220.
  4. In the Trunk Settings page (see [Configuring Trunk Settings](#) on page 850), configure your E1 or T1 CAS Trunk. Make sure that you select the CAS table file that you loaded in the previous step, in the 'CAS Table per Trunk' field:

☒ CAS Table per Trunk

Private\_Wire .dat (200)

5. In the Trunk Groups table (see [Configuring Trunk Groups](#) on page 903), configure the Trunk Group ID for the E1/T1 CAS Trunk, as shown in the following example:

Group Index	Module	From Trunk	To Trunk	Channels	Phone Number	Trunk Group ID	Tel Profile Name
1	Module 1 PRI	1	1	1-30	4000	1	None

6. In the Trunk Group Settings table (see [Configuring Trunk Group Settings](#) on page 906), configure the method for selecting channels for the E1/T1 CAS Trunk to **By Dest Phone Number**, as shown in the following example:

INDEX	NAME	TRUNK GROUP ID	CHANNEL SELECT MODE ▾
0	PW	1	By Dest Phone Number

7. In the IP-to-Tel Routing table (see [Configuring IP-to-Tel Routing Rules](#) on page 928), configure IP-to-Tel Routing rules.

## QSIG Tunneling

The device supports QSIG tunneling over SIP, according to IETF Internet-Draft draft-elwell-sipping-qsig-tunnel-03 ("Tunnelling of QSIG over SIP") and ECMA-355/ISO/IEC 22535. This is applicable to all ISDN variants. QSIG tunneling can be applied to all calls or to specific calls using IP Profiles.



TDM tunneling is applicable only to PRI .

QSIG tunneling sends all QSIG messages as raw data in corresponding SIP messages using a dedicated message body. This is used, for example, to enable two QSIG subscribers connected to the same or different QSIG PBX to communicate with each other over an IP network. Tunneling is supported in both directions (Tel-to-IP and IP-to-Tel).

The term tunneling means that messages are transferred 'as is' to the remote side without being converted (QSIG > SIP > QSIG). The advantage of tunneling over QSIG-to-SIP interworking is that by using interworking, QSIG functionality can only be partially achieved. When tunneling is used, all QSIG capabilities are supported and the tunneling medium (the SIP network) doesn't need to process these messages.

QSIG messages are transferred in SIP messages in a separate Multipurpose Internet Mail Extensions (MIME) body. Therefore, if a message contains more than one body (e.g., SDP and QSIG), multipart MIME must be used. The Content-Type of the QSIG tunneled message is 'application/QSIG'. The device also adds a Content-Disposition header in the following format:

Content-Disposition: signal; handling=required.

QSIG tunneling is done as follows:

- **Call setup (originating device):** The QSIG Setup request is encapsulated in the SIP INVITE message without being altered. After the SIP INVITE request is sent, the device doesn't encapsulate the subsequent QSIG message until a SIP 200 OK response is received. If the originating device receives a 4xx, 5xx, or 6xx response, it disconnects the QSIG call with a 'no route to destination' cause.
- **Call setup (terminating device):** After the terminating device receives a SIP INVITE request with a 'Content-Type: application/QSIG', it sends the encapsulated QSIG Setup message to the Tel side and sends a 200 OK response (no 1xx response is sent) to IP. The 200 OK response includes an encapsulated QSIG Call Proceeding message (without waiting for a Call Proceeding message from the Tel side). If tunneling is disabled and the incoming INVITE includes a QSIG body, a 415 response is sent.

- **Mid-call communication:** After the SIP connection is established, all QSIG messages are encapsulated in SIP INFO messages.
- **Call tear-down:** The SIP connection is terminated once the QSIG call is complete. The Release Complete message is encapsulated in the SIP BYE message that terminates the session.

➤ **To enable QSIG tunneling:**

1. Open the Digital Gateway Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Digital Gateway** > **Digital Gateway Settings**).
2. Select the 'Enable QSIG Tunneling' check box (EnableQSIGTunneling) on the originating and terminating devices:

Enable QSIG Tunneling ☒

3. Configure the [QSIGTunnelingMode] parameter for defining the format of encapsulated QSIG message data in the SIP message MIME body (0 for ASCII presentation; 1 for binary encoding).
4. Configure the [ISDNDuplicateQ931BuffMode] parameter to 128 to duplicate all messages.
5. Configure the [ISDNInCallsBehavior] parameter to 4096.
6. Configure the [ISDNRxOverlap] parameter to 0 for tunneling of QSIG overlap-dialed digits (see below for description).

The [ISDNInCallsBehavior] and [ISDNRxOverlap] parameters enable tunneling of QSIG overlap-dialed digits (Tel to IP). In this configuration, the device **delays** the sending of the QSIG Setup Ack message upon receipt of the QSIG Setup message. Instead, the device sends the Setup Ack message to QSIG only when it receives the SIP INFO message with Setup Ack encapsulated in its MIME body. The PBX sends QSIG Information messages (to complete the Called Party Number) only after it receives the Setup Ack. The device relays these Information messages encapsulated in SIP INFO messages to the remote party.

## ISDN Non-Facility Associated Signaling (NFAS)

In regular T1 ISDN trunks, a single 64 kbps channel carries signaling for the other 23 B-channels of that particular T1 trunk. This channel is called the D-channel and usually resides on timeslot # 24. ISDN Non-Facility Associated Signaling (NFAS) enables the use of a single D-channel to control multiple PRI interfaces.



NFAS is applicable only to T1 trunks.

With NFAS it is possible to define a group of T1 trunks, called an *NFAS group*, in which a single D-channel carries ISDN signaling messages for the entire group. The NFAS group's B-channels are used to carry traffic such as voice or data. The NFAS mechanism also enables definition of a backup D-channel on a different T1 trunk, to be used if the primary D-channel fails.

The device supports up to 12 NFAS groups. Each group can comprise up to 10 T1 trunks and each group must contain different T1 trunks. Each T1 trunk is called an "NFAS member". The T1 trunk whose D-channel is used for signaling is called the "Primary NFAS Trunk". The T1 trunk whose D-channel is used for backup signaling is called the "Backup NFAS Trunk". The primary and backup trunks each carry 23 B-channels while all other NFAS trunks each carry 24 B-channels.

The NFAS group is identified by an NFAS GroupID number (possible values are 1 to 12). To assign a number of T1 trunks to the same NFAS group, use the `NFASGroupNumber_x = groupID` (where x is the physical trunk ID (0 to the maximum number of trunks) or the Web interface (see [Configuring Trunk Settings](#) on page 850).

The parameter `DchConfig_x = Trunk_type` defines the type of NFAS trunk. `Trunk_type` is set to 0 for the primary trunk, to 1 for the backup trunk, and to 2 for an ordinary NFAS trunk. 'x' denotes the physical trunk ID (0 to the maximum number of trunks). You can also use the Web interface (see [Configuring Trunk Settings](#) on page 850).

For example, to assign the first four T1 trunks to NFAS group #1, in which trunk #0 is the primary trunk and trunk #1 is the backup trunk, use the following configuration:

```
NFASGroupNumber_0 = 1
NFASGroupNumber_1 = 1
NFASGroupNumber_2 = 1
NFASGroupNumber_3 = 1
DchConfig_0 = 0      ;Primary T1 trunk
DchConfig_1 = 1      ;Backup T1 trunk
DchConfig_2 = 2      ;24 B-channel NFAS trunk
DchConfig_3 = 2      ;24 B-channel NFAS trunk
```

The NFAS parameters are described in [PSTN Parameters](#) on page 1815.

## NFAS Interface ID

Several ISDN switches require an additional configuration parameter per T1 trunk that is called 'Interface Identifier'. In NFAS T1 trunks, the Interface Identifier is sent explicitly in Q.931 Setup / Channel Identification IE for all NFAS trunks, except for the B-channels of the Primary trunk (see note below).

The Interface ID can be defined per member (T1 trunk) of the NFAS group, and must be coordinated with the configuration of the Switch. The default value of the Interface ID is identical to the number of the physical T1 trunk (0 for the first trunk, 1 for the second T1 trunk, and so on, up to the maximum number of trunks).

To define an explicit Interface ID for a T1 trunk (that is different from the default), use the following parameters:

- `ISDNIBehavior_x = 512` (x = 0 to the maximum number of trunks identifying the device's physical trunk)



- ISDNNFASInterfaceID\_x = ID (x = 0 to 255)



- Usually the Interface Identifier is included in the Q.931 Setup/Channel Identification IE only on T1 trunks that doesn't contain the D-channel. Calls initiated on B-channels of the Primary T1 trunk, by default, don't contain the Interface Identifier. Setting the parameter ISDNIBehavior\_x to 2048' forces the inclusion of the Channel Identifier parameter also for the Primary trunk.
- The parameter ISDNNFASInterfaceID\_x = ID can define the 'Interface ID' for any Primary T1 trunk, even if the T1 trunk is not a part of an NFAS group. However, to include the Interface Identifier in Q.931 Setup/Channel Identification IE configure ISDNIBehavior\_x = 2048 in the *ini* file.

## Working with DMS-100 Switches

The DMS-100 switch requires the following NFAS Interface ID definitions:

- InterfaceID #0 for the Primary trunk
- InterfaceID #1 for the Backup trunk
- InterfaceID #2 for a 24 B-channel T1 trunk
- InterfaceID #3 for a 24 B-channel T1 trunk, and so on for subsequent T1 trunks

For example, if four T1 trunks on a device are configured as a single NFAS group with Primary and Backup T1 trunks that is used with a DMS-100 switch, the following parameters should be used:

```
NFASGroupNumber_0 = 1
NFASGroupNumber_1 = 1
NFASGroupNumber_2 = 1
NFASGroupNumber_3 = 1
DchConfig_0 = 0 ;Primary T1 trunk
DchConfig_1 = 1 ;Backup T1 trunk
DchConfig_2 = 2 ;B-Channel NFAS trunk
DchConfig_3 = 2 ;B-channel NFAS trunk
```

If there is no NFAS Backup trunk, the following configuration should be used:

```
ISDNNFASInterfaceID_0 = 0
ISDNNFASInterfaceID_1 = 2
ISDNNFASInterfaceID_2 = 3
ISDNNFASInterfaceID_3 = 4
ISDNIBehavior = 512 ;The parameter should be added because of
;ISDNNFASInterfaceID configuration above
NFASGroupNumber_0 = 1
NFASGroupNumber_1 = 1
NFASGroupNumber_2 = 1
```

```
NFASGroupNumber_3 = 1
DchConfig_0 = 0 ;Primary T1 trunk
DchConfig_1 = 2 ;B-Channel NFAS trunk
DchConfig_2 = 2 ;B-Channel NFAS trunk
DchConfig_3 = 2 ;B-channel NFAS trunk
```

## Creating an NFAS-Related Trunk Configuration

The procedures for creating and deleting an NFAS group must be performed in the correct order, as described below.

### ➤ To create an NFAS Group:

1. If there's a backup ('secondary') trunk for this group, it must be configured first.
2. Configure the primary trunk before configuring any NFAS ('slave') trunk.
3. Configure NFAS ('slave') trunks.

### ➤ To stop / delete an NFAS Group:

1. Stop or delete (by setting ProtocolType to 0, i.e., 'None') all NFAS ('slave') trunks.
2. Stop or delete (by setting ProtocolType to 0, i.e., 'None') the backup trunk if a backup trunk exists.
3. Stop or delete (by setting ProtocolType to 0, i.e., 'None') the primary trunk.



- All trunks in the group must be configured with the same values for trunk parameters TerminationSide, ProtocolType, FramingMethod, and LineCode.
- After stopping or deleting the backup trunk, delete the group and then reconfigure it.

## Performing Manual D-Channel Switchover in NFAS Group

If an NFAS group is configured with two D-channels (Primary and Backup), you can do a manual switchover between these D-channels.

### ➤ To manually switchover from active to standby D-channel:

1. Open the NFAS Group & D-Channel Status page (**Monitor** menu > **PSTN Status** tab > **NFAS Group & D-Channel Status**).
2. Select the required NFAS group, and then click the **Switch Activity** button.



- The **Switch Activity** button is unavailable (i.e, grayed out) if a switchover cannot be done due to, for example, alarms or unsuitable states.
- This feature is applicable only to T1 ISDN protocols supporting NFAS, and only if the NFAS group is configured with two D-channels.

## ISDN Overlap Dialing

Overlap dialing is a dialing scheme used by several ISDN variants to send and/or receive called number digits one after the other (or several at a time). This is in contrast to en-bloc dialing in which a complete number is sent in one message.

The device supports the following ISDN overlap dialing methods:

- Collects ISDN called party number digits and then sends the SIP INVITE to the IP side with the complete destination number (see [Collecting ISDN Digits and Sending Complete Number in SIP](#) below)
- Interworks ISDN overlap dialing with SIP, according to RFC 3578 (see [Interworking ISDN Overlap Dialing with SIP According to RFC 3578](#) on the next page)



ISDN overlap dialing is applicable to PRI .

## Collecting ISDN Digits and Sending Complete Number in SIP

The device can support an overlap dialing mode whereby the device collects the called party number digits from ISDN Q.931 Information messages or DTMF signals, and then sends a SIP INVITE message to the IP side containing the complete destination number.

ISDN overlap dialing for incoming ISDN calls can be configured for the entire device or per ISDN trunk. This is configured using the global parameter, [ISDNRxOverlap] or the [ISDNRxOverlap\_x] parameter (where x denotes the trunk number), respectively.

By default (see the [ISDNINCallsBehavior] parameter), the device plays a dial tone to the ISDN user side when it receives an empty called number from the ISDN. In this scenario, the device includes the Progress Indicator in the SetupAck ISDN message that it sends to the ISDN side.

The device can also mute in-band DTMF detection until it receives the complete destination number from the ISDN. This is configured by the [MuteDTMFInOverlap] parameter. The Information digits can be sent in-band in the voice stream, or out-of-band using Q.931 Information messages. If Q.931 Information messages are used, the DTMF in-band detector must be disabled. Note that when at least one digit is received in the ISDN Setup message, the device stops playing a dial tone.

The device stops collecting digits (from the ISDN) upon the following scenarios:

- The device receives a Sending Complete IE in the ISDN Setup or Information messages, indicating no more digits.

- The timeout between received digits expires (configured by the [TimeBetweenDigits] parameter).
- The maximum number of received digits has been reached (configured by the [MaxDigits parameter]).
- A match is found with the defined digit map (configured by the [DigitMapping] parameter).

Relevant parameters (described in [PSTN Parameters](#) on page 1815):

- [ISDNRxOverlap\_x = 1] (can be configured per trunk)
- [TimeBetweenDigits]
- [MaxDigits]
- [MuteDTMFInOverlap]
- [DigitMapping]

To configure ISDN overlap dialing using the Web interface, see [Configuring Trunk Settings](#) on page 850.

## Interworking ISDN Overlap Dialing with SIP According to RFC 3578

With overlap dialing disabled, the device expects to receive the digits all at once (enbloc) or with very little delay between digits and then sends the complete number in a single message. Overlap signaling sends portions of the number in separate messages as it collects the digits from the sender. The interval between receiving the digits (*time between digits*) is relatively long. However, overlap dialing allows the device to begin call setup (routing) even before all digits have been collected. For example, if the dialed (destination) number is "3312418", the device first receives the digits "331" and then routes the call based on these digits. It then delivers the remaining 4 digits "2418" in overlap mode. The device supports the interworking of ISDN overlap dialing to SIP and vice versa, according to RFC 3578.

- **Interworking ISDN overlap dialing to SIP (Tel to IP):** The device sends the first digits (e.g., "331") received from the ISDN Setup message to the IP side in the initial SIP INVITE message. Each time it receives additional (collected) digits, which are received from subsequent Q.931 Information messages, it sends them to the IP side in SIP re-INVITE or SIP INFO messages. You can use the following parameters to configure overlap dialing for Tel-to-IP calls:
  - ISDNRxOverlap: Enables Tel-to-IP overlap dialing and defines how the device sends the collected digits to the IP side - in SIP re-INVITE [2] or INFO messages [3].
  - MinOverlapDigitsForRouting: Defines the minimum number of overlap digits to collect from the Tel side before the device can send the first SIP message (INVITE) for routing the call to the IP side.
  - MaxDigits: Defines the maximum number of collected digits that can be received from the Tel side (if ISDN Sending Complete IE is not received). When the number of collected digits reaches the maximum, the device uses these digits for the called destination number.

- **TimeBetweenDigits:** Defines the maximum time (in seconds) that the device waits between digits received from the Tel side. When the time expires, the device uses the collected digits to dial the called destination number.
- **MuteDTMFInOverlap:** Enables the device to ignore in-band DTMF digits received during overlap dialing.



If the device receives SIP 4xx responses during the overlap dialing (while collecting digits), it doesn't release the call.

- **Interworking SIP to ISDN overlap dialing (IP to Tel):** The device sends the first digits (e.g., "331") received from the initial SIP INVITE message to the Tel side in an ISDN Setup message. Each time it receives additional (collected) digits for the same dialog, which are received from subsequent SIP re-INVITE messages or SIP INFO messages, it sends them to the Tel side in SIP Q.931 Information messages. For each subsequent re-INVITE or SIP INFO message received, the device sends a SIP 484 "Address Incomplete" response to the IP side to maintain the current dialog session and to receive additional digits from subsequent re-INVITE or INFO messages. You can use the following parameters to configure overlap dialing for IP-to-Tel calls:

- **ISDNtxOverlap:** Enables IP-to-Tel overlap dialing and defines how the device receives the collected digits from the IP side - in SIP re-INVITE [1] or INFO messages [2].
- **TimeBetweenDigits:** Defines the maximum time (in seconds) that the device waits between digits received from the IP side. When the time expires, the device uses the collected digits to dial the called destination number.



For IP-to-Tel overlap dialing, to send ISDN Setup messages without including the Sending Complete IE, you must configure the `ISDNOutCallsBehavior` parameter to `USER SENDING COMPLETE` [2].

For more information on the above mentioned parameters, see [PSTN Parameters](#) on page 1815. To configure ISDN overlap dialing using the Web interface, see [Configuring Trunk Settings](#) on page 850.

## Redirect Number and Calling Name (Display)

The following tables define the device's redirect number and calling name (Display) support for various ISDN variants according to NT (Network Termination) / TE (Termination Equipment) interface direction:

**Table 23-3: Calling Name (Display) per ISDN Variant**

NT/TE Interface	DMS-100	NI-2	4/5ESS	Euro ISDN	QSIG	NTT	KOR
NT-to-TE	Yes	Yes	Yes	Yes	Yes	Yes	Yes
TE-to-NT	Yes	Yes	Yes	No	Yes	No	No

**Table 23-4: Redirect Number per ISDN Variant**

NT/TE Interface	DMS-100	NI-2	4/5ESS	Euro ISDN	QSIG
NT-to-TE	Yes	Yes	Yes	Yes	Yes
TE-to-NT	Yes	Yes	Yes	Yes*	Yes

\* When using ETSI DivertingLegInformation2 in a Facility IE (not Redirecting Number IE).

## 24 Trunk Groups

This section describes Trunk Group configuration.

### Configuring Trunk Groups

The Trunk Groups table lets you configure up to 24 Trunk Groups. A Trunk Group is a logical group of physical trunks and channels. A Trunk Group can include multiple trunks and a range of channels. To enable and activate the channels, you need to configure the Trunk Group and assign it telephone numbers. Channels that are not configured in this table are disabled.

Once you have configured your Trunk Group, you can use it for call routing. To configure IP-to-Tel routing rules, see [Configuring IP-to-Tel Routing Rules](#) on page 928. To configure Tel-to-IP routing rules, see [Configuring Tel-to-IP Routing Rules](#) on page 914.

The following procedure describes how to configure Trunk Groups through the Web interface. You can also configure it through ini file [TrunkGroup\_x] or CLI (`configure voip > gateway trunk-group`).



It's recommended **not** to configure a Trunk Group with Trunk Group ID **0**. A Trunk Group with ID 0 doesn't support some of the device's features (e.g., not counted in performance monitoring).

#### ➤ To configure a Trunk Group:

1. Open the Trunk Groups table (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Trunks & Groups** > **Trunk Groups**).

Add Phone Context As Prefix Disable ▾  
 Trunk Group Index 1-12 ▾

GROUP INDEX	MODULE	FROM TRUNK	TO TRUNK	CHANNELS	PHONE NUMBER	TRUNK GROUP ID	TEL PROFILE NAME
1	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text" value="None"/>
2	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text" value="None"/>
3	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text" value="None"/>
4	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text" value="None"/>
5	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text" value="None"/>
6	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text" value="None"/>
7	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text" value="None"/>
8	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text" value="None"/>
9	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text" value="None"/>
10	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text" value="None"/>
11	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text" value="None"/>
12	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text"/>	<input type="text" value="None"/>

Register
Un-Register

2. Configure a Trunk Group according to the parameters described in the table below.

### 3. Click **Apply**.

You can also register all your Trunk Groups. The registration method per Trunk Group is configured by the 'Registration Mode' parameter in the Trunk Group Settings page (see [Configuring Trunk Group Settings](#) on page 906).

- To register Trunk Groups, click the **Register** button.
- To unregister Trunk Groups, click the **Unregister** button.

**Table 24-1: Trunk Group Table Parameter Descriptions**

Parameter	Description
'Module' module [Module]	Defines the telephony interface module for which you want to define the Trunk Group.
'From Trunk' first-trunk-id [FirstTrunkId]	Defines the starting physical Trunk number in the Trunk Group. The number of listed Trunks depends on the device's hardware configuration. <b>Note:</b> The parameter is applicable only to digital interfaces.
'To Trunk' last-trunk-id [LastTrunkId]	Defines the ending physical Trunk number in the Trunk Group. The number of listed Trunks depends on the device's hardware configuration. <b>Note:</b> The parameter is applicable only to digital interfaces.
'Channels' first-b-channel [FirstBChannel] last-b-channel [LastBChannel]	<ul style="list-style-type: none"> <li>■ Digital: Defines the Trunk's B-channels .</li> </ul> <p>To enable channels, enter the channel numbers. You can enter a range of channels by using the syntax <i>n-m</i>, where <i>n</i> represents the lower channel number and <i>m</i> the higher channel number. For example, "1-4" (without quotation marks) specifies channels 1 through 4. For digital interfaces, to represent all the Trunk's B-channels, enter a single asterisk (*).</p> <p><b>Note:</b> For digital interface, the number of defined channels must not exceed the maximum number of the Trunk's B-channels.</p>
'Phone Number' first-phone-number [FirstPhoneNumber]	Defines the telephone number(s) of the channels. The valid value can be up to 50 characters. For a range of channels, enter only the first telephone number. Subsequent channels are assigned the next consecutive telephone number. For



Parameter	Description
	<p>example, if you enter 400 for channels 1 to 4, then channel 1 is assigned phone number 400, channel 2 is assigned phone number 401, and so on.</p> <p>These numbers are also used for channel allocation for IP-to-Tel calls if the Trunk Group's 'Channel Select Mode' parameter is set to <b>By Dest Phone Number</b>.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If this field includes alphabetical characters and the phone number is defined for a range of channels (e.g., 1-4), then the phone number must end with a number (e.g., 'user1').</li> <li>■ This field is optional. The logical numbers defined in this field are used when an incoming Tel call doesn't contain the calling number or called number (the latter being determined by the [ReplaceEmptyDstWithPortNumber] parameter). These numbers are used to replace them.</li> <li>■ This field is ignored if routing of IP-to-Tel calls is done according to the Supplementary Services table, where multiple line extension numbers are configured per port (see Configuring Trunk Groups). For this routing method, the 'Channel Select Mode' parameter must be configured to <b>Select Trunk By Supplementary Services Table</b> in the Trunk Group Settings table (see <a href="#">Configuring Trunk Group Settings</a> on the next page).</li> </ul>
'Trunk Group ID' trunk-group-id [TrunkGroupNum]	<p>Defines the Trunk Group ID for the specified channels. The same Trunk Group ID can be assigned to more than one group of channels. If an IP-to-Tel call is assigned to a Trunk Group, the IP call is routed to the channel(s) pertaining to that Trunk Group ID. The valid value can be 0 to 100.</p> <p><b>Note:</b> Currently, Trunk Group ID #0 is not counted in the device's performance monitoring and no SNMP alarms are sent for it.</p>
'Tel Profile Name' tel-profile-id [ProfileName]	<p>Assigns a Tel Profile to the Trunk Group.</p> <p>To configure Tel Profiles, see <a href="#">Configuring Tel Profile</a> on page 738.</p>

## Configuring Trunk Group Settings

The Trunk Group Settings table lets you configure various settings per Trunk Group ID, which is assigned to a Trunk Group in [Configuring Trunk Groups](#) on page 903. The main configuration includes the following:

- Channel select method, which defines how the device allocates incoming IP-to-Tel calls to the channels of a Trunk Group.
- Registration method for registering Trunk Groups to remote IP servers (*Serving IP Group*).

The Trunk Group Settings table also provides an **Action** drop-down button with commands that let you perform various actions per configured Trunk Group:

- **Lock / Unlock:** Locks (blocks) a Trunk Group in order to take its member trunks out-of-service. For more information, see [Locking and Unlocking Trunk Groups](#) on page 1208.
- **Register / Un-Register:** Initiates a registration request for the Trunk Group with a Serving IP Group. For more information, see the description of the 'Registration Mode' parameter of the Trunk Group Settings table in this section.

The following procedure describes how to configure settings for Trunk Groups through the Web interface. You can also configure it through ini file [TrunkGroupSettings] or CLI (`configure voip > gateway trunk-group-setting`).

### ➤ To configure Trunk Group settings per Trunk Group ID:

1. Open the Trunk Group Settings table (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Trunks & Groups** > **Trunk Group Settings**).
2. Click **New**; the following dialog box appears:

3. Configure settings for a Trunk Group ID according to the parameters described in the table below.
4. Click **Apply**.

**Table 24-2: Trunk Group Settings Table Parameter Descriptions**

Parameter	Description
General	
'Index'	Defines an index number for the new table row. Up to 101 rows can be configured.

Parameter	Description
[Index]	<b>Note:</b> Each row must be configured with a unique index.
'Name' trunk-group-name [TrunkGroupName]	<p>Defines a descriptive name, which is used when associating the row in other tables.</p> <p>The valid value can be a string of up to 40 characters. By default, no name is configured.</p> <p>if you enable the [UseSIPtgrp] or [UseBroadsoftDTG] parameters, the name also represents the Trunk Group in the SIP 'tgrp' parameter in outgoing INVITE messages (according to RFC 4904) and/or REGISTER messages (depending on the [UseSIPtgrp] parameter settings). For example, if you configure the parameter to "ITSP-ABC":  <code>sip:+16305550100;tgrp=ITSP-ABC;trunk-context=+1-630@isp.example.net;user=phone</code></p> <p>If you don't configure the 'Name' parameter, the Trunk Group number is set as the value in the 'tgrp' parameter, for example:  <code>sip:+16305550100;tgrp=TG-1;trunk-context=+1-630@isp.example.net;user=phone</code></p> <p><b>Note:</b> Configure each row with a unique name.</p>
'Trunk Group ID' trunk-group-id [TrunkGroupId]	Defines the Trunk Group by its ID number, which you configured in <a href="#">Configuring Trunk Groups</a> on page 903.
'Channel Select Mode' channel-select-mode [ChannelSelectMode]	<p>Defines the method by which IP-to-Tel calls are assigned to the channels of the Trunk Group.</p> <ul style="list-style-type: none"> <li>■ [0] <b>By Dest Phone Number</b> = The channel is selected according to the called (destination) number. If the number is not located, the call is released. If the channel is unavailable (e.g., busy), the call is put on call waiting (if call waiting is enabled and no other call is on call waiting); otherwise, the call is released.</li> <li>■ [1] <b>Channel Cyclic Ascending</b> = The next available channel in the Trunk Group, in ascending cyclic order is selected. After the device reaches the highest channel number in the Trunk Group, it selects the lowest channel number in the Trunk Group, and then starts ascending again.</li> <li>■ [2] <b>Always Ascending</b> = The lowest available channel in the Trunk Group is selected, and if unavailable, the next</li> </ul>

Parameter	Description
	<p>higher channel is selected.</p> <ul style="list-style-type: none"> <li>■ [3] <b>Cyclic Descending</b> = The next available channel in descending cyclic order is selected. The next lower channel number in the Trunk Group is always selected. When the device reaches the lowest channel number in the Trunk Group, it selects the highest channel number in the Trunk Group, and then starts descending again.</li> <li>■ [4] <b>Always Descending</b> = The highest available channel in the Trunk Group is selected, and if unavailable, the next lower channel is selected.</li> <li>■ [5] <b>Dest Number &amp; Cyclic Ascending</b> = The channel is selected according to the called number. If the called number isn't found, the next available channel in ascending cyclic order is selected.</li> </ul> <p><b>Note:</b> If the called number is located, but the port associated with the number is busy, the call is released.</p> <ul style="list-style-type: none"> <li>■ [6] <b>By Source Phone Number</b> = The channel is selected according to the calling number.</li> <li>■ [7] <b>Trunk Cyclic Ascending</b> = The channel from the first channel of the next trunk (adjacent to the trunk from which the previous channel was selected) is selected.</li> <li>■ [8] <b>Trunk &amp; Channel Cyclic Ascending</b> = The device implements the Trunk Cyclic Ascending and Cyclic Ascending methods to select the channel. This method selects the next physical trunk in the Trunk Group, and then selects the B-channel of this trunk according to the Cyclic Ascending method (i.e., selects the channel after the last allocated channel).</li> </ul> <p>For example, if the Trunk Group includes two physical trunks, 0 and 1:</p> <ul style="list-style-type: none"> <li>✓ For the first incoming call, the first channel of Trunk 0 is selected.</li> <li>✓ For the second incoming call, the first channel of Trunk 1 is selected.</li> <li>✓ For the third incoming call, the second channel of Trunk 0 is selected.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [11] <b>By Dest Number &amp; Ascending</b> = The device allocates channels to incoming IP-to-Tel calls as follows: <ul style="list-style-type: none"> <li>a. The device attempts to route the call to the channel that is associated with the destination (called) number. If located, the call is sent to that channel.</li> <li>b. If the number is not located or the channel is unavailable (e.g., busy), the device searches in ascending order for the next available channel in the Trunk Group. If located, the call is sent to that channel.</li> <li>c. If all channels are unavailable, the call is released.</li> </ul> </li> </ul> <p><b>Note:</b> If the parameter is not configured, the Trunk Group's channel select method is according to the global parameter [ChannelSelectMode].</p>
'Registration Mode' registration-mode [RegistrationMode]	<p>Defines the registration method of the Trunk Group.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Per Endpoint</b> = Each channel in the Trunk Group registers individually. The registrations are sent to the 'Serving IP Group ID' if configured in the table; otherwise, it is sent to the default Proxy, and if no default Proxy, then to the Registrar IP.</li> <li>■ [1] <b>Per Gateway</b> = (Default) Single registration for the entire device. This is applicable only if a default Proxy or Registrar IP is configured and Registration is enabled (i.e., parameter [IsRegisterUsed] is set to 1). In this mode, the SIP URI user part in the From, To, and Contact headers is set to the value of the global registration parameter, [GWRegistrationName] or username if [GWRegistrationName] is not configured.</li> <li>■ [4] <b>Don't Register</b> = No registrations are sent by endpoints pertaining to the Trunk Group. For example, if the device is configured globally to register all its endpoints (using the parameter [ChannelSelectMode]), you can exclude some endpoints from being registered by assigning them to a Trunk Group and configuring the Trunk Group registration mode to <b>Don't Register</b>.</li> <li>■ [5] <b>Per Account</b> = Registrations are sent (or not) to an IP Group according to the settings in the Accounts table (see <a href="#">Configuring Registration Accounts</a> on page 750).</li> </ul>

Parameter	Description
	<p>An example is shown below of a REGISTER message for registering endpoint "101" using the registration Per Endpoint mode:</p> <pre>REGISTER sip:SipGroupName SIP/2.0 Via: SIP/2.0/UDP 10.33.37.78;branch=z9hG4bKac862428454 From: &lt;sip:101@GatewayName&gt;;tag=1c862422082 To: &lt;sip:101@GatewayName&gt; Call-ID: 9907977062512000232825@10.33.37.78 CSeq: 3 REGISTER Contact: &lt;sip:101@10.33.37.78&gt;;expires=3600 Expires: 3600 User-Agent: Sip-Gateway/7.60A.100.022 Content-Length: 0</pre> <p>The "SipGroupName" in the Request-URI is configured in the IP Groups table (see <a href="#">Configuring IP Groups</a> on page 581).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If the parameter is not configured, registration is done according to the global registration parameter [ChannelSelectMode].</li> <li>■ To enable Trunk Group registration, configure the global parameter [IsRegisterNeeded] to 1. This is unnecessary for <b>Per Account</b> registration mode.</li> <li>■ If the device is configured globally to register Per Endpoint and an channel group includes four channels to register Per Gateway, the device registers all channels except the first four channels. The group of these four channels sends a single registration request.</li> <li>■ When configured to <b>Per Account</b>, you can configure (using the [RegisterByTrunkGroupStatus] parameter) if the device sends a registration request to the Serving Trunk Group (SIP registrar), based on the Trunk Group's status (in-service or out-of-service) for ISDN PRI and CAS.</li> </ul>
'Used By Routing Server' used-by-routing-server	<p>Enables the use of the Trunk Group by ARM for routing decisions.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Not Used</b> (default)</li> </ul>

Parameter	Description
[UsedByRoutingServer]	<ul style="list-style-type: none"> <li>■ [1] <b>Used</b></li> </ul> <p>For more information on routing by ARM, see <a href="#">Centralized Routing by ARM (AudioCodes Routing Manager)</a> on page 442.</p>
SIP Configuration	
'Gateway Name' gateway-name [GatewayName]	<p>Defines the host name of the SIP From header in INVITE messages, and the From and To headers in REGISTER requests.</p> <p>By default, no value is defined.</p> <p><b>Note:</b> If the parameter is not configured, the global parameter [SIPGatewayName] is used.</p>
'Contact User' contact-user [ContactUser]	<p>Defines the user part for the SIP Contact URI in INVITE messages, and the From, To, and Contact headers in REGISTER requests.</p> <p>The valid value is a string of up to 60 characters. By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if the 'Registration Mode' parameter is configured to <b>Per Account</b> and registration based on the Accounts table is successful.</li> <li>■ If registration fails, the user part in the INVITE Contact header is set to the source party number.</li> <li>■ The 'Contact User' parameter in the Accounts table overrides this parameter (see <a href="#">Configuring Registration Accounts</a> on page 750).</li> </ul>
'Serving IP Group' serving-ip-group [ServingIPGroupName]	<p>Assigns an IP Group to where the device sends INVITE messages for calls received from the Trunk Group. The actual destination to where the INVITE messages are sent is according to the Proxy Set associated with the IP Group. The Request-URI host name in the INVITE and REGISTER messages (except for <b>Per Account</b> registration mode) is set to the value of the 'SIP Group Name' parameter configured in the IP Groups table (see <a href="#">Configuring IP Groups</a> on page 581).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If the parameter is not configured, the INVITE messages are sent to the default Proxy or according to the Tel-to-IP</li> </ul>

Parameter	Description
	<p>Routing table (see <a href="#">Configuring Tel-to-IP Routing Rules</a> on page 914).</p> <ul style="list-style-type: none"> <li>■ If the PreferRouteTable parameter is set to 1 (see <a href="#">Configuring Proxy and Registration Parameters</a> on page 765), the routing rules in the Tel-to-IP Routing table take precedence over the selected Serving IP Group ID.</li> </ul>
<p>'MWI Interrogation Type'</p> <p>mwi-interrogation-type</p> <p>[MWIInterrogationType]</p>	<p>Defines message waiting indication (MWI) QSIG-to-IP interworking for interrogating MWI supplementary services.</p> <ul style="list-style-type: none"> <li>■ [255] <b>Not configured</b>.</li> <li>■ [0] <b>None</b> = Disables the feature.</li> <li>■ [1] <b>Use Activate Only</b> = MWI Interrogation messages are not sent and only "passively" responds to MWI Activate requests from the PBX.</li> <li>■ [2] <b>Result Not Used</b> = MWI Interrogation messages are sent, but the result is not used. Instead, the device waits for MWI Activate requests from the PBX.</li> <li>■ [3] <b>Use Result</b> = MWI Interrogation messages are sent, its results are used, and the MWI Activate requests are used. MWI Activate requests are interworked to SIP NOTIFY MWI messages. The SIP NOTIFY messages are sent to the IP Group defined by the [NotificationIPGroupName] parameter.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to digital interfaces.</li> <li>■ The parameter appears in the table only if the [VoiceMailInterface] parameter is set to 3 (QSIG) (see <a href="#">Configuring Voice Mail</a> on page 1014).</li> </ul>
Status	
<p>'Admin State'</p> <p>[AdminState]</p>	<p>(Read-only) Displays the administrators state:</p> <ul style="list-style-type: none"> <li>■ "Locked": The Lock command has been chosen from the Action drop-down button.</li> <li>■ "Unlocked": The Unlock command has been chosen from the Action drop-down button.</li> </ul>
'Status'	<p>(Read-only) Displays the current status of the trunks/channels in the Trunk Group:</p>



Parameter	Description
	<ul style="list-style-type: none"><li>■ "In Service": Indicates that all channels in the Trunk Group are in service, for example, when the Trunk Group is unlocked or Busy Out state cleared (see the [EnableBusyOut] parameter for more information).</li><li>■ "Going Out Of Service": Appears as soon as you choose the Lock command and indicates that the device is starting to lock the Trunk Group and take channels out of service.</li><li>■ "Going Out Of Service (&lt;duration remaining of graceful period&gt; sec / &lt;number of calls still active&gt; calls)": Appears when the device is locking the Trunk Group and indicates the number of busy channels and the time remaining until the graceful period ends, after which the device locks the channels regardless of whether the call has ended or not.</li><li>■ "Out Of Service": All fully configured trunks in the Trunk Group are out of service, for example, when the Trunk Group is locked or in Busy Out state (see the [EnableBusyOut] parameter).</li></ul>

## 25 Routing

This section describes the configuration of call routing for the Gateway application.

### Configuring Tel-to-IP Routing Rules

The Tel-to-IP Routing table lets you configure up to 180 Tel-to-IP routing rules. Tel-to-IP routing rules are used to route calls from the Tel side to an IP destination.

Configuration of Tel-to-IP routing rules includes two areas:


- **Match:** Defines the characteristics of the incoming Tel call (e.g., Trunk Group on which the call is received). You can configure routing rules with one or more of the following incoming Tel characteristics:
  - Source Trunk Group (from where the call is received)
  - Source (calling) and destination (called) telephone number prefix and suffix
  - Source and destination Dial Plan tags
- **Action:** Defines the action that is done if the incoming call matches the characteristics of the rule (i.e., routes the call to the specified IP destination). You can configure the IP destination to one of the following:
  - IP address or FQDN.
  - E.164 Telephone Number Mapping (ENUM service).
  - Lightweight Directory Access Protocol (LDAP). For more information, see [LDAP-based Services](#) on page 369 and [Routing for Microsoft Teams or Skype for Business using Microsoft Entra ID](#) on page 397.
  - IP Group. When an IP Group is selected, the device sends the call to the IP address configured for the Proxy Set that is associated with the IP Group (configured in [Configuring IP Groups](#) on page 581). The SRD associated with the IP Group determines the:
    - ◆ SIP Interface (SIP port and control network interface) - important when using multiple SIP control VLANs
    - ◆ Media Realm (port and network interface for media / RTP voice)
    - ◆ SRD-related features on which the call is routed

If you configure the routing rule to send the call to any destination other than an IP Group (e.g., an IP address), you need to select a SIP Interface for the call. If no SIP Interface is selected, the device uses the SIP Interface associated with the default SRD (Index 0). If you have deleted this SRD or SIP Interface, for whatever reason, the device drops the call. The SIP Interface determines many attributes for the destination:

- Device's logical SIP port and network interface through which the call signaling is sent

- Device's logical RTP port and network interface through which the media is sent (Media Realm)
- Other features that can be configured for the SIP Interface
- SRD. As one of the attributes of a SIP Interface is an SRD and as you can configure multiple SIP Interfaces per SRD, the specific SIP Interface not only determines the above-mentioned attributes, but also the SRD for routing the call.

The device searches the table from **top to bottom** for the **first** rule that matches the characteristics of the incoming call. If it finds a matching rule, it sends the call to the IP destination configured for that rule. If it doesn't find a matching rule, it rejects the call.



In addition to normal Tel-to-IP routing, you can configure the following features:

- **Least Cost Routing (LCR):** If the LCR feature is enabled, the device searches the routing table for matching routing rules and then selects the one with the lowest call cost. The call cost of the routing rule is done by assigning it a Cost Group. To configure Cost Groups, see [Least Cost Routing](#) on page 452. If two routing rules have identical costs, the rule appearing higher up in the table (i.e., first-matched rule) is used. If a selected route is unavailable, the device uses the next least-cost routing rule. However, even if a matched rule is not assigned a Cost Group, the device can select it as the preferred route over other matched routing rules with Cost Groups, according to the optional, default LCR settings configured by the Routing Policy (see [Configuring a Gateway Routing Policy Rule](#) on page 934).

- **Call Forking:** If the Tel-to-IP Call Forking feature is enabled, the device can send a Tel call to multiple IP destinations. An incoming Tel call with multiple matched routing rules (e.g., all with the same source prefix numbers) can be sent (forked) to multiple IP destinations if all these rules are configured with a Forking Group. The call is established with the first IP destination that answers the call.
- **Call Restriction:** Calls whose matching routing rule is configured with the destination IP address of 0.0.0.0 are rejected.
- **Always Use Routing Table:** Even if a proxy server is used, the SIP Request-URI host name in the outgoing INVITE message is obtained from this table. Using this feature, you can assign a different SIP URI host name for different called and/or calling numbers. This feature is enabled using the AlwaysUseRouteTable parameter.
- **IP Profiles:** IP Profiles can be assigned to destination addresses (also when a proxy is used).
- **Alternative Routing (when a proxy isn't used):** An alternative IP destination (alternative routing rule) can be configured for specific calls ("main" routing rule). When the "main" route fails (e.g., busy), the device can send the call to the alternative route. You must configure the alternative routing rules in table rows (indices) that are located anywhere **below** the "main" routing rule. For example, if you configure a "main" routing rule in Index 4, the alternative routing rule can be configured in Index 6. In addition, you must configure the alternative routing rules with identical matching characteristics (e.g., destination prefix number) as the "main" routing rule, but assigned with different destination IP addresses. Instead of an IP address, you can use an FQDN to resolve into two IP addresses. For more information on alternative routing, see [Alternative Routing for Tel-to-IP Calls](#) on page 937.
- **Advice of Charge (AOC):** AOC is a pre-billing feature that tasks the rating engine with calculating the cost of using a service (Tel-to-IP call) and relaying that information to the customer. AOC, which is configured in the Charge Codes table, can be applied per Tel-to-IP routing rule.



- Instead of using the table for Tel-to-IP routing, you can use ARM to handle the routing decisions. For more information on routing by ARM, see [Centralized Routing by ARM \(AudioCodes Routing Manager\)](#) on page 442.
- You can configure up to three alternative routing rules per "main" routing rule in the Tel-to-IP Routing table.
- By default, the device applies telephone number manipulation (if configured) only after processing the routing rule. You can change this and apply number manipulation before processing the routing rule (see the RouteModeTel2IP parameter).
- By default, if the device receives a REFER message, it forwards the message to the destination specified in the message. Alternatively, if you want the device to search again for a matching routing rule in the Tel-to-IP Routing table and to then forward the REFER message to the destination of the matched rule, you need to configure the [SIPReRoutingMode] parameter to [2].
- When using a proxy server, it is unnecessary to configure routing rules in the Tel-to-IP Routing table unless you require one of the following:
  - ✓ Alternative routing (fallback) when communication with the proxy server fails.
  - ✓ IP security, whereby the device routes only received calls whose source IP addresses are configured in the table. Enable IP security using the SecureCallsFromIP parameter.
  - ✓ Filter Calls to IP feature. The device checks the table before a call is routed to the proxy server. However, if the number is not allowed (i.e., the number is not specified in the table or a Call Restriction routing rule is configured), the call is rejected.
  - ✓ Obtain different SIP URI host names (per called number).
  - ✓ Assign IP Profiles to calls.
  - ✓ For the table to take precedence over a proxy server for routing calls, you need to configure the PreferRouteTable parameter to 1. The device checks the 'Destination IP Address' field in the table for a match with the outgoing call; a proxy is used only if a match is not found.

The following procedure describes how to configure Tel-to-IP routing rules through the Web interface. You can also configure it through ini file [Prefix] or CLI (`configure voip > gateway routing tel2ip-routing`).

➤ **To configure Tel-to-IP routing rules:**

1. Open the Tel-to-IP Routing table (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Routing > Tel > IP Routing**).
2. Click **New**; the following dialog box appears:

**GENERAL**

Index: 1  
 Name:   
 Connectivity Status:

**MATCH**

Source Trunk Group ID: -1  
 Source Phone Pattern: \*  
 Source Tag:   
 Destination Phone Pattern: \*  
 Destination Tag:

**ACTION**

Destination IP Group: -- View  
 SIP Interface: -- View  
 Destination IP Address:   
 IP Profile: -- View  
 Destination Port: 0  
 Transport Type:   
**ADVANCED**  
 Call Setup Rules Set ID: -1  
 Forking Group: -1  
 Cost Group: -- View

3. Configure a routing rule according to the parameters described in the table below.

4. Click **Apply**.

The following table shows configuration examples of Tel-to-IP routing rules:

**Table 25-1: Example of Tel-to-IP Routing Rules**

Parameter	Rule 1	Rule 2	Rule 3	Rule 4	Rule 5	Rule 6	Rule 7	Rule 8
<b>Matching Characteristics of Incoming Call</b>								
'Source Trunk Group ID'	-	-	-	4	-	*	*	*
'Source Phone Pattern'	100	100	*	*	*	*	*	*
'Destination Phone Pattern'	10	10	20	[5,7-9]	00	100	100	100
<b>Action</b>								
'Destination IP Group'	-	-	ITS P-ZA	-	-	-	-	-
'Destination IP Address'	10.33.45.63	10.33.45.50		itsp.com	0.0.0.0	10.33.45.68	10.33.45.67	domain.com
'IP'	ABC	ABC	-	-	-	-	-	-

Parameter	Rule 1	Rule 2	Rule 3	Rule 4	Rule 5	Rule 6	Rule 7	Rule 8
Profile'								
'Forking Group'	-	-	-	-	-	1	2	1
'Cost Group ID'	Weekend-Low	Weekend_High	-	-	-	-	-	-

Below are descriptions of each rule:

- **Rules 1 and 2 (Least Cost Routing):** For both rules, the called (destination) phone number prefix is 10, the caller's (source) phone number prefix is 100, and the call is assigned IP Profile "ABC". However, Rule 1 is assigned a cheaper Cost Group than Rule 2, and therefore, the call is sent to the destination IP address (10.33.45.63) associated with Rule 1.
- **Rule 3 (IP Group destination):** For all callers (\*), if the called phone number prefix is 20, the call is sent to IP Group "ITSP-ZA".
- **Rule 4 (domain name destination):** For called phone number prefixes 5, 7, 8, or 9, and the caller belongs to Trunk Group ID 4, the call is sent to the domain "itsp.com".
- **Rule 5 (block):** For all callers (\*), if the called phone number prefix is 00, the call is rejected (IP address 0.0.0.0).
- **Rule 6, 7, and 8 (Forking Group):** For all callers (\*), if the called phone number prefix is 100, the call is sent to Rule 7 and 9 (belonging to Forking Group "1"). If their destinations are unavailable and alternative routing is enabled, the call is sent to Rule 8 (Forking Group "2").

**Table 25-2: Tel-to-IP Routing Table Parameter Descriptions**

Parameter	Description
General	
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' route-name [RouteName]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 40 characters. By default, no value is defined. <b>Note:</b> <ul style="list-style-type: none"> <li>■ Configure each row with a unique name.</li> <li>■ The name can't be configured with the character string</li> </ul>

Parameter	Description
	"any" (upper or lower case).
'Connectivity Status'	<p>(Read-only field) Displays the connectivity status of the routing rule's destination. The destination can be an IP address or an IP Group, as configured in the 'Destination IP Address' and 'Destination IP Group' fields respectively.</p> <p>For IP Groups, the status indicates the connectivity with the SIP proxy server's address configured for the Proxy Set that is associated with the IP Group. For the status to be displayed, the Proxy Keep-Alive feature, which monitors the connectivity with proxy servers per Proxy Set, must be enabled for the Proxy Set (see <a href="#">Configuring Proxy Sets</a> on page 622). If a Proxy Set is configured with multiple proxies for redundancy, the status may change according to the proxy server with which the device attempts to verify connectivity. For example, if there is no response from the first configured proxy address, the status displays "No Connectivity". However, if there is a response from the next proxy server in the list, the status changes to "OK".</p> <p>If there is connectivity with the destination, the field displays "OK" and the device uses the routing rule if required. The routing rule is not used if any of the following is displayed:</p> <ul style="list-style-type: none"> <li>■ "n/a" = IP Group is unavailable.</li> <li>■ "No Connectivity" = No connection with the destination (no response to the SIP OPTIONS).</li> <li>■ "QoS Low" = Poor Quality of Service (QoS) of the destination.</li> <li>■ "DNS Error" = No DNS resolution. This status is applicable only when a domain name is used (instead of an IP address).</li> <li>■ "Not Available" = Destination is unreachable due to networking issues.</li> </ul>
Match	
'Source Trunk Group ID' src-trunk-group-id [SrcTrunkGroupID]	<p>Defines the Trunk Group from where the call is received. To denote any Trunk Group, use the asterisk (*) symbol. By default, no Trunk Group is defined (-1).</p>



Parameter	Description
'Source Phone Pattern' src-phone-pattern [SourcePrefix]	<p>Defines the prefix and/or suffix of the calling (source) telephone number. You can use special notations for denoting the prefix. For example, [100-199](100,101,105) denotes a number that starts with 100 to 199 and ends with 100, 101 or 105. To denote any prefix, use the asterisk (*) symbol (default) or to denote calls without a calling number, use the \$ sign. For a description of available notations, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The number can include up to 50 digits.</p>
'Source Tags' src-tags [SrcTags]	<p>Assigns a Dial Plan tag to denote a group of users by calling (source) number prefixes and/or suffixes.</p> <p>The valid value is a string of up to 70 characters. The tag is case insensitive.</p> <p>To configure Dial Plan tags, see <a href="#">Configuring Dial Plans</a> on page 798.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The tag must belong to the Dial Plan that is assigned for Tel-to-IP routing. To do this, use the 'Tel-to-IP Dial Plan Name' (Tel2IPDialPlanName) parameter.</li> <li>■ The device uses the tag before or after manipulation, depending on the 'Tel-to-IP Routing Mode' (RouteModeTel2IP) parameter. If configured to <b>Route calls before manipulation</b>, the tag is used before manipulation. If configured to <b>Route calls after manipulation</b>, the tag is used after manipulation.</li> </ul>
'Destination Phone Pattern' dst-phone-pattern [DestinationPrefix]	<p>Defines the called (destination) telephone number.</p> <p>You can use special patterns (notations) to denote the number. For example, if you want to match this rule to user parts whose last four digits (i.e., suffix) are 4 followed by any three digits (e.g., 4008), then configure this parameter to "(4xxx)". As another example, the pattern "[100-199](100,101,105)" denotes a number that starts with 100 to 199 and ends with 100, 101 or 105. To denote any number, use the asterisk (*) symbol (default). To denote calls without a called number, use the dollar (\$) sign. For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The number can include up to 50 digits.</p>

Parameter	Description
	<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For LDAP-based routing, enter the LDAP query keyword as the prefix number to denote the IP domain: <ul style="list-style-type: none"> <li>✓ "PRIVATE" = Private number</li> <li>✓ "OCS" = Skype for Business / OCS client number</li> <li>✓ "PBX" = PBX / IP PBX number</li> <li>✓ "MOBILE" = Mobile number</li> <li>✓ "LDAP_ERR" = LDAP query failure</li> </ul> </li> </ul> <p>For more information, see <a href="#">Routing for Microsoft Teams or Skype for Business using Microsoft Entra ID</a> on page 397.</p> <ul style="list-style-type: none"> <li>■ If you want to configure re-routing of ISDN Tel-to-IP calls to fax destinations, enter the value string "FAX" (case-sensitive) as the destination phone prefix. For more information, see the [FaxReroutingMode] parameter.</li> </ul>
'Destination Tags' dest-tags [DestTags]	<p>Assigns a Dial Plan tag to denote a group of users by called (destination) number prefixes and/or suffixes.</p> <p>The valid value is a string of up to 70 characters. The tag is case insensitive.</p> <p>To configure Dial Plan tags, see <a href="#">Configuring Dial Plans</a> on page 798.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The tag must belong to the Dial Plan that is assigned for IP-to-Tel routing. To do this, use the 'Tel-to-IP Dial Plan Name' (Tel2IPDialPlanName) parameter.</li> <li>■ The device uses the tag before or after manipulation, depending on the 'Tel-to-IP Routing Mode' (RouteModeTel2IP) parameter. If configured to <b>Route calls before manipulation</b>, the tag is used before manipulation. If configured to <b>Route calls after manipulation</b>, the tag is used after manipulation.</li> </ul>
Action	
'Destination IP Group'	Assigns an IP Group to where you want to route the call.

Parameter	Description
dst-ip-group-id [DestIPGroupName]	<p>The SIP INVITE message is sent to the IP address configured for the Proxy Set that is associated with the IP Group.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you select an IP Group, you do not need to configure a destination IP address. However, if both parameters are configured in the table, the INVITE message is sent only to the IP Group.</li> <li>■ If the destination is a User-type IP Group, the device searches for a match of the Request-URI in the received INVITE to an AOR registration record in the device's database. The INVITE is then sent to the IP address of the registered contact.</li> <li>■ If the AlwaysUseRouteTable parameter is set to 1 (see <a href="#">Configuring IP Groups</a> on page 581), the Request-URI host name in the INVITE message is set to the value configured for the 'Destination IP Address' parameter (in this table); otherwise, if no IP address is defined, it is set to the value of the 'SIP Group Name' parameter (configured in the IP Groups table).</li> <li>■ The parameter is used as the 'Serving IP Group' in the Accounts table for acquiring authentication username/password for this call (see <a href="#">Configuring Registration Accounts</a> on page 750).</li> <li>■ To configure Proxy Sets, see <a href="#">Configuring Proxy Sets</a> on page 622.</li> </ul>
'SIP Interface' dest-sip-interface-name [DestSIPInterfaceName]	<p>Assigns a SIP Interface to the routing rule. The call is sent to its' destination through this SIP interface.</p> <p>To configure SIP Interfaces, see <a href="#">Configuring SIP Interfaces</a> on page 561.</p> <p><b>Note:</b> If a SIP Interface is not assigned, the device uses the SIP Interface associated with the default SRD (Index 0). If, for whatever reason, you have deleted the default SRD and there are no SRDs, the call is rejected.</p>
'Destination IP Address' dst-ip-address [DestAddress]	<p>Defines the IP address (in dotted-decimal notation or FQDN) to where the call is sent. If an FQDN is used (e.g., domain.com), DNS resolution is done according to the DNSQueryType parameter.</p>

Parameter	Description
	<p>For ENUM-based routing, enter the string "ENUM". The device sends an ENUM query containing the destination phone number to an external DNS server (configured in the IP Interfaces table). The ENUM reply includes a SIP URI which is used as the Request-URI in the subsequent outgoing INVITE and for routing (if a proxy is not used). To configure the type of ENUM service (e.g., e164.arpa), see the [EnumService] parameter.</p> <p>For LDAP-based routing, enter the string "LDAP" to denote the IP address of the LDAP server. For more information, see <a href="#">Routing for Microsoft Teams or Skype for Business using Microsoft Entra ID</a> on page 397.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is ignored if you have configured a destination IP Group in the 'Destination IP Group' field (in this table).</li> <li>■ To reject calls, enter the IP address 0.0.0.0. For example, if you want to prohibit international calls, then in the 'Destination Phone Prefix' field, enter 00 and in the 'Destination IP Address' field, enter 0.0.0.0.</li> <li>■ For routing calls between phones connected to the device (i.e., local routing), enter the device's IP address. If the device's IP address is unknown (e.g., when DHCP is used), enter IP address 127.0.0.1.</li> <li>■ When using domain names, enter the DNS server's IP address or alternatively, configure these names in the Internal DNS table (see <a href="#">Configuring the Internal DNS Table</a> on page 197).</li> </ul>
'IP Profile' ip-profile-id [ProfileName]	<p>Assigns an IP Profile to the routing rule in the outgoing direction. The IP Profile allows you to assign various configuration attributes (e.g., voice coder) per routing rule. To configure IP Profiles, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p>If you do not configure the parameter, the device uses the following IP Profile:</p> <ul style="list-style-type: none"> <li>■ If an IP Group is configured for the destination ('Destination IP Group' parameter), the device uses the IP Profile associated with the IP Group.</li> <li>■ If no IP Group is configured, the device uses IP Profile 0</li> </ul>

Parameter	Description
'Destination Port' dst-port [DestPort]	Defines the destination port to where you want to route the call.
'Transport Type' transport-type [TransportType]	<p>Defines the transport layer type used for routing the call.</p> <ul style="list-style-type: none"> <li>■ [-1] = (Default) Not configured and the transport type is according to the settings of the global parameter, SIPTransportType.</li> <li>■ [0] UDP</li> <li>■ [1] TCP</li> <li>■ [2] TLS</li> </ul>
Advanced	
'Call Setup Rules Set ID' call-setup-rules-set-id [CallSetupRulesSetId]	<p>Assigns a Call Setup Rule Set ID to the routing rule. The device performs the Call Setup rules of this Set ID if the incoming call matches the characteristics of the routing rule. The device routes the call to the destination according to the routing rule's configured action only after it has performed the Call Setup rules.</p> <p>By default, no value is defined.</p> <p>To configure Call Setup rules, see <a href="#">Configuring Call Setup Rules</a> on page 782.</p>
'Forking Group' forking-group [ForkingGroup]	<p>Defines a Forking Group number for the routing rule. This enables forking of incoming Tel calls to multiple IP destinations. The device sends simultaneous INVITE messages and handles multiple SIP dialogs until one of the calls is answered. When one of the calls is answered, the other calls are dropped.</p> <p>Each Forking Group can contain up to 10 members. In other words, up to 10 routing rules can be configured with the same Forking Group number.</p> <p>By default, no value is defined.</p> <p>If all matched routing rules belong to the same Forking Group number, the device sends an INVITE to all the destinations belonging to this group. If matched routing rules belong to different Forking Groups, the device sends the call to the Forking Group of the first matched routing rule. If the call cannot be established with any of the destinations associated with the Forking Group and</p>

Parameter	Description
	<p>alternative routing is enabled, the device forks the call to the Forking Group of the next matched routing rules, as long as the Forking Group is defined with a <b>higher</b> number than the previous Forking Group. For example:</p> <ul style="list-style-type: none"> <li>■ Table index entries 1 and 2 are defined with Forking Group "1", and index entries 3 and 4 with Forking Group "2": The device first sends the call according to index entries 1 and 2, and if unavailable and alternative routing is enabled, sends the call according to index entries 3 and 4.</li> <li>■ Table index entry 1 is defined with Forking Group "2", and index entries 2, 3, and 4 with Forking Group "1": The device sends the call according to index entry 1 only and ignores the other index entries even if the destination is unavailable and alternative routing is enabled. This is because the subsequent index entries are defined with a Forking Group number that is lower than that of index entry 1.</li> <li>■ Table index entry 1 is defined with Forking Group "1", index entry 2 with Forking Group "2", and index entries 3 and 4 with Forking Group "1": The device first sends the call according to index entries 1, 3, and 4 (all belonging to Forking Group "1"), and if the destination is unavailable and alternative routing is enabled, the device sends the call according to index entry 2.</li> <li>■ Table index entry 1 is defined with Forking Group "1", index entry 2 with Forking Group "3", index entry 3 with Forking Group "2", and index entry 4 with Forking Group "1": The device first sends the call according to index entries 1 and 4 (all belonging to Forking Group "1"), and if the destination is unavailable and alternative routing is enabled, the device sends the call according to index entry 2 (Forking Group "3"). Even if index entry 2 is unavailable and alternative routing is enabled, the device ignores index entry 3 because it belongs to a Forking Group that is lower than index entry 2.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For Tel-to-IP call forking, enable the 'Tel-to-IP Call Forking Mode' (<i>Tel2IPCallForkingMode</i>) parameter.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ You can configure the device to immediately send the INVITE message to the first member of the Forking Group (as in normal operation) and then only after a user-defined interval, send the INVITE messages simultaneously to the other members. If the device receives a SIP 4xx or 5xx in response to the first INVITE, it immediately sends INVITEs to all the other members, regardless of the interval. To configure this feature, see the ForkingDelayTimeForInvite ini file parameter.</li> <li>■ You can implement Forking Groups when the destination is an LDAP server or a domain name using DNS. In such scenarios, the INVITE is sent to all the queried LDAP or resolved IP addresses, respectively. You can also use LDAP routing rules with standard routing rules for Forking Groups.</li> <li>■ When the UseDifferentRTPportAfterHold parameter is enabled, every forked call is sent with a different RTP port. Thus, ensure that the device has sufficient available RTP ports for these forked calls.</li> </ul>
'Cost Group' cost-group-id [CostGroup]	<p>Assigns a Cost Group to the routing rule for determining the cost of the call (i.e., Least Cost Routing or LCR). By default, no value is defined.</p> <p>To configure Cost Groups, see <a href="#">Configuring Cost Groups</a> on page 455.</p> <p><b>Note:</b> To implement LCR and its Cost Groups, you must enable LCR</p> <ul style="list-style-type: none"> <li>■ To implement LCR and its Cost Groups, the Routing Policy must be enabled for LCR (see <a href="#">Configuring a Gateway Routing Policy Rule</a> on page 934). If LCR is disabled, the device ignores the parameter.</li> <li>■ The Routing Policy also determines whether matched routing rules that are <b>not</b> assigned Cost Groups are considered as a higher or lower cost route compared to matching routing rules that are assigned Cost Groups. For example, if the 'Default Call Cost' parameter in the Routing Policy is configured to <b>Lowest Cost</b>, even if the device locates matching routing rules that are assigned Cost Groups, the first-matched routing rule without an assigned Cost Group is considered as the lowest cost route and thus, chosen</li> </ul>

Parameter	Description
	as the preferred route.
'Charge Code' charge-code [MeteringCode]	<p>Assigns a Charge Code to the routing rule for generating metering pulses (Advice of Charge).</p> <p>By default, no value is defined.</p> <p>To configure Charge Codes, see <a href="#">Configuring Charge Codes</a> on page 1010.</p> <p><b>Note:</b> The parameter is applicable only to , Euro ISDN PRI, .</p>

## Configuring IP-to-Tel Routing Rules

The IP-to-Tel Routing table lets you configure up to 120 IP-to-Tel routing rules. IP-to-Tel routing rules route incoming IP calls to Trunk Groups. The specific channel pertaining to the Trunk Group to which the call is routed is determined according to the Trunk Group's channel selection mode. The channel selection mode can be configured per Trunk Group (see [Configuring Trunk Group Settings](#) on page 906) or for all Trunk Groups, using the global parameter ChannelSelectMode.

Configuration of IP-to-Tel routing rules includes two areas:

- **Match:** Defines the characteristics of the incoming IP call (e.g., source IP address from which the call is received).
- **Action:** Defines the action that is done if the incoming call matches the characteristics of the rule (i.e., routes the call to the specified Tel/Trunk Group destination).

The device searches the table from **top to bottom** for the **first** rule that matches the characteristics of the incoming call. If it finds a matching rule, it sends the call to the Tel destination configured for that rule. If it doesn't find a matching rule, it rejects the call.

If an IP-to-Tel call cannot be routed to the Trunk Group, the device can route it to an alternative destination:

- **Routing to an Alternative Trunk Group:** If the device sends the IP call to the Tel destination and a subsequent call release reason (cause) code (e.g., 17 for User Busy) is received from the Tel side, and you have configured this release reason code in the Reasons for IP-to-Tel Alternative Routing table, the device re-routes the call to an alternative Trunk Group if an alternative routing rule has been configured in the table. Alternative routing rules must be configured in table rows (indices) located anywhere below the "main" routing rule. For example, if you configure a "main" routing rule in Index 4, the alternative routing rule can be configured in Index 6. In addition, you must configure alternative routing rules with identical matching characteristics (e.g., destination prefix number) to the "main" routing rule, but assigned with different destinations (Trunk Groups). For more information on IP-to-Tel alternative routing and for configuring call release reasons for alternative routing, see [Alternative Routing to Trunk upon Q.931 Call Release Cause Code](#) on page 945.



- **Routing to an IP Destination (i.e., Call Redirection):** The device can re-route the IP-to-Tel call to an alternative IP destination, using SIP 3xx responses. For more information, see [Alternative Routing to an IP Destination upon a Busy Trunk](#) on page 947.
- **Routing to an Alternative Physical Trunk within Same Trunk Group:** The device can re-route an IP-to-Tel call to a different physical trunk if the destined trunk within the same Trunk Group is out of service (e.g., physically disconnected). When the physical trunk is disconnected, the device sends the SNMP trap, GWAPP\_TRAP\_BUSYOUT\_LINK notifying of the out-of-service state for the specific trunk number. When the physical trunk is physically reconnected, this trap is sent notifying of the back-to-service state.



- Instead of using the table for IP-to-Tel routing, you use ARM to handle the routing decisions. For more on routing by ARM, see [Centralized Routing by ARM \(AudioCodes Routing Manager\)](#) on page 442.
- You can configure up to three alternative routing rules per "main" routing rule in the table.
- If your deployment includes calls of many different called (source) and/or calling (destination) numbers that need to be routed to the same destination, you can employ user-defined prefix tags to represent these numbers. Thus, instead of configuring many routing rules, you need to configure only one routing rule using the prefix tag as the source and destination number matching characteristics, and a destination for the calls. For more information on prefix tags, see [Configuring IP-to-Tel Routing Rules](#).
- By default, the device applies destination telephone number manipulation (if configured) only after processing the routing rule. You can change this and apply number manipulation before processing the routing rule (see the [RouteModelP2Tel] parameter). To configure number manipulation, see [Configuring Source-Destination Number Manipulation Rules](#) on page 950.

The following procedure describes how to configure IP-to-Tel routing rules through the Web interface. You can also configure it through ini file [PSTNPrefix] or CLI (`configure voip > gateway routing ip2tel-routing`).

#### ➤ To configure IP-to-Tel routing rules:

1. Open the IP-to-Tel Routing table (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Routing** > **IP** > **Tel Routing**).
2. Click **New**; the following dialog box appears:

The screenshot shows the 'IP-to-Tel Routing' configuration window. It is divided into two panes: 'GENERAL' and 'ACTION'.  
**GENERAL Pane:**  
 - **Index:** 1  
 - **Name:** (empty field)  
 - **MATCH Section:**  
 - **Source SIP Interface:** Any (dropdown menu with a 'View' link)  
 - **Source IP Address:** \* (text field)  
 - **Source Phone Pattern:** \* (text field)  
 - **Source Host Pattern:** \* (text field)  
 - **Source Tag:** (text field)  
 - **Destination Phone Pattern:** \* (text field)  
 - **Destination Host Pattern:** \* (text field)  
 - **Destination Tag:** (text field)  
**ACTION Pane:**  
 - **Destination Type:** Trunk Group (dropdown menu)  
 - **Trunk Group ID:** 0 (text field)  
 - **Source IP Group:** -- (dropdown menu with a 'View' link)  
 - **IP Profile:** -- (dropdown menu with a 'View' link)  
 - **Trunk ID:** -1 (text field)  
 - **Call Setup Rules Set ID:** -1 (text field)

3. Configure a routing rule according to the parameters described in the table below.
4. Click **Apply**.

The following table shows configuration examples of Tel-to-IP routing rules:

**Table 25-3: Example of IP-to-Tel Routing Rules**

Parameter	Rule 1	Rule 2	Rule 3
'Source Host Pattern'	-	-	abcd.domain
'Destination Phone Pattern'	1x	[501-502]	-
'Source Phone Pattern'	-	101	-
'Trunk Group ID'	3	2	4
'IP Profile'	ITSP-A	ITSP-B	-

Below provides descriptions of each rule:

- **Rule 1:** If the incoming IP call destination phone prefix is between 10 and 19, the call is assigned settings configured for IP Profile "ITSP-A" and routed to Trunk Group ID 3.
- **Rule 2:** If the incoming IP call destination phone prefix is between 501 and 502 and source phone prefix is 101, the call is assigned settings configured for IP Profile "ITSP-B" and routed to Trunk Group ID 2.
- **Rule 3:** If the incoming IP call has a From URI host prefix as abcd.com, the call is routed to Trunk Group ID 4.

**Table 25-4: IP-to-Tel Routing Table Parameter Description**

Parameter	Description
General	
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' route-name [RouteName]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 40 characters. By default, no value is defined. <b>Note:</b> <ul style="list-style-type: none"> <li>■ Configure each row with a unique name.</li> <li>■ The name can't be configured with the character string "any" (upper or lower case).</li> </ul>

Parameter	Description
Match	
'Source SIP Interface' src-sip- interface-name [SrcSIPInterfaceName]	<p>Defines the SIP Interface on which the incoming IP call is received.</p> <p>The default is Any (i.e., any SIP Interface).</p> <p>To configure SIP Interfaces, see <a href="#">Configuring SIP Interfaces</a> on page 561.</p> <p><b>Note:</b> If the incoming INVITE is received on the specified SIP Interface and the SIP Interface associated with the specified IP Group in the 'Source IP Group' parameter (in this table) is different, the incoming SIP call is rejected. If the 'Source IP Group' parameter is not defined, the SIP Interface associated with the default SRD (Index 0) is used. If there is no valid source IP Group, the call is rejected.</p>
'Source IP Address' src-ip-address [SourceAddress]	<p>Defines the source IP address of the incoming IP call.</p> <p>The IP address must be configured in dotted-decimal notation (e.g., 10.8.8.5); not as an FQDN. The default is the asterisk (*) symbol, meaning any IP address.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The source IP address is obtained from the Contact header in the INVITE message.</li> <li>■ You can configure from where the source IP address is obtained, using the SourceIPAddressInput parameter.</li> <li>■ The source IP address can include the following wildcards:               <ul style="list-style-type: none"> <li>✓ "x": denotes single digits. For example, 10.8.8.xx represents all the addresses between 10.8.8.10 and 10.8.8.99.</li> <li>✓ "*": denotes any number between 0 and 255. For example, 10.8.8.* represents all addresses between 10.8.8.0 and 10.8.8.255.</li> </ul> </li> </ul>
'Source Phone Pattern' src-phone-pattern  [SourcePrefix]	<p>Defines the calling (source) telephone number.</p> <p>The valid value can be up to 49 digits. You can use special patterns to denote the number. For example, "[100-199] (100,101,105)" denotes a number that starts with 100 to 199 and ends with 100, 101 or 105. To denote any number, use the asterisk (*) symbol (default). To denote calls without a calling number, use the dollar (\$) sign. For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on</p>

Parameter	Description
	<p>page 1559.</p> <p><b>Note:</b> If the SIP P-Asserted-Identity header is present in the incoming INVITE message, the value of the parameter is compared to the URI user part in the P-Asserted-Identity header (not the From header).</p>
'Source Host Pattern' src-host-pattern [SrcHostPrefix]	<p>Defines the URI host part in the From header of the incoming INVITE message.</p> <p>You can use special patterns (notations) to denote the host part. For example, if you want to match this rule to host parts that end (suffix) in ".com", then configure this parameter to "(.com)". To denote any host part, use the asterisk (*) symbol. For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>By default, no value is defined.</p> <p><b>Note:</b> If the P-Asserted-Identity header is present in the incoming INVITE message, the value of the parameter is compared to the P-Asserted-Identity URI host name (and not the From header).</p>
'Source Tags' src-tags [SrcTags]	<p>Assigns a Dial Plan tag to denote a group of source URI user names.</p> <p>The valid value is a string of up to 70 characters. The tag is case insensitive.</p> <p>To configure Dial Plan tags, see <a href="#">Configuring Dial Plans</a> on page 798.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The tag must belong to the Dial Plan that is assigned for IP-to-Tel routing. To do this, use the 'IP-to-Tel Dial Plan Name' (IP2TelDialPlanName) parameter.</li> <li>■ The device uses the tag before or after manipulation, depending on the 'IP-to-Tel Routing Mode' (RouteModelIP2Tel) parameter. If configured to <b>Route calls before manipulation</b>, the tag is used before manipulation. If configured to <b>Route calls after manipulation</b>, the tag is used after manipulation.</li> </ul>
'Destination Phone Pattern' dst-host-pattern [DestPrefix]	<p>Defines the called (destined) telephone number.</p> <p>You can use special patterns (notations) to denote the number. For example, "[100-199](100,101,105)" denotes a number that starts with 100 to 199 and ends with 100, 101 or</p>

Parameter	Description
	<p>105. To denote any prefix, use the asterisk (*) symbol (default). To denote calls without a called number, use the dollar (\$) sign. For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The value can include up to 49 digits.</p>
'Destination Host Pattern' <code>dst-phone-pattern</code> [DestHostPrefix]	<p>Defines the Request-URI host name of the incoming INVITE message.</p> <p>You can use special patterns (notations) to denote the host part. For example, if you want to match this rule to host parts that end (suffix) in ".com", then configure this parameter to "(.com)". To denote any host part, use the asterisk (*) symbol. For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>By default, no value is defined.</p>
'Destination Tags' <code>dest-tags</code> [DestTags]	<p>Assigns a prefix tag to denote destination URI user names corresponding to the tag configured in the associated Dial Plan.</p> <p>The valid value is a string of up to 70 characters. The tag is case insensitive.</p> <p>To configure Dial Plan tags, see <a href="#">Configuring Dial Plans</a> on page 798.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The tag must belong to the Dial Plan that is assigned for IP-to-Tel routing. To do this, use the 'IP-to-Tel Dial Plan Name' (IP2TelDialPlanName) parameter.</li> <li>■ The device uses the tag before or after manipulation, depending on the 'IP-to-Tel Routing Mode' (RouteModeIP2Tel) parameter. If configured to <b>Route calls before manipulation</b>, the tag is used before manipulation. If configured to <b>Route calls after manipulation</b>, the tag is used after manipulation.</li> </ul>
Action	
'Destination Type' <code>dst-type</code> [DestType]	<p>Defines the type of Tel destination.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Trunk Group</b> (default)</li> <li>■ [1] <b>Trunk</b></li> </ul>
'Trunk Group ID'	Defines the Trunk Group ID to where the incoming SIP call is

Parameter	Description
trunk-group-id [TrunkGroupId]	sent. <b>Note:</b> This parameter is applicable only if you configure the 'Destination Type' parameter (see above) to <b>Trunk Group</b> .
'Trunk ID' trunk-id [TrunkId]	Defines the Trunk to where the incoming SIP call is sent. <b>Note:</b> <ul style="list-style-type: none"> <li>■ If both 'Trunk Group ID' and 'Trunk ID' parameters are configured in the table, the routing is done according to the 'Trunk Group ID' parameter.</li> <li>■ To configure the method for selecting the trunk's channel to which the IP call is sent, see the global parameter, ChannelSelectMode.</li> </ul>
'Source IP Group' src-ip-group-id [SrcIPGroupName]	Assigns an IP Group from where the SIP message (INVITE) is received. By default, no value is defined. To configure IP Groups, see <a href="#">Configuring IP Groups</a> on page 581. The IP Group can be used as the 'Serving IP Group' in the Accounts table for obtaining authentication username/password for the call. To configure registration accounts, see <a href="#">Configuring Registration Accounts</a> on page 750.
'IP Profile' ip-profile-id [ProfileName]	Assigns an IP Profile to the call. To configure IP Profiles, see <a href="#">Configuring IP Profiles</a> on page 664.
'Call Setup Rules Set' ID call-setup-rules-set-id [CallSetupRulesSetId]	Assigns a Call Setup Rule Set ID to the routing rule. The device performs the Call Setup rules of this Set ID if the incoming call matches the characteristics of the routing rule. The device routes the call to the destination according to the routing rule's configured action, only after it has performed the Call Setup rules. To configure Call Setup rules, see <a href="#">Configuring Call Setup Rules</a> on page 782.

## Configuring a Gateway Routing Policy Rule

The Routing Policies table lets you edit the default Routing Policy rule. The Routing Policy is used for Gateway call routing and defines the following:

- LDAP server (LDAP Server Group) for LDAP-based call routing (LDAP or Call Setup Rules queries). LDAP-based routing is applicable to Tel-to-IP routing ([Configuring Tel-to-IP Routing Rules](#) on page 914) and IP-to-Tel routing ([Configuring IP-to-Tel Routing Rules](#) on page 928).
- Enables Least Cost Routing (LCR), and defines default call cost (highest or lowest) and average call duration for Tel-to-IP routing rules that are not assigned LCR Cost Groups. The default call cost determines whether matched routing rules that are not assigned a Cost Group are considered as a higher or lower cost route compared to other matching routing rules that are assigned Cost Groups. If you disable LCR, the device ignores the Cost Groups assigned to Tel-to-IP routing rules in the Tel-to-IP Routing table. LCR is applicable only to Tel-to-IP routing.

The following procedure describes how to configure Routing Policy rules through the Web interface. You can also configure it through ini file [GwRoutingPolicy] or CLI (`configure voip > gateway routing gw-routing-policy`).

➤ **To edit the Routing Policy rule:**

1. Open the Routing Policies table (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Routing** > **Routing Policies**).
2. Click **New**; the following dialog box appears:

**Routing Policies [GwRoutingPolicy]**

**GENERAL**

Index: 0

Name: GwRoutingPolicy

LDAP Servers Group Name: -- [View](#)

LCR Feature: Disable

Default Call Cost: Lowest Cost

LCR Call Duration [min]: 1

3. Configure the Routing Policy rule according to the parameters described in the table below.
4. Click **Apply**.

**Table 25-5: Routing Policies Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	(Read-only) Displays the index number of the table row.

Parameter	Description
'Name' name [Name]	<p>Defines a descriptive name, which is used when associating the row in other tables.</p> <p>The valid value is a string of up to 40 characters. The default value is "GwRoutingPolicy".</p>
'LDAP Servers Group Name' ldap-srv-group-name [LdapServersGroupName]	<p>Assigns an LDAP Server Group to the Routing Policy. IP-to-Tel and Tel-to-IP routing rules that require LDAP-based routing (or Call Setup Rules) use the LDAP server(s) assigned to the LDAP Server Group.</p> <p>By default, no value is defined.</p> <p>For more information on LDAP Server Groups, see <a href="#">Configuring LDAP Server Groups</a> on page 373.</p>
'LCR Feature' lcr-enable [LCREnable]	<p>Enables the Least Cost Routing (LCR) feature for the Routing Policy.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p>For more information on LCR, see <a href="#">Least Cost Routing</a> on page 452.</p> <p><b>Note:</b> LCR is applicable only to Tel-to-IP routing.</p>
'Default Call Cost' lcr-default-cost [LCRDefaultCost]	<p>Defines whether routing rules in the Tel-to-IP Routing table that are not assigned a Cost Group are considered a higher cost or lower cost route compared to other matched routing rules that are assigned Cost Groups.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Lowest Cost</b> = (Default) The device considers a matched routing rule that is not assigned a Cost Group as the lowest cost route. Therefore, it uses the routing rule.</li> <li>■ [1] <b>Highest Cost</b> = The device considers a matched routing rule that is not assigned a Cost Group as the highest cost route. Therefore, it is only used if the other matched routing rules that are assigned Cost Groups are unavailable.</li> </ul>
'LCR Call Duration' lcr-call-length [LCRAverageCallLength]	<p>Defines the average call duration (in minutes) and is used to calculate the variable portion of the call cost. This is useful, for example, when the average call duration spans over multiple time bands. The LCR is calculated as follows:</p> $\text{cost} = \text{call connect cost} + (\text{minute cost} * \text{average call duration})$



Parameter	Description
	<p>The valid value is 0-65533. The default is 1.</p> <p>For example, assume the following Cost Groups:</p> <ul style="list-style-type: none"> <li>■ "Weekend A": call connection cost is 1 and charge per minute is 6. Therefore, a call of 1 minute cost 7 units.</li> <li>■ "Weekend B": call connection cost is 6 and charge per minute is 1. Therefore, a call of 1 minute cost 7 units.</li> </ul> <p>Therefore, for calls under one minute, "Weekend A" carries the lower cost. However, if the average call duration is more than one minute, "Weekend B" carries the lower cost.</p>

## Alternative Routing for Tel-to-IP Calls

The device supports various alternative Tel-to-IP call routing methods, as described in this section.

### IP Destinations Connectivity Feature

The device can be configured to check the integrity of the connectivity to IP destinations of Tel-to-IP routing rules in the Tel-to-IP Routing table. The IP Connectivity feature can be used for the Alternative Routing feature, whereby the device attempts to re-route calls from unavailable Tel-to-IP routing destinations to available ones (see [Alternative Tel-to-IP Routing Based on IP Connectivity](#) on the next page).

The device supports the following methods for checking the connectivity of IP destinations:

- **Network Connectivity:** The device checks the network connectivity by sending "keep-alive" SIP OPTIONS messages to the IP destination. If the device receives a SIP 200 OK in response (or any response, even an error response), it considers the destination available. If the destination doesn't respond to the OPTIONS message, it considers the destination unavailable. You can configure the time interval for sending these OPTIONS messages, using the 'Tel-to-IP Alt Routing Keep-Alive Time' parameter on the Routing Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Routing** > **Routing Settings**):

Tel-to-IP Alt Routing Keep-Alive Time

60

- **Quality of Service (QoS):** You can enable the device to check the QoS of IP destinations. The device measures the QoS according to RTCP statistics of previously established calls with the IP destination. The RTCP includes packet delay (in milliseconds) and packet loss (in percentage). If these measured statistics exceed a user-defined threshold, the destination is considered unavailable. Note that if call statistics is not received within two minutes, the QoS data is reset. These thresholds are configured using the following parameters:

- 'Max Allowed Packet Loss for Alt Routing' (IPConnQoSMaxAllowedPL): defines the threshold value for packet loss after which the IP destination is considered unavailable.
- 'Max Allowed Delay for Alt Routing' (IPConnQoSMaxAllowedDelay): defines the threshold value for packet delay after which the IP destination is considered unavailable

These parameters are configured in the Routing Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Routing** > **Routing Settings**), as shown below:

Max Allowed Packet Loss for Alt Routing [%]	<input type="text" value="20"/>
Max Allowed Delay for Alt Routing [msec]	<input type="text" value="250"/>

- **DNS Resolution:** When a host name (FQDN) is used (instead of an IP address) for the IP destination, it is resolved into an IP address by a DNS server. The device checks network connectivity and QoS of the resolved IP address. If the DNS host name is unresolved, the device considers the connectivity of the IP destination as unavailable.

You can view the connectivity status of IP destinations in the following Web interface pages:

- **Tel-to-IP Routing table:** The connectivity status of the IP destination per routing rule is displayed in the 'Status' column. For more information, see [Configuring Tel-to-IP Routing Rules](#) on page 914.
- **IP Connectivity:** This page displays a more informative connectivity status of the IP destinations used in Tel-to-IP routing rules in the Tel-to-IP Routing table. For viewing this page, see [Viewing IP Connectivity](#) on page 1360.

## Alternative Tel-to-IP Routing Based on IP Connectivity

You can configure the device to route Tel-to-IP calls to an alternative IP destination when the connectivity state of an IP destination is unavailable. The alternative routing rules are configured in the Tel-to-IP Routing table. These rules must be configured anywhere below the "main" routing rule and with identical matching characteristics (e.g., destination prefix number) to the "main" routing rule. The device uses the first alternative route that is available. For more information on configuring alternative Tel-to-IP routing rules in the Tel-to-IP Routing table, see [Configuring Tel-to-IP Routing Rules](#) on page 914.



- Alternative routing based on IP connectivity is applicable only when a proxy server is **not** used.
- You can also enable the Busy Out feature, whereby the device can take specified actions if all IP destinations of matching routing rules in the Tel-to-IP Routing table do not respond to connectivity checks. For more information, see the [EnableBusyOut] parameter.
- If you enable the [AltRoutingTel2IPEnable] parameter, the Busy Out feature doesn't function with the Proxy Set keep-alive mechanism (see [Alternative Tel-to-IP Routing Based on SIP Responses](#) on page 940). To use the Busy Out feature with the Proxy Set keep-alive mechanism (for IP Groups), disable the [AltRoutingTel2IPEnable] parameter.

The device searches for an alternative routing rule (IP destination) when any of the following connectivity states are detected with the IP destination of the "main" routing rule:

- No response received from SIP OPTIONS messages.
- Poor QoS according to the configured thresholds for packet loss and delay.
- No response from a DNS-resolved IP address, where the domain name (FQDN) is configured for the IP destination. If the device sends the INVITE message to the first IP address and receives no response, the device makes a user-defined number of attempts (configured by the [HotSwapRtx] parameter) to send it again (re-transmit). If there is still no response after all the attempts, it sends it to the next DNS-resolved IP address, and so on. For example, if you configure the parameter to "3" (without quotation marks) and the device receives no response from the first IP address, it attempts up to three times to send the INVITE to the first IP address and if unsuccessful, it attempts to send the call to the next DNS-resolved IP address, and so on.
- No response for in-dialog request from a DNS-resolved IP address, where the domain name is received in the Contact header of an incoming setup or target refresh SIP message (e.g., 200 OK). If no response is received from the first IP address, the device tries to send it again for up to a user-defined number of attempts (configured by the [HotSwapRtx] parameter). If there is still no response, it attempts to send the SIP request to the next DNS-resolved IP address, and so on.

The connectivity status of the IP destination is displayed in the 'Status' column of the Tel-to-IP Routing table per routing rule. If it displays a status other than "ok", the device considers the IP destination as unavailable and attempts to re-route the call to an alternative destination. For more information on the IP connectivity methods and viewing IP connectivity status, see [IP Destinations Connectivity Feature](#) on page 937.

The table below shows an example of alternative routing where the device uses an available alternative routing rule in the Tel-to-IP Routing table to re-route the initial Tel-to-IP call.

**Table 25-6: Alternative Routing based on IP Connectivity Example**

	Destination Phone Prefix	IP Destination	IP Connectivity Status	Rule Used?
<b>Main Route</b>	40	10.33.45.68	"No Connectivity"	No
<b>Alternative Route #1</b>	40	10.33.45.70	"QoS Low"	No
<b>Alternative Route #2</b>	40	10.33.45.72	"ok"	Yes

The following procedure describes how to configure alternative Tel-to-IP routing based on IP connectivity.

➤ **To configure alternative Tel-to-IP routing based on IP connectivity:**

1. In the Tel-to-IP Routing table (see [Configuring Tel-to-IP Routing Rules](#) on page 914), add alternative Tel-to-IP routing rules for specific calls.
2. Open the Routing Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Routing** > **Routing Settings**):

Enable Tel-to-IP Alt Routing	• <span>Enable</span> ▼
Tel-to-IP Alt Routing Mode	• <span>Connectivity</span> ▼
Tel-to-IP Alt Routing Keep-Alive Time	<span>60</span>

3. Under the Alternative Route group, do the following:
  - a. From the 'Enable Tel-to-IP Alt Routing' [AltRoutingTel2IPEnable] drop-down list, select **Enable** to enable alternative Tel-to-IP routing based on IP connectivity.
  - b. From the 'Tel-to-IP Alt Routing Mode' drop-down list [AltRoutingTel2IPMode], configure the IP connectivity reason for triggering alternative routing.
    - ◆ **Connectivity:** Alternative routing is performed if SIP OPTIONS message to the initial destination fails
    - ◆ **QoS:** Alternative routing is performed if poor QoS is detected. QoS is quantified according to delay and packet loss calculated according to previous calls.
    - ◆ **Both** (above)
  - c. Enable the connectivity feature (see [IP Destinations Connectivity Feature](#) on page 937).

## Alternative Tel-to-IP Routing Based on SIP Responses

The device can do alternative routing based on the received SIP response code (i.e., 4xx, 5xx, 6xx, or 8xx). If the received SIP response code is also configured in the Reasons for Tel-to-IP Alternative Routing table, the device attempts to re-route the call to an alternative destination (if configured). You can configure up to 10 SIP response codes in the Reasons for Tel-to-IP Alternative Routing table.

Typically, the device does alternative routing when there is no response to an INVITE message. This is done after a user-defined number of INVITE re-transmissions, configured by the [SIPMaxRtx] parameter. In such a scenario, the device issues itself the SIP response code 408 (Request Timeout). You can also configure the device to do alternative routing for the following proprietary response codes that are issued by the device itself:

- **805 IP Profile Call Limit:** The device generates this response code when Call Admission Control (CAC) limits are exceeded for an IP Group. The CAC rules are configured in the IP Profiles table (see [Configuring IP Profiles](#) on page 664). When this occurs, the device sends a SIP 480 (Temporarily Unavailable) response to the SIP user agent (UA).

- **806 Media Limits Exceeded:** The device generates Release Cause Code 806 when the call is terminated due to crossed thresholds of QoE metrics such as MOS, packet delay, and packet loss (configured in the Quality of Experience Profile table - see [Configuring Quality of Experience Profiles](#) on page 519) and/or media bandwidth (configured in the Bandwidth profile table - see [Configuring Bandwidth Profiles](#) on page 526). When this occurs, the device sends a SIP 480 (Temporarily Unavailable) response to the SIP entity. When the threshold is crossed, the device maintains the existing call and applies alternative routing only to subsequent calls. To configure alternative routing based on Release Cause 806, do the following :

- a. Assign an IP Group with a QoE and/or Bandwidth profile that rejects calls if the threshold is crossed.
- b. Configure Release Cause Code 806 in the Reasons for Tel-to-IP Alternative Routing table.
- c. Configure an alternative routing rule.

The device always routes at least two calls to the destination that has crossed the threshold, so that it can continue measuring QoE / bandwidth. When the threshold drops below the configured QoE / bandwidth threshold (i.e., good QoE), the device stops using the alternative routing rule and starts routing the calls using the initial routing rule.



- You can also enable the Busy Out feature, whereby the device can take specified actions if all Proxy Sets of associated destination IP Groups of matching routing rules in the Tel-to-IP Routing table do not respond to connectivity checks. For more information, see the [EnableBusyOut] parameter.
- If you enable the [AltRoutingTel2IPEnable] parameter for the IP Connectivity feature (see [Alternative Tel-to-IP Routing Based on IP Connectivity](#) on page 938), the Busy Out feature doesn't function with the Proxy Set keep-alive mechanism (see below). To use the Busy Out feature with the Proxy Set keep-alive mechanism (for IP Groups), disable the [AltRoutingTel2IPEnable] parameter.

Depending on configuration, alternative routing uses one of the following configuration entities:

- **Tel-to-IP Routing Rules:** Alternative routing rules can be configured for a specific routing rule in the Tel-to-IP Routing table. If the destination of the "main" routing rule is unavailable, the device searches the table for the next matching rule (e.g., destination phone number), and if available attempts to re-route the call to the IP destination configured for this alternative routing rule. For more information on configuring alternative Tel-to-IP routing rules, see [Configuring Tel-to-IP Routing Rules](#) on page 914. The table below shows an example of alternative routing where the device uses the first available alternative routing rule to re-route the initial, unsuccessful Tel-to-IP call destination.

Table 25-7: Alternative Routing based on SIP Response Code Example

	Destination Phone Prefix	IP Destination	SIP Response	Rule Used?
Main Route	40	10.33.45.68	408 Request Timeout	No
Alternative Route #1	40	10.33.45.70	486 Busy Here	No
Alternative Route #2	40	10.33.45.72	200 OK	Yes

- **Proxy Sets:** Proxy Sets are used for Server-type IP Groups (e.g., an IP PBX or proxy), which define the address (IP address or FQDN) of the server. As you can configure multiple proxy servers per Proxy Set, the device supports proxy redundancy, which works together with the alternative routing feature. If the destination of a routing rule in the Tel-to-IP Routing table is a Server-type IP Group, the device routes the call to the IP destination configured for the Proxy Set associated with the IP Group. If the IP destination of the Proxy Set is offline, the device attempts to re-route the call to another online proxy destination with the highest priority. To enable the Proxy Redundancy feature for a Proxy Set, configure the 'Proxy Hot Swap Mode' parameter to **Enable** and the 'Proxy Keep-Alive' parameter to **Using OPTIONS**. For more information on proxy redundancy, see [Configuring Proxy Sets](#) on page 622.



The device assumes that all proxy servers belonging to a Proxy Set are synchronized with regards to registered users. Therefore, when the device locates an available proxy using the Hot Swap feature, it doesn't re-register the users; new registration (refresh) is done as normal.

The following procedure describes how to configure alternative Tel-to-IP routing based on SIP response codes through the Web. You can also configure it through ini file [AltRouteCauseTel2Ip] or CLI (`configure voip > gateway routing alt-route-cause-tel2ip`).

➤ **To configure alternative Tel-to-IP routing based on SIP response codes:**

1. Configure SIP response codes (call failure reasons) that invoke alternative Tel-to-IP routing:
  - a. Open the Reasons for Tel-to-IP Alternative Routing table (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Routing** > **Alternative Routing Reasons** > **Reasons for Tel > IP**).
  - b. Click **New**; the following dialog box appears:

- c. Configure a SIP response code for alternative routing according to the parameters described in the table below.
- d. Click **Apply**.

**Table 25-8: Reasons for Tel-to-IP Alternative Routing Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Release Cause' rel-cause [ReleaseCause]	Defines a SIP response code that if received, the device attempts to route the call to an alternative destination (if configured).

2. Enable alternative routing based on SIP responses:
  - a. Open the Routing Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Routing** > **Routing Settings**).
  - b. From the 'Redundant Routing Mode' drop-down list, select one of the following:
    - ◆ **Routing Table:** The device uses the Tel-to-IP Routing table for alternative routing.
    - ◆ **Proxy:** The device uses the Proxy Set redundancy feature for alternative routing.

Redundant Routing Mode Routing Table ▼

3. If you are using the Tel-to-IP Routing table, configure alternative routing rules with identical call matching characteristics, but different IP destinations. If you are using the Proxy Sets table, configure redundant proxies.

## Alternative Tel-to-IP Routing upon SIP 3xx with Multiple Contacts

You can configure how the device handles received SIP 3xx responses containing multiple alternative contacts. The 3xx response indicates that the original destination is unavailable (e.g., 301 "Moved Permanently – user cannot be found") and that the call can be redirected to alternative destinations specified in the SIP Contact headers.

You can configure the device to handle the receipt of 3xx responses in one of the following ways:

- The device tries each contact sequentially in the Contact headers, until a successful destination is found. If a contact responds with a SIP 486 or 600, the device doesn't redirect the call to the next contact, but instead rejects the call.
- The device tries each contact sequentially in the Contact headers. If a SIP 6xx Global Failure response is received (e.g., 600 Busy Everywhere), the device doesn't redirect the call to the next contact, but instead rejects the call.
- The device redirects the call to the first contact listed in the Contact header. If the contact responds with a SIP response that is configured in the Reasons for Tel-to-IP Alternative Routing table (see [Alternative Tel-to-IP Routing Based on SIP Responses](#) on page 940), the device tries to redirect the call to the next contact, and so on. If a contact responds with a response that is not configured in the table, the device doesn't try to redirect the call to the next contact, but instead rejects the call.

➤ **To configure handling of SIP 3xx response with multiple contacts:**

1. Open the Routing Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Routing** > **Routing Settings**).
2. From the '3xx Use Alt Route Reasons' drop-down list, select the required handling.

3xx Use Alt Route Reasons

No ▼

3. Click **Apply**.



If a SIP 401 or 407 response is received from a contact, the device doesn't try to redirect the call to the next contact. Instead, the device continues with regular authentication as indicated by these response types.

## PSTN Fallback

The PSTN Fallback feature enables the device to re-route a Tel-to-IP call to the legacy PSTN using one of its trunks if the IP destination is unavailable. For example, if poor voice quality is detected over the IP network, the device attempts to re-route the call to the PSTN.

The following procedure describes how to configure alternative Tel-to-IP routing to the PSTN.

➤ **To configure alternative Tel-to-IP routing to the PSTN:**

1. In the Tel-to-IP Routing table (see [Configuring Tel-to-IP Routing Rules](#) on page 914), configure an alternative routing rule with the same call matching characteristics (e.g., phone number destination) as the "main" routing rule, but where the destination is the IP address of the device itself.



2. In the IP-to-Tel Routing table (see [Configuring IP-to-Tel Routing Rules](#) on page 928), configure an IP-to-Tel routing rule to route calls received from the device (i.e., its IP address) to a specific Trunk Group connected to the PSTN. This configuration is necessary as the re-routed call is now considered an IP-to-Tel call.

## Alternative Routing for IP-to-Tel Calls

This section describes configuration for alternative IP-to-Tel call routing.

### Alternative Routing to Trunk upon Q.931 Call Release Cause Code

You can configure up to 10 ISDN Q.931 release cause codes. If the device receives a configured release cause code from the Tel side, it routes the IP-to-Tel call to an alternative Trunk Group, if configured.

Alternative IP-to-Tel routing rules are configured in the IP-to-Tel Routing table. These rules must be configured anywhere below the "main" routing rule and with identical matching characteristics (e.g., destination prefix number) to the "main" routing rule. The device uses the first alternative route that is available. For more information on configuring alternative IP-to-Tel routing rules in the IP-to-Tel Routing table, see [Configuring IP-to-Tel Routing Rules](#) on page 928.

A release cause code indicates that the IP-to-Tel call has been rejected or disconnected on the Tel side. The release cause codes are configured in the Reasons for IP-to-Tel Alternative Routing table. For example, you can configure alternative IP-to-Tel routing for scenarios where the initial Tel destination is busy and a Q.931 Cause Code No. 17 is received (or for other call releases that issue the default Cause Code No. 3).

You can configure a default release cause code that the device issues itself upon the following scenarios:

- The device initiates a call release whose cause is unknown.
- No free channels (i.e., busy) in the Trunk Group.
- No appropriate routing rule located in the IP-to-Tel Routing table.
- Phone number is not located in the IP-to-Tel Routing table.

The default release code is Cause Code No. 3 (No Route to Destination). You can change the default code as follows:

#### ➤ To change the default Q.931 release code:

1. Open the Gateway Advanced Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Gateway Advanced Settings**).
2. In the 'Default Release Cause' field, enter the release cause code:

Default Release Cause

3. Click **Apply**.



- If a Trunk is disconnected or not synchronized, the device issues itself the internal Cause Code No. 27. This cause code is mapped (by default) to SIP 502.
- The default release cause is described in the Q.931 notation and translated to corresponding SIP 40x or 50x values (e.g., Cause Code No. 3 to SIP 404, and Cause Code No. 34 to SIP 503).
- For mapping SIP-to-Q.931 and Q.931-to-SIP release causes, see [Configuring Release Cause Mapping](#) on page 975.

The following procedure describes how to configure alternative routing reasons for IP-to-Tel calls through the Web interface. You can also configure it through ini file [AltRouteCauseIP2Tel] or CLI (`configure voip > gateway routing alt-route-cause-ip2tel`).

➤ **To configure alternative Trunk Group routing based on Q.931 cause codes:**

1. Open the Routing Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Routing** > **Routing Settings**).
2. From the 'Redundant Routing Mode' drop-down list, select **Routing Table** so that the device uses the IP-to-Tel Routing table for alternative routing:

Redundant Routing Mode

Routing Table ▼

3. Open the IP-to-Tel Routing table, and then configure alternative routing rules with the same call matching characteristics as the "main" routing rule, but with different Trunk Group destinations.
4. Configure Q.931 cause codes that invoke alternative IP-to-Tel routing:
  - a. Open the Reasons for IP-to-Tel Alternative Routing table (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Routing** > **Alternative Routing Reasons** > **Reasons for IP > Tel**).
  - b. Click **New**; the following dialog box appears:

- c. Configure a Q.931 release cause code for alternative routing according to the parameters described in the table below.
- d. Click **Apply**.

**Table 25-9: Reasons for IP-to-Tel Alternative Routing Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Release Cause' rel-cause [ReleaseCause]	Defines a Q.931 release code that if received, the device attempts to route the call to an alternative destination (if configured).

## Alternative Routing to an IP Destination upon a Busy Trunk

The Forward on Busy Trunk Destination table lets you configure up to 100 alternative routing rules for forwarding (i.e., call redirection) IP-to-Tel calls to an alternative IP destination (instead of the Tel destination) using SIP 3xx responses. The alternative routing is triggered upon the following:

- Trunk Group has no free channels (i.e., “busy”).



The feature is not applicable to Trunk Groups whose 'Channel Select Mode' parameter is configured to **By Dest Phone Number**, **Dest Number & Cyclic Ascending**, or **By Dest Number & Ascending** in the Trunk Group Settings table (see [Configuring Trunk Group Settings](#) on page 906).

This feature is configured per Trunk Group. The alternative destination can be defined as a host name or as a SIP Request-URI user name and host part (i.e., user@host). For example, the below configuration forwards IP-to-Tel calls to destination user “112” at host IP address 10.13.4.12, port 5060, using transport protocol TCP, if Trunk Group ID 2 is unavailable:

```
ForwardOnBusyTrunkDest 1 = 2, 112@10.13.4.12:5060;transport=tcp;
```

When configured with user@host, the original destination number is replaced by the user part.

The device forwards calls using this table **only** if no alternative IP-to-Tel routing rule has been configured in the IP-to-Tel Routing table or alternative routing fails and the following reason(s) in the SIP Diversion header of 3xx messages exists:

- Digital interfaces: “out-of-service” - all trunks are unavailable/disconnected
- "unavailable":
  - Digital interfaces: All trunks are busy or unavailable

The following procedure describes how to configure Forward on Busy Trunks through the Web interface. You can also configure it through ini file [ForwardOnBusyTrunkDest] or CLI (configure voip > gateway routing fwd-on-busy-trk-dst).

➤ **To configure a Forward on Busy Trunk Destination rule:**

1. Open the Forward on Busy Trunk Destination table (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Routing** > **Forward on Busy Trunk Destination**).
2. Click **New**; the following dialog box appears:

The figure above displays a configuration that forwards IP-to-Tel calls destined for Trunk Group ID 1 to destination IP address 10.13.5.67 if conditions mentioned earlier exist.

3. Configure a rule according to the parameters described in the table below.
4. Click **Apply**, and then restart the device with a save-to-flash for your settings to take effect.

**Table 25-10:Forward on Busy Trunk Destination Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Trunk Group ID' trunk-group-id [TrunkGroupId]	Defines the Trunk Group ID to where the IP call is destined.
'Forward Destination' forward-dst [ForwardDestination]	Defines the alternative IP destination for the call used if the Trunk Group is busy or unavailable.  The valid value can be an IP address in dotted-decimal notation, an FQDN, or a SIP Request-URI user name and host part (i.e., user@host). The following syntax can also be used: host:port;transport=xxx (i.e., IP address, port and transport type). <b>Note:</b> <ul style="list-style-type: none"> <li>■ If you do not specify a port, the device uses UDP port 5060.</li> <li>■ When configured with a user@host, the original destination number is replaced by the user part.</li> </ul>

## Alternative Routing upon ISDN Disconnect

You can configure when the device sends a call to an alternative route if it receives an ISDN Q.931 Disconnect message with a Progress Indicator (PI) IE from the Tel side for IP-to-Tel calls. The Disconnect message indicates that the call cannot be established due to, for example, a busy state on the Tel side.

You can enable or disable this mode of operation:

- **Disabled:** The device doesn't immediately disconnect the call. Instead, it waits for any subsequent media from the Tel side (e.g., "this number is currently busy") and forwards it to the IP side (SIP 183 for early media). Only when it receives a Q.931 Release message, does the device disconnect the call (sends a SIP BYE message to the IP side). If you have configured an alternative route, the device sends the IP call to the alternative route.
- **Enabled:** The device immediately sends the IP call to an alternative route, if you have configured one. If no alternative route has been configured and the Disconnect message is received with PI, the device forwards the subsequent early media to the IP side. The device disconnects the IP call only upon receipt of the subsequent Release message.

### ➤ To configure alternative routing upon receipt of ISDN Disconnect:

1. Open the Digital Gateway Parameters page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Digital Gateway** > **Digital Gateway Settings**).
2. Select the 'Disconnect Call With PI If Alt' check box (DisconnectCallwithPIIfAlt):

Disconnect Call With PI If Alt ☒

3. Click **Apply**.

## 26 Manipulation

This section describes configuration of various manipulation processes for the Gateway application.

### Configuring Redirect Reasons

You can manipulate call redirect (diversion) reasons between IP (SIP) and Tel (ISDN). The SIP Diversion header contains the information on the redirection of the call, including the reason (e.g., 'reason=user-busy'). The ISDN provides the Redirect Number and the Reason for Redirection. You can configure the following redirect manipulations:

- Redirect Number screening indicator (e.g., User Failed) in ISDN Setup messages for IP-to-Tel calls. Configuration is done using the [SetIp2TelRedirectScreeningInd] parameter.
- IP-to-Tel redirect reason for IP-to-Tel calls in the ISDN message if redirect information is received from the IP side. Configuration is done using the [SetIp2TelRedirectReason] parameter.
- Tel-to-IP redirect reason in SIP messages for Tel-to-IP calls if redirect information is received from the Tel side. Configuration is done using the [SetTel2IpRedirectReason] parameter.

#### ➤ To configure redirect reason manipulation:

1. Open the Manipulations Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Manipulation** > **Manipulations Settings**).

Set IP-to-Tel Redirect Reason	Not Configured ▼
Redirect Number IP to Tel	Not Configured ▼
Set Tel-to-IP Redirect Reason	Not Configured ▼

2. Configure the parameters as required, and then click **Apply**.

### Configuring Source-Destination Number Manipulation Rules

The number manipulation tables let you configure rules for manipulating source and destination telephone numbers for IP-to-Tel and Tel-to-IP calls. Number manipulation include the following tables:

#### ■ Tel-to-IP calls:

- Source Phone Number Manipulation for Tel-to-IP Calls (up to 120 entries)
- Destination Phone Number Manipulation for Tel-to-IP Calls (up to 120 entries)

#### ■ IP-to-Tel calls:

- Source Phone Number Manipulation for IP-to-Tel Calls (up to 120 entries)

- Destination Phone Number Manipulation for IP-to-Tel Calls (up to 120 entries)

Configuration of number manipulation rules includes two areas:

- **Match:** Defines the matching characteristics of the incoming call (e.g., prefix of destination number).
- **Action:** Defines the action that is done if the incoming call matches the characteristics of the rule (e.g., removes a user-defined number of digits from the left of the number).

The device searches the table from **top to bottom** for the **first** rule that matches the characteristics of the incoming call. If it finds a matching rule, it applies the manipulation configured for that rule. In other words, a rule at the top of the table takes precedence over a rule defined lower down in the table. Therefore, define more specific rules above more generic rules. For example, if you configure the source prefix number as "551" for rule index 1 and "55" for rule index 2, the device uses rule index 1 for numbers that start with 551 and uses rule index 2 for numbers that start with 550, 552, 553, and so on until 559. However, if you configure the source prefix number as "55" for rule index 1 and "551" for rule index 2, the device applies rule index 1 to all numbers that start with 55, including numbers that start with 551. If the device doesn't find a matching rule, no manipulation is done on the call.

You can perform a second "round" (additional) of source and destination number manipulations for IP-to-Tel calls on an already manipulated number. The initial and additional number manipulation rules are both configured in the number manipulation tables for IP-to-Tel calls. The additional manipulation is performed on the initially manipulated number. Thus, for complex number manipulation schemes, you only need to configure relatively few manipulation rules in these tables (that would otherwise require many rules). To enable this additional manipulation, use the following parameters:

- Source number manipulation - [PerformAdditionalIP2TELSrcManipulation]
- Destination number manipulation - [PerformAdditionalIP2TELDestinationManipulation]

Telephone number manipulation can be useful, for example, for the following:

- Stripping or adding dialing plan digits from or to the number, respectively. For example, a user may need to first dial 9 before dialing the phone number to indicate an external line. This number 9 can then be removed by number manipulation before the call is setup.
- Allowing or blocking Caller ID information according to destination or source prefixes.
- Assigning Numbering Plan Indicator (NPI) and Type of Numbering (TON) to IP-to-Tel calls. The device can use a single global setting for NPI/TON classification or it can use the setting in the manipulation tables on a call-by-call basis.



- Number manipulation can be performed before or after a routing decision is made. For example, you can route a call to a specific Trunk Group according to its original number, and then you can remove or add a prefix to that number before it is routed. To determine when number manipulation is performed, use the 'IP to Tel Routing Mode' parameter (RouteModeIP2Tel) and 'Tel-to-IP Routing Mode' parameter (RouteModeTel2IP).
- The device manipulates the number in the following order: 1) strips digits from the left of the number, 2) strips digits from the right of the number, 3) retains the defined number of digits, 4) adds the defined prefix, and then 5) adds the defined suffix.

The following procedure describes how to configure number manipulation rules through the Web interface. You can also configure this using the following management tools:

- **Destination Phone Number Manipulation for IP-to-Tel Calls table:** ini file [NumberMapIP2Tel] or CLI (configure voip > gateway manipulation dst-number-map-ip2tel)
- **Destination Phone Number Manipulation for Tel-to-IP Calls table:** ini file [NumberMapTel2IP] or CLI (configure voip > gateway manipulation dst-number-map-tel2ip)
- **Source Phone Number Manipulation for IP-to-Tel Calls table:** ini file [SourceNumberMapIP2Tel] or CLI (configure voip > gateway manipulation src-number-map-ip2tel)
- **Source Phone Number Manipulation for Tel-to-IP Calls table:** ini file [SourceNumberMapTel2IP] or CLI (configure voip > gateway manipulation src-number-map-tel2ip)

➤ **To configure a number manipulation rule:**

1. Open the required Phone Number Manipulation table (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Manipulation** > **Dest Number IP->Tel**, **Dest Number Tel->IP**, **Source Number IP->Tel**, or **Source Number Tel->IP**).
2. Click **New**; the following dialog box appears:

GENERAL		ACTION	
Index	0	Stripped Digits From Left	0
Name		Stripped Digits From Right	0
		Number of Digits to Leave	255
<b>MATCH</b>		Prefix to Add	
Source Trunk Group	-1	Suffix to Add	
Source Phone Pattern	*	TON	
Destination Phone Pattern	*	NPI	
		Presentation	

3. Configure a number manipulation rule according to the parameters described in the table below.
4. Click **Apply**.



The table below shows configuration examples of Tel-to-IP source phone number manipulation rules configured in the Source Phone Number Manipulation for Tel-to-IP Calls table:

**Table 26-1: Configuration Examples of Source Phone Number Manipulation for Tel-to-IP Calls**

Parameter	Rule 1	Rule 2	Rule 3	Rule 4	Rule 5
Destination Phone Pattern	03		*	*	[6,7,8]
Source Phone Pattern	201	1001	123451001#	[30-40]x	2001
Stripped Digits From Left	-	4	-	-	5
Stripped Digits From Right	-	-	-	1	-
Prefix to Add	971	5	-	2	3
Suffix to Add	-	23	8	-	-
Number of Digits to Leave	-	-	4	-	-
Presentation	Allowed	Restricted	-	-	-

Below is a description of each rule:

- **Rule 1:** When the destination number has the prefix 03 (e.g., 035000), source number prefix 201 (e.g., 20155), and from source IP Group ID 2, the source number is changed to, for example, 97120155.
- **Rule 2:** When the source number has prefix 1001 (e.g., 1001876), it is changed to 587623.
- **Rule 3:** When the source number has prefix 123451001 (e.g., 1234510012001), it is changed to 20018.
- **Rule 4:** When the source number has prefix from 30 to 40 and a digit (e.g., 3122), it is changed to 2312.
- **Rule 5:** When the destination number has the prefix 6, 7, or 8 (e.g., 85262146), source number prefix 2001, it is changed to 3146.

**Table 26-2: Phone Number Manipulation Tables Parameter Descriptions**

Parameter	Description
General	

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' manipulation-name [ManipulationName]	Defines a descriptive name, which is used when associating the row in other tables.  The valid value is a string of up to 40 characters. By default, no value is defined. <b>Note:</b> Configure each row with a unique name.
Match	
'Source IP Address' src-ip-address [SourceAddress]	Defines the source IP address of the caller. This is obtained from the Contact header in the INVITE message.  The default is the asterisk (*) wildcard (i.e., any address). <b>Note:</b> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Destination Phone Number Manipulation for IP-to-Tel Calls table and Source Phone Number Manipulation for IP-to-Tel Calls table.</li> <li>■ The source IP address can include the 'x' wildcard to represent single digits. For example, 10.8.8.xx represents all IP addresses between 10.8.8.10 to 10.8.8.99.</li> <li>■ The source IP address can include the asterisk (*) wildcard to represent any number between 0 and 255. For example, 10.8.8.* represents all IP addresses between 10.8.8.0 and 10.8.8.255.</li> </ul>
'Destination IP Group' dst-ip-group-name [DestIPGroupID]	Defines the IP Group to where the call is sent.  The default is Any (i.e., any IP Group). <b>Note:</b> The parameter is applicable only to the Destination Phone Number Manipulation for Tel-to-IP Calls table.
'Source Trunk Group' src-trunk-group-id [SrcTrunkGroupID]	Defines the source Trunk Group ID for Tel-to-IP calls.  The default is -1 (i.e., any Trunk Group). <b>Note:</b> The parameter is applicable only to the number manipulation tables for Tel-to-IP calls.
'Source Phone Pattern' src-pattern [SourcePrefix]	Defines the source (calling) telephone number.  You can use special patterns (notations) to denote the number. For example, "[100-199](100,101,105)" denotes a

Parameter	Description
	<p>number that starts with 100 to 199 and ends with 100, 101 or 105. You can use the dollar (\$) sign to denote calls without a calling number. For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The default is the asterisk (*) symbol, meaning any source number.</p>
'Source Host Pattern' src-host-pattern [SrcHost]	<p>Defines the URI host part of the incoming SIP INVITE message in the From header.</p> <p>You can use special patterns (notations) to denote the host part. For example, if you want to match this rule to host parts that end (suffix) in ".com", then configure this parameter to "(.com)". For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The default is the asterisk (*) symbol, meaning any source host part.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Destination Phone Number Manipulation for IP-to-Tel Calls table and Source Phone Number Manipulation for IP-to-Tel Calls table.</li> <li>■ If the P-Asserted-Identity header is present in the incoming INVITE message, then the value of the parameter is compared to the P-Asserted-Identity URI host name (instead of the From header).</li> </ul>
'Destination Phone Pattern' dst-pattern [DestinationPrefix]	<p>Defines the destination (called) telephone number.</p> <p>You can use special patterns (notations) to denote the number. For example, "[100-199](100,101,105)" denotes a number that starts with 100 to 199 and ends with 100, 101 or 105. You can also use the dollar (\$) sign to denote calls without a called number. For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The default is the asterisk (*) symbol, meaning any destination number.</p>
'Destination Host Pattern' dst-host-pattern [DestHost]	<p>Defines the Request-URI host part of the incoming SIP INVITE message.</p> <p>You can use special patterns (notations) to denote the host</p>

Parameter	Description
	<p>part. For example, if you want to match this rule to host parts that end (suffix) in ".com", then configure this parameter to "(.com)". For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The default is the asterisk (*) symbol, meaning any destination host part.</p> <p><b>Note:</b> The parameter is applicable only to the Destination Phone Number Manipulation for IP-to-Tel Calls table and Source Phone Number Manipulation for IP-to-Tel Calls table.</p>
'Source IP Group' src-ip-group-id [SrcIPGroupID]	<p>Defines the IP Group from where the IP call originated. The default is Any (i.e., any IP Group).</p> <p><b>Note:</b> The parameter is applicable only to the Destination Phone Number Manipulation for IP-to-Tel Calls table and Source Phone Number Manipulation for IP-to-Tel Calls table.</p>
Action	
'Stripped Digits From Left' remove-from-left [RemoveFromLeft]	<p>Defines the number of digits to remove from the left of the telephone number prefix. For example, if you enter 3 and the phone number is 5551234, the new phone number is 1234.</p>
'Stripped Digits From Right' remove-from-right [RemoveFromRight]	<p>Defines the number of digits to remove from the right of the telephone number prefix. For example, if you enter 3 and the phone number is 5551234, the new phone number is 5551.</p>
'Number of Digits to Leave' num-of-digits-to-leave [LeaveFromRight]	<p>Defines the number of digits that you want to keep from the right of the phone number. For example, if you enter 4 and the phone number is 00165751234, then the new number is 1234.</p>
'Prefix to Add' prefix-to-add [Prefix2Add]	<p>Defines the number or string that you want added to the front of the telephone number. For example, if you enter 9 and the phone number is 1234, the new number is 91234.</p>
'Suffix to Add' suffix-to-add [Suffix2Add]	<p>Defines the number or string that you want added to the end of the telephone number. For example, if you enter 00 and the phone number is 1234, the new number is 123400.</p>

Parameter	Description
'TON' ton [NumberType]	<p>Defines the Type of Number (TON).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Unknown</b> (default)</li> <li>■ [1] <b>International-Level2 Regional</b></li> <li>■ [2] <b>National-Level1 Regional</b></li> <li>■ [3] <b>Network-PSTN Specific</b></li> <li>■ [4] <b>Subscriber-Level0 Regional</b></li> <li>■ [6] <b>Abbreviated</b></li> </ul> <p>The applicable values depend on the NPI value:</p> <ul style="list-style-type: none"> <li>■ If you select <b>Unknown</b> for NPI, you can select <b>Unknown</b>.</li> <li>■ If you select <b>Private</b> for NPI, you can set TON to one of the following: <ul style="list-style-type: none"> <li>✓ <b>Unknown</b></li> <li>✓ <b>International-Level2 Regional</b></li> <li>✓ <b>National-Level1 Regional</b></li> <li>✓ <b>PISN Specific</b></li> <li>✓ <b>Subscriber-Level0 Regional</b></li> </ul> </li> <li>■ If you select <b>E.164 Public</b> for NPI, you can set TON to one of the following: <ul style="list-style-type: none"> <li>✓ <b>Unknown</b></li> <li>✓ <b>International-Level2 Regional</b></li> <li>✓ <b>National-Level1 Regional</b></li> <li>✓ <b>Network-PSTN Specific</b></li> <li>✓ <b>Subscriber-Level0 Regional</b></li> <li>✓ <b>Abbreviated</b></li> </ul> </li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ TON can be used in the SIP Remote-Party-ID header by using the EnableRPIHeader and AddTON2RPI parameters.</li> <li>■ For more information on available NPI/TON values, see <a href="#">Numbering Plans and Type of Number</a> on page 989.</li> </ul>

Parameter	Description
'NPI' np i [NumberPlan]	<p>Defines the Numbering Plan Indicator (NPI).</p> <ul style="list-style-type: none"> <li>■ [-1] = Not configured and the value received from PSTN/IP is used.</li> <li>■ [0] <b>Unknown</b> (default)</li> <li>■ [1] <b>E.164 Public</b></li> <li>■ [9] <b>Private</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ NPI can be used in the SIP Remote-Party-ID header by using the EnableRPIHeader and AddTON2RPI parameters.</li> <li>■ For more information on available NPI/TON values, see <a href="#">Numbering Plans and Type of Number</a> on page 989.</li> </ul>
'Presentation' is-presentation- restricted [IsPresentationRestricted]	<p>Enables caller ID.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Allowed</b> = Sends Caller ID information when a call is made using these destination/source prefixes.</li> <li>■ [1] <b>Restricted</b> = Restricts Caller ID information for these prefixes.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Source Phone Number Manipulation for IP-to-Tel Calls table and Source Phone Number Manipulation for Tel-to-IP Calls table.</li> <li>■ If you configure the parameter to <b>Restricted</b> and the 'Asserted Identity Mode' (AssertedIdMode) parameter to <b>Add P-Asserted-Identity</b>, the From header in the INVITE message includes the following:</li> </ul> <pre>From: 'anonymous' &lt;sip: anonymous@anonymous.invalid&gt; and 'privacy: id' header</pre>

## Manipulating Number Prefix

The device supports a notation for adding a prefix where part of the prefix is first extracted from a user-defined location in the original destination or source number. The notation is entered in the 'Prefix to Add' field in the Number Manipulation tables (see [Configuring Source-Destination Number Manipulation Rules](#) on page 950): x[n,l]y...

where,

- $x$  = any number of characters/digits to add at the beginning of the number (i.e. first digits in the prefix).
- $[n,l]$  = defines the location in the original destination or source number where the digits  $y$  are added:
  - $n$  = location (number of digits counted from the left of the number) of a specific string in the original destination or source number.
  - $l$  = number of digits that this string includes.
- $y$  = prefix to add at the specified location.

For example, assume that you want to manipulate an incoming IP call with destination number "+5492028888888" (i.e., area code "202" and phone number "8888888") to the number "020215888888". To perform such manipulation, the following configuration is required in the Number Manipulation table:

1. The following notation is used in the 'Prefix to Add' field:

0[5,3]15

where,

- 0 is the number to add at the beginning of the original destination number.
  - [5,3] denotes a string that is located after (and including) the fifth character (i.e., the first '2' in the example) of the original destination number, and its length being three digits (i.e., the area code 202, in the example).
  - 15 is the number to add immediately after the string denoted by [5,3] - in other words, 15 is added after (i.e. to the right of) the digits 202.
2. The first seven digits from the left are removed from the original number, by entering "7" in the 'Stripped Digits From Left' field.

**Table 26-3: Example of Configured Rule for Manipulating Prefix using Special Notation**

Parameter	Rule 1
Destination Phone Pattern	+5492028888888
Source Phone Pattern	*
Source IP Address	*
Stripped Digits from Left	7
Prefix to Add	0[5,3]15

In this configuration example, the following manipulation process occurs:

1. The prefix is calculated as 020215.

2. The first seven digits from the left are removed from the original number, thereby changing the number to 8888888.
3. The prefix that was previously calculated is then added.

## SIP Calling Name Manipulations

The calling name manipulation tables let you configure up to 120 manipulation rules for manipulating the calling name (i.e., caller ID) in SIP messages for IP-to-Tel and Tel-to-IP calls. Manipulation includes modifying or removing the calling name. For example, assume that an incoming SIP INVITE message includes the following header:

```
P-Asserted-Identity: "company:john" sip:6666@78.97.79.104
```

Using the Calling Name Manipulation for IP-to-Tel Calls table, "company" can be changed to "worker" in the outgoing INVITE, as shown below:

```
P-Asserted-Identity: "worker:john" sip:996666@10.13.83.10
```

The calling name manipulation tables include the following:

- Calling Name Manipulation for IP-to-Tel Calls table
- Calling Name Manipulation for Tel-to-IP Calls table

Configuration of calling name manipulation rules includes two areas:

- **Match:** Defines the matching characteristics of an incoming call (e.g., prefix of destination number).
- **Action:** Defines the action that is done if the incoming call matches the characteristics of the rule (e.g., removes a user-defined number of digits from the left of the calling name).

The device searches the table from **top to bottom** for the **first** rule that matches the characteristics of the incoming call. If it finds a matching rule, it applies the manipulation configured for that rule.



To use the Calling Name Manipulation for Tel-to-IP Calls table for retrieving the calling name (display name) from an Active Directory using LDAP queries, see [Querying Microsoft Entra ID for Calling Name](#) on page 404.

The following procedure describes how to configure calling name manipulation rules through the Web interface. You can also configure these rules using the following management tools:

- Calling Name Manipulation for Tel-to-IP Calls table: *ini* file [CallingNameMapTel2Ip] or CLI (configure voip > gateway manipulation calling-name-map-tel2ip)
- Calling Name Manipulation for IP-to-Tel Calls table: *ini* file [CallingNameMapIp2Tel] or CLI (configure voip > gateway manipulation calling-name-map-ip2tel)



➤ **To configure calling name manipulation rules:**

1. Open the required calling name manipulations table (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Manipulation** > **Calling Name IP->Tel** or **Calling Name Tel->IP**).
2. Click **New**; the following dialog box appears:

Calling Name Manipulation for IP-to-Tel Calls

GENERAL		ACTION	
Index	<input type="text" value="1"/>	Stripped Characters From Left	<input type="text" value="0"/>
Name	<input type="text"/>	Stripped Characters From Right	<input type="text" value="0"/>
		Number of Characters to Leave	<input type="text" value="255"/>
		Prefix to Add	<input type="text"/>
		Suffix to Add	<input type="text"/>

**MATCH**

Source IP Address	<input type="text" value="*"/>
Source Phone Pattern	<input type="text" value="*"/>
Source Host Pattern	<input type="text" value="*"/>
Destination Phone Pattern	<input type="text" value="*"/>
Destination Host Pattern	<input type="text" value="*"/>
Calling Name Pattern	<input type="text" value="*"/>

3. Configure a manipulation rule according to the parameters described in the table below.
4. Click **Apply**.

**Table 26-4: Calling Name Manipulation Tables Parameter Descriptions**

Parameter	Description
<b>General</b>	
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' manipulation-name [ManipulationName]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 40 characters. <b>Note:</b> <ul style="list-style-type: none"> <li>■ Configure each row with a unique name.</li> <li>■ The parameter value can't be configured with the character string "any" (upper or lower case).</li> </ul>
<b>Match</b>	
'Destination Phone'	Defines the destination (called)

Parameter	Description
Pattern' dst-pattern [DestinationPrefix]	<p>telephone number.</p> <p>You can use special patterns (notations) to denote the number. For example, "[100-199] (100,101,105)" denotes a number that starts with 100 to 199 and ends with 100, 101 or 105. You can use the dollar (\$) sign to denote calls without a called number. For available notations, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The default value is the asterisk (*) symbol, meaning any destination number.</p>
'Source Phone Pattern' src-pattern [SourcePrefix]	<p>Defines the source (calling) telephone number.</p> <p>You can use special patterns (notations) to denote the number. For example, "[100-199] (100,101,105)" denotes a number that starts with 100 to 199 and ends with 100, 101 or 105. You can also use the dollar (\$) sign to denote calls without a calling number. For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The default value is the asterisk (*) symbol, meaning any source number.</p>
'Calling Name Pattern' calling-name-pattern [CallingNamePrefix]	<p>Defines the calling name (i.e., caller ID).</p> <p>The valid value is a string of up to 50 alphanumeric characters (e.g., "JohnD20") or any of the following special patterns (notations):</p> <ul style="list-style-type: none"> <li>■ Dollar (\$) sign - denotes calls</li> </ul>

Parameter	Description
	<p>without a calling name.</p> <ul style="list-style-type: none"> <li>■ Asterisk (*) sign - denotes any calling name.</li> </ul> <p>The default value is * .</p>
<p>'Source Trunk Group ID'</p> <p>src-trunk-group-id</p> <p>[SrcTrunkGroupID]</p>	<p>Defines the source Trunk Group ID from where the Tel-to-IP call was received.</p> <p>The default value is -1, which denotes any Trunk Group.</p> <p><b>Note:</b> The parameter is applicable only to the Calling Name Manipulation for Tel-to-IP Calls table.</p>
<p>'Source IP Address'</p> <p>src-ip-address</p> <p>[SourceAddress]</p>	<p>Defines the source IP address of the caller for IP-to-Tel calls. The source IP address appears in the SIP Contact header in the INVITE message.</p> <p>The default value is the asterisk (*) symbol (i.e., any IP address).</p> <p>The source IP address can include the following wildcards:</p> <ul style="list-style-type: none"> <li>■ "x" wildcard: represents single digits. For example, 10.8.8.xx represents all IP addresses between 10.8.8.10 to 10.8.8.99.</li> <li>■ "*" (asterisk) wildcard: represents any number between 0 and 255. For example, 10.8.8.* represents all IP addresses between 10.8.8.0 and 10.8.8.255.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the Calling Name Manipulation for IP-to-Tel Calls table.</p>
'Source Host Pattern'	Defines the URI host part of the

Parameter	Description
src-host-pattern [SrcHost]	<p>incoming SIP INVITE message in the From header.</p> <p>The valid value is a string of up to 49 alphanumeric characters. You can also use special patterns (notations) to denote the host part. For example, if you want to match this rule to host parts that end (suffix) in ".com", then configure this parameter to "(.com)". For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The default value is the asterisk (*) symbol, meaning any source host part.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Calling Name Manipulation for IP-to-Tel Calls table.</li> <li>■ If the P-Asserted-Identity header is present in the incoming INVITE message, the value of the parameter is compared to the P-Asserted-Identity URI host name (instead of the From header).</li> </ul>
'Destination Host Pattern' dst-host-pattern [DestHost]	<p>Defines the Request-URI host part of the incoming SIP INVITE message.</p> <p>The valid value is a string of up to 49 alphanumeric characters. You can also use special patterns (notations) to denote the host part. For example, if you want to match this rule to host parts that end (suffix) in ".com", then configure this parameter to "</p>

Parameter	Description
	<p>(.com)". For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The default value is the asterisk (*) symbol, meaning any destination host part.</p> <p><b>Note:</b> The parameter is applicable only to the Calling Name Manipulation for IP-to-Tel Calls table.</p>
Action	
<p>'Stripped Characters From Left'</p> <p>remove-from-left</p> <p>[RemoveFromLeft]</p>	<p>Defines the number of characters to remove from the left of the calling name.</p> <p>For example, if you enter 3 and the calling name is "company:john", the new calling name is "pany:john".</p>
<p>'Stripped Characters From Right'</p> <p>remove-from-right</p> <p>[RemoveFromRight]</p>	<p>Defines the number of characters to remove from the right of the calling name.</p> <p>For example, if you enter 3 and the calling name is "company:name", the new name is "company:n".</p>
<p>'Number of Characters to Leave'</p> <p>num-of-digits-to-leave</p> <p>[LeaveFromRight]</p>	<p>Defines the number of characters that you want to keep from the right of the calling name.</p> <p>For example, if you enter 4 and the calling name is "company:name", the new name is "name".</p>
<p>'Prefix to Add'</p> <p>prefix-to-add</p> <p>[Prefix2Add]</p>	<p>Defines the number or string to add at the front of the calling name.</p> <p>For example, if you enter ITSP and the calling name is</p>

Parameter	Description
	"company:name", the new name is ITSPcompany:john".
'Suffix to Add' suffix-to-add [Suffix2Add]	Defines the number or string to add at the end of the calling name.  For example, if you enter 00 and calling name is "company:name", the new name is "company:name00".

## Configuring Redirect Number Manipulation

Each redirect number manipulation table lets you configure up to 20 rules for manipulating the redirect number received in SIP messages. The redirect number manipulation tables include:

- **Redirect Number IP-to-Tel table:** (Applicable only to ISDN) Defines IP-to-Tel redirect number manipulation. You can manipulate the value of the received SIP Diversion, Resource-Priority, or History-Info headers, which is then added to the Redirecting Number Information Element (IE) in the ISDN Setup message sent to the Tel side. This also includes the reason for the call redirection.
- **Redirect Number Tel-to-IP table:** Defines Tel-to-IP redirect number manipulation. You can manipulate the prefix of the redirect number received from the Tel side, in the outgoing SIP Diversion, Resource-Priority, or History-Info headers sent to the IP side.

Configuration of redirect number manipulation rules includes two areas:

- **Match:** Defines the matching characteristics of an incoming call (e.g., prefix of redirect number).
- **Action:** Defines the action that is done if the incoming call matches the characteristics of the rule (e.g., removes a user-defined number of digits from the left of the redirect number).

The device searches the table from **top to bottom** for the **first** rule that matches the characteristics of the incoming call. If it finds a matching rule, it applies the manipulation configured for that rule.



- If the device copies the received destination number to the outgoing SIP redirect number (enabled by the CopyDest2RedirectNumber parameter), no redirect number Tel-to-IP manipulation is done.
- The manipulation rules are done in the following order: 'Stripped Digits From Left', 'Stripped Digits From Right', 'Number of Digits to Leave', 'Prefix to Add', and then 'Suffix to Add'.
- The device uses the 'Redirect Prefix' parameter before it manipulates the prefix.

The following procedure describes how to configure redirect number manipulation rules through the Web interface. You can also configure these rules using the following management tools:

- Redirect Number IP-to-Tel table: ini file [RedirectNumberMapIp2Tel] or CLI (`configure voip > gateway manipulation redirect-number-map-ip2tel`)
- Redirect Number Tel-to-IP table: ini file [RedirectNumberMapTel2Ip] or CLI (`configure voip > gateway manipulation redirect-number-map-tel2ip`)

➤ **To configure a redirect number manipulation rule:**

1. Open the required redirect number manipulation table (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Manipulation** > **Redirect Number Tel** > **IP** or **Redirect Number IP** > **Tel**).
2. Click **New**; the following dialog box appears (e.g., Redirect Number Tel-to-IP table):

3. Configure a manipulation rule according to the parameters described in the table below.
4. Click **Apply**.

**Table 26-5: Redirect Number Manipulation Tables Parameter Description**

Parameter	Description
<b>General</b>	
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' manipulation-name [ManipulationName]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 40 characters. <b>Note:</b> The parameter value can't be configured with the character string "any" (upper or lower case).
<b>Match</b>	
'Destination Phone Pattern' dst-pattern [DestinationPrefix]	Defines the destination (called) telephone number. You can use special patterns (notations) to denote the number. For example, if you want to match this rule to a

Parameter	Description
	<p>number whose last four digits (i.e., suffix) are 4 followed by any three digits (e.g., 4008), then configure this parameter to "(4xxx)". For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The default value is the asterisk (*) symbol, meaning any destination number.</p> <p>For manipulating the diverting and redirected numbers for call diversion, you can use the strings "DN" and "RN" to denote the destination prefix of these numbers. For more information, see <a href="#">Manipulating Redirected and Diverted Numbers for Call Diversion</a> on page 971.</p>
'Redirect Phone Pattern' redirect-pattern [RedirectPrefix]	<p>Defines the redirect telephone number.</p> <p>You can use special patterns (notations) to denote the number. For example, if you want to match this rule to a number whose last four digits (i.e., suffix) are 4 followed by any three digits (e.g., 4008), then configure this parameter to "(4xxx)". For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The default value is the asterisk (*) symbol, meaning any redirect number.</p>
'Source Trunk Group ID' src-trunk-group-id [SrcTrunkGroupID]	<p>Defines the Trunk Group from where the Tel call is received.</p> <p>To denote any Trunk Group, leave this field empty. The value -1 indicates that this field is ignored in the rule.</p> <p><b>Note:</b> The parameter is applicable only to the Redirect Number Tel-to-IP table.</p>
'Source IP Address' src-ip-address [SourceAddress]	<p>Defines the IP address of the caller. The IP address appears in the SIP Contact header of the incoming INVITE message.</p> <p>The default value is the asterisk (*) symbol (i.e., any IP address). The value can include the following wildcards:</p> <ul style="list-style-type: none"> <li>■ "x": represents single digits, for example, 10.8.8.xx denotes all addresses between 10.8.8.10 and 10.8.8.99.</li> <li>■ "*": represents any number between 0 and 255, for example, 10.8.8.* denotes all addresses between 10.8.8.0 and 10.8.8.255.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the Redirect Number IP-to-Tel table.</p>



Parameter	Description
'Source Host Pattern' src-host-pattern [SrcHost]	<p>Defines the URI host part of the caller. The host name appears in the SIP From header of the incoming SIP INVITE message.</p> <p>You can use special patterns (notations) to denote the host part. For example, if you want to match this rule to host parts that end (suffix) in ".com", then configure this parameter to "(.com)". For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The default value is the asterisk (*) symbol, meaning any source host part.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Redirect Number IP-to-Tel table.</li> <li>■ If the P-Asserted-Identity header is present in the incoming INVITE message, the value of the parameter is compared to the P-Asserted-Identity URI host name (instead of to the From header).</li> </ul>
'Destination Host Pattern' dst-host-pattern [DestHost]	<p>Defines the Request-URI host part, which appears in the incoming SIP INVITE message.</p> <p>You can use special patterns (notations) to denote the host part. For example, if you want to match this rule to host parts that end (suffix) in ".com", then configure this parameter to "(.com)". For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The default value is the asterisk (*) symbol, meaning any destination host part.</p> <p><b>Note:</b> The parameter is applicable only to the Redirect Number IP-to-Tel table.</p>
Action	
'Stripped Digits From Left' remove-from-left [RemoveFromLeft]	<p>Defines the number of digits to remove from the left of the redirect number prefix.</p> <p>For example, if you enter 3 and the redirect number is 5551234, the new number is 1234.</p>
'Stripped Digits From Right' remove-from-right [RemoveFromRight]	<p>Defines the number of digits to remove from the right of the redirect number prefix.</p> <p>For example, if you enter 3 and the redirect number is 5551234, the new number is 5551.</p>

Parameter	Description
'Number of Digits to Leave' num-of-digits-to-leave [LeaveFromRight]	Defines the number of digits that you want to retain from the right of the redirect number.
'Prefix to Add' prefix-to-add [Prefix2Add]	Defines the number or string that you want added to the front of the redirect number.  For example, if you enter 9 and the redirect number is 1234, the new number is 91234.
'Suffix to Add' suffix-to-add [Suffix2Add]	Defines the number or string that you want added to the end of the redirect number.  For example, if you enter 00 and the redirect number is 1234, the new number is 123400.
'TON' ton [NumberType]	<p>Defines the Type of Number (TON).</p> <ul style="list-style-type: none"> <li>■ [-1] = (Default) Not configured</li> <li>■ [0] <b>Unknown</b> (default)</li> <li>■ [1] <b>International-Level2 Regional</b></li> <li>■ [2] <b>National-Level1 Regional</b></li> <li>■ [3] <b>Network-PSTN Specific</b></li> <li>■ [4] <b>Subscriber-Level0 Regional</b></li> <li>■ [6] <b>Abbreviated</b></li> </ul> <p>The applicable values depend on the NPI value:</p> <ul style="list-style-type: none"> <li>■ If NPI is set to <b>Unknown</b>, you can set TON to Unknown.</li> <li>■ If NPI is set to Private, you can set TON to one of the following: <ul style="list-style-type: none"> <li>✓ <b>Unknown</b></li> <li>✓ <b>International-Level2 Regional</b></li> <li>✓ <b>National-Level1 Regional</b></li> <li>✓ <b>Network-PSTN Specific</b></li> <li>✓ <b>Subscriber-Level0 Regional</b></li> </ul> </li> <li>■ If NPI is set to <b>E.164 Public</b>, you can set TON to one of the following: <ul style="list-style-type: none"> <li>✓ <b>Unknown</b></li> </ul> </li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>✓ <b>International-Level2 Regional</b></li> <li>✓ <b>National-Level1 Regional</b></li> <li>✓ <b>Network-PSTN Specific</b></li> <li>✓ <b>Subscriber-Level0 Regional</b></li> <li>✓ <b>Abbreviated</b></li> </ul> <p>For more information on available NPI/TON values, see <a href="#">Numbering Plans and Type of Number</a> on page 989.</p>
'NPI' npi [NumberPlan]	<p>Defines the Numbering Plan Indicator (NPI).</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> = (Default) Value received from PSTN/IP is used</li> <li>■ [0] <b>Unknown</b></li> <li>■ [1] <b>E.164 Public</b></li> <li>■ [9] <b>Private</b></li> </ul> <p>For more information on available NPI/TON values, see <a href="#">Numbering Plans and Type of Number</a> on page 989.</p> <p><b>Note:</b> The parameter is applicable only to digital interfaces.</p>
'Presentation' is-presentation- restricted [IsPresentationRestricted]	<p>Enables caller ID.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Allowed</b> = Sends Caller ID information when a call is made using these destination / source prefixes.</li> <li>■ [1] <b>Restricted</b> = Restricts Caller ID information for these prefixes.</li> </ul> <p><b>Note:</b> If you configure the parameter to <b>Restricted</b> and the 'AssertedIdMode' parameter to <b>Add P-Asserted-Identity</b>, the From header in the INVITE message includes the following:</p> <pre>From: 'anonymous' &lt;sip:anonymous@anonymous.invalid&gt; and 'privacy: id' header.</pre>

## Manipulating Redirected and Diverted Numbers for Call Diversion

You can configure manipulation rules to manipulate the Diverted-to and Diverting numbers received in the incoming Call Redirection Facility message for call diversion, which is

interworked to outgoing SIP 302 responses.



This feature is applicable only to the Gateway application - Euro ISDN and QSIG variants in the IP-to-Tel call direction.

The incoming redirection Facility message includes, among other parameters, the Diverted-to number and Diverting number. The Diverted-to number (i.e., new destination) is mapped to the user part in the Contact header of the SIP 302 response. The Diverting number is mapped to the user part in the Diversion header of the SIP 302 response. These two numbers can be manipulated by entering the following special strings in the 'Destination Phone Pattern' field of the Redirect Number Tel-to-IP table:

- "RN" - used in the rule to manipulate the Redirected number (i.e., originally called number or Diverting number).
- "DN" - used in the rule to manipulate the Diverted-to number (i.e., the new called number or destination). This manipulation is done on the user part in the Contact header of the SIP 302 response.

For example, assume the following required manipulation:

- Manipulate Redirected number 6001 (originally called number) to 6005
- Manipulate Diverted-to number 8002 (the new called number or destination) to 8005

The configuration in the Redirect Number Tel-to-IP table is as follows:

**Table 26-6: Redirect Number Configuration Example**

Parameter	Rule 1	Rule 2
Destination Phone Pattern	RN	DN
Redirect Phone Pattern	6	8
Stripped Digits From Right	1	1
Suffix to Add	5	5
Number of Digits to Leave	5	-

After the above manipulation is done, the device sends the following outgoing SIP 302 response:

```
SIP/2.0 302 Moved Temporarily
Via: SIP/2.0/TLS 10.33.45.68;branch=z9hG4bKac54132643;alias
From: "MP118 1" <sip:8001@10.33.45.68>;tag=1c54119560
To: <sip:6001@10.33.45.69;user=phone>;tag=1c664560944
Call-ID: 541189832710201115142@10.33.45.68
CSeq: 1 INVITE
```

**Contact:** <sip:8005@10.33.45.68;user=phone>

Supported: em,timer,replaces,path,early-session,resource-priority

Allow:

REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE

**Diversion:** <tel:6005>;reason=unknown;counter=1

Server: Sip-Gateway/7.60A.100.022

Reason: SIP ;cause=302 ;text="302 Moved Temporarily"

Content-Length: 0

## Mapping NPI/TON to SIP Phone-Context

The Phone Contexts table lets you configure up to 20 rules for mapping the Numbering Plan Indication (NPI) and Type of Number (TON) to the SIP 'phone-context' parameter, and vice versa. The 'phone-context' parameter appears in the standard SIP headers where a phone number is used (i.e., Request-URI, To, From, and Diversion). When a call is received from the Tel side, the device searches the table for a matching rule (i.e., same NPI and TON values). If a matching rule is found, the device uses the rule's corresponding 'phone-context' value in the outgoing SIP INVITE message. The same mapping occurs when an INVITE with a 'phone-context' parameter is received.

For example, for a Tel-to-IP call with NPI/TON set as E164 National (values 1/2), the device can send the following SIP INVITE URI:

```
sip:12365432;phone-context=na.e.164.nt.com
```

For an IP-to-Tel call, if the incoming INVITE contains this 'phone-context' (e.g. "phone-context=na.e.164.nt.com"), the NPI/TON of the called number in the outgoing Setup message is changed to E164 National.

The following procedure describes how to configure NPI/TON-SIP phone-context mapping rules through the Web interface. You can also configure it through ini file [PhoneContext] or CLI (configure voip > gateway manipulation phone-context-table).

### ➤ To configure NPI/TON-SIP phone-context mapping rules:

1. Open the Phone Contexts table (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Manipulation** > **Phone Contexts**).
2. Click **New**; the following dialog box appears:

3. Configure a mapping rule according to the parameters described in the table below.

4. Click **Apply**.



- You can configure multiple rows with the same NPI/TON or same SIP 'phone-context'. In such a configuration, a Tel-to-IP call uses the first matching rule in the table.
- To add the incoming SIP 'phone-context' parameter as a prefix to the outgoing ISDN Setup message (for digital interfaces) with called and calling numbers, select the 'Add Phone Context As Prefix' check box ☒ [AddPhoneContextAsPrefix].

**Table 26-7: Phone Contexts table Parameter Description**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'NPI' npi [Npi]	Defines the Number Plan Indicator (NPI). <ul style="list-style-type: none"> <li><input checked="" type="checkbox"/> [0] <b>Unknown</b> (default)</li> <li><input checked="" type="checkbox"/> [1] <b>E.164 Public</b></li> <li><input checked="" type="checkbox"/> [9] <b>Private</b></li> </ul> For a detailed list of the available NPI/TON values, see <a href="#">Numbering Plans and Type of Number</a> on page 989.
'TON' ton [Ton]	Defines the Type of Number (TON). <ul style="list-style-type: none"> <li><input checked="" type="checkbox"/> [0] <b>Unknown</b></li> <li><input checked="" type="checkbox"/> [1] <b>International-Level2 Regional</b></li> <li><input checked="" type="checkbox"/> [2] <b>National-Level1 Regional</b></li> <li><input checked="" type="checkbox"/> [3] <b>Network-PSTN Specific</b></li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [4] <b>Subscriber-Level0 Regional</b></li> <li>■ [6] <b>Abbreviated</b></li> </ul> <p>The applicable values depend on the NPI value:</p> <ul style="list-style-type: none"> <li>■ If you select <b>Unknown</b> as NPI, you can select <b>Unknown</b>.</li> <li>■ If you select <b>Private</b> as NPI, you can select one of the following: <ul style="list-style-type: none"> <li>✓ [0] <b>Unknown</b></li> <li>✓ [1] <b>International-Level2 Regional</b></li> <li>✓ [2] <b>National-Level1 Regional</b></li> <li>✓ [3] <b>Network-PSTN Specific</b></li> <li>✓ [4] <b>Subscriber-Level0 Regional</b></li> </ul> </li> <li>■ If you select <b>E.164 Public</b> as NPI, you can select one of the following: <ul style="list-style-type: none"> <li>✓ [0] <b>Unknown</b></li> <li>✓ [1] <b>International-Level2 Regional</b></li> <li>✓ [2] <b>National-Level1 Regional</b></li> <li>✓ [3] <b>Network-PSTN Specific</b></li> <li>✓ [4] <b>Subscriber-Level0 Regional</b></li> <li>✓ [6] <b>Abbreviated</b></li> </ul> </li> </ul>
'SIP Phone-Context' context [Context]	Defines the SIP 'phone-context' URI parameter.

## Configuring Release Cause Mapping

When a call is disconnected, the reason for the disconnection (or call failure) is sent by the side (IP or Tel) on which the call disconnection occurred. From the IP side, a SIP response is sent (e.g., 406); from the Tel side, an ISDN cause code is sent (e.g., 6). You can configure ISDN-SIP release cause mapping rules, as discussed in this section.

### SIP-to-ISDN Release Cause Mapping

This section shows SIP-to-ISDN release cause mapping.

## Configuring SIP-to-ISDN Release Cause Mapping

The Release Cause Mapping from SIP to ISDN table lets you configure up to 12 SIP response code to ISDN ITU-T Q.850 release cause code (call failure) mapping rules. The table lets you override the default SIP-to-ISDN release cause mappings, listed in [Fixed Mapping of SIP Response to ISDN Release Reason](#) on the next page. When the device receives a SIP response from the IP side, it searches the table for a matching SIP response. If found, the device sends the corresponding Q.850 Release Cause to the PSTN. If the SIP response is not configured in the table, the default, fixed SIP-to-ISDN release reason mapping is used.



For Tel-to-IP calls, you can also map less commonly used SIP responses to a single, default ISDN release cause code, using the [DefaultCauseMapISDN2IP] parameter. The parameter defines a default ISDN cause code that is always used, except when the following Release Causes are received: Normal Call Clearing (16), User Busy (17), No User Responding (18) or No Answer from User (19).

The following procedure describes how to configure SIP-to-ISDN release cause mapping through the Web interface. You can also configure it through ini file [CauseMapSIP2ISDN] or CLI (configure voip > gateway manipulation cause-map-sip2isdn).

### ➤ To configure a SIP-to-ISDN release cause mapping rule:

1. Open the Release Cause Mapping from SIP to ISDN table (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Manipulation** > **Release Cause SIP > ISDN**).
2. Click **New**; the following dialog box appears:

The screenshot shows a web-based configuration dialog titled "Release Cause Mapping from SIP to ISDN". It features a "GENERAL" tab. Below the tab, there are three labeled input fields: "Index" containing the value "0", "SIP Response" containing the value "-1", and "Q.850 Causes" containing the value "-1". The dialog has standard window controls (minimize, maximize, close) in the top right corner.

3. Configure a mapping rule according to the parameters described in the table below.
4. Click **Apply**.

**Table 26-8: Release Cause Mapping from SIP to ISDN Table Parameter Descriptions**

Parameter	Description
'Index'	Defines an index number for the new table row.
[Index]	<b>Note:</b> Each row must be configured with a unique index.



Parameter	Description
'SIP Response' sip-response [SipResponse]	Defines the SIP response code. For example, you can enter "406" (without quotation marks) to represent the SIP 406 Not Acceptable response.
'Q.850 Causes' q850-causes [IsdnReleaseCause]	Defines the ISDN Q.850 cause code. For example, you can enter "6" (without quotation marks) to represent Cause Code 6 Channel Unacceptable.

### Fixed Mapping of SIP Response to ISDN Release Reason

The following table shows the mapping of SIP response to ISDN release reason.

**Table 26-9: Mapping of SIP Response to ISDN Release Reason**

SIP Response	Description	ISDN Release Reason	Description
400*	Bad request	31	Normal, unspecified
401	Unauthorized	21	Call rejected
402	Payment required	21	Call rejected
403	Forbidden	21	Call rejected
404	Not found	1	Unallocated number
405	Method not allowed	63	Service/option unavailable
406	Not acceptable	79	Service/option not implemented
407	Proxy authentication required	21	Call rejected
408	Request timeout	102	Recovery on timer expiry
409	Conflict	41	Temporary failure
410	Gone	22	Number changed w/o diagnostic
411	Length required	127	Interworking

SIP Response	Description	ISDN Release Reason	Description
413	Request entity too long	127	Interworking
414	Request URI too long	127	Interworking
415	Unsupported media type	79	Service/option not implemented
417	Unknown Resource Priority	127	Interworking
420	Bad extension	127	Interworking
480	Temporarily unavailable	18	No user responding
481*	Call leg/transaction doesn't exist	127	Interworking
482*	Loop detected	127	Interworking
483	Too many hops	127	Interworking
484	Address incomplete	28	Invalid number format
485	Ambiguous	1	Unallocated number
486	Busy here	17	User busy
488	Not acceptable here	31	Normal, unspecified
489	Bad Event	31	Normal, unspecified
491	Request Pending	31	Normal, unspecified
500	Server internal error	41	Temporary failure
501	Not implemented	38	Network out of order
502	Bad gateway	38	Network out of order
503	Service unavailable	41	Temporary failure
504	Server timeout	102	Recovery on timer expiry
505*	Version not supported	127	Interworking
600	Busy everywhere	17	User busy

SIP Response	Description	ISDN Release Reason	Description
603	Decline	21	Call rejected
604	Does not exist anywhere	1	Unallocated number
606*	Not acceptable	38	Network out of order

\* Messages and responses were created because the 'ISUP to SIP Mapping' draft doesn't specify their cause code mapping.

### SIP-to-ISDN Disconnect Release Cause Code Mapping

For trunks configured for the Japanese NTT ISDN PRI (T1) variant, you can configure the device to send an ISDN Disconnect message if it receives from the IP network a SIP 183 response with SDP that contains a specific cause value (SIP status code) in the Reason header, in response to an INVITE message. The device translates this cause code in the Release Cause field of the outgoing Disconnect message. After the device sends the Disconnect message, it can send early media (e.g., an announcement) received from the IP side to the ISDN. If after sending the Disconnect message the device receives a SIP failure response (e.g., 4xx) or a 200 OK from the IP side, it sends a Release message to the ISDN. However, you can configure the device to send the Release after a user-defined timeout, activated from when the Disconnect is sent, if no SIP message is received. The timeout is configured using the [ISDNJapanNttTimerT305] parameter. If the device receives a SIP failure response or 200 OK before the timeout expires, it sends the Release instead of waiting for the timeout to expire.

The above described behavior is configured using SIP Message Manipulation rules.



- This feature is applicable only to digital interfaces (T1 NTT protocol variant), and applies only to Tel-to-IP calls.
- For normal Disconnect scenarios (not due to SIP 183 with specific cause), you must configure the timer to 30 seconds, using the [TimeToWaitForPstnReleaseAck] parameter.

#### ➤ To configure the ISDN Disconnect feature:

1. Open the Message Manipulations table (see [Configuring SIP Message Manipulation](#) on page 829), and then configure the following SIP Message Manipulation rules:
  - Index #0:
    - ◆ 'Name': Clean var with cause
    - ◆ 'Manipulation Set ID': 0
    - ◆ 'Message Type': Invite.Request
    - ◆ 'Action Subject': Var.Call.Dst.0

- ◆ 'Action Type': Modify
- ◆ 'Action Value': '0'
- Index #1 (specifies the cause value in the SIP Reason header of the 18x response):
  - ◆ 'Name': Disconnect on 183 with cause
  - ◆ 'Manipulation Set ID': 1
  - ◆ 'Message Type': invite.response.18x
  - ◆ 'Condition': header.Reason.Reason.Cause == '1' or header.Reason.Reason.Cause == '22' or header.Reason.Reason.Cause == '31'
  - ◆ 'Action Subject': Var.Call.dst.0
  - ◆ 'Action Type': Modify
  - ◆ 'Action Value': header.Reason.Reason.Cause
- Index #2 (adds X-AC-Action header):
  - ◆ 'Name': Add X\_Action header
  - ◆ 'Manipulation Set ID': 1
  - ◆ 'Action Subject': Header.X-AC-Action
  - ◆ 'Action Type': Add
  - ◆ 'Action Value': 'SendPSTNDisconnect;Q850Cause='+var.Call.Dst.0
- Index #3 (if SIP 410 response, translate to 102 cause in ISDN message):
  - ◆ 'Name': Add reason if not exist
  - ◆ 'Manipulation Set ID': 1
  - ◆ 'Message Type': invite.response.410
  - ◆ 'Condition': Var.Call.Dst.0 != '0' and header.Reason !exists
  - ◆ 'Action Subject': header.Reason
  - ◆ 'Action Type': Add
  - ◆ 'Action Value': 'Q.850 ;cause=102 ; text="recovery of timer expiry"'
- Index #4:
  - ◆ 'Name': Translate 3xx to 500
  - ◆ 'Manipulation Set ID': 1
  - ◆ 'Message Type': invite.response.3xx
  - ◆ 'Condition': Var.Call.Dst.0 != '0'
  - ◆ 'Action Subject': Header.Request-URI.MethodType
  - ◆ 'Action Type': Modify

- ◆ 'Action Value': '500'
- Index #5:
  - ◆ 'Name': Add reason if not exist
  - ◆ 'Manipulation Set ID': 1
  - ◆ 'Condition': header.Reason !exists
  - ◆ 'Action Subject': Header.Reason
  - ◆ 'Action Type': Add
  - ◆ 'Action Value': 'Q.850 ;cause=31 ; text="normal, unspecified"'



The cause codes in the above Message Manipulation rules are used only as examples; you can define different cause codes according to your requirements.

2. Assign Manipulation Set #1 to inbound calls, by configuring the [GWInboundManipulationSet] parameter to [1].
3. Assign Manipulation Set #0 to outbound calls, by configuring the [GWOOutboundManipulationSet] parameter to [0].
4. (Optional) Configure how long the device must wait before sending an ISDN Release message if no SIP message is received, using the [ISDNJapanNttTimerT305] parameter. An explanation on this feature is described at the beginning of the section.



For Step 4, make sure that the [IPAlertTimeout] parameter value is greater than the [ISDNJapanNttTimerT305] parameter. If not, the device will use the timeout configured by the [IPAlertTimeout] parameter.

## ISDN-to-SIP Release Cause Mapping

This section shows ISDN-to-SIP release cause mapping.

### Configuring ISDN-to-SIP Release Cause Mapping

The Release Cause Mapping from ISDN to SIP table lets you configure up to 12 ISDN ITU-T Q.850 release cause code (call failure) to SIP response code mapping rules. The table lets you override the default ISDN-to-SIP release cause mappings, listed in [Fixed Mapping of ISDN Release Reason to SIP Response](#) on page 983. When the device receives an ISDN cause code from the PSTN side, it searches the table for a matching ISDN cause code. If found, the device sends the corresponding SIP response to the IP. If the ISDN cause code is not configured in the table, the default, fixed ISDN-to-SIP release reason mapping is used.



You can change the originally received ISDN cause code to any other ISDN cause code, using the Release Cause ISDN to ISDN table (see [Configuring ISDN-to-ISDN Release Cause Mapping](#) on page 987). If the originally received ISDN cause code appears in both the Release Cause ISDN to ISDN table and the Release Cause Mapping ISDN to SIP table, the mapping rule in the Release Cause Mapping ISDN to SIP table is ignored. The device only uses a mapping rule that matches the new ISDN cause code.

The following procedure describes how to configure ISDN-to-SIP release cause mapping through the Web interface. You can also configure it through ini file [CauseMapISDN2SIP] or CLI (configure voip > gateway manipulation cause-map-isdn2sip).

➤ **To configure a ISDN-to-SIP release cause mapping rule:**

1. Open the Release Cause Mapping from ISDN to SIP table (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Manipulation** > **Release Cause ISDN > SIP**).
2. Click **New**; the following dialog box appears:

3. Configure a mapping rule according to the parameters described in the table below.
4. Click **Apply**.

**Table 26-10:Release Cause Mapping from ISDN to SIP Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Q.850 Causes' q850-causes [IsdnReleaseCause]	Defines the ISDN Q.850 cause code. For example, you can enter "6" (without quotation marks) to represent Cause Code 6 Channel Unacceptable.
'SIP Response' sip-response [SipResponse]	Defines the SIP response code. For example, you can enter "406" (without quotation marks) to represent the SIP 406 Not Acceptable response.

## Fixed Mapping of ISDN Release Reason to SIP Response

The following table shows the mapping of ISDN release reason to SIP response.

**Table 26-11: Mapping of ISDN Release Reason to SIP Response**

ISDN Release Reason	Description	SIP Response	Description
1	Unallocated number	404	Not found
2	No route to network	404	Not found
3	No route to destination	404	Not found
4	Send Special Information Tone	400	Bad Request
5	Misdialed Trunk Prefix	400	Bad Request
6	Channel unacceptable	406*	Not acceptable
7	Call awarded and being delivered in an established channel	500	Server internal error
8	Preemption	480	Temporarily unavailable
9	Preemption - Circuit Reserved for Reuse	488	Not Acceptable Here
16	Normal call clearing	-*	BYE
17	User busy	486	Busy here
18	No user responding	408	Request timeout
19	No answer from the user	480	Temporarily unavailable
21	Call rejected	403	Forbidden
22	Number changed w/o diagnostic	410	Gone
23	Redirection	400	Bad Request
25	Exchange Routing Error	400	Bad Request

ISDN Release Reason	Description	SIP Response	Description
26	Non-selected user clearing	404	Not found
27	Destination out of order	502	Bad gateway
28	Address incomplete	484	Address incomplete
29	Facility rejected	501	Not implemented
30	Response to status enquiry	501*	Not implemented
31	Normal unspecified	480	Temporarily unavailable
32	Circuit Congestion	500	Server internal error
33	User Congestion	500	Server internal error
34	No circuit available	503	Service unavailable
38	Network out of order	503	Service unavailable
39	Permanent Frame Mode Connection Out-of-Service	503	Service unavailable
40	Permanent Frame Mode Connection Operational	503	Service unavailable
41	Temporary failure	503	Service unavailable
42	Switching equipment congestion	503	Service unavailable
43	Access information discarded	502*	Bad gateway
44	Requested channel not available	503*	Service unavailable



ISDN Release Reason	Description	SIP Response	Description
46	Precedence Call Blocked	488	Not Acceptable Here
47	Resource unavailable	503	Service unavailable
49	QoS unavailable	503*	Service unavailable
50	Facility not subscribed	503*	Service unavailable
53	Outgoing Calls Barred within CUG	488	Not Acceptable Here
55	Incoming calls barred within CUG	403	Forbidden
57	Bearer capability not authorized	403	Forbidden
58	Bearer capability not presently available	503	Service unavailable
62	Inconsistency In Outgoing Information Element	503	Service unavailable
63	Service/option not available	503*	Service unavailable
65	Bearer capability not implemented	501	Not implemented
66	Channel type not implemented	480*	Temporarily unavailable
69	Requested facility not implemented	503*	Service unavailable
70	Only restricted digital information bearer capability is available	503*	Service unavailable
79	Service or option not implemented	501	Not implemented

ISDN Release Reason	Description	SIP Response	Description
81	Invalid call reference value	502*	Bad gateway
82	Identified channel doesn't exist	502*	Bad gateway
83	Suspended call exists, but this call identity doesn't	503*	Service unavailable
84	Call identity in use	503*	Service unavailable
85	No call suspended	503*	Service unavailable
86	Call having the requested call identity has been cleared	408*	Request timeout
87	User not member of CUG	503	Service unavailable
88	Incompatible destination	503	Service unavailable
90	Non-Existent CUG	503	Service unavailable
91	Invalid transit network selection	502*	Bad gateway
95	Invalid message	503	Service unavailable
96	Mandatory information element is missing	409*	Conflict
97	Message type non-existent or not implemented	480*	Temporarily not available
98	Message not compatible with call state or message type non-existent or not implemented	409*	Conflict
99	Information element non-existent or not implemented	480*	Not found
100	Invalid information elements contents	501*	Not

ISDN Release Reason	Description	SIP Response	Description
			implemented
101	Message not compatible with call state	503*	Service unavailable
102	Recovery of timer expiry	408	Request timeout
103	Parameter Non-Existent Or Not Implemented - Passed On	400	Bad Request
110	Message With Unrecognized Parameter Discarded	400	Bad Request
111	Protocol error	500	Server internal error
112	Unknown Error	400	Bad Request
127	Interworking unspecified	500	Server internal error

\* Messages and responses were created because the 'ISUP to SIP Mapping' draft doesn't specify their cause code mapping.

## Configuring ISDN-to-ISDN Release Cause Mapping

The Release Cause ISDN to ISDN table lets you configure up to 10 ISDN ITU-T Q.850 release cause code (call failure) to ISDN ITU-T Q.850 release cause code mapping rules. In other words, it lets you change the originally received ISDN cause code to a different ISDN cause code. For example, the PSTN may indicate disconnected calls (hang up) by sending cause code 127. However, you can change the cause code to 16, which is a more typical cause code for such call scenarios. When the device receives an ISDN cause code from the PSTN side, it searches the table for a matching ISDN cause code. If found, the device changes the cause code to the corresponding ISDN cause code. If the ISDN cause code is not configured in the table, the originally received ISDN cause code is used. If the new ISDN cause code also appears in the Release Cause Mapping ISDN to SIP table (see [Configuring ISDN-to-SIP Release Cause Mapping](#) on page 981), the device maps it to the corresponding SIP response code, which it sends to the IP side.



If the originally received ISDN cause code is configured in both the Release Cause ISDN to ISDN table and the Release Cause Mapping ISDN to SIP table, the mapping rule with the originally received code in the Release Cause Mapping ISDN to SIP table is ignored; the device uses only the mapping rule in the Release Cause Mapping ISDN to SIP table that matches the new ISDN cause code. For example, if you configure a mapping rule in the Release Cause ISDN to ISDN table to change a received 127 code to 16, the device searches for a rule in the Release Cause Mapping ISDN to SIP table for an ISDN code of 16 (ignoring any entry with code 127).

The following procedure describes how to configure ISDN-to-ISDN release cause mapping through the Web interface. You can also configure it through ini file [CauseMapIsdn2Isdn] or CLI (configure voip > gateway manipulation cause-map-isdn2isdn).

➤ **To configure a ISDN-to-ISDN release cause mapping rule:**

1. Open the Release Cause Mapping from ISDN to ISDN table (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Manipulation** > **Release Cause ISDN** > **ISDN**).
2. Click **New**; the following dialog box appears:

3. Configure a mapping rule according to the parameters described in the table below.
4. Click **Apply**.

**Table 26-12:Release Cause Mapping ISDN to ISDN Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Orig. Q.850 Causes' orig-q850-cause [OrigIsdnReleaseCause]	Defines the originally received ISDN Q.850 cause code. For example, you can enter "127" (without quotation marks) to represent cause code 127 Interworking, Unspecified. The valid value (cause code) is 1 to 127.
'Map Q.850 Causes'	Defines the ISDN Q.850 cause code to which you want to

Parameter	Description
map-q850-cause [MapIsdnReleaseCause]	change the originally received cause code. For example, you can enter "16" (without quotation marks) to represent cause code 16 Normal Call Clearing. The valid value (cause code) is 1 to 127.

## SIP Reason Header for Release Cause

The device supports the SIP Reason header according to RFC 3326. The Reason header describes the disconnection cause of a call:

- **Sending Reason header:** If a call is disconnected from the Tel side (ISDN), the Reason header contains the value of the received Q.850 cause in the appropriate message (BYE/CANCEL/final failure response) and sent to the IP side. If the call is disconnected because of a SIP reason, the Reason header is set to the appropriate SIP response.
- **Receiving Reason header:** If a call is disconnected from the IP side and the SIP message includes the Reason header, it is sent to the Tel side according to the following logic:
  - If the Reason header includes a Q.850 cause, it is sent as is.
  - If the Reason header includes a SIP response:
    - ◆ If the message is a final response, the response status code is translated to Q.850 format and passed to ISDN.
    - ◆ If the message isn't a final response, it is translated to a Q.850 cause.
  - When the Reason header is received twice (i.e., SIP Reason and Q.850), the Q.850 takes precedence over the SIP reason and is sent to the Tel side.

## Numbering Plans and Type of Number

The IP-to-Tel destination or source number manipulation tables allow you to classify numbers by their Numbering Plan Indication (NPI) and Type of Number (TON). The device supports all NPI/TON classifications used in the ETSI ISDN variant, as shown in the table below:

**Table 26-13:NPI/TON Values for ETSI ISDN Variant**

NPI	TON	Description
Unknown [0]	Unknown [0]	A valid classification, but one that has no information about the numbering plan.

NPI	TON	Description
E.164 Public [1]	Unknown [0]	A public number in E.164 format, but no information on what kind of E.164 number.
	International-Level2 Regional [1]	A public number in complete international E.164 format, e.g., 16135551234.
	National-Level1 Regional [2]	A public number in complete national E.164 format, e.g., 6135551234.
	Network-PSTN Specific [3]	The type of number "network specific number" is used to indicate administration / service number specific to the serving network, e.g., used to access an operator.
	Subscriber-Level0 Regional [4]	A public number in complete E.164 format representing a local subscriber, e.g., 5551234.
	Abbreviated [6]	The support of this code is network

NPI	TON	Description
		dependent. The number provided in this information element presents a shorthand representation of the complete number in the specified numbering plan as supported by the network.
Private [9]	Unknown [0]	A private number, but with no further information about the numbering plan.
	International-Level2 Regional [1]	-
	National-Level1 Regional [2]	A private number with a location, e.g., 3932200.
	PISN Specific [3]	-
	Subscriber-Level0 Regional [4]	A private local extension number, e.g., 2200.

For NI-2 and DMS-100 ISDN variants, the valid combinations of TON and NPI for calling and called numbers include (Plan/Type):

- 0/0 - Unknown/Unknown
- 1/1 - International number in ISDN/Telephony numbering plan
- 1/2 - National number in ISDN/Telephony numbering plan
- 1/4 - Subscriber (local) number in ISDN/Telephony numbering plan
- 9/4 - Subscriber (local) number in Private numbering plan

## 27 Configuring DTMF and Dialing

This section describes configuration of dual-tone multi-frequency (DTMF) and dialing for the Gateway application.

### Dialing Plan Features

This section describes various dialing plan features.

#### Digit Mapping

You can use digit mapping to determine when the device stops collecting the digits of a dialed phone number from the Tel side (caller), after which it uses them for the destination number to establish the call. Digit mapping is typically used for closed numbering schemes.

The device stops collecting digits and starts sending the digits upon any of the following scenarios:

- **The maximum number of digits is received:** You can configure the maximum number of collected digits that can be received from the Tel side. When the number of collected digits reaches this maximum (or a digit map pattern is matched before the maximum), the device stops collecting more digits and uses the collected digits for the called destination number. To configure the maximum number of collected digits, use the [MaxDigits parameter] parameter.
- **The inter-digit timeout expires (e.g., for open numbering schemes):** The inter-digit timeout is the time that the device waits between each received (collected) digit. When the timeout expires, the device stops collecting more digits and uses the collected digits for the called destination number. To configure the timeout, use the [TimeBetweenDigits] parameter.
- **The digits match one of the digit map patterns:** Digit map (pattern) rules are configured by the [DigitMapping] parameter. The digit map pattern can contain up to 52 options (rules), each separated by a vertical bar ("|"). The maximum length of the entire digit pattern is 152 characters. The digit mapping notations are described in the following table:

**Table 27-1: Digit Map Pattern Notations**

Notation	Description
[n-m]	Range of numbers (e.g., "1-7").
.	(Single dot) Repeat digits until the next notation (e.g., T).
x	Any single digit. <b>Note:</b> This notation doesn't apply to some scenarios when using the * or # key. For example, the key sequence of "***" must be presented in the dial plan as "*x.s" (instead of xx).



Notation	Description
<b>T</b>	Dial timeout between received digits, which is configured by the [TimeBetweenDigits] parameter.
<b>S</b>	Short timeout between received digits, which is configured by the [TimeBetweenDigits] parameter whose value is then divided by 2. For example, if you leave the parameter at its default (i.e., 4), then the short timeout is 2 (i.e., 4 divided by 2). You can use the short timeout when you configure a specific rule after a more general rule. For example, if the digit map is "99 998", the device terminates digit collection when the first two 9 digits are received. Therefore, the second rule "998" can never be matched. But if you configure the digit map as "99S 998", then after the first two 9 digits are dialed, the device waits another two seconds, within which the caller can dial the digit 8.

Below is an example of a digit map containing eight rules:

```
DigitMapping = 11xS|00[1-7]xxx|8xxxxxxx|#xxxxxxx|*xx|91xxxxxxx|9011x|9011x.T
```

In the example, the rule:

- "00[1-7]xxx" denotes dialed numbers that begin with 00, and then any digit from 1 through 7, followed by three digits (of any number). Once the device receives these digits, it doesn't wait for additional digits, but starts sending the collected digits (dialed number) immediately.
- "9011x.T" can apply to International numbers where 9 is for the dialing tone, 011 the country code, and then any number of digits for the local number.

Digit maps are used for Tel-to-IP ISDN overlap dialing (by configuring the [ISDNRxOverlap] parameter to 1) to reduce the dialing period. For more information, see [ISDN Overlap Dialing](#) on page 899.



- If you want the device to accept any number, make sure that the digit map contains the rule "xx.T"; otherwise, the device rejects all dialed numbers that can't be matched to any digit map.
- If you are using an external Dial Plan file for dialing plans (see Digit Mapping), the device first attempts to locate a matching digit pattern in the Dial Plan file. Only if not found, does the device search for a matching digit pattern in the digit map.
- It may be useful to configure both Dial Plan file and digit maps. For example, the digit map can be used for complex digit patterns (which are not supported by the Dial Plan) and the Dial Plan can be used for long lists of relatively simple digit patterns. In addition, as timeout between digits is not supported by the Dial Plan, the digit map can be used to configure digit patterns that are shorter than those configured in the Dial Plan ( [MaxDigits] parameter) or left at default. For example, the digit map "xx.T" uses the Dial Plan and if no matching digit pattern is found, the device waits for two more digits and then after a timeout ([TimeBetweenDigits] parameter), it sends the collected digits. Therefore, this ensures that calls are not rejected as a result of their digit pattern not been completed in the Dial Plan.

## Dial Plan Rules

You can configure dialing plans by using Dial Plan rules or loading a Dial Plan file. For more information, see [Configuring Dial Plans](#) on page 798.

## Interworking Keypad DTMFs for SIP-to-ISDN Calls

The device can interwork DTMF tones received from the IP to the PSTN, using the ISDN Keypad Facility information element (IE) in Q.931 INFORMATION messages.



The feature is applicable only to the Euro ISDN variant (User side).

If the device receives from the IP side an INVITE message whose called party number (To header) contains the asterisk (\*) or pound (#) character, or a SIP NOTIFY or SIP INFO message that contains these characters (e.g., 123#456), the device sends the character and the digits positioned to its right, as Keypad IE in the INFORMATION message. The device sends only the digits positioned before the character to the PSTN (in SETUP message) as the called party number. For example, if the device receives the below INVITE, it sends "123" to the PSTN as the called party number and #456 as Keypad IE in the INFORMATION message:

```
INVITE sip:%7B54443994-BDFF-413C-AE4F-
D039B0FFB134%7D@192.168.100.214:5064;transport=tcp;rinstance=9f25c4452
eff4acb SIP/2.0
To: sip:123#456@192.168.100.214;user=phone;x-type=unknown;x-
plan=unknown;x-pres=allowed
```

The destination number can be manipulated when this feature is enabled. Note that if manipulation before routing is required, the \* and # characters should not be used, as the device will handle them according to the above keypad protocol. For example, a manipulation rule should not be configured to add #456 to the destination number. If manipulation after routing is required, the destination number to be manipulated will not include the keypad part. For example, if you configure a manipulation rule to add the suffix 888 and the received INVITE contains the number 123#456, only 123 is manipulated and the number dialed toward the PSTN is 123888; #456 is sent as keypad.

To enable this feature, use the ISDNKeypadMode parameter.

## Configuring Hook Flash

The following procedure describes how to configure various hook-flash features.

### ➤ To configure hook-flash features:

1. Configure the digit pattern used by the Tel side to indicate a hook-flash event:
  - a. Open the Supplementary Services Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **DTMF & Supplementary** > **Supplementary Services Settings**).
  - b. In the 'Hook-Flash Code' (HookFlashCode) field, enter the digit pattern.

Hook-Flash Code

- c. Click **Apply**.
2. Configure the hook-flash transport type:
  - a. Open the DTMF & Dialing page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **DTMF & Supplementary** > **DTMF & Dialing**).
  - b. From the 'Hook-Flash Option' (HookFlashOption) drop-down list, select the required transport type.

Hook-Flash Option

Not Supported ▼

- c. Click **Apply**.

## 28 Configuring Supplementary Services

This section describes the Gateway application's SIP supplementary services that can enhance your telephone service.



- All call participants must support the specific supplementary service that is used.
- When working with certain application servers (such as BroadSoft's BroadWorks) in client server mode (the application server controls all supplementary services and keypad features by itself), the device's supplementary services must be disabled.

### Call Hold and Retrieve

Call hold and retrieve:

- The party that initiates the hold is called the *holding* party; the other party is called the *held* party.
- After a successful Hold, the holding party hears a dial tone (HELD\_TONE defined in the device's Call Progress Tones file).
- After a successful retrieve, the voice is connected again.
- The hold and retrieve functionalities are implemented by re-INVITE messages. The IP address 0.0.0.0 as the connection IP address or the string 'a=inactive' in the received re-INVITE SDP cause the device to enter Hold state and to play the held tone (configured in the device) to the PBX/PSTN. If the string 'a=sendonly' is received in the SDP message, the device stops sending RTP packets, but continues to listen to the incoming RTP packets. Usually, the remote party plays, in this scenario, Music on Hold (MOH) and the device forwards the MOH to the held party.

You can also configure the device to keep a call on-hold for a user-defined time after which the call is disconnected, using the [HeldTimeout] parameter.



When the Tel side puts the call on hold (hookflash), the device plays a dial tone to the Tel side (dial tone timeout starts according to the 'Dial Tone Duration' parameter, which is 16 sec. by default), expecting the Tel side to do some action (e.g., make another call, conferencing, or call transfer). If the 'Dial Tone Duration' parameter expires as no DTMF digits were collected (i.e., Tel side did nothing), the device plays a congestion tone to the Tel side (and if the Tel side goes on-hook, the phone rings and if the Tel side then goes off-hook, the IP side is retrieved).

### Call Transfer

This section describes configuration of call transfer for the Gateway application.

## Consultation Call Transfer

The device supports Consultation Call Transfer.

The common method to perform consultation transfer is described in the following example, which assumes three call parties:

- A = transferring party
  - B = transferred party
  - C = transferred to party
1. A Calls B.
  2. B answers.
  3. A presses the hook-flash button and places B on-hold (party B hears a hold tone).
  4. A dials C.
  5. After A completes dialing C, A on-hooks the phone to transfer the call so that the call is established between B and C.

The transfer can be initiated at any of the following stages of the call between A and C:

- Immediately after A completes dialing C (transfer at call setup)
- While A hears a ringback (transfer from alert)
- While A speaks to C (transfer from active)

The Explicit Call Transfer (ECT, according to ETS-300-367, 368, 369) supplementary service is supported for PRI trunks. This service provides the served user who has two calls to ask the network to connect these two calls together and release its connection to both parties. The two calls can be incoming or outgoing calls. This service is similar to NI-2 Two B-Channel Transfer (TBCT) Supplementary Service. The main difference is that in ECT one of the calls must be in HELD state. The ECT standard defines two methods - Implicit and Explicit. In implicit method, the two calls must be on the same trunk. PRI uses the explicit mechanism.

## Consultation Transfer for QSIG Path Replacement

The device can interwork consultation call transfer requests for ISDN QSIG-to-IP calls. When the device receives a request for a consultation call transfer from the PBX, the device sends a SIP REFER message with a Replaces header to the SIP UA to transfer it to another SIP UA. Once the two SIP UA parties are successfully connected, the device requests the PBX to disconnect the ISDN call, thereby freeing resources on the PBX.

For example, assume legacy PBX user "A" has two established calls connected through the device – one with remote SIP UA "B" and the other with SIP UA "C". In this scenario, user "A" initiates a consultation call transfer to connect "B" with "C". The device receives the consultation call transfer request from the PBX and then connects "B" with "C", by sending "B" a REFER message with a Replaces header (i.e., replace caller "A" with "C"). Upon receipt of a SIP

NOTIFY 200 message in response to the REFER, the device sends a Q.931 Disconnect messages to the PBX, notifying the PBX that it can disconnect the ISDN calls (of user "A").

This feature is enabled by the QSIGPathReplacementMode parameter.

## Blind Call Transfer

Blind call transfer is done (using SIP REFER messages) after a call is established between call parties A and B, and party A decides to immediately transfer the call to C without first speaking to C. The result of the transfer is a call between B and C (similar to consultation transfer, but skipping the consultation stage).

You can also use the ManipulateIP2PSTNReferTo parameter to manipulate the destination number according to the number received in the SIP Refer-To header. This is applicable to all types of blind transfers to the PSTN (e.g., TBCT, ECT, RLT, QSIG, FXO, and CAS). During blind transfer, the device initiates a new call to the PSTN and the destination number of this call can be manipulated if the parameter is enabled. The following is an example of such a blind transfer:

1. IP phone A calls PSTN phone B, and the call is established.
2. A performs a blind transfer to PSTN phone C. It does this as follows:
  - a. A sends a SIP REFER message (with the phone number of C in the Refer-To header) to the device.
  - b. The device sends a Q.931 Setup message to C. This feature enables manipulating the called party number in this outgoing Setup message.

The manipulation is done as follows:

1. If you configure a value for the xferPrefix parameter, the value (string) is added as a prefix to the number in the Refer-To header.
2. This called party number is then manipulated using the Destination Phone Number Manipulation for IP-to-Tel Calls table.
3. The source number of the transferred call is taken from the original call, according to its initial direction:
  - Tel-to-IP call: source number of the original call.
  - IP-to-Tel call: destination number of the original call.
  - If the UseReferredByForCallingNumber parameter is set to 1, the source number is taken from the SIP Referred-By header if included in the received SIP REFER message.

This source number can also be used as the value for the 'Source Phone Pattern' field in the Destination Phone Number Manipulation for IP-to-Tel Calls table. The local IP address is used as the value for the 'Source IP Address' field.



Manipulation using the ManipulateIP2PSTNReferTo parameter doesn't affect IP-to-Trunk Group routing rules.

## Call Forward

The device supports Call Deflection (ETS-300-207-1) for Euro ISDN and QSIG (ETSI TS 102 393) for Network and User sides, which provides IP-ISDN interworking of call forwarding (call diversion) when the device receives a SIP 302 response.

Call forward performed by the SIP side: Upon receipt of a Facility message with Call Rerouting IE from the PSTN, the device initiates a SIP transfer process by sending a SIP 302 (including the Call Rerouting destination number) to the IP in response to the remote SIP entity's INVITE message. The device then responds with a Disconnect message to the PSTN side.

Call forward performed by the PSTN side: When the device sends the INVITE message to the remote SIP entity and receives a SIP 302 response, the device sends a Facility message with the same IE mentioned above to the PSTN, and waits for the PSTN side to disconnect the call. This is configured using the CallReroutingMode.



- When call forward is initiated, the device sends a SIP 302 response with a contact that contains the phone number from the Call Forward table (see Configuring Call Forward) and its corresponding IP address from the routing table (or when a proxy is used, the proxy's IP address).
- For receiving call forward, the device handles SIP 3xx responses for redirecting calls with a new contact.

## Enabling Call Forwarding

The following procedure describes how to enable call forwarding.

### ➤ To enable call forwarding:

1. Open the Supplementary Services Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **DTMF & Supplementary** > **Supplementary Services Settings**).
2. Select the 'Enable Call Forward' check box (EnableForward):

Enable Call Forward



3. Click **Apply**.

## Message Waiting Indication

The device supports Message Waiting Indication (MWI) according to IETF RFC 3842. The device also supports subscribing to an MWI server (using SIP SUBSCRIBE messages).



For more information on configuring IP-based voice mail, refer to the *IP Voice Mail CPE Configuration Guide*.

To configure MWI, use the following parameters:

- EnableMWI
- MWIServerIP, or MWISubscribeIPGroupID and ProxySet
- EnableMWISubscription
- MWIExpirationTime
- SubscribeRetryTime
- SubscriptionMode
- VoiceMailInterface
- EnableVMURI

The device supports the following PSTN-based (digital) MWI features:

- Euro-ISDN MWI: The device supports Euro-ISDN MWI for IP-to-Tel calls. The device interworks SIP MWI NOTIFY messages to Euro-ISDN Facility information element (IE) MWI messages. This is configured by setting the VoiceMailInterface parameter to 8.
- ISDN PRI NI-2: The device support the interworking of the SIP MWI NOTIFY messages to ISDN PRI NI-2 Message Waiting Notification (MWN), sent in the ISDN Facility IE message. This is applicable when the device is connected to a PBX through an ISDN PRI trunk configured to NI-2. This is configured by setting the VoiceMailInterface parameter to [9].
- QSIG MWI: The device supports the interworking of QSIG MWI to IP (in addition to interworking of SIP MWI NOTIFY to QSIG Facility MWI messages). This provides interworking between an ISDN PBX with voice mail capabilities and a softswitch, which requires information on the number of messages waiting for a specific user. To enable this feature, use the 'MWI Interrogation Type' parameter in the Trunk Group Settings table, which defines the device's handling of MWI Interrogation messages. The process for sending the MWI status upon request from a softswitch is as follows:
  - a. The softswitch sends a SIP SUBSCRIBE message to the device.
  - b. The device responds by sending an empty SIP NOTIFY to the softswitch, and then sending an ISDN Setup message with Facility IE containing an MWI Interrogation request to the PBX.
  - c. The PBX responds by sending to the device an ISDN Connect message containing Facility IE with an MWI Interrogation result, which includes the number of voice messages waiting for the specific user.
  - d. The device sends another SIP NOTIFY to the softswitch, containing this MWI information.



- e. The SIP NOTIFY messages are sent to the IP Group defined by the [NotificationIPGroupName] parameter.

When a change in the status occurs (e.g., a new voice message is waiting or the user has retrieved a message from the voice mail), the PBX initiates an ISDN Setup message with Facility IE containing an MWI Activate request, which includes the new number of voice messages waiting for the user. The device forwards this information to the softswitch by sending a SIP NOTIFY.

Depending on PBX support, the MWIInterrogationType parameter can be configured to handle these MWI Interrogation messages in different ways. For example, some PBXs support only the MWI Activate request (and not MWI Interrogation request). Some support both these requests. Therefore, the device can be configured to disable this feature or enable it with one of the following support:

- Responds to MWI Activate requests from the PBX by sending SIP NOTIFY MWI messages (i.e., doesn't send MWI Interrogation messages).
- Send MWI Interrogation message, but don't use its result. Instead, wait for MWI Activate requests from the PBX.
- Send MWI Interrogation message, use its result, and use the MWI Activate requests.

## Emergency E911 Phone Number Services

This section describes the device's support for emergency phone number services.

### Pre-empting Existing Calls for E911 IP-to-Tel Calls

If the device receives an emergency call (E911) from the IP network destined to the Tel and there are unavailable channels (e.g., all busy), the device terminates one of the current calls (arbitrary) and then sends the emergency call to that channel. The preemption is done only on a channel belonging to the same Trunk Group for which the emergency call was initially destined and if the 'Channel Select Mode' parameter (ChannelSelectMode) is configured with a value other than **By Dest Phone Number** (0). Call preemption is done only if the incoming IP-to-Tel call is identified as an emergency call.

#### ➤ To configure call preemption for emergency calls:

1. Enable call preemption for emergency calls:
  - **For all calls:** Open the Priority & Emergency page (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **Priority and Emergency**), and then from the 'Call Priority Mode' drop-down list (CallPriorityMode), select **Emergency**:

Call Priority Mode Emergency ▼

- **For specific calls:** Open the Tel Profiles table (see [Configuring Tel Profile](#) on page 738), and then for the required Tel Profile, configure the 'Call Priority Mode' drop-down list to **Emergency**.

2. Configure the [EmergencyCallAlertInfoUri] parameter with a value that if the SIP Alert-Info header in the incoming INVITE message contains the same value, then the INVITE is considered an emergency call. If not configured, the call is not considered an emergency call (even if the header is present).
3. (Optional) Block device restarts that are triggered through CLI (`reload` command) during and after emergency calls, by configuring the [ReloadTimeoutForEmergencyCall] parameter to a non-zero value. This value is the duration for blocking restarts after the call has ended (regardless of whether it was successfully established or not). A value of -1 disables this feature.
4. (Optional) Configure emergency telephone numbers (e.g., 911). Open the Priority & Emergency page (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **Priority and Emergency**), and then in the 'Emergency Number' fields (EmergencyNumbers), configure the emergency numbers:

Emergency Number 1	<input type="text" value="911"/>
Emergency Number 2	<input type="text"/>
Emergency Number 3	<input type="text"/>
Emergency Number 4	<input type="text"/>

The device identifies the IP-to-Tel call as an emergency call if the destination number matches one of these configured emergency numbers. For E911, you must configure the parameter to "911".



- The feature is applicable to the following interfaces:
  - ✓ ISDN
  - ✓ CAS
- The device also identifies emergency calls if the Priority header of the incoming SIP INVITE message contains the "emergency" value.
- For Trunk Groups configured with call preemption, you must configure all to **MLPP** or all to **Emergency**.
- If you are using a Tel Profile, you must configure the 'Call Priority Mode' parameter in the Tel Profile table and on the Priority & Emergency page with the same value; otherwise, the Tel Profile parameter is not applied.
- If you configure call preemption using the global parameter, and you subsequently add a new Tel Profile, the Tel Profile parameter 'Call Priority Mode' automatically acquires the same setting.

## Multilevel Precedence and Preemption

The device supports Multilevel Precedence and Preemption (MLPP) service. MLPP is a call priority scheme, which does the following:

- Assigns a precedence level (priority level) to specific phone calls or messages.

- Allows higher priority calls (*precedence call*) and messages to preempt lower priority calls and messages (i.e., terminates existing lower priority calls) that are recognized within a user-defined domain (*MLPP domain ID*). The domain specifies the collection of devices and resources that are associated with an MLPP subscriber. When an MLPP subscriber that belongs to a particular domain places a precedence call to another MLPP subscriber that belongs to the same domain, MLPP service can preempt the existing call that the called MLPP subscriber is on for a higher-precedence call. MLPP service availability doesn't apply across different domains.

MLPP is typically used in the military where, for example, high-ranking personnel can preempt active calls during network stress scenarios such as a national emergency or degraded network situations.

MLPP can be enabled for all calls, using the global parameter, *CallPriorityMode*, or for specific calls using the Tel Profile parameter, *CallPriorityMode*.



- For digital interfaces, MLPP is applicable only to PRI interfaces.
- The device provides MLPP interworking between SIP and ISDN (both directions).
- For Trunk Groups configured with call preemption, you must configure all to **MLPP** or all to **Emergency**.
- The global parameter must be set to the same value as that of the Tel Profile parameter; otherwise, the Tel Profile parameter is not applied.
- If you configure call preemption using the global parameter, and you subsequently add a new Tel Profile, the Tel Profile parameter 'Call Priority Mode' automatically acquires the same setting.
- If required, you can exclude the "resource-priority" tag from the SIP Require header in INVITE messages for Tel-to-IP calls when MLPP priority call handling is used. This is configured using the [RPRequired] parameter.
- For a complete list of the MLPP parameters, see [MLPP and Emergency Call Parameters](#) on page 1806.

The Resource Priority value in the Resource-Priority SIP header can be any one of those listed in the table below.

A default MLPP call Precedence Level (configured by the *SIPDefaultCallPriority* parameter) is used if the incoming SIP INVITE or ISDN Setup message contains an invalid priority or Precedence Level value respectively.

For each MLPP call priority level, the Multiple Differentiated Services Code Points (DSCP) can be set to a value from 0 to 63.

**Table 28-1: MLPP Call Priority Levels (Precedence) and DSCP Configuration Parameters**

MLPP Precedence Level	Precedence Level in Resource-Priority SIP Header	DSCP Configuration Parameter
0 (lowest)	routine	MLPPRoutineRTPDSCP
2	priority	MLPPPRIORITYRTPDSCP

MLPP Precedence Level	Precedence Level in Resource-Priority SIP Header	DSCP Configuration Parameter
4	immediate	MLPPImmediateRTPDSCP
6	flash	MLPPFlashRTPDSCP
8	flash-override	MLPPFlashOverRTPDSCP
9 (highest)	flash-override-override	MLPPFlashOverOverRTPDSCP

The device automatically interworks the network identity digits (NI) in the ISDN Q.931 Precedence Information Element (IE) to the network domain subfield of the INVITE's Resource-Priority header, and vice versa. The SIP Resource-Priority header contains two fields, namespace and priority. The namespace is subdivided into two subfields, network-domain and precedence-domain. Below is an example of a Resource-Priority header whose network-domain subfield is "uc", r-priority field is "priority" (2), and precedence-domain subfield is "000000":

Resource-Priority: uc-000000.2

The MLPP Q.931 Setup message contains the Precedence IE. The NI digits are presented by four nibbles found in octets 5 and 6. The device checks the NI digits according to the translation table of the Department of Defense (DoD) Unified Capabilities (UC) Requirements (UCR 2008, Changes 3) document, as shown below:

**Table 28-2: NI Digits in ISDN Precedence**

Level IE	Network Domain in SIP Resource-Priority Header
0000	uc
0001	cuc
0002	dod
0003	nato



- If the received ISDN message contains NI digits that are not listed in the translation table, the device sets the network-domain to "uc" in the outgoing SIP message.
- If the received SIP message contains a network-domain value that is not listed in the translation table, the device sets the NI digits to "0000" in the outgoing ISDN message.
- If the received ISDN message doesn't contain a Precedence IE, you can configure the namespace value - dsn (default), dod, drsn, uc, or cuc - in the SIP Resource-Priority header of the outgoing INVITE message. This is done using the MLPPDefaultNamespace parameter. You can also configure up to 32 user-defined namespaces, using the table ini file parameter, ResourcePriorityNetworkDomains. Once defined, you need to set the MLPPDefaultNamespace parameter value to the desired table row index.

By default, the device maps the received Resource-Priority field of the SIP Resource-Priority header to the outgoing ISDN Precedence Level (priority level) field as follows:

- If the network-domain field in the Resource-Priority header is "uc", then the device sets the Precedence Level field in the ISDN Precedence Level IE according to Table 5.3.2.12-4 (Mapping of RPH r-priority Field to ISDN Precedence Level Value):

**Table 28-3: Mapping of SIP Resource-Priority Header to ISDN Precedence Level for MLPP**

MLPP Precedence Level	ISDN Precedence Level	SIP Resource-Priority Header Field
Routine	4	0
Priority	3	2
Immediate	2	4
Flash	1	6
Flash Override	0	8

- If the network-domain field in the Resource-Priority header is any value other than "uc", then the device sets the Precedence Level field to "0 1 0 0" (i.e., "routine").

This can be modified using the EnableIp2TelInterworkingtable field of the ini file parameter, ResourcePriorityNetworkDomains.

## MLPP Preemption Events in SIP Reason Header

The device sends the SIP Reason header (as defined in RFC 4411) to indicate the reason and type of a preemption event. The device sends a SIP BYE or CANCEL request, or SIP 480, 486, 488 response (as appropriate) with a Reason header whose Reason-params can includes one of the following preemption cause classes:

- Reason: preemption ;cause=1 ;text="UA Preemption"

- Reason: preemption ;cause=2 ;text="Reserved Resources Preempted"
- Reason: preemption ;cause=3 ;text="Generic Preemption"
- Reason: preemption ;cause=4 ;text="Non-IP Preemption"

This Reason cause code indicates that the session preemption has occurred in a non-IP portion of the infrastructure. The device sends this code in the following scenarios:

- The device performs a network preemption of a busy call (when a high priority call is received), the device sends a SIP BYE or CANCEL request with this Reason cause code.
- The device performs a preemption of a B-channel for a Tel-to-IP outbound call request from the softswitch for which it has not received an answer response (e.g., Connect), and the following sequence of events occurs:
  - i. The device sends a Q.931 DISCONNECT over the ISDN MLPP to the partner switch to preempt the remote end instrument.
  - ii. The device sends a 488 (Not Acceptable Here) response with this Reason cause code.

- Reason: preemption; cause=5; text="Network Preemption"

This Reason cause code indicates preempted events in the network. Within the Defense Switched Network (DSN) network, the following SIP request messages and response codes for specific call scenarios have been identified for signaling this preemption cause:

- SIP:BYE - If an active call is being preempted by another call
- CANCEL - If an outgoing call is being preempted by another call
- 480 (Temporarily Unavailable), 486 (User Busy), 488 (Not Acceptable Here) - Due to incoming calls being preempted by another call.

The device receives SIP requests with preemption reason cause=5 in the following cases:

- The softswitch performs a network preemption of an active call - the following sequence of events occurs:
  - i. The softswitch sends the device a SIP BYE request with this Reason cause code.
  - ii. The device initiates the release procedures for the B-channel associated with the call request and maps the preemption cause to ISDN Cause = #8 'Preemption'. This value indicates that the call is being preempted. For ISDN, it also indicates that the B-channel is not reserved for reuse.
  - iii. The device sends a SIP 200 OK in response to the received BYE, before the SIP end instrument can proceed with the higher precedence call.
- The softswitch performs a network preemption of an outbound call request for the device that has not received a SIP 2xx response - the following sequence of events occur:
  - i. The softswitch sends the device a SIP 488 (Not Acceptable Here) response code with this Reason cause code. The device initiates the release procedures for the B-

channel associated with the call request and maps the preemption cause to ISDN Cause = #8 'Preemption'.

- ii. The device deactivates any user signaling (e.g., ringback tone) and when the call is terminated, it sends a SIP ACK message to the softswitch.

## Precedence Ring Tone

You can configure the duration for which the device plays a preemption tone to the Tel and IP sides if a call is preempted, using the [PreemptionToneDuration] parameter.

## Detecting Collect Calls

The device detects collect calls (reverse charge calls) using any of the following information elements (IE) in the received Q.931 ISDN Setup message for Tel-to-IP calls:

- Reverse Charging Indication IE
- Facility IE

When the device detects a collect call, it adds a proprietary header (*X-Siemens-Call-Type: collect call*) to the outgoing SIP INVITE message.

No special configuration is required for the feature.



The feature is applicable only to the Euro ISDN protocol variant.

## Advice of Charge Services for Euro ISDN

Advice of charge (AOC) is a pre-billing function that tasks the rating engine with calculating the cost of using a service and relaying that information back to the customer (caller). This allows users to obtain call charging information periodically during the call (AOC-D) or at the end of the call (AOC-E).

AOC messages are sent in the EURO ISDN Facility Information Element (IE) message. The device interworks these ISDN messages with SIP by converting the AOC messages into SIP INFO (during call) and BYE messages (end of call) using the AudioCodes proprietary SIP AOC header, and vice versa. The device supports both currency (monetary units) and pulse (non-monetary units) AOC messages.

This feature can typically be implemented in the hotel industry, where external calls made by guests can be billed accurately. In such a setup, the device is connected on one side to a PBX through an ISDN line (Euro ISDN), and on the other side to a SIP trunk provided by an ITSP. When a call is made by a guest, the device first sends an AOC-D Facility message to the PBX indicating the connection charge unit, and then sends subsequent AOC-D messages every user-defined interval to indicate the charge unit during the call. When the call ends, the device sends an AOC-E Facility message to the PBX indicating the total number of charged units.



The feature is applicable only to Euro ISDN PRI .

The device supports various AOC methods:

- **Tel-to-IP Direction:** The device converts the AOC messages received in the EURO ISDN Facility IE messages into SIP INFO and BYE messages using the proprietary SIP AOC header.
- **Device Generation of AOC to Tel:** The device generates the metering tones according to user-defined amounts, intervals, currency type, and multiplier. For more information, see [Configuring Charge Codes](#) on page 1010.
- **IP-to-Tel Direction:**
  - SIP-to-Tel interworking: The device uses the AOC header from the IP side and sends to Tel in EURO ISDN Facility IE messages. Below shows the SIP AOC header:

```
AOC: charged; <parameters>
```

Where parameters can be:

- ◆ state="active" or "terminated"
- ◆ charging-info="currency" or "pulse"

If "currency", the following parameters are available:

- ◆ currency=<string>
- ◆ currency-type="iso4217-a" or <string>
- ◆ amount=<number>
- ◆ multiplier=("0.001","0.01","0.1","1","10","100","1000")

If "pulse", the following parameter is available:

- ◆ recorded-units=<number>

The device can also receive AOC data in the SIP INFO message containing an 'application/vnd.etsi.aoc+xml' body. For example:

```
INFO sip:103@10.10.12.188:5060 SIP/2.0
Via: SIP/2.0/UDP 10.10.12.159:5061;branch=z9hG4bK-1-18439@10.10.12.159;rport
From: "2110017: Bob" <sip:4988@10.10.12.188>;tag=1
To: <sip:103@10.10.12.188;user=phone>;tag=pmvsivy1ju
Call-ID: 1-18439@10.10.12.159
CSeq: 3 INFO
Max-Forwards: 70
Contact: <sip:4988@10.10.12.159:5061;line=qhpk806>;reg-id=1
Content-Type: application/vnd.etsi.aoc+xml
```



Content-Length: 405

```
<?xml version="1.0" encoding="UTF-8"?>
<aoc xmlns="http://uri.etsi.org/ngn/params/xml/simservs/aoc">
  <aoc-d>
    <charging-info>subtotal</charging-info>
    <recorded-charges>
      <recorded-currency-units>
        <currency-id>EUR</currency-id>
        <currency-amount>0.1</currency-amount>
      </recorded-currency-units>
    </recorded-charges>
    <billing-id>normal-charging</billing-id>
  </aoc-d>
</aoc>
```

In such a case, you should use message manipulation rules on the SIP INFO message to convert the advice of charge data in the XML to the AOC SIP header with the relevant format (parameters) as discussed above:

Parameter	Value	
'Index'	1	2
'Name'	Add AOC header	Remove XML body
'Manipulation Set ID'	0	0
'Row Rule'	<b>Use Current Condition</b>	<b>Use Previous Condition</b>
'Message Type'	Any	
'Condition'	body.application/vnd.etsi.aoc+xml REGEX (<currency-amount>)(\d+) (<\currency-amount>)	body.application/vnd.etsi.aoc+xml exists
'Action Subject'	Header.AOC	body.application/vnd.etsi.aoc+xml
'Action Type'	<b>Add</b>	<b>Remove</b>
'Action Value'	'charged;charging- info=pulse;recorded-units='+\$2	

- TELES proprietary method
- Cirpack proprietary methods

For more information on the proprietary methods, see the `PayPhoneMeteringMode` parameter in [Metering Tone Parameters](#) on page 1861.

➤ **To configure AOC:**

1. Make sure that the PSTN protocol for the trunk line is configured to Euro ISDN and network side.
2. Make sure that the date and time of the device is correct. For accuracy, it is recommended to use an NTP server to obtain the date and time. For more information, see [Date and Time](#) on page 135.

3. Configure the required AOC method:

- **Device Generation of AOC to Tel:**

- i. Open the Supplementary Services page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **DTMF & Supplementary** > **Supplementary Services Settings**), and then configure the 'Generate Metering Tones' parameter (`PayPhoneMeteringMode`) to **Charge Code Table**.

Generate Metering Tones

Charge Code Table ▼

- ii. In the Charge Codes table, configure Charge Codes (see [Configuring Charge Codes](#) below).
- iii. In the Tel-to-IP Routing table, assign the Charge Code index to the relevant Tel-to-IP routing rule (see [Configuring Tel-to-IP Routing Rules](#) on page 914).

- **AOC in Tel-to-IP Direction:** Open the Supplementary Services Settings page, and then select the 'AoC Support' check box to send AOC to IP:

AoC Support



- **AOC in IP-to-Tel Direction:** Open the Supplementary Services page, and then configure the 'Generate Metering Tones' parameter (`PayPhoneMeteringMode`) to one of the following: **SIP Interval Provided**, **SIP RAW Data Provided**, **SIP RAW Data Incremental Provided**, or **SIP-to-Tel Interworking**.

## Configuring Charge Codes

The Charge Codes table lets you configure metering tones:

- Digital interfaces: Advice of Charge (AOC) services for Euro ISDN trunks (see [Advice of Charge Services for Euro ISDN](#) on page 1007).

You can configure up to 25 different Charge Codes, where each table row represents a Charge Code. Each Charge Code can include up to four different time periods in a day (24 hours). The device selects the time period by comparing the device's current time to the end time of each time period of the selected Charge Code. The device generates the number of pulses (units) upon call connection (answer), and from that point on, it generates a pulse (unit) for each

interval. If a call starts at a certain time period and crosses to the next period, the information of the next time period is used. For Advice of Charge services (digital interfaces only), you can also configure the currency type in the sent AOC messages as well as a multiplier that is applied to the charged units.

To assign Charge Codes to Tel-to-IP calls, use the Tel-to-IP Routing table.



- The Charge Codes table is applicable only to the following interfaces:  
 ✓ Euro ISDN PRI

The following procedure describes how to configure Charge Codes through the Web interface. You can also configure it through ini file [ChargeCode] or CLI (`configure voip > gateway dtmf-supp-service charge-code`).

➤ **To configure a Charge Code:**

1. Open the Charge Codes table (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Routing** > **Charge Codes**).
2. Click **New**; the following dialog box appears:

GENERAL	
Index	0
Name	
End Time 1	
Interval 1	
Amount On Answer 1	
End Time 2	
Interval 2	
Amount On Answer 2	
End Time 3	
Interval 3	
Amount On Answer 3	
End Time 4	

3. Configure a Charge Code according to the parameters described in the table below.
4. Click **Apply**.

**Table 28-4: Charge Codes Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.

Parameter	Description
'Name' charge-code-name [ChargeCodeName]	<p>Defines a descriptive name, which is used when associating the row in other tables.</p> <p>The valid value is a string of up to 40 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Configure each row with a unique name.</li> <li>■ The parameter value cannot contain a forward slash (/).</li> </ul>
'End Time (1 - 4)' end-time-<1-4> [EndTime<1-4>]	<p>Defines the time at which this charging code ends.</p> <p>The valid value is a time in 24-hour format (<i>hh</i>). For example, to denote 4 AM, configure the parameter to "04" (without quotation marks).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The first time period always starts at midnight (00).</li> <li>■ It is mandatory that the last time period of each rule end at midnight (00). This prevents undefined time frames in a day.</li> </ul>
'Interval (1 - 4)' interval-<1-4> [PulseInterval<1-4>]	<p>Defines the interval (in tenths of a second) for charging the call. The first interval starts from when the call is answered (connected).</p> <ul style="list-style-type: none"> <li>■ Defines the interval between every sent AOC-D message, which is included in the ISDN Facility information element (IE) message.</li> </ul> <p>For example, if you configure the parameter to 20, the device sends a charge every 2 seconds (i.e., 20 x 0.1). If the call duration is 10 seconds, the total call charge amount (excluding the connection charge, which is configured by the 'Amount On Answer' parameter) is 5. In other words, 10 seconds divided by 2-second intervals is 5, and then 5 multiplied by the default interval charge of 1 is 5.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the charged amount sent per interval is <b>one</b> pulse (unit). However, for digital interfaces, you can configure this charge, using the ISDNAoCAmountPerInterval parameter.</li> <li>■ If you configure the 'Multiplier of Amount' parameter (see below), then the actual interval charge is multiplied by the 'Multiplier of Amount' parameter value. For example, if the interval charge is 1 (default) and you configure the 'Multiplier of Amount' parameter to 0.1, then the interval charge is 0.1 (i.e., 1 x 0.1).</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>You can configure the interval for sending the AOC messages, using the ISDNAoCMinIntervalGeneration global parameter. This doesn't affect the interval charge. If this global parameter value is less than the 'Interval' parameter, the global parameter is ignored. For example, if you configure the 'Interval' parameter to 20 (i.e., 2 seconds) and the ISDNAoCMinIntervalGeneration parameter to 40 (i.e., 4 seconds), the device sends AOC messages every 0.4 seconds, but charges the call every 2 seconds.</li> </ul>
'Amount On Answer (1-4)' amount-on-answer-<1-4> [PulsesOnAnswer<1-4>]	<p>Defines the one-time call charge upon call connection (call answer).</p> <ul style="list-style-type: none"> <li>Defines the number of charging units or amount that the device generates when the call is answered, which it sends as the first AOC-D message in the ISDN Facility information element (IE) message.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>If you configure the 'Currency' parameter (see below), the charge is sent with this currency (e.g., 5 USD).</li> <li>If you configure the 'Multiplier of Amount' parameter (see below), then the actual charge is the value of the 'Amount On Answer' parameter multiplied by the 'Multiplier of Amount' parameter value. For example, if you configure the 'Amount On Answer' parameter to 50 and the 'Multiplier of Amount' parameter to 0.1, then the charge sent is 5 (i.e., 50 x 0.1).</li> </ul>
'Currency' currency [Currency]	<p>Defines the currency of the charge.</p> <p>The valid value is a string of up to 10 characters. For example, "USD" (without quotation marks). By default, no value is defined. The device includes the currency in AOC messages in IA5 format.</p> <ul style="list-style-type: none"> <li>The parameter is applicable only to Tel-to-IP calls.</li> </ul>
'Multiplier of Amount' multiplier [Multiplier]	<p>Defines the multiplier of the call connection charge (configured by the 'Amount On Answer' parameter) and the interval charge.</p> <ul style="list-style-type: none"> <li>[0] <b>0.001</b></li> <li>[1] <b>0.01</b> (default)</li> <li>[2] <b>0.1</b></li> <li>[3] <b>1</b></li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [4] 10</li> <li>■ [5] 100</li> <li>■ [6] 1000</li> </ul> <p>For example, if you configure the parameter to <b>0.1</b> and the 'Amount On Answer' parameter to 50, the sent call connection charge is 5 (i.e., 50 x 0.1). In addition, if the interval charge is 1 (default), the charge for every interval is 0.1 (i.e., 1 x 0.1).</p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to Tel-to-IP calls.</li> </ul>

## Configuring Voice Mail

The Voice Mail Settings page lets you configure voice mail.



- For more information on voice mail, refer to the document *IP-based Voice Mail Configuration Note*.
- For a detailed description of the voice mail parameters, see [Voice Mail Parameters](#) on page 1790.
- Voice mail is applicable only to , CAS, QSIG, Euro ISDN, and NI2 interfaces.

### ➤ To configure voice mail:

1. Open the Supplementary Services Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **DTMF & Supplementary** > **Supplementary Services Settings**).
  - 'Line Transfer Mode' (LineTransferMode): Defines the call transfer method used by the device.
2. Open the Message Waiting Indicator Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **DTMF & Supplementary** > **Message Waiting Indicator Settings**).
  - 'Voice Mail Interface' (VoiceMailInterface): Enables the device's Voice Mail feature and defines the communication method between the device and PBX.
  - Configure the digit codes used by the device for relaying message waiting indication information to the PBX:
    - ◆ 'MWI Off Digit Pattern' (MWIOffCode): Defines the digit code indicating no messages waiting for a specific extension.
    - ◆ 'MWI On Digit Pattern' (MWIONCode): Defines the digit code indicating messages waiting for a specific extension.
    - ◆ 'MWI Suffix Pattern' (MWISuffixCode): Defines the digit code used as a suffix for 'MWI On Digit Pattern' and 'MWI Off Digit Pattern'.

- ◆ 'MWI Source Number' (MWISourceNumber): Defines the calling party's phone number in the Q.931 MWI Setup message to PSTN.
- Configure Simplified Message Desk Interface (SMDI):
  - ◆ 'Enable SMDI' (SMDI): Enables SMDI interface on the device.
  - ◆ 'SMDI Timeout' (SMDITimeOut): Defines the time (in msec) that the device waits for an SMDI Call Status message before or after a Setup message is received.
- 3. Open the DTMF & Dialing page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **DTMF & Supplementary** > **DTMF & Dialing**).
  - Under the Digit Patterns group, configure the digit patterns used by the PBX to indicate various services:
    - ◆ 'Forward on Busy Digit Pattern Internal' (DigitPatternForwardOnBusy): Defines the digit pattern to indicate 'call forward on busy' when the original call is received from an internal extension.
    - ◆ 'Forward on No Answer Digit Pattern Internal' (DigitPatternForwardOnNoAnswer): Defines the digit pattern to indicate 'call forward on no answer' when the original call is received from an internal extension.
    - ◆ 'Forward on Do Not Disturb Digit Pattern Internal' (DigitPatternForwardOnDND): Defines the digit pattern to indicate 'call forward on do not disturb' when the original call is received from an internal extension.
    - ◆ 'Forward on No Reason Digit Pattern Internal' (DigitPatternForwardNoReason): Defines the digit pattern to indicate 'call forward with no reason' when the original call is received from an internal extension.
    - ◆ 'Forward on Busy Digit Pattern External' (DigitPatternForwardOnBusyExt): Defines the digit pattern to indicate 'call forward on busy' when the original call is received from an external line.
    - ◆ 'Forward on No Answer Digit Pattern External' (DigitPatternForwardOnNoAnswerExt): Defines the digit pattern to indicate 'call forward on no answer' when the original call is received from an external line.
    - ◆ 'Forward on Do Not Disturb Digit Pattern External' (DigitPatternForwardOnDNDExt): Defines the digit pattern to indicate 'call forward on do not disturb' when the original call is received from an external line.
    - ◆ 'Forward on No Reason Digit Pattern External' (DigitPatternForwardNoReasonExt): Defines the digit pattern to indicate 'call forward with no reason' when the original call is received from an external line.
    - ◆ 'Internal Call Digit Pattern' (DigitPatternInternalCall): Defines the digit pattern to indicate an internal call.
    - ◆ 'External Call Digit Pattern' (DigitPatternExternalCall): Defines the digit pattern to indicate an external call.

- ◆ 'Disconnect Call Digit Pattern' (TelDisconnectCode): Defines a digit pattern that when received from the Tel side indicates the device to disconnect the call.
- ◆ 'Digit To Ignore Digit Pattern' (DigitPatternDigitToIgnore): Defines a digit pattern that if received as Src (S) or Redirect (R) numbers is ignored and not added to that number.

4. Click **Apply**.

## Converting Accented Characters from IP to Tel

The Char Conversion table lets you configure up to 40 Character Conversion rules. A Character Conversion rule maps (converts) accented characters (Unicode / UTF-8) received from the IP side into simple ASCII characters (ISO-8859) for sending to the Tel side. Typically, the device receives the caller ID and calling name in Unicode characters (in the SIP INVITE message). Unicode characters consist of two bytes, while ASCII characters consist of one byte. Accented characters are used in various languages such as German. An example of such a character is the umlaut (or diaeresis), which consists of two dots placed over a letter, as in ä. The importance of this conversion feature is that it allows Tel entities that do not support accented characters, to receive ASCII characters. For example, the device can convert the Unicode character ä into the ASCII character "ae".



The table functions together with the [ISO8859CharacterSet] parameter. When the parameter is set to [0] (Latin only), it converts accented characters into ASCII (e.g., ä to "a"). However, the table can be used to overwrite these "basic" conversions and customize them (e.g., ä to "ae" instead of the default "a").

The following procedure describes how to configure Character Conversion rules through the Web interface. You can also configure it through ini file [CharConversion] or CLI (`configure voip > gateway dtmf- supp- service dtmf- and- dialing > char- conversion`).

### ➤ To configure a Character Conversion rule:

1. Open the Char Conversion table (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **DTMF & Supplementary** > **Char Conversion**).
2. Click **New**; the following dialog box appears:



**Char Conversion**

**GENERAL**

Index: 0

Character Name: a with Diaeresis

First Byte: 195

Second Byte: 164

Converted Output: ae

The figure above shows a configuration example where ä is converted to ae.

3. Configure a Character Conversion rule according to the parameters described in the table below.
4. Click **Apply**.

**Table 28-5: Char Conversion Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Character Name' char-name [CharName]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 40 characters. <b>Note:</b> Configure each row with a unique name.
'First Byte' first-byte [FirstByte]	Defines the first byte of the Unicode character (e.g., 195). The default is 194.
'Second Byte' second-byte [SecondByte]	Defines the second byte of the Unicode character (e.g., 164). The default is 128.
'Converted Output' converted-output [ConvertedOutput]	Defines the ASCII character (e.g., "ae") to which the Unicode character must be converted. The valid value is a string of up to four characters. The valid value is up to four ASCII characters. This can include any ASCII character - alphanumeric (e.g., a, A, 6) and/or symbols (e.g., !, ?, _, &).

# **Part VI**

## **Session Border Controller Application**

## 29 Overview

This section provides an overview of the device's SBC application.



- For guidelines on how to deploy your SBC device, refer to the *SBC Design Guide* document.
- The SBC feature is available only if the device is installed with a License Key that includes this feature. For installing a License Key, see [License Key](#) on page 1233.
- For the maximum number of supported SBC sessions, and SBC users than can be registered in the device's registration database, see [Technical Specifications](#) on page 1953.

### Feature List

The SBC application supports the following main features:

- NAT traversal: The device supports NAT traversal, allowing, for example, communication with ITSPs with globally unique IP addresses and with far-end users located behind NAT on the WAN. The device supports this by:
  - Continually registering far-end users with its users registration database.
  - Maintaining remote NAT binding state by frequent registrations and thereby, off-loading far-end registrations from the LAN IP PBX.
  - Using Symmetric RTP (RFC 4961) to overcome bearer NAT traversal.
- VoIP firewall and security for signaling and media:
  - SIP signaling:
    - ◆ Deep and stateful inspection of all SIP signaling packets.
    - ◆ SIP dialog initiations may be rejected based on values of incoming SIP INVITE message and other Layer-3 characteristics.
    - ◆ Packets not belonging to an authorized SIP dialog are discarded.
  - RTP:
    - ◆ Deep packet inspection of all RTP packets.
    - ◆ Late rogue detection - if a SIP session was gracefully terminated and someone tries to "ride on it" with rogue traffic from the already terminated RTP and SIP context, the VoIP Firewall prevents this from occurring.
    - ◆ Disconnects call (after user-defined time) if RTP connection is broken.
    - ◆ Black/White lists for both Layer-3 firewall and SIP classification.

- **Stateful Proxy Operation Mode:** The device can act as a Stateful Proxy by enabling SIP messages to traverse it transparently (with minimal interference) between the inbound and outbound legs.
- **B2BUA and Topology Hiding:** The device intrinsically supports topology hiding, limiting the amount of topology information displayed to external parties. For example, IP addresses of ITSPs' equipment (e.g. proxies, gateways, and application servers) can be hidden from outside parties. The device's topology hiding is provided by implementing back-to-back user agent (B2BUA) leg routing:
  - Strips all incoming SIP Via header fields and creates a new Via value for the outgoing message.
  - Each leg has its own Route/Record Route set.
  - User-defined manipulation of SIP To, From, and Request-URI host names.
  - Generates a new SIP Call-ID header value (different between legs).
  - Changes the SIP Contact header and sets it to the device's address.
  - Layer-3 topology hiding by modifying source IP address in the SIP IP header.
- **SIP normalization:** The device supports SIP normalization, whereby the SBC application can overcome interoperability problems between SIP user agents. This is achieved by the following:
  - Manipulation of SIP URI user and host parts.
  - Connection to ITSP SIP trunks on behalf of an IP-PBX - the device can register and utilize user and password to authenticate for the IP-PBX.
- **Survivability:**
  - Routing calls to alternative routes such as the PSTN.
  - Routing calls between user agents in the local network using a dynamic database (built according to registrations of SIP user agents).
- **Routing:**
  - IP-to-IP routing translations of SIP, UDP, TCP, TLS (when extensive transcoding is not required).
  - Load balancing and redundancy of SIP servers.
  - Routing according to Request-URI\Specific IP address\Proxy\FQDN.
  - Alternative routing.
  - Routing between different Layer-3 networks (e.g., LAN and WAN).
- **Load balancing\redundancy of SIP servers.**
- **ITSP accounts.**
- **SIP URI user and host name manipulations.**

## B2BUA and Stateful Proxy Operating Modes

The device can operate in one or both of the following SBC modes:

- **Back-to-Back User Agent (B2BUA):** Maintains independent sessions toward the endpoints, processing an incoming request as a user agent server (UAS) on the inbound leg, and processing the outgoing request as a user agent client (UAC) on the outbound leg. SIP messages are modified regarding headers between the legs and all the device's interworking features may be applied.
- **Stateful Proxy Server:** SIP messages traverse the device transparently (with minimal interference) between the inbound and outbound legs, for connecting SIP endpoints.

By default, the device's B2BUA mode changes SIP dialog identifiers and topology data in SIP messages traversing through it:

- Call identifiers: Replaces the From-header tag and Call-ID header so that they are different for each leg (inbound and outbound).
- Routing headers:
  - Removes all Via headers in incoming requests and sends the outgoing message with its own Via header.
  - Doesn't forward any Record-Route headers from the inbound to outbound leg, and vice versa.
  - Replaces the address of the Contact header in the incoming message with its own address in the outgoing message.
- Replaces the User-Agent/ Server header value in the outgoing message, and replaces the original value with itself in the incoming message.

In contrast, when the device operates in Stateful Proxy mode, the device by default forwards SIP messages transparently (unchanged) between SIP endpoints (from inbound to outbound legs). The device retains the SIP dialog identifiers and topology headers received in the incoming message and sends them as is in the outgoing message. The device handles the above mentioned headers transparently (i.e., they remain unchanged) or according to configuration (enabling partial transparency), and only adds itself as the top-most Via header and optionally, to the Record-Route list. To configure the handling of these headers for partial transparency, use the following IP Profile parameters (see [Configuring IP Profiles](#) on page 664):

- 'Remote Representation Mode': Contact and Record-Route headers
- 'Keep Incoming Via Headers': Via headers
- 'Keep User-Agent Header': User-Agent headers
- 'Keep Incoming Routing Headers': Record-Route headers
- 'Remote Multiple Early Dialogs': To-header tags

Thus, the Stateful Proxy mode provides full SIP transparency (no topology hiding) or asymmetric topology hiding. Below is an example of a SIP dialog-initiating request when operating in

Stateful Proxy mode for full transparency, showing all the incoming SIP headers retained in the outgoing INVITE message.

Incoming INVITE	Outgoing INVITE
<pre> INVITE sip:bob@domain.com SIP/2.0 To: Bob &lt;sip:bob@domain.com&gt; From: Alice &lt;sip:alice@caller.com&gt;;tag=100 Call-ID: callid1@caller.com Contact: &lt;sip:alice@pc1.caller.com&gt; Via: SIP/2.0/UDP pc2.com;branch=branch2 Via: SIP/2.0/UDP pc1.com;branch=branch1 Record-Route: &lt;pc2.com;lr&gt; Record-Route: &lt;pc1.com;lr&gt; CSeq: 666 INVITE User-Agent: IPPv3.1 Max-Forwards: 70 Content-Type: application/sdp Content-Length: 142  v=0 ... </pre>	<pre> INVITE sip:bob@domain.com SIP/2.0 To: Bob &lt;sip:bob@domain.com&gt; From: Alice &lt;sip:alice@caller.com&gt;;tag=100 Call-ID: callid1@caller.com Contact: &lt;sip:alice@pc1.caller.com&gt; Via: SIP/2.0/UDP Proxy-IP;branch=branch3 Via: SIP/2.0/UDP pc2.com;branch=branch2 Via: SIP/2.0/UDP pc1.com;branch=branch1 Record-Route: &lt;Proxy-IP;lr&gt; Record-Route: &lt;pc2.com;lr&gt; Record-Route: &lt;pc1.com;lr&gt; CSeq: 666 INVITE User-Agent: IPPv3.1 Max-Forwards: 70 Content-Type: application/sdp Content-Length: 142  v=0 ... </pre>

Some of the reasons for implementing Stateful Proxy mode include:

- B2BUA typically hides certain SIP headers for topology hiding. In specific setups, some SIP servers require the inclusion of these headers to know the history of the SIP request. In such setups, the requirement may be asymmetric topology hiding, whereby SIP traffic toward the SIP server must expose these headers whereas SIP traffic toward the users must not expose these headers.
- B2BUA changes the call identifiers between the inbound and outbound SBC legs and therefore, call parties may indicate call identifiers that are not relayed to the other leg. Some SIP functionalities are achieved by conveying the SIP call identifiers either in SIP specific headers (e.g., Replaces) or in the message bodies (e.g. Dialog Info in an XML body).
- In some setups, the SIP client authenticates using a hash that is performed on one or more of the headers that B2BUA changes (removes). Therefore, implementing B2BUA would cause authentication to fail.
- For facilitating debugging procedures, some administrators require that the value in the Call-ID header remains unchanged between the inbound and outbound SBC legs. As B2BUA changes the Call-ID header, such debugging requirements would fail.

The operating mode can be configured per the following configuration entities:

- SRDs in the SRDs table (see [Configuring SRDs](#) on page 549)
- IP Groups in the IP Groups table (see [Configuring IP Groups](#) on page 581)


If the operation mode is configured in both tables, the operation mode of the IP Group is applied. Once configured, the device uses default settings in the IP Profiles table for handling the SIP headers, as mentioned previously. However, you can change the default settings to enable partial transparency.



- The To-header tag remains the same for inbound and outbound legs of the dialog, regardless of operation mode.
- If the Operation Mode of the SRD\IP Group of one leg of the dialog is set to 'Call Stateful Proxy', the device also operates in this mode on the other leg with regards to the dialog identifiers (Call-ID header, tags, CSeq header).
- It is recommended to implement the B2BUA mode, unless one of the reasons mentioned previously is required. B2BUA supports all the device's feature-rich offerings, while Stateful Proxy may offer only limited support. The following features are not supported when in Stateful Proxy mode:
  - ✓ Alternative routing
  - ✓ Call forking
  - ✓ Terminating REFER/3xx
- If Stateful Proxy mode is enabled and any one of the unsupported features is enabled, the device disables the Stateful Proxy mode and operates in B2BUA mode.
- You can configure the device to operate in both B2BUA and Stateful Proxy modes for the same users. This is typically implemented when users need to communicate with different SIP entities (IP Groups). For example, B2BUA mode for calls destined to a SIP Trunk and Stateful Proxy mode for calls destined to an IP PBX. The configuration is done using IP Groups and SRDs.
- If Stateful Proxy mode is used only due to the debugging benefits, it is recommended to configure the device to only forward the Call-ID header unchanged

## Call Processing of SIP Dialog Requests

The device processes incoming SIP dialog requests (SIP methods) such as INVITE, SUBSCRIBE, OPTIONS, REFER, INFO, UNSOLICITED NOTIFY, MESSAGE, and REGISTER. The process is summarized in the following figure and subsequently described:



The first stage of the SIP dialog-initiating process is **determining source and destination URLs**. The SIP protocol has more than one URL in a dialog-initiating request that may represent the source and destination URLs. The device obtains the source and destination URLs from certain SIP headers. Once the URLs are determined, the user and host parts of the URLs can be used as matching rule characteristics for classification, message manipulation, and call routing.

■ **All SIP requests (e.g., INVITE) except REGISTER:**

- Source URL: Obtained from the From header. If the From header contains the value 'Anonymous', the source URL is obtained from the P-Preferred-Identity header. If the P-Preferred-Identity header doesn't exist, the source URL is obtained from the P-Asserted-Identity header.
- Destination URL: Obtained from the Request-URI.



**■ REGISTER dialogs:**

- Source URL: Obtained from the To header.
- Destination URL: Obtained from the Request-URI.



You can specify the SIP header from where you want the device to obtain the source URL in the incoming dialog request. This is configured in the IP Groups table using the 'Source URI Input' parameter (see [Configuring IP Groups](#) on page 581).

The next stages of the SIP dialog-initiating process is as follows:

1. **Determining the SIP Interface:** The device checks the SIP Interface on which the SIP dialog is received. The SIP Interface defines the local SIP "listening" port and IP network interface. For more information, see [Configuring SIP Interfaces](#) on page 561.
2. **Applying Pre-parsing SIP Message Manipulation:** If configured, the device can apply SIP message manipulation to the incoming SIP message before it is parsed by the device. This type of manipulation is called Pre-Parsing Manipulation, which is configured in the Pre-Parsing Manipulation Sets table (see [Configuring Pre-Parsing Manipulation Rules](#) on page 843) and is assigned to the SIP Interface.
3. **Applying Pre-classification SIP Message Manipulation:** If configured, the device can apply SIP message manipulation to the incoming SIP message before it is classified to a source IP Group. This manipulation is configured in the SIP Message Manipulations table (see [Configuring SIP Message Manipulation](#) on page 829 and is assigned to the SIP Interface.
4. **Classifying to a Source IP Group using Tags:** If configured, the device can classify the incoming SIP message to a source IP Group, based on a source tag that is determined by running a Call Setup Rule. The Call Setup Rule is configured in the Call Setup Rules table (see [Configuring Call Setup Rules](#) on page 782) and is assigned to the SIP Interface. For more information on tag-based classification, see [Configuring Classification Based on Tags](#) on page 1073.
5. **Classifying to a Source IP Group:** Classification identifies the incoming SIP dialog request as belonging to a specific IP Group (i.e., from where the SIP dialog request originated). The classification process is based on the SRD to which the dialog belongs (the SRD is determined according to the SIP Interface). For more information, see [Configuring Classification Rules](#) on page 1061.
6. **Applying Inbound Manipulation:** Depending on configuration, the device can apply an Inbound Manipulation rule to the incoming dialog. This manipulates the user part of the SIP URI for source (e.g., in the SIP From header) and destination (e.g., in the Request-URI line). The manipulation rule is associated with the incoming dialog, by configuring the rule with incoming matching characteristics such as source IP Group and destination host name. The manipulation rules are also assigned a Routing Policy, which in turn, is assigned to IP-to-IP routing rules. As most deployments require only one Routing Policy, the default Routing Policy is automatically assigned to manipulation and routing rules. For more information, see [Configuring IP-to-IP Inbound Manipulations](#) on page 1121.

- 7. Applying a Dial Plan to Determine Tag:** If configured, the device can run a Dial Plan rule based on the source (or destination) number of the incoming SIP message to determine its' tag. The tag can later be used in the routing and manipulation stages. Dial Plan rules are configured in the Dial Plan table (see [Configuring Dial Plans](#) on page 798) and assigned to the IP Group.
- 8. Applying Call Setup Rules for Various Functions:** If configured, the device can run Call Setup Rules to apply various functions to the call, for example, querying an LDAP server. The Call Setup Rule is configured in the Call Setup Rules table (see [Configuring Call Setup Rules](#) on page 782) and is assigned to the IP Group.
- 9. SBC IP-to-IP Routing:** The device searches the IP-to-IP Routing table for a routing rule that matches the characteristics of the incoming call. If found, the device routes the call to the configured destination which can be, for example, an IP Group, the Request-URI if the user is registered with the device, and a specified IP address. For more information, see [Configuring SBC IP-to-IP Routing Rules](#) on page 1076.
- 10. Applying Call Setup Rules for Various Functions:** If configured, the device can run Call Setup Rules to apply various functions to the call. The Call Setup Rule is configured in the Call Setup Rules table (see [Configuring Call Setup Rules](#) on page 782) and is assigned to the IP-to-IP Routing table.
- 11. Applying Inbound SIP Message Manipulation:** Depending on configuration, the device can apply a SIP message manipulation rule (assigned to the IP Group) on the incoming dialog. For more information, see Stage 3.
- 12. Applying Outbound Manipulation:** Depending on configuration, the device can apply an Outbound Manipulation rule to the outbound dialog. This manipulates the user part of the Request-URI for source (e.g., in the SIP From header) or destination (e.g., in the SIP To header) or calling name in the outbound SIP dialog. The manipulation rule is associated with the dialog, by configuring the rule with incoming matching characteristics such as source IP Group and destination host name. The manipulation rules are also assigned a Routing Policy, which in turn, is assigned to IP-to-IP routing rules. As most deployments require only one Routing Policy, the default Routing Policy is automatically assigned to manipulation rules and routing rules. For more information, see [Configuring IP-to-IP Outbound Manipulations](#) on page 1126.
- 13. Applying Outbound SIP Message Manipulation:** Depending on configuration, the device can apply a SIP message manipulation rule (assigned to the IP Group) on the outbound dialog. For more information, see Stage 3.
- 14.** The call is sent to the configured destination.

## User Registration

The device provides a registration database for registering users. Only users belonging to a User-type IP Group can register with the device. User-type IP Groups represent a group of SIP user agents that share the following characteristics:

- Perform registrations and share the same serving proxy\registrar

- Same SIP and media behavior
- Same IP Profile
- Same SIP handling configuration
- Same Call Admission Control (CAC)

Typically, the device is configured as the user's outbound proxy, routing requests (using the IP-to-IP Routing table) from the user's User-type IP Group to the serving proxy, and vice versa. Survivability can be achieved using the alternative routing feature.

The device forwards registration requests (REGISTER messages) from a Server-type IP Group, but doesn't save the registration binding in its' registration database.

## Initial Registration Request Processing

A summary of the device's handling of registration requests (REGISTER messages) is as follows:

- The URL in the SIP To header of the REGISTER message constitutes the primary Address of Record (AOR) for registration (according to SIP standards). If the To header's URL includes the "user=phone" parameter, then only the user part of the URL constitutes the AOR. If the To header's URL doesn't include the "user=phone" parameter, then both the user part and host part of the URL constitutes the AOR.
- The device can save other AORs in its registration database as well. When the device searches for a user in its' registration database, any of the user's AORs can result in a match.
- The device's Classification process for initial REGISTER messages is slightly different than for other SIP messages. Unlike other requests, initial REGISTER requests can't be classified according to the registration database.
- If registration succeeds (replied with 200 OK by the destination server), the device adds a record to its' registration database, which identifies the specific contact of the specific user (AOR). The device uses this record to route subsequent SIP requests to the specific user (in normal or survivability modes).
- The records in the device's registration database include the Contact header. The device adds every REGISTER request to the registration database before manipulation, allowing correct user identification in the Classification process for the next received request.
- You can configure Call Admission Control (CAC) rules for incoming and outgoing REGISTER messages. For example, you can limit REGISTER requests from a specific IP Group or SRD. Note that this applies only to concurrent REGISTER dialogs and not concurrent registrations in the device's registration database.

The device provides a dynamic registration database that it updates according to registration requests traversing it. Each database entry for a user represents a binding between an AOR (obtained from the SIP To header), optional additional AORs, and one or more contacts (obtained from the SIP Contact headers). Database bindings are added upon successful

registration responses from the proxy server (SIP 200 OK). The device removes database bindings in the following cases:

- Successful de-registration responses (REGISTER with Expires header that equals zero).
- Registration failure responses.
- Timeout of the Expires header value (in scenarios where the UA did not send a refresh registration request).



- The same contact cannot belong to more than one AOR.
- Contacts with identical URIs and different ports and transport types are not supported (same key is created).
- Multiple contacts in a single REGISTER message is not supported.
- One database is shared between all User-type IP Groups.

## Classification and Routing of Registered Users

The device can classify incoming SIP dialog requests (e.g., INVITE) from registered users to an IP Group, by searching for the sender's details in the registration database. The device uses the AOR from the From header and the URL in the Contact header of the request to locate a matching registration binding. The found registration binding contains information regarding the registered user, including the IP Group to which it belongs. (Upon initial registration, the Classification table is used to classify the user to a User-type IP Group and this information is then added with the user in the registration database.)

The destination of a dialog request can be a registered user and the device thus uses its registration database to route the call. This can be achieved by various ways such as configuring a rule in the IP-to-IP Routing table where the destination is a User-type IP Group or any matching user registered in the database ('Destination Type' is configured to **All Users**). The device searches the registration database for a user that matches the incoming Request-URI (listed in chronological order):

- Unique Contact generated by the device and sent in the initial registration request to the serving proxy.
- AOR. The AOR is originally obtained from the incoming REGISTER request and must either match both user part and host part (user@host) of the Request-URI, or only user part.
- Contact. The Contact is originally obtained from the incoming REGISTER request.

If registrations are destined to the database (using the above rules), the device doesn't attempt to find a database match, but instead replies with a SIP 200 OK (used for Survivability). Once a match is found, the request is routed either to the contact received in the initial registration or (if the device identifies that the user agent is behind a NAT) to the source IP address of the initial registration.

You can configure (using the [SBCDBRoutingSearchMode] parameter) for which part of the destination Request-URI in the INVITE message the device must search in the registration database:

- Only by entire Request-URI (user@host), for example, "4709@joe.company.com".
- By entire Request-URI, but if not found, by the user part of the Request-URI, for example, "4709".

When an incoming INVITE is received for routing to a user and the user is located in the registration database, the device sends the call to the user's corresponding contact address specified in the database.



If the Request-URI contains the "tel:" URI or "user=phone" parameter, the device searches only for the user part.

You can also configure which URI parameters are excluded when the device compares the URIs of two incoming dialog-initiating SIP requests (e.g., INVITEs) to determine if they were sent from a user that is registered in the device's registration database. For example, you can configure the parameter to exclude ports from the comparison. For more information, see the description of the [SBCURIComparisonExcludedParams] parameter.

## General Registration Request Processing

The device's general handling of registration requests (REGISTER messages) for unregistered users is as follows:

- The device routes REGISTER requests according to the IP-to-IP Routing table. If the destination is a User-type IP Group, the device doesn't forward the registration; instead, it accepts (replies with a SIP 200 OK response) or rejects (replies with a SIP 4xx) the request according to the user's IP Group configuration.
- Alternative routing can be configured for REGISTER requests in the IP-to-IP Routing table.
- By default, the SIP Expires header has the same value in incoming and outgoing REGISTER messages. However, you can modify the its value using the following parameters: [SBCUserRegistrationTime], [SBCProxyRegistrationTime], [SBCRandomizeExpires], and [SBCSurvivabilityRegistrationTime]. You can also modify the Expires value of REGISTER requests received from users located behind NAT, using the IP Profile parameters 'NAT UDP Registration Time' and 'NAT TCP Registration Time'.
- By default, the SIP Contact header in the outgoing REGISTER message is different than the Contact header in the incoming REGISTER. The user part of the Contact header is populated with a unique contact generated by the device and associated with the specific registration. The IP address in the host part is changed to the address of the device. Alternatively, the original user can be retained in the Contact header and used in the outgoing REGISTER request, using the [SBCKeepContactUserinRegister] parameter.

## Registration Refreshes

Registration refreshes are incoming REGISTER requests from users that are registered in the device's registration database. The device sends these refreshes to the serving proxy only if the serving proxy's Expires time is about to expire; otherwise, the device responds with a 200 OK to

the user without routing the REGISTER. Each such refresh also refreshes the internal timer set on the device for this specific registration.

The device automatically notifies SIP proxy / registrar servers of users that are registered in its registration database and whose registration timeout has expired. When a user's registration timer expires, the device removes the user's record from the database and sends an un-register notification (REGISTER message with the Expires header set to 0) to the proxy/registrar. This occurs only if a REGISTER message is sent to an IP Group destination type (in the IP-to-IP Routing table).

You can also apply a graceful period to unregistered requests, using the 'User Registration Grace Time' parameter ([SBCUserRegistrationGraceTime]):

- You can configure the device to add extra time (grace period) to the expiration timer of registered users in the database. If you configure this grace period, the device keeps the user in the database (and doesn't send an unregister to the registrar server), allowing the user to send a "late" re-registration to the device. The device removes the user from the database only when this additional time expires.
- The graceful period is also used before removing a user from the registration database when the device receives a successful unregister response (200 OK) from the registrar/proxy server. This is useful in scenarios, for example, in which users (SIP user agents) such as IP Phones erroneously send unregister requests. Instead of immediately removing the user from the registration database upon receipt of a successful unregister response, the device waits until it receives a successful unregister response from the registrar server, waits the user-defined graceful time and if no register refresh request is received from the user agent, removes the contact (or AOR) from the database.

The device keeps registered users in its' registration database even if connectivity with the proxy is lost (i.e., proxy doesn't respond to users' registration refresh requests). The device removes users from the database only when their registration expiry time is reached (with the additional grace period, if configured).

## Registration Restriction Control

The device provides flexibility in controlling user registrations:

- **Limiting Number of Registrations:** You can limit the number of users that can register with the device per IP Group, SIP Interface, and/or SRD, in the IP Group, SIP Interface and SRDs tables respectively. By default, no limitation exists.
- **Blocking Incoming Calls from Unregistered Users:** You can block incoming calls (INVITE requests) from unregistered users belonging to User-type IP Groups. By default, calls from unregistered users are not blocked. This is configured per SIP Interface or SRD. When the call is rejected, the device sends a SIP 500 (Server Internal Error) response to the remote end.

## Deleting Registered Users

You can remove registered users from the device's registration database through CLI:

- To delete a specific registered user:

```
# clear voip register db sbc user <AOR of user - user part or user@host>
```

For example:

```
# clear voip register db sbc user John@10.33.2.22  
# clear voip register db sbc user John
```

- To delete all registered users belonging to a specific IP Group:

```
# clear voip register db sbc ip-group <ID or name>
```

## Media Handling

Media behavior includes anything related to the establishment, management and termination of media sessions within the SIP protocol. Media sessions are created using the SIP offer-answer mechanism. If successful, the result is a bi-directional media (RTP) flow (e.g. audio, fax, modem, DTMF). Each offer-answer may create multiple media sessions of different types (e.g. audio and fax). In a SIP dialog, multiple offer-answer transactions may occur and each may change the media session characteristics (e.g. IP address, port, coders, media types, and RTP mode).

The media capabilities exchanged in an offer-answer transaction include the following:

- Media types (e.g., audio, secure audio, video, fax, and text).
- IP addresses and ports of the media flow.
- Media flow mode (send receive, receive only, send only, inactive).
- Media coders (coders and their characteristics used in each media flow).
- Other (standard or proprietary) media and session characteristics.

Typically, the device doesn't change the negotiated media capabilities (mainly performed by the remote user agents). However, it does examine and may take an active role in the SDP offer-answer mechanism. This is done mainly to anchor the media to the device (default) and also to change the negotiated media type, if configured. Some of the media handling features, which are described later in this section, include the following:

- Media anchoring (default).
- Direct media (see [Direct Media Calls](#) on page 1033).
- Early media and ringback tone handling.
- Call hold translations and held tone generation.
- NAT traversal.
- RTP broken connections.

#### ■ Media firewall:

- RTP pin holes - only RTP packets related to a successful offer-answer negotiation traverse the device: When the device initializes, there are no RTP pin holes opened. This means that each RTP\RTCP packets destined to the device are discarded. Once an offer-answer transaction ends successfully, an RTP pin hole is opened and RTP\RTCP flows between the two remote user agents. Once a pin hole is opened, the payload type and RTP header version is validated for each packet. RTP pin holes close if one of the associated SIP dialogs is closed (may also be due to broken connection).
- Late rogue detection - once a dialog is disconnected, the related pin holes also disconnect.
- Deep Packet inspection of the RTP that flows through the opened pin holes.

### Media Anchoring


By default, the device anchors the media (RTP) traffic. In other words, the media between SIP endpoints traverses the device. You can change this default mode by enabling direct media between SIP endpoints. Media anchoring may be required, for example, to resolve NAT problems, enforce media security policies, perform media transcoding, and media monitoring.

To enforce RTP traffic to flow through the device, the device modifies all IP address fields in the SDP:

- Origin: IP address, session and version id
- Session connection attribute ('c=' field)
- Media connection attribute ('c=' field)
- Media port number
- RTCP media attribute IP address and port

The device uses different local ports (e.g., for RTP, RTCP and fax) for each leg (inbound and outbound). The local ports are allocated from the Media Realm associated with each leg. The Media Realm assigned to the leg's IP Group (in the IP Groups table) is used. If not assigned to the IP Group, the Media Realm assigned to the leg's SIP Interface (in the SIP Interfaces table) is used. The following figure provides an example of SDP handling for a call between a LAN IP Phone 10.2.2.6 and a remote IP Phone 212.179.1.13 on the WAN.






## Direct Media Calls

You can configure the device to allow the media (RTP/SRTP) session to flow directly between the SIP endpoints without traversing the device. This is referred to as No Media Anchoring (also known as Anti-Tromboning or Direct Media). SIP signaling continues to traverse the device with minimal intermediation and involvement to enable certain SBC capabilities such as routing. By default, the device employs media anchoring, whereby the media session traverses the device, as described in [Media Anchoring](#) on the previous page.

Direct media offers the following benefits:

- Saves network bandwidth
- Reduces the device's CPU usage (as there is no media handling)
- Avoids interference in SDP negotiation and header manipulation on RTP/SRTP

Direct media is typically implemented for calls between users located in the same LAN or domain, and where NAT traversal is not required and other media handling features such as media transcoding is not required. The following figure provides an example of direct media between LAN IP phones, while SIP signaling continues to traverse the device between LAN IP phones and the hosted WAN IP-PBX.



➤ **To enable direct media:**

- **For all calls:** Use the global parameter [SBCDirectMedia], which **overrides** all other direct media configuration.
- **For specific calls:**
  - SIP Interface: You can enable direct media per SIP Interface (in the SIP Interfaces table), whereby calls (source and destination) associated with **this same** SIP Interface are handled as direct media calls. The SIP Interface can also enable direct media for users located behind the same NAT. For more information, see [Configuring SIP Interfaces](#) on page 561.
  - Direct Media Tag: You can enable direct media between users that are configured with the same Direct Media tag value. The tag is configured by the IP Profile parameter 'Direct Media Tag' (see [Configuring IP Profiles](#) on page 664).



Regardless of the device's settings for direct media (mentioned in this section), the device always handles calls whose incoming SIP dialog-initiating request (e.g., INVITE message) contains the proprietary SIP header 'X-AC-Action' with the value 'direct-media' (i.e., 'X-AC-Action: direct-media'), as direct media calls. These calls remain as direct media calls until they end. The device doesn't open voice channels and doesn't allocate any resources (media ports) for these calls.

The device employs direct media between endpoints under the following configuration conditions (listed in chronological order):

1. Direct media is enabled by the global parameter [SBCDirectMedia].

2. IP Groups of the endpoints are associated with IP Profiles whose 'Direct Media Tag' parameter has the same value (non-empty value).
3. IP Groups of the endpoints have the 'SBC Operation Mode' parameter set to **Microsoft Server** (direct media is required in the Skype for Business environment). For more information, see [Configuring IP Groups](#) on page 581.
4. IP Groups of the endpoints use the same SIP Interface and the SIP Interface's 'SBC Direct Media' parameter is set to **Enable**.
5. IP Groups of the endpoints use the same SIP Interface and the SIP Interface's 'SBC Direct Media' parameter is set to **Enable When Single NAT**, and the endpoints are located behind the same NAT.



- **Direct Media configured for all calls (i.e., using the [SBCDirectMedia] parameter):** The device doesn't open voice channels and doesn't allocate media ports for these calls, because the media always bypasses the device.
- **Direct Media configured for specific calls (i.e., using the IP Profile's 'Direct Media Tag' parameter or SIP Interface's 'Direct Media' parameter):** The device always allocates ports for these calls, because these ports may be required at some stage during the call if it changes to a **non-direct media** call for mid-call services such as early media, call forwarding, call transfer, or playing on-hold tones. Therefore, make sure that you have allocated sufficient media ports (Media Realm) for these calls.
- The following features are not supported for Direct Media calls:
  - ✓ Manipulation of SDP data (offer-answer transaction) such as ports, IP address, coders
  - ✓ Extension of RFC 2833 / out-of-band DTMF / in-band DTMF
  - ✓ Extension of SRTP/RTP
  - ✓ All restriction features (Allowed Coders, restrict SRTP/RTP, and restrict RFC 2833)
  - ✓ All media-related parameters in the IP Profiles table are not applicable to Direct Media calls
- The device doesn't fully support call transfer (SIP REFER) terminations for direct media calls. One of the SIP User Agents (UA) in the call must support re-INVITE messages without SDP for the device to synchronize the media.
- For two users belonging to the same SIP Interface that is enabled for direct media and one of the users is defined as a foreign user (example, "follow me service") located in the WAN while the other is located in the LAN: calls between these two users cannot be established until direct media is disabled for the SIP Interface. The reason for this is that the device doesn't interfere in the SIP signaling. In other words, parameters such as IP addresses are not manipulated for calls between LAN and WAN (although required).
- If you have configured a SIP Recording rule (see [SIPREC SIP-based Media Recording](#) on page 330) for calls that have also been configured for direct media, using a SIP Interface ('Direct Media' parameter) or an IP Profile ('Direct Media Tag' parameter), the device automatically disables direct media for these calls (during their SIP signaling setup). This ensures that the media passes through the device so that it can be recorded and sent to the SRS. However, if you enable direct media using the [SBCDirectMedia] parameter (i.e., for all calls), direct media is always enforced and calls will not be recorded.

## Restricting Audio Coders

You can configure a list of permitted (allowed) voice coders that can be used for a specific SIP entity (leg). In other words, you can enforce the use of specific coders. If the SDP offer in the incoming SIP message doesn't contain any coder that is configured as an allowed coder, the device rejects the calls. If the SDP offer contains some coders that are configured as allowed coders, the device manipulates the SDP offer by removing the coders that are not configured as allowed coders, before routing the SIP message to its destination. The device also re-orders (prioritizes) the coder list in the SDP according to the listed order of configured allowed coders.

For example, assume the following:

- The SDP offer in the incoming SIP message contains the G.729, G.711, and G.723 coders.
- The allowed coders configured for the SIP entity include G.711 and G.729.

The device removes the G.723 coder from the SDP offer, re-orders the coder list so that G.711 is listed first, and sends the SIP message containing only the G.711 and G.729 coders in the SDP.

The allowed coders are configured in the Allowed Audio Coders Groups table. For more information, see [Configuring Allowed Audio Coder Groups](#) on page 659.

## Prioritizing Coder List in SDP Offer

In addition to restricting the use of coders using Allowed Audio Coders Groups (see [Configuring Allowed Audio Coder Groups](#) on page 659), you can also prioritize the coders listed in the SDP offer. This feature is referred to as *Coder Preference* and applies to both SBC legs:

- **Incoming SDP offer:** The device arranges the coder list in the incoming SDP offer according to the order of appearance of the Allowed Audio Coders Group that is associated with the incoming dialog. The coders listed higher up in the group take preference over ones listed lower down. To configure this, configure the 'Allowed Coders Mode' parameter in the associated IP Profile to **Preference** or **Restriction and Preference**. If you configure the parameter to **Preference**, the coders in the SDP offer that also appear in the Allowed Audio Coders Group are listed first in the SDP offer, and the coders in the SDP offer that do not appear in the Allowed Audio Coders Group are listed after the Allowed coders in the SDP offer. Therefore, this setting doesn't restrict coder use to Allowed coders, but uses (prefers) the Allowed coders whenever possible.
- **Outgoing SDP offer:** If only Allowed coders are used, the device arranges the coders in the SDP offer as described above.

## Multiple RTP Media Streams per Call Session

The device's SBC application supports multiple RTP media streams per SBC call session. It supports the negotiation of up to five media streams ('m=' line) in the SDP offer/answer model per session. The media can include a combination of any of the following types:

- Audio, indicated in the SDP as 'm=audio'
- Video, indicated in the SDP as 'm=video'
- Text, indicated in the SDP as 'm=text'
- Fax, indicated in the SDP as 'm=image'
- Binary Floor Control Protocol (BFCP), indicated in the SDP as 'm=application <port> UDP/BFCP'

The device transparently forwards Binary Floor Control Protocol (BFCP) signaling over UDP between IP entities (RFC 4582). BFCP is a signaling protocol used by some third-party conferencing servers to share content (such as video conferencing, presentations or documents) between conference participants (SIP clients supporting BFCP). The SDP offer/answer exchange model is used to establish (negotiate) BFCP streams between clients.

The BFCP stream is identified in the SDP as 'm=application <port> UDP/BFCP' and a dedicated UDP port is used for the BFCP streams.

## Interworking Miscellaneous Media Handling

This section describes various interworking features relating to media handling.

### Interworking RTP Redundancy

The device supports interworking of RTP redundancy (according to RFC 2198) between SIP entities. Employing IP Profiles, you can configure RTP redundancy handling per SIP entity:

- Generate RFC 2198 redundant packets, using the 'RTP Redundancy Depth' parameter.
- Determine RTP redundancy support in the RTP redundancy negotiation in SDP offer/answer, using the 'RTP Redundancy Mode' parameter. If not supported, the device discards RTP redundancy packets (if present) received from or sent to the SIP entity.

For more information, see the above parameters in [Configuring IP Profiles](#) on page 664.

### Interworking RTP-RTCP Multiplexing

The device supports interworking of RTP-RTCP multiplexing onto a single, local UDP port (according to RFC 5761) between SIP entities. Employing IP Profiles, you can configure RTP multiplexing per SIP entity, using the 'RTCP Mux' parameter (see [Configuring IP Profiles](#) on page 664).

### Interworking RTCP Attribute in SDP

The device supports interworking the RTCP attribute 'a=rtcp' in the SDP between SIP entities. Employing IP Profiles, you can configure RTCP attribute handling (add, remove or transparent) per SIP entity, using the 'SDP Handle RTCP' parameter (see [Configuring IP Profiles](#) on page 664).

### Interworking Crypto Lifetime Field

The device supports interworking the lifetime field in the 'a=crypto' attribute of the SDP, between SIP entities. Employing IP Profiles, you can configure the lifetime field handling (remove or retain) per SIP entity, using the IP Profile parameter 'SBC Remove Crypto Lifetime in SDP' (see [Configuring IP Profiles](#) on page 664).

### Interworking Media Security Protocols

The device supports interworking media security protocols for SRTP, between SIP entities. Employing IP Profiles, you can configure the security protocol (SDS and DTLS) per SIP entity, using the 'SBC Media Security Method' parameter (see [Configuring IP Profiles](#) on page 664). For more information on SDS and DTLS, see [Configuring SRTP](#) on page 313.

## Interworking ICE for NAT Traversal

The device supports interworking ICE for NAT traversal, between SIP entities. Employing IP Profiles, you can enable ICE per SIP entity, using the 'ICE Mode' parameter (see [Configuring IP Profiles](#) on page 664).

## SBC Authentication

The device can authenticate SIP servers and SBC users (clients). The different authentication methods are described in the subsequent subsections.

### SIP Authentication Server Functionality

The device can function as an Authentication server for authenticating incoming SIP message requests, based on HTTP authentication Digest with MD5 or SHA-256 (configured by [SIPServerDigestAlgorithm]). Alternatively, such requests can be authenticated by an external, third-party server.

When functioning as an Authentication server, the device can authenticate the following SIP entities:

- **SIP servers:** This is applicable to Server-type IP Groups. This provides protection from rogue SIP servers, preventing unauthorized usage of device resources and functionality. To authenticate remote servers, the device challenges the server with a user-defined username and password that is shared with the remote server. When the device receives an INVITE request from the remote server, it challenges the server by replying with a SIP 401 Unauthorized response containing the WWW-Authenticate header. The remote server then re-sends the INVITE containing an Authorization header with authentication information based on this username-password combination to confirm its identity. The device uses the username and password to authenticate the message prior to processing it.
- **SIP clients:** These are clients belonging to a User-type IP Group. This support prevents unauthorized usage of the device's resources by rogue SIP clients. When the device receives an INVITE or REGISTER request from a client (e.g., SIP phone) for SIP message authorization, the device processes the authorization as follows:
  - a. The device challenges the received SIP message only if it is configured as a SIP method (e.g., INVITE) for authorization. This is configured in the IP Groups table, using the 'Authentication Method List' parameter.
  - b. If the message is received without a SIP Authorization header, the device "challenges" the client by sending a SIP 401 or 407 response. The client then resends the request with an Authorization header (containing the username and password).
  - c. The device validates the SIP message according to the AuthNonceDuration, AuthChallengeMethod and AuthQOP parameters.
    - ◆ If validation fails, the device rejects the message and sends a 403 (Forbidden) response to the client.

- ◆ If validation succeeds, the device verifies client identification. It checks that the username and password received from the client is the same username and password in the device's SBC User Information table / database (see [Configuring SBC User Information](#) on page 775). If no username and password is configured in the SBC User Information table, the device authenticates the users based on the username and password configured for the relevant IP Group in the IP Groups table ('Username As Server' and 'Password As Server' parameters). If the client is not successfully authenticated after three attempts, the device sends a SIP 403 (Forbidden) response to the client. If the user is successfully identified, the device accepts the SIP message request.

The device's Authentication server functionality is configured per IP Group, using the 'Authentication Mode' parameter in the IP Groups table (see [Configuring IP Groups](#) on page 581).

## RADIUS-based Authentication of SIP User Agents

The device can authenticate SIP clients (users) using a remote RADIUS server. The device supports the RADIUS extension for digest authentication of SIP clients, according to draft-sterman-aaa-sip-01. Based on this standard, the device generates the nonce (in contrast to RFC 5090, where it is done by the RADIUS server).

RADIUS based on draft-sterman-aaa-sip-01 operates as follows:

1. The device receives a SIP request without an Authorization header from the SIP client.
2. The device generates the nonce and sends it to the client in a SIP 407 (Proxy Authentication Required) response.
3. The SIP client sends the SIP request with the Authorization header to the device.
4. The device sends an Access-Request message to the RADIUS server.
5. The RADIUS server verifies the client's credentials and sends an Access-Accept (or Access-Reject) response to the device.
6. The device accepts the SIP client's request (sends a SIP 200 OK or forwards the authenticated request) or rejects it (sends another SIP 407 to the SIP client).

To configure this feature, set the SBCServerAuthMode ini file parameter to 2.

## Interworking SIP Signaling

The device supports interworking of SIP signaling messages to ensure interoperability between communicating SIP UAs or entities. This is critical in network environments where the UAs on opposing SBC legs have different SIP signaling support. For example, some UAs may support different versions of a SIP method while others may not even support a specific SIP method. The configuration method for assigning specific SIP message handling modes to UAs, includes configuring an IP Profile with the required interworking mode, and then assigning the IP Profile to the relevant IP Group.



This section describes some of the device's support for handling SIP methods to ensure interoperability.

## Interworking SIP 3xx Redirect Responses

The device supports interworking of SIP 3xx redirect responses. By default, the device's handling of SIP 3xx responses is to send the Contact header unchanged. However, some SIP UAs may support different versions of the SIP 3xx standard while others may not even support SIP 3xx.

The handling of SIP 3xx can be configured for all calls, using the global parameter SBC3xxBehavior. To configure different SIP 3xx handling options for different UAs (i.e., per IP Group), use the IP Profiles table parameter, 'SBC Remote 3xx Mode'.

## Resultant INVITE Traversing Device

The device can handle SIP 3xx responses so that the new INVITE message sent as a result of the 3xx traverses the device. The reasons for enforcing resultant INVITEs to traverse the device may vary:


- The user that receives the 3xx is unable to route to the 3xx contact (i.e., the user is on the LAN and the new contact is on the WAN). In such a scenario, the device enables the user to reach the WAN contact and overcome NAT problems.
- Enforce certain SBC policies (e.g., call admission control, header manipulation) on the resultant INVITE.

The device enforces this by modifying each Contact in the 3xx response as follows:

- Changes the host part to the device's IP address – this change causes the remote user agent to send the INVITE to the device.
- Adds a special prefix ("T~&R\_") to the Contact user part – to identify the new INVITE as a 3xx resultant INVITE.

The SBC handling for the 3xx resultant INVITE is as follows:

1. The incoming INVITE is identified as a 3xx resultant INVITE according to the special prefix.
2. The device automatically replaces the SBC host part (in the Request-URI) with the host from the 3xx Contact.
3. The prefix ("T~&R\_") remains in the user part for the classification, manipulation, and routing mechanisms.
4. The classification, manipulation, and routing processes are done exactly like any other INVITE handling. The special prefix can be used for specific routing rules for 3xx resultant INVITEs.
5. The prefix is removed before the resultant INVITE is sent to the destination.



The process of this feature is described using an example:

1. The device receives the Redirect server's SIP 3xx response (e.g., Contact: <sip:User@IPPBX:5060;transport=tcp;param=a;q=0.5).
2. The device replaces the Contact header value with the special prefix and database key value as user part, and with the device's URL as host part (e.g., Contact: <sip:Prefix\_Key\_User@SBC:5070;transport=udp;q=0.5).
3. The device sends this manipulated SIP 3xx response to the Far-End User (FEU).
4. The FEU sends a new request with the Request-URI set to the value of the received 3xx response's Contact header (e.g., RequestURI: sip:Prefix\_Key\_User@SBC:5070;transport=udp).
5. Upon receipt of the new request from the FEU, the device replaces the Request-URI with the new destination address (e.g., RequestURI: sip:Prefix\_Key\_User@IPPBX:5070;transport=tcp;param=a).
6. The device removes the user prefix from the Request-URI, and then sends this Request-URI to the new destination (e.g., RequestURI: sip:User@IPPBX:5070;transport=tcp;param=a).

### Local Handling of SIP 3xx

The device can handle SIP 3xx responses on behalf of the dialog-initiating UA and retry the request (e.g., INVITE) using one or more alternative URIs included in the 3xx response. The new request includes SIP headers from the initial request such as Diversion, History-Info, P-Asserted-Id, and Priority. The source and destination URIs can be manipulated using the regular manipulation mechanism.

The device sends the new request to the alternative destination according to the IP-to-IP Routing table rules. (where the 'Call Trigger' field is set to **3xx**). It is also possible to specify the IP Group that sent the 3xx request as matching criteria for the re-routing rule in this table ('ReRoute IP Group ID' field).

## Interworking SIP Diversion and History-Info Headers

This device can be configured to interwork between the SIP Diversion and History-Info headers. This is important, for example, to networks that support the Diversion header but not the History-Info header, or vice versa. Therefore, mapping between these headers is crucial for preserving the information in the SIP dialog regarding how and why (e.g., call redirection) the call arrived at a certain SIP UA. If the Diversion header is used, you can specify the URI type (e.g., "tel:") to use in the header, using the SBCDiversionUriType parameter.

This feature is configured in the IP Profiles table using the following parameters:

- 'Diversion Header Mode' - defines the device's handling of the Diversion header
- 'History-Info Header Mode' - defines the device's handling of the History-Info header

The handling of the SIP Diversion and History-Info headers is described in the table below:

**Table 29-1: Handling of SIP Diversion and History-Info Headers**

Parameter Value	SIP Header Present in incoming SIP Message		Device Action	IP Header Present in outgoing SIP Message	
	Diversion	History-Info		Diversion	History-Info
'Diversion Header Mode' = <b>Add</b> 'History-Info Header Mode' = <b>Add</b>	Not present	Present	Diversion added from History-Info	Present	Present
'Diversion Header Mode' = <b>Add</b> 'History-Info Header Mode' = <b>Add</b>	Present	Not present	History-Info added from Diversion	Present	Present
'Diversion Header Mode' = <b>Add</b> 'History-Info Header Mode' = <b>Add</b>	Present	Present	Diversion replaced and added from History-Info History-Info replaced and added from Diversion	Present	Present

Parameter Value	SIP Header Present in incoming SIP Message		Device Action	IP Header Present in outgoing SIP Message	
'Diversion Header Mode' = * 'History-Info Header Mode' = *	Not present	Not present	As no headers are present on incoming message, nothing is added	Not present	Not present
'Diversion Header Mode' = <b>Add</b> 'History-Info Header Mode' = <b>As Is</b>	Not present	Present	Diversion added from History-Info	Present	Present
'Diversion Header Mode' = <b>As Is</b> 'History-Info Header Mode' = <b>Add</b>	Present	Not present	History-Info added from Diversion	Present	Present
'Diversion Header Mode' = <b>Add</b> 'History-Info Header Mode' = <b>Remove</b>	Not present	Present	Diversion added from History-Info History-Info removed	Present	Not present
'Diversion Header Mode' = <b>Remove</b> 'History-Info Header Mode' = <b>Add</b>	Present	Not present	History-Info added from Diversion Diversion removed	Not present	Present
'Diversion Header Mode' = <b>Remove</b> 'History-Info	Present	Present	Both removed	Not present	Not present

Parameter Value	SIP Header Present in incoming SIP Message		Device Action	IP Header Present in outgoing SIP Message	
Header Mode' = Remove					

## Interworking SIP REFER Messages

The device supports interworking of SIP REFER messages. SIP UAs may support different versions of the REFER standard while others may not even support REFER.

This feature supports the following:

- Attended, unattended, and semi-attended call transfers
- Sending INVITE, REFER-notifications, BYE, PRACK and Session Timer on behalf of peer PBXs
- Advanced routing rules for the new, initiated INVITE
- Forwarding early media after REFER while attempting to avoid transcoding (by sending session update)
- Interoperate with environments where different SIP UAs lack basic SIP functionality such as re-INVITE, UPDATE, PRACK, Delayed Offer, re-INVITE without SDP
- Session updates after connect to avoid transcoding

The handling of REFER can be configured for all calls, using the global parameter [SBCReferBehavior]. To configure different REFER handling options for different UAs (i.e., IP Groups), use the IP Profiles table parameter, 'Remote REFER Mode'.

- Local handling of REFER: This option is used for UAs that do not support REFER. Upon receipt of a REFER request, instead of forwarding it to the IP Group, the device handles it locally. It generates a new INVITE to the alternative destination according to the rules in the IP-to-IP Routing table (where the 'Call Trigger' field is set to **REFER**). It is also possible to specify the IP Group that sent the REFER request, as matching criteria for the re-routing rule in this table ('ReRoute IP Group ID' field).
- Transparent handling: The device forwards the REFER with the Refer-To header unchanged.
- Re-routing through SBC: The device changes the Refer-To header so that the re-routed INVITE is sent through the SBC application.
- IP Group Name: The device sets the host part in the REFER message to the name configured for the IP Group in the IP Groups table.

## Interworking SIP PRACK Messages

The device supports interworking of SIP Provisional Response ACKnowledgement (PRACK) messages (18x). While some UAs may not support PRACK (RFC 3262) others may require it. The

device can be configured to resolve this interoperable issue and enable sessions between such endpoints. SIP PRACK handling is configured using the IP Profile parameter, 'SBC Prack Mode':

- **Optional:** PRACK is optional for these UAs. If required, the device performs the PRACK process on behalf of the destination UA.
- **Mandatory:** PRACK is required for these UAs. Calls from UAs that do not support PRACK are rejected. Calls destined to these UAs are also required to support PRACK.
- **Transparent (default):** The device doesn't intervene with the PRACK process and forwards the request as is.

## Interworking SIP Session Timer

The device supports interworking of the SIP signaling keep-alive mechanism. The SIP standard provides a signaling keep-alive mechanism using re-INVITE and UPDATE messages. In certain setups, keep-alive may be required by some SIP UAs while for others it may not be supported. The device can resolve this mismatch by performing the keep-alive process on behalf of SIP UAs that do not support it.

To configure the handling of session expires, use the IP Profile parameter, 'SBC Session Expires Mode'.

## Interworking SIP Early Media

The device supports early media. Early media is when the media flow starts before the SIP call is established (i.e., before the 200 OK response). This occurs when the first SDP offer-answer transaction completes. The offer-answer options can be included in the following SIP messages:

- Offer in first INVITE, answer on 180, and no or same answer in the 200 OK
- Offer in first INVITE, answer on 180, and a different answer in the 200 OK (not standard)
- INVITE without SDP, offer in 180, and answer in PRACK
- PRACK and UPDATE transactions can also be used for initiating subsequent offer-answer transactions before the INVITE 200 OK response.
- In a SIP dialog life time, media characteristics after originally determined by the first offer-answer transaction can be changed by using subsequent offer-answer transactions. These transactions may be carried either in UPDATE or re-INVITE transactions. The media handling is similar to the original offer-answer handling. If the offer is rejected by the remote party, no media changes occur (e.g., INVITE without SDP, then 200 OK and ACK, offer-answer within an offer-answer, and Hold re-INVITE with IP address of 0.0.0.0 - IP address is unchanged).


The device supports various interworking modes for early media between SIP UAs (i.e., IP Groups):


- **Early Media Enabling:** The device supports the interworking of early media between SIP UAs that support early media and those that do not support receipt of early media. Early media can arrive in provisional responses to an INVITE request. The device forwards the

request of early media for IP Groups that support this capability; otherwise, the device terminates it. Provisional responses whose SDP are suppressed are changed to a SIP 180 response. This feature is also supported for delayed offers. This is configured using the IP Profile parameter, 'SBC Remote Early Media Support'. The device refers to the parameter also for features that require early media such as playing ringback tone.

- **Early Media Response Type:** The device supports the interworking of different SIP provisional response types between UAs for forwarding the early media to the caller. This can support all early media response types (default), SIP 180 only, or SIP 183 only, and is configured by the IP Profile parameter, 'SBC Remote Early Media Response Type'.
- **Multiple 18x:** The device supports the interworking of different support for multiple 18x responses (including 180 Ringing, 181 Call is Being Forwarded, 182 Call Queued, and 183 Session Progress) that are forwarded to the caller. The UA can be configured as supporting only receipt of the first 18x response (i.e., the device forwards only this response to the caller), or receipt of multiple 18x responses (default). This is configured by the IP Profile parameter, 'SBC Remote Multiple 18x Support'.
- **Early Media RTP:** The device supports the interworking with remote clients that send 18x responses with early media and whose subsequent RTP is delayed, and with remote clients that do not support this and require RTP to immediately follow the 18x response. Some clients do not support 18x with early media, while others require 18x with early media (i.e., they cannot play ringback tone locally). These various interworking capabilities are configured by the IP Profile parameters, 'Remote Early Media RTP Detection Mode', 'SBC Remote Supports RFC 3960', and 'SBC Remote Can Play Ringback'. See the flowcharts below for the device's handling of such scenarios:

**Figure 29-1: SBC Early Media RTP - 18x without SDP**



**Figure 29-2: SBC Early Media RTP - 18x with SDP**

## Interworking SIP re-INVITE Messages

The device supports interworking of SIP re-INVITE messages. This enables communication between endpoints that generate re-INVITE requests and those that do not support the receipt of re-INVITES. The device doesn't forward re-INVITE requests to IP Groups that do not support it. Instead, it sends a SIP response to the re-INVITE request, which can either be a success or a failure, depending on whether the device can bridge the media between the endpoints. The device can also handle re-INVITES with or without an SDP body, enabling communication between endpoints that do not support re-INVITE requests without SDP, and those that require SDP. The device generates an SDP offer and adds it to the incoming re-INVITE request if it doesn't contain an SDP and only then forwards it to the destination endpoint. This interworking support is configured by the IP Profile parameter, 'SBC Remote Reinvite Support'.

## Interworking SIP UPDATE Messages

The device supports interworking of the SIP UPDATED message. This enables communication between UAs that generate UPDATE requests and those that do not support the receipt of UPDATE requests. The device doesn't forward UPDATE requests to IP Groups that do not



support it. Instead, it sends a SIP response to the UPDATE request which can either be a success or a failure, depending on whether the device can bridge the media between the endpoints. The handling of UPDATE messages is configured by the IP Profile parameter 'SIP UPDATE Support'.

## Interworking SIP re-INVITE to UPDATE

The device enables communication between endpoints (IP Groups) that do not support re-INVITE requests but support the UPDATE method, and vice versa. The device translates the re-INVITE request to the UPDATE request, and vice versa. Note that if a re-INVITE request arrives without SDP, the device generates the SDP and adds it to the outgoing UPDATE request. To enable this feature, each IP Group needs to be configured with its unique capabilities by associating it with a relevant IP Profile. For example, an IP Group that supports UPDATE requests but not re-INVITES would be configured as follows:

- SBCRemoteUpdateSupport = 2 (Supported)
- SBCRemoteReinviteSupport = 0 (Not Supported)

If a re-INVITE request needs to be forwarded to this IP Group, it is translated to an UPDATE request.

## Interworking Delayed Offer

The device supports interworking of INVITE messages with and without SDP between SIP entities. The device enables sessions between endpoints (IP Groups) that send INVITES without SDP (i.e., delayed media) and those that do not support the receipt of INVITES without SDP. The device creates an SDP and adds it to INVITES that arrive without SDP. Delayed offer is also supported when early media is present.

Employing IP Profiles, you can configure this interworking feature per SIP entity, using the 'SBC Remote Delayed Offer Support' parameter (see [Configuring IP Profiles](#) on page 664).

## Interworking Call Hold

The device supports the interworking of call hold / retrieve requests between SIP entities supporting different call hold capabilities:

- Interworking SDP call hold formats. This is configured by the IP Profile parameter, 'SBC Remote Hold Format'.
- Interworking the play of the held tone for IP entities that cannot play held tones locally. This is configured by the IP Profile parameter, 'Play Held Tone'.
- Interworking generation of held tone where the device generates the tone to the held party instead of the call hold initiator. This is configured by the IP Profile parameter, 'SBC Reliable Held Tone Source'.

To configure IP Profiles, see [Configuring IP Profiles](#) on page 664.

## Interworking SIP Via Headers

The device supports the interworking of SIP Via headers between SIP entities. For the outgoing message sent to a SIP entity, the device can remove or retain all the Via headers received in the incoming SIP request from the other side. Employing IP Profiles, you can configure this interworking feature per SIP entity, using the 'Keep Incoming Via Headers' parameter (see [Configuring IP Profiles](#) on page 664).

## Interworking SIP User-Agent Headers

The device supports the interworking of SIP User-Agent headers between SIP entities. For the outgoing message sent to a SIP entity, the device can remove or retain all the User-Agent headers received in the incoming SIP request/response from the other side. Employing IP Profiles, you can configure this interworking feature per SIP entity, using the 'Keep User-Agent Header' parameter (see [Configuring IP Profiles](#) on page 664).

## Interworking SIP Record-Route Headers

The device supports the interworking of SIP Record-Route headers between IP entities. For the outgoing message sent to a SIP entity, the device can remove or retain all the Record-Route headers received in the incoming SIP request/response from the other side. Employing IP Profiles, you can configure this interworking feature per SIP entity, using the 'Keep Incoming Routing Headers' parameter (see [Configuring IP Profiles](#) on page 664).

## Interworking SIP To-Header Tags in Multiple SDP Answers

The device supports the interworking of SIP To-header tags in call forking responses (i.e., multiple SDP answers) between IP entities. The device can either use the same To-header tag value for all SDP answers sent to the SIP entity, or send each SDP answer with its original tag. Employing IP Profiles, you can configure this interworking feature per SIP entity, using the 'Remote Multiple Early Dialogs' parameter (see [Configuring IP Profiles](#) on page 664).

## Interworking In-dialog SIP Contact and Record-Route Headers

The device supports the interworking of in-dialog, SIP Contact and Record-Route headers between SIP entities. Employing IP Profiles, you can configure this interworking feature per SIP entity, using the 'Remote Representation Mode' parameter (see [Configuring IP Profiles](#) on page 664).

## 30 Utilizing Gateway Channel Resources for SBC

The device can utilize resources of non-configured Gateway channels for SBC sessions, regardless of whether the device is licensed for SBC functionality. This feature, in essence, allows "call" resources to be migrated from the Gateway application to the SBC application, allowing you to migrate your Gateway deployment to an all IP-based voice network with only a simple configuration change. One of the main advantages of the feature is that if you purchased the device for deploying it initially as a Gateway for PSTN calls, you can at any stage easily use the device for SBC calls without having to purchase an SBC license.

A Gateway channel is considered "not configured" if it is not associated with any Trunk Group (see [Configuring Trunk Groups](#) on page 903). If all Gateway channels are configured, resources from these channels cannot be used for SBC sessions. If the resources of a currently active SBC call is obtained from a Gateway channel and you configure all Gateway channels during the call, the device maintains the SBC call until it is terminated by the call parties, but obtaining resources from Gateway channels for new SBC calls will not be made possible.

For every non-configured Gateway channel, one SBC session can be processed. For example:

A License Key licensing 1 E1 can support up to 31 SBC sessions (31 channels for E1) if all the Gateway channels are not configured. If the License Key also provides a license for 5 SBC sessions, up to 36 SBC sessions (31 channels for E1 + 5 for SBC) can be supported.

The number of SBC sessions that can be derived from using resources from Gateway channels that are not configured is displayed in the Web interface's License Key page (see [Viewing the License Key](#) on page 1233), in the 'TDM-to-SBC Sessions' field.



- To support the feature, the License Key installed on your device must include the "TDM-to-SBC" (TDM2SBC) feature key; otherwise, to purchase the feature, contact the sales representative of your purchased device to upgrade your License Key.
- The maximum number of SBC sessions that can be supported is according to the device's maximum SBC capacity (see [Capacity for Signaling, Media and User Registrations](#) on page 1952).


## 31 Configuring General SBC Settings

This section describes configuration of various SBC features.

### Interworking Dialog Information in SIP NOTIFY Messages

You can enable the device to interwork dialog information (XML body) received in SIP NOTIFY messages from a remote (WAN) application server. The NOTIFY message is sent by application servers to notify a SIP client, subscribed to a service and located behind the device (LAN), of the status of another SIP client in the LAN. For example, user B can subscribe to an application server for call pick-up service, whereby if user A's phone rings, the application server notifies user B. User B can then press a pre-configured key sequence to answer the call.

The NOTIFY message contains the XML body with call identifiers (call-id and tags). However, as the application server is located in the external network WAN and the SIP clients behind the device, the call dialog information sent by the application server reflects only the dialog between the device and itself; not that of the involved SIP clients. This is due to, for example, the device's topology hiding (e.g., IP address) of its LAN elements. The device resolves this by replacing the call identifiers received from the application server with the correct call identifiers (e.g., user A and user B). Thus, users subscribed to the service can receive relevant NOTIFY messages from the device and use the service.



#### ➤ To enable the feature:

- Configure the 'SBC Dialog-Info Interworking' (EnableSBCDialogInfoInterworking) parameter to **Enable**.

When the feature is disabled, the device forwards the NOTIFY message as is, without modifying its XML body.

Below is an example of an XML body where the call-id, tags, and URIs have been replaced by the device:

```
<?xml version="1.0"?>
<dialog-info xmlns="urn:ietf:params:xml:ns:dialog-info"
```

```
version="10" state="partial"
entity="sip:alice@example.com">
<dialog id="zxcvbnm3" call-id="67402270@10.132.10.150"
local-tag="1c137249965"
remote-tag="CCDORRTDRKIKWFVBRWYM" direction="initiator">
<state event="replaced">terminated</state>
</dialog>
<dialog id="sfhjsjk12" call-id="67402270@10.132.10.150"
local-tag="1c137249965"
remote-tag="CCDORRTDRKIKWFVBRWYM" direction="receiver">
<state reason="replaced">confirmed</state>
<replaces
call-id="67402270@10.132.10.150"
local-tag="1c137249965"
remote-tag="CCDORRTDRKIKWFVBRWYM"/>
<referred-by>
sip:bob-is-not-here@vm.example.net
</referred-by>
<local>
<identity display="Jason Forster">
sip:jforsters@home.net
</identity>
<target uri="sip:alice@pc33.example.com">
<param pname="+sip.rendering" pval="yes"/>
</target>
</local>
<remote>
<identity display="Cathy Jones">
sip:cjones@example.net
</identity>
<target uri="sip:line3@host3.example.net">
<param pname="actor" pval="attendant"/>
<param pname="automaton" pval="false"/>
</target>
</remote>
</dialog>
</dialog-info>
```

## 32 Configuring Call Admission Control

You can implement Call Admission Control (CAC) to regulate the volume of voice traffic handled by the device.



Call Admission Control applies the **same** maximum concurrent call limit to all users associated with it. If you want to apply a different maximum concurrent call limit to each user, you need to use tags in Call Setup Rules and Dial Plans, as described in [Configuring Maximum Concurrent Calls per Specific User](#) on page 1171.

CAC configuration is done using two tables with parent-child type relationship:

- Call Admission Control Profile table: This is the parent table, which defines a name for the CAC profile.
- Call Admission Control Rule table: This is the child table, which defines the actual CAC rules for the profile.

You can configure up to 102 CAC profiles and up to 102 CAC rules. In addition, a CAC profile can be configured with up to 8 CAC rules.

Once you have configured a CAC profile with CAC rules, you need to assign it to any of the following SIP configuration entities (using the 'CAC Profile' parameter):

- IP Group (see [Configuring IP Groups](#) on page 581)
- SIP Interface (see [Configuring SIP Interfaces](#) on page 561)
- SRD (see [Configuring SRDs](#) on page 549)

CAC rules define the maximum number of allowed concurrent calls (SIP dialog-initiating requests) for the assigned SIP entity (listed above) and per registered user belonging to the SIP entity. This can also include the maximum number of allowed concurrent SIP dialogs per second (*rate*). The CAC rule can be defined for a specific SIP message type (e.g., only INVITEs) as well as for a specific call direction (e.g., only outbound calls).

- **Token Bucket:** This scheme is a SIP-dialog rate control using the token-bucket mechanism. Token bucket is a control mechanism that determines the rate of SIP dialog processing based on the presence of tokens in the bucket. Tokens in the bucket are removed ("cached in") for the ability to process each dialog. If there are no tokens, the device rejects the dialog request with a SIP 480 (Temporarily Unavailable). Configuration of the token-bucket mechanism involves the following:
  - Configuring the number of tokens that are added to the bucket per second. This is referred to as *rate*. To process (allow) a SIP dialog, the device needs a token from the bucket.
  - Configuring the maximum number of tokens that the bucket can hold and thus, the maximum number of tokens that can be used for processing SIP dialogs that are received at one time. This is referred to as *burst*.

For example, assume that the rate is configured to 1 and the burst to 4:

- One token is added to the bucket every second.
- The maximum number of tokens that the bucket can hold is four.
- If SIP dialogs have never been received by the device, the bucket is filled to its maximum, which is four tokens (i.e., burst), regardless of the number of seconds that have passed.
- If four SIP dialogs are received at the same time (i.e., burst), the device uses the four tokens to process the dialogs. The bucket is now left with no tokens at that given moment, but after a second, a new token is added to the bucket (due to the rate). If there are no calls for the next three seconds, the bucket fills up again to four tokens (and no more).
- If the bucket contains four tokens (i.e., full) and five SIP dialogs are received at the same time, the device uses the four tokens to process four of the dialogs and rejects one.
- If the bucket has one token and SIP dialogs are then received every second, the device uses the token to process the first dialog, adds a token to the bucket after a second and processes the second dialog, and so on.

Your CAC rule can also define a guaranteed number of concurrent calls (reserved capacity) for the assigned SIP entity (see above) . Reserved capacity is especially useful when the device operates with multiple entities. For example, if the total call capacity supported by the device is 200, a scenario may arise where a SIP entity may reach 200 call sessions, leaving no available call resources for the other SIP entities. If the reserved call capacity of a SIP entity is threatened by a new call for a different SIP entity, the device rejects the call to safeguard the reserved capacity.

Requests that reach the user-defined call limit (maximum concurrent calls or call rate) are sent to an alternative route, if configured (in the IP-to-IP Routing table). If no alternative routing rule exists, the device rejects the SIP request with a SIP 480 "Temporarily Unavailable" response.



- If the device rejects an incoming SIP dialog request due to CAC, it sends a SIP 480 "Temporarily Unavailable" response.
- The device applies the CAC rule for the incoming leg immediately after the Classification process. If the call / request is rejected at this stage, no routing is performed. The enforcement for the outgoing leg is performed within each alternative route iteration. This is accessed from two places - during initial classification / routing and during alternative routing.
- CAC doesn't apply to Test Calls (see [Configuring Basic Incoming Test Calls](#) on page 1550).

The following procedure describes how to configure CAC profiles through the Web interface. You can also configure them through other management interfaces:

- Call Admission Control Profile table: ini file [SBCAdmissionProfile] or CLI (`configure voip > sbc cac-profile`)

- Call Admission Control Rule table: ini file [SBCAdmissionRule] or CLI (`configure voip > sbc cac-rule`)

➤ **To configure a CAC profile:**

1. Open the Call Admission Control Profile table (**Setup** menu > **Signaling & Media** tab > **SBC** folder > **Call Admission Control Profile**).
2. Click **New**; the following dialog box appears:

Call Admission Control Profile

GENERAL

Index: 0

Name:

3. Configure a CAC profile according to the parameters described in the table below.
4. Click **Apply**.

**Table 32-1: Call Admission Control Profile Table Parameter Description**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [Name]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 40 characters. By default, no value is defined. <b>Note:</b> <ul style="list-style-type: none"> <li>■ The parameter value can't contain a forward slash (/).</li> <li>■ The parameter value can't be configured with the character string "any" (upper or lower case).</li> </ul>

5. In the Call Admission Control Profile table, select the required row, and then click the **Call Admission Control Rule** link located below the table; the Call Admission Control Rule table appears.
6. Click **New**; the following dialog box appears:

Call Admission Control Rule

MATCH

Index: 0

Request Type: All

Request Direction: Both

ACTION

Limit: -1

Limit per User: -1

Rate: 0

Maximum Burst: 0

Rate Per User: 0

Maximum Burst Per User: 0

Reserved Capacity: 0



7. Configure a CAC rule according to the parameters described in the table below.
8. Click **Apply**.

**Table 32-2: Call Admission Control Rule Table Parameter Description**

Parameter	Description
<b>Match</b>	
'Index' sbc-admission-rule- <Index>/<Index> [SBCAdmissionRule_RuleIndex]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Request Type' request-type [SBCAdmissionRule_ RequestType]	Defines the type of SIP dialog-initiating request to which you want to apply the rule (not to subsequent requests, which can be of different type and direction). <ul style="list-style-type: none"> <li>■ [0] <b>All</b> (default)</li> <li>■ [1] <b>INVITE</b></li> <li>■ [2] <b>SUBSCRIBE</b></li> <li>■ [3] <b>Other</b> = All SIP request types except INVITEs and SUBSCRIBEs (e.g., REGISTER).</li> </ul>
'Request Direction' request-direction [SBCAdmissionRule_ RequestDirection]	Defines the call direction of the SIP request to which the rule applies. <ul style="list-style-type: none"> <li>■ [0] <b>Both</b> = (Default) Rule applies to inbound and outbound SIP dialogs.</li> <li>■ [1] <b>Inbound</b> = Rule applies only to inbound SIP dialogs.</li> <li>■ [2] <b>Outbound</b> = Rule applies only to outbound SIP dialogs.</li> </ul>
<b>Action</b>	
'Limit' limit [SBCAdmissionRule_Limit]	Defines the maximum allowed number of concurrent SIP dialogs. You can also use the following special values: <ul style="list-style-type: none"> <li>■ [-1] <b>-1</b> = (Default) Unlimited number of concurrent SIP dialogs.</li> <li>■ [0] <b>0</b> = Blocks all the SIP dialog types specified in the 'Request Type' parameter (above).</li> </ul> <b>Note:</b> The parameter is not related to the rate-limiting algorithms.

Parameter	Description
'Limit per User' limit-per-user [SBCAdmissionRule_LimitPerUser]	<p>Defines the maximum number of allowed concurrent SIP dialogs per user.</p> <p>You can also use the following special values:</p> <ul style="list-style-type: none"> <li>■ [-1] <b>-1</b> = (Default) Unlimited number of concurrent SIP dialogs per user.</li> <li>■ [0] <b>0</b> = Blocks all the SIP dialog types specified in the 'Request Type' parameter (above).</li> </ul> <p><b>Note:</b> The parameter is not related to the rate-limiting algorithms.</p>
'Rate' rate [SBCAdmissionRule_Rate]	<ul style="list-style-type: none"> <li>■ <b>Token Bucket algorithm:</b> Defines the number of tokens added to the token "bucket" per second, where a token "buys" a SIP dialog. For example, if you configure the parameter to 1, one token is added to the bucket every second. If there are no calls for five seconds, the bucket would have accumulated 5 tokens.</li> </ul> <p>The valid value is 0 to 65,535. The default is 0 (i.e., unlimited rate).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you configure the parameter, you <b>must</b> also configure the 'Maximum Burst' parameter to a non-zero value.</li> </ul>
'Maximum Burst' max-burst [SBCAdmissionRule_MaxBurst]	<p>Defines the maximum number of SIP dialogs that can be processed at any given time.</p> <p>Token Bucket algorithm: In other words, it defines the maximum number of tokens that the "bucket" can hold. The device only accepts a SIP dialog if a token exists in the "bucket". Once the SIP dialog is accepted, a token is removed from the "bucket". If a SIP dialog is received by the device and the token "bucket" is empty, the device rejects the SIP dialog. Alternatively, if the "bucket" is full, for example, 100 tokens, and 101 SIP dialogs arrive (before another token is added to the "bucket", i.e., faster than that configured in the 'Rate' parameter), the device accepts the first 100 SIP dialogs and rejects the last one. Dropped requests are not counted in the "bucket".</p> <p>The valid value is 0 to 65,535. The default is 0 (i.e.,</p>

Parameter	Description
	<p>unlimited SIP dialogs).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter functions together with the 'Rate' parameter (see above). Therefore, the parameter must be configured.</li> <li>■ The parameter's value cannot be greater than 10 times (x) the value of the 'Rate' parameter. For example, if you configured the 'Rate' parameter to 2, you can configure the 'Maximum Burst' parameter to any value less than or equal to 20 (i.e., 10 x 2).</li> <li>■ The token bucket feature is per SIP request type and SIP request direction.</li> </ul>
'Rate Per User' <code>rate-per-user</code> [SBCAdmissionRule_ RatePerUser]	<p>Defines the maximum allowed number of concurrent SIP dialogs per registered user that can be handled per second.</p> <p>The valid value is 0 to 65,535. The default is 0 (i.e., unlimited rate).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you configure this parameter, you must also configure the 'Maximum Burst per User' parameter to a non-zero value (see below).</li> </ul>
'Maximum Burst Per User' <code>max-burst-per-user</code> [SBCAdmissionRule_ MaxBurstPerUser]	<p>Defines the maximum number of tokens (SIP dialogs) per user that the bucket can hold (see the 'Maximum Burst' parameter for a detailed description).</p> <p>The valid value is 0 to 65,535. The default is 0 (i.e., unlimited SIP dialogs).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter functions together with the 'Rate Per User' parameter (see above).</li> </ul>
'Reserved Capacity' <code>reservation</code> [SBCAdmissionRule_ Reservation]	<p>Defines the guaranteed (minimum) call capacity.</p> <p>The default is 0 (i.e., no reserved capacity).</p> <p>If you configure reserved call capacity for an SRD and each of its associated IP Groups, the SRD's reserved call capacity must be greater or equal to the summation of the reserved call capacity of all these IP Groups. In other words, the SRD serves as the "parent" reserved call capacity. If the SRD's reserved call capacity is greater, the</p>

Parameter	Description
	<p>extra call capacity can be used as a shared pool between the IP Groups for unreserved calls when they exceed their reserved capacity. For example, assume that the reserved capacity for an SRD and its associated IP Groups are as follows:</p> <ul style="list-style-type: none"> <li>■ SRD reserved call capacity: 40</li> <li>■ IP Group ID 1 reserved call capacity: 10</li> <li>■ IP Group ID 2 reserved call capacity: 20</li> </ul> <p>In this setup, the SRD offers a shared pool for unreserved call capacity of 10 [i.e., <math>40 - (10 + 20)</math>]. If IP Group ID 1 needs to handle 15 calls, it is guaranteed 10 calls and the remaining 5 is provided from the SRD's shared pool. If the SDR's shared pool is currently empty and resources for new calls are required, the quota is taken from the device's total capacity, if available. For example, if IP Group ID 1 needs to handle 21 calls, it's guaranteed 10, the SRD's shared pool provides another 10, and the last call is provided from the device's total call capacity support (e.g., of 200).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is not related to the rate-limiting algorithms.</li> <li>■ Reserved call capacity is applicable only to IP Groups and SRDs.</li> <li>■ Reserved call capacity is applicable only to INVITE and SUBSCRIBE messages.</li> <li>■ Reserved call capacity must be less than the maximum capacity (limit) configured for the CAC rule (see the 'Limit' parameter).</li> <li>■ The total reserved call capacity configured for all CAC rules must be within the device's total call capacity support.</li> </ul>

## 33 Routing SBC

This section describes configuration of call routing for the SBC application.

### Configuring Classification Rules

The Classification table lets you configure up to 102 Classification rules. A Classification rule classifies incoming SIP dialog-initiating requests (e.g., INVITE messages) to a "source" IP Group. The source IP Group is the SIP entity that sent the SIP dialog request. Once classified, the device uses the IP Group to process the call (manipulation and routing).

You can also use the Classification table for employing SIP-level access control for successfully classified calls, by configuring Classification rules with whitelist and blacklist settings. If a Classification rule is configured as a whitelist ("Allow"), the device accepts the SIP dialog and processes the call. If the Classification rule is configured as a blacklist ("Deny"), the device rejects the SIP dialog.

Configuration of Classification rules includes two areas:

- **Match:** Defines the matching characteristics of the incoming IP call (e.g., source SIP Interface and IP address). Classification is primarily based on the SIP Interface as the matching characteristics on which the incoming dialog is received. As Classification rules must first be assigned an SRD, the SIP Interface is one that belongs to the SRD. Therefore, Classification rules are configured per SRD, where multiple SIP Interfaces can be used as matching characteristics. However, as multiple SRDs are relevant only for multi-tenant deployments, for most deployments only a single SRD is required. As the device provides a default SRD ("Default\_SRD"), where only one SRD is required, the device automatically assigns it to the Classification rule.
- **Action:** Defines the action that is done if the incoming call matches the characteristics of the rule (i.e., classifies the call to the specified IP Group).

The device searches the table from **top to bottom** for the **first** rule that matches the characteristics of the incoming call. If it finds a matching rule, it classifies the call to the IP Group configured for that rule. If you are using source tags to classify incoming calls to IP Groups, then once the device locates a matching rule (including a match for the source tag), the device searches the IP Groups table for an IP Group with the matching tag. For more information on classification based on tags, see [Configuring Classification Based on Tags](#) on page 1073.



Configure stricter classification rules higher up in the table than less strict rules to ensure incoming dialogs are classified to the desired IP Group. *Strict* refers to the number of matching characteristics configured for the rule. For example, a rule configured with source host name and destination host name as matching characteristics is stricter than a rule configured with only source host name. If the rule configured with only source host name appears higher up in the table, the device ("erroneously") uses the rule to classify incoming dialogs matching this source host name (even if they also match the rule appearing lower down in the table configured with the destination host name as well).

If the device doesn't find a matching rule (i.e., classification fails), the device rejects or allows the call depending on configuration. For more information, see [Configuring Action for Classification Failure](#) on page 1075.

The Classification table is used to classify incoming SIP dialog-initiating requests **only** if the following classification stages **fail**:

1. **Classification Stage 1 - Classification by Users Registration Database:** The device searches its users registration database to check whether the incoming SIP dialog-initiating request arrived from a registered user. The device searches the database for a user that matches the address-of-record (AOR) and Contact of the incoming SIP message:

- Compares the SIP Contact header to the contact value in the database.
- Compares the URL in the SIP P-Asserted-Identity/From header to the registered AOR in the database.

If the device finds a matching registered user, it classifies the user to the IP Group that is associated with the user in the database.

If this classification stage fails, the device proceeds to classification by Proxy Set (see below).



You can enable or disable classification by the device's users registration database per SIP Interface. For more information, see the 'Classify By Registration DB' parameter in the SIP Interfaces table, as described in [Configuring SIP Interfaces](#) on page 561.

2. **Classification Stage 2 - Classification by Proxy Set:** If classification of the incoming SIP dialog-initiating request by users registration database fails (see above), the device performs classification based on Proxy Set. This classification is applicable only to Server-type IP Groups and is done only if you've enabled classification by Proxy Set ('Classify By Proxy Set' parameter in the IP Groups table, as described in [Configuring IP Groups](#) on page 581).

By default, the device checks if the **source IP address** (ISO Layer 3) of the incoming SIP dialog message (e.g., INVITE) matches an IP address in the Proxy Set that is associated with the IP Group (assigned in the IP Groups table). If the Proxy Set is configured with a host name, the device checks if the source IP address matches one of the dynamically DNS-

resolved IP addresses. If such a Proxy Set exists, the device classifies the SIP dialog to the IP Group associated with the Proxy Set.

You can also configure Classification by Proxy Set whereby the device checks if the IP address in the **SIP Contact header** of the incoming SIP dialog matches an IP address in the Proxy Set that is associated with the IP Group. If the header contains a SIP URI that has an IP address (not hostname) in the host part and it matches an IP address in the Proxy Set, the call is classified to the IP Group. This mode is useful, for example, when the source IP address is an internal address.

The IP address to use (source IP address or IP address in Contact header) of the incoming SIP dialog for classification by Proxy Set is configured by the global parameter, 'Classify By Proxy Set Mode' (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **SIP Definitions General Settings**), as shown below. When configured to **Both**, the device first checks if the source IP address matches an IP address in the Proxy Set. Only if there is no match, does it check if the IP address in the SIP Contact header matches an IP address in the Proxy Set.

#### Classify By Proxy Set Mode

IP address ▼

If more than one Proxy Set is configured with the same IP address and associated with the same SIP Interface, the device may classify and route the SIP dialog to an incorrect IP Group. In such a scenario, a warning is generated in the syslog message. However, if some Proxy Sets are configured with the same IP address but different ports (e.g., 10.1.1.1:5060 and 10.1.1.1:5070) and the 'Classification Input' parameter is configured to **IP Address, Port & Transport Type**, classification (based on IP address and port combination) to the correct IP Group is achieved. Therefore, when classification is by Proxy Set, pay attention to the configured IP addresses and the 'Classification Input' parameter of your Proxy Sets. When more than one Proxy Set is configured with the same IP address, the device selects the matching Proxy Set in the following precedence order:

- a. Selects the Proxy Set whose IP address, port, and transport type match the source of the incoming dialog.
- b. If no match is found for a), it selects the Proxy Set whose IP address and transport type match the source of the incoming dialog (if the 'Classification Input' parameter is configured to **IP Address Only**).
- c. If no match is found for b), it selects the Proxy Set whose IP address match the source of the incoming dialog (if the 'Classification Input' parameter is configured to **IP Address Only**).


If classification by Proxy Set fails (or classification by Proxy Set is disabled), the device proceeds to classification by the Classification table, as described in this section



- For security, it is recommended to classify SIP dialogs based on Proxy Set only if the IP address of the Server-type IP Group is **unknown**. In other words, if the Proxy Set associated with the IP Group is configured with an FQDN. In such cases, the device classifies incoming SIP dialogs to the IP Group based on the DNS-resolved IP address. If the IP address is known, it is recommended to use a Classification rule instead (and disable the Classify by Proxy Set feature), where the rule is configured with not only the **IP address, but also with SIP message characteristics** to increase the strictness of the classification process. The reason for preferring classification based on Proxy Set when the IP address is unknown is that IP address forgery (commonly known as IP spoofing) is more difficult than malicious SIP message tampering and therefore, using a Classification rule without an IP address offers a weaker form of security. When classification is based on Proxy Set, the Classification table for the specific IP Group is ignored.
- If multiple IP Groups are associated with the same Proxy Set, use Classification rules to classify the incoming dialogs to the IP Groups (do **not** use the Classify by Proxy Set feature).
- When using the Classification table for classification instead of by Proxy Set, it's recommended to enable the 'Validate Source IP' parameter in the IP Groups table. This setting verifies that the request was sent from one of the IP addresses (including DNS-resolved IP addresses) of the associated Proxy Set.
- The device saves incoming SIP REGISTER messages in its registration database. If the REGISTER message is received from a User-type IP Group, the device sends the message to the configured destination.

The flowchart below illustrates the classification process:





The following procedure describes how to configure Classification rules through the Web interface. You can also configure it through ini file [Classification] or CLI (`configure voip > sbc classification`).

➤ **To configure a Classification rule:**

1. Open the Classification table (**Setup** menu > **Signaling & Media** tab > **SBC** folder > **Classification Table**).
2. Click **New**; the following dialog box appears (cropped for convenience):

3. Configure the Classification rule according to the parameters described in the table below.

4. Click **Apply**.

**Table 33-1: Classification Table Parameter Descriptions**

Parameter	Description
'SRD' srd-name [SRDName]	<p>Assigns an SRD to the rule as a matching characteristic for the incoming SIP dialog.</p> <p>If only one SRD is configured in the SRDs table, the SRD is assigned to the rule by default. If multiple SRDs are configured in the SRDs table, no value is assigned.</p> <p>To configure SRDs, see <a href="#">Configuring SRDs</a> on page 549.</p> <p><b>Note:</b> The parameter is mandatory.</p>
<b>Match</b>	
'Index' [Index]	<p>Defines an index number for the new table row.</p> <p><b>Note:</b> Each row must be configured with a unique index.</p>
'Name' classification-name [ClassificationName]	<p>Defines a descriptive name, which is used when associating the row in other tables.</p> <p>The valid value is a string of up to 40 characters. By default, no name is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Configure each row with a unique name.</li> <li>■ The parameter value can't be configured with the character string "any" (upper or lower case).</li> </ul>
'Source SIP Interface' src-sip-interface-name [SrcSIPInterfaceName]	<p>Assigns a SIP Interface to the rule as a matching characteristic for the incoming SIP dialog.</p> <p>The default is <b>Any</b> (i.e., all SIP Interfaces belonging to the SRD assigned to the rule).</p> <p><b>Note:</b> The SIP Interface must belong to the SRD assigned to</p>

Parameter	Description
	the rule (see the 'SRD' parameter in the table).
'Source IP Address' src-ip-address [SrcAddress]	<p>Defines a source IP address as a matching characteristic for the incoming SIP dialog.</p> <p>The valid value is an IP address in dotted-decimal notation. In addition, the following wildcards can be used:</p> <ul style="list-style-type: none"> <li>■ "x" wildcard: represents single digits. For example, 10.8.8.xx represents all addresses between 10.8.8.10 and 10.8.8.99.</li> <li>■ Asterisk (*) wildcard: represents any number between 0 and 255. For example, 10.8.8.* represents all addresses between 10.8.8.0 and 10.8.8.255.</li> </ul> <p>By default, no value is defined (i.e., any source IP address is accepted).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to Server-type IP Groups.</li> <li>■ If the IP address is unknown (i.e., configured for the associated Proxy Set as an FQDN), it is recommended to classify incoming dialogs based on Proxy Set (instead of using a Classification rule). For more information on classification by Proxy Set or by Classification rule, see the note bulletin in the beginning of this section.</li> </ul>
'Source Transport Type' src-transport-type [SrcTransportType]	<p>Defines the source transport type as a matching characteristic for the incoming SIP dialog.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Any</b> = (Default) All transport types</li> <li>■ [0] <b>UDP</b></li> <li>■ [1] <b>TCP</b></li> <li>■ [2] <b>TLS</b></li> <li>■ [3] <b>SCTP</b></li> </ul>
'Source Port' src-port [SrcPort]	<p>Defines the source port number as a matching characteristic for the incoming SIP dialog.</p> <p>By default, no value is defined.</p>
'Source Username Pattern' src-user-name-	<p>Defines the source URI user part as a matching characteristic for the incoming SIP dialog. The URI is</p>

Parameter	Description
<p>pattern</p> <p>[SrcUsernamePrefix]</p>	<p>typically located in the SIP From header. However, you can configure the SIP header from where the device obtains the source URI, in the IP Groups table ('Source URI Input' parameter). For more information on how the device obtains the URI, see <a href="#">Call Processing of SIP Dialog Requests</a> on page 1023.</p> <p>You can use special patterns (notations) to denote the user part. For example, if you want to match this rule to user parts whose last four digits (i.e., suffix) are 4 followed by any three digits (e.g., 4008), then configure this parameter to "(4xxx)", without the quotation marks. For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The valid value is a string of up to 60 characters. The default is the asterisk (*) symbol, meaning any source user part.</p> <p><b>Note:</b> For REGISTER requests, the source URI is obtained from the To header.</p>
<p>'Source Host'</p> <p>src-host</p> <p>[SrcHost]</p>	<p>Defines the prefix of the source URI host name as a matching characteristic for the incoming SIP dialog.</p> <p>The URI is typically located in the SIP From header. However, you can configure the SIP header from where the device obtains the source URI, in the IP Groups table ('Source URI Input' parameter). For more information on how the device obtains this URI, see <a href="#">Call Processing of SIP Dialog Requests</a> on page 1023.</p> <p>The default is the asterisk (*) symbol, which represents any source host prefix.</p> <p><b>Note:</b> For REGISTER requests, the source URI is obtained from the To header.</p>
<p>'Destination Username Pattern'</p> <p>dst-user-name-pattern</p> <p>[DestUsernamePrefix]</p>	<p>Defines the destination Request-URI user part as a matching characteristic for the incoming SIP dialog.</p> <p>You can use special patterns (notations) to denote the user part. For example, if you want to match this rule to user parts whose last four digits (i.e., suffix) are 4 followed by any three digits (e.g., 4008), then configure this parameter to "(4xxx)", without the quotation marks. For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The valid value is a string of up to 60 characters. The</p>

Parameter	Description
	default is the asterisk (*) symbol, meaning any destination user part.
'Destination Host' dst-host [DestHost]	<p>Defines the prefix of the destination Request-URI host name as a matching characteristic for the incoming SIP dialog.</p> <p>The default is the asterisk (*) symbol, which represents any destination host prefix.</p>
'Message Condition' message-condition-name [MessageConditionName]	<p>Assigns a Message Condition rule to the Classification rule as a matching characteristic for the incoming SIP dialog.</p> <p>By default, no value is defined.</p> <p>To configure Message Condition rules, see <a href="#">Configuring Message Condition Rules</a> on page 838.</p>
'TLS Remote Subject Name' tls-remote-subject-name [TLSRemoteSubjectName]	<p>Defines the Subject Name of the TLS certificate used for the TLS connection upon which the SIP dialog message is received, as a matching characteristic for the incoming SIP dialog.</p> <p>If there is no match and the SAN is marked as "critical", classification to the specific rule fails. If there is no match but the Subject Alternative Name (SAN) isn't marked as "critical", the device checks if the configured value matches the certificate's Common Name (CN).</p> <p>By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For classification of incoming SIP dialogs by TLS certificate Subject Name, make sure that you also do the following: <ul style="list-style-type: none"> <li>✓ Enable TLS mutual authentication globally using the 'TLS Mutual Authentication' parameter [SIPSRequireClientCertificate], or per SIP Interface using the 'TLS Mutual Authentication' parameter.</li> <li>✓ Configure the Proxy Set's 'Peer Host Name Verification Mode' parameter to <b>Disable</b> (prevents TLS connections closing before the Classification stage).</li> </ul> </li> <li>■ If you are classifying incoming SIP dialogs by Proxy Set (configured by the 'Classify By Proxy Set' parameter in the IP Groups table), classification by certificate Subject Name isn't supported and therefore, this parameter</li> </ul>

Parameter	Description
	<p>isn't applicable. For classification by Proxy Set, enable the Proxy Set's 'Peer Host Name Verification Mode' parameter (see <a href="#">Configuring Proxy Sets</a> on page 622).</p> <ul style="list-style-type: none"> <li>■ A certificate may include multiple SAN types (e.g., Email, DNS, URI, and IP). The only SAN types that the device compares for matching are DNS and IP.</li> </ul>
Action	
'Action Type' action-type [ActionType]	<p>Defines a whitelist or blacklist for the matched incoming SIP dialog.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Deny</b> = Blocks incoming SIP dialogs that match the characteristics of the rule (blacklist).</li> <li>■ [1] <b>Allow</b> = (Default) Allows incoming SIP dialogs that match the characteristics of the rule (whitelist) and assigns it to the associated IP Group.</li> </ul>
'Destination Routing Policy' dest-routing-policy [DestRoutingPolicy]	<p>Assigns a Routing Policy to the matched incoming SIP dialog.</p> <p>The assigned Routing Policy overrides the Routing Policy assigned to the SRD (in the SRDs table). The option to assign Routing Policies to Classification rules is useful in deployments requiring different routing and manipulation rules for specific calls pertaining to the <b>same</b> SRD. In such scenarios, you need to configure multiple Classification rules for the same SRD, where for some rules no Routing Policy is assigned (i.e., the SRD's assigned Routing Policy is used) while for others a different Routing Policy is specified to override the SRD's assigned Routing Policy.</p> <p>By default, no value is defined.</p> <p>To configure Routing Policies, see <a href="#">Configuring SBC Routing Policies</a> on page 1108.</p>
'IP Group Selection' ip-group-selection [IPGroupSelection]	<p>Defines how the incoming SIP dialog is classified to an IP Group.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Source IP Group</b> = (Default) The SIP dialog is classified to the IP Group that is specified in the 'Source IP Group' parameter (see below).</li> <li>■ [1] <b>Tagged IP Group</b> = The SIP dialog is classified to an IP Group based on source tag, which is specified in the 'IP Group Tag Name' parameter (see below). For more</li> </ul>

Parameter	Description
	information on Classification of incoming SIP dialogs to IP Groups using tags, see <a href="#">Configuring Classification Based on Tags</a> on page 1073.
'Source IP Group' src-ip-group-name [SrcIPGroupName]	<p>Assigns an IP Group to the matched incoming SIP dialog. By default, no value is defined.</p> <p>To configure IP Groups, see <a href="#">Configuring IP Groups</a> on page 581.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if you configure the 'IP Group Selection' parameter to <b>Source IP Group</b>.</li> <li>■ The IP Group must be associated with the assigned SRD (see the 'SRD' parameter in the table).</li> </ul>
'IP Group Tag Name' ip-group-tag-name [IpGroupTagName]	<p>Defines the source tag of the incoming SIP dialog. The tag is used for classifying the SIP dialog to an IP Group. The tag is obtained from the Call Setup Rule that is associated with the SIP Interface on which the dialog is received.</p> <p>The valid value is a string of up to 70 characters. The default value is "default" (without quotation marks), which must be used when the resultant tag from the Call Setup Rule is only a value (e.g., "Ireland"). If the resultant tag is a name=value (e.g., "Country=Ireland"), then configure the parameter with the <b>name</b> only (e.g., "Country"). Only <b>one</b> tag name can be configured.</p> <p>For more information on Classification of incoming SIP dialogs to IP Groups using tags, see <a href="#">Configuring Classification Based on Tags</a> on page 1073.</p> <p><b>Note:</b> The parameter is applicable only if you configure the 'IP Group Selection' parameter to <b>Tagged IP Group</b>.</p>
'IP Profile' ip-profile-id [IpProfileName]	<p>Assigns an IP Profile to the matched incoming SIP dialog. The assigned IP Profile overrides the IP Profile assigned to the IP Group (in the IP Groups table) to which the SIP dialog is classified. Therefore, assigning an IP Profile during classification allows you to assign different IP Profiles to specific users (calls) that belong to the same IP Group (User or Server type).</p> <p>For example, you can configure two Classification rules to classify incoming calls to the same IP Group. However, one Classification rule is a regular rule that doesn't specify any</p>

Parameter	Description
	<p>IP Profile (IP Profile assigned to IP Group is used), while the second rule is configured with an additional matching characteristic for the source hostname prefix (e.g., "abcd.com") and with an additional action that assigns a different IP Profile.</p> <p>By default, no value is defined.</p> <p><b>Note:</b> For User-type IP Groups, if a user is already registered with the device (from a previous, initial classification process), the device classifies subsequent INVITE requests from the user according to the device's users database instead of the Classification table. In such a scenario, the same IP Profile that was previously assigned to the user by the Classification table is also used (in other words, the device's users database stores the associated IP Profile).</p>

### Classification Based on URI of Selected Header Example

The following example describes how to configure classification of incoming calls to IP Groups, based on source URI in a specific SIP header. The example assumes the following incoming INVITE message:

```
INVITE sip:8000@10.33.4.226 SIP/2.0
Via: SIP/2.0/UDP 10.33.4.226;branch=z9hG4bKVEBTDHAHSUYRTEXEDEGJY
From: <sip:100@10.33.4.226>;tag=YSQQKXXREVDPYPTNFMWG
To: <sip:8000@10.33.4.226>
Call-ID: FKPNOYRNKROIMEGBSSKS@10.33.4.226
CSeq: 1 INVITE
Contact: <sip:100@10.33.4.226>
Route: <sip:2000@10.10.10.10>,<sip:300@10.10.10.30>
Supported: em,100rel,timer,replaces
P-Caller-Party-ID: <sip:1111@10.33.38.1>
User-Agent: Sip Message Generator V1.0.0.5
Content-Length: 0
```

1. In the Classification table, add the following classification rules:

Index	Source Username Pattern	Destination Username Pattern	Destination Host	Source IP Group
0	333	-	-	1
1	1111	2000	10.10.10.10	2



2. In the IP Groups table, add the following IP Groups:

Index	Source URI Input	Destination URI Input
1	-	-
2	P-Called-Party-ID	Route

In the example, a match exists only for Classification Rule #1. This is because the source (1111) and destination (2000) username prefixes match those in the INVITE's P-Called-Party-ID header (i.e., "<sip:1111@10.33.38.1>") and Route header (i.e., "<sip:2000@10.10.10.10>"), respectively. These SIP headers were determined in IP Group 2.

## Configuring Classification Based on Tags

You can classify incoming SIP dialogs to IP Groups, using tags (source tags) that are obtained from Call Setup Rules associated with the SIP Interfaces on which dialogs are received. Using tags can significantly reduce the number of required Classification rules. In some scenarios, a single Classification rule may suffice.

Classification based on tags includes the following stages:

1. The device determines the tag of the incoming SIP dialog by running a Call Setup Rule that is associated with the SIP Interface on which the dialog is received. The Call Setup Rule on SIP Interfaces can be based on synchronous or asynchronous queries. For example, the Call Setup Rule can send an asynchronous query to an external HTTP server (AudioCodes ARM) for a source tag, which can then be used to classify the incoming SIP dialog to a source IP Group. Alternatively, you can configure the Call Setup Rule to generate a tag with a name and value (e.g., "Country=Ireland") or only a value (e.g., "Ireland").
2. The device searches the Classification table for a matching rule based on the SIP Interface (and optionally, any other existing matching properties) as well as the tag. The tag can be a name (e.g., "Country"), or "default" if the tag only has a value (e.g., "Ireland").
3. The device searches the IP Groups table for an IP Group that is configured with the tag from the Call Setup Rule (name=value or value only) and if found, classifies the dialog to that IP Group.



- Classification based on tags is done only if classification based on user registration and Proxy Set fail.
- The IP Group Set table is not used for classification (i.e., ignores tags).

The following procedure describes how to configure incoming SIP dialog classification based on tags. The procedure is based on an example that uses Dial Plan tags to classify calls to three different IP Groups:

- Calls with source number (user) 410 are classified to IP Group-1
- Calls with source number (user) 420 are classified to IP Group-2

- Calls with source number (user) 430 are classified to IP Group-3

➤ **To configure Classification based on tags:**

1. Open the Dial Plan table (see [Configuring Dial Plans](#) on page 798), and then configure Dial Plan tags. In our example, the following Dial Plan rules are configured for Dial Plan "ITSP":

Name	Prefix	Tag
Rule1	410	Country=Ireland
Rule2	420	Country=Scotland
Rule3	430	Country=England

2. Open the Call Setup Rules table (see [Configuring Call Setup Rules](#) on page 782), and then configure Call Setup Rules for obtaining source tags of incoming SIP dialogs. In our example, the following Call Setup Rule is configured:

General	
'Rules Set ID'	1
'Request Type'	Dial Plan
'Request Target'	ITSP
'Request Key'	Param.Call.Src.User
'Condition '	DialPlan.Found exists
Action	
'Action Subject'	SrcTags
'Action Type'	Modify
'Action Value'	DialPlan.Result

3. Open the SIP Interfaces table (see [Configuring SIP Interfaces](#) on page 561), and then configure a SIP Interface with the 'Call Setup Rules Set ID' parameter set to the 'Rules Set ID' value of your Call Setup Rules. In our example, the SIP Interface is named "SIPIfx-Tags" and the parameter is configured to 1.
4. Open the Classification table, and then configure a rule with the following:

Match	
'Source SIP	SIPIfx-Tags (or select Any)

Match	
Interface'	
Action	
'IP Group Selection'	<b>Tagged IP Group</b>
'IP Group Tag Name'	<b>Country</b> <b>Note:</b> Enter the tag's name only. If the tag only has a value, then enter "default" (without quotation marks).

5. Open the IP Groups table (see [Configuring IP Groups](#) on page 581), and then configure IP Groups with the 'Tags' parameter set to the appropriate tag. If the source tag has a name and value, then configure the parameter as name=value (e.g., "Country=Ireland"). If it only has a value, then configure it with the value. In our example, the following IP Groups are configured:

Name	Tags
IPGroup-1	Country=Ireland
IPGroup-2	Country=Scotland
IPGroup-3	Country=England

## Configuring Action for Classification Failure

If the device doesn't find a matching rule in the Classification table for the incoming SIP dialog-initiating request (i.e., classification fails), you can configure the device to reject or allow the call.

### ➤ To configure action for unclassified calls:

1. Open the SBC General Settings (**Setup** menu > **Signaling & Media** tab > **SBC** folder > **SBC General Settings**).
2. From the 'Unclassified Calls' drop-down list, select one of the following:
  - **Reject:** The device rejects the call.
  - **Allow:** The device accepts the call and classifies it to an IP Group as follows:
    - i. The device determines the SIP listening port (e.g., 5061) on which the incoming SIP dialog request was received and then determines the SIP Interface that is configured with this same port (in the SIP Interfaces table).

- ii. The device determines the SRD associated with the SIP Interface, and then classifies the SIP dialog to the first IP Group in the IP Groups table that is associated with this specific SRD. For example, if IP Groups #3 and #4 belong to the same SRD, the device classifies the call to IP Group #3.

Unclassified Calls

Reject

3. Click **Apply**.

## Configuring SBC IP-to-IP Routing Rules

The IP-to-IP Routing table lets you configure up to 615 SBC IP-to-IP routing rules.

Configuration of IP-to-IP routing rules includes two areas:

- **Match:** Defines the characteristics of the incoming SIP dialog message (e.g., IP Group from which the message is received).
- **Action:** Defines the action that is done if the incoming call matches the characteristics of the rule (i.e., routes the call to the specified destination).

The device searches the table from **top to bottom** for the **first** rule that matches the characteristics of the incoming call. If it finds a matching rule, it sends the call to the destination configured for that rule. If it doesn't find a matching rule, it rejects the call.




Configure stricter rules higher up in the table than less strict rules to ensure the desired rule is used to route the call. *Strict* refers to the number of matching characteristics configured for the rule. For example, a rule configured with source host name and source IP Group as matching characteristics is stricter than a rule configured with only source host name. If the rule configured with only source host name appears higher up in the table, the device ("erroneously") uses the rule to route calls matching this source host name (even if they also match the rule appearing lower down in the table configured with the source IP Group as well).

The IP-to-IP Routing table lets you route incoming SIP dialog messages (e.g., INVITE) to any of the following IP destinations:

- According to registered user Contact listed in the device's registration database (only for User-type IP Groups).
- IP Group - the destination is the address configured for the Proxy Set associated with the IP Group.
- IP Group Set - the destination can be based on multiple IP Groups for load balancing, where each call may be sent to a different IP Group within the IP Group Set depending on the IP Group Set's definition.
- Routing tag - the device sends the call to an IP Group (or IP Group Set) based on a destination tag (determined by Dial Plans or Call Setup Rules).

- IP address in dotted-decimal notation or FQDN. Routing to a host name can be resolved using NAPTR/SRV/A-Record.
- Request-URI of incoming SIP dialog-initiating requests.
- Any registered user in the registration database. If the Request-URI of the incoming INVITE exists in the database, the call is sent to the corresponding contact address specified in the database.
- According to result of an ENUM query.
- Hunt Group - used for call survivability of call centers (see [Configuring Call Survivability for Call Centers](#) on page 1164).
- According to result of LDAP query (for more information on LDAP-based routing, see [LDAP-based Services](#) on page 369).
- ARM, which determines the destination (next hop) of the call (IP Group). The IP Group represents the next device in the routing path to the final destination. For more information on routing by ARM, see [Centralized Routing by ARM \(AudioCodes Routing Manager\)](#) on page 442.
- Tel destination (Gateway application). The rule redirects the call to the IP-to-Tel Routing table where the device searches for a matching IP-to-Tel routing rule. This feature can also be done for alternative routing. If an IP-to-IP routing rule fails and it is configured with a "Gateway" routing rule as an alternative route, the device uses the IP-to-Tel Routing table to send the call to the Tel. The device identifies (internally) calls re-directed for alternative Gateway routing, by appending a user-defined string to the prefix destination Request-URI user part (by default, "acgateway-<prefix destination>", for example, acgateway-200). The device removes this prefix before sending it to the Tel side. To configure this prefix string, use the [GWDirectRoutePrefix] parameter.
- Back to the sender of the incoming message, where the reply can be a SIP response code or a 3xx redirection response (with an optional Contact field to where the sender must re-send the message).

The following figure summarizes the destination types:



To configure and apply an IP-to-IP Routing rule, the rule must be associated with a Routing Policy. The Routing Policy associates the routing rule with an SRD(s). Therefore, the Routing Policy lets you configure routing rules for calls belonging to specific SRD(s). However, as multiple Routing Policies are relevant only for multi-tenant deployments (if needed), for most deployments, only a single Routing Policy is required. As the device provides a default Routing Policy ("Default\_SBCRoutingPolicy"), when only one Routing Policy is required, the device automatically assigns the default Routing Policy to the routing rule. If you are implementing LDAP-based routing (with or without Call Setup Rules) and/or Least Cost Routing (LCR), you need to configure these settings for the Routing Policy (regardless of the number of Routing Policies employed). For more information on Routing Policies, see [Configuring SBC Routing Policies](#) on page 1108.

The IP-to-IP Routing table also provides the following features:

■ **Alternative Routing:** In addition to the alternative routing/load balancing provided by the Proxy Set associated with the destination IP Group, the table allows the configuration of alternative routes where if a route fails, the next adjacent (below) rule in the table that is configured to **Alt Route Ignore/Consider Inputs** are used. The alternative routing rules can be set to enforce the input matching criteria or to ignore any matching criteria. Alternative routing occurs upon one of the following conditions:

- A request sent by the device is responded with one of the following:
  - ◆ SIP response code (e.g., 4xx, 5xx, and 6xx) that is also configured for an Alternative Reasons Set (see [Configuring SIP Response Codes for Alternative Routing Reasons](#))

on page 1104) assigned to the IP Group ('SBC Alternative Routing Reasons Set' parameter).

- ◆ SIP 408 Timeout or no response (after timeout).
- The DNS resolution includes IP addresses that the device has yet to try (for the current call).

Messages are re-routed with the same SIP Call-ID and CSeq header fields (increased by 1).



If the Proxy Set (see [Configuring Proxy Sets](#) on page 622) associated with the destination of the call is configured with multiple IP addresses, the device first attempts to route the call to one of these IP addresses, starting with the first listed address. Only when the call cannot be routed to any of the Proxy Set's IP addresses does the device search the IP-to-IP Routing table for an alternative routing rule for the call.

- **Load Balancing:** You can implement load balancing of calls, belonging to the same source, between a set of destination IP Groups known as an *IP Group Set*. The IP Group Set can include up to five IP Groups (Server-type and/or Gateway-type only) and the chosen IP Group depends on the configured load-balancing policy (e.g., Round Robin). To configure the feature, you need to first configure an IP Group Set (see [Configuring IP Group Sets](#) on page 1113), and then assign it to a routing rule with 'Destination Type' configured to **IP Group Set**.
- **Re-routing SIP Requests:** This table enables you to configure "re-routing" rules of requests (e.g., INVITEs) that the device sends upon receipt of SIP 3xx responses or REFER messages. These rules are configured for destinations that do not support receipt of 3xx or REFER and where the device handles the requests locally (instead of forwarding the 3xx or REFER to the destination).
- **Least Cost Routing (LCR):** If the LCR feature is enabled, the device searches the routing table for matching routing rules and then selects the one with the lowest call cost. The call cost of the routing rule is done by assigning it a Cost Group. To configure Cost Groups, see [Least Cost Routing](#) on page 452. If two routing rules have identical costs, then the rule appearing higher up in the table (i.e., first-matched rule) is used. If a selected route is unavailable, the device uses the next least-cost routing rule. However, even if a matched rule is not assigned a Cost Group, the device can select it as the preferred route over other matched routing rules that are assigned Cost Groups, according to the default LCR settings configured for the assigned Routing Policy (see [Configuring SBC Routing Policies](#) on page 1108).
- **Call Forking:** The IP-to-IP Routing table can be configured to route an incoming IP call to multiple destinations (call forking). The incoming call can be routed to multiple destinations of any type such as an IP Group or IP address. The device forks the call by sending simultaneous INVITE messages to all the specified destinations. It handles the multiple SIP dialogs until one of the calls is answered and then terminates the other SIP dialogs.

Call forking is configured by creating a Forking group. A Forking group consists of a main routing rule ('Alternative Route Options' set to **Route Row**) whose 'Group Policy' is set to

**Forking**, and one or more associated routing rules ('Alternative Route Options' set to **Group Member Ignore Inputs** or **Group Member Consider Inputs**). The group members must be configured in contiguous table rows to the main routing rule. If an incoming call matches the input characteristics of the main routing rule, the device routes the call to its destination and all those of the group members.

An alternative routing rule can also be configured for the Forking group. The alternative route is used if the call fails for the Forking group (i.e., main route and all its group members). The alternative routing rule must be configured in the table row immediately below the last member of the Forking group. The 'Alternative Route Options' of this alternative route must be set to **Alt Route Ignore Inputs** or **Alt Route Consider Inputs**. The alternative route can also be configured with its own forking group members, where if the device uses the alternative route, the call is also sent to its group members. In this case, instead of setting the alternative route's 'Group Policy' to **None**, you must set it to **Forking**. The group members of the alternative route must be configured in the rows immediately below it.

The LCR feature can also be employed with call forking. The device calculates a maximum call cost for each Forking group and routes the call to the Forking group with the lowest cost. Thus, even if the call can successfully be routed to the main routing rule, a different routing rule can be chosen (even an alternative route, if configured) based on LCR. If routing to one Forking group fails, the device tries to route the call to the Forking group with the next lowest cost (main or alternative route), and so on. The prerequisite for this functionality is that the incoming call must successfully match the input characteristics of the main routing rule.

- **Tags Representing Source / Destination Numbers:** If your deployment includes calls of many different called (source URI user part) and/or calling (destination URI user part) numbers that need to be routed to the same destination, you can employ user-defined tags to represent these numbers. Therefore, instead of configuring many routing rules, you can configure only one routing rule using the tag(s) as the source or destination number matching characteristics, and a destination for the calls. Tags can be obtained using Dial Plans (see [Using Dial Plan Tags for Matching Routing Rules](#) on page 814) or Call Setup Rules ([Configuring Call Setup Rules](#) on page 782).
- **Destination Tags for Determining Destination IP Group:** Instead of configuring multiple routing rules, you can configure a single routing rule with a destination tag. The tag can be determined using Dial Plans or Call Setup Rules. The device uses the tag to search the IP Groups table for a destination IP Group that matches the tag ('Tags' parameter). For more information on tag-based routing, see [Using Destination Tags for Choosing Routing Destinations](#) on page 815.
- **Fax Rerouting:** You can configure the device to reroute incoming calls that it identifies as fax calls to a new IP destination. For more information, see [Configuring Rerouting of Calls to Fax Destinations](#) on page 1096.



Call forking is not applicable to LDAP-based routing.



The following procedure describes how to configure IP-to-IP routing rules through the Web interface. You can also configure it through ini file [IP2IPRouting] or CLI (`configure voip > sbc routing ip2ip-routing`).

➤ **To configure an IP-to-IP routing rule:**

1. Open the IP-to-IP Routing table (**Setup** menu > **Signaling & Media** tab > **SBC** folder > **Routing** > **IP-to-IP Routing**).
2. Click **New**; the following dialog box appears:

3. From the 'Routing Policy' drop-down list, select a Routing Policy (configured in [Configuring SBC Routing Policies](#) on page 1108).
4. Configure an IP-to-IP routing rule according to the parameters described in the table below.
5. Click **Apply**.

**Table 33-2: IP-to-IP Routing Table Parameter Descriptions**

Parameter	Description
'Routing Policy' sbc- routing- policy-name [RoutingPolicyName]	<p>Assigns a Routing Policy to the rule. The Routing Policy associates the rule with an SRD(s). The Routing Policy also defines default LCR settings as well as the LDAP servers used if the routing rule is based on LDAP routing (and Call Setup Rules).</p> <p>If only one Routing Policy is configured in the Routing Policies table, the Routing Policy is automatically assigned. If multiple Routing Policies are configured, no value is assigned.</p> <p>To configure Routing Policies, see <a href="#">Configuring SBC Routing Policies</a> on page 1108.</p> <p><b>Note:</b> The parameter is mandatory.</p>
<b>General</b>	
'Index' [Index]	<p>Defines an index number for the new table row.</p> <p><b>Note:</b> Each row must be configured with a unique index.</p>
'Name'	Defines a descriptive name, which is used when associating the row in

Parameter	Description
route-name [RouteName]	<p>other tables.</p> <p>The valid value is a string of up to 40 characters. By default, no value is defined.</p> <p><b>Note:</b> The parameter value can't be configured with the character string "any" (upper or lower case).</p>
'Alternative Route Options' alt-route-options [AltRouteOptions]	<p>Determines whether this routing rule is the main routing rule or an alternative routing rule (to the rule defined directly above it in the table).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Route Row</b> = (Default) Main routing rule - the device first attempts to route the call to this route if the incoming SIP dialog's input characteristics matches this rule.</li> <li>■ [1] <b>Alternative Route Ignore Inputs</b> = If the call cannot be routed to the main route (Route Row), the call is routed to this alternative route regardless of the incoming SIP dialog's input characteristics.</li> <li>■ [2] <b>Alternative Route Consider Inputs</b> = If the call cannot be routed to the main route (Route Row), the call is routed to this alternative route only if the incoming SIP dialog matches this routing rule's input characteristics.</li> <li>■ [3] <b>Group Member Ignore Inputs</b> = This routing rule is a member of the Forking routing rule. The incoming call is also forked to the destination of this routing rule. The matching input characteristics of the routing rule are ignored.</li> <li>■ [4] <b>Group Member Consider Inputs</b> = This routing rule is a member of the Forking routing rule. The incoming call is also forked to the destination of this routing rule only if the incoming call matches this rule's input characteristics.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The alternative routing entry ([1] or [2]) must be defined in the next consecutive table entry index to the Route Row entry (i.e., directly below it). For example, if Index 4 is configured as a Route Row, Index 5 must be configured as the alternative route.</li> <li>■ The Forking Group members must be configured in a table row that is immediately below the main Forking routing rule, or below an alternative routing rule for the main rule, if configured.</li> <li>■ For IP-to-IP alternative routing, configure alternative routing based on the receipt of specific SIP responses (see <a href="#">Configuring SIP Response Codes for Alternative Routing Reasons</a> on page 1104). However, if no response, ICMP, or a SIP 408 response is received,</li> </ul>

Parameter	Description
	<p>the device attempts to use the alternative route even if you haven't configured any SIP responses for alternative routing.</p> <ul style="list-style-type: none"> <li>Multiple alternative route entries can be configured (e.g., Index 1 is the main route - Route Row - and indices 2 through 4 are configured as alternative routes).</li> </ul>
Match	
'Source IP Group' src-ip-group-name [SrcIPGroupName]	<p>Defines the IP Group from where the IP call is received (i.e., the IP Group that sent the SIP dialog). Typically, the IP Group of an incoming SIP dialog is determined (or classified) using the Classification table (see <a href="#">Configuring Classification Rules</a> on page 1061).</p> <p>The default is <b>Any</b> (i.e., any IP Group).</p> <p><b>Note:</b> The selectable IP Group for the parameter depends on the assigned Routing Policy (in the 'Routing Policy' parameter in this table). For more information, see <a href="#">Configuring SBC Routing Policies</a> on page 1108.</p>
'Request Type' request-type [RequestType]	<p>Defines the SIP dialog request type (SIP Method) of the incoming SIP dialog.</p> <ul style="list-style-type: none"> <li>[0] <b>ALL</b> (default)</li> <li>[1] <b>INVITE</b></li> <li>[2] <b>REGISTER</b></li> <li>[3] <b>SUBSCRIBE</b></li> <li>[4] <b>INVITE and REGISTER</b></li> <li>[5] <b>INVITE and SUBSCRIBE</b></li> <li>[6] <b>OPTIONS</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>For User-type IP Groups, if you also need to send REGISTER messages received from this IP Group, then it's recommended that the configured destination of the routing rule is a Server-type IP Group and <b>not</b> an IP address (configured by the 'Destination Type' parameter). If you need to send non-REGISTER messages (e.g., INVITE) to a destination that is configured as an IP address, then you need to configure two IP-to-IP Routing rules for this User-type IP Group -- one for routing REGISTER messages and one for routing non-REGISTER messages.</li> <li>If the device receives a REFER message, it searches again for a</li> </ul>

Parameter	Description
	matching routing rule in the IP-to-IP Routing table and then forwards the message to the destination configured of the matched rule.
'Source Username Pattern' src-user-name-pattern [SrcUsernamePrefix]	<p>Defines the user part of the incoming SIP dialog's source URI (usually the From URI).</p> <p>You can use special patterns (notations) to denote the user part. For example, if you want to match this rule to user parts whose last four digits (i.e., suffix) are 4 followed by any three digits (e.g., 4008), then configure this parameter to "(4xxx)". To denote calls without a user part in the URI, use the dollar (\$) sign. For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The valid value is a string of up to 60 characters. The default is the asterisk (*) symbol (i.e., any user part).</p> <p>If this rule is not required, leave this field empty.</p> <p><b>Note:</b> If you need to route calls of many different source URI user names to the same destination, you can use tags (see 'Source Tags' parameter below) instead of this parameter.</p>
'Source Host' src-host [SrcHost]	<p>Defines the host part of the incoming SIP dialog's source URI (usually the From URI).</p> <p>The default is the asterisk (*) symbol (i.e., any host name). If this rule is not required, leave this field empty.</p>
'Source Tags' src-tags [SrcTags]	<p>Defines a source tag(s) for matching this routing rule.</p> <p>The source tag can be obtained using a Dial Plan (assigned to the source IP Group or SRD) or Call Setup Rules (assigned to the source IP Group or SIP Interface).</p> <p>The valid value is:</p> <ul style="list-style-type: none"> <li>■ A string of up to 70 characters.</li> <li>■ Up to eight tags, where each tag is separated by a semicolon (;).</li> <li>■ Up to seven tags containing a name with a value (e.g., Country=Ireland). If you are configuring multiple tags in the name=value format, the names of each tag must be unique (e.g., <b>Country</b>=Ireland;<b>Land</b>=Scotland).</li> <li>■ Only <b>one</b> tag containing a value only (e.g., USA).</li> </ul> <p>By default, no value is defined.</p> <p>The following example configures the maximum number of tags (i.e., seven name=value tags and one value-only tag):</p> <p>Country=Ireland;Country2=Scotland;Country3=RSA;Country4=Canada;</p>

Parameter	Description
	<p>Country5=UK;Country6=France;Country7=Germany;USA.</p> <p>To configure Dial Plans, see <a href="#">Configuring Dial Plans</a> on page 798. To configure tags using Call Setup Rules (i.e., using the SrcTags attribute), see <a href="#">Configuring Call Setup Rules</a> on page 782.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The tag is case insensitive.</li> <li>■ Instead of using tags and configuring the parameter, you can use the 'Source Username Pattern' parameter to configure a specific URI source user part (or all source users).</li> </ul>
'Destination Username Pattern' dst-user-name-pattern [DestUsernamePrefix]	<p>Defines the incoming SIP dialog's destination URI (usually the Request URI) user part.</p> <p>You can use special patterns (notations) to denote the user part. For example, if you want to match this rule to user parts whose last four digits (i.e., suffix) are 4 followed by any three digits (e.g., 4008), then configure this parameter to "(4xxx)". To denote calls without a user part in the URI, use the dollar (\$) sign. For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The valid value is a string of up to 60 characters. The default is the asterisk (*) symbol (i.e., any user part). If this rule is not required, leave this field empty.</p> <p><b>Note:</b> If you need to route calls of many different destination URI user names to the same destination, you can use tags (see 'Source Tags' parameter below) instead of this parameter.</p>
'Destination Host' dst-host [DestHost]	<p>Defines the host part of the incoming SIP dialog's destination URI (usually the Request-URI).</p> <p>The default is the asterisk (*) symbol (i.e., any destination host). If this rule is not required, leave this field empty.</p>
'Destination Tags' dest-tags [DestTags]	<p>Defines a destination tag(s) for matching this routing rule.</p> <p>The destination tag can be obtained using a Dial Plan (assigned to the source IP Group or SRD) or Call Setup Rules (assigned to the source IP Group or SIP Interface).</p> <p>The valid value is:</p> <ul style="list-style-type: none"> <li>■ A string of up to 70 characters.</li> <li>■ Up to eight tags, where each tag is separated by a semicolon (;).</li> <li>■ Up to seven tags containing a name with a value (e.g., Country=Ireland). If you are configuring multiple tags in the name=value format, the names of each tag must be unique (e.g.,</li> </ul>

Parameter	Description
	<p><b>Country=Ireland;Land=Scotland).</b></p> <ul style="list-style-type: none"> <li>Only <b>one</b> tag containing a value only (e.g., USA).</li> </ul> <p>By default, no value is defined.</p> <p>The following example configures the maximum number of tags (i.e., seven name=value tags and one value-only tag):</p> <p>Country=Ireland;Country2=Scotland;Country3=RSA;Country4=Canada;Country5=UK;Country6=France;Country7=Germany;USA.</p> <p>To configure Dial Plans, see <a href="#">Configuring Dial Plans</a> on page 798. To configure tags using Call Setup Rules (i.e., using the DstTags attribute), see <a href="#">Configuring Call Setup Rules</a> on page 782.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The tag is case insensitive.</li> <li>Instead of using tags and configuring the parameter, you can use the 'Destination Username Pattern' parameter to configure a specific URI destination user (or all destinations users).</li> </ul>
'Message Condition' message-condition-name [MessageConditionName]	<p>Assigns a SIP Message Condition rule to the IP-to-IP Routing rule.</p> <p>To configure Message Condition rules, see <a href="#">Configuring Message Condition Rules</a> on page 838.</p>
'Call Trigger' trigger [Trigger]	<p>Defines the reason (i.e., trigger) for re-routing (i.e., alternative routing) the SIP request.</p> <ul style="list-style-type: none"> <li>[0] <b>Any</b> = (Default) This routing rule is used for all scenarios (re-routes and non-re-routes).</li> <li>[1] <b>3xx</b> = Re-routes the request if it was triggered as a result of a SIP 3xx response.</li> <li>[2] <b>REFER</b> = Re-routes the INVITE if it was triggered as a result of a REFER request.</li> <li>[3] <b>3xx or REFER</b> = Applies to optional values <b>3xx</b> and <b>REFER</b>.</li> <li>[4] <b>Initial only</b> = This routing rule is used for regular requests that the device forwards to the destination. This rule is not used for re-routing of requests triggered by the receipt of REFER or 3xx.</li> <li>[5] <b>Broken Connection</b> = If the device detects a broken RTP or</li> </ul>

Parameter	Description
	<p>MSRP connection (no packets received for a user-defined timeout) during the call and the Broken RTP/MSRP Connection feature is enabled (IP Profile parameter 'Broken Connection Mode' configured to <b>Reroute</b> or <b>Reroute with Original SIP Headers</b>), you can use this option as an explicit matching characteristics to route the call to an alternative destination. Therefore, for alternative routing upon broken RTP or MSRP detection, position the routing rule configured with this option above the regular routing rule associated with the call. Such configuration ensures that the device uses this alternative routing rule only when RTP or MSRP broken connection is detected.</p> <ul style="list-style-type: none"> <li>■ <b>[6] Fax Rerouting</b> = Reroutes the INVITE to a fax destination (different IP Group) if it is identified as a fax call. For more information, see <a href="#">Configuring Rerouting of Calls to Fax Destinations</a> on page 1096.</li> </ul>
'ReRoute IP Group' re-route-ip-group-id  [ReRouteIPGroup Name]	<p>Defines the IP Group that initiated (sent) the SIP redirect response (e.g., 3xx) or REFER message. This parameter is typically used for rerouting requests (e.g., INVITEs) when interworking is required for SIP 3xx redirect responses or REFER messages. For more information, see <a href="#">Interworking SIP 3xx Redirect Responses</a> on page 1041 and <a href="#">Interworking SIP REFER Messages</a> on page 1045, respectively. The parameter functions together with the 'Call Trigger' parameter (in the table).</p> <p>The default is <b>Any</b> (i.e., any IP Group).</p> <p><b>Note:</b> The selectable IP Group for the parameter depends on the assigned Routing Policy (in the 'Routing Policy' parameter in this table). For more information, see <a href="#">Configuring SBC Routing Policies</a> on page 1108.</p>
Action	
'Destination Type' dst-type [DestType]	<p>Defines the type of destination to where the device sends the outgoing SIP dialog.</p> <ul style="list-style-type: none"> <li>■ <b>[0] IP Group</b> = (Default) The device sends the SIP dialog to the IP Group as configured in the 'Destination IP Group' parameter. For more information on the actual address, see the 'Destination IP Group' parameter.</li> <li>■ <b>[1] Dest Address</b> = The device sends the SIP dialog to the address that is configured by the following parameters: 'Destination Address', 'Destination Port', and 'Destination Transport Type'.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [2] <b>Request URI</b> = The device sends the SIP dialog to the address indicated in the incoming SIP Request-URI. If you have configured the 'Destination Port' and 'Destination Transport Type' parameters, the device overrides the parameters of the incoming Request-URI and these parameters take precedence.</li> <li>■ [3] <b>ENUM</b> = The device sends an ENUM query to include the destination address. If you have configured the 'Destination Port' and 'Destination Transport Type' parameters, the device overrides the parameters of the incoming Request-URI and these parameters take precedence.</li> <li>■ [4] <b>Hunt Group</b> = This option is used for call center survivability (see <a href="#">Configuring Call Survivability for Call Centers</a> on page 1164).</li> <li>■ [5] <b>Dial Plan</b> = (<b>For Backward Compatibility Only - see Note below</b>) The IP destination is determined by a Dial Plan index of the loaded Dial Plan file. The syntax of the Dial Plan index in the Dial Plan file is as follows: &lt;destination / called prefix number&gt;,0,&lt;IP destination&gt;  Note that the second parameter "0" is ignored. An example of a configured Dial Plan (# 6) in the Dial Plan file is shown below:   <div style="background-color: #f0f0f0; padding: 10px; border-radius: 5px;"> <pre>[ PLAN6 ] 200,0,10.33.8.52    ; called prefix 200 is routed to destination 10.33.8.52 201,0,10.33.8.52 300,0,itsp.com     ; called prefix 300 is routed to destination itsp.com</pre> </div> <p>Once the Dial Plan is defined, you need to assign it (0 to 7) to the routing rule as the destination in the 'Destination Address' parameter, where "0" denotes [PLAN1], "1" denotes [PLAN2], and so on.</p> </li> <li>■ [7] <b>LDAP</b> = This option does LDAP-based routing. Make sure that the Routing Policy assigned to the routing rule is configured with the LDAP Server Group for defining the LDAP server(s) to query.</li> <li>■ [8] <b>Gateway</b> = The device sends the SBC call to the Tel side (Gateway call) using an IP-to-Tel routing rule in the IP-to-Tel Routing table (see <a href="#">Configuring IP-to-Tel Routing Rules</a> on page 928). The IP-to-Tel routing rule must be configured with the same call matching characteristics as this SBC IP-to-IP routing rule. This option is also used for alternative routing of an IP-to-IP route</li> </ul>



Parameter	Description
	<p>to the PSTN. In such a case, the IP-to-Tel routing rule must also be configured with the same call matching characteristics as this SBC IP-to-IP routing rule.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>✓ If you configure the parameter to <b>Gateway</b> for a rule that is used for alternative routing (i.e., 'Alternative Route Options' parameter is configured to any value other than <b>Route Row</b>), the device uses two DSP session resources. One session resource is for the new Gateway route and one for the initial SBC session used for the incoming leg.</li> <li>✓ When the device uses this rule that is configured to <b>Gateway</b> and the 'Alternative Route Options' parameter is configured to <b>Route Row</b>, it ignores all other matching rules listed below this rule in the IP-to-IP Routing table.</li> </ul> <ul style="list-style-type: none"> <li>■ [9] <b>Routing Server</b> = The device sends a request to ARM for an appropriate destination (next hop) for the matching call. For more information on routing by ARM, see <a href="#">Centralized Routing by ARM (AudioCodes Routing Manager)</a> on page 442.</li> <li>■ [10] <b>All Users</b> = The device checks if the SIP Request-URI (i.e., destination user) in the incoming INVITE is registered in its' users database. If registered, the device sends the INVITE to the address of the corresponding contact that is specified in the database. If the Request-URI is not registered, the call is rejected.</li> </ul> <p>If the incoming SIP dialog is a REGISTER message, the device acts as a registrar and only responds to the sender of the request (200 OK) without sending the REGISTER message to a destination (i.e., termination of REGISTER messages).</p> <ul style="list-style-type: none"> <li>■ [11] <b>IP Group Set</b> = The device employs load balancing and sends the call to an IP Group in the IP Group Set that you assigned using the 'IP Group Set' parameter (below).</li> <li>■ [12] <b>Destination Tag</b> = The device sends the call to an IP Group that is matched by destination tag. For more information on tag-based routing, see <a href="#">Using Destination Tags for Choosing Routing Destinations</a> on page 815.</li> </ul> <p><b>Note:</b> For tag-based routing, you also need to configure the 'Routing Tag Name' parameter (below).</p> <ul style="list-style-type: none"> <li>■ [13] <b>Internal</b> = Instead of sending the incoming SIP dialog to another destination, the device replies to the sender of the dialog</li> </ul>

Parameter	Description
	<p>with a SIP response code or a redirection response, configured by the 'Internal Action' parameter below.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Use the <b>Dial Plan</b> option only for backward compatibility purposes; otherwise, use prefix tags as described in <a href="#">Configuring Dial Plans</a> on page 798.</li> <li>■ If you configure the parameter to <b>Dest Address, Request URI, ENUM, Dial Plan</b> or <b>LDAP</b>, you must specify a destination IP Group using the 'Destination IP Group' parameter, even though these calls are <b>not</b> sent to the specified IP Group (i.e., its associated Proxy Set). This allows you to associate other configuration entities (such as an IP Profile) that are assigned to the IP Group, with the destination of these calls. If you do not specify a destination IP Group, the device uses its own logic in choosing a destination IP Group (and thus its associated configuration entities) for the routing rule.</li> <li>■ You can configure up to 20 IP-to-IP Routing rules whose 'Destination Type' is <b>Internal</b>.</li> </ul>
'Destination IP Group' dst-ip-group-name [DestIPGroupName]	<p>Defines the IP Group to where you want to route the call. The actual destination of the SIP dialog message depends on the IP Group type (as defined in the 'Type' parameter):</p> <ul style="list-style-type: none"> <li>■ Server-type IP Group: The SIP dialog is sent to the IP address configured for the Proxy Set that is associated with the IP Group.</li> <li>■ User-type IP Group: The device checks if the SIP dialog is from a registered user, by searching for a match between the Request-URI of the received SIP dialog and an AOR registration record in the device's database. If found, the device sends the SIP dialog to the IP address specified in the database for the registered contact.</li> </ul> <p>By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if the 'Destination Type' parameter is configured to <b>IP Group</b>. However, you also need to specify this parameter if the 'Destination Type' parameter is configured to <b>Dest Address, Request URI, ENUM, Dial Plan</b> or <b>LDAP</b> (even though these calls are <b>not</b> sent to the specified IP Group). For these cases, it allows you to associate other configuration entities (such as an IP Profile) that are assigned to the IP Group, with the destination of these calls.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>The selectable IP Group for the parameter depends on the assigned Routing Policy (in the 'Routing Policy' parameter in this table). For more information, see <a href="#">Configuring SBC Routing Policies</a> on page 1108.</li> </ul>
'Destination SIP Interface' <code>dest-sip-interface-name</code> [DestSIPInterfaceName]	<p>Defines the destination SIP Interface to where the call is sent. By default, no value is defined.</p> <p>To configure SIP Interfaces, see <a href="#">Configuring SIP Interfaces</a> on page 561.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The parameter is applicable <b>only</b> if the 'Destination Type' parameter is configured to any value other than <b>IP Group</b>. If the 'Destination Type' parameter is configured to <b>IP Group</b>, the following SIP Interface is used:               <ul style="list-style-type: none"> <li>✓ Server-type IP Groups: SIP Interface that is assigned to the Proxy Set associated with the IP Group.</li> <li>✓ User-type IP Groups: SIP Interface is determined during user registration with the device.</li> </ul> </li> <li>For multi-tenancy, if the assigned Routing Policy is not shared (i.e., the Routing Policy is associated with an Isolated SRD), the SIP Interface must be one that is associated with the Routing Policy or with a shared Routing Policy (i.e., the Routing Policy is associated with one or more Shared SRDs). If the Routing Policy is shared, the SIP Interface can be one that is associated with any SRD or Routing Policy (but it's recommended that it belong to the same SRD/Routing Policy or to shared SRD/Routing Policy to avoid "bleeding").</li> </ul>
'Destination Address' <code>dst-address</code> [DestAddress]	<p>Defines the destination address to where the call is sent.</p> <p>The valid value is an IP address in dotted-decimal notation or an FQDN (domain name, e.g., domain.com).</p> <p>If ENUM-based routing is used (i.e., the 'Destination Type' parameter is set to <b>ENUM</b>) the parameter configures the address of the ENUM service, for example, e164.arpa, e164.customer.net or NRENum.net. The device sends the ENUM query containing the destination phone number to an external DNS server, configured in the IP Interfaces table. The ENUM reply includes a SIP URI (user@host) which is used as the destination Request-URI in this routing table.</p> <p>The valid value is a string of up to 50 characters (IP address or FQDN). By default, no value is defined.</p> <p><b>Note:</b></p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ The parameter is applicable only if the 'Destination Type' parameter is configured to <b>Dest Address</b> [1] or <b>ENUM</b> [3]; otherwise, the parameter is ignored.</li> <li>■ When using domain names, enter the DNS server's IP address or alternatively, define these names in the Internal DNS table (see <a href="#">Configuring the Internal SRV Table</a> on page 199).</li> <li>■ To terminate SIP OPTIONS messages at the device (i.e., to handle them locally), set the parameter to "internal".</li> </ul>
'Destination Port' dst-port [DestPort]	Defines the destination port to where the call is sent.
'Destination Transport Type' dst-transport-type [DestTransportType]	<p>Defines the transport layer type for sending the call.</p> <ul style="list-style-type: none"> <li>■ [-1] = (Default) Not configured. The transport type is determined by the [SIPTransportType] global parameter.</li> <li>■ [0] <b>UDP</b></li> <li>■ [1] <b>TCP</b></li> <li>■ [2] <b>TLS</b></li> <li>■ [3] <b>SCTP</b></li> </ul>
'IP Group Set' ipgroupset-name [IPGroupSetName]	<p>Assigns an IP Group Set to the routing rule. The device routes the call to one of the IP Groups in the IP Group Set according to the load-balancing policy configured for the IP Group Set. For more information, see <a href="#">Configuring IP Group Sets</a> on page 1113.</p> <p><b>Note:</b> The parameter is applicable only if you configure the 'Destination Type' parameter to <b>IP Group Set</b> (above).</p>
'Pre Route Call Setup Rules Set ID' pre-route-call-setup-rules-set-id [PreRouteCallSetupRulesSetId]	<p>Assigns a Call Setup Rule Set ID to the routing rule. The device runs this Call Setup Rules Set if the incoming call matches the characteristics of this routing rule. The device routes the call to the destination according to the routing rule's configured action, only after it has run the Call Setup rules.</p> <p>To configure Call Setup rules, see <a href="#">Configuring Call Setup Rules</a> on page 782.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you have assigned a Call Setup Rules Set using both the 'Pre Route Call Setup Rules Set ID' and 'Call Setup Rules Set ID'</li> </ul>

Parameter	Description
	<p>parameters, the device first runs the Call Setup Rules Set of the 'Pre Route Call Setup Rules Set ID' parameter.</p> <ul style="list-style-type: none"> <li>■ For tag-based routing during the routing stage (IP-to-IP Routing table): <ul style="list-style-type: none"> <li>✓ Assign the Call Setup Rules Set that determines the tag name, using the 'Pre Route Call Setup Rules Set ID' parameter (not 'Call Setup Rules Set ID' parameter). This tag <b>overrides</b> tags of any previously run Call Setup Rules Sets (of SIP Interfaces, source IP Groups, or Dial Plans).</li> <li>✓ Configure the 'Destination Type' parameter to <b>Destination Tag</b> (see above).</li> <li>✓ Configure the tag name in the 'Routing Tag Name' parameter (see below).</li> <li>✓ The device uses the resultant tag name to find a matching destination IP Group (i.e., in 'Tags' parameter) in the IP Groups table.</li> <li>✓ For alternative routing, you can assign a different Call Setup Rules Set to each alternative routing rule so that they each use a different destination tag and therefore, a different destination IP Group.</li> <li>✓ For more information on tag-based routing, see <a href="#">Using Destination Tags for Choosing Routing Destinations</a> on page 815.</li> </ul> </li> </ul>
<p>'Call Setup Rules Set ID'</p> <p><code>call-setup-rules-set-id</code></p> <p>[CallSetupRulesSetId]</p>	<p>Assigns a Call Setup Rule Set ID to the routing rule. The device runs the Call Setup rules of this Set ID if the incoming call matches the characteristics of this routing rule. The device routes the call to the destination according to the routing rule's configured action, only after it has run the Call Setup rules.</p> <p>To configure Call Setup rules, see <a href="#">Configuring Call Setup Rules</a> on page 782.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you have assigned a Call Setup Rules Set using both the 'Pre Route Call Setup Rules Set ID' and 'Call Setup Rules Set ID' parameters, the device first runs the Call Setup Rules Set of the 'Pre Route Call Setup Rules Set ID' parameter.</li> <li>■ If you want to use Call Setup Rules to determine the destination tag, assign the Call Setup Rule Set using the 'Pre Route Call Setup Rules Set ID' parameter (instead of 'Call Setup Rules Set ID').</li> </ul>

Parameter	Description
'Group Policy' group-policy [GroupPolicy]	<p>Defines if the routing rule includes call forking.</p> <ul style="list-style-type: none"> <li>■ [0] <b>None</b> = (Default) Call uses only this route (even if Forking Group members are configured in the rows below it).</li> <li>■ [1] <b>Forking</b> = Call uses this route and the routes of Forking Group members, if configured (in the rows below it).</li> </ul> <p><b>Note:</b> Each Forking Group can contain up to 20 members. In other words, up to 20 routing rules can be configured for the same Forking Group.</p>
'Cost Group' cost-group [CostGroup]	<p>Assigns a Cost Group to the routing rule for determining the cost of the call.</p> <p>By default, no value is defined.</p> <p>To configure Cost Groups, see <a href="#">Configuring Cost Groups</a> on page 455.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ To implement LCR and its Cost Groups, you must enable LCR for the Routing Policy assigned to the routing rule (see <a href="#">Configuring SBC Routing Policies</a> on page 1108). If LCR is disabled, the device ignores the parameter.</li> <li>■ The Routing Policy also determines whether matched routing rules that are <b>not</b> assigned Cost Groups are considered as a higher or lower cost route compared to matching routing rules that are assigned Cost Groups. For example, if the 'Default Call Cost' parameter in the Routing Policy is configured to <b>Lowest Cost</b>, even if the device locates matching routing rules that are assigned Cost Groups, the first-matched routing rule without an assigned Cost Group is considered as the lowest cost route and thus, chosen as the preferred route.</li> </ul>
'Routing Tag Name' routing-tag-name [RoutingTagName]	<p>Defines the destination tag name, which is used to determine the destination IP Group. The device searches the IP Groups table for an IP Group whose 'Tags' parameter value matches this tag name (and value).</p> <p>The valid value:</p> <ul style="list-style-type: none"> <li>■ A string of up to 70 characters.</li> <li>■ Only <b>one</b> tag can be configured.</li> <li>■ Only the tag <b>name</b> (not value, if exists) can be configured. For example, if the tag in the Dial Plan rule is "Country=England", configure the parameter to "Country".</li> <li>■ The tag is case insensitive.</li> </ul>

Parameter	Description
	<p>The default value is "default", meaning that the device uses the first tag name that is configured without a value. For example, if the Dial Plan rule is configured with tags "Country=England;City=London;Essex", the default tag is "Essex".</p> <p>An example of configuring this parameter when Call Setup Rules (assigned to the 'Pre Route Call Setup Rules Set ID' parameter above) are used to obtain the tag name: If you configure the parameter to "IPGroupName" (i.e., tag name) and the Call Setup Rule's 'Action Subject' parameter is "DstTags.IPGroupName" which results in the value "Teams" (i.e., tag value), the device searches the IP Groups table for a destination IP Group whose 'Tags' parameter is configured to "ipGroupName=Teams".</p> <p>For more information on tag-based routing, see <a href="#">Using Destination Tags for Choosing Routing Destinations</a> on page 815.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if the 'Destination Type' parameter is configured to <b>Destination Tag</b> (see above).</li> <li>■ If you're using a Call Setup Rule to determine the tag during the device's routing stage, assign the Call Setup Rules Set to the 'Pre Route Call Setup Rules Set ID' parameter (see above).</li> </ul>
'Internal Action' internal-action [InternalAction]	<p>Defines a SIP response code (e.g., 200 OK) or a redirection response (with an optional Contact field indicating to where the sender must re-send the message) that the device sends to the sender of the incoming SIP dialog (instead of sending the call to another destination). The parameter is applicable only when the 'Destination Type' parameter in this table is configured to <b>Internal</b> (see above).</p> <p>The valid value syntax (case-insensitive) is:</p> <ul style="list-style-type: none"> <li>■ For SIP response codes: <pre>reply(response='&lt;code&gt;')</pre> <p>The following example sends a SIP 200:</p> <pre>reply(response='200')</pre> </li> <li>■ For redirection responses: <pre>redirect(response='&lt;code&gt;',contact='sip:'+....)</pre> </li> </ul>

Parameter	Description
	<div>redirect(contact='...',response='&lt;code&gt;')</div> <div>redirect(contact='sip:user@host')</div> <p>Examples:</p> <ul style="list-style-type: none"> <li>✓ The device responds to the dialog with a SIP 300 redirect response that includes a contact value:</li> </ul> <div>redirect(response='300',contact='sip:102@host')</div> <ul style="list-style-type: none"> <li>✓ The device redirects the call from the sender to a SIP Recording Server (SRS):</li> </ul> <div>           redirect            (response='302',contact='sip:'+header.to.url.user+'@siprecording.com')         </div> <p>You can use the built-in syntax editor to help you configure the field. Click the <b>Editor</b> button located alongside the field to open the Editor, and then simply follow the on-screen instructions.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter can be used for normal and alternative routing.</li> <li>■ The response code for redirect messages can only be 3xx.</li> </ul>
'Modified Destination User Name' modified-dest-user-name [ModifiedDestUserName]	<p>Defines the user part of the Request-URI in the outgoing SIP dialog message.</p> <p>The valid value is a string of up to 60 characters. By default, no value is defined.</p> <p><b>Note:</b> The parameter is currently used only when the device communicates with VoiceAI Connect.</p>

## Configuring Rerouting of Calls to Fax Destinations

You can configure the device to reroute incoming SBC calls identified as fax calls to a new IP destination. The device identifies a fax call if it detects, within a user-defined interval, a calling (CNG) tone on the originator side (incoming IP leg). If the device detects a fax call, it terminates the call and reroutes it using a new INVITE to the new fax destination (new IP Group). If the



initial INVITE that was used to establish the voice call was already sent, the device sends a CANCEL (if not connected yet) or a BYE (if already connected) to release the call (with the internal disconnect reason RELEASE\_BECAUSE\_FAX\_REROUTING, translated to Q.850 reason GWAPP\_NORMAL\_UNSPECIFIED 31).



- You must configure the originating fax to use the G.711 coder.
- If the remote side replies with T.38 or G.711 VBD, fax rerouting is not done.
- If both fax rerouting and fax re-INVITE are configured, only fax rerouting is done.

The following provides a basic example on how to configure fax rerouting.

➤ **To configure fax rerouting:**

1. Open the Fax/Modem/CID Settings page (**Setup** menu > **Signaling & Media** tab > **Media** folder > **Fax/Modem/CID Settings**).
  - a. In the 'Fax Detection Timeout' field [SBCFaxDetectionTimeout], enter the duration (in seconds) for which the device attempts to detect fax (CNG tone):

Fax Detection Timeout [sec]

10

- b. From the 'CNG Detector Mode' drop-down list [CNGDetectorMode], select **Event Only**.
2. Upload an ini file to the device through the Auxiliary Files page (see [Uploading Auxiliary Files through Web Interface](#) on page 1221) with the following parameter setting, which enables in-band network detection related to fax:

EnableFaxModemInbandNetworkDetection = 1

3. In the IP Groups table (see [Configuring IP Groups](#) on page 581), configure the following IP Groups:
  - IP Group #0 "HQ": This is the source IP Group, sending voice calls and fax calls.
  - IP Group #1 "Voice": This is the destination for voice calls sent from IP Group #0.
  - IP Group #2 "Fax": This is the destination for fax calls sent from IP Group #0.
4. For the fax destination (IP Group #2), do the following:
  - a. In the Coders Groups table (see [Configuring Coders Groups](#) on page 651), configure a Coder Group with T.38 to enable fax transmission over IP.
  - b. In the IP Profiles table (see [Configuring IP Profiles](#) on page 664), configure an IP Profile:
    - i. From the 'Fax Coders Group' drop-down list, select the Coder Group that you configured above.
    - ii. From the 'Fax Mode' drop-down list, select **Handle always**.

- c. In the IP Groups table, edit IP Group #2, and then from the 'IP Profile' drop-down list, select the IP Profile that you configured above.
- 5. For the voice destination (IP Group #1), do the following:
  - a. In the IP Profiles table, configure an IP Profile - from the 'Fax Rerouting Mode' drop-down list, select **Rerouting without delay**:

Fax Rerouting Mode      • Rerouting without delay ▼

- b. In the IP Groups table, edit IP Group #1, and then from the 'IP Profile' drop-down list, select the IP Profile that you configured above.
- 6. In the IP-to-IP Routing table (see [Configuring SBC IP-to-IP Routing Rules](#) on page 1076), configure the following adjacent rows of IP-to-IP Routing rules:
  - IP-to-IP Routing Rule #0 to route voice calls from IP Group #0 to IP Group #1:

Match	
Source IP Group	HQ (IP Group #0)
Call Trigger	Initial Only
ReRoute IP Group	Voice (IP Group #1)
Action	
Destination Type	IP Group
Destination IP Group	Voice (IP Group #1)


- IP-to-IP Routing Rule #1 to route fax calls from IP Group #0 to IP Group #2:

Match	
Source IP Group	HQ (IP Group #0)
Call Trigger	Fax Rerouting
Action	
Destination Type	IP Group
Destination IP Group	Fax (IP Group #2)

## Configuring Specific UDP Ports using Tag-based Routing

You can configure the device to use a specific local UDP port for each SIP entity (e.g., PBX) communicating with a common proxy server (e.g., ITSP). The figure below illustrates an

example scenario of such an implementation, whereby the device uses a specific local UDP port (e.g., 6001, 6002, and 6003) for each IP PBX, on the leg interfacing with the proxy server:



For each IP PBX, the device sends SIP messages to the proxy server using the specific local, UDP port on the leg interfacing with the proxy server. For SIP messages received from the proxy server, the device routes the messages to the appropriate IP PBX according to the local UDP port on which the message was received. On the leg interfacing with the IP PBXs, the device uses the same local UDP port (e.g., 5060) for all IP PBXs (send and receive).

To configure this feature, you need to configure the SIP Interface of the proxy server with a special UDP port range, and use tag-based routing with Call Setup Rules to specify the exact UDP port you want assigned to each SIP entity (IP PBX), from the SIP Interface port range. The following procedure describes how to configure the device to use a specific local UDP port per SIP entity on the leg interfacing with a proxy server that is common to all the SIP entities. To facilitate understanding, the procedure is based on the previous example.

➤ **To configure specific UDP ports for SIP entities communicating with common proxy server:**

1. Open the SIP Interfaces table (see [Configuring SIP Interfaces](#) on page 561), and then configure the following SIP Interfaces:
  - SIP Interface for leg interfacing with IP PBXs (local UDP port 5060 is used):

General	
Index	<b>1</b>
Name	<b>PBX</b>
Network Interface	<b>WAN</b>
UDP Port	<b>5060</b>

- SIP Interface for leg interfacing with proxy server (specific local UDP ports are later taken from this port range):

General	
Index	<b>2</b>
Name	<b>ITSP</b>
Network Interface	<b>LAN</b>
UDP Port	<b>5060</b>
Additional UDP Ports	<b>6000-7000</b>



For guidelines on configuring the 'Additional UDP Ports' parameter, see [Configuring SIP Interfaces](#) on page 561.

- Open the IP Groups table (see [Configuring IP Groups](#) on page 581), and then configure the following IP Groups:
  - IP Group for the first IP PBX ("Type" and "Port" tags are later used to identify the IP PBX and assign it a local UDP port 6001 on the leg interfacing with the proxy server):

General	
Index	<b>1</b>
Name	<b>PBX-1</b>
Type	<b>Server</b>
SBC Advanced	
Call Setup Rules Set ID	<b>1</b>
Tags	<b>Type=PBX;Port=6001</b>

- IP Group for the second IP PBX ("Type" and "Port" tags are later used to identify the IP PBX and assign it a local UDP port 6002 on the leg interfacing with the proxy server):

General	
Index	<b>2</b>
Name	<b>PBX-2</b>
Type	<b>Server</b>
SBC Advanced	

General	
Call Setup Rules Set ID	<b>1</b>
Tags	<b>Type=PBX;Port=6002</b>

- IP Group for the third IP PBX ("Type" and "Port" tags are later used to identify the IP PBX and assign it a local UDP port 6003 on the leg interfacing with the proxy server):

General	
Index	<b>3</b>
Name	<b>PBX-3</b>
Type	<b>Server</b>
SBC Advanced	
Call Setup Rules Set ID	<b>1</b>
Tags	<b>Type=PBX;Port=6003</b>

- IP Group for the proxy server ("Type" tag is later used to identify proxy server):

General	
Index	<b>4</b>
Name	<b>ITSP</b>
Type	<b>Server</b>
SBC Advanced	
Call Setup Rules Set ID	<b>1</b>
Tags	<b>Type=ITSP</b>

3. Open the Call Setup Rules table (see [Configuring Call Setup Rules](#) on page 782), and then configure the following Call Setup rules:
  - Uses the value of the "Type" tag name, configured in the IP Group's 'Tags' parameter, as the source tag:

General	
Index	<b>1</b>

General	
Rule Set ID	<b>1</b>
<b>Action</b>	
Action Subject	<b>srctags.Type</b>
Action Type	<b>Modify</b>
Action Value	<b>param.ipg.src.tags.Type</b>

- If the source tag name "Type" equals "PBX" (i.e., SIP message from an IP Group belonging to one of the IP PBXs), then use the value of the "Port" tag name, configured in the 'Tags' parameter of the classified IP Group, as the local UDP port on the leg interfacing with the proxy server for messages sent to the proxy server:

General	
Index	<b>2</b>
Rule Set ID	<b>1</b>
Condition	<b>srctags.Type=='PBX'</b>
<b>Action</b>	
Action Subject	<b>message.outgoing.local-port</b>
Action Type	<b>Modify</b>
Action Value	<b>param.ipg.src.tags.Port</b>

- If the source tag name "Type" equals "ITSP" (i.e., SIP message from the ITSP), then use the value (port number) of the local port on which the incoming message from the proxy server is received by the device, as the value of the destination tag name "Port". In other words, the value could either be "6001", "6002", or "6003". This value is then used by the IP-to-IP Routing table to determine to which IP PBX to send the message. For example, if the destination tag value is "6001", the device identifies the destination as "PBX-1":

General	
Index	<b>3</b>
Rule Set ID	<b>1</b>

General	
Condition	<b>srctags.Type=='ITSP'</b>
<b>Action</b>	
Action Subject	<b>dsttags.Port</b>
Action Type	<b>Modify</b>
Action Value	<b>message.incoming.local-port</b>

4. Open the IP-to-IP Routing table (see [Configuring SBC IP-to-IP Routing Rules](#) on page 1076), and then configure the following IP-to-IP Routing rules:
- Routes calls from the IP PBXs (identified by the source tag name-value "Type=PBX") to the ITSP (identified as an IP Group):

General	
Index	<b>1</b>
Name	<b>PBX-to-ITSP</b>
<b>Match</b>	
Source Tag	<b>Type=PBX</b>
<b>Action</b>	
Destination Type	<b>IP Group</b>
Destination IP Group	<b>ITSP</b>

- Routes calls from the ITSP (identified by the source tag name-value "Type=ITSP") to the IP PBXs (identified by the specific port assigned to the IP PBX by the value of the destination tag name "Port"):

General	
Index	<b>2</b>
Name	<b>ITSP-to-PBX</b>
<b>Match</b>	
Source Tag	<b>Type=ITSP</b>
<b>Action</b>	

General	
Destination Type	Destination Tag
Routing Tag Name	Port

## Configuring a Routing Response Timeout

If you have routing rules in the IP-to-IP Routing table that need to query external servers (e.g., LDAP server, ENUM server, or HTTP GET method requests) on whose responses the device uses to determine where to route the SBC calls, you can configure a timeout for the responses. If the timeout expires before the device receives a response, the device sends a routing failure message (SIP 500) to the caller or uses an alternative routing rule (if configured).

### ➤ To configure a timeout for routing query responses:

1. Open the SBC General Settings page (**Setup** menu > **Signaling & Media** tab > **SBC** folder > **SBC General Settings**).
2. In the 'Routing Timeout' [SbcRoutingTimeout] field, enter the maximum duration (in seconds) that the device is prepared to wait for a response from external servers.

Routing Timeout [sec]

10

3. Click **Apply**.

## Configuring SIP Response Codes for Alternative Routing Reasons

The Alternative Reasons Set table lets you configure groups of SIP response codes for SBC call release (termination) reasons that trigger alternative routing. This feature works together with the Proxy Hot Swap feature, which is configured in the Proxy Sets table.

Alternative routing based on SIP responses is configured using two tables with "parent-child" relationship:

- **Alternative Reasons Set table ("parent"):** Defines the name of the Alternative Reasons Set. You can configure up to 10 Alternative Reasons Sets.
- **Alternative Reasons Rules table ("child"):** Defines SIP response codes per Alternative Reasons Set. You can configure up to 200 Alternative Reasons Rules in total, where each Alternative Reasons Set can include up to 20 Alternative Reasons Rules.

To apply your configured alternative routing reason rules, you need to assign the Alternative Reasons Set for which you configured the rules, to the relevant IP Group in the IP Groups table, using the 'SBC Alternative Routing Reasons Set' parameter.



In addition to configuring the response codes described in this section, you need to configure the following:

- A Proxy Set with one or more addresses (proxy servers) and whose 'Proxy Hot Swap Mode' parameter is configured to **Enable** (see [Configuring Proxy Sets](#) on page 622).
- An IP-to-IP Routing rule 1) whose 'Destination IP Group' parameter is a Server-type IP Group that is associated with the above Proxy Set (see [Configuring SBC IP-to-IP Routing Rules](#) on page 1076) and 2) that is assigned the relevant Alternative Reasons Set (using the 'SBC Alternative Routing Reasons Set' parameter).
- An alternative IP-to-IP Routing rule for the above rule.

Alternative routing based on SIP response codes functions as follows:

1. The device sends (outgoing) a SIP dialog-initiating message (e.g., INVITE, OPTIONS, and SUBSCRIBE) to one of the online proxy servers (addresses) configured for the Proxy Set that is associated with the destination IP Group of the matched IP-to-IP Routing rule.
2. If there is no response to the sent SIP message, or a "reject" (release) response is received (e.g., SIP 406) that is also configured for the Alternative Reasons Set assigned to the destination IP Group, the device tries to route the SIP message again (re-transmission) to the same proxy for a user-defined number of times, configured by the [HotSwapRtx] parameter. If still unsuccessful, the device tries to send the message to a different online proxy of the Proxy Set and if unsuccessful, it tries another online proxy, and so on (up to four online proxies are attempted). The order of attempted online proxies is according to the Proxy Set's configuration.

The following can then occur depending on received response codes or no responses:

- If any attempted proxy sends a response code that you have not configured for the assigned Alternative Reasons Set, the routing of the SIP message fails and the device **doesn't** make any further attempts to route the message.
- If the device has tried all the online proxies of the Proxy Set and no response has been received or responses have been received that you have also configured for the assigned Alternative Reasons Set, the device searches the IP-to-IP Routing table for a matching alternative routing rule and if found, sends the SIP message to the destination configured for that alternative routing rule (repeating steps 1 through 2 above, if needed).

You can also configure alternative routing for the following proprietary response codes (if configured in the table) that are issued by the device itself:

- **806 Media Limits Exceeded:** The device generates the response code when the call is terminated due to crossed user-defined thresholds of QoE metrics such as MOS, packet delay, and packet loss (see [Configuring Quality of Experience Profiles](#) on page 519) and/or media bandwidth (see [Configuring Bandwidth Profiles](#) on page 526). When this occurs, the device sends a SIP 480 (Temporarily Unavailable) response to the SIP entity (IP Group). This is configured by 1) assigning an IP Group a QoE and/or Bandwidth profile that rejects calls if

the threshold is crossed, 2) configuring 806 for an Alternative Reasons Set that is assigned to the IP Group and 3) configuring an alternative routing rule.

The device also generates the response code when it rejects a call based on Quality of Service rules due to crossed Voice Quality and Bandwidth thresholds (see [Configuring Quality of Service Rules](#) on page 531). If the response code is configured in the table and the device rejects a call due to threshold crossing, it searches in the IP-to-IP Routing table for an alternative routing rule.

- **850 Signalling Limits Exceeded:** The device generates the response code when it rejects a call based on Quality of Service rules due to crossed ASR, NER or ACD thresholds (see [Configuring Quality of Service Rules](#) on page 531). If the response code is configured for an Alternative Reasons Set that is assigned to the IP Group and the device rejects a call due to threshold crossing, it searches in the IP-to-IP Routing table for an alternative routing rule.




- This section is applicable only to the SBC application.
- The device issues itself the SIP response code 408 when no response is received from a sent SIP message.
- If the device receives a SIP 408 response, an ICMP message, or no response, it still does alternative routing even if you have not configured this code for an Alternative Reasons Set.
- SIP requests belonging to an SRD or IP Group that have reached the call limit (maximum concurrent calls and/or call rate), configured in the Call Admission Control Profile table are sent to an alternative route (if configured in the IP-to-IP Routing table for the SRD or IP Group). If no alternative routing rule is found, the device automatically rejects the SIP request with a SIP 480 (Temporarily Unavailable) response.
- If due to an INVITE message the device receives from the proxy a SIP 18x response (e.g., 180 or 183) followed by any failure response (e.g., 400 Not Found), the device doesn't do alternative routing, but instead terminates the call. This occurs even if the failure response is configured in the associated Alternative Reasons Set.

The following procedure describes how to configure Alternative Reasons sets through the Web interface. You can also configure it through other management platforms:

- Alternative Reasons Set table: ini file [SBCAltRoutingReasonsSet] or CLI (`configure voip > sbc routing alt-route-reasons-set`)
- Alternative Reasons Rules table: ini file [SBCAltRoutingReasonsList] or CLI (`configure voip > sbc routing alt-route-reasons-set < alt-route-reasons-rules`)

#### ➤ To configure SIP reason codes for alternative IP routing:

1. Open the Alternative Reasons Set table (**Setup** menu > **Signaling & Media** tab > **SBC** folder > **Routing** > **Alternative Reasons Set**).
2. Click **New**; the following dialog box appears:



Alternative Reasons Set

GENERAL

Index: 1

Name:


Description:

3. Configure an Alternative Reasons Set according to the parameters described in the table below.
4. Click **Apply**.

**Table 33-3: Alternative Reasons Set Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [Name]	Defines an arbitrary name to easily identify the row. The valid value is a string of up to 40 characters. <b>Note:</b> Configure each row with a unique name.
'Description' description [Description]	Defines a description for the Alternative Reasons Set. The valid value is a string of up to 99 characters. By default, no value is defined.

5. Select the index row of the Alternative Reasons Set that you added, and then click the **Alternative Reasons Rules** link located at the bottom of the page; the Alternative Reasons Rules table opens.
6. Click **New**; the following dialog box appears:



Alternative Reasons Rules

GENERAL

Index: 0

Release Cause Code: 408 Request Timeout

7. Configure Alternative Reasons rules according to the parameters described in the table below.

8. Click **Apply**.**Table 33-4: Alternative Reasons Rules Table Parameter Descriptions**

Parameter	Description
'Index' alt-route-reasons- rules [SBCAltRoutingReasonsList_ SBCAltRouteIndex]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Release Cause Code' rel-cause-code [SBCAltRoutingReasonsList_ ReleaseCauseCode]	Defines a SIP response code that triggers the device's alternative routing mechanism. [4] <b>4xx</b> ; [5] <b>5xx</b> ; [6] <b>6xx</b> ; [400] <b>400 Bad Request</b> ; [402] <b>402 Payment Required</b> ; [403] <b>403 Forbidden</b> ; [404] <b>404 Not Found</b> ; [405] <b>405 Method Not Allowed</b> ; [406] <b>406 Not Acceptable</b> ; [408] <b>408 Request Timeout</b> (Default); [409] <b>409 Conflict</b> ; [410] <b>410 Gone</b> ; [413] <b>413 Request Too Large</b> ; [414] <b>414 Request URI Too Long</b> ; [415] <b>415 Unsupported Media</b> ; [420] <b>420 Bad Extension</b> ; [421] <b>421 Extension Required</b> ; [423] <b>423 Session Interval Too Small</b> ; [480] <b>480 Unavailable</b> ; [481] <b>481 Transaction Not Exist</b> ; [482] <b>482 Loop Detected</b> ; [483] <b>483 Too Many Hops</b> ; [484] <b>484 Address Incomplete</b> ; [485] <b>485 Ambiguous</b> ; [486] <b>486 Busy</b> ; [487] <b>487 Request Terminated</b> ; [488] <b>488 Not Acceptable Here</b> ; [491] <b>491 Request Pending</b> ; [493] <b>493 Undecipherable</b> ; [500] <b>500 Internal Error</b> ; [501] <b>501 Not Implemented</b> ; [502] <b>502 Bad Gateway</b> ; [503] <b>503 Service Unavailable</b> ; [504] <b>504 Server Timeout</b> ; [505] <b>505 Version Not Supported</b> ; [513] <b>513 Message Too Large</b> ; [600] <b>600 Busy Everywhere</b> ; [603] <b>603 Decline</b> ; [604] <b>604 Does Not Exist Anywhere</b> ; [606] <b>606 Not Acceptable</b> ; [806] <b>806 Media Limits Exceeded</b> ; [850] <b>850 Signalling Limits Exceeded</b> .

## Configuring SBC Routing Policies

The Routing Policies table lets you configure up to 20 Routing Policy rules. A Routing Policy determines the routing and manipulation (inbound and outbound) rules per SRD in a multiple SRD configuration topology. The Routing Policy also configures the following:

- Enables Least Cost Routing (LCR), and configures default call cost (highest or lowest) and average call duration for routing rules that are not assigned LCR Cost Groups. The default call cost determines whether matched routing rules that are not assigned Cost Groups are considered as a higher or lower cost route compared to other matching routing rules that

are assigned Cost Groups. If you disable LCR, the device ignores the Cost Groups assigned to the routing rules in the IP-to-IP Routing table.

- Assigns LDAP servers (LDAP Server Group) for LDAP-based routing. IP-to-IP routing rules configured for LDAP or CSR (Call Setup Rules) queries use the LDAP server(s) that is assigned to the routing rule's associated Routing Policy. You can configure a Routing Policy per SRD or alternatively, configure a single Routing Policy that is shared between all SRDs.

The implementation of Routing Policies is intended for the following deployments **only**:


- Deployments requiring LCR and/or LDAP-based routing.
- Multi-tenant deployments that require multiple, logical routing tables where each tenant has its own dedicated ("separated") routing (and manipulation) table. In such scenarios, each SRD (tenant) is configured as an Isolated SRD and assigned its own unique Routing Policy, implementing an almost isolated, non-bleeding routing configuration topology.

For all other deployment scenarios, the Routing Policy is irrelevant and the handling of the configuration entity is not required as a default Routing Policy ("Default\_SBCRoutingPolicy" at Index 0) is provided. When only one Routing Policy is required, the device automatically associates the default Routing Policy with newly added configuration entities that can be associated with the Routing Policy (as mentioned later in this section, except for Classification rules). This facilitates configuration, eliminating the need to handle the Routing Policy configuration entity (except if you need to enable LCR and/or assign an LDAP server to the Routing Policy). In such a setup, where only one Routing Policy is used, single routing and manipulation tables are employed for all SRDs.



If possible, it is recommended to use only **one** Routing Policy for all SRDs (tenants), unless deployment requires otherwise (i.e., a dedicated Routing Policy per SRD).

Once configured, you need to associate the Routing Policy with an SRD(s) in the SRDs table. To determine the routing and manipulation rules for the SRD, you need to assign the Routing Policy to routing and manipulation rules. The figure below shows the configuration entities to which Routing Policies can be assigned:



Typically, assigning a Routing Policy to a Classification rule is not required, as when an incoming call is classified it uses the Routing Policy associated with the SRD to which it belongs. However, if a Routing Policy is assigned to a Classification rule, it overrides the Routing Policy assigned to the SRD. The option to assign Routing Policies to Classification rules is useful in deployments requiring different routing and manipulation rules for specific calls pertaining to the **same** SRD.

In such scenarios, you need to configure multiple Classification rules for the same SRD, where for some rules no Routing Policy is assigned (i.e., the SRD's assigned Routing Policy is used) while for others a different Routing Policy is specified to override the SRD's assigned Routing Policy.

In multi-tenant environments employing multiple SRDs and Routing Policies, the IP Groups that can be used in routing rules (in the IP-to-IP Routing table) are as follows:

- If the Routing Policy is assigned to only one SRD and the SRD is an Isolated SRD, the routing rules of the Routing Policy can be configured with IP Groups belonging to the Isolated SRD and IP Groups belonging to all Shared SRDs.
- If the Routing Policy is assigned to a Shared SRD, the routing rules of the Routing Policy can be configured with any IP Group (i.e., belonging to Shared and Isolated SRDs). In effect, the Routing Policy can include routing rules for call routing between Isolated SRDs.
- If the Routing Policy is assigned to multiple SRDs (Shared and/or Isolated), the routing rules of the Routing Policy can be configured with IP Groups belonging to all Shared SRDs as well as IP Groups belonging to Isolated SRDs that are assigned the Routing Policy.

To facilitate the configuration of routing rules in the IP-to-IP Routing table through the Web interface, only the permitted IP Groups (according to the above) are displayed as optional values.

The general flow for processing the call for multi-tenant deployments and Routing Policies is as follows:

1. Using the Classification table, the device classifies the incoming call to an IP Group, based on the SIP Interface on which the call is received. Based on the SIP Interface, the device associates the call to the SRD that is assigned to the SIP Interface.
2. Once the call has been successfully classified to an IP Group, the Routing Policy assigned to the associated SRD is used. However, if a Routing Policy is configured in the Classification table, it overrides the Routing Policy assigned to the SRD.
3. The regular manipulation (inbound and outbound) and routing processes are done according to the associated Routing Policy.



- The Classification table is used only if classification by registered user in the device's users registration database or by Proxy Set fails.
- If the device receives incoming calls (e.g., INVITE) from users that have already been classified and registered in the device's registration database, the device ignores the Classification table and uses the Routing Policy that was determined for the user during the initial classification process.

The following procedure describes how to configure Routing Policies rules through the Web interface. You can also configure it through ini file [SBCRoutingPolicy] or CLI (`configure voip > sbc routing sbc-routing-policy`).

➤ **To configure a Routing Policy rule:**

1. Open the Routing Policies table (**Setup** menu > **Signaling & Media** tab > **SBC** folder > **Routing** > **Routing Policies**).
2. Click **New**; the following dialog box appears:

**Routing Policies**

**GENERAL**

Index: 1

Name:

LDAP Servers Group Name: -- [View](#)

**LEAST COST ROUTING**

LCR Feature: Disable

Default Call Cost: Lowest Cost

LCR Call Duration [min]: 1

3. Configure the Routing Policy rule according to the parameters described in the table below.
4. Click **Apply**.

**Table 33-5: Routing Policies table Parameter Descriptions**

Parameter	Description
<b>General</b>	
'Index'	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [SBCRoutingPolicy_Name]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 40 characters. By default, no name is defined. If you don't configure a name, the device automatically assigns a name in the following format: "SBCRoutingPolicy_<Index>", for example, "SBCRoutingPolicy_2". <b>Note:</b> ■ Configure each row with a unique name.

Parameter	Description
	<ul style="list-style-type: none"> <li>■ The parameter value can't contain a forward slash (/).</li> <li>■ The parameter value can't be configured with the character string "any" (upper or lower case).</li> </ul>
'LDAP Servers Group Name' ldap-srv-group-name [SBCRoutingPolicy_ LdapServersGroupName]	<p>Assigns an LDAP Server Group to the Routing Policy. Routing rules in the IP-to-IP Routing table that are associated with the Routing Policy and that are configured with LDAP and/or Call Setup Rules, use the LDAP server(s) configured for this LDAP Server Group.</p> <p>By default, no value is defined.</p> <p>For more information on LDAP Server Groups, see <a href="#">Configuring LDAP Server Groups</a> on page 373.</p> <p><b>Note:</b> The default Routing Policy is assigned the default LDAP Server Group ("DefaultCTRLServersGroup").</p>
Least Cost Routing	
'LCR Feature' lcr-enable [SBCRoutingPolicy_ LCREnable]	<p>Enables the Least Cost Routing (LCR) feature for the Routing Policy.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p>For more information on LCR, see <a href="#">Least Cost Routing</a> on page 452.</p>
'Default Call Cost' lcr-default-cost [SBCRoutingPolicy_ LCRDefaultCost]	<p>Defines whether routing rules in the IP-to-IP Routing table that are not assigned a Cost Group are considered a higher cost or lower cost route compared to other matched routing rules that are assigned Cost Groups.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Lowest Cost</b> = (Default) The device considers a matched routing rule (belonging to the Routing Policy) that is not assigned a Cost Group as the lowest cost route. Therefore, it uses the routing rule.</li> <li>■ [1] <b>Highest Cost</b> = The device considers a matched routing rule (belonging to the Routing Policy) that is not assigned a Cost Group as the highest cost route. Therefore, it is only used if the other matched routing rules that are assigned Cost Groups are unavailable.</li> </ul> <p><b>Note:</b> If multiple matched routing rules without an assigned Cost Group exist, the device selects the first matched rule in the table.</p>



Parameter	Description
'LCR Call Duration' lcr-call-length [SBCRoutingPolicy_ LCRAverageCallLength]	<p>Defines the average call duration (in minutes) and is used to calculate the variable portion of the call cost. This is useful, for example, when the average call duration spans over multiple time bands. The LCR is calculated as follows: cost = call connect cost + (minute cost * average call duration). The valid value is 0-65533. The default is 1.</p> <p>For example, assume the following Cost Groups:</p> <ul style="list-style-type: none"> <li>■ "Weekend A": call connection cost is 1 and charge per minute is 6. Therefore, a call of 1 minute cost 7 units.</li> <li>■ "Weekend B": call connection cost is 6 and charge per minute is 1. Therefore, a call of 1 minute cost 7 units.</li> </ul> <p>Therefore, for calls under one minute, "Weekend A" carries the lower cost. However, if the average call duration is more than one minute, "Weekend B" carries the lower cost.</p>

## Configuring IP Group Sets

The IP Group Set table lets you configure up to 51 IP Group Sets. An IP Group Set is a group of IP Groups used for load balancing of calls, belonging to the same source, to a call destination (i.e., IP Group). Each IP Group Set can include up to five IP Groups (Server-type and Gateway-type only). The chosen destination IP Group for each call depends on the configured load-balancing policy, which can be Round Robin, Random Weights, or Homing (for more information, see the table's description, later in this section).



IP Group Sets are applicable only to the SBC application.

Alternative routing within the IP Group Set is also supported. If a chosen destination IP Group responds with a reject response that is configured for an Alternative Reasons Set (see [Configuring SIP Response Codes for Alternative Routing Reasons](#) on page 1104) that is assigned to the IP Group ('SBC Alternative Routing Reasons Set' parameter), or doesn't respond at all (i.e., keep-alive with its' associated Proxy Set fails), the device attempts to send the call to another IP Group in the IP Group Set (according to the load-balancing policy). For enabling Proxy Set keep-alive, see [Configuring Proxy Sets](#) on page 622.

An example of round-robin load-balancing and alternative routing: The first call is sent to IP Group #1 in the IP Group Set, the second call to IP Group #2, and the third call to IP Group #3. If the call sent to IP Group #1 is rejected, the device employs alternative routing and sends it to IP Group #4.

Once you have configured your IP Group Set, to implement call load-balancing by IP Groups, do one of the following:

- In the IP-to-IP Routing table, configure the routing rule's 'Destination Type' parameter to **IP Group Set**, and then assign it the IP Group Set in the 'IP Group Set' parameter.
- If you are routing to IP Groups based on Dial Plan tags:
  - In the IP Group Set table (see below), specify the tag name.
  - In the IP-to-IP Routing table, configure the routing rule's 'Destination Type' parameter to **Destination Tag**, and then specify the tag name in the 'Routing Tag Name' parameter.

For more information on IP-to-IP Routing rules, see [Configuring SBC IP-to-IP Routing Rules](#) on page 1076. For more information on routing based on destination Dial Plan tags, see [Using Destination Tags for Choosing Routing Destinations](#) on page 815.

IP Group Sets are configured using two tables with parent-child type relationship:

- **Parent table:** IP Group Set table, which defines the name and load-balancing policy of the IP Group Set.
- **Child table:** IP Group Set Member table, which assigns IP Groups to IP Group Sets. You can assign up to five IP Groups per IP Group Set.

The following procedure describes how to configure IP Group Sets through the Web interface. You can also configure it through other management platforms:

- **IP Group Set Table:** *ini* file [IPGroupSet] or CLI (`configure voip > sbc routing ip-group-set`)
- **IP Group Set Member Table:** *ini* file [IPGroupSetMember] or CLI (`configure voip > sbc routing ip-group-set-member`)

➤ **To configure an IP Group Set:**

1. Open the IP Group Set table (**Setup** menu > **Signaling & Media** tab > **SBC** folder > **Routing** > **IP Group Set**).
2. Click **New**; the following dialog box appears:

The screenshot shows a web-based configuration window titled "IP Group Set". It features a "GENERAL" tab. Below the tab, there are four configuration fields: "Index" (text input with "0"), "Name" (text input), "Policy" (dropdown menu with "Round-Robin" selected), and "Tags" (text input). The window has standard minimize and close buttons in the top right corner.

3. Configure the IP Group Set according to the parameters described in the table below.

4. Click **Apply**.**Table 33-6: IP Group Set Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [Name]	Defines a descriptive name, which is used when associating the row in other tables. <b>Note:</b> <ul style="list-style-type: none"> <li>■ Configure each row with a unique name.</li> <li>■ The parameter value cannot contain a forward slash (/).</li> </ul>
'Policy' policy [Policy]	Defines the load-balancing policy. <ul style="list-style-type: none"> <li>■ [0] <b>Round-Robin</b> = (Default) The device selects the next consecutive, available IP Group for each call. The device selects the first IP Group in the table (i.e., lowest index) for the first call and the next consecutive IP Groups for the next calls. For example, first call to IP Group at Index 0, second call to IP Group at Index 2, third call to IP Group at Index 3, and so on. If an IP Group is offline, the device selects the next consecutive IP Group. Once the last IP Group in the IP Group Set list is selected for a call, the device goes to the beginning of the list and sends the next call to the first IP Group, and so on.</li> <li>■ [1] <b>Random Weight</b> = The device selects IP Groups at random and their weights determine their probability of getting chosen over others. The higher the weight, the more chance of the IP Group being chosen.</li> <li>■ [2] <b>Homing</b> = The device always attempts to send all calls to the first IP Group in the table (i.e., lowest index). If unavailable, it sends the calls to the next consecutive, available IP Group. However, if the first IP Group comes online again, the device selects it.</li> </ul> <b>Note:</b> For the <b>Random Weight</b> optional value, use the 'Weight' parameter in the IP Group Set Member table (below) to configure weight value per IP Group.
'Tags' tags [Tags]	Assigns a Dial Plan tag that is used to determine whether the incoming SIP dialog is sent to IP Groups belonging to this IP Group Set. The parameter is used when IP-to-IP Routing rules are configured for destination based on tags (i.e., 'Destination Type' parameter configured to Destination Tag). For more information on routing based on destination tags, see <a href="#">Using Destination Tags for Choosing Routing Destinations</a> on page 815.

Parameter	Description
	<p>The valid value is a string of up to 70 characters. By default, no value is defined. You can configure the parameter with up to five tags, where each tag is separated by a semicolon (;). However, you can configure only up to four tags containing a name and value (e.g., Country=Ireland), and <b>one</b> tag containing a value only (e.g., Ireland). You can also configure multiple tags with the same name (e.g., Country=Ireland;Country=Scotland). The following example configures the maximum number of tags (i.e., four name=value tags and one value-only tag):</p> <p>Country=Ireland;Country=Scotland;Country=RSA;Country=Canada;USA.</p> <p><b>Note:</b> If the IP Groups belonging to the IP Group Set are also configured with Dial Plan tags, the Dial Plan tag configured for the parameter takes precedence. If the same Dial Plan tag is also configured for other IP Groups in the IP Groups table, the IP Group Set takes precedence and the device sends the SIP dialog to the IP Group(s) belonging to the IP Group Set.</p>

- Select the IP Group Set row for which you want to assign IP Groups, and then click the **IP Group Set Member** link located below the table; the IP Group Set Member table appears.
- Click **New**; the following dialog box appears:

- Configure IP Group Set members according to the parameters described in the table below.
- Click **Apply**, and then save your settings to flash memory.

**Table 33-7: IP Group Set Member Table Parameter Descriptions**

Parameter	Description
'Index' index [IPGroupSetMember_ IPGroupSetMemberIndex]	<p>Defines an index number for the new table row.</p> <p><b>Note:</b> Each row must be configured with a unique index.</p>

Parameter	Description
'IP Group' ip-group-name [IPGroupSetMember_ IPGroupName]	Assigns an IP Group to the IP Group Set. To configure IP Groups, see <a href="#">Configuring IP Groups</a> on page 581. <b>Note:</b> The IP Group can only be a Server-type or Gateway-type.
'Weight' weight [IPGroupSetMember_ Weight]	Defines the weight of the IP Group. The higher the weight, the more chance of the IP Group being selected as the destination of the call. The valid value is 1 to 9. The default is 1. <b>Note:</b> The parameter is applicable only if you configure the 'Policy' parameter to <b>Random Weight</b> .

## 34 SBC Manipulations


This section describes the configuration of the manipulation rules for the SBC application.



For additional manipulation features, see the following:

- [Configuring SIP Message Policy Rules](#) on page 840
- [Configuring SIP Message Manipulation](#) on page 829

The device supports SIP URI user part (source and destination) manipulations for inbound and outbound routing. These manipulations can be applied to a source IP group, source and destination host and user prefixes, and/or user-defined SIP request (e.g., INVITE, OPTIONS, SUBSCRIBE, and/or REGISTER). Since outbound manipulations are performed after routing, the outbound manipulation rule matching can also be done by destination IP Group. Manipulated destination user and host are performed on the following SIP headers: Request-URI, To, and Remote-Party-ID (if exists). Manipulated source user and host are performed on the following SIP headers: From, P-Asserted (if exists), P-Preferred (if exists), and Remote-Party-ID (if exists).



You can also restrict source user identity in outgoing SIP dialogs in the Outbound Manipulation table (using the column PrivacyRestrictionMode). The device identifies an incoming user as restricted if one of the following exists:

- From header user is 'anonymous'.
- P-Asserted-Identity and Privacy headers contain the value 'id'.

All restriction logic is done after the user number has been manipulated.

Host name (source and destination) manipulations are simply host name substitutions with the names defined for the source and destination IP Groups respectively (if any, in the IP Groups table).

Below is an example of a call flow and consequent SIP URI manipulations:

### ■ Incoming INVITE from LAN:

```
INVITE sip:1000@10.2.2.3;user=phone;x=y;z=a SIP/2.0
Via: SIP/2.0/UDP 10.2.2.6;branch=z9hGLLLLLan
```

```
From:<sip:7000@10.2.2.6;user=phone;x=y;z=a>;tag=OILAN;paramer1=abe
To: <sip:1000@10.2.2.3;user=phone>
Call-ID: USELLLAN@10.2.2.3
CSeq: 1 INVITE
Contact: <sip:7000@10.2.2.3>
Supported: em,100rel,timer,replaces
Allow: REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK
User-Agent: Sip Message Generator V1.0.0.5
Content-Type: application/sdp
Content-Length: 155
```

```
v=0
o=SMG 791285 795617 IN IP4 10.2.2.6
s=Phone-Call
c=IN IP4 10.2.2.6
t=0 0
m=audio 6000 RTP/AVP 8
a=rtpmap:8 pcma/8000
a=sendrecv
a=ptime:20
```

■ **Outgoing INVITE to WAN:**

```
INVITE sip: 9721000@ITSP;user=phone;x=y;z=a SIP/2.0
Via: SIP/2.0/UDP 212.179.1.12;branch=z9hGWWan
From: <sip:97000@IP_PBX;user=phone;x=y;z=a>;tag=OWan;paramer1=abe
To: <sip: 9721000@ ITSP;user=phone>
Call-ID: USEVWWAN@212.179.1.12
CSeq: 38 INVITE
Contact: <sip:7000@212.179.1.12>
Supported: em,100rel,timer,replaces
Allow:
REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER
User-Agent: Sip Message Generator V1.0.0.5
Content-Type: application/sdp
Content-Length: 155
```

```
v=0
o=SMG 5 9 IN IP4 212.179.1.11
s=Phone-Call
c=IN IP4 212.179.1.11
t=0 0
m=audio 8000 RTP/AVP 8
a=rtpmap:8 pcma/8000
```

```
a=sendrecv  
a=ptime:20
```

The SIP message manipulations in the example above (contributing to typical topology hiding) are as follows:

- Inbound source SIP URI user name from "7000" to "97000":

```
From:<sip:7000@10.2.2.6;user=phone;x=y;z=a>;tag=OILAN;paramer1=abe
```

to

```
From: <sip:97000@IP_PBX;user=phone;x=y;z=a>;tag=OWan;paramer1=abe
```

- Source IP Group name (i.e., SIP URI host name) from "10.2.2.6" to "IP\_PBX":

```
From:<sip:7000@10.2.2.6;user=phone;x=y;z=a>;tag=OILAN;paramer1=abe
```

to

```
From: <sip:97000@IP_PBX;user=phone;x=y;z=a>;tag=OWan;paramer1=abe
```

- Inbound destination SIP URI user name from "1000" to 9721000":

```
INVITE sip:1000@10.2.2.3;user=phone;x=y;z=a SIP/2.0  
To: <sip:1000@10.2.2.3;user=phone>
```

to

```
INVITE sip:9721000@ITSP;user=phone;x=y;z=a SIP/2.0  
To: <sip:9721000@ITSP;user=phone>
```

- Destination IP Group name (SIP URI host name) from "10.2.2.3" to "ITSP":

```
INVITE sip:1000@10.2.2.3;user=phone;x=y;z=a SIP/2.0  
To: <sip:1000@10.2.2.3;user=phone>
```

to

```
INVITE sip:9721000@ITSP;user=phone;x=y;z=a SIP/2.0  
To: <sip:9721000@ITSP;user=phone>
```



## Configuring IP-to-IP Inbound Manipulations

The Inbound Manipulations table lets you configure up to 205 IP-to-IP Inbound Manipulation rules. An Inbound Manipulation rule defines a manipulation sequence for the source or destination SIP URI user part of inbound SIP dialog requests. You can apply these manipulations to different SIP dialog message types (e.g., INVITE or REGISTER) and SIP headers as follows:

- Manipulated **destination URI user part** are done on the following SIP headers: Request-URI and To
- Manipulated **source URI user part** are done on the following SIP headers: From, P-Asserted-Identity (if exists), P-Preferred-Identity (if exists), and Remote-Party-ID (if exists)



Manipulated URI user part of the SIP From and Request-URI headers overwrite the user part of other headers.

Configuration of Inbound Manipulation rules includes two areas:

- **Match:** Defines the matching characteristics of an incoming SIP dialog (e.g., source host name).
- **Action:** Defines the action that is done if the incoming call matches the characteristics of the rule. In other words, the device manipulates the source or destination SIP URI user part of the SIP dialog (e.g., removes a user-defined number of characters from the left of the SIP URI user part).



Configure stricter classification rules higher up in the table than less strict rules to ensure the desired rule is used to manipulate the incoming dialog. *Strict* refers to the number of matching characteristics configured for the rule. For example, a rule configured with source host name and source IP Group as matching characteristics is stricter than a rule configured with only source host name. If the rule configured with only source host name appears higher up in the table, the device ("erroneously") uses the rule to manipulate incoming dialogs matching this source host name (even if they also match the rule appearing lower down in the table configured with the source IP Group as well).

To configure and apply an Inbound Manipulation rule, the rule must be associated with a Routing Policy. The Routing Policy associates the rule with an SRD(s). Therefore, the Routing Policy lets you configure manipulation rules for calls belonging to specific SRD(s). However, as multiple Routing Policies are relevant only for multi-tenant deployments (if needed), for most deployments, only a single Routing Policy is required. As the device provides a default Routing Policy ("Default\_SBCRoutingPolicy"), when only one Routing Policy is required, the device automatically assigns the default Routing Policy to the routing rule. If you are implementing LDAP-based routing (with or without Call Setup Rules) and/or Least Cost Routing (LCR), you need to configure these settings for the Routing Policy (regardless of the number of Routing Policies employed). For more information on Routing Policies, see [Configuring SBC Routing Policies](#) on page 1108.



The IP Groups table can be used to configure a host name that overwrites the received host name. This manipulation can be done for source and destination IP Groups (see [Configuring IP Groups](#) on page 581).



If you have configured call routing from the device's SBC application (IP-to-IP routing) to the device's Gateway application for IP-to-Tel routing, the device uses the initial SIP message as if it's a new call. Therefore, if any manipulations were done on the SIP message by the SBC application, the device ignores them.

The following procedure describes how to configure Inbound Manipulation rules through the Web interface. You can also configure it through ini file [IPInboundManipulation] or CLI (configure voip > sbc manipulation ip-inbound-manipulation).

➤ **To configure an Inbound Manipulation rule:**

1. Open the Inbound Manipulations table (**Setup** menu > **Signaling & Media** tab > **SBC** folder > **Manipulation** > **Inbound Manipulations**).
2. Click **New**; the following dialog box appears:

3. Configure the Inbound Manipulation rule according to the parameters described in the table below.
4. Click **Apply**.

**Table 34-1: Inbound Manipulations Table Parameter Descriptions**

Parameter	Description
'Routing Policy' routing-policy-name [RoutingPolicyName]	<p>Assigns an Routing Policy to the rule. The Routing Policy associates the rule with an SRD(s). The Routing Policy also defines default LCR settings as well as the LDAP servers if the routing rule is based on LDAP routing (and Call Setup Rules).</p> <p>If only one Routing Policy is configured in the Routing Policies table, the Routing Policy is automatically assigned. If multiple Routing Policies are configured, no value is</p>

Parameter	Description
	<p>assigned.</p> <p>To configure Routing Policies, see <a href="#">Configuring SBC Routing Policies</a> on page 1108.</p> <p><b>Note:</b> The parameter is mandatory.</p>
<b>General</b>	
<p>'Index'</p> <p>[Index]</p>	<p>Defines an index number for the new table record.</p> <p><b>Note:</b> Each table row must be configured with a unique index.</p>
<p>'Name'</p> <p>manipulation-name</p> <p>[ManipulationName]</p>	<p>Defines an arbitrary name to easily identify the manipulation rule.</p> <p>The valid value is a string of up to 40 characters. By default, no value is defined.</p> <p><b>Note:</b> The parameter value can't be configured with the character string "any" (upper or lower case).</p>
<p>'Additional Manipulation'</p> <p>is-additional-manipulation</p> <p>[IsAdditionalManipulation]</p>	<p>Determines whether additional SIP URI user part manipulation is done for the table entry rule listed directly above it.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) Regular manipulation rule (not done in addition to the rule above it).</li> <li>■ [1] <b>Yes</b> = If the above row entry rule matched the call, consider this row entry as a match as well and perform the manipulation specified by this rule.</li> </ul> <p><b>Note:</b> Additional manipulation can only be done on a different SIP URI, source or destination, to the rule configured in the row above as configured by the 'Manipulated URI' parameter (see below).</p>
<p>'Manipulation Purpose'</p> <p>purpose</p> <p>[ManipulationPurpose]</p>	<p>Defines the purpose of the manipulation.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Normal</b> = (Default) Inbound manipulations affect the routing input and source and/or destination number.</li> <li>■ [1] <b>Routing input only</b> = Inbound manipulations affect the routing input only, retaining the original source and destination number.</li> <li>■ [2] <b>Shared Line</b> = Used for the Shared-Line Appearance feature. This manipulation is for registration requests</li> </ul>

Parameter	Description
	to change the destination number of the secondary extension numbers to the primary extension. For more information, see <a href="#">Configuring BroadSoft's Shared Phone Line Call Appearance for Survivability</a> on page 1162.
<b>Match</b>	
'Request Type' request-type [RequestType]	<p>Defines the SIP request type to which the manipulation rule is applied.</p> <ul style="list-style-type: none"> <li>■ [0] <b>All</b> = (Default) All SIP messages.</li> <li>■ [1] <b>INVITE</b> = All SIP messages except REGISTER and SUBSCRIBE.</li> <li>■ [2] <b>REGISTER</b> = Only REGISTER messages.</li> <li>■ [3] <b>SUBSCRIBE</b> = Only SUBSCRIBE messages.</li> <li>■ [4] <b>INVITE and REGISTER</b> = All SIP messages except SUBSCRIBE.</li> <li>■ [5] <b>INVITE and SUBSCRIBE</b> = All SIP messages except REGISTER.</li> </ul>
'Source IP Group' src-ip-group-name [SrcIpGroupName]	<p>Defines the IP Group from where the incoming INVITE is received.</p> <p>The default is <b>Any</b> (i.e., any IP Group).</p>
'Source Username Pattern' src-user-name-pattern [SrcUsernamePrefix]	<p>Defines the source SIP URI user name (usually in the From header).</p> <p>The default is the asterisk (*) symbol (i.e., any source user name). You can use special pattern notations to denote the user part. For available notations, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p><b>Note:</b> You can only use a comma (,) as a separator in the pattern and not as a special comma character.</p>
'Source Host' src-host [SrcHost]	<p>Defines the source SIP URI host name - full name (usually in the From header).</p> <p>The default is the asterisk (*) symbol (i.e., any host name).</p>
'Destination Username Pattern' dst-user-name-pattern	<p>Defines the destination SIP URI user name, typically located in the Request-URI and To headers.</p> <p>The default is the asterisk (*) symbol (i.e., any destination user name). You can use special pattern notations to</p>

Parameter	Description
[DestUsernamePrefix]	denote the user part. For available notations, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559. <b>Note:</b> You can only use a comma (,) as a separator in the pattern and not as a special comma character.
'Destination Host' dst-host [DestHost]	Defines the destination SIP URI host name - full name, typically located in the Request URI and To headers. The default is the asterisk (*) symbol (i.e., any destination host name).
<b>Operation Rule - Action</b>	
'Manipulated Item' manipulated-uri [ManipulatedURI]	Determines whether the source or destination SIP URI user part is manipulated.  ■ [0] <b>Source</b> = (Default) Manipulation is done on the source SIP URI user part.  ■ [1] <b>Destination</b> = Manipulation is done on the destination SIP URI user part.
'Remove From Left' remove-from-left [RemoveFromLeft]	Defines the number of digits to remove from the left of the user name prefix. For example, if you enter 3 and the user name is "john", the new user name is "n".
'Remove From Right' remove-from-right [RemoveFromRight]	Defines the number of digits to remove from the right of the user name prefix. For example, if you enter 3 and the user name is "john", the new user name is "j". <b>Note:</b> If both 'Remove From Right' and 'Leave From Right' parameters are configured, the 'Remove From Right' setting is applied first.
'Leave From Right' leave-from-right [LeaveFromRight]	Defines the number of characters that you want retained from the right of the user name. <b>Note:</b> If both 'Remove From Right' and 'Leave From Right' parameters are configured, the 'Remove From Right' setting is applied first.
'Prefix to Add' prefix-to-add [Prefix2Add]	Defines the number or string that you want added to the front of the user name. For example, if you enter 'user' and the user name is "john", the new user name is "userjohn".
'Suffix to Add' suffix-to-add	Defines the number or string that you want added to the end of the user name. For example, if you enter '01' and

Parameter	Description
[Suffix2Add]	the user name is "john", the new user name is "john01".

## Configuring IP-to-IP Outbound Manipulations

The Outbound Manipulations table lets you configure up to 205 IP-to-IP Outbound Manipulation rules. An Outbound Manipulation rule defines a manipulation action for the SIP Request-URI user part (source or destination) or calling name of outbound SIP dialog requests. You can apply these manipulations to different SIP request types (e.g., INVITE) and SIP headers as follows:

- Manipulated **destination URI user part** are done on the following SIP headers: Request URI and To
- Manipulated **source URI user part** are done on the following SIP headers: From, P-Asserted (if exists), P-Preferred (if exists), and Remote-Party-ID (if exists)



Manipulated URI user part of the SIP From and Request-URI headers overwrite the user part of other headers.

Configuration of Outbound Manipulation rules includes two areas:

- **Match:** Defines the matching characteristics of an incoming SIP dialog (e.g., source host name). As the device performs outbound manipulations only after the routing process, destination IP Groups can also be used as matching characteristics.
- **Action:** Defines the action that is done if the incoming call matches the characteristics of the rule. In other words, the device manipulates the source or destination SIP URI user part or calling name of the SIP dialog (e.g., removes a user-defined number of characters from the left of the SIP URI user part).



- Configure stricter classification rules higher up in the table than less strict rules to ensure the desired rule is used to manipulate the outbound dialog. *Strict* refers to the number of matching characteristics configured for the rule. For example, a rule configured with source host name and source IP Group as matching characteristics is stricter than a rule configured with only source host name. If the rule configured with only source host name appears higher up in the table, the device ("erroneously") uses the rule to manipulate outbound dialogs matching this source host name (even if they also match the rule appearing lower down in the table configured with the source IP Group as well).
- SIP URI host name (source and destination) manipulations can also be configured in the IP Groups table (see [Configuring IP Groups](#) on page 581). These manipulations are simply host name substitutions with the names configured for the source and destination IP Groups, respectively.
- If you have configured call routing from the device's SBC application (IP-to-IP routing) to the device's Gateway application for IP-to-Tel routing, the device uses the initial SIP message as if it's a new call. Therefore, if any manipulations were done on the SIP message by the SBC application, the device ignores them.

The following procedure describes how to configure Outbound Manipulations rules through the Web interface. You can also configure it through ini file [IPOutboundManipulation] or CLI (configure voip > sbc manipulation ip-outbound-manipulation).

➤ **To configure Outbound Manipulation rules:**

1. Open the Outbound Manipulations table (**Setup** menu > **Signaling & Media** tab > **SBC** folder > **Manipulation** > **Outbound Manipulations**).
2. Click **New**; the following dialog box appears:

3. Configure an Outbound Manipulation rule according to the parameters described in the table below.
4. Click **Apply**.

**Table 34-2: Outbound Manipulations Table Parameter Description**

Parameter	Description
'Routing Policy'	Assigns a Routing Policy to the rule. The Routing Policy associates the

Parameter	Description
routing-policy-name [RoutingPolicy Name]	<p>rule with an SRD(s). The Routing Policy also defines default LCR settings as well as the LDAP servers if the routing rule is based on LDAP routing (and Call Setup Rules).</p> <p>If only one Routing Policy is configured in the Routing Policies table, the Routing Policy is automatically assigned. If multiple Routing Policies are configured, no value is assigned.</p> <p>To configure Routing Policies, see <a href="#">Configuring SBC Routing Policies</a> on page 1108.</p> <p><b>Note:</b> The parameter is mandatory.</p>
<b>General</b>	
'Index' [Index]	<p>Defines an index number for the new table row.</p> <p><b>Note:</b> Each row must be configured with a unique index.</p>
'Name' manipulation-name [Manipulation Name]	<p>Defines a descriptive name, which is used when associating the row in other tables.</p> <p>The valid value is a string of up to 40 characters. By default, no value is defined.</p> <p><b>Note:</b> The parameter value can't be configured with the character string "any" (upper or lower case).</p>
'Additional Manipulation' is-additional-manipulation [IsAdditionalManipulation]	<p>Determines whether additional manipulation is done for the table entry rule listed directly above it.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) Regular manipulation rule - not done in addition to the rule above it.</li> <li>■ [1] <b>Yes</b> = If the previous table row entry rule matched the call, consider this row entry as a match as well and perform the manipulation specified by this rule.</li> </ul> <p><b>Note:</b> Additional manipulation can only be done on a different item (source URI, destination URI, or calling name) to the rule configured in the row above (configured by the 'Manipulated URI' parameter).</p>
'Call Trigger' trigger [Trigger]	<p>Defines the reason (i.e., trigger) for re-routing the SIP request.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Any</b> = (Default) Re-routed for all scenarios (re-routes and non-re-routes).</li> <li>■ [1] <b>3xx</b> = Re-routed if triggered as a result of a SIP 3xx response.</li> <li>■ [2] <b>REFER</b> = Re-routed if triggered as a result of a REFER request.</li> <li>■ [3] <b>3xx or REFER</b> = Applies to optional values <b>3xx</b> and <b>REFER</b>.</li> </ul>



Parameter	Description
	<ul style="list-style-type: none"> <li>■ [4] <b>Initial only</b> = Regular requests that the device forwards to a destination. In other words, re-routing of requests triggered by the receipt of REFER or 3xx doesn't apply.</li> </ul>
<b>Match</b>	
'Request Type' request-type [RequestType]	Defines the SIP request type to which the manipulation rule is applied. <ul style="list-style-type: none"> <li>■ [0] <b>All</b> = (Default) all SIP messages.</li> <li>■ [1] <b>INVITE</b> = All SIP messages except REGISTER and SUBSCRIBE.</li> <li>■ [2] <b>REGISTER</b> = Only SIP REGISTER messages.</li> <li>■ [3] <b>SUBSCRIBE</b> = Only SIP SUBSCRIBE messages.</li> <li>■ [4] <b>INVITE and REGISTER</b> = All SIP messages except SUBSCRIBE.</li> <li>■ [5] <b>INVITE and SUBSCRIBE</b> = All SIP messages except REGISTER.</li> </ul>
'Source IP Group' src-ip-group-name  [SrcIPGroupName]	Defines the IP Group from where the INVITE is received. The default value is <b>Any</b> (i.e., any IP Group).
'Destination IP Group' dst-ip-group-name  [DestIPGroupName]	Defines the IP Group to where the INVITE is to be sent. The default value is <b>Any</b> (i.e., any IP Group).
'Source Username Pattern' src-user-name-pattern [SrcUsernamePrefix]	Defines the source SIP URI user name (typically used in the SIP From header). You can use special patterns (notations) to denote the user part. For example, if you want to match this rule to user parts whose last four digits (i.e., suffix) are 4 followed by any three digits (e.g., 4008), then configure this parameter to "(4xxx)". For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559. The valid value is a string of up to 60 characters. The default value is the asterisk (*) symbol, meaning any source user part. <b>Note:</b>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ If you need to manipulate calls of many different source URI user parts, you can use tags (see 'Source Tags' parameter below) instead of this parameter.</li> <li>■ You can only use a comma (,) as a separator in the pattern and not as a special comma character.</li> </ul>
'Source Host' src-host [SrcHost]	<p>Defines the source SIP URI host name - full name, typically in the From header.</p> <p>The default value is the asterisk (*) symbol (i.e., any source host name).</p>
'Source Tags' src-tags [SrcTags]	<p>Assigns a prefix tag to denote source URI user names corresponding to the tag configured in the associated Dial Plan.</p> <p>The valid value is a string of up to 70 characters. The tag is case insensitive. By default, no value is defined. You can configure the parameter with up to five tags, where each tag is separated by a semicolon (;). However, you can configure only up to seven tags containing a name and value (e.g., Country=Ireland), and <b>one</b> tag containing a value only (e.g., Ireland). If you are configuring multiple tags in the name=value format, the names of each tag must be unique (e.g., <b>Country</b>=Ireland;<b>Land</b>=Scotland). The following example configures the maximum number of tags (i.e., seven name=value tags and one value-only tag):</p> <p>Country=Ireland;Country2=Scotland;Country3=RSA;Country4=Canada;Country5=UK;Country6=France;Country7=Germany;USA.</p> <p>To configure prefix tags, see <a href="#">Configuring Dial Plans</a> on page 798.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Make sure that you assign the Dial Plan in which you have configured the prefix tag, to the related IP Group or SRD.</li> <li>■ Instead of using tags and configuring the parameter, you can use the 'Source Username Pattern' parameter to specify a specific URI source user or all source users.</li> </ul>
'Destination Username Pattern' dst-user-name-pattern [DestUsernamePrefix]	<p>Defines the destination SIP URI user part (typically located in the Request-URI and To headers).</p> <p>You can use special patterns (notations) to denote the user part. For example, if you want to match this rule to user parts whose last four digits (i.e., suffix) are 4 followed by any three digits (e.g., 4008), then configure this parameter to "(4xxx)". For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p> <p>The valid value is a string of up to 60 characters. The default value is the asterisk (*) symbol, meaning any destination user part.</p>

Parameter	Description
	<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you need to manipulate calls of many different destination URI user names, you can use tags (see 'Destination Tags' parameter below) instead of this parameter.</li> <li>■ You can only use a comma (,) as a separator in the pattern and not as a special comma character.</li> </ul>
'Destination Host' dst-host [DestHost]	<p>Defines the destination SIP URI host name - full name, typically located in the Request-URI and To headers.</p> <p>The default value is the asterisk (*) symbol (i.e., any destination host name).</p>
'Destination Tags' dest-tags [DestTags]	<p>Assigns a prefix tag to denote destination URI user names corresponding to the tag configured in the associated Dial Plan.</p> <p>The valid value is a string of up to 70 characters. The tag is case insensitive. By default, no value is defined. You can configure the parameter with up to five tags, where each tag is separated by a semicolon (;). However, you can configure only up to seven tags containing a name and value (e.g., Country=Ireland), and <b>one</b> tag containing a value only (e.g., Ireland). If you are configuring multiple tags in the name=value format, the names of each tag must be unique (e.g., <b>Country</b>=Ireland;<b>Land</b>=Scotland). The following example configures the maximum number of tags (i.e., seven name=value tags and one value-only tag):</p> <p>Country=Ireland;Country2=Scotland;Country3=RSA;Country4=Canada;Country5=UK;Country6=France;Country7=Germany;USA.</p> <p>To configure prefix tags, see <a href="#">Configuring Dial Plans</a> on page 798.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Make sure that you assign the Dial Plan in which you have configured the prefix tag, to the related IP Group or SRD.</li> <li>■ Instead of using tags and configuring the parameter, you can use the 'Destination Username Pattern' parameter to specify a specific URI destination user or all destinations users.</li> </ul>
'Calling Name Pattern' calling-name-pattern [CallingNamePrefix]	<p>Defines the calling name (caller ID). The calling name appears in the SIP From header.</p> <p>The valid value is a string of up to 37 characters. By default, no calling name is defined. You can use special patterns (notations) to denote the calling name. For available patterns, see <a href="#">Patterns for Denoting Phone Numbers and SIP URIs</a> on page 1559.</p>

Parameter	Description
'Message Condition' message-condition-name [MessageConditionName]	<p>Assigns a Message Condition rule as a matching characteristic. Message Condition rules define required SIP message formats.</p> <p>To configure Message Condition rules, see <a href="#">Configuring Message Condition Rules</a> on page 838.</p>
'ReRoute IP Group' re-route-ip-group-name [ReRouteIPGroupUpName]	<p>Defines the IP Group that initiated (sent) the SIP redirect response (e.g., 3xx) or REFER message. The parameter is typically used for re-routing requests (e.g., INVITEs) when interworking is required for SIP 3xx redirect responses or REFER messages.</p> <p>The default is <b>Any</b> (i.e., any IP Group).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter functions together with the 'Call Trigger' parameter (see below).</li> <li>■ For more information on interworking of SIP 3xx redirect responses or REFER messages, see <a href="#">Interworking SIP 3xx Redirect Responses</a> on page 1041 and <a href="#">Interworking SIP REFER Messages</a> on page 1045, respectively.</li> </ul>
<b>Action</b>	
'Manipulated Item' manipulated-uri [IsAdditionalManipulation]	<p>Defines the element in the SIP message that you want manipulated.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Source URI</b> = (Default) Manipulates the source SIP Request-URI user part.</li> <li>■ [1] <b>Destination URI</b> = Manipulates the destination SIP Request-URI user part.</li> <li>■ [2] <b>Calling Name</b> = Manipulates the calling name in the SIP message.</li> </ul>
'Remove From Left' remove-from-left [RemoveFromLeft]	<p>Defines the number of digits to remove from the left of the manipulated item prefix. For example, if you enter 3 and the user name is "john", the new user name is "n".</p>
'Remove From Right' remove-from-right	<p>Defines the number of digits to remove from the right of the manipulated item prefix. For example, if you enter 3 and the user name is "john", the new user name is "j".</p>

Parameter	Description
[RemoveFromRight]	
'Leave From Right' leave-from-right [LeaveFromRight]	Defines the number of digits to keep from the right of the manipulated item.
'Prefix to Add' prefix-to-add [Prefix2Add]	<p>Defines the number or string to add in the front of the manipulated item. For example, if you enter 'user' and the user name is "john", the new user name is "userjohn".</p> <p>If you set the 'Manipulated Item' parameter to <b>Source URI</b> or <b>Destination URI</b>, you can configure the parameter to a string of up to 49 characters. If you set the 'Manipulated Item' parameter to <b>Calling Name</b>, you can configure the parameter to a string of up to 36 characters.</p>
'Suffix to Add' suffix-to-add [Suffix2Add]	<p>Defines the number or string to add at the end of the manipulated item. For example, if you enter '01' and the user name is "john", the new user name is "john01".</p> <p>If you set the 'Manipulated Item' parameter to <b>Source URI</b> or <b>Destination URI</b>, you can configure the parameter to a string of up to 49 characters. If you set the 'Manipulated Item' parameter to <b>Calling Name</b>, you can configure the parameter to a string of up to 36 characters.</p>
'Privacy Restriction Mode' privacy-restriction-mode [PrivacyRestrictionMode]	<p>Defines user privacy handling (i.e., restricting source user identity in outgoing SIP dialogs).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Transparent</b> = (Default) No intervention in SIP privacy.</li> <li>■ [1] <b>Don't change privacy</b> = The user identity remains the same as in the incoming SIP dialog. If a restricted number exists, the restricted presentation is normalized as follows: <ul style="list-style-type: none"> <li>✓ From URL header: "anonymous@anonymous.invalid"</li> <li>✓ If a P-Asserted-Identity header exists (either in the incoming SIP dialog or added by the device), a Privacy header is added with the value "id".</li> </ul> </li> <li>■ [2] <b>Restrict</b> = The user identity is restricted. The restriction is as follows:</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>✓ From URL header: "anonymous@anonymous.invalid"</li> <li>✓ If a P-Asserted-Identity header exists (either in the incoming SIP dialog or added by the device), a Privacy header is added with the value "id".</li> <li>■ [3] <b>Remove Restriction</b> = The device attempts to reveal the user identity by setting user values in the From header and removing the privacy "id" value if the Privacy header exists. If the From header user is "anonymous", the value is taken from the P-Preferred-Identity, P-Asserted-Identity, or Remote-Party-ID header (if exists).</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Restriction is done only after user number manipulation, if any.</li> <li>■ The device identifies an incoming user as restricted if one of the following exists: <ul style="list-style-type: none"> <li>✓ From header user is "anonymous".</li> <li>✓ P-Asserted-Identity and Privacy headers contain the value "id".</li> </ul> </li> </ul>

## Using Proprietary SIP X-AC-Action Header

You can use AudioCodes proprietary SIP header *X-AC-Action* in Message Manipulation rules to trigger certain actions. These actions can be used to support, for example, interworking of SIP-I and SIP endpoints for the ISUP SPIROU variant (see [Enabling Interworking of SIP and SIP-I Endpoints](#) on page 1152).

The following actions are supported by the X-AC-Action header:

■ **To disconnect a call (optionally, after a user-defined time):**

X-AC-Action: 'disconnect'

X-AC-Action: 'disconnect;delay=<time in ms>'

■ **To resume a previously suspended call:**

X-AC-Action: 'abort-disconnect'

■ **To automatically reply to a message without forwarding the response to the other side:**

X-AC-Action: 'reply'

- **To automatically reply to a message with a specific SIP response without forwarding the response to the other side:**

```
X-AC-Action: 'reply;response=<response code, e.g., 200>'
```

- **To override device's handling of SIP REFER messages for SBC calls, which is configured by the 'Remote REFER Mode' parameter.** The X-AC-Action header can be added to the incoming SIP REFER request using Message Manipulation rules. This is useful if you don't want the settings of this parameter to apply to all calls that are associated with the IP Profile. For example, if you configure the 'Remote REFER Mode' parameter to **Handle Locally**, all incoming SIP REFER requests associated with the IP Profile are terminated at the device. However, you can configure a Message Manipulation rule with the proprietary header to override this parameter setting and allow the device to forward the REFER requests as is for calls with a specific URI, for example. You can configure Message Manipulation rules to add this X-AC-Action header for REFER handling, with one of the following values:

- To allow the device to forward the REFER as is, regardless of the 'Remote REFER Mode' parameter settings:

```
X-AC-Action: 'use-config;refer-behavior=regular'
```

- To allow the device to handle (terminate) the REFER request regardless of the 'Remote REFER Mode' parameter settings:

```
X-AC-Action: 'use-config;refer-behavior= handle-locally'
```

- **To switch to a different IP Profile for the call (re-INVITE only), as defined in the IP Group:**

```
X-AC-Action: 'switch-profile;profile-name=<IP Profile Name>'
```

```
X-AC-Action: 'switch-profile;profile-name=<IP Profile  
Name>;reason=<PoorInVoiceQuality or PoorInVoiceQualityFailure>'
```

If the IP Profile name contains one or more spaces (e.g., "ITSP NET"), enclose the name in double quotation marks, for example:

```
X-AC-Action: 'switch-profile;profile-name="ITSP NET"'
```



The X-AC-Action header for triggering the actions *disconnect*, *abort-disconnect*, and *reply* is supported only for the following SIP messages (methods):

- re-INVITE
- UPDATE
- INFO
- REFER

For example, to use the X-AC-Action header to switch IP Profiles from "ITSP-Profile-1" to "ITSP-Profile-2" during a call for an IP Group (e.g., IP PBX) if the negotiated media port changes to 7550, perform the following configuration:

1. In the IP Profiles table, configure two IP Profiles ("ITSP-Profile-1" and "ITSP-Profile-2").
2. In the IP Groups table, assign the main IP Profile ("ITSP-Profile-1") to the IP Group using the 'IP Profile' parameter.
3. In the Message Manipulations table (see [Configuring SIP Message Manipulation](#) on page 829), configure the following manipulation rule:
  - Manipulation Set ID: **1**
  - Message Type: **reinvite.request**
  - Condition: **body.sdp regex (.\*)(m=audio 7550 RTP/AVP)(.\*)**
  - Action Subject: **header.X-AC-Action**
  - Action Type: **Add**
  - Action Value: **'switch-profile;profile-name=ITSP-Profile-2'**
4. In the IP Groups table, assign the Message Manipulation rule to the IP Group, using the 'Inbound Message Manipulation Set' parameter.

In the above example, if the device receives from the IP Group a re-INVITE message whose media port value is 7550, the device adds the SIP header "X-AC-Action: switch-profile;profile-name=ITSP-Profile-2" to the incoming re-INVITE message. As a result of receiving this manipulated message, the device starts using IP Profile "ITSP-Profile-2" instead of "ITSP-Profile-1", for the IP Group.



## 35 Configuring Malicious Signatures

The Malicious Signature table lets you configure up to 20 Malicious Signature patterns. Malicious Signatures are signature patterns that identify SIP user agents (UA) who perform malicious attacks on SIP servers by SIP scanning. Malicious Signatures allow you to protect SBC calls handled by the device from such malicious activities, thereby increasing your SIP security. The Malicious Signature patterns identify specific scanning tools used by attackers to search for SIP servers in the network. The feature identifies and protects against SIP (Layer 5) threats by examining new inbound SIP dialog messages. Once the device identifies an attack based on the configured malicious signature pattern, it marks the SIP message as invalid and discards it or alternatively, rejects it with a SIP response (by default, 400), configured in the Message Policies table (see [Configuring SIP Message Policy Rules](#) on page 840). Protection applies only to new dialogs (e.g., INVITE and REGISTER messages) and unauthenticated dialogs.

Malicious signatures can also be used with the Intrusion Detection System (IDS) feature (see [Configuring IDS Policies](#) on page 259). You can configure an IDS Policy that is activated if the device detects a malicious signature (when the 'Reason' parameter is configured to **Dialog establishment failure**).

Malicious signature patterns are typically based on the value of SIP User-Agent headers, which attackers use as their identification string (e.g., "User-Agent: VaxSIPUserAgent"). However, you can configure signature patterns based on any SIP header. To configure signature patterns, use the same syntax as that used for configuring Conditions in the Message Manipulations table (see [Configuring SIP Message Manipulation](#) on page 829). Below are configured signature patterns based on the User-Agent header:

- Malicious signature for the VaxSIPUserAgent malicious UA:

```
header.user-agent prefix 'VaxSIPUserAgent'
```

- Malicious signature for the scanning tool "sip-scan":

```
header.user-agent prefix 'sip-scan'
```

By default, the table provides preconfigured malicious signatures of known, common attackers.



- Malicious Signatures do not apply to the following:
  - ✓ Calls from IP Groups where Classification is by Proxy Set.
  - ✓ In-dialog SIP sessions (e.g., refresh REGISTER requests and re-INVITEs).
  - ✓ Calls from users that are registered with the device.
- If you delete all the entries in the table, when you next restart the device, the table is populated again with all the default signatures.

You can export / import Malicious Signatures in CSV file format to / from a remote server through HTTP, HTTPS, or TFTP. To do this, use the following CLI commands:

```
(config-voip)# sbc malicious-signature-database <export-csv-to | import-csv-from>
<URL>
```

To apply malicious signatures to calls, you need to enable the use of malicious signatures for a Message Policy and then assign the Message Policy to the SIP Interface associated with the calls (i.e., IP Group). To configure Message Policies, see [Configuring SIP Message Policy Rules](#) on page 840.

The following procedure describes how to configure Malicious Signatures through the Web interface. You can also configure it through ini file [MaliciousSignatureDB] or CLI (`configure voip > sbc malicious-signature-database`).

➤ **To configure a Malicious Signature:**

1. Open the Malicious Signature table (**Setup** menu > **Signaling & Media** tab > **SBC** folder > **Malicious Signature**).
2. Click **New**; the following dialog box appears:

3. Configure a Malicious Signature according to the parameters described in the table below.
4. Click **Apply**.

**Table 35-1: Malicious Signature Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Name' name [MaliciousSignatureDB_ Name]	Defines a descriptive name, which is used when associating the row in other tables. The valid value is a string of up to 30 characters. <b>Note:</b> Configure each row with a unique name.
'Pattern' pattern [MaliciousSignatureDB_ Pattern]	Defines the signature pattern. The valid value is a string of up to 60 characters. You can use the built-in syntax editor to help you configure the field. Click the <b>Editor</b> button located alongside the field to open the Editor, and then simply follow the on-screen instructions. <b>Note:</b> The parameter is mandatory.

## 36 Advanced SBC Features

This section describes configuration of advanced SBC features.

### Configuring Call Preemption for SBC Emergency Calls

The device supports emergency call preemption for SBC calls by prioritizing emergency calls over regular calls. If the device receives an incoming emergency call when there are unavailable resources to process the call, the device preempts one of the regular calls to free up resources for sending the emergency call to its' destination (i.e., emergency service provider), instead of rejecting it. The device may preempt more than one active call in order to provide sufficient resources for processing the emergency call. Available resources depends on the number of INVITE messages currently processed by the device.

If the device preempts a call, it disconnects the call as follows:

- If the call is being setup (not yet established), it sends a SIP 488 response to the incoming leg and a SIP CANCEL message to the outgoing leg.
- If the call is already established, it sends a SIP BYE message to each leg. The device includes in the SIP BYE message, the Reason header describing the cause as "preemption".

Once the device terminates the regular call, it immediately sends the INVITE message of the emergency call to its' destination without waiting for any response from the remote sides (e.g., 200 OK after BYE). If the device is unable to preempt a call for the emergency call, it rejects the emergency call with a SIP 503 "Emergency Call Failed" (instead of "Service Unavailable") response.

For the device to identify incoming calls as emergency calls, you need to configure a Message Condition rule in the Message Conditions table. Below are examples of Message Condition rules for identifying emergency calls:

**Table 36-1: Examples of Message Condition Rules for Emergency Calls**

Index	Name	Condition
0	Emergency1 - RP header	header.resource-priority contains 'emergency'
1	Emergency2 - RP header	header.resource-priority contains 'esnet'
2	Emergency1 - user with providers address	header.to.url.user=='911'
3	Emergency2 - user with providers address	header.to.url.user=='100'    header.to.url.user=='101'    header.to.url.user=='102'

Index	Name	Condition
4	Emergency3 - user with providers address	header.request.uri contains 'urn:service:sos'

- Indices 0 and 1: SIP Resource-Priority header contains a string indicating an emergency call.
- Indices 2 to 4: Destination user-part contains the emergency provider's address.

The device applies the Message Condition rule only after call classification (but, before inbound manipulation).



The device doesn't preempt established emergency calls.

➤ **To configure SBC emergency call preemption:**

1. In the Message Conditions table (see [Configuring Message Condition Rules](#) on page 838), configure a Message Condition rule to identify incoming emergency calls. See above for examples.
2. Open the SBC General Settings page (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **Priority and Emergency**), and then scroll down to the below group of fields:

Preemption Mode	• <input checked="" type="checkbox"/>
Emergency Message Condition	• <input type="text" value="0"/>
Emergency RTP DiffServ	<input type="text" value="46"/>
Emergency Signaling DiffServ	<input type="text" value="40"/>

3. Select the 'Preemption Mode' check box (SBCPreemptionMode) to enable call preemption.
4. In the 'Emergency Message Condition' field, enter the row index of the Message Condition rule that you configured in Step 1.
5. (Optional) Assign DiffServ levels (markings) to packets belonging to emergency calls:
  - In the 'Emergency RTP DiffServ' field (SBCEmergencyRTPDiffServ), enter the QoS level for RTP packets.
  - In the 'Emergency Signaling DiffServ' field (SBCEmergencySignalingDiffServ), enter the QoS level for SIP signaling packets.
6. Click **Apply**.



The call preemption feature uses only total licensed SBC signaling (SIP) resources and/or the Call Admission Control feature (see [Configuring Call Admission Control](#) on page 1054), and not the number of configured available media (RTP) ports for determining an out-of-resources scenario. Therefore, it's highly recommended that you configure the number of media session legs in the Media Realm table with at least twice the number of SBC signaling resources.

## Configuring Message Session Relay Protocol

The device supports Message Session Relay Protocol (MSRP), which is a text-based protocol for exchanging a series of related instant messages (IM) across an IP network (TCP or TLS only) in the context of a session. The protocol can also be used to transfer large files or images, or share remote desktops or whiteboards. MSRP is typically required for Next Generation 911 (NG911) services, allowing 911 callers to not only access 911 services through voice calls, but also through text messages with Public Safety Answering Points (PSAPs). The device's MSRP support is in accordance with RFC 4975 (The Message Session Relay Protocol (MSRP)) and RFC 6135 (An Alternative Connection Model for the Message Session Relay Protocol (MSRP)). The device also supports secure MSRP sessions (MSRPS), using TLS certificates (TLS Context).



MSRP is applicable only to the SBC application.

The device establishes MSRP sessions using the SDP offer/answer negotiation model over SIP. The MSRP session starts with a SIP INVITE and ends with a SIP BYE message. As a B2BUA, the device interoperates between the MSRP endpoints, terminating the incoming MSRP message on the inbound leg and then generating a new MSRP message on the outbound leg. Before sending the INVITE, the device manipulates the SDP body (e.g., 'a=path', 'c=', 'm=', 'a=setup' and 'a=fingerprint' lines). The device can perform optional message manipulation and other translations such as resolving NAT traversal when the endpoints or device are located behind NAT.

An example of an SDP body with the fields for MSRP negotiation in the INVITE message is shown below:

```
INVITE sip:alice@atlanta.example.com SIP/2.0
To: <sip:bob@biloxi.example.com>
From: <sip:alice@atlanta.example.com>;tag=786
Call-ID: 3413an89KU
Content-Type: application/sdp

c=IN IP4 atlanta.example.com
m=message 7654 TCP/MSRP *
a=accept-types:text/plain
a=path:msrp://atlanta.example.com:7654/jshA7weztas;tcp
a=setup:active
```

Where,

- 'c=' line ignores IP address and port
- 'm=' line indicates an MSRP message
- 'a=accept-types:' line lists allowed content types
- 'a=path:msrp:' line indicates the URI to where the messages are to be sent
- 'a=setup' line indicates the MSRP role (active UA initiates connection; passive UA listens on port)

If secured MSRP (MSRPS) is required (i.e., incoming SDP contains 'm=' line with 'TCP/TLS/MSRP' value, 'a=path' with 'msrps', and 'a=fingerprint'), during MSRP session establishment, the device enforces the validity of the fingerprint from the TLS handshake (public key) with the fingerprint in the received SDP. When the device establishes a secured MSRP session, the offered fingerprint is obtained from the TLS Context, which is assigned to the IP Profile of the endpoint.

The device handles MSRP sessions as follows:

1. When the device receives an INVITE message with the MSRP offer, it initiates an SDP offer to the destination endpoint on the outgoing leg. Before sending the INVITE message, the device does the following:
  - Uses the configured MSRP TCP or MSRP TLS port (SIP Interface) in the SDP 'm=' line.
  - Uses the IP address (SDP 'c=' line) of the associated IP Interface (SIP Interface).
  - Sets the 'a=setup' line to the configured preferred MSRP role of the device.
2. When the device receives the MSRP answer from the destination endpoint, it sends an SDP answer to the dialog-initiating endpoint. Before sending the INVITE message, the device does the following:
  - If the device has chosen a TCP server role, it selects the listening port configured for MSRP in the associated SIP Interface. The port number is included in the media line of the SDP.
  - The device includes the IP address of the associated IP Interface in the 'c=' line of the SDP.
  - Sets the 'a=setup' line to the device's negotiated role.

Once SDP negotiation between the UAs is complete and the MSRP session is being established, the device initiates a TCP/TLS connection (or waits to be initiated) on each leg, depending on SDP negotiation. Once a TCP/TLS connection is established, the endpoints can start sending MSRP messages using MSRP SEND requests, as shown in the following example:

```
MSRP a786hjs2 SEND
To-Path: msrp://biloxi.example.com:12763/kjhd37s2s20w2a;tcp
From-Path: msrp://atlanta.example.com:7654/jshA7weztas;tcp
Message-ID: 87652491
Byte-Range: 1-25/25
```


Content-Type: text/plain

Hey Bob, are you there?  
-----a786hjs2\$

The MSRP payload or content (i.e., the actual message) follows the Content-Type header. Finally, the SEND request is closed with an end-line of seven hyphens, the Transaction ID, and one of the following symbols:

- **\$**: The request contains the final part of the message (end).
- **+**: The request doesn't contain the final part of the message (\$), but is only part of a series of messages.
- **#**: The sender is aborting an incomplete message and intends to send no further chunks in that message (message should be discarded).

An example of a basic MSRP flow is shown below:



- When the device operates in HA mode, MSRP sessions are terminated during an HA switchover. MSRP endpoints are expected to re-initiate failed sessions.
- MSRP is not supported with other media types (i.e., voice) in the same SDP session.
- MSRP is supported on IPv4 and IPv6 networks.
- The Call Admission Control (CAC) mechanism handles MSRP sessions as regular media sessions (i.e., they are not calculated and monitored separately from regular media calls).
- CDRs generated by the device for MSRP calls include the value "msrp" in the Media List CDR field.

The following procedure provides the basic steps for configuring MSRP.

➤ **To configure MSRP:**

1. Enable MSRP functionality:

- a. Open the Media Settings page (**Setup** menu > **Signaling & Media** tab > **Media** folder > **Media Settings**).
- b. Select the 'Enable MSRP' check box:

Enable MSRP



- c. Click **Apply**, and then restart the device with a burn-to-flash for your settings to take effect.
2. Configure the MSRP endpoint's IP Profile:
- a. Open the IP Profiles table (see [Configuring IP Profiles](#) on page 664).
  - b. Configure the following (in addition to other IP Profile settings):
    - ◆ From the 'SBC Media Security Mode' drop-down list, select the transport protocol for the outgoing leg - **Secured** or **Both** for MSRPS (example below); **Not Secured** for MSRP.

SBC Media Security Mode

Secured



- ◆ From the 'MSRP Offer Setup Role' drop-down list, select the MSRP role mode in SDP negotiations ('a=setup' line). The device's role is according to the response: If 'a=setup passive', it's the "active" role; if 'a=setup active', it's the "passive" role. If no 'a=setup' in the response, it's the "active" role.

MSRP Offer Setup Role

ActPass



- ◆ In the 'Data DiffServ' field, configure the DiffServ value of MSRP traffic ('m=message').

Data DiffServ

5

- ◆ From the 'MSRP re-INVITE/UPDATE' drop-down list, select if the destination MSRP endpoint supports the receipt of re-INVITE requests and UPDATE messages.

MSRP re-INVITE/UPDATE

Supported



- ◆ From the 'MSRP Empty Message Format' drop-down list, select if the device must add a Content-Type header to empty MSRP messages that are used to initiate the connection.



**MSRP Empty Message Format**

With Content Type



- ◆ If you want to implement alternative routing if the MSRP endpoints don't establish an MSRP connection within a specific timeout (configured by the 'Timeout to Establish MSRP Connection' global parameter) or if the MSRP socket is closed after the call was established, then from the 'Broken Connection Mode' drop-down list, select **Reroute** or **Reroute with Original SIP Headers**:

**Broken Connection Mode**

Reroute



For more information on the Broken Connection feature, see the description of the 'Broken Connection Mode' parameter in [Configuring IP Profiles](#) on page 664.

- c. Click **Apply**.
3. Configure the SIP Interface for the MSRP endpoint:
- a. Open the SIP Interfaces table (see [Configuring SIP Interfaces](#) on page 561).
  - b. In the 'MSRP TCP Port' field and 'MSRP TLS Port' field, configure a single TCP and/or TLS port number, respectively. The port number is used in the SDP's 'a=path' line.

MSRP TCP Port

4000

MSRP TLS Port

4060

- c. Click **Apply**.



- For secured MSRP (MSRPS), the TLS Context assigned to the SIP Interface ('TLS Context Name' field) is used.
- The IP Interface assigned to the SIP Interface is used for the MSRP sessions.

4. Configure the timeout for establishing the MSRP connection through the MSRP port. If the timeout expires and the connection has yet to be established, the device ends the SIP session.
- a. Open the Media Settings page (**Setup** menu > **Signaling & Media** tab > **Media** folder > **Media Settings**).
  - b. In the 'Timeout to Establish MSRP Connection' field, enter the timeout:

**Timeout to Establish MSRP Connection**

1009

- c. Click **Apply**.

- For NAT traversal of MSRP sessions when the device is located behind NAT, use the NAT Translation table (see [Configuring NAT per IP Interface](#) on page 179). The target IP address:port (public) is used in the SDP's 'a=path' line.

## Emergency Call Routing using LDAP to Obtain ELIN

The device can route emergency calls (e.g., 911) for INVITE messages that are received without an ELIN number. This is in contrast to when the device is deployed in a Microsoft Teams / Skype for Business environment, whereby the received INVITE messages contain ELIN numbers. For a detailed explanation on ELIN numbers and handling of emergency calls by emergency server providers, see [E9-1-1 Support for Microsoft Teams and Skype for Business](#) on page 489.

To obtain an ELIN number for emergency calls received without ELINs, you can configure the device to query an LDAP server for the 911 caller's ELIN number. The device adds the resultant ELIN number and a Content-Type header for the PIDF XML message body to the outgoing INVITE message, for example:

```
Content-Type: application/pidf+xml
<ELIN>1234567890</ELIN>
```

### ➤ To enable emergency call routing using LDAP to obtain ELIN:

- Configure a Call Setup rule in the Call Setup Rules table (see [Configuring Call Setup Rules](#) on page 782). The following example shows a Call Setup rule that queries an Active Directory (AD) server for the attribute "telephoneNumber" whose value is the E9-1-1 caller's number (source), and then retrieves the user's ELIN number from the attribute "numberELIN":

The screenshot shows the 'Call Setup Rules' configuration window for a rule named 'ELIN from LDAP'. The interface is divided into two main sections: 'GENERAL' and 'ACTION'.

**GENERAL Section:**

- Index:** 1
- Name:** ELIN from LDAP
- Rules Set ID:** 1
- Request Type:** LDAP
- Request Target:** (empty)
- Request Key:** telephoneNumber=Param.Call.Src.User
- Attributes To Get:** numberELIN
- Row Role:** Use Current Condition
- Condition:** LDAP.Attr.numberELIN exists

**ACTION Section:**

- Action Subject:** Body:application/pidf+xml
- Action Type:** Add
- Action Value:** <ELIN>{ldap.attr.numberELIN}</ELIN>

- Enable the E9-1-1 feature, by configuring the 'PSAP Mode' parameter to **PSAP Server** in the IP Groups table for the IP Group of the PSAP server (see [Enabling the E9-1-1 Feature](#) on page 501).
- Configure routing rules in the IP-to-IP Routing table for routing between the emergency callers' IP Group and the PSAP server's IP Group. The only special configuration required for the routing rule from emergency callers to the PSAP server:
  - Configure the emergency number (e.g., 911) in the 'Destination Username Pattern' field.

- Assign the Call Setup rule that you configured for obtaining the ELIN number from the AD (see Step 1) in the 'Call Setup Rules Set ID' field (see [Configuring SBC IP-to-IP Routing Rule for E9-1-1](#) on page 503).

## Configuring Dual Registration for SIP Entity

Some SIP entities (e.g., IP Phones) are setup to register with two registrar/proxy servers (primary and secondary). The reason for this is to provide call redundancy for the SIP entity in case one of the proxy servers fail. When the SIP entity registers with the proxy servers, it sends two identical REGISTER messages - one to the primary proxy and one to the secondary proxy. When the device is located between the SIP entity and the two proxy servers, it needs to differentiate between these two REGISTER messages even though they are identical. This is crucial to ensure that the device forwards the two registrations to the proxy servers and that the device performs correct call routing between the SIP entity and the two proxy servers.

To differentiate between these REGISTER messages, a unique SIP Interface needs to be used for each REGISTER message. Each REGISTER message is registered in the registration database using a unique "ac-int=<value>" string identifying the SIP Interface for the Contact user. In addition, for SIP requests (e.g., INVITE) from the proxy servers, the device needs to search its registration database for the contact user so that it can forward it to the user. In normal registration, the host part of the Request-URI contains the IP address of the device and therefore, there is no way of knowing which registered user the INVITE is intended for. To overcome this issue, you can configure the device to use a special string with a unique value, "ac-feu=<value>" for each registration, allowing the device to differentiate between two registrations from the same user (identical REGISTER requests). Each REGISTER message is registered in the registration database using the unique "ac-feu=" string identifier for the Contact user.

A summary of how the device registers the two REGISTER messages in its registration database is as follows:

1. The addresses of the proxy servers that are configured on the SIP entity (IP Phone) must be the device's IP address with a different SIP local port for each one, for example:
  - Primary Proxy Server: 172.17.0.1:5060
  - Secondary Proxy Server: 172.17.0.1:5080
2. When the device receives two identical REGISTER messages from the SIP entity, it differentiates them by the SIP port on which they are received. The port allows the device to associate them with a SIP Interface (5060 for "Interface-1" and 5080 for "Interface-2").
3. The device performs SIP message manipulation (Pre-classification Manipulation) on the REGISTER messages to add a special parameter ("ac-int=<value>") to the Contact header to identify the SIP Interface on which each message is received. For example:
  - REGISTER for Primary Proxy received on SIP Interface "Interface-1":

**REGISTER**

To: &lt;sip:100@example.com&gt;

Contact: &lt;sip:100@172.17.100.20;ac-int=1&gt;

- REGISTER for Secondary Proxy received on SIP Interface "Interface-2":


**REGISTER**

To: &lt;sip:100@example.com&gt;


Contact: &lt;sip:100@172.17.100.20;ac-int=2&gt;

4. The device adds to the Contact header a special string with a unique value, "ac-feu=<value>" for each registration (e.g., "Contact: <sip:100@172.17.100.20;ac-int=1;ac-feu=x>").
5. The device saves the two contacts (100@172.17.100.20;ac-int=1;ac-feu=x and 100@172.17.100.20;ac-int=2;ac-feu=y) under the **same AOR** (100@example.com) in its user registration database.

The SIP call flow for dual registration is shown below:



The basic SIP call flow for INVITEs to and from the registered user is shown below:



➤ **To configure support for dual registration:**

1. On the SIP entity (IP Phone), configure the primary and secondary proxy server addresses as the IP address of the device and where each address has a different SIP port number.
2. Open the SBC General Settings page (**Setup** menu > **Signaling & Media** tab > **SBC** folder > **SBC General Settings**), and then from the 'Keep Original User in Register' drop-down list, select **Keep user; add unique identifier as URI parameter**.
3. In the Message Manipulations table, configure the following rules:
  - Index 0:
    - ◆ Manipulation Set ID: **1**
    - ◆ Action Subject: **header.contact.url.ac-int**
    - ◆ Action Type: **Modify**
    - ◆ Action Value: **'1'**
  - Index 1:
    - ◆ Manipulation Set ID: **2**
    - ◆ Action Subject: **header.contact.url.ac-int**
    - ◆ Action Type: **Modify**
    - ◆ Action Value: **'2'**
4. In the SIP Interfaces table, configure the following SIP Interfaces:
  - Index 0 (SIP Interface for IP Phone A):
    - ◆ Name: **Interface-1**
    - ◆ UDP Port: **5060**
    - ◆ Pre-classification Manipulation Set ID: **1**
  - Index 1 (SIP Interface for IP Phone B):
    - ◆ Name: **Interface-2**
    - ◆ UDP Port: **5080**

- ◆ Pre-classification Manipulation Set ID: **2**
5. In the Proxy Sets table, configure a Proxy Set for each proxy server (primary and secondary):
- Index 0:
    - ◆ Proxy Name: **Primary**
    - ◆ SBC IPv4 SIP Interface: **Interface-1**
    - ◆ Proxy Address: **200.10.10.1**
  - Index 1:
    - ◆ Proxy Name: **Secondary**
    - ◆ SBC IPv4 SIP Interface: **Interface-2**
    - ◆ Proxy Address: **200.10.10.2**
6. In the IP Groups table, configure the following IP Groups:
- Index 0:
    - ◆ Type: **Server**
    - ◆ Name: **Primary-Proxy**
    - ◆ Proxy Set: **Primary**
    - ◆ Classify By Proxy Set: **Enable**
  - Index 1:
    - ◆ Type: **Server**
    - ◆ Name: **Sec-Proxy**
    - ◆ Proxy Set: **Secondary**
    - ◆ Classify By Proxy Set: **Enable**
  - Index 2:
    - ◆ Type: **User**
    - ◆ Name: **IP-Phone-A**
  - Index 3:
    - ◆ Type: **User**
    - ◆ Name: **IP-Phone-B**
7. In the Classification table, configure rules to classify calls from the IP Phones based on SIP Interface:
- Index 0:
    - ◆ Source SIP Interface: **Interface-1**

- ◆ Source IP Group: **IP-Phone-A**
- Index 1:
  - ◆ Source SIP Interface: **Interface-2**
  - ◆ Source IP Group: **IP-Phone-B**
- 8. In the IP-to-IP Routing table, configure the routing rules:
  - Index 0:
    - ◆ Source IP Group: **IP-Phone-A**
    - ◆ Destination IP Group: **Primary-Proxy**
  - Index 1:
    - ◆ Source IP Group: **Primary-Proxy**
    - ◆ Destination IP Group: **IP-Phone-A**
  - Index 2:
    - ◆ Source IP Group: **IP-Phone-B**
    - ◆ Destination IP Group: **Sec-Proxy**
  - Index 3:
    - ◆ Source IP Group: **Sec-Proxy**
    - ◆ Destination IP Group: **IP-Phone-B**

## Handling Registered AORs with Same Contact URIs

The device can handle registration and call routing in cases where user registration includes AORs with the same Contact header URIs, as shown in the example below. Such a scenario typically occurs when two SIP endpoints reside in separate private networks and both are assigned the same local IP address.

### ■ User 1 Registration:

```
REGISTER sip:300@10.33.4.140;user=phone SIP/2.0
```

```
Via: SIP/2.0/UDP 10.33.2.40;branch=OTGHREPCXDBIWECOCPIK
```

```
From: <sip:300@domain1;user=phone>;tag=ULYEYCGXHXMBPSOCXVWH
```

```
To: <sip:300@domain1;user=phone>
```

```
Call-ID: XDRXGAAWNVTBFHBMQCKE@10.33.2.38
```

```
CSeq: 1 REGISTER
```

```
Contact: <sip:300@10.33.2.40>
```

■ User 2 Registration:

```
REGISTER sip:300@10.33.4.140;user=phone SIP/2.0
```

```
Via: SIP/2.0/UDP 10.33.2.40;branch=YHDWUJRMMOEIJRXVYKHD
```

```
From: <sip:300@domain2;user=phone>;tag=CVYTCHLIVMPBCGNGRTUA
```

```
To: <sip:300@domain2;user=phone>
```

```
Call-ID: INRNGFCHFHEPTRXAQNAIT@10.33.2.38
```

```
CSeq: 1 REGISTER
```

```
Contact: <sip:300@10.33.2.40>
```

For two such user registrations as shown in the example above, the device adds two AORs ("300@domain1" and "300@domain2") to its registration database, where each AOR is assigned the same Contact URI ("300@10.33.2.40"). To route a call to the correct user, the device needs to search the database for the full URI (user@host parts). To enable this support, perform the following configuration steps:

➤ **To enable handling of multiple AORs with identical Contact URIs:**

1. Open the Proxy & Registration page (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **Proxy & Registration**).
2. From the 'DB Routing Search Mode' drop-down list (SBCDBRoutingSearchMode), select **Dest URI dependant**, and then click **Apply**.


## Enabling Interworking of SIP and SIP-I Endpoints

The device can interwork between SIP and SIP-I endpoints for SBC calls. SIP-I endpoints are entities that are connected to the SS7 PSTN network, referred to as the ISDN User Part (ISUP) domain. The device supports the SIP-I Application-layer signaling protocol, which is the standard for encapsulating a complete copy of the SS7 ISUP message in SIP messages, according to ITU-T Q.1912.5, Interworking between Session Initiation Protocol (SIP) and Bearer



Independent Call Control protocol or ISDN User Part. In other words, SIP-I is SIP encapsulated with ISUP and the interworking is between SIP signaling and ISUP signaling. This allows you to deploy the device in a SIP environment where part of the call path involves the PSTN.

The SIP-I sends calls, originating from the SS7 network, to the SIP network by adding ISUP messaging in the SIP INVITE message body. The device can receive such a message from the SIP-I and remove the ISUP information before forwarding the call to the SIP endpoint. In the other direction, the device can receive a SIP INVITE message that has no ISUP information and before forwarding it to the SIP-I endpoint, create a SIP-I message by adding ISUP information in the SIP body. For SIP-I to SIP-I calls, the device can pass ISUP data transparently between the endpoints.



For the interworking process, the device maps between ISUP data (including cause codes) and SIP headers. For example, the E.164 number in the Request-URI of the outgoing SIP INVITE is mapped to the Called Party Number parameter of the IAM message, and the From header of the outgoing INVITE is mapped to the Calling Party Number parameter of the IAM message.

The ISUP data is included in SIP messages using the Multipurpose Internet Mail Extensions (MIME) body part, for example (some headers have been removed for simplicity):

```
INVITE sip:1774567@172.20.1.177;user=phone SIP/2.0
Via: SIP/2.0/UDP 172.20.73.230:5060;branch=z9hG4bK.il
```

...

```
Accept: application/sdp, application/isup, applicatio
Content-Type: multipart/mixed; boundary=unique-bounda
MIME-Version: 1.0
Content-Length: 350
```

...

```
Content-Type: application/isup; version=FTSSURI; base
Content-Disposition: signal; handling=required
01 00 40 01 0a 02 02 08 06 83 10 71 47 65 07 08
01 00 00
--unique-boundary-1--
```

```

D6 SIP-T ISUP/IAM (Initial address message)
(-- ) len:-- >> Nature of connection indicators
Oct 1 : ---0---- Echo ctrl = Half echo not included
----00-- Cont. check = Not required
-----00 Satellite = No circuit
(-- ) len:-- >> Forward call indicators
Oct 1 : 01----- ISUP pref. = Not req. all the way
--0----- ISUP indic. = Not used all the way
---0---- End-end inf = Not available
----0--- Interwork. = Not encountered
-----00- Method. ind = No method available
-----0 Call indic. = as National call
Oct 2 : -----00- SCCP method = No indication

```

ISUP data, received in the MIME body of the incoming SIP message is parsed according to the ISUP variant (SPIROU itu or ansi), indicated in the SIP Content-Type header. The device supports the following ISUP variants (configured by the 'ISUP Variant' parameter in the IP Profile table):

- French (France) specification, SPIROU (Système Pour l'Interconnexion des Réseaux OUverts), which regulates Telecommunication equipment that interconnect with networks in France. For SPIROU, the device sets the value of the SIP Content-Type header to "version=spirou; base=itu-t92+".
- ITU-92, where the device sets the value of the SIP Content-Type header to "version=itu-t92+; base=itu-t92+".

To configure interworking of SIP and SIP-I endpoints, using the IP Profile parameter 'ISUP Body Handling' (see [Configuring IP Profiles](#) on page 664).

You can manipulate ISUP data, by configuring manipulation rules for the SIP Content-Type and Content-Disposition header values, in the Message Manipulations table (see [Configuring SIP Message Manipulation](#) on page 829). For a complete description of the ISUP manipulation syntax, refer to the document *Syntax for SIP Message Manipulation Reference Guide*. In addition, you can use the AudioCodes proprietary SIP header X-AC-Action in Message Manipulation rules to support the various call actions (e.g., SIP-I SUS and RES messages) for the ISUP SPIROU variant. For more information, see [Using Proprietary SIP X-AC-Action Header](#) on page 1134.

## Configuring SBC MoH from External Media Source

The External Media Source table lets you configure an external media (audio) source (streamer). The device can play Music-on-Hold (MoH) audio originating from this external media source, to SBC call parties that are placed on hold. Implementing an external media source offers flexibility in the type of audio that you want played as MoH (e.g., radio, adverts, or music). If you are not using an external media source, the device plays its' local default hold tone or a hold tone from an installed PRT file (depending on your configuration).

When a user (A) initiates call on-hold (i.e., sends a re-INVITE with SDP 'a=sendonly' or 'a=inactive' to the device), the device sends a new re-INVITE with SDP 'a=sendonly' to place the user (B) on hold. Once the user (B) responds with a SIP 200 OK, the device forwards the RTP audio stream for MoH from the external media source to the held party. When the user (A) retrieves the call (i.e., sends a re-INVITE with SDP 'a=sendrecv') to the held user (B), which then responds with a 200 OK, the device disconnects the held party from the external media source.



- Only one external media source can be connected to the device.
- The device can play MoH from an external media source to a maximum of 20 concurrent call sessions (on-hold parties).
- If you have configured an external media source and connection between the media source and the device is established, and you then modify configuration in this table, the device disconnects from the media source and then reconnects with it.
- If the connection with the media source is lost for any reason other than reconfiguration (e.g., receives a SIP BYE from the media source or RTP broken connection occurs), the device waits three seconds before attempting to re-establish the session by sending a new INVITE to the media source. This is repeated until the media source is reconnected or you disable the feature.

The following procedure describes how to configure an external media source through the Web interface. You can also configure it through ini file [ExternalMediaSource] or CLI (`configure voip > sbc external-media-source`).

➤ **To configure an external media source:**

1. Open the External Media Source table (**Setup** menu > **Signaling & Media** tab > **SBC** folder > **External Media Source**).
2. Click **New**; the following dialog box appears:

3. Configure the external media source according to the parameters described in the table below.
4. Click **Apply**; the device sends a SIP INVITE to the external media source and when SDP negotiation (e.g., for the offered coder) is complete and the device receives a SIP 200 OK response, connection is established and audio is continuously sent by the external media source to the device.

You can refresh the connection between the device and the external media source (mainly needed if you have modified configuration). When you do this, the device disconnects from the external media source and then reconnects with a new session.

➤ **To refresh connectivity:**

- On the table's toolbar, from the **Action** drop-down list, choose **Re-establish**.

**Table 36-2: External Media Source Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row.
'IP Group' ip-group-name [IPGroupName]	Assigns an IP Group from the IP Groups table (see <a href="#">Configuring IP Groups</a> on page 581). This is the IP Group that represents the external audio streamer. <b>Note:</b> The parameter is mandatory.
'Source URI' src-uri [SourceURI]	Defines the source URI (user@host) of the SIP From header contained in the INVITE message that the device sends to the external media source. If you do not configure this parameter, the device sets the URI to the local IP address of the IP Interface on which the device sends the message.
'Destination URI' dst-uri [DestinationURI]	Defines the destination URI (user@host) of the SIP To header contained in the INVITE message that the device sends to the external media source. If you do not configure this parameter, the device sets the URI to the value of the IP Group's 'SIP Group Name' parameter.

Configuration of MoH from an external media source includes the following basic settings:


- Configuring an IP Profile (namely, the 'Extension Coders Group' parameter) and IP Group (namely, the 'IP Profile' parameter) for the media source
- Designating the media source IP Group as the external media source (in the External Media Source table, as described above)
- Configuring IP Profiles (namely, the 'Reliable Held Tone Source' and 'Play Held Tone' parameters) and IP Groups for the users

However, specific configuration may differ based on your implementation of this MoH feature. For example, you may implement this feature in one of the following architectures:

- A company with an on-site external media source for playing all MoH to branch users.

- A company with an on-site external media source that only plays MoH to branch users when connectivity with the remote media source is down

A configuration example of an on-site external media source that is always used to play MoH to its branch users is shown below and subsequently described.



1. Open the Coders Groups table (see [Configuring Coders Groups](#) on page 651), and then configure a Coders Group (e.g., AudioCodersGroups\_0) with the coder(s) to use for communication between the device and the media source.
2. Open the IP Profiles table (see [Configuring IP Profiles](#) on page 664), and then configure two IP Profiles:
  - External Media Source:
    - ◆ 'Extension Coders Group': Assign the Coders Group configured in Step 1 (above).
  - Branch Users:
    - ◆ 'Reliable Held Tone Source': **No**
    - ◆ 'Play Held Tone': **External**
3. Open the IP Groups table (see [Configuring IP Groups](#) on page 581), and then configure two IP Groups:
  - External Media Source:
    - ◆ 'IP Profile': Assign the IP Profile configured for the external media source in Step 2 (above)
  - Branch Users:
    - ◆ 'IP Profile': Assign the IP Profile configured for the branch users in Step 2 (above)
4. Open the External Media Source table (see the beginning of this section), and then configure an External Media Source entity and associate it with the IP Group that you configured for the external media source in Step 3 (above).

## Configuring Background Tones for SBC Calls

You can configure the device to play a background tone (defined in the PRT file) to the call parties in an SBC call. The tone can be played to one or both of the call parties (caller and/or callee). When played to both parties, the tone is played simultaneously. The device can play the tone after call establishment or during early media.

For playing background tones, you need to configure a Message Manipulation rule (see [Configuring SIP Message Manipulation](#) on page 829) with the following special options:

- 'Action Subject' field: `Var.Call.Dst|Src.PlayBackgroundTone` - enables background tone on the configured side (Dst) or peer side (Src)
- 'Action Value' field: `<side>,<tone ID>,<time between play>`, where:
  - `<side>` defines the call party to which the device plays the tone – **both** (caller and callee) or **single** (only on side according to `Var.Call.Dst|Src.PlayBackgroundTone`).
  - `<tone ID>` defines the user-defined tone to play, by index in the PRT file (`acUserDefineTone<ID>`). For an explanation on the PRT file, see [Uploading a Prerecorded Tones File](#) on page 1228.
  - `<time between play>` defines the duration (1 to 600,000 msec) of no tone play between each play of tone. For example, you can use this option to play a beep every 3 seconds (periodically). Alternatively, if you want the device to play the tone continuously, don't configure this option.

For example:


- The value "both,5,3000" means that the device plays the `acUserDefineTone5` tone (in the PRT file) every 3000 msec to both caller and callee.
- The value "single,5" means that the device plays the `acUserDefineTone5` tone (in the PRT file) continuously to the configured party only.



- If you want the device to play the tone only once, make sure that when you're converting the recorded tone to a file (PRT) that's loadable to the device using the DConvert utility, that you configure the 'Default' field to a non-zero value:

**Prerecorded Tones File(s)** [X]

Prerecorded Tones File(s)

Add files by dropping or using the "Add File(s)" button  Add File(s)...

Tone Type	Name	Coder
acUserDefineTone1	C:\Users\miked\Downloads\lobby-tone.raw	G711Alaw_64

**File Data** [X]

Type: acUserDefineTone1 Coder: G711Alaw\_64

Description: Background tone for Default: 3000 (msec)

- For devices in HA, the device resumes playing the tone after a switchover.
- This feature is applicable only to the SBC application.

## Call Forking

This section describes various Call Forking features supported by the device.

### Initiating SIP Call Forking

The SBC device supports call forking of an incoming call to multiple SBC users (destinations). Call forking is supported by the device's capability of registering multiple SIP client user phone contacts (mobile and fixed-line extensions) under the same Address of Record (AOR) in its registration database. This feature can be implemented in the following example scenarios:

- An enterprise Help Desk, where incoming customer calls are simultaneously sent to multiple customer service agent extensions.
- An employee's phone devices, where the incoming call is simultaneously sent to multiple devices (e.g., to the employee's office phone and mobile SIP phone).
- An enterprise reception desk, where an incoming call is simultaneously sent to multiple receptionists.

The device supports various modes of call forking. For example, in Parallel call forking mode, the device sends the INVITE message simultaneously to all the users registered under the same AOR, resulting in the ringing of all extensions; the first extension to pick up the call receives the call, and all other extensions stop ringing. The Call Forking feature is configured by creating a User-type IP Group and configuring the IP Groups table's parameter, 'SBC Client Forking Mode' (see [Configuring IP Groups](#) on page 581).

The device can also fork INVITE messages received for a Request-URI of a specific contact (user), belonging to the destination IP Group User-type, registered in the database to all other users located under the same AOR as the specific contact. This is configured by the [SBCSendInviteToAllContacts] parameter.

## Configuring SIP Forking Initiated by SIP Proxy

The device can handle the receipt of multiple SIP 18x responses as a result of SIP forking initiated by a proxy server. This occurs when the device forwards an INVITE, received from a user agent (UA), to a proxy server and the proxy server then forks the INVITE request to multiple UAs. Several UAs may answer and the device may therefore, receive several replies (responses) for the single INVITE request. Each response has a different 'tag' value in the SIP To header.

During call setup, forked SIP responses may result in a single SDP offer with two or more SDP answers. The device "hides" all the forked responses from the INVITE-initiating UA, except the first received response ("active" UA) and it forwards only subsequent requests and responses from this active UA to the INVITE-initiating UA. All requests/responses from the other UAs are handled by the device; SDP offers from these UAs are answered with an "inactive" media.

The device supports two forking modes:

- **Latch On First:** The device forwards only the first received 18x response to the INVITE-initiating UA and disregards subsequently received 18x forking responses (with or without SDP).
- **Sequential:** The device forwards all 18x responses to the INVITE-initiating UA, sequentially (one after another). If 18x arrives with an offer only, only the first offer is forwarded to the INVITE-initiating UA.

### ➤ To configure the call forking mode:

1. Open the SBC General Settings page (**Setup** menu > **Signaling & Media** tab > **SBC** folder > **SBC General Settings**).
2. From the 'Forking Handling Mode' [SBCForkingHandlingMode] drop-down list, select the required mode:

Forking Handling Mode Latch On First ▼

3. Click **Apply**.

The device also supports media synchronization for call forking. If the active UA is the first one to send the final response (e.g., 200 OK), the call is established and all other final responses are acknowledged and a BYE is sent if needed. If another UA sends the first final response, it is possible that the SDP answer that was forwarded to the INVITE-initiating UA is irrelevant and thus, media synchronization is needed between the two UAs. Media synchronization is done by sending a re-INVITE request immediately after the call is established. The re-INVITE is sent without an SDP offer to the INVITE-initiating UA. This causes the INVITE-initiating UA to send an



offer which the device forwards to the UA that confirmed the call. Media synchronization is enabled by the EnableSBCMediaSync parameter.

## Configuring Call Forking-based IP-to-IP Routing Rules

You can configure call forking routing rules in the IP-to-IP Routing table. This is done by configuring multiple routing rules under a forking group. These rules send an incoming IP call to multiple destinations of any type (e.g., IP Group or IP address). The device forks the call by sending simultaneous INVITE messages to all the specified destinations. It handles the multiple SIP dialogs until one of the calls is answered and then terminates the other SIP dialogs. For more information, see [Configuring SBC IP-to-IP Routing Rules](#) on page 1076.

## Call Survivability

This section describes various call survivability features supported by the SBC device.


### Enabling Auto-Provisioning of Subscriber-Specific Information of BroadWorks Server for Survivability

This feature enables SBC user registration for interoperability with BroadSoft BroadWorks server to provide call survivability in case of connectivity failure with the BroadWorks server, for example, due to a WAN failure. The feature enables local users to dial a local extension (or any other configured alias) that identifies another local user, in survivability mode.

In normal operation, when subscribers (such as IP phones) register with the BroadWorks server through the device, the device includes the SIP Allow-Events header in the sent REGISTER message. In response, the BroadWorks server sends the device a SIP 200 OK containing an XML body with subscriber information such as extension number, phone number, and URIs (aliases), as shown in the example below:

```
<?xml version="1.0" encoding="utf-8"?>
<BroadsoftDocument version="1.0" content="subscriberData">
  <phoneNumbers>
    <phoneNumber>2403645317</phoneNumber>
    <phoneNumber>4482541321</phoneNumber>
  </phoneNumbers>
  <aliases>
    <alias>sip:bob@broadsoft.com</alias>
    <alias>sip:rhughes@broadsoft.com</alias>
  </aliases>
  <extensions>
    <extension>5317</extension>
    <extension>1321</extension>
  </extensions>
</BroadSoftDocument>
```

The device forwards the 200 OK to the subscriber (without the XML body). The call flow is shown below:



The device saves the users in its registration database with their phone numbers and extensions, enabling future routing to these destinations during survivability mode when communication with the BroadWorks server is lost. When in survivability mode, the device routes the call to the Contact associated with the dialed phone number or extension number in the registration database.

➤ **To enable BroadWorks survivability:**

1. Open the SBC General Settings page (**Setup** menu > **Signaling & Media** tab > **SBC** folder > **SBC General Settings**).
2. Select the 'BroadWorks Survivability Feature' check box (SBCExtensionsProvisioningMode):


BroadWorks Survivability Feature ☒

3. Click **Apply**.

## Configuring BroadSoft's Shared Phone Line Call Appearance for Survivability

The device can provide redundancy for BroadSoft's Shared Call Appearance feature. When the BroadSoft application server switch (AS) fails or doesn't respond, or when there is no network connection between the device and the BroadSoft AS, the device manages the Shared Call Appearance feature for the SIP clients.

The feature is supported by configuring a primary extension and associating it with secondary extensions (i.e., *shared lines*) so that incoming calls to the primary extension also ring at the secondary extensions. The call is established with the first extension to answer the call and consequently, the ringing at the other extensions stop. For example, assume primary extension number 600 is shared with secondary extensions 601 and 602. In the case of an incoming call to 600, all three phone extensions ring simultaneously, using the device's call forking feature as described in [Configuring SIP Forking Initiated by SIP Proxy](#) on page 1160. Note that incoming calls specific to extensions 601 or 602 ring only at these specific extensions.



To configure this capability, you need to configure a shared-line, inbound manipulation rule for registration requests to change the destination number of the secondary extension numbers (e.g. 601 and 602) to the primary extension (e.g., 600). Call forking must also be enabled. The following procedure describes the main configuration required.



- The device enables outgoing calls from all equipment that share the same line simultaneously (usually only one simultaneous call is allowed per a specific shared line).
- You can configure whether REGISTER messages from secondary lines are terminated on the device or forwarded transparently (as is), using the `SBCSharedLineRegMode` parameter.
- The LED indicator of a shared line may display the wrong current state.

#### ➤ To configure BroadSoft's Shared Line feature:


1. In the IP Groups table (see [Configuring IP Groups](#) on page 581), add a Server-type IP Group for the BroadWorks server.
2. In the IP Groups table, add a User-type IP Group for the IP phone users and set the 'SBC Client Forking Mode' parameter to **Parallel** so that the device forks incoming calls to all contacts under the same AOR registered in the device's registration database.
3. In the IP-to-IP Routing table (see [Configuring SBC IP-to-IP Routing Rules](#) on page 1076), add a rule for routing calls between the above configured IP Groups.
4. In the Inbound Manipulations table (see [Configuring IP-to-IP Inbound Manipulations](#) on page 1121), add a manipulation rule for the secondary extensions (e.g., 601 and 602) so that they also register to the device's database under the primary extension contact (e.g., 600):
  - 'Manipulation Purpose': **Shared Line**
  - Match:
    - ◆ 'Request Type': **REGISTER**
    - ◆ 'Source IP Group': IP Group that you created for the users (e.g., 2)
    - ◆ 'Source Username Pattern': Represents the secondary extensions, e.g., 601 and 602

- Action:
  - ◆ 'Manipulated URI': **Source** (manipulates the source URI)
  - ◆ 'Remove From Right': 1 (removes the last digit of the extensions, e.g., 601 is changed to 60)
  - ◆ 'Suffix to Add': 0 (adds 0 to the end of the manipulated number, e.g., 60 is changed to 600)

## Configuring Call Survivability for Call Centers

The device supports call survivability for call centers. When a communication failure (e.g., in the network) occurs with the remote voice application server responsible for handling the call center application (such as IVR), the device routes the incoming calls received from the customer (i.e., from the TDM gateway) to the call center agents.

In normal operation, the device registers the agents in its users registration database. Calls received from the TDM gateway are forwarded by the device to the application server, which processes the calls and sends them to specific call center agents, through the device. Upon a failure with the application server, the device routes the calls from the TDM Gateway to the agents. The device routes the call to the first available user it finds. If the call is not answered by the user, the device routes it to the next available user. The SBC can handle a sequence of up to five users, after which the session is timed out and the call is dropped.



➤ **To configure call survivability for a call center application:**

1. In the IP Groups table (see [Configuring IP Groups](#) on page 581), add IP Groups for the following entities:
  - TDM Gateway (Server-type IP Group). This entity forwards the customer calls through the device to the Application server.
  - Application server (Server-type IP Group). This entity processes the call and sends the call through the device to the specific call center agent located on a different network (remote).
  - Call center agents (User-type IP Group). You can configure multiple IP Groups to represent different groups of call center agents, for example, agents and managers.
2. In the Classification table (see [Configuring Classification Rules](#) on page 1061), add rules to classify incoming calls that are received from the entities listed in Step 1, to IP Groups.
3. In the SBC IP-to-IP Routing table (see [Configuring SBC IP-to-IP Routing Rules](#) on page 1076), add the following IP-to-IP routing rules:
  - For normal operation:
    - ◆ Routing from TDM Gateway to Application server.
    - ◆ Routing from Application server to call center agents.
  - For call survivability mode: Routing from TDM Gateway to call center agents. This configuration is unique due to the following settings:
    - ◆ The 'Source IP Group' field is set to the IP Group of the TDM Gateway.
    - ◆ The 'Destination Type' field is set to **Hunt Group**, which is specifically used for call center survivability.
    - ◆ The 'Destination IP Group' field is set to the IP Group of the call center agents.

The figure below displays a routing rule example, assuming IP Group #1 represents the TDM Gateway and IP Group #3 represents the call center agents:

**IP-to-IP Routing**

**GENERAL**

Index: 3

Name: TDM GW > Call Center

Alternative Route Options: Route Row

**MATCH**

Source IP Group: #1 [TDM Gateway] View

Request Type: All

Source Username Prefix: \*

Source Host: \*

Source Tags:

Destination Username Prefix: \*

Destination Host: \*

**ACTION**

Destination Type: Hunt Group

Destination IP Group: #3 [Call Center] View

Destination SIP Interface: -- View

Destination Address:

Destination Port: 0

Destination Transport Type:

Call Setup Rules Set ID: -1

Group Policy: None

Cost Group: -- View

## Enabling Survivability Display on Aastra IP Phones

If the SBC device is deployed in a network with Aastra IP phones and connectivity with the WAN fails, the device provides call survivability by enabling communication between IP phone users within the LAN enterprise. In such a scenario, the device can be configured to notify the IP phones that it is currently operating in Survivability mode. When this occurs, the Aastra IP phones display the message, "Stand Alone Mode" on their LCD screens.

If you enable the feature and the device is in Survivability mode, it responds to SIP REGISTER messages from the IP phones with a SIP 200 OK containing the following XML body:

```
Content-Type: application/xml
<?xml version="1.0" encoding="utf-8"?>
<LMIDocument version="1.0">
  <LocalModeStatus>
    <LocalModeActive>true</LocalModeActive>
    <LocalModeDisplay>StandAlone Mode</LocalModeDisplay>
  </LocalModeStatus>
</LMIDocument>
```

### ➤ To enable survivability display on Aastra phones:

1. Upload an ini file to the device that includes the following parameter setting:

```
SBCEnableSurvivabilityNotice = 1
```

## Alternative Routing upon Detection of Failed SIP Response

The device can detect failure of a sent SIP response (e.g., TCP timeout, and UDP ICMP). In such a scenario, the device re-sends the response to an alternative destination. This support is in addition to alternative routing if the device detects failed SIP requests.

For example, assume the device sends a SIP 200 OK in response to a received INVITE request. If the device doesn't receive a SIP ACK in response to this, it sends a new 200 OK to the next alternative destination. This new destination can be the next given IP address resolved from a DNS from the Contact or Record-Route header in the request related to the response.

## Configuring Push Notification Service

The device supports the Push Notification Service per IETF draft "[Push Notification with the Session Initiation Protocol \(SIP\)](#)". This service is used to wake end-user equipment (typically, mobile platforms) and operating systems that have gone to "sleep" (to save resources such as battery life) so that they can receive traffic. Typically, each operating system uses a dedicated Push Notification Service. For example, Apple iOS devices use the Apple Push Notification service (APNs) while Android devices use the Firebase Cloud Messaging (FCM) service. Without using a Push Notification Service to wake SIP User Agents (UAs), UAs wouldn't be able to send binding-refresh SIP REGISTER requests, receive SIP requests (e.g., INVITE), or send periodic keep-alive messages for maintaining connectivity with SIP servers. The device communicates with third-party, HTTP-based Push Notification Servers over HTTP, using RESTful APIs for exchanging information (currently, only JSON format is supported).



The Push Notification Service feature is applicable only to the SBC application.

SIP users wanting to receive push notifications must specify the following parameters in the Contact header of the SIP REGISTER request that it sends to the device for registration:

- 'pn-provider': Specifies the type of Push Notification Service.
- 'pn-prid': Specifies the unique identifier (Push Resource ID / PRID) that the Push Notification Service uses to identify the user.
- 'pn-param': (Optional) Specifies additional implementation-specific data required by the Push Notification Service.

Below shows an example of a REGISTER message containing the Push Notification parameters (in bold):


```
REGISTER sip:alice@example.com SIP/2.0
Via: SIP/2.0/TCP alicemobile.example.com:5060;branch=z9hG4bKnashds7
Max-Forwards: 70
To: Alice <sip:alice@example.com>
From: Alice <sip:alice@example.com>;tag=456248
Call-ID: 843817637684230@998sdasdh09
```

```

CSeq: 1826 REGISTER
Contact: <sip:alice@alicemobile.example.com;
pn-provider=acme;
pn-param=acme-param;
pn-prid=ZTY4ZDJIMzODE1NmUgKi0K>
Expires: 7200
Content-Length: 0

```

The device handles registrations from users requiring Push Notification Service, as follows:




1. The user sends a REGISTER request to the device that contains the Push Notification parameters in the Contact header, as mentioned previously.
2. The device searches its Push Notification Servers table for a row whose 'Provider' parameter has the \* wildcard character value, or the same value as the 'pn-provider' parameter in the REGISTER request.
3. Regardless of the search, the device adds the user in its registration database with the Push Notification parameters (mentioned previously).
4. If a matching row in the Push Notification Servers table is located, the device sends a SIP 200 OK response containing the Feature-Caps header with the 'sip.pns=' feature-capability indicator, identifying the type of Push Notification Service as specified in the 'pn-provider' parameter (e.g., Feature-Caps: \*;**+sip.pns="acme"**;**+sip.pnsreg="121"**). If no matching row in the table is located (i.e., Push Notification Service is not supported), the device sends a 200 OK response, but without the Feature-Caps header.
5. (6 and 7) At a user-defined time (using the [PNSReminderPeriod] parameter) before the user's registration expires, the device sends a push notification request containing the user's PRID to the Push Notification Server to trigger it into sending a push notification to the user to remind it to send a refresh REGISTER message to the device.

If the user sends the device a refresh REGISTER request without the Push Notification parameters, the device considers the user as no longer using Push Notification Service. In this



scenario, the device stops sending push notification requests to the Push Notification Server for the user.

Once a user is registered with the device, the device can route calls to it. The following figure shows how the device processes an incoming dialog-initiating SIP request (e.g., INVITE) whose destination is a mobile user that uses Push Notification Service:



6. The device receives an incoming call (SIP INVITE message) for the mobile user, which according to the device's registration database (i.e., user's registration includes Push Notification parameters), uses a Push Notification Service.
7. The device sends a push notification request containing the user's PRID (over HTTP) to the Push Notification Server. The device uses the Push Notification Servers table to determine which Push Notification Server to send this push notification request. The device searches the table for a row that is configured with the value of the user's 'pn-provider' parameter (table's 'Provider' parameter) and if located, sends the push notification request to the address of the associated Remote Web Service.
8. The Push Notification Server sends a push notification to the user to "wake" it up.
9. The user sends a refresh SIP REGISTER message to the device, which indicates that the user is "awake" and ready to receive the call.
10. The device sends the INVITE message to the user, using its regular routing logic.



- If the push notification request that is sent to the Push Notification Server fails, the device rejects the INVITE message with a SIP 480 response.
- If the device doesn't receive a refresh REGISTER message within a user-defined time (configured by the [PNSRegisterTimeout] parameter), the device rejects the INVITE with a SIP 480 response.
- When the device receives an incoming INVITE message for a user who is registered for push notification, but the corresponding row in the Push Notification Servers table has been deleted, the device immediately forwards the INVITE message to the user (as though the user had not requested push notification service).

➤ **To configure Push Notification Service:**

1. Configure a Remote Web Service (see [Configuring Remote Web Services](#) on page 429) to represent the HTTP-based Push Notification Server (address and other required parameters). You must configure the Remote Web Service with the 'Type' parameter set to **General**.
2. Configure the Push Notification service in the Push Notification Servers table (see [Configuring Push Notification Servers](#) on page 826). This table configures the Push Notification Service type, the Remote Web Service that you configured in Step 1, and the information-exchange protocol (currently, only JSON) used between the device and the server. Therefore, the device uses this table to determine which Push Notification Server to send push notification requests for a specific user. The device searches the table for a row that is configured with the value of the user's 'pn-provider' parameter (table's 'Provider' parameter) and if located, sends the push notification request to the Push Notification Server using the address of the associated Remote Web Service.
3. Configure the time (in seconds) before the user's registration on the device expires, when the device sends a push notification request (over HTTP) to the Push Notification Server to trigger it into sending a push notification to the user to remind it to send a refresh REGISTER message to the device. This is configured by the [PNSReminderPeriod] parameter or CLI command `configure voip > sbc settings > pns-reminder-period`.
4. Configure the time (in seconds) that the device must wait for a refresh REGISTER message from the user after the device sends a push notification request to the Push Notification Server for the user, when the device receives an incoming SIP dialog-initiating request (e.g., INVITE) that it must send to the user. This is configured by the [PNSRegisterTimeout] parameter or CLI command `configure voip > sbc settings > pns-register-timeout`.

## Configuring Maximum SBC Call Duration

You can configure the maximum allowed call duration (in minutes) for SBC calls. If an established call reaches this user-defined limit, the device ends the call. The feature ensures that calls are properly terminated, allowing available resources for new calls.

The following procedure describes how to configure the feature for all SBC calls (globally).

➤ **To configure maximum call duration:**

1. Open the SBC General Settings page (**Setup** menu > **Signaling & Media** tab > **SBC** folder > **SBC General Settings**).
2. In the 'Max Call Duration' field [SBCMaxCallDuration], enter the maximum call duration for an SBC call:

Max Call Duration [min]

### 3. Click **Apply**.



Instead of configuring a global maximum call duration for all SBC calls as described in this section, you can configure maximum call duration for specific calls, using any of the following configuration methods:

- Using the IP Profile parameter 'Max Call Duration' (see [Configuring IP Profiles](#) on page 664). This parameter overrides the global parameter.
- Using Message Manipulation rules with call variables `Var.Call.Dst.MaxDuration` or `Var.Call.Src.MaxDuration`. You then need to assign the Manipulation Set ID of the rule(s) to the desired IP Group, using the 'Inbound Message Manipulation Set' or 'Outbound Message Manipulation Set' parameters. This call duration overrides all other parameters that configure maximum call duration. For more information on this call variable, refer to the *SIP Message Manipulation Syntax Reference Guide*, by clicking [here](#).

## Configuring Maximum Concurrent Calls per Specific User

You can configure a different maximum concurrent call limit (incoming or outgoing) for each user. This is done using tags in Call Setup Rules and Dial Plans, which are assigned to the relevant SIP Interface, IP Group, or IP-to-IP Routing rule.

This feature uses the device's hardcoded tag called `cac`. This tag has the format *key/value*, where *key* identifies the call (SIP URL user-part or IP address) and *value* defines maximum concurrent call. For example, 'cac=+12345678|3' (or 'cac=10.4.4.4|3') limits the user (or IP address) with phone number +12345678 (or IP address 10.4.4.4) to a maximum of three concurrent calls.

The following procedure describes how to configure maximum concurrent incoming calls for each specific users.

### ➤ To configure maximum concurrent calls for each user:

1. Configure a Dial Plan with multiple rules, where each rule defines a user by prefix number, and the maximum concurrent calls value by any user-defined tag. For example:
  - 'Name': MyMaxCall
  - 'Prefix': +123
  - 'Tag': cacMax=3
2. Configure a Call Setup Rule to check the existence and value of your Dial Plan tag. For example:
  - 'Condition': SrcTags.cacMax exists And SrcTags.cac !exists
  - 'Action Subject': SrcTags.cac
  - 'Action Type': Modify
  - 'Action Value': Header.From.URL.User + '|' + SrcTags.cacMax

3. Assign the Dial Plan and Call Setup Rule to the relevant SIP Interface, IP Group, or IP-to-IP Routing rule.

If you want all users to have the **same** maximum concurrent calls, you only need to use a Call Setup Rule. For example, the below applies a maximum concurrent incoming call value of 3 to every user (defined by SIP user-part or IP address):

- 'Action Subject': SrcTags.cac
- 'Action Type': Modify
- 'Action Value': (one of following)
  - Per IP address: Param.Message.Address.Src.IP + '|3'
  - Per user: Header.From.Url.User + '|3'

To view a list of 'cac' keys with their current concurrent calls out of their maximum allowed concurrent calls, use the following CLI command:

```
show voip tags-cac
```

To view the above output for a specific user, use the following command:

```
show voip tags-cac key <SIP user part or IP Address>
```

If the maximum number of concurrent calls is reached, the device rejects new calls and sends the following syslog message:

- For incoming calls: "RELEASE\_BECAUSE\_IN\_PER\_KEY\_CAC\_LIMIT\_REACHED"
- for outgoing calls: "RELEASE\_BECAUSE\_OUT\_PER\_KEY\_CAC\_LIMIT\_REACHED"



- This section is applicable only to the SBC application.
- You can also configure maximum concurrent calls using the following configuration entities, but different limits per user can't configured:
  - ✓ Call Admission Control Profiles (configured in the Call Admission Control Profile table see [Configuring Call Admission Control](#) on page 1054) - applies the same limit to all users associated with the specific Call Admission Control Profile.
  - ✓ IP Profiles (see the 'Number of Calls Limit' parameter in [Configuring IP Profiles](#) on page 664) - applies the same limit to the entire IP Group to which the IP Profile is assigned.

## Playing Tone upon Call Connect

You can configure the device to play a specific tone (recorded audio message / announcement) from a loaded PRT file upon call connection (after SIP 200 OK). The tone can be played to both

called and calling parties. When the device finishes playing the tone, the call is connected and the call parties can begin talking.

This feature is configured using a Message Manipulation rule that contains the variable `var.call.src|dst.PlayToneOnConnect`, which specifies the recorded tone to play from the PRT file. The rule is then assigned to the call party (IP Group) to which you want the device to play the tone.

If the device fails to play the tone for whatever reason (for example, the PRT file is not loaded or the specified tone index doesn't exist in the file), you can configure the device to connect or disconnect the call.



This section is applicable only to the SBC application.

#### ➤ To configure play of tone upon call connect:

1. Record your tone (.wav file) and convert it to a loadable PRT file, using AudioCodes DConvert utility (see [Call Progress Tones File](#) on page 1224). The tone must be defined in DConvert as an **acUserDefineTone<Index>** tone type (e.g., **acUserDefineTone50**).
2. Upload the PRT file to the device (see [Uploading Auxiliary Files](#) on page 1220).
3. In the Message Manipulations table (see [Configuring SIP Message Manipulation](#) on page 829), configure a rule to specify the tone (index) you recorded in Step 1 and the call party (source or destination) you want it played to. Below is an example for configuring the device to play the tone to call source and destination:
  - 'Index': 0 (plays to called party)
    - ◆ 'Manipulation Set ID': **1**
    - ◆ 'Message Type': **invite.request**
    - ◆ 'Condition': **Header.From contains '100'**
    - ◆ 'Action Subject': **var.call.dst.PlayToneOnConnect**
    - ◆ 'Action Type': **Add**
    - ◆ 'Action Value': **'50'**
  - 'Index': 1 (plays to calling party)
    - ◆ 'Manipulation Set ID': **1**
    - ◆ 'Message Type': **invite.request**
    - ◆ 'Condition': **Header.From contains '100'**
    - ◆ 'Action Subject': **var.call.src.PlayToneOnConnect**
    - ◆ 'Action Type': **Add**
    - ◆ 'Action Value': **'50'**

4. In the IP Groups table, assign the Manipulation Set ID that you configured in Step 3 to the relevant IP Group (see [Configuring IP Groups](#) on page 581).
5. Configure what the device should do if it can't play the tone:
  - a. Open the SBC General Settings page (**Setup** menu > **Signaling & Media** tab > **SBC** folder > **SBC General Settings**).
  - b. From the 'Play Tone on Connect Failure Behavior' drop-down list, select one of the following:
    - ◆ **Disconnect** - disconnects the call
    - ◆ **Ignore** - connects the call

Play Tone on Connect Failure Behavior

Disconnect ▼


# Part VII

## High-Availability System

## 37 Overview of High Availability Mode

The device's High Availability (HA) feature provides 1+1 system redundancy using two devices. If failure occurs in the active device, a switchover occurs to the redundant device which takes over the call handling process. Thus the continuity of call services is ensured. All active calls (signaling and media) are maintained upon switchover.

The figure below illustrates the Active-Redundant HA devices under normal operation. Communication between the two devices is through a Maintenance interface, having a unique IP address for each device. The devices have identical software and configuration including network interfaces (i.e., OAMP, Control, and Media), and have identical local-port cabling of these interfaces.



### Connectivity and Synchronization between Devices

In HA mode, the Ethernet connectivity between the two devices is through a special LAN interface on each device, referred to as the *Maintenance* interface. Each device has its own Maintenance interface with a unique address, and each device knows the Maintenance address of the other. The Maintenance interface can use a dedicated Ethernet port group or share the same Ethernet port group with the other network interface types (i.e., OAMP, Media, and Control).

When only one of the devices is operational it is in HA stand-alone state. This means that the device has no connectivity to the second device. When the second device is powered up, it recognizes the active device through the Maintenance network and acquires the HA redundant state. It then begins synchronizing for HA with the active device through the Maintenance network. During synchronization, the active device sends the redundant device its current



configuration settings, including Auxiliary files. The active device also sends its software file (.cmp) if the redundant device is running a different software version. Once loaded to the redundant device, the redundant device reboots to apply the new configuration and/or software. This ensures that the two units are synchronized regarding configuration and software.

Thus, under normal operation, one of the devices is in active state while the other is in redundant state, where both devices share the same configuration and software. Any subsequent configuration update or software upgrade on the active device is also done on the redundant device.

In the active device, all logical interfaces (i.e., Media, Control, OAMP, and Maintenance) are active. In the redundant device, only the Maintenance interface is active, which is used for connectivity to the active device. Therefore, management is done only through the active device. Upon a failure in the active device, the redundant device becomes active and activates all its logical interfaces exactly as was used on the active device.



- If the active device runs an earlier version (e.g., 7.0) than the redundant device (e.g., 7.2), the redundant device is downgraded to the same version as the active device (e.g., 7.0).
- You can delay the transition from HA non-operational state, which occurs during HA synchronization between the active and redundant device, to HA operational state. This is configured by the [HAOperationalStateDelayInSec] parameter. This may be useful, for example, to delay HA switchover when using switches with spanning tree protocol (STP) that take a long time until their ports (to which the redundant device is connected) is ready.

## Device Switchover upon Failure

When a failure occurs in the active device, a switchover occurs to the redundant device making it the new active device. Whether a switchover is later done back to the repaired failed device, depends on whether you have enabled the Preempt mode:

- **Enabled:** The Preempt mode specifies one of the device's as the "preferred" device. This is done by assigning different priority levels (1 to 10, where 1 is the lowest) to the two devices. Typically, you would configure the active device with a higher priority level (number) than the redundant device. The only factor that influences the configuration is which device has the greater number; the actual number is not important. For example, configuring the active with 5 and redundant with 4, or active with 9 and redundant with 2 both assign highest priority to the active device. Whenever the device with higher priority recovers from a failure, it first becomes the redundant device but then initiates a switchover to become the active device once again; otherwise, after recovery, it becomes the redundant device and remains as redundant. If you change the priority level of the redundant device to one that is higher than the active device and then restart the redundant device, a switchover occurs to the redundant device making it the active device and the "preferred" device. If both devices are configured with the same priority level, Preempt mode is disabled. Please see note below when using priority level 10.

- **Disabled:** A switchover is done only upon failure of the currently active device.

Failure detection by the devices is done by the constant keep-alive messages they send between themselves to verify connectivity. Upon detection of a failure in one of the devices, the following occurs:

- **Failure in active device:** The redundant device initiates a switchover. The failed device restarts and the previously redundant device becomes the active device in stand-alone mode. If at a later stage this newly active device detects that the failed device has been repaired, the system returns to HA mode. If Preempt mode is enabled and the originally active device was configured with a higher priority, a switchover occurs to this device; otherwise, if it was configured with a lower priority (or Preempt mode was disabled), the repaired device is initialized as the redundant device.
- **Failure in redundant device:** The active device moves itself into stand-alone mode until the redundant device is returned to operation. If the failure in the redundant device is repaired after restart, it's initialized as the redundant device once again and the system returns to HA mode.

Connectivity failure triggering a switchover can include, for example, one of the following:


- **Loss of physical (link) connectivity:** If one or more physical network groups (i.e., Ethernet port pair) used for one or more network interfaces of the active device disconnects (i.e., no link) and these physical network groups are connected OK on the redundant device, a switchover occurs to the redundant device.
- **Loss of network (logical) connectivity:** No network connectivity, verified by keep-alive packets between the devices. This applies only to the Maintenance interface.



- Switchover triggered by loss of physical connectivity in one or more Ethernet Group is not done if the active device has been configured to a Preempt mode level of 10. In such a scenario, the device remains active.
- After HA switchover, the active device updates other hosts in the network about the new mapping of its Layer-2 hardware address to the global IP address, by sending a broadcast gratuitous Address Resolution Protocol (ARP) message.

## Viewing HA Status on Monitor Web Page

You can view the status of the HA system on the Monitor page of the device's Web interface. The page provides a graphical display of both active and redundant devices, as shown below:



You can distinguish between active and redundant devices as follows:

- **Active device:**

- Color of border surrounding device is green.
- Title above device is "Active Device". The default name is "Device 1".

#### ■ Redundant device:

- Color of border surrounding device is blue.
- Title above device is "Redundant Device". The default name is "Device 2".

The Monitor page also displays the HA operational status of the device to which you are currently logged in. This is displayed in the 'HA Status' field under the Device Information pane:

■ "Synchronizing": Redundant device is synchronizing with Active device

■ "Operational": The device is in HA mode

■ "Stand Alone": HA is configured, but the Redundant device is missing and HA is currently unavailable

To view active alarms raised by the Active and Redundant devices, click the **Alarms** area to open the Active Alarms page (see [Viewing Active Alarms](#) on page 1323).



- The trunk status icons of the redundant device on the Monitor page are not operational (i.e., displayed in gray color).
- When the redundant device's trunks are connected to the remote side (e.g., PBX), they are synchronized on the physical E1/T1 layer, but without D-channel synchronization (not in service) and a D-channel alarm will be sent for the remote side.

You can change the name of each device, as described in the following procedure:

#### ➤ To define a name for the device:

1. Open the HA Settings page (**Setup** menu > **IP Network** tab > **Core Entities** folder > **HA Settings**).
2. In the 'HA Device Name' field, enter a name for the active device.

HA Device Name

• 84

3. In the 'HA Remote Device Name' field, enter a name for the redundant device.

HA Remote Device Name

• 86

4. Click **Apply**.



- Once the devices are running in HA mode, you can change the name of the redundant device through the active device only, in the 'HA Remote Device Name' field.
- When the device sends alarms to OVOC, the name is displayed at the beginning of the alarm description in OVOC, for example, "(SBCSITE01): Proxy lost. looking for another proxy". However, the name is not displayed when OVOC **initially** connects to the device and retrieves the alarms (from the device's Active Alarms table).

## 38 HA Configuration

This section describes HA configuration.

### Prerequisites for HA

The following lists the prerequisites for the HA feature:

- The HA feature is available only if both devices participating in the HA system are installed with a License Key that includes this feature. For installing a License Key, see [License Key](#) on page 1233.
- The physical connections of the first and second devices to the network (i.e., Maintenance interface and OAMP, Control and Media interfaces) **must be identical**. This also means that the two devices must use the same Ethernet Groups and the port numbers belonging to these Ethernet Groups. For example, if the first device uses Ethernet Group 1 (with ports 1 and 2), the second device must also use Ethernet Group 1 (with ports 1 and 2).
- Each network interface of the first device must be connected to the same broadcast domain as the identical network interface on the second device. For example, both Management interfaces must be connected to the same broadcast domain, and so on.
- Before configuring HA, determine the required network topology, as described in [Network Topology Types and Rx/Tx Ethernet Port Group Settings](#) below.
- Maintenance interfaces restrictions:
  - The Maintenance interface on each device must be configured (each with a different IP address).
  - The maximum delay allowed between the Maintenance interfaces of both devices is 50 ms.
  - The Maintenance interface should be able to perform a fast switchover in case of link failure. Therefore, Spanning Tree Protocol (STP) should not be used in this network. The Ethernet connectivity of the Maintenance interface between the two devices should be constantly reliable without any disturbances.

### Initial HA Configuration

By default, HA is disabled on the device. When a device is loaded with valid HA configuration and is the first device to be loaded, it becomes the active device. The second device that is loaded with HA configuration becomes the redundant (standby) device.

### Network Topology Types and Rx/Tx Ethernet Port Group Settings

Initial HA configuration depends on how you want to deploy your HA system in the network. The Maintenance interface, which is used for the HA link between Active and Redundant units, can use a dedicated Ethernet Device and Ethernet Group, or share the same Ethernet Device

and Ethernet Group with other IP network interface types (such as OAMP, Media and Control). However, it is recommended that you configure the Maintenance interface with a dedicated Ethernet Device and Ethernet Group (port) to separate it from other IP network interfaces

If you want to separate the Maintenance interface from other interfaces, the separation must also be done externally to the units, either physically (different physical networks) or logically (using VLANs). When using VLANs, make sure that you use a different Ethernet Device for each IP network interface (see [Configuring Underlying Ethernet Devices](#) on page 154 and [Configuring IP Network Interfaces](#) on page 157).




- The Maintenance interface is used for heartbeats and data transfer from active to standby device and therefore, any short interval interruption in communication may cause undesired switchovers.
- If you assign the same Underlying Ethernet Device to all the IP network interfaces, logical separation of traffic may not occur.


The Maintenance interface can employ Ethernet port redundancy (recommended), by using two ports. This is enabled by configuring the Ethernet Group associated with the Maintenance interface with two ports.

The required receive (Rx) and transmit (TX) mode for the port pair in the Ethernet Group used by the Maintenance interface is as follows:


- (Recommended Physical Connectivity) If the Maintenance ports of both devices are connected directly to each other without intermediation of switches, configure the mode to **2RX/1TX**:



- If the two devices are connected through two (or more) isolated LAN switches (i.e., packets from one switch cannot traverse the second switch), configure the mode to **2RX/2TX**:



- For Geographical HA (both units are located far from each other), **2Rx/1Tx** port mode connected to a port aggregation switch is the recommended option:



- When two LAN switches are used, the LAN switches must be in the same subnet (i.e., broadcast domain).
- Don't use port mode **REDUN\_1RX\_1TX** for the Maintenance interface where the Ethernet cables are connected back to back between the two devices (as both sides may choose different ports, resulting in disconnected traffic).
- To configure Rx/Tx modes of the Ethernet ports, see [Configuring Ethernet Port Groups](#) on page 151

## Configuring the HA Devices

To initially configure the two devices comprising the HA system:

1. Configure the first device for HA (see [Step 1: Configure the First Device](#) below)
2. Configure the second device for HA (see [Step 2: Configure the Second Device](#) on page 1185)
3. Activate HA on the devices (see [Step 3: Initialize HA on the Devices](#) on page 1186)

### Step 1: Configure the First Device

The first stage is to configure the first device for HA.



During this stage, make sure that the second device is powered off or disconnected from the network.

#### ➤ To configure the first device for HA:

1. Configure the network interfaces, including the default OAMP interface:
  - a. Connect your PC to the device using a local, direct physical cable connection and then access the Web interface using the default OAMP network address. For more information on initial access, see [Configuring OAMP Interface](#) on page 13.
  - b. Open the IP Interfaces table (see [Configuring IP Network Interfaces](#) on page 157).
  - c. Change the default OAMP network settings to suit your networking scheme.

- d. Configure the Control and Media network interfaces, as required.
- e. Add the HA Maintenance interface (i.e., the **MAINTENANCE** Application Type).



Make sure that the Maintenance interface uses an Ethernet Device and Ethernet Group that is **not** used by any other IP network interface. The Ethernet Group is associated with the Ethernet Device, which is assigned to the interface.

The IP Interfaces table below shows an example where the Maintenance interface is configured with Ethernet Device "vlan 2" (which is associated with Ethernet Group "GROUP\_2"), while the other interface is assigned "vlan 1" (associated with Ethernet Group "GROUP\_1"):

INDEX	NAME	APPLICATION TYPE	INTERFACE MODE	IP ADDRESS	PREFIX LENGTH	DEFAULT GATEWAY	PRIMARY DNS	SECONDARY DNS	ETHERNET DEVICE
0	Voice	OAMP + Media	IPv4 Manual	10.8.40.47	16	10.8.0.1	0.0.0.0	0.0.0.0	vlan 1
1	maint	MAINTENANCE	IPv4 Manual	10.3.0.11	16	10.3.0.1	0.0.0.0	0.0.0.0	vlan 2

2. If the connection is through a switch, the packets of both interfaces should generally be untagged. To do this, open the Ethernet Devices table (see [Configuring Underlying Ethernet Devices](#) on page 154 ), and then configure the 'Tagging' parameter to **Untagged** for the Ethernet Device assigned to the Maintenance interface. The figure below shows an example (highlighted) where VLAN 2 is configured as the Native (untagged) VLAN ID of the Ethernet Group "GROUP\_2":

INDEX	VLAN ID	UNDERLYING INTERFACE	NAME	TAGGING
0	1	GROUP_1	vlan 1	Untagged
1	2	GROUP_2	vlan 2	Untagged


3. Set the Ethernet port Tx / Rx mode of the Ethernet Group used by the Maintenance interface (see [Configuring Ethernet Port Groups](#) on page 151). The port mode depends on the type of Maintenance connection between the devices, as described in [Network Topology Types and Rx/Tx Ethernet Port Group Settings](#) on page 1181.
4. Configure HA parameters:
  - a. Open the HA Settings page (**Setup** menu > **IP Network** tab > **Core Entities** folder > **HA Settings**):



**HIGH AVAILABILITY**

HA Remote Address

• 10.3.4.61



Preempt Mode

• ☒

Preempt Priority

5

HA Device Name

• Device 1

HA Remote Preempt Priority

• 4

HA Remote Device Name

• Device 2

- b. In the 'HA Remote Address' field, enter the Maintenance IP address of the **second** device.
  - c. (Optional) Enable the HA Preempt feature, by selecting the 'Preempt Mode' check box, and then setting the priority level of the device in the 'Preempt Priority' field. Make sure that you configure different priority levels for the two devices. Typically, you would configure the active device with a higher priority level (number) than the redundant device. The only factor that influences the configuration is which device has the greater number; the actual number is not important. For example, configuring the active with 5 and redundant with 4, or active with 9 and redundant with 2 both assign highest priority to the active device. Configuring the level to 10 doesn't cause a switchover upon Ethernet connectivity loss. For more information on the feature, see [Device Switchover upon Failure](#) on page 1177.
5. Click **Apply**, and then save configuration to flash **without** a restart.
6. Power down the device.
7. Configure the second device (see [Step 2: Configure the Second Device](#) below).

## Step 2: Configure the Second Device

Once you have configured the first device for HA, you can configure the second device for HA. As the configuration of the second device is similar to the first device, the following procedure briefly describes each step. For detailed configuration such as the path to the Web configuration pages, refer to the section on configuring the first device ([Step 1: Configure the First Device](#) on page 1183).



During this stage, ensure that the first device is powered off or disconnected from the network.

➤ To configure the second device for HA:

1. Connect to the device in the same way as you did with the first device.

2. Configure the **same** OAMP, Media, and Control interfaces as configured for the first device.
3. Configure a Maintenance interface for this device. The IP address must be different to that configured for the Maintenance interface of the first device. The Maintenance interfaces of the devices must be in the same subnet.
4. Configure the **same** Ethernet Groups and VLAN IDs of the network interfaces as configured for the first device.
5. Configure the **same** Ethernet port Tx / Rx mode of the Ethernet Group used by the Maintenance interface as configured for the first device.
6. Configure HA parameters in the HA Settings page:
  - a. In the 'HA Remote Address' field, enter the Maintenance IP address of the **first** device.
  - b. (Optional) Enable the HA Preempt feature by selecting the 'Preempt Mode' check box, and then setting the priority level of the device in the 'Preempt Priority' field. Make sure that you configure different priority levels for the two devices. Typically, you would configure the active device with a higher priority level (number) than the redundant device. The only factor that influences the configuration is which device has the greater number; the actual number is not important. For example, configuring the active with 5 and redundant with 4, or active with 9 and redundant with 2 both assign highest priority to the active device. Configuring the level to 10 doesn't cause a switchover upon Ethernet connectivity loss. For more information on the HA Preempt feature, see [Device Switchover upon Failure](#) on page 1177.
7. Click **Apply**, and then save configuration to flash **without** a restart.
8. Power down the device.
9. Continue to [Step 3: Initialize HA on the Devices](#) below.

### Step 3: Initialize HA on the Devices

Once you have configured both devices for HA as described in the previous sections, follow the procedure below to complete and initialize HA so that the devices become operational in HA. This last stage applies to both devices.

#### ➤ To initialize the devices for HA:

1. Cable the devices to the network.



You must connect both ports (two) in the Ethernet Group of the Maintenance interface to the network (i.e., two network cables are used). This provides 1+1 Maintenance port redundancy.

2. Power up the devices; the redundant device synchronizes with the active device and updates its configuration according to the active device. The synchronization status is indicated as follows:

- Active device: The Web interface's Monitor page displays "Synchronizing" in the 'HA Status' field.

When synchronization completes, the redundant device restarts to apply the received configuration and software.

When both devices become operational in HA, the HA status is indicated as follows:

- Both devices: The Web interface's Monitor page displays "Operational" in the 'HA Status' field.
  - Active device: The **Status** LED is lit green - slow-flash, steady on, and then slow flash.
  - Redundant device: The **Status** LED is lit green - slow-fast flash.
3. Access the active device with its' OAMP IP address and configure the device as required. For information on configuration done after HA is operational, see [Configuration while HA is Operational](#) on the next page.

## Quick-and-Easy Initial HA Configuration

You can quickly set up two stand-alone devices into an HA system, by loading the same ini configuration file with special parameters to each device. This ini file contains basic configuration that identifies the devices by MAC address and applies the configuration accordingly.

### ➤ To quickly set up two devices for HA:

1. Make sure that the License Key installed on both devices includes the HA license (see [Viewing the License Key](#) on page 1233).
2. Obtain the MAC address of each device. The MAC address is displayed on the Device Information page (see [Viewing Device Information](#) on page 1312).
3. Prepare a single ini file with the following configuration:
  - Parameters relating to the first device ("local"):
    - ◆ HALocalMAC - specifies the MAC address
    - ◆ (Optional) HAUunitIdName - defines a descriptive name
    - ◆ (Optional) HArevertiveEnabled - enables the HA Preempt feature
    - ◆ (Optional) HAPriority - defines the priority of the device if the HA Preempt feature is enabled
  - Parameters relating to the second device ("remote"):
    - ◆ HARemoteMAC - specifies the MAC address
    - ◆ HARemoteAddress - defines the HA Maintenance interface address
    - ◆ (Optional) HARemoteUnitIdName - defines a descriptive name

- ◆ (Optional) HARemotePriority - defines the priority of the device if the HA Preempt feature is enabled
- InterfaceTable - defines the IP Interfaces table with two network interfaces for the following Application Types:
  - ◆ OAMP + Media + Control: This is the same for both devices.
  - ◆ HA Maintenance: This is the Maintenance address of the device whose MAC address is the value of the HALocalMAC parameter.

An example of a configured ini file is shown below:

```
HALocalMAC = '00908f737a89'
HAUnitIdName = 'Device_1'
HARevertiveEnabled = 1
HAPriority = 6
HARemoteMAC = '00908f594667'
HARemoteAddress = 1.1.1.2
HARemoteUnitIdName = 'Device_2'
HARemotePriority = 4

[ InterfaceTable ]
FORMAT Index = ApplicationTypes, InterfaceMode, IPAddress, PrefixLength,
Gateway, InterfaceName, PrimaryDNSServerIPAddress,
SecondaryDNSServerIPAddress, UnderlyingDevice;
InterfaceTable 0 = 6, 10, 10.33.45.40, 16, 10.33.0.1, "Voice", 0.0.0.0, 0.0.0.0,
"vlan 1";
InterfaceTable 1 = 99, 10, 1.1.1.1, 24, 0.0.0.0, "HA", 0.0.0.0, 0.0.0.0, "vlan 2";
[ \InterfaceTable ]
```

4. Upload the file to both devices (see [Uploading an ini File to Device](#) on page 129).
5. To test your HA system, perform an HA switchover (see [Initiating an HA Switchover](#) on page 1197).



- If the HA Preempt feature is enabled, the device with the highest priority becomes the active unit. If the HA Preempt feature is not enabled, the first device to upload the file becomes the active unit, or if both upload the file simultaneously, the device with the "highest" IP address becomes the active unit.
- When configuration is applied to the device whose MAC is the value of the HARemoteMAC parameter, all HA configuration is swapped between local and remote parameters, including the IP address of the Maintenance interface, which is swapped with the address configured for the HARemoteAddress parameter.

## Configuration while HA is Operational

When the devices are operating in HA state, subsequent configuration is as follows:

- All configuration, including HA, is done on the active device **only**.
- Non-HA configuration on the active device is automatically updated on the redundant device (through the Maintenance interface).
- HA-related configuration on the active device is automatically updated on the redundant device:
  - Maintenance interface:
    - ◆ Modified Maintenance interface address of the active device: The address is set as the new 'HA Remote Address' value on the redundant device.
    - ◆ Modified 'HA Remote Address' value on the active device: The address is set as the new Maintenance interface address on the redundant device (requires a device restart).
    - ◆ Modifications on all other Maintenance interface parameters (e.g., Default Gateway and VLAN ID): updated to the Maintenance interface on the redundant device.
  - 'Preempt Mode' parameter.
  - 'Preempt Priority' parameter is set for the active device.
  - Modified 'HA Remote Preempt Priority' value is set for the redundant device.



If the HA system is already in HA Preempt mode and you want to change the priority of the device, to ensure that system service is maintained and traffic is not disrupted, it is recommended to set the higher priority to the redundant device and then restart it. After it synchronizes with the active device, it initiates a switchover and becomes the new active device (the former active device restarts and becomes the new redundant device).

## Configuring Firewall Allowed Rules

The Active device communicates with the Redundant device through the Maintenance interface. This interface is used by the Active device for HA maintenance with the Redundant device, for example, synchronizing configuration and software updates, and performing an HA switchover (see [Connectivity and Synchronization between Devices](#) on page 1176 for more information).

For HA maintenance, the following ports are used:

Type	Protocol	Direction	Source Port	Destination Port
HA Messages	UDP	Both directions (Active-Redundant)	669	669
HA Keep-	UDP	Both directions	670+n (multiple	680

Type	Protocol	Direction	Source Port	Destination Port
Alive		(Active- Redundant)	streams)	
HA Control and Data	TCP	Redundant to Active	Any	2442
HA Files	TCP/TLS	Redundant to Active	Any	80/443



- By default, the device's internal firewall keeps the above listed ports open. If you have an **external** firewall located between the Active and Redundant devices, make sure that it keeps these ports open as well (i.e., allows this traffic).
- If the device needs to communicate with AudioCodes OVOC, you must add rules to the external firewall (if required) and also to the device's internal firewall to allow incoming traffic from OVOC. For more information, see [Configuring Firewall Rules to Allow Incoming OVOC Traffic](#) on page 256.

## Configuring DiffServ for HA Maintenance Traffic

You can configure Differentiated Services (DiffServ) for HA Maintenance traffic which flows between the active and redundant devices on the HA Maintenance network interface. The default DiffServ value for this traffic is 46, which should be sufficient in most setups. However, you may need to increase the DiffServ priority if you are also running non-HA traffic on this network. Prioritizing HA Maintenance traffic ensures low latency for this critical network traffic.

### ➤ To configure DiffServ for HA Maintenance traffic:

1. Upload an ini file with the [HAMaintenanceIFDiffServValue] parameter configured to the required DiffServ value - 0 is the lowest priority (best effort) and 63 is the highest priority.
2. Restart the device with a save-to-flash for your settings to take effect.

## Configuring Ports for File Transfer between Active and Redundant Devices

By default, file transfer between active and redundant devices uses port 80 for unsecured transfers and port 443 for secured (HTTPS) transfers. You can change these local device ports according to your security and network requirements.

### ➤ To configure ports for HA file transfer:

1. Open the HA Settings page (**Setup** menu > **IP Network** tab > **Core Entities** folder > **HA Settings**).
2. In the 'HA File Transfer Port' field, enter a port number for unsecured file transfer.

3. In the 'HA Secure File Transfer Port' field, enter a port number for secured file transfer.

HA File Transfer Port	<input type="text" value="80"/>	
HA Secure File Transfer Port	<input type="text" value="443"/>	

4. Click **Apply**, and then restart the device with a burn-to-flash for your settings to take effect.

## Enabling Secured TLS Communication between Active and Redundant Devices

You can enable secure communication between the active and redundant devices in the HA system. This ensures that all data exchanges, including file transfers and other packets, are encrypted using TLS (HTTPS). This means that communication through the HA Maintenance interface, which handles all maintenance operations between the active and redundant devices is secure.

### ➤ To enable secure communication between active and redundant device:

1. Open the HA Settings page (**Setup** menu > **IP Network** tab > **Core Entities** folder > **HA Settings**).
2. Select the 'HA Secured Connectivity Mode' check box:

HA Secured Connectivity Mode ☒ 

3. Click **Apply**, and then restart the device with a burn-to-flash for your settings to take effect.

## Monitoring IP Entities and HA Switchover upon Ping Failure

The device's HA Network Monitor feature monitors the connectivity (*reachability*) with network entities (destinations), by pinging them using Internet Control Message Protocol (ICMP) Echo messages. This feature can be used, for example, to check connectivity with nearby routers (or first hops) that the device uses to reach other destinations for sending calls.

The HA Network Monitor table lets you configure up to 10 monitored rows, where each row can include up to 5 destinations to monitor, defined by IP address or hostname (FQDN). You can then configure the device to perform an HA switchover if a user-defined number of monitored rows whose destinations fail to reply to the device's sent pings (i.e., *unreachable* destinations) is reached or exceeded.



- The HA Network Monitor feature is a license-based feature (which is part of the general HA license) and is available only if it is included in the device's License Key.
- Switchover decisions of the HA Network Monitor feature are non-functional under the following conditions:
  - ✓ HA is disabled (i.e., active device is in standalone mode).
  - ✓ The HA Preempt Priority feature is used (enabled by the 'Preempt Mode' and 'Preempt Priority' parameters).
  - ✓ The number of Ethernet Groups (Ethernet links) on the redundant device that are in "up" status are less than on the active device.
- Destinations that have never replied to the device's pings are not used to determine reachability status and the unreachability threshold for triggering a switchover. They need to reply at least once to the device's pings in order to participate in the device's logic for this feature.
- Once a switchover occurs, the device doesn't perform switchover loops due to continued ping failures with the monitored row(s). Once a switchover occurs, the device changes the status of the monitored row(s) to "Reachability Unverified". A second switchover occurs only if the row(s) become reachable again and then unreachable.
- The following SNMP alarms are related to the HA Network Monitor feature:
  - ✓ acHASystemFaultAlarm: This alarm is sent to indicate that you have configured the HA Network Monitor feature, but switchover decisions are non-functional (see above).
  - ✓ acHANetworkMonitorAlarm: This alarm is sent to indicate that all destinations of a specific row in the HA Network Monitor table that replied in the past to the device's pings are now "unreachable".
  - ✓ acHASystemSwitchOverAlarm: This alarm is sent to indicate that an HA switchover has occurred due to the HA Network Monitor feature.

The following procedure describes how to configure monitored network entities through the Web interface. You can also configure it through ini file [HaNetworkMonitor] or CLI (`configure network > high-availability network-monitor`).

➤ **To configure monitoring of network entities:**

1. Open the HA Settings page (**Setup** menu > **IP Network** tab > **Core Entities** folder > **HA Settings**), and then do the following:

- a. Select the 'HA Network Monitor' check box (HAPingEnabled):

HA Network Monitor ☒

- b. In the 'Monitor Threshold' (HaNetworkMonitorThreshold) field, enter the minimum number of failed ("Not Reachable") monitored rows that are required to trigger an HA switchover:

Monitor Threshold



2. Open the HA Network Monitor table (**Setup** menu > **IP Network** tab > **Core Entities** folder > **HA Network Monitor**), and then do the following:
  - a. Click **New**; the following dialog box appears:

- b. Configure an HA network monitor entry according to the parameters described in the table below.
  - c. Click **Apply**.

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Destination Address' dest-address [DestAddress]	Defines destination addresses of network hosts that you want monitored by the device for the monitored row. The valid value is an IP address (IPv4 or IPv6) or hostname (FQDN). You can configure only one hostname (which can be resolved by DNS into up to five IP addresses). You can configure up to five IP addresses, where each IP address is separated by a comma or space, for example, "10.1.1.1 20.2.2.2,30.3.3.3" (without quotation marks). <b>Note:</b> <ul style="list-style-type: none"> <li>■ You can configure the parameter with either a hostname or an IP address, but not both.</li> <li>■ The IP address version (IPv4 or IPv6) of the 'Destination</li> </ul>

Parameter	Description
	Address' parameter and the 'Network Interface' parameter (below) must be the same.
'Network Interface' network- interface [NetworkInterface]	<p>Assigns one of the device's IP network interfaces from where you want to send ping requests to the monitored destinations configured for the monitored row.</p> <p>To configure IP interfaces, see <a href="#">Configuring IP Network Interfaces</a> on page 157.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ You can assign any IP Interface type (OAMP, Media or Control).</li> <li>■ The IP address version (IPv4 or IPv6) of the 'Network Interface' parameter and the 'Destination Address' parameter (above) must be the same.</li> </ul>
'Ping Timeout' ping-timeout [PingTimeout]	<p>Defines how often (in milliseconds) the device sends ping requests to the destinations configured for the monitored row. This also provides the device time to wait for a reply (if any) from the destination. For example, if configured to 100, the device pings the destination every 100 ms.</p> <p>If the device receives a reply from a destination within this timeout, it considers the destination as online (reachable). If no reply has been received from a user-defined number of consecutive pings (see the 'Ping Count' parameter, below), the device considers the destination as offline (unreachable).</p> <p>The valid value is 100 to 60000. The default is 1000.</p>
'Ping Count' ping-count [PingCount]	<p>Defines the number of consecutive failed pings (no replies) before the device considers the destination as offline (unreachable). For example, if you configure the parameter to 2, the destination is considered unreachable after 2 consecutive pings evoked no reply. If this destination later replies to any subsequent ping, the device considers it reachable.</p> <p>The valid value is 1 to 10. The default is 3.</p> <p><b>Note:</b> If the destination has never replied to a ping, the device doesn't consider it unreachable. Instead, it considers it as undetermined ("Reachability Unverified").</p>
'Entry Reachability Status'	Read-only field displaying the connectivity (reachable) status with the monitored row, which is based on ping results of all its configured destinations:

Parameter	Description
	<ul style="list-style-type: none"> <li>■ "Reachability Unverified": The reachability status of the monitored row is currently undetermined. In other words, <b>all</b> the destinations configured for the monitored row have never replied to the device's pings.</li> <li>■ "Reachable": The device considers the monitored row as online (reachable). In other words, the device has received a ping reply from <b>at least one</b> of the destinations configured for the monitored row.</li> <li>■ "Not Reachable": The device considers the monitored row as offline (unreachable). In other words, the number of failed pings equals to (or is greater than) that configured by the 'Ping Count' parameter, for <b>all</b> the destinations configured for the monitored row and on condition that all these destinations have replied in the past to the device's pings. The status of the monitored row returns to "Reachable" if at least one of the destinations replies to a ping.</li> <li>■ "Host not resolved": The hostname (if configured in the 'Destination Address' parameter) couldn't be resolved into an IP address.</li> </ul>

Once you have configured the destinations to monitor, you can view the status of each destination of a selected monitored row, as described in the following procedure.

➤ **To view reachability status of destinations per monitored row:**

1. Open the HA Network Monitor table (**Setup** menu > **IP Network** tab > **Core Entities** folder > **HA Network Monitor**).
2. In the table, select the required index row (monitored row), and then click the **HA Network Monitor Peers Status** link located below the table; the HA Network Monitor Peers Status table appears, displaying the reachability status of each destination ('Peer Destination Address') of the monitored row, as shown in the below example:

INDEX ↕	PEER DESTINATION ADDRESS	PEER REACHABILITY STATUS
0	10.4.4.60	Reachable
1	10.4.0.1	Reachable

The reachability status is displayed in the 'Peer Reachability Status' read-only field:

- "Reachability unverified": The reachability status of the destination is currently undetermined. In other words, the destination has never replied to the device's pings.
- "Reachable": The device considers the destination as online (reachable). In other words, the device has received a ping reply from the destination.

- "Not reachable": The device considers the destination as offline (unreachable). In other words, the number of consecutive failed pings equaled to (or was greater than) that configured by the 'Ping Count' parameter.
- "Terminated by ping error": The device is unable to send a ping to the destination (typically, due to a routing issue or incorrect destination address). To resolve the problem, correct your routing configuration or the address of the destination, and then enter the edit mode of the HA network monitor row belonging to the destination and click **Apply** to refresh your changes.

The 'Ping Loss Percentage' read-only field displays the percentage of pings sent to the destination that failed to get a reply, in the last five minutes.

## 39 HA Maintenance

This section describes HA maintenance.

### Maintenance of Redundant Device

The only interface that is operational on the redundant device is the Maintenance interface. The following protocols can be used for maintenance purposes for this interface:

- **Syslog:** To receive syslog messages from the redundant device, make sure that you have configured a valid VLAN and routing rule from the Maintenance network to the syslog server.
- **Telnet:** A Telnet server is always available on the redundant device (even if disabled by configuration).

The active device runs the above maintenance protocols on its' OAMP interface.

### Replacing a Failed Device

If you need to replace a faulty device, the new device must be configured exactly as the second device, as described in [Configuring the HA Devices](#) on page 1183.

### Initiating an HA Switchover

You can initiate a switchover from the Active to Redundant device.



When performing an HA switchover, the HA mode becomes temporarily unavailable.

#### ➤ To perform a switch-over:

1. Open the High Availability Maintenance page:
  - Toolbar: Click the **Actions** button, and then from the drop-down menu, choose **Switchover**.
  - Navigation tree: **Setup** menu > **Administration** tab > **Maintenance** folder > **High Availability Maintenance**.

#### SWITCH OVER

Switch between Active and Redundant Devices

Switch Over

2. Click **Switch Over**; a confirmation box appears requesting you to confirm.
3. Click **OK**.

## Restarting Redundant Device

You can restart the Redundant device if necessary.



When restarting the Redundant device, the HA mode becomes temporarily unavailable.

### ➤ To restart the Redundant device:

1. Open the High Availability Maintenance page:
  - Toolbar: Click the **Actions** button, and then from the drop-down menu, choose **Switchover**.
  - Navigation tree: **Setup** menu > **Administration** tab > **Maintenance** folder > **High Availability Maintenance**.

### REDUNDANT OPTIONS

Restart Redundant Device

Restart

2. Click **Restart**; a confirmation box appears.
3. Click **OK** to confirm.

## Software Upgrade

You can perform the following types of software upgrades on the HA system:

- **Software Upgrade with Device Restart:** Both active and redundant devices save and restart with the new software version. This method is quick and simple, but it disrupts traffic (i.e., traffic affecting).
- **Hitless Software Upgrade:** This method maintains service (i.e., not traffic affecting).

For more information, see [Upgrading the Device's \(.cmp\) Software](#) on page 1213.

## Disconnecting and Reconnecting HA

You can disconnect the two devices in the HA system and return them to standalone devices.

### ➤ To disconnect HA through CLI:

1. From the CLI of the active device, connect (Telnet) to the redundant device, by typing the following command:

```
# debug ha conn-to-red
```

2. Log in to the redundant device's CLI with its username (e.g., **Admin**) and password:

```
Username: Admin
Password:
```

3. Access the Privileged mode, by typing the following command, and the mode's password:

```
> enable
Password:
#
```

4. At the prompt, type the following command and enter a new OAMP IP address for the redundant device:

```
# debug ha disconnect-system <New OAMP Address for Redundant Device>
```

The redundant device restarts, the HA status of the active device changes to "Standalone", and the redundant device now becomes a non-HA device.



- The new OAMP address of the redundant device must be different to the active device.
- The HA Maintenance network interface (in the IP Interfaces table) on the redundant device is unaffected by the command.
- All **Media + Control** network interfaces (in the IP Interfaces table) on the redundant device are deleted.
- The 'HA Remote Address' [HARemoteAddr] field value, which specifies the HA Maintenance address of the active device is deleted on the redundant device.

You can later restore the HA system, by following the below procedure.

#### ➤ To restore the HA system through CLI:

1. On the previously **redundant** device, configure the HA Maintenance interface address of the active device:

```
(config-network)# high-availability
(ha)# remote-address <HA Maintenance Address of Active Device>
```

The HA Maintenance address can alternatively be configured in the Redundant device's Web interface's 'HA Remote Address' parameter.

2. Restart the redundant device:

```
(ha)# do reload now
```



The procedure assumes that no network changes were made to both devices' HA Maintenance interface or Ethernet Devices (VLAN); otherwise, the devices may not be able to communicate with each other.

## Accessing Files on Redundant Device from Active through SSH

From the active device, you can access files stored on the redundant device's flash memory, through SSH (or SFTP). Once accessed, your SSH client can download files to your PC (e.g., debug file, locally stored CDR, and Configuration Package file). This eliminates the need to perform an HA switchover to change the redundant device to active in order to access the device's files.

Access to the redundant device uses a proxy SSH server port on the active device. As this is a secure connection, your SSH client needs to authenticate itself with the device (SSH server). The device performs standard user authentication, where you can configure it to check the user's credentials in the device's Local Users table or with a remote authentication server. Access is granted only to users with **Security Administrator** user level.

Perform the following procedure on the **active** device.

### ➤ To access redundant device from active device for file download:

1. Enable SSH (see [Configuring CLI over SSH using Public Key Authentication](#) on page 92).
2. Open the Administration Settings page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Administration Settings**).
3. In the 'Redundant Device Server Port' field (SSHRedundantProxyPort), configure a port for SSH through which the active device accesses the redundant device. This proxy port must be different to the active device's regular SSH server port (configured in the 'Server Port' parameter).

Redundant Device Server Port

4. Click **Apply**.



- The device may take a long time to prepare the debug file for transfer when it contains much information. Some SFTP clients (for example, WinSCP and FileZilla) have a short default connection timeout and if the file transfer is not started within this timeout, the transfer attempt is aborted. Therefore, it is recommended to configure a longer timeout for your SFTP client application.
- For more information on the Configuration Package file, see [Downloading or Uploading Configuration Package File](#) on page 1260.



## Backing Up and Restoring HA Configuration

Once you have your HA system up and running, you can make a backup of your HA configuration, by saving an ini configuration file from the active device. If your HA system fails, for whatever reason, you can simply upload this file to the devices to restore HA.

### ➤ To backup and then restore HA:

1. Save the ini file from the active device to a folder on your PC. Store this file in a safe location for future use (i.e., HA backup).
2. If a failure occurs in one or both devices, upload the backup ini file to the failed device(s).



If one or both devices in the HA system have been replaced (RMA) for whatever reason (e.g., a hardware failure), before loading the file, update the file with the new MAC addresses ([HALocalMAC] or [HARemoteMAC] parameters).

# Part VIII

## Maintenance

## 40 Basic Maintenance

This section describes basic maintenance.

### Restarting the Device

You can restart the device through the device's management tools. Device restart may be required for maintenance purposes. Certain parameters require a device restart for their settings to take effect. These parameters are displayed in the Web interface with the lightning ⚡ icon. In addition, whenever you make any configuration change that requires a restart, the **Restart** button on the Web interface's toolbar is displayed with a red border, as shown below:



The Web interface also provides you with the following options when restarting the device:

- Saving current configuration to the device's flash memory (non-volatile) prior to the restart.
- Restarting the device only after a user-defined time (*Graceful Restart*) to allow current calls to end (calls are terminated after this interval).

To restart the device (and save configuration to flash) through CLI, use the following command:

```
# reset now
```

#### ➤ To restart device through Web interface:

1. Open the Maintenance Actions page:
  - Toolbar: Click the **Restart** button.
  - Navigation tree: **Setup** menu > **Administration** tab > **Maintenance** folder > **Maintenance Actions**.

RESTART DEVICE	
Restart Device	<input type="button" value="RESTART"/>
Save To Flash	<input type="text" value="Yes"/>
Graceful Restart	<input type="text" value="Yes"/>
Graceful Timeout [sec]	<input type="text" value="0"/>

2. From the 'Save To Flash' drop-down list, select one of the following:

- **Yes:** Current configuration is saved to flash memory prior to restart (default).
  - **No:** The device restarts without saving the current configuration to flash. All configuration done after the last configuration save will be discarded (lost) after restart.
3. From the 'Graceful Restart' drop-down list, select one of the following:
- **Yes:** The device restarts only after a user-defined time, configured in the 'Graceful Timeout' field (see next step). During this interval, the device rejects all new traffic. If no traffic exists and the time has not yet expired, the device restarts immediately.
  - **No:** The device restarts immediately, regardless of traffic. Any existing traffic is immediately terminated.
4. In the 'Graceful Timeout' field (available only if you have configured the 'Graceful Restart' field to **Yes**), enter the time (in seconds) after which the device restarts. Note that if no traffic exists and the time has not yet expired, the device restarts.
5. Click the **Restart** button; a confirmation message box appears.
6. Click **OK** to confirm device restart; if you configured the 'Graceful Restart' field to **Yes** (in Step 3), restart is delayed and a screen appears displaying the number of remaining calls and time. When the device begins to restart, a message appears notifying you.

## Remotely Restarting Device using SIP NOTIFY

The device can be remotely restart upon the receipt of a SIP NOTIFY message that contains an Event header set to 'check-sync;reboot=true' (proprietary to AudioCodes), as shown in the example below:

```
NOTIFY sip:<user>@<dsthost> SIP/2.0
To: sip:<user>@<dsthost>
From: sip:sipsak@<srchost>
CSeq: 10 NOTIFY
Call-ID: 1234@<srchost>
Event: check-sync;reboot=true
```

### ➤ To enable remote restart upon receipt of SIP NOTIFY:

1. Open the SIP Definitions General Settings page (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **SIP Definitions General Settings**).
2. Select the 'Remote Management by SIP NOTIFY' check box (EnableSIPRemoteReset):

Remote Management by SIP NOTIFY



3. Click **Apply**.

## Locking and Unlocking the Device

You can lock the device so that it stops processing calls. This may be useful, for example, when you want to upload new software files to the device and you don't want any traffic to interfere with the process. Locking the device may be done gracefully, whereby the device stops accepting new calls, but allows existing calls to continue for up to a user-defined duration before terminating them.



You can also configure the device to wait without a timeout until all active calls end on their own, before going into lock state. This is done through the CLI, using the following command: `# admin state lock graceful forever`

### ➤ To lock the device:

1. Open the Maintenance Actions page:
  - Toolbar: Click the **Restart** button.
  - Navigation tree: **Setup** menu > **Administration** tab > **Maintenance** folder > **Maintenance Actions**.

LOCK / UNLOCK	
Lock	<input type="button" value="LOCK"/>
Graceful Option	<input type="text" value="Yes"/>
Disconnect Client Connections	<input type="text" value="Disable"/>
Lock Timeout [sec]	<input type="text" value="180"/>
Device Operational State	UNLOCKED

2. From the 'Graceful Option' drop-down list, select one of the following options:
  - **Yes:** The device locks only after a user-defined duration, configured in the 'Lock Timeout' field (see next step). During this interval, no new traffic is accepted, allowing only existing calls to continue until the timeout expires. If at any time during this timeout there are no active calls, the device locks. If there are still active calls when the timeout expires, the device terminates them and locks.
  - **No:** The device locks immediately, terminating all existing traffic.

**Note:** These options are available only if the current status of the device is in "UNLOCKED" state.
3. If you configured 'Graceful Option' to **Yes** (see previous step), then in the 'Lock Timeout' field, enter the time (in seconds) after which the device locks.

4. If you also want the device to terminate (close) existing TLS/TCP client connections and reject new incoming TLS/TCP client connections during the locked state, then from the 'Disconnect Client Connections' drop-down list, select **Enable**. If disabled (default), existing client connections will remain and incoming TLS/TCP client connections will be accepted during the locked state.
5. Click the **LOCK** button; a confirmation message box appears requesting you to confirm device lock.
6. Click **OK** to confirm;
  - If you configured 'Graceful Option' to **Yes**, a lock icon is displayed and a window appears displaying the number of remaining calls and time. To cancel the lock, click the **Cancel Graceful Lock** button.

**Graceful reset initiated.**

**Device will be reset when all active calls are terminated,  
or when shutdown timer expires.**

Remaining Active Calls  Remaining Time [sec]

Click button to cancel the Graceful Lock

**Cancel Graceful Lock**

- If you configured 'Graceful Option' to **No**, the lock process begins immediately.

The 'Device Operational State' read-only field displays "LOCKED" and the device doesn't process any calls.

➤ **To unlock the device:**

- Click the **UNLOCK** button; the device unlocks immediately and accepts new incoming calls. The 'Device Operational State' read-only field displays "UNLOCKED".

## Saving Configuration

When you configure parameters and tables in the Web interface and then click the **Apply** button, changes are saved to the device's *volatile* memory (RAM). These changes revert to their previous settings when the device restarts (hardware or software) or powers off. Therefore, to ensure that your configuration changes are retained, you must save them to the device's non-volatile memory (i.e., flash memory).

To save your settings to flash, click the **Save** button located on the toolbar. To remind you to save your settings to flash, the **Save** button is displayed with a red border, as shown below:

**Save**

To save configuration to flash through CLI, use the following command:

# write

## 41 Channel Maintenance

This chapter describes channel-related maintenance.

### Restarting a B-Channel

You can restart a specific B-channel belonging to an ISDN or CAS trunk, using the SNMP MIB variable, `acTrunkISDNCommonRestartBChannel`. This may be useful, for example, for troubleshooting specific voice channels.



- If a voice call is currently in progress on the B-channel, it is disconnected when the B-channel is restarted.
- B-channel restart can only be done if the D-channel of the trunk to which it belongs is synchronized (Layer 2).
- B-channel restart doesn't affect the B-channel's configuration.

### Locking and Unlocking Trunk Groups

You can lock a Trunk Group to take its trunks (and their channels) out of service. When you initiate a lock, the device rejects all new incoming calls for the Trunk Group and immediately terminates active calls (busy channels), eventually taking the entire Trunk Group out of service.

You can lock a Trunk Group “gracefully”, whereby the device rejects new incoming calls, but terminates busy channels only after a user-defined graceful period if they are still busy by the end of the period. When configured to 0, graceful lock is disabled.

When you lock a Trunk Group, the method for taking channels out-of-service is determined by the following parameters:

- `DigitalOOSBehaviorForTrunk` parameter per trunk or `DigitalOOSBehavior` parameter for all trunks.

If you have configured registration for the Trunk Group (see the 'Registration Mode' parameter in the Trunk Group Settings table) and you subsequently lock the Trunk Group, it stops performing registration requests (un-registers) with the Serving IP Group with which you have configured it to register. When you unlock such a Trunk Group, it starts performing registration requests (re-registers) with the Serving IP Group once its trunks return to service.

#### ➤ To lock or unlock a Trunk Group:

1. Configure a graceful lock:
  - a. Open the Gateway Advanced Settings page (**Setup** menu > **Signaling & Media** tab > **Gateway** folder > **Gateway Advanced Settings**).
  - b. In the 'Graceful Busy Out Timeout' (`GracefulBusyOutTimeout`) field, enter the period after which the Trunk Group is locked:



Graceful Busy Out Timeout [sec]

- c. Click **Apply**.
  2. Lock the Trunk Group:
    - a. Open the Trunk Group Settings table (see [Configuring Trunk Group Settings](#) on page 906).
    - b. Select the row of the Trunk Group that you want to lock or unlock.
    - c. Click the **Action** button located on the table's toolbar, and then from the drop-down list, choose one of the following:
      - ◆ **Lock**: Locks the Trunk Group.
      - ◆ **Un-Lock**: Unlocks a locked Trunk Group.

The Trunk Group Settings table provides the following read-only fields related to locking and unlocking of a Trunk Group:

- 'Admin State': Displays the administrators state - "Locked" or "Unlocked"
- 'Status': Displays the current status of the channels in the Trunk Group:
  - "In Service": Indicates that all channels in the Trunk Group are in service, for example, when the Trunk Group is unlocked or Busy Out state cleared (see the EnableBusyOut parameter for more information).
  - "Going Out Of Service": Appears as soon as you choose the **Lock** button and indicates that the device is starting to lock the Trunk Group and take channels out of service.
  - "Going Out Of Service (<duration remaining of graceful period> sec / <number of calls still active> calls)": Appears when the device is locking the Trunk Group and indicates the number of busy channels and the time remaining until the graceful period ends, after which the device locks the channels regardless of whether the call has ended or not.
  - "Out Of Service": All fully configured trunks in the Trunk Group are out of service, for example, when the Trunk Group is locked or in Busy Out state (see the EnableBusyOut parameter).



- If the device restarts, a locked Trunk Group remains locked. If the device restarts while graceful lock is in progress, the Trunk Group is forced to lock immediately after the device finishes its restart.
- When the device is in High Availability (HA) mode:
  - ✓ After an HA switchover, a locked Trunk Group remains locked.
  - ✓ If an HA switchover is initiated while a Trunk Group is in locking progress, the locking process is stopped and only starts again (with the configured graceful period) once switchover completes.
  - ✓ When HA status is in "Synchronizing" state, the Trunk Group status is not updated in the Trunk Group Settings table. In addition, the lock/unlock actions cannot be invoked during this time. When HA synchronization finishes and HA status is in "Operational" state, the Trunk Group Settings table is refreshed with the lock/unlock status. The HA state is displayed on the Monitor home page.

## Disconnecting Active Calls

You can forcibly disconnect all active calls, or specific calls based on Session ID or Dial Plan tag (name=value) through CLI.

- To disconnect all calls:

```
# clear voip calls
```

- To disconnect a call with a specific Session ID:

```
# clear voip calls <Session ID>
```

- To disconnect calls with a specific Dial Plan tag:

```
# clear voip calls tag <name=value>
```

## Remotely Disconnecting Calls using SIP NOTIFY

The device can be triggered to disconnect all current calls upon the receipt of a SIP NOTIFY message containing an Event header with the value 'soft-sync' (proprietary to AudioCodes), as shown in the example below:

```
NOTIFY sip:<user>@<dsthost> SIP/2.0
To: sip:<user>@<dsthost>
From: sip:sipsak@<srchost>
CSeq: 10 NOTIFY
Call-ID: 1234@<srchost>
Event: soft-sync
```

➤ **To enable remote call disconnect upon receipt of SIP NOTIFY:**

1. Open the SIP Definitions General Settings page (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **SIP Definitions General Settings**).
2. Select the 'Remote Management by SIP NOTIFY' check box (EnableSIPRemoteReset):

Remote Management by SIP NOTIFY ☒

3. Click **Apply**.


## Configuring a Description for Telephony Ports

You can configure a short description per telephony port. The port's description is displayed as a tooltip when you hover your mouse over the port on the Web interface's Monitor page, and displayed in the output of various CLI commands (e.g., `show run`).

The following procedure describes how to configure a port description through the Web interface. You can also configure it through ini file ([AnalogPortInfo\_x] or [DigitalPortInfo\_x]) or CLI (`port-info` under relevant interface).

➤ **To configure a port description:**

1. Open the Monitor home page (see [Viewing Device Status on Monitor Page](#) on page 1314).
2. Click the required port icon, and then from the shortcut menu, choose **Port Description**; the following dialog box appears (top area cropped for convenience):



The description can contain only alphanumerical characters (without spaces).

3. Type a short description, and then click **Apply**.



For digital port interfaces, you can also configure the port description using the 'Description' field on the Trunk Settings page (see [Configuring Trunk Settings](#) on page 850).

## 42 Upgrading the Device's (.cmp) Software

You can use the Web interface's Software Upgrade Wizard to easily upgrade the device's software version (.cmp file).

For upgrading your standalone device, see [Upgrading a Standalone Device](#) below.

For upgrading devices operating in High-Availability mode, see [Upgrading Devices in High-Availability Mode](#) on page 1216.

### Recommendations Before Upgrading

Before upgrading the device, it's recommended to do the following:

- Make sure that the device's License Key is compatible with the software version to which you want to upgrade the device (see [License Key](#) on page 1233).
- Enable the Graceful Lock feature (see [Locking and Unlocking the Device](#) on page 1205) because the device restarts at the end of the software upgrade process, terminating all active calls. The Graceful Lock feature minimizes traffic disruption by blocking the establishment of new calls.
- Back up the device's configuration to your computer. If an upgrade failure occurs (for whatever reason), you can restore configuration by uploading the backup file to the device. For more information, see [Downloading and Uploading Configuration Files](#) on page 1257.

### Upgrading a Standalone Device

You can use the Web interface's Software Upgrade wizard to easily upgrade your standalone device.




- Prior to upgrading your device, read the pre-upgrade recommendations in [Recommendations Before Upgrading](#) above.
- You can download the latest software version files from AudioCodes website (registered users only) at <https://www.audiocodes.com/library/firmware>.
- The device cannot be configured during the upgrade.
- You can cancel the upgrade process at any time before the restart stage begins, by clicking the dialog's close (X) button.
- If the "SW version mismatch" message appears in the syslog or web interface after the upgrade, it indicates that the device's License Key doesn't support the new .cmp file version. In this case, contact AudioCodes Support for assistance.
- Instead of manually upgrading the device, you can use the device's Automatic Update feature for automatic provisioning (see [Automatic Provisioning](#)).
- You can also upgrade the device by uploading the .cmp file from an external USB hard drive connected to the device's USB port. For more information, see [USB Storage Capabilities](#).

➤ **To upgrade device using Software Upgrade wizard:**


1. Start the Software Upgrade wizard:

- **Toolbar:** From the **Actions** drop-down menu, choose **Software Upgrade**.
- **Navigation tree:** **Setup** menu > **Administration** tab > **Maintenance** folder > **Software Upgrade**.

Software Upgrade page appears:




2. Click **Start Software Upgrade**; the wizard starts, prompting you to choose the software version file (.cmp):




3. Click **Choose File**, and then navigate to and select the .cmp file.

4. Click **Upload File and Restart**; the device begins uploading the .cmp file and upgrading the firmware:




When the file is uploaded and installed, the device automatically restarts:




Device restart may take several minutes (even up to 30 minutes), depending on .cmp file version.

After restart completes, the "Upgrade Completed Successfully" message appears, along with the upgraded software version number:



5. Click **Close**; the wizard closes and you're automatically logged out of the device.
6. Log in again with your credentials; the following pop-up message appears, informing you that the device is now running a new software version:



7. Click **Close** to close the message box.

## Upgrading Devices in High-Availability Mode

You can use the Web interface's Software Upgrade wizard to upgrade devices operating in High-Availability (HA) mode.

You can choose between two HA upgrade methods:

- **Non-Hitless Upgrade):** In a Non-Hitless Upgrade, both the active and redundant devices are upgraded simultaneously. This method doesn't trigger an HA switchover, making it traffic-affecting and causing active calls to terminate during the upgrade process.

The upgrade process proceeds as follows:

- a. The active device uploads the .cmp file.
- b. The active device transfers the .cmp file to the redundant device.
- c. Both devices install the file, save it to flash memory, and then restart.

- **Hitless Upgrade:** A Hitless Upgrade updates both the active and redundant devices without disrupting traffic. It ensures ongoing calls are maintained using the HA switchover feature.

The upgrade process proceeds as follows:



- a. The active device uploads the .cmp file.
- b. The active device transfers the file to the redundant device.
- c. The redundant device installs the file, saves it to flash memory, and then restarts, now running the new software version.
- d. The redundant device initiates an HA switchover to become the new active device. Ongoing calls are uninterrupted and now processed by this device.
- e. The previously active device (now redundant) installs the file, saves it to flash memory, and then restarts. Both devices now run the new software version.
- f. The redundant device initiates an HA switchover to become the active device again. Only the initial redundant device restarts to resume redundant mode.



- The software upgrade process, which includes a device restart, may take several minutes (even up to 30 minutes), depending on .cmp file version.
- Hitless downgrade (i.e., to an earlier version) is **not** supported. For software downgrade, use the Non-Hitless upgrade.
- Instead of upgrading through the Web interface, you can use the device's CLI:
  - ✓ **Hitless Upgrade:** # copy firmware from <URL and file name>
  - ✓ **Non-Hitless Upgrade:** # copy firmware from <URL and file name> non-hitless



- Prior to upgrading your device, read the pre-upgrade recommendations in [Recommendations Before Upgrading](#) on page 1213.
- You can download the latest software version files from AudioCodes website (registered users only) at <https://www.audiocodes.com/library/firmware>.
- The device cannot be configured during the upgrade.
- You can cancel the upgrade process at any time before the restart stage begins, by clicking the dialog's close (X) button.
- If the "SW version mismatch" message appears in the syslog or web interface after the upgrade, it indicates that the device's License Key doesn't support the new .cmp file version. In this case, contact AudioCodes Support for assistance.
- Instead of manually upgrading the device, you can use the device's Automatic Update feature for automatic provisioning (see [Automatic Provisioning](#)).
- You can also upgrade the device by uploading the .cmp file from an external USB hard drive connected to the device's USB port. For more information, see [USB Storage Capabilities](#).


The following procedure describes how to perform a Hitless upgrade.

#### ➤ To upgrade device in HA mode using Software Upgrade wizard:

1. Start the Software Upgrade wizard:
  - **Toolbar:** From the **Actions** drop-down menu, choose **Software Upgrade**.

- **Navigation tree:** Setup menu > Administration tab > Maintenance folder > Software Upgrade.

The Software Upgrade page is displayed:




**Software Upgrade**

Start Software Upgrade

**Warning:**  
In case of an upgrade failure, the device will restart and the previous configuration saved to flash will be restored.

2. Click **Start Software Upgrade**; the wizard starts, prompting you to choose the software version file (.cmp):




**Upload CMP file**

Choose File No file chosen

Upload File and Restart Upload File and Hitless Restart

3. Click **Choose File**, and then navigate to and select the .cmp file.
4. Choose the upgrade method:
  - **For Non-Hitless upgrade:** Click **Upload File and Restart**.
  - **For Hitless upgrade:** Click **Upload File and Hitless Restart**; the active device uploads the .cmp file, and then transfers it to the redundant device:



**Upload CMP file**

Uploading file and upgrading firmware ...

Once the active device uploads the file and transfers it to the redundant device, the redundant device saves the software to flash memory and then restarts to install the software.

When the redundant device completes the software upgrade, it initiates an HA switchover to become the active device, and now handles all the currently active calls (Stage 1/3):

Hitless Software Upgrade process currently in progress

Stage 1/3: Burning and initiating switch-over...

The previously active device (now redundant) saves the file to flash memory, and then restarts to install the software.

When the currently redundant device (previously active) completes the software upgrade, it initiates an HA switchover to become the active device once again, and now handles all the currently active calls (Stage 2/3):

Hitless Software Upgrade process currently in progress

Stage 1/3: Burning and initiating switch-over...

Stage 2/3: Burning and initiating switch-back...

The active device then reconnects with the redundant device (Stage 3/3):

Hitless Software Upgrade process is currently in progress

Stage 1/3: Burning and initiating switch-over...

Stage 2/3: Burning and initiating switch-back...

Stage 3/3: Connecting to redundant device...

5. When the upgrade process completes, the Web Login page is displayed. Log in again to the device with your credentials.

## 43 Uploading Auxiliary Files

You can upload Auxiliary files to the device using any of the following methods:

- Web interface (see [Uploading Auxiliary Files through Web Interface](#) on the next page)
- CLI (see [Uploading Auxiliary Files through CLI](#) on page 1223)
- Automatic Update mechanism (see [Automatic Update Mechanism](#))
- One Voice Operations Center (OVOC) – refer to the *OVOC User's Manual*

The following table lists the different types of Auxiliary files.

**Table 43-1: Auxiliary Files**

File	Description
<b>INI</b>	Configures the device. The Web interface enables practically full device provisioning. However, some features may only be configured by ini file or you may wish to configure your device through ini file. For more information, see <a href="#">INI File-Based Management</a> on page 126.
<b>CAS</b>	Contains CAS Protocol definitions for CAS-terminated trunks (for various types of CAS signaling). You can use the supplied files or construct your own files. Up to eight different CAS files can be installed on the device. For more information, see <a href="#">Uploading CAS Files</a> on page 1230.
<b>Call Progress Tones</b>	Region-specific, telephone exchange-dependent file that contains the Call Progress Tones (CPT) levels and frequencies for the device. The default CPT file is U.S.A. For more information, see <a href="#">Call Progress Tones File</a> on page 1224.
<b>Prerecorded Tones</b>	The Prerecorded Tones (PRT) file enhances the device's capabilities of playing a wide range of telephone exchange tones that cannot be defined in the CPT file. For more information, see <a href="#">Uploading a Prerecorded Tones File</a> on page 1228.
<b>User Info</b>	Uploads a User Information file. <b>Note:</b> Upload a User Information file using the Auxiliary Files page only for <b>backward compatibility</b> (old file format); otherwise, upload the file or configure users in the SBC User Information table for SBC users (see <a href="#">Configuring SBC User Information Table through Web Interface</a> on page 776) and for Gateway users (see <a href="#">Configuring Gateway User Information Table through Web Interface</a> on page 770).
<b>AMD Sensitivity</b>	Answer Machine Detector (AMD) Sensitivity file containing the AMD Sensitivity suites. For more information, see <a href="#">Uploading an AMD Sensitivity File</a> on page 1231.

File	Description
<b>SBC Wizard Template Package</b>	<p>Contains the vendor-interoperability configuration templates for the SBC Configuration Wizard. For more information, see <a href="#">SBC Configuration Wizard</a> on page 1295.</p> <p><b>Note:</b> The SBC Configuration Wizard isn't supported (and not available in the Web interface) if you have configured any IPv6 IP Interfaces in the IP Interfaces table (see <a href="#">Configuring IP Network Interfaces</a> on page 157).</p>

## Uploading Auxiliary Files through Web Interface

The following procedure describes how to upload Auxiliary files through the Web interface.



- When uploading an ini file through the Auxiliary Files page, only parameter settings specified in the ini file are applied to the device; all other parameters remain at their current settings. This is known as an *incremental* ini file upload.
- If you upload an ini file containing Auxiliary file(s), the Auxiliary files specified in the file overwrite the Auxiliary files currently installed on the device.
- For the User Information file, use the Auxiliary Files page **only for backward compatibility** (old file format). If backward compatibility is not needed, upload the file or configure users in the SBC User Information table for SBC users (see [Configuring SBC User Information Table through Web Interface](#) on page 776) and for Gateway users (see [Configuring Gateway User Information Table through Web Interface](#) on page 770).

### ➤ To upload Auxiliary files through Web interface:

1. Open the Auxiliary Files page:
  - Toolbar: From the **Actions** drop-down menu, choose **Auxiliary Files**.
  - Navigation tree: **Setup** menu > **Administration** tab > **Maintenance** folder > **Auxiliary Files**.

## Auxiliary Files

INI file (incremental)

Choose File

No file chosen


Load File

CAS file

Choose File

No file chosen

Load File

 Call Progress Tones file

Choose File

No file chosen

Load File

Prerecorded Tones file

Choose File

No file chosen

Load File

User Info file

Choose File

No file chosen

Load File

AMD Sensitivity file

Choose File

No file chosen

Load File

SBC Wizard Template package file

Choose File

No file chosen

Load File



The above figure is used only as an example; some Auxiliary files may not be supported by your device.

2. Click the **Browse** or **Choose File** button (depending on browser) corresponding to the Auxiliary file type that you want to upload, navigate to the folder in which the file is located, and then click **Open**; the name of the file appears next to the **Browse** button.
3. Click the corresponding **Load File** button.
4. Repeat steps 2 through 3 for each file you want to upload.
5. If you uploaded a file that requires a device restart (e.g., Call Progress Tones file), the **Restart** button on the toolbar appears with a red border, which you need to click to restart the device with a save-to-flash for your settings to take effect. If you uploaded a file that doesn't need a device restart, only the **Save** button on the toolbar appears with a red border, which you need to click for your settings to take effect.

## Uploading Auxiliary Files through CLI

You can upload Auxiliary files from remote servers through CLI:

### ■ Single Auxiliary file:

```
# copy <file> from <URL of remote server>
```

For example:

```
# copy call_progress_tones from http://192.169.11.11:80/cpt_us.dat
```

- ### ■ Multiple (batch) Auxiliary files:
- The Auxiliary files must be contained in a TAR (Tape Archive) file (.tar). The TAR file can contain any number and type of Auxiliary files (e.g., Dial Plan file and CPT file).

```
# copy aux-package from | to <URL of remote server with TAR file name>
```

For example:

```
# copy aux-package from http://192.169.11.11:80/aux_files.tar
```

For more information on CLI, refer to the *CLI Reference Guide*.

## Deleting Auxiliary Files

You can delete loaded Auxiliary files through the Web interface, as described below.

### ➤ To delete a loaded Auxiliary file:

1. Open the Device Information page (see [Viewing Device Information](#) on page 1312); the loaded files are listed under the Loaded Files group:

LOADED FILES	
Call Progress Tones File Name:	usa_tones_13.dat <span>Delete</span>
Loaded Coder Table :	Default CODERTABLE

2. Click the **Delete** button corresponding to the file that you want deleted; a confirmation message box appears.
3. Click **OK** to confirm.
4. Restart the device with a save-to-flash for your settings to take effect.

## Uploading an ini File

You can upload an ini file to the device using the Auxiliary page.

When using the Auxiliary Files page to upload an ini file, **only** parameters specified in the ini file are applied to the device's configuration; all other parameters remain at their current settings. This is referred to as *incremental* ini file upload.



- If you upload an ini file that also contains other Auxiliary files, the Auxiliary files specified in the file overwrite the Auxiliary files currently installed on the device.
- Only if the ini file contains the parameter [ResetNow = 1], does the device restart after the file is uploaded.

### ➤ To upload an ini file:

1. Open the Auxiliary Files page (see [Uploading Auxiliary Files through Web Interface](#) on page 1221).
2. Under the **INI file (incremental)** group, click the **Choose File** button (or **Browse** button, depending on browser) to select the file from a folder on your computer, and then click **Load File**:

#### INI file (incremental)

Choose File	No file chosen	Load File
-------------	----------------	-----------

3. On the toolbar, click **Save** for your settings to take effect.

## Call Progress Tones File

The Call Progress Tones (CPT) file contains definitions of the CPT (levels and frequencies) that are detected and generated by the device.

You can use one of the supplied Auxiliary files (.dat file format) or create your own file. To create your own file, it's recommended to modify the supplied *usa\_tone.ini* file (in any standard text editor) to suit your specific requirements and then convert the modified *ini* file into binary



*.dat* file format, using AudioCodes DConvert utility. For more information, refer to the document [DConvert Utility User's Guide](#).



The CPT file can only be loaded in *.dat* file format.

You can create up to 32 different Call Progress Tones, each with frequency and format attributes. The frequency attribute can be single or dual-frequency (in the range of 300 to 1980 Hz) or an Amplitude Modulated (AM). Up to 64 different frequencies are supported. Only eight AM tones, in the range of 1 to 128 kHz, can be configured (the detection range is limited to 1 to 50 kHz). Note that when a tone is composed of a single frequency, the second frequency field must be set to zero.

The format attribute can be one of the following:

- **Continuous:** A steady non-interrupted sound (e.g., a dial tone). Only the 'First Signal On time' should be specified. All other on and off periods must be set to zero. In this case, the parameter specifies the detection period. For example, if it equals 300, the tone is detected after 3 seconds (300 x 10 msec). The minimum detection time is 100 msec.
- **Cadence:** A repeating sequence of on and off sounds. Up to four different sets of on/off periods can be specified.
- **Burst:** A single sound followed by silence. Only the 'First Signal On time' and 'First Signal Off time' should be specified. All other on and off periods must be set to zero. The burst tone is detected after the off time is completed.

You can specify several tones of the same type. These additional tones are used only for tone detection. Generation of a specific tone conforms to the first definition of the specific tone. For example, you can define an additional dial tone by appending the second dial tone's definition lines to the first tone definition in the *ini* file. The device reports dial tone detection if either of the two tones is detected.

The Call Progress Tones section of the *ini* file comprises the following segments:

- **[NUMBER OF CALL PROGRESS TONES]:** Contains the following key:  
'Number of Call Progress Tones' defining the number of Call Progress Tones that are defined in the file.
- **[CALL PROGRESS TONE #X]:** containing the Xth tone definition, starting from 0 and not exceeding the number of Call Progress Tones less 1 defined in the first section (e.g., if 10 tones, then it is 0 to 9), using the following keys:
  - **Tone Type:** Call Progress Tone types:
    - ◆ **[1]** Dial Tone
    - ◆ **[2]** Ringback Tone
    - ◆ **[3]** Busy Tone
    - ◆ **[4]** Congestion Tone
    - ◆ **[6]** Warning Tone

- ◆ [7] Reorder Tone
- ◆ [8] Confirmation Tone
- ◆ [9] Call Waiting Tone - heard by called party
- ◆ [15] Stutter Dial Tone
- ◆ [16] Off Hook Warning Tone
- ◆ [17] Call Waiting Ringback Tone (heard by the calling party)
- ◆ [18] Comfort Tone
- ◆ [23] Hold Tone
- ◆ [46] Beep Tone
- **Tone Modulation Type:** Amplitude Modulated (1) or regular (0)
- **Tone Form:** The tone's format can be one of the following:
  - ◆ Continuous (1)
  - ◆ Cadence (2)
  - ◆ Burst (3)
- **Low Freq [Hz]:** Frequency (in Hz) of the lower tone component in case of dual frequency tone, or the frequency of the tone in case of single tone. This is not relevant to AM tones.
- **High Freq [Hz]:** Frequency (in Hz) of the higher tone component in case of dual frequency tone, or zero (0) in case of single tone (not relevant to AM tones).
- **Low Freq Level [-dBm]:** Generation level 0 dBm to -31 dBm in dBm (not relevant to AM tones).
- **High Freq Level:** Generation level of 0 to -31 dBm. The value should be set to 32 in the case of a single tone (not relevant to AM tones).
- **First Signal On Time [10 msec]:** 'Signal On' period (in 10 msec units) for the first cadence on-off cycle. For continuous tones, the parameter defines the detection period. For burst tones, it defines the tone's duration.
- **First Signal Off Time [10 msec]:** 'Signal Off' period (in 10 msec units) for the first cadence on-off cycle (for cadence tones). For burst tones, the parameter defines the off time required after the burst tone ends and the tone detection is reported. For continuous tones, the parameter is ignored.
- **Second Signal On Time [10 msec]:** 'Signal On' period (in 10 msec units) for the second cadence on-off cycle. Can be omitted if there isn't a second cadence.
- **Second Signal Off Time [10 msec]:** 'Signal Off' period (in 10 msec units) for the second cadence on-off cycle. Can be omitted if there isn't a second cadence.

- **Third Signal On Time [10 msec]:** 'Signal On' period (in 10 msec units) for the third cadence on-off cycle. Can be omitted if there isn't a third cadence.
- **Third Signal Off Time [10 msec]:** 'Signal Off' period (in 10 msec units) for the third cadence on-off cycle. Can be omitted if there isn't a third cadence.
- **Fourth Signal On Time [10 msec]:** 'Signal On' period (in 10 msec units) for the fourth cadence on-off cycle. Can be omitted if there isn't a fourth cadence.
- **Fourth Signal Off Time [10 msec]:** 'Signal Off' period (in 10 msec units) for the fourth cadence on-off cycle. Can be omitted if there isn't a fourth cadence.
- **Carrier Freq [Hz]:** Frequency of the carrier signal for AM tones.
- **Modulation Freq [Hz]:** Frequency of the modulated signal for AM tones (valid range from 1 to 128 Hz).
- **Signal Level [-dBm]:** Level of the tone for AM tones.
- **AM Factor [steps of 0.02]:** Amplitude modulation factor (valid range from 1 to 50). Recommended values from 10 to 25.



- When the same frequency is used for a continuous tone and a cadence tone, the 'Signal On Time' parameter of the continuous tone must have a value that is greater than the 'Signal On Time' parameter of the cadence tone. Otherwise, the continuous tone is detected instead of the cadence tone.
- The tones frequency must differ by at least 40 Hz between defined tones.

Below shows an example of a configured dial tone to 440 Hz only:

```
[NUMBER OF CALL PROGRESS TONES]
Number of Call Progress Tones=1
#Dial Tone
[CALL PROGRESS TONE #0]
Tone Type=1
Tone Form =1 (continuous)
Low Freq [Hz]=440
High Freq [Hz]=0
Low Freq Level [-dBm]=10 (-10 dBm)
High Freq Level [-dBm]=32 (use 32 only if a single tone is required)
First Signal On Time [10msec]=300; the dial tone is detected after 3 sec
First Signal Off Time [10msec]=0
Second Signal On Time [10msec]=0
Second Signal Off Time [10msec]=0
```

➤ **To upload a Call Progress Tones file:**

1. Open the Auxiliary Files page (see [Uploading Auxiliary Files through Web Interface](#) on page 1221).
2. Under the **Call Progress Tones file** group, click the **Choose File** button (or **Browse** button, depending on browser) to select the file from a folder on your computer, and then click **Load File**:



3. Restart the device with a burn-to-flash for your settings to take effect.



Uploading a CPT file requires a device restart. After you have uploaded the file, the **Restart** button on the toolbar appears with a red border, which you need to click.

## Uploading a Prerecorded Tones File

The Prerecorded Tones (PRT) file can contain up to 80 user-defined prerecorded tones (and up to 10 minutes of recorded audio in total) that can be played by the device. The PRT file overcomes the limitations of the CPT file (such as limited number of predefined tones and limited number of frequency integrations in a single tone).

Some usage examples of the PRT file include:

- Playing a held tone (music on hold) to a call party that has been put on hold, or playing a ringback tone to a calling party.
- Playing different held and ringback tones to different groups of users. To do this, configure an IP Profile (see [Configuring IP Profiles](#) on page 664) with the desired ringback tone ('Local Ringback Tone Index' parameter) and/or held tone ('Local Held Tone Index' parameter), and then associate the IP Profile with the desired IP Group.
- Playing background tones to the call parties (caller and/or callee) in an SBC call. For more information, see [Configuring Background Tones for SBC Calls](#) on page 1158.



- Playing tones from the PRT file is applicable to Gateway and SBC calls.
- The PRT file only generates (plays) tones; detection of tones is according to the CPT file.
- The PRT file can be up to 4 megabytes in size.
- If the PRT file contains a tone that also exists in the CPT file, the tone in the PRT file is played instead (i.e., overrides the tone in the CPT file).
- For SBC calls, you can define a PRT file with multiple tones for the same tone type, but where each tone is defined with a different coder. If the coder of the tone is the same as that used in the current call, DSPs are not required by the device to play the tone. Therefore, if a tone is defined with a coder that is also used in the call, the device always selects this specific tone. However, if the coders are different, the device uses DSPs to play the appropriate tone from the Call Progress Tones (CPT) file (if the tone and CPT file exist).
- The device requires DSPs for local generation of tones.
- The PRT file supports only the ringback tone and hold tone for SBC calls.


You can record the tones using a standard third-party, recording utility. You need to record the tones (raw data files) with the following properties:

- Coders: G.711 A-law, G.711  $\mu$ -law, or G.729
- Rate: 8 kHz
- Resolution: 8-bit
- Channels: mono

The PRT file can include prerecorded audio tones of different coders (e.g., some with G.711 and some with G.729). The prerecorded tones are played repeatedly. This allows you to record only part of the tone and then play the tone for the full duration. For example, if a tone has a cadence of 2 seconds on and 4 seconds off, the recorded file should contain only these 6 seconds. The device repeatedly plays this cadence for the configured duration. Similarly, a continuous tone can be played by repeating only part of it.

Once recorded, you need to combine the recorded files into a single and loadable PRT file (.dat), using the latest version of AudioCodes DConvert utility. In DConvert, each recording must be added to the PRT file with the tone type "acUserDefineTone<Index>". When you want to specify the tone (ringback or held tone) to play for a specific IP Profile ('Local Ringback Tone Index' and 'Local Held Tone Index' parameters), you need to use this index number. For more information on the DConvert utility, refer to the [DConvert Utility User's Guide](#). Once you have created the PRT .dat file, you need to upload it to the device (flash memory).

The following figure shows an example of creating a PRT file with multiple user-defined tones ("acUserDefineTone<Index>"), using the DConvert utility:



### ➤ To upload a Prerecorded Tones file:

1. Open the Auxiliary Files page (see [Uploading Auxiliary Files through Web Interface](#) on page 1221).
2. Under the **Prerecorded Tones** file group, click the **Choose File** button (or **Browse** button, depending on browser) to select the file from a folder on your computer, and then click **Load File**:

#### Prerecorded Tones file

Choose File

No file chosen

Load File

3. On the toolbar, click **Save** for your settings to take effect.

## Uploading CAS Files

The CAS files contain the CAS Protocol definitions that are used for CAS-terminated trunks. You can use the supplied CAS files or create your own files. You can upload up to eight files to the device. You can assign different files to different trunks (CASTableIndex\_x), and different CAS tables to different B-channels (CASChannelIndex) in the Trunk Settings page (see [Configuring Trunk Settings](#) on page 850).



All CAS files that are uploaded together must belong to the same trunk type (i.e., either E1 or T1).

### ➤ To upload a CAS file:

1. Open the Auxiliary Files page (see [Uploading Auxiliary Files through Web Interface](#) on page 1221).
2. Under the **CAS file** group, click the **Choose File** button (or **Browse** button, depending on browser) to select the file from a folder on your computer, and then click **Load File**:

CAS file

**Choose File** No file chosen

Load File

3. On the toolbar, click **Save** for your settings to take effect.

## Uploading an AMD Sensitivity File

The device is shipped with a default, pre-installed *AMD Sensitivity* file for its Answering Machine Detection (AMD) feature (as described in [Answering Machine Detection \(AMD\)](#) on page 304). This file includes the detection algorithms for detecting whether a human or answering machine has answered the call, and is based on North American English. In most cases, the detection algorithms in this file suffice even when your deployment is in a region where a language other than English is spoken. However, if you wish to replace the default file with a different AMD Sensitivity file containing customized detection algorithms, please contact the your AudioCodes sales representative for more information.

The AMD Sensitivity file is created in .xml format and then converted to a binary .dat file that can be installed on the device. The XML-to-binary format conversion can be done using AudioCodes DConvert utility. For more information, refer to the document [DConvert Utility User's Guide](#).



- You can upload only one AMD Sensitivity file to the device.
- When you upload an AMD Sensitivity file, it replaces the currently installed AMD Sensitivity file (if exists).

### ➤ To upload an AMD Sensitivity file:

1. Open the Auxiliary Files page (see [Uploading Auxiliary Files through Web Interface](#) on page 1221).
2. Under the **AMD Sensitivity file** group, click the **Choose File** button (or **Browse** button, depending on browser) to select the file from a folder on your computer, and then click **Load File**:

AMD Sensitivity file

**Choose File** No file chosen

Load File

3. On the toolbar, click **Save** for your settings to take effect.



You can also upload an AMD Sensitivity file, using the following methods:

- **TFTP during initialization:** Configure the [AMDSensitivityFileName] parameter, and then copy the AMD Sensitivity file to the TFTP directory.
- **Automatic Update mechanism:** Configure the [AMDSensitivityFileUrl] parameter through ini file. For more information, see [Automatic Update Mechanism](#).

## Uploading a User Info File



For uploading a User Info (User Information) file, use the Auxiliary Files page **only for backward compatibility** (old file format).

If backward compatibility is not required, upload the file (or configure users) in the SBC User Information table for SBC users (see [Configuring SBC User Information Table through Web Interface](#) on page 776) and for Gateway users (see [Configuring Gateway User Information Table through Web Interface](#) on page 770). For file syntax when uploading the file using the Auxiliary Files page, see the notes in these sections.



## 44 License Key

The License Key determines the licensed features (e.g., Test Call and voice coders) and various capacity figures (e.g., number of Test Calls and SBC call sessions) that you have ordered for your device.

The local License Key, which is installed on the device through ini file (locally or through the Automatic Update mechanism), contains all the licenses for the ordered features and capacity.

However, capacity licenses for SIPREC and SBC sessions (regular sessions, transcoding sessions, and registered far-end users), you can use AudioCodes OVOC management tool to provide and manage them. OVOC provides various SBC capacity licensing modes, as described in [OVOC-Managed Capacity Licenses](#) on page 1243.



- The availability of certain Web pages in the Web interface depends on the licensed features in the License Key.

### Viewing the License Key

The License Key is displayed on the License Key page, showing all the device's licensed features and capacity.

#### ➤ To view License Key through Web interface:

■ Open the License Key page:

- **Toolbar:** From the **Actions** drop-down menu, choose **License Key**.
- **Navigation tree:** **Setup** menu > **Administration** tab > **License** folder > **License Key**.



- Ordered features are always licensed by the **local** License Key. In other words, even if you are using OVOC to manage the device's SIPREC and SBC capacity licenses, all the other features and capacity figures are licensed by the local License Key.
- If you save the device's ini configuration file to a folder on your computer, the local License Key is also included (see [Downloading or Uploading ini File](#) on page 1257). If the device is in High-Availability mode, the saved ini file of the Active device also includes the License Key of the Redundant device.

In addition to displaying the licensed features and capacity, the License Key page also displays general information on a bar at the top of the page, as shown in the example below:

	NA	Floating License	5967925	72	Not connected
Product Key	OVOC Product Key	Mode	Serial Number	Device Type	License Server Status

**Table 44-1: Description of General information on License Key Page**

Field	Description
<b>Serial Number</b>	Displays the device's serial number.
<b>Product Key</b>	Displays the device's Product Key. For more information, see <a href="#">Viewing the Device's Product Key</a> on page 1256.
<b>OVOC Product Key</b>	Displays the Product Key of OVOC that is providing and managing the SBC capacity licenses for the device. <b>Note:</b> The field is displayed only if the device uses OVOC to manage its SBC capacity licenses, as described in <a href="#">OVOC-Managed Capacity Licenses</a> on page 1243.
<b>Mode</b>	Displays the type of license used for the device's SBC capacity licenses: <ul style="list-style-type: none"> <li>■ "Local License Key": SBC capacity licenses are only based on the local License Key.</li> <li>■ "License Pool": SBC capacity licenses are obtained remotely from the Fixed License Pool, which is managed by OVOC. For more information, see <a href="#">Fixed License Pool Model</a> on page 1243.</li> <li>■ "Floating License": SIPREC and SBC capacity licenses are obtained remotely from the Floating License, which is managed by OVOC. For more information, see <a href="#">Floating License Model</a> on page 1245.</li> <li>■ "Flex License": SIPREC and SBC capacity licenses are obtained remotely from the Flex License, which is managed by OVOC. For more information, see <a href="#">Flex License Model</a> on page 1248.</li> </ul>
<b>Device Type</b>	Displays AudioCodes internal model identification number of the device.
<b>License Server Status</b>	Displays the connectivity status between the device and OVOC when the device uses OVOC to manage its SBC capacity licenses (Fixed License, Floating License, or Flex License): <ul style="list-style-type: none"> <li>■ "Connected": This indicates that the device is connected to OVOC.</li> <li>■ "Disconnected": This indicates that the device was connected to OVOC, but has lost connection with OVOC due to network problems (HTTPS TCP</li> </ul>

Field	Description
	<p>connection).</p> <ul style="list-style-type: none"> <li>■ "Not Connected": This indicates that the device has not connected to OVOC.</li> </ul> <p><b>Note:</b> The field is displayed only when the device uses OVOC to manage its SBC capacity licenses, as described in <a href="#">OVOC-Managed Capacity Licenses</a> on page 1243.</p>

## Local License Key

The local License Key contains all the licenses for your ordered features and capacity. This License Key is installed locally on the device.



- When you install a new License Key, it overwrites the previously installed License Key. Therefore, features that were licensed by the previous License Key and not included in the new License Key will no longer be available.
- The local License Key is unique to the device (based on Serial Number) and cannot be installed on other devices.
- You can also install the local License Key remotely using the device's Automatic Update mechanism (see [Automatic Provisioning](#) on page 1266).
- If you want to use OVOC to manage SIPREC and SBC capacity licenses, see [OVOC-Managed Capacity Licenses](#) on page 1243.

## Installing License Key through Web Interface



You can install the local License Key through the Web interface, using one of the following methods:

- Installing a License Key file (see [Installing a License Key File](#) on page 1238)
- Installing a License Key string (see [Installing a License Key String](#) on the next page)

When you initially upload the License Key before installing it, the License Key page uses color-coded icons to indicate the changes between the currently installed License Key and the new License Key that you loaded. The following table describes these color codes:

**Table 44-2: Color-Coded Icons for Newly Loaded License Key**

Icon	Color	Description
	Green	Indicates new features added by the new License Key.
	Orange	Indicates the capacity change of an existing feature. Move your mouse over the icon to view a pop-up describing the capacity change, as shown in the following example for the SBC Sessions

Icon	Color	Description
		<p>license:</p> 
	Red	Indicates features of the previously installed License Key that are not included in the new License Key and are no longer available.



After you install the License Key with a device restart, the icons are no longer displayed and the License Key page displays only the features and capacity that are licensed by the new License Key.

### Installing a License Key String

You can install the License Key as a string in encrypted format through the Web interface.



- The License Key installation process includes a device restart and therefore, is traffic-affecting. To minimize disruption of current calls, it is recommended to perform this procedure during periods of low traffic.
- Installation of the License Key in string format is not applicable to devices in HA mode. To install the License Key for devices in HA mode, you need to upload a License Key file, as described in [Installing License Key on HA Devices](#) on page 1239.

#### ➤ To install a License Key string through Web interface:

1. Open the License Key page (see [Viewing the License Key](#) on page 1233).
2. Back up the currently installed License Key as a precaution. If the new License Key doesn't comply with your requirements, you can re-upload the backed-up License Key to restore the device's original capabilities. For backing up the License Key, see [Backing up Local License Key](#) on page 1242.
3. Copy the License Key string (from the License Key file or email) to your clipboard. Make sure that you copy **only** the encrypted string (and not the serial number or any other part of the string), as shown in the example below:

```
[LicenseKeys]
S/N5967925F4Rqr5to27458ANud3hru6x402R5c0lcbgNfuhcsiP8ealNefjQ9ay0c405bcihdbgM8f9G1iP8ealNe80cpdHic04055c019bg
Mehfcsjgjealp4820ba28e4055c01cbgMfehcsiP8ealtestNefjQba20c4055c01cbgMfeggkqN8ealNefjQba20c4057ciV9bgMD4hcsiP8
eal17pmbka3Ui4055c01cbgMfehcsiJgcaRvcf3Maai4d4050d2CMkdofPNhgrh3c19BzBanBuba24d4idheypfQwk62y00
```

- Click **Load String**; the Load License Key String dialog box appears.
- In the text box, paste your License Key string, as shown in the following example:

Load License Key String

Paste your License Key string:

r4Rqr5to274caQZtd3hru6R14it7citebMUdeN8tiP8280gmfjQldy0c4O55cOtebgMfehMth3Qbbq2OgAbTR2sb52vcKylcbgMfejlQlP8dbjYjfjQaaI8e62h5cNRQbgMfehcsM3U68IvcfjRbq20c4O55cOlcbgMdeNcsiP8qa5ZdaOM3820c4O55cOlcbgMfehcsiP8ealNefjQba20c4O55cOlcewkj6NcsiP8ealNefjQba2g8405bcihdbgMbeNsoiP8su03OfjQba2E64O50dylca0AfehAmtwYealp4fjQba3go4O5h9OlcgbMfehcsiP8ealNefjQba20c4O55cOlcbgMfehcsiP8ealNefjQ18y0cX2j7fgl0

384 chars

Cancel

Apply

- Click **Apply**; the dialog box closes and the "String Uploaded!" message is briefly displayed at the bottom of the page when the License Key is successfully loaded to the device. The License Key page uses color-coded icons to indicate the changes between the currently installed License Key and the newly loaded License Key. For more information, see [Installing License Key through Web Interface](#) on page 1235.

7. Click **Apply New License Key**; the following message box appears:

Apply New License Key X

A new local license key was loaded and a restart is required for it to take effect

The License Key is installed on the device with a restart. Current calls will be disconnected!

- Click **Restart**; the device saves the file to flash memory with a device restart, displaying a progress message box. When installation completes, the following message box appears:

- Click **Close** to close the message box; you are logged out of the Web interface and prompted to log in again. The features and capabilities displayed on the License Key page now reflect the newly installed License Key.

## Installing a License Key File

You can install the License Key as a file through the Web interface. The procedure depends if the device is in standalone mode (see [Installing on Standalone Devices](#) below) or operating in HA mode (see [Installing License Key on HA Devices](#) on the next page).

### Installing on Standalone Devices

You can install the License Key as a file through the Web interface when the device operates as a standalone device. For standalone devices, you can also install the License Key as a string, as described in [Installing a License Key String](#) on page 1236.



The License Key installation process includes a device restart and is therefore, traffic-affecting. To minimize disruption of current calls, it is recommended to perform this procedure during periods of low traffic.


#### ➤ To install License Key file through Web interface:

1. Place the purchased License Key file in a folder on the computer from where you are logged into the device.
2. Open the License Key page (see [Viewing the License Key](#) on page 1233).
3. Back up the currently installed License Key as a precaution. If the new License Key doesn't comply with your requirements, you can re-upload the backed-up License Key to restore the device's original capabilities. For backing up the License Key, see [Backing up Local License Key](#) on page 1242.
4. Click the **Load File** button to select the License Key file on your computer; the **Apply New License Key** button appears. The License Key page uses color-coded icons to indicate the changes between the currently installed License Key and the newly loaded License Key (see [Installing License Key through Web Interface](#) on page 1235).



If want to cancel installation, restart the device without a save to flash. For more information, see [Restarting the Device](#) on page 1203.

5. Click **Apply New License Key**; the following message box appears:



6. Click **Restart**; the device saves the file to flash memory with a restart and a progress message box appears. When installation completes, a message box appears informing you that the License Key was successfully loaded,
7. Click **Close** to close the message box; you are logged out of the Web interface and prompted to log in again. The features and capabilities displayed on the License Key page now reflect the newly installed License Key.

### Installing License Key on HA Devices

When the device operates in HA mode, you can install the License Key **only** from a License Key file.



The License Key file for HA contains two License Keys - one for the active device and one for the redundant device. Each License Key has a different serial number ("S/N"), which reflects the serial number of each device in the HA system.

You can install the License Key using one of the following methods:

- **Hitless Installation:** This method allows you to install the License Key on both active and redundant devices without affecting traffic. The installation process is as follows:
  - a. The License Key file is loaded to the active device.
  - b. The active device sends the file to the redundant device.
  - c. The redundant device installs the file and saves it to flash memory with a restart.
  - d. The active device saves the file to flash memory (**but without** a restart).
  - e. The devices undergo an HA switchover, whereby the active device becomes redundant and the redundant device becomes active. Current calls are maintained and handled by the active device (previously the redundant device).
  - f. The redundant device (previously the active device) restarts to install the file.



Hitless installation of the License Key is applicable only if the new License Key includes changes, compared to the currently installed License Key, within the limited set of features below:

- FEU
- SBC
- Coder Transcoding
- SBC Signaling
- WebRTC
- SIPREC

- **Non-hitless Installation:** This method allows you to install the License Key simultaneously on both active and redundant devices (both restart at the same time). Therefore, this method is traffic-affecting and current calls are terminated. The installation process is as follows:

- a. The License Key file is loaded to the active device.
- b. The active device sends the file to the redundant device.
- c. Both devices install the file and save it to flash memory with a restart.

➤ **To install License Key file for HA through Web interface:**

1. Place the purchased License Key file in a folder on the computer from where you are logged into the device.
2. Open the License Key page (see [Viewing the License Key](#) on page 1233).
3. Back up the currently installed License Key as a precaution. If the new License Key doesn't comply with your requirements, you can re-upload this backed-up License Key to restore the device's original capabilities. For backing up the License Key, see [Backing up Local License Key](#) on page 1242.
4. Click the **Load File** button to select the License Key file on your computer; the **Apply New License Key** button appears. The License Key page uses color-coded icons to indicate the changes between the currently installed License Key and the newly loaded License Key (see [Installing License Key through Web Interface](#) on page 1235).



If want to cancel the License key installation, restart the device without a save to flash. For more information, see [Restarting the Device](#) on page 1203.

5. Click **Apply New License Key**; the following appears:

Apply New License Key x

A new local license key was loaded. For the license key to take effect, perform a hitless license key update (Hitless-Apply) or reset the device

<p>The License Key is installed on both devices with a reset, using the active-redundant switchover method which doesn't affect current traffic.</p>	<p>The License Key is installed simultaneously on both devices with a reset. Current calls will be disconnected!</p>
<a href="#" style="background-color: #0070c0; color: white; padding: 5px 15px; text-decoration: none;">Hitless Installation</a>	<a href="#" style="background-color: #0070c0; color: white; padding: 5px 15px; text-decoration: none;">Non-Hitless Installation</a>


[Close](#)




If the new License Key includes changes in licenses for features other than (or in addition to) FEU, SBC, Codec Transcoding, and/or SBC Signaling, then you can **only** use the **Non-Hitless Installation** method. Instead of the above page, the Web interface displays a page prompting you to click **Reset** (or **Close** to cancel the operation) to perform a non-hitless installation. In this scenario, skip Step 5.

6. Click one of the following buttons:
  - **Hitless Installation:** Installs the License Key without affecting traffic by employing the HA switchover mechanism. When you click the button, the process starts and a message box is displayed indicating the installation progress:







When installation completes, the following message box appears:



- Non-Hitless Installation:** Installs the License Key simultaneously on both devices where both undergo a restart and therefore, current calls are terminated. When you click the button, the process starts and the following progress message box appears:



When installation completes, the following message box appears:



- Click **Close** to close the message box; you are logged out of the Web interface and prompted to log in again. The features and capabilities displayed on the License Key page now reflect the newly installed License Key.

## Installing License Key String through CLI

To install the License Key string through CLI, use the following command:

```
(config-system)# feature-key <"License Key string enclosed in double quotation marks">
```

To view the installed License Key, use the following command:

```
show system feature-key
```

## Verifying Installed License Key



To verify that the new License Key has been installed:

1. On the License Key page, check that the listed features and capabilities of the new License Key match those that you ordered.
2. Access the syslog server and check that the following message appears:  
"S/N<serial number> Key Was Updated. The Board Needs to be Reloaded with ini file\n"  
If the syslog server indicates that the License Key was unsuccessfully loaded (i.e., the "SN\_" line is blank), do the following preliminary troubleshooting procedures:
  - a. Open the License Key file and check that the "S/N" line appears. If it doesn't appear, contact your AudioCodes sales representative.
  - b. Verify that you have loaded the correct file. Open the file and ensure that the first line displays "[LicenseKeys]".
  - c. Verify that the content of the file has not been altered.

## Backing up Local License Key

You can back up the installed local License Key. This may be useful, for example, if you have installed a new License Key and you want to revert to the previous License Key.

### ➤ To back up local License Key:

1. Open the License Key page (see [Viewing the License Key](#) on page 1233).
2. Click one of the following buttons:
  -  : Saves the License Key as a file to a folder on your computer. By default, the device saves the License Key as a .txt file type with the name license.txt.
  -  : Copies the License Key as a string to your computer's clipboard. You can then paste the string into, for example, an e-mail message or a text-based program such as Notepad.

## OVOC-Managed Capacity Licenses

The device's licenses for SIPREC and SBC capacity (SBC sessions and far-end user registrations) can be provided and managed remotely by OVOC.

OVOC offers the following capacity licensing models:

- Fixed License Pool (see [Fixed License Pool Model](#) below)
- Floating License ([Floating License Model](#) on page 1245)
- Flex License ([Flex License Model](#) on page 1248)

### Fixed License Pool Model

The device can receive SBC capacity licenses from a centralized pool of SBC licenses that is located on and managed by AudioCodes OVOC management tool. The license pool is purchased for OVOC as one bulk license and is used to provide SBC licenses to multiple devices. The OVOC user manually allocates a specific number of SBC licenses per license type (see list below) from the pool to each device in the network. Whenever required, the OVOC user can increase or decrease the number of allocated SBC licenses according to the device's capacity demands. The allocation of licenses to the devices cannot exceed the purchased Fixed License pool.

The Fixed License pool includes the following SBC capacity license types:

- SBC Sessions (maximum number of concurrent SBC call sessions - media and signaling)
- Far End Users (maximum number of SIP endpoints or users that can be registered with the device)



- The Fixed License doesn't involve any configuration on the device; it is enabled and managed entirely by OVOC. For more information on the OVOC License Pool, refer to the *OVOC User's Manual*.

As an example of how the Fixed License pool allocates licenses, assume that the pool contains a maximum of 20 SBC far-end user (registration) licenses and it needs to service three devices (A, B and C). It can allocate 10 to A, 8 to B, and 2 to C. In this example, because all the far-end user licenses in the pool have been allocated, it cannot allocate any more far-end user licenses to the devices. However, if it de-allocates 5 licenses from A, for example, it can allocate these additional licenses to B and/or C.

As another example, assume that an OVOC tenant is allocated 500 SBC Session licenses to service 4 devices (A, B, and C), where each device has a capacity of 250 SBC sessions. If A and B are operating at maximum capacity (i.e. aggregated number of active SBC call sessions is 500), and C requires 50 SBC sessions, then C is taken out-of-service until the number of active calls on A and B combined drops to 450 sessions. When this occurs, the 50 free licenses can be allocated by the pool to C. If over a period of time, call traffic on A and B is showing a downward trend, the OVOC user can reallocate extra licenses to C.

The device periodically (and after a device restart or HA switchover if operating in HA mode) checks with OVOC for any SBC capacity license updates. OVOC identifies the device by serial number and sends licenses to the device according to OVOC configuration. If the device's local License Key already includes SBC capacity licenses, the SBC licenses allocated by OVOC are added to it (but up to the device's maximum supported capacity capabilities). When the device applies the licenses received from OVOC, the License Key page displays "License Pool" in the 'Mode' field (see [Viewing the License Key](#) on page 1233) and displays the allocated SBC licenses under the **SBC Capacity** group, as shown in the example below:

SBC CAPACITY			
	<u>Remote</u>	<u>Local</u>	<u>Actual</u>
SBC Sessions	5	10	15
SBC Signaling Sessions	2	5	7
SBC Media Sessions		5	5
Far End Users (FEU)	2	22	24
Transcoding Sessions	2	20	22

- 'Remote': This column displays the number of SBC licenses per license type received from the OVOC Fixed License pool.
- 'Local': This column displays the number of SBC licenses per license type from the locally installed License Key.
- 'Actual': This column displays the total SBC licenses per license type, which is the summation of the remote and local licenses.



(Standalone devices only) For the SBC licenses allocated by OVOC to take effect, the device **must** restart with a save to flash. The restart can be initiated by the OVOC user or locally on the device by you. The total licenses (displayed in the "Actual" column) is only updated once the device completes this restart.

Communication between the device and OVOC is through HTTPS (port 443) and SNMP. If a firewall exists in the network, make sure that ports for these applications are opened. If the device loses connectivity with OVOC for a long duration, it discards the allocated SBC licenses and restarts with its initial SBC licenses according to the local License Key. This mechanism prevents misuse of SBC licenses allocated by the OVOC license pool. Connectivity status with OVOC is displayed in the 'License Server Status' field on the License Key page (see [Viewing the License Key](#) on page 1233).

When the device operates in High-Availability (HA) mode, the SBC licenses allocated from the OVOC Fixed License pool are installed on the active and redundant devices without affecting traffic. This is achieved by the Hitless Installation mechanism:

1. OVOC downloads the licenses to the redundant device, and then restarts it.
2. OVOC triggers an HA switchover.

3. OVOC downloads the same licenses to the previously active device (now redundant), and then restarts it.
4. OVOC triggers another HA switchover.

The device sends the following SNMP alarms to indicate various conditions relating to the allocation of SBC licenses by the OVOC Fixed License pool:

- `acLicensePoolInfraAlarm` (OID 1.3.6.1.4.1.5003.9.10.1.21.2.0.106): Sent if the device loses connection with OVOC, for example.
- `acLicensePoolApplicationAlarm` (OID 1.3.6.1.4.1.5003.9.10.1.21.2.0.107): Sent when the device receives new SBC licenses from the Fixed License pool.
- `acLicensePoolOverAllocationAlarm` (OID 1.3.6.1.4.1.5003.9.10.1.21.2.0.125): Sent when the device receives new SBC licenses from the Fixed License pool, which has caused the device to exceed its maximum supported capacity.

For more information, refer to the [SBC-Gateway Series SNMP Alarm Reference Guide](#).



- The Fixed License only provides SBC capacity licenses (listed in the beginning of this section). Therefore, your device must still be installed with a local License Key to enable other ordered license-based features (e.g., Test Calls) and capacity.
- The allocation and de-allocation of SBC licenses to standalone devices by the OVOC Fixed License pool is service affecting because it requires a device restart.
- For HA systems, the OVOC Fixed License pool automatically allocates an equal number of SBC licenses to the active and redundant devices. For example, if the license pool allocates 200 signaling sessions to the active device, it also allocates 200 to the redundant. Therefore, it is important to take this into consideration when ordering a license pool.
- If the device is restored to factory defaults, the SBC licenses allocated by the OVOC Fixed License pool are removed and only the SBC licenses from the locally installed License Key are applied instead.
- If the device is allocated SBC licenses by the OVOC Fixed Licenses pool that exceeds the maximum number of sessions that the device can support, the device sets the number of sessions to its maximum supported capacity.
- The Fixed License pool cannot operate with the other OVOC-managed license modes (e.g., Floating License). Therefore, before using the Fixed License, make sure that the other license modes are disabled on the device and OVOC.

## Floating License Model

The Floating License is a network-wide license pool for SIPREC and SBC capacity, which is managed by AudioCodes OVOC and the cloud-based License Manager, and shared dynamically among multiple devices. The Floating License is a pay-as-you-grow service, eliminating the need to manually purchase additional licenses each time your capacity requirements increase. You initially purchase a Floating License based on your estimated capacity requirements. If you later experience business growth and your devices use more licenses (sessions) than specified by the

Floating License, you are billed for these additional licenses. In other words, the Floating License pool capacity can be exceeded.



- The Floating License model supports SIPREC session capacity licensing only from OVOC Version 8.0.3000 and later. If you are using an earlier OVOC version, SIPREC capacity is according to the device's **local** License Key only.
- To enable the use of the Floating License model for licensing WebRTC or SIPREC sessions, the device's local License Key must have WebRTC or SIPREC sessions (whichever functionality is required) set to zero (0).

The Floating License pool includes the following capacity license types:

- "SBC Sessions" - maximum number of concurrent SBC call sessions (media and signaling)
- "Far End Users" - maximum number of SIP endpoints (user agents) that can be registered with the device
- "SIPREC Streams" - maximum number of SIPREC sessions
- "SIPREC Redundancy Streams" - maximum number of SIPREC sessions for the standby SRS in the active-standby redundancy pair

As an example of how the Floating License pool operates, assume that an OVOC tenant is allocated 500 SBC Session licenses and the tenant has deployed three devices (A, B, and C), where each device has a maximum capacity of 250 SBC sessions. If A and B are operating at maximum capacity (i.e. the aggregated number of active SBC call sessions is 500), and then C requires 50 SBC sessions, even though the initially purchased Floating License pool capacity has been reached (500), C is allowed to process these 50 new call sessions. When you are next billed, you are charged for these extra 50 SBC session licenses.

For providing the Floating License service, OVOC and the Cloud License Manager need to be set up accordingly (refer to the *OVOC User's Manual*). The Floating License service also needs to be enabled on these devices. Once these devices connect to OVOC, they are "open" to use any number of licenses in the Floating License pool. However, capacity is limited by the device's inherent maximum capacity support and by an optional user-defined limit called *Allocation Profile* (discussed later in this section), which specifies a capacity that is less than the device's inherent capacity per SBC license type.

Connection between the devices and OVOC is established over SNMP. Functionality of the Floating License service is managed over TCP/HTTPS REST. For more information, see the *One Voice Operations Center IOM Manual* and the *OVOC Security Guidelines*. Connectivity status with OVOC is displayed in the 'License Server Status' field on the License Key page (see [Viewing the License Key](#) on page 1233). If the device loses connectivity with OVOC, it continues using the licenses that it received before the disconnection for a specific grace period, and then once this period expires, it stops accepting new calls.

The devices report their SBC license consumption per license type to OVOC at fixed intervals (typically, every five minutes). OVOC accumulates these reports and sends them to AudioCodes Cloud License Manager every 12 hours with all the SBC licenses usage in the last 12 hours. OVOC uses REST APIs over HTTPS to report to the Cloud License Manager. AudioCodes

personnel analyze these license consumption reports in the Cloud License Manager on a monthly basis to check if capacity specified by your Floating License was exceeded. If it was exceeded, AudioCodes sends you a report detailing the excess licenses and requests that you purchase additional SBC licenses for your Floating License. To view the Floating License reports of SBC license consumption that the device sends OVOC, see [Viewing Floating or Flex License Reports](#) on page 1255.

When the device uses the Floating License, the License Key page (see [Viewing the License Key](#) on page 1233) displays "Floating License" in the 'Mode' field and displays the capacity licenses received from the Floating License under the **VoIP Capacity** group, as shown in the following example:

VOIP CAPACITY			
	<u>Local</u>	<u>Floating</u>	<u>Actual</u>
Far End Users (FEU)	<del>5</del>	0	0
SBC Media Sessions		250	250
SBC Signaling Sessions		250	250
Transcoding Sessions		0	0
SBC Sessions	<del>2</del>		

- 'Local': Displays the licensed capacity from the locally installed License Key. These licenses are not used by the device and the figures are displayed crossed out (strikethrough).
- 'Floating': Displays the number of licensed capacity received from the OVOC Floating License pool.
- 'Actual': (see the 'Floating' above).

The device sends the following SNMP alarms to indicate various conditions relating to the allocation of licenses from the OVOC Floating License pool:

- acFloatingLicenseAlarm: Sent if you have configured an Allocation Profile that exceeds the device's maximum supported capacity.
- acCloudLicenseManagerAlarm: Sent upon various conditions such as loss of connectivity between the device and OVOC.

For more information, refer to the [SBC-Gateway Series SNMP Alarm Reference Guide](#).



- The Floating License only provides the SIPREC and SBC capacity licenses (listed previously). Therefore, your device must still be installed with a local License Key to enable the other ordered license-based features (e.g., Test Calls) and capacity.
- The Floating License uses the device's IPv4 OAMP interface.
- For configuring the Floating License on OVOC, refer to the *OVOC User's Manual*.
- The Floating License cannot operate with other OVOC-managed capacity license modes (e.g., Fixed License). Therefore, before enabling the Floating License, make sure that the other license modes are disabled on OVOC.
- The Floating License ignores OVR, TDM2SBC, and LAD capacity licenses in the local License Key.

## Flex License Model

The Flex License model is a network-wide license for SIPREC and SBC capacity, managed by AudioCodes OVOC, which is dynamically shared among multiple devices. The Flex License is ordered as a single license, which provides a pool of these licenses that cannot be exceeded. The Flex License pool includes the following capacity license types:

- "SBC Sessions" - maximum number of concurrent SBC call sessions (media and signaling)
- "Far End Users" - maximum number of SIP endpoints (user agents) that can be registered with the device
- "SIPREC Streams" - maximum number of SIPREC sessions
- "SIPREC Redundancy Streams" - maximum number of SIPREC sessions for the standby SRS in the active-standby redundancy pair



The Flex License model supports SIPREC capacity licensing only from OVOC Version 8.0.3000 and later. If you are using an earlier OVOC version, SIPREC capacity is according to your local License Key only.

The Flex License model is similar to the Floating License model (as described in [Floating License Model](#) on page 1245), but provides some important advantages:

- The Flex License is solely managed by OVOC; it doesn't employ a cloud-based license manager like the Floating License. This reduces the exposure of OVOC to security risks from its connectivity with the public cloud.
- The Flex License gracefully enforces license capacity of the pool, whereas the Floating License allows devices to exceed pool capacity, resulting in you being billed at the end of the month for unexpected license usages.

The Flex License is managed by OVOC, which defines the devices using the Flex License. Once connected to OVOC, each device can handle calls using the licenses of the different license types in the Flex License pool, as long as the pool has available (unused) licenses. However, the device's capacity is limited by its inherent maximum capacity support and by an optional user-



defined limit called *Allocation Profile* (discussed later in this section), which specifies a capacity that is less than the device's inherent capacity per license type.

The devices periodically (typically, every five minutes) report their current license consumption (usage) per license type to OVOC. OVOC uses these reports to calculate the total number of currently used licenses from the pool and therefore, determines the remaining licenses in the pool per license type. To view the license usage reports, see [Viewing Floating or Flex License Reports](#) on page 1255.

Each device in OVOC is configured with a priority level (Low, Normal, or Critical). When all the licenses of a specific license type in the Flex License pool are being used (or even exceeded) by the devices, OVOC uses this priority level to determine which of the devices to initially "take out" of service. OVOC first notifies a certain percentage of devices of this "over-license" status, instructing them to **reject all new calls** that require this specific license type. This percentage of devices starts from those with Low priority level, then Normal priority level, and lastly Critical priority level.

For example, assume there are 100 devices in the network, 10 configured with Low priority, 20 with Normal priority, and 70 with Critical priority, and OVOC notifies 20% of them of an "over-license" state for a specific license type. In this example, OVOC takes out of service the 10 devices with Low priority and 10 devices with Normal priority (i.e., total of 20, which is 20% of 100). This selective process allows devices with higher priority to continue providing call service, while attempting to restore licenses to the Flex License pool due to the rejection of new calls by the selected devices. During this period, the devices send their usage reports more frequently to OVOC, providing OVOC with a more up-to-date status of license usages in the network. If licenses become available for the specific license type in the pool, OVOC allows the selected devices to start accepting new calls ("ok" status). However, if after a certain period there are still unavailable licenses for the specific license type in the pool, OVOC notifies all devices (including those with Critical priority level) of this "over-license" status, and instructs **all of them to reject new calls**. To view the device's current license utilization (in percentage) per license type of the OVOC Flex License pool and the status ("ok" and "overlicense") of each license type, see [Viewing Flex License Utilization and Status](#) on page 1252.

Connection between the devices and OVOC is established over SNMP and functionality of the Flex License service is managed over TCP/HTTPS REST. If the device loses connectivity with OVOC, the device continues handling calls for a graceful period. If connectivity is not restored when this period expires, the device is blocked from handling new calls. When the device succeeds in connecting again with OVOC, it continues using the Flex License pool as normal.

When the device uses the Flex License, the License Key page (see [Viewing the License Key](#) on page 1233) displays "Flex License" in the 'Mode' field and displays the licensed capacity received from the Flex License pool per license type under the **VoIP Capacity** group, as shown in the following example:

## VOIP CAPACITY

	<u>Local</u>	<u>Flex</u>	<u>Actual</u>
Far End Users (FEU)	<del>240</del>	10	200
SBC Media Sessions		9	20
SBC Signaling Sessions		12	60
Transcoding Sessions		5	120
SBC Sessions	<del>240</del>		

- 'Local': Displays the number of licensed capacity per license type from the locally installed License Key. These licenses are not used by the device and the figures are displayed crossed out (strikethrough).
- 'Flex': Displays the maximum number of licensed capacity per license type in the OVOC Flex License pool.
- 'Actual': (This column can be ignored.)



After a device restart or HA switchover, the figures in the 'Flex' column appear only after the device receives its first report from OVOC on the Flex License pool capacity. This typically takes about five minutes.

The device sends the following SNMP alarms to indicate various conditions relating to the OVOC Flex License pool:

- **acFloatingLicenseAlarm:** Sent if you have configured an Allocation Profile that exceeds the device's resource capability.
- **acCloudLicenseManagerAlarm:** Sent upon various conditions such as loss of connectivity between device and OVOC.

For more information, refer to the document [SBC-Gateway Series SNMP Alarm Reference Guide](#).



- For configuring the Flex License on OVOC, refer to the document *OVOC User's Manual*, which can be downloaded from AudioCodes [website](#).
- The Fixed License only provides SIPREC and SBC capacity licenses (listed in the beginning of this section). Therefore, your device must still be installed with a local License Key to enable other ordered license-based features (e.g., Test Call) and capacity.
- The Flex License cannot operate with the other OVOC-managed license modes (e.g., Fixed License and Floating License). Therefore, before enabling the Flex License, make sure that the other license modes are disabled on OVOC.
- The Flex License ignores OVR, TDM2SBC, and LAD capacity licenses in the local License Key.

## Enabling Floating or Flex License

Before you can use the Floating or Flex license, you need to enable this feature.





Prior to enabling the Floating or Flex License, make sure that the following OVOC-related prerequisites have been fulfilled:

- The Floating or Flex License has been purchased from AudioCodes with the required SBC license capacities and installed on OVOC.
  - The devices for which you want to use the Floating or Flex License have been configured on OVOC.
  - For Floating License, OVOC has been configured for communication with AudioCodes Cloud License Manager.
  - For Flex License, the devices have been configured with priority levels on OVOC.
- For more information on configuring and managing the Floating or Flex License on OVOC, refer to the document *OVOC User's Manual*, which can be downloaded from AudioCodes [website](#).

### ➤ To enable the Floating or Flex License:

1. Open the Floating License page (**Setup** menu > **Administration** tab > **License** folder > **Floating License**).
2. From the 'Floating License' drop-down list, select **Enable**.

**Figure 44-1: Enabling the Floating or Flex License**

GENERAL	
Floating License	Enable 
Connection with OVOC	Connected 
OVOC IP Address	10.8.6.250
OVOC Product Key	F83FBC1BFBCF

3. Restart the device with a save-to-flash for your settings to take effect. After the device restarts, it connects with OVOC and OVOC-related information is displayed in the read-only fields:
  - **'Connection with OVOC':** Displays the device's connectivity status with OVOC:
    - ◆ "Connected": The device is connected to OVOC.
    - ◆ "Disconnected" The device has disconnected from OVOC due to problems with the network (HTTPS TCP connection).
    - ◆ "Not Connected": The device is not connected to OVOC.
  - **'OVOC IP Address':** Displays the IP address of OVOC.

- **'OVOC Product Key':** Displays the Product Key of OVOC that is providing the Floating or Flex License.



Once you enable the Floating or Flex License, OVOC initiates a connection with the device. In other words, you don't configure the address of OVOC. The device connects with OVOC over SNMP and an SNMP manager is automatically added to the SNMP Trap Destinations table for this connection (see [Configuring SNMP Trap Destinations](#) on page 110).

The status of the Floating License or Flex License is also displayed on the top bar of the License Key page, as shown below (e.g., Flex License mode):

Product Key	E25B13DE2205	Flex License	2576900	72	Connected
	OVOC Product Key	Mode	Serial Number	Device Type	License Server Status

- **'OVOC Product Key':** Product Key of the OVOC tool providing the Floating License or Flex License
- **'Mode':** Indicates the license type:
  - "Floating License": Floating License mode
  - "Flex License": Flex License mode
- **'License Server Status':** Connectivity status with OVOC (for more information, see [Viewing the License Key](#) on page 1233)

## Viewing Flex License Utilization and Status

You can view the device's current license utilization (in percentage) per license type of the OVOC Flex License pool.



- The **Flex Pool** group (below) appears only if you have enabled the Floating License or Flex License feature (see [Floating License Model](#) on page 1245).

### ➤ To view Flex License utilization and status:

1. Open the Floating License page (**Setup** menu > **Administration** tab > **License** folder > **Floating License**).
2. Scroll down to the **Flex Pool** group:

## FLEX POOL

	Utilization	Status
SBC Media Sessions	66.67%	OK
SBC Signaling Sessions	50.00%	OK
Far End Users	<1%	OK
Transcoding Sessions	120.00%	Reached/ Exceeded License
WebRTC Sessions	<1%	OK
SIPREC Streams	<1%	OK

- 'Utilization': Displays the percentage (%) of the license capacity per license type in the OVOC Flex License pool that the device is currently using. Utilization of less than 1% is displayed as "<1%".
- 'Status': Displays the utilization status of the OVOC Flex License pool by all devices:
  - ◆ "OK": Utilization is within the pool capacity.
  - ◆ "Reached/Exceeded License": Utilization has reached or exceeded the Flex License pool capacity. In this case, OVOC first attempts to return licenses to the pool by instructing certain devices (based on their priority level) to block new calls. If this doesn't help after a graceful period, OVOC instructs all devices to block new calls until licenses return to the pool. For more information, see [Flex License Model](#) on page 1248

## Configuring Floating or Flex License Allocation Profiles

The Floating and Flex License allows you to configure *Allocation Profiles*, which specify license capacity per license type that you want allocated to the device by OVOC. For example, you may want to limit the device to only 20 Far End Users, even though OVOC could allocate up to 100 Far End Users.

You can choose a default Allocation Profile (**SIP Trunking** or **Registered Users**) that has a predefined capacity suited for these applications, or you can configure a customized Allocation Profile. In addition, once you have chosen an Application Profile and restarted the device to apply it, you can easily reduce (*limit*) the predefined capacity or customized capacity when needed, without restarting the device.



You can only configure Allocation Profiles once you have enabled the Floating or Flex License (see [Enabling Floating or Flex License](#) on page 1251).

➤ **To configure Allocation Profiles:**

1. Open the Floating License page (**Setup** menu > **Administration** tab > **License** folder > **Floating License**).
2. From the 'Allocation Profile' drop-down list, select an SBC license Allocation Profile:
  - **SIP Trunking:** Provides default capacity (cannot be modified) in the 'Allocation' field per license type and is suited for SIP Trunking applications (i.e., where user registration is typically not required). You can later reduce the capacity using the 'Limit' field after you restart the device, as described in Step 4.
  - **Registered Users:** Provides default capacity (cannot be modified) in the 'Allocation' field per license type and is suited for applications where user registration is required. You can later reduce the capacity using the 'Limit' field after you restart the device, as described in Step 4.
  - **Custom:** Allows you to configure a customized Allocation Profile. In the 'Allocation' field corresponding to each license type, configure the desired capacity.

**Figure 44-2: Configuring Allocation Profile (e.g., Custom)**

Allocation Profile	Allocation ⚡	Limit
Far End Users	1600	<input type="checkbox"/>
SBC Media Sessions	400 <small>Range: 0-400</small>	<input type="checkbox"/>
SBC Signaling Sessions	400	<input type="checkbox"/>
Transcoding Sessions	60	<input type="checkbox"/>
WebRTC Sessions	60	<input type="checkbox"/>
SIPREC Streams	60	<input type="checkbox"/>



When configuring a customized Allocation Profile (i.e., 'Allocation Profile' configured to **Custom**):

- To view the device's maximum supported capacity per license type, hover your mouse over the corresponding 'Allocation' field and a pop-up appears displaying the capacity.
- The 'Transcoding Sessions' license type capacity cannot be modified in the 'Allocation' field. However, you can reduce the license using its corresponding 'Limit' field, as described below.

3. Restart the device with a save-to-flash for your settings to take effect.

4. You can now reduce each SBC license type capacity whenever needed **without** restarting the device:
  - a. Select the check box corresponding to the license type you want reduced.
  - b. In the corresponding 'Limit' field, enter a new capacity. The value can be equal to or less than the value in the 'Allocation' field.
  - c. Click **Apply**.

The figure below shows an example of using the 'Limit' field to reduce the allocation of SBC Media Sessions to 40 and the SBC Signaling Sessions to 80 for the **SIP Trunking** Allocation Profile:

**Figure 44-3: Configuring Limits for Allocation Profile**

ALLOCATION			
Allocation Profile	Allocation	Limit	
SIP Trunking	250	40	<input checked="" type="checkbox"/>
SBC Media Sessions	250	80	<input checked="" type="checkbox"/>
SBC Signaling Sessions	0		<input type="checkbox"/>
Far End Users	15		<input type="checkbox"/>
Transcoding Sessions			

## Viewing Floating or Flex License Reports

You can view resource consumption reports of the Floating or Flex License that the device periodically sends to OVOC. This includes SBC capacity (signaling sessions, media sessions, transcoding sessions, and far-end user registrations), and SIPREC streams.



- The Floating License Reports page is available only if you have enabled the Floating License or Flex License feature (see [Floating License Model](#) on page 1245).

### ➤ To view the Floating License or Flex License Report through Web interface:

- Open the Floating License Reports page (**Setup** menu > **Administration** tab > **License** folder > **Floating License Reports**).


REPORT DATE	SIGNALING SESSIONS	FAR END USERS	TRANSCODING SESSIONS	MEDIA SESSIONS	WEBRTC SESSIONS	SIPREC STREAMS
2022-01-19 17:04:37	0	0	0	0	0	0
2022-01-19 17:03:37	0	0	0	0	0	0
2022-01-19 17:02:36	0	0	0	0	0	0
2022-01-19 17:01:36	0	0	0	0	0	0
2022-01-19 17:00:36	0	0	0	0	0	0

## Viewing the Device's Product Key

The Product Key identifies a specific purchase of your device installation for the purpose of subsequent communication with AudioCodes (e.g., for support and software upgrades). The Product Key is your chassis' serial number--"S/N(Product Key)"--which also appears on the product label affixed to the chassis.

The Product Key is included in the License Key. You can view the Product Key on the following Web pages:

- License Key page (see [Viewing the License Key](#) on page 1233). The Product Key is displayed in the read-only 'Product Key' field, as shown in the example below:



- Device Information page (see [Viewing Device Information](#) on page 1312).

If your License Key was purchased in an earlier version, the 'Product Key' field may appear empty.



## 45 Downloading and Uploading Configuration Files

This section describes how to download and upload the device's configuration:

- ini file - see [Downloading or Uploading ini File](#) below
- CLI Script file - see [Downloading or Uploading CLI Script File](#) on the next page
- CLI Startup Script file -see [Uploading CLI Startup Script File](#) on page 1259
- Configuration Package file - see [Downloading or Uploading Configuration Package File](#) on page 1260

### Downloading or Uploading ini File

You can download the device's configuration as an ini file to a folder on your computer or upload an ini file to the device. Downloading an ini file can serve as a backup of your configuration and if needed, you can later upload the file to the device to restore your previous configuration settings.

The file is downloaded as a .ini file with the file name "BOARD\_SN<Serial>" (e.g., BOARD\_SN5967925.ini). The uploaded file must have a .ini extension (and any file name).



- When uploading the file, the device restarts for the parameter settings to take effect.
- When uploading the file, parameters not included in the file **are restored to default settings**. If you want to keep the device's current configuration settings and also apply the settings specified in the ini file, upload the file through the Auxiliary Files page (see [Uploading Auxiliary Files through Web Interface](#) on page 1221).
- The downloaded file includes only the following:
  - ✓ Configuration tables that contain row entries (default and non-default).
  - ✓ Standalone parameters whose values you changed from default. However, it also includes parameters whose values you changed from non-default back to default without subsequently restarting the device. If you changed from non-default back to default but subsequently restart the device, then they'll not be included.
  - ✓ All SNMP performance monitoring MIBs whose threshold values (low or high) you changed from default. (To apply these same threshold values to other devices, upload the ini file to the devices.)
  - ✓ The device's License Key. If the device is in High-Availability mode, the ini file of the Active device also includes the Redundant device's License Key.
- To download the file to a USB device plugged into the device, use the following CLI command: # write-and-backup to usb:///<file name>

#### ➤ To download or upload an ini file through Web interface:

1. Open the Configuration File page:
  - **Toolbar:** From the **Actions** drop-down menu, choose **Configuration File**

- **Navigation tree:** Setup menu > Administration tab > Maintenance folder > Configuration File

The relevant buttons for downloading and loading an ini file are located under the INI File group:

Download INI file to the PC

Download INI File

Upload INI file to the device.

Choose File

No file chosen

Upload INI File

2. To download the file, click the **Download INI File** button, and then save the file to a folder on your computer.
3. To upload the file:
  - a. Click the **Choose File** button, and then browse to and select the .ini file on your computer.
  - b. Click the **Upload INI File** button; a message box appears, informing you that the device will restart.
  - c. Click **Yes** to continue; the device uploads the file and then restarts with a save to flash for the settings to take effect.

## Downloading or Uploading CLI Script File

You can download the device's configuration as a CLI Script file to a folder on your computer or upload a CLI Script file to the device. Downloading the file to your computer can serve as a backup of your configuration and if needed, you can later upload the file to the device to restore previous configuration settings.

The file is download as a .cli file with the file name "BOARD\_SN<Serial Number>" (e.g., BOARD\_SN5967925.cli). The uploaded file must have the .cli extension (and any file name).



- When uploading the file, you need to restart the device if it contains the **reload now** command (on the last line).
- The downloaded file includes only parameters whose values you have modified.
- To save the file to a remote server (TFTP or HTTP/S), use the following CLI command: `# write-and-backup to <URL with file name>`
- To download the file to a USB stick plugged into the device: `# write-and-backup to usb:///<file name>`

### ➤ To download or upload a CLI Script file:

1. Open the Configuration File page:
  - **Toolbar:** From the **Actions** drop-down menu, choose **Configuration File**

- **Navigation tree:** Setup menu > Administration tab > Maintenance folder > Configuration File

2. To download the file:

- a. Under the CLI Script group, click the **Download CLI Script File** button, and then save the file to a folder on your computer.

Download CLI Script file to the PC

Download CLI Script File

3. To upload the file:

- a. Under the CLI Script group, click the **Choose File** button, and then browse to and select the .cli file on your computer.

Upload CLI Script file to the device.

Choose File No file chosen

Upload CLI Script File

- b. Click the **Upload CLI Script File** button; the device uploads the file and displays a message box confirming when the file has been successfully uploaded:

Upload CLI Script File

x

File was uploaded successfully!

Close

- c. Click **Close**.
- d. If the CLI Script file contains changes to configuration, click the **Save** button on the toolbar to save your settings to flash memory. If a device restart is required for the new settings to take effect, instead of clicking the **Save** button, click the **Restart** button (which appears with a red border).

## Uploading CLI Startup Script File

You can upload a CLI Startup Script file to the device. The uploaded file must have a .cli extension (and any file name).



- The CLI Startup Script file is not supported when the device operates in HA mode.
- When uploading the file, the device restarts twice for its settings to take effect.

### ➤ To upload a CLI Startup Script file:

1. Open the Configuration File page:

- **Toolbar:** From the **Actions** drop-down menu, choose **Configuration File**.
  - **Navigation tree:** **Setup** menu > **Administration** tab > **Maintenance** folder > **Configuration File**.
2. Under the CLI Startup Script to the device group, click the **Choose File** button, and then browse to and select the .cli file on your computer.

Upload CLI Startup Script to the device.

Choose File

No file chosen

Upload CLI Startup Script

3. Click the **Upload CLI Startup Script** button; the following message box appears:

Upload CLI Startup Script File

X

After the file is uploaded to the device, the device will automatically restart. Do you want to continue?

No

Yes

4. Click **Yes** to continue; the device uploads the file and then restarts with a save to flash for the settings to take effect.

## Downloading or Uploading Configuration Package File

You can download and upload a bundle of files used by the device in a single, packaged file called the Configuration Package file. This file is in 7-Zip archive file format (.7z) using the LZMA2 compression algorithm. In addition, you can optionally password-protect the file and encrypt it using the AES-256 algorithm.

You can use the Configuration Package file to fully back up the device's configuration. If needed, you can later restore the device to this backup configuration for whatever reason (e.g., configuration failure). You can also upload the Configuration Package file to other devices that need similar configuration.

The Configuration Package file can include the following files:

File	Description
ini.ini	INI configuration file.
cli-startup-script.txt	CLI Startup Script file. <b>Note:</b> This file is applicable only for uploading a Configuration Package file.

File	Description
<TLS Context ID>.pkey	Private key of the TLS Context (by ID). <b>Note:</b> You can only choose to include certificates in the Configuration Package file if you enable the password-protect (encrypt) option.
<TLS Context ID>.crt	TLS certificate of the TLS Context (by ID). <b>Note:</b> You can only choose to include certificates in the Configuration Package file if you enable the password-protect (encrypt) option.
<TLS Context ID>.root	Trusted root certificate of the TLS Context (by ID). <b>Note:</b> You can only choose to include certificates in the Configuration Package file if you enable the password-protect (encrypt) option.
LOGO.dat	Image file used as the logo in the Web interface.
FAVICON.dat	Favicon file used by Web browsers to represent the device's Web interface.
CPT.dat	Call Progress Tone file (CPT).
PRT.dat	Pre-recorded Tone file (PRT).
AMD.dat	Answer Machine Detection file (AMD).
SBC_WIZARD.dat	SBC Configuration Wizard template file
CAS-<ID>.dat	CAS file.
DPLN.dat	Dial Plan file. <b>Note:</b> Only for backward compatibility for versions that supported a Dial Plan file. For current versions, the Dial Plan is included in the ini file.
DialPlanRule.csv	Dial Plan file.



- The device downloads the Configuration Package file with the name "ConfBackupPkg<Serial Number>.7z".
- When uploading the Configuration Package file, the device restarts for the settings to take effect.
- The Configuration Package file is included in the device's debug file and core dump file (see [Debug \(and Core Dump\) File Contents](#) on page 1527).
- The device's SNMP MIB allows OVOC to back up the Configuration Package file. OVOC only uploads the file if it was modified, compared to the current file in OVOC, using file checksum (acSysConfigurationPackageChecksum).
- For configuring (and clearing) an encryption key for password obfuscation using the Configuration Package file, see [Password Obfuscation in CLI Script and ini Files](#) on page 209.
- For backward compatibility, a Configuration Package file in TAR format (.tar.gz) can still be uploaded to the device.

You can download or upload the Configuration Package file, using the following methods:

#### ■ CLI:

```
# copy configuration-pkg from|to <URL> [encrypted <password>] [certificates]
```



- For uploading a Configuration File that is password-protected, use the `encrypted` option to specify the password: `copy configuration-pkg from <URL> encrypted <password>`
- For downloading the Configuration File, if you want to password-protect it (and optionally include the TLS certificates), use the `encrypted` and `certificates` options, respectively: `copy configuration-pkg from <URL> encrypted <password> certificates`

#### ■ Auto-Update Mechanism:

```
(config-system)# automatic-update
(auto-update)# configuration-pkg <URL>
```

If the file is password-protected, specify the password using the following CLI command:

```
(config-system)# automatic-update
(auto-update)# default-configuration-package-password <password>
```

- **SFTP:** You can also download (Get) the Configuration Package file through SFTP. The file is located in the device's `/configuration` directory. Your SFTP client needs to authenticate itself with the SFTP server (i.e., the device).

**SFTP Notes:**

- You can access the `/configuration` folder only if you are a **Security Administrator** user.
- The Configuration Package file can only be downloaded.
- When the file is password-protected, it includes the TLS certificates and the file is listed in the device's `/configuration` directory as `configuration-package-full.7z`. If it's not password-protected (and therefore, doesn't include certificates), the file is listed as `configuration-package.7z`.
- For configuring the password for protecting the Configuration Package file, see [Configuring Default Password for Configuration Package File](#) on the next page.

■ **Web interface:**

- a. Open the Configuration File page:

- ◆ **Toolbar:** From the **Actions** drop-down menu, choose **Configuration File**
- ◆ **Navigation tree:** **Setup** menu > **Administration** tab > **Maintenance** folder > **Configuration File**

#### CONFIGURATION PACKAGE

Encrypted Configuration Package ☐

Download Configuration Package to the PC.

Download Configuration Package

Upload Configuration Package to the device.

Choose File No file chosen

Upload Configuration Package

- b. To download Configuration Package file:

- To password-protect the file, select the 'Encrypted Configuration Package' check box.
- Click the **Download Configuration Package** button; if the 'Encrypted Configuration Package' check box was selected, the following dialog box appears (otherwise, the file is downloaded to your computer):

Download Configuration Package
X

Password

Verify

☐ Include Private Keys and device Certificates

No

Yes

- In the 'Password' and 'Verify' fields, type the password to protect the file.

- iv. To include the TLS certificates, select the 'Include Private Keys and device Certificates' check box.
- v. Click **Yes**.
- c. **To upload Configuration Package file:**
  - i. If the file is password-protected, select the 'Encrypted Configuration Package' check box.
  - ii. Click the **Choose File** button, and then browse to and select the file on your computer.
  - iii. Click the **Upload Configuration Package** button:

If the file is password-protected (i.e., you selected the check box in Step i), the following appears:

**Upload Configuration Package** X

After the file is uploaded to the device, the device will automatically restart. Do you want to continue?

Password

---

No **Yes**

If the file is not password-protected (i.e., you didn't select the check box in Step i), the following appears:

**Upload Configuration Package** X

After the file is uploaded to the device, the device will automatically restart. Do you want to continue?

---

No **Yes**

- iv. If the file is password-protected, in the 'Password' field, type the password.
- v. Click **Yes**; the device uploads the file and then restarts with a save to flash for the settings to take effect.

## Configuring Default Password for Configuration Package File

You can configure the default password that protects (encrypt) the Configuration Package file for the following scenarios:



- When uploading a password-protected Configuration Package file to the device through the Automatic Update feature (see the `configuration-pkg` command).
- When downloading a password-protected Configuration Package file from the device through SFTP.

➤ **To configure default password for Configuration Package file:**

1. Open the Administration Settings page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Administration Settings**).
2. In the 'Default password for configuration package' field, type the password.
3. Click **Apply**.

## 46 Automatic Provisioning

This chapter describes automatic provisioning of the device.

### Automatic Configuration Methods

The device supports the following automatic provisioning methods:

- DHCP (Option 66, Option 67, Option 160)
- HTTP/S
- TFTP
- FTP
- SNMP (AudioCodesOVOC)

### DHCP-based Provisioning

You can use a third-party DHCP server to automatically provide each device (acting as a DHCP client) with an IP address for the management interface so that individual MAC addresses are not required. The DHCP server can provide additional networking parameters such as subnet mask, default gateway, primary and secondary DNS servers, and two SIP server addresses. These network parameters have a time limit, after which the device 'renews' its lease on the addresses from the DHCP server.

The device can use a host name in the DHCP request. The host name is set to "acl\_nnnnn", where *nnnnn* denotes the device's serial number. The serial number is the last six digits of the device's MAC address converted into decimal representation. In networks that support this feature and if the DHCP server registers this host name to a DNS server, you can access the device (through a Web browser) using the URL "http://acl\_<serial number>" instead of the device's IP address. For example, if the device's MAC address is 00908f010280, the DNS name is "acl\_66176".



- For DHCP-based provisioning of IPv4 or IPv6 interfaces, in the IP Interfaces table, configure the IP Interface with the 'Interface Mode' parameter set to **IPv4 DHCP** or **IPv6 DHCP** respectively (see [Configuring IP Network Interfaces](#) on page 157).
- When using DHCP to acquire an IP address, VLANs and other advanced configuration options are disabled.
- For additional DHCP parameters, see [DHCP Parameters](#) on page 1618.

#### ➤ To enable device as a DHCP client:

1. In the IP Interfaces table, configure the IP Interface with the 'Interface Mode' parameter set to **IPv4 DHCP** or **IPv6 DHCP** (depending on IP version).
2. Restart the device to activate the DHCP process.

The following shows an example of a configuration file for a Linux DHCP server (dhcpd.conf). The devices are allocated temporary IP addresses in the range 10.31.4.53 to 10.31.4.75. TFTP is assumed to be on the same computer as the DHCP server (alternatively, the "next-server" directive may be used).

```
ddns-update-style ad-hoc;  
default-lease-time 60;  
max-lease-time 60;
```

```
class "gateways" {  
    match if(substring(hardware, 1, 3) = 00:90:8f);  
}  
subnet 10.31.0.0 netmask 255.255.0.0 {  
    pool {  
        allow members of "AudioCodes";  
        range 10.31.4.53 10.31.4.75;  
        filename "SIP_F6.60A.217.003.cmp -fb;device.ini";  
        option routers          10.31.0.1;  
        option subnet-mask      255.255.0.0;  
    }  
}
```



- If the DHCP server denies the use of the device's current IP address and specifies a different IP address (according to RFC 1541), the device must change its networking parameters. If this occurs while calls are in progress, they are not automatically rerouted to the new network address. Therefore, administrators are advised to configure DHCP servers to allow renewal of IP addresses.
- If the device's network cable is disconnected and then reconnected, a DHCP renewal is performed (to verify that the device is still connected to the same network). The device also includes its product name in the DHCP Option 60 Vendor Class Identifier. The DHCP server can use this product name to assign an IP address accordingly.
- After power-up, the device performs two distinct DHCP sequences. Only in the second sequence is DHCP Option 60 included. If the device is software restart (e.g., from the Web interface or SNMP), only a single DHCP sequence containing Option 60 is sent.

### Provisioning from HTTP Server using DHCP Option 67

You can provision the device through HTTP using DHCP Option 67. In this setup, DHCP Option 67 informs the device of the URL address of the HTTP server from where it can download the configuration file. This provisioning method is possible only if the DHCP server allows configuration of DHCP Option values for different equipment in the network.

Upon device startup, the device sends a DHCP request. The DHCP response received from the DHCP server contains IPv4 networking (e.g., management IP address and DNS server) information. In addition, the response includes DHCP Option 67, which specifies the URL address of the HTTP server where the device's configuration file is located. The device then automatically downloads the configuration file from this HTTP server.

Below is an example of a configuration file (dhcpd.conf) of a Linux-based DHCP server, showing the required format of Option 67:

```
ddns-update-style ad-hoc;
default-lease-time 3600;
max-lease-time 3600;
```

```
class "AudioCodes" {
    match if(substring(hardware, 1, 3) = 00:90:8f);
}
subnet 10.31.0.0 netmask 255.255.0.0 {
    pool {
        allow members of "AudioCodes";
        range 10.31.4.53 10.31.4.75;
        option routers          10.31.0.1;
        option subnet-mask      255.255.0.0;
        option domain-name-servers 10.1.0.11;
        option bootfile-name     "INI=http://www.corp.com/master.ini";
        option dhcp-parameter-request-list 1,3,6,51,67;
    }
}
```



- The value of Option 67 must include the URL address, using the following syntax: "INI=<URL with ini file name>"
- This method is NAT-safe.

➤ **To configure the device for automatic provisioning through HTTP/S using DHCP Option 67:**

1. In the IP Interfaces table, configure the IP Interface with the 'Interface Mode' parameter set to **IPv4 DHCP** or **IPv6 DHCP** (depending on IP version).
2. Enable the device to include DHCP Option 67 in DHCP Option 55 (Parameter Request List) when requesting HTTP provisioning parameters from a DHCP server, using the following ini file parameter:

```
DHCPRequestTFTPParams = 1
```

3. Restart the device with a save-to-flash for your settings to take effect.

### Provisioning from TFTP Server using DHCP Option 66

Provisioning the device from a third-party TFTP server is suitable when the network in which the device is deployed includes a provisioning TFTP server for all network equipment, without the capability of distinguishing between the device and other third-party devices.

Upon startup, the device checks for DHCP Option 66 in the DHCP response received from the DHCP server. If Option 66 contains a valid IP address (or FQDN) of the TFTP provisioning server, the device attempts to download through TFTP, a configuration file whose filename contains the device's MAC address (e.g., 00908f0130aa.ini).

This method uploads the configuration file to the device as a one-time action. The download is repeated only if the device is manually restored to factory defaults (by pressing the hardware reset button while the Ethernet cable is not connected).

#### ➤ To configure the device for automatic provisioning through TFTP using DHCP Option 66:

1. In the IP Interfaces table, configure the IP Interface with the 'Interface Mode' parameter set to **IPv4 DHCP** or **IPv6 DHCP** (depending on IP version).
2. Enable the device to include DHCP Option 66 in DHCP Option 55 (Parameter Request List) when requesting TFTP provisioning parameters from a DHCP server, using the following ini file parameter:

```
DHCPRequestTFTPPParams = 1
```

3. Restart the device with a save-to-flash for your settings to take effect.



- Access to the core network through TFTP is not NAT-safe.
- The TFTP data block size (packets) when downloading a file from a TFTP server for the Automatic Update mechanism can be configured using the AUPDTftpBlockSize parameter.

### Provisioning the Device using DHCP Option 160

You can provision the device using DHCP Option 160. DHCP Option 160 provides the device with the URL address of the provisioning server from where it can download its software (.cmp) and configuration (.ini) files. The URL can also include the names of the required files to download and their folder location on the server.

If you enable DHCP client functionality with DHCP Option 160, upon a device restart or power up, the device (as a DHCP client) sends a DHCP request to the DHCP server to obtain networking information (device's IPv4 management IP address) and the URL address of the provisioning server.

The following syntax is supported for defining the URL and configuration/firmware filenames in DHCP Option 160 (on the DHCP server):

- <protocol>://<server IP address or hostname>
- <protocol>://<server IP address or hostname>/<software filename>
- <protocol>://<server IP address or hostname>/<configuration filename>
- <protocol>://<server IP address or hostname>/<software filename>;<configuration filename>

The protocol can be HTTP, HTTPS, FTP, or TFTP. As shown above, the URL can include both the software and configuration filenames. In this case, they must be separated by a semicolon (;) and without spaces.

If the URL doesn't specify a configuration filename or the file doesn't exist on the provisioning server, the device requests from the server a "default" configuration file whose name includes the device's product name and MAC address (<Product><MAC>.ini, for example, "M800B00908f5b1035.ini"). If this "default" file also doesn't exist on the server, the device attempts to retrieve another "default" configuration file whose name includes only the device's product name (<Product>.ini, for example, "M800B.ini"). The device makes up to three attempts to download the configuration file if a failure occurs (i.e., file not exist or any other failure reason). This applies to each of the configuration files, as mentioned previously.

If the URL specifies a software file, the device makes only one attempt to download the file (even if a failure occurs). If the URL doesn't specify a software file, the device doesn't make any attempt to download a software file.

Once the device downloads the file(s), it restarts to apply the configuration and/or software. In addition, once the file(s) has been downloaded, the device ignores all future DHCP Option 160 messages. Only if the device is restored to factory defaults will it process Option 160 again (and download any required files).

➤ **To enable provisioning using DHCP Option 160:**

1. Make sure that the DHCP server is configured with the appropriate information (including the URL address of the provisioning server for Option 160).
2. Make sure that the required configuration and/or software files are located on the provisioning server.
3. Enable DHCP client functionality, as described in [DHCP-based Provisioning](#) on page 1266
4. Enable the device to include DHCP Option 160 in the DHCP Parameter Request List field of the DHCP request packet that is sent to the DHCP server. Do this by loading an ini file to the device with the following parameter setting:

```
DhcpOption160Support = 1
```

1. Restart the device with a save-to-flash for your settings to take effect.

## HTTP-based Provisioning

An HTTP or HTTPS server can be located in the network in which the device is deployed, storing configuration and software files for the device to download. This doesn't require additional servers and is NAT-safe.

For example, assume the core network HTTPS server is `https://www.corp.com`. A master configuration ini file can be stored on the server, for example, `https://www.corp.com/gateways/master.ini`. This file could point to additional ini files, Auxiliary files (e.g., call progress tones), and software files (cmp), all on the same HTTP server or different HTTP servers in the network.

The main advantage of this method is that the device can be configured to periodically check the HTTP server for file updates. HTTP(S) is not sensitive to NAT devices, enabling configuration whenever needed without on-site intervention. For additional security, the URL may contain a different port, and username and password.

The only configuration required is to preconfigure the device(s) with the URL of the initial (master) ini file. This can be done using one of the following methods:

- DHCP, as described in [DHCP-based Provisioning](#) on page 1266 or via TFTP at a staging warehouse. The URL is configured using the `IniFileURL` parameter.
- Private labeling (preconfigured during the manufacturing process).
- Using DHCP Option 67 (see [Provisioning from HTTP Server using DHCP Option 67](#) on page 1267).
- Manually on-site, using the RS-232 port or Web interface.

When the device is deployed at the customer site, local DHCP server provides the devices with IP addressing and DNS server information. From the URL provided in the DHCP response, the device can then contact the HTTP server at the core network and automatically download its configuration. The URL can be a simple file name or contain the device's MAC or IP address, e.g.:

- `http://corp.com/config-<MAC>.ini` - which becomes, for example, `http://corp.com/config-00908f030012.ini`
- `http://corp.com/<IP>/config.ini` - which becomes, for example, `http://corp.com/192.168.0.7/config.ini`

For more information on HTTP-based provisioning, see [HTTP/S-Based Provisioning using the Automatic Update Feature](#) on the next page.

## FTP-based Provisioning

The Automatic Update feature provides limited support for FTP/FTPS connectivity. Periodic polling for updates is not possible since these protocols do not support conditional fetching (i.e., updating files only if they are changed on the server).

The only difference between FTP-based provisioning and those described in [HTTP-based Provisioning](#) on the previous page and [Provisioning from HTTP Server using DHCP Option 67](#) on page 1267 is that the protocol in the URL is "ftp" (instead of "http").

## Provisioning through OVOC

AudioCodes One Voice Operations Center (OVOC) server functions as a core-network provisioning server. The device's SNMP Manager should be configured with the IP address of the OVOC server, using one of the methods detailed in the previous sections. As soon as a registered device contacts OVOC through SNMP, OVOC handles all required configuration automatically, upgrading software as needed. This alternative method doesn't require additional servers at the customer premises, and is NAT-safe.

## HTTP/S-Based Provisioning using the Automatic Update Feature

The Automatic Update feature can be used for automatic provisioning of the device through HTTP/S. Automatic provisioning is useful for large-scale deployment of devices. In some cases, the devices are shipped to the end customer directly from the manufacturer. In other cases, they may pass through a staging warehouse. Configuration may occur at the staging warehouse or at the end-customer premises.

The device may be preconfigured during the manufacturing process (commonly known as private labeling). Typically, a two-stage configuration process is implemented whereby initial configuration includes only basic configuration, while the final configuration is done only when the device is deployed in the live network.



If you use the [IniFileURL] parameter for the Automatic Update feature, do **not** use the Web interface to configure the device. If you do configure the device through the Web interface and save the new settings to the device's flash memory, the [IniFileURL] parameter is automatically set to 0 and Automatic Updates is consequently disabled. To enable Automatic Updates again, you need to upload the ini file again (using the Web interface or BootP) with the correct [IniFileURL] settings. As a safeguard to an unintended save-to-flash when restarting the device, if the device is configured for Automatic Updates, the 'Save To Flash' field in the Web interface's Maintenance Actions page is automatically set to **No** by default.



- For a description of all the Automatic Update parameters, see [Automatic Update Parameters](#) on page 1593.
- For additional security, use HTTPS or FTPS. The device supports HTTPS (RFC 2818) and FTPS using the AUTH TLS method <draft-murray-auth-ftp-ssl-16>.

## File Provisioning

This section discusses file provisioning for the Automatic Update mechanism.



## Files Provisioned by Automatic Update

You can use the Automatic Update feature to update the device with any of the following files:

- Software file (*.cmp*)
- License Key file
- Configuration Package file (for more information, see [Downloading or Uploading Configuration Package File](#) on page 1260)
- Auxiliary files (e.g., Dial Plan file, CAS file, SBC User Information file, and Call Progress Tones file)
- TLS security files (trusted root certificate file, TLS certificate file, and private key)
- Web GUI file (favicon file)
- Configuration file:
  - **ini File:** Contains only ini file parameters and configures all the device's functionality.
  - **CLI Script File:** Contains only CLI commands and configures all the device's functionalities (except commands such as show, debug or copy). The file updates the device's configuration only according to the configuration settings in the file and existing configuration settings (not included in the file) are retained (i.e., **incremental** configuration). The device doesn't restart and therefore, this file typically contains configuration settings that do not require a device restart. If a restart is required, for example, to apply certain settings, you must include the following CLI command (root level) at the end of the file:

```
# reload if-needed
```

To configure the URL of the server where the file is located, use the [CliScriptURL] ini file parameter or CLI command `configure system > automatic-update > cli-script <URL>`.

- **Startup Script File:** Contains only CLI commands and configures all the device's functionality (except commands such as show, debug or copy). The file updates the device's configuration according to the configuration settings in the file and sets all other parameters that are not included in the file to factory defaults. The file causes two device restarts to apply the settings. Therefore, the file typically contains the Automatic Update settings and other configuration settings that require a device restart.

To configure the URL of the server where the file is located, use the [CLIScriptURL] ini file parameter or CLI command `configure system > automatic-update > startup-script <URL>`.



- You can use any filename extension for the CLI script files.
- The CLI Startup Script file is not supported when the device operates in HA mode.

### File Location for Automatic Update

The files for updating the device can be stored on any standard Web (HTTP/S), TFTP, or FTP server. The files can be loaded periodically to the device using HTTP/S, TFTP, or FTP. This mechanism can be used even when the device is installed behind NAT and firewalls. The Automatic Update feature is done per file and configured by specifying the file name and URL address of the provisioning server where the file is located. If the device needs to authenticate itself with the server, you can use the same parameters to configure the authentication username and password (for more information, see [Access Authentication with HTTP Server](#) on page 1281). For a description of the parameters for configuring the URLs of the servers of the files, see [Automatic Update Parameters](#) on page 1593.

Below are examples for configuring the file names and their URLs for Automatic Update:

#### ■ ini File:

```
IniFileURL = 'http://www.corp.com/configuration.ini'  
CptFileURL = 'http://www.corp.com/call_progress.dat'  
AutoCmpFileUrl = 'http://www.corp.com/SIP_F7.20A.008.cmp'  
FeatureKeyURL = 'https://www.company.com/License_Key.txt'
```

#### ■ CLI:

```
# configure system  
(config-system)# automatic update  
(auto-update)# cli-script https://company.com/cli/<MAC>  
(auto-update)# startup-script https://company.com/startup/<MAC>  
(auto-update)# ini-file http://www.company.com/configuration.ini  
(auto-update)# call-progress-tones http://www.company.com/call_  
progress.dat  
(auto-update)# feature-key http://www.company.com/License_Key.txt  
(auto-update)# auto-firmware http://www.company.com/SIP_F7.20A.008.cmp
```



- When using the Auto-Update mechanism to upload the Configuration Package file (`automatic update > configuration-pkg`), if the file is password-protected (encrypted), specify the password using the command `automatic update > default-configuration-package-password`.
- For configuration files, the file name in the URL can automatically contain the device's MAC address for enabling the device to download a file unique to the device. For more information, see [MAC Address Placeholder in URL and File Name](#) below.
- When using the `[IniFileURL]` parameter, parameters not included in the file are restored to default settings. If you want to keep the settings of these parameters, use the `[IncrementalIniFileURL]` parameter instead.

### MAC Address Placeholder in URL and File Name

You can use the placeholder "`<MAC>`" or "`<mac>`" (case-sensitive) to include the device's MAC address in the URL path (folders) and the filename when configuring the Auto-Update file parameters ([File Location for Automatic Update](#) on the previous page). The device automatically replaces the placeholder with its MAC address.

For example, the following Auto-Update file parameters are configured with the placeholder for a folder and for filenames:

```
IniFileURL = 'https://www.company.com/config_<MAC>.ini'
(auto-update)# cli-script https://company.com/files-<MAC>/cli_script.txt
(auto-update)# startup-script https://company.com/files/startup_<MAC>.txt
```

The device automatically replaces the string with its MAC address, resulting in a file name request that contains the device's MAC address, for example, `config_00908F033512.ini` or `startup_00908F033512.txt`. Therefore, you can configure all the devices with the same URL and file name.



If you write the MAC address placeholder string in lowercase (i.e., "`<mac>`"), the device adds the MAC address in lowercase to the file name (e.g., `config_<mac>.ini` results in `config_00908f053736e`); if in uppercase (i.e., "`<MAC>`"), the device adds the MAC address in uppercase to the file name (e.g., `config_<MAC>.ini` results in `config_00908F053736E`).

### Downloading TLS-Related Files for a Specific TLS Context

For downloading a TLS-related file through the Automatic Update mechanism, you can specify the TLS Context for which you want to download the file. This is done by including the "`#<TLS Context index row>`" placeholder in the URLs of the following file provisioning parameters:

- `[TLSCertFileUrl]` - certificate file
- `[TLSPkeyFileUrl]` - private key file
- `[TLSRootFileUrl]` - trusted root file

For example, if you want the device to download a certificate file for the TLS Context that is configured in the TLS Contexts table for index row #2, configure the [TLSCertFileUrl] parameter to "http://10.1.1.12/certs.pem#2". In this example, the device downloads the file from URL http://10.1.1.12/cert.pem (i.e., without the placeholder) and adds it to TLS Context #2. If such a TLS Context doesn't appear in the TLS Contexts table, the device doesn't download the file (and generates a syslog message with the appropriate error).



- If the URL doesn't contain the "#<TLS Context index row>" placeholder (e.g., "http://10.1.1.12/certs/cert.pem"), the device attempts to download the TLS-related file for TLS Context #0 only.
- You can provision the device with a Configuration Package file that contains all the device's certificates (automatic update > configuration-pkg). If this file contains the certificates, it's password-protected (encrypted) and therefore, you need to specify the password (automatic update > default-configuration-package-password). For more information on this file, see [Downloading or Uploading Configuration Package File](#) on page 1260.

### Downloading TLS-related Files for All TLS Contexts

You can download a specific TLS-related file in one configuration through the Automatic Update mechanism, for all TLS Contexts in the TLS Contexts table. This is done by including the <ID> meta-variable in the URLs of the following file provisioning parameters:

- [TLSCertFileUrl] - certificate file
- [TLSPkeyFileUrl] - private key file
- [TLSRootFileUrl] - trusted root file

If you configure a parameter with a URL containing the <ID> meta-variable (e.g., "http://10.1.1.12/certs/<ID>/cert.pem"), the device attempts to download the TLS-related file for **every** existing TLS Context in the TLS Contexts table. For each URL, the device replaces the <ID> placeholder with a number, which is consecutively incremented, starting from 0, according to the number of configured TLS Contexts.

For example, assume that you have configured three TLS Contexts in the TLS Contexts table (Index 0, 1, and 2) and you have configured the [TLSCertFileUrl] parameter to "http://10.1.1.12/certs/<ID>/cert.pem". In this example, the device attempts to download certificate files from the following three URLs:

- http://10.1.1.12/certs/0/cert.pem (file for TLS Context #0)
- http://10.1.1.12/certs/1/cert.pem (file for TLS Context #1)
- http://10.1.1.12/certs/2/cert.pem (file for TLS Context #2)



- If the URL doesn't contain the <ID> meta-variable (e.g., "http://10.1.1.12/certs/cert.pem"), the device attempts to download the TLS-related file for TLS Context #0 only.
- You can provision the device with a Configuration Package file that contains all the device's certificates (automatic update > configuration-pkg). If this file contains the certificates, it's password-protected (encrypted) and therefore, you need to specify the password (automatic update > default-configuration-package-password). For more information on this file, see [Downloading or Uploading Configuration Package File](#) on page 1260.

## File Template for Automatic Provisioning

To facilitate automatic provisioning setup, you can use a single template to define the files to download during automatic provisioning. The template uses special keywords to denote the different file types to download and in the URL address of the provisioning server it uses a placeholder for the file names which is replaced by hardcoded file names and extensions according to file type, as described in more detail below.



- Unlike the parameters that define specific URLs for Auxiliary files (e.g., [CptFileURL]), the file template feature always retains the URLs after each automatic update process. Therefore, with the file template the device always attempts to download the files upon each automatic update process.
- If you configure a parameter used to define a URL for a specific file (e.g., [CptFileURL]), the settings of the [TemplateUrl] parameter is ignored for the specific file type (e.g., CPT file).
- Additional placeholders can be used in the file name in the URL, for example, <MAC> for MAC address (see [MAC Address Placeholder in URL and File Name](#) on page 1275).

### ➤ To use a file template for automatic provisioning:

1. Define the file **types** to download by the file template, using the [AupdFilesList] parameter. Use the keywords listed in the table below to specify each file type. For example, to specify ini, License Key, and CPT files:

- ini File:

```
AupdFilesList = 'ini', 'fk', 'cpt'
```

- CLI:

```
# configure system
(config-system)# automatic update
(auto-update)# template-files-list ini,fk,cpt
```

2. Define the URL address of the provisioning server on which the files (specified in Step 1) are located for download, using the [TemplateUrl] parameter. When you configure the URL, you must include the file type placeholder, "<FILE>", which represents the file name. For each file type specified in Step 1, the device sends an HTTP request to the server, where the placeholder in the URL is replaced with the filename and extension, as listed in the below table. For example, if you configure the [AupdFilesList] parameter as in Step 1 and the [TemplateUrl] parameter to:

- ini File:

```
TemplateUrl = 'http://10.8.8.20/Site1_<FILE>'
```

- CLI:

```
# configure system
(config-system)# automatic update
(auto-update)# template-url http://10.8.8.20/Site1_<FILE>
```

The device sends HTTP requests to the following URLs:

- http://10.8.8.20/Site1\_\*\*device.ini
  - http://10.8.8.20/Site1\_\*\*fk.ini
  - http://10.8.8.20/Site1\_\*\*cpt.data
3. Place the files to download on the provisioning server. Make sure that their file names and extensions are based on the hardcoded string values specific to the file type for the <FILE> placeholder (e.g., "Site1\_device.ini" for the ini file), as shown in the table below.

**Table 46-1: File Template Keywords and Placeholder Values per File Type**

File Type	Keywords for Template File	Value Replacing <FILE> Placeholder
ini file	ini	device.ini
CLI Script file	cli	cliScript.txt
CLI Startup Script file	clis	cliStartupScript.txt
CMP file based on timestamp	acmp	autoFirmware.cmp
User Information file	usrinf	userInfo.txt
CMP file	cmp	firmware.cmp
License Key file	fk	fk.ini

File Type	Keywords for Template File	Value Replacing <FILE> Placeholder
Call Progress Tone (CPT) file	cpt	cpt.dat
Prerecorded Tones (PRT) file	prt	prt.dat
CAS file	cas	cas.dat
Dial Plan file	dpln	dialPlan.dat
Answering Machine Detection (AMD) file	amd	amd.dat
TLS Private Key file	sslp	pkey.pem pkey<ID>.pem (for multi-certificate system)
TLS Root Certificate file	sslr	root.pem root<ID>.pem (for multi-certificate system)
TLS Certificate file	sslc	cert.pem cert<ID>.pem (for multi-certificate system)

## Triggers for Automatic Update

The Automatic Update feature can be triggered by the following:

- Upon device startup (restart or power up). To disable this trigger, run the following CLI command:

```
(config-system)# automatic-update
(auto-update)# run-on-reboot off
```

- Periodically:
  - Specified time of day (e.g., 18:00), configured by the ini file parameter [AutoUpdatePredefinedTime] or CLI command `configure system > automatic-update > predefined-time`. You can configure (using the [AutoUpdatePredefinedRandomTime] parameter) an interval from the specified time in which the automatic update is randomly triggered. This is useful for reducing load on the provisioning server when you have deployed multiple devices that are implementing the Automatic Update feature. For example, if you configure [AutoUpdatePredefinedTime] to 18:00 and

[AutoUpdatePredefinedRandomTime] to 300 seconds (i.e., 5 min.), the automatic update process is randomly triggered anywhere between 18:00 and 18:05.

- Interval between Automatic Updates (e.g., every 60 minutes), configured by the ini file parameter [AutoUpdateFrequencySeconds] or CLI command `configure system > automatic-update > update-frequency-sec`.



Configure either [AutoUpdatePredefinedTime] or [AutoUpdateFrequencySeconds]; not both. When configuring one of the parameters, make sure that the other parameter is at its default value (i.e., disabled).

#### ■ Centralized provisioning server request:

- Upon receipt of an SNMP request from the provisioning server.
- Upon receipt of a special SIP NOTIFY message from the provisioning server. The NOTIFY message includes an Event header with the AudioCodes proprietary value, "check-sync;reboot=false", as shown in the example below:

```
NOTIFY sip:<user>@<dsthost> SIP/2.0
To: sip:<user>@<dsthost>
From: sip:sipsak@<srchost>
CSeq: 10 NOTIFY
Call-ID: 1234@<srchost>
Event: check-sync;reboot=false
```

#### To enable the feature:

- Open the SIP Definitions General Settings page (**Setup** menu > **Signaling & Media** tab > **SIP Definitions** folder > **SIP Definitions General Settings**).
- Select the 'Remote Management by SIP NOTIFY' check box (EnableSIPRemoteReset):

Remote Management by SIP NOTIFY ☒

- Click **Apply**.

To enable this feature through CLI: `configure voip > sip-definition advanced-settings > sip-remote-reset`

## Applying Downloaded ini File after Graceful Timeout

If you use the Automatic Update feature for updating the device's configuration from an ini file, you can configure the device to gracefully lock itself before applying the settings of the ini file. When the Automatic Update feature is triggered (for example, by a device restart) and the device downloads the ini file from the remote provisioning server, the graceful timeout begins. During this period, the device doesn't accept any new calls, allowing only existing calls to continue until the timeout expires. If all existing calls end before the timeout expires, the device



applies the configuration of the downloaded ini file. If there are still existing calls when the timeout expires, the device terminates the calls, and then applies the configuration of the downloaded ini file.

➤ **To configure graceful timeout for automatic update of ini file:**

1. In the ini file used for enabling and configuring the device for Automatic Update, include the following parameters with the other parameters (such as IniFileURL) relating to Automatic Update setup:

```
...
AupdGracefulShutdown=1
AdminStateLockControl=<Graceful Timeout>
...
```

2. Upload the ini file to the device.

## Assigning IP Interface for Auto-Update Mechanism

By default, the device uses the IPv4 OAMP interface in the IP Interfaces table (see [Configuring IP Network Interfaces](#) on page 157) for the Auto-Update mechanism. You can assign a different IP Interface (IPv4 or IPv6), using the [AUPDInterface] parameter.



- The IP version (IPv4 or IPv6) of the assigned IP Interface and the configured addresses (IP addresses or FQDNs) in the URLs that define the locations of the different files for Auto-Update (e.g., [CmpFileURL] parameter) must be the same. If the IP version is different between the IP Interface and a file's URL, auto-update fails for that specific file.
- You can assign any IP Interface type to the Auto-Update mechanism (configured by the 'Application Type' parameter in the IP Interfaces table).

## Access Authentication with HTTP Server

You can configure the device to authenticate itself with the HTTP/S server storing the files that you want to download for the Automatic Update mechanism. The device authenticates itself by providing the HTTP/S server with its authentication username and password. The credentials are used for both Digest access authentication (MD5 cryptographic hashing) and the non-secured Basic access authentication method.

When configuring the URL of the server with the name of the file that you want downloaded, you can also include the username and password in the format "username:password" (without quotation marks), as shown in the example below for the software file (.cmp):

- ini file:

```
AutoCmpFileUrl = 'https://JoeD:1234@10.1.1.1/mysw.cmp'
```

## ■ CLI:

```
# configure system
(config-system)# automatic update
(auto-update)# auto-firmware https://JoeD:1234@10.1.1.1/mysw.cmp
```

If you have not included the username and password in the parameters used for configuring the URL of the server with the name of the file that you want downloaded, the device uses the username and password that you configured for the ini file parameter [AUPDUserPassword] or CLI command `configure system > automatic-update > credentials`.



The password cannot be configured with wide characters (for example, Chinese characters).

## Querying Provisioning Server for Updated Files

Each time the Automatic Update feature is triggered, for each file and its configured URL the device does the following:

1. If you have configured the device to authenticate itself to the HTTP/S server for secure access, the device sends the access authentication username and password to the HTTP/S server (for more information, see [Access Authentication with HTTP Server](#) on the previous page). If authentication succeeds, Step 2 occurs.
2. The device establishes an HTTP/S connection with the URL host (provisioning server). If the connection is HTTPS, the device verifies the certificate of the provisioning server, and presents its own certificate if requested by the server.
3. The device queries the provisioning server for the requested file by sending an HTTP Get request. This request contains the HTTP User-Agent Header, which identifies the device to the provisioning server. By default, the header includes the device's model name, MAC address, and currently installed software and configuration versions. Based on its own dynamic applications for logic decision making, the provisioning server uses this information to check if it has relevant files available for the device and determines which files must be downloaded (working in conjunction with the HTTP If-Modified-Since header, described further on in this section).

You can configure the information sent in the User-Agent header, using the [AupdHttpUserAgent] parameter or CLI command, `configure system > http-user-agent`. The information can include any user-defined string or the following supported string variable tags (case-sensitive):

- **<NAME>**: product name, according to the installed License Key
- **<MAC>**: device's MAC address
- **<VER>**: software version currently installed on the device, e.g., "7.00.200.001"

- **<CONF>**: configuration version, as configured by the ini file parameter, [INIFileVersion] or CLI command, `configuration-version`

The device automatically populates these tag variables with actual values in the sent header. By default, the device sends the following in the User-Agent header:

```
User-Agent: Mozilla/4.0 (compatible; AudioCodes;
<NAME>;<VER>;<MAC>;<CONF>)
```

For example, if you configure [AupdHttpUserAgent] to "MyWorld-<NAME>;<VER> (<MAC>)", the device sends the following User-Agent header:

```
User-Agent: MyWorld-Mediant;7.00.200.001(00908F1DD0D3)
```



If you configure the [AupdHttpUserAgent] parameter with the <CONF> variable tag, you must restart the device with a save-to-flash for your settings to take effect.

4. If the provisioning server has relevant files available for the device, the following occurs, depending on file type and configuration:
  - **File Download upon each Automatic Update process:** This is applicable to software (.cmp) and configuration files. In the sent HTTP Get request, the device uses the HTTP If-Modified-Since header to determine whether to download these files. The header contains the date and time (timestamp) of when the device last downloaded the file from the specific URL. This date and time is regardless of whether the file was installed or not on the device. An example of an If-Modified-Since header is shown below:

```
If-Modified-Since: Mon, 1 January 2014 19:43:31 GMT
```

If the file on the provisioning server was unchanged (not modified) since the date and time specified in the header, the server replies with an HTTP 304 response and the file is not downloaded. If the file was modified, the provisioning server sends an HTTP 200 OK response with the file in the body of the HTTP response. The device downloads the file and compares the version of the file with the currently installed version on its flash memory. If the downloaded file is of a later version, the device installs it after the device restarts (which is only done after the device completes all file downloads); otherwise, the device doesn't restart and doesn't install the file.

To enable the automatic software (.cmp) file download method based on this timestamp method, use the [AutoCmpFileUrl] parameter or CLI command `configure system > automatic-update > auto-firmware <URL>`. The device uses the same configured URL to download the .cmp file for each subsequent Automatic Update process.

You can also enable the device to run a CRC on the downloaded configuration file to determine whether the file has changed in comparison to the previously downloaded file. Depending on the CRC result, the device can install or discard the downloaded file.

For more information, see [Cyclic Redundancy Check on Downloaded Configuration Files](#) on page 1286.



- When this method is used, there is typically no need for the provisioning server to check the device's current firmware version using the HTTP-User-Agent header.
- The Automatic Update feature assumes that the Web server conforms to the HTTP standard. If the Web server ignores the If-Modified-Since header or doesn't provide the current date and time during the HTTP 200 OK response, the device may restart itself repeatedly. To overcome this problem, modify the update frequency, using the [AutoUpdateFrequencySeconds] parameter or CLI command `configure system > automatic update > update-frequency-sec`.

- **One-time File Download:** This is applicable to software (.cmp) and Auxiliary (e.g., License Key, CPT and Dial Plan) files. The device downloads these files only **once**, regardless of how many times the device may repeat the Automatic Update process. Once they are downloaded, the device discards their configured URLs. To update these files again, you need to configure their URL addresses and filenames again. Below is an example of how to configure URLs for some of these files:

#### Auxiliary Files:

- ◆ ini:

```
CptFileURL = 'https://www.company.com/call_progress.dat'
FeatureKeyURL = 'https://www.company.com/License_Key.txt'
```

- ◆ CLI:

```
(config-system)# automatic-update
(auto-update)# call-progress-tones http://www.company.com/call_
progress.dat
(auto-update)# tls-root-cert https://company.com/root.pem
```

#### Software (.cmp) File:

- ◆ ini:

```
CmpFileUrl = 'https://www.company.com/device/7.60A.100.022.cmp'
```

- ◆ CLI:

```
(config-system)# automatic-update
(auto-update)# firmware
https://www.company.com/device/7.60A.100.022.cmp
```



- For one-time file download, the HTTP Get request sent by the device doesn't include the If-Modified-Since header. Instead, the HTTP-User-Agent header can be used in the HTTP Get request to determine whether firmware update is required.
- When downloading TLS certificate files, it is recommended to use HTTPS with mutual authentication for secure transfer of the TLS Private Key.
- For devices in HA mode, the License Key is applied to both active and redundant units.

5. If the device receives an HTTP 301/302/303 redirect response from the provisioning server, it establishes a connection with the new server at the redirect URL and re-sends the HTTP Get request.

## File Download Sequence

Whenever the Automatic Update feature is triggered (see [Triggers for Automatic Update](#) on page 1279), the device attempts to download the files (if available) from the configured URLs in the following order:

1. ini file
2. CLI Script file
3. CLI Startup Script file
4. Periodic software file (.cmp) download
5. One-time software file (.cmp) download
6. Auxiliary file(s)

The following files instruct the device to restart:

- CLI Startup Script file
- Periodic software file (.cmp)
- One-time software file (.cmp)

When multiple files requiring a restart are downloaded, the device restarts only **after** it has downloaded and installed **all** the files. However, you can explicitly instruct the device to immediately restart for the following files:

- ini file: Use the [ResetNow] in file parameter
- CLI Script file: Use the `reload if-needed` CLI command



If you use the [ResetNow] parameter in an ini file for periodic automatic provisioning with non-HTTP (e.g., TFTP) and without CRC, the device restarts after every file download. Therefore, use the parameter with caution and only if necessary for your deployment requirements.



- For ini file downloads, parameters excluded from the file are set to default. To retain the current settings of these parameters, configure the [SetDefaultOnINIFileProcess] parameter to 0.
- The CLI Startup Script file is not supported when the device operates in HA mode.
- If you have configured one-time software file (.cmp) download (configured by the [CmpFileURL] parameter or CLI command `configure system > automatic-update > firmware`), the device will only apply the file if one-time software updates are enabled. This is disabled by default to prevent unintentional software upgrades. To enable one-time software upgrades, set the [AutoUpdateCmpFile] parameter to [1] or CLI command, `configure system > automatic-update > update-firmware on`.
- If you need to update the device's software and configuration, it is recommended to first update the software. This is because the current ("old") software (before the upgrade) may not be compatible with the new configuration. However, if both files are available for download on the provisioning server(s), the device first downloads and applies the new configuration, and only then does it download and install the new software. Therefore, this is a very important issue to take into consideration.
- If more than one file needs to be updated:
  - ✓ CLI Script and cmp: The device downloads and applies the CLI Script file on the currently ("old") installed software version. It then downloads and installs the cmp file with a restart. Therefore, the CLI Script file **MUST** have configuration compatible with the "old" software version.
  - ✓ CLI Startup Script and cmp: The device downloads both files, restarts, applies the new cmp, and then applies the configuration from the Startup Script file on the new software version.
  - ✓ CLI Script and Startup Script: The device downloads and applies both files; but the Startup Script file overwrites all the configuration of the CLI Script file.
- To configure the maximum time (timeout) allowed for downloading a file from the provisioning server, use the [AupdMaxTransferTime] parameter.

## Cyclic Redundancy Check on Downloaded Configuration Files

You can enable the device to perform cyclic redundancy checks (CRC) on downloaded configuration files during the Automatic Update process. The CRC checks whether the content (raw data) of the downloaded file is different to the content of the previously downloaded file from the previous Automatic Update process. The device compares the CRC check value (code) result with the check value of the previously downloaded file. If the check values are identical, it indicates that the file has no new configuration settings, and the device discards the file. If the check values are different, it indicates that the downloaded file is different (i.e., includes updates), and the device installs the downloaded file and applies the new configuration settings.

CRC is useful, for example, when the service provider replaces a file, on the provisioning server, with another file whose contents are the same. When the device sends an HTTP Get request during the Automatic Update process, the provisioning server sends the new file to the device. This occurs as the timestamp between the previously downloaded file and this new file is

different (determined by the HTTP If-Modified-Since header in the Get request). Therefore, the CRC feature can be used to prevent the device from installing such files.

For enabling CRC, use the ini file parameter AUPDCheckIfIniChanged or CLI command, configure `system > automatic-update > crc-check regular`. By default, CRC is disabled. For more information on the parameter, see [Automatic Update Parameters](#) on page 1593.

## Automatic Update Configuration Examples

This section provides a few examples on configuring the Automatic Update feature.

### Automatic Update for Single Device

This simple example describes how to configure the Automatic Update feature for updating a single device. In this example, the device queries the provisioning server for software, configuration and Auxiliary files every 24 hours.

#### ➤ To set up Automatic Provisioning for single device (example):

1. Set up an HTTP Web server (e.g., `http://www.company.com`) and place all the required configuration files on this server.
2. Configure the device with the IP address of the DNS server for resolving the domain name (e.g., `http://www.company.com`) that is used in the URL of the provisioning server. You configure this in the IP Interfaces table:

- ini File:

```
[ InterfaceTable ]
FORMAT Index = ApplicationTypes, InterfaceMode, IPAddress,
PrefixLength, Gateway, VlanID, InterfaceName,
PrimaryDNSServerIPAddress, SecondaryDNSServerIPAddress,
UnderlyingDevice;InterfaceTable 0 = 6, 10, 10.15.7.95, 16, 10.15.0.1, 1,
"Voice", 80.179.52.100, 0.0.0.0, "vlan 1";
[ \InterfaceTable ]
```

- CLI:

```
# configure network
(config-network)# interface network-if 0
(network-if-0)# primary-dns 80.179.52.100
```

3. Configure the device with the following Automatic Update settings:

- a. Automatic Update is done every 24 hours (1440 minutes):

- ◆ ini File:

```
AutoUpdateFrequencySeconds = 1440
```

- ◆ CLI:

```
# configure system
(config-system)# automatic update
automatic-update)# update-frequency 1440
```

**b.** Automatic Update of software file (.cmp):

- ◆ ini File:

```
AutoCmpFileUrl = 'https://www.company.com/sw.cmp'
```

- ◆ CLI:

```
# configure system
(config-system)# automatic update
(auto-update)# auto-firmware 'http://www.company.com/sw.cmp'
```

**c.** Automatic Update of Call Progress Tone file:

- ◆ ini File:

```
CptFileURL = 'https://www.company.com/call_progress.dat'
```

- ◆ CLI:

```
# configure system
(config-system)# automatic update
(auto-update)# call-progress-tones 'http://www.company.com/call_
progress.dat'
```

**d.** Automatic Update of ini configuration file:

- ◆ ini File:

```
IniFileURL = 'https://www.company.com/config.ini'
```

- ◆ CLI:



```
# configure system
(config-system)# automatic update
(auto-update)# ini-file 'http://www.company.com/config.ini'
```

- e. Enable Cyclical Redundancy Check (CRC) on downloaded ini file:

- ◆ ini File:

```
AUPDCheckIfIniChanged = 1
```

- ◆ CLI:

```
# configure system
(config-system)# automatic update
(auto-update)# crc-check regular
```

4. Power down and then power up the device.

### Automatic Update from Remote Servers

This example describes how to configure the Automatic Update feature where files are stored and downloaded from different file server types. The example scenario includes the following:

- FTPS server at ftpserver.corp.com for storing the License Key file. The login credentials to the server are username "root" and password "wheel".
- HTTP server at www.company.com for storing the configuration file.
- DNS server at 80.179.52.100 for resolving the domain names of the provisioning servers (FTPS and HTTP).

#### ➤ To set up Automatic Provisioning for files stored on different server types (example):

##### 1. License Key file:

- a. Set up an FTPS server and copy the License Key file to the server.
- b. Configure the device with the URL path of the License Key file:

- ◆ ini File:

```
FeatureKeyURL = 'ftps://root:wheel@ftpserver.corp.com/license_
key.txt'
```

- ◆ CLI:

```
# configure system
(config-system)# automatic update
(auto-update)# feature-key
'ftps://root:wheel@ftpsserver.corp.com/license_key.txt'
```

## 2. Software (.cmp) and ini files:

- a. Set up an HTTP Web server and copy the .cmp and configuration files to the server.
- b. Configure the device with the URL paths of the .cmp and ini files:

### ◆ ini File:

```
AutoCmpFileUrl = 'http://www.company.com/device/sw.cmp'
IniFileURL = 'http://www.company.com/device/inifile.ini'
```

### ◆ CLI:

```
# configure system
(config-system)# automatic update
(auto-update)# auto-firmware 'http://www.company.com/sw.cmp'

(auto-update)# startup-script https://company.com/files/startup_
script.txt
```

3. Configure the device with the IP address of the DNS server for resolving the domain names of the FTPS and HTTP servers:

```
[ InterfaceTable ]
FORMAT Index = ApplicationTypes, InterfaceMode, IPAddress, PrefixLength,
Gateway, VlanID, InterfaceName, PrimaryDNSServerIPAddress,
SecondaryDNSServerIPAddress, UnderlyingDevice;
InterfaceTable 0 = 6, 10, 10.15.7.95, 16, 10.15.0.1, 1, "Voice", 80.179.52.100,
0.0.0.0, "vlan 1";
[ \InterfaceTable ]
```

4. Configure the device to perform the Automatic Update process daily at 03:00 (3 a.m):

### ● ini File:

```
AutoUpdatePredefinedTime = '03:00'
```

### ● CLI:

```
# configure system
(config-system)# automatic update
(auto-update)# predefined-time 03:00
```

## Automatic Update for Mass Deployment

This example describes how to configure the Automatic Update feature for updating multiple devices (i.e., mass deployment) using an HTTP provisioning server. In this example, all the devices are configured to download the same "master" configuration file. This file serves as the configuration template and instructs the devices which files to download and how often to perform the Automatic Update process. In addition, the master file also instructs each device to download an ini configuration file whose file name contains the MAC address of the device.

The example scenario is as follows:

- All devices download a "master" configuration file that contains the following:
  - Common configuration shared by all device's.
  - [MAC Address Placeholder in URL and File Name](#) on page 1275.
- Device queries the provisioning server daily at 24:00 (midnight) for software, configuration and Auxiliary files.
- HTTP-based provisioning server at [www.company.com](http://www.company.com) for storing the files.
- DNS server at 80.179.52.100 for resolving the domain name of the provisioning server.

### ➤ To set up automatic provisioning for mass provisioning (example):

1. Create a "master" configuration file template named "master\_configuration.ini" or "master\_startup.txt" with the following settings:
  - Common configuration for all devices:
    - ◆ ini file:

```
AutoUpdatePredefinedTime = '24:00'
CptFileURL = 'https://www.company.com/call_progress.dat'
AutoCmpFileUrl = 'https://www.company.com/sw.cmp'
```

- ◆ CLI:

```
# configure system
(config-system)# automatic update
(auto-update)# predefined-time 24:00
(auto-update)# call-progress-tones https://www.company.com/call_
progress.dat
(auto-update)# auto-firmware https://www.company.com/sw.cmp
```

- Configuration per device based on MAC address:

- ◆ ini file:

```
IniFileURL = 'http://www.company.com/config_<MAC>.ini'
```

- ◆ CLI:

```
# configure system
(config-system)# automatic update
(auto-update)# cli-script https://company.com/files/cli_script_
<MAC>.txt
(auto-update)# ini-file http://www.company.com/config_<MAC>.ini
```

2. Copy the master configuration file that you created in Step 1 as well as the CPT and .cmp files to the HTTP-based provisioning server.

3. Configure **each** device with the following:

- a. URL of the master configuration file:

- ◆ ini File:

```
IniFileURL = 'http://www.company.com/master_configuration.ini'
```

- ◆ CLI:

```
# configure system
(config-system)# automatic update
(auto-update)# ini-file http://www.company.com/master_
configuration.ini
(auto-update)# cli-script https://company.com/files/master_startup.txt
```

- b. Configure the device with the IP address of the DNS server for resolving the domain name (e.g., http://www.company.com) that is used in the URL for the provisioning server. This is done in the IP Interfaces table:

- ◆ ini File:

```
[ InterfaceTable ]
FORMAT Index = ApplicationTypes, InterfaceMode, IPAddress,
PrefixLength, Gateway, VlanID, InterfaceName,
PrimaryDNSServerIPAddress, SecondaryDNSServerIPAddress,
UnderlyingDevice;
InterfaceTable 0 = 6, 10, 10.15.7.95, 16, 10.15.0.1, 1, "Voice",
```

```
80.179.52.100, 0.0.0.0, "vlan 1";  
[ \InterfaceTable ]
```

◆ CLI:

```
# configure network  
(config-network)# interface network-if 0  
(network-if-0)# primary-dns 80.179.52.100
```

4. Power down and then power up the device.

## 47 USB Storage Capabilities

The device supports USB storage using an external USB hard drive or flash disk (disk on key) connected to its USB port. The storage capabilities are configured using the CLI and include the following:

- To save network captures to the USB:

```
# debug capture data physical stop usb
```

- To update the device's firmware from the USB:

```
# copy firmware from usb:///<cmp file name>
```

- To update the device's configuration from the USB:

```
# copy ini-file from usb:///<ini configuration file name>
```

- To save the current configuration to the USB:

```
# copy ini-file to usb:///<ini configuration file name>
```



Only a single USB storage (formatted to FAT/FAT32) operation is supported at any given time.

## 48 SBC Configuration Wizard

The SBC Configuration Wizard provides you with a quick-and-easy method for initial configuration of your device. The SBC Configuration Wizard guides you through a sequence of pages, assisting you in defining your device. Once the wizard is complete, your device is sufficiently configured to successfully process and route calls in your deployment.

The SBC Configuration Wizard is based on partially and fully tested interoperability setups between the device and a wide range of vendors, including SIP trunking providers, IP PBXs, and contact centers. Once you have selected the involved vendors and defined basic settings in the SBC Configuration Wizard, it then generates a configuration file based on the matching interoperability configuration template. Alternatively, instead of basing your configuration on specific vendors, you can use the SBC Configuration Wizard to generate a configuration file based on a generic template for commonly used setups. In such cases, you may later need to manually fine-tune your configuration to suit your setup needs.

The SBC Configuration Wizard can automatically load the generated configuration (with a restart) to the device, or you can simply download the generated configuration file to a folder on your PC and then upload the file to the device at a later stage.


The generated configuration is a good starting point to enable the successful establishment of basic calls. For complete device configuration, you may need to manually configure additional functionality. For example, you may need to configure security settings (e.g., firewalls and IDS) to ensure that the device is protected from malicious activity and DoS attacks.

For AudioCodesfull interoperability list, click [here](#).




- The SBC Configuration Wizard is not supported (and not available in the Web interface) in the following cases:
  - ✓ If the device is operating in High-Availability (HA) mode.
  - ✓ If you have configured IPv6 interfaces in the IP Interfaces table (see [Configuring IP Network Interfaces](#) on page 157).
  - ✓ If you have configured WebSocket tunneling with OVOC (see [Configuring WebSocket Tunnel with OVOC](#) on page 122).
- When the SBC Configuration Wizard applies the configuration template to the device, all parameters configured by the SBC Configuration Wizard overwrite the device's existing configuration of those parameter. Parameters not configured by the SBC Configuration Wizard are restored to factory defaults, except basic device settings such as management users (Web and CLI). Some of these basic settings also appear in the SBC Configuration Wizard and their fields are automatically populated with their current settings; if you do modify them in the SBC Configuration Wizard, their new settings are used.
- On some wizard pages, the availability of certain fields depends on the selected application.

## Starting the SBC Configuration Wizard

The following procedure describes how to start the SBC Configuration Wizard. Throughout the wizard, you can get help on the current wizard page, by clicking the  icon, located on the top-right of the page.

### ➤ To start the SBC Configuration Wizard:

1. Access the SBC Configuration Wizard's Welcome page:
  - **Toolbar:** Click **Actions**, and then from the drop-down list, choose **Configuration Wizard**.
  - **Navigation Tree:** **Setup** menu > **Administration** tab > **Maintenance** folder > **Configuration Wizard**.



2. The version of the template pack currently installed on the device is displayed by the 'Template Pack Version' field. The template pack contains the interoperability configuration templates available on the SBC Configuration Wizard. If the template pack is the latest, "Template pack is up to date" is displayed below the field. If the template pack is not the latest version, you can update it by clicking the **Update from Remote Server** button (see below note). Alternatively, if you have received a template pack file from the sales representative of your purchased device, you can install it on the device using the Auxiliary Files page (see [Uploading Auxiliary Files](#) on page 1220). If you click the version number, the Template Pack Version History window appears, displaying the updates for the current and previous versions.



The device checks with AudioCodes server if it has the latest template pack only if it has Internet connectivity. Therefore, the **Update from Remote Server** button is displayed only if the device has connectivity to the Internet and has subsequently found that the template pack is not the latest.

3. Click **Next**; the General Setup page appears (see [General Setup Page](#) on the next page).



## General Setup Page

The General Setup wizard page defines the network topology of the device, which includes the application (e.g., SIP trunk) and the involved third-party vendors, configuration template based on the selected vendor interoperability, and physical network (ports).

### ➤ To define the general setup:

#### 1. Select one of the following 'Application' options:

- SIP Trunk (IP-PBX with SIP Trunk):** The device connects the Enterprise IP PBX with the Internet Telephony Service Provider (ITSP) or SIP Trunk Provider. The IP PBX resides on the Enterprise LAN, while the ITSP resides on the WAN. Only calls between the IP PBX and ITSP traverse the device. Calls between Enterprise phones, users and certain SIP messages (REGISTER, SUBSCRIBE and NOTIFY) are managed locally by the IP PBX and do not traverse the device.
- SIP Normalization (two IP-PBX's):** The device performs SIP "normalization" of traffic between two IP PBXs. The first IP PBX resides on the Enterprise LAN (co-located with the device) and the second IP PBX resides on the WAN (or at another branch site). Only calls between the IP PBXs traverse the device. Calls between the phones and users of the same IP PBX, and certain SIP messages (REGISTER, SUBSCRIBE and NOTIFY) are managed locally by each IP PBX and do not traverse the device.
- Hosted IP-PBX (IP-PBX with Users):** The device connects phones (users) with the "hosted" IP PBX. The users reside on the Enterprise LAN (co-located with the device) and the IP PBX resides on the WAN (or at the datacenter). All traffic between users and IP PBX traverse the device, including SIP REGISTER, SUBSCRIBE and NOTIFY messages.
- Remote Users (IP-PBX with Remote Users):** The device connects remote phones (users) with the "local" IP PBX (additional IP PBX servers can be configured). The IP PBX resides on the Enterprise LAN (co-located with the device) and the remote users reside on the WAN (or at the datacenter). All traffic between users and IP PBX traverse the device, including SIP REGISTER, SUBSCRIBE and NOTIFY messages.

#### 2. If you selected the **SIP Trunk** application in Step 1, do the following:

- a. From the 'IP-PBX' drop-down list, select the IP PBX model. If the model is not listed, select **Generic IP-PBX**.
  - b. From the 'SIP-Trunk' drop-down list, select the SIP trunk provider. If the provider is not listed, select **Generic SIP Trunk**.
3. From the 'Network Setup' drop-down list, select the physical network topology:
  - **Two ports: LAN and WAN:** The device connects to the network through two separate physical network links (interfaces). The first interface ("LAN") is connected to the Enterprise LAN (typically, a switch) and has a private IP address. The second interface ("WAN") is connected to the DMZ port of the Enterprise router and has a public (globally routable) IP address. Each link may be accompanied with a backup link for Ethernet link redundancy.
  - **One port: LAN:** The device connects to the Enterprise LAN (typically, a switch) through a single physical network link (interface). The interface ("LAN") has a private IP address. You must enable port forwarding on the Enterprise router to forward all VoIP traffic from the ITSP (located on the WAN) to the device. The exact port forwarding configuration is shown on the Conclusion page and consists of the device's address, SIP port (e.g. 5060) and a media port range (e.g. 6000-6999).
  - **One port: WAN:** The device connects to the DMZ port of the Enterprise router through a single physical network link (interface). The interface ("WAN") has a public (globally routable) IP address. You must enable port forwarding on the Enterprise router to forward all VoIP traffic from the device to the IP PBX (located on the LAN). The exact port forwarding configuration is shown on the Conclusion page and consists of the IP PBX address, SIP port (e.g. 5060) and a media port range (e.g. 6000-6999).
  - **One port: LAN only:** The device connects to the Enterprise LAN (typically, a switch) through a single physical network link (interface). All SIP entities (IP PBX and users) connect to the same LAN. Note that this option is applicable to all applications (see Step 1), except **SIP Trunk**.
4. Click **Next**; the System page appears (see [System Page](#) below).

## System Page

The System wizard page configures the device's basic system settings, including management interface protocol, date and time, and syslog.

➤ **To configure system settings:**

1. Configure the protocol for accessing the management interfaces:
  - 'Web Interface': Select the type of Web interface protocol (**HTTP** or **HTTPS**).
  - 'CLI Interface': Select the type of CLI protocol (**Disabled**, **Telnet**, **SSH**).
2. (Optional) Enable syslog by selecting the 'Enable Syslog' check box, and then in the 'Syslog IP' field, configuring the syslog server's IP address. Note that if you enable syslog, the device generates verbose logs (debug level 5), which adversely affects performance. For more information on syslog, see [Configuring Syslog](#) on page 1482.
3. Configure the time and date:
  - 'Time Zone': Select the GMT time zone in which the device is located.
  - 'Primary NTP Server' and 'Secondary NTP Server': Configure the IP address (or hostname) of the primary (and optionally, secondary) NTP server in your network. The NTP server synchronizes the time of the device. This is mandatory when the IP PBX or ITSP uses a TLS connection, as correct time is required for certificate validation.

For more information on configuring date and time, see [Date and Time](#) on page 135.

4. (Optional) Configure a local DNS table, which allows the device to resolve domain names (hostnames) using a locally defined address resolution table. This may be needed when your setup lacks a DNS server and the IP PBX or ITSP require the use of hostnames instead of IP addresses. Select the 'Apply local DNS' check box, and then configure the following parameters:
  - 'Domain Name': Domain name to resolve into an IP address.
  - 'First IP address': IP address of the domain name.
  - 'Secondary IP address': Second IP address of the domain name (optional).

For more information on configuring the device's DNS table, see [Configuring the Internal DNS Table](#) on page 197.

5. Click **Next**; the Interfaces page appears (see [Interfaces Page](#) on the next page).

## Interfaces Page

The Interfaces wizard page configures the device's LAN and WAN settings.

### ➤ To configure LAN and WAN interface settings:

1. From the 'Physical Port' drop-down list, select the Ethernet Group containing the required physical Ethernet port for connecting the device to the 1) Enterprise LAN (typically, a switch) or 2) DMZ port of the Enterprise router for WAN. You may configure two physical ports for Ethernet link redundancy.
2. Select the **VLAN Tagging** check box, and then in the 'VLAN ID' field, configure the VLAN ID for the interface. For untagged traffic, clear the check box.
3. In the 'IP Address' field, configure the device's IP address on the interface.
  - For LAN interfaces: The IP address must be part of the Enterprise LAN and therefore, is typically a private IP address. The address is used for communicating with the IP PBX and/or users that reside on the LAN, as well as for management (OAMP) traffic.
  - For WAN interfaces: The IP address must be a public (globally routable) address and is used for communicating with the ITSP and/or IP PBX that resides on the WAN. If the WAN is the only interface, it is also used for management (OAMP) traffic.
4. In the 'Subnet Mask' field, configure the subnet mask of the interface.
5. In the 'Default Gateway' field, configure the default gateway of the interface.
6. If the device is connected through an Enterprise router that performs NAT, then in the 'NAT Public IP' address, configure the public IP address (of the Enterprise router) used by the device to communicate with the ITSP (for the **SIP Trunk** application) or IP PBX (for the **Hosted IP-PBX** application).

7. In the 'Primary DNS Server' (and optionally, 'Secondary DNS Server') field, configure your primary (and optionally, secondary) DNS server in the network. This is mandatory if you use a hostname (FQDN) for ITSP (WAN only) and IP PBX addresses.
8. From the 'OAM Interface' drop-down list, select the device's interface for management traffic:
  - **LAN:** Management traffic is carried over the regular LAN interface, as defined above.
  - **WAN:** Management traffic is carried over the WAN interface, as defined above.
  - **Additional:** Configure a different interface for management traffic.
9. Click **Next**; the IP-PBX page appears (see [IP-PBX Page](#) below).

## IP-PBX Page

The IP-PBX wizard page configures the IP PBX settings.

The screenshot shows the 'IP-PBX configuration' page with the following sections and fields:

- WELCOME** | **GENERAL SETUP** | **SYSTEM** | **INTERFACES** | **IP-PBX** | **SIP TRUNK** | **REMOTE USERS(FEU)** | **NUMBER MANIPULATION** | **SUMMARY** | **FINISH**
- IP-PBX configuration**
- NETWORK INTERFACE**
  - Network Type:
- IP-PBX**
  - Address:
  - Backup Address:
  - SIP Domain:
  - Keep Alive: ☐
- SIP INTERFACE**
  - Transport Type:
  - Destination Port:
  - Listening Port:
- MEDIA PORTS (REALM)**
  - Media Protocol:
  - Base Port:
  - Number Of Sessions:
- Navigation buttons: **< Back** | **Next >** | **Cancel**



- The following fields are read-only:
  - ✓ 'Network Type': Displays the IP network interface for communicating with the IP PBX.
  - ✓ 'NAT Public IP': Displays the public IP address (of the Enterprise router) for communicating with the IP PBX. The field is applicable only when the device is connected to a router that performs NAT.
- Depending on the application type that you selected on the General Setup page ([General Setup Page](#) on page 1297), the wizard may provide additional IP-PBX pages ("IP-PBX2" and "IP-PBX3") for configuring additional servers.

### ➤ To configure IP PBX settings:

1. Under the IP-PBX group, configure the following:

- 'Address': Configure the IP address (or hostname) of the IP PBX. Note that for the **One port: WAN** network topology, when the device is assigned a public IP address, you must use the public IP address (of the Enterprise router) instead of the private address of the IP PBX, and configure the Enterprise router to forward VoIP traffic from the device to the IP PBX.
  - 'Backup Address': (Optional) Configure the backup IP address (or hostname) of the IP PBX.
  - 'SIP Domain': Configure the SIP domain name used for communication with the IP PBX. The domain name is used in the following SIP message headers:
    - ◆ Outbound calls: Request-URI and To headers
    - ◆ Inbound calls: From header
  - 'Keep Alive': Enable the periodic keep-alive check for multiple IP PBX addresses.
2. Under the Media Ports (Realm) group, configure the media protocol type and ports used by the device for communicating with the IP PBX:
    - 'Media Protocol': Configure the media protocol type (**RTP** or **SRTP**).
    - 'Base Port' Configure the first media port in the port range.
    - 'Number Of Sessions': Configure the number of required media sessions. For more information on media port ranges and number of sessions, see [Configuring RTP Base UDP Port](#) on page 295.
  3. Under the SIP Interface group, configure SIP ports and transport type for communicating with the IP PBX:
    - 'Transport Type': Configure the SIP transport type.
    - 'Destination Port': Configure the SIP port used by the IP PBX.
    - 'Listening Port': Configure the SIP port used by the device when communicating with the IP PBX.
  4. Click **Next**; the SIP Trunk page appears ([SIP Trunk Page](#) below).

## SIP Trunk Page

The SIP Trunk wizard page configures the SIP Trunk settings.

The following fields are read-only:

- 'Network Type': Displays the IP network interface for communicating with the SIP Trunk.
- 'NAT Public IP': Displays the public IP address (of the Enterprise router) for communicating with the SIP Trunk. The field is applicable only when the device is connected to a router that performs NAT. Note that the Enterprise router must be configured to "port forward" all VoIP traffic from the SIP Trunk (located on the WAN) to the device. The exact port forwarding configuration is displayed on the Conclusion page and consists of the device's address, SIP listening port (e.g. 5060) and a range of media ports defined below (e.g. 6000-6999).

➤ **To configure SIP Trunk settings:**

1. Under the SIP Trunk group, configure the following:
  - 'Address': Configures the IP address or hostname of the SIP Trunk.
  - 'Backup Address': (Optional) Configures the backup IP address or hostname of the SIP Trunk.
  - 'SIP Domain': Configures the SIP domain name for communicating with the SIP Trunk. The domain name is used in the following SIP message headers:
    - ◆ Outbound calls: Request-URI and To headers
    - ◆ Inbound calls: From header
  - 'Keep Alive': Enables the periodic keep-alive check of multiple SIP Trunk addresses.
2. Under the SIP Interface group, configure the SIP ports and transport type for communicating with the SIP Trunk:
  - 'Transport Type': Configure the SIP transport type.
  - 'Destination Port': Configure the SIP port used by the SIP Trunk.

- 'Listening Port': Configure the SIP port used by the device for communicating with the SIP Trunk. Note that for the **One port: WAN** network topology, the device must use different Listening Ports when communicating with the IP PBX and SIP Trunk.
3. Under the Media Ports (Realm) group, configure the media protocol type and ports used by the device for communicating with the IP PBX:
- 'Media Protocol': Configure the media protocol type.
  - 'Base Port': Configure the first media port.
  - 'Number Of Sessions': Configure the number of required media sessions. For more information on media port ranges and number of sessions, see [Configuring RTP Base UDP Port](#) on page 295.
4. Under the SIP Account group, configure the device's registration with the SIP Trunk:
- 'Account Type': Configure whether the device must perform registration or authentication with the SIP Trunk (**None**, **Registration** or **Authentication**).
  - 'Trunk Main Line': Configure the "leading number" assigned by the SIP Trunk. Many SIP Trunks use the same value for Trunk Main Line and Username parameters.
  - 'Username': Configure the SIP authentication username (as provided by the SIP Trunk provider).
  - 'Password': Configure the SIP authentication password (as provided by the SIP Trunk provider).



The password cannot be configured with wide characters.

5. Click **Next**; the Number Manipulation page appears (see [Number Manipulation Page](#) on the next page).

## Remote Users or Users Page

The Remote Users or Users wizard page configures remote users settings.



- This page is applicable only to IP PBXs that support such configuration.
- The parameters displayed on the page depends on the application type and template that you selected on the General Setup wizard page (see [General Setup Page](#) on page 1297).



### ➤ To configure remote users:

1. Select the 'Enable remote users' check box.
2. Under the SIP Interface group, configure the SIP interface for the remote users:
  - 'Transport Type': Configure the SIP transport type.
  - 'Listening Port': Configure the SIP port used by the device for communicating with remote users. For **One Port: LAN** and **One Port: WAN** network topologies, you must configure different listening ports for communication with the IP PBX and remote users.
3. Under the Media Ports (Realm) group, configure the media protocol type and ports used by the device for communicating with the remote users:
  - 'Media Protocol': Configure the media protocol type (RTP or SRTP).
  - 'Base Port': Configure the first media port.
  - 'Number Of Sessions': Configure the number of required media sessions. For more information on media port ranges and number of sessions, see [Configuring RTP Base UDP Port](#) on page 295.
4. Click **Next**; the Summary page appears (see [Summary Page](#) on page 1307).

## Number Manipulation Page

The Number Manipulation wizard page configures caller (source) and callee (destination) number manipulation for outbound and inbound calls, and allows you to use AudioCodes Routing Manager (ARM) to determine the routing.

Number Manipulation configuration

OUTBOUND CALLS (IP-PBX → SIP TRUNK)

Destination Number Manipulation ☒

Prefix

Remove

Add

Source Number Manipulation ☐

INBOUND CALLS (SIP TRUNK → IP-PBX)

Destination Number Manipulation ☒

Prefix

Remove

Add

Source Number Manipulation ☐

ADVANCED ROUTING MANAGER

Use ARM for call routing ☐

[< Back](#) [Next >](#) [Cancel](#)

➤ **To configure number manipulation:**

**1. Configure number manipulation:**


- a. Under the Outbound Calls and/or Inbound Calls groups, select the required manipulation check box:
  - ◆ Destination Number Manipulation: Manipulates the destination number.
  - ◆ Source Number Manipulation: Manipulates the source number.
- b. In the 'Prefix' field, configure the prefix (digits at the beginning of the number) to which you want to apply manipulation. If configured to "\*" (asterisk), manipulation is applied to all numbers.
- c. In the 'Remove' field, configure the number of digits to be removed from the beginning of the number. If configured to "0", no digits are removed.
- d. In the 'Add' field, configure a new prefix to be added to the beginning of the number. If not configured, no prefix is added.

The example below changes the number "+15033311432" to "03311432":

- Prefix: "+1503"
  - Remove: "4"
  - Add: "0"
2. To enable routing by ARM, select the 'Use ARM for call routing' check box, and then configure the following fields:
    - 'Host': IP address or FQDN of the ARM server.
    - 'Username': Username for communication with ARM.
    - 'Password': Password for communication with ARM.
  3. Click **Next**; Remote Users (FEU) page appears (see [Remote Users or Users Page](#) on page 1304).

## Summary Page

The Summary wizard page displays a summary of your configuration.




### ➤ To review your configuration:

1. Review the configuration:
  - To view the configuration in ini-file format, click the **INI File** tab.
  - To view the configuration in normal format, click the **Configuration Summary** tab.
2. To download the configuration as an ini file to a folder on your PC, click the **Save INI file** button. You can later upload the file to the device (see [Uploading an ini File to Device](#) on page 129).
3. Click **Next**; the Congratulations page appears (see [Finish Page](#) below).

## Finish Page

The Finish wizard page is the last wizard page and allows you to complete configuration.



### ➤ To complete the SBC Configuration Wizard:

- Click **Apply & Reset** to apply configuration to the device or click **Save INI File** to save configuration as an ini file on your PC.

## 49 Restoring Factory Defaults

This section describes how to restore the device's configuration to factory defaults.

### Restoring Factory Defaults through CLI

You can restore the device to factory defaults through CLI. You can restore all configuration to factory defaults or you can restore all configuration to factory defaults except the current network settings. Preserving network settings allows you to remotely connect to the device using its current OAMP IP address even after the device has been restored to default settings.

#### ➤ To restore factory defaults through CLI:

1. Access the CLI:
  - a. Connect the RS-232 serial port of the device to the communication port on your computer. For serial cabling, refer to the Hardware Installation Manual.
  - b. Establish serial communication with the device using a serial communication program (such as HyperTerminal™) with the following communication port settings:
    - ◆ Baud Rate: 115,200 bps
    - ◆ Data Bits: 8
    - ◆ Parity: None
    - ◆ Stop Bits: 1
    - ◆ Flow Control: None
2. At the CLI prompt, type the username (default is "Admin" - case sensitive), and then press Enter:

```
# Username: Admin
```

3. At the prompt, type the password (default is "Admin" - case sensitive), and then press Enter:

```
# Password: Admin
```

4. At the prompt, type the following, and then press Enter:

```
# enable
```

5. At the prompt, type the password again, and then press Enter:

```
# Password: Admin
```

6. At the prompt, type one of the following commands, and then press Enter:

- To restore all configuration to factory defaults:

```
# write factory
```

- To restore configuration to factory defaults except current network settings:

```
# write factory keep-network-and-users-configuration
```

- To restore configuration to factory defaults and delete all TLS-related files (e.g., certificates, root certificates and public keys):

```
# write factory clear-keys-and-certs
```

## Restoring Factory Defaults through Web Interface

You can restore the device to factory defaults through the Web interface.



When restoring the device to factory defaults, you can preserve basic IP network settings (configured in the IP Interfaces table - see [Configuring IP Network Interfaces](#) on page 157), as described below. This ensures that connectivity to the device (through the OAMP interface) is maintained after factory defaults have been applied.

### ➤ To restore factory defaults through Web interface:

1. Open the Configuration File page:

- **Toolbar:** From the **Actions** drop-down menu, choose **Configuration File**.
- **Navigation tree:** **Setup** menu > **Administration** tab > **Maintenance** folder > **Configuration File**.

RESTORE THE DEFAULT CONFIGURATION OF THE DEVICE

Restore Factory Defaults

☒ Preserve basic connectivity.

2. To keep your current IP network settings (e.g., OAMP), select the **Preserve basic connectivity** check box. To overwrite all your IP network settings with the default IP network interface, clear this check box.
3. Click the **Restore Defaults** button; a message appears requesting you to confirm.
4. Click **OK** to confirm or **Cancel** to return to the page.

5. Once the device is restored to factory defaults, restart the device for the settings to take effect.

## Restoring Defaults using Hardware Reset Button

You can restore the device to factory defaults by pressing the device's hardware reset pinhole button.

### ➤ To restore default settings using the hardware reset pinhole button:

- With a paper clip or any other similar pointed object, press and hold down the device's reset pinhole button for at least 15 seconds (but no more than 25 seconds).

For the exact location of the reset pinhole button on the device, refer to the *Hardware Installation Manual*.

## Restoring Defaults through ini File

You can restore the device to factory defaults as described below.

### ➤ To restore the device to factory defaults:

1. Create an **empty** text-based file and save it in a folder on your PC with the filename extension .ini.
2. Upload the file to the device using the Configuration File page (see [Downloading and Uploading Configuration Files](#) on page 1257).



The only settings that are not restored to default are the management (OAMP) LAN IP address and the Web interface's login username and password.

# **Part IX**

## **Status, Performance Monitoring and Reporting**

## 50 System Status

This section describes how to view system status.

### Viewing Device Information

You can view hardware and software information about the device on the Device Information page.

➤ **To view device information:**

- Open the Device Information page (**Monitor** menu > **Monitor** tab > **Summary** folder > **Device Information**).

GENERAL		LOADED FILES	
MAC Address	00:90:8f:5b:10:35	Loaded Call Progress Tones	Default Progress Tones
Serial Number	5967925		
BID	5b1035:238		
Product Key			
Device Name	M500		
Device Up Time	0d:0h:30m:51.13s		
Device Administrative State	Unlocked		
Device Operational State	Enabled		
Flash Size [Mbytes]	64		
RAM Size [Mbytes]	512		
CPU Model	Cavium Networks Octeon V0.1 @ 500Mhz		
CPU Speed [MHz]	500		
VERSIONS			
Version ID	7.40A.250.235		
DSP Software Version	0724.20		
DSP Software Name	5014AE3_R		

**Table 50-1: Device Information Page Description**

Parameter	Description
<b>General Info</b>	
'MAC Address'	Media access control (MAC) address.
'Serial Number'	Serial number of the CPU. This serial number also appears on the product label that is affixed to the chassis.
'BID'	Board ID, which is a unique number that identifies the device and non-SIP session related logs generated by the device. For more




Parameter	Description
	information, see <a href="#">Syslog Message Format</a> on page 1482.
'Product Key'	Product Key, which identifies the specific device purchase (and used for communication with AudioCodes, for example, for support and software upgrades). The Product Key also appears on the product label that is affixed to the chassis. For more information, see <a href="#">Viewing the Device's Product Key</a> on page 1256.
'Device Name'	Numerical identification of the product (device).
'Device Up Time'	Duration that the device has been up and running since the last restart (uptime). The duration is displayed in the following format: <i>dd:hh:mm:ss.ss</i> . For example, "1d:21h:40m:21s:75.22" means that the device has been running for one day and 21 hours, 40 minutes and 21.22 seconds.
'Device Administrative State'	Administrative status, as performed in <a href="#">Locking and Unlocking the Device</a> on page 1205. <ul style="list-style-type: none"> <li>■ "Unlocked"</li> <li>■ "Locked"</li> </ul>
'Device Operational State'	Operational status: <ul style="list-style-type: none"> <li>■ "Disabled"</li> <li>■ "Enabled"</li> <li>■ "Error"</li> <li>■ "Unknown"</li> </ul>
'Flash Size'	Size of the non-volatile storage memory (flash), measured in megabytes.
'RAM Size'	Size of the random access memory (RAM), measured in megabytes.
'CPU Model'	CPU model.
'CPU Speed'	Clock speed of the CPU, measured in megahertz (MHz).
<b>Versions</b>	
'Version ID'	Software version number.

Parameter	Description
'DSP Software Version'	DSP software version.
'DSP Software Name'	DSP software name.
<b>Loaded Files</b>	
'<File Type> File Name'	Displays installed Auxiliary files (e.g., Dial Plan). You can delete a file, by clicking the corresponding <b>Delete</b> button.
<b>Redundant Info</b>	
<b>Note:</b> This group is only displayed if the device is operating in High-Availability (HA) mode.	
'Redundant MAC Address'	MAC address of the redundant device.
'Redundant Serial Number'	Serial number of the redundant device.

## Viewing Device Status on Monitor Page

The Web interface's Monitor page provides basic status and information on the device. The page is useful in that it allows you to easily obtain an overview of the device's operating status at a glance.

### ➤ To view device status and information on the Monitor home page:


- On the Menu bar, click **Monitor** or if you are already in the Monitor menu's Navigation tree, click  **Monitor**.

The Monitor page displays the following groups of information:

#### ■ Top bar, displaying general device information:


- **Address:** IP address of the device's OAMP interface
- **Firmware:** Software version currently running on the device
- **Type:** Name of device
- **HA Status:** High-Availability (HA) status of the device, if configured for HA. For more information, see [Viewing HA Status on Monitor Web Page](#) on page 1178.
- **S/N:** Serial number of device

#### ■ SBC tab:



- **Active Calls:** Displays the total number of currently active SBC calls. The corresponding SNMP performance monitoring MIB is `ackPisbcCallStatsCurrentGlobalActiveCallsIn`.
- **Answer Seizure Ratio (ASR):** Displays the number of successfully answered calls out of the total number of attempted calls. The corresponding SNMP performance monitoring MIB is `ackPisbcCallStatsCurrentGlobalAnswerSeizureRatio`.
- **Average Call Duration (ACD):** Displays the average call duration in seconds of established calls. The value is refreshed every 15 minutes and therefore, this value reflects the average duration of all established calls made within a 15 minute period. The corresponding SNMP performance monitoring MIB is `ackPisbcCallStatsCurrentGlobalAverageCallDuration`.
- **Calls per Sec:** Displays the total number of new calls per second (CPS).
- **Transactions per Sec:** Displays the total number of new SIP transactions per second (out-of-dialog transactions such as INVITE and REGISTER, or in-dialog transactions such as UPDATE and BYE). The corresponding SNMP performance monitoring MIB is `ackPiotherStatsCurrentGlobalTransactionRate`. The counter is applicable to SBC and Gateway calls.
- **Registered Users:** Displays the number of users registered with the device. The corresponding SNMP performance monitoring MIB is `ackPiotherStatsCurrentGlobalRegisteredUsers`.

#### ■ GW tab:




- **Active Calls:** Displays the total number of currently active Gateway calls. The corresponding SNMP performance monitoring MIB is `ackPigatewayCallStatsIntervalGlobalActiveCallsMax`.
- **Tel-to-IP Answer Seizure Ratio (ASR):** Displays the number of successfully answered Tel-to-IP calls out of the total number of attempted calls. The corresponding SNMP performance monitoring MIB is `ackPigatewayCallStatsIntervalGlobalAnswerSeizureRatioAvg`.

- **Average Call Duration (ACD):** Displays the average call duration in seconds of established calls. The value is refreshed every 15 minutes and therefore, this value reflects the average duration of all established calls made within a 15 minute period. The corresponding SNMP performance monitoring MIB is `ackpiGatewayCallStatsCurrentGlobalAverageCallDuration`.
- **Tel-to-IP Call Attempts per Sec.:** Displays the current number of attempted Tel-to-IP calls per second. The corresponding SNMP performance monitoring MIB is `ackpiGatewayCallStatsIntervalGlobalAttemptedCallsRateTel2IpAvg`.
- **IP-to-Tel Call Attempts per Sec:** Displays the current number of attempted IP-to-Tel calls per second. The corresponding SNMP performance monitoring MIB is `ackpiGatewayCallStatsIntervalGlobalAttemptedCallsRateIp2TelAvg`.
- **Transactions per Sec.:** Displays the current number of SIP transactions per second (i.e., transaction rate). The corresponding SNMP performance monitoring MIB is `ackpiGatewayOtherStatsCurrentGlobalTransactionRate`.
- **Average Trunks Utilization:** Displays the average number of trunks currently in use (busy). Only SIP requests are considered in the SIP transaction count. For example, a single SIP transaction is from the initial SIP INVITE request to the final SIP 200 OK response. The corresponding SNMP performance monitoring MIB is `ackpiTrunkStatsIntervalTrunkUtilizationAvg`.

- **Graphical Display of device:** Shows color-coded status icons, as shown in the figure below and described in the subsequent table:










Figure 50-1: Graphical Display of Device on Monitor Page - Mediant 500 Gateway and E-SBC




- The figure above is used only as an example as the graphical display of your device in the Web interface reflects your specific ordered hardware configuration.
- For a description of the Monitor page when the device is in High Availability (HA) mode, see [Viewing HA Status on Monitor Web Page](#) on page 1178 Viewing Device Status on Monitor Page.

Table 50-2: Description of Graphical Display of Device on Monitor Page

Item #1	Description
1	<p><b>Alarms:</b> Displays the highest severity of an active alarm raised (if any) by the device:</p> <p>■ Green = no alarms</p>

Item #1	Description
	<ul style="list-style-type: none"> <li>■ Red = Critical alarm</li> <li>■ Orange = Major alarm</li> <li>■ Yellow = Minor alarm</li> </ul> <p>To view active alarms, click <b>Alarms</b> to open the Active Alarms page (see <a href="#">Viewing Active Alarms</a> on page 1323).</p>
2	STATUS LED icon, displaying the operating status.
3	USB ports for USB storage services.
4	RS-232 interface port.
5	Module number.
6	<p>Ethernet port status icons:</p> <ul style="list-style-type: none"> <li>■  (green): Ethernet link is working.</li> <li>■  (gray): Ethernet link is not configured.</li> <li>■  (red): Ethernet link error.</li> </ul> <p>To view detailed port information, click the port icon. For more information, see <a href="#">Viewing Ethernet Port Information</a> on page 1370.</p>
7	Module name.
8	<p>Port trunk status icon:</p> <ul style="list-style-type: none"> <li>■  (gray): The trunk is not configured (i.e., not in use or disabled).</li> <li>■  (green): The trunk is synchronized.</li> <li>■  (yellow): The trunk has a Remote Alarm Indication (RAI), also known as the Yellow Alarm.</li> <li>■  (red): The trunk has a loss due to LOS (Loss of Signal) or LOF (Loss of Frame).</li> <li>■  (blue): The trunk has an Alarm Indication Signal (AIS), also known as the Blue Alarm.</li> <li>■  (orange): The trunk has a D-channel alarm.</li> </ul>

Item #1	Description
	<ul style="list-style-type: none"> <li>■  (dark orange): The trunk has an NFAS alarm.</li> </ul> <p>If you click a port, a shortcut menu appears with commands allowing you to do the following:</p> <ul style="list-style-type: none"> <li>■ <b>Port Status:</b> Displays trunk status (see <a href="#">Viewing Trunks &amp; Channels Status</a> on page 1365).</li> <li>■ <b>Port Description:</b> Let's you configure a description for the port (see <a href="#">Configuring a Description for Telephony Ports</a> on page 1211)</li> </ul> <p><b>Note:</b> For HA mode, the trunk status icons of the redundant device are not operational (i.e., displayed in gray color).</p>

## Viewing Voice Channel Information

You can view detailed information per voice port (channel).

### ➤ To view channel information:

1. Open the Monitor home page (see [Viewing Device Status on Monitor Page](#) on page 1314).
2. On the graphical display of the device, click a telephony port.
3. From the shortcut menu, choose **Port Status**.
4. (Digital ports only) In the Trunks & Channel Status page (see [Viewing Trunks & Channels Status](#) on page 1365), click a trunk's channel.

The following pop-up appears:

Channel Id 34

Table 50-3: Channel Description

Tab / Field	Description
<b>Physical</b>	
Last Current Disconnect Duration	Duration of the last current disconnect signal (far-end call party has disconnected call).
Line Current	Line current (in mA).
Line Voltage	Line voltage (in V).
Ring (0-Off, 1-On)	Displays the ringing state ("Off" or "On").
Line Connected	Displays if the line is connected or not ("Disconnected" or "Connected").
Polarity State	Displays the polarity state.
Line Polarity	Displays the line polarity ("Positive" or "Negative").
Message Waiting Indication	Displays if MWI is enabled or disabled ("On" or "Off").

Tab / Field	Description
Hook	Displays the hook state ("On Hook" or "Off Hook").
<b>SIP</b>	
Status	Status of port ("Inactive" - no call; "Active" - active call).
Call Type	Type of call: <ul style="list-style-type: none"> <li>■ "Voice" - voice call</li> <li>■ "Fax" - fax call</li> </ul>
Endpoint Status	Status of the endpoint: <ul style="list-style-type: none"> <li>■ "IDLE" - no call</li> <li>■ "ACTIVE" - active call</li> </ul>
Assigned Phone Number	Phone number assigned to the port.
MWI Information	Indicates if the phone has a voicemail (Message Waiting Indicator): <ul style="list-style-type: none"> <li>■ "yes" - endpoint has a voicemail message</li> <li>■ "..." - no voicemail</li> </ul>
Call ID	ID of the call (SIP Call-ID header).
Call Originator	Where the call originated from (caller): <ul style="list-style-type: none"> <li>■ "TEL" - call made from Tel side (i.e., the port)</li> <li>■ "IP" - call made from IP side</li> </ul>
Source Tel Number	Telephone number of the caller.
Destination Tel Number	Telephone number of the called party.
Redirect Calling Number	Telephone number of the redirected number.
Remote Signaling IP	IP address used for SIP on the IP side.
Remote RTP	IP address and port used for RTP on the IP side.
Call	Length of time (in seconds) it took to establish the call.



Tab / Field	Description
Establishment Duration	
Call Duration	Call duration (in seconds) from when the call was established.
Call State	<p>Current state of the call:</p> <ul style="list-style-type: none"> <li>■ "IDLE" - no call.</li> <li>■ "SETUP" - signaling to setup call (SIP INVITE)</li> <li>■ "ALERT" - ringing at remote end (SIP 180 Ringing)</li> <li>■ "RINGBACK" - ringback played to port</li> <li>■ "SESSION" - call has been answered and is established</li> <li>■ "RELEASE" - call has been terminated (SIP 200 OK)</li> </ul>
Coder + PTime	Coder and packetization time used for the call.
Call Type	<p>Type of call:</p> <ul style="list-style-type: none"> <li>■ "Voice" - voice call</li> <li>■ "Fax" - fax call</li> </ul>
Call Establishment Method	<p>Mode of call:</p> <ul style="list-style-type: none"> <li>■ "Normal" - no early media during SIP session establishment (before call accepted).</li> <li>■ "EarlyMedia" - media sent (e.g., announcements) before call accepted by called party.</li> </ul>
DTMF Selected Method for Tx/Rx	DTMF Transport method used for the call. For configuring the transport method, see <a href="#">Configuring DTMF Transport Types</a> on page 293.
<b>Media</b>	
RTP Direction	<p>Direction of RTP.</p> <p>"Tx &amp; Rx": both directions (transmit and receive)</p>
Local UDP Port	Local UDP port on the device.
Remote IP Address	IP address of the remote IP side.
Remote UDP	Port of the remote IP side.

Tab / Field	Description
Port	
Rx Octet Count	Total number of received packets.
Tx Octet Count	Total number of transmitted packets.
Network Jitter	Network jitter (in msec).
Roundtrip Delay	Round-trip delay time (in msec).
Packet Loss	Packet loss (in %).
Frame Duration	Frame duration (in msec).
Echo Canceller	Displays whether echo cancellation is enabled or disabled.
Silence Suppression	Displays whether silence suppression is enabled or disabled.
Input Gain	Displays the input volume gain (in dB).
Voice Volume	Displays the voice volume (in dB).
Enabled Detectors	Displays enabled detectors (e.g., AMD).
DTMF Transport Type	Displays the DTMF transport type (e.g., RFC 2833).
Fax Transport Type	Displays the fax/modem transport type (e.g., T.38).

## 51 Viewing Carrier-Grade Alarms

This section describes how to view SNMP alarms raised by the device.

### Viewing Active Alarms

You can view current (active) alarms in the Web interface that have been raised by the device. If an alarm is cleared, it is moved into the History Alarms table (see [Viewing History Alarms](#) on the next page). The alarms are displayed from newest to oldest. In other words, the most recently raised alarm is shown first in the list. The table is automatically refreshed every 60 seconds.


If the device is in High Availability (HA) mode, the table also displays alarms raised by the Redundant device. These alarms are shown in the 'Source' field with the alarm source varbind prefix, "Redundant" (e.g., "Redundant#1/EthernetLink#7"). Alarms raised by the Active device are shown without this source varbind prefix (e.g., Board#1/EthernetLink#7).



- The alarms in the table are deleted upon a device restart.
- If the device is in HA mode, the Redundant device's alarms in the table are deleted upon an HA switchover or if the device changes from HA to a Standalone device.
- To configure the maximum number of active alarms that can be displayed in the table, see the ini file parameter, ActiveAlarmTableMaxSize.
- The alarm bell icon, located on the top-right of the Web interface's window, displays the number of currently active alarms raised by the device and the highest severity (color coded - see below) of these alarms. If the device is in HA mode, the icon displays the number of currently active alarms raised by both Active and Redundant devices as well as the highest severity of all these active alarms.
- For more information, refer to the [SBC-Gateway Series SNMP Alarm Reference Guide](#).







#### ➤ To view active alarms:

##### 1. Open the Active Alarms table:

- Navigation tree: **Monitor** menu > **Monitor** tab > **Summary** folder > **Active Alarms**.
- Monitor home page: Click the "Alarms" area on the graphical display of the device (see [Viewing Device Status on Monitor Page](#) on page 1314).
- Alarm bell  icon (located in the top-right area of the Web interface)

SEQUENTIAL #	SEVERITY	SOURCE	DESCRIPTION	TIME
5	Major	Board#1/EthernetGroup#2	Ethernet Group alarm. Ethernet Group 2 is Down.	18/10/2023, 06:46:52
4	Minor	Board#1/EthernetLink#4	Ethernet link alarm. LAN port number 4 is down.	18/10/2023, 06:46:49
3	Minor	Board#1/EthernetLink#2	Ethernet link alarm. LAN port number 2 is down.	18/10/2023, 06:46:49
2	Major	Board#1/IPGroup#1	IP Group is temporarily blocked. IP Group (Joe) Blocked Reasc	18/10/2023, 06:46:47

**Table 51-1: Active Alarms Table Description**

Field	Description
<b>Sequential #</b>	The number of the alarm. Alarms are numbered sequentially as they are raised by the device. The numbering resets to 1 after a device restart (i.e., the first alarm raised after a restart is assigned #1).
<b>Severity</b>	Severity level of the alarm:   Critical (red)   Major (orange)   Minor (yellow)
<b>Source</b>	Component of the device from which the alarm was raised.
<b>Description</b>	Brief description of the alarm.
<b>Time</b>	Date (DD/MM/YYYY) and time (HH:MM:SS) the alarm was raised.

## Viewing History Alarms

You can view all SNMP alarms, in the Web interface's Alarms History table, that have been raised (active alarms) as well as cleared (resolved). One of the benefits of this is that you can view alarms that may have been raised and then cleared on a continuous basis. For example, such an alarm may be raised due to an Ethernet cable that is not securely attached to the device's Ethernet port, causing the Ethernet link to be sometimes up and sometimes down. This alarm would not be listed in the Active Alarms table due to it being cleared.

The alarms in the table are displayed from newest to oldest. In other words, the most recently raised alarm is shown first in the list. The table displays both the cleared alarm and the alarm for which it was cleared adjacent to one another, as shown in the figure below for alarms #8 and #9.

To configure the maximum number of alarms that can be displayed in the table, use the [AlarmHistoryTableMaxSize] parameter. If the maximum is reached and a new alarm is added to the table, the oldest alarm is removed from the table to accommodate the new alarm.

If the device is in High Availability (HA) mode, the table also displays alarms raised by the Redundant device. These alarms are shown in the 'Source' field with the alarm source varbind prefix, "Redundant" (e.g., "Redundant#1/EthernetLink#7"). Alarms raised by the Active device are shown without this source varbind prefix (e.g., Board#1/EthernetLink#7).



- The alarms in the table are deleted upon a device restart (or power off). In other words, all the alarms listed in the Alarms History table occurred from after the last device restart. If you want to store the alarms on the device's flash memory so that they also remain listed after a restart, see [Storing Alarms History on Flash](#) on the next page.
- If the device is in HA mode, the Redundant device's alarms in the table are deleted upon an HA switchover or if the device changes from HA to a Standalone device.
- For more information, refer to the [SBC-Gateway Series SNMP Alarm Reference Guide](#).

➤ **To view history alarms:**

- Open the Alarms History table (**Monitor** menu > **Monitor** tab > **Summary** folder > **Alarms History**).

SEQUENTIAL #	SEVERITY	SOURCE	DESCRIPTION	TIME
6	Cleared	Interface#0/trunk#0	Alarm cleared: Trunk LOS Alarm.	18/10/2023, 07:13:16
5	Major	Board#1/EthernetGroup#2	Ethernet Group alarm. Ethernet Group 2 is Down.	18/10/2023, 06:46:52
4	Minor	Board#1/EthernetLink#4	Ethernet link alarm. LAN port number 4 is down.	18/10/2023, 06:46:49
3	Minor	Board#1/EthernetLink#2	Ethernet link alarm. LAN port number 2 is down.	18/10/2023, 06:46:49
2	Major	Board#1/IPGroup#1	IP Group is temporarily blocked. IP Group (Joe) Blocked Reason	18/10/2023, 06:46:47
1	Critical	Interface#0/trunk#0	Trunk LOS Alarm.	18/10/2023, 06:46:46

**Table 51-2: Alarms History Table Description**

Field	Description
<b>Sequential #</b>	The number of the alarm. The alarms are numbered sequentially as they are raised by the device. The numbering resets to 1 immediately after a device restart (i.e., the first alarm raised after a restart is assigned the number #1).
<b>Severity</b>	Severity level of the alarm: Critical (red) Major (orange) Minor (yellow) Cleared (green)
<b>Source</b>	Component of the device from which the alarm was raised.
<b>Description</b>	Brief description of the alarm.
<b>Time</b>	Date (DD/MM/YYYY) and time (HH:MM:SS) the alarm was raised.
<b>Note</b>	This column is displayed only if you have enabled the device to save alarms to flash memory. For more information, see <a href="#">Storing Alarms</a>

Field	Description
	<a href="#">History on Flash</a> on the next page

## Deleting Alarm History Table

You can delete all the alarms listed in the Alarms History table.

### ➤ To delete all alarms in Alarms History table:

1. Click the **Delete History Table** button; a confirmation message box appears.
2. Click **OK** to confirm.

## Storing Alarms History on Flash

By default, alarms in the Alarms History table are automatically deleted upon a device restart. You can avoid this by enabling the device to store these alarms on its flash memory.



Currently, the device can't be connected to (and operate with) OVOC when this feature is enabled.

### ➤ To enable persistent storage of alarms history on flash:

1. Enable the feature, by configuring the [AlarmsPersistentHistory] parameter to 1.
2. Configure how often you want the device to save all the alarms of the Alarms History table to flash, using the [SavePersistentHistoryInterval] parameter. By default, the device saves the alarms every 24 hours. When the device does a new save, it overwrites the previously stored alarms.
3. Restart the device.

After you enable this feature, the Alarms History table displays an additional column titled 'Note'. This column indicates if the alarm occurred before or after the last device restart. If the alarm occurred (raised or cleared) after the last restart, the column displays "Stored after last restart". If the alarm occurred before the last restart, the column is empty. The following figure shows an example of the Alarms History table with four alarms that occurred after the last restart (bottom of table):

SEQUENTIAL # ↕	SEVERITY	SOURCE	DESCRIPTION	TIME	NOTE
1	Critical	Board#1/CertificateExpiry#1	Rsa keys mismatch: CTX 1: Private key and Certificate do not r	01/01/2020, 08:59:30	
2	Minor	Board#1/EthernetLink#2	Ethernet link alarm. LAN port number 2 is down.	01/01/2020, 08:59:33	
3	Minor	Board#1/EthernetLink#3	Ethernet link alarm. LAN port number 3 is down.	01/01/2020, 08:59:33	
4	Minor	Board#1/EthernetLink#4	Ethernet link alarm. LAN port number 4 is down.	01/01/2020, 08:59:33	
5	Major	Board#1/EthernetGroup#2	Ethernet Group alarm. Ethernet Group 2 is Down.	01/01/2020, 08:59:36	
6	Minor	Board#1	SYS_HA: Maintenance Group - One of the links is down - NO H	01/01/2020, 08:59:36	
7	Cleared	Board#1/EthernetLink#3	Alarm cleared: Ethernet link alarm. LAN port number 3 is down.	01/01/2020, 09:27:16	
8	Cleared	Board#1/EthernetGroup#2	Alarm cleared: Ethernet Group alarm. Ethernet Group 2 is Dow	01/01/2020, 09:27:16	
9	Minor	Board#1/EthernetLink#3	Ethernet link alarm. LAN port number 3 is down.	01/01/2020, 09:27:18	
10	Major	Board#1/EthernetGroup#2	Ethernet Group alarm. Ethernet Group 2 is Down.	01/01/2020, 09:27:18	
11	Cleared	Board#1/EthernetLink#3	Alarm cleared: Ethernet link alarm. LAN port number 3 is down.	01/01/2020, 09:27:39	
12	Cleared	Board#1/EthernetGroup#2	Alarm cleared: Ethernet Group alarm. Ethernet Group 2 is Dow	01/01/2020, 09:27:39	
13	Critical	Board#1/CertificateExpiry#1	Rsa keys mismatch: CTX 1: Private key and Certificate do not r	01/01/2020, 09:30:16	
14	Minor	Board#1/EthernetLink#2	Ethernet link alarm. LAN port number 2 is down.	01/01/2020, 09:30:19	
15	Minor	Board#1/EthernetLink#4	Ethernet link alarm. LAN port number 4 is down.	01/01/2020, 09:30:19	
16	Minor	Board#1	SYS_HA: Maintenance Group - One of the links is down - NO H	01/01/2020, 09:30:22	
17	Major	Board#1	No HA! SYS_HA: Redundant unit is disconnected. HA is not op	01/01/2020, 09:43:47	Stored after last restart
18	Critical	Board#1/CertificateExpiry#1	Rsa keys mismatch: CTX 1: Private key and Certificate do not r	01/01/2020, 09:44:20	Stored after last restart
19	Minor	Board#1/EthernetLink#2	Ethernet link alarm. LAN port number 2 is down.	01/01/2020, 09:44:23	Stored after last restart
20	Minor	Board#1/EthernetLink#4	Ethernet link alarm. LAN port number 4 is down.	01/01/2020, 09:44:23	Stored after last restart



- If the device powers off, the alarms stored on flash are deleted (and the alarms in the Alarms History table are removed).
- To configure the maximum number of stored alarms (rows in Alarms History table), use the [AlarmHistoryTableMaxSize] parameter.
- This feature is not supported by the High-Availability mode (i.e., table not synchronized between active and redundant device; each has its own alarms).

## 52 Viewing Management User Activity Logs

If you have enabled the reporting of management user activities performed in the device's management interfaces (see [Reporting Management User Activities](#) on page 1502), you can view the logged activities in the Web interface, as described in the procedure below.

➤ **To view management user activity logs:**

- Open the Activity Log table (**Monitor** menu > **Monitor** tab > **Summary** folder > **Activity Log**).

ID	TIME	DESCRIPTION	USER	INTERFACE	CLIENT
10	18/10/2023, 06:51:23	CLI: 'sip-definition settings'	Admin	Telnet	10.13.2.3
9	18/10/2023, 06:51:06	CLI: 'configure voip'	Admin	Telnet	10.13.2.3
8	18/10/2023, 06:51:00	CLI: 'enable'	Admin	Telnet	10.13.2.3
7	18/10/2023, 06:50:59	User login succeeded	Admin	Telnet	10.13.2.3
6	18/10/2023, 06:50:40	CodersTable row 3 - 'PacketizationTimeIndex' was changed from '0' to '1'	Admin	WEB	10.13.2.3
5	18/10/2023, 06:50:40	CodersTable row 3 - 'CoderIndex' was changed from '99' to '1'	Admin	WEB	10.13.2.3
4	18/10/2023, 06:50:17	System configuration has been saved	Admin	WEB	10.13.2.3
3	18/10/2023, 06:50:12	Fake Retry After was changed from '6' to '7'	Admin	WEB	10.13.2.3
2	18/10/2023, 06:50:08	Reject Cancel after Connect was changed from '1' to '0'	Admin	WEB	10.13.2.3
1	18/10/2023, 06:49:42	WEB: Successful login at 10.15.7.96:80	Admin	WEB	10.13.2.3

**Table 52-1: Activity Log Table Description**

Parameter	Description
Time	Date (DD/MM/YYYY) and time (hh:mm:ss) that the activity was performed.
Description	Description of the activity.
User	Username of the user account that performed the activity.
Interface	Protocol used for connecting to the device's management interface (e.g., Telnet, SSH, Web, or HTTP).
Client	IP address of the client PC from where the user accessed the management interface.



## 52 Performance Monitoring

This section describes configuration of various performance monitoring features:

- [Configuring Alarm Thresholds for Performance Monitoring](#) below
- [Configuring User-Defined Performance Monitoring for SIP Failure Responses](#)
- [Configuring Performance Monitoring for Short and Long Calls](#) on page 1335
- [Performance Monitoring Graphs](#) on page 1337



For a detailed description of the device's performance monitoring parameters, refer to the [SBC-Gateway Performance Monitoring Reference Guide](#).

### Configuring Alarm Thresholds for Performance Monitoring

The Alarm Thresholds table lets you configure up to 100 customized alarm threshold rules for any of the device's performance monitoring parameters. These alarms are sent by the device through SNMP as SNMP trap events, notifying the SNMP manager of alarm severity level changes in performance monitoring parameters.

For each performance monitoring parameter(s), you can configure an Alarm Threshold rule with the following:

- Thresholds:
    - You can configure a threshold value that if crossed by the performance monitoring parameter raises an alarm. This is referred to as the *raise watermark*.
    - You can configure a threshold value that if crossed by the performance monitoring parameter clears a raised alarm. This is referred to as the *clear watermark*.
- The area between these two thresholds provides a hysteresis. This allows fluctuation between the thresholds and eliminates false alarms.
- Threshold crossing direction to raise or clear the alarm:
    - You can configure the alarm to be raised when the performance monitoring parameter result becomes greater than the *raise watermark* threshold and cleared when it becomes less than the *clear watermark* threshold. This is referred to as the *up* direction.
    - You can configure the alarm to be raised when the performance monitoring parameter result becomes less than the *raise watermark* threshold and cleared when it becomes greater than the *clear watermark* threshold. This is referred to as the *down* direction.
  - Alarm text (description) that is displayed when the alarm is raised or cleared.
  - Alarm severity level of the raised alarm (e.g., Major). If you want alarms raised for different threshold crossings where each threshold has a different severity level, you need to configure multiple Alarm Threshold rules for the same performance monitoring parameter.

Each rule will have different thresholds and different severity levels. For example, if you want two alarm severity levels (Major and Minor) for a performance monitoring parameter, the following two Alarm Threshold rules need to be configured for that performance monitoring specific parameter:

Parameter	Rule #1	Rule #2
'Raise Watermark'	40	20
'Clear Watermark'	30	10
'Severity'	<b>Major</b>	<b>Minor</b>

When multiple severity levels are configured for a performance monitoring parameter, the device raises or clears the different alarm severity levels according to a certain logic, explained using scenarios (chronological) base on the above configuration example:


- a. Performance monitoring parameter measurement increases to 25: A minor alarm event message is sent.
- b. Performance monitoring parameter measurement increases to 63: A major alarm event message is sent; no clear minor alarm event message is sent.
- c. Performance monitoring parameter measurement decreases to 27: Another minor alarm event message is sent; no clear alarm event messages are sent for the previous minor and major alarms.
- d. Performance monitoring parameter measurement decreases to 9: A clear minor alarm event message is sent.



A performance monitoring parameter may match multiple threshold alarms definitions. As a result, multiple thresholds may be crossed simultaneously. However, the device raises only one threshold alarm at a time. The device regulates for which of the crossed thresholds to raise an alarm:

- Among the crossed threshold alarms that the performance monitoring parameter is associated with, an alarm event is sent only for the one with the **highest** severity.
- The device sends a clear alarm event only when there are no currently crossed threshold alarms.
- The device may send multiple raised alarm events if multiple threshold alarms partially overlap.

The following illustration provides an example of an alarm threshold configured for the *up* direction:



As shown in the illustration, the alarm is only raised once it crosses the *raise watermark* threshold in the up direction (i.e., performance monitoring parameter value is greater than the threshold). The raised alarm is only cleared when it crosses the clear watermark threshold.

The following procedure describes how to configure alarm threshold rules through the Web interface. You can also configure it through ini file [PMAAlarmThresholds] or CLI (`configure system > kpi alarm-thresholds`).

➤ **To configure an alarm threshold:**

1. Open the Alarm Thresholds table (**Setup** menu > **Administration** tab > **Performance Monitoring** folder > **Alarm Thresholds**).
2. Click **New**; the following dialog box appears:

**Alarm Thresholds** [Close]

**GENERAL**

Index	<input type="text" value="0"/>
Path	<input type="text"/>
Entity Index	<input type="text"/>
KPI Name	<input type="text"/>
Direction	<input type="text" value="Up"/>
Raise Watermark	<input type="text" value="0"/>
Clear Watermark	<input type="text" value="0"/>
Raise Message	<input type="text"/>
Clear Message	<input type="text"/>
Severity	<input type="text" value="Default"/>
Mode	<input type="text" value="Disabled"/>

3. Configure an alarm threshold rule according to the parameters described in the table below.

4. Click **Apply**.**Table 52-2: Alarm Thresholds Table Parameter Description**

Parameter	Description
'Index' [Index]	<p>Defines an index number for the new table row.</p> <p><b>Note:</b> Each row must be configured with a unique index.</p>
'Path' pm-path [PMPPath]	<p>Defines the path (application name, group name and element name) of the performance monitoring parameter.</p> <p>The valid value is a string of characters (case insensitive), where the path names are separated by forward slashes (/).</p> <p>For example, the path of the licenseFeuUsage performance monitoring parameter is "system/licensestats/global".</p> <p>The valid value is a string of up to 119 characters (case insensitive).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> <li>■ For the path of the performance monitoring parameter, refer to the document <i>Performance Monitoring Reference Guide</i>. In this document, the path (application, group and element names) are the titles of the section headings under which the parameter is located.</li> </ul>
'Entity Index' entity-index [EntityIndex]	<p>Defines a specific index row of the entity with which the performance monitoring parameter is associated. For example, you may want to configure this Alarm Thresholds rule only for IP Group #7.</p> <p>The value can be a numerical index of an instance (e.g., "7"). For all indices (e.g., all IP Groups), leave the parameter's value empty. To configure a range of indices, use the syntax x-z (e.g., "1-4"). To configure multiple indices that are not consecutive, separate each by a comma without spaces before or after (e.g., "1-2,5").</p>
'KPI Name' kpi-name [KPIName]	<p>Defines the name of the performance monitoring parameter for which this alarm threshold rule applies.</p> <p>The valid value is a string of up to 255 characters (case insensitive). To configure the parameter with multiple performance monitoring parameters, separate each parameter by a comma without spaces before or after (e.g., "licenseFeuUsage,licenseSbcSignalingUsage").</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> <li>■ For the name of the performance monitoring parameter, refer to the document <i>Performance Monitoring Reference Guide</i>.</li> </ul>

Parameter	Description
'Direction' threshold- direction [Direction]	<p>Defines the direction of crossing the threshold values (watermarks) for which the alarm is raised or cleared.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Down</b> = An alarm is raised when the value of the performance monitoring parameter becomes less than the value configured for the 'Raise Watermark' parameter. The alarm is cleared when the value becomes greater than the value configured for the 'Clear Watermark' parameter.</li> <li>■ [1] <b>Up</b> = (Default) An alarm is raised when the value of the performance monitoring parameter becomes greater than the value configured for the 'Raise Watermark' parameter (threshold). The alarm is cleared when the value becomes less than the value configured for the 'Clear Watermark' parameter.</li> </ul> <p>For example, assume that you configure the parameter to <b>Down</b>, the 'Raise Watermark' parameter to 50 and the 'Clear Watermark' parameter to 60. When the performance monitoring parameter's value becomes less than 50 (e.g., 45), an alarm is raised. When the performance monitoring parameter's value becomes greater than 60 (e.g., 62), the alarm is cleared.</p> <p><b>Note:</b> The parameter is mandatory.</p>
'Raise Watermark' threshold- raise- watermark [RaiseWatermark]	<p>Defines a value that if crossed by the performance monitoring parameter, raises the alarm.</p> <p>The valid value is a number.</p> <p><b>Note:</b> The parameter is mandatory.</p>
'Clear Watermark' threshold- clear- watermark [ClearWatermark]	<p>Defines a value that if crossed by the performance monitoring parameter, clears the raised alarm.</p> <p>The valid value is a number.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is mandatory.</li> <li>■ For performance monitoring parameters that logically cannot be negative (like activeSessions), a value of "0" is not allowed.</li> </ul>
'Raise Message' threshold- raise-message [RaiseMessage]	<p>Defines the alarm text that is displayed when the alarm is raised. The valid value is a string of up to 80 characters. You can also use the following placeholders in your customized text, which the device replaces with the actual value:</p> <ul style="list-style-type: none"> <li>■ <b>%CATEGORY%</b>: Name of the category ("Application Name") to which the performance monitoring parameter belongs (e.g.,</li> </ul>

Parameter	Description
	<p>"sbc")</p> <ul style="list-style-type: none"> <li>■ <b>%GROUP%:</b> Name of the group ("Group Name") to which the performance monitoring parameter belongs (e.g., "callstats")</li> <li>■ <b>%OBJECT%:</b> Name of the configuration element ("Element Name") to which the performance monitoring parameter belongs (e.g., "ipGroups/1")</li> <li>■ <b>%PATH%:</b> Full path and name of the performance monitoring parameter (e.g., "sbc/callstats/ipgroup/1/callDialogsIn")</li> <li>■ <b>%PM%:</b> Name of the performance monitoring parameter itself (e.g. "callDialogsIn")</li> <li>■ <b>%VALUE%:</b> Value of the performance monitoring parameter</li> <li>■ <b>%CLEARWM%:</b> Value configured for the 'Clear Watermark' parameter</li> <li>■ <b>%RAISEWM%:</b> Value configured for the 'Raise Watermark' parameter</li> </ul> <p>For example: "The %PM% parameter value (%VALUE%) has exceeded the high threshold (%RAISEWM%)."</p>
'Clear Message' threshold- clear-message [ClearMessage]	<p>Defines the alarm text that is displayed when the alarm is cleared. The valid value is a string of up to 80 characters. You can also use the following placeholders in your customized text, which the device replaces with the actual value:</p> <ul style="list-style-type: none"> <li>■ <b>%CATEGORY%:</b> Name of the category ("Application Name") to which the performance monitoring parameter belongs (e.g., "sbc")</li> <li>■ <b>%GROUP%:</b> Name of the group ("Group Name") to which the performance monitoring parameter belongs (e.g., "callstats")</li> <li>■ <b>%OBJECT%:</b> Name of the configuration element ("Element Name") to which the performance monitoring parameter belongs (e.g., "ipGroups/1")</li> <li>■ <b>%PATH%:</b> Full path and name of the performance monitoring parameter (e.g., "sbc/callstats/ipgroup/1/callDialogsIn")</li> <li>■ <b>%PM%:</b> Name of the performance monitoring parameter itself (e.g. "callDialogsIn")</li> <li>■ <b>%VALUE%:</b> Value of the performance monitoring parameter</li> <li>■ <b>%CLEARWM%:</b> Value configured for the 'Clear Watermark'</li> </ul>

Parameter	Description
	<p>parameter</p> <ul style="list-style-type: none"> <li>■ <b>%RAISEWM%:</b> Value configured for the 'Raise Watermark' parameter</li> </ul> <p>For example: "The %PM% parameter value (%VALUE%) has returned to below the high threshold value (%RAISEWM%)."</p>
'Severity' threshold-severity [Severity]	<p>Defines the severity level of the alarm.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Default</b> (Default)</li> <li>■ [1] <b>Indeterminate</b></li> <li>■ [2] <b>Warning</b></li> <li>■ [3] <b>Minor</b></li> <li>■ [4] <b>Major</b></li> <li>■ [5] <b>Critical</b></li> </ul>
'Mode' threshold-mode [Mode]	<p>Enables (activates) the Alarm Threshold rule.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disabled</b> (Default)</li> <li>■ [1] <b>Enabled</b></li> </ul>

## Configuring Performance Monitoring for Short and Long Calls

The device provides performance monitoring statistics for short and long calls. By default, a call duration of less than 2 seconds is considered a short call; a call duration greater than 30 minutes is considered a long call. However, you can change these duration threshold values, as described in the procedure below.

Statistics of short calls are provided by the performance monitoring parameters shortCallsCounterTotal and shortCallsCounter. Statistics of long calls are provided by the performance monitoring parameters longCallsCounterTotal and longCallsCounter.

### ➤ To configure performance monitoring for short and long calls:

1. Open the SBC General Settings page (**Setup** menu > **Signaling & Media** tab > **SBC** folder > **SBC General Settings**).
2. In the 'Call Duration for Short Calls' field, enter the duration (in seconds) for which calls that are less than or equal to this value are considered short calls.
3. In the 'Call Duration for Long Calls' field, enter the duration (in minutes) for which calls that are greater than or equal to this value are considered long calls.

Call Duration for Short Calls [sec]

Call Duration for Long Calls [min]

4. Click **Apply**.



## Performance Monitoring Graphs

This section describes how to configure performance monitoring graphs in the device's Web interface.




- Performance monitoring is also referred to as *key performance indicators* (KPI).
- For a detailed description of all the device's performance monitoring parameters, refer to the *SBC-Gateway Performance Monitoring Reference Guide* (click [here](#)).

### Configuring KPI Layouts


The KPI Layouts table lets you configure up to 20 graph layout pages for the device's performance monitoring parameters (key performance indicators or KPI). Each KPI Layout defines the number and positioning of the graphs on the page. The graphs contain the selected performance monitoring parameters (configured later in [Adding Performance Monitoring Graphs to KPI Layouts](#) on page 1340).

You can configure a KPI Layout with one of the following layout designs:


- 1x1 (one graph):




- 1x2 (two graphs, positioned side by side):



- 2x1 (two graphs, positioned one below the other):



- 2x2 (four graph panels, two positioned side by side on one row and another two below, also positioned side by side):



Once you have configured a KPI Layout, you can configure a graph to plot performance monitoring parameters, as described in [Adding Performance Monitoring Graphs to KPI Layouts](#) on page 1340.

The following procedure describes how to configure KPI layouts through the Web interface. You can also configure it through ini file [KPIGraphs] or CLI (`configure system > kpi > layouts`).

➤ **To configure a KPI layout:**

1. Open the KPI Layouts table (**Monitor** menu > **Monitor** tab > **Performance Monitoring** folder > **KPI Layouts**).
2. Click **New**; the following dialog box appears:

3. Configure a KPI Layout according to the parameters described in the table below.
4. Click **Apply**.

**Table 53-1: KPI Layouts Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.

Parameter	Description
'Title' layouts-title [Title]	<p>Defines a name for the layout. Once you have configured the layout, it is listed with this name in the Navigation pane under the <b>Performance Monitoring</b> folder &gt; <b>Layouts</b> subfolder.</p> <p>The valid value is a string of up to 39 characters.</p> <p><b>Note:</b> Configure each row with a unique name.</p>
'Description' layouts-description [Description]	<p>Defines an arbitrary name to easily identify the layout.</p>
'Layout' layouts-layout [Layout]	<p>Defines the layout, regarding number and positioning of graphs (see also the illustrations in the beginning of this section).</p> <ul style="list-style-type: none"> <li>■ [0] <b>1x1</b> = (Default) The layout has only one graph.</li> <li>■ [1] <b>1x2</b> = The layout has two graphs, positioned side by side.</li> <li>■ [2] <b>2x1</b> = The layout has two graphs, positioned one below the other.</li> <li>■ [3] <b>2x2</b> = The layout has four graphs, two positioned side by side on one row and another two below, also positioned side by side.</li> </ul>
'Graph 1-4' layouts-graph1-4 [Graph1], [Graph2], [Graph3], [Graph4]	<p>Selects the graphs (configured in <a href="#">Adding Performance Monitoring Graphs to KPI Layouts</a> on the next page) to add to the layout. This field is used after you have configured your graphs, especially when you want to select graphs that were originally added to other KPI layouts.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Even though the Web interface displays four fields for selecting graphs, the maximum number of</li> </ul>

Parameter	Description
	<p>graphs depends on the selected KPI layout ('Layout' field above).</p> <ul style="list-style-type: none"><li>■ You can assign the same graph to multiple KPI layouts.</li></ul>


## Adding Performance Monitoring Graphs to KPI Layouts

Once you have configured a KPI Layout (see [Configuring KPI Layouts](#) on page 1337), you can add graphs to it for the device's performance monitoring parameters. You can add and plot multiple performance monitoring parameters per graph. For example, if you have configured a KPI Layout with a 1x2 layout design (i.e., two graphs, positioned side by side), you can add two performance monitoring parameters to one graph and three performance monitoring parameters to the other graph.

Adding graphs to KPI Layouts offers the following main feature-rich capabilities:

- Each graph can be configured with customized labels (titles), for example, for the x and y axis.
- Each graph can be enabled to display a tooltip showing the values of a specific point on the graph when the mouse hovers over it.
- A powerful drill-down selection list allows you to quickly and easily select the required performance monitoring parameter from the device's hierarchical structure of performance monitoring parameters.
- Each plotted performance monitoring parameter can be configured with a specific line color on the graph for easy identification.

The following uses an example of a graph to show the graph's main areas. The example shows a graph containing two plotted performance monitoring parameters, where each has a different color line.

**Legend:**

1. KPI Layout name
2. Graph title
3. Tooltip
4. Y-axis title
5. X-axis title
6. Legend of plotted performance monitoring parameters
7. Hamburger button with a drop-down menu for adding graphs and for other functionality (discussed later in this chapter)




- You can plot up to 2,100 performance monitoring parameters in total (all KPI Layouts).
- If you delete a KPI Layout in the KPI Layouts table, its listing in the Navigation pane under the **KPI Layouts > Layouts** folder is removed. However, performance monitoring graphs that were added to the deleted KPI Layout are not deleted and can be used in any other KPI Layout.
- To configure alarm thresholds per performance monitoring parameter, see [Configuring Alarm Thresholds for Performance Monitoring](#) on page 1329.

The following procedure describes how to configure performance monitoring graphs through the Web interface. You can also configure it through ini file [KPIGraphs] or CLI (`configure system > kpi > graphs`).

➤ **To add performance monitoring graphs to KPI Layout:**

1. In the Navigation pane, select the required KPI Layout name (**Monitor** menu > **Monitor** tab > **Performance Monitoring** folder > **KPI Layouts** > **Layouts**); the layout appears, as shown in the following example of a 1x2 graph layout:



2. In the required graph panel, from the 'Select Graph' drop-down list, click **Add New**; the following dialog box appears:




If you have already added performance monitoring parameters to graphs (regardless of KPI Layout), when you click the 'Select Graph' drop-down list, it also displays these performance monitoring parameters, which you can select and add to the graph.

3. Under the **General** group, configure the general settings for the graph, according to the parameters described in the table below.

**Table 53-2: Edit Graph Table Parameter Descriptions**

Parameter	Description
General	
'Graph Title' graphs-title	Defines a label (title) for the graph, which is displayed above the graph.

Parameter	Description
[KPIGraphs_Title]	<b>Note:</b> The graph's title must be unique.
'X-axis Title' graphs-xtitle [KPIGraphs_XTitle]	Defines a label for the graph's x axis, which is displayed horizontally below the x axis.
'Y-axis Title' graphs-ytitle [KPIGraphs_YTitle]	Defines a label for the y axis, which is displayed vertically alongside the y axis.
'Show Tooltip' graphs-tooltip [KPIGraphs_Tooltip]	<p>Enables a tooltip that appears when you hover your mouse over a point on the plotted line of the graph. The tooltip displays the values of the x and y axis at the specific point.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p>When enabled, you can also add text to the tooltip that is displayed with the values (see the 'Tooltip Text' parameter below).</p>
'Tooltip Text' graphs-tooltip-text [KPIGraphs_TooltipText]	<p>Defines text that is displayed in the tooltip with the plotted values, as shown in the following example:</p>  <p>If you don't configure the parameter, no text is displayed with the values in the tooltip.</p> <p><b>Note:</b> The parameter is applicable only if you configure the 'Show Tooltip' parameter to <b>Enable</b>.</p>

4. For each performance monitoring parameter that you want added to the graph, do the following:
  - a. Click the **Add New KPI** button; the following appears:

KEY PERFORMANCE INDICATORS (KPI) +

KPI # 1 ✎

Select KPI path

✎
📄
📄
🗑

- b. Use the 'Select KPI path' drop-down list to drill-down the device's hierarchical tree of performance monitoring parameters to select the performance monitoring parameter that you want added to the graph. Selection of the performance monitoring parameter includes the following drill-down stages:
- i. The type of performance monitoring parameter - realtime (**Real-time KPIs**) or historical (**Historical KPIs**).
  - ii. The application level to which the performance monitoring parameter belongs (**Gateway, Media, Network, SBC, or System**).
  - iii. The group level within the application to which the performance monitoring parameter belongs.
  - iv. The element level within the group to which the performance monitoring parameter belongs.
  - v. The performance monitoring parameter itself.

For example, the Answer Seizure Ratio performance monitoring parameter is selected as shown below:

Answer Seizure Ratio ✎

Select KPI path

▶ Real-time KPIs
 ▶ SBC application statistics
 ▶ Call statistics
 ▶ Per-IPGroup statistics

▶ IPGroup\_2

✎
📄
📄
🗑

Select specific KPI


Answer Seizure Ratio - Answer/seizure ratio (ASR, %) over 1 min sliding window

✕
▼


- c. If you are adding to the graph multiple performance monitoring parameters that are located on the same level (or near by) in the hierarchical tree, instead of drilling all the way down for each parameter, you can simply duplicate the KPI path of an already selected parameter, and then modify the path for the new parameter. To do this:
- i. Click the **Duplicate KPI** 📄 icon of the already configured KPI path (#1 in figure); the KPI path is duplicated (#2 in figure).



- ii. If you want to select a parameter that is located on the same level as the duplicated KPI path, then from the 'Select specific KPI' drop-down list (#3 in the figure), select the parameter (#4 in the figure), for example:





- iii. If you need to modify the path, in the 'Select specific KPI' field, click the x icon; the selected parameter is removed and an "x" appears at the end of the path in the 'Select KPI path' field, as shown in the following example:



In the 'Select KPI path' field, click the "x" at the end of the path; the lowest level in the hierarchical path is removed and a drop-down list appears, offering all the optional path values of that level. If you need to modify the path from a higher level in the path, keep clicking the "x" at the end of the path until the required


level. For example, the below shows the path (compare to previous figure) removed until the application level:



You can copy the path of a selected performance monitoring parameter in REST API format (e.g., `/api/v1/kpi/current/sbc/callStats/ipGroup/2/answerSeizureRatio`), by clicking the  icon corresponding to the configured performance monitoring parameter. This is useful, for example, when managing the device through REST API (see [REST-Based Management](#) on page 131) or when searching for the parameter in the *Performance Monitoring Parameters Reference Guide*. If the path includes an index, as shown in the example ("`.../ipGroup/2/...`"), when searching in the *Performance Monitoring Parameters Reference Guide*, replace the index number with "`<index>`" (e.g., `/api/v1/kpi/current/sbc/callStats/ipGroup/<index>/answerSeizureRatio`).

5. To apply a color to the graph's plotted line of the performance monitoring parameter:

- a. Click the color picker  icon; the color palette appears:



- b. Choose a line color, by using the main-colors bar (1), color slide (2), color field (3), or the hexadecimal color-code field (4).
  - c. Click **Save**.
- 6. Each plotted performance monitoring parameter has a default name, which is displayed as a legend below the graph. To modify the name:
  - a. Click the pencil icon (1) located next to the added performance monitoring name; the text box becomes available.
  - b. In the text box (2), enter a new name.
  - c. Click anywhere outside of the text box to apply your settings.



- 7. Click **Save** to save all your graph settings.

## Editing Performance Monitoring Graphs

You can edit configured graphs.

### ➤ To edit a graph:


1. In the Navigation pane, select the required KPI Layout (**Monitor** menu > **Monitor** tab > **Performance Monitoring** folder > **KPI Layouts** > **Layouts**).
2. Click the hamburger button located in the top-right corner of the graph, and then from the drop-down menu, choose **Edit Graph**; the Edit Graph dialog box appears. For more information on modifying graphs, see [Adding Performance Monitoring Graphs to KPI Layouts](#) on page 1340.

## Deleting Performance Monitoring Graphs

The device provides various options for deleting performance monitoring graphs:

### ■ Deleting a specific plotted performance monitoring parameter from a graph:


- a. In the Navigation pane, select the required KPI Layout (**Monitor** menu > **Monitor** tab > **Performance Monitoring** folder > **KPI Layouts** > **Layouts**).
- b. Click the hamburger button located in the top-right corner of the graph, and then from the drop-down menu, choose **Edit Graph**; the Edit Graph dialog box appears.

- c. Click the  icon corresponding to the performance monitoring parameter that you want to delete.



Deleting plotted performance monitoring parameters from graphs removes them from all KPI Layouts.

#### ■ Deleting all plotted performance monitoring parameters from a graph:


- a. In the Navigation pane, select the required KPI Layout (**Monitor** menu > **Monitor** tab > **Performance Monitoring** folder > **KPI Layouts** > **Layouts**).
- b. Click the hamburger  button located in the top-right corner of the graph, and then from the drop-down menu, choose **Delete Graph**.



Deleting plotted performance monitoring parameters from graphs removes them from all KPI Layouts.

#### ■ Removing all performance monitoring parameters from a graph without deleting them.


These performance monitoring parameters are not deleted from the device, but simply removed from the specific graph. You can add them at any time to a graph, by clicking the 'Select Graph' drop-down list, and then selecting them from the list (see [Adding Performance Monitoring Graphs to KPI Layouts](#) on page 1340).

- a. In the Navigation pane, select the required KPI Layout (**Monitor** menu > **Monitor** tab > **Performance Monitoring** folder > **KPI Layouts** > **Layouts**).
- b. Click the hamburger  button located in the top-right corner of the graph, and then from the drop-down menu, choose **Remove Graph from Layout**.

## Viewing Options for Performance Monitoring Graphs

The device provides the following options for viewing plotted performance monitoring parameters on graphs:


#### ■ Viewing a graph in full screen:

- a. In the Navigation pane, select the required KPI Layout (**Monitor** menu > **Monitor** tab > **Performance Monitoring** folder > **KPI Layouts** > **Layouts**).
- b. Click the hamburger  located in the top-right corner of the graph, and then from the drop-down menu, choose **View in full screen**.
- c. To exit full-screen mode, press the Escape key.

#### ■ Zooming in and out on graphs:

- a. In the Navigation pane, select the required KPI Layout (**Monitor** menu > **Monitor** tab > **Performance Monitoring** folder > **KPI Layouts** > **Layouts**).


- b. Left-click on the graph and drag the cursor to draw a box around the area into which you would like to zoom.
- c. Release the mouse; the display changes to show only the area within the box.



- d. To zoom out and return to normal view, click the **Reset Zoom** button (appears below the hamburger button).

#### ■ Showing or hiding plotted performance monitoring parameters in a graph:


- To hide a plotted performance monitoring parameter, click its legend name (located below the graph); the plotted parameter is hidden from the graph and its legend name is grayed out .
- To show a hidden plotted performance monitoring parameter, click its legend name again; the plotted parameter is displayed on the graph and its legend name is in normal font.



## Printing Performance Monitoring Graphs

You can send performance monitoring graphs to your local printer.

### ➤ To print a graph:


1. In the Navigation pane, select the required KPI Layout (**Monitor** menu > **Monitor** tab > **Performance Monitoring** folder > **KPI Layouts** > **Layouts**).
2. Click the hamburger  button located in the top-right corner of the graph, and then from the drop-down menu, choose **Print Graph**.
3. Select and define your printer, and then click **Print**.

## Downloading Performance Monitoring Graphs

You can download the current view of performance monitoring graphs to your computer in various file formats (PNG, JPEG, SVG, PDF, or CSV). The downloaded image files (PNG, JPEG, and SVG) provide a screenshot of the current view of the graph. The PDF file provides a screenshot of the current view as well as general device information (e.g., serial number). The CSV file lists the plotted values of the current view of the graph.

### ➤ To download a performance monitoring graph:

1. In the Navigation pane, select the required KPI Layout (**Monitor** menu > **Monitor** tab > **Performance Monitoring** folder > **KPI Layouts** > **Layouts**).

2. Click the hamburger  button located in the top-right corner of the graph, and then from the drop-down menu, choose one of the following: **Download Graph as PNG Image**, **Download Graph as JPEG Image**, **Download Graph as SVG Image**, **Download Graph as PDF**, or **Download Graph as CSV**.

## 54 Configuring PacketSmart Agent for Network Monitoring

You can configure the device to send voice traffic data to BroadSoft's BroadCloud™ PacketSmart™ solution for monitoring and assessing the network in which the device is deployed. The support is offered by the PacketSmart management agent embedded in the device. The PacketSmart embedded agent allows network operators and service providers to remotely measure and manage network performance at the point of demarcation and simplify the deployment of VoIP networks. By providing real-time monitoring of live traffic, PacketSmart can identify any network issues as they arise that may impact VoIP quality, enabling service providers to address issues prior to customer complaints.



- The PacketSmart feature is a license-based feature and is available only if it is included in the License Key installed on the device. For ordering the feature, please contact the sales representative of your purchased device.
- Before configuring the PacketSmart agent, configure the following:
  - ✓ Correct data and time of the device. It is recommended to use an NTP server to obtain the date and time (see [Synchronizing Date and Time through SNTP](#) on page 137).
  - ✓ IP network interface for communicating with the PacketSmart server. Typically, the OAMP interface is used. To configure IP network interfaces, see [Configuring IP Network Interfaces](#) on page 157.
  - ✓ IP network interface for the VoIP traffic that you want monitored by PacketSmart.
- For detailed information on setting up the PacketSmart solution, refer to the document *Mediant Gateways and SBCs with BroadCloud PacketSmart Configuration Note*.

The following procedure describes how to configure PacketSmart through the Web interface. You can also configure it through ini file or CLI (`configure system > packetsmart`).

### ➤ To configure the PacketSmart agent:

1. Open the Network Settings page (**Setup** menu > **IP Network** tab > **Advanced** folder > **Network Settings**).

PACKETSMART	
PacketSmart Agent Mode	Disable
ID	AUDC_MEDIANT_00908F5B1035
Platform	MEDIANT
PacketSmart Server IP Address	0.0.0.0
PacketSmart Server Port	80
Monitoring Interface	0
Network Interface	0



2. From the 'PacketSmart Agent Mode' drop-down list, select **Enable** to enable the feature.
3. Configure the remaining parameters, as required. For parameter descriptions, see [PacketSmart Parameters](#) on page 1653.

The following read-only fields are displayed:

- 'ID': Displays the name and serial number of the PacketSmart agent (i.e., the device) on the PacketSmart server.
  - 'Platform': Displays the name of the device.
4. Click **Submit**, and then restart the device with a save-to-flash for your settings to take effect.

## 55 Viewing VoIP Status

This section describes how to view VoIP-related status.

### Viewing SBC Registered Users

You can view SBC users that are registered with the device and listed in its users registration database.



This section is applicable only to the SBC application.

The following procedure describes how to view registered users through the web interface. You can also view them through CLI - `show voip register db sbc list` or `show voip register db sbc user <Address Of Record>`.

#### ➤ To view registered SBC users:

1. Open the SBC Registered Users page (**Monitor** menu > **Monitor** tab > **VoIP Status** folder > **SBC Registered Users**).

SBC Registered Users Number of AORs: 100000

CONTACT	STATUS	AVERAGE MOS	IP GROUP	RECEIVED FROM ADDRESS
AOR: 1@0.0.0.0 (8 items)				
AOR: 2@0.0.0.0 (9 items)				
AOR: 3@0.0.0.0 (7 items)				
AOR: 4@0.0.0.0 (7 items)				
0:sip@0...	Active	● 4	IP Group (#0)	0.0.0.0
1:sip@7...	Active	● 11	IP Group (#7)	0.0.0.0
2:sip@1...	Inactive	● 39	IP Group (#14)	0.0.0.0
3:sip@2...	Inactive	● 36	IP Group (#21)	0.0.0.0
4:sip@2...	Inactive	● 25	IP Group (#28)	0.0.0.0
5:sip@3...	Active	● 20	IP Group (#35)	0.0.0.0
6:sip@4...	Active	● 26	IP Group (#42)	0.0.0.0
AOR: 5@0.0.0.0 (3 items)				

**BASIC DETAILS**

Contact	3:sip@21.21.21.21
Associated Contact	
User IP Group	IP Group (#21)
Status	Active

**FEATURE DETAILS**

User Info	No
Leg Type	SBC
IP Profile	IP Profile (#21)

**TRANSPORT DETAILS**

SIP Interface	SIP (#21)
Received From IP	0.0.0.0
Received From Port	0

**MOS**

Recent MOS Value	● 22
Recent MOS Update Time	8/7/2023 16:24:44 UTC+05:30
Average	● 11

The number of AORs in the device's registration database is displayed in the 'Number Of AORs' read-only field, located in the top-right corner of the page.

2. To search for a specific AOR, in the search box located in the top-right corner of the page, type the **user part** of the SIP URI. You must type the full user part (not partial). For example, to search for AOR 1000@10.8.5.91, type "1000".
3. Click the required AOR folder to expand its contents and view its associated contacts.
4. To view detailed information of a contact associated with an AOR, select the contact; a pane appears below the table, displaying the contact's information, as described below.



Each Address of Record (AOR) can include up to 10 registered contacts.

**Table 55-1: SBC Registered Users Table Description**

Parameter	Description
<b>Basic Details</b>	
'Contact'	<p>Displays a contact associated with the Address of Record (AOR). If the contact is registered, the field shows the contact of the SIP REGISTER request.</p> <p>If the user is from the SBC User Information table (see <a href="#">Configuring SBC User Information Table through Web Interface</a> on page 776), the field shows an arbitrarily constant value (e.g., "sip:ANY@CONTACT").</p>
'Associated Contact'	<p>Displays the contact or part of the contact in the outgoing SIP REGISTER request that is forwarded by the device to the registrar server.</p> <p><b>Note:</b> This field is not applicable when the contact is from the SBC User Information table (see <a href="#">Configuring SBC User Information Table through Web Interface</a> on page 776).</p>
'User IP Group'	Displays the IP Group associated with the contact (classified to this IP Group).
'Status'	<p>Displays the registration status:</p> <ul style="list-style-type: none"> <li>■ "Active": The contact is successfully registered with the device and calls for the contact can be processed.</li> <li>■ "Inactive": The contact is currently not active. Possible causes may also include that the contact is in the middle of the initial registration process, or the contact's registration has expired.</li> </ul>
<b>Transport Details</b>	
'SIP Interface'	Displays the SIP Interface associated with the contact.
'Received from IP'	Displays the IP address from where the device received the SIP REGISTER request.
'Received from Port'	Displays the port from where the device received the SIP REGISTER request.
'Behind NAT'	Indicates if the contact is located behind NAT ("Yes" or "No").

Parameter	Description
'Allocated Port'	Displays the local port allocated by the device for the contact, toward the server. <b>Note:</b> This field is applicable only if the 'User UDP Port Assignment' parameter of the IP Group associated with the contact is configured to <b>Enable</b> .
<b>Feature Details</b>	
'User Info'	Indicates if the contact is defined in the SBC User Information table ("Yes" or "No"). For more information on the SBC User Information table, see <a href="#">Configuring SBC User Information Table through Web Interface</a> on page 776.
'Leg Type'	Displays the application type ("SBC", "LAD", or "OVR").
'IP Profile'	Displays the IP Profile associated with the contact. <b>Note:</b> This field is applicable only if the IP Profile is configured in the Classification table (not in the IP Groups table).
<b>MOS</b> For more information on MOS calculation and reporting of calls belonging to registered users, see <a href="#">Configuring Voice Quality for Registered Users</a> on page 535.	
'Recent MOS Value'	Displays the last (most recent) measured MOS (value and color) during the call. <b>Note:</b> The MOS value displayed for the registered user is reset ("0" and gray) if there have been no calls for the user for a user-defined period configured by the 'MOS Stored Timeout For No Calls' parameter.
'Recent MOS Update Time'	Displays the timestamp when the last (most recent) MOS during the call was measured (above).
'Average'	Displays the overall average MOS (value and color) of all 12 average MOS measurements done for the 12 observation intervals (12 or 24 hours).
'Minimum'	Displays the lowest average MOS (value and color) out of all the 12 average MOS measurements done for the 12 observation intervals (12 or 24 hours).

## Viewing Proxy Set Status

You can view the status of Proxy Sets that are used in your call routing topology. Proxy Sets that are not associated with any routing rule are not displayed. To configure Proxy Sets, see [Configuring Proxy Sets](#) on page 622.

### ➤ To view the status of Proxy Sets:

- Open the Proxy Sets Status page (**Monitor** menu > **Monitor** tab > **VoIP Status** folder > **Proxy Sets Status**).

PROXY SET ID	NAME	MODE	KEEP ALIVE	ADDRESS	PRIORITY	WEIGHT	SUCCESS COUNT	FAILURE COUNT	STATUS
0	ITSP-1	Load Balancing	Enabled						ONLINE
				10.8.6.88	-	-	0	18	OFFLINE
				10.8.6.89(*)	-	-	3	0	ONLINE
1	IP-PBX	Homing	Enabled						OFFLINE
				10.8.6.66	-	-	0	24	
2	ITSP-2	Parking	Enabled						NOT RESOLVED
				abc.com	-	-	0	0	NOT RESOLVED

**Table 55-2: Proxy Sets Status Table Description**

Parameter	Description
Proxy Set ID	Displays the Proxy Set ID.
Name	Displays the Proxy Set name.
Mode	Displays the Proxy Sets' operational mode: <ul style="list-style-type: none"> <li>■ "Parking" or "Homing": Redundancy mode, as configured by the Proxy Set parameter 'Redundancy Mode'.</li> <li>■ "Load Balancing: Proxy load balancing mode, as configured by the Proxy Set parameter 'Redundancy Mode'.</li> </ul>
Keep Alive	Displays whether the Proxy Keep-Alive feature is enabled ("Enabled") or disabled ("Disabled"), as configured by the Proxy Set parameter 'Proxy Keep-Alive'.
Address	Displays the IP address of the proxy server. This can be the IP address as configured in dotted-decimal notation for the Proxy Set, or the resolved IP address of a DNS query if an FQDN is configured for the Proxy Set. <ul style="list-style-type: none"> <li>■ IP addresses resolved from FQDNs are displayed as "&lt;FQDN name&gt; (&lt;resolved IP address&gt;)", for example, "abc.com(10.8.6.80)".</li> <li>■ The IP address that is currently used for routing is indicated with an</li> </ul>

Parameter	Description
	asterisk, for example, "10.8.6.89(*)". <ul style="list-style-type: none"> <li>■ If the FQDN failed to be resolved, only the FQDN name is displayed (e.g., "abc.com").</li> </ul>
Priority	Displays the priority of IP addresses resolved from FQDNs. <b>Note:</b> The field is applicable only to Proxy Sets configured with FQDNs.
Weight	Displays the weight of IP addresses resolved from FQDNs. <b>Note:</b> The field is applicable only to Proxy Sets configured with FQDNs.
Success Count	Displays the total number of successful keep-alive messages (by SIP OPTIONS) sent by the device to the proxy.
Failure Count	Displays the total number of failed keep-alive messages (by SIP OPTIONS) sent by the device to the proxy.
Status	Displays the status of the Proxy Set and its' proxy servers. <ul style="list-style-type: none"> <li>■ "ONLINE":               <ul style="list-style-type: none"> <li>✓ Proxy Set ID row: At least one proxy is online as determined by the device's keep-alive feature. The status is also "ONLINE" for IP addresses resolved from DNS queries even if keep-alive is disabled.</li> <li>✓ Proxy server rows (if multiple addresses): The proxy server is online as determined by the device's keep-alive feature.</li> </ul> </li> <li>■ "OFFLINE": The proxy is offline as determined by the device's keep-alive feature and the Proxy Set is configured for Homing ('Redundancy Mode' parameter) or enabled for load balancing ('Proxy Load Balancing Method' parameter):               <ul style="list-style-type: none"> <li>✓ Homing: The proxy is the main proxy, but the keep-alive has failed.</li> <li>✓ Load balancing: The keep-alive for the proxy has failed.</li> </ul> </li> <li>■ "NOT RESOLVED": Proxy address is configured as an FQDN, but the DNS resolution has failed.</li> <li>■ Empty field: Keep-alive for the proxy is disabled or the device has yet to send a keep-alive to the proxy.</li> </ul>

## Viewing Registration Status

The Registration Status page displays registration status of the following:

- Registration status mode of the device. This displays if you have configured single registration and authentication for the entire device (i.e., 'Registration Mode' [AuthenticationMode] parameter set to **Per Gateway**).
- Registration status of SIP Accounts, which are configured in the Accounts table (see [Configuring Registration Accounts](#) on page 750).

➤ **To view registration status:**

- Open the Registration Status page (**Monitor** menu > **Monitor** tab > **VoIP Status** folder > **Registration Status**).

**Table 55-3: Registration Status Page Description**

Parameter	Description
'Registered Per Gateway'	Displays the registration status of the device: <ul style="list-style-type: none"> <li>■ "Yes"</li> <li>■ "No"</li> </ul> <b>Note:</b> The parameter is applicable only to the Gateway application.
<b>Ports Registration Status table</b> Displays the registration status per analog (FXS) port	
'Group Name'	Displays the analog port number.
'Status'	Displays the port's registration status: <ul style="list-style-type: none"> <li>■ "Registered"</li> <li>■ "Not Registered"</li> </ul>
<b>Accounts Registration Status table</b> Displays the registration status per Account.	
'Group Type'	Displays the row index number of the Served Trunk Group or IP Group.
'Group Name'	Displays the name of the Served Trunk Group or IP Group (if applicable).
'Server Address'	Displays the address (IP address and port) of the registrar server (Proxy Set of Serving IP Group) to which the Account is registered.
'Status'	Displays the Account's registration status: <ul style="list-style-type: none"> <li>■ "Registered"</li> <li>■ "Not Registered"</li> </ul>

## Viewing IP Connectivity

You can view on-line, read-only network diagnostic connectivity information on destination IP addresses configured in the Tel-to-IP Routing table (see [Configuring Tel-to-IP Routing Rules](#) on page 914).



The table is applicable only to the Gateway application.

### ➤ To view IP connectivity status:

1. Enable alternative Tel-to-IP routing that is triggered by connectivity loss with destination. This is done by configuring the `AltRoutingTel2IPEnable` parameter to **Enable** or **Status Only**. For more information, see [Alternative Tel-to-IP Routing Based on IP Connectivity](#) on page 938.
2. Open the IP Connectivity table (**Monitor** menu > **Monitor** tab > **VoIP Status** folder > **IP Connectivity**).

IP ADDRESS	HOST NAME	CONNECTIVITY METHOD	CONNECTIVITY STATUS	QUALITY STATUS	QUALITY INFO	DNS STATUS
------------	-----------	---------------------	---------------------	----------------	--------------	------------

**Table 55-4: IP Connectivity Table Description**

Column Name	Description
<b>IP Address</b>	Displays the destination IP address, which can be one of the following: <ul style="list-style-type: none"> <li>■ Destination IP address as configured in the Tel-to-IP Routing table.</li> <li>■ Destination IP address resolved from the host name (FQDN) as configured in the Tel-to-IP Routing table.</li> </ul>
<b>Host Name</b>	Displays the host name (or IP address) as configured in the Tel-to-IP Routing table.
<b>Connectivity Method</b>	Displays the method according to which the destination IP address is queried periodically by the device to check keep-alive connectivity status (SIP OPTIONS request). To configure the keep-alive mechanism, see <a href="#">IP Destinations Connectivity Feature</a> on page 937.
<b>Connectivity Status</b>	Displays the connectivity status with the destination: <ul style="list-style-type: none"> <li>■ "OK": Remote side responds to periodic connectivity queries.</li> <li>■ "Lost": Remote side didn't respond for a short period.</li> <li>■ "Fail": Remote side doesn't respond.</li> </ul>



Column Name	Description
	<ul style="list-style-type: none"> <li>■ "Init": Connectivity queries not started (e.g., IP address not resolved).</li> <li>■ "Disable": Connectivity option is disabled (i.e., [AltRoutingTel2IPMode] parameter is configured to <b>None</b> or <b>QoS</b>). For more information, see <a href="#">Alternative Tel-to-IP Routing Based on IP Connectivity</a> on page 938.</li> </ul>
<b>Quality Status</b>	<p>Displays the QoS (according to packet loss and delay) of the destination:</p> <ul style="list-style-type: none"> <li>■ "Unknown": Recent quality information isn't available.</li> <li>■ "OK"</li> <li>■ "Poor"</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if the parameter 'Tel-to-IP Alt Routing Mode' is configured to <b>QoS</b> or <b>Both</b>.</li> <li>■ The parameter is reset if two minutes elapse without a call to the destination.</li> </ul>
<b>Quality Info</b>	<p>Displays QoS information: delay and packet loss, calculated according to previous calls.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if the parameter 'Tel-to-IP Alt Routing Mode' is configured to <b>QoS</b> or <b>Both</b>.</li> <li>■ The parameter is reset if two minutes elapse without a call to the destination.</li> </ul>
<b>DNS Status</b>	<p>DNS status:</p> <ul style="list-style-type: none"> <li>■ "DNS Disable"</li> <li>■ "DNS Resolved"</li> <li>■ "DNS Unresolved"</li> </ul>

## Viewing Gateway CDR History

You can view historical Call Detail Records (CDR) of Gateway calls in the Gateway CDR History table. The table displays the last 4,096 CDRs. CDR history information is stored on the device's memory. When a new CDR is generated, the device adds it to the top of the table and all existing entries are shifted one down in the table. If the table has reached maximum capacity of entries and a new CDR is added, the last CDR entry is removed from the table.



- The CDR fields in the table cannot be customized.
- If the device restarts, all CDRs are deleted from memory and from the table.
- You can mask (hide) values of certain CDR fields, as described in [Masking PII in CDRs](#) on page 206.

➤ **To view Gateway CDR history:**

- Web: Open the Gateway CDR History table (**Monitor** menu > **Monitor** tab > **VoIP Status** folder > **Gateway CDR History**).

CALL END TIME	END POINT	CALLER	CALLEE	DIRECTION	REMOTE IP	DURATION	TERMINATION REASON	SESSION ID
03:05:44.506	FXS-3/50	20049	20193	Incoming	10.8.128.82	00:01:03	NORMAL_CA	8bd531:46:7570959
03:05:44.503	FXS-1/50	20049	20193	Outgoing	10.8.128.82	00:01:03	NORMAL_CA	8bd531:46:7570889
03:05:43.803	FXS-4/5	20076	20220	Incoming	10.8.128.82	00:01:03	NORMAL_CA	8bd531:46:7570954
03:05:43.797	FXS-2/5	20076	20220	Outgoing	10.8.128.82	00:01:03	NORMAL_CA	8bd531:46:7570887

- CLI:

- All CDR history:

```
# show voip calls history gw
```

- CDR history for a specific SIP session ID:

```
# show voip calls history gw <session ID>
```

**Table 55-5: Gateway CDR History Table**

Field	Description
<b>Call End Time</b>	Displays the time at which the call ended. The time is displayed in the format, hh:mm:ss, where <i>hh</i> is the hour, <i>mm</i> the minutes and <i>ss</i> the seconds (e.g., 15:06:36).
<b>End Point</b>	Displays the device's endpoint involved in the call, displayed in the format: <ul style="list-style-type: none"> <li>■ Digital: &lt;interface&gt;-&lt;module&gt;/&lt;Trunk ID&gt;/&lt;B-channel&gt;. For example, "ISDN-1/2/3" denotes ISDN module 1, Trunk ID 2, B-channel 3.</li> </ul>
<b>Caller</b>	Displays the phone number (source number) of the party who made the call.
<b>Callee</b>	Displays the phone number (destination number) of the party to whom the call was made.

Field	Description
<b>Direction</b>	Displays the direction of the call with regards to IP and Tel sides: <ul style="list-style-type: none"> <li>■ "Incoming": IP-to-Tel call</li> <li>■ "Outgoing": Tel-to-IP call</li> </ul>
<b>Remote IP</b>	Displays the IP address of the call party. For an "Incoming" call, this is the source IP address; for an "Outgoing" call, this is the destination IP address.
<b>Duration</b>	Displays the duration of the call, displayed in the format hh:mm:ss, where <i>hh</i> is hours, <i>mm</i> minutes and <i>ss</i> seconds. For example, 00:01:20 denotes 1 minute and 20 seconds.
<b>Termination Reason</b>	Displays the reason for the call being released (ended). For example, "NORMAL_CALL_CLEAR" indicates a normal off-hook (hang up) of the call party.
<b>Session ID</b>	Displays the SIP session ID of the call.

## Viewing CDR History of SBC and Test Calls

You can view historical Call Detail Records (CDR) of SBC calls and Test calls in the SBC CDR History table. History CDRs are stored on the device's memory. When a new CDR is generated, the device adds it to the top of the table and all existing entries are shifted one down in the table. The table displays the last 2,048 CDRs. If the table reaches maximum capacity of entries and a new CDR is added, the last CDR entry is removed from the table.



- The CDR fields in the table cannot be customized.
- If the device restarts, all CDRs are deleted from memory and from the table.
- You can mask (hide) certain values, as described in [Masking PII in CDRs](#) on page 206.

### ➤ To view SBC and Test Call CDR history:

- **Web:** Open the SBC CDR History table (**Monitor** menu > **Monitor** tab > **VoIP Status** folder > **SBC CDR History**).

CALL END TIME	ENDPOINT TYPE	IP GROUP	CALLER	CALLEE	DIRECTION	REMOTE IP	DURATION	TERMINATION REASON	SESSION ID
11:53:30.140 UTC Su	TEST	IPGroup_1	200	200	Incoming	10.33.8.52	00:00:41	NORMAL_CALL_CLEAR	f0000d:1.228
11:52:39.415 UTC Su	TEST	IPGroup_2	201	100	Outgoing	10.33.8.52	00:00:20	NORMAL_CALL_CLEAR	f0000d:1.227
11:52:04.458 UTC Su	SBC	IPGroup_2	200	236	Incoming	10.33.8.52	00:00:02	NORMAL_CALL_CLEAR	f0000d:1.226
11:52:04.444 UTC Su	SBC	IPGroup_2	200	236	Outgoing	10.33.8.52	00:00:02	NORMAL_CALL_CLEAR	f0000d:1.226

### ■ CLI:

- All CDR history:

```
# show voip calls history sbc
```

- CDR history for a specific SIP session ID:

```
# show voip calls history sbc <session ID>
```

**Table 55-6: SBC CDR History Table**

Field	Description
<b>Call End Time</b>	Displays the time at which the call ended. The time is displayed in the format, hh:mm:ss, where <i>hh</i> is the hour, <i>mm</i> the minutes and <i>ss</i> the seconds (e.g., 15:06:36).
<b>Endpoint Type</b>	Indicates the type of CDR: <ul style="list-style-type: none"> <li>■ "SBC": CDR belongs to an SBC call.</li> <li>■ "TEST": CDR belongs to a Test call.</li> </ul>
<b>IP Group</b>	Displays the IP Group of the leg for which the CDR was generated.
<b>Caller</b>	Displays the phone number (source URI user@host) of the party who made the call.
<b>Callee</b>	Displays the phone number (destination URI user@host) of the party to whom the call was made.
<b>Direction</b>	Displays the direction of the call: <ul style="list-style-type: none"> <li>■ "Incoming"</li> <li>■ "Outgoing"</li> </ul>
<b>Remote IP</b>	Displays the IP address of the call party. For an "Incoming" call, this is the source IP address; for an "Outgoing" call, this is the destination IP address.
<b>Duration</b>	Displays the duration of the call, displayed in the format hh:mm:ss, where <i>hh</i> is hours, <i>mm</i> minutes and <i>ss</i> seconds. For example, 00:01:20 denotes 1 minute and 20 seconds.
<b>Termination Reason</b>	Displays the reason for the call being released (ended). For example, "NORMAL_CALL_CLEAR" indicates a normal termination.
<b>Session ID</b>	Displays the SIP session ID of the call.

## 56 Viewing PSTN Status

This section describes how to view PSTN-related status.

### Viewing Trunks & Channels Status

















































































































































































































































































































































































































You can view the status of the device's PSTN trunks and corresponding channels in the Web interface. It also enables you to view trunk configuration and channel information.

➤ **To view trunk and channel status:**

■ Open the Trunks & Channels Status page:

- **Navigation tree:** Monitor menu > Monitor tab > PSTN Status folder > Trunks & Channels Status.
- **Monitor home page:**
  - i. Open the Monitor home page (see [Viewing Device Status on Monitor Page](#) on page 1314).
  - ii. Click a PSTN port.

Trunks		Channels																															
Status		0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
 Trunk 1																																	



Trunks	Channels																															
	Status	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30
	Trunk 1																															
	Trunk 2																															
	Trunk 3																															
	Trunk 4																															
	Trunk 5																															
	Trunk 6																															
	Trunk 7																															
	Trunk 8																															
	Trunk 9																															
	Trunk 10																															
	Trunk 11																															
	Trunk 12																															
	Trunk 13																															



The number of displayed trunks and channels depends on configuration.

Trunk status is depicted by color-coded icons, as described in the table below:








### Table 56-1: Description of Color-Coded Icons for Trunk Status

Icon	Color	Trunk
		Label
	Gray	Disabled
	Green	Active - OK

Icon	Color	Trunk
		Label
	Yellow	RAI Alarm
	Red	LOS / LOF Alarm
	Blue	AIS Alarm
	Light Orange	D-Channel Alarm
	Dark Orange	NFAS Alarm

Channel status within a trunk is depicted by color-coded icons, as described in the table below:

**Table 56-2: Description of Color-Coded Icons for Channel Status**

Icon	Color	Label	Description
	Light blue	<b>Inactive</b>	Channel is configured, but currently has no calls
	Green	<b>Active</b>	Call in progress (RTP traffic) and no alarms
	Gray	<b>Non Voice</b>	Channel is not configured
	Blue	<b>ISDN Signaling</b>	Channel is configured as a D-channel
	Yellow	<b>CAS Blocked</b>	-
	Dark Orange	<b>Maintenance</b>	B-channel has been intentionally taken out of service due to maintenance
	Red	<b>Out Of Service</b>	B-channel is out of service

The Trunks & Channels Status page also allows you to do the following:

- **To view configuration settings of a trunk:** Click the trunk's icon, and then from the shortcut menu, choose **Trunk Settings**; the Trunk Settings page opens, displaying the trunk's settings. For more information, see [Configuring Trunk Settings](#) on page 850.
- **To view or provide a description of a trunk:**
  - a. Click the trunk's icon, and then from the shortcut menu, choose **Trunk Description**; the following appears:

## Trunk 15 Description

- b. Enter a description, and then click **Apply**.



The description can only include alphanumeric characters (without spaces).

- **To view detailed information of a trunk's channel:** Click the channel icon; a page appears with various tabs, displaying the information. For more information, see [Viewing Voice Channel Information](#) on page 1318.

## Viewing NFAS Groups and D-Channel Status

You can view the status of the device's D-channels and NFAS groups, if configured. The status of a D-channel and NFAS group can be "In Service" or "Out of Service" and the D-channel can be "Primary" or "Backup".

You can also perform a switchover from active and to standby D-channel belonging to the same NFAS group. This is done using the **Switch Activity** button. For more information, see [Performing Manual D-Channel Switchover in NFAS Group](#) on page 898.



This page is applicable only to T1 ISDN protocols supporting NFAS, and only if the NFAS group is configured with two D-channels.

### ➤ To view the status of the D-channels and NFAS groups:

- Open the NFAS Group & D-Channel Status page (**Monitor** menu > **Monitor** tab > **PSTN Status** folder > **NFAS Group & D-Channel Status**).



▼ NFAS Group #2

Status: **In Service**

D-Channels:

Trunk#1

Configuration: Primary

Status: **In Service**

NFAS Status: Active

Trunk#2

Configuration: Backup

Status: **Out Of Service**

NFAS Status: Not Applicable

Switch Activity Group #2

## 57 Viewing Network Status

This section describes how to view network-related status.

### Viewing Active IP Interfaces

You can view the device's active IP interfaces that are configured in the IP Interfaces table (see [Configuring IP Network Interfaces](#) on page 157).

➤ **To view active IP network interfaces:**

- Open the IP Interface Status page (**Monitor** menu > **Monitor** tab > **Network Status** folder > **IP Interface Status**).

INDEX	APPLICATION TYPE	IP ADDRESS	INTERFACE MODE	PREFIX LENGTH	DEFAULT GATEWAY	INTERFACE NAME	PRIMARY DNS SERVER IP ADDRESS	SECONDARY DNS SERVER IP ADDRESS	UNDERLYING DEVICE	ADDRESS STATE
0	O+M+C	10.15.7.96	IPv4 Manual	16	10.15.0.1	O+M+C	0.0.0.0	0.0.0.0	vlan 1	Permanent
NA	Internal	169.253.254.254	IPv4 Manual	16	0.0.0.0	Internalif 2	0.0.0.0	0.0.0.0	Internalif 2	Permanent

### Viewing Ethernet Device Status

You can view the status of configured Ethernet Devices that have been successfully applied. To configure Ethernet Devices, see [Configuring Underlying Ethernet Devices](#) on page 154.

➤ **To view Ethernet Device status:**

- Open the Ethernet Device Status page (**Monitor** menu > **Monitor** tab > **Network Status** folder > **Ethernet Device Status**).

INDEX	VLAN ID	UNDERLYING INTERFACE	NAME
0	1	GROUP_1	vlan 1
1	2	GROUP_2	vlan 2

### Viewing Ethernet Port Information

You can view status information of the device's Ethernet ports. To configure Ethernet ports, see [Configuring Underlying Ethernet Devices](#) on page 154



If the device is operating in High-Availability mode, you can also view Ethernet port information of the redundant device, by opening the Redundant Ethernet Port Information page (**Monitor** menu > **Monitor** tab > **Network Status** folder > **Redundant Ethernet Port Information**).

➤ **To view Ethernet port information:**

- Open the Ethernet Port Information table, by doing one of the following:

- Navigation tree: **Monitor** menu > **Monitor** tab > **Network Status** folder > **Ethernet Port Information**.
- Monitor home page: Click an Ethernet port on the graphical display of the device (see [Viewing Device Status on Monitor Page](#) on page 1314).

	PORT NAME	ACTIVE	SPEED	DUPLEX MODE	STATE	GROUP MEMBER
1	GE_1_1	Yes	1 Gbps	Full Duplex	Forwarding	GROUP_1
2	GE_1_2	No	10 Mbps	Half Duplex	Disabled	GROUP_1

Table 57-1: Ethernet Port Information Table Description

Parameter	Description
Port Name	Displays the user-defined name of the port.
Active	Displays if the port is active ("Yes") or not ("No").
Speed	Displays the speed of the Ethernet port.
Duplex Mode	Displays if the port is half- or full-duplex mode.
State	<p>Displays the status of the port.</p> <p>If the Ethernet Group contains a single port, the port status is always "Forwarding" (i.e., data is being transmitted and received on the port).</p> <p>If the Ethernet Group contains two ports (for 1+1 port redundancy):</p> <ul style="list-style-type: none"> <li>■ If the 'Mode' of the port is <b>REDUN_1RX_1TX</b>, one port is "Forwarding" (i.e., active port) and one port is "Disabled" (i.e., standby port).</li> <li>■ If the 'Mode' of the port is <b>REDUN_2RX_1TX</b> or <b>REDUN_2RX_2TX</b>, both ports are "Forwarding".</li> </ul>
Group Member	Displays the Ethernet Group to which the port belongs.

## Viewing Static Routes Status

You can view the status of static IP routes, configured in the Static Routes table (see [Configuring Static IP Routes](#) on page 174) and routes through the Default Gateway.

The status of the static routes can be one of the following:

- "Active": Static route is used by the device.
- "Inactive": Static route is not used. When the destination IP address is not on the same segment with the next hop, or the interface doesn't exist, the route state changes to "Inactive".

➤ To view the status of static IP routing:

- Open the Static Route Status table (**Monitor** menu > **Monitor** tab > **Network Status** folder > **Static Route Status**).

INDEX	DESTINATION IP ADDRESS	PREFIX LENGTH	GATEWAY IP ADDRESS	METRIC	DEVICE NAME	STATUS	DESCRIPTION
NA	10.15.0.0	16	0.0.0.0	0	vlan 1	Active	
NA	10.13.0.0	16	0.0.0.0	0	vlan 2	Active	
NA	0.0.0.0	0	10.15.0.1	1	vlan 1	Active	

## Viewing IDS Active Blocked List

The IDS Active Blocked List table displays the remote hosts that are currently blocked by the device's Intrusion Detection System (IDS).

For more information on IDS configuration, see [Intrusion Detection System](#) on page 258



For devices in High-Availability (HA) mode, all the table's entries are deleted upon an HA switchover.

The following procedure describes how to view the IDS Active Blocked List table through the Web interface. You can also view the table through CLI using the command, `show voip ids blacklist active`.

➤ To view the active IDS blocked list:

- Open the IDS Active Blocked List page (**Monitor** menu > **Monitor** tab > **Network Status** folder > **IDS Active Blocked List**).

Page 1 of 1 10 ▼ No records to view

REMAINING TIME (SECONDS)	NETWORK INTERFACE	IP ADDRESS	PORT	TRANSPORT TYPE	REMOVAL KEY
--------------------------	-------------------	------------	------	----------------	-------------

### Table 57-2: IDS Active Blocked List Table Description

Field	Description
Remaining Time	The duration left until the device deletes the attacker (remote host) from the table and takes it off the IDS blocked list. The blocked period is configured by the 'Deny Period' (IDSRule_DenyPeriod) parameter.
Network Interface	The device's IP Interface on which the malicious attack was detected.
IP Address	The IP address of the attacker (remote host).

Field	Description
Port	The port of the attacker (remote host). <b>Note:</b> The field is applicable only if the 'Threshold Scope' (IDSRule_ThresholdScope) parameter of the associated IDS rule is configured to <b>IP+Port</b> .
Transport Type	The transport type used for the attack.
Removal Key	A unique number (key) that the device assigns to the listed blocked entry. This is used if you want to remove a specific blocked entry from the table, which is done through the CLI command, <code>clear voip ids blacklist &lt;Removal Key&gt;</code> .

## 58 Reporting Information to External Party

This section describes features for reporting various information to an external party.

### Configuring RTCP XR

RTP Control Protocol Extended Reports (RTCP XR) is a VoIP management control that defines a set of metrics containing information for assessing VoIP call quality and for diagnosing problems. RTCP XR (RFC 3611) extends the RTCP reports defined in RFC 3550 by providing additional VoIP metrics (Quality of Experience). RTCP XR information publishing is implemented in the device according to RFC 6035. The draft defines how a SIP User Agent (UA) publishes the detailed information to a defined collector. RTCP XR measures VoIP call quality such as packet loss, delay, signal / noise / echo levels, estimated R-factor, and mean opinion score (MOS). RTCP XR measures these parameters using metrics as listed in the table below. RTCP XR messages containing key call-quality-related metrics are exchanged periodically (user-defined) between the device and the SIP UA. This allows an analyzer to monitor these metrics midstream, or a device to retrieve them through SNMP.



- The RTCP XR feature is available only if the device is installed with a License Key that includes this feature. For installing a License Key, see [License Key](#) on page 1233.
- If the RTCP XR feature is unavailable (not licensed or disabled), the R-factor VoIP metrics are not provided in CDRs (CDR fields, Local R Factor and Remote R Factor) generated by the device. Instead, these CDR fields are sent with the value 127, meaning that information is unavailable.
- While the device attempts to determine the signal level, it reports a MOS value of "127 (NA)". Once it has determined the signal level, it reports the estimated MOS.
- Packet loss effects voice quality estimation only during periods of voice. During periods of silence, packet loss doesn't effect or degrade voice quality.

You can configure the device to send RTCP XR to a specific IP Group. The device sends RTCP XR in SIP PUBLISH messages. The PUBLISH message contains the following RTCP XR related header values:

- From and To: Telephone extension number of the user
- Request-URI: IP Group name to where RTCP XR is sent
- Event: "vq-rtcpxr"
- Content-Type: "application/vq-rtcpxr"

You can also configure the stage of the call at which you want the device to send RTCP XR:

- End of the call.
- Periodically, according to a user-defined interval between consecutive reports.
- (Gateway Application Only) End of a media segment. A media segment is a change in media, for example, when the coder is changed or when the caller toggles between two

called parties (using call hold/retrieve). The RTCP XR sent at the end of a media segment contains information only of that segment. For call hold, the device sends RTCP XR each time the call is placed on hold and each time it is retrieved. In addition, the Start timestamp in the RTCP XR indicates the start of the media segment; the End timestamp indicates the time of the last sent periodic RTCP XR (typically, up to 5 seconds before reported segment ends).

The type of RTCP XR report event (VQReportEvent) supported by the device is VQSessionReport (SessionReport). The device can include local and remote metrics in the RTCP XR. Local metrics are generated by the device while remote metrics are provided by the remote endpoint. The following table lists the supported voice metrics (parameters) published in the RTCP XR.

**Table 58-1: RTCP XR Published VoIP Metrics**

Metric	Parameter	Description
<b>CallID</b>	-	Call ID - call ID from the SIP dialog
<b>LocalID</b>	-	Local ID - identifies the reporting endpoint for the media session
<b>RemoteID</b>	-	Remote ID - identifies the remote endpoint of the media session
<b>OrigID</b>	-	Originating ID - Identifies the endpoint which originated the session
<b>LocalAddr</b>	-	Local Address - IP address, port, and SSRC of the endpoint/UA which is the receiving end of the stream being measured
<b>RemoteAddr</b>	-	Remote Address - IP address, port, and SSRC of the source of the stream being measured
<b>LocalGroup</b>	-	Local Group ID - identification for the purposes of aggregation for the local endpoint
<b>RemoteGroup</b>	-	Remote Group ID - identification for the purposes of aggregation for the remote endpoint
<b>LocalMAC</b>	-	Media Access Control (MAC) address of the local SIP device
<b>Timestamps</b>	START	Start time of the media session, or of the media segment for the Gateway application.
	STOP	End time of the media session, or media segment (last sent RTCP XR packet) for the Gateway

Metric	Parameter	Description
		application.
<b>SessionDesc</b>	PT	Payload Type - 'payload type' parameter in the RTP packets (i.e., the codec).
	PD	Payload Description - description of the codec
	SR	Sample Rate - rate at which the voice was sampled
	FD	Frame Duration (msec) - packetization rate
	FO	Frame Octets - number of octets in each frame per RTP packet
	FPP	Frames per Packets - number of frames per RTP packet
	PLC	Packet Loss Concealment - indicates whether a PLC algorithm was used for the session ("0" - unspecified; "1" - disabled; "2" - enhanced; "3" - standard)
	SSUP	Silence Suppression State - indicates whether silence suppression, also known as Voice Activity Detection (VAD) is enabled ("on" or "off")
<b>JitterBuffer</b>	JBA	Jitter Buffer Adaptive - indicates the jitter buffer in the endpoint ("0" - unknown; "1" - reserved; "2" - non-adaptive; "3" - adaptive)
	JBR	Jitter Buffer Rate
	JBN	Jitter Buffer Nominal
	JBM	Jitter Buffer Max
	JBX	Jitter Buffer Abs Max
<b>PacketLoss</b>	NLR	Network Packet Loss Rate
	JDR	Jitter Buffer Discard Rate



Metric	Parameter	Description
<b>BurstGapLoss</b>	BLD	Burst Loss Density
	BD	Burst Duration
	GLD	Gap Loss Density
	GD	Gap Duration
	GMIN	Minimum Gap Threshold
<b>Delay</b>	RTD	Round Trip Delay (msec)
	ESD	End System Delay (msec)
	OWD	One Way Delay (msec)
	IAJ	Inter-Arrival Jitter (msec)
	MAJ	Mean Absolute Jitter (msec)
<b>Signal</b>	SL	Signal Level (dB) - ratio of the signal level to a 0 dBm0 reference
	NL	Noise Level (dB) - ratio of the silent period background noise level to a 0 dBm0 reference
	RERL	Residual Echo Return Noise (dB) - ratio between the original signal and the echo level as measured after echo cancellation or suppression has been applied
<b>QualityEst</b>	RLQ	Listening Quality R - listening quality expressed as an R factor (0-95 for narrowband calls and 0-120 for wideband calls)
	RLQEstAlg	RLQ Est. Algorithm - name (string) of the algorithm used to estimate RLQ
	RCQ	Conversational Quality R - cumulative measurement of voice quality from the start of the session to the reporting time (R is 0-95 for narrowband calls and 0-120 for wideband calls)
	RCQEstAlg	RCQ Est. Algorithm - name (string) of the algorithm used to estimate RCQ

Metric	Parameter	Description
	EXTRI	External R In - voice quality as measured by the local endpoint for incoming connection on "other" side (R is 0-95 for narrowband calls and 0-120 for wideband calls)
	ExtRIEstAlg	Ext. R In Est. Algorithm - name (string) of the algorithm used to estimate EXTRI
	EXTRO	External R Out - value is copied from RTCP XR received from the remote endpoint on the "other" side of this endpoint (R is 0-95 for narrowband calls and 0-120 for wideband calls)
	ExtROEstAlg	Ext. R Out Est. Algorithm - name (string) of the algorithm used to estimate EXTRO
	MOSLQ	MOS-LQ - estimated mean opinion score for listening voice quality on a scale from 1 to 5, in which 5 represents excellent and 1 represents unacceptable
	MOSLQEstAlg	MOS-LQ Est. Algorithm - name (string) of the algorithm used to estimate MOSLQ
	MOSCQ	MOS-CQ - estimated mean opinion score for conversation voice quality on a scale from 1 to 5, in which 5 represents excellent and 1 represents unacceptable
	MOSCQEstAlg	MOS-CQ Est. Algorithm - name (string) of the algorithm used to estimate MOSCQ
	QoEEstAlg	QoE Est. Algorithm - name (string) of the algorithm used to estimate all voice quality metrics
<b>DialogID</b>	-	Identification of the SIP dialog with which the media session is related

Below shows an example of a SIP PUBLISH message sent with RTCP XR and QoE information:

```
PUBLISH sip:172.17.116.201 SIP/2.0
Via: SIP/2.0/UDP 172.17.116.201:5060;branch=z9hG4bKac2055925925
Max-Forwards: 70
From: <sip:172.17.116.201>;tag=1c2055916574
```

To: <sip:172.17.116.201>  
Call-ID: 20559160721612201520952@172.17.116.201  
CSeq: 1 PUBLISH  
Contact: <sip:172.17.116.201:5060>  
Allow:  
REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE  
Event: vq-rtcpvr  
Expires: 3600  
User-Agent: device/7.60A.100.022  
Content-Type: application/vq-rtcpvr  
Content-Length: 1066

VQSessionReport  
CallID=20328634741612201520943@172.17.116.201  
LocalID: <sip:1000@172.17.116.201>  
RemoteID: <sip:2000@172.17.116.202;user=phone>  
OrigID: <sip:1000@172.17.116.201>  
LocalAddr: IP=172.17.116.201 Port=6000 SSRC=0x54c62a13  
RemoteAddr: IP=172.17.116.202 Port=6000 SSRC=0x243220dd  
LocalGroup:  
RemoteGroup:  
LocalMAC: 00:90:8f:57:d9:71

LocalMetrics:  
Timestamps: START=2015-12-16T20:09:45Z STOP=2015-12-16T20:09:52Z  
SessionDesc: PT=8 PD=PCMA SR=8000 FD=20 PLC=3 SSUP=Off  
JitterBuffer: JBA=3 JBR=0 JBN=7 JBM=10 JBX=300  
PacketLoss: NLR=0.00 JDR=0.00  
BurstGapLoss: BLD=0.00 BD=0 GLD=0.00 GD=6325 GMIN=16  
Delay: RTD=0 ESD=11  
Signal: SL=-34 NL=-67 RERL=17  
QualityEst: RLQ=93 MOSLQ=4.1  
MOSCQ=4.10

RemoteMetrics:  
Timestamps: START=2015-12-16T20:09:45Z STOP=2015-12-16T20:09:52Z  
JitterBuffer: JBA=3 JBR=0 JBN=0 JBM=0 JBX=300  
PacketLoss: NLR=0.00 JDR=0.00  
BurstGapLoss: BLD=0.00 BD=0 GLD=0.00 GD=0 GMIN=16  
Delay: RTD=65535 ESD=0  
QualityEst:

DialogID: 20328634741612201520943@172.17.116.201;to-tag=1c1690611502;from-tag=1c2032864069

➤ **To configure RTCP XR:**

1. Open the RTP/RTCP Settings page (**Setup** menu > **Signaling & Media** tab > **Media** folder > **RTP/RTCP Settings**).
2. Under the RTCP-XR group, configure the following:
  - From the 'Enable RTCP XR' drop-down list (*VQMonEnable*), select the required option for voice quality monitoring and RTCP XR.
  - In the 'Tx RTCP Packets Interval' field (*RTCPInterval*), type the time interval between consecutive RTCP reports.
  - Select the 'Disable RTCP XR Interval Randomization' check box (*DisableRTCPRandomize*) to disable randomization of RTCP report intervals, or clear the check box so that each report interval accords exactly to the parameter [RTCPInterval].
  - In the 'Burst Threshold' field (*VQMonBurstTHR*), type the voice quality monitoring excessive burst alert threshold.
  - In the 'Delay Threshold' field (*VQMonDelayTHR*), type the voice quality monitoring excessive delay alert threshold.
  - In the 'R-Value Delay Threshold' field (*VQMonEOCRValTHR*), type the voice quality monitoring end of call low quality alert threshold.
  - In the 'Minimum Gap Size' field (*VQMonGMin*), type the voice quality monitoring minimum gap size (number of frames).

#### RTCP-XR

Enable RTCP XR	• <span>Enable Fully</span> ▼
Tx RTCP Packets Interval (in msec)	<input type="text" value="5000"/>
Disable RTCP XR Interval Randomization	• <input checked="" type="checkbox"/>
Burst Threshold	<input type="text" value="-1"/>
Delay Threshold	<input type="text" value="-1"/>
R-Value Delay Threshold	<input type="text" value="-1"/>
Minimum Gap Size	<input type="text" value="16"/>

3. Under the RTCP-XR Collection Server group, configure the following:

- (Gateway Application Only) From the 'Gateway RTCP XR Report Mode' drop-down list (RTCPXRReportMode), select the required option for sending RTCP XR reports and the stage of the call to send.
- From the 'Publication IP Group ID' drop-down list (PublicationIPGroupID), select the IP Group to where you want the device to send the RTCP XR reports.
- (SBC Application Only) From the 'SBC RTCP XR Report Mode' drop-down list (SBCRtcpXrReportMode), select the option to enable the sending of RTCP XR reports of QoE metrics at the end of each call session (i.e., after a SIP BYE).

#### RTCP-XR COLLECTION SERVER

Gateway RTCP XR Report Mode	•	End Call & Periodic	▼
Publication IP Group ID	•	#0 [Default_IPG]	▼ View
SBC RTCP XR Report Mode	•	End of Call	▼

4. Click **Apply**, and then restart the device with a save-to-flash for your settings to take effect.

## Call Detail Records

Call Detail Records (CDR) contain vital statistics and information on calls processed by the device. The device can generate and report CDRs at various stages of the call (e.g., start of call or end of call). CDRs can be generated for SIP signaling and media.

The device can send CDRs to any of the following:

- **Syslog server:** The CDR Syslog message complies with RFC 3164 and is identified by Facility 17 ("local1") and Severity 5 (Notice).
- **RADIUS server:** For CDR in RADIUS format, see [Configuring RADIUS Accounting](#) on page 1456. To configure RADIUS servers for CDR reporting, see [Configuring RADIUS Servers](#) on page 360.
- **REST server:** The device can send signaling-related CDRs to a REST server using AudioCodesREST API (see [Configuring CDR Reporting to REST Server](#) on page 1383).
- **Locally on the device:** CDRs can be stored locally on the device (see [Storing CDRs Locally on the Device](#) on page 1384).



- To view Gateway CDRs stored in the device's memory, see [Viewing Gateway CDR History](#) on page 1361.
- To view SBC and Test Call CDRs stored on the device's memory, see [Viewing CDR History of SBC and Test Calls](#) on page 1363.

## Enabling CDR Generation and Configuring the CDR Server Address

For the device to generate CDRs, you need to enable the syslog feature and configure a collecting server address. The collecting server can be a dedicated CDR server or the server used for syslog messages.

### ➤ To enable CDR generation and configure the CDR server address:

1. Enable the syslog feature (see [Enabling Syslog](#) on page 1490).
2. Open the Call Detail Record Settings page (**Troubleshoot** menu > **Troubleshoot** tab > **Call Detail Record** folder > **Call Detail Record Settings**).
3. In the 'CDR Syslog Server IP Address' [CDRSyslogServerIP] field, enter the address (IPv4 or IPv6, or FQDN) of the server to where you want the CDRs sent.

CDR Syslog Server IP Address

14.7.8.9

4. Click **Apply**.



- If you don't configure an address for the CDR server, the device sends the CDRs to the address that you configured for the syslog servers in [Configuring the Primary Syslog Server Address](#) on page 1490 and [Configuring Secondary Syslog Servers](#) on page 1492.
- The IP Interface, port configured for the syslog server in [Configuring the Primary Syslog Server Address](#) on page 1490 are also used for the CDR server.

## Configuring CDR Filters and Report Level

You can configure various CDR filters and the stage of the call at which you want the device to generate and send CDRs. For a detailed description of the parameters described in this section, see [Syslog, CDR and Debug Parameters](#) on page 1624.

### ➤ To configure CDR filters and report level:

1. Open the Call Detail Record Settings page (**Troubleshoot** menu > **Troubleshoot** tab > **Call Detail Record** folder > **Call Detail Record Settings**).
2. Configure CDR filters:
  - In the 'Call-End CDR SIP Reasons Filter' [CallEndCDRSIPReasonsFilter] field, configure the SIP release cause codes that if received for calls, the device doesn't generate and send Call-End CDRs:

Call-End CDR SIP Reasons Filter

• 300,4xx

- Select the 'Call-End CDR Zero Duration Filter' check box [CallEndCDRZeroDurationFilter] if you want the device to not generate and send Call-End CDRs for calls of zero (0) duration:

Call-End CDR Zero Duration Filter ☒

3. Configure the call stage at which CDRs are generated and sent:

- From the 'CDR Report Level' [CDRReportLevel] drop-down list, select the stage of the call at which you want signaling-related CDRs to be generated and sent.
- (SBC Application Only) From the 'Media CDR Report Level' [MediaCDRReportLevel] drop-down list, select the stage of the call at which you want media-related CDRs to be generated and sent.

CDR Report Level	None	▼
Media CDR Report Level	None	▼

4. Click **Apply**.

## Configuring CDR Reporting to REST Server

You can configure the device to send signaling-related CDRs to a REST server using AudioCodes REST API. The device sends the CDRs in JSON format.



You can customize the CDRs that are sent to the REST server, by adding CDR fields or changing their names. For more information, see [Customizing CDRs for SBC Calls and Test Calls](#) on page 1446 for SBC calls and [Customizing CDRs for Gateway Calls](#) on page 1440 for Gateway calls.

➤ **To configure CDR reporting to a REST server:**

1. Enable the syslog feature for sending log messages (CDRs) generated by the device to a collecting log message server. For more information, see [Enabling Syslog](#) on page 1490.
2. Configure the REST server:
  - a. Open the Remote Web Services table (see [Configuring Remote Web Services](#) on page 429).
  - b. Click **New**, and then configure an HTTP/S-based server to represent the REST server. Make sure that you configure the 'Type' parameter to **General**. Configure the remaining HTTP/S server parameters according to your requirements.
  - c. Click **Apply**.
3. Open the Call Detail Record Settings page (**Troubleshoot** menu > **Troubleshoot** tab > **Call Detail Record** folder > **Call Detail Record Settings**), and then do the following:

- a. From the 'REST CDR Report Level' drop-down list, select the stage of the call at which you want the CDRs to be generated and sent.
- b. From the 'REST CDR HTTP Server Name' drop-down list, select the REST server that you configured in the Remote Web Services table (see Step 2) to where you want the device to send the CDRs.

REST CDR REPORT

REST CDR Report Level

•

Start & End Call

▼

REST CDR HTTP Server Name

•

#0 [REST-CDRS]

▼

[View](#)

- c. Click **Apply**.

## Miscellaneous CDR Configuration

Miscellaneous but important CDR configuration parameters are listed below:

- To enable or disable the inclusion of the sequence number (S=) in CDR Syslog messages, use the 'CDR Syslog Sequence Number' [CDRSyslogSeqNum] parameter.
- The device sends CDRs only for dialog-initiating INVITE messages (call start), 200 OK responses (call connect) and BYE messages (call end). For SBC calls only: If you want to enable the generation of CDRs for non-call SIP dialogs (such as SUBSCRIBE, OPTIONS, and REGISTER), use the [EnableNonCallCdr] parameter.
- To configure the units of measurement for the call duration in CDRs ("Duration" CDR field), use the [CallDurationUnits] parameter.
- To configure the time zone (e.g., GMT+1) that is displayed with the timestamp in CDRs ("Connect Time", "Release Time", and "Setup Time" CDR fields), use the [TimeZoneFormat] parameter

## Storing CDRs Locally on the Device

CDRs generated by the device can be stored locally on the device (RAM).

You can specify the calls for which you wish to create locally stored CDRs. This is done using Logging Filter rules in the Logging Filters table. For example, you can configure a rule to create locally stored CDRs for traffic belonging only to IP Group #2.

Locally stored CDRs are saved in a comma-separated values file (\*.csv), where each CDR is on a dedicated row or line. An example of a CSV file with two CDRs are shown below :

- CSV file viewed in Excel:

	A	B	C	D	E	F	G	H
1	3b463e:215:1	CALL_END	4	14:34:40.000 UTC Wed Dec 16 2015	14:34:35.000 UTC Wed Dec 16 2015	14:34:33.000 UTC Wed Dec 16 2015	RMT	GWAPP_NORMAL
2	3b463e:215:1	CALL_END	4	14:34:40.000 UTC Wed Dec 16 2015	14:34:35.000 UTC Wed Dec 16 2015	14:34:33.000 UTC Wed Dec 16 2015	LCL	GWAPP_NORMAL
3								

- CSV file viewed in a text editor (Notepad):



1	3b463e:215:1,CALL_END,4,14:34:40.000	UTC Wed Dec 16 2015,14:34:35.000	UTC Wed Dec 16 2015,14:34:33.000	UTC Wed Dec 16 2015,RMT,GWAPP_NORMAL_I
2	3b463e:215:1,CALL_END,4,14:34:40.000	UTC Wed Dec 16 2015,14:34:35.000	UTC Wed Dec 16 2015,14:34:33.000	UTC Wed Dec 16 2015,LCL,GWAPP_NORMAL_I
3				

The device's CLI provides enhanced support for performing various actions on locally stored CDRs:

- To view the CDR column headers corresponding to the CDR data in the CSV file:

- SBC CDRs:

```
(config-system)# cdr
(cdr)# cdr-format show-title local-storage-sbc
session id,report type,call duration, call end time, call connect time,call
start time, call originator, termination reason, call id, srce uri, dest uri
```

- Gateway CDRs:

```
(config-system)# cdr
(cdr)# cdr-format show-title local-storage-gw
```

- To view stored CDR files:

- View all stored CDR files:

```
# show storage-history
```

- View all stored, unused CDR files:

```
# show storage-history unused
```

- To copy stored CDR files to a remote destination:

```
# copy storage-history cdr-storage-history <filename> to
<protocol://destination>
```

Where:

- *filename*: name you want to assign the file. Any file extension name can be used, but as the file content is in CSV format, it is recommended to use the .csv file extension.
- *protocol*: protocol over which the file is sent (tftp, http, or https).

For example:

```
copy storage-history cdr-storage-history my_cdrs.csv to
tftp://company.com/cdrs
```

- To delete stored CDR files, see [Deleting Locally Stored CDRs](#) on page 209.



- If the device restarts or powers off, locally stored CDRs are deleted.
- Locally stored CDRs are applicable only to "CALL\_END" CDR Report Types and to SBC signaling and Gateway CDRs.
- When the device operates in High-Availability (HA) mode, active and redundant devices maintain their own stored CDRs. In other words, upon an HA switchover the stored CDRs on the active device are not copied to the redundant device (which becomes the new active device). However, you can view the stored CDRs on the redundant device without performing a switchover, by accessing the redundant device from the active device through SSH (or SFTP), as described in [Accessing Files on Redundant Device from Active through SSH](#) on page 1200.
- You can customize the CDR fields for local storage. See [Customizing CDRs for SBC Calls and Test Calls](#) on page 1446 for SBC calls. For Gateway calls, see [Customizing CDRs for Gateway Calls](#) on page 1440.

➤ **To configure local CDR storage:**

1. Open the Logging Filters table (see [Configuring Logging Filter Rules](#) on page 1470), and then enable CDR local storage by configuring a log filtering rule with the following settings:
  - 'Filter Type' and 'Value': (as desired)
  - 'Log Destination': **Local Storage**
  - 'Log Type': **CDR**
  - 'Mode': **Enable**
2. Open the Call Detail Record Settings page (**Troubleshoot** menu > **Troubleshoot** tab > **Call Detail Record** folder > **Call Detail Record Settings**), and then configure the following parameters:
  - 'File Size' [CDRLocalMaxFileSize]: Enter the maximum size (in kilobytes) of the CDR file. When the Current file reaches this size, the device creates a CDR file. However, if the 'Rotation Period' is reached before the file has reached this maximum size, the CDR file is created.
  - 'Number of Files' [CDRLocalMaxNumOfFiles]: Enter the maximum number of CDR files. If this maximum is reached, any new CDR file replaces the oldest CDR file (i.e., FIFO).
  - 'Rotation Period' [CDRLocalInterval]: Enter the periodic duration (in minutes) of how often a CDR file is created from the Current file (even if empty). For example, if configured to 60, a file is created every hour (or before, if the maximum size has been reached).

For a detailed description of each parameter, see [Syslog, CDR and Debug Parameters](#) on page 1624.

File Size (KBytes)	1024
Number Of Files	5
Rotation period (min)	60



If the CDR storage feature is enabled and you later change the maximum number of files (using the [CDRLocalMaxNumOfFiles] parameter) to a lower value (e.g., from 50 to 10), the device stores the remaining files (e.g., 40) in its memory as *unused* files.


## CDR Field Description

This section describes the CDR fields that can be generated by the device. Some are generated by default, while others are generated only if you customize the CDR to include them, as described in [Customizing CDRs for Gateway Calls](#) on page 1440 and [Customizing CDRs for SBC Calls and Test Calls](#) on page 1446.

■ For SBC calls, the device generates a signaling CDR and a media CDR:

- **Media CDR:** This CDR is published per active media stream. Each media CDR has a unique call ID that corresponds to its signaling CDR. There are three different CDR Report Types (CDRReportType), which the device sends to the CDR server at different stages of the SIP dialog session:
  - ◆ "MEDIA\_START": This CDR is sent upon an INVITE message.
  - ◆ "MEDIA\_UPDATE": This CDR is sent upon a re-INVITE message (e.g., the established call is placed on hold by one of the call parties).
  - ◆ "MEDIA\_END": This CDR is sent upon a BYE message (i.e., call ends).


The CDR Report Types for SBC media and the SIP dialog stages at which they are sent are shown in the following figure:



- **Signaling CDR:** This CDR contains SIP signaling information. A typical SBC session consists of two SBC legs. Each leg generates its own signaling CDRs. Each leg generates three different CDR Report Types (CDRReportType), which the device sends to the CDR server at different stages of the SIP dialog:
  - ◆ "CALL\_START": This CDR is sent upon an INVITE message.
  - ◆ "CALL\_CONNECT": This CDR is sent upon an ACK message (i.e., call is established).
  - ◆ "CALL\_END": This CDR is sent upon a BYE message (i.e., call ends).

The CDR Report Types for SBC signaling and the SIP dialog stages at which they are sent are shown in the following figure:

**Figure 58-2: CDR Report Types for SBC Signaling**



You can customize the signaling CDR that is sent at the end of the SBC call ("CALL\_END") to also include media-related CDR fields. This is applicable only to syslog CDRs, local storage CDRs, and RADIUS CDRs. For customizing SBC CDRs, see [Customizing CDRs for SBC Calls and Test Calls](#) on page 1446. When there is more than one media stream in the SBC session, the added media-related fields only represent the first audio media.

CDRs belonging to the same SBC session (both incoming and outgoing legs) have the same Session ID (SessionId CDR field). CDRs belonging to the same SBC leg have the same Leg ID (LegId CDR field).

For billing applications, the CDR that the device sends at the end of the call ("CALL\_END" CDR Report Type) is usually sufficient. This CDR may be based on the following CDR fields:


- Leg ID
- Source URI
- Destination URI
- Call originator (i.e., caller)
- Call duration
- Call time

- For Gateway calls, the CDR includes both media and signaling CDR fields. The CDR can be one of the following report types (CDRReportType field), depending at which stage of the SIP dialog it was sent:

- "CALL\_START": This CDR is sent upon an INVITE message.
- "CALL\_CONNECT": This CDR is sent upon a 200 OK response (i.e., call is established).
- "CALL\_END": This CDR is sent upon a BYE message (i.e., call ends).

The CDR Report Types and the SIP dialog stages at which they are sent are shown in the following figure:

**Figure 58-3: CDR Report Types for Gateway Calls**



The syslog displays CDRs in tabular format, whereby the CDR field names (titles) are displayed on the first lines and their corresponding values on the subsequent lines. Below shows an example of an SBC signaling CDR sent at the end of a normally terminated call:

```
[S=40] |CDRReportType |EPTyp |SIPCallId |SessionId |Orig |SourceIp |SourcePort
|DestIp |DestPort |TransportType |SrcURI |SrcURIBeforeMap |DstURI
|DstURIBeforeMap |Durat |TrmSd |TrmReason |TrmReasonCategory |SetupTime
|ConnectTime |ReleaseTime |RedirectReason |RedirectURINum
|RedirectURINumBeforeMap |TxSigIPDiffServ |IPGroup (description) |SrdId (name)
|SIPInterfacId (name) |ProxySetId (name) |IpProfileId (name) |MediaRealmId
(name) |DirectMedia |SIPTrmReason |SIPTermDesc |Caller |Callee
```

```
[S=40] |CALL_END |SBC |20767593291410201017029@10.33.45.80
|1871197419|LCL |10.33.45.80 |5060 |10.33.45.72 |5060 |UDP |9001@10.8.8.10
|9001@10.8.8.10 |6001@10.33.45.80 |6001@10.33.45.80 |15 |LCL |GWAPP_
NORMAL_CALL_CLEAR |NORMAL_CALL_CLEAR |17:00:29.954 UTC Thu Oct
14 2014 |17:00:49.052 UTC Thu Oct 14 2014 |17:01:04.953 UTC Thu Oct 14 2014
|-1 ||40 |1 |0 (SRD_GW) |1 |1 |1 () |0 (MR_1) |no |BYE |Q.850 ;cause=16 ;text="loc
user 9928019 |
```

If all CDR field values are within a specific number of characters, they appear aligned under their corresponding field names. However, if some of the values exceed their specific number of characters for syslog tabular alignment, the values do not appear fully aligned with their corresponding field names. If you customize the title of a CDR field and it contains more

characters than the default title, the maximum number of characters to ensure syslog tabular alignment will be updated accordingly to fit the customized title. For example, if you customize the default CDR field title "Duration" (8 characters) to "Duration in Sec" (15 characters), the tabular alignment of field names to corresponding values will be updated to 15 as well. The maximum number of characters for syslog tabular alignment when CDR field titles are not customized are given in the table below.

**Table 58-2: CDR Field Descriptions**

Field	Description
Accounting Status Type [305]	<p>Displays the CDR Report Type in numeric representation (integer), used mainly for the RADIUS Accounting Status Type attribute (40):</p> <ul style="list-style-type: none"> <li>■ "1" = "Accounting Start" for "CALL_START" or "CALL_CONNECT"</li> <li>■ "2" = "Accounting Stop" for "CALL_END"</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable to SBC media and signaling, and Gateway CDRs (all CDR Report Types).</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Alerting Time [443]	<p>Displays the duration (in milliseconds) between ringing (SIP 180 Ringing) and call answered (SIP 200 OK) or unanswered (CANCEL).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>■ The field is applicable only to SBC signaling, and Gateway CDRs ("CALL_CONNECT" and "CALL_END" Report Types).</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
AMD Decision Probability [630]	<p>Displays the success (in percentage) that the answering type (probability) was correctly detected for the Answering Machine Detection (AMD) feature.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>■ The default field title is "%" for syslog.</li> </ul>

Field	Description
	<ul style="list-style-type: none"> <li>The maximum number of characters for syslog tabular alignment is 3.</li> </ul>
AMD Decision [629]	<p>Displays the detected answering type for the AMD feature:</p> <ul style="list-style-type: none"> <li>"V": voice</li> <li>"A": answer machine</li> <li>"S": silence</li> <li>"U": unknown</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>By default, the field is included in the CDR.</li> <li>The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>The default field title is "AMD" for syslog.</li> <li>The maximum number of characters for syslog tabular alignment is 3.</li> </ul>
AOC Amount [523]	<p>Displays the total amount charged for the call for the Advice of Charge (AOC) feature. The field is an integer from 0 to 999999.</p> <p>Data is stored per call and sent in the syslog as follows:</p> <ul style="list-style-type: none"> <li>currency-type: amount multiplier for currency charge (euro or usd)</li> <li>recorded-units: for unit charge (1-999999)</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>By default, the field is included in the CDR.</li> <li>The field is applicable only to Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>The default field title is "Amount" for syslog.</li> <li>The maximum number of characters for syslog tabular alignment is 9.</li> </ul>
AOC Currency [522]	<p>Displays the currency of the AOC (e.g., "EUR").</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The field is optional. You can include it in the CDR by CDR customization using the Gateway CDR Format table.</li> <li>The field is applicable only to Gateway CDRs ("CALL_END" CDR Report Type).</li> </ul>

Field	Description
	<ul style="list-style-type: none"> <li>The maximum number of characters for syslog tabular alignment is 3.</li> </ul>
AOC Multiplier [524]	<p>Displays the AOC multiplier information. The field is an integer from 0,001 to 1000 (in steps of 10).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>By default, the field is included in the CDR.</li> <li>The field is applicable only to Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>The default field title is "Mult" for syslog.</li> <li>The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
B-Channel [501]	<p>Displays the B-channel.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>By default, the field is included in the CDR.</li> <li>The field is applicable only to Gateway CDRs (all CDR Report Types).</li> <li>The default field title is "BChan" for syslog.</li> <li>The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Blank [308]	<p>Displays an empty string value " " and 0 for an integer value. This is typically used for RADIUS CDRs.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>The field is applicable to all CDR Report Types.</li> <li>The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Call Duration [408]	<p>Displays the duration of the call. The field is an integer.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>To configure the units of measurement (seconds - default, deciseconds, centiseconds, or milliseconds), use the [CallDurationUnits] parameter.</li> <li>By default, the field is included in the CDR.</li> </ul>



Field	Description
	<ul style="list-style-type: none"> <li>■ The field is applicable only to SBC signaling and GatewayCDRs ("CALL_END" CDR Report Type).</li> <li>■ The default field title is "Duration" for syslog and Local Storage, and none for RADIUS (ACCT_SESSION_TIME standard ID 46).</li> <li>■ The maximum number of characters for syslog tabular alignment is 8.</li> </ul>
Call End Sequence Number [442]	<p>Displays the sequence number of the call. The field is an integer. For each call-end CDR, the field is assigned the next consecutive number. For example, for the first terminated call processed by the device, the field is assigned the value "1"; for the second terminated call, the field is assigned the value "2", and so on. The field value resets to 1 upon a device restart, an HA switchover (for HA-supporting products), or when it reaches the value FFFFFFFF (hexadecimal).</p> <p>As the field is consecutive, you can use this field to check whether there are any missing CDRs.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs ("CALL_END" CDR Report Type).</li> <li>■ The maximum number of characters for syslog tabular alignment is 10.</li> </ul>
Call ID [301]	<p>Displays the unique ID of the call, which appears in the SIP Call-ID header. The field is a string of up to 130 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable to SBC media and signaling, and Gateway CDRs (all CDR Report Types).</li> <li>■ The default field title is "SIPCallId" for syslog and Local Storage, and "call-id=" for RADIUS.</li> <li>■ The maximum number of characters for syslog tabular alignment is 50.</li> </ul>
Call Orig RADIUS [434]	<p>Displays the originator of the call:</p> <ul style="list-style-type: none"> <li>■ "answer": Call originated from the IP side (Gateway) or incoming leg</li> </ul>

Field	Description
	<p>(SBC)</p> <ul style="list-style-type: none"> <li>■ "originate": Call originated from the Tel side (Gateway) or outgoing leg (SBC)</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable to CDR Report Types "Start Acc" and "Stop Acc".</li> <li>■ The field is applicable to all types, but mainly to RADIUS (SBC and GatewayCDRs).</li> <li>■ The default field title is "h323-call-origin=" for RADIUS.</li> <li>■ The maximum number of characters for syslog tabular alignment is 10.</li> </ul>
Call Orig [401]	<p>Displays which side originated the call for the specific leg.</p> <ul style="list-style-type: none"> <li>■ "LCL": SBC Outgoing leg (called party side) or Tel side</li> <li>■ "RMT": SBC Incoming leg (i.e., caller party side) or IP side</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs (all CDR Report Types).</li> <li>■ The default field title is "Orig" for syslog and "Direction" in the Web SBC CDR History table and Web Gateway CDR History table.</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Callee Display ID [432]	<p>Displays the name of the called party. The field is a string of up to 36 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs (all CDR Report Types).</li> <li>■ The default field title is "Callee" in the sent CDR.</li> <li>■ The maximum number of characters for syslog tabular alignment is 37.</li> </ul>

Field	Description
Caller Display ID [431]	<p>Displays the name of the caller (caller ID). The field is a string of up to 50 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs (all CDR Report Types).</li> <li>■ The default field title is "Caller" in the CDR.</li> <li>■ The maximum number of characters for syslog tabular alignment is 51.</li> </ul>
CDR Type [300]	<p>Displays the application type of the CDR. The field is an integer:</p> <ul style="list-style-type: none"> <li>■ "2": Gateway CDR</li> <li>■ "3": SBC signaling CDR</li> <li>■ "4": SBC media CDR</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>■ The field is applicable only to SBC media and signaling, and Gateway CDRs (all CDR Report Types).</li> <li>■ The maximum number of characters for syslog tabular alignment is 6.</li> </ul>
Channel ID [600]	<p>Displays the port (channel) ID.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_START" and "MEDIA_END" CDR Report Types) and Gateway CDRs ("CALL_START", "CALL_CONNECT" and "CALL_END" CDR Report Types).</li> <li>■ The default field title is "Cid" in the CDR.</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Coder Type [601]	<p>Displays the coder used for the call. The field is a string, for example, "g711Alaw64k", "g711Ulaw64k" and "g729".</p> <p><b>Note:</b></p>

Field	Description
	<ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_START" and "MEDIA_END" CDR Report Types) and Gateway CDRs ("CALL_CONNECT" and "CALL_END" CDR Report Types).</li> <li>■ The default field title is "Coder" in the CDR.</li> <li>■ The maximum number of characters for syslog tabular alignment is 15.</li> </ul>
Conn ID [502]	<p>Displays the Digital Connection ID.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to Gateway CDRs (all CDR Report Types).</li> <li>■ The default field title is "ConId" in the CDR.</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Connect Time [412]	<p>Displays the date and time that the call was connected. The field is a string of up to 35 characters and in the following format: &lt;hh:mm:ss:ms&gt; UTC &lt;DDD&gt; &lt;MMM&gt; &lt;DD&gt; &lt;YYYY&gt;. For example, "17:00:49.053 UTC Thu Dec 14 2017"</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ To configure the time zone string (e.g., "UTC" - default, "GMT+1" and "EST"), use the TimeZoneFormat parameter.</li> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and Gateway CDRs ("CALL_CONNECT" and "CALL_END" CDR Report Types).</li> <li>■ The default field title is "ConnectTime" for syslog and Local Storage, and "h323-connect-time=" for RADIUS.</li> <li>■ The maximum number of characters for syslog tabular alignment is 35.</li> </ul>
Dest Port [406]	<p>Displays the SIP signaling destination UDP port. The field is an integer of up to 10 digits.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and Gateway CDRs (all CDR Report Types).</li> </ul>

Field	Description
	<ul style="list-style-type: none"> <li>■ The default field title is "SigDestPort" for Gateway syslog and Local Storage, and "DestPort" for SBC syslog and Local Storage.</li> <li>■ The maximum number of characters for syslog tabular alignment is 11.</li> </ul>
Destination Host Before Manipulation [815]	<p>Displays the original destination hostname (before manipulation, if any).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table.</li> <li>■ The field is applicable only to SBC signaling CDRs (all CDR Report Types).</li> <li>■ The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Destination Host Name Before Manipulation [518]	<p>Displays the original destination hostname (before manipulation, if any).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to Gateway CDRs (all CDR Report Types).</li> <li>■ The default field title is "DstHostBeforeMap".</li> <li>■ The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Destination Host Name [519]	<p>Displays the destination hostname (after manipulation, if any).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to Gateway CDRs (all CDR Report Types).</li> <li>■ The default field title is "DstHost".</li> <li>■ The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Destination Host [813]	<p>Displays the destination hostname (after manipulation, if any).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table.</li> <li>■ The field is applicable only to SBC CDRs (all CDR Report Types).</li> </ul>

Field	Description
	<ul style="list-style-type: none"> <li>The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Destination IP [403]	<p>Displays the destination IP address. The field is a string of up to 20 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>By default, the field is included in the CDR.</li> <li>The field is applicable only to SBC signaling and GatewayCDRs (all CDR Report Types).</li> <li>The default field title is "DestIp".</li> <li>The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Destination Number Before Manipulation [510]	<p>Displays the original destination number (before manipulation, if any).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>By default, the field is included in the CDR.</li> <li>The field is applicable only to Gateway CDRs (all CDR Report Types).</li> <li>The default field title is "DstNumBeforeMap".</li> <li>The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Destination Number Plan [513]	<p>Displays the destination Numbering Plan Identification (NPI).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>By default, the field is included in the CDR.</li> <li>The field is applicable only to Gateway CDRs (all CDR Report Types).</li> <li>The default field title is "NPI".</li> <li>The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Destination Number Type [512]	<p>Displays the destination Type of Number (TON).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>By default, the field is included in the CDR.</li> <li>The field is applicable only to Gateway CDRs (all CDR Report Types).</li> <li>The default field title is "TON".</li> <li>The maximum number of characters for syslog tabular alignment is 5.</li> </ul>

Field	Description
Destination Number [511]	<p>Displays the destination phone number.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to Gateway CDRs (all CDR Report Types).</li> <li>■ The default field title is "DstPhoneNum" for syslog, "" (empty string) for RADIUS (CALLED_STATION_ID standard ID 31), and "Callee" in the Web Gateway CDR History table.</li> <li>■ The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Destination Tags [441]	<p>Displays destination tags.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs (all CDR Report Types).</li> <li>■ The maximum number of characters for syslog tabular alignment is 32.</li> </ul>
Destination URI Before Manipulation [803]	<p>Displays the original destination URI (username@host) before manipulation, if any. The field is a string of up to 150 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling CDRs (all CDR Report Types).</li> <li>■ The default field title is "DstURIBeforeMap".</li> <li>■ The maximum number of characters for syslog tabular alignment is 41.</li> </ul>
Destination URI [801]	<p>Displays the destination URI (username@host) after manipulation, if any. The field is a string of up to 150 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling CDRs (all CDR Report Types).</li> <li>■ The default field title is "DstURI".</li> </ul>

Field	Description
	<ul style="list-style-type: none"> <li>The maximum number of characters for syslog tabular alignment is 41.</li> </ul>
Destination Username Before Manipulation [811]	<p>Displays the original destination username (before manipulation, if any).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format tables.</li> <li>The field is applicable only to SBC signaling CDRs (all CDR Report Types).</li> <li>The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Destination Username [809]	<p>Displays the destination username (after manipulation, if any).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format tables.</li> <li>The field is applicable only to SBC signaling CDRs (all CDR Report Types).</li> <li>The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Direct Media [807]	<p>Displays whether the call session flowed directly between the endpoints (i.e., Direct Media). The field is a string:</p> <ul style="list-style-type: none"> <li>"yes": The call is a direct media call session.</li> <li>"no": The call traversed the device.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>By default, the field is included in the CDR.</li> <li>The field is applicable only to SBC signaling CDRs (all CDR Report Types).</li> <li>The default field title is "DirectMedia".</li> <li>The maximum number of characters for syslog tabular alignment is 11.</li> </ul>
Endpoint Type [400]	<p>Displays the endpoint type. The field is a string:</p> <ul style="list-style-type: none"> <li>"NONE"</li> <li>"ISDN"</li> </ul>



Field	Description
	<ul style="list-style-type: none"> <li>■ "CAS"</li> <li>■ "TRANSPARNT" (E1/T1 calls without D-channel / signaling)</li> <li>■ "SBC" (SBC calls)</li> <li>■ "TEST" (for Test Call calls)</li> <li>■ "3WCONF" (three-way conferencing calls)</li> <li>■ "SIPREC" (SIPREC calls)</li> <li>■ "MOH" (Music-on-Hold calls)</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and Gateway CDRs (all CDR Report Types).</li> <li>■ The default field title is "EPTyp".</li> <li>■ The maximum number of characters for syslog tabular alignment is 10.</li> </ul>
Fax On Call [505]	<p>Displays whether a fax transaction was detected during the call. The field is an integer:</p> <ul style="list-style-type: none"> <li>■ "0": No</li> <li>■ "1": Yes</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>■ The default field title is "Fax".</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Global Session ID [309]	<p>Displays the global session ID.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>■ The field is applicable to SBC signaling and media, and Gateway CDRs.</li> </ul>

Field	Description
	<ul style="list-style-type: none"> <li>■ The default field title is "h323-gw-id=" for RADIUS (A_ACCT_SESSION_TIME).</li> <li>■ The maximum number of characters for syslog tabular alignment is 16.</li> <li>■ For more information on the global session ID, see <a href="#">Enabling Same Call Session ID over Multiple Devices</a> on page 1533.</li> </ul>
H323 ID [306]	<p>Displays the device ID which can configured by the H323IDString parameter. It is typically used for RADIUS CDRs. The field is a string.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is included in the default RADIUS CDR.</li> <li>■ The field is applicable only to RADIUS SBC and GatewayCDRs (all CDR Report Types).</li> <li>■ The default field title is "h323-gw-id for RADIUS.</li> <li>■ The maximum number of characters for syslog tabular alignment is 33.</li> </ul>
IP Group ID [416]	<p>Displays the IP Group ID. The field is an integer.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs (all CDR Report Types).</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
IP Group Name [417]	<p>Displays the IP Group name. The field is a string of up to 40 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs (all CDR Report Types).</li> <li>■ The default field title is "IPG (name)" for Gateway syslog and Local Storage, "IPGroup (name)" for SBC syslog and Local Storage, and "IP Group" in the Web SBC CDR History table.</li> <li>■ The maximum number of characters for syslog tabular alignment is 32.</li> </ul>

Field	Description
IP Profile ID [425]	<p>Displays the IP Profile ID. The field is an integer.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs (all CDR Report Types).</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
IP Profile Name [426]	<p>Displays the IP Profile name. The field is a string of up to 40 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs (all CDR Report Types).</li> <li>■ The default field title is "IpProfileId (name)".</li> <li>■ The maximum number of characters for syslog tabular alignment is 32.</li> </ul>
Is Recorded [822]	<p>Displays if the SBC leg was recorded (SIPREC) or not.</p> <p>The field is a string:</p> <ul style="list-style-type: none"> <li>■ "yes"</li> <li>■ "no"</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format tables.</li> <li>■ The field is applicable only to SBC signaling CDRs ("CALL_END" CDR Report Type; other Report Types will display "no").</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
ISDN Line Type [525]	<p>Displays the ISDN line type. The field is an integer:</p> <ul style="list-style-type: none"> <li>■ "10": E1</li> <li>■ "11": T1</li> <li>■ "12": BRI</li> </ul>

Field	Description
	<ul style="list-style-type: none"> <li>■ "21": Unknown</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the Gateway CDR Format table.</li> <li>■ The field is applicable only to Gateway CDRs (all CDR Report Types).</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Latched RTP IP [631]	<p>Displays the remote IP address of the incoming RTP stream that the device "latched" onto as a result of the RTP latching mechanism for NAT traversal.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>■ The default field title is "LatchedRtpIp".</li> <li>■ The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Latched RTP Port [632]	<p>Displays the remote RTP port of the incoming RTP stream that the device "latched" onto as a result of the RTP latching mechanism for NAT traversal. The field is an integer 0 to 0xFFFF.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>■ The default field title is "LatchedRtpPort".</li> <li>■ The maximum number of characters for syslog tabular alignment is 15.</li> </ul>
Latched T38 IP [633]	<p>Displays the latching of a new T.38 stream (new IP address).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>■ The default field title is "LatchedT38Ip".</li> </ul>

Field	Description
	<ul style="list-style-type: none"> <li>The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Latched T38 Port [634]	<p>Displays the latching of a new T.38 stream (new port). The field is an integer 0 to 0xFFFF.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>By default, the field is included in the CDR.</li> <li>The field is applicable only to SBC CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>The default field title is "LatchedT38Port".</li> <li>The maximum number of characters for syslog tabular alignment is 15.</li> </ul>
Leg ID [310]	<p>Displays the unique ID of the call leg within a specific call session. The field is an integer.</p> <p>A basic SBC call consists of two legs (incoming and outgoing) and thus, two leg IDs are generated for the session, one for each leg.</p> <p>A basic Gateway call consists of only one leg ID.</p> <p>For each new call, the device assigns leg ID "1" to the first leg. The device then increments the leg ID for subsequent legs according to the leg sequence in the call session.</p> <p>For example, the device generates leg ID "1" for the SBC incoming leg and leg ID "2" for the SBC outgoing leg. If the call is transferred, the device generates leg ID "3" for the leg belonging to the call transfer target. Another example is a call forking session where the leg ID sequence may be as follows: incoming leg is "1", outgoing leg to user's office phone is "2" and outgoing leg to the user's mobile phone is "3". If the call is then transferred, the leg ID for the transfer leg is "4".</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>By default, the field is included in the CDR.</li> <li>The field is applicable only to SBC signaling and media, and Gateway CDRs ("CALL_START", "CALL_CONNECT" and "CALL_END" CDR Report Types).</li> <li>The default field title is "LegId".</li> <li>The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Local Input Octets	<p>Displays the local input octets (bytes).</p> <p><b>Note:</b></p>

Field	Description
[606]	<ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>■ The default field title is empty for RADIUS (ACCT_INPUT_OCTETS standard ID 42).</li> <li>■ The maximum number of characters for syslog tabular alignment is 10.</li> </ul>
Local Input Packets [604]	<p>Displays the number of packets received by the device. The field is an integer from 0 to 0xFFFFFFFF.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>■ The default field title is "InPackets" for syslog and Local Storage, and empty for RADIUS (ACCT_INPUT_PACKETS).</li> <li>■ The maximum number of characters for syslog tabular alignment is 10.</li> </ul>
Local Jitter [610]	<p>Displays the RTP jitter. The field is an integer from 0 to 40000 samples (-1 if unavailable).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>■ The default field title is "RTPjitter".</li> <li>■ The maximum number of characters for syslog tabular alignment is 9.</li> </ul>
Local MOS CQ [627]	<p>Displays the local MOS for conversation quality. The field is an integer from 10 to 46 (127 if information is unavailable).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> </ul>

Field	Description
	<ul style="list-style-type: none"> <li>■ The default field title is "LocalMosCQ".</li> <li>■ The maximum number of characters for syslog tabular alignment is 10.</li> </ul>
Local Output Octets [607]	<p>Displays the local output octets (bytes).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>■ The default field title is empty for RADIUS (ACCT_OUTPUT_OCTETS standard ID 43).</li> <li>■ The maximum number of characters for syslog tabular alignment is 10.</li> </ul>
Local Output Packets [605]	<p>Displays the number of packets sent by the device. The field is an integer from 0 to 0xFFFFFFFF.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>■ The default field title is "OutPackets" for syslog and Local Storage, and empty for RADIUS (ACCT_OUTPUT_PACKETS standard ID 48).</li> <li>■ The maximum number of characters for syslog tabular alignment is 10.</li> </ul>
Local Packet Loss [608]	<p>Displays the number of packets lost of the entire stream. The field is an integer from 0 to 0xFFFFFFFF (-1 if information is unavailable).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>■ The default field title is "PackLoss" for Gateway syslog and Local Storage, and "LocalPackLoss" for SBC syslog.</li> <li>■ The maximum number of characters for syslog tabular alignment is 10.</li> </ul>

Field	Description
Local R Factor [625]	<p>Displays the local R-factor conversation quality. The field is an integer from 0 to 120 (127 if information is unavailable).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>■ The default field title is "LocalRFactor".</li> <li>■ If the RTCP XR feature is unavailable (not licensed or disabled), this R-factor VoIP metric is not provided. Instead, the device sends the CDR field with the value 127, meaning that information is unavailable.</li> <li>■ The maximum number of characters for syslog tabular alignment is 12.</li> </ul>
Local Round Trip Delay [609]	<p>Displays the average round-trip delay time of the entire RTP stream. The field is an integer from 0 to 10000 ms (-1 if information is unavailable).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>■ The default field title is "RTPdelay".</li> <li>■ The maximum number of characters for syslog tabular alignment is 9.</li> </ul>
Local RTP IP [620]	<p>Displays the local RTP IP address.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_START" and "MEDIA_END" CDR Report Types) and Gateway CDRs ("CALL_CONNECT" and "CALL_END" CDR Report Types).</li> <li>■ The default field title is "LocalRtpIp".</li> <li>■ The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Local RTP Port [621]	<p>Displays the local RTP port. This field is an integer from 0 to 0xFFFF.</p> <p><b>Note:</b></p>



Field	Description
	<ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_START" and "MEDIA_END" CDR Report Types) and Gateway CDRs ("CALL_CONNECT" and "CALL_END" CDR Report Types).</li> <li>■ The default field title is "LocalRtpPort".</li> <li>■ The maximum number of characters for syslog tabular alignment is 15.</li> </ul>
Local SSRC Sender [611]	<p>Displays the local RTP synchronization source (SSRC). The field is an integer from 0 to 0xFFFFFFFF.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>■ The default field title is "RTPssrc" for Gateway syslog and Local Storage, and "TxRTPssrc" for SBC syslog.</li> <li>■ The maximum number of characters for syslog tabular alignment is 14.</li> </ul>
Media List [819]	<p>Displays all the media types (e.g., "audio", "text", "msrp", and "video") that was used for the call session. The field is a string.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table.</li> <li>■ The field is applicable only to SBC signaling CDRs ("CALL_END" CDR Report Type).</li> <li>■ The maximum number of characters for syslog tabular alignment is 40.</li> </ul>
Media Realm ID [427]	<p>Displays the Media Realm ID. The field is an integer.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>■ The field is applicable only to SBC signaling and Gateway CDRs (all CDR Report Types).</li> <li>■ The maximum number of characters for syslog tabular alignment is</li> </ul>

Field	Description
	5.
Media Realm Name [428]	<p>Displays the Media Realm name. The field is a string of up to 40 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs (all CDR Report Types).</li> <li>■ The default field title is "MediaRealmId (name)".</li> <li>■ The maximum number of characters for syslog tabular alignment is 32.</li> </ul>
Media Type [304]	<p>Displays the media type (e.g., "audio", "text", or "video").</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media and GatewayCDRs ("CALL_END" and "MEDIA_END" CDR Report Type).</li> <li>■ The default field title is "MediaType".</li> <li>■ The maximum number of characters for syslog tabular alignment is 10.</li> </ul>
Metering Pulses Generated [504]	<p>Displays the number of generated metering pulses.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to Gateway CDRs ("CALL_END" CDR Report Types).</li> <li>■ The default field title is "MeteringPulses".</li> <li>■ The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Module And Port [521]	<p>Displays the module and port used.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the Gateway CDR Format table.</li> <li>■ The field is applicable only to Gateway CDRs (all CDR Report Types).</li> <li>■ The default field title is "End Point" in the Web Gateway CDR History</li> </ul>

Field	Description
	<p>table.</p> <ul style="list-style-type: none"> <li>The maximum number of characters for syslog tabular alignment is 15.</li> </ul>
Packet Interval [602]	<p>Displays the coder packet interval. The field is an integer from 10 to 200 ms.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>By default, the field is included in the CDR.</li> <li>The field is applicable only to SBC media CDRs ("MEDIA_START", "MEDIA_UPDATE" and "MEDIA_END" CDR Report Types) and Gateway CDRs ("CALL_CONNECT" and "CALL_END" CDR Report Types).</li> <li>The default field title is "Intrv".</li> <li>The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Payload Type [603]	<p>Displays the RTP payload type. The field is an integer, for example:</p> <ul style="list-style-type: none"> <li>"0" for G.711 U-law</li> <li>"8" for G.711 A-law</li> <li>"18" for G.729</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>The field is applicable only to SBC media CDRs ("MEDIA_START", "MEDIA_UPDATE" and "MEDIA_END" CDR Report Types) and Gateway CDRs ("CALL_CONNECT" and "CALL_END" CDR Report Types).</li> <li>The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Proxy Set ID [424]	<p>Displays the Proxy Set ID.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>The field is applicable only to SBC signaling and GatewayCDRs (all</li> </ul>

Field	Description
	<p>CDR Report Types).</p> <ul style="list-style-type: none"> <li>The maximum number of characters for syslog tabular alignment is 10.</li> </ul>
Proxy Set Name [438]	<p>Displays the Proxy Set name. The field is a string of up to 40 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>By default, the field is included in the CDR.</li> <li>The field is applicable only to SBC signaling and GatewayCDRs (all CDR Report Types).</li> <li>The default field title is "ProxySetId (name)".</li> <li>The maximum number of characters for syslog tabular alignment is 32.</li> </ul>
PSTN Termination Reason [520]	<p>Displays the Q.850 protocol termination reason. The field is an integer from 0 to 127.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>By default, the field is included in the CDR.</li> <li>The field is applicable only to Gateway CDRs ("CALL_END" CDR Report Types).</li> <li>The default field title is "PstnTermReason".</li> <li>The maximum number of characters for syslog tabular alignment is 14.</li> </ul>
RADIUS Call ID [307]	<p>Displays the RADIUS call ID.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>The field is applicable only to SBC and GatewayRADIUS CDRs (all CDR Report Types).</li> <li>The default field title is "h323-conf-id=" in RADIUS CDRs.</li> <li>The maximum number of characters for syslog tabular alignment is 50.</li> </ul>
Redirect Number Before Manipulation	<p>Displays the redirect phone number before manipulation, if any.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The field is optional. You can include it in the CDR by CDR</li> </ul>

Field	Description
[514]	<p>customization using the Gateway CDR Format table.</p> <ul style="list-style-type: none"> <li>■ The field is applicable only to Gateway CDRs ("CALL_END" CDR Report Types).</li> <li>■ The default field title is "RedirectNumBeforeMap".</li> <li>■ The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Redirect Number Plan [527]	<p>Displays the redirect Numbering Plan Identification (NPI).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the Gateway CDR Format table.</li> <li>■ The field is applicable only to Gateway CDRs (all CDR Report Types).</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Redirect Number Type [526]	<p>Displays the redirect Type of Number (TON).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the Gateway CDR Format table.</li> <li>■ The field is applicable only to Gateway CDRs (all CDR Report Types).</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Redirect Number [515]	<p>Displays the original redirect number (before manipulation, if any).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to Gateway CDRs ("CALL_END" CDR Report Types).</li> <li>■ The default field title is "RedirectPhonNum".</li> <li>■ The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Redirect Reason [414]	<p>Displays the reason for the call redirection. The field is an integer of up to 15 digits:</p> <ul style="list-style-type: none"> <li>■ "-1": Not relevant</li> <li>■ "0": Unknown reason</li> </ul>

Field	Description
	<ul style="list-style-type: none"> <li>■ "1": Call forward busy (CFB)</li> <li>■ "2": Call forward no reply (CFNR)</li> <li>■ "3": Call forward network busy</li> <li>■ "4": Call deflection</li> <li>■ "5": Immediate call deflection</li> <li>■ "6": Mobile subscriber not reachable</li> <li>■ "9": DTE out of order</li> <li>■ "10": Call forwarding DTE</li> <li>■ "13": Call transfer</li> <li>■ "14": Call pickup</li> <li>■ "15": Call systematic or call forward unconditional (CFU)</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs ("CALL_END" CDR Report Types).</li> <li>■ The default field title is "RedirectReason".</li> <li>■ The maximum number of characters for syslog tabular alignment is 15.</li> </ul>
Redirect URI Before Manipulation [805]	<p>Displays the original call redirect URI (username@host) before manipulation, if any. The field is a string of up to 150 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling CDRs ("CALL_END" CDR Report Types).</li> <li>■ The default field title is "RedirectURINumBeforeMap".</li> <li>■ The maximum number of characters for syslog tabular alignment is 41.</li> </ul>
Redirect URI [804]	<p>Displays the original call redirect URI (username@host) after manipulation, if any. The field value is a string of up to 150 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> </ul>

Field	Description
	<ul style="list-style-type: none"> <li>■ The field is applicable only to SBC signaling CDRs ("CALL_END" CDR Report Types).</li> <li>■ The default field title is "RedirectURINum".</li> <li>■ The maximum number of characters for syslog tabular alignment is 41.</li> </ul>
Release Time [413]	<p>Displays the date and time the call ended (disconnected). The field is a string of up to 35 characters and presented in the following format: &lt;hh:mm:ss.ms&gt; UTC &lt;DDD&gt; &lt;MMM&gt; &lt;DD&gt; &lt;YYYY&gt;. For example, "17:00:55.002 UTC Thu Dec 14 2017".</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ To configure the time zone string (e.g., "UTC" - default, "GMT+1" and "EST"), use the TimeZoneFormat parameter.</li> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs ("CALL_END" CDR Report Types).</li> <li>■ The default field title is "ReleaseTime" for syslog, "h323-disconnect-time=" for RADIUS, and "Call End Time" in the Web SBC CDR History table and Web Gateway CDR History table.</li> <li>■ The maximum number of characters for syslog tabular alignment is 35.</li> </ul>
Remote Input Octets [614]	<p>Displays the remote input octets (bytes).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>■ The maximum number of characters for syslog tabular alignment is 10.</li> </ul>
Remote Input Packets [612]	<p>Displays the number of packets that the remote side reported it received. The field is an integer from 0 to 0xFFFFFFFF.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> </ul>

Field	Description
	<ul style="list-style-type: none"> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>■ The maximum number of characters for syslog tabular alignment is 10.</li> </ul>
Remote IP [404]	<p>Displays the remote SIP IP address.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs ("CALL_START", "CALL_CONNECT", and "CALL_END" CDR Report Types).</li> <li>■ The field is applicable to syslog, RADIUS, Local Storage, and Web History CDRs.</li> <li>■ The default CDR title is "Remote IP" in the Web SBC CDR History table and Web Gateway CDR History table.</li> <li>■ The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Remote Jitter [618]	<p>Displays the remote RTP jitter. The field is an integer from 0 to 40000 samples (-1 if unavailable).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>■ The maximum number of characters for syslog tabular alignment is 9.</li> </ul>
Remote MOS CQ [628]	<p>Displays the remote MOS for conversation quality. The field is an integer from 10 to 46 (127 if information is unavailable).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>■ The default field title is "RemoteMosCQ".</li> </ul>



Field	Description
	<ul style="list-style-type: none"> <li>The maximum number of characters for syslog tabular alignment is 11.</li> </ul>
Remote Output Octets [615]	<p>Displays the remote output octets (bytes).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>The maximum number of characters for syslog tabular alignment is 10.</li> </ul>
Remote Output Packets [613]	<p>Displays the number of packets received by the device. The field is an integer from 0 to 0xFFFFFFFF.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>The maximum number of characters for syslog tabular alignment is 10.</li> </ul>
Remote Packet Loss [616]	<p>Displays the number of packets lost of the entire remote stream. The field is an integer from 0 to 0xFFFFFFFF (-1 if information is unavailable).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>By default, the field is included in the CDR.</li> <li>The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>The default field title is "RemotePackLoss".</li> <li>The maximum number of characters for syslog tabular alignment is 14.</li> </ul>
Remote Port [407]	<p>Displays the remote SIP port. This field is an integer from 0 to 0xFFFF.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR</li> </ul>

Field	Description
	<p>Format table.</p> <ul style="list-style-type: none"> <li>■ The field is applicable only to SBC signaling and GatewayCDRs ("CALL_START", "CALL_CONNECT", and "CALL_END" CDR Report Types).</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Remote R Factor [626]	<p>Displays the remote R-factor conversation quality. The field is an integer from 0 to 120 (127 if information is unavailable).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>■ The default field title is "RemoterRFactor".</li> <li>■ If the RTCP XR feature is unavailable (not licensed or disabled), this R-factor VoIP metric is not provided. Instead, the device sends the CDR field with the value 127, meaning that information is unavailable.</li> <li>■ The maximum number of characters for syslog tabular alignment is 13.</li> </ul>
Remote Round Trip Delay [617]	<p>Displays the average round-trip delay time of the remote RTP stream. The field is an integer from 0 to 10000 ms (-1 if information is unavailable).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>■ The maximum number of characters for syslog tabular alignment is 9.</li> </ul>
Remote RTP IP [622]	<p>Displays the remote RTP IP address.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_START", "MEDIA_UPDATE" and "MEDIA_END" CDR Report Types) and Gateway CDRs ("CALL CONNECT" and "CALL_END" CDR Report</li> </ul>

Field	Description
	<p>Types).</p> <ul style="list-style-type: none"> <li>■ The default field title is "Rtplp" for syslog Signaling and Local Storage, "RemoteRtplp" for syslog Media, and "h323-remote-address=" for RADIUS.</li> <li>■ The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Remote RTP Port [623]	<p>Displays the remote RTP port. This field is an integer from 0 to 0xFFFF.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_START", "MEDIA_UPDATE" and "MEDIA_END" CDR Report Types) and Gateway CDRs ("CALL_CONNECT" and "CALL_END" CDR Report Types).</li> <li>■ The default field title is ""Port" for syslog Signaling and "RemoteRtpPort" for syslog Media.</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Remote SIP User Agent [818]	<p>Displays the remote SIP User-Agent header value.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table.</li> <li>■ The field is applicable only to SBC signaling ("CALL_START", "CALL_CONNECT" and "CALL_END" CDR Report Types).</li> <li>■ The maximum number of characters for syslog tabular alignment is 41.</li> </ul>
Remote SSRC Sender [619]	<p>Displays the remote (sender) RTP synchronization source (SSRC). The field is an integer from 0 to 0xFFFFFFFF.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Type) and Gateway CDRs ("CALL_END" CDR Report Type).</li> <li>■ The default field title is "RemoteRTPssrc" for Gateway syslog and "RxRTPssrc" for SBC syslog Media.</li> <li>■ The maximum number of characters for syslog tabular alignment is</li> </ul>

Field	Description
	14.
Report Type [303]	<p>Displays the type of CDR report. The field is a string:</p> <ul style="list-style-type: none"> <li>■ "CALL_START": The CDR is sent upon an INVITE message.</li> <li>■ "CALL_CONNECT": The CDR is sent upon a 200 OK response.</li> <li>■ "CALL_END": The CDR is sent upon a BYE message.</li> <li>■ "DIALOG_START": The CDR is sent upon the start of a non-INVITE session (only when enabled, using the EnableNonCallCdr parameter).</li> <li>■ "DIALOG_END": The CDR is sent upon the end of a non-INVITE session (only when enabled, using the EnableNonCallCdr parameter).</li> <li>■ "DIALOG_CONNECT ": The CDR is sent upon establishment of a non-INVITE session (only when enabled, using the EnableNonCallCdr parameter).</li> <li>■ "MEDIA_START": The CDR is sent upon 200 OK response or early media</li> <li>■ "MEDIA_UPDATE": The CDR is sent upon a re-INVITE message</li> <li>■ "MEDIA_END": The CDR sent is upon a BYE message</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable to SBC media and signaling, and Gateway CDRs.</li> <li>■ The default field title is "GWReportType" for Gateway syslog and Local Storage, "SBCReportType" for SBC syslog and Local Storage, and "MediaReportType" for SBC syslog Media.</li> <li>■ The maximum number of characters for syslog tabular alignment is 15.</li> </ul>
RTP IP DiffServ [624]	<p>The field displays the RTP IP DiffServ. The valid value is an integer from 0 to 63.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_START", "MEDIA_UPDATE" and "MEDIA_END" CDR Report Types) and Gateway CDRs ("CALL CONNECT" and "CALL_END" CDR Report</li> </ul>

Field	Description
	<p>Types).</p> <ul style="list-style-type: none"> <li>■ The default field title is "TxRTPIPDiffServ".</li> <li>■ The maximum number of characters for syslog tabular alignment is 15.</li> </ul>
Session ID [302]	<p>Displays the unique session ID. The field value is a string of up to 24 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable to SBC media and signaling, and Gateway CDRs (all CDR Report Types).</li> <li>■ The default field title is "SessionId".</li> <li>■ The maximum number of characters for syslog tabular alignment is 24.</li> </ul>
Setup Time [411]	<p>Displays the date and time that the call was setup. The field value is a string of up to 35 characters and presented in the following format: &lt;hh:mm:ss.ms&gt; UTC &lt;DDD&gt; &lt;MMM&gt; &lt;DD&gt; &lt;YYYY&gt;. For example, "17:00:49.052 UTC Thu Dec 14 2017"</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ To configure the time zone string (e.g., "UTC" - default, "GMT+1", and "EST"), use the TimeZoneFormat parameter.</li> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs (all CDR Report Types).</li> <li>■ The default field title is "SetupTime"" for syslog and Local Storage, and "h323-setup-time=" for RADIUS.</li> <li>■ The maximum number of characters for syslog tabular alignment is 35.</li> </ul>
Signaling IP DiffServ [422]	<p>Displays the signaling IP DiffServ. The field value is an integer of up to 15 digits.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs (all CDR Report Types).</li> <li>■ The default field title is "TxSigIPDiffServ".</li> </ul>

Field	Description
	<ul style="list-style-type: none"> <li>The maximum number of characters for syslog tabular alignment is 15.</li> </ul>
SIP Interface ID [420]	<p>Displays the SIP Interface table row index (integer).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>The field is applicable only to SBC signaling and GatewayCDRs (all CDR Report Types).</li> <li>The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
SIP Interface Name [433]	<p>Displays the SIP Interface name. The field value is a string of up to 40 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>By default, the field is included in the CDR.</li> <li>The field is applicable only to SBC signaling and GatewayCDRs (all CDR Report Types).</li> <li>The default field title is "SIPInterfaceId (name)".</li> <li>The maximum number of characters for syslog tabular alignment is 32.</li> </ul>
SIP Local Tag [445]	<p>Displays the 'tag' parameter of the SIP From / To headers that is generated by the device in the outgoing SIP message. The field value is a string of up to 100 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>The field is applicable to all CDR Report Types, but it may not be added to some Report Types in all call scenarios.</li> <li>The field is applicable only to SBC signaling and GatewayCDRs.</li> <li>The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
SIP Method [806]	<p>Displays the SIP message type (method). The field value is a string of up to 10 characters:</p>

Field	Description
	<ul style="list-style-type: none"> <li>■ "INVITE"</li> <li>■ "OPTIONS"</li> <li>■ "REGISTER"</li> <li>■ "NOTIFY"</li> <li>■ "INFO"</li> <li>■ "SUBSCRIBE"</li> <li>■ "MESSAGE"</li> <li>■ "BENOTIFY"</li> <li>■ "SERVICE"</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling CDRs (all CDR Report Types).</li> <li>■ The default field title is "SIPMethod".</li> <li>■ The maximum number of characters for syslog tabular alignment is 10.</li> </ul>
SIP Remote Tag [446]	<p>Displays the 'tag' parameter of the SIP From / To headers that is received by the device in the incoming SIP message. The field value is a string of up to 100 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>■ The field is applicable to all CDR Report Types, but it may not be added to some Report Types in all call scenarios.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs.</li> <li>■ The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
SIP Termination Description [430]	<p>Displays the description of the SIP call termination reason. The field value is a string of up to 70 characters and is set to one of the following:</p> <ul style="list-style-type: none"> <li>■ SIP Reason header, if exists, for example: SIP ;cause=200 ;text="Call completed elsewhere".</li> </ul>

Field	Description
	<ul style="list-style-type: none"> <li>■ If no SIP Reason header exists, the description is taken from the reason text, if exists, of the SIP response code, for example: "417 Unknown Resource-Priority".</li> <li>■ If no reason text exists in the SIP response code, the description is taken from an internal SIP response mapping mechanism. For example, if the device receives a SIP response "422", it sends in the CDR "422 Session Interval Too Small method" as the description.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs ("CALL_END" CDR Report Types).</li> <li>■ The default field title is "SipTermDesc".</li> <li>■ The maximum number of characters for syslog tabular alignment is 26.</li> </ul>
SIP Termination Reason [429]	<p>Displays the SIP reason for call termination. The field value is a string of up to 12 characters and is set to one of the following:</p> <ul style="list-style-type: none"> <li>■ "BYE"</li> <li>■ "CANCEL"</li> <li>■ SIP error codes (e.g., "404")</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs ("CALL_END" CDR Report Types).</li> <li>■ The default field title is "SIPTrmReason".</li> <li>■ The maximum number of characters for syslog tabular alignment is 12.</li> </ul>
Source Host Before Manipulation [814]	<p>Displays the original source hostname (before manipulation, if any).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table.</li> <li>■ The field is applicable only to SBC signaling CDRs (all CDR Report Types).</li> <li>■ The maximum number of characters for syslog tabular alignment is</li> </ul>



Field	Description
	20.
Source Host Name Before Manipulation [516]	<p>Displays the original source hostname (before manipulation, if any).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to Gateway CDRs (all CDR Report Types).</li> <li>■ The default field title is "SrcHostBeforeMap".</li> <li>■ The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Source Host Name [517]	<p>Displays the source hostname (after manipulation, if any).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to Gateway CDRs (all CDR Report Types).</li> <li>■ The default field title is "SrcHost".</li> <li>■ The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Source Host [812]	<p>Displays the source hostname (after manipulation, if any).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table.</li> <li>■ The field is applicable only to SBC signaling CDRs (all CDR Report Types).</li> <li>■ The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Source IP [402]	<p>Displays the source IP address. The field value is a string of up to 20 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs (all CDR Report Types).</li> <li>■ The default field title is "SourceIp".</li> <li>■ The maximum number of characters for syslog tabular alignment is 20.</li> </ul>

Field	Description
Source Number Before Manipulation [506]	<p>Displays the source number (before manipulation, if any).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to Gateway CDRs (all CDR Report Types).</li> <li>■ The default field title is "SrcNumBeforeMap" for syslog, and "Caller" for Web CDR History.</li> <li>■ The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Source Number Plan [509]	<p>Displays the source Numbering Plan Identification (NPI).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to Gateway CDRs (all CDR Report Types).</li> <li>■ The default field title is "NPI".</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Source Number Type [508]	<p>Displays the source Type of Number (TON).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to Gateway CDRs (all CDR Report Types).</li> <li>■ The default field title is "TON".</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Source Number [507]	<p>Displays the source number (after manipulation).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to Gateway CDRs (all CDR Report Types).</li> <li>■ The default field title is "SrcPhoneNum" for syslog and Local Storage, and "" for RADIUS (A_CALLING_STATION_ID).</li> <li>■ The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Source Port	Displays the SIP signaling source UDP port. The field value is an integer

Field	Description
[405]	<p>of up to 10 digits.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs (all CDR Report Types).</li> <li>■ The default field title is "SigSourcePort" for Gateway syslog, and "SourcePort" for SBC syslog and Local Storage.</li> <li>■ The maximum number of characters for syslog tabular alignment is 13.</li> </ul>
Source Tags [440]	<p>Displays source tags.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs (all CDR Report Types).</li> <li>■ The maximum number of characters for syslog tabular alignment is 32.</li> </ul>
Source URI Before Manipulation [802]	<p>Displays the source URI (username@host) before manipulation. The field value is a string of up to 150 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling CDRs (all CDR Report Types).</li> <li>■ The default field title is "SrcURIBeforeMap".</li> <li>■ The maximum number of characters for syslog tabular alignment is 41.</li> </ul>
Source URI [800]	<p>Displays the source URI (username@host). The field value is a string of up to 150 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling CDRs (all CDR Report Types).</li> <li>■ The default field title is "SrcURI".</li> </ul>

Field	Description
	<ul style="list-style-type: none"> <li>The maximum number of characters for syslog tabular alignment is 41.</li> </ul>
Source Username Before Manipulation [810]	<p>Displays the original source username (before manipulation, if any).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format tables.</li> <li>The field is applicable only to SBC signaling CDRs (all CDR Report Types).</li> <li>The default field title is "Caller" in the Web SBC CDR History table.</li> <li>The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
Source Username [808]	<p>Displays the source username (after manipulation, if any).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format tables.</li> <li>The field is applicable only to SBC signaling CDRs (all CDR Report Types).</li> <li>The maximum number of characters for syslog tabular alignment is 20.</li> </ul>
SRD ID [418]	<p>Displays the SRD table row index.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>The field is applicable only to SBC signaling and GatewayCDRs (all CDR Report Types).</li> <li>The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
SRD Name [419]	<p>Displays the SRD name. The field value is a string of up to 40 characters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>The field is applicable only to SBC signaling and GatewayCDRs (all</li> </ul>

Field	Description
	<p>CDR Report Types).</p> <ul style="list-style-type: none"> <li>■ The default field title is "SrdId (name)".</li> <li>■ The maximum number of characters for syslog tabular alignment is 32.</li> </ul>
Call Success [447]	<p>Displays whether the call succeeded ("yes") or failed ("no").</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs ("CALL_END" CDR Report Types).</li> </ul>
Termination Reason Category [423]	<p>Displays the category of the call termination reason. The field value is up to 17 characters and is set to one of the following:</p> <p><b>Calls with duration 0 (i.e., not connected):</b></p> <ul style="list-style-type: none"> <li>■ "NO_ANSWER": <ul style="list-style-type: none"> <li>✓ "GWAPP_NORMAL_CALL_CLEAR"</li> <li>✓ "GWAPP_NO_USER_RESPONDING"</li> <li>✓ "GWAPP_NO_ANSWER_FROM_USER_ALERTED"</li> </ul> </li> <li>■ "BUSY": <ul style="list-style-type: none"> <li>✓ "GWAPP_USER_BUSY"</li> </ul> </li> <li>■ "NO_RESOURCES": <ul style="list-style-type: none"> <li>✓ "GWAPP_RESOURCE_UNAVAILABLE_UNSPECIFIED"</li> <li>✓ "RELEASE_BECAUSE_NO_CONFERENCE_RESOURCES_LEFT"</li> <li>✓ "RESOURCE_BECAUSE_NO_TRANSCODING_RESOURCES_LEFT"</li> <li>✓ "RELEASE_BECAUSE_GW_LOCKED"</li> </ul> </li> <li>■ "NO_MATCH": <ul style="list-style-type: none"> <li>✓ "RELEASE_BECAUSE_UNMATCHED_CAPABILITIES"</li> </ul> </li> <li>■ "FORWARDED": <ul style="list-style-type: none"> <li>✓ "RELEASE_BECAUSE_FORWARD"</li> </ul> </li> <li>■ "GENERAL_FAILED": Any other reason</li> </ul> <p><b>Calls with duration:</b></p>

Field	Description
	<ul style="list-style-type: none"> <li>■ "NORMAL_CALL_CLEAR": <ul style="list-style-type: none"> <li>✓ "GWAPP_NORMAL_CALL_CLEAR"</li> </ul> </li> <li>■ "ABNORMALLY_TERMINATED": Anything else</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs ("CALL_END" CDR Report Types).</li> <li>■ The default field title is "TrmReasonCategory" for syslog and Local Storage, and "Termination Reason" for Web CDR History.</li> <li>■ The maximum number of characters for syslog tabular alignment is 17.</li> </ul>
Termination Reason Value [437]	<p>Displays the Q.850 reason codes (1-127) for call termination. For example, "16" for Normal Termination.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR for RADIUS CDRs.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs ("CALL_END" CDR Report Types).</li> <li>■ The default field title is "h323-disconnect-cause=" (e.g., "h323-disconnect-cause=16").</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Termination Reason [410]	<p>Displays the reason for the call termination. The field value is a string of up to 40 characters and is set to one of the following:</p> <ul style="list-style-type: none"> <li>■ Standard Call Termination Reasons: <ul style="list-style-type: none"> <li>✓ "GWAPP_REASON_NOT_RELEVANT" (0)</li> <li>✓ "GWAPP_ALL_RELEASE_REASONS" (0)</li> <li>✓ "GWAPP_UNASSIGNED_NUMBER" (1)</li> <li>✓ "GWAPP_NO_ROUTE_TO_TRANSIT_NET" (3)</li> <li>✓ "GWAPP_NO_ROUTE_TO_DESTINATION" (3)</li> <li>✓ "GWAPP_SEND_SPECIAL_INFORMATION_TONE" (4)</li> <li>✓ "GWAPP_MISDIALED_TRUNK_PREFIX" (5)</li> <li>✓ "GWAPP_CHANNEL_UNACCEPTABLE" (6)</li> </ul> </li> </ul>

Field	Description
	✓ "GWAPP_CALL_AWARDED_AND" (7)
	✓ "GWAPP_PREEMPTION" (8)
	✓ "GWAPP_PREEMPTION_CIRCUIT_RESERVED_FOR_REUSE" (9)
	✓ "GWAPP_NORMAL_CALL_CLEAR" (16)
	✓ "GWAPP_USER_BUSY" (17)
	✓ "GWAPP_NO_USER_RESPONDING" (18)
	✓ "GWAPP_NO_ANSWER_FROM_USER_ALERTED" (19)
	✓ "MFCR2_ACCEPT_CALL" (20)
	✓ "GWAPP_CALL_REJECTED" (21)
	✓ "GWAPP_NUMBER_CHANGED" (22)
	✓ "GWAPP_REDIRECTION" (23)
	✓ "GWAPP_EXCHANGE_ROUTING_ERROR" (25)
	✓ "GWAPP_NON_SELECTED_USER_CLEARING" (26)
	✓ "GWAPP_INVALID_NUMBER_FORMAT" (28)
	✓ "GWAPP_FACILITY_REJECT" (29)
	✓ "GWAPP_RESPONSE_TO_STATUS_ENQUIRY" (30)
	✓ "GWAPP_NORMAL_UNSPECIFIED" (31)
	✓ "GWAPP_CIRCUIT_CONGESTION" (32)
	✓ "GWAPP_USER_CONGESTION" (33)
	✓ "GWAPP_NO_CIRCUIT_AVAILABLE" (34)
	✓ "GWAPP_NETWORK_OUT_OF_ORDER" (38)
	✓ "GWAPP_PERM_FR_MODE_CONN_OUT_OF_S" (39)
	✓ "GWAPP_PERM_FR_MODE_CONN_OPERATIONAL" (40)
	✓ "GWAPP_NETWORK_TEMPORARY_FAILURE" (41)
	✓ "GWAPP_NETWORK_CONGESTION" (42)
	✓ "GWAPP_ACCESS_INFORMATION_DISCARDED" (43)
	✓ "GWAPP_REQUESTED_CIRCUIT_NOT_AVAILABLE" (44)
	✓ "GWAPP_PRECEDENCE_CALL_BLOCKED" (46)
	✓ "GWAPP_RESOURCE_UNAVAILABLE_UNSPECIFIED" (47)
	✓ "GWAPP_QUALITY_OF_SERVICE_UNAVAILABLE" (49)

Field	Description
	<ul style="list-style-type: none"> <li>✓ "GWAPP_REQUESTED_FAC_NOT_SUBSCRIBED" (50)</li> <li>✓ "GWAPP_BC_NOT_AUTHORIZED" (57)</li> <li>✓ "GWAPP_BC_NOT_PRESENTLY_AVAILABLE" (58)</li> <li>✓ "GWAPP_SERVICE_NOT_AVAILABLE" (63)</li> <li>✓ "GWAPP_CUG_OUT_CALLS_BARRED" (53)</li> <li>✓ "GWAPP_CUG_INC_CALLS_BARRED" (55)</li> <li>✓ "GWAPP_ACCES_INFO_SUBS_CLASS_INCONS" (62)</li> <li>✓ "GWAPP_BC_NOT_IMPLEMENTED" (65)</li> <li>✓ "GWAPP_CHANNEL_TYPE_NOT_IMPLEMENTED" (66)</li> <li>✓ "GWAPP_REQUESTED_FAC_NOT_IMPLEMENTED" (69)</li> <li>✓ "GWAPP_ONLY_RESTRICTED_INFO_BEARER" (70)</li> <li>✓ "GWAPP_SERVICE_NOT_IMPLEMENTED_UNSPECIFIED" (79)</li> <li>✓ "GWAPP_INVALID_CALL_REF" (81)</li> <li>✓ "GWAPP_IDENTIFIED_CHANNEL_NOT_EXIST" (82)</li> <li>✓ "GWAPP_SUSPENDED_CALL_BUT_CALL_ID_NOT_EXIST" (83)</li> <li>✓ "GWAPP_CALL_ID_IN_USE" (84)</li> <li>✓ "GWAPP_NO_CALL_SUSPENDED" (85)</li> <li>✓ "GWAPP_CALL_HAVING_CALL_ID_CLEARED" (86)</li> <li>✓ "GWAPP_INCOMPATIBLE_DESTINATION" (88)</li> <li>✓ "GWAPP_INVALID_TRANSIT_NETWORK_SELECTION" (91)</li> <li>✓ "GWAPP_INVALID_MESSAGE_UNSPECIFIED" (95)</li> <li>✓ "GWAPP_NOT_CUG_MEMBER" (87)</li> <li>✓ "GWAPP_CUG_NON_EXISTENT" (90)</li> <li>✓ "GWAPP_MANDATORY_IE_MISSING" (96)</li> <li>✓ "GWAPP_MESSAGE_TYPE_NON_EXISTENT" (97)</li> <li>✓ "GWAPP_MESSAGE_STATE_INCONSISTENCY" (98)</li> <li>✓ "GWAPP_NON_EXISTENT_IE" (99)</li> <li>✓ "GWAPP_INVALID_IE_CONTENT" (100)</li> <li>✓ "GWAPP_MESSAGE_NOT_COMPATIBLE" (101)</li> <li>✓ "GWAPP_RECOVERY_ON_TIMER_EXPIRY" (102)</li> </ul>



Field	Description
	<ul style="list-style-type: none"> <li>✓ "GWAPP_PARAMETER_NON_EXISTENT" (103)</li> <li>✓ "GWAPP_MESSAGE_WITH_UNRECOGNIZED_PARAM" (110)</li> <li>✓ "GWAPP_PROTOCOL_ERROR_UNSPECIFIED" (111)</li> <li>✓ "GWAPP_UNKNOWN_ERROR" (112)</li> <li>✓ "GWAPP_INTERWORKING_UNSPECIFIED" (127)</li> <li>■ AudioCodes Proprietary: <ul style="list-style-type: none"> <li>✓ "RELEASE_BECAUSE_UNKNOWN_REASON" (304)</li> <li>✓ "RELEASE_BECAUSE_TRUNK_DISCONNECTED" (305)</li> <li>✓ "RELEASE_BECAUSE_REMOTE_CANCEL_CALL" (306)</li> <li>✓ "RELEASE_BECAUSE_UNMATCHED_CAPABILITIES" (307)</li> <li>✓ "RELEASE_BECAUSE_UNMATCHED_CREDENTIALS" (308)</li> <li>✓ "RELEASE_BECAUSE_UNABLE_TO_HANDLE_REMOTE_REQUEST" (309)</li> <li>✓ "RELEASE_BECAUSE_NO_CONFERENCERESOURCES_LEFT" (310)</li> <li>✓ "RELEASE_BECAUSE_CONFERENCERESOURCES_FULL" (311)</li> <li>✓ "RELEASE_BECAUSE_MANUAL_DISC" (315)</li> <li>✓ "RELEASE_BECAUSE_SILENCE_DISC" (316)</li> <li>✓ "RELEASE_BECAUSE_NORTEL_XFER_SUCCESS" (317)</li> <li>✓ "RELEASE_BECAUSE_RTP_CONN_BROKEN" (318)</li> <li>✓ "RELEASE_BECAUSE_DISCONNECT_CODE" (319)</li> <li>✓ "RELEASE_BECAUSE_GW_LOCKED" (320)</li> <li>✓ "RELEASE_BECAUSE_FAIL" (321)</li> <li>✓ "RELEASE_BECAUSE_FORWARD" (322)</li> <li>✓ "RELEASE_BECAUSE_ANONYMOUS_SOURCE" (323)</li> <li>✓ "PREEMPTION_ANALOG_CIRCUIT_RESERVED_FOR_REUSE" (324)</li> <li>✓ "RELEASE_BECAUSE_PRECEDENCE_CALL_BLOCKED" (325)</li> <li>✓ "RELEASE_BECAUSE_HELD_TIMEOUT" (326)</li> <li>✓ "RELEASE_BECAUSE_MEDIA_MISMATCH" (327)</li> <li>✓ "RELEASE_BECAUSE_MAX_DURATION_TIMER_EXPIRED" (328)</li> </ul> </li> </ul>

Field	Description
	✓ "RELEASE_BECAUSE_TRANSCODING_FULL" (329)
	✓ "RELEASE_BECAUSE_NO_TRANSCODING_RESOURCES_LEFT" (330)
	✓ "RELEASE_POSTPONE_POSSIBLE" (331)
	✓ "RELEASE_BECAUSE_PREEMPTION_DUE_TO_HIGH_PRIORITY" (332)
	✓ "RELEASE_BECAUSE_PREEMPTION_FAILED" (333)
	✓ "RELEASE_BECAUSE_LACK_OF_MEDIA_RESOURCES" (334)
	✓ "RELEASE_BECAUSE_IP_PROFILE_CALL_LIMIT" (805)
	✓ "RELEASE_BECAUSE_OUT_MEDIA_LIMITS_EXCEEDED" (806)
	✓ "RELEASE_BECAUSE_CALL_TRANSFERRED" (807)
	✓ "RELEASE_BECAUSE_CLASSIFICATION_FAILED" (808)
	✓ "RELEASE_BECAUSE_AUTHENTICATION_FAILED" (809)
	✓ "RELEASE_BECAUSE_ARM_DROP" (811)
	✓ "RELEASE_BECAUSE_MEDIA_DEST_UNREACHABLE" (812)
	✓ "RELEASE_BECAUSE_START_ARM_ROUTING" (813)
	✓ "RELEASE_BECAUSE_FORWARD_SUPPLEMENTARY" (814)
	✓ "RELEASE_BECAUSE_FAX_REROUTING" (815)
	✓ "RELEASE_BECAUSE_LDAP_FAILURE" (816)
	✓ "RELEASE_BECAUSE_CALLSETUPRULES_FAILURE" (817)
	✓ "RELEASE_BECAUSE_NO_USER_FOUND" (818)
	✓ "RELEASE_BECAUSE_IN_ADMISSION_FAILED" (819)
	✓ "RELEASE_BECAUSE_OUT_ADMISSION_FAILED" (820)
	✓ "RELEASE_BECAUSE_IN_MEDIA_LIMITS_EXCEEDED" (821)
	✓ "RELEASE_BECAUSE_USER_BLOCKED" (822)
	✓ "RELEASE_BECAUSE_BAD_INFO_PACKAGE" (823)
	✓ "RELEASE_BECAUSE_SRC_IP_IS_NOT_DEDICATED_REGISTRAR" (824)
	✓ "RELEASE_BECAUSE_ACD_THRESHOLD_CROSSED" (850)
	✓ "RELEASE_BECAUSE_ASR_THRESHOLD_CROSSED" (851)
	✓ "RELEASE_BECAUSE_NER_THRESHOLD_CROSSED" (852)

Field	Description
	<ul style="list-style-type: none"> <li>✓ "RELEASE_BECAUSE_IPGROUP_REGISTRATION_MODE" (853)</li> <li>✓ "RELEASE_BECAUSE_FEATUREKEY_CHANGED" (854)</li> <li>✓ "RELEASE_BECAUSE_INTERNAL_ROUTE" (855)</li> <li>✓ "RELEASE_BECAUSE_CID_CMD_FAILURE" (856)</li> <li>✓ "RELEASE_BECAUSE_OTHER_FORKED_CALL_ANSWERED" (857)</li> <li>✓ "RELEASE_BECAUSE_MEDIA_SYNC_FAILED" (858)</li> <li>✓ "RELEASE_BECAUSE_REG_MAX_THRESHOLD_CROSSED" (859)</li> <li>✓ "RELEASE_BECAUSE_PUSH_NOTIFICATION_FAILED" (860)</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs ("CALL_END" CDR Report Types).</li> <li>■ The default field title is "TrmReason".</li> <li>■ The maximum number of characters for syslog tabular alignment is 40.</li> </ul>
Termination Side RADIUS [435]	<p>Displays the party that terminated the call. The field value is a string:</p> <ul style="list-style-type: none"> <li>■ "originate": SBC incoming leg or IP side for Gateway calls</li> <li>■ "answer": SBC outgoing leg or Tel side for Gateway calls</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is mainly relevant to RADIUS CDRs, but can also be used in syslog and Local Storage.</li> <li>■ The default field title is "terminator=".</li> <li>■ The maximum number of characters for syslog tabular alignment is 10.</li> </ul>
Termination Side Yes No [436]	<p>Displays the party that terminated the call. The field value is a string:</p> <ul style="list-style-type: none"> <li>■ "yes": SBC outgoing leg or Tel side for Gateway calls</li> <li>■ "no": SBC incoming leg or IP side for Gateway calls</li> </ul> <p>The field is applicable to RADIUS CDRs</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> </ul>

Field	Description
	<ul style="list-style-type: none"> <li>■ The field is mainly relevant to RADIUS CDRs, but can also be used in syslog and Local Storage.</li> <li>■ The default field title is "terminator=" (e.g., "terminator=yes").</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Termination Side [409]	<p>Displays the party that terminated the call. The field value is a string:</p> <ul style="list-style-type: none"> <li>■ "LCL": SBC Outgoing leg or Tel side.</li> <li>■ "RMT": SBC Incoming leg or IP side.</li> <li>■ "UNKN": Unknown</li> </ul> <p>For example, if the Orig field is "RMT" and this Termination Side field is "LCL", then the called party ended the call.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs ("CALL_END" CDR Report Types).</li> <li>■ The default field title is "TrmSd".</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Transport Type [421]	<p>Displays the SIP signaling transport type protocol. The field value is a string:</p> <ul style="list-style-type: none"> <li>■ "UDP"</li> <li>■ "TCP"</li> <li>■ "TLS"</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs (all CDR Report Types).</li> <li>■ The default field title is "SigTransportType" for Gateway syslog and Local Storage, and "TransportType" for SBC syslog and Local Storage.</li> <li>■ The maximum number of characters for syslog tabular alignment is 16.</li> </ul>

Field	Description
Trigger [439]	<p>Displays the reason for the call (i.e., what triggered it):</p> <ul style="list-style-type: none"> <li>■ "Normal": regular call</li> <li>■ "Refer": call transfer</li> <li>■ "AltRoute": alternative routing</li> <li>■ "Forward": call forward</li> <li>■ "Reroute": When a broken connection on the outgoing leg occurs, the call is rerouted to another destination according to the IP-to-IP Routing table (where matching characteristics includes the trigger for reroute).</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs (all CDR Report Types).</li> <li>■ The default field title is "Trigger".</li> <li>■ The maximum number of characters for syslog tabular alignment is 8.</li> </ul>
Trunk Group ID [503]	<p>Displays the Trunk Group ID (integer).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to Gateway CDRs (all CDR Report Types).</li> <li>■ The default field title is "TG".</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Trunk ID [500]	<p>Displays the physical trunk number (integer).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to Gateway CDRs (all CDR Report Types).</li> <li>■ The default field title is "Trunk".</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Var Call User Defined 1-5	<p>Displays the SIP header data obtained from using call variables (Var.Call.Src/Dst.UserDefined1-5) in Message Manipulation rules.</p>

Field	Description
[448-452]	<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>■ The field is applicable only to SBC signaling and Gateway CDRs (all CDR Report Types).</li> <li>■ The field is applicable only to syslog, RADIUS, Local Storage, and JSON.</li> <li>■ For each variable-based field, the maximum number of characters for syslog tabular alignment is 20.</li> <li>■ The maximum characters for all five variable-based CDR fields combined is 200. For example, if the summation of Var Call User Defined 1 and Var Call User Defined 2 is 1,024 characters, no characters are displayed for the other variables.</li> </ul>
Was Call Started [415]	<p>Displays if the call was started or not (i.e., if a "CALL_START" CDR Report was generated).</p> <ul style="list-style-type: none"> <li>■ "0": No INVITE was sent to the IP side for the Tel-to-IP call, or no Setup message was sent to the Tel side for the IP-to-Tel call. Note that the first "CALL_START" CDR report type of a new signaling leg has value "0".</li> <li>■ "1": The call was started – an INVITE was sent to the IP side for the Tel-to-IP call, or a Setup message was sent to the Tel side for the IP-to-Tel call.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table and Gateway CDR Format table.</li> <li>■ The field is applicable only to SBC signaling and GatewayCDRs ("CALL_END" CDR Report Types).</li> <li>■ The field is applicable only to syslog, RADIUS, and Local Storage.</li> <li>■ The maximum number of characters for syslog tabular alignment is 5.</li> </ul>
Coder Transcoding [635]	<p>Displays whether there was coder transcoding for the SBC call. The field is a string:</p> <ul style="list-style-type: none"> <li>■ "TRANSCODING"</li> </ul>

Field	Description
	<ul style="list-style-type: none"> <li>■ "NO_TRANSCODING"</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table.</li> <li>■ The field is applicable only to SBC media CDRs ("MEDIA_END" CDR Report Types).</li> <li>■ The field is applicable only to syslog and RADIUS.</li> <li>■ The maximum number of characters for syslog tabular alignment is 17.</li> </ul>
Voice AI Connector ID [820]	<p>Displays the ID of the VoiceAI Connect when the device is used as a VoiceAI Connect Gateway.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table.</li> <li>■ The field is applicable only to SBC signaling (all CDR Report Types).</li> <li>■ The default field title is "VoiceAIConnectorName".</li> <li>■ For more information on the VoiceAI Connect, click <a href="#">here</a>.</li> </ul>
Voice AI Connector Name [821]	<p>Displays the name of the VoiceAI Connect when the device is used as a VoiceAI Connect Gateway.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ By default, the field is included in the CDR.</li> <li>■ The field is applicable only to SBC signaling (all CDR Report Types).</li> <li>■ The default field title is "VoiceAIConnectorName".</li> <li>■ For more information on the VoiceAI Connect, click <a href="#">here</a>.</li> </ul>
Tenant ID [823]	<p>Displays the Tenant ID, which is typically used by OVOC. The value is obtained from the SIP message (header data) using Message Manipulation rules with the call variable <i>Var.Call.Src/Dst.TenantId</i>.</p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table.</li> <li>■ The field is applicable only to SBC signaling ("CALL_CONNECT" and "CALL_END" CDR Report Types).</li> <li>■ The maximum number of characters for syslog tabular alignment is 71.</li> </ul>

Field	Description
Released From IP [824]	<p>Displays if the call was terminated by the device (i.e., internal reason, for example, register user not found), or by the callee or called party. The field is a string:</p> <ul style="list-style-type: none"> <li>■ "Yes" = Call was terminated by the callee or called party.</li> <li>■ "No" = Call was terminated by the device.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The field is optional. You can include it in the CDR by CDR customization using the SBC CDR Format table.</li> <li>■ The field is applicable only to SBC signaling CDRs ("CALL_END" CDR Report Type).</li> </ul>

## Customizing CDRs for Gateway Calls

The Gateway CDR Format table lets you configure CDR customization rules for Gateway-related CDRs that are generated by the device for the following:

- CDRs (media and SIP signaling) sent in syslog messages. For CDRs sent in syslog messages, you can customize the name of CDR fields. You can configure up to 128 Syslog CDR customization rules.
- CDRs related to RADIUS accounting and sent in RADIUS accounting request messages. For RADIUS accounting CDRs, you can customize the RADIUS Attribute's prefix name and ID, for standard RADIUS Attributes and vendor-specific RADIUS Attributes (VSA). For example, instead of the default VSA name, "h323-connect-time" with RADIUS Attribute ID 28, you can change the name to "Call-Connect-Time" with ID 29. You can configure up to 40 RADIUS-accounting CDR customization rules. For more information on RADIUS accounting, see [Configuring RADIUS Accounting](#) on page 1456.
- CDRs stored locally on the device. For local storage of CDRs, you can customize the name of CDR fields. You can configure up to 64 locally-stored CDR customization rules. For more information on local storage of CDRs, see [Storing CDRs Locally on the Device](#) on page 1384.
- CDRs (signaling only) sent to the REST server in JSON format using the device's REST API. You can configure up to 64 JSON CDR customization rules. For more information on CDRs and REST, see [Configuring CDR Reporting to REST Server](#) on page 1383.

Customizing the CDR means the following:

- Defining which CDR fields are included in the CDR. For example, if you configure only one customization rule for the Syslog CDR type with the Call Duration CDR field, the device generates these CDR types with only this single CDR field.

You can also customize the CDR to include the User-Defined CDR fields whose value is obtained from SIP messages (e.g., a specific header), using Message Manipulation rules with call variables. The call variables store the value and then the device adds the stored



value to these special CDR fields when the CDR is generated. You can configure up to five User-Defined CDR fields, titled "Var Call User Defined <1-5>", which you can optionally include in the CDR.

To obtain the values from the SIP message for these CDR fields, use the following call variable syntax in your Message Manipulation rules:

```
Var.Call.Dst.UserDefined<1-5>
```

To apply the Message Manipulation rule (set) to the incoming or outgoing SIP message, using the [GWInboundManipulationSet] or [GWOutboundManipulationSet] parameter, respectively.

For a configuration example, see [CDR Customization using Call Variables Example](#) on page 1453.

- Changing the default name (`title`) of the CDR field. For example, you can change the title of the Call Duration CDR field to "Call Length".
- (RADIUS Only) Changing the RADIUS Attribute's prefix name and ID, for standard RADIUS Attributes and vendor-specific RADIUS Attributes (VSA).



- If you don't customize the CDR for a specific CDR type, the device generates the CDR in a default format (fields and titles). For a detailed description of the fields that can be included in the CDR (customized and default), see [CDR Field Description](#) on page 1387.
- To return to the default CDR format for a specific CDR type, remove all your customization rules of that CDR type.



- To view Gateway CDRs in the Web interface, see [Viewing Gateway CDR History](#) on page 1361.
- The following standard RADIUS Attributes cannot be customized: 1 through 6, 18 through 20, 22, 23, 27 through 29, 32, 34 through 39, 41, 44, 52, 53, 55, 60 through 85, 88, 90, and 91.
- If the RTCP XR feature is unavailable (not licensed or disabled), the R-factor VoIP metrics are not provided in CDRs (CDR fields, Local R Factor and Remote R Factor) generated by the device. Instead, these CDR fields are sent with the value 127, meaning that information is unavailable.
- To customize CDRs for Test Calls, use the SBC CDR Format table (see [Customizing CDRs for SBC Calls and Test Calls](#) on page 1446).

The following procedure describes how to customize Gateway CDRs through the Web interface. You can also configure it through ini file [GWCDRFormat] or CLI (`configure troubleshoot > cdr > cdr-format gw-cdr-format`).

#### ➤ To customize Gateway CDRs:

1. Open the Gateway CDR Format table (**Troubleshoot** menu > **Troubleshoot** tab > **Call Detail Record** folder > **Gateway CDR Format**).

2. Click **New**; the following dialog box appears:

3. Configure CDR format rules according to the parameters described in the table below.

4. Click **Apply**.

An example of CDR customization rules configured in the table is shown below:

INDEX ↕	CDR TYPE	FIELD TYPE	TITLE	RADIUS ATTRIBUTE TYPE	RADIUS ATTRIBUTE ID
0	Syslog Gateway	Call Orig	Caller	Standard	0
1	Syslog Gateway	Destination IP	"Destination IP Address"	Vendor Specific	0
2	Syslog Gateway	Setup Time	setup-time=	Standard	0
3	Local Storage Gateway	Call Duration	call-duration=	Standard	0

- Index 0: The default CDR field "Call Orig" for syslog is changed to "Caller".
- Index 1: The default CDR field "Destination IP" for syslog is changed to "Destination IP Address" (enclosed by quotation marks).
- Index 2: The default CDR field "Setup Time" for syslog is changed to "setup-time=".
- Index 3: The default CDR field "Call Duration" for local CDR storage is changed to "call-duration=".

**Table 58-3: Gateway CDR Format Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'CDR Type' cdr-type [CDRType]	Defines the application type for which you want to customize CDRs.  ■ [0] <b>Syslog Gateway</b> = (Default) Customizes CDR field names for CDRs (media and signaling) sent in syslog

Parameter	Description
	<p>messages.</p> <ul style="list-style-type: none"> <li>■ [6] <b>RADIUS Gateway</b> = Customizes CDR field names (RADIUS Attribute prefix names) for CDRs (media and signaling) sent in RADIUS accounting requests.</li> <li>■ [9] <b>Local Storage Gateway</b> = Customizes CDR fields (media and signaling) that are stored locally on the device.</li> <li>■ [10] <b>JSON Gateway</b> = Customizes CDR field names for CDRs (signaling only) that are sent in JSON format to the REST server using the device's REST API.</li> </ul>
<p>'Field Type' col-type [FieldType]</p>	<p>Defines the CDR field (column) that you want to customize.</p> <p>[300] <b>CDR Type</b> (default); [301] <b>Call ID</b>; [302] <b>Session ID</b>; [303] <b>Report Type</b>; [304] <b>Media Type</b>; [305] <b>Accounting Status Type</b>; [306] <b>H323 ID</b>; [307] <b>RADIUS Call ID</b>; [308] <b>Blank</b>; [309] <b>Global Session ID</b>; [310] <b>Leg ID</b>; [400] <b>Endpoint Type</b>; [401] <b>Call Orig</b>; [402] <b>Source IP</b>; [403] <b>Destination IP</b>; [404] <b>Remote IP</b>; [405] <b>Source Port</b>; [406] <b>Dest Port</b>; [407] <b>Remote Port</b>; [408] <b>Call Duration</b>; [409] <b>Termination Side</b>; [410] <b>Termination Reason</b>; [411] <b>Setup Time</b>; [412] <b>Connect Time</b>; [413] <b>Release Time</b>; [414] <b>Redirect Reason</b>; [415] <b>Was Call Started</b>; [416] <b>IP Group ID</b>; [417] <b>IP Group Name</b>; [418] <b>SRD ID</b>; [419] <b>SRD Name</b>; [420] <b>SIP Interface ID</b>; [421] <b>Transport Type</b>; [422] <b>Signaling IP DiffServ</b>; [423] <b>Termination Reason Category</b>; [424] <b>Proxy Set ID</b>; [425] <b>IP Profile ID</b>; [426] <b>IP Profile Name</b>; [427] <b>Media Realm ID</b>; [428] <b>Media Realm Name</b>; [429] <b>SIP Termination Reason</b>; [430] <b>SIP Termination Description</b>; [431] <b>Caller Display ID</b>; [432] <b>Callee Display ID</b>; [433] <b>SIP Interface Name</b>; [434] <b>Call Orig RADIUS</b>; [435] <b>Termination Side RADIUS</b>; [436] <b>Termination Side Yes No</b>; [437] <b>Termination Reason Value</b>; [438] <b>Proxy Set Name</b>; [439] <b>Trigger</b>; [442] <b>Call End Sequence Number</b>; [443] <b>Alerting Time</b>; [445] <b>SIP Local Tag</b>; [446] <b>SIP Remote Tag</b>; [447] <b>Call Success</b>; [448] <b>Var Call User Defined 1</b>; [449] <b>Var Call User Defined 2</b>; [450] <b>Var Call User Defined 3</b>; [451] <b>Var Call User Defined 4</b>; [452] <b>Var Call User Defined 5</b>; [500] <b>Trunk ID</b>; [501] <b>B-Channel</b>; [502] <b>Conn ID</b>; [503] <b>Trunk Group ID</b>; [504] <b>Metering Pulses Generated</b>; [505] <b>Fax On Call</b>; [506] <b>Source Number Before Manipulation</b>; [507] <b>Source</b></p>

Parameter	Description
	<p><b>Number; [508] Source Number Type; [509] Source Number Plan; [510] Destination Number Before Manipulation; [511] Destination Number; [512] Destination Number Type; [513] Destination Number Plan; [514] Redirect Number Before Manipulation; [515] Redirect Number; [526] Redirect Number Type; [527] Redirect Number Plan; [516] Source Host Name Before Manipulation; [517] Source Host Name; [518] Destination Host Name Before Manipulation; [519] Destination Host Name; [520] PSTN Termination Reason; [521] Module And Port; [522] AOC Currency; [523] AOC Amount; [524] AOC Multiplier; [525] ISDN Line Type; [600] Channel ID; [601] Coder Type; [602] Packet Interval; [603] Payload Type; [604] Local Input Packets; [605] Local Output Packets; [606] Local Input Octets; [607] Local Output Octets; [608] Local Packet Loss; [609] Local Round Trip Delay; [610] Local Jitter; [611] Local SSRC Sender; [612] Remote Input Packets; [613] Remote Output Packets; [614] Remote Input Octets; [615] Remote Output Octets; [616] Remote Packet Loss; [617] Remote Round Trip Delay; [618] Remote Jitter; [619] Remote SSRC Sender; [620] Local RTP IP; [621] Local RTP Port; [622] Remote RTP IP; [623] Remote RTP Port; [624] RTP IP DiffServ; [625] Local R Factor; [626] Remote R Factor; [627] Local MOS CQ; [628] Remote MOS CQ; [629] AMD Decision; [630] AMD Decision Probability; [631] Latched RTP IP; [632] Latched RTP Port; [633] Latched T38 IP; [634] Latched T38 Port.</b></p>
<p>'Title' title [Title]</p>	<p>Defines a new name for the CDR field (for syslog) or for the RADIUS Attribute prefix name (for RADIUS accounting) that you selected in the 'Column Type' parameter.</p> <p>The valid value is a string of up to 31 characters.</p> <p>You can configure the name to be enclosed by quotation marks (single or double). For example, if you want the CDR field name to appear as 'Phone Duration', you must configure the parameter to 'Phone Duration'. You can also configure the CDR field name with an equals (=) sign, for example "call-connect-time=".</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For RADIUS Attributes that do not require a prefix name, leave the parameter undefined.</li> <li>■ The parameter's value is case-sensitive. For example, if</li> </ul>

Parameter	Description
	<p>you want the CDR field name to be Phone-Duration, you must configure the parameter to "Phone-Duration" (i.e., uppercase "P" and "D").</p>
'RADIUS Attribute Type' radius-type [RadiusType]	<p>Defines whether the RADIUS Attribute of the CDR field is a standard or vendor-specific attribute.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Standard</b> = (Default) For standard RADIUS Attributes.</li> <li>■ [1] <b>Vendor Specific</b> = For vendor-specific RADIUS Attributes (VSA).</li> </ul> <p><b>Note:</b> The parameter is applicable only for RADIUS accounting (i.e., 'CDR Type' parameter configured to <b>RADIUS Gateway</b>).</p>
'RADIUS Attribute ID' radius-id [RadiusID]	<p>Defines an ID for the RADIUS Attribute. For vendor-specific Attributes, this represents the VSA ID; for standard attributes, this represents the Attribute ID (first byte of the Attribute).</p> <p>The valid value is 0 to 255 (one byte). The default is 0.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only for RADIUS accounting (i.e., 'CDR Type' parameter configured to <b>RADIUS Gateway</b>).</li> <li>■ For VSA's (i.e., 'RADIUS Attribute Type' parameter configured to <b>Vendor Specific</b>), the parameter must be configured to any value other than 0.</li> <li>■ For standard RADIUS Attributes (i.e., 'RADIUS Attribute Type' parameter configured to <b>Standard</b>), the value <b>must</b> be a "known" RADIUS ID (per RFC for RADIUS). However, if you configure the ID to 0 (default) for any of the RADIUS Attributes (configured in the 'Column Type' parameter) listed below and then apply your rule (Click <b>Apply</b>), the device automatically replaces the value with the RADIUS Attribute's ID according to the RFC:               <ul style="list-style-type: none"> <li>✓ <b>Destination Number:</b> 30</li> <li>✓ <b>Source Number:</b> 31</li> <li>✓ <b>Accounting Status Type:</b> 40</li> <li>✓ <b>Local Input Octets:</b> 42</li> </ul> </li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>✓ <b>Local Output Octets:</b> 43</li> <li>✓ <b>Call Duration:</b> 46</li> <li>✓ <b>Local Input Packets:</b> 47</li> <li>✓ <b>Local Output Packets:</b> 48</li> </ul> <p>If you configure the value to 0 and the RADIUS Attribute is not any of the ones listed above, the configuration is invalid.</p>

## Customizing CDRs for SBC Calls and Test Calls

The SBC CDR Format table lets you customize CDRs for SBC calls and CDRs for Test Calls that are generated by the device for the following CDR types:

- CDRs for SIP signaling or media sent in syslog messages. For CDRs sent in syslog messages, you can customize the name of the CDR field. You can configure up to 128 Syslog CDR customization rules.
- CDRs for RADIUS accounting and sent in RADIUS accounting request messages. For RADIUS accounting CDRs, you can customize the RADIUS Attribute's prefix name and RADIUS Attribute's ID, for standard RADIUS Attributes and vendor-specific RADIUS Attributes (VSA). For example, instead of the default VSA name "h323-connect-time" with RADIUS Attribute ID 28, you can change the name to "Call-Connect-Time" with ID 29. You can configure up to 70 RADIUS-Accounting CDR customization rules (i.e., maximum number of RADIUS Attributes that the device can include in the CDR). For more information on RADIUS accounting, see [Configuring RADIUS Accounting](#) on page 1456.
- CDRs stored locally on the device. For local storage of CDRs, you can customize the name of the CDR field. You can configure up to 64 locally-stored CDR customization rules. For more information on storing CDRs on the device, see [Storing CDRs Locally on the Device](#) on page 1384.
- CDRs (signaling only) sent to the REST server in JSON format using the device's REST API. You can configure up to 64 JSON CDR customization rules. For more information on CDRs and REST, see [Configuring CDR Reporting to REST Server](#) on page 1383.

Customizing the CDR means the following:

- Defining which CDR fields are included in the CDR. For example, if you configure only one customization rule for the syslog signaling (SBC) CDR type with the 'Call Duration' CDR field, the device generates these CDR types with only this single CDR field.

You can also customize the CDR to include the following CDR fields whose value is obtained from the SIP message, using Message Manipulation rules with call variables that store the value. The device adds the stored value to these special CDR fields when the CDR is generated:

- **User-defined CDR Fields:** The device provides up to five user-defined CDR fields titled "Var Call User Defined <1-5>", which you can optionally include in the generated CDR. To obtain the values from the SIP message for these CDR fields, use the following call variable syntax in your Message Manipulation rules:

```
Var.Call.Src|Dst.UserDefined<1-5>
```

For an example, see [CDR Customization using Call Variables Example](#) on page 1453.

- **Tenant ID CDR Field:** You can customize the CDR to include the 'Tenant ID' CDR field, which is typically used by OVOC. To obtain the value from the SIP message for this CDR field, use the following call variable syntax in your Message Manipulation rule:

```
Var.Call.Src|Dst.TenantId
```

For more information on SIP Message Manipulation, see [Configuring SIP Message Manipulation](#) on page 829.

- Changing the default name (`title`) of the CDR field. For example, you can change the title of the Call Duration CDR field to "Call Length".
- Changing the RADIUS Attribute's prefix name and ID, for standard RADIUS Attributes and vendor-specific RADIUS Attributes (VSA).



- If you don't customize the CDR, the device generates the CDR in a default format (fields and titles). For a detailed description of the fields that can be included in the CDR (customized and default), see [CDR Field Description](#) on page 1387.
- To return to the default CDR format for a specific CDR type, remove all the customization rules of that CDR type.
- When customizing the RADIUS CDR:
  - ✓ The following standard RADIUS Attributes cannot be customized: 1 through 6, 18 through 20, 22, 23, 27 through 29, 32, 34 through 39, 41, 44, 52, 53, 55, 60 through 85, 88, 90, and 91.
  - ✓ You must add the following RADIUS Attribute as the **first** rule in the SBC CDR Format table to ensure uniqueness (and to differentiate) between Call Connect (START) and Call End (STOP) RADIUS packets:

GENERAL	
Index	0
CDR Type	RADIUS SBC
Field Type	Accounting Status Type
Title	
RADIUS Attribute Type	Standard
RADIUS Attribute ID	40

- If the RTCP XR feature is unavailable (not licensed or disabled), the R-factor VoIP metrics are not provided in CDRs (CDR fields, Local R Factor and Remote R Factor) generated by the device. Instead, these CDR fields are sent with the value 127, meaning that information is unavailable.
- Test Call CDRs include "CALL\_START", "CALL\_CONNECT" and "CALL\_END" CDR Report Types.
- By default, SBC signaling CDRs that are sent at the end of the call ("CALL\_END" CDR Report Type) include only signaling-related CDR fields. However, by using the SBC CDR Format table, you can customize this CDR to also include media-related fields.
- To view historical CDRs stored on the device see [Viewing CDR History of SBC and Test Calls](#) on page 1363.

The following procedure describes how to customize SBC and Test Call CDRs through the Web interface. You can also configure it through ini file [SBCCDRFormat] or CLI (`configure troubleshoot > cdr > cdr-format sbc-cdr-format`).

#### ➤ To customize SBC and Test Call CDRs:

1. Open the SBC CDR Format table (**Troubleshoot** menu > **Troubleshoot** tab > **Call Detail Record** folder > **SBC CDR Format**).
2. Click **New**; the following dialog box appears:



3. Configure the CDR according to the parameters described in the table below.

4. Click **Apply**.

Examples of configured CDR customization rules are shown below:

INDEX	CDR TYPE	FIELD TYPE	TITLE	RADIUS ATTRIBUTE TYPE	RADIUS ATTRIBUTE ID
0	Syslog SBC	Source IP	"Source IP Address"	Standard	0
1	RADIUS SBC	Release Time	disconnect-time=	Vendor Specific	29
2	Local Storage SBC	Call Duration	Lenght of Call	Standard	0

**Table 58-4: SBC CDR Format Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'CDR Type' cdr-type [CDRType]	Defines the application type for which you want to customize CDRs. <ul style="list-style-type: none"> <li>[1] <b>Syslog SBC</b> = (Default) Customizes CDR fields for SIP signaling-related CDRs sent in syslog messages. However, for SBC signaling "CALL_END" CDR Report Types (sent at the end of the call), you can also customize the CDR to include media-related CDR fields (e.g., Local Packet Loss).</li> <li>[3] <b>Syslog Media</b> = Customizes CDR fields for media-related CDRs sent in syslog messages.</li> <li>[5] <b>Local Storage SBC</b> = Customizes CDR fields that are stored locally on the device. Only signaling-related CDRs are stored locally on the device. However, for SBC signaling "CALL_END" CDR Report Types (sent at the end of the call), you can also customize the CDR to include media-related CDR fields (e.g., Local Packet Loss).</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [7] <b>RADIUS SBC</b> = Customizes CDR fields (i.e., RADIUS Attributes) for CDRs sent in RADIUS accounting request messages.</li> <li>■ [11] <b>JSON SBC</b> = Customizes CDR fields for SIP signaling-related CDRs that are sent in JSON format to the REST server using the device's REST API.</li> </ul>
'Field Type' col-type [FieldType]	<p>Defines the CDR field (column) that you want to customize. The applicable CDR field depends on the settings of the 'CDR Type' parameter:</p> <ul style="list-style-type: none"> <li>■ For all types: [300] <b>CDR Type</b> (default); [301] <b>Call ID</b>; [302] <b>Session ID</b>; [303] <b>Report Type</b>; [304] <b>Media Type</b>; [305] <b>Accounting Status Type</b>; [306] <b>H323 ID</b>; [307] <b>RADIUS Call ID</b>; [308] <b>Blank</b>; [309] <b>Global Session ID</b>; [310] <b>Leg ID</b></li> <li>■ <b>Syslog SBC</b> (signaling), <b>Local Storage SBC</b>, <b>RADIUS SBC</b>, and <b>JSON SBC</b>: <ul style="list-style-type: none"> <li>[400] <b>Endpoint Type</b>; [401] <b>Call Orig</b>; [402] <b>Source IP</b>; [403] <b>Destination IP</b>; [404] <b>Remote IP</b>; [405] <b>Source Port</b>; [406] <b>Dest Port</b>; [407] <b>Remote Port</b>; [408] <b>Call Duration</b>; [409] <b>Termination Side</b>; [410] <b>Termination Reason</b>; [411] <b>Setup Time</b>; [412] <b>Connect Time</b>; [413] <b>Release Time</b>; [414] <b>Redirect Reason</b>; [415] <b>Was Call Started</b>; [416] <b>IP Group ID</b>; [417] <b>IP Group Name</b>; [418] <b>SRD ID</b>; [419] <b>SRD Name</b>; [420] <b>SIP Interface ID</b>; [421] <b>Transport Type</b>; [422] <b>Signaling IP DiffServ</b>; [423] <b>Termination Reason Category</b>; [424] <b>Proxy Set ID</b>; [425] <b>IP Profile ID</b>; [426] <b>IP Profile Name</b>; [427] <b>Media Realm ID</b>; [428] <b>Media Realm Name</b>; [429] <b>SIP Termination Reason</b>; [430] <b>SIP Termination Description</b>; [431] <b>Caller Display ID</b>; [432] <b>Callee Display ID</b>; [433] <b>SIP Interface Name</b>; [434] <b>Call Orig RADIUS</b>; [435] <b>Termination Side RADIUS</b>; [436] <b>Termination Side Yes No</b>; [437] <b>Termination Reason Value</b>; [438] <b>Proxy Set Name</b>; [439] <b>Trigger</b>; [442] <b>Call End Sequence Number</b>; [443] <b>Alerting Time</b>; [445] <b>SIP Local Tag</b>; [446] <b>SIP Remote Tag</b>; [447] <b>Call Success</b>; [448] <b>Var Call User Defined 1</b>; [449] <b>Var Call User Defined 2</b>; [450] <b>Var Call User Defined 3</b>; [451] <b>Var Call User Defined 4</b>; [452] <b>Var Call User Defined 5</b></li> </ul> </li> <li>■ <b>Syslog Media</b>, <b>RADIUS SBC</b>, <b>Local Storage SBC</b>, and <b>Syslog SBC</b>: <ul style="list-style-type: none"> <li>[600] <b>Channel ID</b>; [601] <b>Coder Type</b>; [602] <b>Packet Interval</b>; [603] <b>Payload Type</b>; [604] <b>Local Input Packets</b>; [605] <b>Local Output Packets</b>; [606] <b>Local Input Octets</b>; [607] <b>Local Output Octets</b>; [608] <b>Local Packet Loss</b>; [609] <b>Local Round Trip Delay</b>; [610] <b>Local Jitter</b>; [611] <b>Local SSRC Sender</b>; [612] <b>Remote Input Packets</b>; [613] <b>Remote Out-</b></li> </ul> </li> </ul>

Parameter	Description
	<p><b>put Packets; [614] Remote Input Octets; [615] Remote Output Octets; [616] Remote Packet Loss; [617] Remote Round Trip Delay; [618] Remote Jitter; [619] Remote SSRC Sender; [620] Local RTP IP; [621] Local RTP Port; [622] Remote RTP IP; [623] Remote RTP Port; [624] RTP IP DiffServ; [625] Local R Factor; [626] Remote R Factor; [627] Local MOS CQ; [628] Remote MOS CQ; [629] AMD Decision; [630] AMD Decision Probability; [631] Latched RTP IP; [632] Latched RTP Port; [633] Latched T38 IP; [634] Latched T38 Port; [635] Coder Transcoding</b></p> <p><b>Note:</b> For 'CDR Types' <b>Syslog SBC</b>, <b>Local Storage SBC</b>, and <b>RADIUS SBC</b>, the above media-related CDR fields are added only to "CALL_END" SBC signaling CDR report Types (which by default, include only signaling CDR fields).</p> <p>■ <b>Syslog SBC (signaling), Local Storage SBC, RADIUS SBC, and JSON SBC:</b></p> <p>[800] <b>Source URI</b>; [801] <b>Destination URI</b>; [802] <b>Source URI Before Manipulation</b>; [803] <b>Destination URI Before Manipulation</b>; [804] <b>Redirect URI</b>; [805] <b>Redirect URI Before Manipulation</b>; [806] <b>SIP Method</b>; [807] <b>Direct Media</b>; [808] <b>Source Username</b>; [809] <b>Destination Username</b>; [810] <b>Source Username Before Manipulation</b>; [811] <b>Destination Username Before Manipulation</b>; [812] <b>Source Host</b>; [813] <b>Destination Host</b>; [814] <b>Source Host Before Manipulation</b>; [815] <b>Destination Host Before Manipulation</b>; [816] <b>Source Dial Plan Tags</b>; [817] <b>Destination Dial Plan Tags</b>; [818] <b>Remote SIP User Agent</b>; [819] <b>Media List</b>; [820] <b>Voice AI Connector ID</b>; [821] <b>Voice AI Connector Name</b>; [822] <b>Is Recorded</b>; [823] <b>Tenant ID</b>; [824] <b>Released From IP</b>.</p>
'Title' title [Title]	<p>Defines a new name for the CDR field (for Syslog or local storage) or for the RADIUS Attribute prefix name (for RADIUS accounting) that you selected in the 'Column Type' parameter.</p> <p>The valid value is a string of up to 31 characters. You can also configure the name to be enclosed by quotation marks (single or double). For example, if you want the CDR field name to appear as 'Phone Duration', you must configure the parameter to 'Phone Duration'. You can also configure the CDR field name with an equals (=) sign, for example "call-connect-time=".</p> <p><b>Note:</b></p> <p>■ For VSA's that do not require a prefix name, leave the parameter undefined.</p> <p>■ The parameter's value is case-sensitive. For example, if you want the</p>

Parameter	Description
	CDR field name to be Phone-Duration, you must configure the parameter to "Phone-Duration" (i.e., uppercase "P" and "D").
'RADIUS Attribute Type' radius-type [RadiusType]	<p>Defines whether the RADIUS Attribute of the CDR field is a standard or vendor-specific attribute.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Standard</b> = (Default) For standard RADIUS Attributes.</li> <li>■ [1] <b>Vendor Specific</b> = For vendor-specific RADIUS Attributes (VSA).</li> </ul> <p><b>Note:</b> The parameter is applicable only to RADIUS accounting (i.e., 'CDR Type' parameter configured to <b>RADIUS SBC</b>).</p>
'RADIUS Attribute ID' radius-id [RadiusID]	<p>Defines an ID for the RADIUS Attribute. For VSAs, this represents the VSA ID; for standard Attributes, this represents the Attribute ID (first byte of the Attribute).</p> <p>The valid value is 0 to 255 (one byte). The default is 0.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to RADIUS accounting (i.e., 'CDR Type' parameter configured to <b>RADIUS SBC</b>).</li> <li>■ For VSA's (i.e., 'RADIUS Attribute Type' parameter configured to <b>Vendor Specific</b>), the parameter must be configured to any value other than 0.</li> <li>■ For standard RADIUS Attributes (i.e., 'RADIUS Attribute Type' parameter configured to <b>Standard</b>), the value <b>must</b> be a "known" RADIUS ID (per RFC for RADIUS). However, if you configure the ID to 0 (default) for any of the RADIUS Attributes (configured in the 'Column Type' parameter) listed below and then apply your rule (Click <b>Apply</b>), the device automatically replaces the value with the RADIUS Attribute's ID according to the RFC: <ul style="list-style-type: none"> <li>✓ <b>Destination Username:</b> 30</li> <li>✓ <b>Source Username:</b> 31</li> <li>✓ <b>Accounting Status Type:</b> 40</li> <li>✓ <b>Local Input Octets:</b> 42</li> <li>✓ <b>Local Output Octets:</b> 43</li> <li>✓ <b>Call Duration:</b> 46</li> <li>✓ <b>Local Input Packets:</b> 47</li> <li>✓ <b>Local Output Packets:</b> 48</li> </ul> </li> </ul> <p>If you configure the value to 0 and the RADIUS Attribute is not any of</p>

Parameter	Description
	the ones listed above, the configuration is invalid.

## CDR Customization using Call Variables Example

This section provides an example of customizing the CDR to include the 'Var Call User Defined <1-5>' field, whose value is obtained using call variables in Message Manipulation rules.

The example includes the following:

- Uses the call variable `Var.Call.Src.UserDefined1` (for SBC calls) or `Var.Call.Dst.UserDefined1` (for Gateway calls) in a Message Manipulation rule to store the value of the SIP header "X-AccountNumber" received in a 200 OK response.
- Customizes the CDR format to add the CDR field "Var Call User Defined 1", renames it "Account", and obtains its value from the call variable above.

### ➤ To customize CDR using call variable:

1. In the Message Manipulations table (see [Configuring SIP Message Manipulation](#) on page 829), configure the following rule:
  - 'Index': **0**
  - 'Name': **Store X-AccountNumber header**
  - 'Manipulation Set ID': **5**
  - 'Message Type': **Invite.Response.2xx**
  - 'Action Subject': **Var.Call.Src.UserDefined1** (for SBC calls) or **Var.Call.Dst.UserDefined1** (for Gateway calls)
  - 'Action Type': **Modify**
  - 'Action Value': **Header.X-AccountNumber**
2. In the SBC CDR Format table or Gateway CDR Format table, configure the following rule:
  - 'Index': **0**
  - 'CDR Type': **Syslog SBC** (SBC CDR Format table) or **Syslog Gateway** (Gateway CDR Format table)
  - 'Field Type': **Var Call User Defined 1**
  - 'Title': **Account**
3. (Gateway calls only) Configure the [GWInboundManipulationSet] parameter to "5" (i.e., value of 'Manipulation Set' parameter, above).

The following shows an example of a received SIP 200 OK response message with the X-InContact-BusNo header:

```
SIP/2.0 200 OK
Via: SIP/2.0/UDP 172.28.244.31:5060;branch=z9hG4bKac166782921
Contact: <sip:Stack@10.21.19.151:5060>
To: <sip:+18017155444@abc.com>;tag=87245f3d
From: "usera"<sip:usera@abc.com>;tag=1c1187059515
Call-ID: 628022773122202022133@172.28.244.31
CSeq: 1 INVITE
Session-Expires: 1200;refresher=uas
Content-Type: application/sdp
Supported: timer
X-AccountNumber: 87654321
```

The following shows the generated CDR:

```
|Orig |Account|
|LCL |87654321|
```

## Customizing CDR Indication for Call Success or Failure based on Responses

The CDR can indicate if a call was a success ("yes") or failure ("no"), using the 'Call Success' CDR field. This is an optional field that you can include in CDRs, by customizing the CDR format (as described in [Customizing CDRs for Gateway Calls](#) on page 1440 [Customizing CDRs for SBC Calls and Test Calls](#) on page 1446).

The device determines if a call is a success or failure based on the release (termination) reason of the call, which can be a SIP response code received from the SIP User Agent or an internal response generated by the device. However, you can change the device's default mapping of call success and failure with these responses. For example, by default, the device considers a call that is released with a SIP 404 (Not Found) response as a call failure (i.e., 'Call Success' CDR field displays "no"). Using this feature, you can configure the device to consider SIP 404 responses as a call success.

### ➤ To customize CDR indication for call success and failure:

1. Open the Call Detail Record Settings page (**Troubleshoot** menu > **Troubleshoot** tab > **Call Detail Record** folder > **Call Detail Record Settings**).
2. To customize call success or failure indication for SIP reasons:
  - In the 'Call Success SIP Reasons' [CallSuccessSIPReasons] field, configure the SIP response codes that you want the device to consider as call success.
  - In the 'Call Failure SIP Reasons' [CallFailureSIPReasons] field, configure the SIP response codes that you want the device to consider as call failure.

Call Success SIP Reasons

Call Failure SIP Reasons



- If your configuration results in overlapping reasons between the two parameters above, preference is given to the parameter with the specific response code instead of the parameter with the range ("xx"). For example, if 'Call Success SIP Reasons' is configured to "404,5xx" and 'Call Failure SIP Reasons' to "502", a call with SIP response code 502 is considered a call failure, as the 'Call Failure SIP Reasons' parameter is configured with the specific code while the 'Call Success SIP Reasons' is configured with the code range (5xx).
- By default, the device considers these SIP response codes as a call success:
  - ✓ No answer (452 and 487)
  - ✓ Busy (486 and 600)
  - ✓ Forwarded (300, 301, 302, 303, and 305)For all other SIP failure response codes, the device considers them as call failure.

3. To customize call success or failure indication for internal reasons:

- In the 'Call Success Internal Reasons' [CallSuccessInternalReasons] field, configure the internal response codes that you want the device to consider as call success.
- In the 'Call Failure Internal Reasons' [CallFailureInternalReasons] field, configure the internal response codes that you want the device to consider as call failure.

Call Success Internal Reasons

Call Failure Internal Reasons



For a list of the internal response codes, see the 'Termination Reason' [410] CDR field in [CDR Field Description](#) on page 1387.

4. To customize call success or failure indication for the internal response "GWAPP\_NO\_USER\_RESPONDING" (18) before or after call connect (SIP 200 OK):

- From the 'No User Response Before Connect' [NoUserResponseBeforeConnectSuccess] drop-down list, select **Call Failure** if you want the device to consider a call as a failure when this response is received before call connect.
- From the 'No User Response After Connect' [NoUserResponseAfterConnectSuccess] drop-down list, select **Call Success** if you want the device to consider a call as a success when this response is received after call connect.

No User Response Before Connect

No User Response After Connect

5. To customize call success or failure indication for the internal response 'RELEASE\_BECAUSE\_CALL\_TRANSFERRED' (807) before or after call connect (SIP 200 OK):
  - From the 'Call Transferred before Connect' [CallTransferredBeforeConnectSuccess] drop-down list, select **Call Success** if you want the device to consider the call as a success when this response is received before call connect (SIP 200 OK).
  - From the 'Call Transferred after Connect' [CallTransferredAfterConnectSuccess] drop-down list, select **Call Failure** if you want the device to consider the call as a failure when this response is received after call connect (SIP 200 OK).

**Call Transferred Before Connect**

Call Failure


**Call Transferred After Connect**

Call Success

## Configuring RADIUS Accounting

The device supports RADIUS Accounting (per RFC 2866) and sends accounting data of SIP calls as call detail records (CDR) to a RADIUS Accounting server. CDR-based accounting messages can be sent upon call release, call connection and release, or call setup and release. This section lists the CDR attributes for RADIUS accounting.

The following figure shows the interface between the device and the RADIUS server, based on the RADIUS Accounting protocol. For each CDR that the device sends to the RADIUS server, it sends an Accounting-Request Stop with all the CDR attributes. When the RADIUS server successfully receives all the CDR attributes, it responds with an Accounting-Response Stop ACK message to the device. If the device doesn't receive the Accounting-Response ACK message, it can resend the Accounting-Request Stop with all CDR attributes again, up to a user-defined number of re-tries (see [Configuring RADIUS Packet Retransmission](#) on page 364).



There are two types of data that can be sent to the RADIUS server. The first type is the accounting-related attributes and the second type is the vendor specific attributes (VSA):


- **Standard RADIUS Attributes (per RFC):** A typical standard RADIUS attribute is shown below. The RADIUS attribute ID depends on the attribute.

```

2e 06 00 00 00 03 --- Data
|  |
|  Length (including header)
RADIUS ID
  
```




The following figure shows a standard RADIUS attribute collected by Wireshark. The bottom pane shows the RADIUS attribute information as sent in the packet; the upper pane is Wireshark's interpretation of the RADIUS information in a more readable format. The example shows the attribute in numeric format (32-bit number in 4 bytes).



- **Vendor-specific RADIUS Attributes:** RADIUS attributes that are specific to the device (company) are referred to as Vendor-specific attributes (VSA). The CDR of VSAs are sent with a general RADIUS ID of 26 to indicate that they are vendor-specific (non-standard). In addition, the company's registered vendor ID (as registered with the Internet Assigned Numbers Authority or IANA) is also included in the packet. The device's default vendor ID is 5003, which can be changed (see [Configuring the RADIUS Vendor ID](#) on page 364). The VSA ID is also included in the packet.

```
1a 13 00 00 13 8b 21 0d 68 33 32 33 2d 67 77 2d 69 64 3d --- Data
| | | | | | | |
| | Vendor ID | Vendor part length
| | (5003) | Vendor-Specific Attribute (VSA) ID
| Length (including header)
RADIUS ID indicating vendor-specific (26)
```

The following figure shows a vendor-specific RADIUS attribute collected by Wireshark. The bottom pane shows the RADIUS attribute information as sent in the packet; the upper pane is Wireshark's interpretation of the RADIUS information in a more readable format. The example shows the attribute in string-of-characters format.



You can customize the prefix title of the RADIUS attribute name and ID. For more information, see [Customizing CDRs for SBC Calls and Test Calls](#) on page 1446 and [Customizing CDRs for Gateway Calls](#) on page 1440.

To configure the address of the RADIUS Accounting server, see [Configuring RADIUS Servers](#) on page 360. For all RADIUS-related configuration, see [RADIUS-based Services](#) on page 360.

➤ **To configure RADIUS accounting:**

1. Open the Authentication Server page (**Setup** menu > **Administration** tab > **Web & CLI** folder > **Authentication Server**).
2. Select the 'Enable RADIUS Access Control' check box [EnableRADIUS]:

Enable RADIUS Access Control



3. Click **Apply**.
4. Open the Call Detail Record Settings page (**Troubleshoot** menu > **Troubleshoot** tab > **Call Detail Record** folder > **Call Detail Record Settings**).
5. From the 'RADIUS Accounting Type' [RADIUSAccountingType] drop-down list, select the stage of the call that RADIUS accounting messages are sent to the RADIUS accounting server.
6. From the 'AAA Indications' [AAAIndications] drop-down list, select whether you want Authentication, Authorization and Accounting (AAA) indications.

For a detailed description of the parameters, see [RADIUS Parameters](#) on page 1940.

#### RADIUS ACCOUNTING SETTING

RADIUS Accounting Type

At Call Release

AAA Indications

Accounting Only

7. Click **Apply**, and then restart the device with a save-to-flash for your settings to take effect.

The table below lists the RADIUS Accounting CDR attributes included in the communication packets transmitted between the device and a RADIUS server.

**Table 58-5: Default RADIUS Accounting CDR Attributes**

Attribute ID	Attribute Name	Vendor-Specific Attribute (VSA) ID	Description	Value Format	Example	AAA
<b>Request Attributes</b>						
1	user-name	(Standard)	Account number or calling party	String up to	5421385747	Start

Attribute ID	Attribute Name	Vendor-Specific Attribute (VSA) ID	Description	Value Format	Example	AAA
			number or blank	15 digits long		Acc Stop Acc
4	nas-ip-address (for IPv4) nas-ipv6-address (for IPv6)	(Standard)	IP address (IPv4 or IPv6) of the requesting device	Numeric	192.168.14.43 (IPv4)	Start Acc Stop Acc
6	service-type	(Standard)	Type of service requested	Numeric	1: login	Start Acc Stop Acc
26	h323-incoming-conf-id	1	SIP call identifier	Up to 32 octets	h323-incoming-conf-id=38393530	Start Acc Stop Acc
26	h323-remote-address	23	IP address of the remote gateway	Numeric	-	Stop Acc
26	h323-conf-id	24	H.323/SIP call identifier	Up to 32 octets	-	Start Acc Stop Acc
26	h323-setup-time	25	Setup time in NTP format 1	String	h323-setup-time=09:33:26.621 Mon Dec	Start Acc

Attribute ID	Attribute Name	Vendor-Specific Attribute (VSA) ID	Description	Value Format	Example	AAA
					2014	Stop Acc
26	h323-call-origin	26	<p>Originator of call:</p> <ul style="list-style-type: none"> <li>■ "answer": Call originated from the IP side (Gateway) or incoming leg (SBC)</li> <li>■ "originate": Call originated from the Tel side (Gateway) or outgoing leg (SBC)</li> </ul>	String	h323-call-origin=answer	Start Acc Stop Acc
26	h323-call-type	27	Protocol type or family used on this leg of the call. The value is always "VOIP".	String	h323-call-type=VOIP	Start Acc Stop Acc
26	h323-connect-time	28	Connect time in NTP format	String	h323-connect-time=09:33:37.657 UTC Mon Dec 08 2015	Stop Acc
26	h323-disconnect-time	29	Disconnect time in NTP format	String	-	Stop Acc
26	h323-disconnect-cause	30	Disconnect cause code (Q.850)	Numeric	h323-disconnect-cause=16	Stop Acc
26	h323-	33	Name of the	String	h323-gw-	Star

Attribute ID	Attribute Name	Vendor-Specific Attribute (VSA) ID	Description	Value Format	Example	AAA
	gw-id		gateway		id=<SIP ID string>	t Acc Stop Acc
26	sip-call-id	34	SIP Call ID	String	sip-call-id=abcde@ac.com	Start Acc Stop Acc
26	call-terminator	35	Terminator of the call: <ul style="list-style-type: none"> <li>■ "yes": Call terminated by the Tel side (Gateway) or outgoing leg (SBC)</li> <li>■ "no": Call terminated by the IP side (Gateway) or incoming leg (SBC)</li> </ul>	String	call-terminator=yes	Stop Acc
26	terminator	37	Terminator of the call: <ul style="list-style-type: none"> <li>■ "answer": Call originated from the IP side (Gateway) or incoming leg (SBC)</li> <li>■ "originate":</li> </ul>	String	terminator=originate	Stop Acc

Attribute ID	Attribute Name	Vendor-Specific Attribute (VSA) ID	Description	Value Format	Example	AAA
			Call originated from the Tel side (Gateway) or outgoing leg (SBC)			
30	called-station-id	(Standard)	Gateway call: Called (destination) phone number  SBC call: Destination URI	String	8004567145	Start Acc
31	calling-station-id	(Standard)	Calling Party Number (ANI) (Gateway call) or Source URI (SBC call)	String	5135672127	Start Acc Stop Acc
40	acct-status-type	(Standard)	Account Request Type: <ul style="list-style-type: none"> <li>■ "1" (start): Sent in Call Start or Call Connect CDRs</li> <li>■ "2" (stop): Sent in Call End CDRs only.</li> </ul> <p><b>Note:</b> It is highly recommended to add this attribute if you are customizing the RADIUS CDR format (see <a href="#">Customizing CDRs for SBC Calls and</a></p>	Numeric	1	Start Acc Stop Acc

Attribute ID	Attribute Name	Vendor-Specific Attribute (VSA) ID	Description	Value Format	Example	AAA
			<a href="#">Test Calls</a> on page 1446 for SBC calls and <a href="#">Customizing CDRs for Gateway Calls</a> on page 1440 for Gateway calls).			
41	acct-delay-time	(Standard)	No. of seconds tried in sending a particular record	Numeric	5	Start Acc Stop Acc
42	acct-input-octets	(Standard)	Number of octets received for that call duration (for SBC calls, applicable only if media anchoring)	Numeric	-	Stop Acc
43	acct-output-octets	(Standard)	Number of octets sent for that call duration (for SBC calls, applicable only if media anchoring)	Numeric	-	Stop Acc
44	acct-session-id	(Standard)	A unique accounting identifier that corresponds to the acct-status-type attribute and thus, the identifier of the start CDR is identical to the stop CDR ID of the same call.	String	34832	Start Acc Stop Acc

Attribute ID	Attribute Name	Vendor-Specific Attribute (VSA) ID	Description	Value Format	Example	AAA
			This attribute is composed of the Session ID of the call (e.g., [SID=9be7fc:152:99757]) followed by a colon (:) and the leg ID (e.g., 9be7fc:152:99757:1 for the SBC incoming leg or Gateway call, and 9be7fc:152:99757:2 for the SBC outgoing leg).			
46	acct-session-time	(Standard)	For how many seconds the user received the service	Numeric	-	Stop Acc
47	acct-input-packets	(Standard)	Number of packets received during the call	Numeric	-	Stop Acc
48	acct-output-packets	(Standard)	Number of packets sent during the call	Numeric	-	Stop Acc
61	nas-port-type	(Standard)	Physical port type of device on which the call is active	String	0: Asynchronous	Start Acc Stop Acc
<b>Response Attributes</b>						
26	h323-	103	The reason for	Numeric	0 Request	Stop



Attribute ID	Attribute Name	Vendor-Specific Attribute (VSA) ID	Description	Value Format	Example	AAA
	return-code		failing authentication (0 = ok, other number failed)	ic	accepted	p Acc
44	acct-session-id	(Standard)	A unique accounting identifier – match start & stop	String	-	Sto p Acc

Below is an example of RADIUS Accounting, where non-standard parameters are preceded with brackets:

#### Accounting-Request (4)

```

user-name = 111
acct-session-id = 1
nas-ip-address = 212.179.22.213
nas-port-type = 0
acct-status-type = 2
acct-input-octets = 4841
acct-output-octets = 8800
acct-session-time = 1
acct-input-packets = 122
acct-output-packets = 220
called-station-id = 201
calling-station-id = 202

```

#### // Accounting non-standard parameters:

```

(4923 33) h323-gw-id =
(4923 23) h323-remote-address = 212.179.22.214
(4923 1) h323-ivr-out = h323-incoming-conf-id:02102944 600a1899 3fd61009
0e2f3cc5
(4923 30) h323-disconnect-cause = 22 (0x16)
(4923 27) h323-call-type = VOIP
(4923 26) h323-call-origin = Originate
(4923 24) h323-conf-id = 02102944 600a1899 3fd61009 0e2f3cc5

```

## Querying Device Channel Resources using SIP OPTIONS

The device reports its maximum and available channel resources in SIP 200 OK responses upon receipt of SIP OPTIONS messages. The device sends this information in the SIP X-Resources header with the following parameters:

- **telchs:** Specifies the total telephone channels and the number of free (available) telephone channels.
- **mediachs:** Not applicable

Below is an example of the X-Resources:

```
X-Resources: telchs= 12/4;mediachs=0/0
```

In the example above, "telchs" specifies the number of available channels and the number of occupied channels (4channels are occupied and 12channels are available).



This feature is applicable only to the Gateway application.

## 59 Remote Monitoring of Device behind NAT

When the device is located behind a NAT, you can configure it to periodically send monitoring reports to a third-party, remote HTTP-based monitoring server. This third-party server is configured on the device as a Remote Web Service (HTTP host), where the 'Type' parameter is set to **Remote Monitoring**. The device sends the reports over HTTP/S using RESTful API (in JSON format), where the device acts as the client.

You can choose to send various reports to the monitoring server:

- **Status reports:** These reports contain status information of the device, for example, software version, network configuration (IP network interfaces, Ethernet port interfaces, and proxy addresses), IP Groups, Trunk Groups, PSTN trunks, and serial number).
- **Active alarms reports:** These reports contain currently active alarms.
- **Key performance indicators reports:** These reports contain performance monitoring statistics, for example, number of active SBC sessions, average call duration, and number of established inbound calls.
- **Registration status reports:** These reports contain status information of SIP User Agents (UA) currently registered with the device.

If the device receives an HTTP failure response (4xx/5xx/6xx) from the Remote Web Service when it attempts to send it a monitoring report, the device raises the SNMP alarm, `acRemoteMonitoringAlarm` (with Warning severity level). This alarm is cleared only when it receives an HTTP successful response (2xx) from the server.



- Currently, you can configure the device to send monitoring reports to only one Remote Web Service.
- If the report contains the **more** attribute with value "True", it means that the report has reached its maximum file size and the device will send another report with more information. The last report doesn't contain this attribute.

### ➤ To enable remote monitoring of device behind NAT:

1. In the Remote Web Services table (see [Configuring Remote Web Services](#) on page 429), configure a Remote Web Service with the 'Type' parameter set to **Remote Monitoring**.
2. Open the Web Service Settings page (**Setup** menu > **IP Network** tab > **Web Services** folder > **Web Service Settings**).

REMOTE MONITORING

Remote Monitoring	<input checked="" type="checkbox"/>
Reporting Period (sec)	<input type="text" value="60"/>
Device Status	<input type="checkbox"/>
Active Alarms	<input checked="" type="checkbox"/>
Performance Indicators	<input type="checkbox"/>
Registration Status	<input checked="" type="checkbox"/>

3. Select the 'Remote Monitoring' check box to enable the feature.
4. In the 'Reporting Period' field, configure the interval (in seconds) between each sent report.
5. Select the check boxes of the corresponding report types (information) that you want the device to send:
  - 'Device Status': Report contains status information of the device
  - 'Active Alarms': Report contains currently active alarms
  - 'Performance Indicators': Report contains performance monitoring statistics
  - 'Registration Status': Report contains information of users registered with the device
6. Click **Apply**.

# Part X

## Diagnostics

## 60 Syslog and Debug Recording

For debugging and troubleshooting, you can use the device's syslog and/or Debug Recording capabilities:

- **Syslog:** Syslog is an event notification protocol that enables a device to send event notification messages across IP networks to event message collectors, also known as syslog servers. The device contains an embedded syslog client, which sends error reports / events that it generates to a remote syslog server using the IP / UDP protocol. This information is a collection of error, warning, and system messages that records every internal operation of the device.
- **Debug Recording:** The device can send debug recording packets to a debug capturing server. When the debug recording is activated, the device duplicates all messages that are sent and/or received by it and then sends them to an external server defined by IP address. The debug recording can be done for different types of traffic such as RTP/RTCP, T.38, ISDN, CAS, and SIP. Debug recording is used for advanced debugging when you need to analyze internal messages and signals. Debug recording is also useful for recording network traffic in environments where hub or port mirroring is unavailable and for recording internal traffic between two endpoints on the same device.



You can include syslog messages in debug recording (see [Configuring Logging Filter Rules](#) below).

### Configuring Logging Filter Rules

The Logging Filters table lets you configure up to 60 rules for filtering debug recording packets, syslog messages, and Call Detail Records (CDR). The logging filter determines the calls for which you want to generate the log. For example, you can add a rule to generate syslog messages only for calls belonging to IP Groups 2 and 4, or for calls belonging to all IP Groups except IP Group 3.

You can also configure logging filters for generating CDRs only and saving them on the device (local storage). Debug recording logging filters can include signaling information (such as SIP messages), syslog messages, PSTN traces (ISDN and CAS), CDRs, media (RTP, RTCP, and T.38), and pulse-code modulation (PCM) of voice signals from and to the TDM.

You can configure the following special logging filters for OVOC:

- You can filter logged SIP messages that the device sends to OVOC so that OVOC can display SIP call dialog sessions as SIP call flow diagrams (SIP ladder).
- You can filter Quality of Experience (voice metrics in CDRs) reports that the device sends to OVOC.

If you don't configure any rules in the Logging Filters table and you have globally enabled debug recording (by configuring the Debug Recording server's address - see note below), syslog (global parameter - see note below), and/or CDR generation (global parameter for enabling syslog - see note below), logs are generated for all calls. Therefore, the benefit of logging filters is that it

allows you to create logs per specific calls, eliminating the need for additional device resources (CPU consumption) otherwise required when logs are generated for all calls.

You can enable and disable each of your configured logging filter rules. Enabling rules that are not for debugging recording, activates the rule so that the device generates syslog messages or CDRs. For debug recording rules, you need to explicitly start the debug recording, as described in [Starting and Stopping Debug Recording](#) on page 1512. Disabling a rule is useful, for example, if you currently no longer require the rule, but may need it in the future. Therefore, instead of deleting the rule, you can simply disable it.



- If you want to configure a rule that logs syslog messages to a syslog server (i.e., not to a Debug Recording server), you must enable syslog functionality, using the 'Enable Syslog' (EnableSyslog) parameter (see [Enabling Syslog](#) on page 1490). Enabling syslog functionality is not required for rules that include syslog messages in the debug recording sent to the Debug Recording server.
- To configure the syslog server's address, see [Configuring the Primary Syslog Server Address](#) on page 1490. To configure additional, global syslog settings, see [Configuring Syslog](#) on page 1482.
- To configure the Debug Recording server's address, see [Configuring Debug Recording Server Address](#) on page 1511.
- To configure additional, global CDR settings such as at what stage of the call the CDR is generated (e.g., start and end of call), see [Configuring CDR Filters and Report Level](#) on page 1382.
- To start and stop debug recording rules, see [Starting and Stopping Debug Recording](#) on page 1512.

The following procedure describes how to configure logging filter rules through the Web interface. You can also configure it through ini file [LoggingFilters] or CLI (`configure troubleshoot > logging logging-filters`).

#### ➤ To configure a logging filter rule:

1. Open the Logging Filters table (**Troubleshoot** menu > **Troubleshoot** tab > **Logging** folder > **Logging Filters**).
2. Click **New**; the following dialog box appears:

Logging Filters - x

GENERAL	
Index	<input type="text" value="0"/>
Filter Type	<input type="text" value="Any"/>
Value	<input type="text"/>
Log Destination	<input type="text" value="Debug Recording Server"/>
Log Type	<input type="text"/>
Mode	<input type="text" value="Enable"/>

3. Configure a Log Filtering rule according to the parameters described in the table below.

4. Click **Apply**.**Table 60-1: Logging Filters Table Parameter Descriptions**

Parameter	Description
'Index' [Index]	<p>Defines an index number for the new table row.</p> <p><b>Note:</b> Each row must be configured with a unique index.</p>
'Filter Type' filter-type [FilterType]	<p>Defines the filter type criteria.</p> <ul style="list-style-type: none"> <li>■ [1] <b>Any</b>= (Default) Debug recording is done for all calls.</li> <li>■ [2] <b>Trunk ID</b> = Filters the log by Trunk ID.</li> </ul> <p><b>Note:</b> This option is applicable only to the Gateway application.</p> <ul style="list-style-type: none"> <li>■ [3] <b>Trunk Group ID</b> = Filters the log by Trunk Group ID. To configure Trunk Groups, see <a href="#">Configuring Trunk Groups</a> on page 903.</li> </ul> <p><b>Note:</b> Applicable only to the Gateway application.</p> <ul style="list-style-type: none"> <li>■ [4] <b>Trunk &amp; B-channel</b> = Filters the log by Trunk and B-channel.</li> </ul> <p><b>Note:</b> This option is applicable only to the Gateway application.</p> <ul style="list-style-type: none"> <li>■ [6] <b>Tel-to-IP</b> = Filters the log by Tel-to-IP Routing rule. To configure Tel-to-IP Routing rules, see <a href="#">Configuring Tel-to-IP Routing Rules</a> on page 914.</li> </ul> <p><b>Note:</b> This option is applicable only to the Gateway application.</p> <ul style="list-style-type: none"> <li>■ [7] <b>IP-to-Tel</b> = Filters the log by IP-to-Tel Routing rule. To configure IP-to-Tel Routing rules, see <a href="#">Configuring IP-to-Tel Routing Rules</a> on page 928.</li> </ul> <p><b>Note:</b> This option is applicable only to the Gateway application.</p> <ul style="list-style-type: none"> <li>■ [8] <b>IP Group</b> = Filters the log by IP Group. To configure IP Groups, see <a href="#">Configuring IP Groups</a> on page 581.</li> <li>■ [9] <b>SRD</b> = Filters the log by SRD. To configure SRDs, see <a href="#">Configuring SRDs</a> on page 549.</li> <li>■ [10] <b>Classification</b> = Filters the log by Classification rule. To configure Classification rules, see <a href="#">Configuring Classification Rules</a> on page 1061.</li> </ul>



Parameter	Description
	<p><b>Note:</b> This option is applicable only to the SBC application.</p> <ul style="list-style-type: none"> <li>■ <b>[11] IP-to-IP Routing</b> = Filters the log by IP-to-IP Routing rule. To configure IP-to-IP Routing rules, see <a href="#">Configuring SBC IP-to-IP Routing Rules</a> on page 1076.</li> </ul> <p><b>Note:</b> This option is applicable only to the SBC application.</p> <ul style="list-style-type: none"> <li>■ <b>[12] User</b> = Filters the log by user (source and destination). The user is defined by username or username@hostname in the source or destination headers of the SIP request. For example, "2222@10.33.45.201" (without quotation marks) represents the following INVITE request:</li> </ul> <pre>INVITE sip:2222@10.33.45.201;user=phone SIP/2.0 From: sip:2222@10.33.45.201;user=phone</pre> <ul style="list-style-type: none"> <li>■ <b>[13] IP Trace</b> = Filters the log by an IP network trace, using Wireshark-like expressions. For more information, see <a href="#">Filtering IP Network Traces using Wireshark-Like Expressions</a> on page 1478. For filtering IP traces by Ethernet port, or VLAN, see <a href="#">Filtering IP Network Traces by Ethernet Port or VLAN</a> on page 1480. The device adds an "ACDR" header to IP trace recordings.</li> <li>■ <b>[14] SIP Interface</b> = Filters the log by SIP Interface. To configure SIP Interfaces, see <a href="#">Configuring SIP Interfaces</a> on page 561.</li> <li>■ <b>[15] System Trace</b> = Filters the log to include logged information not related to calls, for example, the device's CPU, HA traffic between active and redundant devices, or a disconnection with the LDAP server.</li> <li>■ <b>[16] IP Group Tag</b> = Filters the log by the IP Group's tag (source and destination). The tag is configured by the 'Tags' parameter in the IP Groups table.</li> </ul>
'Value' value [Value]	<p>Defines the value for the filtering type configured in the 'Filter Type' parameter.</p> <p>The value can include the following:</p> <ul style="list-style-type: none"> <li>■ For IP traces ('Filter Type' parameter configured to <b>IP Trace</b>), you need to configure the value with Wireshark-like expressions to filter the IP trace, as described in <a href="#">Filtering IP Network Traces using Wireshark-Like Expressions</a> on page 1478. If the parameter is not configured, the IP trace</li> </ul>

Parameter	Description
	<p>applies to all packets.</p> <ul style="list-style-type: none"> <li>■ For system traces ('Filter Type' parameter configured to <b>System Trace</b>), configure the value to one of the following: <ul style="list-style-type: none"> <li>✓ "syslog": This option includes INFO packet types.</li> <li>✓ "tpncp": This option includes device events and command packets, as displayed when using the Wireshark filter 'tpncp'.</li> <li>✓ "ha": This option includes High Availability (HA) and TPNCPC command packet types (communication between active and redundant devices).</li> </ul> </li> <li>■ A single value.</li> <li>■ A range, using a hyphen "-" between the two values. For example, to specify IP Groups 1, 2 and 3, configure the parameter to "1-3" (without quotation marks).</li> <li>■ Multiple, non-contiguous values, using commas "," between each value. For example, to specify IP Groups 1, 3 and 9, configure the parameter to "1,3,9" (without quotation marks).</li> <li>■ Trunks pertaining to a module, using the syntax module number/port or port, for example: <ul style="list-style-type: none"> <li>✓ "1/2" (without quotation marks) means module 1, port 2</li> <li>✓ "1/[2-4]" (without quotation marks) means module 1, ports 2 through 4</li> </ul> </li> <li>■ To exclude specific configuration entities from the log filter, use the exclamation (!) wildcard character. For example, to include all IP Groups in the filter except IP Group ID 2, configure the 'Filter Type' parameter to <b>IP Group</b> and the 'Value' parameter to "!2" (without quotation marks).</li> </ul> <p><b>Note:</b> For SBC calls, a Logging Filter rule applies to the entire session (i.e., inbound and outbound legs). Therefore, if you want to exclude logging of specific calls, you need to configure the 'Value' parameter with both legs. For example:</p> <ul style="list-style-type: none"> <li>✓ If you want to exclude logs for calls between IP Group 1 and IP Group 2, configure the parameter to "!1,2" (without quotation marks).</li> </ul>

Parameter	Description
	<p>✓ If you want to exclude logs for calls between SIP Interface 4 and SIP Interface 9, configure the parameter to "!4,9" (without quotation marks).</p> <p><b>Note:</b> You can use the index number or string name to specify the configuration entity for the following 'Filter Types': Tel-to-IP, IP-to-Tel, <b>IP Group</b>, <b>SRD</b>, <b>Classification</b>, <b>IP-to-IP Routing</b>, or <b>SIP Interface</b>. For example, to specify IP Group "My SIP Trunk" at Index 2, configure the parameter to either "2" or "My SIP Trunk" (without quotation marks).</p>
'Log Destination' log-dest [LogDestination]	<p>Defines where the device sends the log file.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Syslog Server</b> = The device generates syslog messages for your log filter and sends them to a user-defined syslog server.</li> <li>■ [1] <b>Debug Recording Server</b> = (Default) The device generates debug recording packets for your log filter and sends them to a user-defined Debug Recording server.</li> <li>■ [2] <b>Local Storage</b> = The device generates CDRs for your log filter and stores them locally on the device. For more information on local storage of CDRs, see <a href="#">Storing CDRs Locally on the Device</a> on page 1384.</li> <li>■ [3] <b>OVOC (QoE)</b> = This option is used when the device sends any of the following to OVOC:               <ul style="list-style-type: none"> <li>✓ <b>SIP messages:</b> The SIP messages can be used by OVOC to display SIP call dialog sessions as SIP call flow diagrams (SIP ladder). For this functionality, you also need to configure the 'Log Type' parameter to <b>SIP Ladder</b>. For more information on enabling this functionality, see <a href="#">Enabling SIP Call Flow Diagrams in OVOC</a> on page 1531.</li> <li>✓ <b>Quality of Experience (QoE) voice metric reports:</b> To configure reporting and filtering of QoE to OVOC, see <a href="#">Reporting QoE to OVOC</a> on page 514. For this functionality, you also need to configure the 'Log Type' parameter to <b>CDR</b>.</li> </ul> </li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you configure the parameter to <b>Syslog Server</b>:               <ul style="list-style-type: none"> <li>✓ If you have also configured the debug level to <b>No Debug</b> (see the [GwDebugLevel] parameter in <a href="#">Configuring</a></li> </ul> </li> </ul>

Parameter	Description
	<p><a href="#">Syslog Debug Level</a> on page 1501), the syslog messages include only system warnings and errors.</p> <ul style="list-style-type: none"> <li>✓ The 'Log Type' parameter (below) is not applicable (all syslog messages are sent to the syslog server).</li> <li>■ If you configure the 'Filter Type' parameter to <b>IP Trace</b>, you must configure the parameter to <b>Debug Recording Server</b>.</li> <li>■ For local storage of CDRs, configure the parameter to <b>Local Storage</b> and the 'Log Type' parameter to <b>CDR</b>.</li> <li>■ If you configure the parameter to <b>Debug Recording Server</b>, you can also include syslog messages in the debug recording packets sent to the debug recording server. To include syslog messages, configure the 'Log Type' parameter (see below) to the relevant option.</li> </ul>
'Log Type' log-type [CaptureType]	<p>Defines the type of messages to include in the log file.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Not configured. The option is applicable only for sending syslog messages to a syslog server (i.e., 'Log Destination' parameter is configured to <b>Syslog Server</b>).</li> <li>■ [1] <b>Signaling</b> = The option is applicable only to debug recording (i.e., 'Log Destination' parameter is configured to <b>Debug Recording Server</b>). The debug recording includes signaling information such as SIP signaling messages, syslog messages, CDRs, and the device's internal processing messages.</li> <li>■ [2] <b>Signaling &amp; Media</b> = The option is applicable only to debug recording (i.e., 'Log Destination' parameter is configured to <b>Debug Recording Server</b>). The debug recording includes media (RTP/RTCP/T.38), and only signaling and syslog messages associated with the recorded media.</li> </ul> <p><b>Note:</b> The device requires a lot of resources for media debug recording. The number of media sessions (and associated signaling) that the device records depends on available resources. Therefore, when many media sessions need to be recorded (e.g., when the 'Filter Type' parameter is configured to <b>Any</b>) not all media sessions (and associated signaling) are recorded. If the device has no resources to debug record any media, it doesn't debug record any signaling as well. As debug recording of signaling requires less resources than media debug recording, if you want to perform debug record-</p>

Parameter	Description
	<p>ing only on signaling, then it is recommended to configure the parameter to <b>Signaling</b>.</p> <ul style="list-style-type: none"> <li>■ [3] <b>Signaling &amp; Media &amp; PCM</b> = The option is applicable only to debug recording (i.e., 'Log Destination' parameter is configured to <b>Debug Recording Server</b>). The debug recording includes signaling, syslog messages, media, and PCM (voice signals from and to TDM).</li> <li>■ [4] <b>PSTN Trace</b> = The option is applicable only to debug recording (i.e., 'Log Destination' parameter is configured to <b>Debug Recording Server</b>) and if the 'Filter Type' parameter is configured to <b>Trunk ID</b>. The debug recording includes ISDN and CAS traces.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>✓ This option is applicable only to digital interfaces.</li> <li>✓ To capture traffic of all trunks, configure the 'Value' parameter (above) to "-1" (without quotation marks).</li> <li>✓ You must configure the trace level for the trunks that you want to trace. This is done using the 'Trace Level' parameter on the Trunk Settings page (see <a href="#">Configuring Trunk Settings</a> on page 850).</li> </ul> <ul style="list-style-type: none"> <li>■ [5] <b>CDR</b> = Only CDRs are generated. This option is applicable only when you configure the 'Log Destination' parameter to <b>Local Storage</b> or <b>OVOC (QoE)</b> for QoE reporting to OVOC.</li> <li>■ [6] <b>SIP Ladder</b> = The device sends SIP messages (in XML format), as they occur in real-time, to OVOC for displaying SIP call dialog sessions as call flow diagrams. For this functionality, you also need to configure the 'Log Destination' parameter to <b>OVOC (QoE)</b>. For enabling this functionality, see <a href="#">Enabling SIP Call Flow Diagrams in OVOC</a> on page 1531.</li> <li>■ [7] <b>SIP Only</b> = The option is applicable only to debug recording (i.e. the 'Log Destination' parameter is configured to <b>Debug Recording Server</b>). The debug recording includes only SIP messages.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ This parameter is not applicable if you configure the 'Log Destination' parameter to <b>Syslog Server</b>.</li> <li>■ For local storage of CDRs, configure the 'Log Destination'</li> </ul>

Parameter	Description
	<p>parameter to <b>Local Storage</b> and the 'Log Type' parameter to <b>CDR</b>.</p> <ul style="list-style-type: none"> <li>■ PSTN debug traces may affect performance.</li> <li>■ The parameter is not applicable when the 'Filter Type' parameter is configured to <b>IP Trace</b>.</li> <li>■ To include syslog messages in debug recording, it is unnecessary to enable syslog functionality.</li> </ul>
'Mode' mode [Mode]	<p>Enables and disables the rule.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b></li> <li>■ [1] <b>Enable</b> (Default)</li> </ul> <p><b>Note:</b> For debugging recording rules, you need to explicitly start the debug recording, as described in <a href="#">Starting and Stopping Debug Recording</a> on page 1512.</p>

## Filtering IP Network Traces using Wireshark-Like Expressions

You can filter syslog and debug recording messages for IP network traces, by configuring the 'Filter Type' parameter to **IP Trace** in the Logging Filters table.

IP traces record any IP stream, according to destination and/or source IP address, or port and Layer-4 protocol (UDP, TCP or any other IP type as defined by <http://www.iana.com>). Network traces are typically used to record HTTP.



Using IP traces is only intended for capturing non-media traffic (e.g., SIP and syslog); not media traffic (RTP/RTCP). Capturing only non-media traffic prevents device CPU overload under medium or high traffic. If you want to capture media traffic, configure the 'Filter Type' parameter to a different option (e.g., **Any**) instead of **IP Trace**.

When the **IP Trace** option is selected, only the 'Value' parameter is applicable in the Logging Filters table. This parameter configures Wireshark-like filtering expressions for your IP trace. The following Wireshark-like expressions are supported:

**Table 60-2: Supported Wireshark-like Expressions for 'Value' Parameter**

Expression	Description
and, &&, ==, <, >	Comparison operators used between expressions.
ip.addr	Defines IPv4 addresses (up to two) to capture.

Expression	Description
ip.dst	Defines the destination IPv4 address to capture.
ip.proto	Defines the IP protocol type (PDU) entered as an enumeration value (e.g., 1 is ICMP, 6 is TCP, and 17 is UDP) to capture.
ip.src	Defines the source IPv4 address to capture.
ipv6	Captures all IPv6 packets (source and destination).
ipv6.addr	Defines IPv6 addresses (up to two) to capture.
ipv6.dst	Defines the destination IPv6 address to capture.
ipv6.src	Defines the source IPv6 address to capture.
udp, tcp, icmp, sip, ldap, http, https	Defines single expressions of the protocol type to capture.
udp.dstport, tcp.dstport	Defines the transport layer of the destination port to capture.
udp.port, tcp.port	Defines the transport layer to capture.
udp.srcport, tcp.srcport	Defines the transport layer of the source port to capture.

The following are examples of configured expressions for the 'Value' parameter:

- `udp && ip.addr==10.8.6.55`
- `ip.src==10.8.6.55 && udp.port>=5000 and udp.port<6000`
- `ip.dst==10.8.0.1/16`
- `ip.addr==10.8.6.40`
- `ipv6.addr==2001:0db8:85a3:0000:0000:8a2e:0370:7334`
- `ipv6.src==2001:db8:abcd:0012::0/64`

For conditions requiring the "or" / "||" expression, add multiple rows in the Logging Filters table. For example, the Wireshark condition "ip.src == 1.1.1.1 or ip.src == 2.2.2.2" and "ip.dst == 3.3.3.3" can be done by adding two rows in the table, where the 'Value' parameter of each row has the following value:

- Index #0: 'Value' parameter is configured to "ip.src == 1.1.1.1 and ip.dst == 3.3.3.3" (without apostrophes)
- Index #1: 'Value' parameter is configured to "ip.src == 2.2.2.2 and ip.dst == 3.3.3.3" (without apostrophes)

## Logging Filters (2)

+ New Edit		Page 1 of 1		Show 10 records per page	
INDEX	FILTER TYPE	VALUE	LOG DESTINATION	LOG TYPE	MODE
0	IP Trace	ip.src == 1.1.1.1 and ip.dst == 3.3.3.3	Debug Recording Server		Enable
1	IP Trace	ip.src == 2.2.2.2 and ip.dst == 3.3.3.3	Debug Recording Server		Enable



- If you leave the 'Value' parameter empty, the device records all IP traffic types (IPv4 and IPv6).
- You can't configure the 'Value' parameter with both IPv4 and IPv6 addresses.
- You can't configure the 'Value' parameter with "ip.addr" or "udp/tcp.port" together with "ip.src/dst" or "udp/tcp.srcport/dstport". For example, the following is invalid:  
ip.addr==1.1.1.1 and ip.src==2.2.2.2
- You can't configure the 'Value' parameter with "ipv6.addr" or "udp/tcp.port" together with "ipv6.src/dst" or "udp/tcp.srcport/dstport". For example, the following is invalid:  
ipv6.addr==2001:0db8:85a3:0000:0000:8a2e:0370:7334 and  
ipv6.src==2001:db8:abcd:0012::0/64

## Filtering IP Network Traces by Ethernet Port or VLAN

By default, when you configure a log filter (in the Logging Filters table) for filtering syslog and debug recording messages for IP network traces ('Filter Type' parameter configured to **IP Trace**), the device records (traces) all the packets received and sent on all the device's physical Ethernet ports. However, you can change this by selecting a specific port, or VLAN ID.

### ➤ To filter IP network traces by Ethernet port, Ethernet Group or VLAN:

1. Make sure that you have configured a log filtering rule for IP traces in the Logging Filters table (see [Configuring Logging Filter Rules](#) on page 1470).
2. Open the Debug Recording page (**Troubleshoot** tab > **Troubleshoot** menu > **Logging** folder > **Debug Recording**).

#### IP TRACE

Recording Mode

All Physical Ethernet Port ▼

Physical Ethernet Port

None ▼

VLAN ID

• None ▼

3. From the 'Recording Mode' drop-down list, select one of the following:
  - **All Physical Ethernet Ports:** The log filter for the IP trace is applied on packets received and sent (tagged and untagged) on all the physical Ethernet ports.



- **Physical Ethernet Port:** The log filter for the IP trace is applied on packets received and sent on the specific Ethernet port selected in Step 4.
  - **VLAN ID:** The log filter for the IP trace is applied on packets received and sent on the specific VLAN (underlying Ethernet Device) selected in Step 5.
4. If you selected **Physical Ethernet Port** in Step 3, then from the 'Physical Ethernet Port' drop-down list, select the port. To view the device's Ethernet ports, see [Configuring Physical Ethernet Ports](#) on page 149.



The device has only one Ethernet port into its kernel software and therefore, the 'Physical Ethernet Port' field displays **None**. If you configure tunneling for the device, special tunneling ports are added to the kernel software and these are represented in the field as **Tunnel**.

5. If you selected **VLAN ID** in Step 3, then from the 'VLAN ID' drop-down list, select the VLAN. To configure VLANs (Ethernet Devices), see [Configuring Underlying Ethernet Devices](#) on page 154.



- The recording includes just packets of specific VLAN, but without the VLAN header.
- Untagged packets are not recorded.

6. Click **Apply**.

## Debugging PSTN Calls through CLI

You can also troubleshoot and debug digital (PSTN) calls through the device's CLI.



PSTN traces may affect performance.

- **To configure the debug (trace) level:** The debug (trace) level determines the level of information included in the PSTN trace. For all PSTN traces, the trace level is configured per PSTN interface, using the following command:

```
configure voip > interface {e1-t1} {Slot/Port} > trace-level {full-isdn|full-isdn-
with-duplications|layer3|layer3-no-duplications|no-trace|q921-raw-
data|q931|q931-q921-raw-data|q931-raw-data}
```

For example:

```
# configure voip
(config-voip)# interface e1-t1 1/1
(e1-t1 1/1)# trace-level full-isdn
```

- **To start a PSTN trace:**

- **Per Trunk:** Debugging per trunk is configured in the Logging Filters where there is an option to start and stop the trace:

```
(config-troubleshoot)# logging logging-filters <Table Row Index>
```

For more information on the Logging Filters table, see [Configuring Logging Filter Rules](#) on page 1470.



The trace level is configured using the `interface` command described in the beginning of this section.

- **All Trunks:** You can perform PSTN traces for all trunks for which you have configured trace levels (using the `interface` command described in the beginning of this section). To start the trace for all these trunks, use the following command:

```
# debug debug-recording <IP Address of Debug Recording Server> pstn-trace
```

- **To enable sending traces to syslog:** To send the PSTN traces to a syslog server, use the following command:

```
(config-troubleshoot)# pstn-debug on
```



If you send traces to a syslog server, you must configure the trace level to **q931-raw-data**.

## Configuring Syslog

This section describes how to configure syslog. To filter syslog messages, see [Configuring Logging Filter Rules](#) on page 1470.

### Syslog Message Format

The syslog message is sent from the device to a syslog server as an ASCII (American Standard Code for Information Interchange) message. Syslog uses UDP as its underlying transport layer mechanism. By default, UDP port 514 is assigned to syslog, but this can be changed (see [Enabling Syslog](#) on page 1490).

Syslog includes two types of log messages:

- **SIP Call Session Logs:** Logs relating to call sessions (e.g., call established). These logs are identified by a session ID ("SID"), described in detail in the table below. For example:

```
10:44:11.299 10.15.77.55 local0.notice [S=511941] [SID=50dcb2:31:12079]
(N 483455) ReleaseAddress. IPv4IF=1 IPv6IF=-1 Port=7500 [Time:10-
09@09:42:56.938]
```

- **Board Logs:** Logs relating to the operation of the device (infrastructure) that are non-call (SIP) session related (e.g., device restart or Web login). These logs are identified by a board ID ("BID"), described in detail in the table below. For example:

```
20:05:36.055 10.15.7.96 local0.notice [S=16] [BID=50dcb2:31] Activity Log:
Successful user login at 10.15.7.96:80. User: Admin. Session: Web
(10.13.2.19) [Time:12-03@17:00:58.781] [1108]
```

The format of the syslog message is described in the following table:

**Table 60-3: Syslog Message Format Description**

Message Item	Description
<b>Receive Timestamp</b>	<p>The syslog message includes a timestamp that the syslog server adds to indicate when it received the message.</p> <p>Example (in bold):</p> <pre>20:05:36.055 10.15.7.96 local0.notice [S=16] [BID=50dcb2:31] Activity Log: Successful user login at 10.15.7.96:80. User: Admin. Session: Web (10.13.2.19) [Time:12-03@17:00:58.781] [1108]</pre>
<b>IP Address</b>	<p>The syslog message includes the IP address of the device, which generated the message.</p> <p>Example (in bold):</p> <pre>20:05:36.055 10.15.7.96 local0.notice [S=16] [BID=50dcb2:31] Activity Log: Successful user login at 10.15.7.96:80. User: Admin. Session: Web (10.13.2.19) [Time:12-03@17:00:58.781] [1108]</pre>
<b>Severity Type</b>	<p>The syslog message includes the severity level with which it was generated (in the format &lt;FacilityCode.Severity&gt;).</p> <p>Example (in bold):</p> <pre>20:05:36.055 10.15.7.96 local0.notice [S=16] [BID=50dcb2:31] Activity Log: Successful user login at 10.15.7.96:80. User: Admin. Session: Web (10.13.2.19)</pre>

Message Item	Description
	<p data-bbox="571 309 1023 344">[Time:12-03@17:00:58.781] [1108]</p> <p data-bbox="550 389 1091 421">The severity level can be one of the following:</p> <ul data-bbox="550 445 1356 790" style="list-style-type: none"> <li data-bbox="550 445 1356 517">■ Error: Indicates that a problem has been identified that requires immediate handling.</li> <li data-bbox="550 542 1356 613">■ Warning: Indicates an error that might occur if measures are not taken to prevent it.</li> <li data-bbox="550 638 1219 669">■ Notice: Indicates that an unusual event has occurred.</li> <li data-bbox="550 694 1054 725">■ Info: Indicates an operational message.</li> <li data-bbox="550 750 1038 781">■ Debug: Messages used for debugging.</li> </ul> <p data-bbox="550 815 620 846"><b>Note:</b></p> <ul data-bbox="550 871 1390 1077" style="list-style-type: none"> <li data-bbox="550 871 1390 943">■ The Info and Debug severity messages are required only for advanced debugging. By default, the device doesn't send them.</li> <li data-bbox="550 967 1390 1077">■ Syslog messages displayed in the Web interface (see <a href="#">Viewing Syslog Messages</a> on page 1504) are color coded according to severity level.</li> </ul>
<p data-bbox="311 1122 429 1234"><b>Sequence Number (S=)</b></p>	<p data-bbox="550 1122 1396 1234">By default, the device sequentially numbers generated syslog messages (in the format <i>[S=&lt;number&gt;]</i>). A skip in the number sequence of messages indicates packet loss (i.e., a network issue).</p> <p data-bbox="550 1249 1366 1317">The following example shows two missing syslog messages, S=18 and S=19:</p> <div data-bbox="571 1361 1281 1514"> <p data-bbox="571 1361 1155 1393">20:05:36.055 10.15.7.96 local0.notice <b>[S=16]</b></p> <p data-bbox="571 1402 1281 1473">[BID=50dcb2:31] Activity Log: Successful user login at 10.15.7.96:80. User: Admin. Session: Web (10.13.2.19)</p> <p data-bbox="571 1482 1023 1514">[Time:12-03@17:00:58.781] [1108]</p> </div> <div data-bbox="571 1585 1281 1738"> <p data-bbox="571 1585 1155 1617">20:05:36.055 10.15.7.96 local0.notice <b>[S=17]</b></p> <p data-bbox="571 1626 1281 1697">[BID=50dcb2:31] Activity Log: Successful user login at 10.15.7.96:80. User: Admin. Session: Web (10.13.2.19)</p> <p data-bbox="571 1706 1023 1738">[Time:12-03@17:00:58.781] [1108]</p> </div> <div data-bbox="571 1809 1281 1962"> <p data-bbox="571 1809 1155 1841">20:05:36.055 10.15.7.96 local0.notice <b>[S=20]</b></p> <p data-bbox="571 1850 1281 1921">[BID=50dcb2:31] Activity Log: Successful user login at 10.15.7.96:80. User: Admin. Session: Web (10.13.2.19)</p> <p data-bbox="571 1930 1023 1962">[Time:12-03@17:00:58.781] [1111]</p> </div>

Message Item	Description
	<p><b>Note:</b> You can exclude the sequence number from syslog messages, by disabling the 'CDR Syslog Sequence Number' parameter (see <a href="#">Enabling Syslog</a> on page 1490).</p>
<b>Session ID (SID)</b>	<p>The SID is a unique SIP call session and device identifier. The device identifier facilitates debugging by clearly identifying the specific device that sent the log message, which is especially useful in deployments consisting of multiple devices. In addition, the benefit of unique numbering is that it enables you to filter information (such as SIP, syslog, and media) according to device or session ID.</p> <p>The syntax of the session and device identifiers is as follows:</p> <p><i>[SID=&lt;last 6 characters (3 lower bytes) of MAC address&gt;:&lt;number of times device has restarted&gt;:&lt;unique SID counter indicating the call session, which increments consecutively for each new session and resets to 1 after a device restart&gt;]</i></p> <p>Example (in bold):</p> <pre>10:44:11.299 10.15.77.55 local0.notice [S=511941] [SID=<b>50dcb2:31:12079</b>] (N 483455) ReleaseAddress. IPv4IF=1 IPv6IF=-1 Port=7500 [Time:10-09@09:42:56.938]</pre> <p>Where:</p> <ul style="list-style-type: none"> <li>■ <b>50dcb2</b> is the device's MAC address.</li> <li>■ <b>31</b> is the number of times that the device has restarted.</li> <li>■ <b>12079</b> is a unique SID session number (in other words, this is call session 12,079 since the last device restart).</li> </ul> <ul style="list-style-type: none"> <li>✓ Gateway application: A call session is considered as a Tel-to-IP leg or an IP-to-Tel leg, where each leg is assigned a unique session number.</li> <li>✓ SBC application: A session includes both the outgoing and incoming legs, where both legs share the same session number.</li> <li>✓ Forked legs and alternative legs share the same session number.</li> </ul>
<b>Startup Messages</b>	<p>Some syslog messages that are generated during a device restart (startup) include "[SUP]".</p> <p>Example (in bold):</p> <pre>03/19 12:43:43.539 10.4.4.65 local0.debug [S=93] [<b>SUP</b>]</pre>

Message Item	Description
	<pre>[BID=667402:93] CreateTpappSymbolTable(): symbol tables at 0x7f0a3006f038 [Time:19-03@21:44:35.084] [17]</pre>
<b>Board ID (BID)</b>	<p>Some syslog messages include a BID value. The BID is a unique non-SIP session related (e.g., device restart or a Trunk alarm) and device identifier. The BID value is similar to the SID (above), except that it doesn't contain the session ID. The device identifier facilitates debugging by clearly identifying the specific device that sent the log message, which is especially useful in deployments consisting of multiple devices. In addition, the benefit of unique numbering is that it enables you to filter information according to device.</p> <p>The syntax of the BID is as follows:</p> <p><i>[BID=&lt;last 6 characters (3 lower bytes) of MAC address&gt;:&lt;number of times device has restarted&gt;]</i></p> <p>Example (in bold):</p> <pre>20:05:36.055 10.15.7.96 local0.notice [S=16] <b>[BID=50dcb2:31]</b> Activity Log: Successful user login at 10.15.7.96:80. User: Admin. Session: Web (10.13.2.19) [Time:12-03@17:00:58.781] [1108]</pre> <p>Where:</p> <ul style="list-style-type: none"> <li>■ <i>50dcb2</i> is the device's MAC address.</li> <li>■ <i>31</i> is the number of times that the device has restarted.</li> </ul>
<b>Message Body</b>	<p>The syslog message includes a message body which describes the message.</p> <p>For example, the body (in bold) of the following syslog message indicates that the user logged out of the Web interface:</p> <pre>20:05:36.055 10.15.7.96 local0.notice [S=16] <b>[BID=50dcb2:31] Activity Log: Successful user login at</b> <b>10.15.7.96:80. User: Admin. Session: Web (10.13.2.19)</b> [Time:12-03@17:00:58.781] [1108]</pre>
<b>Transmit Timestamp</b>	<p>Some syslog messages include a timestamp that indicates when the device sent the syslog message. This timestamp is typically only included in syslog messages that are related to the device's software application.</p> <p>Example (in bold):</p>

Message Item	Description
	<pre>20:05:36.055 10.15.7.96 local0.notice [S=16] [BID=50dcb2:31] Activity Log: Successful user login at 10.15.7.96:80. User: Admin. Session: Web (10.13.2.19) [Time:12-03@17:00:58.781] [1108]</pre>
<b>Sequence Number per Process</b>	<p>The syslog message includes a sequence number per application process. This number appears at the end of the syslog message. A skip in the number indicates an internal (not network issue) loss of message (s) by the device's application process (i.e., didn't send the message, for whatever reason). This number is typically used by AudioCodes for debugging.</p> <p>Example (in bold):</p> <pre>20:05:36.055 10.15.7.96 local0.notice [S=16] [BID=50dcb2:31] Activity Log: Successful user login at 10.15.7.96:80. User: Admin. Session: Web (10.13.2.19) [Time:12-03@17:00:58.781] [<b>1108</b>]</pre> <p><b>Note:</b> The sequence number only appears in syslog messages that relate to the device's application process.</p>

### Event Representation in Syslog Messages

The device denotes events in syslog message using unique abbreviations, as listed in the following table. For example, if an invalid payload length event occurs, the syslog message uses the abbreviated event string "IP":

```
Apr 4 12:00:12 172.30.1.14 IP:5 [Code:0x5004] [CID:3294] [Time: 20:17:00]
```



For syslog messages sent for packet loss events, see [Packet Loss Indication in Syslog](#) on page 1509.

**Table 60-4: Syslog Error Event Abbreviations**

Error Abbreviation	Error Name Description
<b>AA</b>	Invalid Accumulated Packets Counter
<b>AC</b>	Invalid Channel ID
<b>AL</b>	Invalid Header Length

Error Abbreviation	Error Name Description
<b>AO</b>	Invalid Codec Type
<b>AP</b>	Unknown Aggregation Payload Type
<b>AR</b>	Invalid Routing Flag Received
<b>AT</b>	Simple Aggregation Packets Lost
<b>CC</b>	Command Checksum Error
<b>CE</b>	Invalid Cell Coder Code
<b>CS</b>	Command Sequence Error
<b>ES</b>	8 sec Timeout Before Disconnect
<b>HO</b>	Host Received Overrun
<b>IA</b>	Invalid AMR Payload
<b>IC</b>	Invalid CID Error
<b>IG</b>	Invalid G723 Code
<b>IP</b>	Invalid payload length
<b>IR</b>	Invalid RTCP Packet
<b>IS</b>	Invalid SID Length
<b>LC</b>	Transmitter Received Illegal Command
<b>LF</b>	Lost Fax Frames In High Speed Mode
<b>LM</b>	Lost Modem Frames In High Speed Mode
<b>MI</b>	Misalignment Error
<b>MR</b>	Modem Relay Is Not Supported
<b>PD</b>	RTP Packet Duplicated
<b>OR</b>	DSP JB Overrun
<b>PH</b>	Packet Header Error
<b>RB</b>	Counts the number of BFI Frames Received From The Host



Error Abbreviation	Error Name Description
<b>RD</b>	No Available Release Descriptor
<b>RO</b>	RTP Reorder
<b>RP</b>	Unknown RTP Payload Type
<b>RS</b>	RTP SSRC Error
<b>UF</b>	Unrecognized Fax Relay Command

### Syslog Fields for Answering Machine Detection (AMD)

The syslog message can include information relating to the Answering Machine Detection (AMD) feature. AMD is used to detect whether a human (including a fax machine), an answering machine, silence, or answering machine beeps have answered the call on the remote side.

The syslog message includes the following AMD-related fields:

■ **AMDSignal:** This field can have one of the following values:

- "V" - voice
- "A" - answer machine
- "S" - silence
- "U" - unknown

■ **AMDDecisionProbability:** The probability (in %) success that the correct answering type was detected.

The following shows an example of a syslog message with AMD information:

```
CallMachine:EVENT_DETECTED_EV - AMDSignal = <type - V/A/S/U>,
AMDDecisionProbability = <percentage> %
```

If there is no AMD detection, the AMDSignal field is shown empty ("AMDSignal = ").

For more information on the AMD feature, see [Answering Machine Detection \(AMD\)](#) on page 304.

### SNMP Alarms in Syslog Messages

SNMP alerts are sent to the syslog server using the following formats:

■ **Raised Alarms:** RAISE-ALARM: <Alarm Name>; Textual Description: <Textual Description>; Severity <Alarm Severity>; Source <Alarm Source>; Unique ID: <Alarm Unique ID >.

If additional information exists in the alarm, then these are also added: Additional Info1:/ Additional Info2:/ Additional Info3

The Messages' Severity is as follows:

**Table 60-5: Syslog Message Severity**

ITU Perceived Severity (SNMP Alarm's Severity)	AudioCodes Syslog Severity
Critical	RecoverableMsg
Major	RecoverableMsg
Minor	RecoverableMsg
Warning	Notice
Indeterminate	Notice
Cleared	Notice

- **Cleared Alarms:** CLEAR-ALARM: <Alarm Name>; Textual Description: <Textual Description>; Severity <Alarm Severity>; Source <Alarm Source>; Unique ID: <Alarm Unique ID >; If exists Additional Info1:/ Additional Info2:/ Additional Info3:

## Enabling Syslog

To use syslog, you first need to enable it.

### ➤ To enable syslog:

1. Open the Logging Settings page (**Troubleshoot** menu > **Troubleshoot** tab > **Logging** folder > **Logging Settings**).
2. Select the 'Enable Syslog' check box:

Enable Syslog



3. Click **Apply**.

## Configuring the Primary Syslog Server Address

This section describes how to configure the "primary" syslog server to where you want the device to send its generated syslog messages.



- To enable the device to send syslog messages, you **MUST** also configure the 'VoIP Debug Level' parameter to **Basic** or **Detailed** (see [Configuring Syslog Debug Level](#) on page 1501).
- In addition to configuring a "primary" syslog server, you can configure "secondary" syslog servers (see [Configuring Secondary Syslog Servers](#) on the next page). The device sends the syslog messages to all configured servers ("primary" and "secondary").
- Unless you configure a dedicated CDR server address (see [Enabling CDR Generation and Configuring the CDR Server Address](#) on page 1382), the syslog server is also used as the CDR server. The syslog server's port number, transport protocol and IP Interface settings then also apply to the CDR server.

➤ **To configure the primary syslog server address:**

1. Open the Logging Settings page (**Troubleshoot** menu > **Troubleshoot** tab > **Logging** folder > **Logging Settings**).
2. Configure the syslog address parameters:
  - a. From the 'Syslog Network Interface Name' drop-down list, select the IP Interface from the IP Interfaces table (see [Configuring IP Network Interfaces](#) on page 157) for communication with the syslog server.
  - b. In the 'Server IP Address' field [SyslogServerIP], enter the address (IPv4 or IPv6 address, or FQDN) of the syslog server.
  - c. In the 'Server Port' field, enter the port of the syslog server.

Syslog Network Interface Name	• #0 [O+M+C] ▼	<a href="#">View</a>
Server IP Address	<input type="text" value="0.0.0.0"/>	
Server Port	<input type="text" value="514"/>	



The IP address version (IPv4 or IPv6) of the IP Interface ('Syslog Network Interface Name') and the syslog server's address ('Server IP Address') must be the same.

3. From the 'Syslog Protocol' drop-down list, select the transport protocol. By default, the device uses the UDP transport protocol for communication with the syslog server. You can change this to TCP or TLS.

Syslog Protocol	• TLS ▼
-----------------	---------

4. If you selected **TLS** as the transport protocol in the previous step, you need to select a TLS Context from the 'Syslog TLS Context' drop-down list:

## Syslog TLS Context



To configure TLS Contexts, see [Configuring TLS Certificate Contexts](#) on page 224.

5. Click **Apply**.

## Configuring Secondary Syslog Servers

In addition to (or instead of) configuring a "primary" syslog server (see [Configuring the Primary Syslog Server Address](#) on page 1490), you can use the Syslog Servers table to configure up to four "secondary" syslog servers to where you want the device to send syslog messages. The device sends the syslog messages to all configured servers ("primary" and "secondary").

You can also configure the device's embedded syslog (Rsyslog) client to send event logs (syslog messages) to Apache Kafka, an open-source platform for event streaming. As a Kafka *producer*, the device transmits syslog messages to the remote Kafka *broker*. The broker can be on a local server or hosted on the cloud.

The Kafka broker manages one or more *topics*, which act like categories for classifying syslog messages. Multiple applications or services (Kafka *consumers*) can subscribe to these topics and receive the syslog messages. When multiple Kafka topics exist, you would need to configure multiple Kafka-based syslog servers with the same address for the Kafka broker in the Syslog Servers table. However, each syslog server would be configured with a different Kafka topic name, and different information type and / or severity level.



- To enable the device to send syslog messages, you **MUST** also configure the 'VoIP Debug Level' parameter to **Basic** or **Detailed** (see [Configuring Syslog Debug Level](#) on page 1501).
- The syslog servers are also used as CDR servers, unless you configure a dedicated CDR server address as described in [Enabling CDR Generation and Configuring the CDR Server Address](#) on page 1382.
- Configuring duplicated secondary syslog servers with the same address and port is invalid.
- Configuring duplicated secondary syslog servers with the same address and port as the primary syslog server is invalid.
- The syslog sequence number resets if the device restarts.

The following procedure describes how to configure secondary syslog servers through the Web interface. You can also configure it through ini file [SyslogServers] or CLI (`configure troubleshoot > syslog > syslog-servers`).

### ➤ To configure secondary syslog servers:

1. Open the Syslog Servers table (**Troubleshoot** menu > **Logging** folder > **Syslog Servers**).
2. Click **New**; the following dialog box appears:

Syslog Servers - x


GENERAL

Index	<input type="text" value="1"/>
Address	<input type="text" value="0.0.0.0"/>
Kafka Topic	<input type="text"/>
Kafka Connection String	<input type="text"/>
Port	<input type="text" value="514"/>
Transport Protocol	<input type="text" value="UDP"/>
Interface	<input type="text" value="--"/> <a href="#" style="color: #0070C0; text-decoration: none;">View</a>
Information Type	<input type="text" value="All"/>
Severity Level	<input type="text" value="Notice"/>
Mode	<input type="text" value="Enable"/>

3. Configure a secondary syslog server according to the parameters described in the table below.
4. Click **Apply**.

Table 60-6: Syslog Servers Parameter Descriptions

Parameter	Description
'Index'	<p>Defines an index number for the new table row.</p> <p><b>Note:</b> Each row must be configured with a unique index.</p>
'Address ' ip-address [Address]	<p>Defines the address of the syslog server.</p> <p>The valid value depends on the type of syslog server:</p> <ul style="list-style-type: none"> <li>■ <b>Regular syslog server:</b> IP address (IPv4 or IPv6) or an FQDN.</li> <li>■ <b>Kafka broker:</b> FQDN of the Kafka broker name. When the Kafka broker is hosted on Microsoft Azure, the FQDN</li> </ul>

Parameter	Description
	<p>is the namespace of the Event Hub.</p> <p>The default is 0.0.0.0.</p>
<p>'Kafka Topic'</p> <p>kafka-topic-name</p> <p>[Topic]</p>	<p>Defines the Kafka topic name.</p> <p>When the Kafka broker is hosted on Microsoft Azure, the topic name is the Event Hub namespace.</p> <p>By default, no value is defined.</p> <p><b>Note:</b> The parameter is applicable only when the syslog server is a Kafka broker.</p>
<p>'Kafka Connection String'</p> <p>kafka-connection-string</p> <p>[ConnectionString]</p>	<p>Defines the authentication string (password) for connecting to the Kafka broker (topic).</p> <p>When configured, the device encrypts the syslog messages.</p> <p>The figure below shows where you can copy the connection string from for the Kafka broker's topic in Azure Event Hubs:</p>  <p>By default, no value is defined, which means that Kafka communication is over TCP.</p>

Parameter	Description
	<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only when the syslog server is a Kafka broker.</li> <li>■ The parameter is mandatory if the Kafka broker is hosted on Microsoft Azure (Event Hub).</li> <li>■ If you configure the parameter, you must also select a TLS Context (using the 'Syslog TLS Context' parameter, as described in <a href="#">Configuring the Primary Syslog Server Address</a> on page 1490).</li> </ul>
<p>'Port'</p> <p>port</p> <p>[Port]</p>	<p>Defines the syslog server's port number. The default is 514.</p> <p><b>Note:</b> When the Kafka broker is hosted on Microsoft Azure, configure the port to 9093.</p>
<p>'Transport Protocol'</p> <p>protocol</p> <p>[Protocol]</p>	<p>Defines the transport protocol for communicating with the syslog server.</p> <ul style="list-style-type: none"> <li>■ [0] <b>UDP</b> (default)</li> <li>■ [1] <b>TCP</b></li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [2] <b>TLS</b></li> <li>■ [3] <b>Kafka</b></li> </ul> <p><b>Note:</b> You also need to select a TLS Context (using the 'Syslog TLS Context' parameter, as described in <a href="#">Configuring the Primary Syslog Server Address</a> on page 1490) for the following settings:</p> <ul style="list-style-type: none"> <li>■ If you configure the parameter to <b>TLS</b>.</li> <li>■ If you configure the parameter to <b>Kafka</b> and you configure a value for the 'Kafka Connection String' parameter.</li> </ul>
'Interface' interface [Interface]	<p>Assigns an IP Interface from the IP Interfaces table (see <a href="#">Configuring IP Network Interfaces</a> on page 157) for communication with the syslog server.</p> <p>By default, no value is defined, which means that the device uses the IPv4 OAMP network interface.</p> <p><b>Note:</b> The address version (IPv4 or IPv6) of the IP Interface and the syslog</p>



Parameter	Description
	server's address (see 'Address' parameter above) must be the same.
'Information Type' info-type [InfoType]	<p>Defines the type of information that the device sends in syslog messages to the remote syslog server.</p> <ul style="list-style-type: none"> <li>■ [0] <b>All</b> = (Default) Sends all below options.</li> <li>■ [1] <b>CDR</b> = Sends only CDRs.</li> <li>■ [2] <b>SDR</b> = Sends only SDRs.</li> <li>■ [3] <b>Syslog</b> = Sends only syslogs.</li> </ul>
'Severity Level' severity-level [SeverityLevel]	<p>Defines the minimum severity level of messages included in the syslog message that the device sends to the syslog server.</p> <p>The severity levels in the list below are in descending order (from highest to lowest). Only the selected severity level and all higher severity levels are included in syslog messages. For example, if you configure the parameter to <b>Alert</b>, the syslog includes only alert ("alert") and emergency</p>

Parameter	Description
	<p>("emerg") messages.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Emergency</b></li> <li>■ [1] <b>Alert</b></li> <li>■ [2] <b>Critical</b></li> <li>■ [3] <b>Error</b></li> <li>■ [4] <b>Warning</b></li> <li>■ [5] <b>Notice</b> (default)</li> <li>■ [6] <b>Info [not recommended]</b></li> <li>■ [7] <b>Debug [not recommended]</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ It's recommended to leave the syslog severity level at default (i.e., <b>Notice</b>) to prevent excessive utilization of the device's resources. Changing severity level is typically done only by AudioCodes Support for debugging.</li> <li>■ Upon a device restart or HA switchover, the parameter restores to default (i.e., <b>Notice</b>).</li> <li>■ To view the corresponding</li> </ul>

Parameter	Description
	strings used in syslog messages for indicating severity levels, see <a href="#">Configuring Syslog Message Severity Level</a> below.
'Mode' mode [Mode]	<p>Activates or deactivates the syslog server.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) The device doesn't send syslog messages to the configured syslog server.</li> <li>■ [1] <b>Enable</b> = The device sends syslog messages to the configured syslog server.</li> </ul>

## Configuring Syslog Message Severity Level

You can configure the minimum severity level of messages that you want to include in syslog messages that are generated by the device. The severity levels are described in the following table.



- It's strongly recommended to leave the syslog severity level at default (i.e., Notice) to prevent excessive utilization of the device's resources. Changing severity level is typically done only by AudioCodes Support for debugging.
- Upon a device restart or HA switchover, the syslog severity level returns to default.
- You can also configure syslog severity levels per syslog server (see [Configuring Secondary Syslog Servers](#) on page 1492).

Severity Level (Lowest to Highest)	Syslog String	Description
[7] <b>Debug</b>	"debug"	Debug message.
[6] <b>Info</b>	"info"	An operational message.
[5] <b>Notice</b> (default)	"notice"	An unusual event has occurred.
[4] <b>Warning</b>	"warning"	An error that might occur if measures are not taken to prevent it.
[3] <b>Error</b>	"error"	An error has been identified.
[2] <b>Critical</b>	"crit"	A problem has been identified that is critical.
[1] <b>Alert</b>	"alert"	A problem has been identified and an action must be taken immediately to resolve it.
[0] <b>Emergency</b>	"emerg"	A panic condition (system is unstable).


The specified severity level and all higher severity levels are included in the syslog message. For example, if you configure the parameter to **Alert**, the syslog includes messages with **Alert** severity level and messages with **Emergency** severity level.

When viewing syslog messages in the Web interface (see [Viewing Syslog Messages](#) on page 1504), each severity level is displayed in a different color.

➤ **To configure the minimum message severity level to include in syslog:**

1. Open the Logging Settings page (**Troubleshoot** menu > **Troubleshoot** tab > **Logging** folder > **Logging Settings**).
2. From the 'Log Severity Level' [SyslogLogLevel] drop-down list, select the severity level.

**Log Severity Level**



3. Click **Apply**.

## Configuring Syslog Debug Level

You can configure the amount of information (debug level) to include in syslog messages. You can also enable the device to send multiple syslog messages bundled into a single packet, and enable a protection mechanism that automatically lowers the debug level when the device's CPU resources become low, ensuring sufficient CPU resources are available for processing voice traffic.

### ➤ To configure syslog debug level:

1. Open the Logging Settings page (**Troubleshoot** menu > **Troubleshoot** tab > **Logging** folder > **Logging Settings**).
2. From the 'VoIP Debug Level' [GwDebugLevel] drop-down list, select the debug level of syslog messages:
  - **No Debug:** Disables syslog and no syslog messages are sent.
  - **Basic:** Sends debug logs of incoming and outgoing SIP messages.
  - **Detailed:** Sends debug logs of incoming and outgoing SIP message as well as many other logged processes.

VoIP Debug Level • Basic ▼

3. Select the 'Optimization' check box [SyslogOptimization] to enable the device to accumulate and bundle multiple debug messages into a single UDP packet before sending it to a syslog server. The benefit of this feature is that it reduces the number of UDP syslog packets, thereby improving (optimizing) CPU utilization. The size of the bundled message is configured by the [MaxBundleSyslogLength] parameter.

Optimization • ☒

4. Select the 'CPU Protection' check box [SyslogCpuProtection] to enable the protection feature for the device's CPU resources during debug reporting, ensuring voice traffic is unaffected. If CPU resources drop (i.e., high CPU usage) to a critical level (user-defined threshold), the device automatically lowers the debug level to free up CPU resources that were required for the previous debug-level functionality. When CPU resources become available again, the device increases the debug level to its' previous setting. For example, if you set the 'Debug Level' to **Detailed** and CPU resources decrease to the defined threshold, the device automatically changes the level to **Basic**, and if that is not enough, it changes the level to **No Debug**. Once CPU resources are returned to normal, the device automatically changes the debug level back to its' original setting (i.e., **Detailed**). The threshold is configured by the [DebugLevelHighThreshold] parameter.

CPU Protection ☒

5. Click **Apply**.

## Reporting Management User Activities

You can enable the device to log various operations (actions) done by management users in the device's management interfaces (e.g., Web and CLI). The actions are logged in the Activity Log and sent in syslog messages. You can also view these logged user activities in the CLI and Web interface (see [Viewing Management User Activity Logs](#) on page 1328).

The logged actions are indicated in syslog messages with the string "Activity Log":

```
14:07:46.300 : 10.15.7.95 : Local 0 :NOTICE : [S=3149] [BID=3aad56:32]
Activity Log: <Message>. User: <User>. Session: <Protocol> (<IP Address>)
[Time:dd-mm@hh:mm:ss.sss]
```

Where:

- **<Message>** describes the performed action.
- **<User>** is the username of the user (e.g., "Admin") that performed the action.
- **<Protocol>** is the protocol that was used to access the management interface (e.g., Web or Telnet).
- **<IP Address>** is the IP address of the client PC from where the user accessed the device's management interface.
- **Time** is the date and time that the action was performed.

The device can report the following types of user activities:

- Modifications of individual parameters, for example:

```
16:19:24.983 10.15.7.96 local0.notice [S=7] [BID=5b1035:7] Activity Log:
No Answer Timeout [sec] was changed from '600' to '550'. User: Admin.
Session: WEB (10.13.2.3) [Time:07-09@16:39:22.736]
```

- Modifications of table fields, and addition and deletion of table rows, for example:

```
16:22:54.287 10.15.7.96 local0.notice [S=16] [BID=5b1035:7] Activity Log:
Classification - remove line 2. User: Admin. Session: HTTP (10.13.2.3)
[Time:07-09@16:39:22.736]
```

```
16:22:54.287 10.15.7.96 local0.notice [S=16] [BID=5b1035:7] Activity Log:
Local Users Table row 1 (MyUser) - 'User Level' was changed from
'Administrator' to 'Security Administrator'. User: Admin. Session: WEB
(10.13.2.3) [Time:07-09@16:39:22.736]
```

- Modifications of parameters due to an incremental ini file upload. If you choose this option, you can also define the maximum number of lines of parameters to log from the ini file, using the 'Incremental INI Activity Logs Max Number' parameter.
- Entered CLI commands (modifications of security-sensitive commands are logged without the entered value).
- Configuration file upload (reported without per-parameter notifications).
- Auxiliary file upload and software update.
- File download (ini file, CLI Script file and Configuration Package file).
- Device restart and save to flash memory.
- Access to unauthorized Web pages according to the Web user's access level.
- Modifications of "sensitive" parameters.
- Log in and log out, for example:

```
16:15:56.946 10.15.7.96 local0.notice [S=3] [BID=5b1035:7] Activity Log:  
WEB: Successful login at 10.15.7.96:80. User: Admin. Session: WEB  
(10.13.2.3) [Time:07-09@16:39:22.736]
```

```
16:16:14.714 10.15.7.96 local0.notice [S=5] [BID=5b1035:7] Activity Log:  
Unauthorized access attempt to Login Page. Reason: bad credentials.  
User: Admin. Session: WEB (10.13.2.3) [Time:07-09@16:39:22.736]
```

- Actions not related to parameter changes (for example, file uploads and downloads, file delete, lock-unlock maintenance actions, LDAP clear cache, register-unregister, and start-stop trunk). In the Web, these actions are typically done by clicking a button (e.g., the LOCK button).

For more information on each of the above listed options, see [Syslog, CDR and Debug Parameters](#) on page 1624.

The following procedure describes how to configure management user activity logging through the Web interface. You can also configure it through ini file [ActivityListToLog] or CLI (configure troubleshoot > activity-log).

➤ **To configure reporting of management user activities:**

1. Open the Logging Settings page (**Troubleshoot** tab > **Troubleshoot** menu > **Logging** folder > **Logging Settings**).
2. Under the Activity Types to Report group, select the actions to report to the syslog server. For all activity types, select the 'Select All' check box.


## ACTIVITY TYPES TO REPORT

Select All ☐Parameters Value Change ☐Auxiliary Files Loading ☐Device Restart ☐Flash Memory Burning ☐Device Software Upgrade ☐Non-Authorized Access ☐Sensitive Parameters Value Change ☐Login and Logout ☐CLI Activity ☐Action Executed ☐Incremental INI ☐Incremental INI Activity Logs Max Number 3. Click **Apply**.

- Logging of CLI commands can only be configured through CLI (`configure troubleshoot > activity-log`) or ini file.
- You can configure the device to send an SNMP trap each time a user performs an action. For more information, see [Enabling SNMP Traps for Web Activity](#) on page 113.
- Passwords are hidden (by asterisks \*) in the Activity Log.

## Viewing Syslog Messages

You can view syslog messages generated by the device using any of the following syslog server types:

- **Device's Web Interface:** The device provides an embedded syslog server, which is accessed through the Web interface (**Troubleshoot** tab > **Troubleshoot** menu > **Message Log** ). You can select the syslog messages displayed on the page, and then copy-and-paste them into a text editor such as Notepad. This text file (*txt*) can then be sent to AudioCodes support team for diagnosis and troubleshooting.



## Message Log

```

Aug 13 16:19:19 local0.notice [S=7782952] [BID=Sb1035:19] Opening Log Web Page - printing error messages sent to Syslog [Code:0x40529]
Aug 13 16:19:19 local0.notice [S=7782951] [SID=Sb1035:19:246258] ( sip_stack) ( 7459456) SIPTransaction(#290)::SendMsgBuffer -
Aug 13 16:19:19 local0.notice [S=7782950] [SID=Sb1035:19:246258] ( sip_stack) ( 7459455) UdpRtxMgr::Transmit 1 OPTIONS Rtx Le:
Aug 13 16:19:18 local0.warn [S=7782949] [BID=Sb1035:19] SNMP Authentication Failure - source: IP = 172.17.118.219, Port = 1161, failed
Aug 13 16:19:18 local0.notice [S=7782948] [SID=Sb1035:19:246257] ( sip_stack) ( 7459454) SIPTransaction(#313)::SendMsgBuffer -
Aug 13 16:19:18 local0.notice [S=7782947] [SID=Sb1035:19:246257] ( sip_stack) ( 7459453) UdpRtxMgr::Transmit 1 OPTIONS Rtx Le:
Aug 13 16:19:18 local0.notice [S=7782946] [SID=Sb1035:19:246258] OPTIONS sip:10.15.7.96 SIP/2.0
Via: SIP/2.0/UDP 10.15.7.96:5060;branch=z9hG4bKac1759650396
Max-Forwards: 70
From: <sip:10.15.7.96>;tag=lc455863529
To: <sip:10.15.7.96>
Call-ID: 2306087331382018161918@10.15.7.96
CSeq: 1 OPTIONS

```

Start Stop Clear

The displayed logged messages are color-coded based on message type:

- "notice": Dark green
- "error", "crit", "alert", "emerg": Red
- "debug": Black
- "info": Blue
- "warn": Magenta

The page provides various buttons to do the following actions:

**Table 60-7: Buttons on Message Log Page**

Button	Description
<b>Start</b>	Resumes the message log after it has been stopped (see the <b>Stop</b> button).
<b>Stop</b>	Stops the message log, allowing you to easily scroll through the messages to a specific message.
<b>Clear</b>	<p>Clears the message log. The button can only be clicked after you have stopped the message log (see the <b>Stop</b> button).</p> <p><b>Note:</b> If you navigate away from the Message Log page to another page, the Message Log is stopped and cleared.</p>



- It's not recommended to keep a Message Log session open for a prolonged period. This may cause the device to overload. For prolonged (and detailed) debugging, use an external syslog server.
- The Message Log page provides limited syslog server functionality.

- **Device's Serial Console:** You can enable the device to also send the syslog messages to the serial console (over the device's physical serial interface). This may be useful, for example, if you no longer have network access to the device and you would like to perform

diagnostics. To enable this feature, configure the [EnableConsoleLog] parameter to 1, and then restart the device.

- **Device's CLI:** The device sends error messages (e.g., syslog messages) to the CLI as well as to the configured destination.

- To start debug recording:

```
debug log
```

- To stop debug recording:

```
no debug log
```

- To stop all debug recording:

```
no debug log all
```

- **Wireshark:** Third-party, network protocol analyzer (<http://www.wireshark.org>).

- **AudioCodes Syslog Viewer:** This utility can be used for two major tasks:

- Recording and displaying syslog messages from the device
- Analyzing recorded logs (including support for interactive SIP ladder diagrams)

To obtain the Syslog Viewer installation file, download it from <https://www.audiocodes.com/library/firmware>.

Figure 60-1: Example of Syslog Messages in Syslog Viewer





Figure 60-2: Example of SIP Ladder Diagram in Syslog Viewer



- **Third-party, Syslog Server:** Any third-party, syslog server program that enables filtering of messages according to parameters such as priority, IP sender address, time, and date.

## Syslog Message Description for CPU Overload

Whenever the device detects a CPU overload, it sends a syslog message that shows CPU utilization of the different processes (tasks) per core. This information can help in identifying the cause of the overload. When the device detects a CPU overload, it sends a syslog message every 10 seconds until it returns to normal state.



You can also view CPU utilization through the CLI, by using the following command:  
show system utilization

The figure below shows an example of a syslog message generated because of a CPU overload. CPU utilization information is shown under the "CPUUtilMonitor" section (shown in pink). The subsequent table describes the displayed information.

```

CPUUtilMonitor: System CPU overload condition [Core 0/96] (CPU Util=98%; period=1000 [msec])
CPU utilization task report (monitored period=1000 [msec]; total=1000 [msec]) [File:CPUUtiliz
  Name(TID) Core Usage[ms] Usage[%] ( Total[ms] (%) Peak[ms] #Switch) [File:CPUUtilize.cpp
Task BKGR( 47)  0   952 ms   95.2% (  952 ms 95.2%   1 ms  1863) [File:CPUUtilize.cpp
Task TLSA( 21)  0    8 ms    0.8% (    8 ms 0.8%   0 ms   975) [File:CPUUtilize.cpp
Task DSPD( 11)  0    7 ms    0.7% (    7 ms 0.7%   0 ms   201) [File:CPUUtilize.cpp
Task LPPT( 40)  0    0 ms    0.0% (    0 ms 0.0%   0 ms    1) [File:CPUUtilize.cpp
Task cli0( 42)  0    0 ms    0.0% (    0 ms 0.0%   0 ms    1) [File:CPUUtilize.cpp
Task STWR( 30)  0    0 ms    0.0% (    0 ms 0.0%   0 ms    1) [File:CPUUtilize.cpp
OS CPU Statistics Report [File:ErrorHandler.cpp Line:1946] [Time:13-02@12:20:00.040]
CPU#  User Nice System Idle IOWait IRQ SoftIRQ [File:ErrorHandler.cpp Line:1946] [Time:13-02
cpu   4%   0%   2% 92%   0%  0%   0% [File:ErrorHandler.cpp Line:1946] [Time:13-02@
cpu0  4%   0%   6% 87%   0%  0%   0% [File:ErrorHandler.cpp Line:1946] [Time:13-02
cpu1  0%   0%   0% 99%   0%  0%   0% [File:ErrorHandler.cpp Line:1946] [Time:13-02
cpu2  7%   0%   1% 90%   0%  0%   0% [File:ErrorHandler.cpp Line:1946] [Time:13-02
cpu3  7%   0%   1% 90%   0%  0%   0% [File:ErrorHandler.cpp Line:1946] [Time:13-02

```

**Table 60-8: CPU Overload Fields Description in Syslog Message**

Field	Description
First line (shown in pink)	
"Core"	Index of the CPU core.
"CPU Util"	CPU utilization (in percentage).
"period"	Total period (in msec).
Second line	
"monitored period"	Duration (in msec) of CPU overload within the total monitored period.
"total"	Monitored period (in msec).
Statistics per task (process) in overloaded cores only <b>Note:</b> By default, the syslog message only shows the five most used tasks in the last period.	
"Name (TID)"	Name of task (process).
"Core"	Index of the CPU core.
"Usage [ms]"	Total time (msec) of monitored period that the task utilized CPU.
"Usage [%]"	Percentage of time of monitored period that the task utilized

Field	Description
	CPU.
"Total [ms (%)]"	Total time (in msec) and percentage that task utilized CPU during entire period.
"peak [ms]"	Maximum lasting time (msec) that the task utilized CPU during the period.
"#Switch"	Context switch time - number of consecutive periods that were allocated for this task.
Statistics per CPU core	
"CPU#"	Index of the CPU core.
"User"	Percentage of CPU utilization that occurred while executing at the user level (application).
"Nice"	Percentage of CPU utilization that occurred while executing at the user level with nice priority (Linux systems).
"System"	Percentage of CPU utilization that occurred while executing at the system level (kernel).
"Idle"	Percentage of time that the CPU was idle (%) during which no tasks were using the CPU core.
"IOWait"	Percentage of time that the CPU was idle (5) during which tasks were using the CPU core.
"IRQ"	IRQ time (in percentage).
"SoftIRQ"	SoftIRQ time (in percentage%).

## Packet Loss Indication in Syslog

The device reports packet loss (PL) of incoming (Rx) RTP media streams (calls) in 15-second intervals. The device obtains packet loss statistics from the RTCP of the RTP streams. When packet loss occurs in the 15-second interval, at the end of the interval the device sends a syslog message with Warning severity level, indicating this packet loss. The syslog indicates the number of calls that experienced packet loss per packet loss range (in percentage) during the interval. It also indicates the number of calls that didn't have packet loss. If no packet loss occurred in all the RTP streams in the 15-second interval, no syslog message is sent.

Below shows an example of a syslog message sent when packet loss occurred in the 15-second interval. This syslog indicates that 6 calls were active during the interval. One call had no packet loss, 3 calls had 1 to 2% packet loss, and 2 calls had 5 to 100% packet loss:

```
16:47:13.921 192.168.8.70 local0.warn [S=2116] [BID=884772:92] Packets-Loss  
report [PL range]=#media-legs: [No PL]=1, [up to 0.5%]=0, [0.5% - 1%]=0, [1% -  
2%]=3, [2% - 5%]=0, [5% - 100%]=2 [[Time:28-12@00:40:18.550|time:28-  
12@00:40:18.550]]
```

Below shows the default packet-loss ranges in the syslog:

- [No PL]: Indicates the number of calls without packet loss.
- [up to 0.5%]: Indicates the number of calls with up to 0.5% packet loss. This packet loss typically has no effect on voice quality.
- [0.5% - 1%]: Indicates the number of calls with 0.5 to 1% packet loss. This packet loss typically has no effect on voice quality.
- [1% - 2%]: Indicates the number of calls with 1 to 2% packet loss. This packet loss may affect voice quality for calls using certain vocoders.
- [2% - 5%]: Indicates the number of calls with 2 to 5% packet loss. This packet loss affects voice quality and typically indicates a network problem.
- [5% - 100%]: Indicates the number of calls with 5 to 100% packet loss. This packet loss affects voice quality and typically indicates a network problem.

You can change these packet-loss ranges, using the [PLThresholdLevelsPerMille] parameter. For more information, see [Syslog, CDR and Debug Parameters](#) on page 1624.



- The packet loss report in the syslog message should be carefully considered. For example, for calls that are opened and then closed during the 15-second interval, packet loss statistics may be misleading due to insufficient packets for accurate calculation. Therefore, if the syslog message shows very few calls in the high packet-loss ranges, then you should probably ignore them as it might be due to this scenario. On the other hand, if there is a large number of calls falling into these high packet-loss ranges, then it probably indicates network problems.

## Configuring Debug Recording

This section describes how to configure debug recording and how to collect debug recording packets.



- For a detailed description of the debug recording parameters, see [Syslog, CDR and Debug Parameters](#) on page 1624.

## Configuring Debug Recording Server Address

The procedure below describes how to configure the address of the debug recording server to where the device sends captured traffic. Once you configure an address, the device generates debug recording packets for all calls. However, you can configure the device to generate debug recording packets for specific calls, using Logging Filter rules in the Logging Filters table (see [Configuring Logging Filter Rules](#) on page 1470).



You can also save debug recordings to an external USB hard drive that is connected to the device's USB port. For more information, see [USB Storage Capabilities](#) on page 1294.

### ➤ To configure debug recording server's address:

1. Open the Debug Recording page (**Troubleshoot** tab > **Troubleshoot** menu > **Logging** folder > **Debug Recording**).

#### DEBUG RECORDING SERVER

Destination IP Address

Destination Port

Interface Name

2. In the 'Destination IP Address' field (DebugRecordingDestIP), configure the IP address (IPv4 or IPv6) of the debug capturing server.
3. In the 'Destination Port' field, configure the port of the debug capturing server.
4. In the 'Interface Name' field (DebugRecordingIpInterfaceName), enter the name of the IP Interface through which you want the device to send captured traffic to the debug server. The value must be the same as the 'Name' field value in the IP Interfaces table (see [Configuring IP Network Interfaces](#) on page 157).
5. Click **Apply**.



- The IP version (IPv4 or IPv6) of the 'Destination IP Address' and 'Interface Name' fields must be the same.
- You can configure the 'Interface Name' field with any IP Interface type (OAMP, Media, or Control), as long as the IP version is the same as the address configured in the 'Destination IP Address' field. By default, the device uses the IPv4 OAMP interface.
- By default, if you configure an address in the 'Destination IP Address' field without configuring the 'Interface Name' field, the device uses the OAMP interface with the same IP version (IPv4 or IPv6) as the configured address. If no OAMP interface with the same IP version exists, then no debug recording is sent.

## Starting and Stopping Debug Recording

To activate debug recording of debug recording rules configured in the Logging Filters table, you need to manually start the debug recording process, as described in this section. By default, debug recording runs for 60 minutes before automatically stopping (unless you manually stop it before this time). You can modify this debug recording duration if needed.



- The device does debug recording only for rules in the Logging Filters table with the following settings:
  - ✓ 'Mode' parameter is configured to **Enable**.
  - ✓ 'Log Destination' parameter is configured to **Debug Recording Server**.
- If debug recording is currently running (i.e., started), the device resets the debug recording timer to the configured debug recording timeout upon the following:
  - ✓ A new rule is added to, or an existing rule is modified in, the Logging Filters table.
  - ✓ A device restart.
  - ✓ An HA switchover.

### ➤ To start debug recording:

1. Configure a debug recording rule(s) in the Logging Filters table and configure its 'Mode' parameter to **Enable** (see [Configuring Logging Filter Rules](#) on page 1470).
2. Open the Debug Recording page (**Troubleshoot** tab > **Troubleshoot** menu > **Logging** folder > **Debug Recording**).
3. Configure the maximum duration for debug recording:
  - a. In the 'Debug Recording Timeout' field, configure the maximum duration (in minutes) for the debug recording process. When this timer expires, the device automatically stops debug recording (unless you've explicitly stopped it before the timer expires).
  - b. Click **Apply**.
4. Click the **Start Debug Recording** button; the device starts debug recording and the following is displayed in these read-only fields:
  - The 'Debug Recording Status' field displays "Started".



- The 'Debug Recording End Date & Time' field displays the date and UTC time when debug recording will automatically stop:

GENERAL	
Debug Recording Status	Started
Stop Debug Recording	<button>Stop Debug Recording</button>
Debug Recording Timeout	<input type="text" value="60"/>
Debug Recording End Date & Time	25/2/2025 12:29:38

➤ **To stop debug recording:**

1. Click the **Stop Debug Recording** button; the device stops debug recording and the read-only 'Debug Recording Status' field displays "Stopped".

## Collecting Debug Recording Messages

To collect debug recording packets, use the open source packet capturing program, Wireshark. This allows you to analyze AudioCodes debug recording protocol.



- The default debug recording port is 925. You can change the port in Wireshark (**Edit menu > Preferences > Protocols > AC DR**).
- The source IP address of the messages is always the OAMP IP address of the device.
- By default (no filters applied), debug recording doesn't capture media (i.e., RTP/RTCP) but captures only non-media (e.g., SIP, syslog, and Web). This is to prevent CPU overload (and even device crashes) when medium or high traffic exists. Therefore, debug recording is **not** intended to capture media. However, if you need to capture full media packets (all headers) using debug recording, please contact AudioCodes support. If you want to capture media, it's recommended to use the Logging Filters table where you can specify media (see [Configuring Logging Filter Rules](#) on page 1470).

➤ **To view debug recording messages using Wireshark:**

1. Install Wireshark on your computer (which can be downloaded from <https://www.wireshark.org>).



During installation, it's recommended to choose (default) the Npcap packet sniffing library for Windows.

2. Only if you are using a Wireshark version that is earlier than 3.4.0 or you want to do PSTN (NetBricks) traces through Wireshark, you need to download AudioCodes proprietary

Wireshark plug-in files to analyze AudioCodes debug recording protocol. Otherwise, skip to Step 3.



- The Wireshark plug-in files are deprecated. Therefore, it's recommended to use Wireshark Version 3.4.0 or later (unless you want to do PSTN traces, which requires the **acdr.dll** plug-in file).
- The plug-in files are per major software release of Wireshark (excluding 3.4.0 and later). For more information, contact the sales representative of your purchased device.
- Make sure that you download the plug-in files that match your computer's Windows operating system (32-bit or 64-bit processor).


- a. Got to AudioCodes firmware download website page at <https://www.audiocodes.com/library/firmware>, and then navigate to the page for the "Wireshark Plugins":







## Wireshark Plugins

[Click here to download](#)

- b. Click the area shown above; folders containing the plug-in files for different Wireshark versions are displayed, as shown in the example below:

 Wireshark

☐ Select All Sort By Name ▾ ☰ ⋮


			
Wireshark 2.0 91 MB	Wireshark 2.4 12 MB	Wireshark 3.0 2 MB	Wireshark 3.2 2 MB

☐ I agree: [Terms and Conditions](#)




0 Items Selected Download

- c. Click the folder icon of the required Wireshark version; zipped folders of the selected Wireshark version are displayed:

Wireshark > Wireshark 3.2

 Wireshark 3.2

☐ Select All Sort By Name ▾ ☰ ⋮

		
dtds.zip 2 KB	plugins.zip 731 KB	Plugins_x64.zip 896 KB

☐ I agree: [Terms and Conditions](#)

0 Items Selected Download

- d. Select the check box of the required zipped plug-in files, select the **I agree** (to the terms and conditions) check box, and then click **Download**; the zipped folder is downloaded to your computer.



Make sure that you select the zipped plug-in folder that matches your computer's Windows operating system (32-bit or 64-bit processor):


- **plugins.zip**: For 32-bit
- **Plugins\_x64.zip**: for 64-bit

- e. Unzip the downloaded plug-in folder; a folder containing all the plug-in files (.dll) is created.
- f. Copy all the .dll files to the *plugin* folder (or for Wireshark Version 3.0 or later, to *plugins\<Wireshark version>\epan*) of the Wireshark installation. If the folder already has existing .dll files with the same name, overwrite them.

3. Start your Wireshark program.

4. In the filter field, type "acdr" to view the debug recording messages.

The device adds the header "AUDIOCODES DEBUG RECORDING" to each debug recording message, as shown below:



## Debug Capturing on Physical VoIP Interfaces

You can capture traffic on the device's physical (Ethernet LAN) VoIP interfaces (Layer-2 VLAN tagged packets). The captured traffic can be saved in a PCAP-format file (suitable for Wireshark) to a TFTP (default) or an FTP server. The generated PCAP file is in the Extensible Record Format (ERF). You can also save the capture to a USB device. The maximum file size of debug captures that can be saved to the device is 20 MB/100 MB.

To capture traffic on physical VoIP interfaces, use the following CLI commands:

- Starts physical VoIP debug capture:

```
# debug capture voip physical eth-lan
# debug capture voip physical start
```

- Captures packets continuously in a cyclical buffer (packets always captured until stop command):

```
# debug capture VoIP physical cyclic buffer
```

- Retrieves latest capture (PCAP file) saved on a specified server:

```
# debug capture VoIP physical get_last_capture <TFTP/FTP server IPv4 / IPv6 address>
```

The file is saved to the device's memory (not flash) and erased after a device restart.

- Marks the captured file (useful for troubleshooting process):

```
# debug capture VoIP physical insert-pad
```

Before running this command, the debug capture must be started.

- Displays debug status and configured rules:

```
# debug capture VoIP physical show
```

- Specifies the destination (FTP, TFTP, or USB) where you want the PCAP file sent:

```
# debug capture VoIP physical target <ftp|tftp|usb>
```

- Stops the debug capture, creates a file named debug-capture-voip-<timestamp>.pcap, and sends it to the TFTP or FTP server:

```
# debug capture voip physical stop <TFTP/FTP server IPv4 / IPv6 address>
```

If no IP address is defined, the capture is saved on the device for later retrieval.

## Debug Capturing on VoIP Interfaces

You can debug capture (record) network traffic on the device's VoIP interfaces per VLAN that is configured in the Ethernet Devices table (see [Configuring Underlying Ethernet Devices](#) on page 154). You can also capture traffic on one of the device's kernel interfaces (e.g., `eth0`, `eth1`, `lo`, or `tun0`). This may be useful, for example, to capture packets on the tunneling interface used for WebSocket traffic.

You can send the captured traffic to the following:

- **CLI terminal screen (tcpdump format):** The captured network packets are displayed in the CLI until you end the capture, by pressing the CTRL + C key combination.
- **Remote server (TFTP or FTP):** The capture is saved as a PCAP file (suitable for Wireshark) and sent to a specified server (default is TFTP) . The generated PCAP file is in the Extensible Record Format (ERF) and is saved on the device during the capture. The maximum file size that can be saved to the device is 10 MB and as long as the capture continues, the packets are written to this 10-MB file in a cyclic manner. When you end the capture (by pressing the CTRL + C key-combination), the device sends the capture file to the server.

The following procedure describes how to configure debug capturing for a specific VLAN. For debug capturing a kernel interface, use the same commands, but instead of `vlan` use `kernel-dev`, as shown below:

```
# debug capture voip interface kernel-dev <Name, e.g., tun0>
```

➤ **To capture traffic on VoIP VLAN interface:**

1. Define the VLAN ID on which you want to do the capture:

```
# debug capture voip interface vlan <VLAN ID>
```

2. Define the protocol that you want to capture (all|arp|icmp|ip|ipv6|tcp|udp):

```
# debug capture voip interface vlan <VLAN ID> proto <Protocol>
```

3. Define a source and/or destination IP address to be captured (any|ipv4\_address|ipv6\_address):

```
# debug capture voip interface vlan <VLAN ID> proto <Protocol> host < IPv4 /  
IPv6 Address>
```

At this stage, you can press Enter to output the capture to the CLI terminal window, or you can continue with the next step to configure additional commands.

4. Define a source and/or destination port number to be captured (any|[1-65535]):

```
# debug capture voip interface vlan <VLAN ID> proto <Protocol> host < IPv4 /  
IPv6 Address> port <Port>
```

At this stage, you can press Enter to output the capture to the CLI terminal window, or you can continue with the next step to configure additional commands.

5. Define the IP address (IPv4) of the server (TFTP or FTP) to where you want the device to send the captured file:

```
# debug capture voip interface vlan <VLAN ID> proto <Protocol> host <IP  
Address> ftp-server|tftp-server < IPv4 / IPv6 Address>
```

6. Press Enter to start debug capturing (and temporarily saves the capture to a file on the device).
7. Press the CTRL+C key-combination to stop the capture and send the file to the defined server.

## Configuring Wireshark Packet Capturing using RPCAP

You can use the device's embedded Remote Capture Protocol (RPCAP) server to capture network packets (IPv4 and IPv6) and then analyze them using the Wireshark tool on your computer. Once you have enabled the device's RPCAP server and then connected (over TCP) your remote Wireshark client to the device, you can use Wireshark to start or stop network capture on a specific device network interface, collect the captured data, and filter the captured data. In other words, control of the packet capturing process is from your Wireshark client. For more information on RPCAP functionality, refer to [Wireshark documentation](#).




- Wireshark filtering is merely a view filter; the device sends **all** packets to the computer running Wireshark, regardless of Wireshark's filtering settings.
- It's not recommended to use RPCAP during heavy traffic as this may utilize much of the device's CPU and network resources. If you need to capture specific traffic during heavy traffic, it's recommended to use the CLI command `debug capture` or the Logging Filters table for IP traces with the relevant filters (see [Configuring Logging Filter Rules](#) on page 1470).
- To free up the device's CPU resources used by the RPCAP server, after you have finished debugging, it's recommended to stop the RPCAP server, as described at the end of this section.
- By default (no filters applied), RPCAP captures **non-media only** (e.g., SIP, syslog, and Web) and doesn't capture media (i.e., RTP/RTCP). This is to prevent CPU overload under medium or high traffic. Therefore, RPCAP is **not** intended to capture media. If you want to capture media, use the Logging Filters table, as described in [Configuring Logging Filter Rules](#) on page 1470.

### ➤ To start packet capturing through RPCAP:


1. Start packet capturing by the device's RPCAP server, using the following CLI command. This command also allows you to configure the first and second ports of the RPCAP server. The first port is an always-open listening port for initial connections. The second port is sent to the client during the initial connection to open a new TCP connection for the captured packets. By default, the first port number is 2002 and the second port number is dynamically allocated by the device.

```
# debug capture rpcap-server start <First Port> <Second Port>
```

2. On your remote computer, start the Wireshark client.
3. From the Capture menu, choose **Options**; the Capture Options dialog box appears:




4. Click **Manage Interfaces**, and then in the Manage Interfaces dialog box, select the **Remote Interfaces** tab: the following appears:




5. Click the plus button; the following dialog box appears:





The 'Remote Interface' dialog box is used to configure remote network interfaces. It contains fields for 'Host' (a dropdown menu) and 'Port' (a text input). Below these is an 'Authentication' section with two radio buttons: 'Null authentication' (selected) and 'Password authentication'. The 'Password authentication' option has associated 'Username' and 'Password' text input fields. At the bottom are 'OK' and 'Cancel' buttons.


6. Fill in the following fields:
  - In the 'Host' field, enter the IP address of the device.
  - In the 'Port' field, enter the port of the device that is used for the packet capture sessions.
7. Click **OK**; the Manage Interfaces dialog box displays a list of all the device's network interfaces:




The 'Manage Interfaces' dialog box shows a list of network interfaces under the 'Remote Interfaces' tab. The list has columns for 'Show' (checkboxes) and 'Host / Device URL'. The URLs are based on the IP 10.15.7.96 and various interface names. At the bottom, there are '+', '-', and 'Remote Settings' buttons, and a note: 'This version of Wireshark does not save remote settings.' The 'OK', 'Cancel', and 'Help' buttons are at the bottom right.

Show	Host / Device URL
<input checked="" type="checkbox"/>	10.15.7.96
<input checked="" type="checkbox"/>	rpcap://10.15.7.96:2002/eth0
<input checked="" type="checkbox"/>	rpcap://10.15.7.96:2002/eth0.1
<input checked="" type="checkbox"/>	rpcap://10.15.7.96:2002/eth0.340
<input checked="" type="checkbox"/>	rpcap://10.15.7.96:2002/eth0.4002
<input checked="" type="checkbox"/>	rpcap://10.15.7.96:2002/lo

8. Using the check boxes, select only the network interfaces on which you want to capture packets, and then click **OK**; the Manage Interfaces dialog closes and you are returned to the Capture Options dialog box, which now displays the device's network interfaces that you selected in the previous step:



9. Select the required network interface, and then click **Start**; the Capture Options dialog box closes and the main Wireshark window displays captured packets as they are collected by Wireshark, as shown in the following example:



To stop the packet capturing on Wireshark, from the Capture menu, choose **Stop**. To continue capturing (with or without saving the previous capture), choose **Start**.

To stop the device's RPCAP server, first stop the Wireshark capturing, and then run the following CLI command:

```
# debug capture rpcap-server stop
```

## 61 Creating Core Dump and Debug Files upon Device Crash

For debugging, you can configure the device to create a core dump file and a debug file. These files may assist you in identifying the cause of the crash. The core dump can either be included in or excluded from the debug file, or alternatively, sent separately to a TFTP server. You can then provide the files to AudioCodes support team for troubleshooting.

### Enabling Core Dump File Generation

You can enable the device to automatically generate a core dump file upon a device crash. The core dump is a copy of the device's memory image at the time of the crash. The device generates a new core dump file each time it crashes, replacing the previous core dump file (if exists). The core dump file provides you with a powerful tool for determining the cause of the crash.

You can also configure the device to send the core dump file to a TFTP server (defined by IP address). If you don't configure an address, the core dump file is saved on the device's flash memory (if it has sufficient memory). The core dump file is saved as a binary file, using the following file name format: *core\_<Device Name>\_ver\_<Firmware Version>\_mac\_<MAC Address>\_<Date>\_<Time>*. For example: "core\_acDevice\_ver\_720-8-4\_mac\_00908F099096\_1-02-2015\_3-29-29".



- When downloading the debug file to your computer, you can also include the core dump file, as described in [Downloading the Debug \(and Core Dump\) File](#) on the next page.

#### ➤ To enable core dump file generation:

1. (Optional) Set up a TFTP server where you want the device to send the core dump file.
2. Open the Debug Files page (**Troubleshoot** menu > **Troubleshoot** tab > **Debug** folder > **Debug Files**).
3. Select the 'Enable Core Dump' check box to enable core dump file creation:

Enable Core Dump



4. (Optional) If you want the device to send the core dump file to a remote TFTP server, in the 'Core Dump Destination IP' field, enter the IP address of the remote server. If not configured, the device saves the file in it's local storage memory:

Core Dump Destination IP

0.0.0.0

5. Click **Apply**.

## Downloading the Debug (and Core Dump) File

You can download the debug file from the device (flash memory) and save it to a folder on your local computer.

The device creates the debug file whenever an exception occurs. Each time the device creates a new debug file, it overwrites the existing file. The debug file is saved as a TAR (Tape ARchive) file (.tar), with the following filename format: *debug\_<Device Name>\_ver\_<Firmware Version>\_mac\_<MAC Address>\_<Date>\_<Time>*. For example, *debug\_SBC\_ver\_740-500-966\_mac\_5b-10-35\_13-3-2024\_10-52-37.tar*.

The debug file contains the following:

- Exception information, indicating the specific point in the code where the crash occurred and a list of up to 50 of the most recent SNMP alarms that were raised by the device before it crashed.
- Restart (reset) history, where each restart entry provides the reason of the restart (e.g., triggered by Web interface or was an exception), date and time the restart occurred, device uptime before restart, and software version of the device. This information appears in the reset-history folder.
- Latest syslog messages that were recorded prior to the crash.
- Core dump file if **all** of the following conditions are met:
  - You have enabled core dump generation (see [Enabling Core Dump File Generation](#) on the previous page).
  - You have not configured an IP address to send the core dump to a remote server (see [Enabling Core Dump File Generation](#) on the previous page).
  - The device has sufficient memory on its flash memory.
  - You have enabled the inclusion of the core dump file in the debug file (see below procedure).
- Information on the Floating and Metering licenses (FloatLicense.lzma and MeterLicense.lzma files, respectively, in the system\_logs folder).
- If the device is configured with a Client Defaults ini file, it's included in the debug file in the Device folder (default.ini).
- Configuration Package file (in the Device folder).
- The debug file may include additional application-proprietary debug information.

### ➤ To download debug file:

1. Open the Debug Files page (**Troubleshoot** menu > **Troubleshoot** tab > **Debug** folder > **Debug Files**), and then scroll down to the 'Save The Debug File To The PC' group:

## SAVE THE DEBUG FILE TO THE PC

Save Debug File

Save Redundant Device's Debug File

2. By default, the core dump file is included in the downloaded debug file. If you don't want to include it, clear the 'Attach Core Dump File' check box.
3. Click the **Save Debug File** button; the device downloads the debug file to a folder on your computer. For devices in HA mode, this button downloads the debug file of the active device. To download the redundant device's debug file, click the **Save Redundant Device's Debug File** button.



- Downloading the debug file may take a few minutes. Depending on file size, it may even take more than 10 minutes.

- **Downloading through SFTP:**

You can also download (Get) the debug file from the device through SFTP. The file is located in the device's `/debug` folder. Your SFTP client needs to authenticate itself with the SFTP server (i.e., the device). You can access the `/debug` folder only if you are a **Security Administrator** user.

For downloading the debug file through SFTP, you need to enable SSH on the device.

The device may take a long time to prepare the debug file for SFTP transfer if it contains much information. Some SFTP clients (for example, WinSCP and FileZilla) have a short default connection timeout and if the file transfer is not started within this timeout, the transfer attempt is aborted. Therefore, it's recommended to configure a longer timeout for your SFTP client application.

## Deleting the Debug (and Core Dump) File

You can delete the debug file that is stored on the device's memory. If you have enabled core dump file generation (see [Enabling Core Dump File Generation](#) on page 1524) without configuring an address of a remote server to send the file to, the core dump file, which is included with the stored debug file is also deleted.

➤ **To delete the debug file (and core dump file):**

1. Establish a CLI session with the device.
2. Type the following command, and then press Enter:

```
# clear debug-file
```

## Debug (and Core Dump) File Contents

The debug file or core dump file contains the following information:

■ **Device:** This folder contains the following file:

- **configuration-package.7z:** This is the Configuration Package file, as described in [Downloading or Uploading Configuration Package File](#) on page 1260.
- **status.tar.gz:** This file contains various status information such as the device's date and available memory. These are some of the files:
  - ◆ **date-u.info** - UTC time
  - ◆ **date.info** - Local time
  - ◆ **uptime.info** - Duration (in seconds) that the device was operational before a restart
  - ◆ **df.info** - Available (free) disk space
  - ◆ **du.info** - Utilized disk space
  - ◆ **HardwareVersionsInfo.txt** - device's hardware version

■ **reset-history:** This folder contains logged device restarts and contains the following:

The *reset-table-of-content.txt* file lists the latest logged device restarts, where each logged restart is sequentially numbered ("Counter"), providing device uptime before the restart, the restart reason, and the date and time that it occurred. If the restart was caused by an error (i.e., crash), "Exception" instead of "Reset" is displayed above the restart counter. Below shows an example of logged device restarts:

```
** Current Reset Counter [84] **

***** Reset *****
Reset Counter:83
Up Time (seconds): 237890
Reset Reason: a hardware reset
Reset Time: 5.3.2025 2:24:18
SwVersion: ramMP500_ESBC_SIP 760A-092-799
*****

***** Reset *****
Reset Counter:82
Up Time (seconds): 890
Reset Reason: Web Reset
Reset Time: 23.2.2025 14:49:12
```

```
SwVersion: ramMP500_ESBC_SIP 760A-092-756
```

```
*****
```

```
**** Exception ****
```

```
Reset Counter:81
```

```
Exception Reason: System crashed due to Kernel Panic
```

```
EXCEPTION TIME : 31.8.2020 10.16.45
```

```
*****
```

Each logged device restart that is listed in the *reset-table-of-content.txt* file has a dedicated subfolder under the *reset-history* folder. For normal restarts, the folder's name is *<Restart Counter>\_Reset* (e.g., "83\_Reset"). For restarts due to errors, the folder's name is *<Restart Counter>\_Exception* (e.g., "81\_Exception").

This subfolder contains system events or messages that were logged immediately prior to the device restart:

- **core.lzma:** This file is generated if Core Dump is enabled and the device restarts (crashes) due to exception event. It is only present in the folder of the latest restart due to an exception.
- **ExceptionInfo.txt:** This file is generated only if device restart was caused by an exception event (error). As mentioned previously, these logged device restarts are displayed in the *reset-table-of-content.txt* file with the title "Exception". The file contains detailed information of the exception.
- **NoSip.lzma:** This file contains the latest syslog messages, but without SIP-related syslog messages.
- **Syslog.lzma:** This file contains all the latest syslog messages.



- To view the debug file in CLI:
  - ✓ Restart history (list of restarts or a specific reset counter): `show debug-file reset-info {list|reset-counter}`
  - ✓ Generated file contents (list of files or a specific file): `show debug-file device-logs list|file`
- The CLI doesn't display the Core Dump file.



## 61 Downloading the DSP Core Dump File

The device automatically creates a DSP Core Dump file whenever a DSP restart occurs. This file captures information about the DSP processes prior to the restart.

You can download the DSP Core Dump file to your computer for debugging. The file is downloaded in 7-Zip archive file format (.7z).



- The Web interface displays the DSP Core Dump file download functionality only when all the following conditions are met:
  - ✓ A DSP Core Dump file has been generated.
  - ✓ You're logged in as an Administrator or a Security Administrator user.
- The DSP Core Dump file is temporarily stored on the device's RAM. Therefore, it's deleted upon a device restart.

### ➤ To download DSP Core Dump file:

1. Open the Debug Files page (**Troubleshoot** menu > **Troubleshoot** tab > **Debug** folder > **Debug Files**).

SAVE THE DSP CORE DUMP FILE TO THE PC

Save DSP Core Dump File

Save

2. Under the **Save the DSP Core Dump File to the PC** group, click the **Save** button; the file is downloaded to a folder on your computer.

## 62 Debugging Web Services

If you have configured remote Web services (see [Remote Web Services](#) on page 429), you can enable debugging of the remote HTTP clients. You can configure the debug level from 1 to 3, where 3 is the most detailed. The debug messages are sent to the syslog server.

➤ **To configure debugging of Web services:**

1. Open the Web Service Settings page (**Setup** menu > **IP Network** tab > **Web Services** folder > **Web Service Settings**).
2. In the 'Debug Level' field (RestDebugMode), enter the debug level (or disable debugging by configuring it to 0):


Debug Level

•

3. Click **Apply**.

## 63 Enabling SIP Call Flow Diagrams in OVOC

You can configure the device to send SIP messages (in XML format) of SIP call dialogs to AudioCodes One Voice Operations Centers (OVOC) so that it can display the call dialog as a call flow diagram (ladder). OVOC displays the call flow on the Call Flow page (**Calls** menu > **Calls List** tab > select call > **Show** button > **Call Flow** tab). The call flow is displayed using vertical and horizontal lines. The vertical lines represent the SIP entities (including the device itself) that are involved in the dialog. The horizontal lines represent the SIP requests and responses. An example of a SIP call flow diagram in OVOC is shown below. For more information on OVOC, refer to the document [One Voice Operations Center User's Manual](#).



SIP call flow diagrams may be useful for debugging and for better understanding of the SIP call. The call flow displays all the SIP messages related to the call session, including requests (e.g., INVITES) and responses (e.g., 200 OK). For SBC calls, the call flow reflects messages as sent "over the wire" - incoming messages before manipulation and outgoing messages after manipulation. For Gateway calls, the call flow reflects incoming messages after Pre-Parsing Manipulation (if configured) but before general Message Manipulation, and outgoing messages after manipulation.

### ➤ To configure SIP call flow support:

1. Enable the OVOC call flow feature:
  - a. Open the Logging Settings page (**Troubleshoot** menu > **Troubleshoot** tab > **Logging** folder > **Logging Settings**).
  - b. Select the 'Call Flow Report Mode' check box [CallFlowReportMode]:

Call Flow Report Mode ☒

- c. Click **Apply**.
2. To send call flow messages of specific calls only (e.g., for a specific IP Group), configure a Log Filter rule:
  - a. Open the Logging Filters table (see [Configuring Logging Filter Rules](#) on page 1470

- b. Click **New** , and then configure the rule as desired, but with the following parameter settings:

◆ 'Log Destination': **OVOC (QoE)**

◆ 'Log Type': **SIP Ladder**

**Logging Filters** — x

GENERAL

Index	<input type="text" value="0"/>
Filter Type	<input type="text" value="IP Group"/>
Value	<input type="text" value="4"/>
Log Destination	<input type="text" value="OVOC"/>
Log Type	<input type="text" value="SIP Ladder"/>
Mode	<input type="text" value="Enable"/>

- c. Click **Apply**.



- If you have not configured any filtering rule for SIP call flow (**SIP Ladder**) in the Logging Filters table, the device sends call flow messages to OVOC for all calls.
- The device doesn't send OVOC SIP messages that fail authentication (SIP 4xx challenge).
- The feature doesn't support SIPREC messages and REGISTER messages.
- When the device is in HA mode, during a switchover it stops sending SIP call flow messages of current SIP dialogs, and continues sending them after the switchover (even though OVOC doesn't display the continuation of the call after switchover).
- If the device experiences a CPU overload, it stops sending SIP call flow messages to OVOC until the CPU returns to normal levels.

## 64 Enabling Same Call Session ID over Multiple Devices

You can enable the use of a Global Session ID to identify call sessions traversing multiple devices.

The Global Session ID is a randomly assigned ID number that identifies each call session. The ID is unique to the call session and remains the same throughout the session even if the call traverses multiple devices.

The Global Session ID appears in SIP messages using the AudioCodes proprietary SIP header, AC-Session-ID, as shown in the example below:

```
INVITE sip:2000@172.17.113.123;user=phone SIP/2.0
...
AC-Session-ID: 7f6941530b31d715
...
```

If the device receives an incoming SIP message containing the Global Session ID, it sends the same Global Session ID in the outgoing SIP message. If the incoming SIP message doesn't contain a Global Session ID or if a new session is initiated by the device, the device generates a new, unique Global Session ID and adds it to the outgoing SIP message.

To enable the Global Session ID, use the ini file [SendAcSessionIdHeader] parameter or CLI command `configure voip > sip-definition settings > send-acsessionid`.



- The Global Session ID is not included in syslog messages.
- By default, the device doesn't include the Global Session ID in CDRs. However, you can customize CDRs to include it. For more information, see [Customizing CDRs for Gateway Calls](#) on page 1440 and [Customizing CDRs for SBC Calls and Test Calls](#) on page 1446.
- The feature must be enabled on all devices through which the call traverses.
- If you disable this feature, the device sends outgoing SIP messages without a Global Session ID (even if a Global Session ID was received in the incoming SIP message).

## 65 Testing SIP Signaling Calls

A simulated endpoint can be configured on the device to test SIP signaling of calls between it and a remote destination. This feature is useful in that it can remotely verify SIP message flow without involving the remote end side in the debug process. The SIP test call simulates the SIP signaling process - call setup, SIP 1xx responses, through to completing the SIP transaction with a 200 OK.

The test call sends syslog messages to a syslog server, showing the SIP message flow, tone signals (e.g., DTMF), termination reasons, as well as voice quality statistics and thresholds (e.g., MOS).

### Configuring Test Call Endpoints

The Test Call Rules table lets you test SIP signaling (setup and registration) and media (DTMF signaling) of calls between a simulated phone on the device and a remote IP endpoint. You can test incoming and outgoing calls, where the test endpoint can be configured as the caller or called party.

The device's simulated phone and the remote endpoints are defined by SIP URIs (user@host). The remote endpoint can be defined as an IP Group or IP address.

Test calls can be dialed automatically at a user-defined interval, or manually when required. When the device initiates a SIP test call, it sends a SIP INVITE towards the remote SIP User Agent (e.g., a SIP proxy server or softswitch). The device simulates the SIP call setup process, managing SIP 1xx responses and completing the SIP transaction with a SIP 200 OK after a user-defined duration.

When the remote SIP UA initiates the call with the device's test call endpoint, the test call ends when the remote UA ends the call (i.e., sends a SIP BYE message). Alternatively, the duration of the test call can be determined by the incoming SIP INVITE message, as described in [Using SIP INVITE to Specify Test Call Duration](#) on page 1545.



- By default, you can configure up to five test call rules. However, you can increase this number by installing a License Key that licenses the required number. For more information, contact the sales representative of your purchased device.
- The device's Call Admission Control (CAC) feature (see [Configuring Call Admission Control](#) on page 1054) doesn't apply to Test Calls.
- When the device operates in High-Availability (HA) mode, current Test Calls are disconnected during an HA switchover.
- For testing incoming calls, the device first tries to find a matching rule in the Test Calls Rules table (i.e., SIP INVITE Request-URI user part equals the 'Endpoint URI' parameter value). If there is no matching rule, the device then checks if the prefix of the user part matches the 'Test Call ID' parameter value configured for the Basic Test Call feature (see [Configuring Basic Incoming Test Calls](#) on page 1550).

The following procedure describes how to configure Test Call rules through the Web interface. You can also configure it through ini file [Test\_Call] or CLI (`configure troubleshoot > test-call test-call-table`).

➤ **To configure a Test Call:**

1. Open the Test Call Rules table (**Troubleshoot** menu > **Troubleshoot** tab > **Test Call** folder > **Test Call Rules**).
2. Click **New**; the following dialog box appears:

3. Configure a test call according to the parameters described in the table below.
4. Click **Apply**, and then save your settings to flash memory.

**Table 65-1: Test Call Rules Table Parameter Descriptions**

Parameter	Description
Common	
'Index'	Defines an index number for the new table row. <b>Note:</b> Each row must be configured with a unique index.
'Endpoint URI' endpoint-uri [Test_Call_EndpointURI]	Defines the endpoint's URI. This can be defined as a user or user@host. The device identifies this endpoint only by the URI's user part. The URI's host part is used in the SIP From header in REGISTER requests. The parameter is used as follows:  ■ <b>Incoming test calls:</b> The parameter defines the destination URI in the user part of the incoming

Parameter	Description
	<p>INVITE Request-URI.</p> <ul style="list-style-type: none"> <li>■ <b>Outgoing test calls:</b> The parameter defines the source URI in the user part of the outgoing INVITE request's From header.</li> </ul> <p>The valid value is a string of up to 150 characters. By default, the parameter is not configured.</p> <p><b>Note:</b> The parameter is mandatory.</p>
<p>'Called URI'</p> <p>called-uri</p> <p>[Test_Call_CalledURI]</p>	<p>Defines the destination (called) URI (user@host) in the user part of the outgoing SIP INVITE Request-URI.</p> <p>The valid value is a string of up to 150 characters. By default, the parameter is not configured.</p> <p><b>Note:</b> The parameter is applicable only to outgoing test calls.</p>
<p>'Route By'</p> <p>route-by</p> <p>[Test_Call_RouteBy]</p>	<p>Defines the type of routing method. This applies to incoming and outgoing calls.</p> <ul style="list-style-type: none"> <li>■ [1] <b>IP Group</b> = (Default) Calls are matched by (or routed to) an IP Group. To specify the IP Group, see the 'IP Group' parameter in the table.</li> <li>■ [2] <b>Dest Address</b> = Calls are matched by (or routed to) a destination IP address. To configure the address, see the 'Destination Address' parameter in the table.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If configured to <b>Dest Address</b>: <ul style="list-style-type: none"> <li>✓ You must assign a SIP Interface (see the 'SIP Interface' below).</li> <li>✓ The IP Profile of the default IP Group (ID 0) is used. You can use a different IP Profile, by specifying an IP Group in the 'IP Group' parameter (below).</li> </ul> </li> <li>■ For REGISTER messages, if configured to <b>IP Group</b>, only Server-type IP Groups can be used.</li> </ul>
<p>'IP Group'</p> <p>ip-group-id</p> <p>[Test_Call_IPGroupName]</p>	<p>Assigns an IP Group where the test call is sent to or received from.</p> <p>By default, no value is defined.</p> <p>To configure IP Groups, see <a href="#">Configuring IP Groups</a> on</p>



Parameter	Description
	<p>page 581.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable if you configure the 'Route By' parameter to <b>IP Group</b>.</li> <li>■ You can also use this parameter if you configure the 'Route By' parameter to <b>Dest Address</b>. This allows you to associate an IP Profile (that is assigned to the specified IP Group) with the Test Call. The Test Call is not routed to the IP Group, but uses only its IP Profile.</li> <li>■ The IP Group is used for incoming and outgoing calls.</li> </ul>
'Destination Address' dst-address [Test_Call_DestAddress]	<p>Defines the destination host.</p> <p>The valid value is an IP address[:port] in dotted-decimal notation or a DNS name[:port].</p> <p><b>Note:</b> The parameter is applicable only if you configure the 'Route By' parameter to <b>Dest Address</b>.</p>
'SIP Interface' sip-interface-name [Test_Call_SIPInterfaceName]	<p>Assigns a SIP Interface. This is the SIP Interface to which the test call is sent and received from.</p> <p>By default, no value is defined.</p> <p>To configure SIP Interfaces, see <a href="#">Configuring SIP Interfaces</a> on page 561.</p> <p><b>Note:</b> The parameter is applicable only if the 'Route By' parameter is configured to <b>Dest Address</b>.</p>
'Application Type' application-type [Test_Call_ApplicationType]	<p>Defines the application type for the endpoint. This associates the IP Group and SRD to a specific SIP interface. For example, assume two SIP Interfaces are configured in the SIP Interfaces table where one is set to "GW" and one to "SBC" for the 'Application Type'. If you configure the parameter to <b>SBC</b>, the device uses the SIP Interface set to "SBC".</p> <ul style="list-style-type: none"> <li>■ [0] <b>GW</b> = (Default) Gateway application</li> <li>■ [2] <b>SBC</b> = SBC application</li> </ul>
'Destination Transport Type' dst-transport [Test_Call_DestTransportType]	<p>Defines the transport type for outgoing calls.</p> <ul style="list-style-type: none"> <li>■ [-1] = Not configured (default)</li> <li>■ [0] <b>UDP</b></li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [1] TCP</li> <li>■ [2] TLS</li> <li>■ [3] SCTP</li> </ul> <p><b>Note:</b> The parameter is applicable only if you configure the 'Route By' parameter to <b>Dest Address</b>.</p>
'QoE Profile' qoe-profile [Test_Call_QOEProfile]	Assigns a QoE Profile to the test call. By default, no value is defined. To configure QoE Profiles, see <a href="#">Configuring Quality of Experience Profiles</a> on page 519.
'Bandwidth Profile' bandwidth-profile [Test_Call_BWProfile]	Assigns a Bandwidth Profile to the test call. By default, no value is defined. To configure Bandwidth Profiles, see <a href="#">Configuring Bandwidth Profiles</a> on page 526.
Media	
'Offered Audio Coders Group' offered-audio-coders-group-name [Test_Call_OfferedCodersGroupName]	Assigns a Coder Group, configured in the Coders Groups table, whose coders are added to the SDP Offer in the outgoing Test Call. If not configured, the device uses the Coder Group specified by the 'Extension Coders Group' parameter of the IP Profile associated with the rule's IP Group (see the 'IP Group' parameter above). To configure Coder Groups, see <a href="#">Configuring Coders Groups</a> on page 651. <b>Note:</b> <ul style="list-style-type: none"> <li>■ The parameter's settings override the corresponding SBC parameter of the IP Profile associated with the rule's IP Group.</li> <li>■ If you don't configure this parameter nor the corresponding parameter of the associated IP Profile, the device uses Coder Group ID 0.</li> </ul>
'Allowed Audio Coders Group' allowed-audio-coders-group-name [Test_Call_AllowedAudioCodersGroupNam	Assigns an Allowed Audio Coders Group, configured in the Allowed Audio Coders Groups table, which defines only the coders that can be used for the test call. For incoming test calls, the device accepts the first offered coder that is supported and allowed.

Parameter	Description
e]	<p>If not configured, the device uses the Allowed Audio Coders Group specified by the 'Allowed Audio Coders' parameter of the IP Profile associated with the rule's IP Group (see the 'IP Group' parameter above).</p> <p>To configure Allowed Audio Coders Groups, see <a href="#">Configuring Allowed Audio Coder Groups</a> on page 659.</p> <p><b>Note:</b> The parameter's settings override the corresponding SBC parameter of the IP Profile associated with the rule's IP Group.</p>
'Allowed Coders Mode' allowed-coders-mode [Test_Call_ AllowedCodersMode]	<p>Defines the mode of the Allowed Coders feature for the Test Call.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> = (Default) The mode is according to the 'Allowed Coders Mode' parameter of the IP Profile associated with the rule's IP Group (see the 'IP Group' parameter above).</li> <li>■ [0] <b>Restriction</b> = The device uses only allowed coders as configured in the 'Allowed Audio Coders Group' parameter (above) and removes all other coders from the SDP offer. If you have also configured additional coders in the 'Offered Audio Coders Group' parameter (above), then these coders are added to the SDP offer if they appear in the assigned Allowed Audio Coders Group.</li> <li>■ [1] <b>Preference</b> = The device re-arranges the priority (order) of the coders in the incoming SDP offer according to their order of appearance in the Allowed Audio Coders Group. The coders in the original SDP offer are listed after the allowed coders.</li> <li>■ [2] <b>Restriction and Preference</b> = The device uses both the <b>Restriction</b> and <b>Preference</b> options.</li> </ul> <p><b>Note:</b> Except for <b>Not Configured</b>, the parameter's settings override the corresponding SBC parameter of the IP Profile associated with the rule's IP Group.</p>
'Media Security Mode' media-security-mode [Test_Call_MediaSecurityMode]	<p>Defines the handling of RTP and SRTP.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> = (Default) Handling is according to the 'SBC Media Security Mode' parameter of the IP Profile associated with the</li> </ul>

Parameter	Description
	<p>rule's IP Group (see the 'IP Group' parameter above).</p> <ul style="list-style-type: none"> <li>■ [0] <b>As is</b> = No special handling for RTP\SRTP is done.</li> <li>■ [1] <b>SRTP</b> = Only SRTP media lines are negotiated and RTP media lines are removed from the incoming SDP offer-answer.</li> <li>■ [2] <b>RTP</b> = Only RTP media lines are negotiated and SRTP media lines are removed from the incoming SDP offer-answer.</li> <li>■ [3] <b>Both</b> = Each SDP offer-answer is extended (if not already) to two media lines - one for RTP and one for SRTP.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ To enable SRTP, configure the [EnableMediaSecurity] parameter to [1].</li> <li>■ Except for <b>Not Configured</b>, the parameter's settings override the corresponding SBC parameter of the IP Profile that is associated with the rule's IP Group.</li> </ul>
<p>'Play DTMF Method'</p> <p>play-dtmf-method</p> <p>[Test_Call_PlayDTMFMethod]</p>	<p>Defines the method used by the device for sending DTMF digits that are played to the called party when the call is answered.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> = The mode is according to the 'Alternative DTMF Method' and 'RFC 2833 Mode' parameters of the IP Profile associated with the rule's IP Group (see the 'IP Group' parameter above).</li> <li>■ [0] <b>RFC 2833</b> = (Default) The device sends the DTMF digits using the RFC 2833 method (out-of-band).</li> <li>■ [1] <b>In Band</b> = The device sends the DTMF digits in-band (in the RTP stream).</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if you configure the 'Play' parameter to <b>DTMF</b>.</li> <li>■ Playing DTMF digits requires DSP resources when the DTMF method is <b>In Band</b>.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ If the Test Call sends the SDP offer, the recommended DTMF configuration of the associated IP Profile is as follows: <ul style="list-style-type: none"> <li>✓ For RFC 2833: 'RFC 2833 Mode' = <b>Extend</b>; 'Alternative DTMF Method' = <b>As Is</b></li> <li>✓ For In Band: 'RFC 2833 Mode' = <b>Disallow</b>; 'Alternative DTMF Method' = <b>As Is</b></li> </ul> </li> <li>■ If the Test Call receives the SDP offer, the recommended configuration is as follows (i.e., incoming SDP offer determines the method): 'RFC 2833 Mode' = <b>As Is</b>; 'Alternative DTMF Method' = <b>As Is</b></li> </ul>
<b>Authentication</b> <b>Note:</b> These parameters are applicable only if the 'Call Party' parameter (below) is configured to <b>Caller</b> .	
'Auto Register' auto-register [Test_Call_AutoRegister]	Enables automatic registration of the endpoint. The endpoint can register to the device itself or to the 'Destination Address' or 'IP Group' parameter settings (see above). <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul>
'Username' user-name [Test_Call_UserName]	Defines the authentication username. The valid value is a string of up to 60 characters. By default, no value is defined.
'Password' password [Test_Call_Password]	Defines the authentication password. By default, no password is defined. <b>Note:</b> The parameter cannot be configured with wide characters.
<b>Test Setting</b>	
'Call Party' call-party [Test_Call_CallParty]	Defines if the test endpoint is the initiator (caller) or receiving side (called) of the test call. <ul style="list-style-type: none"> <li>■ [0] <b>Caller</b> = (Default) The device's test endpoint is the calling party (i.e., applicable only to outgoing test calls).</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [1] <b>Called</b> = The device's test endpoint is the called (callee) party (i.e., applicable only to incoming test calls).</li> </ul>
'Maximum Channels for Session' <code>max-channels</code> [Test_Call_MaxChannels]	Defines the maximum number of concurrent channels for the test session. For example, if you have configured an endpoint "101" and you configure the parameter to "3", the device automatically creates three simulated endpoints - "101", "102" and "103" (i.e., consecutive endpoint URIs are assigned). The default is 1.
'Call Duration' <code>call-duration</code> [Test_Call_CallDuration]	Defines the call duration (in seconds). The valid value is -1 to 100000. The default is 20. A value of 0 means infinite. A value of -1 means that the parameter value is automatically calculated according to the values of the 'Calls per Second' and 'Maximum Channels for Session' parameters. <b>Note:</b> The parameter is applicable only if you configure 'Call Party' to <b>Caller</b> .
'Calls per Second' <code>calls-per-second</code> [Test_Call_CallsPerSecond]	Defines the number of calls per second. <b>Note:</b> The parameter is applicable only if you configure 'Call Party' to <b>Caller</b> .
'Test Mode' <code>test-mode</code> [Test_Call_TestMode]	Defines the test session mode. <ul style="list-style-type: none"> <li>■ [0] <b>Once</b> = (Default) The test runs until the lowest value between the following is reached:               <ul style="list-style-type: none"> <li>✓ Maximum channels is reached for the test session, configured by 'Maximum Channels for Session'.</li> <li>✓ Call duration ('Call Duration') multiplied by calls per second ('Calls per Second').</li> <li>✓ Test duration expires, configured by 'Test Duration'.</li> </ul> </li> <li>■ [1] <b>Continuous</b> = The test runs until the configured test duration is reached. If it reaches the maximum channels configured for the test session (in the 'Maximum Channels for Session'), it waits until the configured call duration of a currently established tested call expires before making the next test call.</li> </ul>

Parameter	Description
	<p>In this way, the test session stays within the configured maximum channels.</p> <p><b>Note:</b> The parameter is applicable only if you configure 'Call Party' to <b>Caller</b>.</p>
'Test Duration' test-duration [Test_Call_TestDuration]	<p>Defines the test duration (in minutes).</p> <p>The valid value is 0 to 100000. The default is 0 (i.e., unlimited).</p> <p><b>Note:</b> The parameter is applicable only if you configure 'Call Party' to <b>Caller</b>.</p>
'Play' play [Test_Call_Play]	<p>Enables the playing of a tone to the answered side of the call.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = No tone is played.</li> <li>■ [1] <b>DTMF</b> = (Default) Plays (loop) a user-defined DTMF string, which is configured in <a href="#">Configuring DTMF Tones for Test Calls</a> on page 1549.</li> <li>■ [2] <b>PRT</b> = Plays (loop) a pre-recorded tone (audio file) from the PRT file that is installed on the device. You can either specify the tone (by index) to play from the PRT file in the 'Play Tone Index' parameter (below), or implement a basic NetAnn feature whereby the tone from the PRT file (and other characteristics) are specified by NetAnn parameters in the Request-URI of the incoming SIP INVITE message. When using NetAnn, instead of connecting the call (i.e., 200 OK), the device replies with a SIP 183 containing SDP.</li> </ul> <p>The NetAnn parameters include the following:</p> <ul style="list-style-type: none"> <li>● <b>early=yes:</b> Indicates that NetAnn is used for playing the tone.</li> <li>● <b>play=&lt;Prompt/Tone Index in PRT file&gt;:</b> Defines the tone to play from the PRT file.</li> <li>● <b>repeat=&lt;Times&gt;:</b> Defines how many times the tone is played (loops) before the device disconnects the call.</li> <li>● <b>delay=&lt;Delay Time&gt;:</b> Defines the delay time (in msec) between each played (loop) tone. If the parameter is not present, the default is</li> </ul>

Parameter	Description
	<p>2,000 ms (2 seconds).</p> <p>The following shows an example of a Request-URI with NetAnn parameters that instruct the device to play three times (loops) the tone that is defined at Index 15 in the PRT file:</p> <pre data-bbox="798 504 1377 678">INVITE sip:200@1.1.1.1;early=yes;play=15;repeat=3</pre> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ You can configure the DTMF signaling type (RFC 2833 or in-band), using the 'Play DTMF Method' parameter (above).</li> <li>■ Playing a tone from the PRT file requires DSP resources if the coder with which the tone was created is different to the coder used for the Test Call.</li> <li>■ You can also use NetAnn parameters to play a specific recorded tone to the caller (source) when the destination fails for a regular IP-to-IP SBC call. To configure this: <ul style="list-style-type: none"> <li>✓ Configure a Message Manipulation rule that adds the NetAnn parameters, based on the tone that you want played, to the INVITE message's Request-URI.</li> <li>✓ Configure a Number Manipulation rule that changes the destination number to the Test Call ID.</li> <li>✓ Configure an IP Group to represent the device itself (which will be the Test Call module) and assign it the Message Manipulation rule and the Number Manipulation rule.</li> <li>✓ Configure an alternative routing rule in the IP-to-IP Routing table that re-routes the call to the IP Group presenting the Test Call module.</li> </ul> </li> </ul> <p>When the IP-to-IP call fails, the device uses the alternative routing rule to re-route the call to the Test Call module, which sends a SIP 183 response to</p>



Parameter	Description
	the caller, playing the specified tone.
'Play Tone Index' play-tone-index [Test_Call_PlayToneIndex]	<p>Defines the tone that you want played from the installed PRT file, to the called party when the call is answered.</p> <p>The valid value is the index number (1-80) of the tone in the PRT file. By default (-1), the device plays the tone defined at index 22 "acDialTone2".</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if you configure the 'Play' parameter to <b>PRT</b>.</li> <li>■ To play user-defined tones, you need to record your tones and then install them on the device using a loadable Prerecorded Tones (PRT) file, which is created using AudioCodes DConvert utility. When you create the PRT file, each recorded tone file must be added to the PRT file with the tone type "acUserDefineTone&lt;Index&gt;". For more information, see <a href="#">Uploading a Prerecorded Tones File</a> on page 1228.</li> </ul>
'Schedule Interval' schedule-interval [Test_Call_ScheduleInterval]	<p>Defines the interval (in minutes) between automatic outgoing test calls.</p> <p>The valid value range is 0 to 100000. The default is 0 (i.e., scheduling is disabled).</p> <p><b>Note:</b> The parameter is applicable only if you configure 'Call Party' to <b>Caller</b>.</p>

## Using SIP INVITE to Specify Test Call Duration

For test call endpoints where the remote SIP UA is the initiator of the test call (i.e., 'Call Party' parameter configured to **Called**), the duration of the test call can be determined by the incoming SIP INVITE message, instead of when the caller ends the call (i.e., sends a SIP BYE message).

The duration in the SIP INVITE message is specified using the 'duration=' parameter of the Request-URI, for example:

```
INVITE sip:3000@10.8.51.29;user=phone;duration=10000 SIP/2.0
```

The duration is in milliseconds, but the device rounds it off to the nearest seconds.

This feature is in accordance with RFC 4240 (Basic Network Services with SIP).

This feature is also used by the device for reporting MOS to WebRTC clients, as described in [Measuring and Reporting MOS to WebRTC Platforms using Test Calls](#).

## Starting and Stopping Test Calls

The following procedure describes how to start, stop, and restart test calls.

### ➤ To start, stop, and restart a test call:

1. In the Test Call Rules table, select the required test call entry.
2. From the **Action** drop-down list, choose the required command:
  - **Dial**: Starts the test call (applicable only if the test call party is the caller).
  - **Drop Call**: Stops the test call.
  - **Restart**: Ends all established calls and then starts the test call session again.

## Viewing Test Call Status

You can view the status of test call rules in the 'Test Status' field of the Test Call Rules table. The status can be one of the following:

**Table 65-2: Test Call Status Description**

Status	Description
"Idle"	Test call is not active.
"Scheduled"	Test call is planned to run (according to the 'Schedule Interval' parameter).
"Running"	Test call has been started (i.e., by clicking <b>Dial</b> from the 'Action' drop-down list).
"Receiving":	Test call has been automatically activated by calls received from the remote endpoint for the test call endpoint (when all these calls end, the status returns to "Idle").
"Terminating"	Test call is in the process of terminating currently established calls (when <b>Drop Call</b> is clicked from the 'Action' drop-down list to stop the test).
"Done"	Test call has successfully completed (or was prematurely stopped by clicking the <b>Drop Call</b> from the 'Action' drop-down list).

## Viewing Test Call Statistics

You can view statistical information on the test call.



- On the receiving side, when the first call is accepted in "Idle" state, statistics are reset.
- The device also generates CDRs for test calls if you have enabled CDR generation (see [Configuring CDR Filters and Report Level](#) on page 1382). To view CDRs of test calls, see [Viewing Gateway CDR History](#) on page 1361.

➤ **To view statistics of a test call:**

1. In the Test Call Rules table, select the required test call row.
2. Scroll down the page to the area below the table. Statistics of the selected test call are displayed under the **Statistics** group, as shown in the example below:

STATISTICS	
Active Calls	0
Call Attempts	1
Total Established Calls	1
Total Failed Attempts	0
Remote Disconnections Count	1
Average CPS	1.00
Elapsed Time [HH:MM:SS]	00:00:20
Test Status	Done
Detailed Status	Done - Established Calls: 1, ASR: 100%
MOS Status	Local:N/A, Remote:N/A
Delay Status	Local:6 msec (Green), Remote:N/A
Jitter Status	Local:75 msec (Red), Remote:0 msec (Green)
Packet Loss Status	Local:0% (Green), Remote:0% (Green)
Bandwidth Status	Rx:0 KBytes/s (Green), Tx:0 KBytes/s (Green)

The statistics fields are described in the following table:

**Table 65-3: Test Call Statistics Description**

Statistics Field	Description
<b>Active Calls</b>	Number of currently established test calls.
<b>Call Attempts</b>	Number of calls that were attempted.
<b>Total Established Calls</b>	Total number of calls that were successfully established.
<b>Total Failed Attempts</b>	Total number of call attempts that failed.
<b>Remote</b>	Number of calls that were disconnected by the remote side.

Statistics Field	Description
<b>Disconnections Count</b>	
<b>Average CPS</b>	Average calls per second.
<b>Elapsed Time</b>	Duration of the test call since it was started (or restarted).
<b>Test Status</b>	Status (brief description) as displayed in the 'Test Status' field (see <a href="#">Viewing Test Call Status</a> on page 1546).
<b>Detailed Status</b>	<p>Displays a detailed description of the test call status:</p> <ul style="list-style-type: none"> <li>■ "Idle": Test call is currently not active.</li> <li>■ "Scheduled - Established Calls: &lt;number of established calls&gt;, ASR: &lt;ASR&gt;%": Test call is planned to run (according to 'Schedule Interval' parameter settings) and also shows the following summary of completed test calls: <ul style="list-style-type: none"> <li>✓ Total number of test calls that were established.</li> <li>✓ Number of successfully answered calls out of the total number of calls attempted (ASR).</li> </ul> </li> <li>■ "Running (Calls: &lt;number of active calls&gt;, ASR: &lt;ASR&gt;%)": Test call has been started (i.e., the <b>Dial</b> command was clicked) and shows the following: <ul style="list-style-type: none"> <li>✓ Number of currently active test calls.</li> <li>✓ Number of successfully answered calls out of the total number of calls attempted (Answer Success Ratio or ASR).</li> </ul> </li> <li>■ "Receiving (&lt;number of active calls&gt;)": Test call has been automatically activated by calls received for this configured test call endpoint from the configured remote endpoint. When all these calls terminate, the status returns to "Idle".</li> <li>■ "Terminating (&lt;number of active calls&gt;)": The <b>Drop Call</b> command has been clicked to stop the test call and the test call is in the process of terminating the currently active test calls.</li> <li>■ "Done - Established Calls: &lt;number of established calls&gt;, ASR: &lt;ASR&gt;%": Test call has been successfully completed (or was prematurely stopped by clicking the <b>Drop Call</b> command) and shows the following: <ul style="list-style-type: none"> <li>✓ Total number of test calls that were established.</li> <li>✓ Number of successfully answered calls out of the total</li> </ul> </li> </ul>

Statistics Field	Description
	number of calls attempted (ASR).
<b>MOS Status</b>	MOS count and color threshold status of local and remote sides according to the assigned QoE Profile.
<b>Delay Status</b>	Packet delay count and color-threshold status of local and remote sides according to the assigned QoE Profile.
<b>Jitter Status</b>	Jitter count and color-threshold status of local and remote sides according to the assigned QoE Profile.
<b>Packet Loss Status</b>	Packet loss count and color-threshold status of local and remote sides according to the assigned QoE Profile.
<b>Bandwidth Status</b>	Tx/Rx bandwidth and color-threshold status according to the assigned Bandwidth Profile.

## Configuring DTMF Tones for Test Calls

By default, the device plays the DTMF signal tone "3212333" to remote tested endpoints for answered calls (incoming and outgoing). For basic test calls (as described in [Configuring Basic Incoming Test Calls](#) on the next page), the device can play only the configured DTMF tones (or none, if not configured). For test call endpoints that are configured in the Test Call Rules table, you can configure the device to play either DTMF tones or a tone from an installed PRT file (Test Call Tone). For more information, see [Configuring Test Call Endpoints](#) on page 1534.



- You can configure the DTMF signaling type (e.g., out-of-band or in-band) using the 'DTMF Transport Type' [DTMFTransportType] parameter.
- To generate DTMF tones, the device's DSP resources are required.

### ➤ To configure played DTMF signal to answered test call:

1. Open the Test Call Settings page (**Troubleshoot** menu > **Troubleshoot** tab > **Test Call** folder > **Test Call Settings**).
2. In the 'Test Call DTMF String' field, enter the DTMF string (up to 15 digits):

Test Call DTMF String

3212333

3. Click **Apply**.


## Configuring Basic Incoming Test Calls

The Basic Test Call feature tests **incoming** calls from remote SIP (IP) endpoints to a single simulated test endpoint on the device. The only required configuration is to assign a prefix number (*Test Call ID*) to the simulated endpoint. The device identifies incoming calls whose SIP INVITE Request-URI user part (i.e., called number) matches this prefix number as basic test calls and sends it to the simulated endpoint (see note below).



The device **first** checks if the incoming call matches a rule in the Test Calls Rules table (see [Configuring Test Call Endpoints](#) on page 1534). A matching rule is one whose 'Endpoint URI' parameter value is **identical** to the user part of the incoming SIP INVITE Request-URI. Only if there is no matching rule does the device check if the prefix of the user part matches the 'Test Call ID' parameter value (see below) configured for this Basic Test Call feature.

For example, if you configure the prefix number (Test Call ID) of the test endpoint (see procedure below) to "101" and the incoming INVITE Request-URI user part is 101, 10123, or 10145, the device considers this call as a basic test call because the prefix of the user part matches the test endpoint's Test Call ID ("101"). The figure below displays a basic test call example:



- You can configure the device to play DTMF tones to the remote endpoint (see [Configuring DTMF Tones for Test Calls](#) on the previous page).
- The Basic Test Call feature uses the default IP Group (ID #0) and its associated IP Profile (if exists).
- Test calls are done on all SIP Interfaces.

### ➤ To configure basic call testing:

1. Open the Test Call Settings page (**Troubleshoot** menu > **Troubleshoot** tab > **Test Call** folder > **Test Call Settings**).
2. In the 'Test Call ID' field, enter a prefix for the simulated endpoint:

GENERAL

Test Call ID

For a full description of the parameter, see [SIP Test Call Parameters](#) on page 1624.

3. Click **Apply**.

## Test Call Rules Configuration Examples

Below are test call configuration examples.


■ **Outgoing Test Call:** This example describes the configuration for testing outgoing calls:

- Test Call Rules table:
  - ◆ Endpoint URI: "101"
  - ◆ Called URI: "201"
  - ◆ Route By: **IP Group**
  - ◆ IP Group: **MyTest**
  - ◆ Call Party: **Caller**
  - ◆ Test Mode: **Once**

■ **Incoming Test Call:** This example describes the configuration for testing incoming calls:

- Test Call Rules table:
  - ◆ Endpoint URI: "201"
  - ◆ Route By: **IP Group**
  - ◆ IP Group: **MyTest**
  - ◆ Call Party: **Called**
  - ◆ Test Mode: **Once**

■ **Single Test Call:** This example describes the configuration of a simple outgoing test call scenario that includes a single test call between a simulated test endpoint on the device and a remote endpoint.




- Test Call Rules table:
  - ◆ Endpoint URI: "101"
  - ◆ Called URI: "201"
  - ◆ Route By: **Dest Address**

- ◆ Destination Address: "10.30.40.01"
- ◆ SIP Interface: SIPInterface\_0
- ◆ Call Party: **Caller**
- ◆ Test Mode: **Once**

Alternatively, if you want to route the test call using the Tel-to-IP Routing table for the Gateway application, configure the following:

- Test Call Rules table:
  - ◆ Endpoint URI: 101@10.0.0.1
  - ◆ Route By: Tel-to-IP
  - ◆ SIP Interface: SIPInterface\_0
  - ◆ Called URI: 201@10.30.40.1
  - ◆ Call Party: Caller
- Tel-to-IP Routing table:
  - ◆ Destination Phone Prefix: 201 (i.e., the Called URI user-part)
  - ◆ Source Phone Prefix: 101 (i.e., the Endpoint URI user-part)
  - ◆ Destination IP Address: 10.30.40.1

■ **Batch Test Calls:** This example describes the configuration of a batch test call setup for scheduled and continuous call testing of multiple endpoints. The test call is done between two AudioCodes devices - Device A and Device B - with simulated test endpoints. This eliminates the need for phone users, who would otherwise need to answer and end calls many times for batch testing. The calls are initiated from Device A, where Device B serves as the remote answering endpoint.




- Test Call Rules table at Device A:
  - ◆ Endpoint URI: "101"
  - ◆ Called URI: "201"
  - ◆ Route By: **Dest Address**



- ◆ Destination Address: "10.13.4.12"
- ◆ SIP Interface: SIPInterface\_0
- ◆ Call Party: **Caller**
- ◆ Maximum Channels for Session: "3" (configures three endpoints - "101", "102" and "103")
- ◆ Call Duration: "5" (seconds)
- ◆ Calls per Sec: "1"
- ◆ Test Mode: **Continuous**
- ◆ Test Duration: "3" (minutes)
- ◆ Schedule Interval: "180" (minutes)
- Test Call Rules table at Device B:
  - ◆ Endpoint URI: "201"
  - ◆ Maximum Channels for Session: "3" (configures three endpoints - "201", "202" and "203")

■ **Registration Test Call:** This example describes the configuration for testing the registration and authentication (i.e., username and password) process of a simulated test endpoint on the device with an external proxy/registrar server. This is useful, for example, for verifying that endpoints located in the LAN can register with an external proxy and subsequently, communicate with one another.



This example assumes that you have configured your device for communication between LAN phone users such as IP Groups to represent the device (10.13.4.12) and the proxy server, and IP-to-IP routing rules to route calls between these IP Groups.

- Test Call Rules table:

- ◆ Endpoint URI: "101"
- ◆ Called URI: "itsp"
- ◆ Route By: **Dest Address**
- ◆ Destination Address: "10.13.4.12" (this is the IP address of the device itself)
- ◆ SIP Interface: SIPInterface\_0
- ◆ Auto Register: **Enable**
- ◆ User Name: "testuser"
- ◆ Password: "12345"
- ◆ Call Party: **Caller**

## 66 Pinging a Remote Host or IP Address

You can verify the network connectivity with a remote host or IP address by pinging the network entity.

- IPv4: The ping to an IPv4 address can be done from any of the device's VoIP interfaces that is configured with an IPv4 address. The ping is done using the following CLI command:

```
# ping <IPv4 ip address or hostname> source [voip] interface
```

For a complete description of the ping command, refer to the *CLI Reference Guide*.

## 67 Accessing Device's File System through SFTP for File Download

You can access certain files on the device's file system through Secure File Transfer Protocol (SFTP) and download (`get`) them to a folder on your local computer.

You can use any third-party SFTP clients such as WinSCP or FileZilla. SFTP uses the SSH protocol to authenticate and establish a secure connection. Therefore, before you can access the device's file system, your SFTP client needs to authenticate itself with the SFTP server (i.e., the device). The device performs standard user authentication, where you can set it up to check the user's credentials in the Local Users table (see [Configuring Local Management User Accounts](#) on page 54) or with a remote authentication server.


You can access the following folders under the root directory:

- **/configuration:** Contains the CLI Script file, Configuration Package file, ini file, License file. For more information on downloading the Configuration Package file, see [Downloading or Uploading Configuration Package File](#) on page 1260
- **/debug:** Contains the debug file and core dump file. For more information, see [Downloading the Debug \(and Core Dump\) File](#) on page 1525
- **/debug-capture:** Contains the stored network capture files (generated using the CLI command `debug capture`).
- **/mnt:** Contains the contents of a mounted USB drive when it's plugged into the device.

### ➤ To access device's file system through SFTP:

1. Enable SSH on the device (see [Configuring CLI over SSH using Public Key Authentication](#) on page 92).
2. Start your SFTP client and connect to the device.
3. Open the file system folder in which the required file is stored, and then view or download the file.

The following shows an example of the device's file system accessed through SFTP. Note that some folders may not be relevant to your device type.



- Access privileges to the device's file system through SFTP depends on user level:
  - ✓ **Security Administrator** users can access all folders.
  - ✓ **Administrator** users can access only folders containing the CDRs and SDRs (i.e., `/cdr`, `/cdr-gw`).
  - ✓ **Monitor** users can't access any folder.
- Only file viewing and downloading operations are supported through SFTP.
- The device may take a long time to prepare the debug file for SFTP transfer if it contains much information. Some SFTP clients (for example, WinSCP and FileZilla) have a short default connection timeout and if the file transfer is not started within this timeout, the transfer attempt is aborted. Therefore, it's recommended to configure a longer timeout for your SFTP client application.
- When the device is in HA mode, you can access from the active device the files stored on the redundant device's flash memory through SFTP. For more information, see [Accessing Files on Redundant Device from Active through SSH](#) on page 1200.
- If you're using the SFTP Cyberduck client and downloading a file from the `/configuration` or `/debug` folder, the client may display a "Transfer incomplete" error message, even though the download is successful. Therefore, please disregard this error message.

# Part XI

## Appendix

## 68 Patterns for Denoting Phone Numbers and SIP URIs

The table below lists the supported patterns (notations) that you can use in various configuration tables for matching rules, based on source and/or destination phone numbers and SIP URIs (user@host parts).



- When configuring phone numbers in the Web interface, enter them only as digits without any other characters. For example, if you wish to enter the phone number 555-1212, type it as 5551212 without the hyphen (-). If the hyphen is entered, the entry is invalid.
- For the Inbound Manipulations table (see [Configuring IP-to-IP Inbound Manipulations](#) on page 1121) and the Outbound Manipulations table (see [Configuring IP-to-IP Outbound Manipulations](#) on page 1126), the comma (,) can only be used as a separator in the pattern and not as a special comma character.

**Table 68-1: Supported Patterns for Phone Numbers and SIP URIs**

Pattern	Description
x (letter "x")	Wildcard that denotes any single digit or character.
# (pound symbol)	<ul style="list-style-type: none"> <li>■ When located at the end of a pattern, it denotes the end of a number. For example, <b>54324#</b> denotes a 5-digit number that starts with the digits 54324.</li> <li>■ When located anywhere in the pattern except at the end, it is part of the number (pound key). For example, <b>3#45</b> represents the prefix number 3#45.</li> <li>■ To denote the # key when it appears at the end of the number, enclose it in square brackets. For example, <b>134[#]</b> denotes any number that starts with 134#.</li> </ul>
* (asterisk symbol)	<ul style="list-style-type: none"> <li>■ When used on its own, it denotes any number or string.</li> <li>■ When used as part of a number, it denotes the asterisk (*) key. For example, <b>*345</b> denotes a number that starts with *345.</li> </ul>
\$ (dollar sign)	<p>For incoming IP calls: Denotes a Request-URI that doesn't have a user part.</p> <p>For incoming Tel calls: Denotes a Tel-to-IP call that doesn't have a called or calling number.</p> <p>This pattern is used for the following matching criteria:</p> <ul style="list-style-type: none"> <li>■ Source and Destination Phone</li> </ul>

Pattern	Description
	<ul style="list-style-type: none"> <li>■ Source and Destination Username</li> <li>■ Source and Destination Calling Name</li> </ul>
Range of Digits	<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ To denote a prefix that is a range, enclose it in square brackets, for example, <b>[4-8]</b> or <b>23xx[456]</b>.</li> <li>■ To denote a prefix that is not a range, do not enclose in brackets, for example, <b>12345#</b>.</li> <li>■ To denote a suffix, enclose it in parenthesis, for example, <b>(4)</b> and <b>(4-8)</b>.</li> <li>■ To denote a suffix that includes multiple ranges, enclose the range in square brackets, for example, <b>(23xx[4,5,6])</b>.</li> </ul> <p>Example of using both a prefix and a suffix in a pattern: Assume you want to match a rule whose destination phone prefix is 4 through 8, and suffix is 234, 235, or 236. The pattern for this would be: <b>[4-8](23[4,5,6])</b>.</p>
<b>[n-m]</b> or <b>(n-m)</b>	<p>Denotes a range of numbers.</p> <p>Examples:</p> <ul style="list-style-type: none"> <li>■ To denote prefix numbers from 5551200 to 5551300: <ul style="list-style-type: none"> <li>✓ <b>[5551200-5551300]#</b></li> </ul> </li> <li>■ To denote prefix numbers from 123100 to 123200: <ul style="list-style-type: none"> <li>✓ <b>123[100-200]#</b></li> </ul> </li> <li>■ To denote prefix and suffix numbers together: <ul style="list-style-type: none"> <li>✓ <b>03(100)</b>: for any number that starts with 03 and ends with 100.</li> <li>✓ <b>[100-199](100,101,105)</b>: for a number that starts with 100 to 199 and ends with 100, 101 or 105.</li> <li>✓ <b>03(abc)</b>: for any number that starts with 03 and ends with abc.</li> <li>✓ <b>03(5xx)</b>: for any number that starts with 03 and ends with 5xx.</li> <li>✓ <b>03(400,401,405)</b>: for any number that starts with 03 and ends with 400 or 401 or 405.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The value <i>n</i> must be less than the value <i>m</i>.</li> <li>■ Only numerical ranges are supported (not letters).</li> <li>■ For suffix ranges, the starting (<i>n</i>) and ending (<i>m</i>) numbers in the</li> </ul> </li></ul>



Pattern	Description
	range must include the same number of digits. For example, (23-34) is correct, but (3-12) is not.
<b>[n,m] or (n,m)</b>	<p>Denotes multiple numbers. The value can include digits or characters. Examples:</p> <ul style="list-style-type: none"> <li>■ To denote a one-digit number starting (prefix) with 2, 3, 4, 5, or 6: <b>[2,3,4,5,6]</b></li> <li>■ To denote a one-digit number ending (suffix) with 7, 8, or 9: <b>(7,8,9)</b></li> <li>■ Prefix with suffix: <b>[2,3,4,5,6](7,8,9)</b> - prefix is denoted in square brackets; suffix in parenthesis</li> </ul> <p>For <b>prefix only</b>, the patterns <i>d[n,m]e</i> and <i>d[n-m]e</i> can also be used:</p> <ul style="list-style-type: none"> <li>■ To denote a five-digit number that starts with 11, 22, or 33: <b>[11,22,33]xxx#</b></li> <li>■ To denote a six-digit number that starts with 111 or 222: <b>[111,222]xxx#</b></li> </ul>
<b>[n1-m1,n2-m2,a,b,c,n3-m3] or (n1-m1,n2-m2,a,b,c,n3-m3)</b>	<p>Denotes a mixed pattern of single numbers and multiple number ranges. For example, to denote numbers 123 through 130, 455, 766, and 780 through 790:</p> <ul style="list-style-type: none"> <li>■ Prefix: <b>[123-130,455,766,780-790]</b></li> <li>■ Suffix: <b>(123-130,455,766,780-790)</b></li> </ul> <p><b>Note:</b> The ranges and the single numbers in the mixed pattern must have the same number of digits. For example, each number range and single number in the examples above consists of three digits (e.g., 780).</p>
<b>Special ASCII Characters</b>	<p>The device doesn't support the use of ASCII characters in manipulation rules. Instead, you need to use the hexadecimal (HEX) format of the ASCII characters for phone numbers.</p> <p>The HEX value must be preceded by a backslash “\”. For example, you can configure a manipulation rule that changes the received number <b>+49 (7303) 165-xxxxx</b> to <b>+49 \287303\29 165-xxxxx</b>, where \28 is the ASCII HEX value for “(” and \29 is the ASCII HEX value for “)”. The manipulation rule in this example would denote the parenthesis in the destination number prefix using “x” wildcards (e.g., xx165xxxxx#); the prefix to add to the number would include the HEX values (e.g., +49 \287303\29 165-).</p> <p>Below is a list of common ASCII characters and their corresponding HEX values:</p>

Pattern	Description
	<ul style="list-style-type: none"><li>■ *:\2a</li><li>■ (\:\28</li><li>■ ):\29</li><li>■ \:\5c</li><li>■ /\:2f</li></ul>

## 69 Configuration Parameters Reference

The device's VoIP functionality configuration parameters, default values, and their descriptions are documented in this section.



Parameters and values enclosed in square brackets [...] represent ini file parameters and their enumeration values.

### Management Parameters

This section describes the device's management-related parameters.

#### General Parameters

The general management parameters are described in the table below.

**Table 69-1: General Management Parameters**

Parameter	Description
'Web Server Name' <code>configure system &gt; web &gt; web-hostname</code> [WebHostname]	Defines a hostname (FQDN) for the device's Web interface. This can be used to access the Web interface instead of the device's IP address.  By default, no value is defined.  For more information, see <a href="#">Configuring a Hostname for Device's Web Interface</a> on page 86.  <b>Note:</b> If not configured, the device uses the [Hostname] parameter.
'Enforce Web Host Name' <code>configure system &gt; web &gt; enforce-web-host-name</code> [EnforceWebHostname]	Enables the enforcement of access to the device's Web interface through a hostname only, and blocks any attempt to access the Web interface through the device's IP address.  <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = Disabled. The Web interface can be accessed through a hostname or an IP address.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = (Default) Enabled. Enforces access to the Web interface only through a hostname if you've configured a hostname. For more information, see <a href="#">Configuring a Hostname for Device's Web Interface</a> on page 86.</li> </ul>

Parameter	Description
	<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Due to a known issue, the following OVOC features <b>don't</b> function when the 'Enforce Web Host Name' parameter is enabled: <ul style="list-style-type: none"> <li>✓ OVOC Single Sign-On (SSO)</li> <li>✓ OVOC Performance Monitoring (PM)</li> <li>✓ OVOC Service Availability</li> </ul> </li> <li>■ If you need to use any of these OVOC features, make sure that the 'Enforce Web Host Name' parameter is disabled.</li> <li>■ To configure a hostname for the Web interface, see the 'Web Server Name' parameter.</li> <li>■ If you disable the parameter or you don't configure the 'Web Server Name' parameter, the Web interface can be accessed through an FQDN or IP address.</li> <li>■ If you're upgrading the device from version 7.4.500-2 (7.40A.500.775) or later to version 7.4.500-5 or later and have configured the 'Web Server Name' parameter and use the device's IP address to access the Web interface, access to the device through the IP address will be denied. If you want to retain such capability, disable the 'Enforce Web Host Name' parameter.</li> </ul>
<p>'Hostname'</p> <pre>configure system &gt; hostname</pre> <p>[Hostname]</p>	<p>Defines a hostname for the device, which is used for various functionality such as the CLI prompt name.</p> <p>The valid value is a string of up to 18 characters. By default, no value is defined.</p> <p>For more information, see <a href="#">Configuring a Hostname for the Device</a> on page 143.</p> <p><b>Note:</b> To configure a hostname for accessing the device's Web interface, use the [WebHostname] parameter.</p>
[WebLoginBlockAutoComplete]	Disables autocompletion when entering the

Parameter	Description
	<p>management login username in the 'Username' field of the device's Web interface. Disabling autocompletion may be useful for security purposes by hiding previously entered usernames and thereby, preventing unauthorized access to the device's management interface.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) Autocompletion is enabled and the 'Username' field automatically offers previously logged in usernames.</li> <li>■ [1] <b>Enable</b> = Autocompletion is disabled.</li> </ul>
<p>'Enforce Username Complexity'</p> <pre>configure system &gt; users- settings &gt; enforce- username-complexity</pre> <p>[EnforceUsernameComplexity]</p>	<p>Enables the enforcement of username complexity.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>For more information, see <a href="#">Configuring Login Username and Password Complexity</a> on page 64.</p>
<p>'Username Complexity Check By Regex'</p> <pre>configure system &gt; users- settings &gt; username- complexity-check-by-regex</pre> <p>[UsernameComplexityCheckByRegex]</p>	<p>Defines a username complexity policy by a regular expression (regex).</p> <p>By default, no regex is defined.</p> <p>For more information, see <a href="#">Configuring Login Username and Password Complexity</a> on page 64.</p>
<p>'Enforce Password Complexity'</p> <pre>configure system &gt; users- settings &gt; enforce- password-complexity</pre> <p>[EnforcePasswordComplexity]</p>	<p>Enables the enforcement of password complexity.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>For more information, see <a href="#">Configuring Login Username and Password Complexity</a> on page 64.</p>
<p>'Password Complexity Check By Regex'</p>	<p>Defines a password complexity policy by a regular expression (regex).</p>

Parameter	Description
<pre>configure system &gt; users- settings &gt; password- complexity-check-by-regex</pre> [PasswordComplexityCheckByRegex]	<p>By default, no regex is defined.</p> <p>For more information, see <a href="#">Configuring Login Username and Password Complexity</a> on page 64.</p>
<pre>configure system &gt; web &gt; min-web-password-len</pre> [MinWebPasswordLen]	<p>Defines the minimum length (number of characters) of the management user's login password when password complexity is enabled.</p> <p>The valid value is a string of 8 to 20 characters. The default is 8.</p> <p><b>Note:</b> To enable password complexity, use the [EnforcePasswordComplexity] parameter.</p>
<pre>configure system &gt; web &gt; check-password-history</pre> [CheckPasswordHistory]	<p>Enables the device to enforce password history policy (reuse an old password), which prohibits a user from changing its password to any of the user's four previous passwords.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable</li> <li>■ [1] = Enable</li> </ul> <p><b>Note:</b> The parameter is not applicable to the password for the CLI privileged mode (&gt; enable).</p>
<p>'Use OAuth for Web Login'</p> <pre>configure system &gt; mgmt- auth &gt; oauth-web-login</pre> [OAuthWebLogin]	<p>Enables user login authentication based on OAuth 2.0.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) Disables OAuth-based login authentication.</li> <li>■ [1] <b>Enable with local login</b> = Enables both OAuth-based login authentication and local authentication (using the Local Users table as described in <a href="#">Configuring Local Management User Accounts</a> on page 54).</li> <li>■ [2] <b>Enable without local login</b> = Enables OAuth-based login authentication only (without local authentication).</li> </ul> <p>For more information, see <a href="#">Enabling OAuth-based User Login Authentication</a> on page 421.</p>
'Local Users Table can be Empty'	Enables (allows) the deletion of all users in the

Parameter	Description
<pre>configure system &gt; web &gt; local-users-table-can-be- empty</pre> <p>[AllowRemoveLocalUsersTable]</p>	<p>Local Users table (see <a href="#">Configuring Local Management User Accounts</a> on page 54). This is used when an external, third-party service (e.g., LDAP, RADIUS, or OAuth) is used to authenticate users.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>For more information, see <a href="#">Deleting All Users in Local Users Table</a> on page 63.</p>
<p>'Lock'</p> <pre>admin state lock</pre> <p>[AdminState]</p>	<p>Locks the device, whereby existing calls are terminated (optionally, after a graceful period) and new calls are rejected.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Lock</b></li> <li>■ [2] <b>Unlock</b> (default)</li> </ul> <p>For more information, see <a href="#">Locking and Unlocking the Device</a> on page 1205.</p>
<p>'Graceful Option'</p> <pre>admin state lock graceful</pre> <p>[AdminStateLockControl]</p>	<p>Defines a graceful period (in seconds) before the device locks. During this period, the device doesn't accept any new calls, allowing only existing calls to continue until the timeout expires. If all existing calls end before the timeout expires, the device locks. If there are still existing calls when the timeout expires, the device terminates them and then locks.</p> <p>The valid value is 0 to 32,768 seconds. The default is 0, meaning no graceful lock (i.e., immediate lock). A value of -1 means that the device locks only after all the existing calls end (on their own accord).</p> <p>For more information, see <a href="#">Locking and Unlocking the Device</a> on page 1205.</p>
<p>'Disconnect Client Connections'</p> <pre>admin state lock no- graceful disconnect-client- connections</pre> <p>[AdminStateRestrictConnections]</p>	<p>Enables the device to close existing TLS/TCP client connections and reject incoming TLS/TCP client connections when the device is in locked state.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> </ul>

Parameter	Description
	<p>■ [1] <b>Enable</b></p> <p>For more information, see <a href="#">Locking and Unlocking the Device</a> on page 1205.</p>
[CustomerSN]	<p>Defines a serial number (S/N) for the device.</p> <p><b>Note:</b> The device's original S/N is automatically added at the end of the configured S/N. For example, if the original S/N is 8906721 and the configured S/N is "abc123", the resultant S/N is "abc1238906721".</p>

## Web Parameters

The Web parameters are described in the table below.

**Table 69-2: Web Parameters**

Parameter	Description
<p>'Password Change Interval'</p> <pre>configure system &gt; web &gt; web-password- change-interval</pre> <p>[WebPassChangeInterval]</p>	<p>Defines the minimum duration (in minutes) between login password changes. For example, if you configure the parameter to 60, you can only change the password if at least 60 minutes has elapsed since the password was last changed.</p> <p>The valid value is 0 to 100,000. The default is 0, meaning that the password can be changed at any time.</p>
<p>'Password Expired Alarm'</p> <pre>configure system &gt; mgmt-auth &gt; password-expired- alarm</pre> <p>[RaiseAlarmXDaysBeforePwExpired]</p>	<p>Defines the number of days before login password expiration when the device sends the acExpiredPasswordAlarm SNMP alarm.</p> <p>The valid range is 0 to 120. The default is 14. A value of 0 disables this alarm from being sent.</p> <p>For more information, see <a href="#">Configuring Login Password Expiration Alarm</a> on page 69.</p>
<p>'User Inactivity Timer'</p> <pre>configure system &gt; web &gt; user- inactivity-timeout</pre> <p>[UserInactivityTimer]</p>	<p>Defines the duration (in days) for which a user has not logged in to the Web interface, after which the status of the user becomes inactive and can no longer access the Web interface. These users can only log in to the Web interface if their status is changed (to New or Valid) by a <b>Security Administrator</b> user.</p> <p>The valid value is 0 to 10000, where 0 means inactive. The default is 90.</p>



Parameter	Description
	<p><b>Note:</b> The parameter is applicable only when using the Local Users table.</p>
<p>'Session Timeout'</p> <pre>configure system &gt; web &gt; session- timeout</pre> <p>[WebSessionTimeout]</p>	<p>Defines the duration (in minutes) of inactivity of a logged-in user in the Web interface, after which the user is automatically logged off the Web session. In other words, the session expires when the user has not performed any operations (activities) in the Web interface for the configured duration.</p> <p>The valid value is 0, or 2 to 100000, where 0 means no timeout. The default is 15.</p> <p><b>Note:</b> You can also configure the feature per user in the Local Users table (see <a href="#">Configuring Local Management User Accounts</a> on page 54), which overrides this global setting.</p>
<p>'Deny Access On Fail Count'</p> <pre>configure system &gt; web &gt; deny-access- on-fail-count</pre> <p>[DenyAccessOnFailCount]</p>	<p>Defines the maximum number of failed login attempts, after which the requesting IP address (management station) for all users is blocked.</p> <p>The valid value range is 0 to 10. The value 0 means that the feature is disabled and no blocking is done. The default is 3.</p>
<p>'Deny Authentication Timer'</p> <pre>configure system &gt; web &gt; deny-auth- timer</pre> <p>[DenyAuthenticationTimer]</p>	<p>Defines the duration (in seconds) for which login to the Web interface is denied from a specific IP address (management station) for all users when the number of failed login attempts exceeds the maximum. This maximum is configured by the [DenyAccessOnFailCount] parameter. Only after this time expires can users attempt to log in from this same IP address.</p> <p>The valid value is 0 to 100000, where 0 means that login is not denied regardless of the number of failed login attempts. The default is 60.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If the [BlockingDurationFactor] parameter is configured to a value greater than 1, the duration that the IP address is blocked is according to the [BlockingDurationFactor] parameter.</li> <li>■ To configure the duration for which the IP address is blocked, use the [DenyAuthenticationTimer] parameter.</li> </ul>


Parameter	Description
	<ul style="list-style-type: none"> <li>Up to 1,000 IP addresses (management stations) can be blocked concurrently.</li> </ul>
<p>'Blocking Duration Factor'</p> <pre>configure system &gt; web &gt; blocking- duration-factor</pre> <p>[BlockingDurationFactor]</p>	<p>Defines the number to multiple the previous blocking time for blocking the IP address (management station) or user upon the next failed login scenario.</p> <p>The valid value is 1 to 100. The default is 1, which means that the blocking time remains the same (not increased). For example, assume the following configuration:</p> <ul style="list-style-type: none"> <li>The 'Deny Access On Fail Count' parameter is configured to 3 (failed login attempts).</li> <li>The 'Block Duration' parameter in the Local Users table is configured to 10 (seconds) for user blocking, or the [DenyAuthenticationTimer] parameter is configured to 10 for IP address blocking.</li> <li>The [BlockingDurationFactor] parameter is configured to 2.</li> </ul> <p>After three failed login attempts, the device blocks the user for 10 seconds. If the user tries again to login but fails after three attempts, the device blocks the user for 20 seconds (i.e., 10 x 2). If the user tries again to login but fails after three attempts, the device blocks the user for 40 seconds (i.e., 20 x 2), and so on.</p>
<p>'Valid time of Deny Access counting'</p> <pre>configure system &gt; web &gt; deny-access- counting-valid-time</pre> <p>[DenyAccessCountingValidTime]</p>	<p>Defines the maximum time interval (in seconds) between failed login attempts to be included in the count of failed login attempts for denying access to the user.</p> <p>The valid value is 30 to 10,000,000. The default is 60. For example, assume the following:</p> <ul style="list-style-type: none"> <li>The [DenyAccessOnFailCount] parameter is configured to 3 (failed login attempts).</li> <li>The [DenyAccessCountingValidTime] parameter is configured to 30 (seconds).</li> </ul> <p>If the user makes a failed login attempt, and then makes another failed login attempt 32 seconds later, and another failed login attempt 10 seconds later, the user is not blocked by the device. This is because the interval between the first and second attempt was greater than the 30 seconds configured for the</p>

Parameter	Description
	[DenyAccessCountingValidTime] parameter. However, if the interval between all three failed login attempts is less than 30 seconds, the device blocks the user.
'Display Last Login Information' <pre>configure system &gt; web &gt; display-last-login-info</pre> [DisplayLoginInformation]	Enables the display of the user's login information upon each successful login attempt.  ■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. ■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.
'Invalid Login Report' <pre>configure system &gt; web &gt; invalid-login-report</pre> [InvalidLoginReport]	Defines the information that is provided in the logged error message (Activity Log) when a user attempts to log in to the device with the wrong username or password (i.e., authentication failure).  ■ [0] <b>General Information</b> = (Default) The logged error message only indicates that incorrect credentials were entered, without specifying if it was the username or the password that was wrong.  ■ [1] <b>Detailed Information</b> = The logged error message indicates if it was the username or the password that was wrong.
<pre>configure system &gt; web &gt; csrf-protection</pre> [CSRFProtection]	Enables cross-site request forgery (CSRF) protection of the device's embedded Web server.  ■ [0] = Disable ■ [1] = (Default) Enable  For more information, see <a href="#">Enabling CSRF Protection</a> on page 82.
<pre>configure system &gt; web &gt; http-port</pre> [HTTPport]	Defines the LAN HTTP port for Web management. To enable Web management from the LAN, configure the desired port.  The default is 80.  <b>Note:</b> For the parameter to take effect, a device restart is required.
[DisableWebConfig]	Defines if the entire Web interface is read-only.  ■ [0] = (Default) Enables modifications of parameters. ■ [1] = Web interface is read-only.

Parameter	Description
	<p>When in read-only mode, parameters can't be modified and the following pages can't be accessed: Web User Accounts, TLS Contexts, Time and Date, Maintenance Actions, Load Auxiliary Files, Software Upgrade Wizard, and Configuration File.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> </ul>
[ResetWebPassword]	<p>Enables the device to restore the default management user accounts.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disabled - currently configured user accounts (usernames and passwords) are retained.</li> <li>■ [1] = Enabled - default user accounts (listed below) are restored and all other configured users (in the Local Users table) are deleted: <ul style="list-style-type: none"> <li>✓ Security Administrator user (username <b>Admin</b> and password <b>Admin</b>)</li> <li>✓ Monitor user (username <b>User</b> and password <b>User</b>)</li> </ul> </li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ You can also restore the default management user accounts (and delete all other configured users) through SNMP, by setting acSysGenericINILine to "ResetWebPassword = 1".</li> <li>■ You can change username and password through SNMP: <ul style="list-style-type: none"> <li>✓ To change the current username, use the following syntax (but without angled brackets) in the acSysWEBAccessEntry table: <div style="background-color: #f0f0f0; padding: 10px; margin: 10px 0;"> acSysWEBAccessUserName:&lt;current username&gt;/&lt;password&gt;/&lt;new username&gt; </div> </li> <li>✓ To change the current password, use the following syntax (but without angled brackets) in the acSysWEBAccessEntry table:</li> </ul> </li> </ul>

Parameter	Description
	<pre>acSysWEBAccessUserCode:&lt;username&gt;/&lt;current password&gt;/&lt;new password&gt;</pre>
<pre>'Check Weak Passwords'</pre> <pre>configure system &gt;</pre> <pre>web &gt; check-weak-psw</pre> <pre>[WeakPasswordsCheck]</pre>	<p>Enables the weak password detection feature, which detects if a user in the Local Users table is configured with a weak password (listed in the Weak Passwords List table).</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>For more information, see <a href="#">Detection of Weak Login Passwords</a> on page 66.</p>
<pre>configure system &gt;</pre> <pre>welcome-msg</pre> <pre>[WelcomeMessage]</pre>	<p>Defines a welcome message displayed on the Web interface's Web Login page.</p> <p>The format of the ini file table parameter is:</p> <pre>[WelcomeMessage ]</pre> <pre>FORMAT Index = Text</pre> <pre>[\WelcomeMessage]</pre> <p>For example:</p> <pre>FORMAT Index = Text</pre> <pre>WelcomeMessage 1 =</pre> <pre>***** ;</pre> <pre>WelcomeMessage 2 = "***** This is a</pre> <pre>Welcome message ***" ;</pre> <pre>WelcomeMessage 3 =</pre> <pre>***** ;</pre> <p>For more information, see <a href="#">Creating a Login Welcome Message</a> on page 50.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Each index row represents a line of text. Up to 20 lines (or rows) of text can be defined.</li> <li>■ The configured text message must be enclosed in double quotation marks (i.e., "...").</li> <li>■ If the parameter is not configured, no Welcome message is displayed.</li> </ul>

Parameter	Description
[UseProductName]	<p>Enables the option to customize the name of the device (product) that appears in the management interfaces.</p> <ul style="list-style-type: none"> <li>■ [0] = Disabled (default).</li> <li>■ [1] = Enables the display of a user-defined name, which is configured by the [UserProductName] parameter.</li> </ul> <p>For more information, see <a href="#">Customizing the Product Name</a> on page 47.</p>
[UserProductName]	<p>Defines a name for the device instead of the default name.</p> <p>The value can be a string of up to 29 characters.</p> <p>For more information, see <a href="#">Customizing the Product Name</a> on page 47.</p> <p><b>Note:</b> To enable customization of the device name, see the [UseProductName] parameter.</p>
<pre>configure system &gt; web &gt; web-logo- enable</pre> <p>[UseWebLogo]</p>	<p>Enables the Web interface to display user-defined text instead of an image (logo).</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) The Web interface displays a logo image, which is configured by the [LogoFileName] parameter.</li> <li>■ [1] = The Web interface displays text (instead of an image), which is configured by the [WebLogoText] parameter (see note).</li> </ul> <p>For more information, see <a href="#">Corporate Logo</a> on page 43.</p> <p><b>Note:</b> If you want to display text instead of an image, configure [UseWebLogo] to 1 and make sure that [LogoFileName] is not configured to any value. If [LogoFileName] is configured, it overrides [UseWebLogo] and an image will always be displayed.</p>
<pre>configure system &gt; web &gt; web-logo-text</pre> <p>[WebLogoText]</p>	<p>Defines the text that is displayed instead of the logo in the Web interface.</p> <p>The valid value is a string of up to 15 characters.</p> <p>For more information, see <a href="#">Replacing Corporate Logo with Text</a> on page 45.</p> <p><b>Note:</b> The parameter is applicable only when the [UseWebLogo] parameter is configured to [1].</p>

Parameter	Description
[LogoFileName]	<p>Defines the name of the image file that you want loaded to the device. This image is displayed as the logo in the Web interface (instead of the AudioCodes logo).</p> <p>The file name can be up to 47 characters.</p> <p>For more information, see <a href="#">Replacing the Corporate Logo with an Image</a> on page 44.</p> <p><b>Notes:</b></p> <ul style="list-style-type: none"> <li>■ The image file type can be one of the following: GIF, PNG, JPG, or JPEG.</li> <li>■ The size of the image file can be up to 64 Kbytes.</li> </ul>
[ExternalDocumentsBaseURL]	<p>When the Web interface is set up for private labeling (e.g., non-default logo on toolbar), the parameter enables the Web interface's toolbar to display the  icon, which provides a drop-down list of documents that can be referenced.</p> <p>Add a forward slash ("/") at the end of the parameter's value:</p> <div> <pre>ExternalDocumentsBaseURL = 'https://acredirect.azurewebsites.net/api/'</pre> </div>

## Telnet and CLI Parameters

The Telnet parameters are described in the table below.

**Table 69-3: Telnet Parameters**

Parameter	Description
<p>'Enable Telnet Server'</p> <pre>configure system &gt; cli- settings &gt; telnet</pre> <p>[TelnetServerEnable]</p>	<p>Enables the device's embedded Telnet server.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable Unsecured</b></li> <li>■ [2] <b>Enable Secured</b></li> </ul> <p><b>Note:</b> Only <b>Security Administrator</b> users can access the CLI's Privileged command mode.</p>
<p>'Idle Timeout'</p> <pre>configure system &gt; cli-</pre>	<p>Defines the duration of an idle CLI (Telnet or SSH) session after which the session is automatically</p>

Parameter	Description
<pre>settings &gt; idle-timeout</pre> <p>[TelnetServerIdleDisconnect]</p>	<p>disconnected.</p> <p>The valid range is any value. The default is 5. When configured to 0, idle sessions are not disconnected.</p> <p><b>Note:</b> If you change the parameter's value when there are current Telnet/SSH sessions, the parameter's previous setting is still applied to these current sessions and the parameter's new setting is applied only to new sessions.</p>
<p>'Maximum Telnet Sessions'</p> <pre>configure system &gt; cli- settings &gt; telnet-max- sessions</pre> <p>[TelnetMaxSessions]</p>	<p>Defines the maximum number of permitted, concurrent Telnet or SSH sessions.</p> <p>The valid range is 1 to 5 sessions. The default is 2.</p> <p><b>Note:</b> Before changing the value, make sure that not more than this number of sessions are currently active; otherwise, the new setting will not take effect.</p>
<pre>configure system &gt; cli- settings &gt; privilege- password</pre> <p>[CLIEnableModePassword]</p>	<p>Defines the password to access the Enable configuration mode in the CLI.</p> <p>The valid value is a string of up to 50 characters. The default is "Admin".</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The password is case-sensitive.</li> <li>■ The parameter cannot be configured with wide characters.</li> </ul>
<p>'Default Terminal Window Height'</p> <pre>configure system &gt; cli- settings &gt; default- window-height</pre> <p>[DefaultTerminalWindowHeight]</p>	<p>Defines the number (height) of output lines displayed in the CLI terminal window. This applies to all new CLI sessions and is preserved after device restarts.</p> <p>The valid value range is -1 (default) and 0-65535:</p> <ul style="list-style-type: none"> <li>■ A value of -1 means that the parameter is disabled and the settings of the CLI command <b>window-height</b> is used.</li> <li>■ A value of 0 means that all the CLI output is displayed in the window.</li> <li>■ A value of 1 or greater displays that many output lines in the window and if there is more output, the "—MORE—" prompt is displayed. For example, if you configure the parameter to 4, up</li> </ul>



Parameter	Description
	<p>to four output lines are displayed in the window and if there is more output, the “—MORE—” prompt is displayed (at which you can press the spacebar to display the next four output lines).</p> <p><b>Note:</b> You can override this parameter for a specific CLI session and configure a different number of output lines, by using the <b>window-height</b> CLI command in the currently active CLI session.</p>
<pre>configure system &gt; mgmt- auth &gt; obscure-password- mode</pre> <p>[CliObscuredPassword]</p>	<p>Enables the device to enforce obscured (i.e., encrypted) passwords whenever you add a new management user or modify the password of an existing user, through CLI (<code>configure system &gt; user</code>).</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disabled - passwords are configured in plain text.</li> <li>■ [1] = Enabled - passwords must be configured in encrypted format. To obtain an encrypted (obscured) password: <ul style="list-style-type: none"> <li>a. Enable the parameter.</li> <li>b. Configure the user's password in the Web interface's Local Users table (see <a href="#">Configuring Local Management User Accounts</a> on page 54).</li> <li>c. Save the device's CLI Script file to your local PC (see <a href="#">Downloading or Uploading CLI Script File</a> on page 1258).</li> <li>d. Open the file, and then copy the encrypted password to the CLI where you are configuring the user.</li> </ul> </li> </ul>

## SNMP Parameters

The SNMP parameters are described in the table below.

**Table 69-4: SNMP Parameters**

Parameter	Description
'Disable SNMP'	Enables and disables device management through SNMP.

Parameter	Description
<pre>configure system &gt; snmp settings &gt; disable</pre> [DisableSNMP]	<ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) SNMP is enabled.</li> <li>■ [1] <b>Yes</b> = SNMP is disabled.</li> </ul>
<p>'SNMP Port'</p> <pre>configure system &gt; snmp settings &gt; port</pre> [SNMPPort]	<p>Defines the device's local (LAN) UDP port used for SNMP Get/Set commands.</p> <p>The range is 100 to 3999. The default port is 161.</p> <p>For more information, see <a href="#">Configuring SNMP Get / Set Port</a> on page 107.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
[ChassisPhysicalAlias]	<p>Defines the 'alias' name object for the physical entity as specified by a network manager, and provides a non-volatile 'handle' for the physical entity.</p> <p>The valid range is a string of up to 255 characters.</p>
[ChassisPhysicalAssetID]	<p>Defines the user-assigned asset tracking identifier object for the device's chassis as specified by OVOC, and provides non-volatile storage of this information.</p> <p>The valid range is a string of up to 255 characters.</p>
[ifAlias]	<p>Defines the textual name of the interface. The value is equal to the ifAlias SNMP MIB object.</p> <p>The valid range is a string of up to 64 characters.</p>
<pre>configure system &gt; snmp trap &gt; auto-send-keep-alive</pre> [SendKeepAliveTrap]	<p>Enables the device to send NAT keep-alive traps to the port of the SNMP network management station (e.g., AudioCodes OVOC). This is used for NAT traversal, and allows SNMP communication with OVOC management platform, located in the WAN, when the device is located behind NAT. It is needed to keep the NAT pinhole open for the SNMP messages sent from OVOC to the device. The device sends the trap periodically - every 9/10 of the time configured by the</p>

Parameter	Description
	<p>NATBindingDefaultTimeout parameter. The trap that is sent is acKeepAlive. For more information, refer to the <a href="#">SBC-Gateway Series SNMP Alarm Reference Guide</a>.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable</li> <li>■ [1] = Enable</li> </ul> <p>To configure the port number, use the KeepAliveTrapPort parameter.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
[KeepAliveTrapPort]	<p>Defines the port of the SNMP network management station to which the device sends keep-alive traps.</p> <p>The valid range is 0 - 65534. The default is port 162.</p> <p>To enable NAT keep-alive traps, use the [SendKeepAliveTrap] parameter.</p>
<p>'Call Duration for Short Calls'</p> <pre>configure voip &gt; sbc settings &gt; short-call-seconds</pre> <p>[ShortCallSeconds]</p>	<p>Defines the maximum duration (in seconds) of an SBC call for it to be considered a short call and included in the performance monitoring count for short calls (shortCallsCounterTotal and shortCallsCounter). The duration must be less than or equal to the configured value for the call to be considered a short call.</p> <p>The valid value is 0 to 60. The default is 2. A value of 0 indicates calls of zero duration, which are calls that do not pass the device's Classification, Manipulation or Routing stages.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<p>'Call Duration for Long Calls'</p> <pre>configure voip &gt; sbc settings &gt; long-call-minutes</pre> <p>[LongCallMinutes]</p>	<p>Defines the minimum duration (in minutes) of an SBC call for it to be considered a long call and included in the performance monitoring count for long calls (longCallsCounterTotal and longCallsCounter). The duration must be greater than or equal to the configured value for the call to be considered a long call.</p>

Parameter	Description
	<p>The valid value is 0 to 60. The default is 30. A value of 0 indicates calls of zero duration, which are calls that do not pass the device's Classification, Manipulation or Routing stages.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
[acUserInputAlarmDescription]	Defines the description of the input alarm.
[acUserInputAlarmSeverity]	Defines the severity of the input alarm.
<pre>configure system &gt; snmp settings &gt; alarm-history- table-max-size</pre> <p>[AlarmHistoryTableMaxSize]</p>	<p>Defines the maximum number of historical alarms that can be displayed in the Alarm History table. The parameter can be controlled by the Config Global Entry Limit MIB (located in the Notification Log MIB). The valid range is 50 to 1000. The default is 500.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
<pre>configure system &gt; snmp settings &gt; active-alarm- table-max-size</pre> <p>[ActiveAlarmTableMaxSize]</p>	<p>Defines the maximum number of active alarms that can be displayed in the Active Alarms table.</p> <p>When the table reaches this user-defined maximum capacity (i.e., full), the device sends the SNMP trap event, acActiveAlarmTableOverflow. If the table is full and a new alarm is raised by the device, the new alarm is not displayed in the table.</p> <p>The valid range is 50 to 300. The default is 120.</p> <p>For more information on the Active Alarms table, see <a href="#">Viewing Active Alarms</a> on page 1323.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ To clear the acActiveAlarmTableOverflow trap, you must restart the device. The restart also deletes all the alarms in the</li> </ul>

Parameter	Description
	Active Alarms table.
<pre>configure system &gt; snmp alarm-settings &gt; alarms- persistent-history</pre> <b>[AlarmsPersistentHistory]</b>	<p>Enables the device to store the alarms of the Alarms History table on its flash memory. When enabled, the alarms are not deleted from table upon a device restart.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disabled</li> <li>■ [1] = Enabled</li> </ul> <p>For more information, see <a href="#">Storing Alarms History on Flash</a> on page 1326.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ The device can't operate with OVOC when the parameter is enabled.</li> </ul>
<pre>configure system &gt; snmp alarm-settings &gt; persistent- history-save-interval</pre> <b>[SavePersistentHistoryInterval]</b>	<p>Defines how often (in minutes) the device saves the alarms of the Alarms History table to its flash memory.</p> <p>The valid value range is 1 to 50,000. The default is 1,440 (24 hours).</p> <p>For more information, see <a href="#">Storing Alarms History on Flash</a> on page 1326.</p>
<pre>no-alarm-for-disabled-port</pre> <b>[NoAlarmForDisabledPort]</b>	<p>Enables the device to not send the SNMP trap <code>acBoardControllerFailureAlarm</code> alarm. This alarm indicates a "disabled" telephony port, which is one that is not configured at all or that is configured but without a Trunk Group ID (i.e., Trunk Group ID is 0), in the Trunk Groups table.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disabled. The device sends the SNMP trap for non-configured ports.</li> <li>■ [1] = Enabled. The device doesn't send the SNMP trap for non-configured ports.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable to all telephony ( digital) port types.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>The parameter is applicable only to the Gateway application.</li> </ul>
[ContextEngineID]	<p>Defines the contextEngineID as mentioned in RFC 3411. An SNMP context is a collection of management information accessible by an SNMP entity. An item of management information may exist in more than one context and an SNMP entity potentially has access to many contexts. A context is identified by the snmpEngineID value of the entity hosting the management information (also called a contextEngineID) and a context name that identifies the specific context (also called a contextName).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>For the parameter to take effect, a device restart is required.</li> <li>When the device operates in HA mode, this parameter has the same value for both active and redundant devices (i.e., system identifier). If the devices return to Standalone mode (i.e., non-HA mode), you must configure the parameter to a 0 value on both devices. When the devices restart to Standalone mode, each device automatically sets this parameter to a unique value based on its serial number (S/N).</li> </ul>
<pre>configure system &gt; snmp settings &gt; engine-id</pre> [SNMPEngineIDString]	<p>Defines the SNMP engine ID for SNMPv2/SNMPv3 agents. This is used for authenticating a user attempting to access the SNMP agent on the device.</p> <p>The ID can be a string of up to 36 characters. The default is 00:00:00:00:00:00:00:00:00:00:00:00 (12 Hex octets characters). The provided key must be set with 12 Hex values delimited by a colon (":") in the format xx:xx:...:xx. For example, 00:11:22:33:44:55:66:77:88:99:aa:bb</p> <p><b>Note:</b></p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ Before setting the parameter, all SNMPv3 users must be deleted; otherwise, the parameter setting is ignored.</li> <li>■ If the supplied key doesn't pass validation of the 12 Hex values input or it is set with the default value, the engine ID is generated according to RFC 3411.</li> <li>■ When the device operates in HA mode, the parameter has the same value for both active and redundant devices (i.e., system identifier). If the two devices return to Standalone mode (i.e., non-HA mode), you must configure the parameter to a NULL value (i.e., no value) for both devices. When the devices restart to the Standalone mode, each device automatically sets the parameter to a unique value based on its' serial number (S/N).</li> </ul>
<b>'Activity Trap'</b> configure troubleshoot > activity-trap [EnableActivityTrap]	Enables the device to send an SNMP trap to notify of Web user activities in the Web interface. The activities to report are configured by the [ActivityListToLog] parameter (see <a href="#">Reporting Management User Activities</a> on page 1502). <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul>
<b>'IPv4 Interface Name'</b> configure system > snmp settings > interface-name [SNMPInterface]	Assigns an IPv4 IP Interface (configured in the IP Interfaces table - see <a href="#">Configuring IP Network Interfaces</a> on page 157) to the SNMP application for SNMP over IPv4.  By default, the OAMP IP Interface is assigned to SNMP over IPv4.  For more information, see <a href="#">Configuring SNMP Interfaces</a> on page 113.

Parameter	Description
<b>'IPv6 Interface Name'</b> <code>configure system &gt; snmp settings &gt; interface-ipv6- name</code> <b>[SNMPIpv6Interface]</b>	<p>Assigns an IPv6 IP Interface (configured in the IP Interfaces table - see <a href="#">Configuring IP Network Interfaces</a> on page 157) to the SNMP application for SNMP over IPv6.</p> <p>For more information, see <a href="#">Configuring SNMP Interfaces</a> on page 113.</p>
<code>configure system &gt; snmp settings &gt; enable- authentication-trap</code> <b>[EnableSnmpAuthenticationTrap]</b>	<p>Disables the sending of the Authentication Failure SNMP trap (authenticationFailure, OID 1.3.6.1.6.3.1.1.5.5).</p> <ul style="list-style-type: none"> <li>■ [0] = Disable - trap is not sent.</li> <li>■ [1] = (Default) Enable - trap is sent.</li> </ul>
<b>'Trap Community String'</b> <code>configure system &gt; snmp trap &gt; community-string</code> <b>[SNMPTrapCommunityStringPassword]</b>	<p>Defines the community string for SNMP traps. For more information, see <a href="#">Configuring SNMP Community String for Traps</a> on page 112.</p> <p><b>Note:</b> The parameter cannot be configured with wide characters.</p>
<code>configure troubleshoot &gt; pool-thresholds settings &gt; alarm-raise-threshold</code> <b>[PoolAlarmRaise]</b>	<p>Defines the threshold (in percentage) to raise the acResourcePoolAlarm SNMP alarm (OID 1.3.6.1.4.1.5003.9.10.1.21.2.0.162). The alarm is triggered (major severity level) when a specific resource pool utilization of the device reaches or exceeds this threshold.</p> <p>The default is 95.</p>
<code>configure troubleshoot &gt; pool-thresholds settings &gt; alarm-clear-threshold</code> <b>[PoolAlarmClear]</b>	<p>Defines the threshold (in percentage) to clear the acResourcePoolAlarm SNMP alarm (OID 1.3.6.1.4.1.5003.9.10.1.21.2.0.162). The alarm is triggered (major severity level) when a specific resource pool utilization of the device reaches or exceeds a specific threshold, configured by the [PoolAlarmRaise] parameter.</p> <p>The default is 90.</p>

## WebSocket Tunneling with OVOC Parameters

The WebSocket tunneling with OVOC parameters are described in the table below. For more information on WebSocket tunneling between the device and OVOC, see [Configuring WebSocket Tunnel with OVOC](#) on page 122.



**Table 69-5: WebSocket Tunneling with OVOC Parameters**

Parameter	Description
<b>'OVOC WebSocket Tunnel Server Address'</b> <code>configure network &gt; ovoc-tunnel-settings &gt; address</code> [WSTunServer]	<p>Defines the address of the WebSocket tunnel server (OVOC).</p> <p>The valid value is an IPv4 address (in dotted-decimal notation) or a hostname. By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ If you configure the parameter to a hostname, the device uses the DNS server configured in <a href="#">Configuring a DNS Server for HTTP Services</a> on page 462 to resolve it into an IP address.</li> </ul>
<b>'Interface Name'</b> <code>configure network &gt; ovoc-tunnel-settings &gt; interface-name</code> [WSTunInterfaceName]	<p>Defines an IP Interface for communication with the WebSocket tunnel server.</p> <p>By default, no value is defined (i.e., device uses the default OAMP IP Interface).</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
<b>'Path'</b> <code>configure network &gt; ovoc-tunnel-settings &gt; path</code> [WSTunServerPath]	<p>Defines the path of the WebSocket tunnel server.</p> <p>Configure the parameter to "tun" (without quotation marks) to match the default OVOC configuration.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
<b>'Username'</b> <code>configure network &gt; ovoc-tunnel-settings &gt; username</code> [WSTunUsername]	<p>Defines the username for connecting the device to the WebSocket tunnel server (OVOC).</p> <p>The valid value is a string of up to 30 characters.</p> <p>Configure the parameter to "VPN" (without quotation marks) to match the default OVOC configuration.</p>

Parameter	Description
	<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ The username must be the same as that configured on OVOC.</li> </ul>
<p>'Password'</p> <pre>configure network &gt; ovoc- tunnel-settings &gt; password [WSTunPassword]</pre>	<p>Defines the password for connecting the device to the WebSocket tunnel server (OVOC).</p> <p>The valid value is a string of up to 30 characters.</p> <p>Configure the parameter to "123456" (without quotation marks) to match the default OVOC configuration.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ The password must be the same as that configured on OVOC.</li> </ul>
<p>'Secured (HTTPS)'</p> <pre>configure network &gt; ovoc- tunnel-settings &gt; secured [WSTunSecured]</pre>	<p>Enables secured (HTTPS) WebSocket tunneling connection.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = (Default) Enabled.</li> </ul> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
<p>'Verify Server'</p> <pre>configure network &gt; ovoc- tunnel-settings &gt; verify-server [WSTunVerifyPeer]</pre>	<p>Enables the device to verify the TLS certificate that is presented by OVOC when establishing the WebSocket tunneling connection.</p> <p>You should upload the corresponding CA certificate to the device's Trusted Root store of the default TLS Context (Index #0).</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = Disabled. No certificate verification is done.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = (Default)</li> </ul>

Parameter	Description
	<p>Enabled. The device verifies that the TLS certificate presented by OVOC is signed by one of the known CAs.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ The parameter is applicable only if you configure the [WSTunSecured] parameter to [1].</li> </ul>

## Serial Parameters

The serial interface parameters are described in the table below.

**Table 69-6: Serial Parameters**

Parameter	Description
[DisableRS232]	<p>Enables or disables the device's RS-232 serial communication port.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Enables RS-232.</li> <li>■ [1] = Disables RS-232.</li> </ul> <p>The RS-232 serial port can be used to change the networking parameters and view error/notification messages. To establish serial communication with the device, see <a href="#">Establishing a CLI Session</a> on page 100.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
[SerialBaudRate]	<p>Defines the serial communication baud rate.</p> <p>The valid values include the following: 1200, 2400, 9600, 14400, 19200, 38400, 57600, or 115200 (default).</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
[SerialData]	<p>Defines the serial communication data bit.</p> <ul style="list-style-type: none"> <li>■ [7] = 7-bit</li> <li>■ [8] = (Default) 8-bit</li> </ul> <p><b>Note:</b> For the parameter to take effect, a device restart is</p>

Parameter	Description
	required.
[SerialParity]	<p>Defines the serial communication polarity.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) None</li> <li>■ [1] = Odd</li> <li>■ [2] = Even</li> </ul> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
[SerialStop]	<p>Defines the serial communication stop bit.</p> <ul style="list-style-type: none"> <li>■ [1] = (Default) 1-bit (default)</li> <li>■ [2] = 2-bit</li> </ul> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
[SerialFlowControl]	<p>Defines the serial communication flow control.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) None</li> <li>■ [1] = Hardware</li> </ul> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
<pre>configure troubleshoot &gt; startup-n- recovery &gt; startup-dark- mode</pre> <p>[EnableDarkenMode]</p>	<p>Enables serial darkening, which hides the bootup log messages from being displayed in the CLI console during a device reset (boot up). However, if the device fails to load, serial darkening is disabled in the next bootup attempt.</p> <ul style="list-style-type: none"> <li>■ [0]</li> <li>■ [1] (Default)</li> </ul> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>

## Auxiliary and Configuration File Name Parameters

The table below lists the parameters associated with the Auxiliary files. For more information on Auxiliary files, see [Uploading Auxiliary Files](#) on page 1220.

**Table 69-7: Auxiliary and Configuration File Parameters**

Parameter	Description
<b>General Parameters</b>	
[SetDefaultOnIniFileProcess]	<p>Determines if all the device's parameters are set to their defaults before processing the updated <i>ini</i> file.</p> <ul style="list-style-type: none"> <li>■ [0] = Disable - parameters not included in the downloaded ini file are not returned to default settings (i.e., retain their current settings).</li> <li>■ [1] = Enable (default).</li> </ul> <p><b>Note:</b> The parameter is applicable only for automatic HTTP update or Web <i>ini</i> file upload (not applicable if the <i>ini</i> file is loaded using BootP).</p>
[SaveConfiguration]	<p>Determines if the device's configuration (parameters and files) is saved to flash (non-volatile memory).</p> <ul style="list-style-type: none"> <li>■ [0] = Configuration isn't saved to flash memory.</li> <li>■ [1] = (Default) Configuration is saved to flash memory.</li> </ul>
<b>Auxiliary Filename Parameters</b>	
'Call Progress Tones File' [CallProgressTonesFilename]	<p>Defines the name of the file containing the Call Progress Tones definitions.</p> <p>For the ini file, the name must be enclosed by a single quotation mark (e.g., 'cpt_us.dat').</p> <p>For more information on how to create and upload this file, refer to the document <a href="#">DConvert Utility User's Guide</a>.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
'Prerecorded Tones File' [PrerecordedTonesFileName]	<p>Defines the name of the file containing the Prerecorded Tones.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
'CAS File' [CASFileName_x]	<p>Defines the CAS file name (e.g., 'E_M_WinkTable.dat'), which defines the CAS protocol (where x denotes the CAS file ID 0 to 7). It is possible to define up to eight different CAS files by repeating the parameter. Each CAS file can be associated with one or more of the</p>

Parameter	Description
	<p>device's trunks, using the parameter CASTableIndex or it can be associated per B-channel using the parameter CASChannelIndex.</p> <p>For the ini file, the name must be enclosed by a single quotation mark (e.g., 'cas_us.dat').</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
'Dial Plan' [CasTrunkDialPlanName_x]	<p>Defines the Dial Plan name (up to 11-character strings) per trunk.</p> <p>For the ini file, the name must be enclosed by a single quotation mark (e.g., 'dial_plan_2.dat').</p> <p><b>Note:</b> The x in the ini file parameter name denotes the trunk number, where 0 is Trunk 1.</p>
'Dial Plan File' [DialPlanFileName]	<p>Defines the name of the Dial Plan file.</p> <p>For the ini file, the name must be enclosed by a single quotation mark (e.g., 'dial_plan.dat').</p> <p><b>Note:</b> This parameter is used only for backward compatibility. For loading (importing) Dial Plan files, use the Dial Plan table instead (see <a href="#">Importing Dial Plans</a> on page 811).</p>
[UserInfoFileName]	<p>Defines the name of the file containing the User Information data.</p> <p>For the ini file, the name must be enclosed by a single quotation mark (e.g., 'userinfo_us.dat').</p> <p><b>Note:</b> The parameter is only used for backward compatibility.</p>

## License Parameters

The license parameters are described in the table below.

**Table 69-8: License Parameters**

Parameter	Description
'Floating License' configure system > floating-license > floating-license [EnableFloatingLicense]	<p>Enables the device to operate with the Floating License.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul>

Parameter	Description
	<p>For more information, see <a href="#">Floating License Model</a> on page 1245.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
<p>'Allocation Profile'</p> <pre>configure system &gt; floating-license &gt; allocation-profile [AllocationProfile]</pre>	<p>Defines an SBC capacity profile (<i>Allocation Profile</i>) for the Floating License feature.</p> <ul style="list-style-type: none"> <li>■ [0] <b>SIP Trunking</b> = (Default) Profile suited for SIP Trunking applications.</li> <li>■ [1] <b>Registered Users</b> = Profile suited for applications requiring registered users.</li> <li>■ [2] <b>Custom</b> = Customized Allocation Profile.</li> </ul> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
<p>('Allocation') 'Far End Users'</p> <pre>configure system &gt; floating-license &gt; allocation- registered-users [AllocationRegisteredUsers]</pre>	<p>Defines the capacity of registered users for a customized Allocation Profile in the Floating License.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ The parameter is applicable only when the 'Allocation Profile' is configured to <b>Custom</b>.</li> </ul>
<p>('Allocation') 'SBC Media Sessions'</p> <pre>configure system &gt; floating-license &gt; allocation-media- sessions [AllocationMediaSessions]</pre>	<p>Defines the capacity of SBC media sessions for a customized Allocation Profile in the Floating License.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ The parameter is applicable only when the 'Allocation Profile' is configured to <b>Custom</b>.</li> </ul>
<p>('Allocation') 'SBC Signaling Sessions'</p> <pre>configure system &gt; floating-license &gt; allocation-signaling- sessions [AllocationSignalingSessions]</pre>	<p>Defines the capacity of SBC signaling sessions for a customized Allocation Profile in the Floating License.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ The parameter is applicable only when the 'Allocation Profile' is configured to <b>Custom</b>.</li> </ul>

Parameter	Description
('Allocation') 'SIPREC Streams' configure system > floating-license > allocation-siprec- sessions [AllocationSIPRecStreams]	Defines the capacity of SIPREC sessions for a customized Allocation Profile in the Floating License. <b>Note:</b> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ The parameter is applicable only when the 'Allocation Profile' is configured to <b>Custom</b>.</li> </ul>
('Limit') 'Far End Users' configure system > floating-license > limit-registered- users [LimitRegisteredUsers]	Defines a limit for the registered users capacity for a customized Allocation Profile in the Floating License. The limit can be equal to or less than the allocated registered users capacity, configured by the [AllocationRegisteredUsers] parameter. <b>Note:</b> The parameter is applicable only when the 'Allocation Profile' is configured to <b>Custom</b> .
('Limit') 'SBC Media Sessions' configure system > floating-license > limit-media-sessions [LimitMediaSessions]	Defines a limit for the SBC media sessions capacity for a customized Allocation Profile in the Floating License. The limit can be equal to or less than the allocated SBC media sessions capacity, configured by the [AllocationMediaSessions] parameter. <b>Note:</b> The parameter is applicable only when the 'Allocation Profile' is configured to <b>Custom</b> .
('Limit') 'SBC Signaling Sessions' configure system > floating-license > limit-signaling- sessions [LimitSignalingSessions]	Defines a limit for the SBC SIP signaling sessions capacity for a customized Allocation Profile in the Floating License. The limit can be equal to or less than the allocated SBC SIP signaling sessions capacity, configured by the [AllocationSignalingSessions] parameter. <b>Note:</b> The parameter is applicable only when the 'Allocation Profile' is configured to <b>Custom</b> .
('Limit') 'Transcoding Sessions' configure system > floating-license > limit-transcoding- sessions [LimitTranscodingSessions]	Defines a limit for the transcoding sessions capacity for a customized Allocation Profile in the Floating License. The limit can be equal to or less than the allocated transcoding sessions capacity. <b>Note:</b> The parameter is applicable only when the 'Allocation Profile' is configured to <b>Custom</b> .
('Limit') 'SIPREC Streams' configure system >	Defines a limit for the SIPREC sessions capacity for a customized Allocation Profile in the Floating License.



Parameter	Description
floating-license > limit-siprec-sessions [LimitSIPRecStreams]	The limit can be equal to or less than the allocated SIPREC sessions capacity, configured by the [AllocationSIPRecStreams] parameter. <b>Note:</b> The parameter is applicable only when the 'Allocation Profile' is configured to <b>Custom</b> .

## Automatic Update Parameters

The automatic update parameters are described in the following table.



Auxiliary file upload through TFTP is not supported in HA mode.

**Table 69-9: Automatic Update of Software and Configuration Files Parameters**

Parameter	Description
<b>General Automatic Update Parameters</b>	
configure system > automatic-update > aupd-interface [AUPDInterface]	Assigns an IP Interface (in the IP Interfaces table - see <a href="#">Configuring IP Network Interfaces</a> on page 157) for the Auto-Update mechanism.  By default, the device uses the IPv4 OAMP interface. For more information, see <a href="#">Assigning IP Interface for Auto-Update Mechanism</a> on page 1281.
configure system > automatic-update > update-firmware [AutoUpdateCmpFile]	Enables the Automatic Update mechanism for the cmp file.  ■ [0] = (Default) The Automatic Update mechanism doesn't apply to the cmp file.  ■ [1] = The Automatic Update mechanism includes the cmp file.  <b>Note:</b> For the parameter to take effect, a device restart is required.
configure system > automatic-update > update-frequency-sec [AutoUpdateFrequencySeconds]	Defines the periodic interval (in seconds) between each automatic update. The count starts from a trigger for auto-update with the provisioning server. The valid value range is 0 to 604,800. The default is 0 (i.e., disabled).  <b>Note:</b>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ This feature can't work with the feature that specifies a specific time of day for automatic updates. Therefore, if you configure this parameter to any value other than 0, leave the [AutoUpdatePredefinedTime] parameter at its default value (i.e., undefined).</li> </ul>
<pre>configure system &gt; automatic-update &gt; predefined-time [AutoUpdatePredefinedTime]</pre>	<p>Defines the time of day at which the device performs automatic updates.</p> <p>The format syntax of the parameter is 'hh:mm', where <i>hh</i> denotes the hour and <i>mm</i> the minutes. The value must be enclosed by a single quotation mark (e.g., '20:18'). The default is undefined (i.e., disabled).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ By default, the actual update time is randomized by five minutes to reduce the load on the Web servers. To change this randomized time, use the [AutoUpdatePredefinedRandomTime] parameter.</li> <li>■ This feature can't work with the feature that specifies a periodic interval for automatic updates. Therefore, if you configure this parameter to any value other than default, leave the [AutoUpdateFrequencySeconds] parameter at its default value (i.e., disabled).</li> </ul>
<pre>configure system &gt; automatic-update &gt; predefined-random-time [AutoUpdatePredefinedRandomTime]</pre>	<p>Defines the maximum randomization interval (in seconds) for the daily scheduled automatic update (configured by the [AutoUpdatePredefinedTime] parameter). For example, if you configure the [AutoUpdatePredefinedTime] parameter to '13:00' (i.e., 1 pm) and [AutoUpdatePredefinedRandomTime] to '300' (i.e., 5 min.), the actual update can start anywhere between the time 13:00 and 13:05.</p> <p>The valid value range 60 to 86400. The default is 300.</p> <p><b>Note:</b> The parameter is applicable only to the [AutoUpdatePredefinedTime] parameter.</p>

Parameter	Description
<pre>configure system &gt; automatic-update &gt; max- transfer-time</pre> <p>[AupdMaxTransferTime]</p>	<p>Defines the file transfer timeout (minutes) for downloading a file from the provisioning server for automatic updates. If the download hasn't finished when this timeout expires, the device stops its attempt to download the file and continues to the next file in the Auto-Update file download queue. The valid value range is 1 to 5. The default is 5.</p>
<pre>configure system &gt; automatic-update &gt; aupd-graceful- shutdown</pre> <p>[AupdGracefulShutdown]</p>	<p>Enables the device to gracefully lock for the Automatic Update feature when updating the ini configuration file. When the file is downloaded from the provisioning server, the device gracefully locks. During this graceful period (configured by the [AdminStateLockControl] ini file parameter), no new calls are accepted. If all existing calls end before the timeout expires, the device locks and applies the settings of the file. If there are still existing calls when the timeout expires, the device terminates them and applies the settings of the file. For more information, see <a href="#">Applying Downloaded ini File after Graceful Timeout</a> on page 1280.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable</li> <li>■ [1] = Enable</li> </ul>
<pre>configure system &gt; automatic-update &gt; http-user-agent</pre> <p>[AupdHttpUserAgent]</p>	<p>Defines the information that is included in the HTTP User-Agent header in HTTP Get requests sent by the device to the provisioning server for the Automatic Update mechanism.</p> <p>The valid value is a string of up to 511 characters. The information can include any user-defined string or the following case-sensitive, string variable tags (placeholders):</p> <ul style="list-style-type: none"> <li>■ &lt;NAME&gt;: Replaced with the product name (according to the License Key).</li> <li>■ &lt;MAC&gt;: Replaced with the device's MAC address.</li> <li>■ &lt;VER&gt;: Replaced with the currently installed software version.</li> <li>■ &lt;CONF&gt;: Replaced with the configuration version (configured by the [INIFileVersion] parameter or CLI command <code>configuration-version</code>).</li> </ul>

Parameter	Description
	<p>The device automatically populates these variables with actual values in the sent User-Agent header. If not configured (default), the device sends the following information in the User-Agent header:</p> <pre>User-Agent: Mozilla/4.0 (compatible; AudioCodes; &lt;product name&gt;;&lt;software version&gt;;&lt;MAC address&gt;;&lt;configuration version&gt;)</pre> <p>For example, if you configure the parameter to <code>Aup-dHttpUserAgent = MyWorld-&lt;NAME&gt;;&lt;VER&gt;(&lt;MAC&gt;)</code>, the device sends the following User-Agent header:</p> <pre>User-Agent: MyWorld- Mediant;7.40A.500.966; 00:90:8f:5b:10:35;0</pre> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The variable tags are case-sensitive.</li> <li>■ If you configure the parameter with the <code>&lt;CONF&gt;</code> variable tag, you must restart the device with a save-to-flash for your settings to take effect.</li> <li>■ The tags can be defined in any order.</li> <li>■ The tags must be defined adjacent to one another (i.e., no spaces).</li> </ul>
<pre>configure system &gt; automatic-update &gt; auto-firmware [AutoCmpFileUrl]</pre>	<p>Defines the filename and path (URL) to the provisioning server from where the software file (.cmp) can be downloaded, based on timestamp for the Automatic Updated mechanism.</p> <p>The valid value is an IP address in dotted-decimal notation or an FQDN.</p>
<pre>configure system &gt; automatic-update &gt; aupd-verify-cert [AUPDVerifyCertificates]</pre>	<p>Enables the Automatic Update mechanism to verify the TLS certificate received from the provisioning server when the connection is HTTPS.</p> <ul style="list-style-type: none"> <li>■ [0] = Disable (default)</li> <li>■ [1] = Enables TLS certificate verification when the connection with the provisioning server is based</li> </ul>

Parameter	Description
	<p>on HTTPS. The device verifies the authentication of the certificate received from the provisioning server. The device authenticates the certificate against its trusted root certificate store (see <a href="#">TLS Certificates</a> on page 224) and if ok, allows communication with the provisioning server. If authentication fails, the device denies communication (i.e., handshake fails).</p>
<pre>configure system &gt; automatic-update &gt; credentials [AUPDUserPassword]</pre>	<p>Defines the username and password for digest (MD5 cryptographic hashing) and basic access authentication with the HTTP server on which the files to download are located for the Automatic Update feature.</p> <p>The valid value is a string of up to 128 characters. The syntax is 'username:password' (e.g., 'joe:1234'). By default, no value is defined.</p> <p><b>Note:</b> The device only uses the username and password configured by this parameter if no username and password has been configured for the parameter used to configure the URL of the server with the name of the file, for example, [CmpFileURL].</p>
<pre>configure system &gt; automatic-update &gt; crc- check regular [AUPDCheckIfIniChanged]</pre>	<p>Enables the device to perform cyclic redundancy checks (CRC) on downloaded configuration files during the Automatic Update process. The CRC checks whether the content (raw data) of the downloaded file is different to the content of the previously downloaded file from the previous Automatic Update process. The device compares the CRC check value (code) result with the check value of the previously downloaded file. If the check values are identical, it indicates that the file has no new configuration settings, and the device discards the file. If the check values are different, the device installs the downloaded file and applies the new configuration settings.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable - the device doesn't perform CRC and installs the downloaded file regardless.</li> <li>■ [1] = Enable CRC for the entire file, including line order (i.e., same text must be on the same lines).</li> </ul>

Parameter	Description
	<p>If there are differences between the files, the device installs the downloaded file. If there are no differences, the device discards the newly downloaded file.</p> <ul style="list-style-type: none"> <li>■ [2] = Enable CRC for individual lines only. Same as option [1], except that the CRC ignores the order of lines (i.e., same text can be on different lines).</li> </ul>
<pre>configure system &gt; automatic-update &gt; tftp-block-size [AUPDTftpBlockSize]</pre>	<p>Defines the size of the TFTP data blocks (packets) when downloading a file from a TFTP server for the Automatic Update mechanism. This is in accordance to RFC 2348. TFTP block size is the physical packet size (in bytes) that a network can transmit. When configured to a value higher than the default (512 bytes), but lower than the client network's Maximum Transmission Unit (MTU), the file download speed can be significantly increased.</p> <p>The valid value is 512 to 8192. The default is 512.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ A higher value doesn't necessarily mean better performance.</li> <li>■ The block size should be small enough to avoid IP fragmentation in the client network (i.e., below MTU).</li> <li>■ This feature is applicable only to TFTP servers that support this option.</li> </ul>
<pre>'Default password for configuration package' configure system &gt; automatic-update &gt; default- configuration-package- password &lt;password&gt; [defaultConfigPackagePassword]</pre>	<p>Defines the password to protect (encrypt) the Configuration Package file when it's uploaded to the device using the Automatic Update feature (see the <code>configuration-pkg</code> command below). If the file is not password-protected, ignore this command.</p> <p><b>Note:</b> This password is also used to protect (encrypt) the Configuration Package file when downloading it from the device through SFTP.</p>
[ResetNow]	<p>Invokes an immediate device restart. This option can be used to activate offline (i.e., not on-the-fly) parameters that are loaded using the [IniFileUrl] parameter.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) The immediate restart mechanism</li> </ul>

Parameter	Description
	<p>is disabled.</p> <ul style="list-style-type: none"> <li>■ [1] = The device immediately restarts after an <i>ini</i> file with the parameter set to 1 is loaded.</li> </ul> <p><b>Note:</b> If you use the parameter in an ini file for periodic automatic provisioning with non-HTTP (e.g., TFTP) and without CRC, the device restarts upon every file download.</p>
<b>Software and Configuration File URL Path for Automatic Update Parameters</b>	
<pre>configure system &gt; automatic-update &gt; firmware [CmpFileURL]</pre>	<p>Defines the name of the <i>cmp</i> file and the URL address (IP address or FQDN) of the server where the file is located. Optionally, the username and password (username:password) for access authentication with the server can also be configured.</p> <p>Example syntax:</p> <pre>'http://192.168.0.1/&lt;filename&gt;' 'https://&lt;username&gt;:&lt;password&gt;@&lt;IP address&gt;/&lt;file name&gt;'</pre> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ When the parameter is configured, the device always uploads the <i>cmp</i> file after it restarts.</li> <li>■ The <i>cmp</i> file is validated before it's saved to flash. The checksum of the <i>cmp</i> file is also compared to the previously saved checksum to avoid unnecessary restarts.</li> <li>■ The maximum length of the URL address is 255 characters.</li> <li>■ When using the ini file, the value must be enclosed by single quotation marks ('...').</li> </ul>
<pre>configure system &gt; automatic-update &gt; ini- file [IniFileURL]</pre>	<p>Defines the name of the <i>ini</i> file (configuration) and the URL address (IP address or FQDN) of the server where the file is located. Parameters that are not included in the ini file are restored to default settings. Optionally, the username and password ('https://username:password@10.1.1.1/&lt;file name&gt;') for access authentication with the server can also be configured.</p>

Parameter	Description
	<p>Example syntax:</p> <pre>'http://192.168.0.1/&lt;filename&gt;' 'http://192.8.77.13/config_&lt;MAC&gt;.ini' 'https://&lt;username&gt;:&lt;password&gt;@&lt;IP address&gt;/&lt;filename&gt;'</pre> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ When using HTTP or HTTPS, the date and time of the <i>ini</i> file are validated. Only more recently dated <i>ini</i> files are loaded.</li> <li>■ The case-sensitive string "&lt;MAC&gt;" can be used in the URL path and filename, which is automatically replaced with the device's MAC address. This option allows the loading of specific configurations for specific devices. For more information, see <a href="#">MAC Address Placeholder in URL and File Name</a> on page 1275.</li> <li>■ The maximum length of the URL address is 99 characters.</li> <li>■ When using the ini file, the value must be enclosed by single quotation marks ('...').</li> <li>■ If you want the device to upload an ini file where parameters not included in the file remain at their current settings (i.e., incremental), then use the [IncrementalIniFileURL] parameter instead.</li> </ul>
<pre>configure system &gt; automatic-update &gt; incremental-ini-file [IncrementalIniFileURL]</pre>	<p>Defines the name of the incremental <i>ini</i> file (configuration) and the URL address (IP address or FQDN) of the server where the file is located. Parameters that are not included in the ini file remain at their current settings. Optionally, the username and password ('https://username:password@10.1.1.1/&lt;file name&gt;') for access authentication with the server can also be configured.</p> <p>Example syntax:</p>



Parameter	Description
	<p>'http://192.168.0.1/&lt;filename&gt;'            'http://192.8.77.13/config_&lt;MAC&gt;.ini'            'https://&lt;username&gt;:&lt;password&gt;@&lt;IP address&gt;/&lt;filename&gt;'</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ When using HTTP or HTTPS, the date and time of the <i>ini</i> file are validated. Only more recently dated <i>ini</i> files are loaded.</li> <li>■ The case-sensitive string "&lt;MAC&gt;" can be used in the URL path and filename, which is automatically replaced with the device's MAC address. This option allows the loading of specific configurations for specific devices. For more information, see <a href="#">MAC Address Placeholder in URL and File Name</a> on page 1275.</li> <li>■ The maximum length of the URL address is 99 characters.</li> <li>■ When using the ini file, the value must be enclosed by single quotation marks ('...').</li> <li>■ If you want the device to upload an ini file where parameters not included in the file are restored to default settings (i.e., not incremental), then use the [IniFileURL] parameter instead.</li> </ul>
<pre>configure system &gt; automatic-update &gt; cli- script &lt;URL&gt; [CliScriptURL]</pre>	<p>Defines the URL of the server where the CLI Script file containing the device's configuration is located. This file is used for automatic provisioning. Optionally, the username and password ('https://username:password@10.1.1.1/&lt;file name&gt;') for access authentication with the server can also be configured.</p> <p><b>Note:</b> The case-sensitive string, "&lt;MAC&gt;" can be used in the URL path and filename, which is automatically replaced with the device's MAC address. For more information, see <a href="#">MAC Address Placeholder in URL and File Name</a> on page 1275.</p>
<pre>configure system &gt; automatic-update</pre>	<p>Defines the URL address of the server where the CLI Startup Script file containing the device's</p>

Parameter	Description
<pre>&gt; startup-script &lt;URL&gt;</pre> <p>[CLIScriptUrl]</p>	<p>configuration is located. This file is used for automatic provisioning. Optionally, the username and password ('https://username:password@10.1.1.1/&lt;file name&gt;') for access authentication with the server can also be configured.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ You can use the placeholder string "&lt;MAC&gt;" (case-sensitive) in the URL path and filename, which the device replaces with its MAC address. For more information, see <a href="#">MAC Address Placeholder in URL and File Name</a> on page 1275.</li> <li>■ When using the ini file, the value must be enclosed by single quotation marks ('...').</li> <li>■ The file is not supported when the device operates in HA mode.</li> </ul>
<pre>configure system &gt; automatic-update &gt; configuration-pkg</pre> <p>[ConfPackageURL]</p>	<p>Defines the name of the Configuration Package file (.7z) and the URL address (IP address or FQDN) of the server where the file is located. Optionally, the username and password ('https://username:password@10.1.1.1/&lt;file name&gt;') for access authentication with the server can also be configured.</p> <p>For example:</p> <div style="background-color: #f0f0f0; padding: 10px; margin: 10px 0;"> <pre>ConfPackageURL = 'http://www.corp.com/ConfBackupPkg5967 925.7z'</pre> </div> <p>For more information on the Configuration Package file, see <a href="#">Downloading or Uploading Configuration Package File</a> on page 1260.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If the file is password-protected (encrypted), define the password using the [defaultConfigPackagePassword] parameter.</li> <li>■ You can use the placeholder string "&lt;MAC&gt;" (case-sensitive) in the URL path and filename, which the device replaces with its MAC address.</li> </ul>

Parameter	Description
	<p>For more information, see <a href="#">MAC Address Placeholder in URL and File Name</a> on page 1275.</p> <ul style="list-style-type: none"> <li>■ When using the ini file, the value must be enclosed by single quotation marks ('...').</li> </ul>
<pre>configure system &gt; automatic-update &gt; prerecorded-tones [PrtFileURL]</pre>	<p>Defines the name of the Prerecorded Tones (PRT) file and the URL address (IP address or FQDN) of the server where the file is located. Optionally, the username and password ('https://username:password@10.1.1.1/&lt;file name&gt;') for access authentication with the server can also be configured.</p> <p>Example syntax:</p> <pre>'http://&lt;server_name&gt;/&lt;filename&gt;' 'https://&lt;server_name&gt;/&lt;filename&gt;'</pre> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The maximum length of the URL address is 99 characters.</li> <li>■ You can use the placeholder string "&lt;MAC&gt;" (case-sensitive) in the URL path and filename, which the device replaces with its MAC address. For more information, see <a href="#">MAC Address Placeholder in URL and File Name</a> on page 1275.</li> <li>■ When using the ini file, the value must be enclosed by single quotation marks ('...').</li> </ul>
<pre>configure system &gt; automatic-update &gt; call-progress-tones [CptFileURL]</pre>	<p>Defines the name of the Call Progress Tone (CPT) file and the URL address (IP address or FQDN) of the server where the file is located. Optionally, the username and password ('https://username:password@10.1.1.1/&lt;file name&gt;') for access authentication with the server can also be configured.</p> <p>Example syntax:</p> <pre>'http://&lt;server_name&gt;/&lt;filename&gt;' 'https://&lt;server_name&gt;/&lt;filename&gt;'</pre> <p><b>Note:</b></p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ The maximum length of the URL address is 99 characters.</li> <li>■ You can use the placeholder string "&lt;MAC&gt;" (case-sensitive) in the URL path and filename, which the device replaces with its MAC address. For more information, see <a href="#">MAC Address Placeholder in URL and File Name</a> on page 1275.</li> <li>■ When using the ini file, the value must be enclosed by single quotation marks ('...').</li> </ul>
<pre>configure system &gt; automatic-update &gt; voice-prompts [VpFileURL]</pre>	<p>Defines the name of the Voice Prompts file and the URL address (IP address or FQDN) of the server on which the file is located. Optionally, the username and password ('https://username:password@10.1.1.1/&lt;file name&gt;') for access authentication with the server can also be configured.</p> <p>Example syntax:</p> <pre>'http://&lt;server_name&gt;/&lt;filename&gt;' 'https://&lt;server_name&gt;/&lt;filename&gt;'</pre> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The maximum length of the URL address is 99 characters.</li> <li>■ You can use the placeholder string "&lt;MAC&gt;" (case-sensitive) in the URL path and filename, which the device replaces with its MAC address. For more information, see <a href="#">MAC Address Placeholder in URL and File Name</a> on page 1275.</li> <li>■ When using the ini file, the value must be enclosed by single quotation marks ('...').</li> </ul>
<pre>configure system &gt; automatic-update &gt; cas- table [CasFileURL]</pre>	<p>Defines the name of the CAS file and the URL address (IP address or FQDN) of the server where the file is located. Optionally, the username and password ('https://username:password@10.1.1.1/&lt;file name&gt;') for access authentication with the server can also be configured.</p> <p>Example syntax:</p>

Parameter	Description
	<p>'http://&lt;server_name&gt;/&lt;filename&gt;' 'https://&lt;server_name&gt;/&lt;filename&gt;'</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The maximum length of the URL address is 99 characters.</li> <li>■ You can use the placeholder string "&lt;MAC&gt;" (case-sensitive) in the URL path and filename, which the device replaces with its MAC address. For more information, see <a href="#">MAC Address Placeholder in URL and File Name</a> on page 1275.</li> <li>■ When using the ini file, the value must be enclosed by single quotation marks ('...').</li> </ul>
<pre>configure system &gt; automatic-update &gt; dial-plan [DialPlanCSVFileUrl]</pre>	<p>Defines the name of the Dial Plan file (.csv) and the URL address of the server where the file is located. Optionally, the username and password ('https://username:password@10.1.1.1/&lt;filename&gt;') for access authentication with the server can also be configured.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ You can use the placeholder string "&lt;MAC&gt;" (case-sensitive) in the URL path and filename, which the device replaces with its MAC address. For more information, see <a href="#">MAC Address Placeholder in URL and File Name</a> on page 1275.</li> <li>■ When using the ini file, the value must be enclosed by single quotation marks ('...').</li> </ul>
<pre>configure system &gt; automatic-update &gt; tls- root-cert [TLSTrustFileUrl]</pre>	<p>Defines the name of the TLS trusted root certificate file and the URL address of the server where the file is located (e.g., tftp://172.17.116.216/Trust.pem). Optionally, the username and password ('https://username:password@10.1.1.1/&lt;file name&gt;') for access authentication with the server can also be configured.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter replaces all previous loaded trusted root certificate files with the new file.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ When using the ini file, the value must be enclosed by single quotation marks ('...').</li> <li>■ You can use the placeholder string "&lt;MAC&gt;" (case-sensitive) in the URL path and filename, which the device replaces with its MAC address. For more information, see <a href="#">MAC Address Placeholder in URL and File Name</a> on page 1275.</li> </ul>
<pre>configure system &gt; automatic-update &gt; tls- root-cert-incr [TLSEncrRootFileUrl]</pre>	<p>Defines the name of the TLS trusted root certificate file and the URL address of the server where the file is located (e.g., tftp://172.17.116.216/Trust.pem). Optionally, the username and password ('https://username:password@10.1.1.1/&lt;file name&gt;') for access authentication with the server can also be configured. The parameter adds the file to any existing trusted root certificate file (i.e., incremental file upload).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ You can use the placeholder string "&lt;MAC&gt;" (case-sensitive) in the URL path and filename, which the device replaces with its MAC address. For more information, see <a href="#">MAC Address Placeholder in URL and File Name</a> on page 1275.</li> <li>■ When using the ini file, the value must be enclosed by single quotation marks ('...')</li> </ul>
<pre>configure system &gt; automatic-update &gt; tls- cert [TLSCertFileUrl]</pre>	<p>Defines the name of the TLS certificate file and the URL address of the server where the file is located. Optionally, the username and password ('https://username:password@10.1.1.1/&lt;file name&gt;') for access authentication with the server can also be configured.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ You can use the placeholder string "&lt;MAC&gt;"</li> </ul>

Parameter	Description
	<p>(case-sensitive) in the URL path and filename, which the device replaces with its MAC address. For more information, see <a href="#">MAC Address Placeholder in URL and File Name</a> on page 1275.</p> <ul style="list-style-type: none"> <li>■ When using the ini file, the value must be enclosed by single quotation marks ('...').</li> </ul>
<pre>configure system &gt; automatic-update &gt; tls- private-key [TLSPkeyFileUrl]</pre>	<p>Defines the URL address of the server on which the TLS private key file is located. Optionally, the username and password ('https://username:password@10.1.1.1/&lt;file name&gt;') for access authentication with the server can also be configured.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ You can use the placeholder string "&lt;MAC&gt;" (case-sensitive) in the URL path and filename, which the device replaces with its MAC address. For more information, see <a href="#">MAC Address Placeholder in URL and File Name</a> on page 1275.</li> <li>■ When using the ini file, the value must be enclosed by single quotation marks ('...').</li> </ul>
<pre>configure system &gt; automatic-update &gt; gw- user-info [GWUserInfoFileUrl]</pre>	<p>Defines the name of the Gateway User Information file and the URL address (IP address or FQDN) of the server where the file is located. Optionally, the username and password ('https://username:password@10.1.1.1/&lt;file name&gt;') for access authentication with the server can also be configured. For example:</p> <div style="background-color: #f0f0f0; padding: 10px; margin: 10px 0;"> <pre>'https://www.company.com/GW-User_ Info.csv'</pre> </div> <p><b>Note:</b> You can use the placeholder string "&lt;MAC&gt;" (case-sensitive) in the URL path and filename, which the device replaces with its MAC address. For more information, see <a href="#">MAC Address Placeholder in URL and File Name</a> on page 1275.</p>
<pre>configure system &gt; automatic-update &gt; sbc- user-info</pre>	<p>Defines the name of the SBC User Information file and the URL address (IP address or FQDN) of the server where the file is located. Optionally, the</p>

Parameter	Description
[SBCUserInfoFileUrl]	<p>username and password (<code>'https://username:password@10.1.1.1/&lt;file name&gt;'</code>) for access authentication with the server can also be configured. For example:</p> <pre>'https://www.company.com/SBC-User-Info.csv'</pre> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>You can use the placeholder string "<code>&lt;MAC&gt;</code>" (case-sensitive) in the URL path and filename, which the device replaces with its MAC address. For more information, see <a href="#">MAC Address Placeholder in URL and File Name</a> on page 1275.</li> <li>When using the ini file, the value must be enclosed by single quotation marks (<code>'...'</code>).</li> </ul>
<pre>configure system &gt; automatic-update &gt; user-info [UserInfoFileURL]</pre>	<p>Defines the name of the User Information file and the URL address (IP address or FQDN) of the server where the file is located. Optionally, the username and password (<code>'https://username:password@10.1.1.1/&lt;file name&gt;'</code>) for access authentication with the server can also be configured.</p> <p>The maximum length of the URL address is 99 characters.</p> <p>Example syntax:</p> <pre>'http://&lt;server_name&gt;/&lt;filename&gt;' 'https://&lt;server_name&gt;/filename'</pre> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The parameter is used for <b>backward compatibility only</b>. Use the [GWUserInfoFileUrl] or [SBCUserInfoFileUrl] parameter (above) instead.</li> <li>When using the ini file, the value must be enclosed by single quotation marks (<code>'...'</code>).</li> </ul>
<pre>configure system &gt; automatic-update &gt; feature-key</pre>	<p>Defines the name of the License Key file and the URL address of the server where the file is located.</p>



Parameter	Description
[FeatureKeyURL]	<p>Optionally, the username and password ('https://username:password@10.1.1.1/&lt;filename&gt;') for access authentication with the server can also be configured.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>You can use the placeholder string "&lt;MAC&gt;" (case-sensitive) in the URL path and filename, which the device replaces with its MAC address. For more information, see <a href="#">MAC Address Placeholder in URL and File Name</a> on page 1275.</li> <li>When using the ini file, the value must be enclosed by single quotation marks ('...').</li> </ul>
<pre>configure system &gt; automatic-update &gt; template-url</pre> <p>[TemplateUrl]</p>	<p>Defines the URL address in the File Template for automatic updates, of the provisioning server where the files to download are located. Optionally, the username and password ('https://username:password@10.1.1.1/&lt;filename&gt;') for access authentication with the server can also be configured.</p> <p>For more information, see <a href="#">File Template for Automatic Provisioning</a> on page 1277.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>You can use the placeholder string "&lt;MAC&gt;" (case-sensitive) in the URL path and filename, which the device replaces with its MAC address. For more information, see <a href="#">MAC Address Placeholder in URL and File Name</a> on page 1275.</li> <li>When using the ini file, the value must be enclosed by single quotation marks ('...').</li> </ul>
<pre>configure system &gt; automatic-update &gt; template-files-list</pre> <p>[AupdFilesList]</p>	<p>Defines the list of file types in the File Template for automatic updates, to download from the provisioning server.</p> <p>For more information, see <a href="#">File Template for Automatic Provisioning</a> on page 1277.</p>
<pre>configure system &gt; automatic-update &gt; web- favicon</pre> <p>[WebFaviconFileUrl]</p>	<p>Defines the name of the favicon image file and the URL address of the server where the file is located. This is used for the Automatic Update feature.</p> <p>For more information, see <a href="#">Customizing the Browser</a></p>

Parameter	Description
	<p><a href="#">Favicon</a> on page 49.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>You can use the placeholder string "&lt;MAC&gt;" (case-sensitive) in the URL path and filename, which the device replaces with its MAC address. For more information, see <a href="#">MAC Address Placeholder in URL and File Name</a> on page 1275.</li> <li>When using the ini file, the value must be enclosed by single quotation marks ('...').</li> </ul>
<p>[SBCWizardUrl]</p> <pre>configure system &gt; automatic-update &gt; sbc- wizard</pre>	<p>Defines the name of the SBC Wizard configuration template file and the URL address of the server where the file is located. Optionally, the username and password ('https://username:password@10.1.1.1/&lt;filename&gt;') for access authentication with the server can also be configured.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>You can use the placeholder string "&lt;MAC&gt;" (case-sensitive) in the URL path and filename, which the device replaces with its MAC address. For more information, see <a href="#">MAC Address Placeholder in URL and File Name</a> on page 1275.</li> <li>When using the ini file, the value must be enclosed by single quotation marks ('...').</li> </ul>
[MatrixCsvFileUrl]	<p>Defines a configuration table as a Comma-Separated Values (CSV) file and the URL address of the server where the file is located.</p> <p>The filename must include the name of the configuration table, for example:</p> <div style="background-color: #f0f0f0; padding: 10px; margin: 10px 0;"> <p>MatrixCsvFileUrl = 'http://www.corp.com/device_IPGroup.csv'</p> </div> <p>You can also include in the filename the string variable tag "MAC" (case-sensitive), which the device automatically replaces with its MAC address, for example:</p>

Parameter	Description
	<p>MatrixCsvFileUrl = 'http://www.corp.com/device_&lt;MAC&gt;_IPGroup.csv'</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to tables that support importing CSV files (e.g., Dial Plan table and SBC User Information table).</li> <li>■ The filename extension must be ".csv".</li> <li>■ You can use the placeholder string "&lt;MAC&gt;" (case-sensitive) in the URL path and filename, which the device replaces with its MAC address. For more information, see <a href="#">MAC Address Placeholder in URL and File Name</a> on page 1275.</li> <li>■ When using the ini file, the value must be enclosed by single quotation marks ('...').</li> </ul>
[AUPDResetURLOnWebConfig]	<p>Determines if the URLs configured for the [CmpFileURL] and [IniFileURL] parameters are deleted when you restart the device with a save to flash through the Web interface.</p> <ul style="list-style-type: none"> <li>■ [0] = The URLs remain defined for the parameters.</li> <li>■ [1] = (Default) The URLs are deleted (as the device assumes that you want to manually configure it instead of using the Automatic Update mechanism).</li> </ul> <p><b>Note:</b> If you have configured a URL for the [IniFileURL] parameter, the default value of the Web interface's 'Save to Flash' field changes to <b>No</b> instead of <b>Yes</b> (see <a href="#">Restarting the Device</a> on page 1203). This is to make sure that you don't unintentionally save configuration to flash when you restart the device through the Web interface.</p>

## Networking Parameters

This subsection describes the device's networking parameters.

## Ethernet Parameters

The Ethernet parameters are described in the table below.

**Table 69-10:Ethernet Parameters**

Parameter	Description
<pre>configure voip &gt; media settings &gt; arp-manager- timeout</pre> <p>[ArpManagerTimeout]</p>	<p>Defines the maximum duration or timeout (in seconds) that the device waits for an Address Resolution Protocol (ARP) reply. If no reply is received within this duration, the device terminates the call.</p> <p>The valid value is 1 to 20. The default is 3.</p> <p><b>Note:</b> The device first checks its internal ARP table for a MAC address that matches the destination IP address. It only sends an ARP request if no match is found.</p>

## Multiple VoIP Network Interfaces and VLAN Parameters

The IP network interfaces and VLAN parameters are described in the table below.

**Table 69-11:IP Network Interfaces and VLAN Parameters**

Parameter	Description
<b>VLAN Parameters</b>	
[EnableNTPasOAM]	<p>Defines the application type for Network Time Protocol (NTP) services.</p> <ul style="list-style-type: none"> <li>■ [1] = OAMP (default)</li> <li>■ [0] = Control</li> </ul> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>

## ICMP Parameters

The ICMP parameters are described in the table below.

**Table 69-12:ICMP Parameters**

Parameter	Description
<p>'Don't Send ICMP Unreachable Messages'</p> <pre>configure network &gt; network- settings &gt; icmp-disable-unreachable</pre>	<p>Enables the device to generate and send ICMP messages, if required.</p> <ul style="list-style-type: none"> <li>■ [0] No= (Default) Device sends</li> </ul>

Parameter	Description
[DisableICMPUnreachable]	ICMP Unreachable messages.  ■ [1] <b>Yes</b> = Device doesn't send ICMP Unreachable messages.
'Send and Receive ICMP Redirect Messages' configure network > network- settings > icmp-disable-redirect [DisableICMPRedirects]	Enables sending and receiving ICMP Redirect messages.  ■ [0] <b>Yes</b> = (Default) Device sends and accepts ICMP Redirect messages.  ■ [1] <b>No</b> = Device rejects ICMP Redirect messages and also doesn't send them.

## Quality of Service Parameters

The Quality of Service (QoS) parameters are described in the table below.

**Table 69-13:QoS Parameters**

Parameter	Description
<b>Layer-3 Class of Service (TOS/DiffServ) Parameters</b> CLI path: configure network > qos application-mapping	
'Media Premium QoS' media-qos [PremiumServiceClassMediaDiffServ]	Global parameter defining the DiffServ value for Premium Media CoS content.  You can also configure this feature per specific calls, using IP Profiles ('RTP IP DiffServ' parameter) or Tel Profiles ('RTP IP DiffServ' parameter). For a detailed description of the parameter and To configure the feature, see <a href="#">Configuring IP Profiles</a> on page 664 or <a href="#">Configuring Tel Profile</a> on page 738.  <b>Note:</b> If the feature is configured for a specific profile, the device ignores this global parameter for calls associated with the profile.
'Control Premium QoS' control-qos [PremiumServiceClassControlDiffServ]	Global parameter defining the DiffServ value for Premium Control CoS content (Call Control applications).  You can also configure the feature per specific calls, using IP Profiles ('Signaling DiffServ'

Parameter	Description
	parameter) or Tel Profiles ('Signaling DiffServ' parameter). For a detailed description of the parameter and To configure the feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664 or <a href="#">Configuring Tel Profile</a> on page 738. <b>Note:</b> If the feature is configured for a specific profile, the device ignores this global parameter for calls associated with the profile.
'Gold QoS' gold-qos [GoldServiceClassDiffServ]	Defines the DiffServ value for the Gold CoS content (Streaming applications). The valid range is 0 to 63. The default is 26.
'Bronze QoS' bronze-qos [BronzeServiceClassDiffServ]	Defines the DiffServ value for the Bronze CoS content (OAMP applications). The valid range is 0 to 63. The default is 10.

## NAT and STUN Parameters

The Network Address Translation (NAT) and Simple Traversal of UDP through NAT (STUN) parameters are described in the table below.

**Table 69-14:NAT and STUN Parameters**

Parameter	Description
<b>STUN Parameters</b>	
[EnableStunForward]	<p>Enables the device to forward incoming STUN packets (RFC 3849).</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable. The device doesn't forward received STUN packets.</li> <li>■ [1] = Enable. The device forwards received STUN packets.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<b>NAT Parameters</b>	
'NAT Traversal' configure voip >	Enables the NAT traversal feature for media when the device communicates with UAs located behind NAT.

Parameter	Description
media settings > disable-NAT-traversal [NATMode]	<ul style="list-style-type: none"> <li>■ [0] <b>Enable NAT Only if Necessary</b> = NAT traversal is performed only if the UA is located behind NAT: <ul style="list-style-type: none"> <li>✓ UA behind NAT: The device sends the media packets to the IP address:port obtained from the source address of the first media packet received from the UA.</li> <li>✓ UA not behind NAT: The device sends the packets to the IP address:port specified in the SDP 'c=' line (Connection) of the first received SIP message.</li> </ul> <p><b>Note:</b> If the SIP session is established (ACK) and the device (not the UA) sends the first packet, it sends it to the address obtained from the SIP message and only after the device receives the first packet from the UA does it determine whether the UA is behind NAT.</p> </li> <li>■ [1] <b>Disable NAT</b> = (Default) The device considers the UA as not located behind NAT and sends media packets to the UA using the IP address:port specified in the SDP 'c=' line (Connection) of the first received SIP message.</li> <li>■ [2] <b>Force NAT</b> = The device always considers the UA as behind NAT and sends the media packets to the IP address:port obtained from the source address of the first media packet received from the UA. The device only sends packets to the UA after it receives the first packet from the UA (to obtain the IP address).</li> <li>■ [3] <b>NAT by Signaling</b> = The device identifies whether or not the UA is located behind NAT based on SIP signaling. The device assumes that if signaling is behind NAT that the media is also behind NAT, and vice versa. <ul style="list-style-type: none"> <li>✓ UA behind NAT: The device sends media according to option <b>Force NAT</b> (2). If the 'Media Latch Mode' parameter is configured to <b>Strict</b>, the 'Media Latch Mode' parameter automatically changes to <b>Dynamic</b>.</li> <li>✓ UA not behind NAT: The device sends media</li> </ul> </li> </ul>

Parameter	Description
	<p>according to option <b>Disable NAT</b> (1).</p> <p><b>Note:</b> : This option is applicable only to SBC calls. If the parameter is configured to this option, Gateway calls use option <b>Enable NAT Only if Necessary</b> (0), by default.</p> <p>■ [4] <b>NAT by Signaling Restricted IP</b> = The device identifies whether or not the UA is located behind NAT based on SIP signaling. The device assumes that if signaling is behind NAT that the media is also behind NAT, and vice versa.</p> <ul style="list-style-type: none"> <li>• UA behind NAT: The device sends media only when the source of the media packets is the signaling IP address (source of the INVITE). If the 'Media Latch Mode' parameter is configured to <b>Strict</b>, the 'Media Latch Mode' parameter automatically changes to <b>Dynamic</b>.</li> <li>• UA not behind NAT: The device sends media according to option <b>Disable NAT</b> (1).</li> </ul> <p><b>Note:</b> This option is applicable only to SBC calls. For more information on NAT traversal, see <a href="#">First Incoming Packet Mechanism</a> on page 183.</p>
<p>'NAT IP Address'</p> <pre>configure voip &gt; sip- definition general- settings &gt; nat-ip- addr</pre> <p>[StaticNatIP]</p>	<p>Defines the global (public) IP address of the device to enable static NAT between the device and the Internet. For more information, see <a href="#">Configuring a Static NAT IP Address for All Interfaces</a> on page 179.</p> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
[NATBindingDefaultTimeout]	<p>The device sends SNMP keep-alive traps periodically - every 9/10 of the time configured by the parameter (in seconds). Therefore, the parameter is applicable only if you configure the [SendKeepAliveTrap] parameter to [1].</p> <p>The parameter is used to allow SNMP communication with AudioCodes One Voice Operations Center (OVOC) management platform, located in the WAN, when the device is located behind NAT. It is needed to keep the NAT pinhole open for the SNMP messages sent from OVOC to the device.</p>



Parameter	Description
	<p>The valid range is 0 to 2,592,000. The default is 30.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
<p>'SIP NAT Detection'</p> <pre>configure voip &gt; sip- definition advanced- settings &gt; sip-nat- detect</pre> <p>[SIPNatDetection]</p>	<p>Enables the device's NAT Detection mechanism to detect if the incoming INVITE message is sent from an endpoint that's located behind NAT. If not enabled, the device processes incoming SIP messages as received from endpoints that are not located behind NAT and sends them according to the SIP standard.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = (Default) Enabled.</li> </ul> <p>For more information on the NAT Detection feature, see <a href="#">Enabling SIP NAT Detection when UA Located behind NAT</a> on page 181.</p>
<p>'BFCP IP from Audio Media'</p> <pre>configure voip &gt; sbc settings &gt; bfcf-ip- from-audio</pre> <p>[BFCPNatFromAudio]</p>	<p>Enables the handling of calls with voice and Binary Floor Control Protocol (BFCP) media streams that are received from behind a NAT.</p> <p>You can also configure this functionality per specific calls, using IP Profiles. For a detailed description of the parameter and for configuring this functionality in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If this functionality is configured for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>

## DNS Parameters

The Domain name System (DNS) parameters are described in the table below.

**Table 69-15:DNS Parameters**

Parameter	Description
<p>'Default Primary DNS Server IP'</p> <pre>configure network &gt; dns settings &gt; dns- default-primary-server-ip</pre>	<p>Defines the address of the default primary IPv4 DNS server.</p>

Parameter	Description
[DefaultPrimaryDnsServerIp]	The valid value is an IPv4 address in dotted-decimal notation. The default is 8.8.8.8. For more information, see <a href="#">Configuring Default DNS Servers</a> on page 195.
'Default Secondary DNS Server IP' <code>configure network &gt; dns settings &gt; dns-default-secondary-server-ip</code> [DefaultSecondaryDnsServerIp]	Defines the address of the default secondary IPv4 DNS server. The valid value is an IPv4 address in dotted-decimal notation. The default is 8.8.4.4. For more information, see <a href="#">Configuring Default DNS Servers</a> on page 195.
'Default Primary DNS Server IPv6' <code>configure network &gt; dns settings &gt; dns-default-primary-server-ipv6</code> [DefaultPrimaryDnsServerIpv6]	Defines the address of the default primary IPv6 DNS server. The valid value is an IPv6 address. The default is 2001:4860:4860::8888. For more information, see <a href="#">Configuring Default DNS Servers</a> on page 195.
'Default Primary DNS Server IPv6' <code>configure network &gt; dns settings &gt; dns-default-secondary-server-ipv6</code> [DefaultSecondaryDnsServerIpv6]	Defines the address of the default secondary IPv6 DNS server. The valid value is an IPv6 address. The default is 2001:4860:4860::8844. For more information, see <a href="#">Configuring Default DNS Servers</a> on page 195.

## DHCP Parameters

The Dynamic Host Control Protocol (DHCP) parameters are described in the table below.

**Table 69-16:DHCP Parameters**

Parameter	Description
[DhcpOption160Support]	<p>Enables the use of DHCP Option 160.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable</li> <li>■ [1] = Enable</li> </ul> <p>For more information, see <a href="#">Provisioning the Device using DHCP Option 160</a> on page 1269.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
[DHCP120OptionMode]	<p>Enables the acceptance of DHCP Option 120 in DHCP responses sent by a DHCP server.</p> <ul style="list-style-type: none"> <li>■ [0] = DHCP Option 120 is not supported and ignored if received in the DHCP response.</li> <li>■ [1] = (Default) DHCP Option 120 is supported and if received, the device adds the SIP server information to the Proxy Set.</li> </ul>
[DHCPSpeedFactor]	<p>Defines the device's DHCP renewal speed for a leased IP address from a DHCP server.</p> <ul style="list-style-type: none"> <li>■ [0] = Disable</li> <li>■ [1] = (Default) Normal</li> <li>■ [2] to [10] = Fast</li> </ul> <p>When set to 0, the DHCP lease renewal is disabled. Otherwise, the renewal time is divided by this factor. Some DHCP-enabled routers perform better when set to 4.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>

## Clock (Date and Time) Synchronization Parameters

The device's clock synchronization parameters are described in the table below.

**Table 69-17:Device Clock Synchronization Parameters**

Parameter	Description
<b>NTP</b>	
<p><b>Note:</b> For more information on Network Time Protocol (NTP), see <a href="#">Synchronizing Date and Time through SNTP</a> on page 137.</p>	

Parameter	Description
<p>'Enable NTP'</p> <pre>configure system &gt; ntp &gt; enable</pre> <p>[NTPEnable]</p>	<p>Enables the device (as an NTP client) to synchronize its local clock (date and time) with an NTP server.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared = Disabled</li> <li>■ [1] Check box selected = (Default) Enabled</li> </ul>
<p>'NTP Interface'</p> <pre>configure system &gt; ntp &gt; ntp-network- interface</pre> <p>[NTPInterface]</p>	<p>Assigns an IP Interface from the IP Interfaces table (see <a href="#">Configuring IP Network Interfaces</a> on page 157) for NTP communication.</p> <p>By default, the IPv4 OAMP interface is assigned.</p> <p><b>Note:</b> The IP address version (IPv4 or IPv6) of the assigned IP Interface and the NTP server's address (see 'Primary NTP Server Address' and 'Secondary NTP Server Address' parameters) must be the same.</p>
<p>'Primary NTP Server Address'</p> <pre>configure system &gt; ntp &gt; primary-server</pre> <p>[NTPServerIP]</p>	<p>Defines the address (IPv4 or IPv6, or FQDN) of the primary (main) NTP server. The benefit of using an FQDN is that multiple IP addresses can be resolved from the DNS server, providing NTP server redundancy.</p> <p>The default IP address is 0.0.0.0.</p> <p><b>Note:</b> The IP address version (IPv4 or IPv6) of the NTP server's address and the assigned IP Interface (see 'NTP Interface' parameter) must be the same.</p>
<p>'Secondary NTP Server Address'</p> <pre>configure system &gt; ntp &gt; secondary-server</pre> <p>[NTPSecondaryServerIP]</p>	<p>Defines the address (IPv4 or IPv6, or FQDN) of the secondary NTP server. This NTP is used for redundancy; if the primary NTP server fails, then this NTP server is used.</p> <p>The default IP address is 0.0.0.0.</p> <p><b>Note:</b> The IP address version (IPv4 or IPv6) of the NTP server's address and the assigned IP Interface (see 'NTP Interface' parameter) must be the same.</p>
<p>'NTP Update Interval'</p> <pre>configure system &gt; ntp &gt; update-interval</pre> <p>[NTPUpdateInterval]</p>	<p>Defines the time interval (in seconds) that the NTP client requests for a time update.</p> <p>The range is 0 to 214783647. The default interval is 86400 (i.e., 24 hours).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ When configuring this parameter through CLI or ini file, the value must be a multiple of 60 (seconds). For example, to set an interval of 2 hours,</li> </ul>

Parameter	Description
	<p>configure the parameter to 7200 (i.e., 2 hours is 7200 seconds). If the value is not a multiple of 60, the device automatically rounds it to the nearest multiple of 60 and logs this adjustment in a syslog message. For example, if you enter 7195, the device rounds it to 7200.</p> <ul style="list-style-type: none"> <li>■ It's not recommended to configure the parameter to beyond one month (i.e., 2592000 seconds).</li> </ul>
'NTP Authentication Key Identifier' <code>auth-key-id</code> <code>[NtpAuthKeyId]</code>	<p>Defines the NTP authentication key identifier for authenticating NTP messages. The identifier must match the value configured on the NTP server. The NTP server may have several keys configured for different clients; this number identifies which key is used.</p> <p>The valid value is 1 to 65535. The default is 0 (i.e., no authentication is done).</p>
'NTP Authentication Secret Key' <code>configure system &gt; ntp</code> <code>&gt; auth-key-md5</code> <code>[ntpAuthMd5KeyPassword]</code>	<p>Defines the secret authentication key shared between the device (client) and the NTP server for authenticating NTP messages.</p> <p>The valid value is a string of up to 32 characters. By default, no key is defined.</p> <p><b>Note:</b> The parameter cannot be configured with wide characters.</p>
<b>Regional Clock and Daylight Saving Time</b>	
'UTC Offset' <code>configure system &gt;</code> <code>clock &gt; utc-offset</code> <code>[NTPServerUTCOffset]</code>	<p>Defines the Universal Time Coordinate (UTC) offset (in seconds) from the local time.</p> <p>The valid range is -86400 (i.e., -24 hours) to 86400 seconds (i.e., +24 hours). The default is 0.</p> <p>For more information, see <a href="#">Configuring UTC Offset or Time Zone</a> on page 140.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The offset setting is applied only on the hour. For example, if you configure the parameter at 15:42, the device applies the setting only at 16:00.</li> <li>■ When configuring this parameter through CLI or ini file, the value must be a multiple of 60 (seconds). For example, to set an offset of 2 hours, configure</li> </ul>

Parameter	Description
	the parameter to 7200 (i.e., 2 hours is 7200 seconds). If the value is not a multiple of 60, the device automatically rounds it to the nearest multiple of 60 and logs this adjustment in a syslog message. For example, if you enter 7195, the device rounds it to 7200.
'Daylight Saving Time' <pre>configure system &gt; clock &gt; summer-time &gt; summer-time</pre> [DayLightSavingTimeEnable]	Enables daylight saving time (DST). <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> For more information, see <a href="#">Configuring Daylight Saving Time</a> on page 141.
'Start Time / Day of Month Start' <pre>configure system &gt; clock &gt; summer-time &gt; start</pre> [DayLightSavingTimeStart]	Defines the date and time when DST begins. This value can be configured using any of the following formats: <ul style="list-style-type: none"> <li>■ Day of year - <i>mm:dd:hh:mm</i>, where:               <ul style="list-style-type: none"> <li>✓ <i>mm</i> denotes month</li> <li>✓ <i>dd</i> denotes date of the month</li> <li>✓ <i>hh</i> denotes hour</li> <li>✓ <i>mm</i> denotes minutes</li> </ul>               For example, "05:01:08:00" denotes daylight saving starting from May 1 at 8 A.M.             </li> <li>■ Day of month - <i>mm:day/wk:hh:mm</i>, where:               <ul style="list-style-type: none"> <li>✓ <i>mm</i> denotes month (e.g., 04)</li> <li>✓ <i>day</i> denotes day of week (e.g., FRI)</li> <li>✓ <i>wk</i> denotes week of the month (e.g., 03)</li> <li>✓ <i>hh</i> denotes hour (e.g., 23)</li> <li>✓ <i>mm</i> denotes minutes (e.g., 10)</li> </ul>               For example, "04:FRI/03:23:00" denotes Friday, the third week of April, at 11 P.M. The week field can be 1-5, where 5 denotes the last occurrence of the specified day in the specified month. For example, "04:FRI/05:23:00" denotes the last Friday of April, at 11 P.M.             </li> </ul> For more information, see <a href="#">Configuring Daylight Saving Time</a> on page 141.

Parameter	Description
'End Time / Day of Month End' configure system > clock > summer-time > end [DayLightSavingTimeEnd]	Defines the date and time when DST ends. For a description of the format of this value, see the [DayLightSavingTimeStart] parameter. For more information, see <a href="#">Configuring Daylight Saving Time</a> on page 141.
'Offset' configure system > clock > summer-time > offset [DayLightSavingTimeOffset]	Defines the DST offset (in minutes). The valid range is 0 to 120. The default is 60. For more information, see <a href="#">Configuring Daylight Saving Time</a> on page 141. <b>Note:</b> The offset setting is applied only on the hour. For example, if you configure the parameter at 15:42, the device applies the setting only at 16:00.
<b>Date Header Date and Time Synchronization</b>	
'Synchronize Time from SIP Date Header' configure system > clock > date-header-time-sync [DateHeaderTimeSync]	Enables the device to obtain its date and time for its internal clock from the SIP Date header in 200 OK messages received in response to sent REGISTER messages.  <div> <input type="checkbox"/> [0] Check box cleared = (Default) Disabled         <input type="checkbox"/> [1] Check box selected = Enabled       </div> For more information, see <a href="#">Synchronizing Date and Time through SIP</a> on page 139.
'Time Synchronization Interval' configure system > clock > date-header-time-sync-interval [DateHeaderTimeSyncInterval]	Defines the minimum time (in seconds) between synchronization updates using the SIP Date header method for clock synchronization. The valid value range is 60 to 86,400. The default is 900. For more information, see <a href="#">Synchronizing Date and Time through SIP</a> on page 139.

## Debugging and Diagnostics Parameters

This subsection describes the device's debugging and diagnostic parameters.

### General Parameters

The general debugging and diagnostic parameters are described in the table below.

**Table 69-18:General Debugging and Diagnostic Parameters**

Parameter	Description
'Delay After Reset [sec]' configure voip > sip- definition advanced- settings > delay-after- reset [GWAppDelayTime]	Defines the time interval (in seconds) that the device's operation is delayed after a restart.  The valid range is 0 to 45. The default is 7 seconds.  <b>Note:</b> This feature helps overcome connection problems caused by some LAN routers or IP configuration parameters' modifications by a DHCP server.
[EnableAutoRAITransmitBER]	Enables the device to send a remote alarm indication (RAI) when the bit error rate (BER) is greater than 0.001.  ■ [0] = Disable (default) ■ [1] = Enable

## SIP Test Call Parameters

The SIP Signaling Test Call parameters are described in the table below.

**Table 69-19:SIP Test Call Parameters**

Parameter	Description
'Test Call DTMF String' configure troubleshoot > test-call settings > testcall-dtmf-string [TestCallDtmfString]	Defines the DTMF tone that is played for answered test calls (incoming and outgoing).  The DTMF string can be up to 15 strings. The default is "3212333". If no string is defined (empty), DTMF is not played.
'Test Call ID' configure troubleshoot > test-call settings > testcall-id [TestCallID]	Defines the test call prefix number ( <i>ID</i> ) of the simulated phone on the device. Incoming calls received with this called prefix number are identified as test calls.  This can be any string of up to 15 characters. By default, no number is defined.  <b>Note:</b> The parameter is only for testing incoming calls destined to this prefix number.

## Syslog, CDR and Debug Parameters

The syslog, CDR and debug parameters are described in the table below.



**Table 69-20: Syslog, CDR and Debug Parameters**

Parameter	Description
<b>Syslog</b>	
<p>'Enable Syslog'</p> <pre>configure troubleshoot &gt; syslog &gt; syslog</pre> <p>[EnableSyslog]</p>	<p>Determines whether the device sends logs and error messages (e.g., CDRs) generated by the device to a syslog server.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you enable syslog, you also need to configure the syslog server's address (IP address or FQDN), using the [SyslogServerIP] parameter.</li> <li>■ Syslog messages may increase the network traffic.</li> <li>■ To configure syslog SIP message logging levels, use the [GwDebugLevel] parameter.</li> </ul>
<p>'Syslog Network Interface Name'</p> <pre>configure troubleshoot &gt; syslog &gt; syslog-interface</pre> <p>[SyslogInterface]</p>	<p>Assigns an IP Interface from the IP Interfaces table (see <a href="#">Configuring IP Network Interfaces</a> on page 157) for communication with the primary syslog server.</p> <p>By default, the OAMP interface is used.</p> <p><b>Note:</b> The IP address version (IPv4 or IPv6) of the IP Interface and the syslog server's address must be the same.</p>
<p>'Server IP Address'</p> <pre>configure troubleshoot &gt; syslog &gt; syslog-ip</pre> <p>[SyslogServerIP]</p>	<p>Defines the address (IP address or FQDN) of the computer on which the primary syslog server is running. The syslog server is an application designed to collect the logs and error messages generated by the device. The default IP address is 0.0.0.0.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ To configure secondary syslog servers, see <a href="#">Configuring Secondary Syslog Servers</a> on page 1492.</li> </ul>

Parameter	Description
<p>'Server Port'</p> <pre>configure troubleshoot &gt; syslog &gt; syslog-port</pre> <p>[SyslogServerPort]</p>	<p>Defines the UDP port of the primary syslog server.</p> <p>The valid range is 0 to 65,535. The default port is 514.</p> <p><b>Note:</b> To configure secondary syslog servers, see <a href="#">Configuring Secondary Syslog Servers</a> on page 1492.</p>
<p>'Syslog Protocol'</p> <pre>configure troubleshoot &gt; syslog &gt; syslog-protocol</pre> <p>[SyslogProtocol]</p>	<p>Defines the transport protocol for communicating with the primary syslog server.</p> <ul style="list-style-type: none"> <li>■ [0] <b>UDP</b> (default)</li> <li>■ [1] <b>TCP</b></li> <li>■ [2] <b>TLS</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you configure the parameter to <b>TLS</b>, you also need to select a TLS Context (certificate), as described in <a href="#">Configuring the Primary Syslog Server Address</a> on page 1490.</li> <li>■ To configure secondary syslog servers, see <a href="#">Configuring Secondary Syslog Servers</a> on page 1492.</li> </ul>
<p>'Syslog TLS Context'</p> <pre>configure troubleshoot &gt; syslog &gt; syslog-tls-context-name</pre> <p>[SyslogTLSContext]</p>	<p>Assigns a TLS Context when the TLS transport protocol is used for communication with the syslog server (primary and secondary servers).</p> <p>For configuring TLS Contexts, see <a href="#">Configuring TLS Certificate Contexts</a> on page 224.</p>
<p>'Log Severity Level'</p> <pre>log-level</pre> <p>[SyslogLogLevel]</p>	<p>Defines the minimum severity level of messages included in the syslog message that is generated by the device.</p> <p>The specified severity level and all higher severity levels are included in the syslog message. For example, if you configure the parameter to <b>Alert</b>, the syslog will include messages with Alert severity level and</p>

Parameter	Description
	<p>messages with Emergency severity level. The severity levels are listed below from highest to lowest severity.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Emergency</b></li> <li>■ [1] <b>Alert</b></li> <li>■ [2] <b>Critical</b></li> <li>■ [3] <b>Error</b></li> <li>■ [4] <b>Warning</b></li> <li>■ [5] <b>Notice</b> (default)</li> <li>■ [6] <b>Info [not recommended]</b></li> <li>■ [7] <b>Debug [not recommended]</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ It's recommended to leave the syslog severity level at its default setting (i.e., <b>Notice</b>) to prevent excessive utilization of the device's resources. Changing severity level is typically done only by AudioCodes Support for debugging.</li> <li>■ If you configure the parameter to <b>Info [not recommended]</b> or <b>Debug [not recommended]</b>, the parameter returns to default value (<b>Notice</b>) after a device restart or HA switchover.</li> </ul>
[EnableConsoleLog]	<p>Enables the device to send the syslog messages to the serial console (over the device's physical serial interface). This may be useful, for example, if you no longer have network access to the device and you would like to perform diagnostics.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable</li> <li>■ [1] = Enable</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ Even when enabled, the device</li> </ul>

Parameter	Description
	continues sending the syslog messages to the configured remote syslog server.
<b>HTTP Client Requests and Response</b>	
<pre>configure troubleshoot &gt; logging settings &gt; enable- http-client-dbg-msg</pre> <p>[EnableHttpClientDbgMsg]</p>	<p>Enables the device to log (syslog) HTTP requests and responses (like CURL's verbose data) received from HTTP clients.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable</li> <li>■ [1] = Enable</li> </ul> <p><b>Note:</b> To log only specific HTTP clients (based on URL filters), see the [HTTPLogFilter] parameter.</p>
<pre>configure troubleshoot &gt; logging settings &gt; http-log- filter</pre> <p>[HTTPLogFilter]</p>	<p>Defines the HTTP clients whose requests and responses you want the device to log, based on the presence of specific strings within their URLs.</p> <p>The valid value is a string of up to 256 characters. You can configure the parameter with multiple strings, where each string is separated by a space (e.g., 'url1 url2 url3'). The value must be enclosed by single quotation marks (' '). The default is an empty string (' '), which means that the device logs requests and responses from all HTTP clients.</p> <p><b>Note:</b> To enable the logging of HTTP client requests and responses, see the [EnableHttpClientDbgMsg] parameter.</p>
<b>CDR</b>	
<p>'CDR Syslog Server IP Address'</p> <pre>configure troubleshoot &gt; cdr &gt; cdr-srvr-ip-adrr</pre> <p>[CDRSyslogServerIP]</p>	<p>Defines the address (IPv4 or IPv6, or FQDN) of the syslog server to where the device sends the CDRs.</p> <p>By default, no address is defined. If not configured, the device sends the CDRs (with the syslog messages) to the syslog server configured by the [SyslogServerIP] parameter. If you configure an address for the [CDRSyslogServerIP] parameter, the</p>

Parameter	Description
	<p>device sends the CDRs only to this CDR syslog server and not to the syslog server configured by the [SyslogServerIP] parameter.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The CDRs are sent to UDP port 514 (default syslog port).</li> <li>■ To enable the device to send CDRs, you also need to enable syslog (see <a href="#">Enabling Syslog</a> on page 1490).</li> </ul>
<p>'Call-End CDR SIP Reasons Filter'</p> <pre>configure troubleshoot &gt; cdr &gt; call-end-cdr-sip-reasons-filter</pre> <p>[CallEndCDRSIPReasonsFilter]</p>	<p>Defines SIP release cause codes that if received for the call, the device doesn't send Call-End CDRs for the call.</p> <p>The valid value is 300 through to 699. You can configure the parameter with multiple codes using a comma to separate them (e.g., 301,400,404). You can also use "xx" to denote a range (e.g., 3xx).</p>
<p>'Call-End CDR Zero Duration Filter'</p> <pre>configure troubleshoot &gt; cdr &gt; call-end-cdr-zero-duration-filter</pre> <p>[CallEndCDRZeroDurationFilter]</p>	<p>Enables the device to not send Call-End CDRs if the call's duration is zero (0).</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul>
<p>'CDR Report Level'</p> <pre>configure troubleshoot &gt; cdr &gt; cdr-report-level</pre> <p>[CDRReportLevel]</p>	<p>Enables media and signaling-related CDRs to be sent to a syslog server and defines the call stage at which they are sent.</p> <ul style="list-style-type: none"> <li>■ [0] <b>None</b> = (Default) CDRs are not used.</li> <li>■ [1] <b>End Call</b> = CDR is sent to the syslog server at the end of each call.</li> <li>■ [2] <b>Start &amp; End Call</b> = CDR report is sent to syslog at the start and end of each call.</li> <li>■ [3] <b>Connect &amp; End Call</b> = CDR report is sent to syslog at connection and at the end of each call.</li> <li>■ [4] <b>Start &amp; End &amp; Connect Call</b> = CDR</li> </ul>

Parameter	Description
	<p>report is sent to syslog at the start, at connection, and at the end of each call.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the SBC application: The parameter enables only signaling-related CDRs. To enable media-related CDRs for SBC calls, use the [MediaCDRReportLevel] parameter.</li> <li>■ The CDR Syslog message complies with RFC 3164 and is identified by: Facility = 17 (local1) and Severity = 6 (Informational).</li> <li>■ This mechanism is active only when syslog is enabled (i.e., the parameter [EnableSyslog] is set to [1]).</li> </ul>
<p>'Media CDR Report Level'</p> <pre>configure troubleshoot &gt; cdr &gt; media-cdr-rprt-level</pre> <p>[MediaCDRReportLevel]</p>	<p>Enables media-related CDRs of SBC calls to be sent to a syslog server and defines the call stage at which they are sent.</p> <ul style="list-style-type: none"> <li>■ [0] <b>None</b> = (Default) No media-related CDR is sent.</li> <li>■ [1] <b>End Media</b> = Sends a CDR only at the end of the call.</li> <li>■ [2] <b>Start &amp; End Media</b> = Sends a CDR once the media starts. In some calls it may only be after the call is established, but in other calls the media may start at ringback tone. A CDR is also sent upon termination (end) of the media in the call.</li> <li>■ [3] <b>Update &amp; End Media</b> = Sends a CDR when an update occurs in the media of the call. For example, a call starts and a ringback tone occurs, a re-INVITE is sent for a fax call and as a result, a CDR with the MediaReportType field set to "Update" is sent, as the media was changed from voice to T.38. A CDR is also sent upon termination (end) of the</li> </ul>

Parameter	Description
	<p>media in the call.</p> <ul style="list-style-type: none"> <li>■ <b>[4] Start &amp; End &amp; Update Media =</b> Sends a CDR at the start of the media, upon an update in the media (if occurs), and at the end of the media.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the SBC application.</li> <li>■ To enable CDR generation as well as enable signaling-related CDRs, use the <code>CDRReportLevel</code> parameter.</li> </ul>
<p>'REST CDR Report Level'</p> <pre>configure system &gt; cdr &gt; rest-cdr-report-level</pre> <p>[RestCdrReportLevel]</p>	<p>Enables signaling-related CDRs to be sent to a REST server and defines the call stage at which they are sent.</p> <ul style="list-style-type: none"> <li>■ <b>[0] None =</b> (Default) CDRs are not sent.</li> <li>■ <b>[1] End Call =</b> CDRs are sent at the end (SIP BYE) of each call.</li> <li>■ <b>[2] Start &amp; End Call =</b> CDRs are sent at the start (SIP INVITE) and end of each call.</li> <li>■ <b>[3] Connect &amp; End Call =</b> CDRs are sent at call connection (200 OK) and end of each call.</li> <li>■ <b>[4] Start &amp; End &amp; Connect Call =</b> CDRs are sent at the start, connection, and end of each call.</li> <li>■ <b>[5] Connect Only =</b> CDRs are sent at call connection.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ To specify the REST server, use the <code>[RestCdrHttpServer]</code> parameter.</li> <li>■ For the device to generate CDRs, you must enable syslog messaging (see the <code>[EnableSyslog]</code> parameter).</li> <li>■ CDRs are sent in JSON format.</li> </ul>

Parameter	Description
<p>'REST CDR HTTP Server Name'</p> <pre>configure system &gt; cdr &gt; rest-cdr-http-servers</pre> <p>[RestCdrHttpServer]</p>	<p>Defines the REST server (configured in the Remote Web Services table) to where the device sends CDRs through REST API.</p> <p>The valid value is a string (i.e., name of the REST server). By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the ini file and CLI command, the parameter value is case sensitive.</li> <li>■ To enable CDR generation for the REST server, see the [RestCdrReportLevel] parameter.</li> <li>■ The REST server is configured in the Remote Web Services table (see <a href="#">Configuring Remote Web Services</a> on page 429).</li> </ul>
<p>'Call Success SIP Reasons'</p> <pre>configure troubleshoot &gt; cdr &gt; call-success-sip-reasons</pre> <p>[CallSuccessSIPReasons]</p>	<p>Defines the SIP response code that you want the device to consider as a call success, which is indicated by the optional 'Call Success' field in the sent CDR. This parameter overrides the device's default behavior of how it considers calls a success or failure based on SIP responses.</p> <p>The valid value is string of up to 128 characters to represent SIP response codes (e.g., 404). You can configure the parameter with multiple response codes, whereby each code is separated by a comma without spaces before or after (e.g., 404,408,406). You can also configure a range of responses using the "xx" wildcard (e.g., 4xx,502). By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If an overlap of a SIP response occurs between the configured 'Call Success SIP Reasons' and 'Call Failure SIP Reasons' parameters, the device uses the parameter that is configured with the specific response code, instead of the parameter configured with the range</li> </ul>



Parameter	Description
	<p>("xx"). For example, if you configure the 'Call Success SIP Reasons' parameter with "404,5xx" and the 'Call Failure SIP Reasons' parameter with "502", for 502 responses, the device uses the settings of the 'Call Failure SIP Reasons' parameter only. In other words, a call with SIP response code 502 is considered as a call failure.</p> <ul style="list-style-type: none"> <li>■ By default, the device considers these SIP response codes as a call success: <ul style="list-style-type: none"> <li>✓ No answer (452 and 487)</li> <li>✓ Busy (486 and 600)</li> <li>✓ Forwarded (300, 301, 302, 303, and 305)</li> </ul> </li> </ul> <p>For all other SIP failure response codes, the device considers them as a call failure.</p>
<p>'Call Failure SIP Reasons'</p> <p><code>call-failure-sip-reasons</code></p> <p>[CallFailureSIPReasons]</p>	<p>Defines the SIP response codes that you want the device to consider as call failure, which is indicated by the optional 'Call Success' field in the sent CDR. This parameter overrides the device's default behavior of how it considers calls a success or failure based on SIP responses.</p> <p>The valid value is string of up to 128 characters to represent SIP response codes (e.g., 486). You can configure the parameter with multiple response codes, whereby each code is separated by a comma without spaces before or after (e.g., 486,408,406). You can also configure a range of responses using the "xx" wildcard (e.g., 4xx,502). By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If an overlap of a SIP response occurs between the configured 'Call Success SIP Reasons' and 'Call Failure SIP Reasons'</li> </ul>

Parameter	Description
	<p>parameters, the device uses the parameter that is configured with the specific response code, instead of the parameter configured with the range ("xx"). For example, if you configure the 'Call Success SIP Reasons' parameter with "486,5xx" and the 'Call Failure SIP Reasons' parameter with "502", for 502 responses, the device uses the settings of the 'Call Failure SIP Reasons' parameter only. In other words, a call with SIP response code 502 is considered as a call failure.</p> <ul style="list-style-type: none"> <li>■ By default, the device considers these SIP response codes as a call success: <ul style="list-style-type: none"> <li>✓ No answer (452 and 487)</li> <li>✓ Busy (486 and 600)</li> <li>✓ Forwarded (300, 301, 302, 303, and 305)</li> </ul> </li> </ul> <p>For all other SIP failure response codes, the device considers them as a call failure.</p>
<p>'Call Success Internal Reasons'  <code>call-success-internal-reasons</code>  [CallSuccessInternalReasons]</p>	<p>Defines the internal response codes (generated by the device) that you want the device to consider as call success, which is indicated by the optional 'Call Success' field in the sent CDR. This parameter overrides the device's default behavior of how it considers calls a success or failure based on internally responses.</p> <p>The valid value is string of up to 128 characters to represent internal response codes (e.g., 851). You can configure the parameter with multiple response codes, whereby each code is separated by a comma without spaces before or after (e.g., 851,320). You can also configure a range of responses using the "xx" wildcard (e.g., 8xx,320). By default, no value is defined.</p>

Parameter	Description
	<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For a list of the internal response codes, see the 'Termination Reason' [410] CDR field in <a href="#">CDR Field Description</a> on page 1387.</li> <li>■ If an overlap of a SIP response occurs between the configured 'Call Success SIP Reasons' and 'Call Failure SIP Reasons' parameters, the device uses the parameter that is configured with the specific response code, instead of the parameter configured with the range ("xx"). For example, if you configure the 'Call Success SIP Reasons' parameter with "320,8xx" and the 'Call Failure SIP Reasons' parameter with "851", for 851 responses, the device uses the settings of the 'Call Failure SIP Reasons' parameter only. In other words, a call with response code 851 is considered as a call failure.</li> </ul>
<p>'Call Failure Internal Reasons'  <code>call-failure-internal-reasons</code>  [CallFailureInternalReasons]</p>	<p>Defines the internal response codes (generated by the device) that you want the device to consider as call failure, which is indicated by the optional 'Call Success' field in the sent CDR. This parameter overrides the device's default behavior of how it considers calls a success or failure based on internally responses.</p> <p>The valid value is string of up to 128 characters to represent internal response codes (e.g., 851). You can configure the parameter with multiple response codes, whereby each code is separated by a comma without spaces before or after (e.g., 851,320). You can also configure a range of responses using the "xx" wildcard (e.g., 8xx,320). By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For a list of the internal response codes,</li> </ul>

Parameter	Description
	<p>see the 'Termination Reason' [410] CDR field in <a href="#">CDR Field Description</a> on page 1387.</p> <ul style="list-style-type: none"> <li>■ If an overlap of a SIP response occurs between the configured 'Call Success SIP Reasons' and 'Call Failure SIP Reasons' parameters, the device uses the parameter that is configured with the specific response code, instead of the parameter configured with the range ("xx"). For example, if you configure the 'Call Success SIP Reasons' parameter with "320,8xx" and the 'Call Failure SIP Reasons' parameter with "851", for 851 responses, the device uses the settings of the 'Call Failure SIP Reasons' parameter only. In other words, a call with response code 851 is considered as a call failure.</li> </ul>
'No User Response Before Connect' no-user-response-before-connect [NoUserResponseBeforeConnectSuccess]	<p>Defines if the device considers a call as a success or failure when the internal response (generated by the device) "GWAPP_NO_USER_RESPONDING" (18) is received before call connect (SIP 200 OK).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Call Failure</b></li> <li>■ [1] <b>Call Success</b> (default)</li> </ul>
'No User Response After Connect' no-user-response-after-connect [NoUserResponseAfterConnectSuccess]	<p>Defines if the device considers a call as a success or failure when the internal response (generated by the device) "GWAPP_NO_USER_RESPONDING" (18) is received after call connect (SIP 200 OK).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Call Failure</b> (default)</li> <li>■ [1] <b>Call Success</b></li> </ul>
'Call Transferred before Connect' call-transferred-before-connect [CallTransferredBeforeConnectSuccess]	<p>Defines if the device considers a call as a success or failure when the internal response (generated by the device) "RELEASE_BECAUSE_CALL_TRANSFERRED" (807) is generated before call connect (SIP</p>

Parameter	Description
	<p>200 OK).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Call Failure</b> (default)</li> <li>■ [1] <b>Call Success</b></li> </ul>
<p>'Call Transferred after Connect'</p> <p><code>call-transferred-after-connect</code></p> <p>[CallTransferredAfterConnectSuccess]</p>	<p>Defines if the device considers a call as a success or failure when the internal response (generated by the device) "RELEASE_BECAUSE_CALL_TRANSFERRED" (807) is generated after call connect (SIP 200 OK).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Call Failure</b></li> <li>■ [1] <b>Call Success</b> (default)</li> </ul>
<p>'VoIP Debug Level'</p> <p><code>configure troubleshoot &gt; syslog &gt; debug-level</code></p> <p>[GwDebugLevel]</p>	<p>Enables syslog debug reporting and logging level.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No Debug</b> = (Default) Debug is disabled and syslog messages are not sent.</li> <li>■ [1] <b>Basic</b> = Sends debug logs of incoming and outgoing SIP messages.</li> <li>■ [5] <b>Detailed</b> = Sends debug logs of incoming and outgoing SIP message as well as many other logged processes.</li> </ul>
<p><code>configure system &gt; cdr &gt; non-call-cdr-rprt</code></p> <p>[EnableNonCallCdr]</p>	<p>Enables creation of CDR messages for non-call SIP dialogs (such as SUBSCRIBE, OPTIONS, and REGISTER).</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable</li> <li>■ [1] = Enable</li> </ul> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<p>'Optimization'</p> <p><code>configure troubleshoot &gt; syslog &gt; syslog-optimization</code></p> <p>[SyslogOptimization]</p>	<p>Enables the device to accumulate and bundle multiple debug messages into a single UDP packet and then send it to a syslog server. The benefit of this feature is that it reduces the number of UDP syslog packets, thereby improving (optimizing) CPU utilization.</p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p><b>Note:</b> The size of the bundled message is configured by the [MaxBundleSyslogLength] parameter.</p>
<pre>configure voip &gt; gateway digital settings &gt; mx-syslog- lgth</pre> <p>[MaxBundleSyslogLength]</p>	<p>Defines the maximum size (in bytes) threshold of logged syslog messages bundled into a single UDP packet, after which they are sent to a syslog server.</p> <p>The valid value range is 0 to 1220 (where 0 indicates that no bundling occurs). The default is 1220.</p> <p><b>Note:</b> The parameter is applicable only if the [GWDebugLevel] parameter is enabled.</p>
<p>'CPU Protection'</p> <pre>configure troubleshoot &gt; syslog &gt; syslog-cpu- protection</pre> <p>[SyslogCpuProtection]</p>	<p>Enables the protection of the device's CPU resources during debug reporting, ensuring voice traffic is unaffected. If CPU resources drop (i.e., high CPU usage) to a critical level (threshold), the device automatically lowers the debug level to free up CPU resources that were required for the previous debug-level functionality. When sufficient CPU resources become available again, the device increases the debug level. The threshold is configured by the 'Debug Level High Threshold' parameter (see below).</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = (Default) Enabled.</li> </ul>
<p>'Debug Level High Threshold'</p> <pre>configure troubleshoot &gt; syslog &gt; debug-level-high- threshold</pre> <p>[DebugLevelHighThreshold]</p>	<p>Defines the threshold (in percentage) for automatically switching to a different debug level, depending on CPU usage. The parameter is applicable only if the 'CPU Protection' parameter is enabled.</p> <p>The valid value is 0 to 100. The default is 90.</p> <p>The debug level is changed upon the following scenarios:</p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ CPU usage equals threshold: Debug level is reduced one level.</li> <li>■ CPU usage is at least 5% greater than threshold: Debug level is reduced another level.</li> <li>■ CPU usage is 5 to 19% less than threshold: Debug level is increased by one level.</li> <li>■ CPU usage is at least 20% less than threshold: Debug level is increased by another level.</li> </ul> <p>For example, assume that the threshold is set to 70% and the Debug Level to Detailed (5). When CPU usage reaches 70%, the debug level is reduced to Basic (1). When CPU usage increases by 5% or more than the threshold (i.e., greater than 75%), the debug level is disabled - No Debug (0). When the CPU usage decreases to 5% less than the threshold (e.g., 65%), the debug level is increased to Basic (1). When the CPU usage decreases to 20% less than the threshold (e.g., 50%), the debug level changes to Detailed (5).</p> <p><b>Note:</b> The device doesn't increase the debug level to a level that is higher than what you configured for the 'Debug Level' parameter.</p>
<pre>configure troubleshoot &gt; cdr &gt; time-zone-format [TimeZoneFormat]</pre>	<p>Defines the time zone that is displayed with the timestamp in CDRs. The timestamp appears in the CDR fields "Setup Time", "Connect Time", and "Release Time".</p> <p>The valid value is a string of up to six characters. The default is UTC. For example, if you configure the parameter TimeZoneFormat = GMT+11, the timestamp in CDRs are generated with the following time zone display:</p> <p>17:47:45.411 <b>GMT+11</b> Sun Jan 03 2018</p> <p><b>Note:</b> The time zone is only for display</p>

Parameter	Description
	purposes; it doesn't configure the actual time zone.
<pre>configure troubleshoot &gt; cdr &gt; call-duration-units</pre> <p>[CallDurationUnits]</p>	<p>Defines the unit of measurement for call duration ("Duration" field) in CDRs generated by the device.</p> <ul style="list-style-type: none"> <li>■ [0] Seconds (default)</li> <li>■ [1] Deciseconds</li> <li>■ [2] Centiseconds</li> <li>■ [3] Milliseconds</li> </ul> <p>The parameter applies to CDRs for syslog, RADIUS, local-device storage, and CDR history displayed in the Web interface.</p>
<p>'CDR Syslog Sequence Number'</p> <pre>configure system &gt; cdr &gt; cdr- seq-num</pre> <p>[CDRSyslogSeqNum]</p>	<p>Enables or disables the inclusion of the sequence number (S=) in CDR Syslog messages.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = (Default) Enabled.</li> </ul>
<pre>configure voip &gt; sip- definition settings &gt; send- acsessionid</pre> <p>[SendAcSessionIDHeader]</p>	<p>Enables the use of the Global Session ID in SIP messages (AC-Session-ID header), which is a unique identifier of the call session, even if it traverses multiple devices.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disables the feature. The device sends outgoing SIP messages without a Global Session ID (even if a Global Session ID was received in the incoming SIP message).</li> <li>■ [1] = Enables the feature. If the device receives an incoming SIP message containing a Global Session ID, it sends the same Global Session ID in the outgoing SIP message. If the incoming SIP message doesn't contain a Global Session ID or if a new session is initiated by the device, the device generates a new, unique Global Session ID and adds</li> </ul>



Parameter	Description
	<p>it to the outgoing SIP message.</p> <p>For more information, see <a href="#">Enabling Same Call Session ID over Multiple Devices</a> on page 1533.</p>
<p>'Activity Types to Report via Activity Log Messages'</p> <pre>configure troubleshoot &gt; activity-log</pre> <p>[ActivityListToLog]</p>	<p>Defines the operations (activities) performed in the Web interface that are reported to a syslog server.</p> <ul style="list-style-type: none"> <li>■ <b>[PVC] Parameters Value Change</b> = Changes made on-the-fly to parameters and tables, and Configuration file upload. Note that the ini file parameter, EnableParametersMonitoring can also be used to set this option.</li> <li>■ <b>[AFL] Auxiliary Files Loading</b> = Loading of Auxiliary files.</li> <li>■ <b>[DR] Device Restart</b> = Restarting the device from the Maintenance Actions page. <b>Note:</b> For this option to take effect, a device restart is required.</li> <li>■ <b>[FB] Flash Memory Burning</b> = Saving configuration with save to flash from the Maintenance Actions page.</li> <li>■ <b>[SWU] Device Software Upgrade</b> = Software updates (i.e., loading of cmp file) through the Software Upgrade Wizard.</li> <li>■ <b>[NAA] Non-Authorized Access</b> = Attempts to log in to the Web interface with a false or empty username or password.</li> <li>■ <b>[SPC] Sensitive Parameters Value Change</b> = Changes made to "sensitive" parameters: <ul style="list-style-type: none"> <li>✓ (1) IP Address</li> <li>✓ (2) Subnet Mask</li> <li>✓ (3) Default Gateway IP Address</li> </ul> </li> </ul>

Parameter	Description
	<p>✓ (4) ActivityListToLog</p> <ul style="list-style-type: none"> <li>■ [LL] <b>Login and Logout</b> = Web login and logout attempts.</li> <li>■ [CLI] <b>CLI Activity</b> = CLI commands entered by the user.</li> <li>■ [AE] <b>Action Executed</b> = Logs user actions that are not related to parameter changes. The actions can include, for example, file uploads, file downloads, file delete, lock-unlock maintenance actions, LDAP clear cache, register-unregister, and start-stop trunk. In the Web, these actions are typically done by clicking a button (e.g., the <b>LOCK</b> button).</li> <li>■ [INI] <b>Incremental INI</b> = Changes made to parameters due to the loading of an incremental ini file. If you choose this option, you can also define the maximum number of lines of parameters to log from the ini file, using the 'Incremental INI Activity Logs Max Number' parameter (see below).</li> </ul> <p><b>Note:</b> For the <i>ini</i> file parameter, enclose values in single quotation marks. To configure the ini file parameter with multiple values, use a comma-separated list, for example: ActivityListToLog = 'PVC', 'AFL', 'DR'.</p>
<p>'Incremental INI Activity Logs Max Number'</p> <pre>configure troubleshoot &gt; max- ini-activity-logs</pre> <p>[MaxINIActivityLog]</p>	<p>Defines the maximum number of lines of parameters from the loaded incremental ini file to log for the Activity Types to Report feature. The parameter is applicable when you configure the [ActivityListToLog] parameter to also include the INI value. The valid value is 0 to 2,000. The default is 1,000.</p> <p><b>Note:</b> The maximum number of lines doesn't count empty lines or lines containing only comments.</p>

Parameter	Description
[EnableParametersMonitoring]	<p>Enables the monitoring, through syslog messages, of parameters that are modified on-the-fly.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable</li> <li>■ [1] = Enable</li> </ul>
<p>'ISDN Facility Trace'</p> <pre>configure voip &gt; gateway digital settings &gt; isdn- facility-trace</pre> <p>[FacilityTrace]</p>	<p>Enables ISDN traces of Facility Information Elements (IE) for ISDN call diagnostics. This allows you to trace all the parameters contained in the Facility IE and view them in the syslog.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the feature to be functional, configure the [GWDebugLevel] parameter to at least level [1].</li> <li>■ The parameter is applicable only to digital interfaces.</li> </ul>
<p>'Destination IP Address'</p> <pre>configure troubleshoot &gt; logging settings &gt; dbg-rec- dest-ip</pre> <p>[DebugRecordingDestIP]</p>	<p>Defines the IP address (IPv4 or IPv6) of the server for capturing debug recording.</p>
<p>'Destination Port'</p> <pre>configure troubleshoot &gt; logging settings &gt; dbg-rec- dest-port</pre> <p>[DebugRecordingDestPort]</p>	<p>Defines the UDP port of the server for capturing debug recording.</p> <p>The default is 925.</p>
<p>'Debug Recording Timeout'</p> <pre>configure troubleshoot &gt; logging settings &gt; dbg-rec- timeout</pre> <p>[DebugRecordingTimeout]</p>	<p>Defines the maximum duration (in minutes) for the debug recording process. When this timer expires, the device automatically stops debug recording (unless you've explicitly stopped it before the timer expires, as described in <a href="#">Starting and Stopping Debug Recording</a> on page 1512).</p>

Parameter	Description
	<p>The valid value is 1 to 10,080 (7 days). The default is 60 (1 hour).</p> <p><b>Note:</b> If debug recording is currently running (i.e., started), the device resets the debug recording timer upon the following:</p> <ul style="list-style-type: none"> <li>■ A new rule is added to, or an existing rule is modified in the Logging Filters table.</li> <li>■ A device restart.</li> <li>■ An HA switchover.</li> </ul>
<p>'Start' Record/ 'Stop Record'</p> <pre>configure troubleshoot &gt; logging-settings &gt; dbg-rec- status</pre> <p>[DebugRecordingStatus]</p>	<p>Starts or stops debug recording.</p> <p>For more information on starting and stopping debug recording, see <a href="#">Starting and Stopping Debug Recording</a> on page 1512.</p> <p><b>Note:</b> The CLI command also displays the current debug recording status (Started or Stopped), and resets the debug recording timer, configured by the [DebugRecordingTimeout] parameter.</p>
<p>'Interface Name'</p> <pre>configure troubleshoot &gt; logging settings &gt; dbg-rec- int-name</pre> <p>[DebugRecordingIpInterfaceName]</p>	<p>Defines the IP Interface through which the device sends captured traffic to the debug server.</p> <p>The valid value is the name of the IP Interface, as configured in the IP Interfaces table (see <a href="#">Configuring IP Network Interfaces</a> on page 157). The default is the OAMP interface.</p>
<p>'Enable Core Dump'</p> <pre>enable-core-dump</pre> <p>[EnableCoreDump]</p>	<p>Enables the automatic generation of a Core Dump file upon a device crash.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul>
<p>'Core Dump Destination IP'</p> <pre>core-dump-dest-ip</pre> <p>[CoreDumpDestIP]</p>	<p>Defines the IP address of the remote server where you want the device to send the Core Dump file.</p> <p>By default, no IP address is defined.</p>

Parameter	Description
'Call Flow Report Mode' call-flow-report [CallFlowReportMode]	<p>Enables the device to send SIP call messages to OVOC so that OVOC can display SIP call dialog sessions as SIP call flow diagrams.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>For more information, see <a href="#">Enabling SIP Call Flow Diagrams in OVOC</a> on page 1531.</p>
configure troubleshoot > syslog > system-log-size [SystemLogSize]	<p>Defines the maximum size (in kilobytes) of the system log file.</p> <p>The valid value range is 10 to 2000 KB. The default is 200 KB.</p> <p>To view the logged information in this file, use the CLI command <code>show system log</code>.</p>
[PLThresholdLevelsPerMille]	<p>Defines packet-loss percentage ranges that are used in sent syslog messages to report packet loss in incoming media streams (RTP) in 15-second intervals.</p> <p>The valid value range is 1 to 1,000. The default is 5, 10, 20, 50.</p> <p>The syntax for configuring the parameter is: PLThresholdLevelsPerMille = Level1, Level2, Level3, Level4</p> <p>Where the levels represent the following ranges in the syslog:</p> <ul style="list-style-type: none"> <li>■ [No PL]</li> <li>■ [up to (Level1/10)% ]</li> <li>■ [(Level1/10)% - (Level2/10)%]</li> <li>■ [(Level2/10)% - (Level3/10)%]</li> <li>■ [(Level3/10)% - (Level4/10)%]</li> <li>■ [(Level4/10)% - 100%]</li> </ul> <p>For example (using default values): PLThresholdLevelsPerMille = 5, 10, 20, 50</p> <p>Therefore, the ranges are:</p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [No PL]</li> <li>■ [up to 0.5% ]</li> <li>■ [0.5% - 1%]</li> <li>■ [1% - 2%]</li> <li>■ [2% - 5%]</li> <li>■ [5% - 100%]</li> </ul> <p>For more information, see <a href="#">Packet Loss Indication in Syslog</a> on page 1509.</p>
<b>CDR Local Storage</b>	
<p>'File Size'</p> <pre>configure troubleshoot &gt; cdr &gt; file-size</pre> <p>[CDRLocalMaxFileSize]</p>	<p>Defines the size (in kilobytes) of each locally stored CDR file. When the Current file reaches this size, the device creates a CDR file containing all the CDRs from the Current file.</p> <p>The valid value is 100 to 10,000. The default is 1024.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ CDR file creation works together with the 'Rotation Period' parameter, whereby the file is created as soon as one of the parameter's ('File Size' or 'Rotation Period') settings are fulfilled (whichever is met earlier). For example, if the 'File Size' parameter is 100 and 'Rotation Period' is 60, and the file size reaches 100 kbytes after only 30 minutes has passed, the device creates the CDR file.</li> <li>■ The parameter is applicable only to local storage of CDRs.</li> </ul>
<p>'Number of Files'</p> <pre>configure troubleshoot &gt; cdr &gt; files-num</pre> <p>[CDRLocalMaxNumOfFiles]</p>	<p>Defines the maximum number of locally stored CDR files. If the maximum number is reached and a new file is created, the oldest file is deleted to make space for the new file (i.e., FIFO).</p> <p>The valid value is 2 to 4096 . The default is</p>

Parameter	Description
	<p>5.</p> <p><b>Note:</b> The parameter is applicable only to local storage of CDRs.</p>
<p>'Rotation Period'</p> <pre>configure troubleshoot &gt; cdr &gt; rotation-period</pre> <p>[CDRLocalInterval]</p>	<p>Defines how often (in minutes) the device creates a new CDR file for locally stored CDRs. For example, if configured to 60, every hour it creates a CDR file containing all the CDRs from the Current file.</p> <p>The valid value is 2 to 1440. The default is 60.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ CDR file creation works together with the 'File Size' parameter, whereby the file is created as soon as one of the parameter's ('File Size' or 'Rotation Period') settings are fulfilled (whichever is met earlier). For example, if the 'Rotation Period' parameter is 60 and 'File Size' is 100, and an hour has passed but the file size is only 50 kbytes, the device creates the CDR file.</li> <li>■ The CDR file is created even if there are no CDRs in the Current file.</li> <li>■ The parameter is applicable only to local storage of CDRs.</li> </ul>
<p><b>IP Trace Filters</b> (For more information, see <a href="#">Filtering IP Network Traces by Ethernet Port or VLAN</a> on page 1480.)</p>	
<p>'Recording Mode'</p> <pre>configure troubleshoot &gt; logging settings &gt; dbg-rec- ip-trace-entity</pre> <p>[DebugRecordingIpTraceEntity]</p>	<p>Defines the filtering of IP traces for log filtering rules (in the Logging Filters table) whose 'Filter Type' parameter is configured to <b>IP Trace</b>.</p> <ul style="list-style-type: none"> <li>■ <b>[0] All Physical Ethernet Ports =</b> (Default) The log filter for the IP trace is applied on packets received and sent (tagged and untagged) on all the physical Ethernet ports.</li> <li>■ <b>[1] Physical Ethernet Port =</b> The log filter for the IP trace is applied on</li> </ul>

Parameter	Description
	<p>packets received and sent on an Ethernet port configured by the 'Physical Ethernet Port' parameter (below).</p> <ul style="list-style-type: none"> <li>■ [3] <b>VLAN ID</b> = The log filter for the IP trace is applied on packets received and sent on a VLAN ID (underlying Ethernet Device) configured by the 'VLAN ID' parameter (below).</li> </ul>
<p>'Physical Ethernet Port'</p> <pre>configure troubleshoot &gt; logging settings &gt; dbg-rec- ip-trace-phy-port</pre> <p>[DebugRecordingIpTracePhysicalPort_ IpTracePhyPort]</p>	Filters IP traces by a specific Ethernet port.
<p>'VLAN ID'</p> <pre>configure troubleshoot &gt; logging settings &gt; dbg-rec- ip-trace-vlan-id</pre> <p>[DebugRecordingIpTraceVlanId_ IpTraceVlanId]</p>	Filters IP traces by a specific VLAN ID.
<b>PII Masking (GDPR)</b>	
<p>'Mask Digits'</p> <pre>configure voip &gt; sip- definition settings &gt; pii- mask-digits</pre> <p>[PIIMaskDigits]</p>	<p>Enables the masking of DTMF and other digits detected by the device in the generated syslog messages and debug recording.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>For more information, see <a href="#">Masking Digits in Syslog Messages</a> on page 208.</p>
<p>'Mask PII in CDRs'</p> <pre>configure voip &gt; sip- definition settings &gt; pii- mask-private-info-in-cdrs</pre> <p>[PIIMaskPrivateInfoInCDRs]</p>	<p>Enables the masking of personally identifiable information (PII) in CDRs generated by the device.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = No masking is done.</li> </ul>



Parameter	Description
	<ul style="list-style-type: none"> <li>■ [1] <b>Mark PII in Web or CLI</b> = The device masks (by a single asterisk * symbol) private information (caller and callee) in the Web interface's SBC CDR History table (see <a href="#">Viewing CDR History of SBC and Test Calls</a> on page 1363) and Gateway CDR History table (see <a href="#">Viewing Gateway CDR History</a> on page 1361), and CLI (e.g., <code>show voip calls</code>). For example, the device masks the URI "name@domain.com" as "*".</li> <li>■ [2] <b>Mask PII in Detailed Records</b> = The device masks (by multiple asterisks *) private information in CDRs and SDRs. This applies to all destinations to where the device sends these records (i.e., syslog, REST, Local Storage, and RADIUS), except ARM and OVOC. This option also affects PII in the Web interface's SBC CDR History table Gateway CDR History table, and CLI (e.g., <code>show voip calls</code>). For URIs, only the user part is masked.</li> </ul> <p>For more information, see <a href="#">Masking PII in CDRs</a> on page 206.</p>
<p>'Number of Unmasked Characters in PII'</p> <pre>configure voip &gt; sip- definition settings &gt; pii- number-of-unmasked-chars</pre> <p>[PIINumberOfUnmaskedChars]</p>	<p>Defines the number of characters in the PII element to show when the 'Mask PII in CDRs' parameter is configured to <b>Mask PII in Detailed Records</b>. The rest of the characters are masked (each by an asterisk sign).</p> <p>The valid value is 0 to 255. The default is 0 (masks all characters).</p> <p>For more information, see <a href="#">Masking PII in CDRs</a> on page 206.</p>
<p>'Location in PII of Unmasked Characters'</p> <pre>configure voip &gt; sip- definition settings &gt; pii- unmasked-chars-location</pre> <p>[PIIUnmaskedCharsLocation]</p>	<p>Defines from where in the PII element to show the number of characters specified by the 'Number of Unmasked Characters in PII' parameters, when the Mask Private Information in CDRs' parameter is</p>

Parameter	Description
	<p>configured to <b>Mask PII in Detailed Records</b>.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Last Characters</b> = (Default) The device shows the number of characters specified by the 'Number of Unmasked Characters in PII' parameter, starting from the end of the PII element.</li> <li>■ [1] <b>First Characters</b> = The device shows the number of characters specified by the 'Number of Unmasked Characters in PII' parameter, starting from the beginning of the PII element.</li> </ul> <p>For more information, see <a href="#">Masking PII in CDRs</a> on page 206.</p>
<p>'Mask PII in CDRs for OVOC'</p> <pre>configure voip &gt; sip- definition settings &gt; pii- mask-private-info-for-ovoc</pre> <p>[PIIMaskPrivateInfoForOVOC]</p>	<p>Enables the PII masking (with asterisks) of phone numbers, URI user parts, and display names in CDRs that the device sends to OVOC.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>For more information, see <a href="#">Masking PII in CDRs</a> on page 206.</p>
<p>'Mask URI Host Part in CDRs'</p> <pre>configure voip &gt; sip- definition settings &gt; pii- mask-host</pre> <p>[PIIMaskHost]</p>	<p>Enables the PII masking (with asterisks) of URI host parts (including IP addresses) in CDRs that the device sends to Web, CLI, syslog, REST, RADIUS, and Local Storage (depending on which targets are anonymized by the 'Mask PII in CDRs' parameter), or to OVOC if the 'Mask PII in CDRs for OVOC' parameter is enabled.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>For more information, see <a href="#">Masking PII in CDRs</a> on page 206.</p>

## Heartbeat Packet Parameters

The Heartbeat packet parameters are described in the table below. The device sends a heartbeat packet to ensure that the far-end is passing traffic.

**Table 69-21:Heartbeat Packet Parameters**

Parameter	Description
[HeartBeatIntervalmsec]	<p>Defines the delay (in msec) between consecutive heartbeat packets.</p> <p>The parameter is used when the device operates in High-Availability (HA) mode. The active and redundant devices send heartbeat (keep-alive) messages to one another to check reachability. They send the keep-alive messages "in bulks" (from multiple local ports) every 100 msec to create multiple flows in the network equipment (e.g., switches or SDN network). If there is no reply from the active device to the sent heartbeat packets within this timeout (HA timeout), the active device is considered unreachable, triggering an HA switchover to the redundant device.</p> <p>The parameter is measured in 10-msec units, meaning that whatever value you define for the parameter, the timeout is the value multiplied by 10. For example, if you configure the parameter to 100 (i.e., <math>100 \times 10 = 1,000</math> msec = 1 second), an HA switchover happens after a 1-second loss of keep-alive messages. You can increase it, for example, to 300 (i.e., <math>300 \times 10 = 3,000</math> msec = 3 seconds), which means that a switchover happens after a 3-second loss of keep-alive messages</p> <p>The valid value range is 100 to 6,000 (i.e., 1 minute). The default is 100.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>

## Resource Allocation Indication Parameters

The Resource Allocation Indication (RAI) parameters are described in the table below.

**Table 69-22:RAI Parameters**

Parameter	Description
[EnableRAI]	Enables Resource Available Indication (RAI) alarm generation if the device's busy endpoints exceed a user-defined threshold, configured by the RAIHighThreshold parameter. When enabled

Parameter	Description
	<p>and the threshold is crossed, the device sends the SNMP trap, <code>acBoardCallResourcesAlarm</code>.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable</li> <li>■ [1] = Enable</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ The parameter is applicable only to the Gateway application.</li> </ul>
[RAIHighThreshold]	<p>Defines the high threshold percentage of total calls that are active (busy endpoints). When the percentage of the device's busy endpoints exceeds this high threshold, the device sends the SNMP <code>acBoardCallResourcesAlarm</code> alarm trap with a 'major' alarm status.</p> <p>The range is 0 to 100. The default is 90.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The percentage of busy endpoints is calculated by dividing the number of busy endpoints by the total number of "enabled" endpoints (trunks are physically connected and synchronized without alarms and endpoints are defined in the Trunk Groups table).</li> <li>■ The parameter is applicable only to the Gateway application.</li> </ul>
[RAILowThreshold]	<p>Defines the low threshold percentage of total calls that are active (busy endpoints).</p> <p>When the percentage of the device's busy endpoints falls below this low threshold, the device sends an SNMP <code>acBoardCallResourcesAlarm</code> alarm trap with a 'cleared' alarm status.</p> <p>The range is 0 to 100%. The default is 90%.</p> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
[RAILoopTime]	<p>Defines the time interval (in seconds) that the device periodically checks call resource availability.</p> <p>The valid range is 1 to 200. The default is 10.</p> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>

## PacketSmart Parameters

The PacketSmart parameters are described in the table below. For more information on PacketSmart, see [Configuring PacketSmart Agent for Network Monitoring](#) on page 1352.

**Table 69-23:PacketSmart Parameters**

Parameter	Description
'PacketSmart Agent Mode' configure system > packetsmart enable [PacketSmartAgentMode]	Enables the embedded PacketSmart agent.  ■ [0] <b>Disable</b> (Default) ■ [1] <b>Enable</b>  <b>Note:</b> For the parameter to take effect, a device restart is required.
'PacketSmart Server IP Address' configure system > packetsmart server address [PacketSmartIpAddress]	Defines the IP address of the PacketSmart server with which the PacketSmart agent communicates. The default is 0.0.0.0.
'PacketSmart Server Port' configure system > packetsmart server port [PacketSmartIpAddressPort]	Defines the TCP port of the PacketSmart server to which the PacketSmart agent connects. The default is 80.
'Monitoring Interface' configure system > packetsmart monitor voip interface-if [PacketSmartMonitorInterface]	Assigns an IP network interface (configured in the IP Interfaces table) that handles the voice traffic.  <b>Note:</b> For the parameter to take effect, a device restart is required.
'Network Interface' configure system > packetsmart network voip interface-if [PacketSmartNetworkInterface ]	Assigns an IP network interface (configured in the IP Interfaces table) for communicating with the PacketSmart server. This is typically the OAMP interface.  <b>Note:</b> For the parameter to take effect, a device restart is required.

## HA Parameters

The High Availability (HA) parameters are described in the table below.



When configuration is applied to the device whose MAC is the value of the HARemoteMAC parameter, all HA configuration is swapped between local and remote parameters, including the IP address of the Maintenance interface, which is swapped with the address configured for the HARemoteAddress parameter. For more information, see [Quick-and-Easy Initial HA Configuration](#) on page 1187.

Table 69-24:HA Parameters

Parameter	Description
[HAMaintenanceIFDiffServValue]	<p>Defines the DiffServ value for HA Maintenance traffic flowing on the HA Maintenance interface. The valid value is 0 (lowest priority or best-effort service) to 63 (highest priority). The default is 46.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
<pre>configure network &gt; high-availability settings &gt; operational-state-delay</pre> [HAOperationalStateDelayInSec]	<p>Defines the duration (in seconds) to delay the transition from HA non-operational state, which occurs during HA synchronization between active and redundant devices, to HA operational state. This feature may be useful, for example, to delay HA switchover when using switches with spanning tree protocol (STP) that take a long time until their ports (to which the redundant device is connected) is ready. In such a scenario, if this feature were not enabled (i.e., 0), after synchronization there would be no connectivity between the redundant device's network interface and the switch.</p> <p>The valid value is 0 to 180. The default is 0.</p>
[HALocalMAC]	<p>Specifies the MAC address of one of the two devices in the HA system.</p> <p>For more information, see <a href="#">Quick-and-Easy Initial HA Configuration</a> on page 1187.</p> <p><b>Note:</b> When downloading an ini file from a device that is operating in HA mode, the parameter is the MAC address of the active device.</p>
[HARemoteMAC]	<p>Specifies the MAC address of one of the two devices in the HA system.</p> <p>For more information, see <a href="#">Quick-and-Easy Initial</a></p>

Parameter	Description
	<p><a href="#">HA Configuration</a> on page 1187.</p> <p><b>Note:</b> When downloading an ini file from a device that is operating in HA mode, the parameter is the MAC address of the redundant device.</p>
<p>'HA Device Name'</p> <pre>configure network &gt; high-availability settings &gt; unit-id-name</pre> <p>[HAGUnitIdName]</p>	<p>Defines a name for the active device, which is displayed on the Home page to indicate the active device.</p> <p>The valid value is a string of up to 128 characters. The default value is "Device 1".</p> <p><b>Note:</b> When the device sends alarms to OVOC, this name is displayed at the beginning of the alarm description in OVOC, for example, "(SBCSITE01): Proxy lost. looking for another proxy". However, the name is not displayed for the alarms retrieved (from the device's Active Alarms table) when OVOC <b>initially</b> connects to the device.</p>
<p>'HA Remote Device Name'</p> <pre>configure network &gt; high-availability settings &gt; redundant-unit-id-name</pre> <p>[HARemoteUnitIdName]</p>	<p>Defines a name for the redundant device, which is displayed on the Home page to indicate the redundant device.</p> <p>The valid value is a string of up to 128 characters. The default value is "Device 2".</p> <p><b>Note:</b> When the device sends alarms to OVOC, this name is displayed at the beginning of the alarm description in OVOC, for example, "(SBCSITE02): Proxy lost. looking for another proxy". However, the name is not displayed for the alarms retrieved (from the device's Active Alarms table) when OVOC <b>initially</b> connects to the device.</p>
<p>'HA Remote Address'</p> <pre>configure network &gt; high-availability settings &gt; remote-address</pre> <p>[HARemoteAddress]</p>	<p>Defines the Maintenance interface address of the redundant device in the HA system.</p> <p>By default, no value is defined.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
<p>'Preempt Mode'</p> <pre>configure network &gt; high-availability settings &gt;</pre>	<p>Enables HA switchover based on HA priority.</p> <p>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. A switchover over to the redundant device is</p>

Parameter	Description
<code>revertive-mode</code> <code>[HARevertiveEnabled]</code>	<p>done only if a failure occurs in the currently active device.</p> <ul style="list-style-type: none"> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled. A switchover over to the redundant device is done if a failure occurs in the currently active device. However, a switchover to the device with the highest priority (configured by the <code>HAPriority</code> parameter) occurs whenever the device recovers from a failure. Therefore, whenever possible, the highest priority device is the active one.</li> </ul> <p>For more information on the HA switchover mechanism, see <a href="#">Device Switchover upon Failure</a> on page 1177.</p>
<p>'Preempt Priority'</p> <code>configure network &gt; high-availability settings &gt; priority</code> <code>[HAPriority]</code>	<p>Defines the priority of the active device used in the HA Preempt mechanism.</p> <p>The valid value is 1 (lowest priority) to 10 (highest priority). The default is 5.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if you enable the 'Preempt Mode' parameter.</li> <li>■ You must configure each device in the HA system with different parameter values (priorities).</li> </ul>
<p>'HA Remote Preempt Priority'</p> <code>configure network &gt; high-availability &gt; redundant-priority</code> <code>[HARemotePriority]</code>	<p>Defines the priority of the redundant device used in the HA Preempt mechanism.</p> <p>The valid value is 1 (lowest priority) to 10 (highest priority). The default is 5.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if you enable the 'Preempt Mode' parameter.</li> <li>■ You must configure each device in the HA system with different parameter values (priorities).</li> </ul>
<p>'HA Secured Connectivity Mode'</p> <code>configure network &gt; high-availability</code>	<p>Enables secure (TLS) communication (HA Maintenance interface) between the active and redundant devices in the HA system.</p>



Parameter	Description
<pre>settings &gt; ha-secured- connectivity</pre> <p>[HASecuredConnectivityMode]</p>	<p>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</p> <p>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</p> <p>For more information, see <a href="#">Enabling Secured TLS Communication between Active and Redundant Devices</a> on page 1191.</p> <p><b>Note:</b>For the parameter to take effect, a device restart is required.</p>
<p>'HA File Transfer Port'</p> <pre>configure network &gt; high- availability settings &gt; ha-file-transfer-port</pre> <p>[HaFileTransferPort]</p>	<p>Defines the device's port for unsecured file transfer between active and redundant devices in HA mode.</p> <p>The default is 80.</p> <p>For more information, see <a href="#">Configuring Ports for File Transfer between Active and Redundant Devices</a> on page 1190.</p> <p><b>Note:</b>For the parameter to take effect, a device restart is required.</p>
<p>'HA Secured File Transfer Port'</p> <pre>configure network &gt; high- availability settings &gt; ha-secure-file-transfer- port</pre> <p>[HaSecureFileTransferPort]</p>	<p>Defines the device's port for secured (HTTPS) file transfer between active and redundant devices in HA mode.</p> <p>The default is 443.</p> <p>For more information, see <a href="#">Configuring Ports for File Transfer between Active and Redundant Devices</a> on page 1190.</p> <p><b>Note:</b>For the parameter to take effect, a device restart is required.</p>
<p>HA Network Monitor Parameters</p> <p>For more information, see <a href="#">Monitoring IP Entities and HA Switchover upon Ping Failure</a> on page 1191.</p>	
<p>'HA Network Monitor'</p> <pre>configure network &gt; high- availability settings &gt; network-monitor-enabled</pre> <p>[HAPingEnabled]</p>	<p>Enables the HA Network Monitor feature, which checks connectivity with network destinations, using pings. When a user-defined number of destinations fail the connectivity test (see 'Network Monitor Threshold' parameter), an HA switchover occurs.</p> <p>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</p> <p>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</p>

Parameter	Description
'Monitor Threshold' configure network > high-availability settings > network-monitor-threshold [HaNetworkMonitorThreshold]	Defines the minimum number of monitored rows (configured in the HA Network Monitor table) whose destinations are unreachable that are required to trigger an HA switchover.  The valid value is 1 to 10. The default is 1.

## Security Parameters

This subsection describes the device's security parameters.

### General Security Parameters

The general security parameters are described in the table below.

**Table 69-25:General Security Parameters**

Parameter	Description
<b>Media Latching</b>	
'Inbound Media Latch Mode' configure voip > media settings > inbound-media-latch-mode [InboundMediaLatchMode]	<p>Enables the Media Latching feature.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Strict</b> = The device is ready to receive (latch on to) media packets, but only if they are from a specific source IP address and UDP port, according to the remote IP address and UDP port in the negotiated SDP of the SIP message.</li> </ul> <p><b>Note:</b> If the SIP user agent is behind NAT and you have configured the [NATMode] parameter to [4] (<b>NAT By Signaling Restricted IP</b>), even if you have configured the 'Inbound Media Latch Mode' parameter to <b>Strict</b>, the device automatically changes it to <b>Dynamic</b>.</p> <ul style="list-style-type: none"> <li>■ [1] <b>Dynamic</b> = (Default) Device latches on to the first stream. If it receives at least a minimum number of consecutive packets (configured by New&lt;media type&gt;StreamPackets) from a different source(s) and the device has not received packets from the current stream for a user-defined period (TimeoutToRelatch&lt;media type&gt;Msec), it latches on to the next packet received from any other stream. If other packets of a different media type are received from the</li> </ul>

Parameter	Description
	<p>new stream, based on IP address and SSRC for RTCP/RTP and based on IP address only for T.38, the packet is accepted immediately.</p> <p><b>Note:</b> If a packet from the original (first latched onto) IP address:port is received at any time, the device latches on to this stream.</p> <p>■ [2] <b>Dynamic-Strict</b> = Device latches onto the first stream. If it receives at least a minimum number of consecutive packets (configured by New&lt;media type&gt;StreamPackets) all from the same source which is different to the first stream and the device has not received packets from the current stream for a user-defined period (TimeoutToRelatch&lt;media type&gt;Msec), it latches on to the next packet received from any other stream. If other packets of different media type are received from the new stream based on IP address and SSRC for RTCP and based on IP address only for T.38, the packet is accepted immediately.</p> <p><b>Note:</b> If a packet from the original (first latched onto) IP address:port is received at any time, the device latches on to this stream.</p> <p>■ [3] <b>Strict-On-First</b> = Typically used for NAT, where the correct IP address:port is initially unknown. The device latches on to the stream received in the first packet. The device doesn't change this stream unless a packet is later received from the original source.</p> <p><b>Note:</b> If you configure the parameter to <b>Strict</b>, the device can't perform NAT traversal. In this setup, configure the [NATMode] parameter to [1].</p>
'New RTP Stream Packets' [NewRtpStreamPackets]	<p>Defines the minimum number of continuous RTP packets received by the device's channel to allow latching onto the new incoming stream.</p> <p>The valid range is 0 to 20. The default is 3. If set to 0, the device is left exposed to attacks against multiple packet streams.</p>
'New RTCP Stream Packets'	<p>Defines the minimum number of continuous RTCP</p>

Parameter	Description
[NewRtcpStreamPackets]	<p>packets received by the device's channel to allow latching onto the new incoming stream.</p> <p>The valid range is 0 to 20. The default is 3. If set to 0, the device is left exposed to attacks against multiple packet streams.</p>
'New SRTP Stream Packets' [NewSRTPStreamPackets]	<p>Defines the minimum number of continuous SRTP packets received by the device's channel to allow latching onto the new incoming stream.</p> <p>The valid range is 0 to 20. The default is 3. If set to 0, the device is left exposed to attacks against multiple packet streams.</p>
'New SRTCP Stream Packets' [NewSRTCPStreamPackets]	<p>Defines the minimum number of continuous SRTCP packets received by the device's channel to allow latching onto the new incoming stream.</p> <p>The valid range is 0 to 20. The default is 3. If set to 0, the device is left exposed to attacks against multiple packet streams.</p>
'Timeout To Relatch RTP' [TimeoutToRelatchRTPMsec]	<p>Defines a period (msec) during which if no packets are received from the current RTP session, the channel can re-latch onto another stream.</p> <p>The valid range is any value from 0. The default is 200.</p>
'Timeout To Relatch SRTP' [TimeoutToRelatchSRTPMsec]	<p>Defines a period (msec) during which if no packets are received from the current SRTP session, the channel can re-latch onto another stream.</p> <p>The valid range is any value from 0. The default is 200.</p>
'Timeout To Relatch Silence' [TimeoutToRelatchSilenceMsec]	<p>Defines a period (msec) during which if no packets are received from the current RTP/SRTP session and the channel is in silence mode, the channel can re-latch onto another stream.</p> <p>The valid range is any value from 0. The default is 200.</p>
'Timeout To Relatch RTCP' [TimeoutToRelatchRTCPMsec]	<p>Defines a period (msec) during which if no packets are received from the current RTCP session, the channel can re-latch onto another RTCP stream.</p> <p>The valid range is any value from 0. The default is</p>

Parameter	Description
	10,000.
'Fax Relay Rx/Tx Timeout' [FaxRelayTimeoutSec]	<p>Defines a period (sec) during which if no T.38 packets are received or sent from the current T.38 fax relay session, the channel can re-latch onto another stream.</p> <p>The valid range is 0 to 255. The default is 10.</p>

## HTTPS Parameters

The Secure Hypertext Transport Protocol (HTTPS) parameters are described in the table below.

**Table 69-26:HTTPS Parameters**

Parameter	Description
<p>'Secured Web Connection (HTTPS)'</p> <pre>configure system &gt; web &gt; secured-connection</pre> <p>[HTTPSOnly]</p>	<p>Defines the HTTP/S application protocol for accessing the device's management interface (Web interface or REST API).</p> <ul style="list-style-type: none"> <li>■ [0] <b>HTTP and HTTPS</b> = (Default) Access to the management interface is allowed from HTTP and HTTPS (secured) requests.</li> <li>■ [1] <b>HTTPS Only</b> = Access to the management interface is allowed only from HTTPS requests (and unencrypted HTTP packets are blocked).</li> <li>■ [2] <b>HTTPS Redirect</b> = Access to the management interface is allowed only from HTTPS redirect URLs. This is required when using OAuth login authentication with Azure AD, which redirects the user to a URI (device's address) upon successful authentication and authorization.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ If you configure the parameter to <b>HTTPS Redirect</b> and you're using Single-Sign On (SSO) to the device from OVOC, you must configure OVOC to connect to the device using HTTPS ('Communication Protocol' field set to <b>HTTPS</b>).</li> </ul>
<pre>configure system &gt; web</pre>	<p>Defines the local Secured HTTPS port of the device.</p>

Parameter	Description
<pre>&gt; https-port</pre> <p>[HTTPSPort]</p>	<p>The parameter allows secure remote device Web- or REST-based management from the LAN. To enable secure Web management from the LAN, configure the desired port.</p> <p>The valid range is 1 to 65535 (other restrictions may apply within this range). The default port is 443.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
<p>'Require Client Certificates for HTTPS connection'</p> <pre>configure system &gt; web</pre> <pre>&gt; req-client-cert</pre> <p>[HTTPSRequireClientCertificate]</p>	<p>Enables the requirement of client certificates for HTTPS connection.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) Client certificates are not required.</li> <li>■ [1] <b>Enable</b> = Client certificates are required. The client certificate must be preloaded to the device and its matching private key must be installed on the managing PC. Time and date must be correctly set on the device for the client certificate to be verified.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ For a description on implementing client certificates, see <a href="#">TLS for Remote Device Management</a> on page 248.</li> </ul>

## SRTP Parameters

The Secure Real-Time Transport Protocol (SRTP) parameters are described in the table below.

**Table 69-27:SRTP Parameters**

Parameter	Description
<p>'Media Security'</p> <pre>configure voip &gt; media security &gt;</pre> <pre>media-security-enable</pre> <p>[EnableMediaSecurity]</p>	<p>Enables Secure Real-Time Transport Protocol (SRTP).</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul>

Parameter	Description
	<b>Note:</b>
<p>'Media Security Behavior'</p> <pre>configure voip &gt; media security &gt; media-sec-bhviior</pre> <p>[MediaSecurityBehaviour]</p>	<p>Global parameter that defines the handling of SRTP, when the [EnableMediaSecurity] parameter is configured to 1. You can also configure this feature per specific calls, using IP Profiles ('Gateway Media Security Mode' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</li> <li>■ The parameter is applicable only to the Gateway application.</li> </ul>
<p>'Master Key Identifier (MKI) Size'</p> <pre>configure voip &gt; media security &gt; srtp-tx-packet-mki-size</pre> <p>[SRTPTxPacketMKISize]</p>	<p>Global parameter that defines the size (in bytes) of the Master Key Identifier (MKI) in SRTP Tx packets. You can also configure this feature per specific calls, using IP Profiles ('MKI Size' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b> If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</p>
<p>'Symmetric MKI Negotiation'</p> <pre>configure voip &gt; media security &gt; symmetric-mki</pre> <p>[EnableSymmetricMKI]</p>	<p>Global parameter that enables symmetric MKI negotiation. You can also configure this feature per specific calls, using IP Profiles ('Symmetric MKI' parameter). For a</p>

Parameter	Description
	<p>detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b> If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</p>
<p>'Offered SRTP Cipher Suites'</p> <pre>configure voip &gt; media security &gt; offer-srtp-cipher</pre> <p>[SRTPofferedSuites]</p>	<p>Defines the offered crypto suites (cipher encryption algorithms) for SRTP.</p> <ul style="list-style-type: none"> <li>■ [0] <b>All</b> = (Default) All available crypto suites.</li> <li>■ [1] <b>AES-CM-128-HMAC-SHA1-80</b> = device uses AES-CM encryption with a 128-bit key and HMAC-SHA1 message authentication with a 80-bit tag.</li> <li>■ [2] <b>AES-CM-128-HMAC-SHA1-32</b> = device uses AES-CM encryption with a 128-bit key and HMAC-SHA1 message authentication with a 32-bit tag.</li> <li>■ [4] <b>ARIA-CM-128-HMAC-SHA1-80</b> = device uses ARIA encryption algorithm with a 128-bit key and HMAC-SHA1 message authentication with a 32-bit tag.</li> <li>■ [8] <b>ARIA-CM-192-HMAC-SHA1-80</b> = device uses ARIA encryption algorithm with a 192-bit key and HMAC-SHA1 message authentication with a 32-bit tag.</li> <li>■ [16] <b>AES-256-CM-HMAC-SHA1-32</b> = AES-CM encryption with a 256-bit key and HMAC-SHA1 message authentication with a 32-bit tag.</li> <li>■ [32] <b>AES-256-CM-HMAC-SHA1-80</b> = AES-CM encryption with a 256-</li> </ul>



Parameter	Description
	<p>bit key and HMAC-SHA1 message authentication with an 80-bit tag.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For enabling ARIA encryption, use the [AriaProtocolSupport] parameter.</li> <li>■ For the Gateway application, if you configure the parameter to <b>All</b>, the device sends only four crypto lines ('a=crypto') in the SDP Offer, which excludes the AES 256 crypto suites. Therefore, if you want to offer an AES 256 crypto suite, you need to configure the parameter to <b>AES-256-CM-HMAC-SHA1-32</b> or <b>AES-256-CM-HMAC-SHA1-80</b>.</li> <li>■ The parameter also affects the selection of the crypto in the device's answer. For example, if the device receives an offer with two crypto lines ('a=crypto:') containing HMAC_SHA1_80 and HMAC_SHA_32, it uses the HMAC_SHA_32 key in its SIP 200 OK response if the parameter is configured to <b>AES-CM-128-HMAC-SHA1-32</b>.</li> </ul>
<p>'ARIA Protocol Support'</p> <pre>configure voip &gt; media security &gt; ARIA-protocol-support</pre> <p>[AriaProtocolSupport]</p>	<p>Enables ARIA algorithm cipher encryption for SRTP. This is an alternative option to the existing support for the AES algorithm. ARIA is a symmetric key block cipher algorithm standard developed by the Korean National Security Research Institute.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> =</li> </ul>

Parameter	Description
	<p>Enabled.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ To configure the ARIA bit-key encryption size (128 or 192 bit) with HMAC SHA-1 cryptographic hash function, use the <code>SRTPOfferedSuites</code> parameter.</li> <li>■ The ARIA feature is available only if the device is installed with a License Key that includes this feature. For installing a License Key, see <a href="#">License Key</a> on page 1233.</li> </ul>
<p>'Authentication on Transmitted RTP Packets'</p> <pre>configure voip &gt; media security &gt; RTP-authentication-disable-tx [RTPAuthenticationDisableTx]</pre>	<p>Enables authentication on transmitted RTP packets in a secured RTP session.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Enable</b> (default)</li> <li>■ [1] <b>Disable</b></li> </ul>
<p>'Encryption on Transmitted RTP Packets'</p> <pre>configure voip &gt; media security &gt; RTP-encryption-disable-tx [RTPEncryptionDisableTx]</pre>	<p>Enables encryption on transmitted RTP packets in a secured RTP session.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Enable</b> (default)</li> <li>■ [1] <b>Disable</b></li> </ul>
<p>'Encryption on Transmitted RTCP Packets'</p> <pre>configure voip &gt; media security &gt; RTCP-encryption-disable-tx [RTCPEncryptionDisableTx]</pre>	<p>Enables encryption on transmitted RTCP packets (outgoing leg) in a secured RTP session (i.e., SRTP). The device generates the cryptos.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Enable</b> (default)</li> <li>■ [1] <b>Disable</b></li> </ul> <p><b>Note:</b> The parameter is applicable only if the IP Profile parameter 'Encryption on RTCP Packets' is configured to <b>As Is</b> for the outgoing leg.</p>
<p>'SRTP Tunneling Authentication for RTP'</p> <pre>configure voip &gt; media security &gt;</pre>	<p>Enables validation of SRTP tunneling authentication for RTP.</p>

Parameter	Description
<code>srtplib-vld-rtplib-auth</code> [SRTPTunnelingValidateRTPRxAuthentication]	<ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. The device doesn't perform any validation and forwards the packets as is.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled. The device validates the packets (e.g., sequence number) and if successful, forwards the packets. If validation fails, it drops the packets.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to SRTP-to-SRTP calls and when both endpoints use the same authentication keys.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
'SRTP Tunneling Authentication for RTCP' <code>configure voip &gt; media security &gt; srtplib-vld-rtcp-auth</code> [SRTPTunnelingValidateRTCPRxAuthentication]	<p>Enables validation of RTP tunneling authentication for RTCP.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. The device doesn't perform any validation and forwards the packets as is.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled. The device validates the packets (e.g., sequence number) and if successful, forwards the packets. If validation fails, it drops the packets.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to SRTP-to-SRTP calls and when both endpoints use the same authentication keys.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
<code>configure voip &gt; sip-definition</code>	Global parameter that enables

Parameter	Description
<pre>settings &gt; reset-srtp-upon-re-key</pre> <p>[ResetSRTPStateUponRekey]</p>	<p>synchronization of the SRTP state between the device and a server when a new SRTP key is generated upon a SIP session expire. You can also configure this feature per specific calls, using IP Profiles ('Reset SRTP Upon Re-key' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</li> <li>■ This parameter resets the SRTP stream on both legs. If you want the device to reset only the SRTP stream with the leg (call party) that changed the crypto key, enable this parameter and the [SrtpResetTxRxSeparately] parameter (below).</li> </ul>
<pre>configure voip &gt; media security &gt; srtp-reset-tx-rx-separately</pre> <p>[SrtpResetTxRxSeparately]</p>	<p>Enables the device to reset only the SRTP stream (roll-over counter / ROC index and other SRTP fields) with the call party that changed the SRTP key ('a=crypto' line in SDP body) during a call. It doesn't reset the SRTP stream with the other call party. The SRTP key is sometimes updated by the call party, using a SIP re-INVITE message (for example, due to a session refresh).</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disabled</li> <li>■ [1] = Enabled</li> </ul> <p><b>Note:</b></p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ For this functionality, you also need to enable the 'Reset SRTP Upon Re-key' (ResetSRTPStateUponRekey) parameter.</li> <li>■ If the [SrtpResetTxRxSeparately] parameter is disabled and the 'Reset SRTP Upon Re-key' parameter is enabled, the device resets the SRTP stream of both call parties if the key is changed.</li> </ul>

## TLS Parameters

The Transport Layer Security (TLS) parameters are described in the table below.

**Table 69-28:TLS Parameters**

Parameter	Description
'TLS Client Re-Handshake Interval' <code>configure network &gt;</code> <code>security-settings &gt; tls-</code> <code>re-hndshk-int</code> [TLSReHandshakeInterval]	Defines the time interval (in minutes) between TLS Re-Handshakes initiated by the device.  The interval range is 0 to 1,500 minutes. The default is 0 (i.e., no TLS Re-Handshake).
'TLS Mutual Authentication' <code>configure network &gt;</code> <code>security-settings &gt; sips-</code> <code>require-client-</code> <code>certificate</code> [SIPSRequireClientCertificate]	Defines the device's mode of operation regarding mutual authentication and certificate verification for TLS connections for SIP. <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled:               <ul style="list-style-type: none"> <li>✓ Device acts as a client: Verification of the server's certificate depends on the [VerifyServerCertificate] parameter.</li> <li>✓ Device acts as a server: The device doesn't request the client certificate.</li> </ul> </li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled:               <ul style="list-style-type: none"> <li>✓ Device acts as a client: Verification of the server certificate is required to establish the TLS connection.</li> <li>✓ Device acts as a server: The device requires</li> </ul> </li> </ul>

Parameter	Description
	<p>the receipt and verification of the client certificate to establish the TLS connection.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>You can configure this feature per SIP Interface (see <a href="#">Configuring SIP Interfaces</a> on page 561).</li> <li>You can change the SIPS certificate files using the [HTTPSCertFileName] and [HTTPSRootFileName] parameters.</li> </ul>
<p>'Peer Host Name Verification Mode'</p> <pre>configure network &gt; security-settings &gt; peer- hostname-verification- mode</pre> <p>[PeerHostNameVerificationMode]</p>	<p>Enables the device to verify the Subject Name of a TLS certificate received from SIP entities for authentication and establishing TLS connections.</p> <ul style="list-style-type: none"> <li>[0] <b>Disable</b> = (Default) No certificate verification is done.</li> <li>[1] <b>Server Only</b> = The device verifies the certificate's Subject Name only when it acts as a client for the TLS connection.</li> <li>[2] <b>Server &amp; Client</b> = The device verifies the certificate's Subject Name when it acts as a server or client for the TLS connection.</li> </ul> <p>If the device receives a certificate from a SIP entity (IP Group) and the parameter is configured to <b>Server Only</b> or <b>Server &amp; Client</b>, it attempts to authenticate the certificate based on the certificate's address:</p> <ol style="list-style-type: none"> <li>If the connection was classified to a Proxy Set, the device compares the certificate's Subject Alternative Names (SANs) with the Proxy Set's addresses (IP address or FQDN). The device checks the FQDN itself and not the DNS-resolved IP addresses.</li> <li>If a SAN matches an address, the device considers the certificate as valid and establishes the TLS connection and allows the call.</li> <li>If there is no match and the SAN is marked as "critical", the device rejects the call. If there is no match and the SAN isn't marked as "critical", the device compares the Proxy Set's 'TLS</li> </ol>

Parameter	Description
	<p>Remote Subject Name' parameter value (or global [TLSRemoteSubjectName] parameter) with the certificate's Common Name (CN). If they match, the device establishes the TLS connection and allows the call; otherwise, the device rejects the call.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ You can configure this functionality per Proxy Set (see <a href="#">Configuring Proxy Sets</a> on page 622). If configured for a Proxy Set, the Proxy Set's settings override this global parameter's settings.</li> <li>■ If you configure the parameter to <b>Server &amp; Client</b>, enable the global 'TLS Mutual Authentication' parameter [SIPSRequireClientCertificate].</li> <li>■ For FQDN, the certificate may use wildcards (*) to replace parts of the domain name.</li> </ul>
<p>'TLS Remote Subject Name'</p> <pre>configure network &gt; security-settings &gt; tls- rmt-subs-name</pre> <p>[TLSRemoteSubjectName]</p>	<p>Defines the Subject Name of the TLS certificate received from the remote side when establishing TLS connections.</p> <p>When the device receives the certificate from the remote side, it validates the certificate by comparing the certificate's Subject Alternative Names (SANs) with the Proxy Set's addresses (IP address and FQDN). If a SAN matches an address, the device considers the certificate as valid and establishes the TLS connection.</p> <p>If there is no match and the SAN is marked as "critical", the device doesn't establish a TLS connection and rejects the call. If there is no match and the SAN isn't marked as "critical", the device compares the parameter's value with the certificate's Common Name (CN). If they match, the device establishes a TLS connection; otherwise, the device doesn't establish a TLS connection and rejects the call.</p> <p>The valid range is a string of up to 49 characters.</p> <p><b>Note:</b></p>

Parameter	Description
	<ul style="list-style-type: none"> <li>You can configure this functionality per Proxy Set (see <a href="#">Configuring Proxy Sets</a> on page 622). If configured for a Proxy Set, the Proxy Set's settings override this global parameter's settings.</li> <li>If the CN uses a domain name, the certificate can also use wildcards ("*") to replace parts of the domain name.</li> <li>The parameter is applicable only if you configure the global parameter [PeerHostNameVerificationMode] or Proxy Set parameter 'Peer Host Name Verification Mode' to <b>Server Only</b> or <b>Server &amp; Client</b>.</li> </ul>
'TLS Client Verify Server Certificate' configure network > security-settings > tls- vrfy-srvr-cert [VerifyServerCertificate]	Enables the device, when acting as a client for TLS connections, to verify the Server certificate. The certificate is verified with the Root CA information. <ul style="list-style-type: none"> <li>[0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>[1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <b>Note:</b> If Subject Name verification is needed, configure the [PeerHostNameVerificationMode] parameter as well.
'TLS Expiry Check Start' configure network > security-settings > tls- expiry-check-start [TLSExpiryCheckStart]	Defines when the device sends an SNMP alarm (acCertificateExpiryAlarm) to notify that the installed TLS server certificate (of TLS Contexts) is about to expire. This is defined by the number of days before the certificate's expiration date. For example, if configured to 5, the alarm is sent 5 days before the expiration date. For more information on the alarm, refer to the <a href="#">SBC-Gateway Series SNMP Alarm Reference Guide</a> . The valid value is 0 to 3650. The default is 60.
'TLS Expiry Check Period' configure network > security-settings > tls- expiry-check-period [TLSExpiryCheckPeriod]	Defines the periodical interval (in days) for checking the TLS server certificate expiry date (of TLS Contexts). The valid value is 1 to 3650. The default is 7.



## SSH Parameters

Secure Shell (SSH) parameters are described in the table below.

**Table 69-29:SSH Parameters**

Parameter	Description
'Enable SSH Server' <pre>configure system &gt; cli-settings &gt; ssh</pre> [SSHServerEnable]	Enables the device's embedded SSH server. <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = (Default) Enabled.</li> </ul>
'Redundant Device Server Port' <pre>configure system &gt; cli-settings &gt; ssh- red-device-port</pre> [SSHRedundantProxyPort]	Defines the proxy SSH port number on the active device for accessing the redundant device's embedded SSH server from the active device for downloading files from the redundant device.  The valid value is any valid port number. The default port is 0 (i.e., disabled).  <b>Note:</b> <ul style="list-style-type: none"> <li>■ The parameter is applicable only when the device is in HA mode.</li> <li>■ The port number must be different to the regular SSH port number, which is configured by the [SSHServerPort] parameter.</li> </ul>
'Public Key' <pre>configure system &gt; cli-settings &gt; ssh- require-public-key</pre> [SSHRequirePublicKey]	Enables RSA or ECDSA public keys for SSH. <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. RSA or ECDSA public keys are optional if a public key is configured.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled. RSA or ECDSA public keys are mandatory.</li> </ul> <b>Note:</b> <ul style="list-style-type: none"> <li>■ Public keys are configured per management user in the Local Users table (see <a href="#">Configuring Local Management User Accounts</a> on page 54).</li> <li>■ To define the key size, use the [TLSPkeySize] parameter.</li> </ul>
'Max Payload Size' <pre>ssh-max-payload-size</pre> [SSHMaxPayloadSize]	Defines the maximum uncompressed payload size (in bytes) for SSH packets.  The valid value is 550 to 32768. The default is 32768.

Parameter	Description
<p>'Max Binary Packet Size'</p> <pre>configure system &gt; cli-settings &gt; ssh- max-binary-packet-size</pre> <p>[SSHMaxBinaryPacketSize]</p>	<p>Defines the maximum packet size (in bytes) for SSH packets.</p> <p>The valid value is 582 to 35000. The default is 35000.</p>
<p>'Maximum SSH Sessions'</p> <pre>configure system &gt; cli-settings &gt; ssh- max-sessions</pre> <p>[SSHMaxSessions]</p>	<p>Defines the maximum number of simultaneous SSH sessions.</p> <p>The valid range is 1 to 5. The default 5.</p>
<p>'Enable Last Login Message'</p> <pre>configure system &gt; cli-settings &gt; ssh- last-login-message</pre> <p>[SSHEnableLastLoginMessage]</p>	<p>Enables message display in SSH sessions of the time and date of the last SSH login. The message displays the number of unsuccessful login attempts since the last successful login.</p> <p>■ [0] Check box cleared <input type="checkbox"/> = Disabled.</p> <p>■ [1] Check box selected <input checked="" type="checkbox"/> = (Default) Enabled.</p> <p><b>Note:</b> The last SSH login information is cleared when the device restarts.</p>
<p>'Max Login Attempts'</p> <pre>configure system &gt; cli-settings &gt; ssh- max-login-attempts</pre> <p>[SSHMaxLoginAttempts]</p>	<p>Defines the maximum SSH login attempts allowed for entering an incorrect password by an administrator before the SSH session is rejected.</p> <p>The valid range is 1 to 5. The default is 3.</p> <p><b>Note:</b> The new setting takes effect only for new subsequent SSH connections.</p>
<p>'Kex Algorithms String'</p> <pre>configure system &gt; cli-settings &gt; ssh- kex-algorithms-string</pre> <p>[SSHKexAlgorithmsString]</p>	<p>Defines the SSH Key Exchange Algorithms.</p> <p>The valid values include:</p> <ul style="list-style-type: none"> <li>■ diffie-hellman-group-exchange-sha256</li> <li>■ diffie-hellman-group14-sha1</li> <li>■ diffie-hellman-group1-sha1</li> <li>■ diffie-hellman-group14-sha256</li> <li>■ diffie-hellman-group16-sha512</li> <li>■ ecdh-sha2-nistp256</li> <li>■ ecdh-sha2-nistp384</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ ecdh-sha2-nistp521</li> <li>■ curve25519-sha256</li> </ul> <p>You can configure the parameter with multiple values, using the colon (:) as a separator. For example, diffie-hellman-group1-sha1:diffie-hellman-group-exchange-sha256.</p> <p>The default is curve25519-sha256:ecdh-sha2-nistp256:ecdh-sha2-nistp384:ecdh-sha2-nistp521:diffie-hellman-group-exchange-sha256:diffie-hellman-group16-sha512:diffie-hellman-group14-sha256:diffie-hellman-group14-sha1.</p>
<b>'Ciphers String'</b> <code>configure system &gt;</code> <code>cli-settings &gt; ssh-</code> <code>ciphers-string</code> <b>[SSHCiphersString]</b>	<p>Defines the SSH cipher string.</p> <p>The valid values include:</p> <ul style="list-style-type: none"> <li>■ aes128-ctr</li> <li>■ aes128-cbc</li> <li>■ aes256-ctr</li> <li>■ aes256-cbc</li> </ul> <p>You can configure the parameter with multiple values, using the colon (:) as a separator. For example, aes128-ctr:aes128-cbc.</p> <p>The default is aes128-ctr:aes128-cbc.</p>
<b>'MACs String'</b> <code>configure system &gt;</code> <code>cli-settings &gt; ssh-</code> <code>macs-string</code> <b>[SSHMACsString]</b>	<p>Defines the SSH MAC algorithms.</p> <p>The valid values include:</p> <ul style="list-style-type: none"> <li>■ hmac-sha1</li> <li>■ hmac-sha2-256</li> </ul> <p>You can configure the parameter with both values using the colon (:) as a separator, for example, hmac-sha1:hmac-sha2-256.</p> <p>The default is hmac-sha1:hmac-sha2-256.</p>

## IDS Parameters

The Intrusion Detection System (IDS) parameters are described in the table below.

Table 69-30:IDS Parameters

Parameter	Description
'Intrusion Detection System (IDS)' <code>configure voip &gt; ids</code> <code>global-parameters &gt;</code> <code>enable-ids</code> [EnableIDS]	Enables the IDS feature. <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul>
'Alarm Clear Period' <code>configure voip &gt; ids</code> <code>global-parameters &gt;</code> <code>alarm-clear-period</code> [IDSAlarmClearPeriod]	Defines the interval (in seconds) after which an IDS alarm is cleared from the Active Alarms table if no thresholds are crossed during this time. However, this "quiet" period must be at least twice the Threshold Window value. For example, if IDSAlarmClearPeriod is set to 20 sec and the Threshold Window is set to 15 sec, the IDSAlarmClearPeriod parameter is ignored and the alarm is cleared only after 30 seconds (2 x 15 sec). The valid value is 0 to 86400. The default is 300.
'Excluded Response Codes' <code>configure voip &gt; ids</code> <code>global-parameters &gt;</code> <code>excluded-responses</code> [IDSExcludedResponseCodes]	Defines the SIP response codes that are excluded from the IDS count for SIP dialog establishment failures. The valid value is 400 through to 699. The maximum length is 100 characters. You can configure the parameter with multiple codes, where each code is separated by a comma (without spaces). The default is 408,422,423,480,481,486,487,500,501,502,503,504,505,600. For more information, see <a href="#">Configuring SIP Response Codes to Exclude from IDS</a> on page 270. <b>Note:</b> <ul style="list-style-type: none"> <li>■ The parameter applies only to rejected responses received from the remote network; not rejected responses generated by the device (except for 404).</li> <li>■ The response codes 401 and 407 are considered authentication failures and therefore, are not applicable to this parameter.</li> </ul>

## OCSP Parameters

The Online Certificate Status Protocol (OCSP) parameters are described in the table below.

**Table 69-31:OCSP Parameters**

Parameter	Description
'Enable OCSP Server' configure network > ocsp > enable [OCSPEnable]	Enables or disables certificate checking using OCSP.  ■ [0] <b>Disable</b> (default)  ■ [1] <b>Enable</b>  For a description of OCSP, see Configuring Certificate Revocation Checking (OCSP).
'Primary Server IP' configure network > ocsp > server-ip [OCSPServerIP]	Defines the IP address of the OCSP server.  The default IP address is 0.0.0.0.
'Secondary Server IP' configure network > ocsp > secondary-server-ip [OCSPSecondaryServerIP]	Defines the IP address (in dotted-decimal notation) of the secondary OCSP server (optional).  The default IP address is 0.0.0.0.
'Server Port' configure network > ocsp > server-port [OCSPServerPort]	Defines the OCSP server's TCP port number.  The default port number is 2560.
'Default Response When Server Unreachable' configure network > ocsp > default-response [OCSPDefaultResponse]	Determines whether the device allows or rejects peer certificates when the OCSP server cannot be contacted.  ■ [0] <b>Reject</b> (default)  ■ [1] <b>Allow</b>

## Proxy, Registration and Authentication Parameters

The proxy server, registration and authentication SIP parameters are described in the table below.

**Table 69-32:Proxy, Registration and Authentication SIP Parameters**

Parameter	Description
'Use Default Proxy'	Enables the use of Proxy Set ID 0 (for backward

Parameter	Description
<pre>configure voip &gt; sip- definition proxy-and- registration &gt; enable- proxy</pre> <p>[IsProxyUsed]</p>	<p>compatibility).</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) Proxy Set 0 is not used.</li> <li>■ [1] <b>Yes</b> = Proxy Set ID 0 is used.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter must be used only for backward compatibility. If not required for backward compatibility, make sure that the parameter is disabled and use the Proxy Sets table for configuring all your Proxy Sets (except for Proxy Set #0).</li> <li>■ If you are not using a proxy server, you must configure routing rules to route the call.</li> <li>■ The parameter is applicable only to the Gateway application.</li> </ul>
<p>'Proxy Name'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; proxy-name</pre> <p>[ProxyName]</p>	<p>Defines the Home Proxy domain name. If specified, this name is used as the Request-URI in REGISTER, INVITE and other SIP messages, and as the host part of the To header in INVITE messages. If not specified, the Proxy IP address is used instead. The valid value is a string of up to 49 characters.</p> <p><b>Note:</b> The parameter functions together with the [UseProxyIPasHost] parameter.</p>
<p>'Use Proxy IP as Host'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; use-proxy- ip-as-host</pre> <p>[UseProxyIPasHost]</p>	<p>Enables the use of the proxy server's IP address (in dotted-decimal notation) as the host name in SIP From and To headers in REGISTER requests.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>If the parameter is disabled and the device registers to an IP Group (i.e., proxy server), it uses the string configured by the ProxyName parameter as the host name in the REGISTER's Request-URI and uses the string configured by the IP Groups table parameter, SIPGroupName as the host name in the To and From headers. If the IP Group is configured with a Proxy Set that has multiple IP addresses, all the REGISTER messages sent to these proxies are sent with the same host name.</p>

Parameter	Description
	<p><b>Note:</b> If the parameter is disabled and the [ProxyName] parameter is not configured, the proxy's IP address is used as the host name in the REGISTER Request-URI.</p>
<pre>configure voip &gt; sip- definition proxy-and- registration &gt; use-rand- user</pre> <p>[UseRandomUser]</p>	<p>Enables the device to assign a random string value for the user part of the SIP Contact header in the REGISTER message (generated by the device) for new user Account registrations with the device. The string includes letters and may include numbers, but it always begins with a letter. The string is unique to each Account. An example of a randomly assigned user part is shown (in bold) below:</p> <p>Contact:</p> <pre>&lt;sip:<b>HRaNEmZnfX6xZ14</b> @pc33.atlanta.com&gt;</pre> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable.</li> <li>■ [1] = Enable. The device generates <b>one</b> unique string for the user part per Account. Each Account registers with its unique user part string. All INVITE messages for this new Account are sent with this unique user part. This same unique user part string is also used for registration refreshes and for un-registering the Account.</li> <li>■ [2] = Enable per registration. The device generates a new string for the user part for <b>each</b> REGISTER message sent for the Account, including initial registration as well as registration refreshes.</li> </ul> <p>The device stops using the random user part in the following scenarios:</p> <ul style="list-style-type: none"> <li>■ The user sends an unregister request.</li> <li>■ The device sends a REGISTER request for the user, but doesn't receive a SIP 200 OK in response.</li> <li>■ The parameter is disabled. When enabled again, new random user parts are assigned to the Accounts.</li> </ul>

Parameter	Description
	To configure Accounts, see <a href="#">Configuring Registration Accounts</a> on page 750.
<p>'Redundancy Mode'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; redundancy-mode</pre> <p>[ProxyRedundancyMode]</p>	<p>Determines whether the device switches back to the primary Proxy after using a redundant Proxy.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Parking</b> = (Default) The device continues working with a redundant (now active) Proxy until the next failure, after which it works with the next redundant Proxy.</li> <li>■ [1] <b>Homing</b> = The device always tries to work with the primary Proxy server (i.e., switches back to the primary Proxy whenever it's available).</li> </ul> <p><b>Note:</b> To use this Proxy Redundancy mechanism, you need to enable the keep-alive with Proxy option, by setting the parameter EnableProxyKeepAlive to 1 or 2.</p>
<p>'Proxy IP List Refresh Time'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; proxy-ip- lst-rfrsh-time</pre> <p>[ProxyIPListRefreshTime]</p>	<p>Defines the interval (in seconds) at which the device performs DNS resolution for Proxy Sets that are configured with an FQDN (host name) to translate (resolve) it into IP addresses. The device maintains a cache of DNS resolutions, and will use cached responses as long as the TTL has not expired. If the TTL is expired, a new DNS request is sent to the DNS server.</p> <p>For example, if configured to 60, the device queries the DNS server every 60 seconds. If successful, the device refreshes the Proxy Set's list of DNS-resolved IP addresses.</p> <p>The valid value is 0, or 5 to 2,000,000. The default is 60. The value 0 disables periodic DNS queries and DNS resolution is done only once - upon device restart, device power up, or new and modified configuration.</p> <p>The device caches the DNS-resolved IP addresses of the last successful DNS query of a Proxy Set, which is used if the DNS server goes offline. This functionality occurs regardless of the setting of the [DNSCache] parameter.</p>



Parameter	Description
<pre>configure network &gt; network-settings &gt; dns- cache</pre> <p>[DNSCache]</p>	<p>Enables the device to cache (store) DNS-resolved IP addresses of the last successful DNS query of entities (e.g., for Remote Web Services, Access List, and LDAP servers) that are configured with an FQDN. The device clears every entry in the cache 30 minutes after their DNS time-to-live (TTL) value expires.</p> <p>When enabled and the DNS server doesn't respond (for whatever reason) to the device's DNS query request, instead of taking the entity offline, the device reuses the cached DNS-resolved addresses, thereby maintaining call service. In such a scenario, the device continues to query the DNS server every 10 seconds. However, if the DNS server is still not responding after the device has cleared the cached DNS-resolved IP addresses, the device considers the entity as offline.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b></li> <li>■ [1] <b>Enable</b> (default)</li> </ul>
<p>'Enable Fallback to Routing Table'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; fallback- to-routing</pre> <p>[IsFallbackUsed]</p>	<p>Enables the device to fallback to the Tel-to-IP Routing table for call routing when proxy servers are unavailable. When this occurs, the device continues scanning for an online proxy. If the device detects an online proxy, it stops using the Tel-to-IP Routing table and switches back to proxy routing.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p><b>Note:</b> To enable the redundant Proxy mechanism, configure the [EnableProxyKeepAlive] parameter to 1 or 2.</p>
<p>'Prefer Routing Table'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; prefer- routing-table</pre> <p>[PreferRouteTable]</p>	<p>Enables the device to route calls according to the Tel-to-IP Routing table instead of Proxy server.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) Only a Proxy server is used to route calls.</li> <li>■ [1] <b>Yes</b> = The device checks the routing rules in the Tel-to-IP Routing table for a match with the Tel-to-IP call. Only if a match is not found is a</li> </ul>

Parameter	Description
	Proxy used.
<p>'Always Use Proxy'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; always- use-proxy</pre> <p>[AlwaysSendToProxy]</p>	<p>Enables the device to send SIP requests and responses through a SIP proxy server. Otherwise, it uses the standard SIP routing rules.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p><b>Note:</b> The parameter is applicable only if a Proxy server is used (i.e., [IsProxyUsed] parameter is configured to 1).</p>
<p>'SIP Re-routing Mode'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; sip- rerouting-mode</pre> <p>[SIPReroutingMode]</p>	<p>Defines the routing mode after call redirection (i.e., a 3xx SIP response is received) or call transfer (i.e., a SIP REFER request is received).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Standard Mode</b>= (Default) INVITE messages that are generated as a result of Transfer or Redirect are sent directly to the URI, according to the Refer-To header in the REFER message, or Contact header in the 3xx response.</li> <li>■ [1] <b>Send to Proxy</b> = Sends a new INVITE to the Proxy. If the INVITE sent to the Proxy fails, the device re-routes the call according to <b>Standard Mode</b>. <b>Note:</b> This option is applicable only if a Proxy server is used and the [AlwaysSendtoProxy] parameter is configured to 0.</li> <li>■ [2] <b>Use Routing Table</b> = The device uses the Routing table to locate the destination and then sends a new INVITE to this destination. If the INVITE fails, the device re-routes the call according to <b>Standard Mode</b>. If DNS resolution fails, the device attempts to route the call to the Proxy. If routing to the Proxy also fails, the Redirect/Transfer request is rejected. <b>Note:</b> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Gateway application.</li> <li>■ If the parameter is configured to <b>Use Routing Table</b>, you can use the [XferPrefix] parameter</li> </ul> </li> </ul>

Parameter	Description
	<p>to configure different routing rules for redirect calls.</p> <ul style="list-style-type: none"> <li>■ The parameter is disregarded if the [AlwaysSendToProxy] parameter is configured to 1.</li> </ul>
<p>'DNS Query Type'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; dns-query [DNSQueryType]</pre>	<p>Enables the use of DNS Naming Authority Pointer (NAPTR) and Service Record (SRV) queries to resolve Proxy and Registrar servers and to resolve all domain names that appear in the SIP Contact and Record-Route headers.</p> <ul style="list-style-type: none"> <li>■ [0] <b>A-Record</b> = (Default) No NAPTR or SRV queries are performed.</li> <li>■ [1] <b>SRV</b> = If the Proxy/Registrar IP address parameter, Contact/Record-Route headers, or IP address configured in the routing tables contain a domain name, an SRV query is performed. The device uses the first host name received from the SRV query. The device then performs a DNS A-record query for the host name to locate an IP address.</li> <li>■ [2] <b>NAPTR</b> = An NAPTR query is performed. If it is successful, an SRV query is sent according to the information received in the NAPTR response. If the NAPTR query fails, an SRV query is performed according to the configured transport type.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If the Proxy/Registrar IP address parameter, the domain name in the Contact/Record-Route headers, or the IP address configured in the routing tables contain a domain name with a port definition, the device performs a regular DNS A-record query.</li> <li>■ If a specific Transport Type is configured, a NAPTR query is not performed.</li> <li>■ To enable NAPTR/SRV queries for Proxy servers only, use the global parameter ProxyDNSQueryType, or use the Proxy Sets</li> </ul>

Parameter	Description
	table.
<p>'Proxy DNS Query Type'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; proxy-dns- query</pre> <p>[ProxyDNSQueryType]</p>	<p>Global parameter that defines the DNS query record type for resolving the Proxy server's configured domain name (FQDN) into an IP address.</p> <ul style="list-style-type: none"> <li>■ [0] <b>A-Record=</b> (Default) A-record DNS query.</li> <li>■ [1] <b>SRV</b> = If the Proxy IP address parameter contains a domain name without port definition (e.g., ProxyIP = domain.com), an SRV query is performed. The SRV query returns up to four Proxy host names and their weights. The device then performs DNS A-record queries for each Proxy host name (according to the received weights) to locate up to four Proxy IP addresses. Thus, if the first SRV query returns two domain names and the A-record queries return two IP addresses each, no additional searches are performed.</li> <li>■ [2] <b>NAPTR</b> = NAPTR query is done. If successful, an SRV query is sent according to the information received in the NAPTR response. If the NAPTR query fails, an SRV query is done according to the configured transport type. If the Proxy IP address parameter contains a domain name with port definition (e.g., ProxyIP = domain.com:5080), the device performs a regular DNS A-record query. If a specific Transport Type is defined, a NAPTR query is not performed.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ This feature can be configured per Proxy Set in the Proxy Sets table (see <a href="#">Configuring Proxy Sets</a> on page 622).</li> <li>■ When enabled, NAPTR/SRV queries are used to discover Proxy servers even if the parameter DNSQueryType is disabled.</li> </ul>
<p>'Use Gateway Name for OPTIONS'</p> <pre>configure voip &gt; sip-</pre>	<p>Defines if the device's IP address, proxy's IP address, or device's name is used as the host part</p>

Parameter	Description
<pre>definition proxy-and- registration &gt; use-gw- name-for-opt</pre> <p>[UseGatewayNameForOptions]</p>	<p>for the Request-URI in keep-alive SIP OPTIONS messages sent to the proxy (if enabled). The device uses the OPTIONS messages as a keep-alive with its primary and redundant SIP proxy servers. Proxy keep-alive by SIP OPTIONS is enabled per Proxy Set, by configuring the 'Proxy Keep-Alive' parameter to <b>Using OPTIONS</b> (see <a href="#">Configuring Proxy Sets</a> on page 622).</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) The device's IP address is used in the keep-alive OPTIONS messages.</li> <li>■ [1] <b>Yes</b> = The device's name, configured by the [SIPGatewayName] parameter, is used in the keep-alive OPTIONS messages.</li> <li>■ [2] <b>Server</b> = The proxy's IP address is used in the SIP From and To headers in the keep-alive OPTIONS messages.</li> </ul>
<pre>configure voip &gt; sip- definition proxy-and- registration &gt; failed- options-retry-time</pre> <p>[FailedOptionsRetryTime]</p>	<p>Defines how long the device waits (in seconds) before re-sending a SIP OPTIONS keep-alive message to the proxy after the device considers the proxy as offline. It considers the proxy as offline after all the device's retransmissions (configured by the Proxy Set parameter 'Failure Detection Retransmissions') have failed.</p> <p>The valid value range is 1 to 3600. The default is 1.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if you enable proxy keep-alive by SIP OPTIONS messages (i.e., 'Proxy Keep-Alive' parameter configured to <b>Using OPTIONS</b> in the Proxy Sets table).</li> <li>■ A failed SIP response is either no response, or a response that is specified by the Proxy Sets table parameter 'Keep-Alive Failure Responses'.</li> </ul>
<pre>configure voip &gt; sbc settings &gt; abort-retries- on-icmp-error</pre> <p>[AbortRetriesOnICMPError]</p>	<p>When using UDP as the transport protocol, the device retries failed transmissions to a proxy server according to the Proxy Set parameter 'Failure Detection Retransmissions'. However, when the failed attempt receives an ICMP error (which indicates Host Unreachable or Network</p>

Parameter	Description
	<p>Unreachable) as opposed to a timeout, it may be desirable to abandon additional retries in favor of trying the next IP address (proxy server) in the Proxy Set. This is often desirable when Proxy Hot Swap is enabled.</p> <ul style="list-style-type: none"> <li>■ [0] = Disable. The device retries the same proxy according to the Proxy Set parameter 'Failure Detection Retransmissions' (regardless of error response type).</li> <li>■ [1] = (Default) Enable. Upon the receipt of an ICMP error response, the device doesn't try the proxy again (i.e., ignores the Proxy Set parameter 'Failure Detection Retransmissions'), but instead tries the next proxy in the Proxy Set.</li> </ul>
<p>'User Name'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; user-name- 4-auth</pre> <p>[UserName]</p>	<p>Defines the username for registration and Basic/Digest authentication with a Proxy/Registrar server.</p> <p>The valid value is a string of up to 60 characters. By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Gateway application.</li> <li>■ The parameter is applicable only if single device registration is used (i.e., 'Registration Mode' parameter is configured to <b>Per Gateway</b> [AuthenticationMode]).</li> <li>■ Analog interfaces: Instead of configuring the parameter, the Authentication table can be used (see Proxy, Registration and Authentication Parameters).</li> </ul>
<p>'Password'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; auth- password</pre> <p>[AuthPassword]</p>	<p>Defines the password for Basic/Digest authentication with a Proxy/Registrar server. A single password is used for all device ports.</p> <p>The default is 'Default_Passwd'.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter cannot be configured with wide</li> </ul>

Parameter	Description
	characters.
<b>'Cnonce'</b> <code>configure voip &gt; sip- definition proxy-and- registration &gt; cnonce-4- auth</code> <b>[Cnonce]</b>	<p>Defines the Cnonce string used by the SIP server and client to provide mutual authentication.</p> <p>The value is free format, i.e., 'Cnonce = 0a4f113b'. The default is 'Default_Cnonce'.</p>
<b>'Challenge Caching Mode'</b> <code>configure voip &gt; sip- definition proxy-and- registration &gt; challenge- caching</code> <b>[SIPChallengeCachingMode]</b>	<p>Enables local caching of SIP message authorization challenges from Proxy servers.</p> <p>The device sends the first request to the Proxy without authorization. The Proxy sends a 401/407 response with a challenge for credentials. The device saves (caches) the response for further uses. The device sends a new request with the appropriate credentials. Subsequent requests to the Proxy are automatically sent with credentials (calculated from the saved challenge). If the Proxy doesn't accept the new request and sends another challenge, the old challenge is replaced with the new one. One of the benefits of the feature is that it may reduce the number of SIP messages transmitted through the network.</p> <ul style="list-style-type: none"> <li>■ [0] <b>None</b> = (Default) Challenges are not cached. Every new request is sent without preliminary authorization. If the request is challenged, a new request with authorization data is sent.</li> <li>■ [1] <b>INVITE Only</b> = Challenges issued for INVITE requests are cached. This prevents a mixture of REGISTER and INVITE authorizations.</li> <li>■ [2] <b>Full</b> = Caches all challenges from the proxies.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Challenge caching is used with all proxies and not only with the active one.</li> <li>■ For the Gateway application: The challenge can be cached per endpoint or per Account.</li> <li>■ For the SBC application: The challenge can be cached per Account or per user whose</li> </ul>

Parameter	Description
	credentials are configured in the SBC User Information table.
<b>Registrar Parameters</b>	
<b>'Enable Registration'</b> <code>configure voip &gt; sip-definition proxy-and-registration &gt; enable-registration</code> <b>[IsRegisterNeeded]</b>	<p>Enables the device to register with a Proxy/Registrar server. Registration occurs when the device is powered up and periodically, configured by the [RegistrationTime] parameter.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Gateway application.</li> <li>■ The device sends a REGISTER request for each channel or for the entire device (according to the 'Registration Mode' parameter).</li> </ul>
<b>'Registrar Name'</b> <code>configure voip &gt; sip-definition proxy-and-registration &gt; registrar-name</code> <b>[RegistrarName]</b>	<p>Defines the Registrar domain name. If specified, the name is used as the Request-URI in REGISTER messages. If it isn't specified (default), the Registrar IP address, or Proxy name or IP address is used instead.</p> <p>The valid range is up to 100 characters.</p> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
<b>'Registrar IP Address'</b> <code>configure voip &gt; sip-definition proxy-and-registration &gt; ip-addr-rgrstr</code> <b>[RegistrarIP]</b>	<p>Defines the IP address (or FQDN) and port number (optional) of the Registrar server. The IP address is in dotted-decimal notation, e.g., 201.10.8.1:&lt;5080&gt;.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Gateway application.</li> <li>■ If not specified, the REGISTER request is sent to the primary Proxy server.</li> <li>■ When a port number is specified, DNS NAPTR/SRV queries aren't performed, even if the parameter DNSQueryType is set to 1 or 2.</li> </ul>



Parameter	Description
	<ul style="list-style-type: none"> <li>■ If the parameter RegistrarIP is set to an FQDN and is resolved to multiple addresses, the device also provides real-time switching (hotswap mode) between different Registrar IP addresses (the parameter IsProxyHotSwap is set to 1). If the first Registrar doesn't respond to the REGISTER message, the same REGISTER message is sent immediately to the next Proxy. To allow this mechanism, the parameter EnableProxyKeepAlive must be set to 0.</li> <li>■ When a specific transport type is defined using the parameter RegistrarTransportType, a DNS NAPTR query is not performed even if the parameter DNSQueryType is set to 2.</li> </ul>
<p>'Registrar Transport Type'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; registrar- transport</pre> <p>[RegistrarTransportType]</p>	<p>Determines the transport layer used for outgoing SIP dialogs initiated by the device to the Registrar.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> (default)</li> <li>■ [0] <b>UDP</b></li> <li>■ [1] <b>TCP</b></li> <li>■ [2] <b>TLS</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Gateway application.</li> <li>■ When set to 'Not Configured', the value of the parameter SIPTransportType is used.</li> </ul>
<p>'Registration Time'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; registration-time</pre> <p>[RegistrationTime]</p>	<p>Defines the time interval (in seconds) for registering to a Proxy server. The value is used in the SIP Expires header. The parameter also defines the time interval between Keep-Alive messages when the parameter EnableProxyKeepAlive is set to 2 (REGISTER).</p> <p>Typically, the device registers every 3,600 sec (i.e., one hour). The device resumes registration according to the parameter RegistrationTimeDivider.</p> <p>The valid range is 10 to 2,000,000. The default is 180.</p>

Parameter	Description
<p>'Re-registration Timing [%]'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; re- registration-timing</pre> <p>[RegistrationTimeDivider]</p>	<p>Defines the re-registration timing (in percentage). The timing is a percentage of the re-register timing set by the Registrar server.</p> <p>The valid range is 50 to 100. The default is 50.</p> <p>For example: If the parameter is set to 70% and the Registration Expires time is 3600, the device re-sends its registration request after 3600 x 70% (i.e., 2520 sec).</p> <p><b>Note:</b> The parameter may be overridden if the parameter RegistrationTimeThreshold is greater than 0.</p>
<p>'Registration Retry Time'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; registration-retry-time</pre> <p>[RegistrationRetryTime]</p>	<p>Defines the time interval (in seconds) after which a registration request is re-sent if registration fails with a 4xx response or if there is no response from the Proxy/Registrar server.</p> <p>The default is 30 seconds. The range is 10 to 3600.</p> <p><b>Note:</b> Registration retry time can also be configured with the MaxRegistrationBackoffTime parameter.</p>
<p>'Max Registration Backoff Time'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; max- registration-backoff-time</pre> <p>[MaxRegistrationBackoffTime]</p>	<p>Defines a dynamic time-to-wait interval before the device attempts to register the SIP entity again after a registration failure. The parameter is applicable only to registrations initiated by the device on behalf of SIP entities (for example, User Info, Accounts, Endpoints or the device itself) with a SIP proxy server (registrar).</p> <p>The valid value is 0 to 3000000 (i.e., 3 million seconds). The default is 0 (i.e., disabled).</p> <p>In contrast to the RegistrationRetryTime parameter, which defines a fixed time to wait between registration attempts due to registration failure, this parameter configures the device to increase the time-to-wait interval for each subsequent registration attempt (per RFC 5626, Section 4.5) for a specific registration flow. In other words, the interval changes between registration attempts.</p> <p>The parameter operates together with the RegistrationRetryTime parameter. When the MaxRegistrationBackoffTime parameter is</p>

Parameter	Description
	<p>configured, the wait-time before another registration attempt increases after each failed registration (until it reaches the maximum value specified by the parameter).</p> <p>The device uses the following algorithm to calculate the incremental augmented wait-time between each registration attempt:</p> $\text{Wait Time} = \min(\text{max-time}, (\text{base-time} * (2^{\text{consecutive-failures}})))$ <p>Where:</p> <ul style="list-style-type: none"> <li>■ <i>max-time</i> is the value configured by MaxRegistrationBackoffTime</li> <li>■ <i>base-time</i> is the value configured by RegistrationRetryTime</li> </ul> <p>For example, if <i>max-time</i> is 1800 seconds and <i>base-time</i> is 30 seconds, and there were three consecutive registration failures, then the upper-bound wait time is the minimum of (1800, <math>30 * (2^3)</math>), which is (1800, 240) and thus, the minimum of the two values is 240 (seconds). The actual time the device waits before retrying registration is computed by a uniform random time between 50% and 100% of the upper-bound wait time (e.g., for an upper-bound wait-time of 240, the actual wait-time is between 120 and 240 seconds). As can be seen from the algorithm, the upper-bound wait time can never exceed the value of the MaxRegistrationBackoffTime parameter.</p>
<p>'Registration Time Threshold'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; registration-time-thres [RegistrationTimeThreshold]</pre>	<p>Defines a threshold (in seconds) for re-registration timing. If the parameter is greater than 0, but lower than the computed re-registration timing (according to the parameter RegistrationTimeDivider), the re-registration timing is set to the following: timing set by the Registration server in the SIP Expires header minus the value of the parameter RegistrationTimeThreshold.</p> <p>The valid range is 0 to 2,000,000. The default is 0.</p>

Parameter	Description
<p>'Re-register On INVITE Failure'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; reg-on- invite-fail</pre> <p>[RegisterOnInviteFailure]</p>	<p>Enables an immediate re-registration if the device doesn't receive a response for its sent SIP INVITE request.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled. The device immediately expires its re-registration timer and commences re-registration to the same Proxy upon any of the following scenarios: <ul style="list-style-type: none"> <li>✓ The response to an INVITE request is 407 (Proxy Authentication Required) without an authentication header included.</li> <li>✓ The remote SIP UA abandons a call before the device has received any provisional response (indicative of an outbound proxy server failure).</li> <li>✓ The remote SIP UA abandons a call and the only provisional response the device has received for the call is 100 Trying (indicative of a home proxy server failure, i.e., the failure of a proxy in the route after the outbound proxy).</li> <li>✓ The device terminates a call due to the expiration of RFC 3261 Timer B or due to the receipt of a 408 (Request Timeout) response and the device has not received any provisional response for the call (indicative of an outbound proxy server failure).</li> <li>✓ The device terminates a call due to the receipt of a 408 (Request Timeout) response and the only provisional response the device has received for the call is the 100 Trying provisional response (indicative of a home proxy server failure).</li> </ul> </li> </ul> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
<p>'ReRegister On Connection Failure'</p> <pre>configure voip &gt; sip-</pre>	<p>Enables the device to perform a SIP re-registration upon a TCP/TLS connection failure.</p>

Parameter	Description
<pre>definition proxy-and- registration &gt; reg-on- conn-failure</pre> <p>[ReRegisterOnConnectionFailure]</p>	<ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul>
<p>'Gateway Registration Name'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; gw- registration-name</pre> <p>[GWRegistrationName]</p>	<p>Defines the user part in the From and To headers in SIP REGISTER messages. If no value is specified (default) for the parameter, the [UserName] parameter is used instead.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Gateway application.</li> <li>■ The parameter is applicable only for single registration per device (i.e., 'Registration Mode' parameter is configured to <b>Per Gateway</b> [AuthenticationMode]). When the device registers each channel separately (i.e., 'Registration Mode' parameter configured to <b>Per Endpoint</b>), the username is set to the channel's phone number.</li> </ul>
<p>'Registration Mode'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; authentication-mode</pre> <p>[AuthenticationMode]</p>	<p>Defines the device's registration and authentication method.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Per Endpoint</b> = The device registers and authenticates each</li> <li>■ [1] <b>Per Gateway</b> = (Default) Single registration and authentication is done for the entire device. This is typically used for digital interfaces.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to endpoints that are either not associated with any row configured in the Trunk Group Settings table, or are associated with a row and the row's 'Registration Mode' parameter is not configured (see <a href="#">Configuring Trunk Group Settings</a> on page 906).</li> <li>■ The parameter is applicable only to the Gateway application.</li> </ul>

Parameter	Description
<p>'Set Out-Of-Service On Registration Failure'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; set-oos- on-reg-failure</pre> <p>[OOSOnRegistrationFail]</p>	<p>Enables the device to set the trunk, or entire device (i.e., all endpoints) to out-of-service if registration fails.</p> <p>If registration is per endpoint (i.e., 'Registration Mode' parameter is configured to <b>Per Endpoint</b>) or per Account (see <a href="#">Configuring Trunk Group Settings</a> on page 906) and a specific endpoint / Account registration fails (SIP 4xx or no response), the device sets that endpoint to out-of-service until a success response is received in a subsequent registration request. If registration is per the entire device (i.e., 'Registration Mode' parameter is configured to <b>Per Gateway</b>) and registration fails, the device sets all endpoints to out-of-service. If all the Accounts of a specific Trunk Group fail registration and if the Trunk Group comprises a complete trunk, the device sets the entire trunk to out-of-service.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Gateway application.</li> </ul>
<p>'Register By Served Trunk Group Status'</p> <pre>configure voip &gt; gateway advanced &gt; register-by- served-tg-status</pre> <p>[RegisterByTrunkGroupStatus]</p>	<p>Defines if the device sends a registration request (SIP REGISTER) to a Serving IP Group (SIP registrar), based on the Trunk Group's status (in-service or out-of-service).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Register Only if In-Service</b> = (Default) The device sends a registration request only if the Trunk Group's status is in-service.</li> <li>■ [1] <b>Register Always</b> = The device sends a registration request regardless of the Trunk Group's status (in-service or out-of-service). For example, even if the Trunk Group is configured, but its E1/T1 PSTN cable has yet to be connected to the device (i.e., out-of-service), the device still sends a registration request.</li> </ul> <p><b>Note:</b></p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Gateway application (ISDN PRI and CAS).</li> <li>■ The parameter is applicable only if the Trunk Group's 'Registration Mode' parameter in the Trunk Group Settings table is configured to <b>Per Account</b> (see <a href="#">Configuring Trunk Group Settings</a> on page 906).</li> </ul>
<pre>configure voip &gt; sip- definition proxy-and- registration &gt; expl-un- reg</pre> <p>[UnregistrationMode]</p>	<p>Enables the device to perform explicit unregisters.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b> = The device sends an asterisk ("*") value in the SIP Contact header, instructing the Registrar server to remove all previous registration bindings. The device removes SIP User Agent (UA) registration bindings in a Registrar, according to RFC 3261. Registrations are soft state and expire unless refreshed, but they can also be explicitly removed. A client can attempt to influence the expiration interval selected by the Registrar. A UA requests the immediate removal of a binding by specifying an expiration interval of "0" for that contact address in a REGISTER request. UA's should support this mechanism so that bindings can be removed before their expiration interval has passed. Use of the "*" Contact header field value allows a registering UA to remove all bindings associated with an address-of-record (AOR) without knowing their precise values.</li> </ul> <p><b>Note:</b> The REGISTER-specific Contact header field value of "*" applies to all registrations, but it can only be used if the Expires header field is present with a value of "0".</p>
<p>'Add Empty Authorization Header'</p> <pre>configure voip &gt; sip- definition settings &gt; add-empty-author-hdr</pre> <p>[EmptyAuthorizationHeader]</p>	<p>Enables the inclusion of the SIP Authorization header in initial registration (REGISTER) requests sent by the device.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>The Authorization header carries the credentials of</p>

Parameter	Description
	<p>a user agent (UA) in a request to a server. The sent REGISTER message populates the Authorization header with the following parameters:</p> <ul style="list-style-type: none"> <li>■ username - set to the value of the private user identity</li> <li>■ realm - set to the domain name of the home network</li> <li>■ uri - set to the SIP URI of the domain name of the home network</li> <li>■ nonce - set to an empty value</li> <li>■ response - set to an empty value</li> </ul> <p>For example:</p> <p>Authorization: Digest username=alice_private@home1.net, realm="home1.net", nonce="", response="e56131d19580cd833064787ecc"</p> <p><b>Note:</b> This registration header is according to the IMS 3GPP TS24.229 and PKT-SP-24.220 specifications.</p>
<p>'Add initial Route Header'</p> <pre>configure voip &gt; sip- definition proxy-and- registration &gt; add-init- rte-hdr</pre> <p>[InitialRouteHeader]</p>	<p>Enables the inclusion of the SIP Route header in initial registration or re-registration (REGISTER) requests sent by the device.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p>When the device sends a REGISTER message, the Route header includes either the Proxy's FQDN, or IP address and port according to the configured Proxy Set, for example:</p> <p>Route:</p> <pre>&lt;sip:10.10.10.10;lr;transport=udp&gt;</pre> <p>or</p> <pre>Route: &lt;sip: pcscf- gm.ims.rr.com;lr;transport=udp&gt;</pre>
<pre>configure voip &gt; sip- definition proxy-and- registration &gt; ping-pong- keep-alive</pre>	<p>Enables the use of the carriage-return and line-feed sequences (CRLF) Keep-Alive mechanism, according to RFC 5626 "Managing Client-Initiated Connections in the Session Initiation Protocol (SIP)"</p>



Parameter	Description
[UsePingPongKeepAlive]	<p>for reliable, connection-orientated transport types such as TCP.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p>The SIP user agent/client (i.e., device) uses a simple periodic message as a keep-alive mechanism to keep their flow to the proxy or registrar alive (used for example, to keep NAT bindings open). For connection-oriented transports such as TCP/TLS this is based on CRLF. This mechanism uses a client-to-server "ping" keep-alive and a corresponding server-to-client "pong" message. This ping-pong sequence allows the client, and optionally the server, to tell if its flow is still active and useful for SIP traffic. If the client doesn't receive a pong in response to its ping, it declares the flow "dead" and opens a new flow in its place. In the CRLF Keep-Alive mechanism the client periodically (defined by the PingPongKeepAliveTime parameter) sends a double-CRLF (the "ping") then waits to receive a single CRLF (the "pong"). If the client doesn't receive a "pong" within an appropriate amount of time, it considers the flow failed.</p> <p><b>Note:</b> The device sends a CRLF message to the Proxy Set only if the Proxy Keep-Alive feature (EnableProxyKeepAlive parameter) is enabled and its transport type is set to TCP or TLS. The device first sends a SIP OPTION message to establish the TCP/TLS connection and if it receives any SIP response, it continues sending the CRLF keep-alive sequences.</p>
<pre>configure voip &gt; sip- definition proxy-and- registration &gt; ping-pong- keep-alive-time</pre> <p>[PingPongKeepAliveTime]</p>	<p>Defines the periodic interval (in seconds) after which a "ping" (double-CRLF) keep-alive is sent to a proxy/registrar, using the CRLF Keep-Alive mechanism.</p> <p>The default range is 5 to 2,000,000. The default is 120.</p> <p>The device uses the range of 80-100% of this user-defined value as the actual interval. For example, if</p>

Parameter	Description
	the parameter value is set to 200 sec, the interval used is any random time between 160 to 200 seconds. This prevents an “avalanche” of keep-alive by multiple SIP UAs to a specific server.
<b>'Max Generated Register Rate'</b> <code>configure voip &gt; sip-definition proxy-and-registration &gt; max-gen-reg-rate</code> [MaxGeneratedRegistersRate]	Defines the maximum number of user register requests (REGISTER messages) that the device sends (to a proxy or registrar server) at a user-defined rate configured by the [GeneratedRegistersInterval] parameter. The parameter is useful in that it may be used to prevent an overload on the device's CPU caused by sending many registration requests at a given time. The valid value is 30 to 300 register requests per second. The default is 150.  For configuration examples, see the description of the [GeneratedRegistersInterval] parameter.
<b>'Generated Register Interval'</b> <code>configure voip &gt; sip-definition proxy-and-registration &gt; gen-reg-int</code> [GeneratedRegistersInterval]	Defines the rate (in seconds) at which the device sends user register requests (REGISTER messages). The parameter is based on the maximum number of REGISTER messages that can be sent at this rate, configured by the [MaxGeneratedRegistersRate] parameter.  The valid value is 1 to 5. The default is 1.  Configuration examples: <ul style="list-style-type: none"> <li>■ If you configure the [MaxGeneratedRegistersRate] parameter to 100 and [GeneratedRegistersInterval] to 5, the device sends a maximum of 20 REGISTER messages per second (i.e., 100 messages divided by 5 sec; 100 per 5 seconds).</li> <li>■ If you configure the [MaxGeneratedRegistersRate] parameter to 100 and [GeneratedRegistersInterval] to 1, the device sends a maximum of a 100 REGISTER messages per second.</li> </ul>
<code>configure voip &gt; sip-definition proxy-and-registration &gt; reg-sync-mode</code>	Enables the synchronization of the registration process. This prevents the device from sending multiple SIP REGISTER requests for multiple Accounts and users in the SBC User Information

Parameter	Description
[RegistrationSyncMode]	<p>table registering to the same proxy server (serving IP Group) that is currently offline.</p> <p>These are Accounts that are configured in the Accounts table (see <a href="#">Configuring Registration Accounts</a> on page 750) and users that are configured in the SBC User Information table (see <a href="#">Configuring SBC User Information Table through Web Interface</a> on page 776).</p> <p>If an Account or user receives a response timeout (see note below) or a response failure (e.g., SIP 403) for a sent SIP REGISTER request, the device stops sending SIP REGISTER messages for all the other Accounts and users that are associated with the same proxy server (<i>serving IP Group</i>). The Account or user that first detected the no response (or failure) from the proxy is considered the <i>lead</i> Account or user. The device continues sending REGISTER requests to the proxy only for this lead Account or user.</p> <p>When the lead Account or user receives a successful response from the proxy, the device resumes the registration process for all the other Accounts and users that are associated with this same proxy.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable</li> <li>■ [1] = Enable</li> </ul> <p><b>Note:</b> You can configure the response timeout using the [SipT1Rtx], [SipT2Rtx], or [SIPMaxRtx] parameters.</p>
<pre>configure voip &gt; sip- definition settings &gt; account-invite-failure- trigger-codes</pre> <p>[AccountInviteFailureTriggerCodes]</p>	<p>Defines SIP response codes that if received for a failed INVITE message sent for an Account, triggers the device to re-register the Account. The parameter is applicable only if the Account's 'Re-Register on Invite Failure' parameter in the Accounts table is configured to <b>Enable</b> (see <a href="#">Configuring Registration Accounts</a> on page 750).</p> <p>The valid value is a SIP response code. Multiple response codes can be configured, where each value is separated by a comma. The default is "403,408,480" (without quotation marks).</p>

Parameter	Description
	<p><b>Note:</b> SIP response code 408 also refers to an INVITE timeout (i.e., no reply from server). Therefore, if re-registration is needed for such a scenario, make sure that you configure the parameter with "408" as well.</p>
<pre>configure voip &gt; sip- definition settings &gt; ignore-auth-stale [IgnoreAuthorizationStale]</pre>	<p>Enables the device to retry registering even if the last SIP 401\407 response included "stale=false". When the device initiates a REGISTER request with an Authorization header (according to the relevant configured credentials), and it receives a SIP 401\407 response with the stale parameter set to "false", by default the device doesn't try to send another REGISTER message. When the parameter is enabled, the device retries registering even if the last 401\407 response had "stale=false".</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) If the device receives a SIP 401\407 response with "stale=true" or no stale parameter at all, it sends another REGISTER message. If "stale=false", the device doesn't send another REGISTER message.</li> <li>■ [1] = If the device receives a SIP 401\407 response with "stale=false", it sends another REGISTER message.</li> </ul> <p><b>Note:</b> This parameter is applicable only to REGISTER requests which the device initiates (e.g., for an Account or for Gateway endpoints); it's not for REGISTER requests that the device forwards from the user to the registrar server.</p>
<pre>configure voip &gt; sip- definition proxy-and- registration &gt; account- registrar-avoidance-time [AccountRegistrarAvoidanceTime]</pre>	<p>Defines a graceful time (in seconds) which is intended to prevent the device from sending REGISTER requests to a registrar server where the device previously registered, if the device also registered successfully to another server since the last successful registration to the registrar server. This can occur if the registrar server has been offline for a brief time. For more information, see the 'Registrar Search Mode' parameter in <a href="#">Configuring Registration Accounts</a> on page 750. The valid value is 0 to 15.2 million. The default is 0.</p>

Parameter	Description
<pre>configure voip &gt; sip- definition settings &gt; authenticated-message- handling</pre> <p>[AuthenticatedMessageHandling]</p>	<p>Defines if a Message Manipulation Set is run again on incoming authenticated SIP messages received after the device sends a SIP 401 response for challenging initial incoming SIP REGISTER requests. Typically, this is not required and the rules of a Message Manipulation Set that are configured to run on incoming REGISTER requests are applied only when the initial unauthenticated REGISTER request is received. However, if the Message Manipulation Set includes a Message Manipulation rule that specifies that manipulation must be done on the SIP Authorization header (i.e., 'Condition' parameter value is "Header.Authorization !exists"), which is present only in authenticated messages, then configure the parameter to [1].</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable - The Message Manipulation Set is not run again on authenticated messages and only applied to initial unauthenticated messages. The device uses this manipulated initial REGISTER request for further processing (e.g., classification or routing).</li> <li>■ [1] = The Message Manipulation Set is run again on authenticated messages (if it includes a rule whose condition is the Authorization header). The device uses this manipulated authenticated REGISTER request for further processing (e.g., classification or routing).</li> </ul>

## Network Application Parameters

The SIP network application parameters are described in the table below.

**Table 69-33:SIP Network Application Parameters**

Parameter	Description
<pre>configure voip &gt; sip-definition settings &gt; tcp-keepalive-time</pre> <p>[TCPKeepAliveTime]</p>	<p>Defines the interval (in sec) between the last data packet sent and the first keep-alive probe to send. The valid value is 10 to</p>

Parameter	Description
	<p>65,000. The default is 60.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Simple ACKs such as keepalives are not considered data packets.</li> <li>■ TCP keepalive is enabled per SIP Interface in the SIP Interfaces table.</li> </ul>
<pre>configure voip &gt; sip-definition settings &gt; tcp-keepalive-interval [TCPKeepAliveInterval]</pre>	<p>Defines the interval (in sec) between consecutive keep-alive probes, regardless of what the connection has exchanged in the meantime.</p> <p>The valid value is 10 to 65,000. The default is 10.</p> <p><b>Note:</b> TCP keepalive is enabled per SIP Interface in the SIP Interfaces table.</p>
<pre>configure voip &gt; sip-definition settings &gt; tcp-keepalive-retry [TCPKeepAliveRetry]</pre>	<p>Defines the number of unacknowledged keep-alive probes to send before considering the connection down.</p> <p>The valid value is 1 to 100. The default is 5.</p> <p><b>Note:</b> TCP keepalive is enabled per SIP Interface in the SIP Interfaces table.</p>

## General SIP Parameters

The general SIP parameters are described in the table below.

Table 69-34:General SIP Parameters

Parameter	Description
'Classify By Proxy Set Mode'  <pre>configure voip &gt; sip-definition settings &gt; classify-by- proxy-set-mode</pre> [ClassifyByProxySetMode]	<p>Defines which IP address to use for classifying the incoming SIP dialog message to a Server-type IP Group, based on Proxy Set.</p> <ul style="list-style-type: none"> <li>■ [0] <b>IP address</b> = (Default) The device checks if the source IP address (ISO Layer 3) of the incoming SIP dialog matches an IP address in the Proxy Set that is associated with the IP Group. If a match is found in the Proxy Set, the call is classified to the IP Group.</li> <li>■ [1] <b>Contact Header</b> = The device checks if the IP address in the SIP Contact header of the incoming SIP dialog matches an IP address in the Proxy Set that is associated with the IP Group. This is only applicable if the header contains a SIP URI that has an IP address (not hostname) in the host part. If a match is found in the Proxy Set, the call is classified to the IP Group. This option is useful, for example, when the source IP address is an internal address.</li> <li>■ [2] <b>Both</b> = The device first checks if the source IP address (ISO Layer 3) of the incoming SIP dialog matches an IP address in the Proxy Set that is associated with the IP Group. Only if there is no match, does the device check if the IP address in the SIP Contact header of the incoming SIP dialog matches an IP address in the Proxy Set.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ To enable classification by Proxy Set, configure the IP Group table's 'Classify By Proxy Set' parameter to <b>Enable</b> (see <a href="#">Configuring IP Groups</a> on page 581).</li> <li>■ Classification using the SIP Contact header is supported only when the header's SIP URI has an IP address (not a DNS hostname).</li> <li>■ For IDS, only the source IP address is used (see <a href="#">Configuring IDS Policies</a> on page 259).</li> <li>■ For TLS Contexts, only the source IP address is used. (If a Proxy Set is not found, the TLS Context configured for the SIP Interface is used.)</li> <li>■ This parameter is applicable only to the SBC application.</li> </ul>
<pre>configure voip &gt; sip-definition settings &gt; max-</pre>	<p>Defines the maximum number of characters allowed in the SDP body's "o=" (originator and session identifier) field for the session ID and session version values.</p>

Parameter	Description
<code>sdp-sess-ver-id</code> [MaxSDPSessionVersionId]	<p>Below is an example of an "o=" line with session ID and session version values (in bold):</p> <pre>o=jdoe <b>2890844526 2890842807</b> IN IP4 10.47.16.5</pre> <p>The valid value range is 1,000 to 214,748,3647 (default).</p>
<code>configure voip</code> <code>&gt; sip-definition settings &gt;</code> <code>unreg-on-startup</code> [UnregisterOnStartup]	<p>Enables the device to unregister all user Accounts that were registered with the device, upon a device restart. During device start-up, each Account sends a REGISTER message (containing "Contact: *") to unregister all contact URIs belonging to its Address-of-Record (AOR), and then a second after they are unregistered, the device re-registers the Account.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable</li> <li>■ [1] = Enable</li> </ul> <p>To configure Accounts, see <a href="#">Configuring Registration Accounts</a> on page 750.</p>
'Send Reject (503) upon Overload' <code>configure voip &gt;</code> <code>sip-definition settings &gt;</code> <code>reject-on-ovrld</code> [SendRejectOnOverload]	<p>Disables the sending of SIP 503 (Service Unavailable) responses upon receipt of new SIP dialog-initiating requests when the device's CPU is overloaded and thus, unable to accept and process new SIP messages.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = Disabled. SIP 503 response isn't sent upon CPU overload.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = (Default) Enabled. SIP 503 response is sent upon CPU overload.</li> </ul> <p><b>Note:</b> Even if the parameter is disabled (i.e., 503 is not sent), the device still discards the new SIP dialog-initiating requests when the CPU is overloaded.</p>
'SIP 408 Response upon non-INVITE' <code>configure voip &gt;</code> <code>sip-definition settings &gt; enbl-non-inv-408</code> [EnableNonInvite408Reply]	<p>Enables the device to send SIP 408 responses (Request Timeout) upon receipt of non-INVITE transactions, if necessary. Disabling this response complies with RFC 4320/4321. By default, and in certain circumstances such as a timeout expiry, the device sends a SIP 408 Request Timeout in response to non-INVITE requests (e.g., REGISTER).</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = (Default) Enabled.</li> </ul>
'Remote Management by SIP NOTIFY'	<p>Enables a specific device action upon the receipt of a SIP NOTIFY request, where the action depends on the value in the Event</p>



Parameter	Description
<pre>configure voip &gt; sip-definition settings &gt; sip- remote-reset</pre> <p>[EnableSIPRemoteReset]</p>	<p>header.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>The action depends on the Event header value:</p> <ul style="list-style-type: none"> <li>■ "Event: check-sync;reboot=false": Triggers the regular Automatic Update feature (if Automatic Update has been enabled on the device).</li> <li>■ "Event: check-sync;reboot=true": Triggers a device restart.</li> <li>■ "Event: soft-sync": Triggers the device to disconnect all current calls.</li> <li>■ If the 'reboot=' parameter is not specified in the Event header, it defaults to 'true' (i.e., triggers a device restart).</li> </ul> <p><b>Note:</b> The Event header value is proprietary to AudioCodes.</p>
<p>'Max SIP Message Length'</p> <p>[MaxSIPMessageLength]</p>	<p>Defines the maximum size (in Kbytes) for each SIP message that can be sent over the network. The device rejects messages exceeding this user-defined size.</p> <p>The valid value range is 1 to 100. The default is 100.</p>
<p>[SIPForceRport]</p>	<p>Determines whether the device sends SIP responses to the UDP port from where SIP requests are received even if the 'rport' parameter is not present in the SIP Via header.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disabled. The device sends the SIP response to the UDP port defined in the Via header. If the Via header contains the 'rport' parameter, the response is sent to the UDP port from where the SIP request is received.</li> <li>■ [1] = Enabled. SIP responses are sent to the UDP port from where SIP requests are received even if the 'rport' parameter is not present in the Via header.</li> </ul>
<p>'Reject Cancel after Connect'</p> <pre>configure voip &gt; sip-definition settings &gt; rej- cancel-after- conn</pre> <p>[RejectCancelAfterConnect]</p>	<p>Enables the device to accept or reject SIP CANCEL requests received after the receipt of a 200 OK in response to an INVITE (i.e., call established). According to the SIP standard, a CANCEL can be sent only during the INVITE transaction (before 200 OK), and once a 200 OK response is received the call can be rejected only by a BYE request.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. Accepts a CANCEL request received during the INVITE transaction by</li> </ul>

Parameter	Description
nect]	<p>sending a 200 OK response and terminates the call session.</p> <ul style="list-style-type: none"> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled. Rejects a CANCEL request received during the INVITE transaction by sending a SIP 481 (Call/Transaction Does Not Exist) response and maintains the call session.</li> </ul>
<pre>configure voip &gt; sip-definition settings &gt; call- info-list</pre> <p>[CallInfoListMode]</p>	<p>Defines how the device handles SIP Call-Info headers with multiple values in outgoing SIP messages.</p> <ul style="list-style-type: none"> <li>■ [0] = The device sends the outgoing SIP message with a Call-Info header for each value.</li> <li>■ [1] = The device sends the outgoing SIP message with a <b>single</b> Call-Info header that contains all the values (comma-separated list) per RFC 3261.</li> </ul>
<pre>configure voip &gt; sip-definition settings &gt; verify-rcvd- requi</pre> <p>[VerifyRecievedRequestUri]</p>	<p>Enables the device to reject SIP requests (e.g., ACK, BYE, or re-INVITE) whose user part in the Request-URI is different from the user part in the Contact header of the last sent SIP request.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable. Even if the user part is different, the device accepts the SIP request.</li> <li>■ [1] = Enable. If the user part in the Contact header of the previous SIP request is different to the user part in the Request-URI for in-dialog requests, the device rejects the SIP request. A BYE request is responded with a SIP 481, a re-INVITE request is responded with a SIP 404, and an ACK request is ignored.</li> <li>■ [2] = If the user part in the Contact header of the previous SIP request is different to the user part in the Request-URI for dialog-initiating INVITE requests, the device rejects the SIP request.</li> <li>■ Verify dialog-initiating INVITE for all required conditions (Via, Source IP and user in Request-URI)</li> <li>■ [3] = Verify dialog-initiating INVITE and in-dialog requests.</li> </ul> <p>The [VerifyRecievedRequestUri] parameter functions together with the [RegistrarProxySetID] parameter, as follows:</p> <ul style="list-style-type: none"> <li>■ <b>Handling Dialog-Initiating INVITES:</b> If the [VerifyRecievedRequestUri] parameter is configured to [2] or [3] and the [RegistrarProxySetID] parameter is configured to some Proxy Set, the device accepts dialog-initiating INVITE requests received from the registrar at which the Accounts</li> </ul>

Parameter	Description
	<p>(configured in the Accounts table) are registered. For dialog-initiating INVITE requests received from the registrar on a specific SIP Interface, the following rules apply (listed according to priority):</p> <ul style="list-style-type: none"> <li>✓ The top-most Via header must contain a host-resolved IP address of the registrar; otherwise, the device drops the INVITE request.</li> <li>✓ The source IP address must be the same as the IP address of the registrar; otherwise, the device rejects the requests and sends a SIP 403 (Forbidden) response to the registrar.</li> <li>✓ The user part, specified in the Request-URI header, must be identical to the Contact user part configured for the associated Account, and the Account must be registered. Otherwise, the device rejects the request with a SIP 404 (Not Found) response. If the [RegistrarProxySetID] parameter is not configured or no Accounts are configured, the device accepts the dialog-initiating INVITE request.</li> </ul> <p><b>Note:</b> This handling is applicable only to the SBC application.</p> <p>■ <b>Handling In-dialog Requests:</b> If the [VerifyRecievedRequestUri] parameter is configured to [1] or [3], for all incoming in-dialog requests (including ACK and CANCEL), the device checks if the Request-URI user part matches the remote Contact user part (i.e., the Contact user configured for the Account). If there is no match, the device rejects the request and sends a SIP 481 response for requests such as BYE and CANCEL, or a SIP 404 for other requests, and for ACK it doesn't send any response.</p> <p><b>Note:</b> This handling is applicable to the Gateway and SBC applications.</p>
[RegistrarProxySetID]	<p>Defines a Proxy Set for the registrar. The parameter functions together with the [VerifyRecievedRequestUri] parameter. For more information, see the description of the [VerifyRecievedRequestUri] parameter.</p> <p>The default value is -1 (not defined).</p> <p><b>Note:</b> This setting assumes that the SIP Interface has only one registrar.</p>

Parameter	Description
<p>'Max Number of Active Calls'</p> <pre>configure voip &gt; sip-definition settings &gt; max- nb-of--act-calls</pre> <p>[MaxActiveCalls]</p>	<p>Defines the maximum number of simultaneous active calls supported by the device. If the maximum number of calls is reached, new calls are not established.</p> <p>The valid range is 1 to the maximum number of supported channels. The default value is the maximum available channels (i.e., no restriction on the maximum number of calls).</p>
<p>'QoS Statistics in Release Msg'</p> <pre>configure voip &gt; sip-definition settings &gt; qos- statistics-in- release-msg</pre> <p>[QoSStatistics]</p>	<p>Enables the device to include call Quality of Service (QoS) statistics in SIP BYE messages and SIP 200 OK responses to BYE messages, using the proprietary SIP header X-RTP-Stat.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>The X-RTP-Stat header contains the following statistics:</p> <ul style="list-style-type: none"> <li>■ Number of received and sent voice packets</li> <li>■ Number of received and sent voice octets</li> <li>■ Received packet loss, jitter (in ms), and latency (in ms)</li> </ul> <p>The X-RTP-Stat header contains the following fields:</p> <ul style="list-style-type: none"> <li>■ PS=&lt;voice packets sent&gt;</li> <li>■ OS=&lt;voice octets sent&gt;</li> <li>■ PR=&lt;voice packets received&gt;</li> <li>■ OR=&lt;voice octets received&gt;</li> <li>■ PL=&lt;receive packet loss&gt;</li> <li>■ JI=&lt;jitter in ms&gt;</li> <li>■ LA=&lt;latency in ms&gt;</li> </ul> <p>Below is an example of the X-RTP-Stat header in a SIP BYE message:</p> <pre>BYE sip:302@10.33.4.125 SIP/2.0 Via: SIP/2.0/UDP 10.33.4.126;branch=z9hG4bKac2127550866 Max-Forwards: 70 From: &lt;sip:401@10.33.4.126;user=phone&gt;;tag=1c2113 553324</pre>

Parameter	Description
	<p>To: &lt;sip:302@company.com&gt;;tag=1c991751121</p> <p>Call-ID: 991750671245200001912@10.33.4.125</p> <p>CSeq: 1 BYE</p> <p><b>X-RTP-Stat:</b></p> <p><b>PS=207;OS=49680;;PR=314;OR=50240;PL=0;JI=600;LA=40;</b></p> <p>Supported: em,timer,replaces,path,resource-priority</p> <p>Allow:</p> <p>REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE</p> <p>User-Agent: Sip-Gateway-/7.60A.100.022</p> <p>Reason: Q.850 ;cause=16 ;text="local"</p> <p>Content-Length: 0</p> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
<p>'PRACK Mode'</p> <p>prack-mode</p> <p>[PrackMode]</p>	<p>Determines the PRACK (Provisional Acknowledgment) mechanism mode for SIP 1xx reliable responses.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b></li> <li>■ [1] <b>Supported</b> (default)</li> <li>■ [2] <b>Required</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The Supported and Required headers contain the '100rel' tag.</li> <li>■ The device sends PRACK messages if 180/183 responses are received with '100rel' in the Supported or Required headers.</li> <li>■ The parameter is applicable only to the Gateway application.</li> </ul>
<p>'Enable Early Media'</p> <p>early-media</p> <p>[EnableEarlyMedia]</p>	<p>Global parameter enabling the Early Media feature for sending media (e.g., ringing) before the call is established.</p> <p>You can also configure this feature per specific calls, using IP Profiles ('Early Media' parameter) or Tel Profiles ('Enable Early Media' parameter). For a detailed description of the parameter and for configuring the feature, see <a href="#">Configuring IP Profiles</a> on page 664 or <a href="#">Configuring Tel Profile</a> on page 738.</p> <p><b>Note:</b> If the feature is configured for a specific profile, the</p>

Parameter	Description
	settings of the global parameter is ignored for calls associated with the profile.
'Early 183' early-183 [EnableEarly183]	<p>Global parameter that enables the device to send SIP 183 responses with SDP to the IP upon receipt of INVITE messages. You can also configure this feature per specific calls, using IP Profiles ('Early 183' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b> If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</p>
[IgnoreAlertAfterEarly Media]	<p>Defines the device's interworking of Alerting messages for IP-to-Tel calls (ISDN). It determines whether the device sends a 180 Ringing response to the caller after the device sends a 183 Session Progress response to the caller. The 180 Ringing response indicates that the INVITE has been received by the ISDN side and that alerting is taking place (i.e., ISDN Progress message), indicating to the IP PBX to play a ringback tone. The 183 Session Progress response allows an early media session to be established prior to the call being answered, for example, to hear a ring tone, busy tone or recorded announcement.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable. If the device sends a 183 response with SDP (due to a received ISDN Progress or Proceeding with PI messages, i.e., a ring tone, busy tone or recorded announcement played to the ISDN side) and an Alerting message is then received from the ISDN side (with or without Progress Indicator), the device also sends a 180 Ringing response to the caller. Therefore, in this case, early media is played to the ISDN side and then the ringback tone is played by the IP PBX.</li> <li>■ [1] = Enable. If the device sends a 183 response with SDP (due to a received ISDN Progress or Proceeding with PI messages) and an Alerting message is then received from the ISDN side (with or without Progress Indicator), the device doesn't send a 180 Ringing response to the caller and the voice channel remains open. Therefore, in this case, early media is played to the ISDN side and a ringback tone is not played by the IP PBX.</li> </ul> <p><b>Note:</b></p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ The parameter is applicable only to digital interfaces.</li> <li>■ The parameter is applicable only if the [EnableEarlyMedia] parameter is set to 1 (i.e., enabled).</li> </ul>
<p>'183 Message Behavior'</p> <pre>configure voip &gt; sip-definition settings &gt; 183- msg-behavior [SIP183Behaviour]</pre>	<p>Defines the ISDN message that is sent when the 183 Session Progress message is received for IP-to-Tel calls.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Progress</b> = (Default) <ul style="list-style-type: none"> <li>✓ The device sends a Progress message.</li> </ul> </li> <li>■ [1] <b>Alert</b> = <ul style="list-style-type: none"> <li>✓ The device sends an Alerting message (upon receipt of a 183 response) instead of an ISDN Progress message.</li> </ul> </li> </ul> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
[ReleaseIP2ISDNCallOnProgressWithCause]	<p>Typically, if an Q.931 Progress message with a Cause is received from the PSTN for an outgoing IP-to-ISDN call and the [EnableEarlyMedia] parameter is set to 1 (i.e., the Early Media feature is enabled), the device interworks the Progress to 183 + SDP to enable the originating party to hear the PSTN announcement about the call failure. Conversely, if EnableEarlyMedia is set to 0, the device disconnects the call by sending a SIP 4xx response to the originating party. However, if the [ReleaseIP2ISDNCallOnProgressWithCause] parameter is set to 1, then the device sends a SIP 4xx response even if the [EnableEarlyMedia] parameter is set to 1.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) If a Progress with Cause message is received from the PSTN for an outgoing IP-to-ISDN call, the device doesn't disconnect the call by sending a SIP 4xx response to the originating party.</li> <li>■ [1] = The device sends a SIP 4xx response when the [EnableEarlyMedia] parameter is set to 0.</li> <li>■ [2] = The device always sends a SIP 4xx response, even if the [EnableEarlyMedia] parameter is set to 1.</li> </ul> <p><b>Note:</b> The parameter is applicable only to digital interfaces.</p>
<p>'Session-Expires Time'</p> <pre>configure voip &gt; sip-definition settings &gt;</pre>	<p>Defines the numerical value sent in the Session-Expires header in the first SIP INVITE request or response (if the call is answered).</p> <p>The valid range is 1 to 86,400 sec. The default is 0 (i.e., the</p>

Parameter	Description
<code>session-expires-time</code> [ <code>SIPSessionExpires</code> ]	<p>Session-Expires header is disabled).</p> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
<p>'Minimum Session-Expires'</p> <code>configure voip &gt; sip-definition settings &gt; min-session-expires</code> [ <code>MinSE</code> ]	<p>Defines the time (in seconds) in the SIP Min-SE header. The header defines the minimum time that the user agent refreshes the session.</p> <p>The valid range is 10 to 100,000. The default is 90.</p> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
<p>'Session Expires Disconnect Time'</p> <code>configure voip &gt; sip-definition settings &gt; sess-exp-disc-time</code> [ <code>SessionExpiresDisconnectTime</code> ]	<p>Defines a session expiry timeout.</p> <p>The new session expiry timeout is calculated by subtracting the configured value from the original timeout as specified in the Session-Expires header. However, the new timeout must be greater than or equal to one-third (1/3) of the Session-Expires value. If the refresher doesn't send a refresh request within the new timeout, the device disconnects the session (i.e., sends a SIP BYE).</p> <p>For example, if you configure the parameter to 32 seconds and the Session-Expires value is 180 seconds, the session timeout occurs 148 seconds (i.e., 180 minus 32) after the last session refresh. If the Session-Expires header value is 90 seconds, the timeout occurs 60 seconds after the last refresh. This is because 90 minus 32 is 58 seconds, which is less than one third of the Session-Expires value (i.e., 60/3 is 30, and 90 minus 30 is 60).</p> <p>The valid range is 0 to 32 (in seconds). The default is 32.</p> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
<p>'Session Expires Method'</p> <code>configure voip &gt; sip-definition settings &gt; session-exp-method</code> [ <code>SessionExpiresMethod</code> ]	<p>Defines the SIP method used for session-timer updates.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Re-INVITE</b> = (Default) Uses re-INVITE messages for session-timer updates.</li> <li>■ [1] <b>UPDATE</b> = Uses UPDATE messages.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Gateway application.</li> <li>■ The device can receive session-timer refreshes using both methods.</li> </ul>



Parameter	Description
	<ul style="list-style-type: none"> <li>■ The UPDATE message used for session-timer is excluded from the SDP body.</li> </ul>
[RemoveToTagInFailureResponse]	<p>Determines whether the device removes the 'to' header tag from final SIP failure responses to INVITE transactions.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Do not remove tag.</li> <li>■ [1] = Remove tag.</li> </ul>
[EnableRTCPAttribute]	<p>Enables the use of the 'rtcp' attribute in the outgoing SDP.</p> <ul style="list-style-type: none"> <li>■ [0] = Disable (default)</li> <li>■ [1] = Enable</li> </ul> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
[OPTIONSUserPart]	<p>Defines the user part value of the Request-URI for outgoing SIP OPTIONS requests. If no value is configured, configuration parameter 'Username' value is used.</p> <p>A special value is 'empty', indicating that no user part in the Request-URI (host part only) is used.</p> <p>The valid range is a 30-character string. By default, this value is not defined.</p>
<p>'Trunk Status Reporting Mode'</p> <pre>configure voip &gt; gateway digital settings &gt; trunk-status- reporting</pre> <p>[TrunkStatusReporting Mode]</p>	<p>Enables the device to not respond to received SIP OPTIONS messages from, and/or not to send keep-alive messages to, a proxy server associated with Trunk Group ID 1 if all its member trunks are down.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) Device responds to SIP OPTIONS messages from, and sends keep-alive messages to, a proxy server associated with Trunk Group ID 1 if all its member trunks are down.</li> <li>■ [1] <b>Don't reply OPTIONS</b> = The device doesn't respond to SIP OPTIONS received from the proxy associated with Trunk Group 1 when all its trunks are down.</li> <li>■ [2] <b>Don't send Keep-Alive</b> = The device doesn't send keep-alive messages to the proxy associated with Trunk Group 1 when all its trunks are down.</li> <li>■ [3] <b>Don't Reply and Send</b> = Both options [1] and [2] are applied.</li> </ul> <p><b>Note:</b></p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ The parameter is applicable only to digital interfaces.</li> <li>■ When the parameter is set to not respond to SIP OPTIONS received from the proxy, it is applicable only if the OPTIONS message doesn't include a user part in the Request-URI.</li> <li>■ The proxy server is determined by the Proxy Set that is associated with the Serving IP Group of the Trunk Group in the Trunk Group Settings table.</li> </ul>
'TDM Over IP Minimum Calls For Trunk Activation' [TDMOverIPMinCallsForTrunkActivation]	<p>Defines the minimal number of SIP dialogs that must be established when using TDM Tunneling, for the specific trunk to be considered active.</p> <p>When using TDM Tunneling, if calls from this defined number of B-channels pertaining to a specific Trunk fail (i.e., SIP dialogs are not correctly set up), an AIS alarm is sent on this trunk toward the PSTN and all current calls are dropped. The originator gateway continues the INVITE attempts. When this number of calls succeed (i.e., SIP dialogs are correctly set up), the AIS alarm is cleared.</p> <p>The valid range is 0 to 31. The default is 0 (i.e., don't send AIS alarms).</p> <p><b>Note:</b> TDM Tunneling is applicable only to E1/T1 interfaces.</p>
[TDMoIPInitiateInviteTime]	<p>Defines the time (in msec) between the first INVITE issued within the same trunk when implementing the TDM tunneling application.</p> <p>The valid value range is 500to 1,000. The default is 500.</p> <p><b>Note:</b> TDM Tunneling is applicable only to E1/T1 interfaces.</p>
[TDMoIPInviteRetryTime]	<p>Defines the time (in msec) between call release and a new INVITE when implementing the TDM tunneling application.</p> <p>The valid value range is 10,000to 20,000. The default is 10,000.</p> <p><b>Note:</b> TDM Tunneling is applicable only to E1/T1 interfaces.</p>
'Fax Signaling Method' fax-sig-method [IsFaxUsed]	<p>Global parameter defining the SIP signaling method for establishing and transmitting a fax session when the device detects a fax.</p> <p>You can also configure this feature per specific calls, using IP Profiles ('Fax Signaling Method' parameter) and Tel Profiles ('Fax Signaling Method' parameter). For a detailed description of the parameter, see <a href="#">Configuring IP Profiles</a> on page 664 and <a href="#">Configuring Tel Profile</a> on page 738.</p>

Parameter	Description
	<p><b>Note:</b> If you configure this feature for a specific IP Profile or Tel Profile, the device ignores this global parameter for calls associated with the IP Profile or Tel Profile.</p>
fax-vbd-behvr [FaxVBDBehavior]	<p>Determines the device's fax transport behavior when G.711 VBD coder is negotiated at call start.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) If the device is configured with a VBD coder (see the [CodersGroup] parameter) and is negotiated OK at call start, then both fax and modem signals are sent over RTP using the bypass payload type (and no mid-call VBD or T.38 Re-INVITES occur).</li> <li>■ [1] = If the [IsFaxUsed] parameter is set to 1, the channel opens with the [FaxTransportMode] parameter set to 1 (relay). This is required to detect mid-call fax tones and to send T.38 Re-INVITE messages upon fax detection. If the remote party supports T.38, the fax is relayed over T.38.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If VBD coder negotiation fails at call start and if the [IsFaxUsed] parameter is set to 1 (or 3), then the channel opens with the [FaxTransportMode] parameter set to 1 (relay) to allow future detection of fax tones and sending of T.38 Re-INVITES. In such a scenario, the [FaxVBDBehavior] parameter has no effect.</li> <li>■ This feature can be used only if the remote party supports T.38 fax relay; otherwise, the fax fails.</li> </ul>
[NoAudioPayloadType]	<p>Defines the payload type of the outgoing SDP offer.</p> <p>The valid value range is 96 to 127 (dynamic payload type). The default is 0 (i.e. NoAudio is not supported). For example, if set to 120, the following is added to the INVITE SDP:</p> <pre>a=rtpmap:120 NoAudio/8000\r\n</pre> <p><b>Note:</b> For incoming SDP offers, NoAudio is always supported.</p>
'SIP Transport Type' configure voip > sip-definition settings > app- sip-transport- type [SIPTransportType]	<p>Determines the default transport layer for outgoing SIP calls initiated by the device.</p> <ul style="list-style-type: none"> <li>■ [0] UDP (default)</li> <li>■ [1] TCP</li> <li>■ [2] TLS (SIPS)</li> </ul> <p><b>Note:</b></p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ It's recommended to use TLS for communication with a SIP Proxy and not for direct device-to-device communication.</li> <li>■ For received calls (i.e., incoming), the device accepts all these protocols.</li> </ul>
'Display Default SIP Port' <pre>configure voip &gt; sip-definition settings &gt; display-default- sip-port</pre> [DisplayDefaultSIPPort]	<p>Enables the device to add the default SIP port 5060 (UDP/TCP) or 5061 (TLS) to outgoing messages that are received without a port. This condition also applies to manipulated messages where the resulting message has no port number. The device adds the default port number to the following SIP headers: Request-Uri, To, From, P-Asserted-Identity, P-Preferred-Identity, and P-Called-Party-ID. If the message is received with a port number other than the default, for example, 5070, the port number is not changed.</p> <p>An example of a SIP From header with the default port is shown below:</p> <p>From:            &lt;sip:+4000@10.8.4.105:5060            ;user=phone&gt;;tag=f25419a96a;epid=009FAB8F3E</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul>
'SIPS' <pre>configure voip &gt; sip-definition settings &gt; enable-sips</pre> [EnableSIPS]	<p>Enables secured SIP (SIPS URI) connections over multiple hops.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>When the [SIPTransportType] parameter is set to 2 (i.e., TLS) and the parameter [EnableSIPS] is disabled, TLS is used for the next network hop only. When the [SIPTransportType] parameter is set to 2 or 1 (i.e., TCP or TLS) and [EnableSIPS] is enabled, TLS is used through the entire connection (over multiple hops).</p> <p><b>Note:</b> If the parameter is enabled and the [SIPTransportType] parameter is set to 0 (i.e., UDP), the connection fails.</p>
'TCP/TLS Connection Reuse' <pre>tcp-conn-reuse</pre> [EnableTCPConnection Reuse]	<p>Enables the device to use the same established TCP or TLS connection with the SIP user agent (UA) for subsequent SIP requests sent to the UA. For all new out-of-dialog requests (e.g., INVITE or REGISTER) the device uses this same secured connection. A benefit of this feature is that it may improve performance, by eliminating the need for performing additional TCP/TLS handshakes with the UA, allowing sessions to be</p>

Parameter	Description
	<p>established rapidly. If disabled, the device uses a new TCP or TLS connection with the UA for all subsequent SIP requests.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = (Default) Enabled.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For SIP responses, the device always uses the same TCP/TLS connection, regardless of the parameter's settings.</li> </ul>
<p>'Fake TCP Alias'</p> <pre>configure voip &gt; sip-definition settings &gt; fake- tcp-alias</pre> <p>[FakeTCPAlias]</p>	<p>Enables the device to use the same TCP/TLS connection for sessions with the same SIP UA even if the 'alias' parameter is not present in the SIP Via header of the SIP dialog-initiating INVITE request.</p> <p>If disabled, the device uses the same TCP/TLS connection <b>only</b> if the 'alias' parameter is present (per RFC 5923).</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p><b>Note:</b> To enable TCP/TLS connection reuse, see the <a href="#">[EnableTCPConnectionReuse]</a> parameter.</p>
<p>'Reliable Connection Persistent Mode'</p> <pre>configure voip &gt; sip-definition settings &gt; reliable-conn- persistent</pre> <p>[ReliableConnectionPersistentMode]</p>	<p>Enables all reusable TCP/TLS (reliable) connections to be persistent (i.e., not released).</p> <p>When sending a SIP message, the device's reliable connection reuse policy determines if current connections to the specific destination are reused.</p> <p>Persistent connections ensure less network traffic due to fewer setting up and tearing down of reliable connections and reduced latency on subsequent requests because there is no need for initial TCP handshakes. Persistent connections may reduce the number of costly TLS handshakes to establish security associations, in addition to the initial TCP connection setup.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. The device releases all reliable connections that aren't being used. However, if the destination is a Proxy server (configured in the Proxy Sets table), the reliable connection is always persistent, regardless of the parameter's settings.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled. The device makes reusable reliable connections to all destinations persistent and doesn't release them (see note below). A persistent</li> </ul>

Parameter	Description
	<p>connection stays open even when it's no longer in use (i.e., not used by any SIP dialog or transaction, and isn't associated with a registered user).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The device releases unnecessary persistent TLS connections to prevent them from accumulating and reaching the device's maximum number of supported TLS connections (refer to the document <a href="#">Release Notes</a>). If the number of incoming TLS connections exceeds 80% of the maximum, the device closes incoming TLS connections that aren't in use (i.e., no active SIP dialogs and not associated with a registered user) and that are kept open only because they are persistent.</li> <li>■ Similar to the above note, the device releases reliable (TCP/TLS) connections that aren't in use and are kept open only because they are persistent, when reaching 80% of the maximum number of supported reliable connections.</li> <li>■ The device sends the SNMP alarm acTLSSocketsLimitAlarm when the number of incoming TLS connections exceeds 95% of the maximum TLS connections supported by the device.</li> <li>■ Connection reuse depends on the [EnableTCPConnectionReuse] parameter; for incoming connections, reuse also depends on SIP message characteristics (presence of Via header's 'alias' parameter in initial request).</li> </ul>
<p>'TCP Timeout'</p> <pre>configure voip &gt; sip-definition settings &gt; tcp- timeout [SIPTCPTimeout]</pre>	<p>Defines the Timer B (INVITE transaction timeout timer) and Timer F (non-INVITE transaction timeout timer), as defined in RFC 3261, when the SIP transport type is TCP.</p> <p>The valid range is 0 to 60 sec. The default is 0, which means that the parameter's value is set to 64 multiplied by the value of the [SipT1Rtx] parameter. For example, if you configure [SipT1Rtx] to 500 msec (0.5 sec) and leave the [SIPTCPTimeout] parameter at its default value (0), the actual value of [SIPTCPTimeout] is 32 sec (64 x 0.5 sec).</p>
[ReliableConnectionFailureRetries]	<p>Defines the number of retry attempts that the device makes when attempting to reconnect to a server (Proxy Set) after a TCP/TLS connection failure.</p> <p>The valid range is 1 to 20. The default port is 5.</p>

Parameter	Description
'SIP Destination Port' <pre>configure voip &gt; sip-definition settings &gt; sip- dst-port</pre> [SIPDestinationPort]	Defines the SIP destination port for sending initial SIP requests. The valid range is 1 to 65534. The default port is 5060. <b>Note:</b> SIP responses are sent to the port specified in the Via header.
'Use user=phone in SIP URL' <pre>configure voip &gt; sip-definition settings &gt; user- phone-in-url</pre> [IsUserPhone]	Defines if the 'user=phone' string is added to the SIP URI and SIP To header. <ul style="list-style-type: none"> <li>■ [0] No</li> <li>■ [1] Yes (default)</li> </ul> <b>Note:</b> The parameter is applicable only to the Gateway application.
'Use user=phone in From Header' <pre>configure voip &gt; sip-definition settings &gt; user- phone-in-from</pre> [IsUserPhoneInFrom]	Defines if the 'user=phone' string is added to the From and Contact SIP headers. <ul style="list-style-type: none"> <li>■ [0] No (default)</li> <li>■ [1] Yes</li> </ul> <b>Note:</b> The parameter is applicable only to the Gateway application.
'Use Tel URI for Asserted Identity' <pre>configure voip &gt; sip-definition settings &gt; uri- for-assert-id</pre> [UseTelURIForAssertedID]	Defines the format of the URI in the SIP P-Asserted-Identity and P-Preferred-Identity headers. <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. The format is 'sip:'.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled. The format is 'tel:'.</li> </ul>
<pre>configure voip &gt; sip-definition settings &gt; p- preferred-id- list</pre> [PPreferredIdListMode]	Defines the number of P-Preferred-Identity SIP headers included in the outgoing SIP message when the header contains multiple values. <ul style="list-style-type: none"> <li>■ [0] = (Default) The device includes multiple P-Preferred-Identity SIP headers in the outgoing message, for example:               <ul style="list-style-type: none"> <li>✓ Incoming message containing a P-Preferred-Identity header with multiple values:</li> </ul> </li> </ul>

Parameter	Description
	<p>P-Preferred-Identity: &lt;sip:someone@test.org&gt;,&lt;tel:+123456789&gt;</p> <p>✓ Outgoing message sent with multiple P-Preferred-Identity headers, each with a value:</p> <p>P-Preferred-Identity: &lt;sip:someone@test.org&gt; P-Preferred-Identity: &lt;tel:+123456789&gt;</p> <p>■ [1] = The device includes only one P-Preferred-Identity header in the outgoing message, for example:</p> <p>✓ Incoming message containing multiple P-Preferred-Identity headers:</p> <p>P-Preferred-Identity: &lt;sip:someone@test.org&gt; P-Preferred-Identity: &lt;tel:+123456789&gt;</p> <p>✓ Outgoing message sent with a single P-Preferred-Identity header containing the multiple values:</p> <p>P-Preferred-Identity: &lt;sip:someone@test.org&gt;,&lt;tel:+123456789&gt;</p> <p><b>Note:</b></p> <p>■ If more than two P-Preferred-Identity headers are received in the incoming message, the device keeps the first two headers (if configured to 0) or the first header (if configured to 1), and removes the others in the outgoing message.</p> <p>■ The parameter is applicable only to the SBC application.</p>
<p>'Tel to IP No Answer Timeout'</p> <pre>configure voip &gt; gateway advanced &gt; tel2ip-no-ans- timeout [IPAlertTimeout]</pre>	<p>Defines the time (in seconds) that the device waits for a 200 OK response from the called party (IP side) after sending an INVITE message, for Tel-to-IP calls. If the timer expires, the call is released.</p> <p>The valid range is 0 to 3600. The default is 180.</p>



Parameter	Description								
<b>'Remote Party ID'</b> configure voip > sip-definition settings > remote-party-id [EnableRPIheader]	<p>Enables the device to include the SIP Remote-Party-Identity header in SIP INVITE messages for both called and calling numbers in Tel-to-IP calls.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul>								
<b>'History-Info Header'</b> configure voip > sip-definition settings > hist- info-hdr [EnableHistoryInfo]	<p>Enables the use of the SIP History-Info header.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>User Agent Client (UAC) Behavior:</p> <ul style="list-style-type: none"> <li>■ Initial request: The History-Info header is equal to the Request-URI. If a PSTN Redirect number is received, it is added as an additional History-Info header with an appropriate reason.</li> <li>■ Upon receiving the final failure response, the device copies the History-Info as is, adds the reason of the failure response to the last entry, and concatenates a new destination to it (if an additional request is sent). The order of the reasons is as follows:               <ol style="list-style-type: none"> <li>a. Q.850 Reason</li> <li>b. SIP Reason</li> <li>c. SIP Response code</li> </ol> </li> <li>■ Upon receiving the final response (success or failure), the device searches for a Redirect reason in the History-Info (i.e., 3xx/4xx SIP reason). If found, it is passed to ISDN according to the following table:</li> </ul> <table border="1"> <thead> <tr> <th>SIP Reason Code</th><th>ISDN Redirecting Reason</th></tr> </thead> <tbody> <tr> <td>302 - Moved Temporarily</td><td>Call Forward Universal (CFU)</td></tr> <tr> <td>408 - Request Timeout</td><td>Call Forward No Answer (CFNA)</td></tr> <tr> <td>480 - Temporarily Unavailable</td><td></td></tr> </tbody> </table>	SIP Reason Code	ISDN Redirecting Reason	302 - Moved Temporarily	Call Forward Universal (CFU)	408 - Request Timeout	Call Forward No Answer (CFNA)	480 - Temporarily Unavailable	
SIP Reason Code	ISDN Redirecting Reason								
302 - Moved Temporarily	Call Forward Universal (CFU)								
408 - Request Timeout	Call Forward No Answer (CFNA)								
480 - Temporarily Unavailable									

Parameter	Description				
	<table border="1"> <tr> <td>487 - Request Terminated</td><td rowspan="3">Call Forward Busy (CFB)</td></tr> <tr> <td>486 - Busy Here</td></tr> <tr> <td>600 - Busy Everywhere</td></tr> </table> <ul style="list-style-type: none"> <li>■ If history reason is a Q.850 reason, it is translated to the SIP reason (according to the SIP-ISDN tables) and then to ISDN Redirect reason according to the table above.</li> </ul> <p>User Agent Server (UAS) Behavior:</p> <ul style="list-style-type: none"> <li>■ The History-Info header is sent only in the final response.</li> <li>■ Upon receiving a request with History-Info, the UAS checks the policy in the request. If a 'session', 'header', or 'history' policy tag is found, the (final) response is sent without History-Info; otherwise, it is copied from the request.</li> </ul> <p><b>Note:</b> The parameter is applicable only to digital interfaces.</p>	487 - Request Terminated	Call Forward Busy (CFB)	486 - Busy Here	600 - Busy Everywhere
487 - Request Terminated	Call Forward Busy (CFB)				
486 - Busy Here					
600 - Busy Everywhere					
'Use SIP tgrp Information' <pre>configure voip &gt; sip-definition settings &gt; use- tgrp-inf [UseSIPtgrp]</pre>	<p>Enables the device to add the SIP 'tgrp' parameter to outgoing SIP message requests. This parameter specifies the Trunk Group to which the call belongs (according to RFC 4904). For example, the INVITE message below indicates that the call belongs to Trunk Group ID 1:</p> <pre>INVITE sip::+16305550100;tgrp=1;trunk- context=example.com@10.1.0.3;user=phone SIP/2.0</pre> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) The device doesn't use (and add) the 'tgrp' parameter.</li> <li>■ [1] <b>Send Only</b> = The device adds the Trunk Group number or name (configured in the Trunk Group Settings table) as the 'tgrp' parameter value in the Contact header of outgoing INVITE messages. If a Trunk Group number or name is not associated with the call, the device doesn't add the 'tgrp' parameter. If a 'tgrp' value is present in incoming messages, the device ignores it.</li> <li>■ [2] <b>Send &amp; Receive</b> = The functionality of outgoing SIP messages is identical to the functionality described for option <b>Send Only</b>. In addition, for incoming SIP INVITES (IP-to-Tel), if the Request-URI includes the 'tgrp' parameter, the device routes the call according to that value (if possible). In</li> </ul>				

Parameter	Description
	<p>the outgoing SIP INVITE (Tel-to-IP call), the device adds "tgrp=&lt;source trunk group ID&gt;;trunk-context=&lt;gateway IP address&gt;" to the Contact header. The &lt;source trunk group ID&gt; is the Trunk Group ID where incoming calls from Tel is received. For IP-to-Tel calls, the SIP 200 OK device's response contains "tgrp=&lt;destination trunk group ID&gt;;trunk-context=&lt;gateway IP address&gt;". The &lt;destination trunk group ID&gt; is the Trunk Group ID used for outgoing Tel calls. You can configure the &lt;gateway IP address&gt; in "trunk-context", using the [SIPGatewayName] parameter.</p> <p>■ [3] <b>Hotline</b> = Interworks the hotline "Off Hook Indicator" parameter between SIP and ISDN. This option is applicable only to digital interfaces.</p> <p>✓ IP-to-ISDN calls:</p> <ul style="list-style-type: none"> <li>• The device interworks the SIP 'tgrp=hotline' parameter (received in INVITE) to ISDN Setup with the Off Hook Indicator IE of "Voice", and "Speech" Bearer Capability IE. Note that the Off Hook Indicator IE is described in UCR 2008 specifications.</li> <li>• The device interworks the SIP 'tgrp=hotline-ccdata' parameter (received in INVITE) to ISDN Setup with an Off Hook Indicator IE of "Data", and with "Unrestricted 64k" Bearer Capability IE. The following is an example of an INVITE with 'tgrp=hotline-ccdata':</li> </ul> <pre>INVITE sip:1234567;tgrp=hotline-ccdata;trunk-context=dsn.mil@example.com</pre> <p>✓ ISDN-to-IP calls:</p> <ul style="list-style-type: none"> <li>• The device interworks ISDN Setup with an Off Hook Indicator of "Voice" to SIP INVITE with 'tgrp=hotline;trunk-context=dsn.mil' in the Contact header.</li> <li>• The device interworks ISDN Setup with an Off Hook indicator of "Data" to SIP INVITE with 'tgrp=hotline-ccdata;trunk-context=dsn.mil' in the Contact header.</li> <li>• If ISDN Setup doesn't contain an Off Hook Indicator IE and the Bearer Capability IE contains "Unrestricted 64k", the outgoing INVITE includes</li> </ul>

Parameter	Description
	<p>'tgrp=ccdata;trunk-context=dsn.mil'. If the Bearer Capability IE contains "Speech", the INVITE in this case doesn't contain 'tgrp' and 'trunk-context' parameters.</p> <ul style="list-style-type: none"> <li>■ [4] <b>Hotline Extended</b> = Interworks the ISDN Setup message's hotline "OffHook Indicator" Information Element (IE) to SIP INVITE's Request-URI and Contact headers. (Note: For IP-to-ISDN calls, the device handles the call as described in option <b>Hotline</b>.) This option is applicable only to digital interfaces. <ul style="list-style-type: none"> <li>✓ The device interworks ISDN Setup with an Off Hook Indicator of "Voice" to SIP INVITE Request-URI and Contact header with 'tgrp=hotline;trunk-context=dsn.mil'.</li> <li>✓ The device interworks ISDN Setup with an Off Hook indicator of "Data" to SIP INVITE Request-URI and Contact header with 'tgrp=hotline-ccdata;trunk-context=dsn.mil'.</li> <li>✓ If ISDN Setup doesn't contain an Off Hook Indicator IE and the Bearer Capability IE contains "Unrestricted 64k", the outgoing INVITE Request-URI and Contact header includes 'tgrp=ccdata;trunk-context=dsn.mil'. If the Bearer Capability IE contains "Speech", the INVITE in this case doesn't contain tgrp and trunk-context parameters.</li> </ul> </li> <li>■ [5] <b>Send Only Including Register</b> = The device adds the 'tgrp', 'trunk-context', and 'user=phone' parameters to the Contact header of outgoing SIP INVITE and REGISTER requests.</li> <li>■ [6] <b>Send &amp; Receive Including Register</b> = The device adds the 'tgrp', 'trunk-context', and 'user=phone' parameters to the Contact header of outgoing SIP INVITE and REGISTER requests. In addition, the device uses these parameters if they are present in the Request-URI of incoming INVITE requests.</li> </ul> <p><b>Note:</b> IP-to-Tel configuration (see <a href="#">Configuring IP-to-Tel Routing Rules</a> on page 928) overrides the 'tgrp' parameter in incoming INVITE messages.</p>
configure voip > gateway routing	Defines the precedence method for IP-to-Tel call routing - according to the IP-to-Tel Routing table or the SIP 'tgrp'

Parameter	Description
<pre>settings &gt; tgrp- routing-prec</pre> <p>[TGRProutingPrecedence]</p>	<p>parameter.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) IP-to-Tel routing is determined by the IP-to-Tel Routing table (see <a href="#">Configuring IP-to-Tel Routing Rules</a> on page 928). If a matching routing rule is not found, the device uses the Trunk Group parameters for routing the call.</li> <li>■ [1] = The device first places precedence on the 'tgrp' parameter for IP-to-Tel routing. If the received Request-URI in the INVITE message doesn't contain the 'tgrp' parameter, or if the Trunk Group number is not defined, the device uses the IP-to-Tel Routing table to route the call.</li> </ul> <p>The following example shows an INVITE Request-URI with the 'tgrp' parameter, indicating that the IP call should be routed to Trunk Group 7:</p> <pre>INVITE sip:200;tgrp=7;trunk- context=example.com@10.33.2.68;user=phone SIP/2.0</pre> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ To enable routing based on the SIP 'tgrp' parameter, see the [UseSIPTrgp] parameter.</li> <li>■ Instead of the 'tgrp' parameter for IP-to-Tel routing, you can use the SIP 'dtg' parameter (see the [UseBroadsoftDTG] parameter).</li> </ul>
<pre>configure voip &gt; sip-definition settings &gt; use- dtg</pre> <p>[UseBroadsoftDTG]</p>	<p>Defines if the device uses the SIP 'dtg' parameter for routing IP-to-Tel calls to a specific Trunk Group.</p> <ul style="list-style-type: none"> <li>■ [0] = Disable (default)</li> <li>■ [1] = Enable</li> </ul> <p>When enabled, if the Request-URI in the received SIP INVITE includes the 'dtg' parameter, the device routes the call to the Trunk Group according to its value. The parameter is used instead of the 'tgrp' and 'trunk-context' parameters. The 'dtg' parameter appears in the INVITE Request-URI (and in the To header). For example, the following received SIP message routes the call to Trunk Group ID 56:</p> <pre>INVITE sip:123456@192.168.1.2;dtg=56;user=phone SIP/2.0</pre> <p><b>Note:</b> If the Trunk Group is not found based on the 'dtg' parameter, the device uses the IP-to-Tel Routing table to route</p>

Parameter	Description
	the call to the appropriate Trunk Group.
'GRUU' configure voip > sbc settings > gruu [EnableGRUU]	<p>Enables the use of the Globally Routable User Agent URIs (GRUU) mechanism (according to RFC 5627). This is used for obtaining a GRUU from a registrar and for communicating a GRUU to a peer within a dialog.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>A GRUU is a SIP URI that routes to an instance-specific UA and can be reachable from anywhere. There are a number of contexts in which it is desirable to have an identifier that addresses a single UA (using GRUU) rather than the group of UA's indicated by an Address of Record (AOR). For example, in call transfer where user A is talking to user B, and user A wants to transfer the call to user C. User A sends a REFER to user C:</p> <pre>REFER sip:C@domain.com SIP/2.0 From: sip:A@domain.com;tag=99asd To: sip:C@domain.com Refer-To: (URI that identifies B's UA)</pre> <p>The Refer-To header needs to contain a URI that user C can use to place a call to user B. This call needs to route to the specific UA instance that user B is using to talk to user A. User B should provide user A with a URI that has to be usable by anyone. It needs to be a GRUU.</p> <ul style="list-style-type: none"> <li>■ Obtaining a GRUU: The mechanism for obtaining a GRUU is through registrations. A UA can obtain a GRUU by generating a REGISTER request containing a Supported header field with the value "gruu". The UA includes a "+sip.instance" Contact header parameter of each contact for which the GRUU is desired. This Contact parameter contains a globally unique ID that identifies the UA instance. The global unique ID is created from one of the following:               <ul style="list-style-type: none"> <li>✓ If the REGISTER is per the device's client (endpoint), it is the MAC address concatenated with the phone number of the client.</li> <li>✓ If the REGISTER is per device, it is the MAC address only.</li> <li>✓ When using TP, "User Info" can be used for registering per endpoint. Thus, each endpoint can get a unique id – its phone number. The globally unique ID in TP is the</li> </ul> </li> </ul>

Parameter	Description
	<p>MAC address concatenated with the phone number of the endpoint.</p> <p>If the remote server doesn't support GRUU, it ignores the parameters of the GRUU. Otherwise, if the remote side also supports GRUU, the REGISTER responses contain the "gruu" parameter in each Contact header. The parameter contains a SIP or SIPS URI that represents a GRUU corresponding to the UA instance that registered the contact. The server provides the same GRUU for the same AOR and instance-id when sending REGISTER again after registration expiration. RFC 5627 specifies that the remote target is a GRUU target if its' Contact URL has the "gr" parameter with or without a value.</p> <ul style="list-style-type: none"> <li>■ Using GRUU: The UA can place the GRUU in any header field that can contain a URI. It must use the GRUU in the following messages: INVITE request, its 2xx response, SUBSCRIBE request, its 2xx response, NOTIFY request, REFER request and its 2xx response.</li> </ul>
[IsCiscoSCEMode]	<p>Determines whether a Cisco gateway exists at the remote side.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) No Cisco gateway exists at the remote side.</li> <li>■ [1] = A Cisco gateway exists at the remote side.</li> </ul> <p>When a Cisco gateway exists at the remote side, the device must set the value of the 'annexb' parameter of the fmtp attribute in the SDP to 'no'. This logic is used if the coder is enabled for Silenced Suppression. In this case, Silence Suppression is used on the channel but not declared in the SDP.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Gateway application.</li> <li>■ The [IsCiscoSCEMode] parameter is applicable only when the selected coder is G.729.</li> </ul>
'User-Agent Information' configure voip > sip-definition settings > user- agent-info [UserAgentDisplayInfo]	<p>Defines the string that is used in the SIP User-Agent and Server response headers. When configured, the string &lt;UserAgentDisplayInfo value&gt;/software version' is used, for example:</p> <p>User-Agent: myproduct/7.60A.100.022</p> <p>If not configured, the default string, "&lt;product-name&gt;/&lt;software version&gt;" is used, for example:</p> <p>User-Agent: AudioCodes-Sip-Gateway/&lt;swver&gt;</p>

Parameter	Description
	<p>The maximum string length is 50 characters.</p> <p><b>Note:</b> The software version number and preceding forward slash (/) cannot be modified. Therefore, it is recommended not to include a forward slash in the parameter's value (to avoid two forward slashes in the SIP header, which may cause problems).</p>
<p>'SDP Session Owner'</p> <pre>configure voip &gt; sip-definition settings &gt; sdp- session-owner</pre> <p>[SIPSDPSessionOwner]</p>	<p>Defines the value of the Owner line ('o' field) in outgoing SDP messages.</p> <p>The valid range is a string of up to 39 characters. The default is "AudioCodesGW".</p> <p>For example:</p> <pre>o=AudioCodesGW 1145023829 1145023705 IN IP4 10.33.4.126</pre> <p><b>Note:</b> The parameter is applicable only to the SBC application when the device creates a new SIP message (and SDP) such as when the device plays a ringback tone. The parameter is not applicable to SIP messages that the device receives from one end and sends to another (i.e., doesn't modify the SDP's 'o' field).</p>
<pre>configure voip &gt; sip-definition settings &gt; sdp- ver-nego</pre> <p>[EnableSDPVersionNegotiation]</p>	<p>Enables the device to ignore new SDP re-offers (from the media negotiation perspective) in certain scenarios (such as session expires). According to RFC 3264, once an SDP session is established, a new SDP offer is considered a new offer only when the SDP origin value is incremented. In scenarios such as session expires, SDP negotiation is irrelevant and thus, the origin field is not changed.</p> <p>Even though some SIP devices don't follow this behavior and don't increment the origin value even in scenarios where they want to re-negotiate, the device can assume that the remote party operates according to RFC 3264, and in cases where the origin field is not incremented, the device doesn't re-negotiate SDP capabilities.</p> <ul style="list-style-type: none"> <li>■ [0] Disable = (Default) The device negotiates any new SDP re-offer, regardless of the origin field.</li> <li>■ [1] Enable = The device negotiates only an SDP re-offer with an incremented origin field.</li> </ul>
<pre>configure voip &gt; gateway advanced &gt; use- conn-sdp-ses-or-</pre>	<p>Defines how the device displays the Connection ("c=") line in the SDP Offer/Answer model.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) The Connection ("c=") line is displayed as</li> </ul>



Parameter	Description
media [GwSDPConnectionMode]	<p>follows:</p> <ul style="list-style-type: none"> <li>✓ Offer: In the session description only.</li> <li>✓ Answer: In the session description and in each media ("m=") description.</li> <li>■ [1] = For Offer and Answer, the Connection ("c=") line is displayed only in the session description; not in any media ("m=") descriptions.</li> <li>■ [2] = The Connection ("c=") line is displayed only in media ("m=") descriptions.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
'Subject' configure voip > sip-definition settings > usr- def-subject [SIPSubject]	<p>Defines the Subject header value in outgoing INVITE messages. If not specified, the Subject header isn't included (default). The maximum length is up to 50 characters.</p>
configure voip > sip-definition settings > coder-priority- nego [CoderPriorityNegotiation]	<p>Defines the priority for coder negotiation in the incoming SDP offer, between the device's or remote UA's coder list.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Coder negotiation is given higher priority to the remote UA's list of supported coders.</li> <li>■ [1] = Coder negotiation is given higher priority to the device's (local) supported coders list.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
'Send All Coders on Retrieve' configure voip > gateway dtmf- supp-service supp-service- settings > send- all-cdrs-on-rtrv [SendAllCodersOnRetrieve]	<p>Enables coder re-negotiation in the sent re-INVITE for retrieving an on-hold call.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) Sends only the initially chosen coder when the call was first established and then put on-hold.</li> <li>■ [1] <b>Enable</b> = Includes all supported coders in the SDP of the re-INVITE sent to the call made un-hold (retrieved). The used coder is therefore, re-negotiated.</li> </ul> <p>The parameter is useful in the following call scenario example:</p> <ol style="list-style-type: none"> <li>1. Party A calls party B and coder G.711 is chosen.</li> </ol>

Parameter	Description
	<ol style="list-style-type: none"> <li>Party B is put on-hold while Party A blind transfers Party B to Party C.</li> <li>Party C answers and Party B is made un-hold. However, as Party C supports only G.729 coder, re-negotiation of the supported coder is required.</li> </ol> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
<p>'Multiple Packetization Time Format'</p> <pre>configure voip &gt; sip-definition settings &gt; mult- ptime-format</pre> <p>[MultiPtimeFormat]</p>	<p>Determines whether the 'mptime' attribute is included in the outgoing SDP.</p> <ul style="list-style-type: none"> <li>[0] <b>None</b> = (Default) Disabled.</li> <li>[1] <b>PacketCable</b> = Includes the 'mptime' attribute in the outgoing SDP - PacketCable-defined format.</li> </ul> <p>The mptime' attribute enables the device to define a separate packetization period for each negotiated coder in the SDP. The 'mptime' attribute is only included if the parameter is enabled even if the remote side includes it in the SDP offer. Upon receipt, each coder receives its 'ptime' value in the following precedence: from 'mptime' attribute, from 'ptime' attribute, and then from default value.</p> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
<pre>configure voip &gt; sip-definition settings &gt; enable-ptime</pre> <p>[EnablePtime]</p>	<p>Defines if the 'ptime' attribute is included in the SDP.</p> <ul style="list-style-type: none"> <li>[0] = Remove the 'ptime' attribute from SDP.</li> <li>[1] = (Default) Include the 'ptime' attribute in SDP.</li> </ul>
<p>'3xx Behavior'</p> <pre>3xx-behavior</pre> <p>[3xxBehavior]</p>	<p>Determines the device's behavior regarding call identifiers when a 3xx response is received for an outgoing INVITE request. The device can use the same call identifiers (Call-ID, To, and From tags) or change them in the new initiated INVITE.</p> <ul style="list-style-type: none"> <li>[0] <b>Forward</b> = (Default) Use different call identifiers for a redirected INVITE message.</li> <li>[1] <b>Redirect</b> = Use the same call identifiers in the new INVITE as the original call.</li> </ul>
<p>'P-Charging Vector'</p> <pre>p-charging-</pre>	<p>Enables the device to include the SIP P-Charging-Vector header in outgoing INVITE messages.</p>

Parameter	Description
vector [EnablePChargingVector]	<ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
configure voip > sip-definition settings > retry-after- mode [RetryAfterMode]	<p>Defines the device's behavior when it receives a SIP 503 (Service Unavailable) containing a Retry-After header, in response to a SIP message (e.g., REGISTER) sent to a proxy server.</p> <p>In certain scenarios (depending on the value of this parameter), the device considers the proxy as offline (down) for the number of seconds specified in the Retry-After header. During this timeout, the device doesn't send any SIP messages to the proxy. This condition is indicated in the syslog message as "server is now Unavailable - setting Retry-After timer to x secs".</p> <ul style="list-style-type: none"> <li>■ [1] = (Default) Handle Locally. The device considers the proxy as offline regardless of the type of SIP message sent to the proxy for which the 503 response was received.</li> <li>■ [0] = Transparent. The behavior depends on the type of SIP message sent to the proxy for which the 503 response was received:               <ul style="list-style-type: none"> <li>✓ SIP OPTIONS message: The device considers the proxy as offline.</li> <li>✓ SIP REGISTER message generated (created) by the device: The device doesn't send REGISTER messages to the proxy for this <b>specific</b> registration process (i.e., Accounts table or SBC User Information table) during the timeout specified in the Retry-After header of the 503 response. However, the device considers the proxy as online and therefore, it continues sending traffic of other entities to the proxy.</li> <li>✓ All other SIP dialogs (e.g., INVITE): The device ignores the Retry-After header and forwards the 503 response transparently to the other user agent.</li> </ul> </li> </ul>
'Retry-After Time' configure voip > sip-definition settings > retry-afttr-time	<p>Defines the time (in seconds) used in the Retry-After header when a 503 (Service Unavailable) response is generated by the device.</p> <p>The time range is 0 to 3,600. The default is 0.</p>

Parameter	Description
<p>[RetryAfterTime]</p> <p>'Fake Retry After' fake-retry-after</p> <p>[FakeRetryAfter]</p>	<p>Defines if the device, upon receiving a SIP 503 response without a Retry-After header, behaves as if the 503 response included a Retry-After header and with the period (in seconds) specified by the parameter.</p> <ul style="list-style-type: none"> <li>■ [0] Disable (default)</li> <li>■ Any positive value (in seconds) for defining the period</li> </ul> <p>When enabled, this feature allows the device to operate with Proxy servers that do not include the Retry-After SIP header in SIP 503 (Service Unavailable) responses to indicate an unavailable service.</p> <p>The Retry-After header is used with the 503 (Service Unavailable) response to indicate how long the service is expected to be unavailable to the requesting SIP client. The device maintains a list of available proxies, by using the Keep-Alive mechanism. The device checks the availability of proxies by sending SIP OPTIONS every keep-alive timeout to all proxies. If the device receives a SIP 503 response to an INVITE, it also marks that the proxy is out of service for the defined "Retry-After" period.</p>
<p>'P-Associated-URI Header' p-associated-uri-hdr</p> <p>[EnablePAssociatedURI Header]</p>	<p>Defines the device usage of the SIP P-Associated-URI header. This header can be received in 200 OK responses to REGISTER requests. When enabled, the first URI in the P-Associated-URI header is used in subsequent requests as the From/P-Asserted-Identity headers value.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p><b>Note:</b> P-Associated-URIs in registration responses is handled only if the device is registered per endpoint (using the User Information file).</p>
<p>configure voip &gt; gateway digital settings &gt; format-dst- phone-number</p> <p>[FormatDestPhoneNumber]</p>	<p>Defines if the destination phone number that the device sends to the Tel side (for IP-to-Tel calls), includes the user-part parameters (e.g., 'password' and 'phone-context') of the destination URI received in the incoming SIP INVITE message.</p> <ul style="list-style-type: none"> <li>■ [0] = (Transparent) The device includes the user-part parameters (if exist) in the destination phone number sent to the Tel side.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [1] = (Default) The device excludes the user-part parameters and letters (if exist) from the destination phone number sent to the Tel side.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
<p>'Source Number Preference'</p> <pre>configure voip &gt; sip-definition settings &gt; src- nb-preference [SourceNumberPreference]</pre>	<p>Defines the SIP header from which the source (calling) number is obtained in incoming INVITE messages.</p> <ul style="list-style-type: none"> <li>■ If not configured or if any string other than "From" or "Pai2" is configured, the calling number is obtained from a specific header using the following logic: <ul style="list-style-type: none"> <li>a. P-Preferred-Identity header.</li> <li>b. If the above header is not present, then the first P-Asserted-Identity header is used.</li> <li>c. If the above header is not present, then the Remote-Party-ID header is used.</li> <li>d. If the above header is not present, then the From header is used.</li> </ul> </li> <li>■ "From" = The calling number is obtained from the From header.</li> <li>■ "Pai2" = The calling number is obtained using the following logic: <ul style="list-style-type: none"> <li>e. If a P-Preferred-Identity header is present, the number is obtained from it.</li> <li>f. If no P-Preferred-Identity header is present and two P-Asserted-Identity headers are present, the number is obtained from the second P-Asserted-Identity header.</li> <li>g. If only one P-Asserted-Identity header is present, the calling number is obtained from it.</li> </ul> </li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The "From" and "Pai2" values are not case-sensitive.</li> <li>■ Once a URL is selected, all the calling party parameters are set from this header. If P-Asserted-Identity is selected and the Privacy header has the value 'id', the calling number is assumed restricted.</li> </ul>
'Enforce Media Order'	Enables the device to include all previously negotiated media

Parameter	Description
<pre>configure voip &gt; gateway advanced &gt; enforce-media- order [EnforceMediaOrder]</pre>	<p>lines ('m=') within the current session in the SDP offer-answer exchange (RFC 3264).</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>For example, assume a call (audio) has been established between two endpoints and one endpoint wants to subsequently send an image in the same call session. If the parameter is enabled, the endpoint includes the previously negotiated media type (i.e., audio) with the new negotiated media type (i.e., image) in its SDP offer:</p> <pre>v=0 o=bob 2890844730 2890844731 IN IP4 host.example.com s= c=IN IP4 host.example.com t=0 0 <b>m=audio</b> 0 RTP/AVP 0 m=image 12345 udpt1 t38</pre> <p>In this example, if the parameter is disabled, the only 'm=' line included in the SDP is the newly negotiated media (i.e., image).</p> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
<pre>configure voip &gt; sip-definition settings &gt; sec- call-src [SecondCallingNumber Source]</pre>	<p>Defines if the device sends a second source (calling) number, obtained from the incoming SIP INVITE message, to the Tel side.</p> <p>The valid value is "P-Asserted" (without quotation marks). By default, no value is defined.</p> <p>If the parameter is not configured to any value (i.e., default) or configured to any value other than "P-Asserted", the device doesn't send a second source number. If the parameter is configured to "P-Asserted" and the incoming INVITE message contains a P-Asserted-Identity header(s), the device sends a second source number that is obtained from the first listed P-Asserted-Identity header in the message. If the message doesn't include a P-Asserted-Identity header, the device sends a second source number that it obtains from the first source number (i.e., same number).</p> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>

Parameter	Description
<p>'Source Header For Called Number'</p> <pre>configure voip &gt; sip-definition settings &gt; src- hdr-4-called-nb</pre> <p>[SelectSourceHeaderForCalledNumber]</p>	<p>Defines the SIP header from which the called (destination) number is obtained for IP-to-Tel calls.</p> <ul style="list-style-type: none"> <li>■ [0] <b>use RequestURI header</b> = (Default) Obtains the destination number from the user part of the Request-URI.</li> <li>■ [1] <b>use To header</b> = Obtains the destination number from the user part of the To header.</li> <li>■ [2] <b>use P-Called-Party-ID header</b> = Obtains the destination number from the P-Called-Party-ID header.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
<p>'Reason Header'</p> <pre>configure voip &gt; sip-definition settings &gt; reason-header</pre> <p>[EnableReasonHeader]</p>	<p>Enables the device to include the SIP Reason header in the outgoing SIP response when a SIP request message fails.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul>
<p>'Gateway Name'</p> <pre>configure voip &gt; sip-definition settings &gt; gw- name</pre> <p>[SIPGatewayName]</p>	<p>Defines a name for the device (e.g., device123.com), which is used as the host part for the SIP URI in the From header for outgoing messages. If not configured, the device's IP address is used instead (default).</p> <p>The valid value is a string of up to 100 characters. By default, no value is defined.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Ensure that the parameter value is the one with which the proxy has been configured with to identify the device.</li> <li>■ If you enable keep-alive by SIP OPTIONS messages with the proxy (see the Proxy Set parameter 'Proxy Keep-Alive'), you can configure, using the [UseGatewayNameForOptions] parameter, if the device's IP address, the proxy's IP address, or the device's name (configured by the [SIPGatewayName] parameter) is used in the keep-alive SIP OPTIONS messages (host part of the Request-URI).</li> <li>■ The parameter can also be configured for an IP Group (in the IP Groups table).</li> </ul>
<pre>configure voip &gt; sip-definition settings &gt; zero-</pre>	<p>Defines if the device's response to an incoming SDP that includes an IP address of 0.0.0.0 in the SDP's Connection Information field (i.e., "c=IN IP4 0.0.0.0").</p>

Parameter	Description
sdp-behavior [ZeroSDPHandling]	<ul style="list-style-type: none"> <li>■ [0] = (Default) Sets the IP address of the outgoing SDP's c= field to 0.0.0.0.</li> <li>■ [1] = Sets the IP address of the outgoing SDP c= field to the IP address of the device. If the incoming SDP doesn't contain the "a=inactive" line, the returned SDP contains the "a=recvonly" line.</li> </ul>
'Delayed Offer' configure voip > sip-definition settings > delayed-offer [EnableDelayedOffer]	<p>Defines if the device sends the initial INVITE message with or without an SDP. Sending the first INVITE without SDP is typically done by clients for obtaining the far-end's full list of capabilities before sending their own offer. (An alternative method for obtaining the list of supported capabilities is by using SIP OPTIONS, which is not supported by every SIP agent.)</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. The device sends the initial INVITE message with an SDP.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled. The device sends the initial INVITE message without an SDP.</li> </ul>
configure voip > sip-definition settings > digest-auth-uri- mode [SIPDigestAuthorization URIMode]	<p>Defines if the device includes or excludes URI parameters for the Digest URI in the SIP Proxy-Authorization or Authorization headers of the request that the device sends in reply to a received SIP 401 (Unauthorized) or 407 (Proxy Authentication Required) response.</p> <p>Below shows an example of a request with an Authorization header containing a Digest URI (shown in bold):</p> <pre>Authorization: Digest username="alice at AudioCodes.com", realm="AudioCodes .com", nonce="", response="", uri="sip: <b>AudioCodes.com</b>"</pre> <ul style="list-style-type: none"> <li>■ [0] = (Default) The device sends the request without a Digest URI.</li> <li>■ [1] = The device sends the request with a Digest URI, which is set to the same value as the URI in the original Request-URI.</li> </ul>
configure voip > sip-definition settings > crypto-life- time-in-sdp [DisableCryptoLifeTime]	<p>Enables the device to send "a=crypto" lines without the lifetime parameter in the SDP. For example, if the SDP contains "a=crypto:12 AES_CM_128_HMAC_SHA1_80 inline:hhQe10yZRCrCpIFPkH5xYY9R1de37ogh9G1MpvNp 2^31", it removes the lifetime parameter "2^31".</p>



Parameter	Description
InSDP]	<ul style="list-style-type: none"> <li>■ [0] Disable (default)</li> <li>■ [1] Enable</li> </ul>
'AES-256 Encryption Key' configure voip > sip-definition settings > encrypt-key- aes256 [EncryptKeyAES256]	<p>Defines the AES-256 encryption key for encrypting (and decrypting) the SIP header value.</p> <p>The valid value is a string of 32 characters. By default, no value is defined.</p> <p>For more information, see <a href="#">Configuring SIP Header Value Encryption</a> on page 271.</p>
'Contact Restriction' contact- restriction [EnableContactRestricti on]	<p>Enables the device to set the SIP Contact header in outgoing INVITE requests to 'anonymous' for restricted calls.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul>
configure voip > sip-definition settings > anonymous-mode [AnonymousMode]	<p>Defines if the device's IP address is used as the URI host part instead of "anonymous.invalid" in the INVITE's From header for Tel-to-IP calls.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) If the device receives a call from the Tel with blocked caller ID, it sends an INVITE with From: "anonymous"&lt;anonymous@anonymous.invalid&gt;</li> <li>■ [1] = The device's IP address is used as the URI host part instead of "anonymous.invalid".</li> </ul> <p>The parameter may be useful, for example, for service providers who identify their SIP Trunking customers by their source phone number or IP address, reflected in the From header of the SIP INVITE. Therefore, even customers blocking their Caller ID can be identified by the service provider. Typically, if the device receives a call with blocked Caller ID from the PSTN side (e.g., Trunk connected to a PBX), it sends an INVITE to the IP with a From header as follows: "From: "anonymous" &lt;anonymous@anonymous.invalid&gt;". This is in accordance with RFC 3325. However, when the parameter is set to 1, the device replaces the "anonymous.invalid" with its IP address.</p>
configure voip > sip-definition settings > p-	<p>Defines a 'representative number' (up to 50 characters) that is used as the user part of the Request-URI in the P-Asserted-Identity header of an outgoing INVITE for Tel-to-IP calls.</p>

Parameter	Description
assrtd-usr-name [PAssertedUserName]	The default is null.
configure voip > sip-definition settings > use- aor-in-refer-to- header [UseAORInReferToHeader]	<p>Defines the source for the SIP URI set in the Refer-To header of outgoing REFER messages.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Use SIP URI from Contact header of the initial call.</li> <li>■ [1] = Use SIP URI from To/From header of the initial call.</li> </ul>
'User-Information Usage' configure voip > sip-definition settings > user- inf-usage [EnableUserInfoUsage]	<p>Enables the User Information table and functionality. For more information on User Information, see <a href="#">Configuring User Information</a> on page 768.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
configure voip > sip-definition settings > handle-reason- header [HandleReasonHeader]	<p>Defines if the device uses the value of the incoming SIP Reason header for Release Reason mapping.</p> <ul style="list-style-type: none"> <li>■ [0] = Disregard Reason header in incoming SIP messages.</li> <li>■ [1] = (Default) Use the Reason header value for Release Reason mapping.</li> </ul>
[EnableSilenceSuppInSDP]	<p>Determines the device's behavior upon receipt of SIP Re-INVITE messages that include the SDP's 'silencesupp:off' attribute.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disregard the 'silecesupp' attribute.</li> <li>■ [1] = Handle incoming Re-INVITE messages that include the 'silencesupp:off' attribute in the SDP as a request to switch to the Voice-Band-Data (VBD) mode. In addition, the device includes the attribute 'a=silencesupp:off' in its SDP offer.</li> </ul> <p><b>Note:</b> The parameter is applicable only if the G.711 coder is used.</p>
'Enables Rport option in VIA header' configure voip > sip-definition	<p>Enables the use of the 'rport' parameter in the SIP Via header.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul>

Parameter	Description
<pre>settings &gt; rport-support [EnableRport]</pre>	<p>The device adds an 'rport' parameter to the Via header of each outgoing SIP message. The first Proxy that receives this message sets the 'rport' value of the response to the actual port from where the request was received. This method is used, for example, to enable the device to identify its port mapping outside a NAT.</p> <ul style="list-style-type: none"> <li>■ If the Via header doesn't include the 'rport' parameter, the destination port of the response is obtained from the host part of the Via header.</li> <li>■ If the Via header includes the 'rport' parameter without a port value, the destination port of the response is the source port of the incoming request.</li> <li>■ If the Via header includes 'rport' with a port value (e.g., rport=1001), the destination port of the response is the port indicated in the 'rport' parameter.</li> </ul>
<pre>'X-Channel Header' configure voip &gt; sip-definition settings &gt; x- channel-header [XChannelHeader]</pre>	<p>Enables the device to add the SIP X-Channel header to outgoing SIP messages. The header provides information on the physical Trunk/B-channel on which the call is received or sent.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. The X-Channel header is not added.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled. The X-Channel header is generated by the device and sent in SIP INVITE requests and 180, 183, and 200 OK responses. The header includes the Trunk/B-channel and the device's IP address, using the following syntax: <p>x-channel: ds/ds1-&lt;digital Trunk number&gt;/&lt;Trunk/B-channel&gt;;IP-P=&lt;device's IP address&gt;</p> <p>For example, the below shows a call on Trunk 1, channel 4 of the device with IP address 192.168.13.1:</p> <p>x-channel: ds/ds1-1/4;IP=192.168.13.1</p> </li></ul>
<pre>'Progress Indicator to IP' configure voip &gt; sip-definition settings &gt; prog- ind-2ip [ProgressIndicator2IP]</pre>	<p>Global parameter defining the progress indicator (PI) sent to the IP.</p> <p>You can also configure the feature per specific calls, using IP Profiles ('Progress Indicator to IP' parameter) or Tel Profiles ('Progress Indicator to IP' parameter). For a detailed description of the parameter and for configuring the feature, see <a href="#">Configuring IP Profiles</a> on page 664 or <a href="#">Configuring Tel Profile</a> on page 738.</p>

Parameter	Description
	<p><b>Note:</b> If you configure this feature for a specific profile, the device ignores this global parameter for calls associated with the profile.</p>
<p>'Enable Rekey After 181'</p> <pre>configure voip &gt; gateway digital settings &gt; rekey-after- 181</pre> <p>[EnableRekeyAfter181]</p>	<p>Enables the device to send a SIP re-INVITE request with a new (different) SRTP key (in the SDP) if a SIP 181 response is received ("call is being forwarded"). The device sends the re-INVITE immediately after receiving the 200 OK (when the call is answered).</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p><b>Note:</b> The parameter is applicable only if SRTP is used.</p>
<pre>configure voip &gt; sip-definition settings &gt; number-of- active-dialogs</pre> <p>[NumberOfActiveDialogs]</p>	<p>Defines the maximum number of concurrent, outgoing SIP REGISTER dialogs. The parameter is used to control the registration rate.</p> <p>The valid range is 1 to 20. The default is 20.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Once a 200 OK is received in response to a REGISTER message, the REGISTER message is not considered in this maximum count limit.</li> <li>■ The parameter applies only to outgoing REGISTER messages (i.e., incoming is unlimited).</li> </ul>
<p>'Network Node ID'</p> <pre>configure voip &gt; sip-definition settings &gt; net- node-id</pre> <p>[NetworkNodeId]</p>	<p>Defines the Network Node Identifier of the device for Avaya UCID.</p> <p>The valid value range is 1 to 0x7FFF. The default is 0.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ To use this feature, you must set the parameter to any value other than 0.</li> <li>■ To enable the generation by the device of the Avaya UCID value and adding it to the outgoing INVITE sent to the IP Group (Avaya entity), use the IP Groups table's parameter 'UUI Format'.</li> </ul>
<p>'Default Release Cause'</p> <pre>configure voip &gt; sip-definition settings &gt; dflt- release-cse</pre>	<p>Defines the default Release Cause (sent to IP) for IP-to-Tel calls when the device initiates a call release and an explicit matching cause for this release is not found.</p> <p>The default release cause is NO_ROUTE_TO_DESTINATION (3). Other common values include NO_CIRCUIT_AVAILABLE (34),</p>

Parameter	Description
[DefaultReleaseCause]	<p>DESTINATION_OUT_OF_ORDER (27), etc.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The default release cause is described in the Q.931 notation and is translated to corresponding SIP 40x or 50x values (e.g., 3 to SIP 404, and 34 to SIP 503).</li> <li>■ When the Trunk is disconnected or is not synchronized, the internal cause is 27. This cause is mapped, by default, to SIP 502.</li> <li>■ For mapping SIP-to-Q.931 and Q.931-to-SIP release causes, see <a href="#">Configuring Release Cause Mapping</a> on page 975.</li> <li>■ For a list of SIP responses-Q.931 release cause mapping, see <a href="#">Alternative Routing to Trunk upon Q.931 Call Release Cause Code</a> on page 945.</li> </ul>
<p>'Enable Microsoft Extension'</p> <pre>configure voip &gt; sip-definition settings &gt; microsoft-ext</pre> <p>[EnableMicrosoftExt]</p>	<p>Enables the modification of the called and calling number for numbers received with Microsoft's proprietary "ext=xxx" parameter in the SIP INVITE URI user part. Microsoft Office Communications Server sometimes uses this proprietary parameter to indicate the extension number of the called or calling party.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>For example, if a calling party makes a call to telephone number 622125519100 Ext. 104, the device receives the SIP INVITE (from Microsoft's application) with the URI user part as INVITE sip:622125519100;ext=104@10.1.1.10 (or INVITE tel:622125519100;ext=104). If the parameter [EnableMicrosoftExt] is enabled, the device modifies the called number by adding an "e" as the prefix, removing the "ext=" parameter, and adding the extension number as the suffix (e.g., e622125519100104). Once modified, the device can then manipulate the number further, using the Number Manipulation tables to leave only the last 3 digits (for example) for sending to a PBX.</p>
<pre>configure voip &gt; sip-definition settings &gt; sip- uri-for- diversion-header</pre>	<p>Defines the URI format in the SIP Diversion header.</p> <ul style="list-style-type: none"> <li>■ [0] = 'tel:' (default)</li> <li>■ [1] = 'sip:'</li> </ul>

Parameter	Description
[UseSIPURIForDiversio nHeader]	
configure voip > sip-definition settings > 100- to-18x-timeout [TimeoutBetween100A nd18x]	Defines the timeout (in msec) between receiving a 100 Trying response and a subsequent 18x response. If a 18x response is not received within this timeout period, the call is disconnected. The valid range is 0 to 180,000 (i.e., 3 minutes). The default is 32000 (i.e., 32 sec).
configure voip > sip-definition settings > immediate-trying [EnableImmediateTryin g]	<p>Determines if and when the device sends a 100 Trying in response to an incoming INVITE request.</p> <ul style="list-style-type: none"> <li>■ [0] = 100 Trying response is sent upon receipt of a Proceeding message from the PSTN.</li> <li>■ [1] = (Default) 100 Trying response is sent immediately upon receipt of INVITE request.</li> </ul>
configure voip > sip-definition settings > trans-coder- present [TransparentCoderPres entation]	<p>Determines the format of the Transparent coder representation in the SDP.</p> <ul style="list-style-type: none"> <li>■ [0] = clearmode (default)</li> <li>■ [1] = X-CCD</li> </ul>
configure voip > sip-definition settings > ignore-remote- sdp-mki [IgnoreRemoteSDPMKI]	<p>Determines whether the device ignores the Master Key Identifier (MKI) if present in the SDP received from the remote side.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable</li> <li>■ [1] = Enable</li> </ul>
'Comfort Noise Generation Negotiation' configure voip > media rtp-rtcp > com-noise-gen- nego [ComfortNoiseNegotiat ion]	<p>Enables negotiation and the use of Comfort Noise (CN) for Gateway calls.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>For more information, see <a href="#">Enabling Comfort Noise Generation</a> on page 292.</p> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>

Parameter	Description
<pre>configure voip &gt; sip-definition settings &gt; sdp- ecan-frmt</pre> <p>[SDPEcanFormat]</p>	<p>Defines the echo canceller format in the outgoing SDP. The 'ecan' attribute is used in the SDP to indicate the use of echo cancellation.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) The 'ecan' attribute appears on the 'a=gpmde' line.</li> <li>■ [1] = The 'ecan' attribute appears as a separate attribute.</li> <li>■ [2] = The 'ecan' attribute is not included in the SDP.</li> <li>■ [3] = The 'ecan' attribute and the 'vbd' parameter are not included in the SDP.</li> </ul> <p><b>Note:</b> The parameter is applicable only when the [IsFaxUsed] parameter is set to 2, and for re-INVITE messages generated by the device as result of modem or fax tone detection.</p>
<p>'First Call Ringback Tone ID'</p> <pre>configure voip &gt; sip-definition settings &gt; 1st- call-rbt-id</pre> <p>[FirstCallRBTId]</p>	<p>Defines the index of the first ringback tone in the CPT file. This option enables an Application server to request the device to play a distinctive ringback tone to the calling party according to the destination of the call. The tone is played according to the Alert-Info header received in the 180 Ringing SIP response (the value of the Alert-Info header is added to the value of the parameter).</p> <p>The valid range is -1 to 1,000. The default is -1 (i.e., play standard ringback tone).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ It is assumed that all ringback tones are defined in sequence in the CPT file.</li> <li>■ In case of an MLPP call, the device uses the value of the parameter plus 1 as the index of the ringback tone in the CPT file (e.g., if this value is set to 1, then the index is 2, i.e., 1 + 1).</li> </ul>
<p>'Reanswer Time'</p> <pre>configure voip &gt; sip-definition settings &gt; reanswer-time</pre> <p>[RegretTime]</p>	<p>Defines the time period the device waits for an MFC R2 Resume (Reanswer) signal once a Suspend (Clear back) signal is received from the PBX. If this timer expires, the call is released.</p> <p>The valid range is 0 to 255 (in seconds). The default is 0.</p> <p><b>Note:</b> For digital interfaces, the parameter is applicable only to the MFC-R2 CAS Brazil variant.</p>
<pre>configure voip &gt; gateway advanced &gt; reans-info-</pre>	<p>The parameter is used for private wire services (see <a href="#">Configuring Private Wire Interworking</a> on page 888).</p>

Parameter	Description
enbl [EnableReansweringINFO]	<ul style="list-style-type: none"> <li>■ [0] = (Default) Disable</li> <li>■ [1] = Enable</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if the [RegretTime] parameter is configured.</li> <li>■ For digital interfaces, the parameter is applicable only to E1/T1 CAS.</li> </ul>
'Presence Publish IP Group ID' presence-publish-ip-group-name [PresencePublishIPGroupName]	<p>Assigns the IP Group configured for Microsoft Teams providing user presence service. the device sends SIP PUBLISH messages to this IP Group to notify changes in presence status of Teams users when making and receiving calls using third-party endpoint devices.</p> <p>For more information on integration with Microsoft presence, see <a href="#">Microsoft Skype for Business Presence of Third-Party Endpoints</a> on page 505.</p>
'Microsoft Presence Status' [EnableMSPresence]	<p>Enables the device to notify (using SIP PUBLISH messages) Microsoft Teams (presence server) of changes in presence status of Teams users when making and receiving calls using third-party endpoint devices.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>For more information on integration with Microsoft presence, see <a href="#">Microsoft Skype for Business Presence of Third-Party Endpoints</a> on page 505.</p>
'PSTN Alert Timeout' configure voip > sip-definition settings > pstn- alert-timeout [PSTNAlertTimeout]	<p>Defines the Alert Timeout (in seconds) for calls sent to the PSTN. This timer is used between the time a Setup message is sent to the Tel side (IP-to-Tel call establishment) and a Connect message is received. If an Alerting message is received, the timer is restarted. If the timer expires before the call is answered, the device disconnects the call and sends a SIP 408 request timeout response to the SIP party that initiated the call. The valid value range is 1 to 600 (in seconds). The default is 180.</p> <p><b>Note:</b> If per trunk configuration, using the [TrunkPSTNAlertTimeout] parameter, is set to other than default, the [PSTNAlertTimeout] parameter value is overridden.</p>



Parameter	Description
'RTP Only Mode' configure voip > sip-definition settings > rtp- only-mode [RTPOnlyMode]	<p>Enables the device to send and receive RTP packets to and from remote endpoints without the need to establish a SIP session. The remote IP address is determined according to the Tel-to-IP Routing table (Prefix parameter). The port is the same port as the local RTP port (configured by the [BaseUDPPort] parameter and the channel on which the call is received).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Transmit &amp; Receive</b> = Send and receive RTP packets.</li> <li>■ [2] <b>Transmit Only</b>= Send RTP packets only.</li> <li>■ [3] <b>Receive Only</b>= Receive RTP packets only.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Gateway application.</li> <li>■ Digital interfaces: To activate the RTP Only feature without using ISDN / CAS signaling, you must do the following:               <ul style="list-style-type: none"> <li>✓ Configure E1/T1 Transparent protocol type (set the [ProtoCoType] parameter to 5 or 6).</li> <li>✓ Enable the TDM-over-IP feature (set the [EnableTDMoverIP] parameter to 1).</li> </ul> </li> <li>■ To configure the RTP Only mode per trunk, use the [RTPOnlyModeForTrunk_x] parameter.</li> <li>■ If per trunk configuration (using the [RTPOnlyModeForTrunk_ID] parameter) is set to a value other than the default, the [RTPOnlyMode] parameter value is ignored.</li> </ul>
[RTPOnlyModeForTrunk_x]	<p>Enables the RTP Only feature per trunk. The x in the parameter name denotes the trunk number, where 0 is Trunk 1. For a description of the parameter, see the [RTPOnlyMode] parameter.</p> <p>Note: For using the global parameter (i.e., setting the RTP Only feature for all trunks), set the parameter to -1 (default).</p>
'Media IP Version Preference' configure voip > media settings > media-ip-ver-	<p>Global parameter that defines the preferred RTP media IP addressing version (IPv4 or IPv6) for outgoing SIP calls. You can also configure this feature per specific calls, using IP Profiles ('Media IP Version Preference' parameter). For a detailed description of the parameter and for configuring this feature in</p>

Parameter	Description
pref [MediaIPVersionPreference]	the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.
'SIT Q850 Cause' configure voip > sip-definition settings > sit- q850-cause [SITQ850Cause]	Defines the Q.850 cause value specified in the SIP Reason header that is included in a 4xx response when a Special Information Tone (SIT) is detected on an IP-to-Tel call.  The valid range is 0 to 127. The default is 34. <b>Note:</b> For mapping specific SIT tones, use the following parameters: [SITQ850CauseForNC], [SITQ850CauseForIC], [SITQ850CauseForVC], and [SITQ850CauseForRO].
'SIT Q850 Cause For NC' configure voip > sip-definition settings > release-cause- for-sit-nc [SITQ850CauseForNC]	Defines the Q.850 cause value specified in the SIP Reason header that is included in a 4xx response when SIT-NC (No Circuit Found Special Information Tone) is detected from the Tel side for IP-to-Tel calls.  The valid range is 0 to 127. The default is 34. <b>Note:</b> When not configured (i.e., default), the [SITQ850Cause] parameter is used.
'SIT Q850 Cause For IC' configure voip > sip-definition settings > q850- cause-for-sit-ic [SITQ850CauseForIC]	Defines the Q.850 cause value specified in the SIP Reason header that is included in a 4xx response when SIT-IC (Operator Intercept Special Information Tone) is detected from the Tel for IP-to-Tel calls.  The valid range is 0 to 127. The default is -1 (not configured). <b>Note:</b> When not configured (i.e., default), the [SITQ850Cause] parameter is used.
'SIT Q850 Cause For VC' configure voip > sip-definition settings > q850- cause-for-sit-vc [SITQ850CauseForVC]	Defines the Q.850 cause value specified in the SIP Reason header that is included in a 4xx response when SIT-VC (Vacant Circuit - non-registered number Special Information Tone) is detected from the Tel for IP-to-Tel calls.  The valid range is 0 to 127. The default is -1 (not configured). <b>Note:</b> When not configured (i.e., default), the [SITQ850Cause] parameter is used.
'SIT Q850 Cause For RO' configure voip > sip-definition settings > q850- cause-for-sit-ro	Defines the Q.850 cause value specified in the SIP Reason header that is included in a 4xx response when SIT-RO (Reorder - System Busy Special Information Tone) is detected from the Tel for IP-to-Tel calls.  The valid range is 0 to 127. The default is -1 (not configured). <b>Note:</b> When not configured (i.e., default), the [SITQ850Cause] parameter is used.

Parameter	Description
[SITQ850CauseForRO]	parameter is used.
<pre>configure voip &gt; message settings &gt; inbound-map-set</pre> [GWInboundManipulationSet]	<p>Gateway application only: Assigns a Manipulation Set ID for manipulating all inbound INVITE messages.</p> <p>Gateway and SBC applications: Assigns a Manipulation Set ID for manipulating incoming responses of requests that the device initiates.</p> <p>The Manipulation Set is defined using the [MessageManipulations] parameter. By default, no manipulation is done (i.e. Manipulation Set ID is set to -1).</p> <p>For more information, see <a href="#">Configuring SIP Message Manipulation</a> on page 829.</p>
<pre>configure voip &gt; message settings &gt; outbound-map-set</pre> [GWOutboundManipulationSet]	<p>Gateway application only: Assigns a Manipulation Set ID for manipulating all outbound INVITE messages.</p> <p>Gateway and SBC applications: Assigns a Manipulation Set ID for manipulating outgoing requests that the device initiates.</p> <p>The Manipulation Set is defined using the [MessageManipulations] parameter. By default, no manipulation is done (i.e. Manipulation Set ID is set to -1).</p> <p>For more information, see <a href="#">Configuring SIP Message Manipulation</a> on page 829.</p>
<p>'WebSocket Keep-Alive Period'</p> <pre>configure voip &gt; sip-definition settings &gt; websocket-keepalive</pre> [WebSocketProtocolKeepAlivePeriod]	<p>Defines how often (in seconds) the device sends ping messages (keep alive) to check whether the WebSocket session with the Web client is still connected.</p> <p>The valid value is 5 to 2000000. The default is 0 (i.e., ping messages are not sent).</p> <p>For more information on WebSocket, see General SIP Parameters.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The device always replies to WebSocket ping control messages with pong messages.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>
<p>'Registered User MOS Observation Window'</p> <pre>configure voip &gt; qoe reg-user-voice-quality &gt;</pre>	<p>Defines the length of each interval (in hours) in the observation window (12 intervals) for calculating average MOS of calls belonging to users registered with the device.</p> <p>The valid value is 1 or 2. The default is 1.</p> <p>As the device measures MOS in 12 intervals, if configured to 1,</p>

Parameter	Description
<code>mos-observ-win</code> <code>[RegUserMosObservationWindow]</code>	<p>then MOS is measured over a 12 hour period; if configured to 2, then MOS is calculated over a 24 hour period. It measures the average and minimum MOS per interval. Intervals without calls are not used in the calculation.</p> <p>For more information on this feature, see <a href="#">Configuring Voice Quality for Registered Users</a> on page 535.</p> <p><b>Note:</b> This parameter is applicable only to the SBC application.</p>
<p>'MOS Stored Timeout For No Calls'</p> <code>configure voip &gt;</code> <code>qoe reg-user-</code> <code>voice-quality &gt;</code> <code>mos-stored-</code> <code>timeout-for-no-</code> <code>calls</code> <code>[MosStoredTimeoutForNoCalls]</code>	<p>Defines the duration (in minutes) of no calls after which the MOS measurement is reset (0 and gray color). In addition, if an alternative IP Profile is configured for the Quality of Service rule and is currently being used, the device changes back to the original IP Profile.</p> <p>The valid value range is 1 to 1,440. The default is 60.</p> <p>For more information on this feature, see <a href="#">Configuring Voice Quality for Registered Users</a> on page 535.</p> <p><b>Note:</b> This parameter is applicable only to the SBC application.</p>
<code>configure voip &gt;</code> <code>sip-definition</code> <code>settings &gt;</code> <code>message-policy-</code> <code>reject-response-</code> <code>type</code> <code>[MessagePolicyRejectResponseType]</code>	<p>Defines the SIP response code that the device sends when it rejects an incoming SIP message due to a matched Message Policy in the Message Policies table, whose 'Send Reject' parameter is configured to <b>Policy Reject</b>.</p> <p>The default is 400 "Bad Request".</p> <p>To configure Message Policies, see <a href="#">Configuring SIP Message Policy Rules</a> on page 840.</p>
<code>[ENUMAllowNonDigits]</code>	<p>Defines if non-digits can be included in ENUM queries sent by the device to an ENUM server for retrieving a SIP URI address for an E.164 telephone number (destination).</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable – non-digits are not accepted in ENUM queries. For example: 9.2.0.0.3.0.9.3.0.3.0.2.5.3.4.4.2.5.7.7.8.My_Domain</li> <li>■ [1] = Enable – non-digits are accepted in ENUM queries (request). For example: 0.0.0.0.0.2.3.3.3.3.2.2.*.9.9.j.a.k.s.*.j.k.a.n.d.b.j.s.+My_Domain</li> </ul> <p>For the Gateway application: ENUM queries can be used for Tel-to-IP Routing (see <a href="#">Configuring Tel-to-IP Routing Rules</a> on page 914). For the SBC application: ENUM queries can be used</p>

Parameter	Description
	for IP-to-IP routing with Call Setup Rules (see <a href="#">Configuring SBC IP-to-IP Routing Rules</a> on page 1076 and <a href="#">Configuring Call Setup Rules</a> on page 782).
'Regions Connectivity Dial Plan' configure voip > sbc settings > regions- connectivity- dial-plan [RegionsConnectivityDialPlan]	Defines the Dial Plan that the device must search in the Dial Plans table to check if the source and destination Teams sites share a common group number. If they do, the call is a direct media call.  For more information, see <a href="#">Using Dial Plans for Microsoft Local Media Optimization</a> on page 825  <b>Note:</b> The ini file parameter is a table, using the following syntax: <pre>[ RegionsConnectivityDialPlan ] FORMAT Index = RCDialPlan; RegionsConnectivityDialPlan 0 = "NameofDialPlan"; [ \RegionsConnectivityDialPlan ]</pre> <b>Note:</b> The feature is applicable only to Teams-to-PSTN calls.
configure voip > sip-definition settings > preserve- multipart- content-type [PreserveMultipartContentType]	Defines the device's handling of the SIP Content-Type header's value when the device sends a SIP message that has multiple bodies.  <ul style="list-style-type: none"> <li>■ [0] = (Default) Disabled. The device sets the type parameter in the Content-Type header to "multipart/mixed" and adds a unique value to the 'boundary' parameter of the Content-Type header.</li> <li>■ [1] = Enabled. The device doesn't change the type or boundary parameter of the Content-Type header. For example, if the incoming message contains 'Content-Type: multipart/relative;boundary=&lt;someUniqueValue&gt;', then this is how the Content-Type will be in the outgoing message.</li> </ul> <b>Note:</b> The parameter is applicable only to the SBC application.
<b>Out-of-Service (Busy Out) Parameters</b>	
'Enable Busy Out' configure voip > sip-definition settings > busy- out [EnableBusyOut]	Enables the Busy Out feature.  <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> When enabled and certain scenarios exist, the device does the following:

Parameter	Description
	<ul style="list-style-type: none"> <li>■ Digital: All trunks are automatically taken out-of-service by taking down the D-Channel, or for T1 PRI trunks, by sending a Service Out message supporting these messages (NI-2, 4/5-ESS, DMS-100, and Meridian).</li> </ul> <p>The above behavior is done upon one of the following scenarios:</p> <ul style="list-style-type: none"> <li>■ The device is physically disconnected from the network (i.e., Ethernet cable is disconnected).</li> <li>■ The device can't communicate with the Proxy Sets (according to the Proxy Keep-Alive mechanism) associated with the destination IP Groups of matching routing rules in the Tel-to-IP Routing table and no other alternative route exists to send the call.</li> <li>■ The IP Connectivity mechanism is enabled (by the [AltRoutingTel2IPEnable] parameter) and there is no connectivity to any destination IP address of matching routing rules in the Tel-to-IP Routing table.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you enable the [AltRoutingTel2IPEnable] parameter, the Busy Out feature doesn't function with the Proxy Set keep-alive mechanism. To use the Busy Out feature with the Proxy Set keep-alive mechanism (for IP Groups), disable the [AltRoutingTel2IPEnable] parameter.</li> <li>■ The Busy Out behavior depends on the PSTN protocol type.</li> <li>■ The Busy Out condition is also applied per Trunk Group. This occurs if there is no connectivity to the Serving IP Group of a specific Trunk Group configured in the Trunk Group Settings table. In such a scenario, all the physical trunks of the Trunk Group are set to the Busy Out condition. Each trunk uses the out-of-service method according to the ISDN / CAS variant.</li> <li>■ To configure the method for taking trunks/channels out-of-service, see the [DigitalOOSBehaviorForTrunk_x] parameter for per trunk or the [DigitalOOSBehavior] parameter for all trunks.</li> </ul>
'Graceful Busy Out Timeout' configure voip > sip-definition	Defines the timeout interval (in seconds) for out-of-service graceful shutdown mode for busy trunks (per trunk) if communication fails with a Proxy server (or Proxy Set). In such a scenario, the device rejects new calls from the PSTN (i.e.,

Parameter	Description
<pre>settings &gt; graceful-busy- out-t-out</pre> <p>[GracefulBusyOutTime out]</p>	<p>Serving Trunk Group), but maintains currently active calls for this user-defined timeout. Once this timeout elapses and there are still active calls, the device terminates the calls and takes the trunk out-of-service (sending the PSTN busy-out signal). Trunks without any active calls are immediately taken out-of-service regardless of the timeout.</p> <p>The parameter is applicable to the locking of Trunk Groups feature (see <a href="#">Locking and Unlocking Trunk Groups</a> on page 1208) and the Busy Out feature (see the [EnableBusyOut] parameter), where trunks/channels are taken out-of-service.</p> <p>The range is 0 to 86,400. The default is 0.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to digital interfaces.</li> <li>■ To configure the method for taking trunks/channels out-of-service, see the [DigitalOOSBehaviorForTrunk_x] parameter for per trunk or the [DigitalOOSBehavior] parameter for all trunks.</li> </ul>
<pre>configure voip &gt; gateway digital settings &gt; isdn- busy-out-based- on-table</pre> <p>[ISDNBusyOutBasedOn Table]</p>	<p>Defines which configuration table (Trunk Group Settings table or Tel-to-IP Routing table) the device uses to determine busy out for a Trunk Group.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Busy Out is determined by the Trunk Group Settings table (see <a href="#">Configuring Trunk Group Settings</a> on page 906). Busy Out of a Trunk Group occurs if its associated Serving IP Group in the table is down.</li> <li>■ [1] = Busy Out is determined by the Tel-to-IP Routing table (see <a href="#">Configuring Tel-to-IP Routing Rules</a> on page 914). Busy Out of a Trunk Group occurs only when all its associated destination IP Groups in the table are down. Busy Out is cleared when at least one IP Group is up.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to digital (ISDN) interfaces.</li> <li>■ For this Busy Out feature, you need to enable proxy keep-alive for the Proxy Set associated with the IP Group.</li> <li>■ For the parameter to take effect, a device restart is required.</li> </ul>
<b>Retransmission Parameters</b>	

Parameter	Description
<p>'SIP T1 Retransmission Timer'</p> <pre>configure voip &gt; sip-definition settings &gt; t1- re-tx-time</pre> <p>[SipT1Rtx]</p>	<p>Defines the time interval (in msec) between the first transmission of a SIP message and the first retransmission of the same message.</p> <p>The default is 500.</p> <p><b>Note:</b> The time interval between subsequent retransmissions of the same SIP message starts with SipT1Rtx. For INVITE requests, it is multiplied by two for each new retransmitted message. For all other SIP messages, it is multiplied by two until SipT2Rtx. For example, assuming SipT1Rtx = 500 and SipT2Rtx = 4000:</p> <ul style="list-style-type: none"> <li>■ The first retransmission is sent after 500 msec.</li> <li>■ The second retransmission is sent after 1000 (2*500) msec.</li> <li>■ The third retransmission is sent after 2000 (2*1000) msec.</li> <li>■ The fourth retransmission and subsequent retransmissions until [SIPMaxRtx] are sent after 4000 (2*2000) msec.</li> </ul>
<p>'SIP T2 Retransmission Timer'</p> <pre>configure voip &gt; sip-definition settings &gt; t2- re-tx-time</pre> <p>[SipT2Rtx]</p>	<p>Defines the maximum interval (in msec) between retransmissions of SIP messages (except for INVITE requests).</p> <p>The default is 4000.</p> <p><b>Note:</b> The time interval between subsequent retransmissions of the same SIP message starts with SipT1Rtx and is multiplied by two until SipT2Rtx.</p>
<p>'SIP Maximum RTX'</p> <pre>configure voip &gt; sip-definition settings &gt; sip- max-rtx</pre> <p>[SIPMaxRtx]</p>	<p>Defines the maximum number of UDP transmissions of SIP messages (first transmission plus retransmissions).</p> <p>The range is 1 to 30. The default is 7.</p>
<p>'Number of RTX Before Hot-Swap'</p> <pre>configure voip &gt; sip-definition proxy-and- registration &gt; nb-of-rtx-b4- hot-swap</pre> <p>[HotSwapRtx]</p>	<p>Defines the number of retransmitted INVITE/REGISTER messages before the call is routed (hot swap) to another Proxy/Registrar.</p> <p>The valid range is 1 to 30. The default is 3.</p> <p>For example, if configured to 3 and no response is received from an IP destination, the device attempts another three times to send the call to the IP destination. If still unsuccessful, it attempts to redirect the call to another IP destination.</p> <p><b>Note:</b> The parameter is also used for alternative routing (see <a href="#">Alternative Tel-to-IP Routing Based on IP Connectivity</a> on</p>



Parameter	Description
	page 938.
<pre>configure voip &gt; sip-definition settings &gt; usr2usr-hdr-frmt</pre> <p>[UserToUserHeaderFormat]</p>	<p>Defines the interworking between the SIP INVITE's User-to-User header and the ISDN User-to-User (UU) IE data.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) SIP header format: X-UserToUser.</li> <li>■ [1] = SIP header format: User-to-User with Protocol Discriminator (pd) attribute (according to IETF Internet-Draft draft-johnston-sipping-cc-uui-04). For example:   User-to-  User=3030373435313734313635353b313233343b3834;pd=4</li> <li>■ [2] = SIP header format: User-to-User with encoding=hex at the end and pd embedded as the first byte (according to IETF Internet-Draft draft-johnston-sipping-cc-uui-03). For example:   User-to-  User=043030373435313734313635353b313233343b3834; encoding=hex   where "04" at the beginning of this message is the pd.</li> <li>■ [3] = Interworks the SIP User-to-User header containing text format to ISDN UUIE in hexadecimal format, and vice versa. For example:   SIP Header in text format:  User-to-User=01800213027b712a;NULL;4582166;   Translated to hexadecimal in the ISDN UUIE:  303138303032313330323762373132613b4e554c4c3b343538323136363b   The Protocol Discriminator (pd) used in UUIE is "04" (IUA characters).</li> </ul> <p><b>Note:</b> The parameter is applicable for Tel-to-IP and IP-to-Tel calls.</p>

## Channel Parameters

This section describes the device's channel parameters.

## Voice Parameters

The voice parameters are described in the table below.

Table 69-35:Voice Parameters

Parameter	Description
<b>'Input Gain'</b> <code>configure voip &gt; media</code> <code>voice &gt; input-gain</code> <b>[InputGain]</b>	<p>Global parameter defining the pulse-code modulation (PCM) input (received) gain control level (in decibels). You can also configure the feature per specific calls, using IP Profiles ('Input Gain' parameter) or Tel Profiles ('Input Gain' parameter). For a detailed description of the parameter and for configuring the feature, see <a href="#">Configuring IP Profiles</a> on page 664 or <a href="#">Configuring Tel Profile</a> on page 738.</p> <p><b>Note:</b> If the feature is configured for a specific profile, the settings of the global parameter is ignored for calls associated with the profile.</p>
<b>'Voice Volume'</b> <code>configure voip &gt; media</code> <code>voice &gt; voice-volume</code> <b>[VoiceVolume]</b>	<p>Global parameter defining the voice gain control (in decibels). This defines the level of the transmitted signal (for the Gateway application, in IP-to-Tel calls). You can also configure the feature per specific calls, using IP Profiles ('Voice Volume' parameter) or Tel Profiles ('Voice Volume' parameter). For a detailed description of the parameter and for configuring the feature, see <a href="#">Configuring IP Profiles</a> on page 664 or <a href="#">Configuring Tel Profile</a> on page 738.</p> <p><b>Note:</b> If the feature is configured for a specific profile, the settings of the global parameter is ignored for calls associated with the profile.</p>
<code>configure voip &gt; media</code> <code>voice codecs &gt; G726-</code> <code>voice-payload-format</code> <b>[VoicePayloadFormat]</b>	<p>Determines the bit ordering of the G.726 voice payload format.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Little Endian</li> <li>■ [1] = Big Endian</li> </ul> <p><b>Note:</b> To ensure high voice quality when using G.726, both communicating ends should use the same endianness format. Therefore, when the device communicates with a third-party entity that uses the G.726 voice coder and voice quality is poor, change the settings of the parameter (between Big Endian and Little Endian).</p>
<b>'Echo Canceller'</b> <code>configure voip &gt; media</code> <code>voice &gt; echo-</code>	<p>Global parameter enabling echo cancellation (i.e., echo from voice calls is removed). You can also configure this feature per specific calls,</p>

Parameter	Description
<code>canceller-enable</code> [EnableEchoCanceller]	<p>using IP Profiles ('Echo Canceller' parameter) or Tel Profiles ('Echo Canceller' parameter). For a detailed description of the parameter and for configuring the feature, see <a href="#">Configuring IP Profiles</a> on page 664 or <a href="#">Configuring Tel Profile</a> on page 738.</p> <p><b>Note:</b> If the feature is configured for a specific profile, the device ignores this global parameter for calls associated with the profile.</p>
<code>configure voip &gt; media</code> <code>voice &gt; echo-</code> <code>canceller-hybrid-loss</code> [ECHybridLoss]	<p>Defines the four-wire to two-wire worst-case Hybrid loss, the ratio between the signal level sent to the hybrid and the echo level returning from the hybrid.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) 6 dB</li> <li>■ [1] = N/A</li> <li>■ [2] = 0 dB</li> <li>■ [3] = 3 dB</li> </ul>
<code>configure voip &gt; media</code> <code>voice &gt; echo-</code> <code>canceller-NLP-mode</code> [ECNLPMODE]	<p>Global parameter enabling Non-Linear Processing (NLP) mode for echo cancellation.</p> <p>You can also configure the feature per specific calls, using Tel Profiles ('EC NLP Mode' parameter). For a detailed description of the parameter and for configuring the feature in the Tel Profiles table, see <a href="#">Configuring Tel Profile</a> on page 738.</p> <p><b>Note:</b> If the feature is configured for a specific Tel Profile, the settings of the global parameter is ignored for calls associated with the Tel Profile.</p>
<code>configure voip &gt; media</code> <code>voice &gt; echo-</code> <code>canceller-aggressive-</code> <code>NLP</code> [EchoCancellerAggressiveNLP]	<p>Enables the Aggressive NLP at the first 0.5 second of the call.</p> <ul style="list-style-type: none"> <li>■ [0] = Disable</li> <li>■ [1] = (Default) Enable. The echo is removed only in the first half of a second of the incoming IP signal.</li> </ul> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
<code>configure voip &gt; media</code> <code>RTP-RTCP &gt; number-of-</code> <code>SID-coefficients</code> [RTPSIDCoeffNum]	<p>Defines the number of spectral coefficients added to an SID packet being sent according to RFC 3389.</p> <p>The valid values are [0] (default), [4], [6], [8] and [10].</p>

## Coder Parameters

The coder parameters are described in the table below.

**Table 69-36:Coder Parameters**

Parameter	Description
'SILK Tx Inband FEC' configure voip > media settings > silk-tx- inband-fec [SilkTxInbandFEC]	Enables forward error correction (FEC) for the SILK coder.  ■ [0] <b>Disable</b> (default) ■ [1] <b>Enable</b>
'SILK Max Average Bit Rate' configure voip > media settings > silk-max- average-bitrate [SilkMaxAverageBitRate]	Defines the maximum average bit rate for the SILK coder.  The valid value range is 6,000 to 50,000. The default is 50,000.  The SILK coder is Skype's default audio codec used for Skype-to-Skype calls.
configure voip > media settings > vbr-coder- header-format [VBRCoderHeaderFormat]	Defines the format of the RTP header for VBR coders.  ■ [0] = (Default) Payload only (no header, TOC, or m-factor) - similar to RFC 3558 Header Free format. ■ [1] = Supports RFC 2658 - 1 byte for interleaving header (always 0), TOC, no m-factor. ■ [2] = Payload including TOC only, allow m-factor. ■ [3] = RFC 3558 Interleave/Bundled format.
configure voip > media settings > vbr-coder- hangover [VBRCoderHangover]	Defines the required number of silence frames at the beginning of each silence period when using the VBR coder silence suppression.  The range is 0 to 255. The default is 1.
'AMR Payload Format' [AmrOctetAlignedEnable]	Defines the AMR payload format type.  ■ [0] <b>Bandwidth Efficient</b> ■ [1] <b>Octet Aligned</b> (default)  <b>Note:</b> The AMR payload type can also be configured per Coder Group (see <a href="#">Configuring Coders Groups</a> on page 651). The Coder Group configuration overrides the parameter.
configure voip > media	Defines the payload format of the AMR header.

Parameter	Description
<pre>settings &gt; amr-header-format</pre> <p>[AMRCoderHeaderFormat]</p>	<ul style="list-style-type: none"> <li>■ [0] = Non-standard multiple frames packing in a single RTP frame. Each frame has a CMR and TOC header.</li> <li>■ [1] = AMR frame according to RFC 3267 bundling.</li> <li>■ [2] = AMR frame according to RFC 3267 interleaving.</li> <li>■ [3] = AMR is passed using the AMR IF2 format.</li> </ul> <p><b>Note:</b> Bandwidth Efficient mode is not supported; the mode is always Octet-aligned.</p>
<p>'Fax/Modem Bypass Packing Factor'</p> <pre>configure voip &gt; media fax-modem &gt; packing-factor</pre> <p>[FaxModemBypassM]</p>	<p>Defines the number (20 msec) of coder payloads used to generate a fax/modem bypass packet.</p> <p>The valid range is 1, 2, or 3 coder payloads. The default is 1 coder payload.</p>
<p>'Transparent on Data Call'</p> <p>[TransparentCoderOnDataCall]</p>	<ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) Only use coders from the coder list.</li> <li>■ [1] <b>Enable</b> = Use Transparent coder for data calls (according to RFC 4040).</li> </ul> <p>The Transparent coder can be used on data calls. When the device receives a Setup message from the ISDN with 'TransferCapabilities = data', it can initiate a call using the coder 'Transparent' (even if the coder is not included in the coder list).</p> <p>The initiated INVITE includes the following SDP attribute:</p> <pre>a=rtpmap:97 CLEARMODE/8000</pre> <p>The default payload type is set according to the [CodersGroup] parameter. If the Transparent coder is not defined, the default is set to 56. The payload type is negotiated with the remote side, i.e., the selected payload type is according to the remote side selection. The receiving device must include the 'Transparent' coder in its coder list.</p> <p><b>Note:</b> The parameter is applicable only to digital interfaces.</p>
<pre>configure voip &gt; sip-</pre>	<p>Defines the payload type of the Transparent coder for</p>

Parameter	Description
<pre>definition settings &gt; transparent-payload- type</pre> <p>[TransparentPayloadType]</p>	<p>outgoing data calls (ISDN-to-IP).</p> <p>When the device receives a Setup message from the ISDN with 'TransferCapabilities = data', it can initiate a call using the coder 'Transparent' (even if the coder is not included in the coder list).</p> <p>The initiated INVITE includes the following SDP attribute:</p> <pre>a=rtpmap:97 CLEARMODE/8000</pre> <p>The valid value range is 1 to 127. The default value is 56.</p> <p><b>Note:</b> The parameter is applicable only to digital interfaces.</p>

## DTMF Parameters

The dual-tone multi-frequency (DTMF) parameters are described in the table below.

**Table 69-37:DTMF Parameters**

Parameter	Description
<pre>'DTMF Transport Type' configure voip &gt; media voice &gt; DTMF-transport- type</pre> <p>[DTMFTransportType]</p>	<p>Defines the DTMF transport type.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Mute DTMF</b> = DTMF digits are removed from the voice stream and are not relayed to remote side.</li> <li>■ [2] <b>Transparent DTMF</b> = DTMF digits remain in the voice stream.</li> <li>■ [3] <b>RFC 2833 Relay DTMF</b> = (Default) DTMF digits are removed from the voice stream and are relayed to the remote side according to RFC 2833.</li> <li>■ [7] <b>RFC 2833 Relay Decoder Mute</b> = DTMF digits are sent according to RFC 2833 and muted when received.</li> </ul> <p><b>Note:</b> The parameter is automatically updated if the parameters [FirstTxDTMFOption] or [RxDTMFOption] are configured.</p>
<pre>'DTMF Volume' (-31 to 0 dB) configure voip &gt; media voice &gt; DTMF-volume</pre>	<p>Global parameter defining the DTMF gain control value (in decibels). For analog interfaces, this is the gain control to the Tel side.</p> <p>You can also configure the feature per specific calls, using Tel Profiles ('DTMF Volume' parameter). For a detailed</p>

Parameter	Description
[DTMFVolume]	<p>description of the parameter and for configuring the feature in the Tel Profiles table, see <a href="#">Configuring Tel Profile</a> on page 738.</p> <p><b>Note:</b> If the feature is configured for a specific Tel Profile, the settings of the global parameter is ignored for calls associated with the Tel Profile.</p>
DTMF Generation Twist configure voip > media voice > DTMF-generation-twist [DTMFGenerationTwist]	<p>Defines the range (in decibels) between the high and low frequency components in the DTMF signal. Positive decibel values cause the higher frequency component to be stronger than the lower one. Negative values cause the opposite effect. For any parameter value, both components change so that their average is constant.</p> <p>The valid range is -10 to 10 dB. The default is 0 dB.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
inter-digit-interval [DTMFInterDigitInterval]	<p>Defines the time (in msec) between generated DTMF digits (to the Tel side for the Gateway application) if FirstTxDTMFOption = 1, 2 or 3.</p> <p>The valid range is 0 to 32767. The default is 100.</p>
[DTMFDigitLength]	<p>Defines the time (in msec) for generating DTMF tones (to the Tel side for the Gateway application) if FirstTxDTMFOption = 1, 2 or 3. It also configures the duration that is sent in INFO (Cisco) messages.</p> <p>The valid range is 0 to 32767. The default is 100.</p>
configure voip > media voice > digit-hangover-time-rx [RxDTMFHangOverTime]	<p>Defines the Voice Silence time (in msec) after playing DTMF or MF digits (to the Tel side for the Gateway application) that arrive as Relay (from the IP side for the Gateway application).</p> <p>Valid range is 0 to 2,000 msec. The default is 1,000 msec.</p>
configure voip > media voice > digit-hangover-time-tx [TxDTMFHangOverTime]	<p>Defines the Voice Silence time (in msec) after detecting the end of DTMF or MF digits (on the Tel side for the Gateway application) when the DTMF Transport Type is either Relay or Mute.</p> <p>Valid range is 0 to 2,000 msec. The default is 1,000 msec.</p>
'NTE Max Duration' configure voip > media voice >	<p>Defines the maximum time for sending Named Telephony Events / NTEs -- RFC 4733/2833 DTMF relay -- (to the IP side for the Gateway application), regardless of the DTMF signal</p>

Parameter	Description
telephony-events-max-duration [NTEMaxDuration]	duration on the other side (TDM for the Gateway application).  The range is -1 to 200,000,000 msec. The default is -1 (i.e., NTE stops only upon detection of an End event).

## RTP, RTCP and T.38 Parameters

The RTP, RTCP and T.38 parameters are described in the table below.

**Table 69-38:RTP/RTCP and T.38 Parameters**

Parameter	Description
'Dynamic Jitter Buffer Minimum Delay' configure voip > media rtp-rtcp > jitter-buffer-minimum-delay [DJBufMinDelay]	Global parameter defining the minimum delay (in msec) of the device's dynamic Jitter Buffer. You can also configure the feature per specific calls, using IP Profiles ('Dynamic Jitter Buffer Minimum Delay' parameter) or Tel Profiles ('Dynamic Jitter Buffer Minimum Delay' parameter). For a detailed description of the parameter and for configuring the feature, see <a href="#">Configuring IP Profiles</a> on page 664 or <a href="#">Configuring Tel Profile</a> on page 738.  <b>Note:</b> If the feature is configured for a specific profile, the settings of the global parameter is ignored for calls associated with the profile.
'Dynamic Jitter Buffer Optimization Factor' configure voip > media rtp-rtcp > jitter-buffer-optimization-factor [DJBufOptFactor]	Global parameter defining the Dynamic Jitter Buffer frame error/delay optimization factor. You can also configure the feature per specific calls, using IP Profiles ('Dynamic Jitter Buffer Optimization Factor' parameter) or Tel Profiles ('Dynamic Jitter Buffer Optimization Factor' parameter). For a detailed description of the parameter and for configuring the feature, see <a href="#">Configuring IP Profiles</a> on page 664 or <a href="#">Configuring Tel Profile</a> on page 738.  <b>Note:</b> If the feature is configured for a specific profile, the settings of the global parameter is ignored for calls associated with the profile.
'RTP Redundancy Depth' configure voip > media	Global parameter that enables the device to generate RFC 2198 redundant packets. You can



Parameter	Description
<pre>rtp-rtcp &gt; RTP-redundancy- depth</pre> <p>[RTPRedundancyDepth]</p>	<p>also configure this feature per specific calls, using IP Profiles ('RTP Redundancy Depth' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b> If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</p>
<p>'Enable RTP Redundancy Negotiation'</p> <pre>configure voip &gt; sip- definition settings &gt; rtp- rdcy-nego-enbl</pre> <p>[EnableRTPRedundancyNegotiation]</p>	<p>Enables the device to include the RTP redundancy dynamic payload type in the SDP (according to RFC 2198).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b> = The device includes in the SDP message the RTP payload type "red" and the payload type configured by the [RFC2198PayloadType] parameter.</li> </ul> <pre>a=rtpmap:&lt;PT&gt; red/8000</pre> <p>Where &lt;PT&gt; is the payload type as defined by the [RFC2198PayloadType] parameter. The device sends the SIP INVITE message with "a=rtpmap:&lt;PT&gt; red/8000" and responds with a 18x/200 OK containing "a=rtpmap:&lt;PT&gt; red/8000" in the SDP.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Gateway application.</li> <li>■ For this feature to work, configure the [RTPRedundancyDepth] parameter to 1 (i.e., enabled).</li> <li>■ Currently, negotiation of the "red" payload type is not supported and therefore, should be configured to the same PT value for both parties.</li> </ul>
<p>'RFC 2198 Payload Type'</p> <pre>configure voip &gt; media rtp-rtcp &gt; RTP-redundancy- payload-type</pre> <p>[RFC2198PayloadType]</p>	<p>Defines the RTP redundancy packet payload type (according to RFC 2198).</p> <p>The valid value is 96 to 127. The default is 104.</p> <p><b>Note:</b></p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ The parameter is applicable only if you configure the [RTPRedundancyDepth] parameter to 1.</li> <li>■ The device ignores this parameter for Rx payload types and uses the payload type determined during SDP negotiation. For using this configured payload type, see the <a href="#">[BackwardPTBehavior]</a> on page 1780] parameter.</li> </ul>
'Packing Factor' [RTPPackingFactor]	N/A (controlled internally by the device according to the selected coder).
'RFC 2833 TX Payload Type' configure voip > media rtp-rtcp > telephony- events-payload-type-tx [RFC2833TxPayloadType]	<p>Defines the Tx RFC 2833 DTMF relay dynamic payload type for outbound calls.</p> <p>The valid range is 96 to 127. The default is 96.</p> <p><b>Note:</b> When RFC 2833 payload type negotiation is used (i.e., the parameter FirstTxDTMFOption is set to 4), this payload type is used for the received DTMF packets. If negotiation isn't used, this payload type is used for receive and for transmit.</p>
'RFC 2833 RX Payload Type' configure voip > media rtp-rtcp > telephony- events-payload-type-rx [RFC2833RxPayloadType]	<p>Defines the Rx RFC 2833 DTMF relay dynamic payload type for inbound calls.</p> <p>The valid range is 96 to 127. The default is 96.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The device ignores this parameter for Rx payload types and uses the payload type determined during SDP negotiation. For using this configured payload type, see the <a href="#">[BackwardPTBehavior]</a> on page 1780] parameter.</li> <li>■ When RFC 2833 payload type negotiation is used (i.e., the parameter [FirstTxDTMFOption] is set to 4), this payload type is used for the received DTMF packets. If negotiation isn't used, this payload type is used for receive and transmit.</li> </ul>
[EnableDetectRemoteMACChange]	Determines whether the device changes the RTP

Parameter	Description
	<p>packets according to the MAC address of received RTP packets and according to Gratuitous Address Resolution Protocol (GARP) messages.</p> <ul style="list-style-type: none"> <li>■ [0] = Nothing is changed.</li> <li>■ [1] = If the device receives RTP packets with a different source MAC address (than the MAC address of the transmitted RTP packets), then it sends RTP packets to this MAC address and removes this IP entry from the device's ARP cache table.</li> <li>■ [2] = (Default) The device uses the received GARP packets to change the MAC address of the transmitted RTP packets.</li> <li>■ [3] = Options 1 and 2 are used.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ If the device is located in a network subnet which is connected to other gateways using a router that uses Virtual Router Redundancy Protocol (VRRP) for redundancy, then set the parameter to 0 or 2.</li> </ul>
<p>'RTP Base UDP Port'</p> <pre>configure voip &gt; media rtp-rtcp &gt; base-udp-port [BaseUDPPort]</pre>	<p>Global parameter that defines the lower boundary of the UDP port used for RTP, RTCP (RTP port + 1) and T.38 (RTP port + 2). For more information on configuring the UDP port range, see <a href="#">Configuring RTP Base UDP Port</a> on page 295. The range of possible UDP ports is 6,000 to 65,535. The default base UDP port is 6000.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
<pre>configure voip &gt; media rtp-rtcp &gt; udp-port-spacing [UdpPortSpacing]</pre>	<p>Defines the port spacing ("jumps") of local UDP ports allocated by the device to media channels (legs) within the configured port range.</p> <ul style="list-style-type: none"> <li>■ [2] = The device allocates ports in "jumps" of 2 ports.</li> </ul>

Parameter	Description
	<p><b>Note:</b> For UDP port spacing of 2, you must configure the device to use the same port for RTP and T.38, by configuring the [T38UseRTPPort] ini file parameter to 1.</p> <ul style="list-style-type: none"> <li>■ [4] = The device allocates ports in "jumps" of 4 ports.</li> <li>■ [5] = The device allocates ports in "jumps" of 5 ports.</li> <li>■ [10] = (Default) The device allocates ports in "jumps" of 10 ports.</li> </ul> <p>For more information on configuring the UDP port range, port allocation and spacing, see <a href="#">Configuring RTP Base UDP Port</a> on page 295.</p> <p><b>Note:</b> A device restart is required for the parameter to take effect.</p>
<pre>configure voip &gt; gateway digital settings &gt; rtcp- act-mode</pre> <p>[RTCPActivationMode]</p>	<p>Disables RTCP traffic when there is no RTP traffic. This feature is useful, for example, to stop RTCP traffic that is typically sent when calls are put on hold (by an INVITE with 'a=inactive' in the SDP).</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Active Always - RTCP is active even during inactive RTP periods, i.e., when the media is in 'recvonly' or 'inactive' mode.</li> <li>■ [1] = Inactive only If RTP inactive - No RTCP is sent when RTP is inactive.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
<p>'T.38 Fax Session'</p> <pre>configure voip &gt; sip- definition settings &gt; t38- sess-imm-strt</pre> <p>[T38FaxSessionImmediateStart]</p>	<p>Enables fax transmission of T.38 "no-signal" packets to the terminating fax machine.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Immediate Start on Fax</b> = Device activates T.38 fax relay upon receipt of a re-INVITE with T.38 only in the SDP.</li> <li>■ [2] <b>Immediate Start on Fax &amp; Voice</b> = Device activates T.38 fax relay upon receipt of a re-INVITE with T.38 and audio media in the SDP.</li> </ul> <p>The parameter is used for transmission from fax</p>

Parameter	Description
	<p>machines connected to the device and located inside a NAT. Generally, the firewall blocks T.38 (and other) packets received from the WAN, unless the device behind NAT sends at least one IP packet from the LAN to the WAN through the firewall. If the firewall blocks T.38 packets sent from the termination IP fax, the fax fails.</p> <p>To overcome this, the device sends No-Op ("no-signal") packets to open a pinhole in the NAT for the answering fax machine. The originating fax doesn't wait for an answer, but immediately starts sending T.38 packets to the terminating fax machine.</p> <p><b>Note:</b> To enable No-Op packet transmission, use the [NoOpEnable] and [NoOpInterval] parameters.</p>
<pre>configure voip &gt; sip- definition settings &gt; t38- use-rtpp-port [T38UseRTTPort]</pre>	<p>Defines the port (with relation to RTP port) for sending and receiving T.38 packets.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Use the RTP port +2 to send/receive T.38 packets.</li> <li>■ [1] = Use the same port as the RTP port to send/receive T.38 packets.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ When the device is configured to use V.152 to negotiate audio and T.38 coders, the UDP port published in SDP for RTP and for T38 must be different. Therefore, set the T38UseRTTPort parameter to 0.</li> </ul>
<p>'T38 Fax Max Buffer'</p> <pre>configure voip &gt; sip- definition settings &gt; t38- fax-mx-buff [T38FaxMaxBufferSize]</pre>	<p>Defines the maximum size (in bytes) of the device's T.38 buffer. This value is included in the outgoing SDP when T.38 is used for fax relay over IP.</p> <p>The valid range is 500 to 3000. The default is 3,000.</p>
<b>QoE Parameters</b>	

Parameter	Description
[QoEMediaStatisticTimer]	<p>Defines the interval (in msec) for QoE collection and report generation.</p> <p>The valid value range is 0 to 65,535. The default is 30,000 (i.e., 30 seconds).</p> <p>For more information, see <a href="#">Configuring Interval for QoE Report Collection and Generation</a> on page 519.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> </ul>
<b>No-Op Packets Parameters</b>	
no-operation-enable [NoOpEnable]	<p>Enables the device to send RTP or T.38 No-Op packets during RTP or T.38 silence periods. This mechanism ensures that the NAT binding remains open.</p> <ul style="list-style-type: none"> <li>■ [0] = Disable (default)</li> <li>■ [1] = Enable</li> </ul> <p><b>Note:</b> You can also enable the feature per IP Profile (for SBC calls only), using the 'Generate No-Op Packets' IP Profile parameter.</p>
[NoOpInterval]	<p>Defines the interval (msec) between each RTP or T.38 No-Op packet sent by the device during the silence period (i.e., no RTP/T.38 traffic).</p> <p>The valid range is 20 to 600,000. The default is 1,000.</p> <p><b>Note:</b> To enable No-Op packet transmission, use the [NoOpEnable] parameter.</p>
no-operation-interval [RTPNoOpPayloadType]	<p>Defines the payload type of No-Op packets.</p> <p>The valid range is 96 to 127. For the range of Dynamic RTP Payload Type for all types of non hard-coded RTP Payload types, refer to RFC 3551. The default is 120.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if the IP Profile parameter 'Generate No-Op Packets' is enabled, or the <a href="#">[[BackwardPTBehavior]</a> on</li> </ul>

Parameter	Description
	<p>page 1780] parameter is enabled.</p> <ul style="list-style-type: none"> <li>■ When configuring the parameter, make sure that its settings don't cause collisions with other payload types.</li> <li>■ The device ignores this parameter for Rx payload types and uses it only for Tx payload types.</li> </ul>
<b>RTP Control Protocol Extended Reports (RTCP XR) Parameters</b> For more information on RTCP XR, see <a href="#">Configuring RTCP XR</a> on page 1374.	
'Enable RTCP XR' <pre>configure voip &gt; media rtp-rtcp &gt; voice-quality- monitoring-enable</pre> [VQMonEnable]	Enables voice quality monitoring and RTCP XR, according to RFC 3611. <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable Fully</b> = Calculates voice quality metrics, uses them for QoE calculations, reports them to OVOC (if configured), and sends them to remote side using RTCP XR.</li> <li>■ [2] <b>Enable Calculation Only</b> = Calculates voice quality metrics, uses them for QoE calculations, reports them to OVOC (if configured), but doesn't send them to remote side using RTCP XR.</li> </ul>
'Minimum Gap Size' [VQMonGMin]	Defines the voice quality monitoring - minimum gap size (number of frames). The default is 16.
'Burst Threshold' [VQMonBurstHR]	Defines the voice quality monitoring - excessive burst alert threshold. The default is -1 (i.e., no alerts are issued).
'Delay Threshold' [VQMonDelayTHR]	Defines the voice quality monitoring - excessive delay alert threshold. The default is -1 (i.e., no alerts are issued).
'R-Value Delay Threshold' [VQMonEOCRValTHR]	Defines the voice quality monitoring - end of call low quality alert threshold. The default is -1 (i.e., no alerts are issued).
'Tx RTCP Packets Interval'	Defines the time interval (in msec) between

Parameter	Description
<pre>configure voip &gt; media rtp-rtcp &gt; rtcp-interval [RTCPInterval]</pre>	<p>adjacent RTCP XR reports. This interval starts from call establishment. Thus, the device can send RTCP XR reports during the call, in addition to at the end of the call. If the duration of the call is shorter than this interval, RTCP XR is sent only at the end of the call.</p> <p>The valid value range is 0 to 65,535. The default is 5,000.</p>
<p>'Disable RTCP XR Interval Randomization'</p> <pre>configure voip &gt; media rtp-rtcp &gt; disable-RTCP- randomization [DisableRTCPRandomize]</pre>	<p>Determines if RTCP report intervals are randomized or each report interval is according to the [RTCPInterval] parameter.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. RTCP report intervals are randomized</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled. Each report interval is according to the [RTCPInterval] parameter.</li> </ul>
<p>'Gateway RTCP XR Report Mode'</p> <pre>configure voip &gt; sip- definition settings &gt; rtcp-xr-rep-mode [RTCPXRReportMode]</pre>	<p>Enables the device to send RTCP XR in SIP PUBLISH messages and defines the interval at which they are sent.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) RTCP XR is not sent.</li> <li>■ [1] <b>End Call</b> = RTCP XR is sent at the end of the call.</li> <li>■ [2] <b>End Call &amp; Periodic</b> = RTCP XR is sent at the end of the call and periodically according to the RTCPInterval parameter.</li> <li>■ [3] <b>End Call &amp; End Segment</b> = RTCP XR is sent at the end of the call and at the end of each media segment of the call. A media segment is a change in media, for example, when the coder is changed or when the caller toggles between two called parties (using call hold/retrieve). The RTCP XR sent at the end of a media segment contains information only of that segment. If the segment doesn't contain RTP/RTCP content, the RTCP XR is not sent. For call hold, the device sends an RTCP XR each time the call is placed on hold and each time it is retrieved. In addition, the Start</li> </ul>



Parameter	Description
	<p>timestamp in the RTCP XR indicates the start of the media segment; the End timestamp indicates the time of the last sent periodic RTCP XR (typically, up to 5 seconds before reported segment ends).</p> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
'Publication IP Group ID' <code>publication-ip-group-id</code> [PublicationIPGroupID]	<p>Defines the IP Group to where the device sends RTCP XR reports.</p> <p>By default, no value is defined.</p>
'SBC RTCP XR Report Mode' <code>configure voip &gt; sip-definition settings &gt; sbc-rtcpxr-report-mode</code> [SBCRtcpXrReportMode]	<p>Enables the sending of RTCP XR reports of QoE metrics at the end of each call session (i.e., after a SIP BYE). The RTCP XR is sent in the SIP PUBLISH message.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>End of Call</b></li> </ul> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>

## Gateway Application Parameters

this section describes the parameters of the Gateway application.

## Fax and Modem Parameters

The fax and modem parameters are described in the table below.

**Table 69-39:Fax and Modem Parameters**

Parameter	Description
'Fax Transport Mode' <code>configure voip &gt; media fax-modem &gt; fax-transport-mode</code> [FaxTransportMode]	<p>Determines the fax transport mode used by the device.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = transparent mode</li> <li>■ [1] <b>T.38 Relay</b> (default)</li> <li>■ [2] <b>Bypass</b></li> <li>■ [3] <b>Events Only</b></li> </ul>

Parameter	Description
	<p><b>Note:</b> The parameter is overridden by the parameter [IsFaxUsed]. If the parameter [IsFaxUsed] is set to 1 (T.38 Relay) or 3 (Fax Fallback), then [FaxTransportMode] is always set to 1 (T.38 relay).</p>
V34-fax-transport-type [V34FaxTransportType]	<p>Determines the V.34 fax transport method (whether V34 fax falls back to T.30 or pass over Bypass).</p> <ul style="list-style-type: none"> <li>■ [0] = Transparent</li> <li>■ [1] = (Default) Relay</li> <li>■ [2] = Bypass</li> <li>■ [3] = Transparent with Events</li> </ul> <p><b>Note:</b> To configure [V34FaxTransportType] to [1] (i.e., fax relay), you also need to configure [FaxTransportMode] to [1] (fax relay).</p>
'V.21 Modem Transport Type' configure voip > media fax-modem > V21-modem-transport-type [V21ModemTransportType]	<p>Determines the V.21 modem transport type.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) Transparent.</li> <li>■ [2] <b>Enable Bypass</b></li> <li>■ [3] <b>Events Only</b> = Transparent with Events.</li> </ul> <p><b>Note:</b> You can also configure this feature per specific calls, using IP Profiles ('Vxx Modem Transport Type' parameter). For more information, see <a href="#">Configuring IP Profiles</a> on page 664.</p>
'V.22 Modem Transport Type' configure voip > media fax-modem > V22-modem-transport-type [V22ModemTransportType]	<p>Determines the V.22 modem transport type.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = Transparent.</li> <li>■ [2] <b>Enable Bypass</b> (default)</li> <li>■ [3] <b>Events Only</b> = Transparent with Events.</li> </ul>

Parameter	Description
	<p><b>Note:</b> You can also configure this feature per specific calls, using IP Profiles ('Vxx Modem Transport Type' parameter). For more information, see <a href="#">Configuring IP Profiles</a> on page 664.</p>
<p>'V.23 Modem Transport Type'</p> <pre>configure voip &gt; media fax-modem &gt; V23-modem-transport-type</pre> <p>[V23ModemTransportType]</p>	<p>Determines the V.23 modem transport type.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = Transparent.</li> <li>■ [2] <b>Enable Bypass</b> (default)</li> <li>■ [3] <b>Events Only</b> = Transparent with Events.</li> </ul> <p><b>Note:</b> You can also configure this feature per specific calls, using IP Profiles ('Vxx Modem Transport Type' parameter). For more information, see <a href="#">Configuring IP Profiles</a> on page 664.</p>
<p>'V.32 Modem Transport Type'</p> <pre>configure voip &gt; media fax-modem &gt; V32-modem-transport-type</pre> <p>[V32ModemTransportType]</p>	<p>Determines the V.32 modem transport type.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = Transparent.</li> <li>■ [2] <b>Enable Bypass</b> (default)</li> <li>■ [3] <b>Events Only</b> = Transparent with Events.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter applies only to V.32 and V.32bis modems.</li> <li>■ You can also configure this feature per specific calls, using IP Profiles ('Vxx Modem Transport Type' parameter). For more information, see <a href="#">Configuring IP Profiles</a> on page 664.</li> </ul>
<p>'V.34 Modem Transport Type'</p> <pre>configure voip &gt; media fax-modem &gt; V34-modem-transport-type</pre> <p>[V34ModemTransportType]</p>	<p>Determines the V.90/V.34 modem transport type.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = Transparent.</li> <li>■ [2] <b>Enable Bypass</b> (default)</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [3] <b>Events Only</b> = Transparent with Events.</li> </ul> <p><b>Note:</b> You can also configure this feature per specific calls, using IP Profiles ('Vxx Modem Transport Type' parameter). For more information, see <a href="#">Configuring IP Profiles</a> on page 664.</p>
bell-modem-transport-type [BellModemTransportType]	<p>Determines the Bell modem transport method.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) Transparent.</li> <li>■ [2] <b>Enable Bypass</b></li> <li>■ [3] <b>Events Only</b> = Transparent with Events.</li> </ul>
'Fax CNG Mode' configure voip > media fax-modem > fax_cng_mode [FaxCNGMode]	<p>Determines the device's handling of fax relay upon detection of a fax CNG tone or a V.34/Super G3 V8-CM (Call Menu) signal from originating faxes.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Doesn't send T.38 Re-INVITE</b> = (Default) SIP re-INVITE is not sent.</li> <li>■ [1] <b>Sends on CNG tone</b> = Sends a SIP re-INVITE with T.38 parameters in SDP to the terminating fax upon detection of a fax CNG tone, if the CNGDetectorMode parameter is set to 1.</li> <li>■ [2] <b>Sends on CNG or v8-cn</b> = Sends a SIP re-INVITE with T.38 parameters in SDP to the terminating fax upon detection of a fax CNG tone (if the CNGDetectorMode parameter is set to 1) or upon detection of a V8-CM signal.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If the parameter is set to [2] and the CNGDetectorMode parameter is set to [0], the device sends a re-INVITE only if it detects a V8-CM signal from</li> </ul>

Parameter	Description
	<p>the originating fax.</p> <ul style="list-style-type: none"> <li>■ This feature is applicable only if the <code>IsFaxUsed</code> parameter is set to [1] or [3].</li> <li>■ The device also sends T.38 re-INVITE if the <code>CNGDetectorMode</code> parameter is set to [2], regardless of the <code>FaxCNGMode</code> parameter settings.</li> </ul>
<p>'CNG Detector Mode'</p> <pre>configure voip &gt; media fax-modem &gt; coder</pre> <p>[CNGDetectorMode]</p>	<p>Global parameter that enables the detection of the fax calling tone (CNG) and defines the detection method. You can also configure this feature per specific calls, using IP Profiles ('CNG Detector Mode' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b> If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</p>
<p>'Fax Detect Timeout Since Connect'</p> <pre>fax-detect-timeout-since-connect</pre> <p>[FaxDetectTimeoutSinceConnect]</p>	<p>Defines a timeout (in msec) for detecting fax from the Tel side during an established voice call. The interval starts from when the voice call is established. If the device detects a fax tone within the interval, it ends the voice session and sends a T.38 or VBD re-INVITE message to the IP side and processes the fax. If the interval expires without any received fax event, the device ignores all subsequent fax events during the voice session.</p> <p>The valid value is 0 to 120000. The default is 0. If set to 0, the device can detect fax during the entire voice call.</p> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>

Parameter	Description
<p>'SIP T.38 Version'</p> <pre>configure voip &gt; sip-definition settings &gt; sip-t38-ver</pre> <p>[SIPT38Version]</p>	<p>Defines the T.38 fax relay version.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> = (Default) No T.38</li> <li>■ [0] <b>Version 0</b></li> <li>■ [3] <b>Version 3</b> = T.38 Version 3 (V.34 over T.38)</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Interworking of T.38 Version 3 is supported only for Gateway calls. For SBC calls, the device forwards T.38 Version 3 transparently (as is) to the other leg (i.e., no transcoding).</li> <li>■ For a description on V.34 over T.38 fax relay, see <a href="#">V.34 Fax Support</a> on page 285.</li> </ul>
<pre>configure voip &gt; media fax-modem &gt; rx-t38-over-rtp-payload-type</pre> <p>[RxT38OverRTPPayloadType]</p>	<p>Defines the received T.38 over RTP payload type.</p> <p>The valid range is 96 to 127. The default is 106.</p> <p><b>Note:</b> The device ignores this parameter for Rx payload types and uses the payload type determined during SDP negotiation. For using this configured payload type, see the <a href="#">[BackwardPTBehavior]</a> parameter.</p>
<p>'Fax Relay Enhanced Redundancy Depth'</p> <pre>configure voip &gt; media fax-modem &gt; enhanced-redundancy-depth</pre> <p>[FaxRelayEnhancedRedundancyDepth]</p>	<p>Defines the number of times that control packets are retransmitted when using the T.38 standard.</p> <p>The valid range is 0 to 4. The default is .</p>
<p>'Fax Relay Redundancy Depth'</p> <pre>configure voip &gt; media fax-modem &gt; redundancy-depth</pre> <p>[FaxRelayRedundancyDepth]</p>	<p>Defines the number of times that each fax relay payload is retransmitted to the network.</p> <ul style="list-style-type: none"> <li>■ [0] <b>0</b> = (Default) No redundancy</li> <li>■ [1] <b>1</b> = One-packet redundancy</li> <li>■ [2] <b>2</b> = Two-packet redundancy</li> </ul>

Parameter	Description
	<p><b>Note:</b> The parameter is applicable only to non-V.21 packets.</p>
<p>'Fax Relay Max Rate' (bps)</p> <pre>configure voip &gt; media fax-modem &gt; max-rate</pre> <p>[FaxRelayMaxRate]</p>	<p>Defines the maximum rate (in bps) at which fax relay messages are transmitted (outgoing calls).</p> <ul style="list-style-type: none"> <li>■ [0] <b>2400</b> = 2.4 kbps</li> <li>■ [1] <b>4800</b> = 4.8 kbps</li> <li>■ [2] <b>7200</b> = 7.2 kbps</li> <li>■ [3] <b>9600</b> = 9.6 kbps</li> <li>■ [4] <b>12000</b> = 12.0 kbps</li> <li>■ [5] <b>14400</b> = 14.4 kbps (default)</li> <li>■ [6] <b>16800bps</b> = 16.8 kbps</li> <li>■ [7] <b>19200bps</b> = 19.2 kbps</li> <li>■ [8] <b>21600bps</b> = 21.6 kbps</li> <li>■ [9] <b>24000bps</b> = 24 kbps</li> <li>■ [10] <b>26400bps</b> = 26.4 kbps</li> <li>■ [11] <b>28800bps</b> = 28.8 kbps</li> <li>■ [12] <b>31200bps</b> = 31.2 kbps</li> <li>■ [13] <b>33600bps</b> = 33.6 kbps</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The rate is negotiated between both sides (i.e., the device adapts to the capabilities of the remote side). Negotiation of the T.38 maximum supported fax data rate is provided in SIP's SDP [T38MaxBitRate] parameter. The negotiated [T38MaxBitRate] is the minimum rate supported between the local and remote endpoints.</li> <li>■ Fax relay rates greater than 14.4 kbps are applicable only to V.34 / T.38 fax relay. For non-T.38 V.34 supporting devices, configuration</li> </ul>

Parameter	Description
	greater than 14.4 kbps is truncated to 14.4 kbps.
'Fax Relay ECM Enable' configure voip > media fax-modem > ecm-mode [FaxRelayECMEnable]	Enables Error Correction Mode (ECM) mode during fax relay.  ■ [0] Check box cleared <input type="checkbox"/> = Disabled. ■ [1] Check box selected <input checked="" type="checkbox"/> = (Default) Enabled.
'Fax/Modem Bypass Coder Type' [FaxModemBypassCoderType]	Determines the coder used by the device when performing fax/modem bypass. Typically, high-bit-rate coders such as G.711 should be used.  ■ [0] <b>G.711Alaw</b> = (Default) G.711 A-law 64 ■ [1] <b>G.711Mulaw</b> = G.711 Mu-law
configure voip > media fax-modem > fax-modem-telephony-events-mode [FaxModemNTEMode]	Determines whether the device sends RFC 2833 ANS/ANSam events upon detection of fax and/or modem Answer tones (i.e., CED tone).  ■ [0] = Disabled (default) ■ [1] = Enabled  <b>Note:</b> The parameter is applicable only when the fax or modem transport type is set to bypass or Transparent-with-Events.
'Fax Bypass Payload Type' configure voip > media rtp-rtcp > fax-bypass-payload-type [FaxBypassPayloadType]	Defines the fax bypass RTP dynamic payload type. The valid range is 0 to 127. The default is 102.  <b>Note:</b> The device ignores this parameter for Rx payload types and uses the payload type determined during SDP negotiation. For using this configured payload type, see the <a href="#">[BackwardPTBehavior]</a> parameter.
'Modem Bypass Payload Type'	Defines the modem bypass dynamic



Parameter	Description
<pre>configure voip &gt; media rtp-rtcp &gt; modem-bypass-payload-type</pre> <p>[ModemBypassPayloadType]</p>	<p>payload type.</p> <p>The range is 0 to 127. The default is 103.</p> <p><b>Note:</b> The device ignores this parameter for Rx payload types and uses the payload type determined during SDP negotiation. For using this configured payload type, see the <a href="#">[BackwardPTBehavior]</a> parameter.</p>
<p>'Enable RFC 3389 CN Payload Type'</p> <pre>configure voip &gt; media rtp-rtcp &gt; enable-standard-sid-payload-type</pre> <p>[EnableStandardSIDPayloadType]</p>	<p>Enables sending and receiving of Silence Indicator (SID) packets according to RFC 3389.</p> <p>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</p> <p>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</p>
<p>volume</p> <p>[FaxModemRelayVolume]</p>	<p>Defines the fax gain control.</p> <p>The range is -18 to -3, corresponding to -18 dBm to -3 dBm in 1-dB steps. The default is -6 dBm fax gain control.</p>
<p>'Fax Bypass Output Gain'</p> <pre>configure voip &gt; media fax-modem &gt; fax-bypass-output-gain</pre> <p>[FaxBypassOutputGain]</p>	<p>Defines the fax bypass output gain control.</p> <p>The range is -31 to +31 dB, in 1-dB steps. The default is 0 (i.e., no gain).</p>
<p>'Modem Bypass Output Gain'</p> <pre>configure voip &gt; media fax-modem &gt; modem-bypass-output-gain</pre> <p>[ModemBypassOutputGain]</p>	<p>Defines the modem bypass output gain control.</p> <p>The range is -31 dB to +31 dB, in 1-dB steps. The default is 0 (i.e., no gain).</p>
<p>modem-bypass-output-gain</p> <p>[FaxModemBypassBasicRTPPacketInterval]</p>	<p>Defines the basic frame size used during fax/modem bypass sessions.</p> <p>■ [0] = (Default) Determined internally</p> <p>■ [1] = 5 msec (not recommended)</p> <p>■ [2] = 10 msec</p> <p>■ [3] = 20 msec</p> <p><b>Note:</b> When set to 5 msec (1), the maximum number of simultaneous channels supported is 120.</p>

Parameter	Description
jitter-buffer-minimum-delay [FaxModemBypasDJBufMinDelay]	<p>Defines the Jitter Buffer delay (in milliseconds) during fax and modem bypass session.</p> <p>The range is 0 to 150 msec. The default is 40.</p>
enable-fax-modem-inband-network-detection [EnableFaxModemInbandNetworkDetection]	<p>Enables in-band network detection related to fax/modem.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable.</li> <li>■ [1] = Enable. When the parameter is enabled on Bypass and transparent with events mode (VxxTransportType is set to 2 or 3), a detection of an Answer Tone from the network triggers a switch to bypass mode in addition to the local Fax/Modem tone detections. However, only a high bit-rate coder voice session effectively detects the Answer Tone sent by a remote endpoint. This can be useful when, for example, the payload of voice and bypass is the same, allowing the originator to switch to bypass mode as well.</li> </ul>
NSE-mode [NSEMode]	<p>Global parameter that enables Cisco's compatible fax and modem bypass mode, Named Signaling Event (NSE) packets. You can also configure this feature per specific calls, using IP Profiles ('NSE Mode' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b> If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</p>
NSE-payload-type	<p>Defines the NSE payload type for Cisco</p>

Parameter	Description
[NSEPayloadType]	<p>Bypass compatible mode.</p> <p>The valid range is 96-127. The default is 105.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Cisco gateways usually use NSE payload type of 100.</li> <li>■ The device ignores this parameter for Rx payload types and uses the payload type determined during SDP negotiation. For using this configured payload type, see the <a href="#">[BackwardPTBehavior]</a> parameter.</li> </ul>
<p>'T.38 Max Datagram Size'</p> <pre>configure voip &gt; sip-definition settings &gt; t38-mx-datagram-sz</pre> <p>[T38MaxDatagramSize]</p>	<p>Defines the maximum size of a T.38 datagram that the device can receive. This value is included in the outgoing SDP when T.38 is used.</p> <p>The valid range is 120 to 600. The default is 560 .</p>
<p>'Detect Fax on Answer Tone'</p> <pre>det-fax-on-ans-tone</pre> <p>[DetFaxOnAnswerTone]</p>	<p>Determines when the device initiates a T.38 session for fax transmission.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Initiate T.38 on Preamble</b> = (Default) The device to which the called fax is connected initiates a T.38 session on receiving . Preamble signal from the fax.</li> <li>■ [1] <b>Initiate T.38 on CED</b> = The device to which the called fax is connected initiates a T.38 session on receiving a CED answer tone from the fax. This option can only be used to relay fax signals, as the device sends T.38 Re-INVITE on detection of any fax/modem Answer tone (2100 Hz, amplitude modulated 2100 Hz, or 2100 Hz with phase reversals). The modem signal fails when using T.38 for fax relay.</li> </ul> <p><b>Note:</b> The parameters is applicable only</p>

Parameter	Description
	if the [IsFaxUsed] parameter is set to 1 (T.38 Relay) or 3 (Fax Fallback).
<p>'CED Transfer Mode'</p> <pre>configure voip &gt; media fax-modem &gt; ced-transfer-mode</pre> <p>[CEDTransferMode]</p>	<p>Defines the method for sending fax/modem CED (answering) tones.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Fax Relay or VBD</b> = (Default) The device transfers the CED tone in Relay mode and starts the fax session immediately.</li> <li>■ [1] <b>Voice Mode or VBD</b> = The device transfers the CED tone in either Voice or Bypass mode and starts the fax session on V21 preamble.</li> <li>■ [2] <b>RFC 4733 Blocking RTP VBD</b> = The device transfers the CED tone in RFC 2833.</li> <li>■ [3] <b>RFC 4733 Along with RTP VBD</b> = The device transfers the CED tone in RFC 2833 and bypass, in parallel.</li> </ul>
<pre>configure voip &gt; sip-definition settings &gt; backward-pt-behavior</pre> <p>[BackwardPTBehavior]</p>	<p>Enables backward compatibility for the following parameters that configure Rx payload types for media features (e.g., RFC 2833 DTMF, RTP redundancy, and fax bypass): [FaxBypassPayloadType], [ModemBypassPayloadType], [RxT38OverRTTPPayloadType], [V1501SSEPayloadTypeRx], [V1501SPRTPayloadTypeRx], [NSEPayloadType], [RFC2833RxPayloadType], and [RFC2198PayloadType].</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disables backward compatibility. The device only supports media features that are negotiated in SDP (and ignores the configured payload types).</li> <li>■ [1] = Enables backward compatibility. The device supports media features by using the configured payload types.</li> </ul>

## DTMF and Hook-Flash Parameters

The DTMF and hook-flash parameters are described in the table below.

**Table 69-40:DTMF and Hook-Flash Parameters**

Parameter	Description
<b>Hook-Flash Parameters</b>	
<p>'Hook-Flash Code'</p> <pre>configure voip &gt; gateway dtmf-suppress-service suppress- service-settings &gt; hook- flash-code</pre> <p>[HookFlashCode]</p>	<p>Defines the digit pattern used by the PBX to indicate a Hook Flash event. When this pattern is detected from the Tel side, the device responds as if a Hook Flash event has occurred and sends a SIP INFO message if the HookFlashOption parameter is set to 1, 5, 6, or 7 (indicating a Hook Flash). If configured and a Hook Flash indication is received from the IP side, the device generates this pattern to the Tel side.</p> <p>The valid range is a 25-character string. The default is a null string.</p> <p><b>Note:</b> The parameter can also be configured in a Tel Profile.</p>
<p>'Hook-Flash Option'</p> <pre>configure voip &gt; gateway dtmf-suppress-service dtmf- and-dialing &gt; hook-flash- option</pre> <p>[HookFlashOption]</p>	<p>Defines the hook-flash transport type (i.e., method by which hook-flash is sent and received). The feature is applicable only if the HookFlashCode parameter is configured.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Not Supported</b> = (Default) Hook-Flash indication is not sent.</li> <li>■ [1] <b>INFO</b> = Sends proprietary INFO message (Broadsoft) with Hook-Flash indication.</li> </ul> <p>The device sends the INFO message as follows:</p> <pre>Content-Type: application/broadsoft; version=1.0 Content-Length: 17 event flashhook</pre> <ul style="list-style-type: none"> <li>■ [4] <b>RFC 2833</b> = This option is currently not supported for digital interfaces.</li> <li>■ [5] <b>INFO (Lucent)</b> = Sends proprietary SIP INFO message with Hook-Flash indication.</li> </ul>

Parameter	Description
	<p>The device sends the INFO message as follows:</p> <pre>Content-Type: application/hook-flash Content-Length: 11 signal=hf</pre> <p>■ <b>[6] INFO (NetCentrex)</b> = Sends proprietary SIP INFO message with Hook-Flash indication. The device sends the INFO message as follows:</p> <pre>Content-Type: application/dtmf-relay Signal=16</pre> <p>Where 16 is the DTMF code for hook flash.</p> <p>■ <b>[7] INFO (HUAWEI)</b> = Sends a SIP INFO message with Hook-Flash indication. The device sends the INFO message as follows:</p> <pre>Content-Length: 17 Content-Type: application/sscc event=flashhook</pre> <p><b>Note:</b></p> <p>■ The device can interwork DTMF HookFlashCode to SIP INFO messages with Hook Flash indication.</p>
<pre>configure voip &gt; gw dtmf- and-suppl &gt; gw digitalgw digital-gw-parameters &gt; flash-from-media-ip [HookFlashFromMediaIP]</pre>	<p>Defines the device's handling of hook-flash telephony events that are received in the media (RTP) from the IP side (typically, RFC 2833) and then sent to the PSTN CAS side.</p> <p>■ <b>[0]</b> = (Default) The device ignores incoming hook-flash events from the media IP.</p> <p>■ <b>[1]</b> = The device generates a wink to the CAS side when it receives a hook-flash event from the media IP.</p> <p><b>Note:</b> The parameter is applicable only to E1/T1 CAS.</p>
<b>DTMF Parameters</b>	
<code>notify-on-sig-end</code>	Determines when the detection of DTMF events is

Parameter	Description
[MGCPDTMFDetectionPoint]	<p>notified.</p> <ul style="list-style-type: none"> <li>■ [0] = DTMF event is reported at the end of a detected DTMF digit.</li> <li>■ [1] = (Default) DTMF event is reported at the start of a detected DTMF digit.</li> </ul>
<p>'Declare RFC 2833 in SDP'</p> <pre>configure voip &gt; gateway dtmf-suppress-service dtmf- and-dialing &gt; rfc-2833- in-sdp</pre> <p>[RxDTMFOption]</p>	<p>Global parameter that enables the device to declare the RFC 2833 'telephony-event' parameter in the SDP. You can also configure this feature per specific calls, using IP Profiles ('Rx DTMF Option' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b> If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</p>
<p>'First Tx DTMF Option'</p> <pre>configure voip &gt; gateway dtmf-suppress-service dtmf- and-dialing &gt; first-dtmf- option-type</pre> <p>[FirstTxDTMFOption]</p>	<p>Defines the first preferred transmit (Tx) DTMF negotiation method.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Not Supported</b> = (Default) No negotiation. DTMF digits are sent according to the [DTMFTransportType] and [RFC2833PayloadType] parameters. The RFC 2833 payload type is according to the [RFC2833PayloadType] parameter for transmit and receive.</li> <li>■ [1] <b>Info NORTEL</b> = Sends DTMF digits according to IETF Internet-Draft draft-choudhuri-sip-info-digit-00.</li> <li>■ [2] <b>NOTIFY</b> = Sends DTMF digits according to IETF Internet-Draft draft-mahy-sipping-signaled-digits-01.</li> <li>■ [3] <b>Info Cisco</b> = Sends DTMF digits according to Cisco format.</li> <li>■ [4] <b>RFC 2833</b> = The device handles DTMF as follows: <ul style="list-style-type: none"> <li>✓ Negotiates RFC 2833 payload type using local and remote SDPs.</li> </ul> </li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>✓ Sends DTMF packets using RFC 2833 payload type according to the payload type in the received SDP.</li> <li>✓ Expects to receive RFC 2833 packets with the same payload type according to the RFC2833PayloadType parameter.</li> <li>✓ Removes DTMF digits in transparent mode (as part of the voice stream).</li> </ul> <p>■ [5] <b>Info KOREA</b> = Sends DTMF digits according to Korea Telecom format.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ When out-of-band DTMF transfer is used -- [1], [2], [3], or [5] -- the [DTMFTransportType] parameter is automatically set to [0] (i.e., DTMF digits are erased from the RTP stream).</li> <li>■ If an ISDN phone user presses digits (e.g., for interactive voice response / IVR applications such as retrieving voice mail messages), ISDN Information messages received by the device for each digit are sent in the voice channel to the IP network as DTMF signals, according to the settings of the parameter.</li> <li>■ For more information on DTMF transport, see <a href="#">Configuring DTMF Transport Types</a> on page 293.</li> <li>■ You can also configure the parameter per specific calls, using IP Profiles ('First Tx DTMF Option' parameter). To configure IP Profiles, see <a href="#">Configuring IP Profiles</a> on page 664.</li> </ul>
<p>'Second Tx DTMF Option'</p> <pre>configure voip &gt; gateway dtmf-supp-service dtmf- and-dialing &gt; second- dtmf-option-type [SecondTxDTMFOption]</pre>	<p>Defines the second preferred transmit (Tx) DTMF negotiation method. The first preferred method is configured by the FirstTxDTMFOption parameter. For a description of the optional values for the parameter, see the FirstTxDTMFOption parameter above.</p> <p><b>Note:</b> You can also configure the parameter per specific calls, using IP Profiles ('Second Tx DTMF Option' parameter). To configure IP Profiles, see</p>



Parameter	Description
	<a href="#">Configuring IP Profiles</a> on page 664.
[AdditionalOutOfBandDtmfFormat]	<p>Enables the device to simultaneously send DTMF tones (signals) in SIP messages such as INFO messages (out-of-band) and in RTP media streams (in-band) with a special payload type (as defined in RFC 2833), when the FirstTxDTMFOption parameter is configured to 4. The parameter must be configured to the method for transporting DTMF digits over the IP network to the remote endpoint. For more information on DTMF transport, see <a href="#">Configuring DTMF Transport Types</a> on page 293.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) DTMF is sent according to FirstTxDTMFOption.</li> <li>■ [1] = Nortel</li> <li>■ [2] = Cisco</li> <li>■ [3] = Threecom</li> <li>■ [4] = Korea</li> </ul>
<pre>configure voip &gt; gateway dtmf-supp-service dtmf- and-dialing &gt; auto-dtmf- mute</pre> <p>[DisableAutoDTMFMute]</p>	<p>Enables the automatic muting of DTMF digits when out-of-band DTMF transmission is used.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Automatic mute is used.</li> <li>■ [1] = No automatic mute of in-band DTMF.</li> </ul> <p>When the parameter is set to [1], the DTMF transport type is set according to the parameter [DTMFTransportType] and the DTMF digits aren't muted if out-of-band DTMF mode is selected -- [FirstTxDTMFOption] set to [1], [2] or [3]. This enables the sending of DTMF digits in-band (transparent of RFC 2833) in addition to out-of-band DTMF messages.</p> <p><b>Note:</b> This mode is usually not recommended.</p>
<p>'Enable Digit Delivery to IP'</p> <pre>configure voip &gt; sip- definition settings &gt; digit-delivery-2ip</pre> <p>[EnableDigitDelivery2IP]</p>	<p>Enables the Digit Delivery feature, which sends DTMF digits to the destination IP address after the Tel-to-IP call is answered.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul>

Parameter	Description
	<p>To enable this feature, modify the called number to include at least one 'p' character. The device uses the digits before the 'p' character in the initial INVITE message. After the call is answered, the device waits for the required time (number of 'p' multiplied by 1.5 seconds), and then sends the rest of the DTMF digits using the method chosen (in-band or out-of-band).</p> <p><b>Note:</b> The called number can include several 'p' characters (1.5 seconds pause), for example, 1001pp699, 8888p9p300.</p>
<p>'Enable Digit Delivery to Tel'</p> <pre>configure voip &gt; sip- definition settings &gt; digit-delivery-2tel [EnableDigitDelivery]</pre>	<p>Global parameter enabling the Digit Delivery feature, which sends DTMF digits of the called number to the Tel side (analog port or B-channel for digital interfaces) after the call is answered for IP-to-Tel calls.</p> <p>You can also configure the feature per specific calls, using Tel Profiles ('Enable Digit Delivery' parameter). For a detailed description of the parameter and To configure the feature in the Tel Profiles table, see <a href="#">Configuring Tel Profile</a> on page 738.</p> <p><b>Note:</b> If the feature is configured for a specific Tel Profile, the settings of the global parameter is ignored for calls associated with the Tel Profile.</p>
<p>'Special Digit Representation'</p> <pre>configure voip &gt; gateway dtmf-supp-service dtmf- and-dialing &gt; special- digit-rep [UseDigitForSpecialDTMF]</pre>	<p>Defines the representation for 'special' digits ('*' and '#') that are used for out-of-band DTMF signaling (using SIP INFO/NOTIFY).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Special</b> = (Default) Uses the strings '*' and '#'.</li> <li>■ [1] <b>Numeric</b> = Uses the numerical values 10 and 11.</li> </ul>
<pre>isdn-keypad-mode [ISDNKeypadMode]</pre>	<p>Enables the device to send DTMF digits received in the called party number from the IP side, as Keypad facility IE in ISDN INFORMATION messages to PSTN.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Don't send - all digits are sent as DTMF to PSTN (i.e., not sent as Keypad).</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [1] = During Call Establishment - DTMF digits after * or # (inclusive) are sent as Keypad only during call establishment and call disconnect. During an established call, all digits are sent as DTMF.</li> <li>■ [2] = Always - DTMF digits after * or # (inclusive) are always sent as Keypad (call establishment, connect, and disconnect).</li> </ul> <p>For more information, see <a href="#">Interworking Keypad DTMFs for SIP-to-ISDN Calls</a> on page 994.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ This feature is not applicable to re-INVITE messages.</li> </ul>

## Digit Collection and Dial Plan Parameters

The digit collection and dial plan parameters are described in the table below.

**Table 69-41:Digit Collection and Dial Plan Parameters**

Parameter	Description
<p>'Dial Plan Index'</p> <pre>configure voip &gt; gateway dtmf- supp-service dtmf-and-dialing &gt; dial-plan-index</pre> <p>[DialPlanIndex]</p>	<p>Defines the Dial Plan index to use in the external Dial Plan file. The Dial Plan file is loaded to the device as a .dat file (converted using the DConvert utility). The Dial Plan index can be defined globally or per Tel Profile.</p> <p>The valid value range is 0 to 7, where 0 denotes PLAN1, 1 denotes PLAN2, and so on. The default is -1, indicating that no Dial Plan file is used.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If the parameter is configured to select a Dial Plan index, the settings of the parameter DigitMapping are ignored.</li> <li>■ If the parameter is configured to select a Dial Plan index from an external Dial Plan file, the device first attempts to locate a matching</li> </ul>

Parameter	Description
	<p>digit pattern in the Dial Plan file, and if not found, then attempts to locate a matching digit pattern in the Digit Map rules configured by the DigitMapping parameter.</p> <ul style="list-style-type: none"> <li>■ The parameter is also applicable to ISDN with overlap dialing.</li> <li>■ Digital interfaces: For E1 CAS MFC-R2 variants (which don't support terminating digit for the called party number, usually I-15), the parameter and the DigitMapping parameter are ignored. Instead, you can define a Dial Plan template per trunk using the parameter CasTrunkDialPlanName_x (or in the Trunk Settings page).</li> <li>■ The parameter can also be configured in a Tel Profile.</li> <li>■ For more information on the Dial Plan file, see Digit Collection and Dial Plan Parameters.</li> </ul>
<pre>configure voip &gt; gateway manipulation settings &gt; tel2ip- src-nb-map-dial-index</pre> <p>[Tel2IPSourceNumberMappingDialPlanIndex]</p>	<p>Defines the Dial Plan index in the external Dial Plan file for the Tel-to-IP Source Number Mapping feature.</p> <p>The valid value range is 0 to 7, defining the Dial Plan index [Plan x] in the Dial Plan file. The default is -1 (disabled).</p> <p>For more information on this feature, see Digit Collection and Dial Plan Parameters.</p>
<p>'Digit Mapping Rules'</p> <pre>configure voip &gt; gateway dtmf- supp-service dtmf-and-dialing &gt; digitmapping</pre> <p>[DigitMapping]</p>	<p>Defines the digit map pattern. If the digit string (i.e., dialed number) matches one of the patterns in the digit map, the device stops collecting digits and establishes a call with the collected number. This is used to reduce the dialing period for ISDN overlap dialing.</p> <p>The digit map pattern can contain up to</p>

Parameter	Description
	<p>52 options (rules), each separated by a vertical bar ( ). The maximum length of the entire digit pattern is 152 characters.</p> <p>For more information on digit maps, see <a href="#">Digit Mapping</a> on page 992.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For ISDN interfaces, the digit map mechanism is applicable only when ISDN overlap dialing is used (ISDNRxOverlap is set to 1).</li> <li>■ If the [DialPlanIndex] parameter is configured (to select a Dial Plan index), then the device first attempts to locate a matching digit pattern in the Dial Plan file, and if not found, then attempts to locate a matching digit pattern in the Digit Map rules configured by the [DigitMapping] parameter.</li> </ul>
<p>'Max Digits in Phone Num'</p> <pre>configure voip &gt; gateway dtmf- supp-service dtmf-and-dialing &gt; mxdig-b4-dialing</pre> <p>[MaxDigits]</p>	<p>Defines the maximum number of collected destination number digits that can be received when ISDN Tel-to-IP overlap dialing is performed. When the number of collected digits reaches this maximum, the device uses these digits for the called destination number.</p> <p>The valid range is 1 to 49. The default is 30 .</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Instead of using the parameter, you can configure digit maps.</li> </ul>
<p>'Inter Digit Timeout for Overlap Dialing'</p> <pre>configure voip &gt; gateway dtmf- supp-service dtmf-and-dialing &gt; time-btwn-dial-digs</pre> <p>[TimeBetweenDigits]</p>	<p>Defines a timeout between digits (i.e., inter-digit timeout).</p> <p><b>ISDN Overlap Dialing:</b> Defines the time (in seconds) that the device waits between digits received from the PSTN or IP during overlap dialing.</p> <p>When this timeout expires, the device</p>

Parameter	Description
	<p>stops waiting for more digits, and uses the collected digits to dial the called destination number.</p> <p>The valid range is 1 to 10. The default is 4.</p>

## Voice Mail Parameters

The voice mail parameters are described in the table below. For more information on the Voice Mail application, refer to the *CPE Configuration Guide for Voice Mail*.

**Table 69-42:Voice Mail Parameters**

Parameter	Description
<p>'Voice Mail Interface'</p> <pre>configure voip &gt; gateway voice-mail-setting &gt; vm- interface</pre> <p>[VoiceMailInterface]</p>	<p>Enables the device's Voice Mail application and determines the communication method between the device and PBX.</p> <ul style="list-style-type: none"> <li>■ [0] <b>None</b> (default)</li> <li>■ [1] <b>DTMF</b></li> <li>■ [2] <b>SMDI</b></li> <li>■ [3] <b>QSIG</b></li> <li>■ [4] <b>SETUP Only</b> = Applicable only to ISDN.</li> <li>■ [5] <b>MATRA/AASTRA QSIG</b></li> <li>■ [6] <b>QSIG SIEMENS</b> = QSIG MWI activate and deactivate messages include Siemens Manufacturer Specific Information (MSI)</li> <li>■ [8] <b>ETSI</b> = Euro ISDN, according to ETS 300 745-1 V1.2.4, section 9.5.1.1. Enables MWI interworking from IP to Tel .</li> <li>■ [9] <b>NI2</b> = ISDN PRI trunks set to NI-2. This is used for interworking the SIP Message Waiting Indication (MWI) NOTIFY message to ISDN PRI NI-2 Message Waiting Notification (MWN) that is sent in the ISDN Facility IE message. This option is applicable when the device is connected to a PBX through an ISDN PRI trunk configured to NI-2.</li> </ul>

Parameter	Description
	<p><b>Note:</b> To disable voice mail per Trunk Group, you can use a Tel Profile with the EnableVoiceMailDelay parameter set to disabled (0). This eliminates the phenomenon of call delay on Trunks not implementing voice mail when voice mail is enabled using this global parameter.</p>
'Enable VoiceMail URI' voicemail-uri [EnableVMURI]	<p>Enables the interworking of target and cause for redirection from Tel to IP and vice versa, according to RFC 4468.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>Digital interfaces: Upon receipt of an ISDN Setup message with Redirect values, the device maps the Redirect phone number to the SIP 'target' parameter and the Redirect number reason to the SIP 'cause' parameter in the Request-URI.</p> <p>Redirecting Reason &gt;&gt; SIP Response Code</p> <p>Unknown &gt;&gt; 404</p> <p>User busy &gt;&gt; 486</p> <p>No reply &gt;&gt; 408</p> <p>Deflection &gt;&gt; 487/480</p> <p>Unconditional &gt;&gt; 302</p> <p>Others &gt;&gt; 302</p> <p>If the device receives a Request-URI that includes a 'target' and 'cause' parameter, the 'target' is mapped to the Redirect phone number and the 'cause' is mapped to the Redirect number reason.</p>
[WaitForBusyTime]	<p>Defines the time (in msec) that the device waits to detect busy and/or reorder tones. This feature is used for semi-supervised PBX call transfers (i.e., the LineTransferMode parameter is set to 2).</p> <p>The valid value range is 0 to 20000 (i.e., 20 sec). The default is 2000 (i.e., 2 sec).</p>

Parameter	Description
<p>'Line Transfer Mode'</p> <pre>configure voip &gt; gateway voice-mail-setting &gt; line- transfer-mode</pre> <p>[LineTransferMode]</p>	<p>Defines the call transfer method used by the device. The parameter is applicable to the following:</p> <ul style="list-style-type: none"> <li>■ Digital interfaces: E1/T1 CAS call transfer if the TrunkTransferMode_x parameter is set to 3 (CAS Normal) or 1 (CAS NFA)</li> </ul> <p>The valid values are:</p> <ul style="list-style-type: none"> <li>■ [0] <b>None</b> = (Default) IP.</li> <li>■ [1] <b>Blind</b> = PBX blind transfer: <ul style="list-style-type: none"> <li>✓ E1/T1 CAS: When a SIP REFER message is received, the device performs a blind transfer, by performing a CAS wink, waiting a user-defined time (configured by the WaitForDialTime parameter), dialing the Refer-To number, and then releasing the call. The PBX performs the transfer internally.</li> </ul> </li> <li>■ [2] <b>Semi Supervised</b> = PBX semi-supervised transfer: <ul style="list-style-type: none"> <li>✓ E1/T1 CAS: The device performs a CAS wink, waits a user-defined time (configured by the WaitForDialTime parameter), and then dials the Refer-To number. If during the user-defined interval set by the WaitForBusyTime parameter, no busy or reorder tones are detected, the device completes the call transfer by releasing the line. If during this interval, the device detects these tones, the transfer operation is cancelled, the device sends a SIP NOTIFY message with a failure reason (e.g., 486 if a busy tone is detected), and then generates an additional wink toward the CAS line to restore connection with the original call.</li> </ul> </li> <li>■ [3] <b>Supervised</b> = PBX Supervised transfer:</li> </ul>



Parameter	Description
	<p>✓ E1/T1 CAS: The device performs a supervised transfer to the PBX. The device performs a CAS wink, waits a user-defined time (configured by the WaitForDialTime parameter), and then dials the Refer-To number. The device completes the call transfer by releasing the line only after detection of the transferred party answer. To enable answer supervision, you also need to do the following:</p> <ol style="list-style-type: none"> <li>1) Enable voice detection (i.e., set the EnableVoiceDetection parameter to 1).</li> <li>2) Set the EnabledSPIPMDetectors parameter to 1.</li> <li>3) Install the IPMDetector DSP option Feature License Key.</li> </ol>
<b>SMDI Parameters</b>	
<p>'Enable SMDI'</p> <pre>configure voip &gt; gateway voice-mail-setting &gt; enable-smdi</pre> <p>[SMDI]</p>	<p>Enables Simplified Message Desk Interface (SMDI) interface on the device.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) Normal serial</li> <li>■ [1] <b>Enable (Bellcore)</b></li> <li>■ [2] <b>Ericsson MD-110</b></li> <li>■ [3] <b>NEC (ICS)</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ When the RS-232 connection is used for SMDI messages (Serial SMDI), it cannot be used for other applications, for example, to access the Command Line Interface (CLI).</li> </ul>
<p>'SMDI Timeout'</p> <pre>configure voip &gt; gateway voice-mail-setting &gt; smdi-timeout-[msec]</pre>	<p>Defines the time (in msec) that the device waits for an SMDI Call Status message before or after a Setup message is received. The parameter synchronizes the SMDI and analog</p>

Parameter	Description
[SMDITimeout]	<p>CAS interfaces.</p> <p>If the timeout expires and only an SMDI message is received, the SMDI message is dropped. If the timeout expires and only a Setup message is received, the call is established.</p> <p>The valid range is 0 to 10000 (i.e., 10 seconds). The default is 2000.</p>
<b>Message Waiting Indication (MWI) Parameters</b>	
<p>'MWI Off Digit Pattern'</p> <pre>configure voip &gt; gateway voice-mail-setting &gt; mwi- off-dig-ptrn</pre> <p>[MWIOffCode]</p>	<p>Defines the digit code used by the device to notify the PBX that there are no messages waiting for a specific extension. This code is added as prefix to the dialed number.</p> <p>The valid range is a 25-character string.</p>
<p>'MWI On Digit Pattern'</p> <pre>configure voip &gt; gateway voice-mail-setting &gt; mwi-on- dig-ptrn</pre> <p>[MWIOnCode]</p>	<p>Defines the digit code used by the device to notify the PBX of messages waiting for a specific extension. This code is added as prefix to the dialed number.</p> <p>The valid range is a 25-character string.</p>
<p>'MWI Suffix Pattern'</p> <pre>configure voip &gt; gateway voice-mail-setting &gt; mwi- suffix-pattern</pre> <p>[MWISuffixCode]</p>	<p>Defines the digit code used by the device as a suffix for 'MWI On Digit Pattern' and 'MWI Off Digit Pattern'. This suffix is added to the generated DTMF string after the extension number.</p> <p>The valid range is a 25-character string.</p>
<p>'MWI Source Number'</p> <pre>configure voip &gt; gateway voice-mail-setting &gt; mwi- source-number</pre> <p>[MWISourceNumber]</p>	<p>Defines the calling party's phone number used in the Q.931 MWI Setup message to PSTN. If not configured, the channel's phone number is used as the calling number.</p>
<pre>configure voip &gt; gateway dtmf-supp-service supp- service-settings &gt; mwi-subs- ipgrp-id</pre> <p>[MWISubscribeIPGroupID]</p>	<p>Defines the IP Group ID used when subscribing to an MWI server. The 'SIP Group Name' field value of the IP Groups table is used as the Request-URI host name in the outgoing MWI SIP SUBSCRIBE message. The request is sent to the IP address defined for the Proxy Set that is associated with the IP</p>

Parameter	Description
	<p>Group. The Proxy Set's capabilities such as proxy redundancy and load balancing are also applied to the message.</p> <p>For example, if the 'SIP Group Name' field of the IP Group is "company.com", the device sends the following SUBSCRIBE message:</p> <pre>SUBSCRIBE sip:company.com...</pre> <p>Instead of:</p> <pre>SUBSCRIBE sip:10.33.10.10...</pre> <p><b>Note:</b> If the parameter is not configured, the MWI SUBSCRIBE message is sent to the MWI server as defined by the [MWIServerIP] parameter.</p>
<p>'Notification IP Group Name'</p> <pre>configure voip &gt; gateway digital settings &gt; notification-ip-group-name [NotificationIPGroupName]</pre>	<p>Defines the IP Group to where the device sends SIP NOTIFY MWI messages.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ This is used for MWI Interrogation. For more information on the interworking of QSIG MWI to IP, see <a href="#">Message Waiting Indication</a> on page 999.</li> <li>■ To define the handling method of MWI Interrogation messages, use the 'MWI Interrogation Type' parameter in the Trunk Group Settings table (see <a href="#">Configuring Trunk Group Settings</a> on page 906).</li> </ul>
<pre>configure voip &gt; gateway dtmf-supp-service supp- service-settings &gt; mwi-qsig- party-num [MWISigMsgCentreIDPartyNumber]</pre>	<p>Defines the Message Centred ID party number used for QSIG MWI messages. If not configured (default), the parameter is not included in MWI (activate and deactivate) QSIG messages.</p> <p>The valid value is a string.</p>
<p><b>Digit Patterns</b> The following digit pattern parameters apply only to voice mail applications that use the DTMF communication method. For available pattern syntaxes, refer to the <i>CPE Configuration Guide for Voice Mail</i>.</p>	
<p>'Forward on Busy Digit Pattern (Internal)'</p> <pre>configure voip &gt; gateway voice-mail-setting &gt; fwd-</pre>	<p>Defines the digit pattern used by the PBX to indicate 'call forward on busy' when the original call is received from an internal</p>

Parameter	Description
bsy-dig-ptn-int [DigitPatternForwardOnBusy]	extension. The valid range is a 120-character string.
'Forward on No Answer Digit Pattern (Internal)' configure voip > gateway voice-mail-setting > fwd-no-ans-dig-pat-int [DigitPatternForwardOnNoAnswer]	Defines the digit pattern used by the PBX to indicate 'call forward on no answer' when the original call is received from an internal extension. The valid range is a 120-character string.
'Forward on Do Not Disturb Digit Pattern (Internal)' configure voip > gateway voice-mail-setting > fwd-dnd-dig-ptn-int [DigitPatternForwardOnDND]	Defines the digit pattern used by the PBX to indicate 'call forward on do not disturb' when the original call is received from an internal extension. The valid range is a 120-character string.
'Forward on No Reason Digit Pattern (Internal)' configure voip > gateway voice-mail-setting > fwd-no-rsn-dig-ptn-int [DigitPatternForwardNoReason]	Defines the digit pattern used by the PBX to indicate 'call forward with no reason' when the original call is received from an internal extension. The valid range is a 120-character string.
'Forward on Busy Digit Pattern (External)' configure voip > gateway voice-mail-setting > fwd-bsy-dig-ptn-ext [DigitPatternForwardOnBusyExt]	Defines the digit pattern used by the PBX to indicate 'call forward on busy' when the original call is received from an external line (not an internal extension). The valid range is a 120-character string.
'Forward on No Answer Digit Pattern (External)' configure voip > gateway voice-mail-setting > fwd-no-ans-dig-pat-ext [DigitPatternForwardOnNoAnswerExt]	Defines the digit pattern used by the PBX to indicate 'call forward on no answer' when the original call is received from an external line (not an internal extension). The valid range is a 120-character string.
'Forward on Do Not Disturb Digit Pattern (External)' configure voip > gateway voice-mail-setting > fwd-dnd-dig-ptn-ext	Defines the digit pattern used by the PBX to indicate 'call forward on do not disturb' when the original call is received from an external line (not an internal extension). The valid range is a 120-character string.

Parameter	Description
[DigitPatternForwardOnDNDExt]	
'Forward on No Reason Digit Pattern (External)' <pre>configure voip &gt; gateway voice-mail-setting &gt; fwd-no-rsn-dig-ptn-ext</pre> [DigitPatternForwardNoReasonExt]	Defines the digit pattern used by the PBX to indicate 'call forward with no reason' when the original call is received from an external line (not an internal extension).  The valid range is a 120-character string.
'Internal Call Digit Pattern' <pre>configure voip &gt; gateway voice-mail-setting &gt; int-call-dig-ptn</pre> [DigitPatternInternalCall]	Defines the digit pattern used by the PBX to indicate an internal call.  The valid range is a 120-character string.
'External Call Digit Pattern' <pre>configure voip &gt; gateway voice-mail-setting &gt; ext-call-dig-ptn</pre> [DigitPatternExternalCall]	Defines the digit pattern used by the PBX to indicate an external call.  The valid range is a 120-character string.
'Disconnect Call Digit Pattern' <pre>configure voip &gt; gateway voice-mail-setting &gt; disc-call-dig-ptn</pre> [TelDisconnectCode]	Defines a digit pattern that when received from the Tel side, indicates the device to disconnect the call.  The valid range is a 25-character string.
'Digit To Ignore Digit Pattern' <pre>configure voip &gt; gateway voice-mail-setting &gt; dig-to-ignore-dig-pattern</pre> [DigitPatternDigitToIgnore]	Defines a digit pattern that if received as Src (S) or Redirect (R) numbers is ignored and not added to that number.  The valid range is a 25-character string.

## Supplementary Services Parameters

This subsection describes the device's supplementary telephony services parameters.

### Caller ID Parameters

The caller ID parameters are described in the table below.

Table 69-43:Caller ID Parameters

Parameter	Description
<p>'Enable Caller ID'</p> <pre>configure voip &gt; gateway dtmf-supp-service supp- service-settings &gt; enable- caller-id</pre> <p>[EnableCallerID]</p>	<p>Global parameter that enables Caller ID.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>✓ CAS: The device detects the Caller ID signal received from the Tel and sends it to the IP in the SIP INVITE message (as the 'Display' element).</p> <p>To configure the Caller ID string per port, see Caller ID Parameters. To enable or disable caller ID generation / detection per port, see Caller ID Parameters.</p>
<p>'Caller ID Type'</p> <pre>configure voip &gt; gateway dtmf-supp-service supp- service-settings &gt; caller- id-type</pre> <p>[CallerIDType]</p>	<p>Determines the standard used for generation (FXS) of Caller ID, and generation (FXS) of MWI (when specified) signals:</p> <ul style="list-style-type: none"> <li>■ [0] <b>Standard Bellcore</b> = (Default) Caller ID and MWI</li> <li>■ [1] <b>Standard ETSI</b> = Caller ID and MWI</li> <li>■ [2] <b>Standard NTT</b></li> <li>■ [4] <b>Standard BT</b> = Britain</li> <li>■ [16] <b>Standard DTMF Based ETSI</b></li> <li>■ [17] <b>Standard Denmark</b> = Caller ID and MWI</li> <li>■ [18] <b>Standard India</b></li> <li>■ [19] <b>Standard Brazil</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to analog interfaces.</li> <li>■ Typically, the Caller ID signals are generated / detected between the first and second rings. However, sometimes the Caller ID is detected before the first ring signal. In such a scenario, set the [RingsBeforeCallerID] parameter to 0.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ To select the Bellcore Caller ID sub standard, use the [BellcoreCallerIDTypeOneSubStandard] parameter. To select the ETSI Caller ID substandard, use the [ETSICallerIDTypeOneSubStandard] parameter.</li> <li>■ To select the Bellcore MWI sub standard, use the [BellcoreVMWITypeOneStandard] parameter. To select the ETSI MWI sub standard, use the [ETSIVMWITypeOneStandard] parameter.</li> <li>■ If you define Caller ID Type as NTT [2], you need to define the NTT DID signaling form (FSK or DTMF) using the [NTTDIDSignallingForm] parameter.</li> </ul>
'Asserted Identity Mode' asserted-identity-m [AssertedIdMode]	<p>Determines whether the SIP header P-Asserted-Identity or P-Preferred-Identity is added to the sent INVITE, 200 OK, or UPDATE request for Caller ID (or privacy). These headers are used to present the calling party's Caller ID, which is composed of a Calling Number and a Calling Name (optional).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disabled</b> = (Default) P-Asserted-Identity and P-Preferred-Identity headers are not added.</li> <li>■ [1] <b>Add P-Asserted-Identity</b></li> <li>■ [2] <b>Add P-Preferred-Identity</b></li> </ul> <p>The used header also depends on the calling Privacy (allowed or restricted). These headers are used together with the Privacy header. If Caller ID is restricted (i.e., P-Asserted-Identity is not sent), the Privacy header includes the value 'id' ('Privacy: id'). Otherwise, for allowed Caller ID, 'Privacy: none' is used. If Caller ID is restricted (received from Tel), the From header is set to &lt;anonymous@anonymous.invalid&gt;.</p> <p>Digital Interfaces: The 200 OK response can contain the connected party CallerID -</p>

Parameter	Description
	<p>Connected Number and Connected Name. For example, if the call is answered by the device, the 200 OK response includes the P-Asserted-Identity with Caller ID. The device interworks (in some ISDN variants), the Connected Party number and name from Q.931 Connect message to SIP 200 OK with the P-Asserted-Identity header. In the opposite direction, if the ISDN device receives a 200 OK with P-Asserted-Identity header, it interworks it to the Connected party number and name in the Q.931 Connect message, including its privacy.</p>
<p>'Use Destination As Connected Number'</p> <pre>configure voip &gt; sip- definition settings &gt; use- dst-as-connected-num</pre> <p>[UseDestinationAsConnectedNumber]</p>	<p>Enables the device to include the Called Party Number, from outgoing Tel calls (after number manipulation), in the SIP P-Asserted-Identity header. The device includes the SIP P-Asserted-Identity header in 180 Ringing and 200 OK responses for IP-to-Tel calls.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For this feature to function, you also need to enable the device to include the P-Asserted-Identity header in 180/200 OK responses, by setting the [AssertedIDMode] parameter to <b>Add P-Asserted-Identity</b>.</li> <li>■ If the received Q.931 Connect message contains a Connected Party Number, this number is used in the P-Asserted-Identity header in 200 OK response.</li> <li>■ The parameter is applicable to , ISDN and CAS interfaces.</li> </ul>
<p>'Caller ID Transport Type'</p> <pre>configure voip &gt; media fax- modem &gt; caller-ID- transport-type</pre> <p>[CallerIDTransportType]</p>	<p>Defines the device's behavior for Caller ID detection.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = The caller ID signal is not detected - DTMF digits remain in the voice stream.</li> </ul>



Parameter	Description
	<ul style="list-style-type: none"> <li>■ [3] <b>Mute</b> = The caller ID signal is detected from the Tel side and then erased from the voice stream.</li> </ul> <p><b>Note:</b> This option is applicable only to Gateway calls.</p> <ul style="list-style-type: none"> <li>■ [4] <b>SetBySoftware</b> = (Default) The behavior as defined for <b>Mute</b> is applied to Gateway calls. The behavior as defined for <b>Disable</b> is applied to SBC calls.</li> </ul>

### Call Waiting Parameters

The call waiting parameters are described in the table below.

**Table 69-44:Call Waiting Parameters**

Parameter	Description
'Enable Call Waiting' configure voip > gateway dtmf-supp- service supp-service- settings > call- waiting [EnableCallWaiting]	Enables the Call Waiting feature. <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = (Default) Enabled.</li> </ul> <p>✓ If enabled and the device initiates a Tel-to-IP call to a destination that is busy, it plays a call waiting ringback tone to the caller. The tone is played only if the destination returns a 182 "Queued" SIP response.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The device's Call Progress Tones (CPT) file must include a Call Waiting ringback tone.</li> </ul>
configure voip > sip- definition settings > send-180-for-call- waiting [Send180ForCallWaiting]	Determines the SIP response code for indicating Call Waiting. <ul style="list-style-type: none"> <li>■ [0] = (Default) Use 182 Queued response to indicate call waiting.</li> <li>■ [1] = Use 180 Ringing response to indicate call waiting.</li> </ul>

### Call Forwarding Parameters

The call forwarding parameters are described in the table below.

**Table 69-45:Call Forwarding Parameters**

Parameter	Description
<p>'Enable Call Forward'</p> <pre>configure voip &gt; gateway dtmf- supp-service supp-service- settings &gt; call-forward</pre> <p>[EnableForward]</p>	<p>Enables call forwarding.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = (Default) Enabled.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ To use this service, the devices at both ends must support call forwarding.</li> <li>■ For the device to respond to SIP 3xx responses with a new SIP request (forwarding the original request), enable the parameter.</li> </ul>

### Call Hold Parameters

The call hold parameters are described in the table below.

**Table 69-46:Call Hold Parameters**

Parameter	Description
<p>'Enable Hold'</p> <pre>configure voip &gt; gateway dtmf- supp-service supp-service- settings &gt; hold</pre> <p>[EnableHold]</p>	<p>Global parameter that enables the following:</p> <ul style="list-style-type: none"> <li>■ Interworking of the Hold/Retrieve supplementary service from ISDN to SIP.</li> </ul> <p>You can also configure this feature per specific calls, using IP Profiles ('Hold'). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b> If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</p>
<p>'Hold Format'</p> <pre>configure voip &gt; gateway dtmf- supp-service supp-service- settings &gt; hold- format</pre> <p>[HoldFormat]</p>	<p>Defines the format of the SDP in the sent re-INVITE hold request.</p> <ul style="list-style-type: none"> <li>■ [0] <b>0.0.0.0</b> = (Default) The SDP 'c=' field contains the IP address "0.0.0.0" and the 'a=inactive' attribute.</li> <li>■ [1] <b>Send Only</b> = The SDP 'c=' field contains the device's IP address and the 'a=sendonly' attribute.</li> <li>■ [2] <b>x.y.z.t</b> = The SDP 'c=' field contains the device's IP</li> </ul>

Parameter	Description
	<p>address and the 'a=inactive' attribute.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The device doesn't send any RTP packets when it is in hold state.</li> <li>■ The parameter is applicable only to QSIG and Euro ISDN protocols.</li> </ul>
<p><b>'Held Timeout'</b></p> <pre>configure voip &gt; gateway dtmf- supp-service supp-service- settings &gt; held- timeout [HeldTimeout]</pre>	<p>Defines the maximum duration (in seconds) that the device allows for a call to remain on hold. This parameter applies to Tel-to-IP calls, where the Tel side places the IP side on hold.</p> <ul style="list-style-type: none"> <li>■ [-1] = (Default) The IP side remains on hold until the Tel side (which placed the call on hold) retrieves the call (SIP re-INVITE message).</li> <li>■ [0 - 2400] = If the IP side is still on hold when this duration expires, the device disconnects the call (sends a SIP BYE message to the IP side). For example, if configured to 60 and the Tel side places the IP side (Alice) on hold and makes a new call to Bob, if the call with Bob gets to 61, the device disconnects the call with Alice.</li> </ul> <p><b>Note:</b> When the Tel side puts the call on hold (hookflash), the device plays a dial tone to the Tel side (dial tone timeout starts according to the 'Dial Tone Duration' parameter, which is 16 sec. by default), expecting the Tel side to do some action (e.g., make another call, conferencing, or call transfer). If the 'Dial Tone Duration' parameter expires as no DTMF digits were collected (i.e., Tel side did nothing), the device plays a congestion tone to the Tel side (and if the Tel side goes on-hook, the phone rings and if the Tel side then goes off-hook, the IP side is retrieved).</p>
<pre>configure voip &gt; gateway dtmf- supp-service supp-service- settings &gt; dtmf- during-hold [PlayDTMFduringHold]</pre>	<p>Determines whether the device sends DTMF signals (or DTMF SIP INFO message) when a call is on hold.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable.</li> <li>■ [1] = Enable - If the call is on hold, the device stops playing the Held tone (if it is played) and sends DTMF: <ul style="list-style-type: none"> <li>✓ To Tel side: plays DTMF digits according to the received SIP INFO message(s). (The stopped held tone is not played again.)</li> <li>✓ To IP side: sends DTMF SIP INFO messages to an IP</li> </ul> </li> </ul>

Parameter	Description
	destination if it detects DTMF digits from the Tel side.

## Call Transfer Parameters

The call transfer parameters are described in the table below.

**Table 69-47:Call Transfer Parameters**

Parameter	Description
<p>'Enable Transfer'</p> <pre>configure voip &gt; gateway dtmf-supp-service supp- service-settings &gt; enable-transfer</pre> <p>[EnableTransfer]</p>	<p>Enables the Call Transfer feature.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = (Default) Enabled.</li> </ul> <p>✓ The device responds to a REFER message with the Referred-To header to initiate a call transfer.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ To use call transfer, the devices at both ends must support this option.</li> <li>■ To use call transfer, configure the [EnableHold] parameter to 1.</li> </ul>
<p>'Transfer Prefix'</p> <pre>configure voip &gt; gateway dtmf-supp-service supp- service-settings &gt; transfer-prefix</pre> <p>[xferPrefix]</p>	<p>Defines the string that is added as a prefix to the transferred/forwarded called number when the REFER/3xx message is received.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The number manipulation rules apply to the user part of the Refer-To and Contact URI before it is sent in the INVITE message.</li> <li>■ The parameter can be used to apply different manipulation rules to differentiate the transferred/forwarded call number from the originally dialed number.</li> </ul>
<p>'Transfer Prefix IP 2 Tel'</p> <pre>configure voip &gt; gateway digital settings &gt; xfer- prefix-ip2tel</pre> <p>[XferPrefixIP2Tel]</p>	<p>Defines the prefix that is added to the destination number received in the SIP Refer-To header (for IP-to-Tel calls). The parameter is applicable only to CAS blind transfer modes (i.e., LineTransferMode = 1, 2 or 3, and TrunkTransferMode = 1 or 3 for CAS).</p>

Parameter	Description
	<p>The valid range is a string of up to 9 characters. By default, no value is defined.</p> <p><b>Note:</b> The parameter is also applicable to ISDN Blind Transfer, according to AT&amp;T Toll Free Transfer Connect Service (TR 50075) "Courtesy Transfer-Human-No Data". To support this transfer mode, you need to configure the parameter [XferPrefixIP2Tel] to "*8" (without quotation marks) and the parameter [TrunkTransferMode] to "5" (without quotation marks).</p>
<p>'Enable Semi-Attended Transfer'</p> <p><code>semi-att-transfer</code></p> <p>[EnableSemiAttendedTransfer]</p>	<p>Defines what the device does when a transfer is initiated while in Alerting state.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. Sends a SIP REFER message with the Replaces header.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled. Sends a SIP CANCEL message and after a SIP 487 response is received, sends a REFER without the Replaces header.</li> </ul>
<p>'Blind'</p> <p><code>configure voip &gt; gateway</code>  <code>analog keypad-features &gt;</code>  <code>blind-transfer</code></p> <p>[KeyBlindTransfer]</p>	<p>Defines the keypad sequence to activate blind transfer for established Tel-to-IP calls. The Tel user can perform blind transfer by dialing the [KeyBlindTransfer] digits, followed by a transferee destination number.</p> <p>After the KeyBlindTransfer DTMF digits sequence is dialed, the current call is put on hold (using a Re-INVITE message), a dial tone is played to the channel, and then the phone number collection starts.</p> <p>After the destination phone number is collected, it is sent to the transferee in a SIP REFER request in a Refer-To header. The call is then terminated and a confirmation tone is played to the channel. If the phone number collection fails due to a mismatch, a reorder tone is played to the channel.</p>
<p><code>configure voip &gt; gateway</code>  <code>digital settings &gt; blind-</code></p>	<p>Defines the duration (in milliseconds) for which the device waits for a disconnection from the Tel</p>

Parameter	Description
<code>xfer-disc-tmo</code> [BlindTransferDisconnectTimeout]	<p>side after the Blind Transfer Code (KeyBlindTransfer) has been identified. When this timer expires, a SIP REFER message is sent toward the IP side. If the parameter is set to 0, the REFER message is immediately sent.</p> <p>The valid value range is 0 to 1,000,000. The default is 0.</p>
'QSIG Path Replacement Mode' <code>configure voip &gt; gateway</code> <code>digital settings &gt; qsig-</code> <code>path-replacement</code> [QSIGPathReplacementMode]	<p>Enables QSIG transfer for IP-to-Tel and Tel-to-IP calls.</p> <ul style="list-style-type: none"> <li>■ [0] <b>IP2QSIGTransfer</b> = (Default) Enables IP-to-QSIG transfer.</li> <li>■ [1] <b>QSIG2IPTransfer</b> = Enables QSIG-to-IP transfer.</li> </ul>
<code>configure voip &gt; gateway</code> <code>digital settings &gt;</code> <code>replace-tel2ip-calnum-to</code> [ReplaceTel2IPCallingNumTimeout]	<p>Defines the maximum duration (timeout) to wait between call Setup and Facility with Redirecting Number for replacing the calling number (for Tel-to-IP calls).</p> <p>The valid value range is 0 to 10,000 msec. The default is 0.</p> <p>The interworking of the received Setup message to a SIP INVITE is suspended when the parameter is set to any value greater than 0. This means that the redirecting number in the Setup message is not checked. When a subsequent Facility with Call Transfer Complete/Update is received with a non-empty Redirection Number, the Calling Number is replaced with the received redirect number in the sent INVITE message.</p> <p>If the timeout expires, the device sends the INVITE without changing the calling number.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The suspension of the INVITE message occurs for all calls.</li> </ul>

## MLPP and Emergency Call Parameters

The Multilevel Precedence and Preemption (MLPP) and emergency E911 call parameters are described in the table below.

**Table 69-48:MLPP and Emergency E911 Call Parameters**

Parameter	Description
'Call Priority Mode' <pre>configure voip &gt; gateway dtmf-supp-service supp- service-settings &gt; call- prio-mode</pre> [CallPriorityMode]	<p>Global parameter defining call priority handling. You can also configure the feature per specific calls, using Tel Profiles ('Call Priority Mode' parameter). For a detailed description of the parameter and for configuring the feature in the Tel Profiles table, see <a href="#">Configuring Tel Profile</a> on page 738.</p> <p><b>Note:</b> If the feature is configured for a specific Tel Profile, the settings of the global parameter is ignored for calls associated with the Tel Profile.</p>
<b>Emergency E911 Parameters</b>	
'E911 Gateway' <pre>configure voip &gt; sip- definition settings &gt; e911-gateway</pre> [E911Gateway]	<p>Enables Enhanced 9-1-1(E9-1-1) support for ELIN handling in a Microsoft Skype for Business environment and routing to a PSTN-based emergency service provider.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>NG911 Callback Gateway</b> = Enables the ELIN Gateway.</li> <li>■ [2] <b>Location Based Manipulations</b> = Enables ELIN Gateway and location-based manipulation. For more information, see <a href="#">Location Based Emergency Routing</a> on page 501.</li> </ul> <p>For more information on E9-1-1 in a Skype for Business environment, see <a href="#">E9-1-1 Support for Microsoft Teams and Skype for Business</a> on page 489.</p> <p><b>Note:</b> The parameter is applicable only to digital interfaces.</p>
'E911 Callback Timeout' <pre>configure voip &gt; sip-definition settings &gt; e911-callback-timeout</pre> [E911CallbackTimeout]	<p>Defines the maximum interval within which the PSAP can use the ELIN to call back the E9-1-1 caller. This interval starts from when the initial call established with the PSAP is terminated. The valid range is 1 to 60 (minutes). The default is 30.</p>
'Emergency Special Release Cause'	Enables the device to send a SIP 503 "Service

Parameter	Description
<pre>configure voip &gt; sip- definition settings &gt; emerg-spcl-rel-cse</pre> <p>[EmergencySpecialReleaseCause]</p>	<p>Unavailable" response if an emergency call cannot be established (i.e., rejected). This can occur, for example, due to the PSTN (for example, the destination is busy or not found) or ELIN Gateway (for example, lack of resources or an internal error).</p> <p>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</p> <p>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</p>
<p>'Emergency Number'</p> <pre>configure voip &gt; sip- definition settings &gt; emerg-nbs</pre> <p>[EmergencyNumbers]</p>	<p>Defines a list of "emergency" numbers. CAS, and ISDN interfaces: These emergency numbers are used for the preemption of E911 IP-to-Tel calls when there are unavailable or busy channels. In this scenario, the device terminates one of the busy channels and sends the emergency call to this channel. This feature is enabled by configuring the [CallPriorityMode] parameter to 2 ("Emergency"). For a description of this feature, see <a href="#">Pre-empting Existing Calls for E911 IP-to-Tel Calls</a> on page 1001.</p> <p>The list can include up to four different numbers, where each number can be up to four digits long. For example:</p> <pre>EmergencyNumbers = '100', '911', '112'</pre> <p><b>Note:</b> The parameter is applicable only to Tel-to-IP calls. For IP-to-Tel calls, use the [EmergencyCallAlertInfoUri] parameter to identify emergency calls.</p>
<pre>configure voip &gt; sip- definition settings &gt; emerg-alert-info-uri</pre> <p>[EmergencyCallAlertInfoUri]</p>	<p>Defines the URI of the SIP Alert-Info header, for the device to consider (identify) the incoming SIP INVITE message as an emergency call.</p> <p>By default, no value is defined. If you don't configure a value, the device doesn't consider any IP-to-Tel call as an emergency call (even if the Alert-Info header is present in the incoming SIP message).</p> <p><b>Note:</b> The parameter is applicable only to IP-to-Tel calls. For Tel-to-IP calls, use the [EmergencyNumbers] parameter to identify</p>



Parameter	Description
	emergency calls.
<pre>configure voip &gt; sip- definition settings &gt; reload-timeout-for- emergency-call</pre> <p>[ReloadTimeoutForEmergencyCall]</p>	<p>Enables the device to block device resets that are triggered through CLI (<code>reload</code> command) during active emergency calls and for a period (configured by this parameter) after the call ends (regardless of whether it was successfully established or not).</p> <p>The valid value is -1 to 3600 (in seconds). A value of -1 disables the feature and allows restarts during and after emergency calls.</p> <p><b>Note:</b> The parameter is applicable to IP-to-Tel and Tel-to-IP emergency calls.</p>
<b>Multilevel Precedence and Preemption (MLPP) Parameters</b>	
<p>'MLPP Default Namespace'</p> <pre>configure voip &gt; gateway digital settings &gt; mlpp- dflt-namespace</pre> <p>[MLPPDefaultNamespace]</p>	<p>Determines the namespace used for MLPP calls received from the ISDN side without a Precedence IE and destined for an Application server. This value is used in the Resource-Priority header of the outgoing SIP INVITE request.</p> <ul style="list-style-type: none"> <li>■ [1] <b>DSN</b> (default)</li> <li>■ [2] <b>DOD</b></li> <li>■ [3] <b>DRSN</b></li> <li>■ [5] <b>UC</b></li> <li>■ [7] <b>CUC</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If the ISDN message contains a Precedence IE, the device automatically interworks the "network identity" digits in the IE to the network domain subfield in the Resource-Priority header. For more information, see <a href="#">Multilevel Precedence and Preemption</a> on page 1002.</li> </ul>
[ResourcePriorityNetworkDomains]	<p>Defines up to 32 user-defined MLPP network domain names (namespaces). This value is used in the AS-SIP Resource-Priority header of the outgoing SIP INVITE request. The parameter is used in combination with the</p>

Parameter	Description
	<p>MLPPDefaultNamespace parameter, where you need to enter the table row index as its value.</p> <p>The parameter is also used for mapping the Resource-Priority field value of the SIP Resource-Priority header to the ISDN Precedence Level IE. The mapping is configured by the field, EnableIp2TelInterworking:</p> <ul style="list-style-type: none"> <li>■ Disabled: The network-domain field in the Resource-Priority header is set to "0 1 0 0" (i.e., "routine") in the Precedence Level field.</li> <li>■ Enabled: The network-domain field in the Resource-Priority header is set in the Precedence Level field according to Table 5.3.2.12-4 (Mapping of RPH r-priority Field to ISDN Precedence Level Value).</li> </ul> <p>The domain name can be a string of up to 10 characters.</p> <p>The format of this table ini file parameter is as follows:</p> <p>FORMAT Index = Name, EnableIp2TelInterworking; ResourcePriorityNetworkDomains 1 = dsn, 0; ResourcePriorityNetworkDomains 2 = dod, 0; ResourcePriorityNetworkDomains 3 = drsn, 0; ResourcePriorityNetworkDomains 5 = uc, 1; ResourcePriorityNetworkDomains 7 = cuc, 0; [ \ResourcePriorityNetworkDomains ]</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Indices 1, 2, 3, 5, and 7 cannot be modified and are defined for DSN, DOD, DRSN, UC, and CUC, respectively.</li> <li>■ If the MLPPDefaultNamespace parameter is set to -1, interworking from PSTN NI digits is done automatically.</li> </ul>
<p>'Default Call Priority'</p> <pre>configure voip &gt; gateway digital settings &gt; dflt- call-prio [SIPDefaultCallPriority]</pre>	<p>Determines the default call priority for MLPP calls.</p> <ul style="list-style-type: none"> <li>■ [0] 0 = (Default) ROUTINE</li> <li>■ [2] 2 = PRIORITY</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [4] 4 = IMMEDIATE</li> <li>■ [6] 6 = FLASH</li> <li>■ [8] 8 = FLASH-OVERRIDE</li> <li>■ [9] 9 = FLASH-OVERRIDE-OVERRIDE</li> </ul> <p>If the incoming SIP INVITE request doesn't contain a valid priority value in the SIP Resource-Priority header, the default value is used in the Precedence IE (after translation to the relevant ISDN Precedence value) of the outgoing ISDN Setup message.</p> <p>If the incoming Setup message doesn't contain a valid Precedence Level value, the default value is used in the Resource-Priority header of the outgoing SIP INVITE request. In this scenario, the character string is sent without translation to a numerical value.</p>
<b>'MLPP DiffServ'</b> <code>configure voip &gt; gateway</code> <code>dtmf-suppress-service supp-</code> <code>service-settings &gt; mlpp-</code> <code>diffserv</code> <b>[MLPPDiffServ]</b>	<p>Defines the DiffServ value (differentiated services code point/DSCP) used in IP packets containing SIP messages that are related to MLPP calls. The parameter defines DiffServ for incoming and, for digital interfaces, outgoing MLPP calls with the Resource-Priority header.</p> <p>The valid range is 0 to 63. The default is 50.</p>
<b>'Preemption Tone Duration'</b> <code>configure voip &gt; gateway</code> <code>digital settings &gt;</code> <code>preemp-tone-dur</code> <b>[PreemptionToneDuration]</b>	<p>Defines the duration (in seconds) in which the device plays a preemption tone to the Tel and IP sides if a call is preempted.</p> <p>The valid range is 0 to 60. The default is 3.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If set to 0, no preemption tone is played.</li> </ul>
<b>'MLPP Normalized Service Domain'</b> <code>configure voip &gt; gateway</code> <code>digital settings &gt; mlpp-</code> <code>norm-ser-dmn</code> <b>[MLPPNormalizedServiceDomain]</b>	<p>Defines the MLPP normalized service domain string. If the device receives an MLPP ISDN incoming call, it uses the parameter (if different from 'FFFFFF') as a Service domain in the SIP Resource-Priority header in outgoing INVITE messages. If the parameter is configured to 'FFFFFF', the Resource-Priority header is set to the MLPP Service Domain obtained from the Precedence IE.</p>

Parameter	Description
	<p>The valid value is 6 hexadecimal digits. The default is '000000'.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The parameter is applicable only to the MLPP NI-2 ISDN variant with CallPriorityMode set to 1.</li> </ul>
<pre>configure voip &gt; gateway digital settings &gt; mlpp- nwrk-id</pre> <p>[MLPPNetworkIdentifier]</p>	<p>Defines the MLPP network identifier (i.e., International prefix or Telephone Country Code/TCC) for IP-to-ISDN calls, according to the UCR 2008 and ITU Q.955 specifications.</p> <p>The valid range is 1 to 999. The default is 1 (i.e., USA).</p> <p>The MLPP network identifier is sent in the Facility IE of the ISDN Setup message. For example:</p> <ul style="list-style-type: none"> <li>MLPPNetworkIdentifier set to default (i.e., USA, 1):</li> </ul> <pre>PlaceCall- MLPPNetworkID:0100 MlppServiceDomain:123abc, MlppPrecLevel:5 Fac(1c): 91 a1 15 02 01 05 02 01 19 30 0d 0a 01 05 0a 01 01 04 05 01 00 12 3a bc</pre> <ul style="list-style-type: none"> <li>MLPPNetworkIdentifier set to 490:</li> </ul> <pre>PlaceCall- MLPPNetworkID:9004 MlppServiceDomain:123abc, MlppPrecLevel:5 Fac(1c): 91 a1 15 02 01 0a 02 01 19 30 0d 0a 01 05 0a 01 01 04 05 90 04 12 3a bc</pre>
<p>'MLPP Default Service Domain'</p> <pre>configure voip &gt; gateway digital settings &gt; mlpp- dflt-srv-domain</pre> <p>[MLPPDefaultServiceDomain]</p>	<p>Defines the MLPP default service domain string. If the device receives a non-MLPP ISDN incoming call (without a Precedence IE), it uses the parameter (if different than "FFFFFF") as a Service domain in the SIP Resource-Priority header in outgoing (Tel-to-IP calls) INVITE messages. The parameter is used in conjunction with the parameter SIPDefaultCallPriority.</p> <p>If MLPPDefaultServiceDomain is set to 'FFFFFF',</p>

Parameter	Description												
	<p>the device interworks the non-MLPP ISDN call to non-MLPP SIP call, and the outgoing INVITE doesn't contain the Resource-Priority header. The valid value is a 6 hexadecimal digits. The default is "000000".</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the MLPP NI-2 ISDN variant with CallPriorityMode set to 1.</li> </ul>												
resource-prio-req [RPRequired]	<p>Defines if the device adds the SIP 'resource-priority' tag to the SIP Require header of INVITE messages for Tel-to-IP calls.</p> <ul style="list-style-type: none"> <li>■ [0] = Disable. The device excludes the SIP 'resource-priority' tag from the SIP Require header.</li> <li>■ [1] = (Default) Enable. The device adds the SIP 'resource-priority' tag to the SIP Require header.</li> </ul> <p><b>Note:</b> The parameter is applicable only to MLPP priority call handling (i.e., only when the CallPriorityMode parameter is configured to [1]).</p>												
<p><b>Multiple Differentiated Services Code Points (DSCP) per MLPP Call Priority Level (Precedence) Parameters</b></p> <p>The MLPP service allows placement of priority calls, where properly validated users can preempt (terminate) lower-priority phone calls with higher-priority calls. For each MLPP call priority level, the DSCP can be set to a value from 0 to 63. The Resource Priority value in the Resource-Priority SIP header can be one of the following:</p> <table> <tr> <th>MLPP Precedence Level</th><th>Precedence Level in Resource-Priority SIP Header</th></tr> <tr> <td>0 (lowest)</td><td>routine</td></tr> <tr> <td>2</td><td>priority</td></tr> <tr> <td>4</td><td>immediate</td></tr> <tr> <td>6</td><td>flash</td></tr> <tr> <td>8</td><td>flash-override</td></tr> </table>		MLPP Precedence Level	Precedence Level in Resource-Priority SIP Header	0 (lowest)	routine	2	priority	4	immediate	6	flash	8	flash-override
MLPP Precedence Level	Precedence Level in Resource-Priority SIP Header												
0 (lowest)	routine												
2	priority												
4	immediate												
6	flash												
8	flash-override												

Parameter		Description
9 (highest)	flash-override-override	
'RTP DSCP for MLPP Routine' <code>configure voip &gt; gateway digital settings &gt; dscp- 4-mlpp-rtn</code> [MLPPRoutineRTPDSCP]		Defines the RTP DSCP for MLPP Routine precedence call level. The valid range is -1 to 63. The default is -1. <b>Note:</b> If set to -1, the DiffServ value is taken from the global parameter PremiumServiceClassMediaDiffServ or as defined in IP Profiles per call.
'RTP DSCP for MLPP Priority' <code>configure voip &gt; gateway digital settings &gt; dscp- 4-mlpp-prio</code> [MLPPPriorityRTPDSCP]		Defines the RTP DSCP for MLPP Priority precedence call level. The valid range is -1 to 63. The default is -1. <b>Note:</b> If set to -1, the DiffServ value is taken from the global parameter PremiumServiceClassMediaDiffServ or as defined in IP Profiles per call.
'RTP DSCP for MLPP Immediate' <code>configure voip &gt; gateway digital settings &gt; dscp- 4-mlpp-immed</code> [MLPPImmediateRTPDSCP]		Defines the RTP DSCP for MLPP Immediate precedence call level. The valid range is -1 to 63. The default is -1. <b>Note:</b> If set to -1, the DiffServ value is taken from the global parameter PremiumServiceClassMediaDiffServ or as defined in IP Profiles per call.
'RTP DSCP for MLPP Flash' <code>configure voip &gt; gateway digital settings &gt; dscp- 4-mlpp-flsh</code> [MLPPFlashRTPDSCP]		Defines the RTP DSCP for MLPP Flash precedence call level. The valid range is -1 to 63. The default is -1. <b>Note:</b> If set to -1, the DiffServ value is taken from the global parameter PremiumServiceClassMediaDiffServ or as defined in IP Profiles per call.
'RTP DSCP for MLPP Flash Override' <code>configure voip &gt; gateway digital settings &gt; dscp- 4-mlpp-flsh-ov</code> [MLPPFlashOverRTPDSCP]		Defines the RTP DSCP for MLPP Flash-Override precedence call level. The valid range is -1 to 63. The default is -1. <b>Note:</b> If set to -1, the DiffServ value is taken from the global parameter PremiumServiceClassMediaDiffServ or as defined in IP Profiles per call.

Parameter	Description
'RTP DSCP for MLPP Flash-Override-Override' configure voip > gateway digital settings > dscp- 4-mlpp-flsh-ov-ov [MLPPFlashOverOverRTPDSCP]	Defines the RTP DSCP for MLPP Flash-Override-Override precedence call level.  The valid range is -1 to 63. The default is -1.  <b>Note:</b> If set to -1, the DiffServ value is taken from the global parameter PremiumServiceClassMediaDiffServ or as defined in IP Profiles per call.

## Call Cut-through Parameters

The call cut-through parameters are described in the table below.

**Table 69-49:Call Cut-Through Parameters**

Parameter	Description
cut-through- anable [DigitalCutThrough]	Global parameter enabling PSTN CAS channels/endpoints to receive incoming IP calls even if the B-channels are in off-hook state.  You can also configure the feature per specific calls, using Tel Profiles ('Digital Cut Through' parameter). For a detailed description of the parameter and for configuring the feature in the Tel Profiles table, see <a href="#">Configuring Tel Profile</a> on page 738.  <b>Note:</b>  ■ If the feature is configured for a specific Tel Profile, the settings of the global parameter is ignored for calls associated with the Tel Profile.

## PSTN Parameters

This subsection describes the device's PSTN parameters.

### General Parameters

The general PSTN parameters are described in the table below.

**Table 69-50:General PSTN Parameters**

Parameter	Description
[ISDNTimerT310]	Defines the T310 override timer for DMS, Euro ISDN, and ISDN NI-2 variants. An ISDN timer is started when a Q.931 Call Proceeding message is

Parameter	Description
	<p>received. The timer is stopped when a Q.931 Alerting, Connect, or Disconnect message is received from the other end. If no ISDN Alerting, Progress, or Connect message is received within the duration of T310 timer, the call clears.</p> <p>The valid value range is 0 to 600 seconds. The default is 0 (i.e., use the default timer value according to the protocol's specifications).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ When both the parameters [ISDNdmsTimerT310] and [ISDNTimerT310] are configured, the value of the parameter [ISDNTimerT310] prevails.</li> </ul>
[ISDNdmsTimerT310]	<p>Defines the override T310 timer for the DMS-100 ISDN variant. T310 defines the timeout between the receipt of a Proceeding message and the receipt of an Alerting/Connect message.</p> <p>The valid range is 10 to 30. The default is 10 (seconds).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Instead of configuring the parameter, it is recommended to use the parameter [ISDNTimerT310].</li> <li>■ The parameter is applicable only to Nortel DMS and Nortel MERIDIAN PRI variants (ProtocolType = 14 and 35).</li> </ul>
[ISDNTimerT301]	<p>Defines the override T301 timer (in seconds). The T301 timer is started when a Q.931 Alert message is received. The timer is stopped when a Q.931 Connect/Disconnect message is received from the other side. If no Connect or Disconnect message is received within the duration of T301, the call is cleared.</p> <p>The valid range is 0 to 2400. The default is 0 (i.e., the default T301 timer value - 180 seconds - is used). If set to any value other than 0, it overrides the timer with this value.</p>



Parameter	Description
	<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ The parameter is applicable only to the ISDN QSIG protocol variant and the Network side of the NTT ISDN protocol variant.</li> <li>■ This timer is also affected by the [PSTNAlertTimeout] parameter.</li> </ul>
[ISDNJapanNTTTimerT3JA]	<p>Defines the T3_JA timer (in seconds). The parameter overrides the internal PSTN T301 timeout on the Users Side (TE side). If an outgoing call from the device to ISDN is not answered during this timeout, the call is released.</p> <p>The valid value is -1 to 300. The default is 0 (meaning 50 sec). The value -1 means that no timer is activated.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ This timer is also affected by the [PSTNAlertTimeout] parameter.</li> <li>■ The parameter is applicable only to the Japan NTT PRI variant (ProtocolType = 16).</li> </ul>
[TrunkLifeLineType]	<p>Defines the scenarios upon which the device activates PSTN Fallback for digital interfaces. When PSTN Fallback is triggered, the device automatically routes incoming Tel calls to the PSTN (instead of to the IP).</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) PSTN Fallback is activated upon the loss of power to the device, for example, due to a power outage or the unplugging of the device's power cable.</li> </ul> <p>PSTN Fallback is provided by two ports, where one port is connected to the PBX, for example, and the other to the PSTN. When PSTN Fallback is triggered, for example, due to a power outage, the device automatically connects the two ports using a metallic relay switch. In such a scenario, calls originating from the PBX are routed directly to the PSTN (instead of the IP network). For more</p>

Parameter	Description
	<p>information on PSTN Fallback cabling, refer to the <i>Hardware Installation Manual</i>.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ The parameter is applicable only to the digital interfaces.</li> <li>■ PSTN Fallback is supported only on specific hardware configurations and where dual digital ports are provided. For more information, refer to the <i>Hardware Installation Manual</i>.</li> <li>■ The PSTN Fallback feature has no relation to the PSTN Fallback License Key.</li> </ul>
[AdminState]	<p>Defines the administrative state for all trunks.</p> <ul style="list-style-type: none"> <li>■ [0] = Lock the trunk; stops trunk traffic to configure the trunk protocol type.</li> <li>■ [1] = Shutting down (read only).</li> <li>■ [2] = (Default) Unlock the trunk; enables trunk traffic.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ When the device is locked from the Web interface, the parameter changes to 0.</li> <li>■ To define the administrative state per trunk, use the [TrunkAdministrativeState] parameter.</li> </ul>
[TrunkAdministrativeState_x]	<p>Defines the administrative state per trunk, where x denotes the trunk number.</p> <ul style="list-style-type: none"> <li>■ [0] = Lock the trunk; stops trunk traffic to configure the trunk protocol type.</li> <li>■ [1] = shutting down (read only).</li> <li>■ [2] = (Default) Unlock the trunk; enables trunk traffic.</li> </ul>
[TDMHairPinning]	Defines static TDM hairpinning (cross-connection)

Parameter	Description
	<p>performed at initialization. The connection is between trunks with an option to exclude a single B-channel in each trunk. Format example: T0-T1/B3,T2-T3,T4-T5/B2.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ The parameter is applicable only to PRI.</li> </ul>
[TDMHairPinningAlarmIndication]	<p>Enables two trunks that are connected through TDM hairpinning to signal the Far-End about the presence of PSTN alarms. When the trunk with TDM hairpinning receives a PSTN alarm, its' connected trunk sends an AIS alarm to its' Far-End.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable</li> <li>■ [1] = Enable</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ The parameter is applicable only to PRI.</li> </ul>
<p>'TDM Tunneling'</p> <pre>configure voip &gt; gateway digital settings &gt; tdm- tunneling</pre> <p>[EnableTDMOverIP]</p>	<p>Enables TDM tunneling for all calls (trunks).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b> = Enables TDM tunneling. For more information, see <a href="#">TDM Tunneling</a> on page 883.</li> <li>■ [2] <b>Private Wire</b> = Enables TDM tunneling for private wire services. For more information, see <a href="#">Configuring Private Wire Interworking</a> on page 888.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ The parameter is applicable only to ISDN PRI.</li> <li>■ To enable TDM tunneling per trunk, use the [EnableTDMOverIPforTrunk] parameter.</li> </ul>
[EnableTDMOverIPforTrunk]	<p>Enables TDM tunneling for a specific trunk. For a</p>

Parameter	Description
	description of the parameter, see the [EnableTDMoverIP] parameter.
<pre>configure voip &gt; gateway digital settings &gt; iso8859-charset</pre> [ISO8859CharacterSet]	<p>Defines the ISO 8859 character set type (languages) for representing the alphanumeric string of the calling name (caller ID) in the forwarded message, for IP-to-Tel and Tel-to-IP calls.</p> <ul style="list-style-type: none"> <li>■ [0] = No Accented - proprietary method where incoming INVITE messages with any accented characters (e.g., á, é, í, ó, and ü), which are represented in a 2-byte unicode character, are translated to Latin-only, which are normal one-byte ASCII characters (a, e, i, o, and u, respectively).</li> <li>■ [1] = Western European (Default)</li> <li>■ [2] = Central European</li> <li>■ [3] = South European</li> <li>■ [4] = North European</li> <li>■ [5] = Cyrillic</li> <li>■ [6] = Arabic</li> <li>■ [7] = Hebrew</li> <li>■ [8] = Turkish</li> </ul>
'Time to Wait before Dialing' [WaitForDialTime]	<p>Defines the delay after hook-flash is generated and until dialing begins.</p> <p>The valid range (in milliseconds) is 0 to 20,000 (i.e., 20 seconds). The default is 1,000 (i.e., 1 second).</p>

## TDM Bus and Clock Timing Parameters

The TDM Bus parameters are described in the table below.

**Table 69-51:TDM Bus and Clock Timing Parameters**

Parameter	Description
TDM Bus Parameters	
Digital PCM	

Parameter	Description
<p>'PCM Law Select'</p> <pre>configure voip &gt; media tdm &gt; pcm-law-select</pre> <p>[PCMLawSelect]</p>	<p>Defines the type of pulse-code modulation (PCM) companding algorithm law in input and output TDM bus.</p> <ul style="list-style-type: none"> <li>■ [1] <b>Alaw</b></li> <li>■ [3] <b>MuLaw</b></li> </ul> <p>The default value is automatically selected according to the Protocol Type of the selected trunk (E1 defaults to A-Law; T1 defaults to Mu-Law). If the Protocol Type is set to NONE, the default is MuLaw.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ Typically, A-Law is used for E1 spans; Mu-Law for T1/J1 spans.</li> </ul>
<p>'Idle PCM Pattern'</p> <pre>configure voip &gt; media tdm &gt; idle-pcm-pattern</pre> <p>[IdlePCMPattern]</p>	<p>Defines the PCM Pattern that is applied to the PSTN timeslot (B-channel) when the channel is idle.</p> <p>The range is 0 to 255. The default is set internally according to the Law select 1 (0xFF for Mu-Law; 0x55 for A-law).</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
<p>'Idle ABCD Pattern'</p> <pre>configure voip &gt; media tdm &gt; idle-abcd-pattern</pre> <p>[IdleABCDPattern]</p>	<p>Defines the ABCD (CAS) Pattern that is applied to the CAS signaling bus when the channel is idle.</p> <p>The valid range is 0x0 to 0xF. The default is -1 (i.e., default pattern is 0000).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ The parameter is applicable only when using PSTN interface with the RAW_CAS protocol.</li> </ul>
General	
'TDM Bus Clock Source'	Defines the clock source to which the

Parameter	Description
<pre>configure voip &gt; media tdm &gt; tdm-bus-clock-source</pre> <p>[TDMBusClockSource]</p>	<p>device synchronizes.</p> <ul style="list-style-type: none"> <li>■ [1] <b>Internal</b> = (Default) Generate clock from local source.</li> <li>■ [4] <b>Network</b> = Recover clock from PSTN line.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> </ul>
<p>'TDM Bus Local Reference'</p> <pre>configure voip &gt; media tdm &gt; pstn-bus-local-reference</pre> <p>[TDMBusPSTNLocalReference]</p>	<p>Defines the physical Trunk ID from which the device recovers (receives) its clock synchronization.</p> <p>The range is 1 to the maximum number of Trunks. The default is 1.</p> <p><b>Note:</b> The parameter is applicable only if the [TDMBusClockSource] parameter is configured to 4 and the [TDMBusPSTNAutoClockEnable] parameter to 0.</p>
<p>'TDM Bus PSTN Auto FallBack Clock'</p> <pre>configure voip &gt; media tdm &gt; pstn-bus-auto-clock</pre> <p>[TDMBusPSTNAutoClockEnable]</p>	<p>Enables the PSTN trunk Auto-Fallback Clock feature.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. Recovers the clock from the trunk line configured by the [TDMBusPSTNLocalReference] parameter.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled. Recovers the clock from any connected synchronized slave trunk line. If this trunk loses its synchronization, the device attempts to recover the clock from the next trunk. Note that initially, the device attempts to recover the clock from the trunk defined by the [TDMBusPSTNLocalReference] parameter.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a</li> </ul>

Parameter	Description
	<p>device restart is required.</p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if the [TDMBusClockSource] parameter is configured to 4.</li> </ul>
<p>'TDM Bus PSTN Auto Clock Reverting'</p> <pre>configure voip &gt; media tdm &gt; pstn-bus-auto-clock-reverting</pre> <p>[TDMBusPSTNAutoClockRevertingEnable]</p>	<p>Enables the PSTN trunk Auto-Fallback Reverting feature. If enabled and a trunk returning to service has an AutoClockTrunkPriority parameter value that is higher than the priority of the local reference trunk (configured by the [TDMBusPSTNLocalReference] parameter), the local reference reverts to the trunk with the higher priority that has returned to service for the device's clock source.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ The parameter is applicable only when the [TDMBusPSTNAutoClockEnable] parameter is set to 1.</li> </ul>

## CAS Parameters

The Common Channel Associated (CAS) parameters are described in the table below.



CAS is applicable only to ISDN PRI interfaces.

**Table 69-52: CAS Parameters**

Parameter	Description
<p>'CAS Transport Type'</p> <pre>cas-transport-type</pre> <p>[CASTransportType]</p>	<p>Determines the ABCD signaling transport type over IP.</p> <ul style="list-style-type: none"> <li>■ [0] <b>CAS Events Only</b> = (Default) Disable CAS relay.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [1] <b>CAS RFC2833 Relay</b> = Enable CAS relay mode using RFC 2833.</li> </ul> <p>The CAS relay mode can be used with the TDM tunneling feature to enable tunneling over IP for both voice and CAS signaling bearers.</p>
[CASAddressingDelimiters]	<p>Enables the addition of delimiters to the received address or received ANI digits string.</p> <ul style="list-style-type: none"> <li>■ [0] = (default) Disable. The address and ANI strings remain without delimiters.</li> <li>■ [1] = Enable. Delimiters such as '*', '#', and 'ST' are added to the received address or received ANI digits string.</li> </ul>
<pre>configure voip &gt; interface e1-t1 &gt; cas-delimiters-types</pre> <p>[CASDelimitersPaddingUsage]</p>	<p>Defines the digits string delimiter padding usage per trunk.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Default address string padding: '*XXX#' (where XXX is the digit string that begins with '*' and ends with '#', when using padding).</li> <li>■ [1] = Special use of asterisks delimiters: '*XXX*YYY*' (where XXX is the address, YYY is the source phone number, and '*' is the only delimiter padding).</li> </ul> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
[CASFileName_x]	<p>Defines the CAS file name (e.g., 'E_M_WinkTable.dat') that defines the CAS protocol, where x denotes the CAS file ID (0-7). It is possible to define up to eight different CAS files by repeating the parameter. Each CAS file can be associated with one or more of the device's trunks, using the parameter CASTableIndex_x.</p>



Parameter	Description
	<b>Note:</b> For the parameter to take effect, a device restart is required.
[CASTablesNum]	<p>Defines the number of loaded CAS protocol configurations files.</p> <p>The valid range is 1 to 8.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
<b>CAS State Machines Parameters</b> <b>Note:</b> To configure the CAS State Machine table using the Web interface, see <a href="#">Configuring CAS State Machines</a> on page 880. The CAS state machine can be configured only through the Web-based management tool.	
'Generate Digit On Time' [CASStateMachineGenerateDigitOnTime]	<p>Generates digit on-time (in msec).</p> <p>The value must be a positive value. The default is -1.</p>
'Generate Inter Digit Time' [CASStateMachineGenerateInterDigitTime]	<p>Generates digit off-time (in msec).</p> <p>The value must be a positive value. The default is -1.</p>
'DTMF Max Detection Time' [CASStateMachineDTMFMaxOnDetectionTime]	<p>Detects digit maximum on time (according to DSP detection information event) in msec units.</p> <p>The value must be a positive value. The default is -1.</p>
'DTMF Min Detection Time' [CASStateMachineDTMFMinOnDetectionTime]	<p>Detects digit minimum on time (according to DSP detection information event) in msec units. The digit time length must be longer than this value to receive a detection. Any number may be used, but the value must be less than CasStateMachineDTMFMaxOnDetection Time.</p> <p>The value must be a positive value. The default is -1.</p>
'MAX Incoming Address Digits' [CASStateMachineMaxNumOfIncomingAddress Digits]	<p>Defines the limitation for the maximum address digits that need to be collected. After reaching this number of digits, the collection of address digits is stopped.</p>

Parameter	Description
	The value must be an integer. The default is -1.
'MAX Incoming ANI Digits' [CASStateMachineMaxNumOfIncomingANIDigits]	Defines the limitation for the maximum ANI digits that need to be collected. After reaching this number of digits, the collection of ANI digits is stopped. The value must be an integer. The default is -1.
'Collect ANI' [CASStateMachineCollectANI]	In some cases, when the state machine handles the ANI collection (not related to MFCR2), you can enable the state machine to collect ANI or discard ANI. <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = Don't collect ANI.</li> <li>■ [1] <b>Yes</b> = Collect ANI.</li> <li>■ [-1] <b>Default</b> = Default value.</li> </ul>
'Digit Signaling System' [CASStateMachineDigitSignalingSystem]	Defines which Signaling System to use in both directions (detection\generation). <ul style="list-style-type: none"> <li>■ [0] <b>DTMF</b> = DTMF signaling.</li> <li>■ [1] <b>MF</b> = (Default) MF signaling.</li> <li>■ [-1] <b>Default</b> = Default value.</li> </ul>

## ISDN Parameters

The ISDN parameters are described in the table below.

**Table 69-53:ISDN Parameters**

Parameter	Description
configure voip > gateway digital settings > ign- isdn-disc-w-pi [KeepISDNCallOnDisconnectWithPI]	Enables the device to ignore ISDN Disconnect messages with Progress Indicator (PI) information element (IE) values 1 or 8. <ul style="list-style-type: none"> <li>■ [1] = The call (in connected state) is not released if a Q.931 Disconnect with PI (PI = 1 or 8) message is received during the call.</li> <li>■ [0] = (Default) The call is disconnected.</li> </ul>

Parameter	Description
<pre>configure voip &gt; gateway digital settings &gt; pi-4- setup-msg</pre> <p>[PIForSetupMsg]</p>	<p>Defines if and which Progress Indicator (PI) information element (IE) is added to the sent ISDN Setup message. Some ISDN protocols such as NI-2 or Euro ISDN can optionally contain PI = 1 or PI = 3 in the Setup message.</p> <ul style="list-style-type: none"> <li>■ [0] = PI is not added (default).</li> <li>■ [1] = PI 1 is added to a sent ISDN Setup message - call is not end-to-end ISDN.</li> <li>■ [3] = PI 3 is added to a sent ISDN Setup message - calling equipment is not ISDN.</li> </ul>
<pre>no-sdp-for-isdn-pi</pre> <p>[NoSdpForIsdnPi]</p>	<p>Defines the value of the Progress Indicator (PI) information element (IE) that if present in the received ISDN Progress message, the device sends SIP 180 messages <b>without</b> an SDP body (for Tel-to-IP calls).</p> <p>The valid value is a bit field, allowing you to specify more than one PI. The default is 0, meaning that SDP is included in the outgoing SIP 180 message, regardless of PI value.</p>
<p>'B-channel Negotiation'</p> <pre>configure voip &gt; gateway digital settings &gt; b-ch- negotiation</pre> <p>[BchannelNegotiation]</p>	<p>Defines the ISDN B-channel negotiation mode for all trunks.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Preferred</b></li> <li>■ [1] <b>Exclusive</b> (default)</li> <li>■ [2] <b>Any</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For some ISDN variants, when 'Any' (2) is selected, the Setup message excludes the Channel Identification IE.</li> <li>■ The 'Any' (2) option is applicable only if the following conditions are met: <ul style="list-style-type: none"> <li>✓ The parameter TerminationSide is set to 0 ('User side').</li> <li>✓ The PSTN protocol type (ProtocolType) is configured as Euro ISDN.</li> </ul> </li> <li>■ To configure B-channel negotiation mode per trunk, see the [BChannelNegotiationForTrunk]</li> </ul>

Parameter	Description
	parameter.
<pre>configure voip &gt; gateway digital settings &gt; isdn- channel-id-format</pre> <p>[ISDNChannelIDFormat]</p>	<p>Defines the channel number format in the Channel Identification IE when sending Q.931 ISDN messages.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Channel Number</li> <li>■ [1] = Slotmap</li> </ul> <p>The device's handling of the Channel Identification format is as follows:</p> <ul style="list-style-type: none"> <li>■ Device as Network Termination (NT): <ul style="list-style-type: none"> <li>✓ Device-to-PBX: The device includes the configured Channel Identification format (Slotmap or Channel Number) in the outgoing ISDN Setup. The PBX can respond (Call Proceeding, Alert or Connect) with its own Channel Identification, which the device adopts. However, if the PBX doesn't include information for the Channel Identification, the device adopts the one that it offered in the Setup.</li> <li>✓ PBX-to-Device: The device adopts the same Channel Identification received in the Setup from the PBX (and notifies this to the PBX in the Call Proceeding). However, If the PBX didn't include information for the Channel Identification, the device adopts the configured format (and notifies this to the PBX in Call Proceeding).</li> </ul> </li> <li>■ Device as Terminal Equipment (TE): <ul style="list-style-type: none"> <li>✓ Device-to-PBX: The device includes the configured Channel Identification format (Slotmap or Channel Number), and notifies this to the PBX in the Setup.</li> <li>✓ PBX-to-Device: The device includes the configured Channel Identification format (Slotmap or Channel Number), and notifies this to the PBX in the Call</li> </ul> </li> </ul>

Parameter	Description
	<p>Proceeding.</p> <p><b>Note:</b> The parameter is applicable only to the NTT ISDN and Euro ISDN protocols.</p>
<code>e1-t1 isdn-channel-id-format-for-trunk</code> <code>[ISDNChannelIDFormatForTrunk]</code>	<p>Defines the channel number format in the Channel Identification IE when sending Q.931 ISDN messages, per Trunk.</p> <ul style="list-style-type: none"> <li>■ [-1] = (Default) According to the global parameter <code>[ISDNChannelIDFormat]</code>.</li> <li>■ [0] = Channel Number</li> <li>■ [1] = Slotmap</li> </ul> <p>For more information, refer to the <code>[ISDNChannelIDFormat]</code> parameter.</p>
<code>[PSTNExtendedParams]</code>	<p>Determines the bit map for special PSTN behavior parameters:</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Applicable for NI-2 ISDN and QSIG "Networking Extensions". This bit (i.e., bit #0) is responsible for the Invoke ID size: <ul style="list-style-type: none"> <li>✓ If this bit is not set (default), then the Invoke ID size is always one byte, with a value of 01 to 7f.</li> <li>✓ If this bit is set, then the Invoke ID size is one or two bytes according to the Invoke ID value.</li> </ul> </li> <li>■ [2] = Applicable to the ROSE format (according to the old QSIG specifications). This bit (i.e., bit #1) is responsible for the QSIG octet 3. According to the ECMA-165 new version, octet 3 in all QSIG supplementary services Facility messages should be 0x9F = Networking Extensions. However, according to the old version, the value should be 0x91 = ROSE: <ul style="list-style-type: none"> <li>✓ If this bit is not set (default): 0x9F = Networking Extensions.</li> <li>✓ If this bit is set: 0x91 = ROSE.</li> </ul> </li> <li>■ [3] = Use options [0] and [2] above.</li> </ul>

Parameter	Description
	<b>Note:</b> For the parameter to take effect, a device restart is required.
<pre>configure voip &gt; gateway digital settings &gt; trunk- restart-mode-on-powerup [TrunkRestartModeOnPowerUp]</pre>	<p>Defines if the device sends the RESTART message upon power up.</p> <ul style="list-style-type: none"> <li>■ [0] = No RESTART message is sent.</li> <li>■ [1] = (Default) Per trunk - device sends only one RESTART message for the whole trunk.</li> <li>■ [2] = Per B-channel - device sends a RESTART message for each B-channel of the trunk.</li> </ul> <p><b>Note:</b> The parameter is applicable only to and ISDN.</p>

## ISDN and CAS Interworking Parameters

The ISDN and CAS interworking parameters are described in the table below.

**Table 69-54:ISDN and CAS Interworking Parameters**

Parameter	Description
<b>ISDN Parameters</b>	
<pre>'Send Local Time To ISDN Connect' [SendLocalTimeToISDNCon nect]</pre>	<p>Determines the device's handling of the date and time sent in the ISDN Connect message (Date / Time IE) upon receipt of SIP 200 OK messages.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) If the SIP 200 OK includes the Date header, the device sends its value in the ISDN Connect Date / Time IE. If the 200 OK doesn't include this header, it doesn't add the Date / Time IE to the sent ISDN Connect message.</li> <li>■ [1] <b>Enable</b> = If the SIP 200 OK includes the Date header, the device sends its value (i.e. date and time) in the ISDN Connect Date / Time IE. If the 200 OK doesn't include this header, the device uses its internal, local date and time for the Date / Time IE, which it adds to the sent ISDN Connect message.</li> <li>■ [2] <b>Always Send Local Date and Time</b> = The device always sends its local date and time (obtained from its internal clock) to PBXs in ISDN Q.931 Connect messages (Date / Time IE). It does this regardless of whether or not</li> </ul>

Parameter	Description
	<p>the incoming SIP 200 OK includes the Date header. If the SIP 200 OK includes the Date header, the device ignores its value.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ This feature is applicable only to Tel-to-IP calls.</li> <li>■ For IP-to-Tel calls, the parameter is not applicable. Only if the incoming ISDN Connect message contains the Date / Time IE does the device add the Date header to the sent SIP 200 OK message.</li> </ul>
<p>'Min Routing Overlap Digits'</p> <pre>configure voip &gt; gateway dtmf-supp- service dtmf-and- dialing &gt; min-dg- b4-routing</pre> <p>[MinOverlapDigitsForRouting]</p>	<p>Defines the minimum number of overlap digits to collect (for ISDN overlap dialing) before sending the first SIP message for routing Tel-to-IP calls.</p> <p>The valid value range is 0 to 49. The default is 1.</p> <p><b>Note:</b> The parameter is applicable when the ISDNRxOverlap parameter is set to [2] or [3].</p>
<p>'ISDN Overlap IP to Tel Dialing'</p> <pre>configure voip &gt; gateway dtmf-supp- service dtmf-and- dialing &gt; isdn-tx- overlap</pre> <p>[ISDNTxOverlap]</p>	<p>Enables ISDN overlap dialing for IP-to-Tel calls. This feature is part of ISDN-to-SIP overlap dialing according to RFC 3578.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Through SIP</b> = The device sends the first received digits from the initial INVITE to the Tel side in an ISDN Setup message. For each subsequently received re-INVITE message of the same dialog session, the device sends the collected digits to the Tel side in ISDN Info Q.931 messages. For each received re-INVITE, the device sends a SIP 484 Address Incomplete response to maintain the current dialog session and to receive additional digits from subsequent re-INVITES.</li> <li>■ [2] <b>Through SIP INFO</b> = The device sends the first received digits from the initial INVITE to the Tel side in an ISDN Setup message and then responds to the IP side with a SIP 183. For each subsequently received SIP INFO message with additional digits of the same dialog session, the device sends the collected digits to the Tel side in ISDN Info Q.931 messages. For each received SIP INFO, the device sends a SIP 200 OK response to</li> </ul>

Parameter	Description
	<p>maintain the current dialog session and to receive additional digits from subsequent INFOs.</p> <p><b>Note:</b> When IP-to-Tel overlap dialing is enabled, to send ISDN Setup messages without the Sending Complete IE, the ISDNOutCallsBehavior parameter must be set to USER SENDING COMPLETE (2).</p>
<p>'Mute DTMF In Overlap'</p> <pre>configure voip &gt; gateway dtmf-supp- service supp- service-settings &gt; mute-dtmf-in- overlap</pre> <p>[MuteDTMFINOverlap]</p>	<p>Enables the muting of in-band DTMF detection until the device receives the complete destination number from the ISDN (for Tel-to-IP calls). In other words, the device doesn't accept DTMF digits received in the voice stream from the PSTN, but only accepts digits from ISDN Info messages.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Don't Mute</b> (default).</li> <li>■ [1] <b>Mute DTMF in Overlap Dialing</b> = The device ignores in-band DTMF digits received during ISDN overlap dialing (disables the DTMF in-band detector).</li> </ul> <p><b>Note:</b> The parameter is applicable to ISDN Overlap mode only when dialed numbers are sent using Q.931 Information messages.</p>
[ConnectedNumberType]	<p>Defines the Numbering Type of the ISDN Q.931 Connected Number IE that the device sends in the Connect message to the ISDN (for Tel-to-IP calls). This is interworked from the P-Asserted-Identity header in SIP 200 OK.</p> <p>The default is [0] (i.e., unknown).</p>
<pre>configure voip &gt; gateway dtmf-supp- service supp- service-settings &gt; connected-number- type</pre> <p>[ConnectedNumberPlan]</p>	<p>Defines the Numbering Plan of the ISDN Q.931 Connected Number IE that the device sends in the Connect message to the ISDN (for Tel-to-IP calls). This is interworked from the P-Asserted-Identity header in SIP 200 OK.</p> <p>The default is [0] (i.e., unknown).</p>
<p>'Enable ISDN Tunneling Tel to IP'</p> <pre>configure voip &gt; gateway digital settings &gt; isdn- tnl-tel2ip</pre> <p>[EnableISDNTunnelingTel2I]</p>	<p>Enables ISDN Tunneling.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default).</li> <li>■ [1] <b>Using Header</b> = Enable ISDN Tunneling from ISDN to SIP using a proprietary SIP header.</li> <li>■ [2] <b>Using Body</b> = Enable ISDN Tunneling from ISDN to SIP using a dedicated message body.</li> </ul>



Parameter	Description
P]	<p>When ISDN Tunneling is enabled, the device sends all ISDN messages using the correlated SIP messages. The ISDN Setup message is tunneled using SIP INVITE, all mid-call messages are tunneled using SIP INFO, and ISDN Disconnect/Release message is tunneled using SIP BYE messages. The raw data from the ISDN is inserted into a proprietary SIP header (X-ISDNTunnelingInfo) or a dedicated message body (application/isdn) in the SIP messages.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For this feature to function, configure the [ISDNDuplicateQ931BuffMode] parameter to 128 (i.e., duplicate all messages).</li> <li>■ ISDN tunneling is applicable for all ISDN variants as well as QSIG.</li> </ul>
<p>'Enable ISDN Tunneling IP to Tel'</p> <pre>configure voip &gt; gateway digital settings &gt; isdn- tnl-ip2tel</pre> <p>[EnableISDNTunnelingIP2Tel]</p>	<p>Enables ISDN Tunneling for IP-to-Tel calls.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable ISDN Tunneling from IP to ISDN</b></li> </ul> <p>When ISDN Tunneling is enabled, the device extracts raw data received in the proprietary SIP header, x-isdntunnelinginfo, or a dedicated message body (application/isdn) in the SIP message and then sends the data in an ISDN message to the PSTN.</p> <p>If the raw data in this SIP header is suffixed with the string "ADDE", then the raw data is extracted and added as Informational Elements (IE) in the outgoing Q.931 message. The tunneling of the x-isdntunnelinginfo SIP header with IEs is converted from INVITE, 180, and 200 OK SIP messages to Q.931 SETUP, ALERT, and CONNECT respectively.</p> <p>For example, if the following SIP header is received,</p> <pre>x-isdntunnelinginfo: ADDE1C269FAA 06 800100820100A10F020136 0201F0A00702010102021F69</pre> <p>then it is added as an IE to the outgoing Q.931 message as 1C269FAA 06 800100820100A10F020136 0201F0A00702010102021F69, where, for example, "1C269F" is a 26 byte length Facility IE.</p> <p><b>Note:</b> The feature is similar to that of the AddIEinSetup parameter. If both parameters are configured, the AddIEinSetup parameter is ignored.</p>

Parameter	Description
'Enable QSIG Tunneling' configure voip > gateway digital settings > qsig- tunneling [EnableQSIGTunneling]	Global parameter that enables QSIG tunneling-over-SIP for all calls. You can also configure this feature per specific calls, using IP Profiles ('QSIG Tunneling' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664. <b>Note:</b> If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.
configure voip > gateway digital settings > qsig- tunneling-mode [QSIGTunnelingMode]	Defines the format of encapsulated QSIG message data in the SIP message MIME body. <ul style="list-style-type: none"><li>■ [0] = (Default) ASCII presentation of Q.931 QSIG message.</li><li>■ [1] = Binary encoding of Q.931 QSIG message (according to ECMA-355, RFC 3204, and RFC 2025).</li></ul> <b>Note:</b> The parameter is applicable only if the QSIG Tunneling feature is enabled, using the [EnableQSIGTunneling] parameter.
'Enable Hold to ISDN' configure voip > gateway dtmf-supp- service supp- service-settings > hold-to-isdn [EnableHold2ISDN]	Enables SIP-to-ISDN interworking of the Hold/Retrieve supplementary service. <ul style="list-style-type: none"><li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li><li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li></ul> <b>Note:</b> <ul style="list-style-type: none"><li>■ The parameter is applicable to Euro ISDN variants - from TE (user) to NT (network).</li><li>■ If the parameter is disabled, the device plays a held tone to the Tel side when a SIP request with 0.0.0.0 or "inactive" in SDP is received. An appropriate CPT file with the held tone should be used.</li></ul>
'ISDN SubAddress Format' configure voip > gateway digital settings > isdn- subaddr-frmt [ISDNSubAddressFormat]	Determines the encoding format of the SIP Tel URI parameter 'isub', which carries the encoding type of ISDN subaddresses. This is used to identify different remote ISDN entities under the same phone number (ISDN Calling and Called numbers) for interworking between ISDN and SIP networks. <ul style="list-style-type: none"><li>■ [0] <b>ASCII</b> = (Default) IA5 format that allows up to 20</li></ul>

Parameter	Description
	<p>digits. Indicates that the 'isub' parameter value needs to be encoded using ASCII characters.</p> <ul style="list-style-type: none"> <li>■ [1] <b>BCD</b> = (Binary Coded Decimal) - allows up to 40 characters (digits and letters). Indicates that the 'isub' parameter value needs to be encoded using BCD when translated to an ISDN message.</li> <li>■ [2] <b>User Specified</b></li> </ul> <p>For IP-to-Tel calls, if the incoming SIP INVITE message includes subaddress values in the 'isub' parameter for the Called Number (in the Request-URI) and/or the Calling Number (in the From header), these values are mapped to the outgoing ISDN Setup message.</p> <p>If the incoming ISDN Setup message includes 'subaddress' values for the Called Number and/or the Calling Number, these values are mapped to the outgoing SIP INVITE message's 'isub' parameter in accordance with RFC 4715.</p>
<pre>configure voip &gt; gateway dtmf-supp- service supp- service-settings &gt; ignore-isdn- subaddress [IgnoreISDNSubaddress]</pre>	<p>Determines whether the device ignores the Subaddress from the incoming ISDN Called and Calling numbers when sending to IP.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) If an incoming ISDN Q.931 Setup message contains a Called/Calling Number Subaddress, the Subaddress is interworked to the SIP 'isub' parameter according to RFC.</li> <li>■ [1] = The device removes the ISDN Subaddress and doesn't include the 'isub' parameter in the Request-URI and doesn't process INVITEs with the parameter.</li> </ul>
[ISUBNumberOfDigits]	<p>Defines the number of digits (from the end) that the device takes from the called number (received from the IP) for the isub number (in the sent ISDN Setup message). This feature is applicable only for IP-to-ISDN calls.</p> <p>The valid value range is 0 to 36. The default is 0.</p> <p>This feature operates as follows:</p> <ol style="list-style-type: none"> <li>1. If an isub parameter is received in the Request-URI, for example, INVITE sip:9565645;<b>isub</b>=1234@host-t.domain:user=phone SIP/2.0 then the isub value is sent in the ISDN Setup message as the destination subaddress.</li> </ol>

Parameter	Description
	<ol style="list-style-type: none"> <li>2. If the isub parameter is not received in the user part of the Request-URI, the device searches for it in the URI parameters of the To header, for example, To: "Alex" &lt;sip: 9565645@host.domain;<b>isub</b>=1234&gt; If present, the isub value is sent in the ISDN Setup message as the destination subaddress.</li> <li>3. If the isub parameter is not present in the Request-URI header nor To header, the device does the following: <ul style="list-style-type: none"> <li>✓ If the called number (that appears in the user part of the Request-URI) starts with zero (0), for example, INVITE sip:05694564@host.domain:user=phone SIP/2.0 then the device maps this called number to the destination number of the ISDN Setup message, and the destination subaddress in this ISDN Setup message remains empty.</li> <li>✓ If the called number (that appears in the user part of the Request-URI) doesn't start with zero, for example, INVITE sip:5694564@host.domain:user=phone SIP/2.0 then the device maps this called number to the destination number of the ISDN Setup message, and the destination subaddress in this ISDN Setup message then contains y digits from the end of the called number. The y number of digits can be configured using the ISUBNumberOfDigits parameter. The default value of ISUBNumberOfDigits is 0, thus, if the parameter is not configured, and 1) and 2) scenarios (described above) have not provided an isub value, the subaddress remains empty.</li> </ul> </li> </ol>
'Default Cause Mapping From ISDN to SIP' <pre>configure voip &gt; gateway digital settings &gt; dflt- cse-map-isdn2sip [DefaultCauseMapISDN2IP]</pre>	Defines a single default ISDN release cause that is used (in ISDN-to-IP calls) instead of all received release causes, except when the following Q.931 cause values are received: Normal Call Clearing (16), User Busy (17), No User Responding (18), or No Answer from User (19). The range is any valid Q.931 release cause (0 to 127). The default is 0 (i.e., not configured - static mapping is used).

Parameter	Description																										
'Enable Calling Party Category'  configure voip > gateway digital settings > ni2-cpc  [EnableCallingPartyCategory]	<p>Enables the mapping of the calling party category (CPC) between the incoming PSTN message and outgoing SIP message, and vice versa (i.e., for IP-to-Tel and Tel-to-IP calls). The CPC characterizes the station used to originate a call (e.g., a payphone or an operator).</p> <p>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. CPC is not relayed between SIP and PSTN.</p> <p>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</p> <p>The CPC is denoted in the PSTN message as follows:</p> <p>■ ISDN PRI NI-2: In the Originating Line Information (OLI) Information Element (IE) of the ISDN Setup message.</p> <p>■ MFC-R2: ANI II digits. The device supports the Brazilian and Argentinian variants. This regional support is configured using the CallingPartyCategoryMode.</p> <p>The CPC is denoted in the SIP INVITE message using the 'cpc=' parameter in the From or P-Asserted-Identity headers. For example, the 'cpc=' parameter in the below INVITE message is set to "payphone":</p> <pre>INVITE sip:bob@biloxi.example.com SIP/2.0</pre> <p>To: "Bob" &lt;sip:bob@biloxi.example.com&gt;</p> <p>From:</p> <pre>&lt;tel:+17005554141;cpc=payphone&gt;;tag=1928301774</pre> <p>The table below shows the mapping of CPC between SIP and PSTN:</p> <table><tr><th rowspan="2">SIP CPC</th><th rowspan="2">NI-2 PRI</th><th colspan="2">MFC-R2</th></tr><tr><th>Argentina</th><th>Brazil</th></tr><tr><td>ordinary</td><td>23</td><td>II-1</td><td>II-1</td></tr><tr><td>priority</td><td>n/a</td><td>II-2</td><td>II-2</td></tr><tr><td>data</td><td>n/a</td><td>II-6</td><td>II-6</td></tr><tr><td>test</td><td>n/a</td><td>II-3</td><td>II-3</td></tr><tr><td>operator</td><td>35</td><td>II-5</td><td>II-5</td></tr></table>	SIP CPC	NI-2 PRI	MFC-R2		Argentina	Brazil	ordinary	23	II-1	II-1	priority	n/a	II-2	II-2	data	n/a	II-6	II-6	test	n/a	II-3	II-3	operator	35	II-5	II-5
SIP CPC	NI-2 PRI			MFC-R2																							
		Argentina	Brazil																								
ordinary	23	II-1	II-1																								
priority	n/a	II-2	II-2																								
data	n/a	II-6	II-6																								
test	n/a	II-3	II-3																								
operator	35	II-5	II-5																								

Parameter	Description			
	payphone	70	II-4	II-7
	unknown	n/a	II-1	II-1
	subscriber	23	n/a	II-1
	cellular	61	II-13	n/a
	locutorio	n/a	II-11	n/a
	servicio-publico	n/a	II-12	n/a
	red-privada-virtual / private-virtual-network	n/a	II-14	n/a
	linea-especial / special-operator-handling-required	n/a	II-15	n/a
	operadora-con-intervencion / telco-operator-handled-call	n/a	II-5	n/a
	prison	29	n/a	n/a
	hotel	66	n/a	n/a
	cellular-roaming	63	n/a	n/a
<b>Note:</b> This feature is applicable only to the NI-2 PRI and E1 MFC-R2 variants.				
'Calling Party Category Mode' <pre>configure voip &gt; gateway digital settings &gt; cpc-mode</pre> [CallingPartyCategoryMode]	Defines the regional Calling Party Category (CPC) mapping variant between SIP and PSTN for MFC-R2. <ul style="list-style-type: none"> <li>■ [0] <b>None</b> (default)</li> <li>■ [1] <b>Brazil R2</b></li> <li>■ [2] <b>Argentina R2</b></li> </ul> <b>Note:</b> <ul style="list-style-type: none"> <li>■ To enable CPC mapping, set the EnableCallingPartyCategory parameter to 1.</li> <li>■ The parameter is applicable only to the E1 MFC-R2</li> </ul>			

Parameter	Description
	variant.
'Remove CLI when Restricted' <pre>configure voip &gt; gateway digital settings &gt; rmv- cli-when-restr</pre> [RemoveCLIWhenRestricted]	Determines (for IP-to-Tel calls) whether the Calling Number and Calling Name IEs are removed from the ISDN Setup message if the presentation is set to Restricted. <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) IE's are not removed.</li> <li>■ [1] <b>Yes</b> = IE's are removed.</li> </ul>
'Remove Calling Name' <pre>configure voip &gt; gateway digital settings &gt; rmv- calling-name</pre> [RemoveCallingName]	Enables the device to remove the Calling Name from SIP-to-ISDN calls for all trunks. <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p><b>Note:</b> Some PSTN switches / PBXs may not be configured to support the receipt of the "Calling Name" information. These switches might respond to an ISDN Setup message (including the Calling Name) with an ISDN "REQUESTED_FAC_NOT_SUBSCRIBED" failure. The parameter can be set to Enable (1) to remove the "Calling Name" from SIP-to-ISDN calls and allow the call to proceed.</p>
'CID Notification' <pre>configure voip &gt; gateway digital settings &gt; cid- notification</pre> [CIDNotification]	Enables presentation in the outgoing SIP message when the presentation indicator in the Calling Party Number information element of the incoming ISDN message has the value "number not available due to interworking". <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. The device restricts presentation in the outgoing SIP message. The device sends the SIP message with "anonymous" in the From header (e.g., From: "anonymous" &lt;sip:anonymous@anonymous.invalid&gt;).</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled. The device allows presentation in the outgoing SIP message (e.g., From: "Bob" &lt;sip:12345@10.33.1.6&gt;;tag=1c172113195).</li> </ul> <p><b>Note:</b> The parameter is applicable only to Tel-to-IP calls.</p>
'CID Not Included Notification' <pre>configure voip &gt;</pre>	Enables presentation in the outgoing SIP message when the Calling Party Number information element of the incoming ISDN message doesn't include the presentation indicator.

Parameter	Description
<pre>gateway digital settings &gt; cid- not-included- notification</pre> <p>[CIDNotIncludedNotification]</p>	<ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = Disabled. The device restricts presentation in the outgoing SIP message. The device sends the SIP message with "anonymous" in the From header (e.g., From: "anonymous" &lt;sip:anonymous@anonymous.invalid&gt;).</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = (Default) Enabled. The device allows presentation in the outgoing SIP message (e.g., From: "Bob" &lt;sip:12345@10.33.1.6&gt;;tag=1c172113195).</li> </ul> <p><b>Note:</b> The parameter is applicable only to Tel-to-IP calls.</p>
[ConnectOnProgressInd]	<p>Enables the play of announcements from IP to Tel without the need to answer the Tel-to-IP call. It can be used with PSTN networks that don't support the opening of a TDM channel before an ISDN Connect message is received.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Connect message isn't sent after SIP 183 Session Progress message is received.</li> <li>■ [1] = Connect message is sent after SIP 183 Session Progress message is received.</li> </ul>
<pre>configure voip &gt; gateway dtmf-supp- service supp- service-settings &gt; snd-isdn-ser-aftr- restart</pre> <p>[SendISDNServiceAfterRestart]</p>	<p>Enables the device to send an ISDN Service message per trunk upon device restart. The message (transmitted on the trunk's D-channel) indicates the availability of the trunk's B-channels (i.e., trunk in service).</p> <ul style="list-style-type: none"> <li>■ [0] = Disable (default)</li> <li>■ [1] = Enable</li> </ul>
<pre>configure voip &gt; sip-definition proxy-and- registration &gt; redirect-in- facility</pre> <p>[SupportRedirectInFacility]</p>	<p>Determines whether the Redirect Number is retrieved from the Facility IE.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Not supported.</li> <li>■ [1] = Supports partial retrieval of Redirect Number (number only) from the Facility IE in ISDN Setup messages. This is applicable to Redirect Number according to ECMA-173 Call Diversion Supplementary Services.</li> </ul> <p><b>Note:</b> To enable this feature, configure the [ISDNDuplicateQ931BuffMode] parameter to 1.</p>
[EnableCIC]	Enables the relay of the Carrier Identification Code (CIC) to



Parameter	Description
	<p>the ISDN.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disabled - CIC is not relayed to the ISDN.</li> <li>■ [1] = Enabled - CIC (received in the INVITE Request-URI) is relayed to the ISDN in the Transit Network Selection (TNS) IE of the Setup message. For example: INVITE sip:555666;cic=2345@100.2.3.4 sip/2.0.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ This feature is supported only for SIP-to-ISDN calls.</li> <li>■ The parameter AddCicAsPrefix can be used to add the CIC as a prefix to the destination phone number for routing IP-to-Tel calls.</li> </ul>
<p>'AoC Support'</p> <pre>configure voip &gt; gateway dtmf-supp- service supp- service-settings &gt; aoc-support [EnableAOC]</pre>	<p>Enables the interworking of ISDN Advice of Charge (AOC) messages to SIP.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>For more information on AOC, see <a href="#">Advice of Charge Services for Euro ISDN</a> on page 1007.</p>
<p>'Add IE in SETUP'</p> <pre>configure voip &gt; gateway digital settings &gt; add-ie- in-setup [AddIEinSetup]</pre>	<p>Global parameter that defines an optional Information Element (IE) data (in hex format) to add to ISDN Setup messages. You can also configure this feature per specific calls, using IP Profiles ('Add IE In Setup' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b> If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</p>
<p>'Trunk Groups to Send IE'</p> <pre>configure voip &gt; gateway digital settings &gt; trkgrps-to-snd-ie [SendIEonTG]</pre>	<p>Defines Trunk Group IDs (up to 50 characters) from where the optional ISDN IE (defined by the parameter AddIEinSetup) is sent. For example: '1,2,4,10,12,6'.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ You can configure different IE data for Trunk Groups by defining the parameter for different IP Profile IDs (using the parameter IPProfile), and then assigning the required IP Profile ID in the IP-to-Tel Routing table (PSTNPrefix).</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ When IP Profiles are used for configuring different IE data for Trunk Groups, the parameter is ignored.</li> </ul>
'Enable User-to-User IE for Tel to IP' <pre>configure voip &gt; gateway digital settings &gt; uui-ie- for-tel2ip</pre> [EnableUUITel2IP]	Enables transfer of User-to-User (UU) IE from ISDN to SIP. <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> The device supports the following ISDN-to-SIP interworking: Setup to SIP INVITE, Connect to SIP 200 OK, User Information to SIP INFO, Alerting to SIP 18x response, and Disconnect to SIP BYE response messages. <p><b>Note:</b> The interworking of ISDN User-to-User IE to SIP INFO is applicable only to the Euro ISDN, QSIG, and 4ESS ISDN variants.</p>
'User-to-User IE for IP-to-Tel' <pre>configure voip &gt; gateway digital settings &gt; uui-ie- for-ip2tel</pre> [EnableUUIP2Tel]	Enables interworking of SIP user-to-user information (UUI) to User-to-User IE in ISDN Q.931 messages. <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. Received UUI is not sent in ISDN message.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled. The device interworks UUI from SIP to ISDN messages. The device supports the following SIP-to-ISDN interworking of UUI:               <ul style="list-style-type: none"> <li>✓ SIP INVITE to Q.931 Setup</li> <li>✓ SIP REFER to Q.931 Setup</li> <li>✓ SIP 200 OK to Q.931 Connect</li> <li>✓ SIP INFO to Q.931 User Information</li> <li>✓ SIP 18x to Q.931 Alerting</li> <li>✓ SIP BYE to Q.931 Disconnect</li> </ul> </li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The interworking of ISDN User-to-User IE to SIP INFO is applicable only to the Euro ISDN, QSIG, and 4ESS ISDN variants.</li> <li>■ To interwork the UUIE header from SIP-to-ISDN messages with the 4ESS ISDN variant, the [ISDNGeneralCCBehavior] parameter must be set to 16384.</li> </ul>
[Enable911LocationIdIP2Te]	Enables interworking of Emergency Location Identification

Parameter	Description						
l]	<p>from SIP to PRI.</p> <ul style="list-style-type: none"> <li>■ [0] = Disabled (default)</li> <li>■ [1] = Enabled</li> </ul> <p>When enabled, the From header received in the SIP INVITE is translated into the following ISDN IE's:</p> <ul style="list-style-type: none"> <li>■ Emergency Call Control.</li> <li>■ Generic Information - to carry the Location Identification Number information.</li> <li>■ Generic Information - to carry the Calling Geodetic Location information.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the NI-2 ISDN variant.</p>						
<pre>configure voip &gt; gateway digital settings &gt; early- answer-timeout</pre> <p>[EarlyAnswerTimeout]</p>	<p>Global parameter that defines the duration (in seconds) that the device waits for an ISDN Connect message from the called party (Tel side), started from when it sends a Setup message. You can also configure this feature per specific calls, using IP Profiles ('Early Answer Timeout' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b> If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</p>						
<p>'Trunk Transfer Mode'</p> <pre>configure voip &gt; interface e1-t1 &gt; trk-xfer-mode-type</pre> <p>[TrunkTransferMode]</p>	<p>Determines the trunk transfer method (for all trunks) when a SIP REFER message is received. The transfer method depends on the Trunk's PSTN protocol (configured by the parameter ProtocolType) and is applicable only when one of these protocols are used:</p> <table border="1"> <thead> <tr> <th>PSTN Protocol</th><th>Transfer Method (Described Below)</th></tr> </thead> <tbody> <tr> <td>E1 Euro ISDN [1]</td><td>ECT [2] or InBand [5]</td></tr> <tr> <td>E1 QSIG [21], T1 QSIG [23]</td><td>Single Step Transfer [4], Path Replacement Transfer [2], or InBand [5]</td></tr> </tbody> </table>	PSTN Protocol	Transfer Method (Described Below)	E1 Euro ISDN [1]	ECT [2] or InBand [5]	E1 QSIG [21], T1 QSIG [23]	Single Step Transfer [4], Path Replacement Transfer [2], or InBand [5]
PSTN Protocol	Transfer Method (Described Below)						
E1 Euro ISDN [1]	ECT [2] or InBand [5]						
E1 QSIG [21], T1 QSIG [23]	Single Step Transfer [4], Path Replacement Transfer [2], or InBand [5]						

Parameter	Description								
	<table> <tr> <td>T1 NI2 ISDN [10], T1 4ESS ISDN [11], T1 5ESS 9 ISDN [12]</td><td>TBCT [2] or InBand [5]</td></tr> <tr> <td>T1 DMS-100 ISDN [14]</td><td>RTL [2] or InBand [5]</td></tr> <tr> <td>T1 RAW CAS [3], T1 CAS [2], E1 CAS [8], E1 RAW CAS [9]</td><td>[1] CAS NFA DMS-100 or [3] CAS Normal transfer</td></tr> <tr> <td>T1 DMS-100 Meridian ISDN [35]</td><td>RTL [2] or InBand [5]</td></tr> </table> <p>The valid values of the parameter are described below:</p> <ul style="list-style-type: none"> <li>■ [0] = Not supported (default).</li> <li>■ [1] = Supports CAS NFA DMS-100 transfer. When a SIP REFER message is received, the device performs a Blind Transfer by executing a CAS Wink, waits for an acknowledged Wink from the remote side, dials the Refer-to number to the switch, and then releases the call. <b>Note:</b> A specific NFA CAS table is required.</li> <li>■ [2] = Supports ISDN PRI transfer - Release Link Trunk (RLT) (DMS-100), Two B Channel Transfer (TBCT) (NI2), Explicit Call Transfer (ECT) (EURO ISDN), and Path Replacement (QSIG). When a SIP REFER message is received, the device performs a transfer by sending Facility messages to the PBX with the necessary information on the call's legs to be connected. The different ISDN variants use slightly different methods (using Facility messages) to perform the transfer. <b>Note:</b> <ul style="list-style-type: none"> <li>✓ For RLT ISDN transfer, the parameter <code>SendISDNTransferOnConnect</code> must be set to 1.</li> <li>✓ The parameter <code>SendISDNTransferOnConnect</code> can be used to define if the TBCT/ECT transfer is performed after receipt of Alerting or Connect messages. For RLT, the transfer is always done after receipt of Connect (<code>SendISDNTransferOnConnect</code> is set to 1).</li> <li>✓ This transfer can be performed between B-channels</li> </ul> </li> </ul>	T1 NI2 ISDN [10], T1 4ESS ISDN [11], T1 5ESS 9 ISDN [12]	TBCT [2] or InBand [5]	T1 DMS-100 ISDN [14]	RTL [2] or InBand [5]	T1 RAW CAS [3], T1 CAS [2], E1 CAS [8], E1 RAW CAS [9]	[1] CAS NFA DMS-100 or [3] CAS Normal transfer	T1 DMS-100 Meridian ISDN [35]	RTL [2] or InBand [5]
T1 NI2 ISDN [10], T1 4ESS ISDN [11], T1 5ESS 9 ISDN [12]	TBCT [2] or InBand [5]								
T1 DMS-100 ISDN [14]	RTL [2] or InBand [5]								
T1 RAW CAS [3], T1 CAS [2], E1 CAS [8], E1 RAW CAS [9]	[1] CAS NFA DMS-100 or [3] CAS Normal transfer								
T1 DMS-100 Meridian ISDN [35]	RTL [2] or InBand [5]								

Parameter	Description
	<p>from different trunks or Trunk Groups, by using the parameter EnableTransferAcrossTrunkGroups.</p> <ul style="list-style-type: none"> <li>✓ The device initiates the ECT process after receiving a SIP REFER message only for trunks that are configured to User side.</li> <li>■ [3] = Supports CAS Normal transfer. When a SIP REFER message is received, the device performs a Blind Transfer by executing a CAS Wink, dialing the Refer-to number to the switch, and then releasing the call.</li> <li>■ [4] = Supports QSIG Single Step transfer PRI : <ul style="list-style-type: none"> <li>✓ IP-to-Tel: When a SIP REFER message is received, the device performs a transfer by sending a Facility message to the PBX, initiating Single Step transfer. Once a success return result is received, the transfer is completed.</li> <li>✓ Tel-to-IP: When a Facility message initiating Single Step transfer is received from the PBX, a SIP REFER message is sent to the IP side.</li> </ul> </li> <li>■ [5] = IP-to-Tel Blind Transfer mode supported for ISDN PRI protocols and implemented according to AT&amp;T Toll Free Transfer Connect Service (TR 50075) "Courtesy Transfer-Human-No Data". When the device receives a SIP REFER message, it performs a blind transfer by first dialing the DTMF digits (transfer prefix) defined by the parameter XferPrefixIP2Tel (configured to "*8" for AT&amp;T service), and then (after 500 msec) the device dials the DTMF of the number (referred) from the Refer-To header sip:URI userpart. If the hostpart of the Refer-To sip:URI contains the device's IP address, and if the Trunk Group selected according to the IP-to-Tel Routing table is the same Trunk Group as the original call, then the device performs the in-band DTMF transfer; otherwise, the device sends the INVITE according to regular transfer rules.</li> </ul> <p>After completing the in-band transfer, the device waits for the ISDN Disconnect message. If the Disconnect message is received during the first 5 seconds, the device sends a SIP NOTIFY with 200 OK message; otherwise, the device sends a NOTIFY with 4xx message.</p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [6] = Supports AT&amp;T toll free out-of-band blind transfer for trunks configured with the 4ESS ISDN protocol. AT&amp;T courtesy transfer is a supplementary service which enables a user (e.g., user "A") to transform an established call between it and user "B" into a new call between users "B" and "C", whereby user "A" doesn't have a call established with user "C" prior to call transfer. The device handles this feature as follows: <ul style="list-style-type: none"> <li>✓ IP-to-Tel (user side): When a SIP REFER message is received, the device initiates a transfer by sending a Facility message to the PBX.</li> <li>✓ Tel-to-IP (network side): When a Facility message initiating an out-of-band blind transfer is received from the PBX, the device sends a SIP REFER message to the IP side (if the EnableNetworkISDNTransfer parameter is set to 1).</li> </ul> </li> </ul> <p><b>Note:</b> To configure trunk transfer mode per trunk, use the parameter TrunkTransferMode_x.</p>
[TrunkTransferMode_x]	Determines the trunk transfer mode per trunk (where x denotes the Trunk number). To configure trunk transfer mode for all trunks and for a description of the parameter options, refer to the parameter TrunkTransferMode.
[EnableTransferAcrossTrunkGroups]	<p>Determines whether the device allows ISDN ECT, RLT or TBCT IP-to-Tel call transfers between B-channels of different Trunk Groups.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable - ISDN call transfer is only between B-channels of the same Trunk Group.</li> <li>■ [1] = Enable - the device performs ISDN transfer between any two PSTN calls (between any Trunk Group) handled by the device.</li> </ul> <p>Note: The ISDN transfer also requires that you configure the parameter TrunkTransferMode_x to 2.</p>
[TransferCapabilityForDataCalls]	<p>Defines the ISDN Transfer Capability for data calls.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) ISDN Transfer Capability for data calls is 64k unrestricted (data).</li> <li>■ [1] = ISDN Transfer Capability for data calls is determined according to the ISDNTransferCapability</li> </ul>

Parameter	Description
	parameter.
<p>'ISDN Transfer On Connect'</p> <pre>configure voip &gt; gateway digital settings &gt; isdn- trsfr-on-conn</pre> <p>[SendISDNTransferOnConnect]</p>	<p>The parameter is used for the ECT/TBCT/RLT/Path Replacement ISDN transfer methods. Usually, the device requests the PBX to connect an incoming and outgoing call. The parameter determines if the outgoing call (from the device to the PBX) must be connected before the transfer is initiated.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Alert</b> = (Default) Enables ISDN Transfer if the outgoing call is in Alerting or Connect state.</li> <li>■ [1] <b>Connect</b> = Enables ISDN Transfer only if the outgoing call is in Connect state.</li> </ul> <p><b>Note:</b> For RLT ISDN transfer (TrunkTransferMode = 2 and ProtocolType = 14 DMS-100), the parameter must be set to 1.</p>
<pre>configure voip &gt; gateway dtmf-supp- service supp- service-settings &gt; isdn-xfer- complete-timeout</pre> <p>[ISDNTransferCompleteTimeout]</p>	<p>Defines the timeout (in seconds) for determining ISDN call transfer (ECT, RLT, or TBCT) failure. If the device doesn't receive any response to an ISDN transfer attempt within this user-defined time, the device identifies this as an ISDN transfer failure and subsequently performs a hairpin TDM connection or sends a SIP NOTIFY message with a SIP 603 response (depending whether hairpin is enabled or disabled, using the parameter DisableFallbackTransferToTDM). The valid range is 1 to 10. The default is 4.</p>
<p>'Network ISDN Transfer'</p> <pre>configure voip &gt; sip-definition settings &gt; network-isdn-xfer</pre> <p>[EnableNetworkISDNTransfer]</p>	<p>Determines whether the device allows interworking of network-side received ECT/TBCT Facility messages (NI-2 TBCT - Two B-channel Transfer and ETSI ECT - Explicit Call Transfer) to SIP REFER.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = Disabled. Rejects ISDN transfer requests.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = (Default) Enabled. The device sends a SIP REFER message to the remote call party if ECT/TBCT Facility messages are received from the ISDN side (e.g., from a PBX).</li> </ul>
[DisableFallbackTransferToTDM]	<p>Enables "hairpin" TDM transfer upon ISDN (ECT, RLT, or TBCT) call transfer failure. When this feature is enabled and an ISDN call transfer failure occurs, the device sends a SIP NOTIFY message with a SIP 603 Decline response.</p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [0] = (Default) The device performs a hairpin TDM transfer upon ISDN call transfer.</li> <li>■ [1] = Hairpin TDM transfer is disabled.</li> </ul>
<pre>configure voip &gt; gateway digital settings &gt; isdn- ignore-18x- without-sdp</pre> <p>[ISDNIgnore18xWithoutSDP]</p>	<p>Enables interworking SIP 18x without SDP and ISDN Q.931 Progress/Alerting messages.</p> <ul style="list-style-type: none"> <li>■ [0] = Disable. Incoming SIP 18x messages without SDP are replied by the device by PRACK (if required), but the device doesn't interwork these SIP messages with Q.931 Progress or Alerting messages (i.e., doesn't send to PSTN).</li> <li>■ [1] = (Default) Enable. The device interworks 18x SIP messages with Q.931 Progress and Alerting messages (if required) and sends them to the PSTN.</li> </ul>
<pre>configure voip &gt; gateway digital settings &gt; isdn- send-progress-for- te</pre> <p>[ISDNSendProgressForTE]</p>	<p>Defines whether the device sends Q.931 Progress messages to the ISDN trunk if the trunk is configured as User side (TE) and/or Network (NT) side, for IP-to-Tel calls.</p> <ul style="list-style-type: none"> <li>■ [0] = Disable. The device sends Progress messages to the trunk only if the trunk is configured as NT.</li> <li>■ [1] = (Default) Enable. The device sends Q.931 Progress messages to the trunk if the trunk is configured as TE or NT.</li> </ul> <p><b>Note:</b> To configure the trunk's ISDN termination side (TE or NT), use the 'ISDN Termination Side' parameter.</p>
<p>'Enable QSIG Transfer Update'</p> <pre>configure voip &gt; gateway digital settings &gt; qsig- xfer-update</pre> <p>[EnableQSIGTransferUpdate]</p>	<p>Determines whether the device interworks QSIG Facility messages with CallTransferComplete or CallTransferUpdate invoke application protocol data units (APDU) to SIP UPDATE messages with P-Asserted-Identity and optional Privacy headers. This feature is supported for IP-to-Tel and Tel-to-IP calls.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) Ignores QSIG Facility messages with CallTransferComplete or CallTransferUpdate invokes.</li> <li>■ [1] <b>Enable</b></li> </ul> <p>For example, assume A and C are PBX call parties and B is the SIP IP phone:</p> <ol style="list-style-type: none"> <li>1. A calls B; B answers the call.</li> </ol>



Parameter	Description
	<p>2. A places B on hold and calls C; C answers the call.</p> <p>3. A performs a call transfer (the transfer is done internally by the PBX); B and C are connected to one another.</p> <p>In the above example, the PBX updates B that it is now talking with C. The PBX updates this by sending a QSIG Facility message with CallTransferComplete invoke APDU. The device interworks this message to a SIP UPDATE message containing a P-Asserted-Identity header with the number and name derived from the QSIG CallTransferComplete RedirectionNumber and RedirectionName.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For IP-to-Tel calls, the RedirectionNumber and RedirectionName in the CallTransferComplete invoke is derived from the P-Asserted-Identity and Privacy headers in the received SIP INFO message.</li> <li>■ To include the P-Asserted-Identity header in outgoing SIP UPDATE messages, set the AssertedIDMode parameter to <b>Add P-Asserted-Identity</b>.</li> </ul>
<pre>configure voip &gt; gateway digital settings &gt; isdn- ntt-noid- interworking-mode [ISDNnttNoidInterworking Mode]</pre>	<p>Defines SIP-ISDN interworking between NTT Japan's No-ID cause in the Facility information element (IE) of the ISDN Setup message, and the calling party number (display name) in the From header of the SIP INVITE message. The No ID cause in the Facility IE indicates one of four reasons (see list of mapping below), for example, why the call was blocked.</p> <ul style="list-style-type: none"> <li>■ [0] =(Default) No interworking of No-ID cause.</li> <li>■ [1] = Interwork No-ID cause only from IP to Tel.</li> <li>■ [2] = Interwork No-ID cause only from Tel to IP.</li> <li>■ [3] = Interwork No-ID cause from IP-to-Tel side and Tel-to-IP side.</li> </ul> <p>The following lists the mapping between the SIP display name in the From header and the cause of the Facility IE in the ISDN Setup message (SIP:ISDN):</p> <ul style="list-style-type: none"> <li>■ Unavailable: IE[03]=1c 11 91 a1 0e 02 01 00 06 06 02 83 38 66 01 01 0a 01 00</li> <li>■ Anonymous: IE[03]=1c 11 91 a1 0e 02 01 00 06 06 02 83 38 66 01 01 0a 01 01</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ Interaction with other service: IE[03]=1c 11 91 a1 0e 02 01 00 06 06 02 83 38 66 01 01 0a 01 02</li> <li>■ Coin line/payphone: IE[03]=1c 11 91 a1 0e 02 01 00 06 06 02 83 38 66 01 01 0a 01 03</li> </ul> <p>Below shows an example of an ISDN No-ID cause mapped to SIP for "Interaction with other service":</p> <div style="background-color: #f0f0f0; padding: 10px; border: 1px solid #ccc;"> <p>From: "Interaction with other service" &lt;sip:anonymous@anonymous.invalid;pstn-params=9082828088&gt;;tag=gK09696ce6</p> </div> <p><b>Note:</b> The parameter is applicable only to Trunks configured with the JAPAN NTT ISDN PRI (T1) protocol variant (i.e., [ProtocolType] parameter configured to 16).</p>
is-cas-sndhook-flsh [CASSendHookFlash]	<p>Enables sending Wink signal toward CAS trunks.</p> <ul style="list-style-type: none"> <li>■ [0] = Disable (default)</li> <li>■ [1] = Enable</li> </ul> <p>If the device receives a mid-call SIP INFO message with flashhook event body (as shown below) and the parameter is set to 1, the device generates a wink signal toward the CAS trunk. The CAS wink signal is done by changing the A bit from 1 to 0, and then back to 1 for 450 msec.</p> <pre>INFO sip:4505656002@192.168.13.40:5060 SIP/2.0 Via: SIP/2.0/UDP 192.168.13.2:5060 From: &lt;sip:06@192.168.13.2:5060&gt; To: &lt;sip:4505656002@192.168.13.40:5060&gt;;tag= 132878796-1040067870294 Call-ID: 0010-0016-D69A7DA8- 1@192.168.13.2 CSeq:2 INFO Content-Type: application/broadsoft Content-Length: 17 event flashhook</pre> <p><b>Note:</b> The parameter is applicable only to T1 CAS protocols.</p>
configure voip > gateway digital settings > cug-	<p>Enables interworking between the ISDN Closed User Group (CUG) supplementary service and SIP, for Tel-to-IP calls. The CUG supplementary service enables users to form groups,</p>

Parameter	Description
data-mode [CugDataMode]	<p>where members of a specific closed user group can communicate among themselves but not, in general, with users outside the group. If the parameter is enabled and the device receives an ISDN Setup message whose Facility IE indicates CUG (cUGCall invoke), it adds an XML body containing CUG information (CUG index and outgoing access) to the outgoing SIP INVITE message.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable. The device doesn't add the XML body containing CUG information to the outgoing SIP INVITE message.</li> <li>■ [1] = Enable. The device adds the XML body containing CUG information to the outgoing SIP INVITE message.</li> </ul> <p>The following shows an example of an added XML body containing CUG information:</p> <pre>&lt;?xml version="1.0" encoding="utf-8"?&gt; &lt;xs:schema xmlns:xs="http://www.w3.org/2001/XMLSchema" xmlns="http://uri.etsi.org/ngn/params/xml/simservs/xcap" targetNamespace="http://uri.etsi.org/ngn/params/xml/simservs/xcap" elementFormDefault="qualified" attributeFormDefault="unqualified"&gt; &lt;xs:annotation&gt; &lt;xs:documentation&gt;XML Schema Definition for the closed user group parameter&lt;/xs:documentation&gt; &lt;/xs:annotation&gt; &lt;xs:include schemaLocation="xcap.xsd"/&gt; &lt;!--Definition of simple types--&gt; &lt;xs:simpleType name="twobitType"&gt; &lt;xs:restriction base="xs:string"&gt; &lt;xs:pattern value="[0-1][0-1]"/&gt; &lt;/xs:restriction&gt; &lt;/xs:simpleType&gt; &lt;xs:simpleType name="networkIdentityType"&gt; &lt;xs:restriction base="xs:hexBinary"&gt;</pre>

Parameter	Description
	<pre> &lt;xs:length value="2"/&gt; &lt;/xs:restriction&gt; &lt;/xs:simpleType&gt; &lt;xs:simpleType name="sixteenbitType"&gt; &lt;xs:restriction base="xs:hexBinary"&gt; &lt;xs:length value="2"/&gt; &lt;/xs:restriction&gt; &lt;/xs:simpleType&gt; &lt;xs:simpleType name="cugIndexType"&gt; &lt;xs:restriction base="xs:integer"&gt; &lt;xs:minInclusive value="0"/&gt; &lt;xs:maxInclusive value="32767"/&gt; &lt;/xs:restriction&gt; &lt;/xs:simpleType&gt; &lt;!--Definition of complex types--&gt; &lt;xs:complexType name="cugRequestType"&gt; &lt;xs:sequence&gt; &lt;xs:element name="outgoingAccessRequest" type="xs:boolean"/&gt; &lt;xs:element name="cugIndex" type="cugIndexType" minOccurs="0"/&gt; &lt;/xs:sequence&gt; &lt;/xs:complexType&gt; &lt;!--Definition of document structure--&gt; &lt;xs:element name="cug" substitutionGroup="ss:absService"&gt; &lt;xs:complexType&gt; &lt;xs:complexContent&gt; &lt;xs:extension base="ss:simservType"&gt; &lt;xs:sequence&gt; &lt;xs:element name="cugCallOperation" type="cugRequestType" minOccurs="0"&gt; &lt;xs:complexType&gt; &lt;xs:sequence&gt; &lt;xs:element name="outgoingAccessRequest" type="xs:boolean" value="True"/&gt; &lt;xs:element name="cugIndex" type="xs:integer" value="32767"/&gt; &lt;/xs:sequence&gt; &lt;/xs:complexType&gt; &lt;/xs:element&gt; </pre>

Parameter	Description
	<pre> &lt;xs:element name="networkIndicator" type="networkIdentityType" minOccurs="0"/&gt; &lt;xs:element name="cugInterlockBinaryCode" type="sixteenbitType" minOccurs="0"/&gt; &lt;xs:element name="cugCommunicationIndicator" type="twobitType" minOccurs="0"/&gt; &lt;/xs:sequence&gt; &lt;/xs:extension&gt; &lt;/xs:complexContent&gt; &lt;/xs:complexType&gt; &lt;/xs:element&gt; &lt;/xs:schema&gt; </pre>

## Tone Parameters

This subsection describes the device's tone parameters.

### Telephony Tone Parameters

The telephony tone parameters are described in the table below.

**Table 69-55:Tone Parameters**

Parameter	Description
<b>'Dial Tone Duration'</b> <code>configure voip &gt; gateway</code> <code>dtmf-supp-service dtmf-</code> <code>and-dialing &gt; dt-duration</code> <code>[TimeForDialTone]</code>	<p>Defines the duration (in seconds) that the dial tone is played.</p> <p>The device plays the tone to an ISDN terminal. The parameter is applicable for overlap dialing if you configure the <code>[ISDNInCallsBehavior]</code> parameter to 65536. The dial tone is played if the ISDN Setup message doesn't include the called number. The valid range is 0 to 60. The default is 5.</p> <p><b>Note:</b></p>
<b>'Reorder Tone Duration'</b> <code>configure voip &gt; gateway</code> <code>analog fxo-setting &gt;</code> <code>reorder-tone-duration</code> <code>[TimeForReorderTone]</code>	<p>Defines the duration (in seconds) that the device plays a busy or reorder tone before releasing the line.</p> <p>You can also configure this feature per specific calls, using Tel Profiles ('Time For Reorder Tone' parameter). For a detailed description of the</p>

Parameter	Description
	<p>parameter and for configuring the feature in the Tel Profiles table, see <a href="#">Configuring Tel Profile</a> on page 738.</p> <p><b>Note:</b> If the feature is configured for a specific Tel Profile, the device ignores this global parameter for calls associated with the Tel Profile.</p>
<p>'Cut Through Reorder Tone Duration'</p> <pre>configure voip &gt; gateway digital settings &gt; cut- thru-reord-dur</pre> <p>[CutThroughTimeForReOrderTone]</p>	<p>Defines the duration (in seconds) of the reorder tone played to the Tel side after the IP call party releases the call, for the Cut-Through feature. After the tone stops playing, an incoming call is immediately answered if:</p> <ul style="list-style-type: none"> <li>■ The PSTN is connected.</li> </ul> <p>The valid values are 0 to 30. The default is 0 (i.e., no reorder tone is played).</p> <p><b>Note:</b> To enable the Cut-Through feature:</p> <ul style="list-style-type: none"> <li>■ CAS channels: DigitalCutThrough parameter</li> </ul>
<p>'Play Busy Tone to Tel'</p> <pre>configure voip &gt; sip- definition settings &gt; play-busy-tone-2tel</pre> <p>[PlayBusyTone2ISDN]</p>	<p>Enables the device to play a busy or reorder tone to the PSTN after a Tel-to-IP call is released.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Don't Play</b> = (Default) Immediately sends an ISDN Disconnect message.</li> <li>■ [1] <b>Play when Disconnecting</b> = Sends an ISDN Disconnect message with PI = 8 and plays a busy or reorder tone to the PSTN (depending on the release cause).</li> <li>■ [2] <b>Play before Disconnect</b> = Delays the sending of an ISDN Disconnect message for a user-defined time (configured by the TimeForReorderTone parameter) and plays a busy or reorder tone to the PSTN. This is applicable only if the call is released from the IP [Busy Here (486) or Not Found (404)] before it reaches the Connect state; otherwise, the Disconnect message is sent immediately and no tones are played.</li> </ul>
<pre>configure voip &gt; gateway digital settings &gt; q850- reason-code-2play-user-</pre>	<p>Defines an ISDN Q.8931 release cause code(s), which if mapped to the SIP release reason received from the IP side, causes the device to</p>

Parameter	Description
<p>tone</p> <p>[Q850ReasonCode2PlayUserTone]</p>	<p>play a user-defined tone from the installed PRT file to the Tel side. For example, if the received SIP release cause is 480 Temporarily Unavailable and you configure the parameter with Q.931 release code 18 (No User Responding), the device plays the user-defined tone to the Tel side.</p> <p>The user-defined tone is configured when creating the PRT file, using AudioCodes DConvert utility. The tone must be assigned to the "acSpecialConditionTone" (Tone Type 21) option in DConvert.</p> <p>The parameter can be configured with up to 10 release codes. When configuring multiple codes, separate the codes by commas (without spaces). For example:</p> <pre>Q850ReasonCode2PlayUserTone = 1,18,24</pre> <p>If the SIP release reason received from the IP side is mapped to the Q.931 release code specified by the parameter, the device plays the user-defined tone. Otherwise, if not specified and the release code is 17 (User Busy), the device plays the busy tone and for all other release codes, the device plays the reorder tone.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ To enable the feature, the 'Play Busy Tone to Tel' (PlayBusyTone2ISDN) parameter must be enabled (set to 1 or 2).</li> </ul>
<p>'Play Ringback Tone to Tel'</p> <pre>configure voip &gt; sip- definition settings &gt; play-rbt2tel</pre> <p>[PlayRBTone2Tel]</p>	<p>Defines the playing method of the ringback tone to the Tel side.</p> <p>Digital interfaces: The parameter applies to all trunks that are not configured by the [PlayRBTone2Trunk] parameter, which defines ringback tone per Trunk.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Don't Play</b> = <ul style="list-style-type: none"> <li>✓ The device doesn't play a ringback tone. No Progress Indicator (PI) is sent to the ISDN, unless the [ProgressIndicator2ISDN_x] parameter is configured differently.</li> </ul> </li> </ul>

Parameter	Description
	<p>■ [1] <b>Play on Local</b> =</p> <p>✓ Digital interfaces:</p> <ul style="list-style-type: none"> <li>• CAS: The device plays a local ringback tone to the PSTN upon receipt of a SIP 180 Ringing response (with or without SDP). Note that the receipt of a 183 response doesn't cause the device to play a ringback tone, unless the [SIP183Behaviour] parameter is configured to 1.</li> <li>• ISDN: The device behaves according to the [LocalISDNRBSrc] parameter:             <ol style="list-style-type: none"> <li>1) If the device receives a SIP 180 Ringing response (with or without SDP) and the [LocalISDNRBSrc] parameter is configured to 1, it plays a ringback tone and sends an ISDN Alert with PI = 8, unless the [ProgressIndicator2ISDN_x] parameter is configured differently.</li> <li>2) If the [LocalISDNRBSrc] parameter is configured to 0, the device doesn't play a ringback tone and an Alert message without PI is sent to the ISDN. In this case, the PBX / PSTN plays the ringback tone to the originating terminal. Note that the receipt of a 183 response doesn't cause the device to play a ringback tone; the device sends a Progress message, unless [SIP183Behaviour] is configured to 1. If the [SIP183Behaviour] parameter is configured to 1, the 183 response is handled the same way as a 180 Ringing response.</li> </ol> </li> </ul> <p>■ [2] <b>Prefer IP</b> = (Default):</p> <p>✓ The device plays a ringback tone according to 'Early Media'. If a SIP 180 response is received and the voice channel</p>



Parameter	Description
	<p>is already open (due to a previous 183 early media response or due to an SDP in the current 180 response), the device configured for ISDN or CAS doesn't play the ringback tone; PI = 8 is sent in an ISDN Alert message, unless the [ProgressIndicator2ISDN_x] parameter is configured differently.</p> <p>When there are multiple 18x responses, if a 18x response without SDP is received after the remote media is played (due to a previously received 18x with SDP), the device plays the local media instead of the remote, until a new 18x with SDP is received.</p> <ul style="list-style-type: none"> <li>• CAS: If a 180 response is received, but the 'early media' voice channel is not opened, the device plays a ringback tone to the PSTN.</li> <li>• ISDN: If a 180 response is received, but the 'early media' voice channel is not opened, the device configured for ISDN operates according to the [LocalISDNRBSource] parameter:             <ol style="list-style-type: none"> <li>1) [LocalISDNRBSource] configured to 1: The device plays a ringback tone and sends an ISDN Alert with PI = 8 to the ISDN (unless the [ProgressIndicator2ISDN_x] parameter is configured differently).</li> <li>2) [LocalISDNRBSource] configured to 0: The device doesn't play a ringback tone. No PI is sent in the ISDN Alert message, unless the [ProgressIndicator2ISDN_x] parameter is configured differently. In this case, the PBX / PSTN plays a ringback tone to the originating terminal. Note that the receipt of a 183 response results in an ISDN Progress message, unless [SIP183Behaviour] is configured to 1.</li> </ol> </li> </ul>

Parameter	Description
	<p>If [SIP183Behaviour] is configured to 1 (183 is handled the same way as a 180 with SDP), the device sends an Alert message with PI = 8 without playing a ringback tone..</p> <p>■ [3] <b>Play Local Until Remote Media Arrive</b> = The device plays a ringback tone according to the received media. The behavior is similar to option [2]. If a SIP 180 response is received and the voice channel is already open (due to a previous 183 early media response or due to an SDP in the current 180 response), the device plays a local ringback tone if there are no prior received RTP packets. The device stops playing the local ringback tone as soon as it starts receiving RTP packets. At this stage, if the device receives additional 18x responses, it doesn't resume playing the local ringback tone.</p> <p><b>Note:</b> For ISDN trunks, this option is applicable only if the [LocalISDNRBSrc] parameter is configured to 1.</p>
<p>'Play Ringback Tone to IP' configure voip &gt; sip- definition settings &gt; play-rbt-2ip [PlayRBTone2IP]</p>	<p>Global parameter that enables the device to play a ringback tone to the IP side for IP-to-Tel calls. You can also configure this feature per specific calls, using IP Profiles ('Play RB Tone to IP' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b> If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</p>
<p>'Play Local RBT on ISDN Transfer' configure voip &gt; gateway digital settings &gt; play- l-rbt-isdn-trsfr [PlayRBTOnISDNTransfer]</p>	<p>Determines whether the device plays a local ringback tone for ISDN's Two B Channel Transfer (TBCT), Release Line Trunk (RLT), or Explicit Call Transfer (ECT) call transfers to the originator when the second leg receives an ISDN Alerting or Progress message.</p> <p>■ [0] <b>Don't Play</b> (default)</p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [1] Play</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For Blind transfer, the local ringback tone is played to first call PSTN party when the second leg receives the ISDN Alerting or Progress message.</li> <li>■ For Consulted transfer, the local ringback tone is played when the second leg receives ISDN Alerting or Progress message if the Progress message is received after a SIP REFER.</li> <li>■ The parameter is applicable only if the parameter SendISDNTransferOnConnect is set to 1.</li> </ul>
<p>'MFC R2 Category'</p> <pre>configure voip &gt; gateway digital settings &gt; mfcr2- category</pre> <p>[R2Category]</p>	<p>Defines the tone for MFC R2 calling party category (CPC). The parameter provides information on the calling party such as National or International call, Operator or Subscriber and Subscriber priority. The value range is 1 to 15 (defining one of the MFC R2 tones). The default is 1.</p>

## Tone Detection Parameters

The signal tone detection parameters are described in the table below.

**Table 69-56:Tone Detection Parameters**

Parameter	Description
<pre>dtmf-detector-enable</pre> <p>[DTMFDetectorEnable]</p>	<p>Enables the detection of DTMF signaling.</p> <ul style="list-style-type: none"> <li>■ [0] = Disable</li> <li>■ [1] = (Default) Enable</li> </ul>
<pre>mfr1-detector-enable</pre> <p>[MFR1DetectorEnable]</p>	<p>Enables the detection of MF-R1 signaling.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable</li> <li>■ [1] = Enable</li> </ul>
<pre>mf-transport-type</pre> <p>[MFTransportType]</p>	<p>Defines the method for sending MF digits over the network to the remote side.</p> <ul style="list-style-type: none"> <li>■ [0] = (Mute) MF digits are erased from the</li> </ul>

Parameter	Description
	<p>audio stream and are not relayed to the remote side. Instead, silence is sent in the RTP stream.</p> <ul style="list-style-type: none"> <li>■ [2] = (Transparent) MF digits are left in the audio stream and MF relay is disabled.</li> <li>■ [3] = (Default) (RFC 2833 Relay) MF digits are relayed to the remote side using the RFC 2833 Relay syntax.</li> </ul>
[R1DetectionStandard]	<p>Determines the MF-R1 protocol used for detection.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) ITU</li> <li>■ [1] = R1.5</li> </ul> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
user-defined-tones-detector-enable [UserDefinedToneDetectorEnable]	<p>Enables the detection of User Defined Tones signaling, applicable for Special Information Tone (SIT) detection.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable</li> <li>■ [1] = Enable</li> </ul>
sit-detector-enable [SITDetectorEnable]	<p>Enables SIT detection according to the ITU-T recommendation E.180/Q.35.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable</li> <li>■ [1] = Enable</li> </ul> <p>To disconnect IP-to-ISDN calls when a SIT tone is detected, configure the following parameters:</p> <ul style="list-style-type: none"> <li>■ [SITDetectorEnable = 1]</li> <li>■ [UserDefinedToneDetectorEnable = 1]</li> <li>■ [ISDNDisconnectOnBusyTone = 1] (applicable for Busy, Reorder and SIT tones)</li> </ul> <p>Another parameter for handling the SIT tone is [SITQ850Cause], which defines the Q.850 cause value specified in the SIP Reason header that is included in a 4xx response when a SIT tone is detected on an IP-to-Tel call.</p>

Parameter	Description
	<p>To disconnect IP-to-Tel calls when a SIT tone is detected, configure the following parameters:</p> <ul style="list-style-type: none"> <li>■ [SITDetectorEnable = 1]</li> <li>■ [UserDefinedToneDetectorEnable = 1]</li> <li>■ [DisconnectOnBusyTone = 1] (applicable for busy, reorder, and SIT tones)</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ The IP-to-ISDN call is disconnected on detection of a SIT tone only in call alert state. If the call is in connected state, the SIT doesn't disconnect the call. Detection of busy or reorder tones disconnect these calls also in call connected state.</li> <li>■ For IP-to-CAS calls, detection of busy, reorder, or SIT tones disconnect the call in any call state.</li> </ul>
udt-detector-frequency-deviation [UDTDetectorFrequencyDeviation]	<p>Defines the deviation (in Hz) allowed for the detection of each signal frequency.</p> <p>The valid range is 1 to 50. The default is 50.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
cpt-detector-frequency-deviation [CPTDetectorFrequencyDeviation]	<p>Defines the deviation (in Hz) allowed for the detection of each CPT signal frequency.</p> <p>The valid range is 1 to 30. The default is 10.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>

## Metering Tone Parameters

The metering tone parameters are described in the table below.

**Table 69-57: Metering Tone Parameters**

Parameter	Description
'Generate Metering Tones'	Defines the method for configuring metering tones

Parameter	Description
<pre>configure voip &gt; gateway analog metering-tones &gt; gen-mtr-tones [PayPhoneMeteringMode]</pre>	<p>that are generated to the Tel side.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) Metering tones are not generated.</li> <li>■ [1] <b>Charge Code Table</b> = Metering tones are generated by the device according to the Charge Code table (see <a href="#">Configuring Charge Codes</a> on page 1010) and sent to the Tel side.</li> <li>■ [2] <b>SIP Interval Provided</b> = (Proprietary method of TELES Communications Corporation) Advice-of-Charge service toward the PSTN. Periodic generation of AOC-D and AOC-E toward the PSTN. Calculation is based on seconds. The time interval is calculated according to the scale and tariff provided in the proprietary formatted file included in SIP INFO messages, which is always sent before 200 OK. The device ignores tariffs sent after the call is established.</li> <li>■ [3] <b>SIP RAW Data Provided</b> = (Proprietary method of Cirpack) Advice-of-Charge service toward the PSTN. The received AOC-D messages contain a subtotal. When receiving AOC-D in raw format, provided in the header of SIP INFO messages, the device parses AOC-D raw data to obtain the number of units. This number is sent in the Facility message with AOC-D. In addition, the device stores the latest number of units in order to send them in AOC-E IE when the call is disconnected.</li> <li>■ [4] <b>SIP RAW Data Incremental Provided</b> = (Proprietary method of Cirpack) Advice-of-Charge service toward the PSTN. The AOC-D message in the payload is an increment. When receiving AOC-D in raw format, provided in the header of SIP INFO messages, the device parses AOC-D raw data to obtain the number of units. This number is sent in the Facility message with AOC-D. The device generates the AOC-E. Parsing every AOC-D received and summing the values is required to obtain the total sum (that is placed in the AOC-E).</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [5] <b>SIP-to-Tel Interworking</b> = Enables IP-to-Tel AOC, using the AudioCodes proprietary SIP header, AOC.</li> </ul> <p><b>Note:</b> The parameter is applicable only to ISDN Euro trunks for sending AOC Facility messages (see <a href="#">Advice of Charge Services for Euro ISDN</a> on page 1007).</p>
[ISDNAoCAmountPerInterval]	<p>Defines the amount (units) charged per interval. The default is 1.</p> <p><b>Note:</b> The parameter is applicable only to the Euro ISDN protocol (Advice of Charge supplementary services).</p>
[ISDNAoCMinIntervalGeneration]	<p>Defines the interval for sending the AOC messages. The default is 0 (meaning that the interval is according to the Charge Codes table).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Euro ISDN protocol (Advice of Charge supplementary services).</li> <li>■ The parameter doesn't affect the interval charge amount.</li> <li>■ The parameter is ignored if its' value is less than the interval configured in the Charge Codes table ('Interval' parameter).</li> </ul>

## Trunk Group and Routing Parameters

The routing parameters are described in the table below.

**Table 69-58:Routing Parameters**

Parameter	Description
'Channel Select Mode' ch-select-mode [ChannelSelectMode]	<p>Defines the method for allocating incoming IP-to-Tel calls to a channel. The parameter applies to the following:</p> <ul style="list-style-type: none"> <li>■ Trunks configured without a channel select mode in the Trunk Group Settings table (see <a href="#">Configuring Trunk Group Settings</a> on page 906).</li> <li>■ Channels and trunks configured without a Trunk Group</li> </ul>

Parameter	Description
	<p>ID.</p> <p>For all channels that are configured without a Trunk Group ID:</p> <ul style="list-style-type: none"> <li>■ [0] <b>By Dest Phone Number</b></li> <li>■ [1] <b>Cyclic Ascending</b> (default)</li> <li>■ [2] <b>Ascending</b></li> <li>■ [3] <b>Cyclic Descending</b></li> <li>■ [4] <b>Descending</b></li> <li>■ [5] <b>Dest Number + Cyclic Ascending</b></li> <li>■ [6] <b>By Source Phone Number</b></li> <li>■ [7] <b>Trunk Cyclic Ascending</b></li> <li>■ [8] <b>Trunk &amp; Channel Cyclic Ascending</b></li> <li>■ [11] <b>Dest Number + Ascending</b></li> </ul> <p>For a detailed description of the parameter's options, see <a href="#">Configuring Trunk Group Settings</a> on page 906.</p>
<p>'Default Destination Number'</p> <pre>configure voip &gt; gateway dtmf-supp- service dtmf-and- dialing &gt; dflt- dest-nb</pre> <p>[DefaultNumber]</p>	<p>For IP-to-Tel calls, the parameter defines the default destination (called) phone number if the received SIP message doesn't contain a called party number and a phone number ('Channels' parameter) is not configured in the Trunk Groups table (see <a href="#">Configuring Trunk Groups</a> on page 903). The final destination number is the value of this parameter plus the channel ID.</p> <p>For Tel-to-IP calls, the parameter defines the default source (calling) phone number if the received ISDN message doesn't contain a calling party number and a phone number ('Channels' parameter) is not configured in the Trunk Groups table.</p> <p>The parameter is used as a starting number for the channels of all the trunks.</p> <p>The default is 1000.</p> <p>For example, for a Tel-to-IP call, if you configure the parameter to "2000" and the 'Channels' parameter in the Trunks Groups table to "34", the source number is 2034.</p>
<p>'Source IP Address Input'</p> <pre>configure voip &gt;</pre>	<p>Defines which IP address the device uses to determine the source of incoming INVITE messages for IP-to-Tel routing.</p>



Parameter	Description
<pre>gateway routing settings &gt; src-ip- addr-input</pre> <p>[SourceIPAddressInput]</p>	<ul style="list-style-type: none"> <li>■ [-1] <b>Not Configure</b> = (Default) The parameter is automatically set to SIP Contact header (1).</li> <li>■ [0] <b>SIP Contact Header</b> = The IP address in the Contact header of the incoming INVITE message is used.</li> <li>■ [1] <b>Layer 3 Source IP</b> = The actual IP address (Layer 3) from where the SIP packet is received is used.</li> </ul>
<p>'Use Source Number As Display Name'</p> <pre>configure voip &gt; sip-definition settings &gt; src-nb- as-disp-name</pre> <p>[UseSourceNumberAsDisplayNumber]</p>	<p>Defines the use of the Tel Source Number and Display Name for Tel-to-IP calls.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) If a Tel Display Name is received, the Tel Source Number is used as the IP Source Number and the Tel Display Name is used as the IP Display Name. If no Display Name is received from the Tel side, the IP Display Name remains empty.</li> <li>■ [1] <b>Yes</b> = If a Tel Display Name is received, the Tel Source Number is used as the IP Source Number and the Tel Display Name is used as the IP Display Name. If no Display Name is received from the Tel side, the Tel Source Number is used as the IP Source Number and also as the IP Display Name.</li> <li>■ [2] <b>Overwrite</b> = The Tel Source Number is used as the IP Source Number and also as the IP Display Name (even if the received Tel Display Name is not empty).</li> <li>■ [3] <b>Original</b> = Similar to option [2], except that the operation is done before regular calling number manipulation.</li> </ul>
<p>'Use Display Name as Source Number'</p> <pre>configure voip &gt; sip-definition settings &gt; disp- name-as-src-nb</pre> <p>[UseDisplayNameAsSourceNumber]</p>	<p>Defines how the display name (caller ID) received from the IP side (in the SIP From header) effects the source number sent to the Tel side, for IP-to-Tel calls.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) If a display name is received from the IP side, the source number of the IP side is used as the Tel source number.</li> <li>■ [1] <b>Yes</b> = If a display name is received from the IP side, the display name of the IP side is used as the Tel source number and Presentation is set to Allowed (0). If no display name is received from the IP side, the source number of the IP side is used as the Tel source number and Presentation is set to Restricted (1). For example:</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>✓ If 'From: 100 &lt;sip:200@201.202.203.204&gt;' is received from the IP side, the outgoing source number (and display name) are set to "100" and Presentation is set to Allowed (0).</li> <li>✓ If 'From: &lt;sip:400@101.102.103.104&gt;' is received from the IP side, the outgoing source number is set to "400" and Presentation is set to Restricted (1).</li> <li>■ [2] <b>Preferred</b> = If a display name is received from the IP side, the display name of the IP side is used as the Tel source number. If no display name is received from the IP side, this setting doesn't affect the Tel source number.</li> </ul>
'ENUM Resolution' configure voip > sip-definition settings > enum- service-domain [EnumService]	Defines the ENUM service for translating telephone numbers to IP addresses or domain names (FQDN), for example, e164.arpa, e164.customer.net, or NRENum.net. The valid value is a string of up to 50 characters. The default is "e164.arpa".  <b>Note:</b> ENUM-based routing is configured in the Tel-to-IP Routing table using the "ENUM" string value as the destination address to denote the parameter's value.
'Use Routing Table for Host Names and Profiles' configure voip > sip-definition settings > rte-tbl- 4-host-names [AlwaysUseRouteTable]	Enables the device to use the Tel-to-IP Routing table for obtaining the URI host name and optionally, an IP Profile (per call) even if a SIP proxy server is used.  <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <b>Note:</b> <ul style="list-style-type: none"> <li>■ The parameter appears only if the 'Use Default Proxy' parameter is enabled.</li> <li>■ The domain name is used instead of a Proxy name or IP address in the INVITE SIP URI.</li> </ul>
'Tel-to-IP Routing Mode' configure voip > gateway routing settings > tel2ip-rte- mode [RouteModeTel2IP]	Determines whether to route Tel calls to an IP destination before or after manipulation of the destination number. This applies to Tel-to-IP routing rules configured in the Tel-to-IP Routing table.  <ul style="list-style-type: none"> <li>■ [0] <b>Route calls before manipulation</b> = Calls are routed before the number manipulation rules are applied (default).</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ <b>[1] Route calls after manipulation</b> = Calls are routed after the number manipulation rules are applied.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is not applicable if outbound proxy routing is used.</li> <li>■ For number manipulation, see <a href="#">Configuring Source-Destination Number Manipulation Rules</a> on page 950.</li> <li>■ To configure Tel-to-IP routing rules, see <a href="#">Configuring Tel-to-IP Routing Rules</a> on page 914.</li> </ul>
<p>'IP-to-Tel Routing Mode'</p> <pre>configure voip &gt; gateway routing settings &gt; ip2tel- rte-mode</pre> <p>[RouteModelP2Tel]</p>	<p>Determines whether to route IP calls to the Trunk Group before or after manipulation of the destination number (configured in <a href="#">Configuring Source-Destination Number Manipulation Rules</a> on page 950).</p> <ul style="list-style-type: none"> <li>■ <b>[0] Route calls before manipulation</b> = (Default) Calls are routed before the number manipulation rules are applied.</li> <li>■ <b>[1] Route calls after manipulation</b> = Calls are routed after the number manipulation rules are applied.</li> </ul>
<p>'IP Security'</p> <pre>configure voip &gt; sip-definition settings &gt; ip- security</pre> <p>[SecureCallsFromIP]</p>	<p>Defines the device's policy for accepting or blocking SIP calls (IP-to-Tel calls). This is useful in preventing unwanted SIP calls, SIP messages, and/or VoIP spam.</p> <ul style="list-style-type: none"> <li>■ <b>[0] Disable</b> = (Default) The device accepts all SIP calls.</li> <li>■ <b>[1] Secure Incoming calls</b> = The device accepts SIP calls only from IP addresses that are configured in the Tel-to-IP Routing table or Proxy Sets table, or IP addresses resolved by DNS servers from FQDN values configured in the Proxy Sets table. All other incoming calls are rejected.</li> <li>■ <b>[2] Secure All calls</b> = The device accepts SIP calls only from IP addresses (in dotted-decimal notation format) that are configured in the Tel-to-IP Routing table and rejects all other incoming calls. In addition, if an FQDN is configured in the Tel-to-IP Routing table or Proxy Sets table, the call is allowed to be sent only if the resolved DNS IP address appears in one of these tables; otherwise, the call is rejected. Therefore, the difference between this option and option [1] is that this option is</li> </ul>

Parameter	Description
	<p>concerned only about numerical IP addresses that are defined in the tables.</p> <p><b>Note:</b> If the parameter is set to [0] or [1], when using Proxies or Proxy Sets, it is unnecessary to configure the Proxy IP addresses in the routing table. The device allows SIP calls received from the Proxy IP addresses even if these addresses are not configured in the routing table.</p>
<p>'Filter Calls to IP'</p> <pre>configure voip &gt; sip-definition settings &gt; filter- calls-to-ip</pre> <p>[FilterCalls2IP]</p>	<p>Enables filtering of Tel-to-IP calls when a Proxy Set is used.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. The device doesn't filter calls when using a proxy.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>When the parameter is enabled and a proxy is used, the device first checks the Tel-to-IP Routing table before making a call through the proxy. If the number is not allowed (i.e., number isn't listed in the table or a call restriction routing rule of IP address 0.0.0.0 is applied), the call is released.</p> <p><b>Note:</b> When no proxy is used, the parameter must be disabled and filtering is according to the Tel-to-IP Routing table.</p>
<p>'Tel-to-IP Dial Plan Name'</p> <pre>configure voip &gt; gateway routing settings &gt; tel- dial-plan-name</pre> <p>[Tel2IPDialPlanName]</p>	<p>Assigns the Dial Plan (by name) to be used for tag-based IP-to-Tel routing rules. The Dial Plan's tags can be used as matching criteria (source and destination) for routing rules in the IP-to-Tel Routing table.</p> <p>For more information, see <a href="#">Using Dial Plans for IP-to-Tel or Tel-to-IP Call Routing</a> on page 822.</p>
<p>'IP-to-Tel Dial Plan Name'</p> <pre>configure voip &gt; gateway routing settings &gt; ip-dial- plan-name</pre> <p>[IP2TelDialPlanName]</p>	<p>Assigns the Dial Plan for tag-based Tel-to-IP routing rules. The Dial Plan's tags can be used as matching criteria (source and destination) for routing rules in the Tel-to-IP Routing table.</p> <p>For more information, see <a href="#">Using Dial Plans for IP-to-Tel or Tel-to-IP Call Routing</a> on page 822.</p>
<p>'IP-to-Tel Tagging Destination Dial Plan Index'</p> <pre>configure voip &gt; gateway routing settings &gt; ip2tel-</pre>	<p>Defines the Dial Plan index in the Dial Plan file for called prefix tags for representing called number prefixes in Inbound Routing rules.</p> <p>The valid values are 0 to 7, where 0 denotes PLAN1, 1 denotes PLAN2, and so on. The default is -1 (i.e., no dial</p>

Parameter	Description
tagging-dst [IP2TelTaggingDestDialPlanIndex]	<p>plan file used).</p> <p>For more information on this feature, see Trunk Group and Routing Parameters.</p>
'IP to Tel Tagging Source Dial Plan Index' cconfigure voip > gateway routing settings > ip-to- tel-tagging-src [IP2TelTaggingSourceDialPlanIndex]	<p>Defines the Dial Plan index in the Dial Plan file for calling prefix tags for representing calling number prefixes in Inbound Routing rules.</p> <p>The valid values are 0 to 7, where 0 denotes PLAN1, 1 denotes PLAN2, and so on. The default is -1 (i.e., no dial plan file used).</p> <p>For more information on this feature, see Trunk Group and Routing Parameters.</p>
configure voip > gateway digital settings > etsi- diversion [EnableETSIDiversion]	<p>Defines the method in which the Redirect Number is sent to the Tel side.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Q.931 Redirecting Number Information Element (IE).</li> <li>■ [1] = ETSI DivertingLegInformation2 in a Facility IE.</li> </ul>
'Add CIC' configure voip > gateway manipulation settings > add-cic [AddCicAsPrefix]	<p>Determines whether to add the Carrier Identification Code (CIC) as a prefix to the destination phone number for IP-to-Tel calls. When the parameter is enabled, the 'cic' parameter in the incoming SIP INVITE can be used for IP-to-Tel routing decisions. It routes the call to the appropriate Trunk Group based on the parameter's value.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> (default)</li> <li>■ [1] <b>Yes</b></li> </ul> <p>The SIP 'cic' parameter enables the transmission of the 'cic' parameter from the SIP network to the ISDN. The 'cic' parameter is a three- or four-digit code used in routing tables to identify the network that serves the remote user when a call is routed over many different networks. The 'cic' parameter is carried in the SIP INVITE and maps to the ISDN Transit Network Selection Information Element (TNS IE) in the outgoing ISDN Setup message (if the EnableCIC parameter is set to 1). The TNS IE identifies the requested transportation networks and allows different providers equal access support, based on customer choice.</p> <p>For example, as a result of receiving the below INVITE, the destination number</p>

Parameter	Description
	<p>after number manipulation is  cic+167895550001:  INVITE  sip:5550001;cic=+16789@172.18.202.60:5060;user=phone SIP/2.0</p> <p><b>Note:</b> After the cic prefix is added, the IP-to-Tel Routing table can be used to route this call to a specific Trunk Group. The Destination Number IP to Tel Manipulation table must be used to remove this prefix before placing the call to the Tel side.</p>
[FaxReroutingMode]	<p>Enables the re-routing of incoming Tel-to-IP calls that are identified as fax calls. If a CNG tone is detected on the Tel side of a Tel-to-IP call, the device adds the string, "FAX" as a prefix to the destination number before routing and manipulation. A routing rule in the Tel-to-IP Routing table having the value "FAX" (case-sensitive) as the destination number is then used to re-route the call to a fax destination and the destination number manipulation mechanism is used to remove the "FAX" prefix before sending the fax, if required. If the initial INVITE used to establish the voice call (not fax) was already sent, a CANCEL (if not connected yet) or a BYE (if already connected) is sent to release the voice call.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Rerouting without Delay</b> = Upon detection of a CNG tone, the device immediately releases the call of the initial INVITE and then sends a new INVITE to a specific IP Group or fax server according to the Tel-to-IP Routing table. To enable this feature, set the CNGDetectorMode parameter to 2 and the IsFaxUsed parameter to 1, 2, or 3.</li> <li>■ [2] <b>Progress and Delay</b> = Incoming ISDN calls are delayed until a CNG tone detection or timeout, set by the FaxReroutingDelay parameter. If the EnableComfortTone parameter is set to 1, a Q.931 Progress message with Protocol Discriminator set to 1 is sent to the PSTN and a comfort tone is played accordingly to the PSTN. When the timeout expires, the device sends an INVITE to a specific IP Group or to a fax server, according to the Tel-to-IP Routing table rules.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [3] <b>Connect and Delay</b> = Incoming ISDN calls are delayed until a CNG tone detection or timeout, set by the FaxReroutingDelay parameter. A Q.931 Connect message is sent to the PSTN. If the EnableComfortTone parameter is set to 1, a comfort tone is played to the PSTN. When the timeout expires, the device sends an INVITE to a specific IP Group or to a fax server according to the Tel-to-IP Routing table rules.</li> </ul> <p><b>Note:</b> The parameter has replaced the [EnableFaxRerouting] parameter ('Enable Fax Re-Routing'). For backward compatibility, the [EnableFaxRerouting] parameter set to 1 is equivalent to the [FaxReroutingMode] parameter set to 1.</p>
[FaxReroutingDelay]	<p>Defines the maximum time interval (in seconds) that the device waits for CNG detection before re-routing calls identified as fax calls to fax destinations (terminating fax machine).</p> <p>The valid value range is 1-10. The default is 5.</p>
<b>Call Forking Parameters</b>	
'Forking Handling Mode' forking-handling [ForkingHandlingMode]	<p>Defines how the device handles the receipt of multiple SIP 18x forking responses for Tel-to-IP calls. The forking 18x response is the response with a different SIP to-tag than the previous 18x response. These responses are typically generated (initiated) by Proxy / Application servers that perform call forking, sending the device's originating INVITE (received from SIP clients) to several destinations, using the same Call ID.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Parallel handling</b> = (Default) If SIP 18x with SDP is received, the device opens a voice stream according to the received SDP and disregards any subsequently received 18x forking responses (with or without SDP). If the first response is 180 without SDP, the device responds according to the PlayRBTone2TEL parameter and disregards the subsequent forking 18x responses.</li> <li>■ [1] <b>Sequential handling</b> = If 18x with SDP is received, the device opens a voice stream according to the received SDP. The device re-opens the stream according to subsequently received 18x responses with SDP, or plays a ringback tone if 180 response without SDP is</li> </ul>

Parameter	Description
	<p>received. If the first received response is 180 without SDP, the device responds according to the PlayRBTone2TEL parameter and processes the subsequent 18x forking responses.</p> <p><b>Note:</b> Regardless of the parameter setting, once a SIP 200 OK response is received, the device uses the RTP information and re-opens the voice stream, if necessary.</p>
<p>'Forking Timeout'</p> <pre>configure voip &gt; gateway advanced &gt; forking-timeout</pre> <p>[ForkingTimeOut]</p>	<p>Defines the timeout (in seconds) that is started after the first SIP 2xx response has been received for a User Agent when a Proxy server performs call forking (Proxy server forwards the INVITE to multiple SIP User Agents). The device sends a SIP ACK and BYE in response to any additional SIP 2xx received from the Proxy within this timeout. Once this timeout elapses, the device ignores any subsequent SIP 2xx.</p> <p>The number of supported forking calls per channel is 20. In other words, for an INVITE message, the device can receive up to 20 forking responses from the Proxy server.</p> <p>The valid range is 0 to 30. The default is 30.</p>
<p>'Tel-to-IP Call Forking Mode'</p> <pre>configure voip &gt; sip-definition settings &gt; tel2ip- call-forking-mode</pre> <p>[Tel2IPCallForkingMode]</p>	<p>Enables Tel-to-IP call forking, whereby a Tel call can be routed to multiple IP destinations.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared = (Default) Disabled.</li> <li>■ [1] Check box selected = Enabled.</li> </ul> <p><b>Note:</b> Once enabled, routing rules must be assigned Forking Groups in the Tel-to-IP Routing table.</p>
<p>'Forking Delay Time for SIP INVITE'</p> <pre>configure voip &gt; sip-definition settings &gt; forking- delay-time-invite</pre> <p>[ForkingDelayTimeForInvite]</p>	<p>Defines the interval (in seconds) to wait before sending INVITE messages to the other members of the forking group. The INVITE is immediately sent to the first member. The valid value range is 0 to 40. The default is 0 (i.e., sends immediately).</p>

## IP Connectivity Parameters

The IP connectivity parameters are described in the table below.



Table 69-59:IP Connectivity Parameters

Parameter	Description
<p>'Enable Tel-to-IP Alt Routing'</p> <pre>configure voip &gt; gateway routing settings &gt; alt- routing-tel2ip</pre> <p>[AltRoutingTel2IPEnable]</p>	<p>Enables the device to check the connectivity status of IP destinations of configured Tel-to-IP routing rules in the Tel-to-IP Routing table. This can then be used to trigger alternative routing for Tel-to-IP calls if connectivity with an IP destination is down and an alternative routing rule has been configured.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) Disables the IP Connectivity feature.</li> <li>■ [1] <b>Enable</b> = Enables the IP Connectivity feature.</li> <li>■ [2] <b>Status Only</b> = The IP Connectivity feature is disabled, but read-only information on the QoS of the IP destination is provided.</li> </ul> <p><b>Note:</b> If the parameter is enabled, the Busy Out feature (see [EnableBusyOut] parameter) doesn't function with the Proxy Set keep-alive mechanism. To use the Busy Out feature with the Proxy Set keep-alive mechanism (for IP Groups), disable the parameter.</p>
<p>'Tel-to-IP Alt Routing Mode'</p> <pre>configure voip &gt; gateway routing settings &gt; alt- rte-tel2ip-mode</pre> <p>[AltRoutingTel2IPMode]</p>	<p>Defines the IP Connectivity event(s) reason for triggering alternative routing.</p> <ul style="list-style-type: none"> <li>■ [0] <b>None</b> = Alternative routing is disabled.</li> <li>■ [1] <b>Connectivity</b> = Alternative routing is done if SIP OPTIONS message to the initial destination fails.</li> <li>■ [2] <b>QoS</b> = Alternative routing is done if poor QoS is detected.</li> <li>■ [3] <b>Both</b> = (Default) Alternative routing is done if a SIP OPTIONS to the initial destination fails, poor QoS is detected, or the DNS host name is not resolved.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ QoS is quantified according to delay and packet loss calculated according to previous calls. QoS statistics are reset if no new data is received within two minutes.</li> <li>■ To receive quality information, displayed in the</li> </ul>

Parameter	Description
	'Quality Status' and 'Quality Info.' fields (see <a href="#">Viewing IP Connectivity</a> on page 1360) per destination, configure the parameter to <b>QoS</b> or <b>Both</b> .
'Tel-to-IP Alt Routing Keep-Alive Time' configure voip > gateway routing settings > alt- rte-tel2ip-keep-alive [AltRoutingTel2IPKeepAliveTime]	Defines the time interval (in seconds) between SIP OPTIONS keep-alive messages for the IP Connectivity feature (see <a href="#">IP Destinations Connectivity Feature</a> on page 937). The valid range is 5 to 2,000,000. The default is 60.
'Max Allowed Packet Loss for Alt Routing' configure voip > gateway routing settings > mx- pkt-loss-4-alt-rte [IPConnQoSMaxAllowedPL]	Defines the packet loss (in percentage) at which the IP connection is considered a failure and Alternative Routing mechanism is activated. The default is 20%.
'Max Allowed Delay for Alt Routing' configure voip > gateway routing settings > mx- all-dly-4-alt-rte [IPConnQoSMaxAllowedDelay]	Defines the transmission delay (in msec) at which the IP connection is considered a failure and the Alternative Routing mechanism is activated. The range is 100 to 10,000. The default is 250.

## Alternative Routing Parameters

The alternative routing parameters are described in the table below.

**Table 69-60:Alternative Routing Parameters**

Parameter	Description
'3xx Use Alt Route Reasons' configure voip > sip- definition settings > 3xx-use-alt-route [UseAltRouteReasonsFor3xx]	Defines the handling of received SIP 3xx responses regarding call redirection to listed contacts in the Contact header.  ■ [0] <b>No</b> = (Default) Upon receipt of a 3xx response, the device tries each contact, one by one, listed in the Contact headers, until a successful destination is found. However, if a contact responds with a 486 or 600, the device doesn't try to redirect the call to next contact, and drops the call.

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [1] <b>No if 6xx</b> = Upon receipt of a 3xx response, the device tries each contact, one by one, listed in the Contact headers. However, if a 6xx Global Failure response is received during this process (e.g., 600 Busy Everywhere) the device doesn't try to redirect the call to the next contact, and drops the call.</li> <li>■ [2] <b>Yes</b> = Upon receipt of a 3xx response, the device redirects the call to the first contact listed in the Contact header. If the contact responds with a SIP response that is defined in the Reasons for Tel-to-IP Alternative Routing table, the device tries to redirect the call to the next contact, and so on. If a contact responds with a response that is not configured in the table, the device doesn't try to redirect the call to the next contact, and drops the call.</li> </ul>
<p>'Redundant Routing Mode'</p> <pre>configure voip &gt; gateway routing settings &gt; redundant- routing-m</pre> <p>[RedundantRoutingMode]</p>	<p>Defines the type of redundant routing mechanism when a call can't be completed using the main route.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = No redundant routing is used. If the call can't be completed using the main route (using the active Proxy or the first matching rule in the Routing table), the call is disconnected.</li> <li>■ [1] <b>Routing Table</b> = (Default) Routing table is used to locate a redundant route.</li> <li>■ [2] <b>Proxy</b> = Proxy list is used to locate a redundant route.</li> </ul> <p><b>Note:</b> To implement the Redundant Routing Mode mechanism, you first need to configure the parameter [AltRouteCauseTEL2IP] (Reasons for Alternative Routing table), as described in <a href="#">Alternative Tel-to-IP Routing Based on SIP Responses</a> on page 940.</p>
<p>'Disconnect Call With PI If Alt'</p> <p>[DisconnectCallwithPIIfAlt]</p>	<p>Defines when the device sends the IP-to-Tel call to an alternative route (if configured) when it receives an ISDN Q.931 Disconnect message from the Tel side.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. The device forwards early media to the IP side if Disconnect includes PI, and disconnects the call when a Release message is received. Only after the call is disconnected does the device send the call to an alternative route.</li> </ul>

Parameter	Description
	<p>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled. The device immediately sends the call to the alternative route.</p> <p>For more information, see <a href="#">Alternative Routing upon ISDN Disconnect</a> on page 949.</p> <p><b>Note:</b> The parameter is applicable only to digital interfaces.</p>
<pre>configure voip &gt; gateway manipulation settings &gt; alt-map- tel-to-ip</pre> <p>[EnableAltMapTel2IP]</p>	<p>Enables different Tel-to-IP destination number manipulation rules per routing rule when several (up to three) Tel-to-IP routing rules are defined and if alternative routing using release causes is used. For example, if an INVITE message for a Tel-to-IP call is returned with a SIP 404 Not Found response, the call can be re-sent to a different destination number, configured by the [NumberMapTel2IP] parameter.</p> <p>■ [0] = Disable (default)</p> <p>■ [1] = Enable</p>

## Number Manipulation Parameters

The number manipulation parameters are described in the table below.

**Table 69-61: Number Manipulation Parameters**

Parameter	Description
<pre>configure voip &gt; gateway manipulation settings &gt; map-ip- to-pstn-refer-to</pre> <p>[ManipulateIP2PSTNReferTo]</p>	<p>Enables the manipulation of the called party (destination) number according to the SIP Refer-To header received by the device for TDM (PSTN) blind transfer. The number in the SIP Refer-To header is manipulated for all types of blind transfers to the PSTN (CAS, TBCT, ECT, RLT, and QSIG ).</p> <p>■ [0] = Disable (default)</p> <p>■ [1] = Enable</p> <p>During the blind transfer, the device initiates a new call to the PSTN and the destination number of this call can be manipulated if the parameter is enabled. When enabled, the manipulation is done</p>

Parameter	Description
	<p>as follows:</p> <ol style="list-style-type: none"> <li>1. If you configure a value for the xfer-Prefix parameter, the value (string) is added as a prefix to the number in the Refer-To header.</li> <li>2. This called party number is then manipulated using the Destination Phone Number Manipulation for IP-to-Tel Calls table. The source number of the transferred call is taken from the original call, according to its initial direction: <ul style="list-style-type: none"> <li>✓ Source number of the original call if it is a Tel-to-IP call</li> <li>✓ Destination number of the original call if it is an IP-to-Tel call</li> </ul> <p>This source number can also be used as the value for the 'Source Phone Pattern' field in the Destination Phone Number Manipulation for IP-to-Tel Calls table. The local IP address is used as the value for the 'Source IP Address' field.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ This manipulation doesn't affect IP-to-Trunk Group routing rules.</li> </ul> </li> </ol>
<p>'Use Endpoint Number as Calling Number Tel-to-IP'</p> <pre>configure voip &gt; gateway digital settings &gt; epn-as-cpn- tel2ip</pre> <p>[UseEPNumAsCallingNumTel2IP]</p>	<p>Enables the use of the B-channel number as the calling number (sent in the From field of the INVITE) instead of the number received in the Q.931 Setup message, for Tel-to-IP calls.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>For example, if the incoming calling party number in the Q.931 Setup message is "12345" and the B-channel number is 17, then the outgoing INVITE From header is</p>

Parameter	Description
	<p>set to "17" instead of "12345".</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ When enabled, this feature is applied before routing and manipulation on the source number.</li> </ul>
<p>'Use Endpoint Number as Calling Number IP-to-Tel'</p> <pre>configure voip &gt; gateway digital settings &gt; epn-as-cpn- ip2tel</pre> <p>[UseEPNumAsCallingNumIP2Tel]</p>	<p>Enables the use of the B-channel number as the calling party number (sent in the Q.931 Setup message) instead of the number received in the From header of the INVITE, for IP-to-Tel calls.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>For example, if the incoming INVITE From header contains "12345" and the destined B-channel number is 17, then the outgoing calling party number in the Q.931 Setup message is set to "17" instead of "12345".</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ When enabled, this feature is applied after routing and manipulation on the source number (i.e., just before sending to the Tel side).</li> </ul>
<p>'Tel2IP Default Redirect Reason'</p> <pre>configure voip &gt; gateway manipulation settings &gt; tel-to- ip-dflt-redir-rsn</pre> <p>[Tel2IPDefaultRedirectReason]</p>	<p>Determines the default redirect reason for Tel-to-IP calls when no redirect reason (or "unknown") exists in the received Q931 ISDN Setup message. The device includes this default redirect reason in the SIP History-Info header of the outgoing INVITE.</p> <p>If a redirect reason exists in the received Setup message, the parameter is ignored and the device sends the INVITE message with the reason according to the received Setup message. If the parameter is not configured (-1), the outgoing INVITE is sent with the redirect reason as received</p>

Parameter	Description
	<p>in the Setup message (if none or “unknown” reason, then without a reason).</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> = (Default) Received redirect reason is not changed</li> <li>■ [1] <b>Busy</b> = Call forwarding busy</li> <li>■ [2] <b>No Reply</b> = Call forwarding no reply</li> <li>■ [9] <b>DTE Out of Order</b> = Call forwarding DTE out of order</li> <li>■ [10] <b>Deflection</b> = Call deflection</li> <li>■ [15] <b>Systematic/Unconditional</b> = Call forward unconditional</li> </ul>
<p>'Redirect Number IP-to-Tel'</p> <pre>configure voip &gt; gateway routing settings &gt; redir-nb-si-2tel</pre> <p>[SetIp2TelRedirectScreeningInd]</p>	<p>Defines the value of the Redirect Number screening indicator in ISDN Setup messages.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> (default)</li> <li>■ [0] <b>User Provided</b></li> <li>■ [1] <b>User Passed</b></li> <li>■ [2] <b>User Failed</b></li> <li>■ [3] <b>Network Provided</b></li> </ul>
<p>'Set IP-to-Tel Redirect Reason'</p> <pre>configure voip &gt; gateway manipulation settings &gt; ip2tel-redir-reason</pre> <p>[SetIp2TelRedirectReason]</p>	<p>Defines the redirect reason for IP-to-Tel calls. If redirect (diversion) information is received from the IP, the redirect reason is set to the value of the parameter before the device sends it on to the Tel.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> (default)</li> <li>■ [0] <b>Unkown</b></li> <li>■ [1] <b>Busy</b></li> <li>■ [2] <b>No Reply</b></li> <li>■ [3] <b>Network Busy</b></li> <li>■ [4] <b>Deflection</b></li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [9] <b>DTE out of Order</b></li> <li>■ [10] <b>Forwarding DTE</b></li> <li>■ [13] <b>Transfer</b></li> <li>■ [14] <b>PickUp</b></li> <li>■ [15] <b>Systematic/Unconditional</b></li> </ul>
<p>'Set Tel-to-IP Redirect Reason'</p> <pre>configure voip &gt; gateway manipulation settings &gt; tel2ip- redir-reason</pre> <p>[SetTel2IpRedirectReason]</p>	<p>Defines the redirect reason for Tel-to-IP calls. If redirect (diversion) information is received from the Tel, the redirect reason is set to the value of the parameter before the device sends it on to the IP.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> (default)</li> <li>■ [0] <b>Unkown</b></li> <li>■ [1] <b>Busy</b></li> <li>■ [2] <b>No Reply</b></li> <li>■ [3] <b>Network Busy</b></li> <li>■ [4] <b>Deflection</b></li> <li>■ [9] <b>DTE out of Order</b></li> <li>■ [10] <b>Forwarding DTE</b></li> <li>■ [13] <b>Transfer</b></li> <li>■ [14] <b>PickUp</b></li> <li>■ [15] <b>Systematic/Unconditional</b></li> </ul>
<p>'Send Screening Indicator to IP'</p> <pre>configure voip &gt; gateway digital settings &gt; send-screen- to-ip</pre> <p>[ScreeningInd2IP]</p>	<p>Overrides the calling party's number (CPN) screening indication in the received ISDN SETUP message for Tel-to-IP calls.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> = (Default) Not configured (interworking from ISDN to IP) or set to 0 for CAS.</li> <li>■ [0] <b>User Provided</b> = CPN set by user, but not screened (verified).</li> <li>■ [1] <b>User Passed</b> = CPN set by user, verified and passed.</li> <li>■ [2] <b>User Failed</b> = CPN set by user, and verification failed.</li> </ul>



Parameter	Description
	<ul style="list-style-type: none"> <li>■ [3] <b>Network Provided</b> = CPN set by network.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if the Remote Party ID (RPID) header is enabled.</li> </ul>
<p>'Send Screening Indicator to ISDN'</p> <pre>configure voip &gt; gateway digital settings &gt; send-screen- to-isdn</pre> <p>[ScreeningInd2ISDN]</p>	<p>Defines (overrides) the screening indicator of the calling party's number in the ISDN Setup message for IP-to-Tel ISDN calls. This is applicable only when the device includes one calling party number in the outgoing ISDN Setup message.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> = (Default) Not configured (interworking from IP to ISDN).</li> <li>■ [0] <b>User Provided</b> = Screening indicator is set to "user provided, not screened".</li> <li>■ [1] <b>User Passed</b> = Screening indicator is set to "user provided, verified and passed".</li> <li>■ [2] <b>User Failed</b> = Screening indicator is set to "user provided, verified and failed".</li> <li>■ [3] <b>Network Provided</b> = Screening indicator is set to "network provided".</li> </ul>
<pre>configure voip &gt; gateway digital settings &gt; send-screen- to-isdn-1</pre> <p>[ScreeningInd2ISDN1]</p>	<p>Defines (overrides) the screening indicator for the first calling party number when the device includes two calling party numbers in the outgoing ISDN Setup message for IP-to-Tel ISDN calls.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> = Not configured (interworking from IP to ISDN).</li> <li>■ [0] <b>User Provided</b> = (Default) Screening indicator is set to "user provided, not screened".</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [1] <b>User Passed</b> = Screening indicator is set to "user provided, verified and passed".</li> <li>■ [2] <b>User Failed</b> = Screening indicator is set to "user provided, verified and failed".</li> <li>■ [3] <b>Network Provided</b> = Screening indicator is set to "network provided".</li> </ul>
<pre>configure voip &gt; gateway digital settings &gt; send-screen- to-isdn-2</pre> <p>[ScreeningInd2ISDN2]</p>	<p>Defines (overrides) the screening indicator for the second calling party number when the device includes two calling party numbers in the outgoing ISDN Setup message for IP-to-Tel ISDN calls.</p> <ul style="list-style-type: none"> <li>■ [-1] <b>Not Configured</b> = Not configured (interworking from IP to ISDN).</li> <li>■ [0] <b>User Provided</b> = Screening indicator is set to "user provided, not screened".</li> <li>■ [1] <b>User Passed</b> = Screening indicator is set to "user provided, verified and passed".</li> <li>■ [2] <b>User Failed</b> = Screening indicator is set to "user provided, verified and failed".</li> <li>■ [3] <b>Network Provided</b> = (Default) Screening indicator is set to "network provided".</li> </ul>
<p>'Copy Destination Number to Redirect Number'</p> <pre>configure voip &gt; gateway digital settings &gt; cp-dst-nb-2- redir-nb</pre> <p>[CopyDest2RedirectNumber]</p>	<p>Enables the device to copy the called number (from the received ISDN message for digital interfaces) to the outgoing SIP Diversion header for Tel-to-IP calls (even if a Redirecting Number IE is not received in the ISDN Setup message for digital interfaces). Therefore, the called number is used as a redirect number. Call redirection information is typically used</p>

Parameter	Description
	<p>for Unified Messaging and voice mail services to identify the recipient of a message.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Don't copy</b> = (Default) Disable.</li> <li>■ [1] <b>Copy after phone number manipulation</b> = Copies the called number after manipulation. The device first performs Tel-to-IP destination phone number manipulation (i.e., on the SIP To header), and only then copies the manipulated called number to the SIP Diversion header for the Tel-to-IP call. Therefore, with this option, the called and redirect numbers are identical.</li> <li>■ [2] <b>Copy before phone number manipulation</b> = Copies the called number before manipulation. The device first copies the original called number to the SIP Diversion header, and then performs Tel-to-IP destination phone number manipulation. Therefore, this allows you to have different numbers for the called (i.e., SIP To header) and redirect (i.e., SIP Diversion header) numbers.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If the incoming ISDN-to-IP call includes a Redirect Number, this number is overridden by the new called number if the parameter is set to [1] or [2].</li> <li>■ You can also use this feature for IP-to-Tel calls, by configuring the parameter per IP Profile ('Copy Destination Number to Redirect Number'). For more information, see <a href="#">Configuring IP Profiles</a> on page 664.</li> </ul>
<code>configure voip &gt; sip-definition settings &gt; rep-calling-w-redir</code>	Enables the replacement of the calling number with the redirect number for

Parameter	Description
[ReplaceCallingWithRedirectNumber]	<p>ISDN-to-IP calls.</p> <ul style="list-style-type: none"> <li>■ [0] = Disable (default)</li> <li>■ [1] = The calling name is removed and left blank. The outgoing INVITE message excludes the redirect number that was used to replace the calling number. The replacement is done only if a redirect number is present in the incoming Tel call.</li> <li>■ [2] = Manipulation is done on the new calling party number (after manipulation of the original calling party number, using the Tel2IPSourceNumberMappingDialPlan Index parameter), but before the regular calling or redirect number manipulation: <ul style="list-style-type: none"> <li>✓ If a redirect number exists, it replaces the calling party number. If there is no redirect number, the calling number is left unchanged.</li> <li>✓ If there is a calling “display” name, it remains unchanged.</li> <li>✓ The redirect number remains unchanged and is included in the SIP Diversion header.</li> </ul> </li> </ul>
<p>'Add Trunk Group ID as Prefix'</p> <pre>configure voip &gt; gateway routing settings &gt; trkgrp-id- prefix</pre> <p>[AddTrunkGroupAsPrefix]</p>	<p>Determines whether the Trunk Group ID is added as a prefix to the destination phone number (i.e., called number) for Tel-to-IP calls.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) Don't add Trunk Group ID as prefix.</li> <li>■ [1] <b>Yes</b> = Add Trunk Group ID as prefix to called number.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ This option can be used to define various routing rules.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>To use this feature, you must configure the Trunk Group IDs (see <a href="#">Configuring Trunk Groups</a> on page 903).</li> </ul>
<p>'Add Trunk ID as Prefix'</p> <pre>configure voip &gt; gateway routing settings &gt; trk-id-as- prefix</pre> <p>[AddPortAsPrefix]</p>	<p>Defines if the slot number / port number / Trunk ID is added as a prefix to the called (destination) number for Tel-to-IP calls.</p> <ul style="list-style-type: none"> <li>[0] <b>No</b> (Default)</li> <li>[1] <b>Yes</b></li> </ul> <p>If enabled, the device adds the following prefix to the called phone number: slot number (a single digit in the range of 1 to 6) and port number/Trunk ID (single digit in the range 1 to 8). For example, for the first trunk/channel located in the first slot, the number "11" is added as the prefix.</p> <p>This option can be used to define various routing rules.</p>
<p>'Add Trunk Group ID as Prefix to Source'</p> <pre>trkgrp-id-pref2source</pre> <p>[AddTrunkGroupAsPrefixToSource]</p>	<p>Enables the device to add the Trunk ID (from where the call originated) as the prefix to the calling number (i.e. source number).</p> <ul style="list-style-type: none"> <li>[0] <b>No</b> (default)</li> <li>[1] <b>Yes</b></li> </ul>
<p>'Replace Empty Destination with B-channel Phone Number'</p> <pre>configure voip &gt; gateway routing settings &gt; empty-dst-w- bch-nb</pre> <p>[ReplaceEmptyDstWithPortNumber]</p>	<p>Determines whether the internal channel number is used as the destination number if the called number is missing.</p> <ul style="list-style-type: none"> <li>[0] <b>No</b> (default)</li> <li>[1] <b>Yes</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The parameter is applicable only to Tel-to-IP calls and if the called number is missing.</li> </ul>
[CopyDestOnEmptySource]	<p>Determines whether the destination number is copied to the source number if</p>

Parameter	Description
	<p>no source number is present, for Tel-to-IP calls.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Source Number is left empty.</li> <li>■ [1] = If the Source Number of a Tel-to-IP call is empty, the Destination Number is copied to the Source Number.</li> </ul>
<p>'Add NPI and TON to Calling Number'</p> <pre>configure voip &gt; gateway routing settings &gt; np-i-n-ton- to-cng-nb</pre> <p>[AddNPIandTON2CallingNumber]</p>	<p>Determines whether the Numbering Plan Indicator (NPI) and Type of Numbering (TON) are added to the Calling Number for Tel-to-IP calls.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) Do not change the Calling Number.</li> <li>■ [1] <b>Yes</b> = Add NPI and TON to the Calling Number ISDN Tel-to-IP call.</li> </ul> <p>For example: After receiving a Calling Number of 555, NPI of 1, and TON of 3, the modified number becomes 13555. This number can later be used for manipulation and routing.</p>
<p>'Add NPI and TON to Called Number'</p> <pre>configure voip &gt; gateway routing settings &gt; np-i-n-ton- to-cld-nb</pre> <p>[AddNPIandTON2CalledNumber]</p>	<p>Determines whether NPI and TON are added to the Called Number for Tel-to-IP calls.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) Do not change the Called Number.</li> <li>■ [1] <b>Yes</b> = Add NPI and TON to the Called Number of ISDN Tel-to-IP call.</li> </ul> <p>For example: After receiving a Called Number of 555, NPI of 1 and TON of 3, the modified number becomes 13555. This number can later be used for manipulation and routing.</p>
<p>'Add NPI and TON to Redirect Number'</p> <pre>configure voip &gt; gateway digital settings &gt; np-n-ton-2- redirnb</pre>	<p>Determines whether the NPI and TON values are added as the prefix to the Redirect number in INVITE messages' Diversion or History-Info headers, for</p>

Parameter	Description
[AddNPlandTON2RedirectNumber]	<p>ISDN Tel-to-IP calls.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Yes</b> (Default)</li> <li>■ [1] <b>No</b></li> </ul>
<p>'IP-to-Tel Remove Routing Table Prefix'</p> <pre>configure voip &gt; gateway routing settings &gt; ip2tel-rmv- rte-tbl</pre> <p>[RemovePrefix]</p>	<p>Determines whether or not the device removes the prefix, as configured in the IP-to-Tel Routing table (see <a href="#">Configuring IP-to-Tel Routing Rules</a> on page 928) from the destination number for IP-to-Tel calls, before sending it to the Tel.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared = (Default) Disabled.</li> <li>■ [1] Check box selected = Enabled.</li> </ul> <p>For example: To route an incoming IP-to-Tel call with destination number "21100", the IP-to-Tel Routing table is scanned for a matching prefix. If such a prefix is found (e.g., "21"), then before the call is routed to the corresponding Trunk Group, the prefix "21" is removed from the original number, and therefore, only "100" remains.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only if number manipulation is done after call routing for IP-to-Tel calls (i.e., RouteModelIP2Tel parameter is set to 0).</li> <li>■ Similar operation (of removing the prefix) is also achieved by using the usual number manipulation rules.</li> </ul>
<p>'Swap Redirect and Called Numbers'</p> <pre>configure voip &gt; gateway digital settings &gt; swap-rdr-n- called-nb</pre> <p>[SwapRedirectNumber]</p>	<ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) Don't change numbers.</li> <li>■ [1] <b>Yes</b> = Incoming ISDN call that includes a redirect number (sometimes referred to as 'original called number') uses the redirect number instead of the called number.</li> </ul>

Parameter	Description
<pre>configure voip &gt; gateway manipulation settings &gt; use- refer-by-for-calling-num</pre> <p>[UseReferredByForCallingNumber]</p>	<p>Determines whether the device uses the number from the URI in the SIP Referred-By header as the calling number in the outgoing Q.931 Setup message, when SIP REFER messages are received.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) No</li> <li>■ [1] = Yes</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable to all ISDN (TBCT, RLT, ECT) and CAS blind call transfers (except for in-band) and when the device receives SIP REFER messages with a Referred-By header.</li> <li>■ This manipulation is done before regular IP-to-Tel source number manipulation.</li> </ul>
<pre>configure voip &gt; gateway manipulation settings &gt; swap- tel-to-ip-phone-num</pre> <p>[SwapTel2IPCalled&amp;CallingNumbers]</p>	<p>Global parameter enabling the device to swap the calling and called numbers received from the Tel side (for Tel-to-IP calls).</p> <p>You can also configure the feature per specific calls, using Tel Profiles ('Swap Tel To IP Phone Numbers' parameter). For a detailed description of the parameter and for configuring the feature in the Tel Profiles table, see <a href="#">Configuring Tel Profile</a> on page 738.</p> <p><b>Note:</b> If the feature is configured for a specific Tel Profile, the settings of the global parameter is ignored for calls associated with the Tel Profile.</p>
<p>'Add Prefix to Redirect Number'</p> <pre>configure voip &gt; gateway digital settings &gt; add-pref-to- redir-nb</pre> <p>[Prefix2RedirectNumber]</p>	<p>Defines a string prefix that is added to the Redirect number received from the Tel side. This prefix is added to the Redirect Number in the SIP Diversion header.</p> <p>The valid range is an 8-character string. By default, no value is defined.</p>
<p>'Add Number Plan and Type to RPI Header'</p>	<p>Determines whether the TON/PLAN</p>



Parameter	Description
<code>np-n-type-to-rpi-hdr</code> <code>[AddTON2RPI]</code>	<p>parameters are included in the Remote-Party-ID (RPID) header.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b></li> <li>■ [1] <b>Yes</b> (default)</li> </ul> <p>If the Remote-Party-ID header is enabled (EnableRPIHeader = 1) and AddTON2RPI = 1, it's possible to configure the calling and called number type and number plan using the Number Manipulation tables for Tel-to-IP calls.</p>
<p>'Source Manipulation Mode'</p> <code>configure voip &gt; gateway</code> <code>routing settings &gt; src-</code> <code>manipulation</code> <code>[SourceManipulationMode]</code>	<p>Determines the SIP headers containing the source number after manipulation:</p> <ul style="list-style-type: none"> <li>■ [0] <b>From and P-Asserted-Identity after Manipulation</b> = (Default) The SIP From and P-Asserted-Identity headers contain the source number after manipulation.</li> <li>■ [1] <b>Only From after Manipulation</b> = Only SIP From header contains the source number after manipulation, while the P-Asserted-Identity header contains the source number before manipulation.</li> </ul>
<code>configure voip &gt; gateway</code> <code>manipulation settings &gt; prfm-</code> <code>ip-to-tel-dst-map</code> <code>[PerformAdditionalIP2TELDestinationManipulation]</code>	<p>Enables additional destination number manipulation for IP-to-Tel calls. The additional manipulation is done on the initially manipulated destination number, and this additional rule is also configured in the manipulation table (NumberMapIP2Tel parameter). This enables you to configure only a few manipulation rules for complex number manipulation requirements (that generally require many rules).</p> <ul style="list-style-type: none"> <li>■ [0] = Disable (default)</li> <li>■ [1] = Enable</li> </ul>
<code>configure voip &gt; gateway</code>	<p>Enables additional source number</p>

Parameter	Description
<pre>manipulation settings &gt; prfm- ip-to-tel-src-map</pre> <p>[PerformAdditionalIP2TELSourceManipulation]</p>	<p>manipulation for IP-to-Tel calls. The additional manipulation is done on the initially manipulated source number, and this additional rule is also configured in the manipulation table (SourceNumberMapIP2Tel parameter). This enables you to configure only a few manipulation rules for complex number manipulation requirements (that generally require many rules).</p> <ul style="list-style-type: none"> <li>■ [0] = Disable (default)</li> <li>■ [1] = Enable</li> </ul>
<p>'Add Phone Context As Prefix'</p> <pre>configure voip &gt; gateway manipulation settings &gt; add-ph- cntxt-as-pref</pre> <p>[AddPhoneContextAsPrefix]</p>	<p>Determines whether the received Phone-Context parameter is added as a prefix to the outgoing called and calling numbers (in ISDN Setup messages for digital interfaces).</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul>

## Answer and Disconnect Supervision Parameters

The answer and disconnect supervision parameters are described in the table below.

**Table 69-62: Answer and Disconnect Parameters**

Parameter	Description
<p>'Wait before PSTN Release-Ack'</p> <pre>configure voip &gt; gateway digital settings &gt; wait- befor-pstn-rel-ack</pre> <p>[TimeToWaitForPstnReleaseAck]</p>	<p>Defines a timeout (in milliseconds) that the device waits for the receipt of an ISDN Q.931 Release message from the PSTN side before releasing the channel. The Release ACK is typically sent by the PSTN in response to the device's Disconnect message to end the call. If the timeout expires and a Release message has not yet been received, the device releases the call channel.</p> <p>The valid value is 1 to 360,000. The default is 6,000.</p>

Parameter	Description
<pre>configure voip &gt; interface e1-t1 &gt; isdn-japan-ntt- timer-t305</pre> <p>[ISDNJapanNttTimerT305]</p>	<p>Defines a timeout (in seconds) that the device waits before sending an ISDN Release message after it has sent a Disconnect message, if no SIP message (e.g., 4xx response) is received within the timeout. The parameter is applicable when the device's trunk is configured for the Japanese NTT ISDN PRI (T1) variant (i.e., [ProtocolType] is [16], as described in <a href="#">Configuring Trunk Settings</a> on page 850).</p> <p>The valid value is 0 to 480. The default is 0 (i.e., timeout is 30 seconds).</p> <p>For more information on this feature, see <a href="#">SIP-to-ISDN Disconnect Release Cause Code Mapping</a> on page 979.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> </ul>
<p>'Answer Supervision'</p> <pre>configure voip &gt; gateway analog fxo-setting &gt; answer-supervision</pre> <p>[EnableVoiceDetection]</p>	<p>Enables the sending of SIP 200 OK upon detection of speech, fax, or modem.</p> <ul style="list-style-type: none"> <li>■ [1] <b>Yes</b> = The device sends a SIP 200 OK (in response to an INVITE message) when speech, fax, or modem is detected.</li> <li>■ [0] <b>No</b> = (Default) The device sends a SIP 200 OK only after it completes dialing.</li> </ul> <p>Typically, this feature is used only when early media, enabled by the [EnableEarlyMedia] parameter, is used to establish the voice path before the call is answered.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Gateway application.</li> <li>■ Digital interfaces: <ul style="list-style-type: none"> <li>✓ The parameter is applicable only when the protocol type is CAS.</li> <li>✓ To activate the feature, configure the [EnableDSPIPMDetectors] parameter to 1.</li> </ul> </li> </ul>

Parameter	Description
<p>'GW Max Call Duration'</p> <pre>configure voip &gt; sip- definition settings &gt; gw- mx-call-duration</pre> <p>[GWMaxCallDuration]</p>	<p>Defines the maximum duration (in minutes) per Gateway call. If this duration is reached, the device ends the call. This feature is useful for ensuring that device resources are available for new calls.</p> <p>The valid range is 0 to 35,791. A value of 0 means unlimited duration. The default is 0.</p> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
<pre>configure voip &gt; sip- definition settings &gt; mn- call-duration</pre> <p>[MinCallDuration]</p>	<p>Defines the minimum call duration (in seconds) for the Tel side. If an established call is terminated by the IP side before this duration expires, the device terminates the call with the IP side, but delays the termination toward the Tel side until this timeout expires.</p> <p>The valid value range is 0 to 10 seconds, where 0 (default) disables this feature.</p> <p>For example: assume the minimum call duration is set to 10 seconds and an IP phone hangs up a call established with a BRI phone after 2 seconds. As the call duration is less than the minimum call duration, the device doesn't disconnect the call on the Tel side. However, it sends a SIP 200 OK immediately upon receipt of the BYE to disconnect from the IP phone. The call is disconnected from the Tel side only when the call duration is greater than or equal to the minimum call duration.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Gateway application.</li> <li>■ The parameter is applicable to IP-to-Tel and Tel-to-IP calls.</li> <li>■ The parameter is applicable only to ISDN and CAS protocols.</li> </ul>
<p>'Send Digit Pattern on Connect'</p> <pre>configure voip &gt; sip- definition settings &gt; digit-pttrn-on-conn</pre>	<p>Defines a digit pattern to send to the Tel side after a SIP 200 OK is received from the IP side. The digit pattern is a user-defined DTMF sequence that is used to indicate an answer</p>

Parameter	Description
[TelConnectCode]	<p>signal (e.g., for billing).</p> <p>The valid value is up to 8 characters.</p> <p><b>Note:</b> The parameter is applicable only to FXO and CAS.</p>
<p>'Broken Connection Mode'</p> <pre>configure voip &gt; sip- definition settings &gt; disc-broken-conn</pre> <p>[DisconnectOnBrokenConnection]</p>	<p>Global parameter that defines the device's handling of calls if RTP or MSRP packets are not received within a user-defined timeout (configured by the 'Broken Connection Timeout' parameter) during an established call (i.e., packet flow suddenly stops during the call).</p> <p>You can also configure this feature per specific calls, using IP Profiles ('<a href="#">Broken Connection Mode</a>' on page 720'). For a detailed description of the global parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b> If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</p>
<p>'No RTP Mode'</p> <pre>configure voip &gt; sbc settings &gt; no-rtp-mode</pre> <p>[NoRTPMode]</p>	<p>Global parameter that defines the device's handling of calls if RTP packets are not received (detected) during early media or upon call connect (i.e., never was RTP) within a timeout. The timeout is configured by the [NoRTPDetectionTimeout] parameter.</p> <p>You can also configure this feature per specific calls, using IP Profiles ('<a href="#">No RTP Mode</a>' on page 721' parameter). For a detailed description of the global parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</li> <li>■ The parameter is applicable only to the SBC application.</li> </ul>

Parameter	Description
<p>'Broken Connection Timeout'</p> <pre>configure voip &gt; sip- definition settings &gt; broken-connection-event- timeout</pre> <p>[BrokenConnectionEventTimeout]</p>	<p>Defines the timeout interval (in 100-msec units) after which a call is disconnected if RTP packets are not received during an established call (i.e., packet flow suddenly stops during the call).</p> <p>The valid range is from 3 (i.e., 3 x 100 = 300 msec) to approx. 2684354 (i.e., 74.5 hours). The default is 100 msec.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only when the 'Broken Connection Mode' parameter is configured to <b>Disconnect</b>.</li> <li>■ For this feature to function, you also need to disable silence suppression.</li> </ul>
<pre>configure voip &gt; sbc settings &gt; no-rtp- detection-timeout</pre> <p>[NoRTPDetectionTimeout]</p>	<p>Defines the timeout interval (in msec) after which a call is disconnected or re-routed if RTP packets are not received within the interval.</p> <p>The valid range is 0 to 50000. The default is 0, which means that this timeout feature is disabled and that the device doesn't disconnect the call due to packets not being received.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable to the 'Broken Connection Mode' and 'No RTP Mode' parameters.</li> <li>■ If a call is already established and RTP exists and at any stage during the call packets are not detected for a user-defined interval (configured by the 'Broken Connection Timeout' parameter), the device disconnects the call or routes it to an alternative destination, configured by the IP Profile parameter "<a href="#">Broken Connection Mode</a>" on page 720'.</li> <li>■ The parameter is not applicable to MSRP and direct media calls for the SBC application (see <a href="#">Direct Media Calls</a> on page 1033).</li> </ul>
<p>'Timeout to Establish MSRP Connection'</p>	<p>Defines the timeout (msec) for establishing MSRP connections.</p>

Parameter	Description
<pre>configure voip &gt; sbc settings &gt; msrp- connection-establish- timeout</pre> <p>[MSRPConnectionEstablishTimeout]</p>	<p>The timer starts from when the device opens the MSRP media socket (port). If the timeout expires and the connection wasn't established, the device does one of the following:</p> <ul style="list-style-type: none"> <li>■ Ends the SIP session.</li> <li>■ If you've enabled the Broken Connection feature, the device searches for an alternative route in the IP-to-IP Routing table. For more information, see the IP Profile's 'Broken Connection Mode' parameter in <a href="#">Configuring IP Profiles</a> on page 664.</li> </ul> <p>The valid value is 10000 to 120000. The default is 10000 (i.e., 10 sec).</p> <p>For more information, see <a href="#">Configuring Message Session Relay Protocol</a> on page 1141.</p>
<p>'Trunk Alarm Call Disconnect Timeout'</p> <pre>trk-alm-call-disc-to</pre> <p>[TrunkAlarmCallDisconnectTimeout]</p>	<p>Defines the duration (in seconds) to wait after a digital trunk Red alarm (LOS / LOF) is raised, before the device disconnects the SIP call. If this timeout expires and the alarm is still raised, the device sends a SIP BYE message to terminate the call. If the alarm is cleared before this timeout expires, the call is not terminated, but continues as normal.</p> <p>The range is 1 to 3600. The default is 0 ( 20 for E1 and 40 for T1).</p> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
<p>'Disconnect Call on Busy Tone Detection (ISDN)'</p> <pre>configure voip &gt; gateway digital settings &gt; disc- on-bsy-tone-i</pre> <p>[ISDNDisconnectOnBusyTone]</p>	<p>Defines if a call is disconnected upon detection of a busy tone.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. Do not disconnect call upon detection of busy tone.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled. Disconnect call upon detection of busy tone.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to ISDN protocols.</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ IP-to-ISDN calls are disconnected on detection of SIT tones only in call alert state. If the call is in connected state, the SIT doesn't disconnect the calls. Detection of busy or reorder tones disconnects the IP-to-ISDN calls also in call connected state.</li> <li>■ For IP-to-CAS calls, detection of busy, reorder, or SIT tones disconnect the calls in any call state.</li> </ul>
'Disconnect Call on Busy Tone Detection (CAS)' <pre>configure voip &gt; gateway analog fxo-setting &gt; disc- on-bsy-tone-c</pre> [DisconnectOnBusyTone]	<p>Global parameter enabling call disconnection upon detection of a busy tone.</p> <p>You can also configure the feature per specific calls, using Tel Profiles ('Disconnect Call on Detection of Busy Tone' parameter). For a detailed description of the parameter and for configuring the feature in the Tel Profiles table, see <a href="#">Configuring Tel Profile</a> on page 738.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to the Gateway application.</li> <li>■ If the feature is configured for a specific Tel Profile, the settings of the global parameter is ignored for calls associated with the Tel Profile.</li> </ul>

## SBC Parameters

The SBC parameters are described in the table below.

**Table 69-63:SBC Parameters**

Parameter	Description
<b>SBC-specific Parameters</b>	
<pre>configure voip &gt; application &gt; enable-sbc</pre> [EnableSBCApplication]	<p>Enables the Session Border Control (SBC) application.</p> <ul style="list-style-type: none"> <li>■ [0] = Disable</li> <li>■ [1] = Enable (default)</li> </ul> <p><b>Note:</b></p>



Parameter	Description
	<ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ The parameter is enabled by default only if the License Key contains at least one of the SBC-related capacity features (e.g., "SBC-Signaling"); otherwise, the parameter is disabled.</li> </ul>
<b>SBC Parameters</b>	
'Terminate Inbound OPTIONS' configure voip > sbc settings > sbc-terminate- options [SBCTerminateOptions]	Enables the device to terminate incoming in-dialog SIP OPTIONS messages or forward them to the outbound leg. <ul style="list-style-type: none"> <li>■ [0] Check box cleared = Disable.</li> <li>■ [1] Check box selected =(Default) Enabled.</li> </ul>
'Unclassified Calls' configure voip > sbc settings > unclassified- calls [AllowUnclassifiedCalls]	Determines whether incoming calls that cannot be classified (i.e. classification process fails) to a Source IP Group are rejected or processed. <ul style="list-style-type: none"> <li>■ [0] <b>Reject</b> = (Default) Call is rejected if classification fails.</li> <li>■ [1] <b>Allow</b> = If classification fails, the incoming packet is assigned to a source IP Group (and subsequently processed) as follows:               <ul style="list-style-type: none"> <li>✓ The source SRD is determined according to the SIP Interface to where the SIP-initiating dialog request is sent. The source IP Group is set to the default IP Group associated with this SRD.</li> <li>✓ If the source SRD is ID 0, then source IP Group ID 0 is chosen. In case of any other SRD, then the first IP Group associated with this SRD is chosen as the source IP Group or the call. If no IP Group is associated with this SRD, the call is rejected.</li> </ul> </li> </ul>

Parameter	Description
<p>'SBC Max Call Duration'</p> <pre>configure voip &gt; sbc settings &gt; sbc-mx-call- duration</pre> <p>[SBCMaxCallDuration]</p>	<p>Defines the maximum duration (in minutes) per SBC call (global). If the duration is reached, the device terminates the call.</p> <p>The valid range is 0 to 35,791, where 0 is unlimited duration. The default is 0.</p> <p><b>Note:</b> You can also configure this feature per specific calls, using IP Profiles ('Max Call Duration' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664. If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</p>
<p>'SBC No Answer Timeout'</p> <pre>configure voip &gt; sbc settings &gt; sbc-no-alert- timeout</pre> <p>[SBCAlertTimeout]</p>	<p>Defines the timeout (in seconds) for SIP INVITE messages sent by the device (outbound IP routing).</p> <p>The device starts the timeout when it sends the INVITE message and when (if) it receives the first SIP 18x response (e.g., 180 Ringing) from the called party. The timeout that is started when the INVITE message is sent, is <b>only</b> used if no 18x response is received.</p> <p>If the timeout expires and no additional SIP response (for example, 200 OK) was received during this interval, the device releases the call.</p> <p>The valid range is 0 to 3600 seconds. the default is 600.</p>
<pre>configure voip &gt; sbc settings &gt; num-of- subscribes</pre> <p>[NumOfSubscribes]</p>	<p>Defines the maximum number of concurrent SIP SUBSCRIBE sessions permitted on the device.</p> <p>The valid value is any value between 0 and the maximum supported SUBSCRIBE sessions. When set to -1, the device uses the default value. For more information, contact the sales representative of your purchased device.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
<pre>configure voip &gt; sbc</pre>	<p>Enables the device to route in-dialog, refresh</p>

Parameter	Description
<pre>settings &gt; sbc-dialog- subsc-route-mode</pre> <p>[SBCInDialogSubscribeRouteMode]</p>	<p>SIP SUBSCRIBE requests to the "working" (has connectivity) proxy.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable – the device sends in-dialog, refresh SUBSCRIBES according to the address in the Contact header of the 200 OK response received from the proxy to which the initial SUBSCRIBE was sent (as per the SIP standard).</li> <li>■ [1] = Enable – the device routes in-dialog, refresh SUBSCRIBES to the "working" proxy (regardless of the Contact header). The "working" proxy (address) is determined by the device's keep-alive mechanism for the Proxy Set that was used to route the initial SUBSCRIBE.</li> </ul> <p><b>Note:</b> For this feature to be functional, ensure the following:</p> <ul style="list-style-type: none"> <li>■ Keep-alive mechanism is enabled for the Proxy Set ('Proxy Keep-Alive' parameter is set to any value other than <b>Disable</b>).</li> <li>■ Load-balancing between proxies is disabled ('Proxy Load Balancing Method' parameter is set to <b>Disable</b>).</li> </ul>
<p>'Backup Subscriptions'</p> <pre>config voip &gt; sbc settings &gt; backup-subscriptions</pre> <p>[BackupSubscriptions]</p>	<p>Defines which SIP SUBSCRIBE dialogs for registered users the device (operating in HA mode) backs up, based on transport protocol. Backing up SUBSCRIBE dialogs allows the redundant (now active) device to maintain user subscriptions and send relevant NOTIFY messages to the users (SIP UAs) after an HA switchover.</p> <ul style="list-style-type: none"> <li>■ [0] <b>All</b> = (Default) The device backs up all SUBSCRIBE dialogs (regardless of used transport protocol).</li> <li>■ [1] <b>UDP</b> = The device backs up only SUBSCRIBE dialogs that use UDP.</li> <li>■ [2] <b>None</b> = The device doesn't back up any SUBSCRIBE dialogs.</li> </ul>

Parameter	Description
	<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For SUBSCRIBE dialogs that use TCP or TLS connections, it may be beneficial to configure the parameter to <b>UDP</b> or <b>None</b>. For these registered users, the device needs to establish new TCP or TLS connections (typically initiated by the remote UA) after the switchover. Therefore, backing up these SUBSCRIBE dialogs is unnecessary, wasting valuable resources.</li> <li>■ The parameter is applicable only when the device operates in HA mode.</li> </ul>
<p>'Disconnect Subscriptions Mode'</p> <pre>config voip &gt; sbc settings &gt; disconnect-subscriptions [DisconnectSubscriptionsMode]</pre>	<p>Enables the device to disconnect (delete from storage) SUBSCRIBE dialogs associated with registered users, upon an unregister, upon register expiration, or upon a refresh register done from a different source IP address / port (like when the transport protocol is TCP or TLS).</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. The device stores the SUBSCRIBE dialogs of registered users until the subscriptions' expiration times are reached.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled. The device disconnects (deletes) SUBSCRIBE dialogs of registered users upon an unregister, upon a register expiration, or upon a refresh register done from a different source IP address / port.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<pre>configure voip &gt; sbc settings &gt; sbc-max-fwd- limit [SBCMaxForwardsLimit]</pre>	<p>Defines the Max-Forwards SIP header value. The Max-Forwards header is used to limit the number of servers (such as proxies) that can forward the SIP request. The Max-Forwards value indicates the remaining number of times this request message is allowed to be forwarded. The count is decremented by each server that forwards the request.</p>

Parameter	Description
	<p>The valid value range is 1-70. The default is 10.</p> <p>The parameter affects the Max-Forwards header in the received message as follows:</p> <ul style="list-style-type: none"> <li>■ If the received header's original value is 0, the message is not passed on and is rejected.</li> <li>■ If the received header's original value is less than the parameter's value, the header's value is decremented before being sent on.</li> <li>■ If the received header's original value is greater than the parameter's value, the header's value is replaced by the user-defined parameter's value.</li> </ul>
<p>'Play Tone on Connect Failure Behavior'</p> <p><code>play-tone-on-connect-failure-behavior</code></p> <p>[PlayToneOnConnectFailureBehavior]</p>	<p>Defines if the device connects or disconnects the call if it can't play the specified tone to the call party. This parameter relates to the feature that is described in <a href="#">Playing Tone upon Call Connect</a> on page 1172.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disconnect</b> (Default)</li> <li>■ [1] <b>Ignore</b></li> </ul>
<p><code>configure voip &gt; sip-definition settings &gt; force-generate-to-tag</code></p> <p>[ForceGenerateToTag]</p>	<p>Enables the device to generate the 'tag' parameter's value in the SIP To header. This is applied to the first SIP response, received from the called party, which the device sends to the dialog-initiating SIP user agent (caller). In other words, this device-generated To tag overwrites the original To tag generated by the called party. All SIP messages between the device and caller use this generated To tag, while all SIP messages between the device and called party use the To tag generated by the called party. As the device-generated To tag value is short (up to 12 characters), this feature may be useful for SIP UAs that cannot handle long tag values.</p> <p>An example of the To tag:</p> <p>To: Alice@company.com; <b>tag</b> = 9777484849@10.10.1.110</p>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [0] = Disable (default). The device forwards the To tag transparently between the SIP UAs.</li> <li>■ [1] = Enable. The device generates the To tag in the response sent to the initiator of the SIP dialog.</li> </ul> <p><b>Note:</b> The feature is applicable only if the 'SBC Operation Mode' parameter is configured to <b>B2BUA</b>. This can be configured in the SRD and IP Groups table. However:</p> <ul style="list-style-type: none"> <li>■ The IP Group's 'SBC Operation Mode' parameter takes precedence over the SRD's 'SBC Operation Mode' parameter. For example, if the IP Group is configured for B2BUA but its' associated SRD is not, then the tag-generation feature can function.</li> <li>■ If the IP Group's 'SBC Operation Mode' parameter is not configured (-1), the tag-generation feature for the IP Group is functional only if its' associated SRD is configured for B2BUA.</li> <li>■ For call routing between IP Groups, the feature can only function if both IP Groups are configured for B2BUA, or if one or both of them is not configured (-1), but the associated SRD is configured for B2BUA.</li> </ul>
<p>'Session-Expires'</p> <pre>configure voip &gt; sbc settings &gt; sbc-sess-exp- time</pre> <p>[SBCSessionExpires]</p>	<p>Defines the SBC session refresh timer (in seconds) in the Session-Expires header of outgoing INVITE messages.</p> <p>The valid value range is 90 (according to RFC 4028) to 86400. The default is 180.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<p>'Minimum Session-Expires'</p> <pre>configure voip &gt; sbc settings &gt; min-session- expires</pre>	<p>Defines the minimum amount of time (in seconds) between session refresh requests in a dialog before the session is considered timed out. This value is conveyed in the SIP Min-SE header.</p>

Parameter	Description
[SBCMinSE]	<p>The valid range is 0 (default) to 1,000,000, where 0 means that the device doesn't limit Session-Expires.</p> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<pre>configure voip &gt; sbc settings &gt; sbc-session- refresh-policy</pre> [SBCSessionRefreshingPolicy]	<p>Defines the SIP user agent responsible for periodically sending refresh requests for established sessions (active calls). The session refresh allows SIP UAs or proxies to determine the status of the SIP session. When a session expires, the session is considered terminated by the UAs, regardless of whether a SIP BYE was sent by one of the UAs.</p> <p>The SIP Session-Expires header conveys the lifetime of the session, which is sent in re-INVITE or UPDATE requests (session refresh requests). The 'refresher=' parameter in the Session-Expires header (sent in the initial INVITE or subsequent 2xx response) indicates who sends the session refresh requests. If the parameter contains the value 'uac', the device performs the refreshes; if the parameter contains the value 'uas', the remote proxy performs the refreshes. An example of the Session-Expires header is shown below:</p> <pre>Session-Expires: 4000;refresher=uac</pre> <p>Thus, the parameter is useful when a UA doesn't support session refresh requests or doesn't support the indication of who performs session refresh requests. In such a scenario, the device can be configured to perform the session refresh requests.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Remote Refresher. The UA (proxy) performs the session refresh requests. The device indicates this to the UA by sending the SIP message with the 'refresher=' parameter in the Session-Expires header set to 'uas'.</li> <li>■ [1] = SBC Refresher. The device performs</li> </ul>

Parameter	Description
	<p>the session refresh requests. The device indicates this to the UA by sending the SIP message with the 'refresher=' parameter in the Session-Expires header set to 'uac'.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>The time values of the Session-Expires (session refresh interval) and Min-SE (minimum session refresh interval) headers can be configured using the [SBCSessionExpires] and [SBCMinSE] parameters, respectively.</li> </ul> <p><b>Note:</b> The parameter is applicable only to the SBC application.</p>
<p>'User Registration Grace Time'</p> <pre>configure voip &gt; sbc settings &gt; sbc-usr-reg- grace-time</pre> <p>[SBCUserRegistrationGraceTime]</p>	<p>Defines additional time (in seconds) to add to the registration expiry time of users that are registered with the device.</p> <p>The valid value is 0 to 15,500,000. The default is 0.</p> <p>For more information, see <a href="#">Registration Refreshes</a> on page 1029.</p>
<p>'DB Routing Search Mode'</p> <pre>configure voip &gt; sbc settings &gt; sbc-db- route-mode</pre> <p>[SBCDBRoutingSearchMode]</p>	<p>Defines the method for searching a registered user in the device's User Registration database when a SIP INVITE message is received for routing to or from a user. If the registered user is found (i.e., destination URI in INVITE), the device routes the call to the user's corresponding contact address specified in the database.</p> <ul style="list-style-type: none"> <li>[0] <b>All permutations</b> = (Default) <ul style="list-style-type: none"> <li>✓ <b>To User:</b> Device searches for the user in the database using the entire Request-URI (user@host). If not found, it searches for the user part of the Request-URI. For example, it first searches for "4709@joe.company.com" and if not found, it searches for "4709".</li> <li>✓ <b>From User:</b> Device searches for the</li> </ul> </li> </ul>



Parameter	Description
	<p>user in the database using the entire From header AOR (user@host). If not found, it searches for the user part of the From header AOR. For example, it first searches for "4709@domain.com" and if not found, it searches for "4709".</p> <p>■ [1] <b>Dest URI dependant =</b></p> <ul style="list-style-type: none"> <li>✓ <b>To User:</b> Device searches for the user in the database using the entire Request-URI (user@host) <b>only</b>. For example, it searches for "4709@joe.company.com".</li> <li>✓ <b>From User:</b> Device searches for the user in the database using the entire From header AOR (user@host) <b>only</b>. For example, for "From: &lt;sip:4709@domain.com&gt;", the device searches for "4709@domain.com".</li> </ul> <p><b>Note:</b> If the Request-URI contains the "tel:" URI or "user=phone" parameter, the device searches only for the user part.</p>
<p>'Handle P-Asserted-Identity'</p> <pre>configure voip &gt; sbc settings &gt; p-assert-id</pre> <p>[SBCAssertIdentity]</p>	<p>Global parameter that defines the handling of the SIP P-Asserted-Identity header. You can also configure this feature per specific calls, using IP Profiles ('P-Asserted-Identity Header Mode' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b> If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</p>
<p>'Keep original user in Register'</p> <pre>configure voip &gt; sbc settings &gt; keep-contact- user-in-reg</pre> <p>[SBCKeepContactUserinRegister]</p>	<p>Defines the device's handling of the SIP Contact header in REGISTER requests which it forwards as the outgoing message.</p> <p>■ [0] <b>Do not keep user; override with unique identifier = (Default)</b> The device</p>

Parameter	Description
	<p>replaces the user part of the Contact header with a unique value, for example:</p> <ul style="list-style-type: none"> <li>✓ Incoming Contact Header: &lt;sip:123@domain.com&gt;</li> <li>✓ Outgoing Contact Header: &lt;sip:FEU1-7-1-3@SBC&gt;</li> </ul> <ul style="list-style-type: none"> <li>■ [1] <b>keep user without unique identifier</b> = The device retains the original user part value of the Contact header in the outgoing REGISTER request.</li> <li>■ [2] <b>Keep user; add unique identifier as URI parameter</b> = The device retains the original user part value of the Contact header in the outgoing REGISTER request. In addition, it adds the special URI parameter "ac-feu=&lt;identifier&gt;" to the Contact header, which is used to differentiate between two SIP entities with the same user part. The identifier value is generated by the device.</li> </ul> <ul style="list-style-type: none"> <li>✓ Incoming Contact Header: &lt;sip:123@domain.com&gt;</li> <li>✓ Outgoing Contact Header: &lt;sip:123@SBC;ac-feu=1-7-1-3&gt;</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable only to REGISTER messages received from User-type IP Groups which are sent to Server-type IP Groups.</li> <li>■ Depending on the 'Remote Representation Mode' parameter of the IP Profiles table ('Remote Representation Mode' parameter), the host part in the SIP Contact header can be replaced by the device's IP address or by the value of the 'SIP Group Name' parameter (configured in the IP Groups table).</li> </ul>
'URI Comparison Excluded Parameters'	Defines which URI parameters are excluded

Parameter	Description
<pre>config-voip &gt; sbc settings &gt; uri-comparison-excluded-params</pre> <p>[SBCURIComparisonExcludedParams]</p>	<p>when the device compares the URIs of two incoming dialog-initiating SIP requests (e.g., INVITEs) to determine if they were sent from a user that is registered in the device's registration database (registered AOR and corresponding Contact URI), during the Classification stage.</p> <p>The value of the parameter is a free-text string, which can't be empty. You can configure it to any sequence of parameters, separated by commas (e.g., transport, maddr, ttl). Alternatively, you can configure it to one of the following values (case-insensitive):</p> <ul style="list-style-type: none"> <li>■ <b>All = (Default)</b> The device excludes all URI parameters and ports in the comparison of the two URIs, except the canonical URI form ('gr' (gruu), 'user=phone', and AudioCodes proprietary 'ac-int' parameters).</li> </ul> <p>Therefore, if there are two different registrations of the same user whose Contacts are differentiated only by ports and/or a proprietary parameter, the device considers them to be the same single registration, even though they are different registrations.</p> <ul style="list-style-type: none"> <li>■ <b>All\&lt;parameter 1&gt;,&lt;parameter 2&gt;&lt;parameter 3&gt;, and so on</b> = The device excludes all URI parameters and ports in the comparison of the two URIs, except the following: <ul style="list-style-type: none"> <li>✓ Canonical URI form ('gr' (gruu), 'user=phone', and AudioCodes proprietary 'ac-int' parameters).</li> <li>✓ The specified parameters (&lt;parameter 1&gt;,&lt;parameter 2&gt;&lt;parameter 3&gt;, and so on).</li> </ul> </li> </ul> <p>Examples:</p> <ul style="list-style-type: none"> <li>✓ "ALL\X":</li> </ul>

Parameter	Description
	<p><b>These URIs are not equal because their URI parameter 'x' has different values:</b></p> <p>sip:John@10.10.10.10;x=11111 sip:John@10.10.10.10;x=22222</p> <p><b>These URIs are not equal because only one of them contains 'user-r=phone' (i.e., different canonical forms):</b></p> <p>sip:John@10.10.10.10;user-r=phone;x=11111 sip:John@10.10.10.10;x=11111</p> <p><b>These URIs are equal:</b></p> <p>sip:John@10.10.10.10;x-x=11111;y=aaaaa sip:John@10.10.10.10;x-x=11111;y=bbbbbb</p> <ul style="list-style-type: none"> <li>■ <b>None</b> = All URI parameters and ports are included in the comparison of the two URIs.</li> <li>■ <b>Port</b> = The ports of the URIs are excluded in the comparison of the two URIs, but all other URI parameters are included in the comparison. "port" can be combined with other URI parameters that you want excluded (e.g., port, transport, proprietary-param).</li> </ul> <p>For example, if two SIP requests are received with different Contact header values, as shown below (in bold) and the parameter is configured to <b>All</b>, then the device considers these requests as received from the same registered user as it disregards the port (5060 and 5070), 'transport', and 'ttl' parameters in its comparison. If configured to <b>None</b>, the device considers these requests as received from two different registered users.</p> <p>Contact:</p> <pre>&lt;sip:1000@172.17.142.105:5060;transport=tcp;ttl=10&gt;</pre>

Parameter	Description
	<p>Contact:</p> <pre>&lt;sip:1000@172.17.142.105:5070;transport=tls;ttl=20&gt;</pre> <p><b>Note:</b> The AudioCodes proprietary 'feu' string value for the user part must be included in the Contact header of REGISTER requests that the device forwards to the registrar server when the parameter is configured to a non-default value (i.e., not <b>All</b>). Therefore, if you configure the parameter to a non-default value, the [SBCKeepContactUserInRegister] parameter must not be configured to <b>Keep User Without Unique Identifier (1)</b>.</p>
<p>'SBC REFER Behavior'</p> <pre>configure voip &gt; sbc settings &gt; sbc-refer-bhvr [SBCReferBehavior]</pre>	<p>Global parameter that defines the handling of SIP REFER requests. You can also configure this feature per specific calls, using IP Profiles ('Remote REFER Mode' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b> If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</p>
<pre>configure voip &gt; sbc settings &gt; sbc-xfer-prefix [SBCXferPrefix]</pre>	<p>When the SBCReferBehavior is set to 1, the device, while interworking the SIP REFER message, adds the prefix "T~&amp;R-" to the user part of the URI in the Refer-To header. After this, the device can receive an INVITE with such a prefix (the INVITE is sent by the UA that receives the REFER message or 302 response). If the device receives an INVITE with such a prefix, it replaces the prefix with the value defined for the SBCXferPrefix parameter. By default, no value is defined.</p> <p><b>Note:</b> This feature is also applicable to 3xx redirect responses. The device adds the prefix "T~&amp;R-" to the URI user part in the Contact header if the SBC3xxBehavior parameter is set to 1.</p>

Parameter	Description
<pre>configure voip &gt; sbc settings &gt; sbc-3xx-bhvt</pre> [SBC3xxBehavior]	<p>Global parameter that defines the handling of SIP 3xx redirect responses. You can also configure this feature per specific calls, using IP Profiles ('Remote 3xx Mode' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b> If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</p>
<p>'Enforce Media Order'</p> <pre>configure voip &gt; sbc settings &gt; enforce-media- order</pre> [SBCEnforceMediaOrder]	<p>Enables the device to include all previously negotiated media lines ('m=') within the current session in the SDP offer-answer exchange (RFC 3264).</p> <p>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</p> <p>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</p> <p>For example, assume a call (audio) has been established between two endpoints and one endpoint wants to subsequently send an image in the same call session. If the parameter is enabled, the endpoint includes the previously negotiated media type (i.e., audio) with the new negotiated media type (i.e., image) in its SDP offer:</p> <pre>v=0 o=bob 2890844730 2890844731 IN IP4 host.example.com s= c=IN IP4 host.example.com t=0 0 <b>m=audio</b> 0 RTP/AVP 0 m=image 12345 udpt1 t38</pre> <p>In this example, if the parameter is disabled, the only 'm=' line included in the SDP is the newly negotiated media (i.e., image).</p>
<p>'SBC Diversion URI Type'</p> <pre>configure voip &gt; sbc</pre>	<p>Defines the URI type to use in the SIP Diversion header of the outgoing SIP message.</p>

Parameter	Description
<pre>settings &gt; sbc-diversion- uri-type</pre> <p>[SBCDiverionUriType]</p>	<ul style="list-style-type: none"> <li>■ [0] <b>Transparent</b> = (Default) The device doesn't change the URI and leaves it as is.</li> <li>■ [1] <b>Sip</b> = The "sip" URI is used.</li> <li>■ [2] <b>Tel</b> = The "tel" URI is used.</li> </ul> <p><b>Note:</b> The parameter is applicable only if the Diversion header is used. The [SBCDiverionMode] and [SBCHistoryInfoMode] parameters in the IP Profiles table determine the call redirection (diversion) SIP header to use - History-Info or Diversion.</p>
<pre>configure voip &gt; sbc general-setting &gt; sip- server-digest-algorithm</pre> <p>[SIPServerDigestAlgorithm]</p>	<p>Defines the cryptographic hash algorithm used in the outgoing authentication challenge (SIP 401 or 407) response when the device authenticates incoming SIP requests as an authentication server.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) MD5</li> <li>■ [1] = SHA-256</li> </ul>
<pre>configure voip &gt; sbc settings &gt; sbc-server-auth- mode</pre> <p>[SBCServerAuthMode]</p>	<p>Defines if authentication of the SIP client is done locally (by the device) or by a RADIUS server.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Authentication is done by the device (locally).</li> <li>■ [1] = Authentication is done by an RFC 5090 compliant RADIUS server.</li> <li>■ [2] = Authentication is done according to the Draft Stermann-aaa-sip-01 method.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ Currently, option [1] is not supported.</li> <li>■ The parameter is overridden by the IP Group parameter 'SBC Server Authentication Type'.</li> </ul>
<p>'Lifetime of nonce'</p> <pre>configure voip &gt; sbc settings &gt; lifetime-of-</pre>	<p>Defines the lifetime (in seconds) that the current nonce is valid for server-based authentication. The device challenges a</p>

Parameter	Description
<p>nonce</p> <p>[AuthNonceDuration]</p>	<p>message that attempts to use a server nonce beyond this period. The parameter is used to provide replay protection (i.e., ensures that old communication streams are not used in replay attacks).</p> <p>The valid value range is 30 to 600. The default is 300.</p>
<p>'Authentication Challenge Method'</p> <p>configure voip &gt; sbc settings &gt; auth-chlng-mthd</p> <p>[AuthChallengeMethod]</p>	<p>Defines the type of server-based authentication challenge.</p> <ul style="list-style-type: none"> <li>■ [0] <b>0</b> = (Default) Send SIP 401 "Unauthorized" with a WWW-Authenticate header as the authentication challenge response.</li> <li>■ [1] <b>1</b> = Send SIP 407 "Proxy Authentication Required" with a Proxy-Authenticate header as the authentication challenge response.</li> </ul>
<p>'Authentication Quality of Protection'</p> <p>configure voip &gt; sbc settings &gt; auth-qop</p> <p>[AuthQOP]</p>	<p>Defines the authentication and integrity level of quality of protection (QoP) for digest authentication offered to the client. When the device challenges a SIP request (e.g., INVITE), it sends a SIP 401 response with the Proxy-Authenticate header or WWW-Authenticate header containing the 'qop' parameter. The QoP offered in the 401 response can be 'auth', 'auth-int', both 'auth' and 'auth-int', or the 'qop' parameter can be omitted from the 401 response. In response to the 401, the client needs to send the device another INVITE with the cryptographic hash algorithm (configured by [SIPServerDigestAlgorithm] parameter) of the INVITE message and indicate the selected auth type.</p> <ul style="list-style-type: none"> <li>■ [0] <b>0</b> = The device sends 'qop=auth' in the SIP response, requesting authentication (i.e., validates user by checking user name and password). This option doesn't authenticate the message body (i.e., SDP).</li> <li>■ [1] <b>1</b> = The device sends 'qop=auth-int' in</li> </ul>



Parameter	Description
	<p>the SIP response, indicating required authentication and authentication with integrity (e.g., checksum). This option restricts the client to authenticating the entire SIP message, including the body, if present.</p> <ul style="list-style-type: none"> <li>■ [2] <b>2</b> = (Default) The device sends 'qop=auth, auth-int' in the SIP response, indicating either authentication or integrity. This enables the client to choose 'auth' or 'auth-int'. If the client chooses 'auth-int', then the body is included in the authentication. If the client chooses 'auth', then the body is not authenticated.</li> <li>■ [3] <b>3</b> = No 'qop' parameter is offered in the SIP 401 challenge message.</li> </ul>
<p>'SBC User Registration Time'</p> <pre>configure voip &gt; sbc settings &gt; sbc-usr-rgstr- time</pre> <p>[SBCUserRegistrationTime]</p>	<p>Global parameter that defines the duration (in seconds) of the periodic registrations that occur between the user and the device (the device responds with this value to the user). You can also configure this feature per specific calls, using IP Profiles ('User Registration Time' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b> If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</p>
<p>'SBC Proxy Registration Time'</p> <pre>configure voip &gt; sbc settings &gt; sbc-prxy-rgstr- time</pre> <p>[SBCProxyRegistrationTime]</p>	<p>Defines the duration (in seconds) for which the user is registered in the proxy database (after the device forwards the REGISTER message). This value is sent in the Expires header. When set to 0, the device sends the Expires header's value as received from the user to the proxy. The valid range is 0 to 2,000,000 seconds. The default is 0.</p>
<pre>configure voip &gt; sbc</pre>	<p>Enables the device to change the expiry time in</p>

Parameter	Description
<p>settings &gt; sbc-rand-expire [SBCRandomizeExpires]</p>	<p>the Expires header of SIP 200 OK responses for user registration or subscription requests.</p> <p>The feature is useful in scenarios where multiple users may refresh their registration or subscription simultaneously, causing the device to handle many such sessions at a given time. This may result in an overload of the device (reaching maximum session capacity), preventing the establishment of new calls or preventing the handling of some user registration or subscription requests. However, when this feature is enabled, the device assigns a random expiry time to each user registration or subscription, ensuring future user registration and subscription requests are more distributed over time (i.e., do not all occur simultaneously).</p> <p>The valid value is 0 (disabled) to 20 (any value from 1 to 20 is considered enabled). The default is enabled (10). If disabled (i.e., 0), the device doesn't change the expiry time. If enabled, the device assigns a random expiry time as follows:</p> <ul style="list-style-type: none"> <li>■ If the received expiry time is less than 610 sec, the device reduces the time by up to 10 sec. For example, if the received expiry time is 110 sec, the device reduces it to anywhere between 100 (i.e., 110 – 10) and 110 sec.</li> <li>■ If the received expiry time is greater than 610 sec, the device reduces the time to anywhere between 600 sec and the received expiry time. For example, if the received expiry time is 700 sec, the device reduces it to anywhere between 600 and 700 sec.</li> <li>■ Minimum expiry time: <ul style="list-style-type: none"> <li>✓ The minimum expiry time that the device can reduce REGISTER messages to is 30 sec and SUBSCRIBE messages</li> </ul> </li> </ul>

Parameter	Description
	<p>to 120 sec. For example, if the received expiry time in a REGISTER message is 35 sec, the device reduces the time to any value between 30 and 35 sec (and not by 10 seconds -- between 25 and 35).</p> <p>✓ If the received expiry time is less than the minimum (as stated above), the expiry time remains unchanged. For example, if the received expiry time in a REGISTER message is 18 sec, the device forwards the message with this same expiry time (i.e., 18).</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ This feature doesn't apply to refresh REGISTER or SUBSCRIBE messages.</li> <li>■ You can configure the device to change the received expiry time before forwarding it, using the <code>SBCUserRegistrationTime</code> parameter.</li> </ul>
<p>'SBC Survivability Registration Time'</p> <pre>configure voip &gt; sbc settings &gt; sbc-surv-rgstr- time</pre> <p>[SBCSurvivabilityRegistrationTime]</p>	<p>Defines the duration of the periodic registrations between the user and the device, when the device is in survivability state (i.e., when REGISTER requests cannot be forwarded to the proxy and are terminated by the device). When set to 0, the device uses the value set by the <code>SBCUserRegistrationTime</code> parameter for the device's response.</p> <p>The valid range is 0 to 2,000,000 seconds. The default is 0.</p>
<pre>configure voip &gt; sbc settings &gt; sas-notice</pre> <p>[SBCEnableSurvivabilityNotice]</p>	<p>Enables the device to notify Aastra IP phones that the device is currently operating in Survivability mode.</p> <ul style="list-style-type: none"> <li>■ [0] = Disable</li> <li>■ [1] = Enable</li> </ul> <p>For more information, see <a href="#">Enabling Survivability Display on Aastra IP Phones</a> on page 1166.</p>

Parameter	Description
<p>'SBC Dialog-Info Interworking'</p> <pre>configure voip &gt; sbc settings &gt; sbc-dialog-info- interwork</pre> <p>[EnableSBCDialogInfoInterworking]</p>	<p>Enables the interworking of dialog information (parsing of call identifiers in XML body) in SIP NOTIFY messages received from a remote application server.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p>For more information, see <a href="#">Interworking Dialog Information in SIP NOTIFY Messages</a> on page 1052.</p>
<pre>configure voip &gt; sbc settings &gt; sbc-keep-call-id</pre> <p>[SBCKeepOriginalCallId]</p>	<p>Global parameter that enables the device to use the same call identification (SIP Call-ID header value) received in incoming messages for the call identification in outgoing messages. The call identification value is contained in the SIP Call-ID header.</p> <p>You can also configure the feature per specific calls, using IP Profiles. For a detailed description of the parameter and for configuring the feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p>
<pre>configure voip &gt; sbc settings -&gt; sbc-terminate- options</pre> <p>[SBCTerminateOptions]</p>	<p>Defines the handling of in-dialog SIP OPTIONS messages.</p> <ul style="list-style-type: none"> <li>■ [0] = Disabled - the device forwards in-dialog SIP OPTIONS to the outbound peer.</li> <li>■ [1] = (Default) Enabled - the device terminates in-dialog SIP OPTIONS and sends a 200 OK response to the peer that sent the OPTIONS message.</li> </ul>
<p>'Routing Timeout'</p> <pre>configure voip &gt; sbc settings &gt; sbc-routing- timeout</pre> <p>[SbcRoutingTimeout]</p>	<p>Defines the maximum duration (in seconds) that the device is prepared to wait for a response from external servers when a routing rule is configured to query an external server (e.g., LDAP server) on whose response the device uses to determine the routing destination.</p> <p>The valid value is 0 to 60. The default is 10.</p> <p>For more information, see <a href="#">Configuring a Routing Response Timeout</a> on page 1104.</p>

Parameter	Description
<p>'SBC GRUU Mode'</p> <pre>configure voip &gt; sbc settings &gt; sbc-gruu-mode</pre> <p>[SBCGruuMode]</p>	<p>Determines the Globally Routable User Agent (UA) URI (GRUU) support, according to RFC 5627.</p> <ul style="list-style-type: none"> <li>■ [0] <b>None</b> = No GRUU is supplied to users.</li> <li>■ [1] <b>As Proxy</b> = (Default) The device provides same GRUU types as the proxy provided the device's GRUU clients.</li> <li>■ [2] <b>Temporary only</b> = Supply only temporary GRUU to users. (Currently not supported.)</li> <li>■ [3] <b>Public only</b> = The device provides only public GRUU to users.</li> <li>■ [4] <b>Both</b> = The device provides temporary and public GRUU to users. (Currently not supported.)</li> </ul> <p>The parameter allows the device to act as a GRUU server for its SIP UA clients, providing them with public GRUU's, according to RFC 5627. The public GRUU provided to the client is denoted in the SIP Contact header parameters, "pub-gruu". Public GRUU remains the same over registration expirations. On the other SBC leg communicating with the Proxy/Registrar, the device acts as a GRUU client.</p> <p>The device creates a GRUU value for each of its registered clients, which is mapped to the GRUU value received from the Proxy server. In other words, the created GRUU value is only used between the device and its clients (endpoints).</p> <p>Public-GRUU:  sip:userA@domain.com;gr=unique-id</p>
<p>'BYE Authentication'</p> <pre>configure voip &gt; sbc settings &gt; sbc-bye-auth</pre> <p>[SBCEnableByeAuthentication]</p>	<p>Enables the device to authenticate a SIP BYE request before disconnecting the call. The device forwards the SIP authentication response (for the BYE request) to the request sender and waits for the user to authenticate</p>

Parameter	Description
	<p>it. The call is disconnected only if the authenticating server responds with a 200 OK. This feature prevents, for example, a scenario in which the SIP client receives a BYE request from a third-party imposer assuming the identity of a participant in the call. As a consequence, the call between the first and second parties is inappropriately disconnected.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul>
<p>'SUBSCRIBE Trying'</p> <pre>configure voip &gt; sbc settings &gt; sbc-subs-try [SBCSendTryingToSubscribe]</pre>	<p>Enables the device to send a SIP 100 Trying response upon receipt of a SUBSCRIBE or NOTIFY message.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul>
<pre>configure voip &gt; sbc settings &gt; sbc-100trying- upon-reinvite [SBC100TryingUponReinvite]</pre>	<p>Enables the device to send a SIP 100 Trying response upon receipt of a re-INVITE request.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable</li> <li>■ [1] = Enable</li> </ul>
<pre>configure voip &gt; sbc settings &gt; session-expires- observer-mode [SipSessionExpiresObserverMode]</pre>	<p>Defines the observer session expiry method when the IP Profile parameter, 'Session Expires Mode' is configured to <b>Observer</b> (see <a href="#">Configuring IP Profiles</a> on page 664).</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) With Grace Time. If the session is not refreshed on time according to the SIP Session-Expires header, the device adds a graceful session expiry time – 120 seconds if the client (UAC) was meant to do the refresh, or 60 seconds if the server (UAS) was meant to do the refresh. If the session is still not refreshed when this graceful time expires, the device disconnects the call (sends a SIP BYE).</li> <li>■ [1] = Strict. If the session is not refreshed</li> </ul>

Parameter	Description
	<p>on time according to RFC 4028 (Session-Expires header time minus the smaller of 32 or 1/3 of the time in Session-Expires header), the call is terminated. For example, if the Session-Expires header is 150 sec., the expected refresh should be done at <math>150 - 32 = 118</math> sec. (as 1/3 of 150 is 50, which is greater than 32). If no refresh is received within this time (e.g., 118 sec.), the device disconnects the call (sends a SIP BYE). Note that the minimum Session Expires is 90 sec.; any received value less than this is set to 90.</p>
<p>'BroadWorks Survivability Feature'</p> <pre>configure voip &gt; sbc settings &gt; sbc-broadworks- survivability</pre> <p>[SBCExtensionsProvisioningMode]</p>	<p>Enables SBC user registration for interoperability with BroadSoft's BroadWorks server, to provide call survivability in case of connectivity failure with the BroadWorks server.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared = (Default) Disabled - normal processing of REGISTER messages.</li> <li>■ [1] Check box selected = Enabled - registration method for BroadWorks server. In a failure scenario with BroadWorks, the device acts as a backup SIP proxy server, maintaining call continuity between the enterprise LAN users (subscribers) and between the subscribers and the PSTN (if provided).</li> </ul> <p><b>Note:</b> For a detailed description of this feature, see <a href="#">Enabling Auto-Provisioning of Subscriber-Specific Information of BroadWorks Server for Survivability</a> on page 1161.</p>
<p>'SBC Direct Media'</p> <pre>configure voip &gt; sip- interface &gt; sbc-direct- media</pre> <p>[SBCDirectMedia]</p>	<p>Enables the Direct Media feature (i.e., no Media Anchoring) for all SBC calls, whereby SIP signaling is handled by the device without handling the RTP/SRTP (media) flow between the user agents (UA). The RTP packets do not traverse the device. Instead, the two SIP UAs establish a direct RTP/SRTP flow between one another. Signaling continues to traverse the</p>

Parameter	Description
	<p>device with minimal intermediation and involvement to enable certain SBC abilities such as routing</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) All calls traverse the device (i.e., no direct media).</li> <li>■ [1] <b>Enable</b> = Direct media flow between endpoints for all SBC calls.</li> </ul> <p>For more information on direct media calls, see <a href="#">Direct Media Calls</a> on page 1033.</p>
<p>'SBC RTCP Mode'</p> <pre>configure voip &gt; sbc settings &gt; sbc-rtcp-mode</pre> <p>[SBCRTCPMode]</p>	<p>Global parameter that defines the handling of RTCP packets. You can also configure this feature per specific calls, using IP Profiles ('RTCP Mode' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b> If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</p>
<pre>configure voip &gt; sbc settings &gt; sbc-send-invite- to-all-contacts</pre> <p>[SBCSendInviteToAllContacts]</p>	<p>Enables call forking of INVITE message received with a Request-URI of a specific contact registered in the device's database, to all users under the same AOR as the contact.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) Sends the INVITE only to the contact of the received Request-URI.</li> <li>■ [1] <b>Enable</b></li> </ul> <p>To configure call forking initiated by the device, see <a href="#">Initiating SIP Call Forking</a> on page 1159.</p>
<p>'SBC Shared Line Registration Mode'</p> <pre>configure voip &gt; sbc settings &gt; sbc-shared-line- reg-mode</pre> <p>[SBCSharedLineRegMode]</p>	<p>Enables the termination on the device of SIP REGISTER messages from secondary lines that belong to the Shared Line feature.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> = (Default) Device forwards the REGISTER messages as is (i.e., not terminated on the device).</li> </ul>



Parameter	Description
	<ul style="list-style-type: none"> <li>■ [1] <b>Enable</b> = REGISTER messages of secondary lines are terminated on the device.</li> </ul> <p><b>Note:</b> The device always forwards REGISTER messages of the primary line.</p>
<p>'SBC Forking Handling Mode'</p> <pre>configure voip &gt; sbc settings &gt; sbc-forking- handling-mode</pre> <p>[SBCForkingHandlingMode]</p>	<p>Defines the handling of SIP 18x responses that are received due to call forking of an INVITE.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Latch On First</b> = (Default) Only the first 18x is forwarded to the INVITE-initiating UA. If SIP 18x with SDP is received, the device opens a voice stream according to the received SDP and disregards any subsequent 18x forking responses (with or without SDP). If the first response is 180 without SDP, the device sends it to the other side.</li> <li>■ [1] <b>Sequential</b> = All 18x responses are forwarded, one at a time (sequentially) to the INVITE-initiating UA. If a 18x arrives with an offer only, then only the first offer is forwarded to the INVITE-initiating UA and subsequent 18x responses are discarded.</li> </ul>
<p>'Gateway Direct Route Prefix'</p> <pre>configure voip &gt; sbc settings &gt; gw-direct-route- prefix</pre> <p>[GWDirectRoutePrefix]</p>	<p>Defines the prefix destination Request-URI user part that is appended to the original user part for alternative IP-to-IP call routing from SBC to Gateway (Tel) interfaces.</p> <p>The valid value is a string of up to 16 characters. The default is "acgateway-&lt;original prefix destination number&gt;". For example, "acgateway-200".</p> <p>For more information, see <a href="#">Configuring SBC IP-to-IP Routing Rules</a> on page 1076.</p>
<pre>configure voip &gt; sbc settings &gt; sbc-media-sync</pre> <p>[EnableSBCMediaSync]</p>	<p>Enables synchronization of media between two SIP user agents when a call is established between them. Media synchronization means that the media is properly negotiated (SDP offer/answer) between the user agents. In</p>

Parameter	Description
	<p>some scenarios, the call is established despite the media not being synchronized. This may occur, for example, in call transfer (SIP REFER) where the media between the transfer target and transferee are not synchronized. The device performs media synchronization by sending a re-INVITE immediately after the call is established in order for the user agents to negotiate the media (SDP offer/answer).</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable. Media synchronization is performed only if the RTP mode (e.g., a=sendrecv, a=sendrecv, a=sendonly, a=recvonly, and a=inactive) between the user agents are different and synchronization is required.</li> <li>■ [1] = Enable. Media synchronization is performed if the media, including RTP mode or any other media such as coders, is different and has not been negotiated between the user agents.</li> <li>■ [2] = Never. Media synchronization is never performed.</li> </ul>
<p>'Remove SIPs from Non-Secured Transport'</p> <pre>configure voip &gt; sbc settings &gt; sbc-remove-sips- non-sec-transp</pre> <p>[SBCRemoveSIPsFromNonSecuredTransport]</p>	<p>Defines the SIP headers for which the device replaces "sips:" with "sip:" in the outgoing SIP-initiating dialog request (e.g., INVITE) when the destination transport type is unsecured (e.g., UDP). (The "sips:" URI scheme indicates secured transport, for example, TLS.)</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. The device replaces "sips:" with "sip:" for the Request-URI and Contact headers only (and retains "sips:" for all other headers).</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled. The device replaces "sips:" with "sip:" for the Request-URI, Contact, From, To, P-Asserted, P-Preferred, and Route headers.</li> </ul>
<p>'SIP Topology Hiding Mode'</p> <pre>configure voip &gt; sbc</pre>	<p>Enables the device to overwrite the host part in SIP headers with IP addresses, unless the</p>

Parameter	Description
<pre>settings &gt; sip-topology- hiding-mode</pre> <p>[SIPTopologyHidingMode]</p>	<p>relevant host name parameters of the IP Group ('SIP Group Name' and 'SIP Source Host Name') are configured:</p> <ul style="list-style-type: none"> <li>■ Headers concerned with the source of the message are overwritten with the IP address of the IP Interface from where the device sends the message.</li> <li>■ Headers concerned with the destination of the message are overwritten with the destination IP address.</li> </ul> <p>The parameter can be configured to one of the following values:</p> <ul style="list-style-type: none"> <li>■ <b>[0] By Host Name Parameters Only</b> = (Default) The device overwrites the host part in the SIP headers according to the configuration of the IP Group's 'SIP Group Name' and 'SIP Source Host Name' parameters. If these parameters are empty, the device doesn't overwrite the host part of the headers.</li> <li>■ <b>[1] Fallback to IP Addresses</b> = This option is applicable only to dialog-initiating requests and in-dialog REFER requests. <ul style="list-style-type: none"> <li>✓ If the 'SIP Group Name' parameter of the destination IP Group is empty, the device overwrites the host part of the following destination-related SIP headers with the destination IP address: Request-URI and P-Called-Party-ID for all types of requests, and To header for non-REGISTER requests. If the 'SIP Group Name' parameter is configured, the device overwrites the host part in these headers with the configured value.</li> <li>✓ The source-related headers which are overwritten when the 'SIP Source Host Name' parameter is configured (From, P-Asserted-Identity, P-Preferred-</li> </ul> </li> </ul>

Parameter	Description
	<p>Identity, Referred-By, P-Charge-Info, Remote-Party-ID, P-Associated-URI, Diversion, and History-info) are always overwritten. If the 'SIP Source Host Name' parameter of the destination IP Group is configured, the device overwrites the host part with the configured value. If the 'SIP Source Host Name' parameter of the destination IP Group is empty, the device overwrites the host part of the mentioned headers with the IP address of the device's IP Interface from where it sends the message.</p> <p>For more information on the IP Group parameters 'SIP Group Name' and 'SIP Source Host Name', see <a href="#">Configuring IP Groups</a> on page 581.</p>
<p>'Enable MSRP'</p> <pre>configure voip &gt; sbc settings &gt; enable-msrp</pre> <p>[EnableMSRP]</p>	<p>Enables Message Session Relay Protocol (MSRP).</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>For more information, see <a href="#">Configuring Message Session Relay Protocol</a> on page 1141.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
<b>Push Notification Service</b>	
<pre>configure voip &gt; sbc settings &gt; pns-reminder- period</pre> <p>[PNSReminderPeriod]</p>	<p>Defines the time (in seconds) before the user's registration with the device expires, at which the device sends an HTTP message to the Push Notification Server to trigger it into sending a push notification to the user to remind the user to send a REGISTER refresh message to the device.</p> <p>The valid value range is 30 to 300. The default is 120.</p>

Parameter	Description
<pre>configure voip &gt; sbc settings &gt; pns-register- timeout</pre> <p>[PNSRegisterTimeout]</p>	<p>Defines the maximum time (in seconds) that the device waits for a SIP REGISTER refresh message from the user, before it forwards an incoming SIP dialog-initiating request (e.g., INVITE) to the user.</p> <p>The valid value range is 5 to 50. The default is 30.</p> <p>When the device receives an incoming SIP dialog-initiating request whose destination is the user, it sends an HTTP message to the Push Notification Server to trigger it into sending the user a push notification so that the user can send a REGISTER refresh message to the device. If the device receives the REGISTER refresh message within this timeout, it forwards the incoming SIP request to the user. If the timeout expires and the device still hasn't received the REGISTER refresh message, the device rejects the call.</p>

## Supplementary Services

The SBC and CRP supplementary services parameters are described in the table below.

**Table 69-64:SBC and CRP Supplementary Services Parameters**

Parameter	Description
<b>Emergency Call Preemption Parameters</b> For more information on SBC emergency call preemption, <a href="#">Configuring Call Preemption for SBC Emergency Calls</a> on page 1139.	
<b>'Preemption Mode'</b> <pre>configure voip &gt; sbc settings &gt; sbc- preemption-mode</pre> <p>[SBCPreemptionMode]</p>	<p>Enables emergency SBC call preemption.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul>
<b>'Emergency Message Condition'</b> <pre>configure voip &gt; sbc settings &gt; sbc-emerg- condition</pre> <p>[SBCEmergencyCondition]</p>	<p>Defines the index of the Message Condition rule in the Message Conditions table that is used to identify emergency calls.</p> <p><b>Note:</b> The device applies the rule only after call classification (but before inbound manipulation).</p>

Parameter	Description
'Emergency RTP DiffServ' configure voip > sbc settings > sbc-emerg- rtplib-diffserv [SBCEmergencyRTPLDiffServ]	Defines DiffServ bits sent in the RTP for SBC emergency calls.  The valid value is 0 to 63. The default is 46.
'Emergency Signaling DiffServ' configure voip > sbc settings > sbc-emerg- sig-diffserv [SBCEmergencySignalingDiffServ]	Defines DiffServ bits sent in SIP signaling messages for SBC emergency calls. This is included in the SIP Resource-Priority header.  The valid value is 0 to 63. The default is 40.

## IP Media Parameters

The IP media parameters are described in the table below.

**Table 69-65:IP Media Parameters**

Parameter	Description
'IPMedia Detectors' configure voip > media ipmedia > ipm-detectors-enable [EnableDSPIPMDetectors]	<p>Enables the device's DSP detectors for detection features such as AMD.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For the parameter to take effect, a device restart is required.</li> <li>■ The DSP Detectors feature is available only if the device is installed with a License Key that includes this feature. For installing a License Key, see <a href="#">License Key</a> on page 1233.</li> <li>■ When enabled, the number of available channels is reduced.</li> </ul>
configure voip > media ip- media-settings > http- streaming-playback-requests- timeout	Defines a timeout for no packets received (e.g., due to playback underruns) from the text-to-speech (TTS) service provider can now be configured.

Parameter	Description
[HttpStreamingPlaybackRequestsTimeout].	<b>Note:</b> The parameter is for AudioCodes <b>internal use only</b> and is applicable only when the device operates with AudioCodes VoiceAI Connect Enterprise.
<b>Automatic Gain Control (AGC) Parameters</b>	
'Enable AGC' configure voip > media ipmedia > agc-enable [EnableAGC]	<p>Global parameter enabling the AGC feature.</p> <p>You can also configure the feature per specific calls, using Tel Profiles ('Enable AGC' parameter). For a detailed description of the parameter and for configuring the feature in the Tel Profiles table, see <a href="#">Configuring Tel Profile</a> on page 738.</p> <p><b>Note:</b> If the feature is configured for a specific Tel Profile, the settings of the global parameter is ignored for calls associated with the Tel Profile.</p> <p>For a description of AGC, see <a href="#">Automatic Gain Control (AGC)</a> on page 311.</p>
'AGC Slope' configure voip > media ipmedia > agc-gain-slope [AGCGainSlope]	<p>Determines the AGC convergence rate:</p> <ul style="list-style-type: none"> <li>■ [0] <b>0</b> = 0.25 dB/sec</li> <li>■ [1] <b>1</b> = 0.50 dB/sec</li> <li>■ [2] <b>2</b> = 0.75 dB/sec</li> <li>■ [3] <b>3</b> = 1.00 dB/sec (default)</li> <li>■ [4] <b>4</b> = 1.25 dB/sec</li> <li>■ [5] <b>5</b> = 1.50 dB/sec</li> <li>■ [6] <b>6</b> = 1.75 dB/sec</li> <li>■ [7] <b>7</b> = 2.00 dB/sec</li> <li>■ [8] <b>8</b> = 2.50 dB/sec</li> <li>■ [9] <b>9</b> = 3.00 dB/sec</li> <li>■ [10] <b>10</b> = 3.50 dB/sec</li> <li>■ [11] <b>11</b> = 4.00 dB/sec</li> <li>■ [12] <b>12</b> = 4.50 dB/sec</li> </ul>

Parameter	Description
	<ul style="list-style-type: none"> <li>■ [13] <b>13</b> = 5.00 dB/sec</li> <li>■ [14] <b>14</b> = 5.50 dB/sec</li> <li>■ [15] <b>15</b> = 6.00 dB/sec</li> <li>■ [16] <b>16</b> = 7.00 dB/sec</li> <li>■ [17] <b>17</b> = 8.00 dB/sec</li> <li>■ [18] <b>18</b> = 9.00 dB/sec</li> <li>■ [19] <b>19</b> = 10.00 dB/sec</li> <li>■ [20] <b>20</b> = 11.00 dB/sec</li> <li>■ [21] <b>21</b> = 12.00 dB/sec</li> <li>■ [22] <b>22</b> = 13.00 dB/sec</li> <li>■ [23] <b>23</b> = 14.00 dB/sec</li> <li>■ [24] <b>24</b> = 15.00 dB/sec</li> <li>■ [25] <b>25</b> = 20.00 dB/sec</li> <li>■ [26] <b>26</b> = 25.00 dB/sec</li> <li>■ [27] <b>27</b> = 30.00 dB/sec</li> <li>■ [28] <b>28</b> = 35.00 dB/sec</li> <li>■ [29] <b>29</b> = 40.00 dB/sec</li> <li>■ [30] <b>30</b> = 50.00 dB/sec</li> <li>■ [31] <b>31</b> = 70.00 dB/sec</li> </ul>
<b>'AGC Redirection'</b> configure voip > media ipmedia > agc-redirection [AGCRedirection]	Determines the AGC direction. <ul style="list-style-type: none"> <li>■ [0] <b>0</b> = (Default) AGC works on signals from the TDM side.</li> <li>■ [1] <b>1</b> = AGC works on signals from the IP side.</li> </ul>
<b>'AGC Target Energy'</b> configure voip > media ipmedia > agc-target-energy [AGCTargetEnergy]	Defines the signal energy value (dBm) that the AGC attempts to attain. The valid range is 0 to -63 dBm. The default is -19 dBm.
<b>'AGC Minimum Gain'</b> configure voip > media ipmedia > agc-min-gain	Defines the minimum gain (in dB) by the AGC when activated. The range is 0 to -31. The default is -20.



Parameter	Description
[AGCMinGain]	<b>Note:</b> For the parameter to take effect, a device restart is required.
AGC Maximum Gain configure voip > media ipmedia > agc-max-gain [AGCMaxGain]	Defines the maximum gain (in dB) by the AGC when activated. The range is 0 to 18. The default is 15. <b>Note:</b> For the parameter to take effect, a device restart is required.
'AGC Disable Fast Adaptation' configure voip > media ipmedia > agc-disable-fast-adaptation [AGCDisableFastAdaptation]	Enables the AGC Fast Adaptation mode.  ■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.  ■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.  <b>Note:</b> For the parameter to take effect, a device restart is required.
<b>Answer Detector (AD) Parameters</b> For more information on AD, see <a href="#">Configuring the Answer Detector Feature</a> on page 310.	
'Enable Answer Detector' configure voip > media ipmedia > answer-detector-enable [EnableAnswerDetector]	Enables the device's Answer Detector feature.  ■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.  ■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.
'Answer Detector Activity Delay' configure voip > media ipmedia > answer-detector-activativity-delay [AnswerDetectorActivityDelay]	Defines the time (in 100-msec resolution) between when the device activates the Answer Detector and when it actually starts to detect. The valid range is 0 to 1023. The default is 0.
'Answer Detector Silence Time' configure voip > media ipmedia > answer-detector-silence-time [AnswerDetectorSilenceTime]	Defines the duration of silence (in 100-msec resolution) from when no speech input is detected by the Answer Detector until the device sends an End Of Speech event. The valid range is 0 to 1023. The default is 10.
'Answer Detector Redirection'	Enables the Answer Detector to apply to

Parameter	Description
<pre>configure voip &gt; media ipmedia &gt; answer-detector-redirect</pre> [AnswerDetectorRedirection]	<p>the IP network side instead of the PSTN side.</p> <ul style="list-style-type: none"> <li>■ [0] <b>No</b> = (Default) PSTN.</li> <li>■ [1] <b>Yes</b> = IP network.</li> </ul>
<p>'Answer Detector Sensitivity'</p> <pre>configure voip &gt; media ipmedia &gt; answer-detector-sensitivity</pre> [AnswerDetectorSensitivity]	<p>Defines the Answer Detector sensitivity. The range is 0 (most sensitive) to 7 (least sensitive). The default is 0.</p>
<pre>configure voip &gt; media ipmedia &gt; answer-detector-low-energy-sensitivity</pre> [AnswerDetectorLowEnergySensitivity]	<p>Enables low-energy sensitivity for the Answer Detector. This allows the Answer Detector to be more sensitive to signaling tones (e.g., Call Progress tones and DTMFs), thereby avoiding false detections of signaling tones as voice.</p> <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable.</li> <li>■ [1] = Enable.</li> </ul>
<p><b>Answering Machine Detector (AMD) Parameters</b></p> <p>For more information on AMD, see <a href="#">Answering Machine Detection (AMD)</a> on page 304.</p>	
<p>'Answer Machine Detector Sensitivity Parameter Suite'</p> <pre>configure voip &gt; media ipmedia &gt; amd-sensitivity-parameter-suite</pre> [AMDSensitivityParameterSuit]	<p>Global parameter that defines which AMD Parameter Suite to use.</p> <p>Each Parameter Suite contains a table with sensitivity levels. Some Parameter Suites are more sensitive to live voice while others are more sensitive to answering machines. The available Parameter Suites depends on the installed AMD Sensitivity file. The default, pre-installed AMD Sensitivity file, which is based on North American English, includes two Parameter Suites:</p> <ul style="list-style-type: none"> <li>■ <b>Parameter Suite #0:</b> Provides normal sensitivity and has 8 sensitivity levels (0-8). (See note below.)</li> <li>■ <b>Parameter Suite #1:</b> Provides high sensitivity and has 16 sensitivity levels (0-15).</li> </ul>

Parameter	Description
	<p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ If you configure the [AMDDetectionSensitivity] parameter to 3 (default), the device ignores the Parameter Suite #0 sensitivity table. In this case, the [AMDSensitivityLevel] parameter is not relevant and sensitivity is hard-coded and similar to sensitivity level 3 of Parameter Suite 0. If you configure the [AMDDetectionSensitivity] parameter to any value other than 3, use the [AMDSensitivityLevel] parameter to specify the sensitivity level of Parameter Suite 0.</li> <li>■ You can also configure this feature per specific calls using IP Profiles ('AMD Sensitivity Parameter Suite' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664. If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</li> </ul>
<p>'Answer Machine Detector Sensitivity Level'</p> <pre>configure voip &gt; media ipmedia &gt; amd-sensitivity-level [AMDSensitivityLevel]</pre>	<p>Global parameter that defines the sensitivity level of the selected Parameter Suite (see 'Answer Machine Detector Sensitivity Parameter Suite' above) for detecting live voice over answering machine (tradeoff between them).</p> <p>A lower sensitivity level favors detection of answering machines while a higher level favors detection of live voice. For sensitivity levels and their tradeoff between live voice and answering machine detection, see the tables in <a href="#">Answering Machine Detection (AMD)</a> on page 304.</p> <p>You can also configure this feature per</p>

Parameter	Description
	<p>specific calls, using IP Profiles ('AMD Sensitivity Level' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ This parameter is applicable to all Parameter Suites other than 0. For Parameter Suite 0, use the [AMDDetectionSensitivity] parameter.</li> <li>■ If you configure the parameter for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</li> </ul>
'Answer Machine Detector Sensitivity' [AMDDetectionSensitivity]	<p>Defines the sensitivity level of the device's core voice answer detector (VAD) that is used by the AMD algorithm to distinguish between voice and silence.</p> <p>The valid value range is 0 to 7. The default is 3.</p> <p>A lower value increases sensitivity, allowing detection of low-level speech parts, but may also lead to more false detections due to background noise. Conversely, a higher value decreases sensitivity and reduces the likelihood of false detections caused by background noise but may cause quieter speech parts to go undetected.</p> <p><b>Note:</b> It's recommended to keep the parameter at its default (unless your deployment requires a specific adjustment).</p>
'AMD Sensitivity File' [AMDSensitivityFileName]	<p>Defines the name of the installed AMD Sensitivity file, which contains the AMD Parameter Suites.</p> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ This file must be in binary format</li> </ul>

Parameter	Description
	<p>(.dat). You can use the DConvert utility to convert the original file format from XML to .dat.</p> <ul style="list-style-type: none"> <li>■ To install this file through the Web interface, see <a href="#">Uploading Auxiliary Files</a> on page 1220.</li> </ul>
[AMDSensitivityFileUrl]	Defines the URL path to the AMD Sensitivity file for downloading from a remote server for the Automatic Update mechanism.
[AMDMinimumVoiceLength]	<p>Defines the AMD minimum voice activity detection duration (in 5-ms units). Voice activity duration below this threshold is ignored and considered as non-voice.</p> <p>The valid value range is 10 to 100. The default is 42 (i.e., 210 ms).</p>
[AMDMaxGreetingTime]	<p>Global parameter that defines the maximum duration that the device can take to detect a greeting message.</p> <p>You can also configure this feature per specific calls, using IP Profiles ('AMD Max Greeting Time' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b> If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</p>
[AMDMaxPostGreetingSilenceTime]	<p>Global parameter that defines the maximum duration of silence from after the greeting time is over, configured by [AMDMaxGreetingTime], until the device's AMD decision.</p> <p>You can also configure this feature per specific calls, using IP Profiles ('AMD Max Post Silence Greeting Time' parameter).</p>

Parameter	Description
	<p>For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664.</p> <p><b>Note:</b> If you configure this feature for a specific IP Profile, the device ignores this global parameter for calls associated with the IP Profile.</p>
<pre>configure voip &gt; gateway digital settings &gt; amd-timeout</pre> <p>[AMDDTimeout]</p>	<p>Defines the timeout (in msec) between receiving Connect messages from the Tel side and sending AMD results.</p> <p>The valid range is 1 to 30,000. The default is 2,000 (i.e., 2 seconds).</p>
<p>'AMD Beep Detection Mode'</p> <pre>configure voip &gt; sip-definition settings &gt; amd-beep-detection</pre> <p>[AMDBeepDetectionMode]</p>	<p>Enables the AMD beep detection mode. This mode detects the beeps played at the end of an answering machine greeting message, by using the X-Detect header extension. The device sends a SIP INFO message containing the field values 'Type=AMD' and 'SubType=Beep'. This feature allows users of certain third-party Application servers to leave a voice message after an answering machine plays the “beep”.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disabled</b> (default)</li> <li>■ [1] <b>Start After AMD</b></li> <li>■ [2] <b>Start Immediately</b></li> </ul> <p><b>Note:</b> It's recommended to configure the parameter to <b>Start After AMD</b> because it reduces the probability of a false beep detection caused by voice that may have parts that sound similar to a beep.</p>
<p>'Answer Machine Detector Beep Detection Timeout'</p> <pre>configure voip &gt; media ipmedia &gt; amd-beep-detection-timeout</pre> <p>[AMDBeepDetectionTimeout]</p>	<p>Defines the AMD beep detection timeout (i.e., the duration that the beep detector functions from when detection is initiated). This is used for detecting beeps at the end of an answering machine message.</p>

Parameter	Description
	The valid value is in units of 100 milliseconds, from 0 to 1638. The default is 200 (i.e., 20 seconds).
<b>'Answer Machine Detector Beep Detection Sensitivity'</b> configure voip > media ipmedia > amd-beep-detection-sensitivity <b>[AMDBeepDetectionSensitivity]</b>	Defines the AMD beep detection sensitivity for detecting beeps at the end of an answering machine message. The valid value is 0 to 3, where 0 (default) is the least sensitive.
configure voip > gateway digital settings > early-amd <b>[EnableEarlyAMD]</b>	Enables AMD detection to be activated upon receipt of an ISDN Alerting or Connect message. <ul style="list-style-type: none"> <li>■ [0] = (Default) Disable - AMD is activated upon receipt of ISDN Connect message.</li> <li>■ [1] = Enable - AMD is activated upon receipt of ISDN Alerting message.</li> </ul>
<b>'AMD Mode'</b> configure voip > sip-definition settings > amd-mode <b>[AMDmode]</b>	Global parameter that enables the device to disconnect the call (IP-to-Tel for the Gateway application) upon detection of an answering machine (on the Tel side for the Gateway application). For more information on the Gateway implementation, see <a href="#">Enabling IP-to-Tel Call Disconnection upon Detection of Answering Machine</a> on page 310. For the SBC application: The parameter is typically used when the device is deployed with VoiceAI Connect. For the Gateway application, you can also configure this feature per specific calls, using IP Profiles ('AMD Mode' parameter). For a detailed description of the parameter and for configuring this feature in the IP Profiles table, see <a href="#">Configuring IP Profiles</a> on page 664. <b>Note:</b> For the Gateway application, if you configure this feature for a specific IP Profile, the device ignores this global

Parameter	Description
	parameter for calls associated with the IP Profile.
<b>Energy Detector Parameters</b>	
'Enable Energy Detector' <pre>configure voip &gt; media ipmedia &gt; energy-detector-enable</pre> [EnableEnergyDetector]	Enables the Energy Detector feature. This feature generates events (notifications) when the signal received from the PSTN is higher or lower than a user-defined threshold, configured by the [EnergyDetectorThreshold] parameter.  ■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.  ■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.
'Energy Detector Quality Factor' <pre>configure voip &gt; media ipmedia &gt; energy-detector-sensitivity</pre> [EnergyDetectorQualityFactor]	Defines the Energy Detector's sensitivity level.  The valid range is 0 to 10, where 0 is the lowest sensitivity and 10 the highest sensitivity. The default is 4.
'Energy Detector Threshold' <pre>configure voip &gt; media ipmedia &gt; energy-detector-threshold</pre> [EnergyDetectorThreshold]	Defines the Energy Detector's threshold. A signal below or above this threshold invokes an 'Above' or 'Below' event.  The threshold is calculated as follows: $-44 \text{ dBm} + (\text{EnergyDetectorThreshold} * 6)$ The valid value range is 0 to 7. The default is 3 (i.e., -26 dBm).
<b>Pattern Detection Parameters</b> <b>Note:</b> For an overview on the pattern detector feature for TDM tunneling, see <a href="#">DSP Pattern Detector</a> on page 887.	
'Enable Pattern Detector' [EnablePatternDetector]	Enables the Pattern Detector (PD) feature.  ■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.  ■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.
[PDPattern]	Defines the patterns that can be detected by the Pattern Detector.  The valid range is 0 to 0xFF.



Parameter	Description
	<b>Note:</b> For the parameter to take effect, a device restart is required.
[PDThreshold]	<p>Defines the number of consecutive patterns to trigger the pattern detection event.</p> <p>The valid range is 0 to 31. The default is 5.</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>

## Services

This section describes services-related parameters.

### SIPREC Parameters

The SIPREC parameters are described in the table below.

**Table 69-66:SIPREC Parameters**

Parameter	Description
<p>'Forward Signaling to SIPREC'</p> <pre>configure voip &gt; sip- definition sip- recording settings &gt; fwd-signaling-to- siprec</pre> <p>[FwdSignalingToSIPRec]</p>	<p>Enables the device to send DTMF digits notifications using SIP INFO messages to the SIPREC SRS.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>DTMF SIP INFO</b></li> </ul> <p>For more information, see <a href="#">Sending DTMF Digits Notifications using SIP INFO Messages to SRS</a> on page 355.</p>
<p>'Recording Server (SRS) Destination Username'</p> <pre>configure voip &gt; sip- definition sip- recording settings &gt; siprec-server-dest- username</pre> <p>[SIPRecServerDestUsername]</p>	<p>Defines the SIP user part for the recording server. This user part is added in the SIP To header of the INVITE message that the device sends to the recording server.</p> <p>The valid value is a string of up to 50 characters. By default, no user part is defined.</p>
<p>'SIP Recording Metadata Format'</p> <pre>configure voip &gt; sip- definition sip-</pre>	<p>Defines the format of the SIPREC recording metadata that the device generates in SIP messages sent to the SRS.</p>

Parameter	Description
<pre>recording settings &gt; siprec-metadata-format</pre> <p>[SIPRecMetadataFormat]</p>	<ul style="list-style-type: none"> <li>■ [0] <b>Legacy</b> = (Default) The device generates the recording metadata in a "legacy" format, whereby the user part of the participant URI (source or destination) is used as the ID.</li> <li>■ [1] <b>RFC 7865</b> = The device generates the recording metadata in a format according to RFC 7865, whereby all IDs (e.g., participant ID) are in Base64 format. This metadata format also includes additional XML tags with association information (e.g., "&lt;participantsessionassoc&gt;").</li> </ul>
<p>'SIP Recording Time Stamp Format'</p> <pre>configure voip &gt; sip- definition sip- recording settings &gt; siprec-time-stamp</pre> <p>[SIPRecTimeStamp]</p>	<p>Defines the format of the device's time (timestamp) in SIP messages that are sent to the SIP Recording Server (SRS).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Local Time</b> = (Default) The device's local time (without the UTC time zone) is used for the timestamp.</li> <li>■ [1] <b>UTC</b> = The device's UTC time is used for the timestamp.</li> </ul> <p><b>Note:</b> The timestamp is contained in the XML body of the SIP message. If the timestamp uses the UTC time, the time is suffixed with the letter "Z", for example:</p> <pre>&lt;associate-time&gt;2017-09- 07T06:33:38Z&lt;/associate-time&gt;</pre>
<p>'Video Recording Sync Timeout'</p> <pre>configure voip &gt; sip- definition sip- recording settings &gt; video-rec-sync-timeout</pre> <p>[VideoRecordingSyncTimeout]</p>	<p>Defines the video synchronization timeout (in msec), which is applicable when the device also records the video stream of audio-video calls for SIPREC. If the SIP 200 OK from the SRS is not received within this timeout, the device connects the video stream between the UAs (instead of waiting for the 200 OK). The valid value is 100 to 5,000. The default is 2,000.</p>

## RADIUS and LDAP Parameters

This section describes the RADIUS and LDAP parameters.

### General Parameters

The general RADIUS and LDAP parameters are described in the table below.

**Table 69-67:General RADIUS and LDAP Parameters**

Parameter	Description
<p>'Use Local Users Table for Authentication'</p> <pre>configure system &gt; mgmt-auth &gt; use-local- users-db</pre> <p>[MgmtUseLocalUsersDatabase]</p>	<p>Defines when and if the device uses the Local Users table when an Authentication server (LDAP or RADIUS) is used for authenticating users attempting to log into the device's management interfaces (e.g., Web or CLI).</p> <ul style="list-style-type: none"> <li>■ [0] <b>When No Auth Server Defined</b> = (Default) If you haven't configured an Authentication server, the device uses the Local Users table (see <a href="#">Configuring Local Management User Accounts</a> on page 54) to authenticate the user.</li> </ul> <p>If you have configured an Authentication server, the device uses the server to authenticate the user.</p> <ul style="list-style-type: none"> <li>✓ If the user is not found in the server, the device denies access (i.e., doesn't fallback to Local Users table).</li> <li>✓ If there is no response from the server (connectivity timeout), the device either denies the user access or authenticates the user using the Local Users table (according to the 'Behavior upon Authentication Server Timeout' parameter).</li> </ul> <ul style="list-style-type: none"> <li>■ [1] <b>Always</b> = The device uses the Authentication server to authenticate the user.</li> </ul> <ul style="list-style-type: none"> <li>✓ If the user is not found in the server, the device uses the Local Users table to authenticate the user.</li> <li>✓ If there is no response from the server (connectivity timeout), the device either denies the user access or authenticates the user using the Local Users table (according to the 'Behavior upon Authentication Server Timeout' parameter).</li> </ul> <ul style="list-style-type: none"> <li>■ [2] <b>Always Before Auth Server</b> = The device uses the Local Users table to authenticate the user. If authentication fails, the device uses the Authentication server.</li> </ul>

Parameter	Description
	<p><b>Note:</b>If you haven't configured an Authentication server, the device always uses the Local Users table to authenticate the user.</p>
<p>'Behavior upon Authentication Server Timeout'</p> <pre>configure system &gt; mgmt-auth &gt; timeout-behavior</pre> <p>[MgmtBehaviorOnTimeout]</p>	<p>Defines the device's behavior when a connection timeout occurs with the LDAP/RADIUS Authentication server that is used for user login authentication.</p> <ul style="list-style-type: none"> <li>■ [0] <b>Deny Access</b> = The device denies user access to its management interface.</li> <li>■ [1] <b>Verify Access Locally</b> = (Default) The device authenticates the user using its Local Users table.</li> </ul> <p><b>Note:</b> The parameter is applicable to LDAP- and RADIUS-based user login authentication.</p>
<p>'Default Access Level'</p> <pre>configure system &gt; mgmt-auth &gt; default-access-level</pre> <p>[DefaultAccessLevel]</p>	<p>Defines the default access level for the device when the LDAP/RADIUS response doesn't include an access level attribute for determining the user's management access level.</p> <ul style="list-style-type: none"> <li>■ [1] <b>No Access</b> = The device blocks these users.</li> <li>■ [50] <b>Monitor</b></li> <li>■ [100] <b>Administrator</b></li> <li>■ [200] <b>Security Administrator</b> (Default)</li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ The parameter is applicable to LDAP- and RADIUS-based management-user login authentication and authorization.</li> <li>■ If a user is not associated with any LDAP Group (at the LDAP server), the device automatically uses the value of this parameter as the access level.</li> </ul>

## RADIUS Parameters

The RADIUS parameters are described in the table below.

**Table 69-68:RADIUS Parameters**

Parameter	Description
<b>General RADIUS Parameters</b>	

Parameter	Description
'Enable RADIUS Access Control' configure system > radius settings > enable [EnableRADIUS]	Enables the RADIUS application. <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <b>Note:</b> For the parameter to take effect, a device restart is required.
'RADIUS VSA Vendor ID' configure system > radius settings > vsa- vendor-id [RadiusVSAVendorID]	Defines the vendor ID that the device accepts when parsing a RADIUS response packet. The valid range is 0 to 0x7FFFFFFF. The default is 5003.
[MaxRADIUSSessions]	Defines the number of concurrent calls that can communicate with the RADIUS server (optional). The valid range is 0 to 240. The default is 240.
'RADIUS Packets Retransmission' [RADIUSRetransmission]	Defines the number of RADIUS retransmission retries when no response is received from the RADIUS server. See also the [RadiusTo] parameter. The valid range is 1 to 10. The default is 1.
'RADIUS Response Time Out' [RadiusTo]	Defines the time interval (in seconds) that the device waits for a response before it performs a RADIUS retransmission. See also the [RADIUSRetransmission] parameter. The valid range is 1 to 30. The default is 2.
configure system > radius settings > rad- pap-req-msg-auth-tx [RadiusPapRequireMsgAuthTx]	Enables the device (for PAP protocol used for user login) to always include RADIUS attribute 80 (Message-Authenticator) in outgoing RADIUS request messages (Access-Request packets) sent to the RADIUS server. <ul style="list-style-type: none"> <li>■ [0] = (Default) The device doesn't include the attribute.</li> <li>■ [1] = The device includes the attribute.</li> </ul> For more information, see <a href="#">Securing RADIUS Messages with Message-Authenticator Attribute</a> on page 365.
configure system > radius settings > rad- req-msg-auth-rx	Enables the requirement of RADIUS attribute 80 (Message-Authenticator) in incoming RADIUS messages from the RADIUS server.

Parameter	Description
[RadiusRequireMsgAuthRx]	<ul style="list-style-type: none"> <li>■ [0] = (Default) The device doesn't require the attribute.</li> <li>■ [1] = The device requires the attribute. If the attribute is not present, the device discards the incoming RADIUS message and denies user login.</li> </ul> <p>For more information, see <a href="#">Securing RADIUS Messages with Message-Authenticator Attribute</a> on page 365.</p>
<b>RADIUS Accounting Parameters</b>	
'RADIUS Accounting Type' configure voip > sip-definition settings > radius-accounting [RADIUSAccountingType]	Defines at what stage of the call RADIUS accounting messages are sent to the RADIUS accounting server. <ul style="list-style-type: none"> <li>■ [0] <b>At Call Release</b> = (Default) Sent at call release only.</li> <li>■ [1] <b>At Connect &amp; Release</b> = Sent at call connect and release.</li> <li>■ [2] <b>At Setup &amp; Release</b> = Sent at call setup and release.</li> </ul>
'AAA Indications' configure system > cdr > aaa-indications [AAAIndications]	Enables the Authentication, Authorization and Accounting (AAA) indications. <ul style="list-style-type: none"> <li>■ [0] <b>None</b> = (Default) No indications.</li> <li>■ [3] <b>Accounting Only</b> = Only accounting indications are used.</li> </ul>
<b>RADIUS User Authentication Parameters</b>	
'Use RADIUS for Web/Telnet Login' configure system > radius settings > enable-mgmt-login [WebRADIUSLogin]	Enables RADIUS queries for Web and Telnet login authentication. When enabled, logging into the device's Web and Telnet embedded servers is done through a RADIUS server. The device communicates with a user-defined RADIUS server and verifies the given username and password against a remote database in a secure manner. <ul style="list-style-type: none"> <li>■ [0] <b>Disable</b> (default)</li> <li>■ [1] <b>Enable</b></li> </ul> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>■ For RADIUS login authentication to function, you must also configure the [EnableRADIUS]</li> </ul>

Parameter	Description
	<p>parameter to 1 (Enable).</p> <ul style="list-style-type: none"> <li>■ RADIUS authentication requires HTTP basic authentication, where the username and password are transmitted in clear text over the network. Therefore, it's recommended to set the [HTTPOnly] parameter to 1 to force the use of HTTPS, since the transport is encrypted.</li> </ul>
<p>'Password Local Cache Mode'</p> <pre>configure system &gt; radius settings &gt; local-cache-mode</pre> <p>[RadiusLocalCacheMode]</p>	<p>Defines the device's mode of operation regarding the timer, configured by the [RadiusLocalCacheTimeout] parameter, which determines the validity of the username and password (verified by the RADIUS server).</p> <ul style="list-style-type: none"> <li>■ [0] <b>Absolute Expiry Timer</b> = When you access a Web page, the timeout doesn't reset, instead it continues decreasing.</li> <li>■ [1] <b>Reset Timer Upon Access</b> = (Default) Upon each access to a Web page, the timeout always resets (reverts to the initial value configured by the [RadiusLocalCacheTimeout] parameter).</li> </ul>
<p>'Password Local Cache Timeout'</p> <pre>configure system &gt; radius settings &gt; local-cache-timeout</pre> <p>[RadiusLocalCacheTimeout]</p>	<p>Defines the duration (in seconds) that the locally stored username and password (verified by the RADIUS server) are valid. When this timeout expires, the username and password become invalid and must be re-verified with the RADIUS server.</p> <p>The valid range is 1 to 0xFFFFFFFF. The default is 900 (15 minutes).</p> <ul style="list-style-type: none"> <li>■ [-1] = Never expires.</li> <li>■ [0] = Each request requires RADIUS authentication.</li> </ul>
<p>'RADIUS VSA Access Level Attribute'</p> <pre>configure system &gt; radius settings &gt; vsa- access-level</pre> <p>[RadiusVSAAccessAttribute]</p>	<p>Defines the code that indicates the access level attribute in the Vendor Specific Attributes (VSA) section of the received RADIUS packet.</p> <p>The valid range is 0 to 255. The default is 35.</p>

## LDAP Parameters

The Lightweight Directory Access Protocol (LDAP) parameters are described in the table below.

Table 69-69:LDAP Parameters

Parameter	Description
'LDAP Service' <pre>configure system &gt; ldap settings &gt; ldap-service</pre> [LDAPServiceEnable]	<p>Enables the LDAP feature.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
'LDAP Authentication Filter' <pre>configure system &gt; ldap settings &gt; auth-filter</pre> [LDAPAuthFilter]	<p>Defines the LDAP search filter attribute for searching the login username in the directory's subtree for LDAP-based user authentication and authorization.</p> <p>You must use the dollar (\$) sign to represent the username. For example, if you configure the parameter to "(sAMAccountName=*)" and the user logs in with the username "SueM", the LDAP query is run for sAMAccountName=SueM.</p> <p><b>Note:</b> The number of characters of the parameter's value plus the length of the login username can't exceed 255. If the length exceeds this maximum, the device sends an error message to syslog.</p>
'Use LDAP for Web/Telnet Login' <pre>configure system &gt; ldap settings &gt; enable-mgmt- login</pre> [MgmtLDAPLogin]	<p>Enables LDAP-based management-user login authentication and authorization.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
[LDAPDebugMode]	<p>Enables debug messages for LDAP tasks and defines the debug level.</p> <p>The valid value range is 0 to 4. The default is 0 (i.e., disabled). The higher the value, the more detailed the information provided.</p>
'LDAP Numeric Attributes' ldap-numeric-attr	<p>Defines up to five LDAP Attributes (separated by commas) for which the device uses for LDAP</p>



Parameter	Description
[LDAPNumericAttributes]	query searches in the AD for numbers that may have characters between the digits.  For more information, see <a href="#">Enabling LDAP Searches for Numbers with Characters</a> on page 396.
'LDAP OCS Number Attribute Name' configure voip > sip- definition settings > ldap- ocs-nm-attr [MSLDAPOCSTNumAttributeName]	Defines the name of the attribute that represents the user's Skype for Business number in the Microsoft AD database.  The valid value is a string of up to 49 characters. The default is "msRTCSIP-Line".
LDAP PBX Number Attribute Name configure voip > sip- definition settings > ldap- pbx-nm-attr [MSLDAPPBXNumAttributeName]	Defines the name of the attribute that represents the user PBX number in the Microsoft AD database.  The valid value is a string of up to 49 characters. The default is "telephoneNumber".
LDAP MOBILE Number Attribute Name configure voip > sip- definition settings > ldap- mobile-nm-attr [MSLDAPMobileNumAttributeName]	Defines the name of the attribute that represents the user Mobile number in the Microsoft AD database.  The valid value is a string of up to 49 characters. The default is "mobile".
LDAP PRIVATE Number Attribute Name configure voip > sip- definition settings > ldap- private-nm-attr [MSLDAPPrivateNumAttributeName]	Defines the name of the attribute that represents the user's private number in the AD. If this value equals the value of the MSLDAPPrimaryKey or MSLDAPSecondaryKey parameter, then the device queries the AD for the destination number in this private attribute name; otherwise, the parameter is not used as a search key.  The default is "msRTCSIP-PrivateLine".
'LDAP DISPLAY Name Attribute Name' configure voip > sip- definition settings > ldap- display-nm-attr [MSLDAPDisplayNameAttributeName]	Defines the attribute name that represents the Calling Name in the AD for LDAP queries based on calling number.  The valid value is a string of up to 49 characters. The default is "displayName".
LDAP Primary Key configure voip > sip-	Defines the name of the attribute used as a query search key for the destination number in

Parameter	Description
<pre>definition settings &gt; ldap- primary-key</pre> <p>[MSLDAPPrimaryKey]</p>	<p>the AD. This is used instead of the "PBX" attribute name (configured by the MSLDAPPBXNumAttributeName parameter). The default is not configured.</p>
<p>LDAP Secondary Key</p> <pre>configure voip &gt; sip- definition settings &gt; ldap- secondary-key</pre> <p>[MSLDAPSecondaryKey]</p>	<p>Defines the name of the attribute used as the second query search key for the destination number in the AD, if the primary search key or PBX search is not found.</p>
<p>'LDAP Cache Service'</p> <pre>configure system &gt; ldap settings &gt; ldap-cache- enable</pre> <p>[LDAPCacheEnable]</p>	<p>Enables the LDAP cache service.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>For more information on LDAP caching, see .</p> <p><b>Note:</b> For the parameter to take effect, a device restart is required.</p>
<p>'LDAP Cache Entry Timeout'</p> <pre>configure system &gt; ldap settings &gt; entry-timeout</pre> <p>[LDAPCacheEntryTimeout]</p>	<p>Defines the duration (in minutes) that an entry in the device's LDAP cache is valid. If the timeout expires, the cached entry is used only if there is no connectivity with the LDAP server. The valid range is 0 to 35791. The default is 1200. If 0, the LDAP entry is always valid. For more information on LDAP caching, see <a href="#">Configuring the Device's LDAP Cache</a> on page 387.</p>
<p>'LDAP Cache Entry Removal Timeout'</p> <pre>configure system &gt; ldap settings &gt; entry-removal- timeout</pre> <p>[LDAPCacheEntryRemovalTimeout]</p>	<p>Defines the duration (in hours) after which the LDAP entry is deleted from the device's LDAP cache. The valid range is 0 to 596. The default is 0 (i.e., the entry is never deleted). For more information on LDAP caching, see <a href="#">Configuring the Device's LDAP Cache</a> on page 387.</p>

## HTTP-based Services

The HTTP-based service parameters are described in the table below.

**Table 69-70:HTTP-based Service Parameters**

Parameter	Description
<p>'Gateway Routing Server'</p> <pre>configure voip &gt; gw routing general-setting &gt; gw-routing- server</pre> <p>[GWRoutingServer]</p>	<p>Enables routing by ARM.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared = (Default) Disable.</li> <li>■ [1] Check box selected = Enabled.</li> </ul> <p>For more information on routing by ARM, see <a href="#">Centralized Routing by ARM (AudioCodes Routing Manager)</a> on page 442.</p> <p><b>Note:</b> The parameter is applicable only to the Gateway application.</p>
<p>'Quality Status'</p> <pre>configure system &gt; http- services &gt; routing-qos-status</pre> <p>[RoutingServerQualityStatus]</p>	<p>Enables QoS-based routing by ARM. The device collects QoS metrics (media and signaling) and sends them to ARM.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>For more information, see <a href="#">Configuring QoS-based Routing by ARM</a> on page 446.</p>
<p>'Quality Status Rate'</p> <pre>configure system &gt; http- services &gt; routing-qos- status-rate</pre> <p>[RoutingServerQualityStatusRate]</p>	<p>Defines the rate (in sec) at which the device sends QoS reports to ARM.</p> <p>The valid range is 15-3600. The default is 60.</p> <p>For more information, see <a href="#">Configuring QoS-based Routing by ARM</a> on page 446.</p>
<p>'Topology Status'</p> <pre>configure system &gt; http- services &gt; routing-server- group-status</pre> <p>[RoutingServerGroupStatus]</p>	<p>Enables the reporting of the device's topology status (using the REST TopologyStatus API command) to remote HTTP hosts.</p> <ul style="list-style-type: none"> <li>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</li> <li>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</li> </ul> <p>For more information, see <a href="#">Configuring Remote Web Services</a> on page 429</p>
<p>'Routing Server Registration Status'</p> <pre>configure system &gt; http- services &gt; routing-server-</pre>	<p>Enables the synchronization of the device's registration database (using the REST registrationStatus API command) with</p>

Parameter	Description
registration-status [RoutingServerRegistrationStatus]	remote HTTP hosts.  ■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.  ■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.  For more information, see <a href="#">Configuring Remote Web Services</a> on page 429
<b>Remote Monitoring</b> For more information, see <a href="#">Remote Monitoring of Device behind NAT</a> on page 1467.	
'Remote Monitoring' configure system > http-services > remote-monitoring [RemoteMonitoringEnable]	Enables the device to send monitoring reports to a remote monitoring server when the device is located behind NAT.  ■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.  ■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.
'Reporting Period' configure system > http-services > remote-monitor-reporting-period [RemoteMonitoringPeriod]	Defines the time interval (in seconds) between each remote monitoring report that is sent to the monitoring server.  The valid value is 30 to 65535. The default is 300.
'Device Status' configure system > http-services > remote-monitor-status [RemoteMonitoringDeviceEnable]	Enables the device to send a remote monitoring report of its status to the monitoring server.  ■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.  ■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.
'Active Alarms' configure system > http-services > remote-monitor-alarms [RemoteMonitoringAlarmsEnable]	Enables the device to send a remote monitoring report of currently active alarms to the monitoring server.  ■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.  ■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.
'Performance Indicators' configure system > http-	Enables the device to send a remote monitoring report of performance monitoring statistics to the monitoring

Parameter	Description
<code>services &gt; remote-monitor-kpi</code> [RemoteMonitoringPMEnable]	server. ■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. ■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.
'Registration Status' <code>configure system &gt; http-services &gt; remote-monitor-registration</code> [RemoteMonitoringSIPUsersEnable]	Enables the device to send a remote monitoring report of users registered with the device to the monitoring server. ■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. ■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.

## HTTP Proxy Parameters

The HTTP Proxy service parameters are described in the table below.

**Table 69-71: HTTP Proxy Service Parameters**

Parameter	Description
'HTTP Proxy Application' <code>configure network &gt; http-proxy &gt; http-proxy-app</code> [HTTPProxyApplication]	Enables the HTTP Proxy application. ■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled. ■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.  <b>Note:</b> For the parameter to take effect, a device restart is required.
'HTTP Proxy Debug Level' <code>configure network &gt; http-proxy &gt; http-proxy-debug-level</code> [HTTPProxySyslogDebugLevel]	Enables debugging of HTTP services and filtering of messages sent to the syslog server by severity (debug) level. ■ [0] <b>No Debug</b> = (Default) Disable. ■ [1] <b>Info</b> = Enables debug and sends basic information in syslog. The logged information includes details of access requests (HTTP requests to read or write files). ■ [2] <b>Notice</b> = Enables debug and

Parameter	Description
	<p>sends normal, but significant information in syslog. The logged information includes details of access requests (HTTP requests to read or write files).</p> <ul style="list-style-type: none"> <li>■ [3] <b>Warning</b> = Enables debug and sends warning conditions in syslog.</li> <li>■ [4] <b>Error</b> = Enables debug and sends error conditions in syslog.</li> <li>■ [5] <b>Critical</b> = Enables debug and sends critical conditions in syslog.</li> <li>■ [6] <b>Alert</b> = Enables debug and sends conditions in syslog that require immediate action.</li> <li>■ [7] <b>Emergency</b> = Enables debug and sends conditions indicating unstable system in syslog.</li> </ul> <p><b>Note:</b> The NGINX Directive for this parameter is "error_log, access_log".</p>
'Primary DNS Server IP' <code>dns-primary-server</code> [HTTPPrimaryDNS]	<p>Defines the primary DNS server (in dotted-decimal notation), which is used for translating domain names into IP addresses for the HTTP service.</p> <p>By default, no IP address is defined.</p>
'Secondary DNS Server IP' <code>dns-secondary-server</code> [HTTPSecondaryDNS]	<p>Defines the secondary DNS server (in dotted-decimal notation), which is used for translating domain names into IP addresses for the HTTP service.</p> <p>By default, no IP address is defined.</p>
'HTTP Proxy Global Address' <code>configure network &gt; http-proxy &gt; http-proxy-global-address</code> [HttpProxyGlobalAddress]	<p>Defines the device's public IP address for the HTTP Proxy service, when the device is located behind NAT.</p> <p>The valid value is an IP address in dotted-decimal notation. The default</p>

Parameter	Description
	<p>is 0.0.0.0.</p> <p>For more information, see <a href="#">Configuring a Public IP Address for NGINX NAT Traversal</a> on page 487.</p>
'HTTP Cache Enable' [HTTPCacheEnable]	<p>Enables the caching of HTTP responses.</p> <p>■ [0] Check box cleared <input type="checkbox"/> = (Default) Disabled.</p> <p>■ [1] Check box selected <input checked="" type="checkbox"/> = Enabled.</p>

## 70 Capacity for Signaling, Media and User Registrations

For supported capacity (SIP signaling, media and user registrations), refer to the device's *Release Notes*, which can be downloaded from AudioCodes [website](#).



## 71 Technical Specifications

For technical specifications, refer to the device's Datasheet, which can be downloaded from AudioCodes [website](#).

**This page is intentionally left blank.**

### **International Headquarters**

6 Ofra Haza Street

Naimi Park

Or Yehuda, 6032303, Israel

Tel: +972-3-976-4000

Fax: +972-3-976-4040

### **AudioCodes Inc.**

80 Kingsbridge Rd

Piscataway, NJ 08854, USA

Tel: +1-732-469-0880

Fax: +1-732-469-2298

**Contact us:** <https://www.audiocodes.com/corporate/offices-worldwide>

**Website:** <https://www.audiocodes.com/>

**Documentation Feedback:** <https://online.audiocodes.com/documentation-feedback>

©2025 AudioCodes Ltd. All rights reserved. AudioCodes, AC, HD VoIP, HD VoIP Sounds Better, IPmedia, Mediant, MediaPack, What's Inside Matters, OSN, SmartTAP, User Management Pack, VMAS, VoIPerfect, VoIPerfectHD, Your Gateway To VoIP, 3GX, AudioCodes One Voice, AudioCodes Meeting Insights, and AudioCodes Room Experience are trademarks or registered trademarks of AudioCodes Limited. All other products or trademarks are property of their respective owners. Product specifications are subject to change without notice.

Document #: LTRT-14024

