

Installation Guide

1. Before Installing

Congratulations on purchasing the Expansion Module for your AudioCodes C455HD IP Phone! Before installing it, make sure the following items are included in the shipped box:

- ✓ Expansion Module
- ✓ Plastic packet containing five screws

2. Installation Process



Note: Before proceeding with the installation:

- Disconnect the phone from the Power Supply / Power over Ethernet (PoE)
- Obtain a Philips screwdriver

🔗 **To connect the Expansion Module to the C455HD phone:**

- ✓ Step 1: Prepare the two units – see [here](#)
- ✓ Step 2: Remove the phone's side panel – see [here](#)
- ✓ Step 3: Connect the Expansion Module to the phone – see [here](#)
- ✓ Step 4: Attach the panel removed from the phone in Step 3, to the Expansion Module – see [here](#)
- ✓ Step 5: Secure the assembly – see [here](#)
- ✓ Step 6: Install the Expansion Module's base stand and the phone's base stand - see [here](#)
- ✓ Step 7: Mount the assembled unit - see [here](#)



- ✓ **Step 1:** Place the phone and the Expansion Module on a table alongside one other.



- ✓ **Step 2:** Invert the phone on a surface that won't scratch the screen such as a towel or printer paper. Avoid inverting the phone on the surface of a desk. Then unscrew the three screws shown below in order to remove the phone's side panel:





- ✓ **Step 3:** Return the phone to an upright position. Remove the Expansion Module's connector's rubber cover as shown in the figure below left, and then connect the Expansion Module to the phone as shown in the figure below right. Note the connector and PEM direction.



- ✓ **Step 4:** Attach the panel that you removed from the phone in Step 2 to the side of the Expansion Module, like this:



- ✓ **Step 5:** Invert the assembled unit and secure the side panel by screwing in the three screws as shown in the figure below:



- ✓ **Step 6:** [Refer again to the figure above] Secure the connection of the two units by screwing in these five screws shipped with the device in a plastic packet.

- ✓ **Step 7:** With the assembly inverted, mount the phone on its dedicated base stand and the Expansion Module on its dedicated base stand.



Slide the stand's slots along the rails on the unit. The figure above shows the Expansion Module being mounted on the *short edge* of its 'L' shaped base stand. The long edge of the 'L' can alternatively be used, depending on user preference and on sources of glare in the office.

Notice Information

Information contained in this document is believed to be accurate and reliable at the time of printing. However, due to ongoing product improvements and revisions, AudioCodes cannot guarantee accuracy of printed material after the Date Published nor can it accept responsibility for errors or omissions. Updates to this document can be downloaded from <https://www.audiocodes.com/library/technical-documents>.

This document is subject to change without notice.

Date Published: December-12-2022

LTRT-12829

