

## Connecting AudioCodes' SBC with Analog Device to Microsoft Teams Direct Routing Enterprise Model

Version 7.2

**Microsoft Partner**  
Gold Communications





---

## Table of Contents

---

<b>1</b>	<b>Introduction .....</b>	<b>7</b>
1.1	About Microsoft Teams Direct Routing .....	7
1.2	About AudioCodes SBC Product Series .....	7
1.3	Validated AudioCodes SBC Version .....	8
<b>2</b>	<b>Topology Example .....</b>	<b>9</b>
2.1.1	Enterprise Model Implementation .....	9
2.1.2	Environment Setup .....	11
2.1.3	Infrastructure Prerequisites .....	11
<b>3</b>	<b>Configuring Teams Direct Routing .....</b>	<b>13</b>
3.1	Prerequisites .....	13
3.2	SBC Domain Name in the Teams Enterprise Model .....	13
3.3	Configuration Example of Office 365 Tenant Direct Routing .....	14
3.3.1	Online PSTN Gateway Configuration .....	14
3.3.2	Online PSTN Usage Configuration .....	14
3.3.3	Online Voice Route Configuration .....	15
3.3.4	Online Voice Routing Policy Configuration .....	15
3.3.5	Enable Online User .....	15
3.3.6	Assigning Online User to the Voice Route .....	15
3.3.7	Analog Device Voice Route Configuration .....	16
3.3.8	Configure with User Management Pack 365 (Optional) .....	16
<b>4</b>	<b>Configuring AudioCodes SBC .....</b>	<b>17</b>
4.1	SBC Configuration Concept in Teams Direct Routing .....	17
4.2	IP Network Interfaces Configuration .....	18
4.2.1	Configure VLANs .....	18
4.2.2	Configure Network Interfaces .....	19
4.3	SIP TLS Connection Configuration .....	20
4.3.1	Configure the NTP Server Address .....	20
4.3.2	Create a TLS Context for Teams Direct Routing .....	21
4.3.3	Configure a Certificate .....	22
4.3.4	Method for Generating and Installing the Wildcard Certificate .....	25
4.3.5	Deploy Baltimore Trusted Root Certificate .....	26
4.4	Configure Media Realms .....	27
4.5	Configure SIP Signaling Interfaces .....	28
4.6	Configure Proxy Sets and Proxy Address .....	29
4.6.1	Configure Proxy Sets .....	29
4.6.2	Configure a Proxy Address .....	30
4.7	Configure Coders .....	32
4.8	Configure IP Profiles .....	35
4.9	Configure IP Groups .....	39
4.10	Configure SRTP .....	41
4.11	Configuring Message Condition Rules .....	42
4.12	Configure Classification Rules .....	43
4.13	Configure IP-to-IP Call Routing Rules .....	45
4.14	Configure Firewall Settings .....	47

<b>5</b>	<b>Verify the Pairing Between the SBC and Direct Routing .....</b>	<b>49</b>
<b>6</b>	<b>Verify ATA Registered Users in the SBC .....</b>	<b>51</b>
<b>A</b>	<b>Configuring MP-1xx ATA for Connecting Analog Devices .....</b>	<b>53</b>
A.1	Configure Proxy Server and Registration.....	53
A.2	Configure the Endpoint Phone Number Table .....	54
A.3	Configure the Hunt Group .....	55
A.4	Configure IP-to-Hunt Group Routing.....	55
A.5	Configure SIP UDP Transport Type and Fax Signaling Method .....	56
<b>B</b>	<b>Configuring MP-20x ATA for Connecting Analog Devices .....</b>	<b>57</b>
B.1	Configure SIP Interface Settings.....	57
B.2	Configure Media Streaming Parameters.....	58
B.3	Configuring Line Settings.....	59
<b>C</b>	<b>Syntax Requirements for SIP Messages 'INVITE' and 'OPTIONS'.....</b>	<b>61</b>
C.1	Terminology .....	61
C.2	Syntax Requirements for 'INVITE' Messages .....	61
C.3	Requirements for 'OPTIONS' Messages Syntax.....	62
C.4	Connectivity Interface Characteristics.....	63

## Notice

Information contained in this document is believed to be accurate and reliable at the time of printing. However, due to ongoing product improvements and revisions, AudioCodes cannot guarantee accuracy of printed material after the Date Published nor can it accept responsibility for errors or omissions. Updates to this document can be downloaded from <https://www.audiocodes.com/library/technical-documents>.

This document is subject to change without notice.

Date Published: August-13-2020

## WEEE EU Directive

Pursuant to the WEEE EU Directive, electronic and electrical waste must not be disposed of with unsorted waste. Please contact your local recycling authority for disposal of this product.

## Customer Support

Customer technical support and services are provided by AudioCodes or by an authorized AudioCodes Service Partner. For more information on how to buy technical support for AudioCodes products and for contact information, please visit our website at <https://www.audiocodes.com/services-support/maintenance-and-support>.

## Stay in the Loop with AudioCodes



## Abbreviations and Terminology

Each abbreviation, unless widely used, is spelled out in full when first used.

## Related Documentation

Document Name
Mediant 500 Gateway & E-SBC User's Manual
Mediant 500L Gateway & E-SBC User's Manual
Mediant 800 Gateway & E-SBC User's Manual
Mediant 1000B Gateway and E-SBC User's Manual
Mediant 2600 SBC User's Manual
Mediant 4000 SBC User's Manual
Mediant 9000 SBC User's Manual
Mediant Software SBC User's Manual
MP-11x and MP-124 SIP User's Manual
MP-20x Telephone Adapter User's Manual
SIP Message Manipulation Reference Guide
AudioCodes Configuration Notes

## Document Revision Record

LTRT	Description
33421	Initial document release for Version 7.2. Teams Enterprise Model.
33422	Modified Section: Deploy Baltimore Trusted Root Certificate (added note for Baltimore Trusted Root Certificate and MTLS implementation).; Configure SIP Signaling Interfaces; Configure IP Groups
33423	Note removed regarding external firewall.
33424	Licenses consolidated into one section.
33425	Update to topology figures and correction for parameter "Remote Update Support" to "SIP UPDATE Support".
33426	Update to the "Related Documentation" table to include the Mediant 1000B Gateway & E-SBC product.

## Documentation Feedback

AudioCodes continually strives to produce high quality documentation. If you have any comments (suggestions or errors) regarding this document, please fill out the Documentation Feedback form on our website at <https://online.audiocodes.com/documentation-feedback>.

# 1 Introduction

This Configuration Note describes an example setup of the AudioCodes Enterprise Session Border Controller (hereafter, referred to as *SBC*) for interworking between Company's SIP Trunk, ATA device and Microsoft's Teams Direct Routing environment.

For configuring the Office 365 side, please refer to <https://docs.microsoft.com/en-us/microsoftteams/direct-routing-configure>.

This document is intended for IT or telephony professionals.

## 1.1 About Microsoft Teams Direct Routing

Teams Direct Routing allows connecting a customer-provided SBC to the Microsoft Phone System. The customer-provided SBC can be connected to almost any telephony trunk, or connect with third-party PSTN equipment. The connection allows:

- Using virtually any PSTN trunk with Microsoft Phone System
- Configuring interoperability between customer-owned telephony equipment, such as third-party PBXs, analog devices, and Microsoft Phone System

## 1.2 About AudioCodes SBC Product Series

AudioCodes' family of SBC devices enables reliable connectivity and security between the Enterprise's and the service provider's VoIP networks.

The SBC provides perimeter defense as a way of protecting Enterprises from malicious VoIP attacks; mediation for allowing the connection of any PBX and/or IP-PBX to any service provider; and Service Assurance for service quality and manageability.

Designed as a cost-effective appliance, the SBC is based on field-proven VoIP and network services with a native host processor, allowing the creation of purpose-built multiservice appliances, providing smooth connectivity to cloud services, with integrated quality of service, SLA monitoring, security and manageability. The native implementation of SBC provides a host of additional capabilities that are not possible with standalone SBC appliances such as VoIP mediation, PSTN access survivability, and third-party value-added services applications. This enables Enterprises to utilize the advantages of converged networks and eliminate the need for standalone appliances.

AudioCodes SBC is available as an integrated solution running on top of its field-proven Mediant Media Gateway and Multi-Service Business Router platforms, or as a software-only solution for deployment with third-party hardware. The SBC can be offered as a Virtualized SBC, supporting the following platforms: Hyper-V, AWS, AZURE, AWP, KVM and VMWare.

## 1.3 Validated AudioCodes SBC Version

Microsoft has successfully conducted validation tests with AudioCodes' Mediant SBC Ver. 7.20A.250. Previous firmware versions may run successfully; however, Microsoft did not test such versions. For updated list refer to [List of Session Border Controllers certified for Direct Routing](#).



**Note:** For implementing Microsoft Teams Direct Routing based on the configuration described in this document, AudioCodes SBC must be installed with a License Key that includes the following features:

- **MSFT** (general Microsoft license)  
Note: By default, all AudioCodes media gateways and SBCs are shipped with this license (except MSBR products, Mediant 500 SBC, and Mediant 500 Media Gateway).
- **SW/TEAMS** (Microsoft Teams license)
- **Number of SBC sessions** (based on requirements)
- **Transcoding sessions** (only if media transcoding is needed)
- **Coders** (based on requirements)

For more information about the License Key, contact your AudioCodes sales representative.

## 2 Topology Example

Teams Direct Routing can be implemented in the *Enterprise* or *Hosting* Models.

### 2.1.1 Enterprise Model Implementation

The interoperability example between AudioCodes SBC and Company SIP Trunk with Teams Direct Routing Enterprise Model assume the following topology setup:

- Enterprise deployed with ATA, connected analog devices and the administrator's management station, located on the LAN
- Enterprise deployed with Teams Phone System Direct Routing Interface located on the WAN for enhanced communication within the Enterprise
- Enterprise wishes to offer its employees enterprise-voice capabilities and to connect the Enterprise to the PSTN network using Company's SIP Trunking service
- AudioCodes SBC is implemented to interconnect between the SIP Trunk and Teams Direct Routing located in the WAN

The figure below illustrates this topology example:

**Figure 2-1: Connection Topology with SIP Trunk on the LAN**





Figure 2-2: Connection Topology with SIP Trunk on the WAN



### 2.1.2 Environment Setup

The example topology includes the following environment setup:

**Table 2-1: Environment Setup**

Area	Setup
<b>Network</b>	<ul style="list-style-type: none"> <li>Teams Direct Routing environment is located on the Enterprise's (or Service Provider's) WAN</li> <li>Company SIP Trunk is located on the LAN</li> </ul>
<b>Signaling Transcoding</b>	<ul style="list-style-type: none"> <li>Teams Direct Routing operates with SIP-over-TLS transport type</li> <li>Company SIP Trunk operates with SIP-over-UDP transport type</li> </ul>
<b>Codecs Transcoding</b>	<ul style="list-style-type: none"> <li>Teams Direct Routing supports G.711A-law, G.711U-law, G.729 and SILK (NB and WB) coders</li> <li>Company SIP Trunk supports G.711A-law, G.711U-law, and G.729 coders</li> </ul>
<b>Media Transcoding</b>	<ul style="list-style-type: none"> <li>Teams Direct Routing operates with SRTP media type</li> <li>Company SIP Trunk operates with RTP media type</li> </ul>

### 2.1.3 Infrastructure Prerequisites

The table below shows the list of infrastructure prerequisites for deploying Teams Direct Routing.

**Table 2-2: Infrastructure Prerequisites**

Infrastructure Prerequisite	Details
Certified Session Border Controller (SBC)	See Microsoft's document <a href="#">Plan Direct Routing</a> .
SIP Trunks connected to the SBC	
Office 365 Tenant	
Domains	
Public IP address for the SBC	
Fully Qualified Domain Name (FQDN) for the SBC	
Public DNS entry for the SBC	
Public trusted certificate for the SBC	
Firewall ports for Direct Routing Signaling	
Firewall IP addresses and ports for Direct Routing Media	
Media Transport Profile	
Firewall ports for Teams Clients Media	

**This page is intentionally left blank.**

## 3 Configuring Teams Direct Routing

This section describes an example of Teams Direct Routing configuration to operate with AudioCodes SBC.

### 3.1 Prerequisites

Before you begin configuration, make sure you have the following for every SBC you want to pair:

- Public IP address
- FQDN name matching SIP addresses of the users
- Public certificate, issued by one of the supported CAs

### 3.2 SBC Domain Name in the Teams Enterprise Model


The SBC domain name must be from one of the names registered in 'Domains' of the tenant. You cannot use the **\*.onmicrosoft.com** tenant for the domain name. For example, in Figure 3-1, the administrator registered the following DNS names for the tenant:

**Table 3-1: DNS Names Registered by an Administrator for a Tenant**

DNS name	Can be used for SBC FQDN	Examples of FQDN names
ACeducation.info	Yes	<p><b>Valid names:</b></p> <ul style="list-style-type: none"> <li>▪ sbc.ACeducation.info</li> <li>▪ ussbcs15.ACeducation.info</li> <li>▪ europe.ACeducation.info</li> </ul> <p><b>Invalid name:</b> sbc1.europe.ACeducation.info (requires registering domain name europe.atatum.biz in 'Domains' first)</p>
adatumbiz.onmicrosoft.com	No	Using <b>*.onmicrosoft.com</b> domains is not supported for SBC names
hybridvoice.org	Yes	<p><b>Valid names:</b></p> <ul style="list-style-type: none"> <li>▪ sbc1.hybridvoice.org</li> <li>▪ ussbcs15.hybridvoice.org</li> <li>▪ europe.hybridvoice.org</li> </ul> <p><b>Invalid name:</b> sbc1.europe.hybridvoice.org (requires registering domain name europe.hybridvoice.org in 'Domains' first)</p>

Users can be from any SIP domain registered for the tenant. For example, you can provide users [user@ACeducation.info](mailto:user@ACeducation.info) with the SBC FQDN **sbc1.hybridvoice.org** so long as both names are registered for this tenant.

Figure 3-1: Example of Registered DNS Names



During creation of the Domain you will be forced to create public DNS record (**sbc1.hybridvoice.org** in our example.)

### 3.3 Configuration Example of Office 365 Tenant Direct Routing



**Note:** This section shows an example only. For more detailed information please refer to Microsoft Site: <https://docs.microsoft.com/en-us/microsoftteams/direct-routing-configure>

#### 3.3.1 Online PSTN Gateway Configuration

Use following PowerShell command for creating new Online PSTN Gateway:

```
New-CsOnlinePSTNGateway -Identity sbc1.hybridvoice.org -SipSignallingPort 5068 -ForwardCallHistory $True -ForwardPai $True -MediaBypass $True -Enabled $True
```

#### 3.3.2 Online PSTN Usage Configuration

Use following PowerShell command for creating an empty PSTN Usage:

```
Set-CsOnlinePstnUsage -Identity Global -Usage @{Add="Interop"}
```

### 3.3.3 Online Voice Route Configuration

Use following PowerShell command for creating new Online Voice Route and associate it with PSTN Usage:

```
New-CsOnlineVoiceRoute -Identity "audc-interop" -NumberPattern "\+" -OnlinePstnGatewayList sbc1.hybridvoice.org -Priority 1 -OnlinePstnUsages "Interop"
```

### 3.3.4 Online Voice Routing Policy Configuration

Use following PowerShell command for assigning the Voice Route to the PSTN Usage:

```
New-CsOnlineVoiceRoutingPolicy "audc-interop" -OnlinePstnUsages "Interop"
```

Use the following command on the Teams Direct Routing Management Shell after reconfiguration to verify correct values:

#### **Get-CsOnlinePSTNGateway**

```
Identity           : sbc1.hybridvoice.org
Fqdn               : sbc1.hybridvoice.org
SipSignallingPort : 5068
CodecPriority      : SILKWB, SILKNB, PCMU, PCMA
ExcludedCodecs    :
FailoverTimeSeconds : 10
ForwardCallHistory : True
ForwardPai        : True
SendSipOptions    : True
MaxConcurrentSessions :
Enabled           : True
MediaBypass       : True
```



**Note:** The commands specified in Sections 3.3.5 and 3.3.6, should be run for each Teams user (excluding ATA device users) in the company tenant.

### 3.3.5 Enable Online User

Use following PowerShell command for enabling online user:

```
Set-CsUser -Identity user1@company.com -EnterpriseVoiceEnabled $true -HostedVoiceMail $true -OnPremLineURI tel:+12345678900
```

### 3.3.6 Assigning Online User to the Voice Route

Use following PowerShell command for assigning online user to the Voice Route:

```
Grant-CsOnlineVoiceRoutingPolicy -PolicyName "audc-interop" -Identity user1@company.com
```



**Note:** The command specified in Section 3.3.7 does not need to be run for each ATA device user, if the number pattern already points to the PSTNGateway and has been associated with PSTN Usage (see Section 3.3.3).

### 3.3.7 Analog Device Voice Route Configuration

Use the following PowerShell command for creating a new Online Voice Route and associating it with PSTN Usage:

```
New-CsOnlineVoiceRoute -Identity "audc-interop" -NumberPattern "\^+12345678901" -OnlinePstnGatewayList sbc1.hybridvoice.org -Priority 1 -OnlinePstnUsages "Interop"
```

### 3.3.8 Configure with User Management Pack 365 (Optional)

As an alternative to PowerShell commands, AudioCodes recommend using User Management Pack 365 (UMP365). UMP365 provides a simple web-portal user interface for configuring and managing the Online Voice Route and associating it with PSTN Usage and PSTN Gateway. See examples below:

Figure 3-2: Example of Adding new Voice Route




Figure 3-3: Example of Voice Routes Table

DataChangeType	Identity	Priority	Pattern	Name	Description	Pattern	PSTN Gateway List	PSTN Usage	
	LocalRoute	0	+999	LocalRoute		+999			▲▲
	US	1	^\+	US		^\+	sbcRTP1.customers.audiocodesaas.com	US	▲▲
	int-il	2	^\+	int-il		^\+	int-sbc2.audctrunk.aceducation.info	Interop	▲▲
	Israel	3	^\+972	Israel		^\+972	sbc1.AUDCTrunk.aceducation.info	Israel	▲▲

# 4 Configuring AudioCodes SBC

This section provides example of step-by-step procedures on how to configure AudioCodes SBC for interworking between Teams Direct Routing and the Company SIP Trunk. These configuration procedures are based on the topology example described in Section 2.1.1 on page 9, and includes the following main areas:

- SBC LAN interface – ATA devices environment
- SBC WAN interface - Company SIP Trunking and Teams Direct Routing environment

This configuration is done using the SBC's embedded Web server (hereafter, referred to as *Web interface*).




**Notes:**

- For implementing Teams Direct Routing based on the configuration described in this section, AudioCodes SBC must be installed with a License Key. For more information, see Section 1.3 on page 8.
- The scope of this document does **not** cover all security aspects for configuring this topology. Comprehensive security measures should be implemented per your organization's security policies. For security recommendations on AudioCodes' products, refer to the *Recommended Security Guidelines* document, which can be found at AudioCodes web site

## 4.1 SBC Configuration Concept in Teams Direct Routing

The diagram below represents AudioCodes' device configuration concept.

**Figure 4-1: SBC Configuration Concept**




## 4.2 IP Network Interfaces Configuration

This section describes how to configure the SBC's IP network interfaces. There are several ways to deploy the SBC; however, this example employs the following deployment method:

- SBC interfaces with the following IP entities:
  - Teams Direct Routing and Company SIP Trunk, located on the WAN
  - IP-PBX and/or ATA, located on the LAN
- SBC connects to the WAN through a DMZ network
- Physical connection: The type of physical connection depends on the method used to connect to the Enterprise's network. In the example topology, SBC connects to the LAN and DMZ using dedicated ethernet ports (i.e., two ports and two network cables are used).
- SBC also uses two logical network interfaces:
  - LAN (VLAN ID 1)
  - DMZ (VLAN ID 2)

**Figure 4-2: Network Interfaces in the Example Topology**



### 4.2.1 Configure VLANs

This section describes how to configure VLANs for each of the following interfaces:

- LAN VoIP (assigned the name "LAN\_IF")
- WAN VoIP (assigned the name "WAN\_IF")

➤ **To configure the VLANs:**

1. Open the Ethernet Device table (**Setup** menu > **IP Network** tab > **Core Entities** folder > **Ethernet Devices**).
2. There will be one existing row for VLAN ID 1 and underlying interface GROUP\_1.
3. Add another VLAN ID 2 for the WAN side

**Figure 4-3: Configured VLAN IDs in Ethernet Device**

INDEX	VLAN ID	UNDERLYING INTERFACE	NAME	TAGGING
0	1	GROUP_1	vlan 1	Untagged
1	2	GROUP_2	vlan 2	Untagged

### 4.2.2 Configure Network Interfaces

This section describes how to configure the IP network interfaces for each of the following interfaces:

- LAN Interface (assigned the name "LAN\_IF")
- WAN Interface (assigned the name "WAN\_IF")

➤ **To configure the IP network interfaces:**

1. Open the IP Interfaces table (**Setup** menu > **IP Network** tab > **Core Entities** folder > **IP Interfaces**).
2. Configure the IP interfaces as follows (your network parameters might be different):

**Table 4-1: Configuration Example of the Network Interface Table**

Index	Application Types	Interface Mode	IP Address	Prefix Length	Gateway	DNS	I/F Name	Ethernet Device
0	OAMP+ Media + Control	IPv4 Manual	10.15.77.77	16	10.15.0.1	10.15.27.1	LAN_IF	vlan 1
1	Media + Control (as this interface points to the internet, enabling OAMP is not recommended)	IPv4 Manual	195.189.192.157 (DMZ IP address of SBC)	25	195.189.192.129 (router's IP address)	According to your Internet provider's instructions	WAN_IF	vlan 2

The configured IP network interfaces are shown below:

**Figure 4-4: Configured Network Interfaces in IP Interfaces Table**

IP Interfaces (2)

+ New Edit |  Page 1 of 1 Show 10 records per page

INDEX	NAME	APPLICATION TYPE	INTERFACE MODE	IP ADDRESS	PREFIX LENGTH	DEFAULT GATEWAY	PRIMARY DNS	SECONDARY DNS	ETHERNET DEVICE
0	LAN_IF	OAMP + Media +	IPv4 Manual	10.15.17.77	16	10.15.0.1	10.15.27.1	0.0.0.0	vlan 1
1	WAN_IF	Media + Control	IPv4 Manual	195.189.192.157	25	195.189.192.129	80.179.52.100	80.179.55.100	vlan 2

## 4.3 SIP TLS Connection Configuration

This section describes how to configure the SBC for using a TLS connection with the Teams Direct Routing Phone System. This configuration is essential for a secure SIP TLS connection. The configuration instructions example in this section are based on the following domain structure that must be implemented as part of the certificate which must be loaded to the host SBC:

- CN: sbc1.hybridvoice.org
- SAN: sbc1.hybridvoice.org

This certificate module is based on the Service Provider's own TLS Certificate. For more certificate structure options, see Microsoft Teams Direct Routing documentation.

The Phone System Direct Routing Interface allows **only** TLS connections from SBCs for SIP traffic with a certificate signed by one of the Trusted Certification Authorities.

Currently, supported Certification Authorities can be found in the following link:

<https://docs.microsoft.com/en-us/microsoftteams/direct-routing-plan#public-trusted-certificate-for-the-sbc>

### 4.3.1 Configure the NTP Server Address

This section describes how to configure the NTP server's IP address. It is recommended to implement an NTP server (Microsoft NTP server or another global server) to ensure that the SBC receives the current date and time. This is necessary for validating certificates of remote parties. It is important, that NTP Server will locate on the OAMP IP Interface (LAN\_IF in our case) or will be accessible through it.

➤ **To configure the NTP server address:**

1. Open the Time & Date page (**Setup** menu > **Administration** tab > **Time & Date**).
2. In the 'Primary NTP Server Address' field, enter the IP address of the NTP server (e.g., **10.15.28.1**).

**Figure 4-5: Configuring NTP Server Address**

NTP SERVER	
Enable NTP	Enable
Primary NTP Server Address (IP or FQDN)	10.15.28.1
Secondary NTP Server Address (IP or FQDN)	
NTP Update Interval	Hours: 24 Minutes: 0
NTP Authentication Key Identifier	0
NTP Authentication Secret Key	

3. Click **Apply**.

### 4.3.2 Create a TLS Context for Teams Direct Routing

This section describes how to configure TLS Context in the SBC. AudioCodes recommends implementing only TLS to avoid flaws in SSL.

➤ **To configure the TLS version:**

1. Open the TLS Contexts table (**Setup** menu > **IP Network** tab > **Security** folder > **TLS Contexts**).
2. Create a new TLS Context by clicking **New** at the top of the interface, and then configure the parameters using the table below as reference:

**Table 4-2: New TLS Context**

Index	Name	TLS Version
1	Teams (arbitrary descriptive name)	TLSv1.2
All other parameters can be left unchanged with their default values.		



**Note:** The table above exemplifies configuration focusing on interconnecting SIP and media. You might want to configure additional parameters according to your company's policies. For example, you might want to configure Online Certificate Status Protocol (OCSP) to check if SBC certificates presented in the online server are still valid or revoked. For more information on the SBC's configuration, see the *User's Manual*, available for download from <https://www.audiocodes.com/library/technical-documents>.

**Figure 4-6: Configuring TLS Context for Teams Direct Routing**

3. Click **Apply**.

### 4.3.3 Configure a Certificate

This section describes how to request a certificate for the SBC and to configure it based on the example of DigiCert Global Root CA. The certificate is used by the SBC to authenticate the connection with Teams Direct Routing.

The procedure involves the following main steps:

- a. Generating a Certificate Signing Request (CSR).
- b. Requesting Device Certificate from CA.
- c. Obtaining Trusted Root/ Intermediate Certificate from CA.
- d. Deploying Device and Trusted Root/ Intermediate Certificates on SBC.

➤ **To configure a certificate:**

1. Open the TLS Contexts page (**Setup** menu > **IP Network** tab > **Security** folder > **TLS Contexts**).
2. In the TLS Contexts page, select the required TLS Context index row, and then click the **Change Certificate** link located below the table; the Context Certificates page appears.
3. Under the **Certificate Signing Request** group, do the following:
  - a. In the 'Subject Name [CN]' field, enter the SBC FQDN name (based on example above, **sbc1.hybridvoice.org**).
  - b. In the '1<sup>st</sup> Subject Alternative Name [SAN]' field, change the type to 'DNS' and enter the SBC FQDN name (based on example above, **sbc1.hybridvoice.org**).



**Note:** The domain portion of the Common Name [CN] and 1st Subject Alternative Name [SAN] must match the SIP suffix configured for Office 365 users.

- c. Change the 'Private Key Size' based on the requirements of your Certification Authority. Many CAs do not support private key of size 1024. In this case, you must change the key size to 2048.
- d. To change the key size on TLS Context, go to: **Generate New Private Key and Self-Signed Certificate**, change the 'Private Key Size' to **2048** and then click **Generate Private-Key**. To use **1024** as a Private Key Size value, you can click **Generate Private-Key** without changing the default key size value.
- e. Fill in the rest of the request fields according to your security provider's instructions.
- f. Click the **Create CSR** button; a textual certificate signing request is displayed in the area below the button:

**Figure 4-7: Example of Certificate Signing Request – Creating CSR**

+
TLS Context [#1] > Change Certificates

CERTIFICATE SIGNING REQUEST

Common Name [CN]	<input type="text" value="sbc1.hybridvoice.org"/>
Organizational Unit [OU] <i>(optional)</i>	<input type="text"/>
Company name [O] <i>(optional)</i>	<input type="text"/>
Locality or city name [L] <i>(optional)</i>	<input type="text"/>
State [ST] <i>(optional)</i>	<input type="text"/>
Country code [C] <i>(optional)</i>	<input type="text"/>
1st Subject Alternative Name [SAN]	DNS <input type="text" value="sbc1.hybridvoice.org"/>
2nd Subject Alternative Name [SAN]	EMAIL <input type="text"/>
3rd Subject Alternative Name [SAN]	EMAIL <input type="text"/>
4th Subject Alternative Name [SAN]	EMAIL <input type="text"/>
5th Subject Alternative Name [SAN]	EMAIL <input type="text" value="Admin"/>
Signature Algorithm	SHA-256

After creating the CSR, copy the text below (including the BEGIN/END lines) and send it to your Certification Authority for signing.

```

-----BEGIN CERTIFICATE REQUEST-----
MIICDCCAZCAQIwHzEdMBsGA1UEAwUc2JjMS5oeWJyaWR2b21jZS5vcmcwggE1
MA0GCsgGSIB3DQEBAAQAA4IBDWAaggEKAoIBAQC8nu05z1bAcEmr1DBk0eJRv0IB
YIcZ02DAWwJxiY/5v8efjjGIVinmAnBXJfdds6MgI8RnWJVTXCLW9Fh5p4RTjeRV
kZuXhzhzI9is1AAwXj0BbeTHP6UOem0P9j6YgDo9e+4GTbDahiDMNkFMDy0i2tCt
YdywNekWIOa5f41MLjkgv07hLp51gRjEgM7okVBXeMMTjNkF+8BvxT2Bn3FKi3m+
5iLU0zwt2r6XXtjvFH0Av3MhsdUBwE+XYVFBGAGISYEh21iNjseiG0KEqcH31y/
RqsrvIXyImCv/C4FJiSmcZaphA48TCYR95W3gQWheQGuRt4/VFJJiDqN1zRagMB
AAGgRDBCBgkqhkiG9w0BCCQ4xNTAzMB8GA1UdEQYMBaCFHNIYzEuaH1cm1kdm9p
Y2Uub3JnMBAGA1UdEQYMAeBBUFkbW1uMA0GCsGSIb3DQEBCCUAA4IBAQCzFYrP
h34bG+m/Lg5n9gGGj2b+Dd6crMnqraM149GShLx+CdwngYuo0h9Zx1yngBp002j
hQaCKLH/P2SVxz6zE9eIHx/s18muGKlW1k0aIXEeXicsU99GuRYdFI74/brFCut
f/Ip/lni0mtFKEIA3z/9M9MnFYNaS0vcFxrV5QG5NKm1paCwraH/dFFf7GP3hngD
7njK6JVNcy3pPr1kSr4XEixsv3aTLYdM6o1GDROb9Gi6uATqJn1XXTsUm0o9wJX
7Nd0saoUxfBKv1+eU4eeJt2Fp30SGiGo6wxsDDMCbj/u3KxoJirx0f3R/KjKEuZ
CqRb8dOU4kbeSwo
-----END CERTIFICATE REQUEST-----
    
```

GENERATE NEW PRIVATE KEY AND SELF-SIGNED CERTIFICATE

Private Key Size	<input type="text" value="1024"/>
Private key pass-phrase <i>(optional)</i>	<input type="text" value="....."/>

Press the "Generate Private Key" button to create new private key.

Press the "Generate Self-Signed Certificate" button to create self-signed certificate.

Note that the certificate will use the subject name configured in "Certificate Signing Request" box.

Important: generation of private key is a lengthy operation during which the device service may be affected.

4. Copy the CSR from the line "**-----BEGIN CERTIFICATE REQUEST-----**" to a text file (such as Notepad), and then save it to a folder on your computer with the file name, for example *certreq.txt*.
5. Send *certreq.txt* file to the Certified Authority Administrator for signing.

6. After obtaining an SBC signed and Trusted Root/Intermediate Certificate from the CA, in the SBC's Web interface, return to the **TLS Contexts** page and do the following:
  - a. In the TLS Contexts page, select the required TLS Context index row, and then click the **Change Certificate** link located below the table; the Context Certificates page appears.
  - b. Scroll down to the **Upload certificates files from your computer** group, click the **Choose File** button corresponding to the 'Send Device Certificate...' field, navigate to the certificate file obtained from the CA, and then click **Load File** to upload the certificate to the SBC.

**Figure 4-8: Uploading the Certificate Obtained from the Certification Authority**

UPLOAD CERTIFICATE FILES FROM YOUR COMPUTER

Private key pass-phrase (optional)

Send **Private Key** file from your computer to the device.  
The file must be in either PEM or PFX (PKCS#12) format.

No file chosen

**Note:** Replacing the private key is not recommended but if it's done, it should be over a physically-secure network link.

Send **Device Certificate** file from your computer to the device.  
The file must be in textual PEM format.

No file chosen  ←

7. Confirm that the certificate was uploaded correctly. A message indicating that the certificate was uploaded successfully is displayed in blue in the lower part of the page.
8. In the SBC's Web interface, return to the **TLS Contexts** page, select the required TLS Context index row, and then click the **Certificate Information** link, located at the bottom of the TLS. Then validate the Key size, certificate status and Subject Name:

**Figure 4-9: Certificate Information Example**

⊕ TLS Context [#1] > Certificate Information

PRIVATE KEY

Key size: 2048 bits

Status: OK

CERTIFICATE

Certificate:

Data:

Version: 3 (0x2)

Serial Number: 1f:dc:b2:f1:fb:ee:fa:db:c1:90:0e:4e:aa:0f:51:49

Signature Algorithm: sha256WithRSAEncryption

Issuer: C=IL, O=Domain The Net Technologies Ltd, CN=Domain The Net Technologies Ltd CA for SSL R2

Validity

Not Before: May 15 13:03:31 2019 GMT

Not After: May 14 13:03:31 2020 GMT

Subject: CN= sbc1.hybridvoice.org

Subject Public Key Info:

Public Key Algorithm: rsaEncryption

Public-Key: (2048 bit)

9. In the SBC's Web interface, return to the **TLS Contexts** page.
  - a. In the TLS Contexts page, select the required TLS Context index row, and then click the **Trusted Root Certificates** link, located at the bottom of the TLS Contexts page; the Trusted Certificates page appears.
  - b. Click the **Import** button, and then select all Root/Intermediate Certificates obtained from your Certification Authority to load.
10. Click **OK**; the certificate is loaded to the device and listed in the Trusted Certificates store:

**Figure 4-10: Example of Configured Trusted Root Certificates**

INDEX	SUBJECT	ISSUER	EXPIRES
0	DigiCert Global Root CA	DigiCert Global Root CA	11/10/2031
1	RapidSSL RSA CA 2018	DigiCert Global Root CA	11/06/2027

#### 4.3.4 Method for Generating and Installing the Wildcard Certificate

To use the same certificate on multiple devices, you may prefer using 3<sup>rd</sup> party application (e.g. [DigiCert Certificate Utility for Windows](#)) to process the certificate request from your Certificate Authority on another machine, with this utility installed.

After you've processed the certificate request and response using the DigiCert utility, test the certificate private key and chain and then export the certificate with private key and assign a password.

➤ **To install the certificate:**

1. Open the TLS Contexts page (**Setup** menu > **IP Network** tab > **Security** folder > **TLS Contexts**).
2. In the TLS Contexts page, select the required TLS Context index row, and then click the **Change Certificate** link located below the table; the Context Certificates page appears.
3. Scroll down to the **Upload certificates files from your computer** group and do the following:
  - a. Enter the password assigned during export with the DigiCert utility in the '**Private key pass-phrase**' field.
  - b. Click the **Choose File** button corresponding to the 'Send **Private Key**...' field and then select the SBC certificate file exported from the DigiCert utility.

### 4.3.5 Deploy Baltimore Trusted Root Certificate



**Note:** Loading Baltimore Trusted Root Certificates into AudioCodes' SBC mandatory for implementing MTLS connection with Microsoft.

The DNS name of the Teams Direct Routing interface is **sip.pstnhub.microsoft.com**. In this interface, a certificate is presented which is signed by Baltimore CyberTrust Root with Serial Number: 02 00 00 b9 and SHA fingerprint: d4:de:20:d0:5e:66:fc:53:fe:1a:50:88:2c:78:db:28:52:ca:e4:74.

To trust this certificate, your SBC *must* have the certificate in Trusted Certificates storage. Download the certificate from <https://cacert.omniroot.com/bc2025.pem> and follow the steps above to import the certificate to the Trusted Root storage.



**Note:** Before importing the Baltimore Root Certificate into AudioCodes' SBC, make sure it's in .PEM or .PFX format. If it isn't, you need to convert it to .PEM or .PFX format. Otherwise, you will receive a 'Failed to load new certificate' error message. To convert to PEM format, use the Windows local store on any Windows OS and then export it as 'Base-64 encoded X.509 (.CER) certificate'.

## 4.4 Configure Media Realms

This section describes how to configure Media Realms. Media Realms allow the dividing of UDP port ranges for use on different interfaces. The simplest configuration is to create Media Realms for internal (ATA) and external (Teams and SIP Trunk) traffic.

➤ **To configure Media Realms:**

1. Open the Media Realms table (**Setup** menu > **Signaling & Media** tab > **Core Entities** folder > **Media Realms**).
2. Configure Media Realms as follows (you can use the default Media Realm (Index 0), but modify it):

**Table 2-3: Configuration Example Media Realms in Media Realm Table**

Index	Name	Topology Location	IPv4 Interface Name	Port Range Start	Number of Media Session Legs
0	SIPTrunk (arbitrary name)	Up	WAN_IF	6000	100 (media sessions assigned with port range)
1	Teams (arbitrary name)	Up	WAN_IF	7000	100 (media sessions assigned with port range)
2	MRLan (arbitrary name)		LAN_IF	6000	100 (media sessions assigned with port range)

The configured Media Realms are shown in the figure below:

**Figure 4-11: Configured Media Realms in Media Realm Table**

Media Realms (3)

+ New Edit | Page 1 of 1 | Show 10 records per page

INDEX	NAME	IPv4 INTERFACE NAME	PORT RANGE START	NUMBER OF MEDIA SESSION LEGS	PORT RANGE END	DEFAULT MEDIA REALM
0	SIPTrunk	WAN_IF	6000	100	6999	No
1	Teams	WAN_IF	7000	100	7999	No
2	MRLan	LAN_IF	6000	100	6999	No

## 4.5 Configure SIP Signaling Interfaces

This section describes how to configure SIP Interfaces. A SIP Interface defines a listening port and type (UDP, TCP, or TLS) for SIP signaling traffic on a specific logical IP network interface (configured in the Interface Table above) and Media Realm.

Note that the configuration of a SIP interface for the SIP Trunk and ATA device shows an example, which may be different to your configuration. For specific configuration of interfaces relating to SIP trunks and/or a third-party PSTN environment connected to the SBC, see the trunk / environment vendor documentation.

➤ **To configure SIP Interfaces:**

1. Open the SIP Interfaces table (**Setup** menu > **Signaling & Media** tab > **Core Entities** folder > **SIP Interfaces**).
2. Configure SIP Interfaces. You can use the default SIP Interface (Index 0), however, modify it as shown in the table below. The table below shows an example of the configuration. You can change some of the parameters according to your requirements.



**Note:** The Direct Routing interface can only use TLS for a SIP port. It does not support using TCP due to security reasons. The SIP port might be any port of your choice. When pairing the SBC with Office 365, the chosen port is specified in the pairing command.

**Table 4-4: Configuration Example of SIP Signaling Interfaces**

Index	Name	Network Interface	Application Type	UDP Port	TCP Port	TLS Port	Enable TCP Keepalive	Classification Failure Response Type	Media Realm	TLS Context Name
0	SIPTrunk (arbitrary name)	WAN_IF	SBC	5060 (according to Service Provider requirement)	0	0	Disable (leave default value)	500 (leave default value)	SIPTrunk	-
1	Teams (arbitrary name)	WAN_IF	SBC	0 (Phone System does not use UDP or TCP for SIP signaling)	0	5061 (as configured in the Office 365)	Enable	0 (Recommended to prevent DoS attacks)	Teams	Teams
2	ATA (arbitrary name)	LAN_IF	SBC	5060 (according to Service Provider requirement)	0	0	Disable (leave default value)	500 (leave default value)	ATA	-



**Note:** For implementing an MTLS connection with the Microsoft Teams network, configure 'TLS Mutual Authentication' to "Enable" for Teams SIP Interface.



**Note:** Loading Baltimore Trusted Root Certificates to AudioCodes' SBC is mandatory for implementing an MTLS connection with the Microsoft Teams network . Refer to Section 4.3.5 on page 26.

The configured SIP Interfaces are shown in the figure below:

**Figure 4-12: Configured SIP Interfaces in SIP Interface Table**

INDEX	NAME	SRD	NETWORK INTERFACE	APPLICATION TYPE	UDP PORT	TCP PORT	TLS PORT	ENCAPSULATION PROTOCOL	MEDIA REALM
0	SIPTrunk	DefaultSf	WAN_IF	SBC	5060	0	0	No encapsula	SIPTrunk
1	Teams	DefaultSf	WAN_IF	SBC	0	0	5061	No encapsula	Teams
2	ATA	DefaultSf	LAN_IF	SBC	5060	0	0	No encapsula	MRLan

## 4.6 Configure Proxy Sets and Proxy Address

### 4.6.1 Configure Proxy Sets

This section describes how to configure Proxy Sets. The Proxy Set defines the destination address (IP address or FQDN) of the IP entity server. Proxy Sets can also be used to configure load balancing between multiple servers.

For the example topology, Proxy Sets need to be configured for the following IP entities:

- Company SIP Trunk
- Teams Direct Routing

The Proxy Sets will later be applied to the VoIP network by assigning them to IP Groups.

➤ **To configure Proxy Sets:**

1. Open the Proxy Sets table (**Setup** menu > **Signaling & Media** tab > **Core Entities** folder > **Proxy Sets**).
2. Configure Proxy Sets as shown in the table below:

**Table 4-5: Configuration Example Proxy Sets in Proxy Sets Table**

Index	Name	SBC IPv4 SIP Interface	TLS Context Name	Proxy Keep-Alive	Proxy Hot Swap	Proxy Load Balancing Method
1	SIPTrunk (arbitrary name)	SIPTrunk	Default	Using Options	-	-
2	Teams (arbitrary name)	Teams	Teams	Using Options	Enable	Random Weights

The configured Proxy Sets are shown in the figure below:

**Figure 4-13: Configured Proxy Sets in Proxy Sets Table**

INDEX	NAME	SRD	GATEWAY IPV4 SIP INTERFACE	SBC IPV4 SIP INTERFACE	PROXY KEEP-ALIVE TIME [SEC]	REDUNDANCY MODE	PROXY HOT SWAP
0	ProxySet_0	DefaultSRD (#0)	--	ATA	60		Disable
1	SIPTrunk	DefaultSRD (#0)	--	SIPTrunk	60		Disable
2	Teams	DefaultSRD (#0)	--	Teams	60		Enable

## 4.6.2 Configure a Proxy Address

This section shows how to configure a Proxy Address for the SIP Trunk and Teams entities..

➤ **To configure a Proxy Address for SIP Trunk:**

1. Open the Proxy Sets table (Setup menu > **Signaling & Media** tab > **Core Entities** folder > Proxy Sets) and then click the Proxy Set **SIPTrunk**, and then click the **Proxy Address** link located below the table; the Proxy Address table opens.
2. Click **+New**; the following dialog box appears:

**Figure 4-14: Configuring Proxy Address for SIP Trunk**

3. Configure the address of the Proxy Set according to the parameters described in the table below:

**Table 4-6: Configuration Proxy Address for SIP Trunk**

Index	Proxy Address	Transport Type	Proxy Priority	Proxy Random Weight
0	SIPTrunk.com:5060 (SIP Trunk IP / FQDN and port)	UDP	0	0

4. Click **Apply**.

➤ **To configure a Proxy Address for Teams:**

1. Open the Proxy Sets table (**Setup** menu > **Signaling & Media** tab > **Core Entities** folder > **Proxy Sets**) and then click the Proxy Set **Teams**, and then click the **Proxy Address** link located below the table; the Proxy Address table opens.
2. Click **+New**; the following dialog box appears:

**Figure 4-15: Configuring Proxy Address for Teams Direct Routing Interface**

3. Configure the address of the Proxy Set according to the parameters described in the table below:

**Table 4-7: Configuration Proxy Address for Teams Direct Routing**

Index	Proxy Address	Transport Type	Proxy Priority	Proxy Random Weight
0	sip.pstnhub.microsoft.com:5061	TLS	1	1
1	sip2.pstnhub.microsoft.com:5061	TLS	2	1
2	sip3.pstnhub.microsoft.com:5061	TLS	3	1

4. Click **Apply**.

## 4.7 Configure Coders

This section describes how to configure coders (termed *Coder Group*). As Teams Direct Routing supports the SILK and OPUS coders while the network connection to Company SIP Trunk may restrict operation with a dedicated coders list, you need to add a Coder Group with the supported coders for each leg, the Teams Direct Routing and the Company SIP Trunk.

Note that the Coder Group ID for this entity will be assigned to its corresponding IP Profile in the next step.

➤ **To configure coders:**

1. Open the Coder Groups table (**Setup** menu > **Signaling & Media** tab > **Coders & Profiles** folder > **Coder Groups**).
2. Configure a Coder Group for Teams Direct Routing:

Parameter	Value
Coder Group Name	<b>AudioCodersGroups_1</b>
Coder Name	<ul style="list-style-type: none"> <li>▪ <b>SILK-NB</b></li> <li>▪ <b>SILK-WB</b></li> <li>▪ <b>G.711 A-law</b></li> <li>▪ <b>G.711 U-law</b></li> <li>▪ <b>G.729</b></li> </ul>

**Figure 4-16: Configuring Coder Group for Teams Direct Routing**

Coder Groups

Coder Group Name: 1 : AudioCodersGroups\_1 Delete Group

Coder Name	Packetization Time	Rate	Payload Type	Silence Suppression	Coder Specific
SILK-NB	20	8	103	N/A	
SILK-WB	20	16	104	N/A	
G.711A-law	20	64	8	Disabled	
G.711U-law	20	64	0	Disabled	
G.729	20	8	18	Disabled	


3. Click **Apply**, and then confirm the configuration change in the prompt that pops up.

The procedure below describes how to configure an Allowed Coders Group to ensure that voice sent to the Company SIP Trunk uses the dedicated coders list whenever possible. Note that this Allowed Coders Group ID will be assigned to the IP Profile belonging to the Company SIP Trunk in the next step.

➤ **To set a preferred coder for the Company SIP Trunk:**

1. Open the Allowed Audio Coders Groups table (**Setup** menu > **Signaling & Media** tab > **Coders & Profiles** folder > **Allowed Audio Coders Groups**).
2. Click **New** and configure a name for the Allowed Audio Coders Group for Company SIP Trunk.


**Figure 4-17: Configuring Allowed Coders Group for Company SIP Trunk**



3. Click **Apply**.
4. Select the new row that you configured, and then click the **Allowed Audio Coders** link located below the table; the Allowed Audio Coders table opens.
5. Click **New** and configure an Allowed Coders as follows:

Parameter	Value
Index	<b>0</b>
Coder	<b>G.729</b>

**Figure 4-18: Configuring Allowed Coders for Company SIP Trunk**



- Open the Media Settings page (**Setup** menu > **Signaling & Media** tab > **Media** folder > **Media Settings**).

**Figure 4-19: SBC Preferences Mode**

Media Settings

<b>GENERAL</b>		<b>ROBUSTNESS</b>	
<b>NAT Traversal</b>	Disable NAT	New RTP Stream Packets	3
Enable Continuity Tones	Disable	New RTCP Stream Packets	3
Inbound Media Latch Mode	Dynamic	New SRTP Stream Packets	3
Number of Media Channels	0	New SRTCP Stream Packets	3
Enforce Media Order	Disable	Timeout To Relatch RTP (msec)	200
SDP Session Owner	AudiocodesGW	Timeout To Relatch SRTP (msec)	200
		Timeout To Relatch Silence (msec)	10000
		Timeout To Relatch RTCP (msec)	10000

<b>SBC SETTINGS</b>	
Preferences Mode	• Include Extensions
Enforce Media Order	Disable

<b>GATEWAY SETTINGS</b>	
Enable Early Media	Disable
Multiple Packetization Time Format	None

Cancel APPLY

- From the '**Preferences Mode**' drop-down list, select **Include Extensions**.
- Click **Apply**.

## 4.8 Configure IP Profiles

This section describes how to configure IP Profiles. The IP Profile defines a set of call capabilities relating to signaling (e.g., SIP message terminations such as REFER) and media (e.g., coder and transcoding method).

In this example topology, IP Profiles need to be configured for the following IP entities:

- Company SIP trunk – to operate in non-secure mode using RTP and SIP over UDP
- Teams Direct Routing – to operate in secure mode using SRTP and SIP over TLS
- ATA device – to operate in non-secure mode using RTP and SIP over UDP

➤ **To configure an IP Profile for the Company SIP Trunk:**

1. Open the IP Profiles table (**Setup** menu > **Signaling & Media** tab > **Coders & Profiles** folder > **IP Profiles**).
2. Click **New**, and then configure the parameters as follows:

Parameter	Value
<b>General</b>	
Index	<b>1</b>
Name	<b>SIPTrunk</b>
<b>Media Security</b>	
SBC Media Security Mode	<b>Not Secured</b>
<b>SBC Media</b>	
Allowed Audio Coders	<b>SIPTrunk Allowed Coders</b>
Allowed Coders Mode	<b>Preference</b> (lists Allowed Coders first and then original coders in received SDP offer)
<b>SBC Signaling</b>	
P-Asserted-Identity Header Mode	<b>Add</b> (required for anonymous calls)
<b>SBC Forward and Transfer</b>	
Remote REFER Mode	<b>Handle Locally</b>
Remote Replaces Mode	<b>Handle Locally</b>
Remote 3xx Mode	<b>Handle Locally</b>

Figure 4-20: Configuration example: Company SIP Trunk IP Profile

3. Click **Apply**.

➤ **To configure IP Profile for the Teams Direct Routing:**

1. Open the IP Profiles table (**Setup** menu > **Signaling & Media** tab > **Coders & Profiles** folder > **IP Profiles**).
2. Click **New**, and then configure the parameters as follows:

Parameter	Value
<b>General</b>	
Index	<b>2</b>
Name	<b>Teams</b> (arbitrary descriptive name)
<b>Media Security</b>	
SBC Media Security Mode	<b>Secured</b>
<b>SBC Early Media</b>	
Remote Early Media RTP Detection Mode	<b>By Media</b> (required, as Teams Direct Routing does not send RTP immediately to remote side when it sends a SIP 18x response)
<b>SBC Media</b>	
Extension Coders Group	<b>AudioCodersGroups_1</b>
RTCP Mode	<b>Generate Always</b> (required, as some ITSPs do not send RTCP packets during while in Hold mode, but Microsoft expected to them)
ICE Mode	<b>Lite</b> (required only when Media Bypass enabled on Teams)

SBC Signaling	
SIP UPDATE Support	<b>Not Supported</b>
Remote re-INVITE Support	<b>Supported Only With SDP</b>
Remote Delayed Offer Support	<b>Not Supported</b>
SBC Forward and Transfer	
Remote REFER Mode	<b>Handle Locally</b>
Remote 3xx Mode	<b>Handle Locally</b>
SBC Hold	
Remote Hold Format	<b>Inactive</b> (some SIP Trunk may answer with a=inactive and IP=0.0.0.0 in response to the Re-Invite with Hold request from Teams. Microsoft Media Stack doesn't support this format. So, SBC will replace 0.0.0.0 with its IP address)
All other parameters can be left unchanged at their default values.	

Figure 4-21: Configuration example: Teams Direct Routing IP Profile

The screenshot shows the configuration window for an IP Profile named 'Teams'. It is divided into two main sections: GENERAL and SBC SIGNALING.

**GENERAL Section:**

- Index: 2
- Name: Teams
- Created by Routing Server: No

**MEDIA SECURITY Section:**

- SBC Media Security Mode: Secured
- Gateway Media Security Mode: Preferable
- Symmetric MKI: Disable
- MKI Size: 0
- SBC Enforce MKI Size: Don't enforce
- SBC Media Security Method: SDES
- Reset SRTP Upon Re-key: Disable

**SBC SIGNALING Section:**

- PRACK Mode: Transparent
- P-Asserted-Identity Header Mode: As Is
- Diversion Header Mode: As Is
- History-Info Header Mode: As Is
- Session Expires Mode: Transparent
- SIP UPDATE Support: Not Supported
- Remote re-INVITE: Supported only with SDP
- Remote Delayed Offer Support: Not Supported
- MSRP re-INVITE/UPDATE: Supported
- MSRP Offer Setup Role: ActPass
- MSRP Empty Message Format: Default
- Remote Representation Mode: According to Operation Mode

At the bottom of the window, there are 'Cancel' and 'APPLY' buttons.

3. Click **Apply**.
- **To configure an IP Profile for the ATA device:**
1. Open the IP Profiles table (**Setup** menu > **Signaling & Media** tab > **Coders & Profiles** folder > **IP Profiles**).

- Click **New**, and then configure the parameters as follows:

Parameter	Value
<b>General</b>	
Index	<b>3</b>
Name	<b>ATA</b>
<b>Media Security</b>	
SBC Media Security Mode	<b>Not Secured</b>
<b>SBC Forward and Transfer</b>	
Remote REFER Mode	<b>Handle Locally</b>
Remote Replaces Mode	<b>Handle Locally</b>
Remote 3xx Mode	<b>Handle Locally</b>

**Figure 4-22: Configuration example: ATA device IP Profile**

- Click **Apply**.

## 4.9 Configure IP Groups

This section describes how to configure IP Groups. The IP Group represents an IP entity on the network with which the SBC communicates. This can be a server (e.g., IP PBX or ITSP) or it can be a group of users (e.g., LAN IP phones). For servers, the IP Group is typically used to define the server's IP address by associating it with a Proxy Set. Once IP Groups are configured, they are used to configure IP-to-IP routing rules for denoting source and destination of the call.

In this example topology, IP Groups must be configured for the following IP entities:

- Company SIP Trunk located on WAN
- Teams Direct Routing located on WAN
- ATA device located on LAN

### ➤ To configure IP Groups:

1. Open the IP Groups table (**Setup** menu > **Signaling & Media** tab > **Core Entities** folder > **IP Groups**).
2. Configure an IP Group for the Company SIP Trunk:

Parameter	Value
Index	<b>1</b>
Name	<b>SIPTrunk</b>
Type	<b>Server</b>
Proxy Set	<b>SIPTrunk</b>
IP Profile	<b>SIPTrunk</b>
Media Realm	<b>MR-SIPTrunk</b>
SIP Group Name	(according to ITSP requirement)
All other parameters can remain unchanged with their default values.	

3. Configure an IP Group for the Teams Direct Routing:

Parameter	Value
Index	<b>2</b>
Name	<b>Teams</b>
Topology Location	<b>Up</b>
Type	<b>Server</b>
Proxy Set	<b>Teams</b>
IP Profile	<b>Teams</b>
Media Realm	<b>MR-Teams</b>
Classify By Proxy Set	<b>Disable</b>
Local Host Name	<b>&lt; FQDN name of the SBC in the enterprise Teams tenant &gt;</b> (For example, <i>sbc.ACeducation.info</i> )
Always Use Src Address	<b>Yes</b>
Proxy Keep-Alive using IP Group settings	<b>Enable</b>
All other parameters can be left unchanged with their default values.	

4. Configure an IP Group for the ATA device:

Parameter	Value
Index	3
Name	ATA
Topology Location	Up
Type	User
IP Profile	ATA
Media Realm	MRLan
SIP Group Name	(according to ITSP requirement)
All other parameters can remain unchanged with their default values.	

The configured IP Groups are shown in the figure below:

**Figure 4-23: Configured IP Groups in IP Group Table**

IP Groups (4)

+ New Edit Page 1 of 1 Show 10 records per page

INDEX	NAME	SRD	TYPE	SBC OPERATION MODE	PROXY SET	IP PROFILE	MEDIA REALM	SIP GROUP NAME	CLASSIFY BY PROXY SET	INBOUND MESSAGE MANIPULATION SET	OUTBOUND MESSAGE MANIPULATION SET
0	Default_IPG	DefaultS	Server	Not Configu	ProxySet_0	--	--		Disable	-1	-1
1	SIPTrunk	DefaultS	Server	Not Configu	SIPTrunk	SIPTrunk	SIPTrunk	interop.adp	Enable	-1	4
2	Teams	DefaultS	Server	Not Configu	Teams	Teams	Teams	interop.adp	Enable	-1	-1
3	ATA	DefaultS	User	Not Configu	--	ATA	MRLan	interop.adp	Enable	-1	-1

## 4.10 Configure SRTP

This section describes how to configure media security. The Direct Routing Interface needs to use of SRTP only, so you need to configure the SBC to operate in the same manner.

➤ **To configure media security:**

1. Open the Media Security page (**Setup menu > Signaling & Media tab > Media folder > Media Security**).
2. From the 'Media Security' drop-down list, select **Enable** to enable SRTP.

**Figure 4-24: Configuring SRTP**



The screenshot shows the 'Media Security' configuration page. It is divided into two sections: 'GENERAL' and 'MASTER KEY IDENTIFIER'. In the 'GENERAL' section, the 'Media Security' dropdown is set to 'Enable', indicated by an arrow. Other settings include 'Media Security Behavior' (Preferable), 'Offered SRTP Cipher Suites' (All), and 'Aria Protocol Support' (Disable). In the 'MASTER KEY IDENTIFIER' section, 'Master Key Identifier (MKI) Size' is set to 0 and 'Symmetric MKI' is set to Disable.

Media Security	
GENERAL	
Media Security	Enable
Media Security Behavior	Preferable
Offered SRTP Cipher Suites	All
Aria Protocol Support	Disable
MASTER KEY IDENTIFIER	
Master Key Identifier (MKI) Size	0
Symmetric MKI	Disable

3. Click **Apply**.

## 4.11 Configuring Message Condition Rules


This section describes how to configure the Message Condition Rules. A Message Condition defines special conditions (pre-requisites) for incoming SIP messages. These rules can be used as additional matching criteria for the IP-to-IP routing rules in the IP-to-IP Routing table. The following condition verifies that the Contact header contains Microsoft Teams FQDN.

➤ **To configure a Message Condition rule:**

1. Open the Message Conditions table (**Setup** menu > **Signaling & Media** tab > **Message Manipulation** folder > **Message Conditions**).
2. Click **New**, and then configure the parameters as follows:

Parameter	Value
Index	0
Name	Teams-Contact (arbitrary descriptive name)
Condition	header.contact.url.host contains 'pstnhub.microsoft.com'

Figure 4-25: Configuring Condition Table



3. Click **Apply**.

## 4.12 Configure Classification Rules

This section describes how to configure Classification rules. A Classification rule classifies incoming SIP dialog-initiating requests (e.g., INVITE messages) to a 'source' IP Group. The source IP Group is the SIP entity that sent the SIP dialog request. Once classified, the device uses the IP Group to process the call (manipulation and routing).

You can also use the Classification table for employing SIP-level access control for successfully classified calls, by configuring Classification rules with whitelist and blacklist settings. If a Classification rule is configured as a whitelist ("Allow"), the device accepts the SIP dialog and processes the call. If the Classification rule is configured as a blacklist ("Deny"), the device rejects the SIP dialog.

➤ **To configure a Classification rule:**

1. Open the Classification table (**Setup** menu > **Signaling & Media** tab > **SBC** folder > **Classification Table**).
2. Click **New**, and then configure classification rule for messages from Teams as follows:

Parameter	Value
Index	0
Name	Teams
Source SIP Interface	Teams
Source IP Address	52.114.*.*
Destination Host	sbc.ACeducation.info
Message Condition	Teams-Contact
Action Type	Allow
Source IP Group	Teams

**Figure 4-26: Configuring Classification Rule for Teams**

The screenshot shows the 'Classification [Teams]' configuration window. At the top, there is a dropdown for 'SRD' set to '#0 [DefaultSRD]'. The window is divided into two main sections: 'MATCH' and 'ACTION'.

**MATCH Section:**

- Index: 0
- Name: Teams
- Source SIP Interface: #2 [Teams]
- Source IP Address: 52.114.\*.\*
- Source Transport Type: Any
- Source Port: 0
- Source Username Pattern: \*
- Source Host: \*
- Destination Username Pattern: \*
- Destination Host: sbc.ACeducation.info
- Message Condition: #0 [Teams-Contact]

**ACTION Section:**

- Action Type: Allow
- Destination Routing Policy: ..
- IP Group Selection: Source IP Group
- Source IP Group: #2 [Teams]
- IP Group Tag Name: default
- IP Profile: ..

At the bottom of the window, there are 'Cancel' and 'APPLY' buttons.

3. Click **Apply**.

- Click **New**, and then configure classification rule for messages from ATA device as follows:

Parameter	Value
Index	1
Name	ATA Users
Source SIP Interface	ATA
Source Username Pattern	+12345678901
Action Type	Allow
Source IP Group	ATA

Figure 4-27: Configuring Classification Rule for ATA users

The screenshot shows the configuration interface for a classification rule named "ATA Users". At the top, there is a dropdown for "SRD" set to "#0 [DefaultSRD]". Below this, the configuration is split into two columns: "MATCH" and "ACTION".

**MATCH Section:**

- Index: 1
- Name: ATA Users
- Source SIP Interface: #2 [ATA]
- Source IP Address: (empty)
- Source Transport Type: Any
- Source Port: 0
- Source Username Pattern: +12345678901
- Source Host: \*
- Destination Username Pattern: \*
- Destination Host: \*

**ACTION Section:**

- Action Type: Allow
- Destination Routing Policy: --
- IP Group Selection: Source IP Group
- Source IP Group: #3 [ATA]
- IP Group Tag Name: default
- IP Profile: --

At the bottom of the window, there are "Cancel" and "APPLY" buttons.

- Click **Apply**.

## 4.13 Configure IP-to-IP Call Routing Rules

This section describes how to configure IP-to-IP call routing rules. These rules define the routes for forwarding SIP messages (e.g., INVITE) received from one IP entity to another. The SBC selects the rule whose configured input characteristics (e.g., IP Group) match those of the incoming SIP message. If the input characteristics do not match the first rule in the table, they are compared to the second rule, and so on, until a matching rule is located. If no rule is matched, the message is rejected. The routing rules use the configured IP Groups (as configured in Section 4.9 on page 39) to denote the source and destination of the call.

For the example topology, the following IP-to-IP routing rules need to be configured to route calls between Teams Direct Routing and Company SIP Trunk:

- Terminate SIP OPTIONS messages on the SBC that are received from any entity
- REGISTER requests from ATA device
- Re-Route REFER messages to Teams Direct Routing
- Calls from Teams Direct Routing to Company SIP Trunk
- Calls from Company SIP Trunk to ATA device
- Calls from Company SIP Trunk to Teams Direct Routing
- Calls from ATA device to Teams Direct Routing
- Calls from ATA device to Company SIP Trunk

➤ **To configure IP-to-IP routing rules:**

1. Open the IP-to-IP Routing table (**Setup** menu > **Signaling & Media** tab > **SBC** folder > **Routing** > **IP-to-IP Routing**).
2. Configure routing rules as shown in the table below:

**Table 4-8: Configuration Example: IP-to-IP Call Routing Rules**

Index	Name	Source IP Group	Request Type	Dest Username Pattern	Call Trigger	ReRoute IP Group	Dest Type	Dest IP Group	Internal Action
0	Terminate OPTIONS	Any	OPTIONS				Internal		Reply(Response ='200')
1	ATA Registration	ATA	REGISTER				All Users		
2	Refer re-routing (arbitrary name)	Any			REFER	Teams	Request URI	Teams	
3	To ATA	Any		+12345678 90			IP Group	ATA	
4	Teams to SIP Trunk	Teams					IP Group	SIPTrunk	
5	SIP Trunk to Teams	SIPTrunk					IP Group	Teams	
6	ATA to Teams	ATA		12345xxxx #			IP Group	Teams	
7	ATA to SIP Trunk	ATA					IP Group	SIPTrunk	

The configured routing rules are shown in the figure below:

**Figure 4-28: Configured IP-to-IP Routing Rules in IP-to-IP Routing Table**

IP-to-IP Routing (8)

+ New Edit Insert ↑ ↓ 🗑️ Page 1 of 1 Show 10 records per page 🔍

INDEX ↕	NAME	ROUTING POLICY	ALTERNATIVE ROUTE OPTIONS	SOURCE IP GROUP	REQUEST TYPE	SOURCE USERNAME PATTERN	DESTINATION USERNAME PATTERN	DESTINATION TYPE	DESTINATION IP GROUP	DESTINATION SIP INTERFACE	DESTINATION ADDRESS
0	Terminate OPTIK	Default_SBCRou	Route Row	Any	OPTIONS	*	*	Internal	--	--	
1	ATA Registration	Default_SBCRou	Route Row	ATA	REGISTER	*	*	All Users	--	--	
2	Refer re-routing	Default_SBCRou	Route Row	Any	All	*	*	Request URI	Teams	--	
3	To ATA	Default_SBCRou	Route Row	Any	All	*	+1234567890	IP Group	ATA	--	
4	Teams to BCLD	Default_SBCRou	Route Row	Teams	All	*	*	IP Group	SIPTrunk	--	
5	BCLD to Teams	Default_SBCRou	Route Row	SIPTrunk	All	*	*	IP Group	Teams	--	
6	ATA to Teams	Default_SBCRou	Route Row	ATA	All	*	12345xxxxx#	IP Group	Teams	--	
7	ATA to BCLD	Default_SBCRou	Route Row	ATA	All	*	*	IP Group	SIPTrunk	--	



**Note:** The routing configuration may change according to your specific deployment topology.

## 4.14 Configure Firewall Settings

As a security measure, there is an option to configure traffic filtering rules (*access list*) for incoming traffic on AudioCodes SBC. For each packet received on the configured network interface, the SBC searches the table from top to bottom until the first matching rule is found. The matched rule can permit (*allow*) or deny (*block*) the packet. Once a rule in the table is located, subsequent rules further down the table are ignored. If the end of the table is reached without a match, the packet is accepted. Please note that the firewall is stateless. The blocking rules will apply to all incoming packets, including UDP or TCP responses.

➤ **To configure a firewall rule:**

1. Open the Firewall table (**Setup** menu > **IP Network** tab > **Security** folder > **Firewall**).
2. Configure the following Access list rules for Teams Direct Rout IP Interface:

**Table 2-9: Firewall Table Rules**

Index	Source IP	Subnet Prefix	Start Port	End Port	Protocol	Use Specific Interface	Interface ID	Allow Type
0	<Public DNS Server IP> (e.g. 8.8.8.8)	32	0	65535	Any	Enable	WAN_IF	Allow
1	52.114.148.0	32	0	65535	TCP	Enable	WAN_IF	Allow
2	52.114.132.46	32	0	65535	TCP	Enable	WAN_IF	Allow
3	52.114.75.24	32	0	65535	TCP	Enable	WAN_IF	Allow
4	52.114.76.76	32	0	65535	TCP	Enable	WAN_IF	Allow
5	52.114.7.24	32	0	65535	TCP	Enable	WAN_IF	Allow
6	52.114.14.70	32	0	65535	TCP	Enable	WAN_IF	Allow
49	0.0.0.0	0	0	65535	Any	Enable	WAN_IF	Block



**Note:** Be aware that if in your configuration, connectivity to SIP Trunk (or other entities) is performed through the same IP Interface as Teams (WAN\_IF in our example), you must add rules to allow traffic from these entities.

**This page is intentionally left blank.**

## 5 Verify the Pairing Between the SBC and Direct Routing

After you have paired the SBC with Teams Direct Routing using the *New-CsOnlinePSTNGateway* PowerShell command, validate that the SBC can successfully exchange OPTIONS with Direct Routing.

➤ **To validate the pairing using SIP OPTIONS:**

1. Open the Proxy Set Status page (**Monitor** menu > **VoIP Status** tab > **Proxy Set Status**).
2. Find the Direct SIP connection and verify that 'Status' is online. If you see a failure, you need to troubleshoot the connection first, before configuring voice routing.

**Figure 5-1: Proxy Set Status**

Proxy Sets Status									
This page refreshes every 60 seconds									
PROXY SET ID	NAME	MODE	KEEP ALIVE	ADDRESS	PRIORITY	WEIGHT	SUCCESS COUNT	FAILURE COUNT	STATUS
0	ProxySet_0	Parking	Disabled						NOT RESOLVED
1	SIPTrunk	Parking	Enabled	nn6300southsipconnect.adpt-tech.com(199.19.196.17:8933)(*)	1	50.00	4816	8	ONLINE
2	Teams	Load Balancing	Enabled	sip.pstnhub.microsoft.com(52.114.75.24:5061)(*)	1	1.00	1	0	ONLINE
				sip2.pstnhub.microsoft.com(52.114.132.46:5061)(*)	2	1.00	1	0	ONLINE
				sip3.pstnhub.microsoft.com(52.114.14.70:5061)(*)	3	1.00	1	0	ONLINE

**This page is intentionally left blank.**


## 6 Verify ATA Registered Users in the SBC

You can view SBC users that are registered with the device. For each user, the Address of Record (AOR) and the corresponding contacts are shown.

➤ **To view registered SBC users:**

1. Open the SBC Registered Users page (**Monitor menu > Monitor tab > VoIP Status folder > SBC Registered Users**).

**Figure 6-1: SBC Registered Users**



**This page is intentionally left blank.**

## A Configuring MP-1xx ATA for Connecting Analog Devices

This section describes how to configure AudioCodes MediaPack™ Series (MP-1xx) VoIP Gateways for connecting analog devices. The ATA device must be configured to send all calls to the AudioCodes SBC.



**Note:** This section shows partial configuration. For detailed configuration of the MediaPack MP-1xx Series refer to the device's *User's Manual* (<https://www.audiocodes.com/library/technical-documents?query=MP-11x>).

### A.1 Configure Proxy Server and Registration

This section describes how to configure the proxy server and registration. The configuration below uses the example of an ATA device registered to the SBC device (10.15.17.55).

➤ **To configure Proxy Server and Registration:**

1. Open the Proxy & Registration page (Configuration tab > VoIP menu > SIP Definitions sub-menu > Proxy & Registration).


**Figure A-1: Proxy and Registration**

Proxy & Registration	
Use Default Proxy	Yes
Proxy Set Table	
Proxy Name	10.15.77.55
Redundancy Mode	Parking
Proxy IP List Refresh Time	60
Enable Fallback to Routing Table	Disable
Prefer Routing Table	No
Use Routing Table for Host Names and Profiles	Disable
Always Use Proxy	Disable
Redundant Routing Mode	Routing Table
SIP ReRouting Mode	Standard Mode
Enable Registration	Enable
Registrar Name	
Registrar IP Address	
Registrar Transport Type	Not Configured
Registration Time	180
Re-registration Timing [%]	50
Registration Retry Time	30
Registration Time Threshold	0
Re-register On INVITE Failure	Disable
ReRegister On Connection Failure	Disable
Gateway Name	10.15.77.55
Gateway Registration Name	
DNS Query Type	A-Record
Proxy DNS Query Type	A-Record
Subscription Mode	Per Endpoint
Number of RTX Before Hot-Swap	3
Use Gateway Name for OPTIONS	No

2. From the 'Use Default Proxy' drop-down list, select **Yes**.
3. In the 'Proxy Name' field, enter the SBC IP address.

4. From the 'Enable Registration' drop-down list, select **Enable**.
5. In the 'Gateway Name' field, enter the SBC IP address.
6. Click the **Proxy Set Table** button, the following page is displayed:

**Figure A-2: Default Proxy Sets Table**



Default Proxy Sets Table

Proxy Set ID: 0

	Proxy Address	Transport Type
1	10.15.77.55	UDP
2		
3		
4		
5		

Enable Proxy Keep Alive: Disable  
 Proxy Keep Alive Time: 60  
 Proxy Load Balancing Method: Disable  
 Is Proxy Hot Swap: No


7. In the 'Proxy Address' field, enter the SBC IP address.
8. Click the **Apply** button.

## A.2 Configure the Endpoint Phone Number Table

The 'Endpoint Phone Number Table' page allows you to activate the MP-1xx ports (endpoints) by defining telephone numbers. The configuration below uses the example of ATA destination phone number '+12345678901' with all routing directed to the SBC device (10.15.17.55).

- **To configure the Endpoint Phone Number table:**
1. Open the Endpoint Phone Number Table page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** submenu > **Hunt Group** sub-menu > **Endpoint Phone Number**).

**Figure A-3: Endpoint Phone Number Table Page**



Endpoint Phone Number Table

	Channel(s)	Phone Number	Hunt Group ID	Tel Profile ID
1	1	+12345678901	1	0
2				
3				
4				

### A.3 Configure the Hunt Group

This section describes how to configure the Hunt Group.

➤ **To configure Hunt Group:**

1. Open the Hunt Group Settings page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** sub-menu > **Hunt Group** > **Hunt Group Settings**).

**Figure A-4: Hunt Group Settings**

Hunt Group ID	Channel Select Mode	Registration Mode	Serving IP Group ID	Gateway Name	Contact User
1	By Dest Phone Number	Per Endpoint			
2					
3					
4					
5					

2. From the 'Channel Select Mode' drop-down list, select **By Dest Phone Number**.
3. From the 'Registration Mode' drop-down list, select **Per Endpoint**.
4. Click the **Apply** button.

### A.4 Configure IP-to-Hunt Group Routing

This section describes how to configure the IP-to-Hunt Group routing rules.

➤ **To configure the IP to Hunt Group Routing table:**

1. Open the Tel to IP Routing page (**Configuration** tab > **VoIP** menu > **GW and IP to IP** sub-menu > **Routing** > **IP to Hunt Group Routing**).

**Figure A-5: IP to Hunt Group Routing Page**

Dest. Host Prefix	Source Host Prefix	Dest. Phone Prefix	Source Phone Prefix	Source IP Address	Hunt Group ID	IP Profile ID	Source IP Group ID
*	*	*	*	*	1	0	-1

2. Configure the entry as shown in the screen above.
3. Click the **Apply** button.

## A.5 Configure SIP UDP Transport Type and Fax Signaling Method

In most cases ATA device is used for interconnection fax devices. This step describes how to configure the fax signaling method for the MP-1xx device.

➤ To configure the fax signaling method:

1. Open the SIP General Parameters page (**Configuration** tab > **VoIP** menu > **SIP Definitions** submenu > **General Parameters**).

Figure A-6: SIP General Parameters Page

SIP General Parameters	
Basic Parameter List ▲	
▼ SIP General	
NAT IP Address	0.0.0.0
PRACK Mode	Supported
Channel Select Mode	By Dest Phone Number
Enable Early Media	Disable
183 Message Behavior	Progress
Session-Expires Time	0
Minimum Session-Expires	90
Session Expires Method	re-INVITE
Asserted Identity Mode	Disabled
Fax Signaling Method	T.38 Relay
Detect Fax on Answer Tone	Initiate T.38 on Preamble
SIP Transport Type	UDP
SIP UDP Local Port	5060
SIP TCP Local Port	5060
SIP TLS Local Port	5061
Enable SIPS	Disable
Enable TCP Connection Reuse	Enable
TCP Timeout	0
SIP Destination Port	5060

2. From the 'FAX Signaling Method' drop-down list, select **G.711 Transport** for G.711 fax support and select **T.38 Relay** for T.38 fax support.
3. From the 'SIP Transport Type' drop-down list, select **UDP**.
4. In the 'SIP UDP Local Port' field, enter **5060** (corresponding to the SBC configuration).
5. In the 'SIP Destination Port', enter **5060** (corresponding to the SBC configuration).

## B Configuring MP-20x ATA for Connecting Analog Devices

This section describes how to configure AudioCodes MediaPack™ Series (MP-20x) Telephony Adapter for connecting analog devices. The ATA device must be configured to send all calls to the AudioCodes SBC.



**Note:** This section shows partial configuration. For detailed configuration of the MediaPack MP-20x Series refer to the device's *User's Manual* (<https://www.audiocodes.com/library/technical-documents?query=MP-20x>).

### B.1 Configure SIP Interface Settings

This section describes how to configure SIP Signaling Protocol.

➤ **To configure SIP Interface Settings:**

1. Click the **Voice Over IP** menu in the side menu bar; the Voice Over IP screen appears.

**Figure B-1: Signaling Protocol Page**

**Voice Over IP**

Signaling Protocol | Dialing | Media Streaming | Voice and Fax | Services | Line Settings | Extension Settings | Speed Dial | Telephone Interface | HTTPS Fax Connections

**Signaling Protocol**

Signaling Protocol: SIP

SIP Transport Protocol: UDP

Local SIP Port: 5060

Gateway Name - User Domain:

Enable PRACK

Include ptime in SDP

Enable rport

Connect media on 180

**SIP Proxy and Registrar**

Use SIP Proxy

Host Name or Address: 10.15.77.55

Proxy Port: 5060

Maximum Number of Authentication Retries: 4

Use SIP Proxy IP and Port for Registration

Register Expires: 3600 Seconds

Register Failed Expires: 60 Seconds

Sip Security: Allow All SIP traffic

Redundancy Mode: None

Enable Keep Alive

Use SIP Outbound Proxy

**SIP Timers**

Retransmission Timer T1: 500 milliseconds

Retransmission Timer T2: 4000 milliseconds

Retransmission Timer T4: 5000 milliseconds

INVITE Timer: 32000 milliseconds

Session-Expires: 0 Seconds

Min-SE: 0 Seconds

OK Apply Cancel Basic <<


2. On the **Signaling Protocol** page, the following parameters enable configuration:
  - a. From the 'SIP Transport Type' drop-down list, select **UDP**.
  - b. In the 'Local SIP Port' field, enter **5060** (corresponding to the SBC configuration)
  - c. In the 'Use SIP Proxy' check the check box.
  - d. In the 'Host Name or Address' field, set the IP address of the SBC.
  - e. In the 'Use SIP Proxy IP and Port for Registration' check the check box.

## B.2 Configure Media Streaming Parameters

The section describes how to configure Media Streaming Parameters.

- **To configure Media Streaming Parameters:**
  1. Click the **Media Streaming** tab. The Media Streaming screens opens, which enables you to configure the following:
    - Supported Codecs
    - Codecs Priority
    - Packetization Time

**Figure B-2: Media Streaming Page**



## B.3 Configuring Line Settings

Before you can make phone calls, you need to configure lines. Lines are logical SIP ID numbers (i.e., telephone numbers) which are registered to a SIP proxy server and for which you are charged for calls you make on it. With a MP-20x line setting configuration, you can associate any phone extension to any line.

➤ **To configure lines:**


1. On the 'Voice Over IP' screen, click the **Line Settings** tab; the following screen appears.

**Figure B-3: Line Settings Tab Screen**



2. For each line, click the corresponding **Edit** icon to configure the line; the following screen appears:

**Figure B-4: Line Settings Screen for a New Line**



3. In the 'User ID' field, enter phone's VoIP user ID used for identification to initiate and accept calls.
4. To hide the phone's ID from the remote party, select the 'Block Caller ID' check box.
5. In the 'Display Name' field, enter a name to intuitively identify the line. This is also displayed to remote parties as your caller ID.
6. Click **OK** to save your settings.

**This page is intentionally left blank.**

## C Syntax Requirements for SIP Messages 'INVITE' and 'OPTIONS'

The syntax of SIP messages must conform with Teams Direct Routing requirements.

This section covers the high-level requirements for the SIP syntax used in 'INVITE' and 'OPTIONS' messages. You can use the information presented here as a first step when troubleshooting unsuccessful calls. AudioCodes has found that most errors are related to incorrect syntax in SIP messages.

### C.1 Terminology

<b>Must</b>	Strictly required. The deployment does not function correctly without the correct configuration of these parameters.
-------------	--

### C.2 Syntax Requirements for 'INVITE' Messages

Figure C-1: Example of an 'INVITE' Message

```
INVITE sip:+97249888108@10.15.40.55;user=phone SIP/2.0
Via: SIP/2.0/TLS sbc.ACeducation.info:5068;alias;branch=z9hG4bKac496289557
Max-Forwards: 69
From: <sip:+97239762000@10.15.77.12>;tag=1c1642854452
To: <sip:+97249888108@10.15.40.55;user=phone>
Call-ID: 1167963076285201992217@ACeducation.info
CSeq: 1 INVITE
Contact: <sip:+97239762000@sbc.ACeducation.info:5068;transport=tls>
Supported: em,100rel,timer,replaces,path,resource-priority,sdp-angat
Allow: REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
User-Agent: 10.15.40.55/v.7.20A.250.273
Content-Type: application/sdp
Content-Length: 1114
```

- **Contact** header
  - **MUST:** When placing calls to the Direct Routing interface, the 'CONTACT' header must have the SBC FQDN in the URI hostname
  - **Syntax:** *Contact:* <phone number>@<FQDN of the SBC>:<SBC Port>;<transport type>
  - If the parameter is not configured correctly, calls are rejected with a '403 Forbidden' message.

### C.3 Requirements for 'OPTIONS' Messages Syntax

Figure C-2: Example of 'OPTIONS' message

```

OPTIONS sip:195.189.192.171 SIP/2.0
Via: SIP/2.0/TLS sbc.ACeducation.info:5068;alias;branch=z9hG4bKac1385438539
Max-Forwards: 70
From: <sip:195.189.192.171>;tag=1c1890841146
To: <sip:195.189.192.171>
Call-ID: 59585523229520193103@ACeducation.info
CSeq: 1 OPTIONS
Contact: <sip:sbc.ACeducation.info:5068;transport=tls>
Allow: REGISTER,OPTIONS,INVITE,ACK,CANCEL,BYE,NOTIFY,PRACK,REFER,INFO,SUBSCRIBE,UPDATE
User-Agent: 10.15.40.55/v.7.20A.250.273
Accept: application/sdp, application/simple-message-summary, message/sipfrag
Content-Length: 0
    
```

- **Contact header**
  - **MUST:** When placing calls to the Direct Routing interface, the 'CONTACT' header must have the SBC FQDN in the URI hostname
  - **Syntax:** *Contact: <phone number>@<FQDN of the SBC>:<SBC Port>;<transport type>*
  - If the parameter is not configured correctly, the calls are rejected with a '403 Forbidden' message

The table below navigates to the path in the Web interface where the parameters are configured and refers to the relevant location in this document including the configuration instructions.

Table C-1: Syntax Requirements for an 'OPTIONS' Message

Parameter	Where Configured	How to Configure
<b>Contact</b>	<p><b>Setup &gt; Signaling and Media &gt; Core Entities &gt; IP Groups &gt; &lt;Group Name&gt; &gt; Local Host Name</b></p> <p>In IP Groups, 'Contact' must be configured. In this field ('Local Host Name'), define the local host name of the SBC as a string, for example, <i>sbc.ACeducation.info</i>. The name changes the host name in the call received from the IP group.</p>	See Section 4.9 Configure IP Groups

## C.4 Connectivity Interface Characteristics

The table below shows the technical characteristics of the Direct Routing interface.

In most cases, Microsoft uses RFC standards as a guide during development, but does not guarantee interoperability with SBCs - even if they support all the parameters in the table below - due to the specifics of the implementation of the standards by SBC vendors.

Microsoft has a partnership with some SBC vendors and guarantees their devices' interoperability with the interface. All validated devices are listed on Microsoft's website. Microsoft only supports devices *that are validated* in order to connect to the Direct Routing interface.

AudioCodes is one of the vendors who are in partnership with Microsoft.

AudioCodes' SBCs are validated by Microsoft to connect to the Direct Routing interface.

**Table C-2: Teams Direct Routing Interface - Technical Characteristics**

Category	Parameter	Value	Comments
Ports and IP ranges	SIP Interface FQDN Name	See Microsoft's document <i>Deploying Direct Routing Guide</i> .	-
	IP Addresses range for SIP interfaces	See Microsoft's document <i>Deploying Direct Routing Guide</i> .	-
	SIP Port	5061	-
	IP Address range for Media	See Microsoft's document <i>Deploying Direct Routing Guide</i> .	-
	Media port range on Media Processors	See Microsoft's document <i>Deploying Direct Routing Guide</i> .	-
	Media Port range on the client	See Microsoft's document <i>Deploying Direct Routing Guide</i> .	-
Transport and Security	SIP transport	TLS	-
	Media Transport	SRTP	-
	SRTP Security Context	DTLS, SIPS <b>Note:</b> Support for DTLS is pending. Currently, SIPS must be configured. When support for DTLS will be announced, it will be the recommended context.	<a href="https://tools.ietf.org/html/rfc5763">https://tools.ietf.org/html/rfc5763</a>
	Crypto Suite	AES_CM_128_HMAC_SHA1_80, non-MKI	-
	Control protocol for media transport	SRTCP (SRTCP-Mux recommended)	Using RTCP MUX helps reduce the number of required ports
	Supported Certification Authorities	See the <i>Deployment Guide</i>	-

Category	Parameter	Value	Comments
	Transport for Media Bypass (of configured)	<ul style="list-style-type: none"> <li>▪ ICE-lite (RFC5245) – recommended</li> <li>▪ Client also has Transport Relays</li> </ul>	-
	Audio codecs	<ul style="list-style-type: none"> <li>▪ G711</li> <li>▪ Silk (Teams clients)</li> <li>▪ Opus (WebRTC clients) - only if Media Bypass is used</li> <li>▪ G729</li> </ul>	-
Codecs	Other codecs	<ul style="list-style-type: none"> <li>▪ CN</li> <li>▪ Required narrowband and wideband</li> <li>▪ RED - Not required</li> <li>▪ DTMF - Required</li> <li>▪ Events 0-16</li> <li>▪ Silence Suppression - Not required</li> </ul>	-

**This page is intentionally left blank.**



**International Headquarters**

1 Hayarden Street,  
Airport City  
Lod 7019900, Israel  
Tel: +972-3-976-4000  
Fax: +972-3-976-4040

**AudioCodes Inc.**

200 Cottontail Lane  
Suite A101E  
Somerset NJ 08873  
Tel: +1-732-469-0880  
Fax: +1-732-469-2298

**Contact us:** <https://www.audiocodes.com/corporate/offices-worldwide>

**website:** <https://www.audiocodes.com>

©2020 AudioCodes Ltd. All rights reserved. AudioCodes, AC, HD VoIP, HD VoIP Sounds Better, IPmedia, Mediant, MediaPack, What's Inside Matters, OSN, SmartTAP, User Management Pack, VMAS, VolPerfect, VolPerfectHD, Your Gateway To VoIP, 3GX, VocaNom, AudioCodes One Voice, AudioCodes Meeting Insights, AudioCodes Room Experience and CloudBond are trademarks or registered trademarks of AudioCodes Limited. All other products or trademarks are property of their respective owners. Product specifications are subject to change without notice.

Document #: LTRT-33426

