

# Simple Network Management Protocol

Version 7.6

## Notice

Information contained in this document is believed to be accurate and reliable at the time of publishing. However, due to ongoing product improvements and revisions, AudioCodes cannot guarantee accuracy of published material after the Date Published nor can it accept responsibility for errors or omissions. Updates to this document can be downloaded from <https://www.audiocodes.com/library/technical-documents>.

This document is subject to change without notice.

Date Published: July-13-2025

## WEEE EU Directive

Pursuant to the WEEE EU Directive, electronic and electrical waste must not be disposed of with unsorted waste. Please contact your local recycling authority for disposal of this product.

## Security Vulnerabilities

All security vulnerabilities should be reported to [vulnerability@audiocodes.com](mailto:vulnerability@audiocodes.com).

## Customer Support

Customer technical support and services are provided by AudioCodes or by an authorized AudioCodes Service Partner. For more information on how to buy technical support for AudioCodes products and for contact information, please visit our website at <https://www.audiocodes.com/services-support/maintenance-and-support>.

## Documentation Feedback

AudioCodes continually strives to produce high quality documentation. If you have any comments (suggestions or errors) regarding this document, please fill out the Documentation Feedback form on our website at <https://online.audiocodes.com/documentation-feedback>.

## Stay in the Loop with AudioCodes



## Related Documentation

<a href="#">SBC-Gateway Release Notes for Latest Release (LR) Version 7.6</a>
<a href="#">SBC-Gateway Series SNMP Alarm Reference Guide</a>
<a href="#">SBC-Gateway Performance Monitoring Reference Guide</a>
<a href="#">MP-1288 High-Density Analog Media Gateway User's Manual</a>
<a href="#">Mediant 500 Gateway &amp; E-SBC User's Manual</a>
<a href="#">Mediant 500L Gateway &amp; E-SBC User's Manual</a>
<a href="#">Mediant 800 Gateway &amp; E-SBC User's Manual</a>
<a href="#">Mediant 1000B Gateway and E-SBC User's Manual</a>
<a href="#">Mediant 2600 E-SBC User's Manual</a>
<a href="#">Mediant 4000 SBC User's Manual</a>
<a href="#">Mediant 9000 SBC User's Manual</a>
<a href="#">Mediant Software SBC User's Manual</a>

## Document Revision Record

LTRT	Description
52474	Initial document release for Version 7.6.

---

## Table of Contents

---

<b>1 Introduction</b>	<b>1</b>
<b>2 SNMP Overview</b>	<b>2</b>
SNMP Standards and Objects	2
SNMP Message Standard	2
SNMP MIB Objects	3
SNMP Extensibility Feature	4
Supported MIBs	4
SNMP Interface Details	8
SNMP Community Names	8
Configuring Community Strings via Web Interface	9
Configuring Community Strings via ini File	9
Configuring Community Strings via SNMP	9
Configuring SNMP Community Strings for Traps	10
SNMPv3 USM Users	11
Configuring SNMPv3 Users via ini File	12
Configuring SNMPv3 Users via SNMP	13
Trusted Managers	14
Configuring Trusted Managers via ini File	15
Configuring Trusted Managers via SNMP	15
SNMP Ports	16
Multiple SNMP Trap Destinations	16
Configuring Trap Managers via ini File	17
Configuring SNMP Engine ID	17
Configuring Trap Managers via SNMP	17
<b>3 Carrier-Grade Alarm System</b>	<b>19</b>
Active Alarm Table	19
Alarm History	19
<b>3 Topology MIB Objects</b>	<b>20</b>
Physical Entity (RFC 2737)	20
IF-MIB (RFC 2863)	20
Ethernet Interface	20
DS1 Interface	22
<b>3 File Management</b>	<b>24</b>
Downloading a File to the Device	24
Uploading and Deleting a File	24
<b>3 Performance Monitoring</b>	<b>26</b>
<b>4 SNMP Traps</b>	<b>27</b>
Standard Traps	27
Proprietary Traps	27
Trap Varbinds	28

---

SNMP Alarms in Syslog .....	33
Cleared Alarms .....	34
<b>5 Advanced SNMP Features .....</b>	<b>35</b>
SNMP NAT Traversal .....	35
Systems .....	35
High-Availability Systems .....	36
SNMP Administrative State Control .....	36

# 1 Introduction

This document provides an overview and supplementary information on Simple Network Management Protocol (SNMP) based management for AudioCodes session border controllers (SBC) and media gateways (referred to in this document as *device*).



The **SNMP MIB manual (files)** is supplied in the Software Release Package delivered with the device. If you have any questions, please contact your AudioCodes representative.



- For a description of the device's SNMP traps (alarms and events), refer to the [SBC-Gateway SNMP Alarm Reference Guide](#).
- For a description of the device's performance monitoring parameters (including SNMP), refer to the [SBC-Gateway Performance Monitoring Reference Guide](#).
- For configuring SNMP through the web interface, see the device's *User's Manual*.
- For large deployments (for example, multiple devices in globally distributed enterprise offices) that need to be managed by central personnel, it is recommended to use AudioCodes One Voice Operations Center (OVOC). OVOC is not included in the device's supplied package. Contact AudioCodes for more information on its OVOC solution for large VoIP deployments.

## 2 SNMP Overview

Simple Network Management Protocol (SNMP) is a standards-based network control protocol for managing elements in a network. The SNMP Manager, usually implemented by a third-party Network Management System (NMS) or AudioCodes One Voice Operations Center (OVOC), connects to an SNMP Agent (embedded on a remote Network Element (NE) to perform network element Operation, Administration, Maintenance, and Provisioning (OAMP).

Both the SNMP Manager and the NE refer to the same database to retrieve information or configure parameters. This database is referred to as the Management Information Base (MIB), and is a set of statistical and control values. Apart from the standard MIBs documented in IETF RFCs, SNMP additionally enables the use of proprietary MIBs, containing non-standard information set (specific functionality provided by the Network Element).

Directives, issued by the SNMP Manager to an SNMP Agent, consist of the identifiers of SNMP variables (referred to as MIB object identifiers or MIB variables) along with instructions to either get the value for that identifier, or set the identifier to a new value (configuration). The SNMP Agent can also send unsolicited events towards an EMS, called SNMP traps.

The definitions of MIB variables supported by a particular agent are incorporated in descriptor files, written in Abstract Syntax Notation (ASN.1) format, made available to EMS client programs so that they can become aware of MIB variables and their usage.

The device contains an embedded SNMP Agent supporting both general network MIBs (such as the IP MIB), VoP-specific MIBs (such as RTP) and proprietary MIBs (acGateway, acAlarm, acMedia, acControl, and acAnalog MIBs) enabling a deeper probe into the interworking of the device. All supported MIB files are supplied to customers as part of the release.

### SNMP Standards and Objects

This section discusses the SNMP standards and SNMP objects.

#### SNMP Message Standard

Four types of SNMP messages are defined:

- **Get:** A request that returns the value of a named object.
- **Get-Next:** A request that returns the next name (and value) of the "next" object supported by a network device given a valid SNMP name.
- **Set:** A request that sets a named object to a specific value.
- **Trap:** A message generated asynchronously by network devices. It notifies the network manager of a problem apart from the polling of the device.

Each of these message types fulfills a particular requirement of network managers:

- **Get Request:** Specific values can be fetched via the "get" request to determine the performance and state of the device. Typically, many different values and parameters can

be determined via SNMP without the overhead associated with logging into the device, or establishing a TCP connection with the device.

- **Get Next Request:** Enables the SNMP standard network managers to "walk" through all SNMP values of a device (via the "get-next" request) to determine all names and values that a device supports.
- **Get-Bulk:** Extends the functionality of GETNEXT by allowing multiple values to be returned for selected items in the request. This is accomplished by beginning with the first SNMP object to be fetched, fetching the next name with a "get-next", and repeating this operation.
- **Set Request:** The SNMP standard provides a action method for a device (via the "set" request) to accomplish activities such as disabling interfaces, disconnecting users, clearing registers, etc. This provides a way of configuring and controlling network devices via SNMP.
- **Trap Message:** The SNMP standard furnishes a mechanism for a device to "reach out" to a network manager on their own (via the "trap" message) to notify or alert the manager of a problem with the device. This typically requires each device on the network to be configured to issue SNMP traps to one or more network devices that are awaiting these traps.

The above message types are all encoded into messages referred to as "Protocol Data Units" (PDUs) that are interchanged between SNMP devices.

## SNMP MIB Objects

The SNMP MIB is arranged in a tree-structure, similar to a disk directory structure of files. The top-level SNMP branch begins with the ISO "internet" directory, which contains four main SNMP branches:

- **"mgmt":** Contains the standard SNMP objects usually supported (at least in part) by all network devices.
- **"private":** Contains those "extended" SNMP objects defined by network equipment vendors.
- **"experimental" and "directory":** Also defined within the "internet" root directory, are usually devoid of any meaningful data or objects.

The "tree" structure described above is an integral part of the SNMP standard, though the most pertinent parts of the tree are the "leaf" objects of the tree that provide actual management data regarding the device. Generally, SNMP leaf objects can be partitioned into two similar but slightly different types that reflect the organization of the tree structure:

- **Discrete MIB Objects:** Contain one precise piece of management data. These objects are often distinguished from "Table" items (below) by adding a ".0" (dot-zero) extension to their names. The operator must merely know the name of the object and no other information.
- **Table MIB Objects:** Contain multiple pieces of management data. These objects are distinguished from "Discrete" items (above) by requiring a "." (dot) extension to their



names that uniquely distinguishes the particular value being referenced. The "." (dot) extension is the "instance" number of an SNMP object. For "Discrete" objects, this instance number is zero. For "Table" objects, this instance number is the index into the SNMP table. SNMP tables are special types of SNMP objects, which allow parallel arrays of information to be supported. Tables are distinguished from scalar objects, such that tables can grow without bounds. For example, SNMP defines the "ifDescr" object (as a standard SNMP object) that indicates the text description of each interface supported by a particular device. Since network devices can be configured with more than one interface, this object can only be represented as an array.

By convention, SNMP objects are always grouped in an "Entry" directory, within an object with a "Table" suffix. (The "ifDescr" object described above resides in the "ifEntry" directory contained in the "ifTable" directory).

## SNMP Extensibility Feature

One of the principal components of an SNMP manager is a MIB Compiler, which allows new MIB objects to be added to the management system. When a MIB is compiled into an SNMP manager, the manager is made "aware" of new objects that are supported by agents on the network. The concept is similar to adding a new schema to a database.

Typically, when a MIB is compiled into the system, the manager creates new folders or directories that correspond to the objects. These folders or directories can typically be viewed with a "MIB Browser", which is a traditional SNMP management tool incorporated into virtually all network management systems.

The act of compiling the MIB allows the manager to know about the special objects supported by the agent and access these objects as part of the standard object set.

## Supported MIBs

The device contains an embedded SNMP agent supporting the MIBs listed below. A description in HTML format for all supported MIBs can be found in the MIBs directory in the release package.

- **Standard MIB (MIB-2):** The various SNMP values in the standard MIB are defined in RFC 1213. The standard MIB includes various objects to measure and monitor IP activity, TCP activity, UDP activity, IP routes, TCP connections, interfaces, IPv4 address to physical address mapping (ipNetToMediaTable), and general system description.
  - The standard icmpStatsTable and icmpMsgStatsTable under MIB-2 support ICMP statistics for both IPv4 and IPv6.
  - The inetCidrRouteTable (from the standard IP-FORWARD-MIB) supports both IPv4 and IPv6.
- **System MIB (under MIB-2):** Standard system group: sysDescr, sysObjectID, sysUpTime, sysContact, sysName, sysLocation, and sysServices. You can replace the value of sysObjectID.0 with a variable value using the ini file parameter [SNMPEnterpriseOID]. This

parameter is polled during startup and overwrites the standard sysObjectID.

SNMPSysName is an administratively assigned name for this managed node. By convention, this is the node's fully-qualified domain name (FQDN). If the name is unknown, the value is the zero-length string. If the [HostName] ini file parameter is configured, its value overwrites the value of SNMPSysName.

- **RTP MIB:** The MIB is supported according to RFC 2959. It contains objects relevant to the RTP streams generated and terminated by the device and to the RTCP information related to these streams.



The inverse tables are not supported.

- **Notification Log MIB:** Standard MIB (RFC 3014 - iso.org.dod.internet.mgmt.mib-2) supported for implementation of Carrier Grade Alarms.
- **Alarm MIB:** IETF MIB (RFC 3877) Supported as part of the implementation of Carrier Grade Alarms.
- **SNMP Target MIB:** (RFC 2273) Allows for configuration of trap destinations and trusted managers.
- **SNMP MIB:** (RFC 3418) Allows support for the coldStart and authenticationFailure traps.
- **SNMP Framework MIB:** (RFC 3411).
- **SNMP Usm MIB:** (RFC 3414) Implements the user-based Security Model.
- **SNMP Vacm MIB:** (RFC 3415) Implements the view-based Access Control Model.
- **SNMP Community MIB:** (RFC 3584) Implements community string management.
- **ipForward MIB:** (RFC 2096) Fully supported.
- **RTCP-XR:** (RFC) implements the following partial support:
  - The rtcpXrCallQualityTable is fully supported.
  - In the rtcpXrHistoryTable, support of the RCQ objects is provided only with no more than 3 intervals, 15 minutes long each.
  - Supports the rtcpXrVoipThresholdViolation trap.
- **ds1 MIB:** supports the following:
  - dsx1ConfigTable: partially supports the following objects with SET and GET applied:
    - ◆ dsx1LineCoding
    - ◆ dsx1LoopbackConfig
    - ◆ dsx1LineStatusChangeTrapEnable
    - ◆ dsx1CircuitIdentifier

All other objects in this table support GET only.

- dsx1CurrentTable

- dsx1IntervalTable
- dsx1TotalTable
- dsx1LineStatusChange trap

■ **acPSTN MIB:**

- acSonetSDHTable: currently has one entry (acSonetSDHFbrGrpMappingType) for selecting a low path mapping type. Relevant only for PSTN applications. (Refer to the MIB for more details.)

In addition to the standard MIBs, the complete product series contains proprietary MIBs:

■ **AC-TYPES MIB:** lists the known types defined by the complete product series. This is referred to by the sysObjectID object in the MIB-II.

■ **AcBoard MIB:** includes the acTrap group.

Each proprietary MIB contains a Configuration subtree for configuring the related parameters. In some, there also are Status and Action subtrees.

■ **AcAnalog MIB**

■ **acControl MIB**

■ **acMedia MIB**

■ **acSystem MIB**

■ **acSysInterfaceStatusTable:** supports the networking multiple interfaces feature status. This table reflects all the device's active interfaces. The lines indices consist of both the Entry Index and the Type Index. The table contains the following columns:

- Entry Index - related Interface index in the interface configuration table (if the table is empty, i.e., there is only single IP address, the index appears with 0)
- Type Index - 1 for IP Address and 2 for IPv6 Link-Local Address
- Application Types - type assigned to the interface
- Status Mode - interface configuration mode
- IP Address - IP address (either IPv4 or IPv6) for this interface
- Prefix Length - number of '1' bits in this interface's net mask
- Gateway - default gateway
- Vlan ID - VLAN ID of this interface
- Name - interface's name
- Primary DNS Server IP Address - IP address of primary DNS server for this interface
- Secondary DNS Server IP Address - IP address of secondary DNS server for this interface

■ **acSysModuleTable**

- **acIPMediaChannelsresourcesTable:** IPMedia channels information such as Module ID and DSP Channels Reserved
- **acPSTN MIB**
- **acGateway MIB:** This proprietary MIB contains objects related to configuration of the SIP device. This MIB complements the other proprietary MIBs. The acGateway MIB includes the following groups:
  - Common: parameters common to both SIP and H.323.
  - SIP: SIP only parameters.
- **AcAlarm:** This is a proprietary carrier-grade alarm MIB. It is a simpler implementation of the notificationLogMIB and the IETF suggested alarmMIB (both supported).

The acAlarm MIB has the following groups:

- **ActiveAlarm:** straight forward (single indexed) table listing all currently active Alarms together with their bindings (the Alarm bindings are defined in acAlarm. acAlarmVarbinds and also in acBoard.acTrap. acBoardTrapDefinitions. oid\_1\_3\_6\_1\_4\_1\_5003\_9\_10\_1\_21\_2\_0).
- **acAlarmHistory:** straight forward (single indexed) table listing all recently sent Alarms together with their bindings (the Alarm bindings are defined in acAlarm. acAlarmVarbinds and also in acBoard.acTrap. acBoardTrapDefinitions. oid\_1\_3\_6\_1\_4\_1\_5003\_9\_10\_1\_21\_2\_0).

The table size can be altered by one of the following:

- notificationLogMIB.notificationLogMIBObjects.nlmConfig.nlmConfigGlobalEntryLimit
- noti-  
fic-  
ationLo-  
gMIB.no-  
tific-  
ationLo-  
gMIBOb-  
jects.nlmConfig.nlmConfigLogTable.nlmConfigLogEntry.nlmConfigLogEntryLimit.

The table size (i.e., number of contained alarms) can be any value between 10 and 1,000 (default is 500)100 (default is 100)



- A detailed explanation of each parameter can be viewed in the MIB Description field.
- A detailed description in HTML format of all MIBs can be found in the MIBs directory (included in the Release package).
- Not all groups in the MIB are implemented.
- MIB Objects that are marked as 'obsolete' are not implemented.
- When a parameter is Set to a new value via SNMP, the change may affect device functionality immediately or may require that the device be soft restart for the change to take effect. This depends on the parameter type.
- The current (updated) device configuration parameters are configured on the device provided the user doesn't load an ini file to the device after restart. Loading an ini file after restart overrides the updated parameters.

## SNMP Interface Details

This subsection describes details of the SNMP interface needed when developing an Element Management System (EMS) for any AudioCodes devices, or to manage a device with a MIB browser.

There are several alternatives for SNMP security:

- SNMPv2c community strings
- SNMPv3 User-based Security Model (USM) users
- SNMP encoded over IPSec
- Various combinations of the above

Currently, both SNMP and ini file commands and downloads are not encrypted. For ini file encoding, refer to the device's *User's Manual*.

## SNMP Community Names

You can configure up to 10 SNMP community strings (read-only and read-write).



SNMP community strings are applicable only to SNMPv1 and SNMPv2c.

If you don't configure any community strings, the device's default community strings are used:

- "public" for the read-only community string
- "private" for the read-write community string

Each community string must be associated with one of the following predefined groups:

**Table 2-1: SNMP Predefined Groups**

Group	Get Access	Set Access	Sends Traps
ReadGroup	Yes	No	Yes
ReadWriteGroup	Yes	Yes	Yes
TrapGroup	No	No	Yes

### Configuring Community Strings via Web Interface

The SNMP community strings are configured in the SNMP Community Strings table. For more information, refer to the device's *User's Manual*.

### Configuring Community Strings via ini File

The SNMP community strings are configured in the SNMP Community Strings table (SNMPCommunityStrings). For more information, refer to the device's *User's Manual*.

The maximum length of the string is 30 characters, which can include only the following:

- Upper- and lower-case letters (a to z, and A to Z)
- Numbers (0 to 9)
- Hyphen (-)
- Underline (\_)

### Configuring Community Strings via SNMP

To configure community strings, the EMS must use the standard snmpCommunityMIB. To configure the trap community string, the EMS must also use the snmpTargetMIB.

#### ➤ To add a read-only v2user community string:

1. Add a new row to the snmpCommunityTable with CommunityName v2user.
2. Add a row to the vacmSecurityToGroupTable for SecurityName v2user, GroupName ReadGroup and SecurityModel snmpv2c.

#### ➤ To delete the read-only v2user community string:

1. If v2user is being used as the trap community string, follow the procedure for changing the trap community string. (See below.)
2. Delete the snmpCommunityTable row with CommunityName v2user.
3. Delete the vacmSecurityToGroupTable row for SecurityName v2user, GroupName ReadGroup and SecurityModel snmpv2c.

➤ **To add a read-write v2admin community string:**

1. Add a new row to the snmpCommunityTable with CommunityName v2admin.
2. Add a row to the vacmSecurityToGroupTable for SecurityName v2admin, GroupName ReadWriteGroup and SecurityModel snmpv2c.

➤ **To delete the read-write v2admin community string:**

1. If v2admin is being used as the trap community string, follow the procedure for changing the trap community string. (See below.)
2. Delete the snmpCommunityTable row with a CommunityName of v2admin and GroupName of ReadWriteGroup.

➤ **To change the only read-write community string from v2admin to v2mgr:**

1. Follow the procedure above to add a read-write community string to a row for v2mgr.
2. Set up the EM such that subsequent set requests use the new community string, v2mgr.
3. If v2admin is being used as the trap community string, follow the procedure to change the trap community string. (See below.)
4. Follow the procedure above to delete a read-write community name in the row for v2admin.

The following procedure assumes that a row already exists in the snmpCommunityTable for the new trap community string. The trap community string can be part of the TrapGroup, ReadGroup, or ReadWriteGroup. If the trap community string is used solely for sending traps (recommended), then it should be made part of the TrapGroup.

➤ **To change the trap community string:**

1. Add a row to the vacmSecurityToGroupTable with these values: SecurityModel=2, SecurityName=the new trap community string, GroupName=TrapGroup, ReadGroup or ReadWriteGroup. The SecurityModel and SecurityName objects are row indices.



You must add GroupName and RowStatus on the same set.

2. Modify the SecurityName field in the appropriate row of the snmpTargetParamsTable.
3. Remove the row from the vacmSecurityToGroupTable with SecurityName=the old trap community string.

## Configuring SNMP Community Strings for Traps

You can configure a unique password-like community string for SNMP traps. The device sends the traps with this community string.

If you don't configure a trap community string, the default community string is "trapuser".

The trap community string is configured by the 'Trap Community String' parameter (SNMPTrapCommunityStringPassword). For more information, refer to the device's *User's Manual*.

## SNMPv3 USM Users

You can configure up to 10 User-based Security Model (USM) users (referred to as SNMPv3 user). Each SNMPv3 user can be configured with one of the following security levels:

**Table 2-2: SNMPv3 Security Levels**

Security Levels	Authentication	Privacy
noAuthNoPriv(1)	none	none
authNoPriv(2)	MD5 or SHA-1	none
authPriv(3)	MD5 or SHA-1	DES, 3DES, AES128, AES192, or AES256

Each SNMPv3 user must be associated with one of the predefined groups listed in the following table:

**Table 2-3: SNMPv3 Predefined Groups**

Group	Get Access	Set Access	Sends Traps	Security Level
ReadGroup1	Yes	No	Yes	noAuthNoPriv(1)
ReadWriteGroup1	Yes	Yes	Yes	noAuthNoPriv(1)
TrapGroup1	No	No	Yes	noAuthNoPriv(1)
ReadGroup2	Yes	No	Yes	authNoPriv(2)
ReadWriteGroup2	Yes	Yes	Yes	authNoPriv(2)
TrapGroup2	No	No	Yes	authNoPriv(2)
ReadGroup3	Yes	No	Yes	authPriv(3)
ReadWriteGroup3	Yes	Yes	Yes	authPriv(3)
TrapGroup3	No	No	Yes	authPriv(3)



The first (initial) SNMPv3 user can only be configured through a management interface other than SNMP (i.e., Web interface, configuration ini file, or CLI). Once configured, additional users can be configured through the SNMP interface as well.



## Configuring SNMPv3 Users via ini File

Use the [SNMPUsers] ini file table parameter to add, modify, and delete SNMPv3 users. The [SNMPUsers] ini table is a hidden parameter. Therefore, when you load the ini file to the device using the Web interface, the table is not included in the generated file.

**Table 2-4: SNMPv3 Table Columns Description**

Parameter	Description	Default
Row number	Table index. Its valid range is 0 to 9.	N/A
Username	Name of the v3 user. Must be unique. The maximum length is 32 characters.	N/A
AuthProtocol	Authentication protocol to be used for this user. Possible valuesL <ul style="list-style-type: none"> <li>■ [0] None (default)</li> <li>■ [1] MD5</li> <li>■ [2] SHA-1</li> <li>■ [3] SHA-2-224</li> <li>■ [4] SHA-2-256</li> <li>■ [5] SHA-2-384</li> <li>■ [6] SHA-2-512</li> </ul>	0
PrivProtocol	Privacy protocol to be used for this user. Possible values are: <ul style="list-style-type: none"> <li>■ 0 (none)</li> <li>■ 1 (DES)</li> <li>■ 2 (3DES)</li> <li>■ 3 (AES128)</li> <li>■ 4 (AES192)</li> <li>■ 5 (AES256)</li> </ul>	0
AuthKey	Authentication key.	""
PrivKey	Privacy key.	""
Group	The group that this user is associated with. Possible values are 0 (read-only group), 1 (read-write group), and 2 (trap group). The actual group	0

Parameter	Description	Default
	will be ReadGroup<sl>, ReadWriteGroup<sl> or TrapGroup<sl> where <sl> is the SecurityLevel (1=noAuthNoPriv, 2=authNoPriv, 3=authPriv)	

Keys can be entered in the form of a text password or in the form of a localized key in hex format. If using a text password, then it should be at least 8 characters in length. Below is an example showing the format of a localized key:

```
26:60:d8:7d:0d:4a:d6:8c:02:73:dd:22:96:a2:69:df
```

The following sample configuration creates three SNMPv3 USM users.

```
[ SNMPUsers ]
FORMAT SNMPUsers_Index = SNMPUsers_Username, SNMPUsers_
AuthProtocol, SNMPUsers_PrivProtocol, SNMPUsers_AuthKey, SNMPUsers_
PrivKey, SNMPUsers_Group;
SNMPUsers 0 = v3user, 0, 0, -, -, 0;
SNMPUsers 1 = v3admin1, 1, 0, myauthkey, -, 1;
SNMPUsers 2 = v3admin2, 2, 1, myauthkey, myprivkey, 1;
[ \SNMPUsers ]
```

The example above creates three SNMPv3 users:

- The user v3user is set up for a security level of noAuthNoPriv(1) and is associated with ReadGroup1.
- The user v3admin1 is setup for a security level of authNoPriv(2), with authentication protocol MD5. The authentication text password is “myauthkey” and the user is associated with ReadWriteGroup2.
- The user v3admin2 is setup for a security level of authPriv(3), with authentication protocol SHA-1 and privacy protocol DES. The authentication text password is “myauthkey”, the privacy text password is “myprivkey”, and the user is associated with ReadWriteGroup3.

### Configuring SNMPv3 Users via SNMP

To configure SNMPv3 users, the EMS must use the standard snmpUsmMIB and the snmpVacmMIB.

#### ➤ To add a read-only, noAuthNoPriv SNMPv3 user, v3user:

1. Clone the row with the same security level. After the clone step, the status of the row will be notReady(3).
2. Activate the row. That is, set the row status to active(1).

3. Add a row to the vacmSecurityToGroupTable for SecurityName v3user, GroupName ReadGroup1 and SecurityModel usm(3).



A row with the same security level (noAuthNoPriv) must already exist in the usmUserTable. (see the usmUserTable for details).

➤ **To delete the read-only, noAuthNoPriv SNMPv3 user, v3user:**

1. If v3user is associated with a trap destination, follow the procedure for associating a different user to that trap destination. (See below.)
2. Delete the vacmSecurityToGroupTable row for SecurityName v3user, GroupName ReadGroup1 and SecurityModel usm.
3. Delete the row in the usmUserTable for v3user.

➤ **To add a read-write, authPriv SNMPv3 user, v3admin1:**

1. Clone the row with the same security level.
2. Change the authentication key and privacy key.
3. Activate the row. That is, set the row status to active(1).
4. Add a row to the vacmSecurityToGroupTable for SecurityName v3admin1, GroupName ReadWriteGroup3 and SecurityModel usm(3).



A row with the same security level (authPriv) must already exist in the usmUserTable (see the usmUserTable for details).

➤ **To delete the read-write, authPriv SNMPv3 user, v3admin1:**

1. If v3admin1 is associated with a trap destination, follow the procedure for associating a different user to that trap destination. (See below.)
2. Delete the vacmSecurityToGroupTable row for SecurityName v3admin1, GroupName ReadWriteGroup1 and SecurityModel usm.
3. Delete the row in the usmUserTable for v3admin1.

## Trusted Managers

By default, the SNMP agent accepts Get and Set requests from any IP address, as long as the correct community string is used in the request. Security can be enhanced implementing Trusted Managers. A Trusted Manager is an IP address from which the SNMP agent accepts and processes Get and Set requests. An element management can be used to configure up to five Trusted Managers.

The concept of Trusted Managers is considered to be a weak form of security and therefore is not a required part of SNMPv3 security, which uses authentication and privacy. Trusted Managers for the devices' SNMP agent are applicable only for SNMPv2c users. An exception to this is when the community string is not the default string ('public'/'private'), at which time Trusted Managers are applicable for SNMPv2c users alongside SNMPv3 users.



If Trusted Managers are defined, then all community strings work from all Trusted Managers. In other words, there is no way to associate a community string with specific Trusted Managers.

### Configuring Trusted Managers via ini File

You can configure up to five SNMP Trusted Managers in the SNMP Trusted Managers table (SNMPTrustedManagers). For more information, refer to the device's *User's Manual*.

### Configuring Trusted Managers via SNMP

To configure Trusted Managers, the Element Management System (EMS) must use the SNMP-COMMUNITY-MIB and snmpCommunityMIB and the snmpTargetMIB.

The following procedure assumes the following: at least one configured read-write community; currently no Trusted Managers; TransportTag for columns for all snmpCommunityTable rows are currently empty.

#### ➤ To add the first Trusted Manager:

1. Add a row to the snmpTargetAddrTable with these values: Name=mgr0, TagList=MGR, Params=v2cparams.
2. Add a row to the snmpTargetAddrExtTable table with these values: Name=mgr0, snmpTargetAddrTMask=255.255.255.255:0. The agent does not allow creation of a row in this table unless a corresponding row exists in the snmpTargetAddrTable.
3. Set the value of the TransportTag field on each non-TrapGroup row in the snmpCommunityTable to MGR.

The following procedure assumes the following: at least one configured read-write community; currently one or more Trusted Managers; TransportTag for columns for all rows in the snmpCommunityTable are currently set to MGR. This procedure must be done from one of the existing Trusted Managers.

#### ➤ To add a subsequent Trusted Manager:

1. Add a row to the snmpTargetAddrTable with these values: Name=mgrN, TagList=MGR, Params=v2cparams, where N is an unused number between 0 and 4.
2. Add a row to the snmpTargetAddrExtTable table with these values: Name=mgrN, snmpTargetAddrTMask=255.255.255.255:0.

An alternative to the above procedure is to set the `snmpTargetAddrTMask` column while you are creating other rows in the table.

The following procedure assumes the following: at least one configured read-write community; currently two or more Trusted Managers; taglist for columns for all rows in the `snmpCommunityTable` are currently set to MGR. This procedure must be done from one of the existing trusted managers, but not the one that is being deleted.

➤ **To delete a Trusted Manager (not the last one):**

- Remove the appropriate row from the `snmpTargetAddrTable`.

The change takes effect immediately. The deleted trusted manager cannot access the device. The agent automatically removes the row in the `snmpTargetAddrExtTable`.

The following procedure assumes the following: at least one configured read-write community; currently only one Trusted Manager; taglist for columns for all rows in the `snmpCommunityTable` are currently set to MGR. This procedure must be done from the final Trusted Manager.

➤ **To delete the last Trusted Manager:**

1. Set the value of the `TransportTag` field on each row in the `snmpCommunityTable` to the empty string.
2. Remove the appropriate row from the `snmpTargetAddrTable`.

The change takes effect immediately. All managers can now access the device. The agent automatically removes the row in the `snmpTargetAddrExtTable`.

## SNMP Ports

The SNMP Request Port is 161 and the SNMP Trap Port is 162. These port numbers for SNMP requests and responses can be changed, by using the `[SNMPPort]` ini file parameter. The valid value is any valid UDP port number. The default is 161 (recommended).

## Multiple SNMP Trap Destinations

You can configure the device's SNMP agent to send traps to up to five managers in the SNMP Trap Destinations table. For each manager you need to define the manager IP address or FQDN (hostname) and trap receiving port along with enabling the sending to that manager. You can also associate a trap destination with a specific SNMPv3 USM user. Traps are sent to this trap destination using the SNMPv3 format and the authentication and privacy protocol configured for that user.

To configure the Trap Managers table, use one of the following methods:

- Web interface (refer to the device's *User's Manual*)
- ini file (see [Configuring Trap Managers via ini File](#) on the next page)
- SNMP (see [Configuring Trap Managers via SNMP](#) on the next page)

When a trap destination is defined by FQDN, the device tries to resolve the hostname into an IP address. Once the name is resolved, the resolved IP address replaces the last trap manager entry of the `snmpTargetAddrTable` in the `snmpTargetMIB`. The port is 162 (unless specified otherwise). The row is marked as 'used' and the sending is 'enabled'.

When using 'host name' resolution, any changes made by the user to this row in either MIBs are overwritten by the device when a resolving is redone (once an hour).



Some traps may be lost until the name resolving is complete.

### Configuring Trap Managers via ini File

You can configure trap destinations (managers) using the SNMP Trap Destinations table (`SNMPTrapDestinations`). For more information, refer to the device's



The same information that is configurable in the ini file can also be configured via the `acBoardMIB`.

### Configuring SNMP Engine ID

The `[SNMPEngineIDString]` ini file parameter configures the SNMP engine ID. The ID can be a string of up to 36 characters. Once defined, the device must be restarted for the parameter to take effect.

The default value is 00:00:00:00:00:00:00:00:00:00:00:00 (12 Hex characters). The provided key must be set with 12 Hex values delimited by ':'.

If the supplied key does not pass validation of the 12 Hex values input or it is set with the default value, the engine ID is then generated, according to RFC 3411.

Before setting this parameter, all SNMPv3 users must be deleted, otherwise the configuration is ignored.



When the device operates in HA mode, the `SNMPEngineIDString` parameter has the same value for both active and redundant devices (i.e., system identifier). If the devices return to Standalone mode (i.e., non-HA mode), you must configure the parameter to a NULL value (i.e., no value) on both devices. When the devices restart to the standalone mode, each device automatically sets this parameter to a unique value based on its serial number (S/N).

### Configuring Trap Managers via SNMP

The `snmpTargetMIB` interface is available for configuring trap managers.

➤ **To add an SNMPv2 trap destination:**

- Add a row to the snmpTargetAddrTable with these values: Name=trapN, TagList=AC\_TRAP, Params=v2cparams, where N is an unused number between 0 and 4

All changes to the trap destination configuration take effect immediately.

➤ **To add an SNMPv3 trap destination:**

1. Add a row to the snmpTargetAddrTable with these values: Name=trapN, TagList=AC\_TRAP, Params=usm<user>, where N is an unused number between 0 and 4, and <user> is the name of the SNMPv3 that this user is associated with.
2. If a row does not already exist for this combination of user and SecurityLevel, add a row to the snmpTargetParamsTable with these values: Name=usm<user>, MPMModel=3(SNMPv3), SecurityModel=3 (usm), SecurityName=<user>, SecurityLevel=M, where M is either 1 (noAuthNoPriv), 2(authNoPriv) or 3(authPriv).

All changes to the trap destination configuration take effect immediately.

➤ **To delete a trap destination:**

- Remove the appropriate row from the snmpTargetAddrTable.
- If this is the last trap destination associated with this user and security level, you could also delete the appropriate row from the snmpTargetParamsTable.

➤ **To modify a trap destination:**

You can change the IP address and or port number for an existing trap destination. The same effect can be achieved by removing a row and adding a new row.

- Modify the IP address and/or port number for the appropriate row in the snmpTargetAddrTable.

➤ **To disable a trap destination:**

- Change TagList on the appropriate row in the snmpTargetAddrTable to the empty string.

➤ **To enable a trap destination:**

- Change TagList on the appropriate row in the snmpTargetAddrTable to 'AC\_TRAP'.
- Change TagList on the appropriate row in the snmpTargetAddrTable to "AC\_TRAP".

## 3 Carrier-Grade Alarm System

The basic alarm system has been extended to a carrier-grade alarm system. A carrier-grade alarm system provides a reliable alarm reporting mechanism that takes into account EMS outages, network outages, and transport mechanism such as SNMP over UDP.

A carrier-grade alarm system is characterized by the following:

- The device allows an EMS to determine which alarms are currently active in the device. That is, the device maintains an active alarm table.
- The device allows an EMS to detect lost alarms and clear notifications [sequence number in trap, current sequence number MIB object]
- The device allows an EMS to recover lost alarm raise and clear notifications [maintains a log history]
- The device sends a cold start trap to indicate that it is starting. This allows the EMS to synchronize its view of the device's active alarms.

When the SNMP alarm traps are sent, the carrier-grade alarm system does not add or delete alarm traps as part of the feature. This system provides the mechanism for viewing of history and current active alarm information.

### Active Alarm Table

The device maintains an active alarm table to allow an EMS to determine which alarms are currently active in the device. Two views of the active alarm table are supported by the agent:

- `acActiveAlarmTable` in the enterprise `AcAlarm`
- `alarmActiveTable` and `alarmActiveVariableTable` in the IETF standard `AcAlarm` MIB (rooted in the MIB tree)

The `acActiveAlarmTable` is a simple, one-row per alarm table that is easy to view with a MIB browser.

### Alarm History

The device maintains a history of alarms that have been sent and traps that have been cleared to allow an EMS to recover any lost raise or clear traps. Two views of the alarm history table are supported by the agent:

- `acAlarmHistoryTable` in the enterprise `AcAlarm` - a simple, one-row per alarm table, that is easy to view with a MIB browser.
- `nImLogTable` and `nImLogVariableTable` in the standard `NOTIFICATION-LOG-MIB`



## 3 Topology MIB Objects

This section describes the topology of the MIB objects.

### Physical Entity (RFC 2737)

The following groups are supported:

- entityPhysical group: Describes the physical entities managed by a single agent.
- entityMapping group: Describes the associations between the physical entities, logical entities, interfaces, and non-interface ports managed by a single agent.
- entityGeneral group: Describes general system attributes shared by potentially all types of entities managed by a single agent.
- entityNotifications group: Contains status indication notifications.

### IF-MIB (RFC 2863)

The following interface types are presented in the ifTable:

- ethernetCsmacd(6): for all Ethernet-like interfaces, regardless of speed, as per RFC 3635
- ds1(18): DS1-MIB
- voiceFXO(101): Voice Foreign Exchange Office
- voiceFXS(102): Voice Foreign Exchange Station

The numbers in the brackets above refer to the IANA's interface-number.

For each interface type, the following objects are supported:

### Ethernet Interface

**Table 3-1: Ethernet Interface**

ifTable & ifXTable	Value
ifIndex	Constructed as defined in the device's Index format.
ifDescr	Ethernet interface.
ifType	ethernetCsmacd(6)
ifMtu	1500
ifSpeed	acSysEthernetFirstPortSpeed in bits per second 0 since it's GBE - refer to ifHighSpeed.
ifPhysAddress	00-90-8F plus acSysIdSerialNumber in hex. Will be same

ifTable & ifXTable	Value
	for both dual ports.
ifAdminStatus	Always UP. [Read Only] - Write access is not required by the standard. Support for 'testing' is not required.
ifOperStatus	Up or Down corresponding to acAnalogFxsFxoType where Unknown is equal to Down.
ifLastChange	The value of sysUpTime at the time the interface entered its current operational state.
ifInOctets	The number of octets in valid MAC frames received on this interface, including the MAC header and FCS. This does include the number of octets in valid MAC Control frames received on this interface.
ifInUcastPkts	As defined in IfMIB.
ifInDiscards	As defined in IfMIB.
ifInErrors	The sum for this interface of dot3StatsAlignmentErrors, dot3StatsFCSErrors, dot3StatsFrameTooLongs, and dot3StatsInternalMacReceiveErrors.
ifInUnknownProtos	As defined in IfMIB.
ifOutOctets	The number of octets transmitted in valid MAC frames on this interface, including the MAC header and FCS. This does include the number of octets in valid MAC Control frames transmitted on this interface.
ifOutUcastPkts	As defined in IfMIB.
ifOutDiscards	As defined in IfMIB.
ifOutErrors	The sum for this interface of: dot3StatsSQETestErrors, dot3StatsLateCollisions, dot3StatsExcessiveCollisions, dot3StatsInternalMacTransmitErrors and dot3StatsCarrierSenseErrors.
ifName	Ethernet port #1 or# 2 Gb Ethernet Port 5/n, where n is the port number
ifInMulticastPkts	As defined in IfMIB.

ifTable & ifXTable	Value
ifInBroadcastPkts	As defined in IfMIB.
ifOutMulticastPkts	As defined in IfMIB.
ifOutBroadcastPkts	As defined in IfMIB.
ifHCInOctets ifHCOctets	64-bit versions of counters. Required for ethernet-like interfaces that are capable of operating at 20 Mb/s or faster, even if the interface is currently operating at less than 20 Mb/s.
ifHCInUcastPkts ifHCInMulticastPkts ifHCInBroadcastPkts ifHCOctetsUcastPkts ifHCOctetsMulticastPkts ifHCOctetsBroadcastPkts	64-bit versions of packet counters. Required for ethernet-like interfaces that are capable of operating at 640 Mb/s or faster, even if the interface is currently operating at less than 640 Mb/s. Therefore, will be constant zero.
ifLinkUpDownTrapEnable	Set to disabled (2). Refer to [RFC 2863].
ifHighSpeed	100010 or 100 according to acSysEthernetFirstPortSpeed
ifPromiscuousMode	Constant False. [R/O]
ifConnectorPresent	Constant True.
ifAlias	An 'alias' name for the interface as specified by a network manager (NVM)
ifCounterDiscontinuityTime	As defined in IfMIB.

## DS1 Interface



The DS1 interface is applicable only to digital PSTN interfaces.

**Table 3-2: DS1 Digital Interface**

ifTable	Value
ifDescr	Digital DS1 interface.
ifType	ds1(18).
ifMtu	Constant zero.

ifTable	Value
ifSpeed	DS1 = 1544000, or E1 = 2048000, according to dsx1LineType
ifPhysAddress	The value of the Circuit Identifier [dsx1CircuitIdentifier]. If no Circuit Identifier has been assigned this object should have an octet string with zero length.
ifAdminStatus	Trunk's Lock & Unlock during run time. In initialization process we need to refer the Admin-Status parameter.
ifOperStatus	Up or Down, according to the operation status.
ifLastChange	The value of sysUpTime at the time the interface entered its current operational state.
ifXTable	Value
ifName	Digital# acTrunkIndex
ifLinkUpDownTrapEnable	Set to disabled(2)
ifHighSpeed	Speed of line in Megabits per second: 2
ifConnectorPresent	Set to true(1) normally, except for cases such as DS1/E1 over AAL1/ATM where false(2) is appropriate
ifCounterDiscontinuityTime	Always zero.

## 3 File Management

SNMP supports file download, upload, and removal.

### Downloading a File to the Device

The file URL is set in the appropriate MIB object under the `acSysHTTPClient` subtree (refer to the subtree objects description for the URL form). The download can be scheduled using the `acSysHTTPClientAutoUpdatePredefinedTime` and `acSysHTTPClientAutoUpdateFrequency` objects. It can also be a manual process using `acSysActionSetAutoUpdate`. In this case (only) and as long as one URL is set at a time, the result can be viewed in `acSysActionSetAutoUpdateActionResult`. In both cases, the `acHTTPDownloadResult` trap is sent, indicating the success or failure of the process.

`acSysActionSetActionId` can be set to any value and can be used to indicate an action performed by a certain manager.

A successful process also ends with the file name in the appropriate object under the `acSysFile` subtree or in the `acCASFileTable` or the `acAuxiliaryFiles` subtree, along with the URL being erased from the object under the `acSysHTTPClient` subtree.



- The action result (both in the `acSysActionSetAutoUpdateActionResult` object and `acHTTPDownloadResult` trap) for the Voice Prompt and XML indicates only that the file reached the device and has no indication on the application's ability to parse the file.
- The action result in `acSysActionSetAutoUpdateActionResult` is reliable as long as only one file is downloaded at a time.

### Uploading and Deleting a File

File upload is the procedure of sending a file from the device to the manager. Deleting a file is erasing it from the device, an offline action that requires a restart for it to be applied. The `acSysUpload` subtree holds all relevant objects.

- `acSysUploadFileURI` indicates the file name and location along with the file transfer protocol (HTTP or NFS), for example, "http:\\server\\filename.txt".
- `acSysUploadFileType` and `acSysUploadFileNumber` are used to determine the file to be uploaded along with its instance when relevant (for CAS or Video Font).
- `acSysUploadActionID` is at the disposal of the manager and can be used to indicate that a certain manager has performed the action.
- `acSysUploadActionType` determines the action that occurs and triggers it off at the same time.



File upload using SNMP is supported only for ini files; file removal using SNMP is supported for all files except ini files.

## 3 Performance Monitoring

The device measures performance at fixed sampling intervals. You can poll (SNMP Get) the device for these performance measurements (performance monitoring parameters) using a third-party, performance monitoring systems through an SNMP interface.

For more information on performance monitoring, refer to the [SBC-Gateway Performance Monitoring Reference Guide](#).



For SNMP management, the device supports SNMPv1, SNMPv2, and SNMPv3. SNMPv2 or SNMPv3 is required to query 64-bit counters as SNMPv1 doesn't support 64-bit counters (per RFC 2233). Therefore, to ensure that your SNMP Get requests for performance monitoring parameters are successful, it's recommended to use SNMPv2 or SNMPv3.

## 4 SNMP Traps

This section provides an overview of the SNMP traps.



For a description of the device's SNMP traps (alarms and events), refer to the [SBC-Gateway SNMP Alarm Reference Guide](#).

### Standard Traps

The device also supports the following standard traps:

- authenticationFailure
- coldStart: The device supports a cold start trap to indicate that the device is starting up. This allows the EMS to synchronize its view of the device's active alarms. In fact, two different traps are sent at start-up:
  - Standard coldStart trap: iso(1).org(3).dod(6).internet(1). snmpV2(6). snmpModules(3). snmpMIB(1). snmpMIBObjects(1). snmpTraps(5). coldStart(1) sent at system initialization.
  - Enterprise acBoardEvBoardStarted: generated at the end of system initialization. This is more of an "application-level" cold start sent after all the initializing process is over and all the modules are ready
- linkDown
- linkup
- entConfigChange
- dsx1LineStatusChange (Applicable only to Digital Series)

### Proprietary Traps

This section provides information on proprietary SNMP traps supported by the device. There is a separation between traps that are alarms and traps that are not (i.e., events or logs). All traps have the same structure made up of the same 16 varbinds (Variable Binding), i.e., 1.3.6.1.4.1.5003.9.10.1.21.1. For a list of the varbinds, see [Trap Varbinds](#) on the next page.

The source varbind is composed of a string that details the device component from which the trap is being sent (forwarded by the hierarchy in which it resides). For example, an alarm from an SS7 link has the following string in its source varbind: acBoard#1/SS7#0/SS7Link#6. The SS7 link number is specified as 6 and is part of the only SS7 module in the device that is placed in slot number 1 (in a chassis) and is the module to which this trap relates. For devices where there are no chassis options, the slot number is always 1.

Full proprietary trap definitions and trap varbinds are found in AcBoard MIB and AcAlarm MIB.





All traps are sent from the SNMP port (default 161).

## Trap Varbinds

Trap varbinds are sent with each proprietary SNMP trap. Refer to the AcBoard MIB for more information on these varbinds.

**Table 4-1: Trap Varbinds for Proprietary SNMP Traps**

Trap Varbind	Description
acBoardTrapGlobalsName (1)	Alarm or event number. The number value is obtained from the last digit(s) of the OID of the sent trap, and then subtracted by 1. For example, for the trap acBoardEthernetLinkAlarm, which has an OID of 1.3.6.1.4.1.5003.9.10.1.21.2.0.10, the value of the varbind is 9 (i.e., 10 – 1). The value is an integer from 0 to 1000.
acBoardTrapGlobalsTextualDescription (2)	Description of the reported issue. The value is an octet string of up to 200 characters.
acBoardTrapGlobalsSource (3)	The source of the issue. For example, Trunk#1 or Entity1#x. The value is an octet string of up to 100 characters.
acBoardTrapGlobalsSeverity (4)	Active alarm severity on the device: <ul style="list-style-type: none"> <li>■ noAlarm(0)</li> <li>■ indeterminate(1)</li> <li>■ warning(2)</li> <li>■ minor(3)</li> <li>■ major(4)</li> <li>■ critical(5)</li> </ul>
AcBoardTrapGlobalsUniqID (5)	Consecutive number count of trap since device was powered on. The number is managed separately for alarms and events. For example, you may have an alarm whose value is 1 and an event whose value is 1.

Trap Varbind	Description
	The value is an integer from 0 to 32000.
acBoardTrapGlobalsType (6)	<ul style="list-style-type: none"> <li>■ other(0)</li> <li>■ communicationsAlarm(1)</li> <li>■ qualityOfServiceAlarm(2)</li> <li>■ processingErrorAlarm(3)</li> <li>■ equipmentAlarm(4)</li> <li>■ environmentalAlarm(5)</li> <li>■ integrityViolation(6)</li> <li>■ operationalViolation(7)</li> <li>■ physicalViolation(8)</li> <li>■ securityServiceOrMechanismViolation(9)</li> <li>■ timeDomainViolation(10)</li> </ul>
acBoardTrapGlobalsProbableCause (7)	<ul style="list-style-type: none"> <li>■ other(0)</li> <li>■ adapterError(1)</li> <li>■ applicationSubsystemFailure(2)</li> <li>■ bandwidthReduced(3)</li> <li>■ callEstablishmentError(4)</li> <li>■ communicationsProtocolError(5)</li> <li>■ communicationsSubsystemFailure(6)</li> <li>■ configurationOrCustomizationError(7)</li> <li>■ congestion(8)</li> <li>■ corruptData(9)</li> <li>■ cpuCyclesLimitExceeded(10)</li> <li>■ dataSetOrModemError(11)</li> <li>■ degradedSignal(12)</li> <li>■ dteDceInterfaceError(13)</li> <li>■ enclosureDoorOpen(14)</li> <li>■ equipmentMalfunction(15)</li> <li>■ excessiveVibration(16)</li> </ul>

Trap Varbind	Description
	<ul style="list-style-type: none"> <li>■ fileError(17)</li> <li>■ fireDetected(18)</li> <li>■ floodDetected(19)</li> <li>■ framingError(20)</li> <li>■ heatingVentCoolingSystemProblem(21)</li> <li>■ humidityUnacceptable(22)</li> <li>■ inputOutputDeviceError(23)</li> <li>■ inputDeviceError(24)</li> <li>■ lanError(25)</li> <li>■ leakDetected(26)</li> <li>■ localNodeTransmissionError(27)</li> <li>■ lossOfFrame(28)</li> <li>■ lossOfSignal(29)</li> <li>■ materialSupplyExhausted(30)</li> <li>■ multiplexerProblem(31)</li> <li>■ outOfMemory(32)</li> <li>■ outputDeviceError(33)</li> <li>■ performanceDegraded(34)</li> <li>■ powerProblem(35)</li> <li>■ pressureUnacceptable(36)</li> <li>■ processorProblem(37)</li> <li>■ pumpFailure(38)</li> <li>■ queueSizeExceeded(39)</li> <li>■ receiveFailure(40)</li> <li>■ receiverFailure(41)</li> <li>■ remoteNodeTransmissionError(42)</li> <li>■ resourceAtOrNearingCapacity(43)</li> <li>■ responseTimeExcessive(44)</li> <li>■ retransmissionRateExcessive(45)</li> <li>■ softwareError(46)</li> </ul>

Trap Varbind	Description
	<ul style="list-style-type: none"> <li>■ softwareProgramAbnormallyTerminated(47)</li> <li>■ softwareProgramError(48)</li> <li>■ storageCapacityProblem(49)</li> <li>■ temperatureUnacceptable(50)</li> <li>■ thresholdCrossed(51)</li> <li>■ timingProblem(52)</li> <li>■ toxicLeakDetected(53)</li> <li>■ transmitFailure(54)</li> <li>■ transmitterFailure(55)</li> <li>■ underlyingResourceUnavailable(56)</li> <li>■ versionMismatch(57)</li> <li>■ authenticationFailure(58)</li> <li>■ breachOfConfidentiality(59)</li> <li>■ cableTamper(60)</li> <li>■ delayedInformation(61)</li> <li>■ denialOfService(62)</li> <li>■ duplicateInformation(63)</li> <li>■ informationMissing(64)</li> <li>■ informationModificationDetected(65)</li> <li>■ informationOutOfSequence(66)</li> <li>■ intrusionDetection(67)</li> <li>■ keyExpired(68)</li> <li>■ nonRepudiationFailure(69)</li> <li>■ outOfHoursActivity(70)</li> <li>■ outOfService(71)</li> <li>■ proceduralError(72)</li> <li>■ unauthorizedAccessAttempt(73)</li> <li>■ unexpectedInformation(74)</li> </ul>
acBoardTrapGlobalsAdditionalInfo1 (8)	Provides additional information regarding the

Trap Varbind	Description
	<p>reported trap.</p> <p>The value is an octet string of up to 100 characters.</p>
acBoardTrapGlobalsAdditionalInfo2 (9)	<p>Provides additional information regarding the reported trap.</p> <p>The value is an octet string of up to 100 characters.</p>
acBoardTrapGlobalsAdditionalInfo3 (10)	<p>Provides additional information regarding the reported trap.</p> <p>The value is an octet string of up to 100 characters.</p>
acBoardTrapGlobalsDateAndTime (11)	Date and time the trap was sent.
acBoardTrapGlobalsSystemSeverity (12)	<p>The highest alarm severity sent by the device when the trap was sent:</p> <ul style="list-style-type: none"> <li>■ cleared(0)</li> <li>■ indeterminate(1)</li> <li>■ warning(2)</li> <li>■ minor(3)</li> <li>■ major(4)</li> <li>■ critical(5)</li> </ul>
acBoardTrapGlobalsDeviceName (13)	<p>Name of the device.</p> <p>The value is an octet string of up to 100 characters.</p> <p><b>Note:</b> The device sends an empty string "\0". AudioCodes OVOC provides the proper string value when it sends it northbound.</p>
acBoardTrapGlobalsDeviceInfo (14)	<p>Device information.</p> <p>The value is an octet string of up to 100 characters.</p> <p><b>Note:</b> The device sends an empty string "\0". AudioCodes OVOC provides the proper string value when it sends it northbound.</p>
acBoardTrapGlobalsDeviceDescription	Device description.

Trap Varbind	Description
(15)	The value is an octet string of up to 100 characters. <b>Note:</b> The device sends an empty string "\0". AudioCodes OVOC provides the proper string value when it sends it northbound.
acBoardTrapGlobalsSystemSerialNumber (16)	The Serial Number of the device that sent the trap. The value is an octet string of up to 255 characters.

## SNMP Alarms in Syslog

SNMP alarms are sent to the Syslog server using the following format.

- **Sent alarms:** RAISE-ALARM: <Alarm Name>; Textual Description: <Textual Description>; Severity <Alarm Severity>; Source <Alarm Source>; Unique ID: <Alarm Unique ID >.

If additional information exists in the alarm, the following are also added: Additional Info1:/ Additional Info2:/ Additional Info3

The message severity is as follows:

**Table 4-2: Message Severity**

ITU Perceived Severity (SNMP Alarm's Severity)	AudioCodes Syslog Severity
Critical	RecoverableMsg
Major	RecoverableMsg
Minor	RecoverableMsg
Warning	Notice
Indeterminate	Notice
Cleared	Notice

- **Cleared alarm:**

CLEAR-ALARM: <Alarm Name>; Textual Description: <Textual Description>; Severity <Alarm Severity>; Source <Alarm Source>; Unique ID: <Alarm Unique ID >; If exists Additional Info1:/ Additional Info2:/ Additional Info3:

## Cleared Alarms

When the device clears an alarm, it adds the prefix "Alarm cleared:" to the alarm's original text description. For example, when an Ethernet link alarm is cleared, the following alarm description is sent: "Alarm cleared: Ethernet link alarm. LAN port number 8 is down.".

## 5 Advanced SNMP Features

This section describes advanced SNMP features.

### SNMP NAT Traversal

A NAT placed between the device and the element manager calls for traversal solutions:

- **Trap source port:** all traps are sent from the SNMP port (default is 161). A manager receiving these traps can use the binding information (in the UDP layer) to traverse the NAT back to the device. The trap destination address (port and IP) are as configured in the `snmpTargetMIB`.
- **acKeepAliveTrap:** this trap is designed to be a constant life signal from the device to the manager, allowing the manager NAT traversal at all times. The `acBoardTrapGlobalsAdditionalInfo1` varbind has the device's serial number.

The destination port (i.e., the manager port for this trap), can be set to be different than the port to which all other traps are sent. To do this, use the `acSysSNMPKeepAliveTrapPort` object in the `acSystem` MIB or the `KeepAliveTrapPort` ini file parameter.

The Trap is instigated in three ways:

- Via an ini file parameter `[SendKeepAliveTrap] = [1]`. This ensures that the trap is continuously sent. The frequency is set via the 9/10 of the `[NATBindingDefaultTimeout]` parameter or MIB object `acSysSTUNBindingLifeTime`.
- After the STUN client has discovered a NAT (any NAT).
- If the STUN client cannot contact a STUN server.



The two latter options require the STUN client be enabled (ini file parameter `[EnableSTUN]`). In addition, once the `acKeepAlive` trap is instigated it does not stop.

- The manager can view the NAT type in the MIB: `audioCodes(5003).acProducts(9).acBoardMibs(10).acSystem(10).acSystemStatus(2).acSysNetwork(6).acSysNAT(2).acSysNATType(1)`
- The manager also has access to the STUN client configuration: `audioCodes(5003).acProducts(9).acBoardMibs(10).acSystem(10).acSystemConfiguration(1).acSysNetworkConfig(3).acSysNATTraversal(6).acSysSTUN(21)`
- **acNATTraversalAlarm:** When the NAT is placed in front of a device that is identified as a symmetric NAT, this alarm is sent. It is cleared when a non-symmetric NAT or no NAT replaces the symmetric one.

### Systems

For the management of a system (a chassis with more than one type of module running), the `acSystem/acSystemChassis` subtree in the `acSystem` MIB should be used:



- The first few objects are scalars that are read-only objects for the dry-contacts' state.
- **acSysModuleTable**: A table containing mostly status information that describes the modules in the system. In addition, the table can be used to restart an entire system, restart a redundant module or perform switchover when for devices supporting HA.
- **acSysFanTrayTable**: A status-only table with the fan tray's state. Objects in the table indicate the specific state of the individual fans within the fan tray.
- **acSysPowerSupplyTable**: A status-only table with the states of the two power supplies.

The above tables are complemented by the following alarm traps (as defined in the acBoard MIB). For more details, see Getting Started with SNMP.

- **acFanTrayAlarm**: Fault in the fan tray or fan tray missing.
- **acPowerSupplyAlarm**: Fault in one of the power supply modules or power supply module is missing.

## High-Availability Systems

For the management of the High Availability (HA) systems, use the acSysChassis MIB subtree (as in the above section). The acSysModuleTable gives the HA state of the system. This includes defining which modules are active and which are in standby mode (redundant). The table also enables to read some of the statuses of the redundant modules (such as SW version, HW version, temperature, license key list, etc.). Restarting the system, restarting the redundant module, and performing switchover are performed done using this table.

Complementing the above are the following alarm traps (as defined in the acBoard MIB):

- **acHASystemFaultAlarm**: the HA is faulty and therefore, there is no HA.
- **acHASystemConfigMismatchAlarm**: configuration to the modules in the HA system is uneven causing instability.
- **acHASystemSwitchOverAlarm**: a switchover from the active to the redundant module has occurred.

## SNMP Administrative State Control

Node maintenance for the device is provided via an SNMP interface. The acBoardMIB provides two parameters for graceful and forced shutdowns of the device. These parameters are in the acBoardMIB as follows:

- **acSysActionAdminState**: Read-write MIB object. When a GET request is sent for this object, the agent returns the current device administrative state - determines the device's desired operational state:
  - **locked (0)**: Shutdown the device in the time frame set by acSysActionAdminStateLockTimeout.

- **shuttingDown (1):** (read-only) Graceful shutdown is being performed - existing calls are allowed to complete, but no new calls are allowed.
- **unlocked (2):** The device is in service.

On a SET request, the manager supplies the required administrative state, either locked(0) or unlocked(2). When the device changes to either shuttingDown or locked state, an adminStateChange alarm is sent. When the device changes to an unlocked state, the adminStateChange alarm is cleared.

■ **acSysActionAdminStateLockTimeout:** Defines the time remaining (in seconds) for the shutdown to complete:

- **0:** immediate shutdown and calls are terminated (forced lock)
- **1:** waits until all calls are terminated (i.e., perform a Graceful shutdown)
- **> 0:** the number of seconds to wait before the graceful shutdown turns into a force lock



The `acSysActionAdminStateLockTimeout` must be set before the `acSysActionAdminState`.

**This page is intentionally left blank.**

**International Headquarters**

6 Ofra Haza Street

Naimi Park

Or Yehuda, 6032303, Israel

Tel: +972-3-976-4000

Fax: +972-3-976-4040

**AudioCodes Inc.**

80 Kingsbridge Rd

Piscataway, NJ 08854, USA

Tel: +1-732-469-0880

Fax: +1-732-469-2298

**Contact us:** <https://www.audiocodes.com/corporate/offices-worldwide>

**Website:** <https://www.audiocodes.com/>

**Documentation Feedback:** <https://online.audiocodes.com/documentation-feedback>

©2025 AudioCodes Ltd. All rights reserved. AudioCodes, AC, HD VoIP, HD VoIP Sounds Better, IPmedia, Mediant, MediaPack, What's Inside Matters, OSN, SmartTAP, User Management Pack, VMAS, VoIPerfect, VoIPerfectHD, Your Gateway To VoIP, 3GX, AudioCodes One Voice, AudioCodes Meeting Insights, and AudioCodes Room Experience are trademarks or registered trademarks of AudioCodes Limited. All other products or trademarks are property of their respective owners. Product specifications are subject to change without notice.

Document #: LTRT-52474

